

Table 8-11 Description for RU Commissioning status

Status	Display	Description
Installed Status	Installed	RU-PCS Text is black
	Not-Installed	RU-CH7 Text is gray
Commissioning Status	Success	Green
	Fail or not yet	Gray

8.2.2.5.3 Alarm

Table 8-12 Alarm Status (Status - RU Hub)

Alarm	Severity	Description
	Link Fail	Soft Fail
	System Halt	Hard Fail
	AC Fail	Soft Fail
	DC Fail	Soft Fail
	Over Current	Hard Fail
	Battery Low	Soft Fail

8.2.2.6 Status – Remote module

Figure 8-28 Status – Remote Module

8.2.2.6.1 Band

Display the spectrum that is being used. The band column displays the bandwidth that has been used. The downlink column displays the center frequency of the used downlink band. The uplink column displays the center frequency of the used uplink band.

PCS Band		
Band	Downlink	Uplink
65 MHz	1962.5 MHz	1882.5 MHz

Figure 8-29 PCS Band Information (Status – Remote Module)

8.2.2.6.2 Power & Gain (Admin/User)

Display the Downlink output, Downlink/Uplink Attenuation, and Uplink Input/output.

Power & Gain		
PCS	Downlink	Uplink
Input [dBm]		-50.8
ALC Atten [dB]	0.0	0.0
Atten [dB]	6.5	0.0
[M]Output [dBm]	-16.1	-17.8
[H]Output [dBm]	16.8	

Figure 8-30 Power & Gain (Admin)

Power & Gain		
PCS	Downlink	Uplink
Input [dBm]		--,-
Atten [dB]	9.0	7.5
Output [dBm]	25.6	

Figure 8-31 Power & Gain (User)

- Admin
 - Input [dBm]: Displays the RF input level for Uplink only for the Remote Module.
 - ALC Atten [dB]: The amount of attenuation used when ALC is activate.
 - Atten [dB]: The amount of attenuation manually set by the user.
 - [M]Output [dBm]: Output power of RF transceiver (1st stage amplification).
 - [H]Output [dBm]: Output power of downlink HPA (2nd stage amplification).
- User
 - Input [dBm]: Displays the RF input level for Uplink only for the Remote Module.
 - Atten [dB]: The amount of attenuation manually set by the user.
 - Output [dBm]: Displays the total composite output power.

8.2.2.6.3 Optic Power (Master-RU Only)

Display the LD Power and PD Power of optic module inside the Master RU.

Optic Power		
---	PD Power	LD Power
Power	0.3	6.9

Figure 8-32 Optic Power (Status – Master RU only)

8.2.2.6.4 Operating Status

Table 8-13 Operating Status (Status – Remote Module)

Alarm	Severity	Description	
	Link Fail	Soft Fail	No communication with NMS.
	Over Temperature	Hard Fail / Soft Fail	Temperature is higher than the threshold level for over temperature alarm.
	Under Temperature	Soft Fail	Temperature is lower than the threshold level for under temperature alarm.
	System Halt	Hard Fail	System halt on either the Master RU or Slave RU. System halt occurs when a hard fail alarm fails to clear after 10 checks.
	ORU LD Fail	Soft Fail	LD Fail present in the Master RU's optic unit.
	ORU PD Fail	Soft Fail	PD Fail present in the Master RU's optic unit.
	Input Overload	Hard Fail	Uplink input signal is higher than the defined threshold.
	Over Power	Hard Fail / Soft Fail	Downlink output signal is higher than the defined threshold by user.
	VSWR	Soft Fail	Triggered when power is being reflected back to the system, typically due to a loose connector.
	AC Fail	Soft Fail	AC power is not operating within parameters.
	DC Fail	Soft Fail	DC power is not operating within parameters.
	Over Current	Hard Fail	Total current of RU is higher than the threshold level for over current alarm.
	Battery Low	Soft Fail	Voltage of battery connected to HE PSU is lower than the defined threshold.

8.2.3 Control Tab

8.2.3.1 Control – NMS




Figure 8-33 Control - NMS

8.2.3.1.1 Heartbeat Time

Allows the user to enable or disable SNMP traps from being sent out and also specify the Heartbeat interval. Time and date stamps of the last 2 heartbeats will be displayed in the “Last heartbeat sent out” section.




Figure 8-34 Heartbeat (Control – NMS)

8.2.3.1.2 HE System

Allows the user to perform a HE system reboot or HE full system factory settings




Figure 8-35 HE System Reboot & Factory Setting (Control – NMS)

8.2.3.1.3 NMS System

Allows the user to perform a NMS Unit reboot or NMS factory settings




Figure 8-36 NMS System Reboot & Factory Setting (Control – NMS)

8.2.3.2 Control – BCU




Figure 8-37 Control – BCU

8.2.3.2.1 Manual ATT Control




Figure 8-38 Control – BCU Manual ATT Control

- **Downlink:** Allows the user to manually adjust the DL attenuation levels for each RF path. Adjusting these settings is not recommended since it will change the power ratios set by the user.
- **Uplink:** Allows the user to manually adjust the UL attenuation levels for each RF path. Adjusting these settings is not recommended, unless additional attenuation is needed on the UL path.
- **DL Output ALC Level:** Allows the user to manually set the DL Output ALC Levels for each RF path. Adjusting these settings is not recommended since it will change the power ratios set by the user. These settings are automatically set by the system during the BCU commissioning process. This section also displays the composite DL Output ALC Level which is the value that can be used to commission the RFU.

8.2.3.2.2 Reboot / Factory Setting

Allows the user reboot or restore factory settings of the BCU.




Figure 8-39 Control – BCU Reboot/Factory Setting

8.2.3.2.3 Alarm Setting




Figure 8-40 Control – BCU Alarm Setting

- **Downlink Input Overload:** Allows the user to specify the level at which the DL Input Overload alarm is triggered. Values range from 0 dBm to +25 dBm.
- **Downlink Signal Low:** Allows the user to specify the level at which the DL Signal Low alarm is triggered. Values range from -10 dBm to +20 dBm.
- **Downlink Input Overload Alarm On:** Allows to user to enable or disable the Input Overload Alarm
- **[Path – A/B/C] Downlink Signal Low Alarm On:** Allows the user to enable or disable the DL Signal Low alarm for each RF path.

8.2.3.3 Control – RFU




Figure 8-41 Control - RFU

8.2.3.3.1 General Setting

To enable any of the settings, click on the checkbox and click the Apply button.




Figure 8-42 General Setting (Control – RFU) (Admin)




Figure 8-43 General Setting (Control – RFU) (User)

Table 8-14 Description for General Setting

Name	Description	Available Accounts
Downlink ALC	Enables or disables Downlink ALC	Administrator
Uplink ALC	Enables or disables Uplink ALC	Administrator
Downlink ON	Enables or disables the RFU Downlink path	Administrator, User
Uplink ON	Enables or disables the RFU Uplink path	Administrator, User
Uplink Noise Det	Displays if the module is turned on or off due to the UL Noise Detection Routine	Administrator

8.2.3.3.2 Reboot / Factory Setting

Allows the user reboot or restore factory settings of the RFU.




Figure 8-44 Reboot & Factory Setting (Control – RFU)

8.2.3.3.3 Uplink Noise Detection (Admin Only)




Figure 8-45 UL Noise Detection (Control – RFU)

The “UL Noise Det” button will take you to the UL Noise Detection page which will allow you to run the UL Noise Detection routine.




Figure 8-46 UL Noise Detection - PCS band

The Auto UL noise measurement routine can be run by clicking on the Check button. After all UL noise measurement have been taken, the levels for each UL path will be displayed and along with the difference between minimum detect level and measured detect level.

The user will be able to see which path is generating the elevated UL noise level based on the measured detect level and difference value.

To navigate back to the RFU control page, click on the Control tab again.

8.2.3.3.4 Manual Atten Control




Figure 8-47 Manual Attenuator Control Setting (Control – RFU)

Table 8-15 Description for Main Gain Control Setting (Control – RFU)

Name	Description	Range	Step	Available Accounts
Downlink Atten	Downlink Attenuator to be adjusted manually	0 ~ 25dB	0.5dB	Administrator, User
Uplink Atten	Uplink Attenuator to be adjusted manually	0 ~ 35dB	0.5dB	Administrator, User
DL Output ALC Level	To set the Max output ALC level	-10 ~ 0dBm	0.5dBm	Administrator
UL Output ALC Level	To set the Max output ALC level	-20 ~ 0dBm	0.5dBm	Administrator, User

DL Output ALC Offset	To set the Max output ALC Offset	-10 ~ 0dBm	0.5dBm	Administrator
UL Output ALC Offset	To set the Max output ALC Offset	-20 ~ 0dBm	0.5dBm	Administrator

8.2.3.3.5 Alarm Setting




Figure 8-48 Alarm Threshold Setting (Control – RFU)

Table 8-16 Description for Alarm Threshold Setting (Control – RFU)

Name	Description	Range	Default threshold
Downlink Signal Low	Allows the user to specify the minimum incoming DL input signal level before triggering a “Downlink Signal Low” soft-fail alarm.	-10 ~ 20dBm	-5dBm
Downlink Signal Not Detected	Allows the user to specify the minimum incoming DL input signal level before triggering a “Downlink Signal Not Detected” soft-fail alarm.	-10 ~ 20dBm	-10dBm
Uplink Over Power	Allows the user to specify the how strong the output signal of uplink can be before triggering an “Uplink Over Power” Hard Fail alarm.	-20 ~ 0dBm	0dBm

8.2.3.4 Control – ODU




Figure 8-49 Control – OPT

8.2.3.4.1 Optic Attenuation (Admin Only)




Figure 8-50 Optic Attenuation – OPT

Table 8-17 Description for Optic Attenuation (Control – OPT)

Name	Description	Range	Default threshold
DL/UL common ATT	Allows the user to control overall optic DL/UL path gain.	0 ~ 30dB	5dB
DL ATT	Used to compensate DL optic loss.	0 ~ 13dB	13dB
UL ATT	Used to compensate UL optic loss.	0 ~ 13dB	13dB

8.2.3.4.2 Reboot/Factory Setting

Allows the user to perform ODU reboot or ODU factory settings.



Figure 8-51 Reboot & factory Setting (Control – OPT)

8.2.3.5 Control – RH Hub




Figure 8-52 Control – RU Hub

8.2.3.5.1 Reboot/Factory Setting

Allows the user to perform RU Hub reboot or RU Hub factory settings




Figure 8-53 Reboot & Factory Setting (Control – RU Hub)

8.2.3.6 Control – Remote Module (Master or Slave RU)




Figure 8-54 Control – Remote Module

8.2.3.6.1 General Setting (Admin/User)




Figure 8-55 General Setting (Control - RU)

Table 8-18 Description for General Setting (Control - RU)

Name	Description	Available Accounts
Downlink ALC	This setting allows you to enable or disable the downlink ALC function. When ALC is enabled, the downlink output power will not exceed the Downlink Output Level specified in the Manual Atten Control section.	Administrator
Downlink On	This setting allows you to enable or disable the Downlink path.	Administrator, User
Uplink ALC	This setting allows you to enable or disable the uplink ALC function. When ALC is enabled, the Uplink output power will not exceed the Uplink Output Level specified in the Manual Atten Control section.	Administrator
Uplink On	This setting allows you to enable or disable the Uplink path.	Administrator, User

8.2.3.6.2 Reboot/Factory Setting

Allows the user to Reboot or restore Factory Settings on the remote module.




Figure 8-56 Reboot & factory Setting (Control - RU)

8.2.3.6.3 Optic Setting (Only Master RU) (Admin Only)




Figure 8-57 Optic Setting (Control - RU)

Table 8-19 Description for Optic Setting (Control - RU)

Name	Description	Range	Step	Available Accounts
Downlink Optic Atten	RF attenuator to compensate the optic loss of downlink	0~ 13.0 dB	0.5 dB	Administrator
PD Power	Incoming power level from the ODU			Administrator
LD Power	Outgoing power level to the ODU			Administrator

8.2.3.6.4 Manual Attenuator Control




Figure 8-58 Manual Atten Control (Control - RU)

Table 8-20 Description for Manual Atten Control (Control - RU)

Name	Description	Range	Default threshold	Available Accounts
Downlink Atten	Allows the user to specify how much attenuation to use.	0 ~ 30dB	30dB	Administrator, User
Uplink Atten	Allows the user to specify how much attenuation to use.	0 ~ 25dB	25dB	Administrator, User
DL Output ALC Level	The remote module will prevent the downlink output power from exceeding the specified value.	5 ~ 30dB	30dBm	Administrator, User
UL Output ALC Level	The system will prevent the output power to exceed the specified value.	0 ~ 10dBm	5 or 6dBm	Administrator
DL Output ALC Offset	When the incoming signal level increases, the system will not adjust the gain levels until it reaches the ALC Offset Level.	0 ~ 10dB	5dB	Administrator, User
UL Output ALC Offset	When the incoming signal level increases, the system will not adjust the gain levels until it reaches the ALC Offset Level.	0 ~ 10dB	3dB	Administrator

8.2.3.6.5 Alarm Setting




Figure 8-59 Alarm Setting (Control - RU)

- DL Over Power Limit: The overpower alarm threshold can be adjusted from 5~30dBm. +2dB from the DL overpower limit will trigger a soft fail and >2dB will trigger a hard fail alarm
- VSWR Alarm ON : Enable or disables the VSWR Alarm.

8.2.4 Install Tab

8.2.4.1 Install – NMS

Figure 8-60 Install - NMS

8.2.4.1.1 HE Commissioning Status

HE Commissioning Status			
<input checked="" type="radio"/> Commissioned			
<input type="radio"/> Not Commissioned			
<input type="radio"/> RFU-PCS	RFU CH5	<input type="radio"/> BCU-1	<input type="radio"/> OPT-1
<input type="radio"/> RFU-Cell	RFU CH6	BCU 2	OPT 2
	RFU CH3	BCU 3	OPT 3
	RFU CH4	RFU CH8	BCU 4
			OPT 4

Figure 8-61 HE Commissioning Status (Install – NMS)

Table 8-21 Description for HE Commissioning Status (Install – NMS)

Status	Display	Description
Installed Status	Physically Installed	RFU-PCS
	Physically Not-Installed	RFU CH5
Commissioning Status	Success	<input checked="" type="radio"/>
	Fail or not commissioned	<input type="radio"/>

8.2.4.1.2 SNMP

The image shows a configuration window titled "SNMP". It contains two text input fields: "Site ID" with the value "adrf" and "Manager IP" with the value "0.0.0.0". Below these fields is a "Set" button.

Figure 8-62 SNMP (Install – NMS)

The SNMP section allows you to specify the Site ID and Manager IP. The Site-ID is the code that is used to identify a particular module. The Manager IP field is where the user inputs the IP address of the NOC system that is being used to monitor the SNMP traps.

8.2.4.1.3 Location

This section allows the user to input the latitude and the longitude of the repeater.

The image shows a configuration window titled "Location". It has two rows. The first row is for "Latitude", with a dropdown menu set to "N", a "+" sign, and a text input field. The second row is for "Longitude", with a dropdown menu set to "E", a "+" sign, and a text input field. A "Set" button is located at the bottom right.

Figure 8-63 Location Setting (Install – NMS)

- Select N or S from the dropdown menu for Latitude
- Select E or W from the dropdown menu for Longitude
- Input the first 3 numbers of the latitude/longitude in the text area after the "+" and before the "."
- Input the last 6 numbers of the latitude/longitude in the text area after the "."

8.2.4.1.4 External Modem Box Settings

This section allows the user to specify an alternative IP, Subnet Mask, and Gateway settings. These settings are enabled when the Host/Remote switch is set to the Remote position.

The image shows a configuration window titled "External Modem Box Settings". It contains three text input fields: "Repeater IP" with the value "192.168.70.202", "Subnet Mask" with the value "255.255.255.0", and "Gateway" with the value "255.255.255.0". A "Set" button is located at the bottom right.

Figure 8-64 External Modem Box Setting (Install – NMS)

8.2.4.1.5 Description

This section allows the user to save the description of NMS.

The screenshot shows a form titled 'Description'. It contains a text input field with the value 'desp_rfu_700' and a 'Set' button positioned to the right of the input field.

Figure 8-65 Description (Install – NMS)

8.2.4.1.6 SNMP Agent False Alarm Test

This section allows the user to generate both soft and hard fail alarms. After alarms are generated, the NOC can poll the ADX to see if alarms are present. All alarms generated during this test are false alarms.

The screenshot shows a form titled 'SNMP Agent False Alarm Test'. It features a 'Progress' label next to a horizontal progress bar and a 'Start' button located below the progress bar.

Figure 8-66 SNMP Agent False Alarm Test (Install – NMS)

8.2.4.1.7 Location Info / Installer Info

This section allows the user to specify the address of the repeater and also the information of the installer.


The screenshot shows a form titled 'ADRF Remote Operation & Management System' with two main sections: 'Location Info' and 'Installer Info'.
 The 'Location Info' section includes input fields for 'Company', 'Address1', 'Address2', 'City', 'State' (a dropdown menu with 'Select one' selected), and 'ZIP Code'.
 The 'Installer Info' section includes input fields for 'Company', 'Name', 'Phone', and 'E-mail'.
 A 'Set' button is located at the bottom center of the form.

Figure 8-67 Location Info / Installer Info (Install – NMS)

8.2.4.1.8 Date & Time

This section allows the user to specify the current date and time.

Date & Time

Date: 

Time:

Figure 8-68 Date & Time Setting (Install – NMS)

8.2.4.2 Install – RFU




Figure 8-69 Install - RFU

8.2.4.2.1 RFU Commissioning

This section allows the user to perform RFU commissioning. To perform RFU commissioning, select a DL Input Commissioning Level from the dropdown menu and click Apply. The commissioning progress is displayed on the Commissioning Progress bar. Any errors, warnings, and messages will appear via a popup window. Please refer to the ADX Installation Guide to determine the proper RFU commissioning levels.




Figure 8-70 RFU Commissioning (Install – RFU)

8.2.4.2.2 Description

This section allows the user to set the description of RFU.




Figure 8-71 Description (Install – RFU)

8.2.4.3 Install – OPT




Figure 8-72 Install – OPT

8.2.4.3.1 Optic Commissioning

This section will allow the user to perform any optic compensation if it is necessary. The Commissioning button will turn orange if optic compensation is needed.




Figure 8-73 Optic control (Control – OPT)

Table 8-22 Description for Optic control (Control – OPT)

Display & Control	Description
	Optic loss is less than 5dBo
	Optic loss is more than 5dBo
	Not connected to a RU
	No optic loss compensation is needed.
	Optic loss compensation is needed.
	Not connected to a RU

8.2.4.3.2 Description

This section allows the user to save the description of OPT.




Figure 8-74 Description (Install – OPT)

8.2.4.4 Install – RU Hub




Figure 8-75 Install-RU Hub

8.2.4.4.1 RU Commissioning Status




Figure 8-76 RU Commissioning Status (Install-RU Hub)

Table 8-23 Description for RU Commissioning status

Status	Display	Description
Installed Status	Physically Installed	RU-PCS Text is black
	Physically Not-Installed	RU-CH7 Text is gray
Commissioning Status	Success	Green
	Fail or not commissioned	Gray

8.2.4.4.2 Description

This section allows the user to save the description of RU Hub.




Figure 8-77 Description (Install-RU Hub)

8.2.4.5 Install – Remote Module (Master or Slave RU)




Figure 8-78 Install-Remote Module

8.2.4.5.1 RU Output Commissioning

This section allows the user to perform RU commission. To perform RU commission, select a DL Output Commissioning Level from the dropdown menu and then click Apply. The commissioning progress is displayed on the Commissioning Progress bar. Any errors, warnings, and messages will appear via a popup window.




Figure 8-79 RU Output Commissioning (Install-RU)

8.2.4.5.2 Description

This section allows the user to save the description of remote module.

Description

Description

Figure 8-80 Description (Install-Remote Module)

8.2.5 System

The System tab allows the user to perform firmware updates, upload closeout packages, view any changes to the system, backup existing configuration, and add/remove user accounts, and change the login credentials of the Administrator.

8.2.5.1 System: Account

8.2.5.1.1 System: Account - Account Management (Admin Only)

The Account Management section allows the Administrator to delete any user/guest account. Please note that the Account Management section is only available if you are logged into the system as the Administrator. To delete a user/guest account click on the Account Management link and under the Delete column, click on the delete button.

Account Management / New account / Change Password

No	Login Name	Password	Status	Last Login	Edit
1	admin	admin	administrator	2012-02-28 18:37:53	-
2	adrf	adrf	user	2012-02-28 00:47:55	<input type="button" value="delete"/>
3	guest	guest	guest	1970-01-01 00:00:00	<input type="button" value="delete"/>

Figure 8-81 Account Management

8.2.5.1.2 System: Account - New Account (Admin Only)

The New account section allows the Administrator to create a new user/guest account. Please note that the new account section is only available if you are logged into the system as the Administrator. To create a new user/guest account click on the new account link and fill in the fields highlighted in yellow as shown below.

Account | Logs | Update | System Information | Backup/Restore | SNMP | Closeout Package

Account Management / New account / Change Password

Account Name
 Account Group
 Password
 Confirm password

Figure 8-82 New Account

8.2.5.1.3 System: Account - Change Password

The Change Password section allows the current user who is logged into the system to change their login credentials.

Figure 8-83 Change Password

8.2.5.2 System: Logs

8.2.5.2.1 System: Logs - Event Log

This section displays system events that have taken place. The Event Log displays who has made the changes, the time and date of when the event took place, and what changes were made to the system. The System Log tracks the following events:

- System Initiation
- Alarm Set
- Alarm Clear

Seq.	Date / Time	Source	Description	Event	Severity Level
1970	2012-02-16 / 08:27:09	OPT-3	12387	PD Path 8 Fail Alarm Set	minor
1969	2012-02-16 / 08:27:09	OPT-3	12387	PD Path 7 Fail Alarm Set	minor
1968	2012-02-16 / 08:27:08	OPT-3	12387	PD Path 6 Fail Alarm Set	minor
1967	2012-02-16 / 08:27:08	OPT-3	12387	PD Path 5 Fail Alarm Set	minor
1966	2012-02-16 / 08:27:08	OPT-3	12387	PD Path 4 Fail Alarm Set	minor
1965	2012-02-16 / 08:27:07	OPT-3	12387	PD Path 3 Fail Alarm Set	minor
1964	2012-02-16 / 08:27:07	OPT-3	12387	PD Path 2 Fail Alarm Set	minor
1963	2012-02-16 / 08:27:07	OPT-3	12387	PD Path 1 Fail Alarm Set	minor
1962	2012-02-16 / 08:27:06	OPT-2		PD Path 8 Fail Alarm Set	minor
1961	2012-02-16 / 08:27:06	OPT-2		PD Path 7 Fail Alarm Set	minor
1960	2012-02-16 / 08:27:06	OPT-2		PD Path 6 Fail Alarm Set	minor
1959	2012-02-16 / 08:27:05	OPT-2		PD Path 5 Fail Alarm Set	minor
1958	2012-02-16 / 08:27:05	OPT-2		PD Path 4 Fail Alarm Set	minor
1957	2012-02-16 / 08:27:05	OPT-2		PD Path 3 Fail Alarm Set	minor
1956	2012-02-16 / 08:27:04	OPT-2		PD Path 2 Fail Alarm Set	minor
1955	2012-02-16 / 08:27:04	OPT-2		PD Path 1 Fail Alarm Set	minor
1954	2012-02-16 / 08:27:04	OPT-1	ADRF_HQ_H-ODU	PD Path 8 Fail Alarm Set	minor
1953	2012-02-16 / 08:27:03	OPT-1	ADRF_HQ_H-ODU	PD Path 7 Fail Alarm Set	minor
1952	2012-02-16 / 08:27:03	OPT-1	ADRF_HQ_H-ODU	PD Path 6 Fail Alarm Set	minor
1951	2012-02-16 / 08:27:03	OPT-1	ADRF_HQ_H-ODU	PD Path 5 Fail Alarm Set	minor

Figure 8-84 Event Log

8.2.5.2.2 System: Logs - User Log

This section tracks user activity within the system. The User Log displays who has made the changes, the time and date of when the event took place, and what changes were made to the system. The User Log tracks the following items:

- Log in / Log out activity
- Changes to gain/attenuation/output values
- System event generated by user(firmware update, backup/resote, create/delete account)
- DAS Navigation Tree Lock/Unlock
- Description change
- Repeater/installer information change
- Setting date/time




Figure 8-85 User Log

8.2.5.3 System: Update

- To perform a firmware update, click on the System:Update tab and the following screen will show up.




Figure 8-86 System update

- Click on the 'Browse' button and locate the firmware file.
- Click on the Update button to perform the firmware update.

8.2.5.4 System: System Information

8.2.5.4.1 System: System Information

System Information Check

System Information

Name	Status
Web GUI Version	X0.0.58
External Modem Box Setting	192.168.63.5 / 255.255.255.0 / 192.168.63.254
Time	01/30/2000 15:52:58

System Notification

[OPT-1 / RU-Hub-3 / S-RU-PCS] Multiple (PCS) remote units have been detected.
 [OPT-2 / RU-Hub-2 / S-RU-PCS] Multiple (PCS) remote units have been detected.
 [OPT-2 / RU-Hub-2 / S-RU-PCS] Multiple (PCS) remote units have been detected.

BOM

Seq.	Model Name	Source	Serial Number	Firmware Version	Description	Alarm Status	Commissioned	Module Status (DL / UL)
140	ADX-CELL-S-30R	OPT-4 / RU-Hub-8 / S-RU-Cell		1.5.63		Normal	---	On / On
139	ADX-AWS-S-30R	OPT-4 / RU-Hub-8 / S-RU-AWS		1.5.63		Normal	---	On / On
138	ADX-PCS-S-30R	OPT-4 / RU-Hub-8 / S-RU-PCS		1.5.63		Normal	---	On / On
137	ADX-700-M-30R	OPT-4 / RU-Hub-8 / M-RU-700		1.5.63		Normal	---	On / On
136	ADX-CELL-S-30R	OPT-4 / RU-Hub-7 / S-RU-Cell		1.5.63		Normal	---	On / On
135	ADX-PCS-S-30R	OPT-4 / RU-Hub-7 / S-RU-PCS		1.5.63		Normal	---	On / On
134	ADX-AWS-S-30R	OPT-4 / RU-Hub-7 / S-RU-AWS		1.5.63		Normal	---	On / On

- System Information Check
The System Information Check button will check the ADX configuration and report possible discrepancies.

System Information Check

- System Information
This section displays the general system information of the ADX DAS.

System Information

Name	Status
Web GUI Version	X0.0.49
External Modem Box Setting	192.168.63.44 / 255.255.255.0 / 192.168.63.254
Time	02/16/2012 09:07:35

Figure 8-87 System Information

- System Notification
This section is displayed only when the following conditions are present:
 - When multiple remote modules with same frequency band exist in a RU.
 - When the remote module does not match with the RFU being used.

System Notification

[OPT-1 / RU-Hub-3 / S-RU-PCS] Multiple (PCS) remote units have been detected.
 [OPT-2 / RU-Hub-2 / S-RU-PCS] Multiple (PCS) remote units have been detected.
 [OPT-2 / RU-Hub-2 / S-RU-PCS] Multiple (PCS) remote units have been detected.

Figure 8-88 System Notification

- BOM

BOM displays all parts that are connected to the ADX-H-NMS.
 The BOM can be downloaded as a CSV file by clicking the 'Download' button at the bottom right.

Seq.	Model Name	Serial Number	Firmware Version	Description	Alarm Status	Commissioned	Module Status (DL / UL)
16	ADX-AWS-S-30R		1.5.5D	3rd chassis(bottom)	Normal	---	On / Off
15	ADX-AWS-S-30R		1.5.5D	2nd chassis(top)	Normal	---	Off / Off
14	ADX-700-S-30R		1.5.5D	~~~~~	Normal	---	Off / On
13	ADX-CELL-S-30R		1.5.5D	abcde	Normal	---	Off / Off
12	ADX-AWS-S-30R		1.5.5D	1st chassis	Normal	---	On / On
11	ADX-700-S-30R		1.5.5D	s-ru-700	Normal	---	On / On
10	ADX-CELL-S-30R		1.5.5D	~~~~~	Normal	---	On / On
9	ADX-PCS-M-30R		1.5.5D	~~~~~	Normal	---	On / On
8	ADX-H-OPT		1.5.1C	12387	Normal	---	-- / --
7	ADX-H-OPT		1.5.1C		Normal	---	-- / --
6	ADX-H-OPT		1.5.1C	ADRF_HQ_H-ODU	Normal	---	-- / --
5	ADX-H-RFU-A		1.5.52	ADRF_HQ_H-A	Normal	Not Commissioned	Off / Off
4	ADX-H-RFU-C		1.5.52	ADRF_HQ_H-C	Normal	Not Commissioned	On / On
3	ADX-H-RFU-7		1.5.52	ADRF_HQ_H-7	Normal	Not Commissioned	On / On
2	ADX-H-RFU-P		1.5.52	ADRF_HQ_H-P	Soft Fail	Commissioned	On / On
1	ADX-H-NMS	13000F01002X1017		---	Normal	---	-- / --

Model Name

Figure 8-89 Bill of material

8.2.5.5 System: Backup/Restore



- **Settings Backup**

Clicking the Backup will create a temporary backup file stored inside of the ADX. Once the file is created, it will need to be downloaded to a computer. A download button will appear after the backup file has been created. If the ADX is power cycled or rebooted, then the temporary backup file will be lost. We recommend downloading the backup file immediately after it has been created. Click on the Download button to download the backup file.




Figure 8-90 Setting Backup (Before)




Figure 8-91 Setting Backup (After)

- **Setting Restore**

Restore function can be used to restore the saved settings from the backup file. Once the backup file is loaded, the tree in the figure below will appear. Check the boxes of the modules that you would like to restore and then click the “Restore” button at the bottom on this section.

We recommend creating a new backup file if adding or removing modules from the ADX. Discrepancies between the backup file and the existing tree could cause restore errors.



Figure 8-92 Setting Restore

8.2.5.6 System: SNMP

- **SNMP V1/V2**

This section allows you to add community strings for SNMP v1 and v2.



Figure 8-93 SNMP V1/V2

- **SNMP V3**

This section allows the user to add accounts for SNMP v3.

The screenshot shows the SNMP V3 configuration interface. It has two main sections: 'ADD SNMP' and 'Active SNMP'. The 'ADD SNMP' section contains a table with columns: User ID, Permission, Auth Algorithm / Password, Privacy Algorithm, and Command. The 'Active SNMP' section contains a similar table but without the 'Command' column.

User ID	Permission	Auth Algorithm / Password	Privacy Algorithm	Command
	read/write	MD5	None	add

User ID	Permission	Auth Algorithm / Password	Privacy Algorithm

Figure 8-94 SNMP V3

8.2.5.7 System: Closeout Package

The closeout package section will allow the user to upload documents to the ADX-H-NMS. The maximum file size for each upload is limited to 10 MB. The total amount of space available for uploading document is 100 MB. Please do not use this section as the primary storage location of your documents. Documents may become unavailable if the system goes down.

The screenshot shows the file upload interface. It includes a 'File Name' field with a 'Browse...' button, a 'Description' field, and a 'Maximum file size is 10 MB' warning. Below these are 'Add File' and 'Cancel' buttons. At the bottom, there is a table showing the current upload status.

File Name	File Size	Description
0.0 M / 100 MB (0.0%)		

Figure 8-95 System- Closeout Package

To upload documents to the module, click on the “Browse” button and locate the file that you would like to upload, then enter in a Description of the file being uploaded. Afterwards, click on the “Add File” button to upload the file. Below is what you will see after the file upload. To delete the file, click on the delete button located in the last column.

The screenshot shows the file upload interface after a file has been uploaded. The 'File Name' field is empty, and the 'Description' field contains 'Test'. The 'Maximum file size is 10 MB' warning is still present. Below are 'Add File' and 'Cancel' buttons. At the bottom, there is a table showing the uploaded file and its details, including a 'delete' button.

File Name	File Size	Description	
Test.txt	100 Bytes	Test	delete
0.0 M / 100 MB (0.0%)			

Figure 8-96 System- Closeout Package after the file upload

8.2.6 Help

If an internet connection is available, clicking on the Help Tab will redirect the user to our Technical Support page.




Figure 8-97 Help

8.2.7 Logout

Clicking the Logout button will log the current user off the system.

8.3 Guest Mode

When logging into the system as a guest, the guest will only have read-only privileges and will not be able to make any changes to the system.

9. SYSTEM SPECIFICATION

9.1 Specification for PS78, SMR

Parameters		PS78		SMR	
Frequency	Downlink	P7	758-775MHz	S8	851-869MHz
				S9	929-930MHz 935-940MHz
	Uplink	P7	788-805MHz	S8	806-824MHz
				S9	896-901MHz
Input Power Range		0~+25dBm			
Gain	Downlink	5~30dB, 0.5dB step, ATT range: 0~25dB			
	Uplink	-5~30dB, 0.5dB step, ATT range: 0~35dB			
Maximum Output Power ¹	Downlink at RU	30dBm±2dB			
	Uplink at HE	-15dBm±2dB			
Noise Figure		< 10dB@maximum gain			
VSWR		< 1:1.5			
Optical Loss		0~5dB			
System Delay		< 2us			
Spurious		Meet FCC rules, 3GPP TS 36.104, 3GPP2 C.S0010-C			
Nominal Band/BW for Industry Canada	Downlink	P7	749-781 MHz	S8	840-880MHz
				S9	925-949MHz
	Uplink	P7	782-831 MHz	S8	811-834MHz
				S9	887-911MHz
Dimension (WXDXH)	Head-End Shelf	19.0 x 14.6 x 12.2 inches (482 x 370 x 311 mm)			
	Remote-Unit Shelf	19.0 x 12.9 x 10.5 inches (482 x 328.2 x 266.5 mm)			
	Master RU	11.8 x 9.8 x 4.5 inches (300 x 249.6 x 114.5 mm)			
	Slave RU	11.8 x 9.8 x 3.7 inches (300 x 249.6 x 94.5 mm)			
Weight	Head-End Shelf	83.7 lbs (38.0 Kg) @4 RFU, CHC-H, PSU and NMS			
	Remote-Unit Shelf	61.0 lbs (27.7 kg) @ 1 master RU, 3 Slave RU			
	Master RU	13.2 lbs (6.0 kg)			
	Slave RU	11.7 lbs (5.3 kg)			
Operating Temperature		14-122°F(-10-50°C)			
Operating Humidity		5~90%RH			
Power Input		110/220V, 50-60Hz, 24V or -48V DC(optional)			
Power	Head-End	52W@4 RFU, 1 ODU Rack with 2 ODUs and NMS			

메모 [H5]: 주파수 범위 수정 15/05/19

메모 [Y6]: 실제로 측정하셔서 기입요청합니다. 15/02/03

¹ The Manufacturer's rated output power of this equipment is for single carrier operation. For situations when multiple carrier signals are present, the rating would have to be reduced by 3.5 dB, especially where the output signal is re-radiated and can cause interference to adjacent band users. This power reduction is to be by means of input power or gain reduction and not by an attenuator at the output of the device

consumption		28W@1 RFU, , 1 ODU Rack with 2 ODU's and NMS	
	Remote-Unit	60W	53W
Network Management System		Ethernet(RJ45)	
RF connector	Head-End	N-type(Female)	
	Remote-Unit	N-type(Female)	
Input/output Impedance		50Ω	

9.2 Specification for VU, BT

Parameters		BT	TBD
Frequency	Downlink	2496-2690MHz (BRS TDD)	
	Uplink	2496-2690MHz (BRS TDD)	
Input Power Range		-15~+37dBm	
Gain	Downlink	0~52dB, 0.5dB step, ATT range: 0~52dB	
	Uplink	-5~30dB, 0.5dB step, ATT range: 0~35dB	
Maximum Output Power ²	Downlink at RU	37dBm±2dB	
	Uplink at HE	-15dBm±2dB	
Noise Figure		< 10dB@maximum gain	
VSWR		< 1:1.5	
Optical Loss		0~5dB	
System Delay		< 2us	
Spurious		Meet FCC rules, 3GPP TS 36.104, 3GPP2 C.S0010-C	
Dimension (WXDXH)	Master RU	11.8 x 9.8 x 4.5 inches (300 x 249.6 x 114.5 mm)	
	Slave RU	11.8 x 9.8 x 3.7 inches (300 x 249.6 x 94.5 mm)	
Weight	Master RU	13.2 lbs (6.0 kg)	
	Slave RU	11.7 lbs (5.3 kg)	
Operating Temperature		14-122°F(-10-50°C)	
Operating Humidity		5~90%RH	
Power Input		110/220V, 50-60Hz, 24V or -48V DC(optional)	
Power consumption	Head-End	52W@4 RFU, 1 ODU Rack with 2 ODU's and NMS	
	Remote-Unit	28W@1 RFU, 1 ODU Rack with 2 ODU's and NMS	87W
Network Management System		Ethernet(RJ45)	
RF	Head-End	N-type(Female)	

² The Manufacturer's rated output power of this equipment is for single carrier operation. For situations when multiple carrier signals are present, the rating would have to be reduced by 3.5 dB, especially where the output signal is re-radiated and can cause interference to adjacent band users. This power reduction is to be by means of input power or gain reduction and not by an attenuator at the output of the device

connector	Remote-Unit	N-type(Female)
Input/output Impedance	50Ω	

9.3 FCC Certification

Item	FCC Certification
ADX-R-SMR	Part 20, Part 90
ADX-R-78P	Part 90
ADX-R-BT	Part 20

메모 [Y7]: FCC part 명기
15/02/03

10. ANTENNA SPECIFICATIONS

10.1 Omni Antenna

Frequency	698-960MHz	1710-2690MHz
Polarization	Vertical	
Gain	2dBi	3dBi
VSWR	<1.7:1	<1.5:1
Impedance	50Ω	
Power Rating	50W	

메모 [Y8]: 안테나 규격 추가
15/02/03

Note.

Please note that integrators, end-users or installers should not use the antenna with more gain than 3dBi(For Model: ADX-R-BT), 2dBi (For Model: ADX-R-SMR, ADX-R-78P) to meet the RF exposure requirement.

Part 90.635 requirement

Antennas must be installed in accordance with FCC 90.635. With 2 dBi gain antennas the height of the antenna above average terrain (HAAT) is permitted over 1372m. For different gain antennas refer to the relevant rules.

Part 90.219 requirement

The radiated power must be limited to 1W. Therefore, this device meet the 90.219 (e)(1) 5W ERP limitation requirement.

Prior to equipment use the service must be registered with the FCC. This can be done through the FCC’s website at <https://signalboosters.fcc.gov/signal-boosters>

11. MECHANICAL DRAWING




Figure 11-1 HE Drawing




Figure 11-2 RFU Drawing for SMR/PS




Figure 11-6 Master RU Drawing for BT




Figure 11-7 Slave RU Drawing for SMR




Figure 11-9 RU Rack Shelf Drawing