



# **TRACER 6420 System Manual**

**12806420L1A**

**TRACER 6420 5.8 GHz System (Plan A)**

**12806420L1B**

**TRACER 6420 5.8 GHz System (Plan B)**

## Trademarks

Any brand names and product names included in this manual are trademarks, registered trademarks, or trade names of their respective holders.

## To the Holder of the Manual

The contents of this manual are current as of the date of publication. ADTRAN reserves the right to change the contents without prior notice.

In no event will ADTRAN be liable for any special, incidental, or consequential damages or for commercial losses even if ADTRAN has been advised thereof as a result of issue of this publication.

## About this Manual

This manual provides a complete description of the TRACER 6420 system and system software. The purpose of this manual is to provide the technician, system administrator, and manager with general and specific information related to the planning, installation, operation, and maintenance of the TRACER 6420. This manual is arranged so that needed information can be quickly and easily found.



901 Explorer Boulevard  
P.O. Box 140000  
Huntsville, AL 35814-4000  
Phone: (256) 963-8000

Copyright © 2005 ADTRAN, Inc.  
All Rights Reserved.  
Printed in U.S.A.

## Revision History

Document Revision	Date	Description of Changes
A	December 2004	Initial release of manual to include the TRACER 6420 (5.8 GHz integrated system) and the Quad T1 and Ethernet Switch modules.

**NOTE**

*Notes provide additional useful information.*

**CAUTION**

*Cautions signify information that could prevent service interruption.*

**WARNING**

*Warnings provide information that could prevent damage to the equipment or endangerment to human life.*

**Safety Instructions**

When using your telephone equipment, please follow these basic safety precautions to reduce the risk of fire, electrical shock, or personal injury:

1. Do not use this product near water, such as a bathtub, wash bowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool.
2. Avoid using a telephone (other than a cordless-type) during an electrical storm. There is a remote risk of shock from lightning.
3. Do not use the telephone to report a gas leak in the vicinity of the leak.
4. Use only the power cord, power supply, and/or batteries indicated in the manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for special disposal instructions.

**Save These Important Safety Instructions**

## FCC-Required Information

### Federal Communications Commission Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio frequencies. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

 **NOTE**

*Shielded cables must be used with this unit to ensure compliance with Class A FCC limits.*

**WARNING**

*Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.*

### Radio Frequency Interface Statement

This equipment has been tested and found to comply with the limits for an intentional radiator, pursuant to Part 15, Subpart C of the FCC Rules. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause interference to radio communications.

The limits are designed to provide reasonable protection against such interference in a residential situation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna of the affected radio or television.
- Increase the separation between the equipment and the affected receiver.
- Connect the equipment and the affected receiver to power outlets on separate circuits.
- Consult the dealer or an experienced radio/TV technician for help.

**WARNING**

*Changes or modifications not expressly approved by ADTRAN could void the user's authority to operate the equipment.*

### FCC Output Power Restrictions

The FCC does not require licensing to implement this device. License-free operation in the industrial, scientific, and medical band is documented in FCC Rules Part 15.247. It is the responsibility of the individuals designing and implementing the radio system to ensure compliance with any pertinent FCC Rules and Regulations. **This device must be professionally installed.**

### Exposure to Radio Frequency Fields

The TRACER 6420 is designed to operate at 5.8 GHz with 100 mW maximum transmit power.

This level of RF energy is below the Maximum Permissible Exposure (MPE) levels specified in FCC OET 65:97-01. The installation of high gain antenna equipment in the system configuration may create the opportunity for exposure to levels higher than recommended for the general population at a distance less than 15 feet (4.6 meters) from the center of the antenna. **The following precautions must be taken during installation of this equipment:**



*Verify the antenna installation meets all regulations specified in the National Electric Code (NEC) Article 810.*

- The installed antenna must not be located in a manner that allows exposure of the general population to the direct beam path of the antenna at a distance less than 15 feet (4.6 meters). Installation on towers, masts, or rooftops not accessible to the general population is recommended; or
- Mount the antenna in a manner that prevents any personnel from entering the area within 15 feet (4.6 meters) from the front of the antenna.
- It is recommended that the installer place radio frequency hazard warnings signs on the barrier that prevents access to the antenna.
- Prior to installing the antenna to the TRACER output, make sure the power is adjusted to the settings specified in section 2 of this manual.
- During antenna installation, be sure that power to the TRACER equipment is turned off in order to prevent any energy presence on the coaxial connector.
- During installation and alignment of the antenna, do not stand in front of the antenna assembly.
- During installation and alignment of the antenna, do not handle or touch the front of the antenna.

These simple precautions must be taken to prevent general population and installation personnel from exposure to RF energy in excess of specified MPE levels.

## Warranty and Customer Service

ADTRAN will repair and return this product within the warranty period if it does not meet its published specifications or fails while in service. Warranty information can be found at [www.adtran.com/warranty](http://www.adtran.com/warranty).

## Customer Service, Product Support Information, and Training

ADTRAN will repair and return this product within the warranty period if it does not meet its published specifications or fails while in service. Warranty information can be found at [www.adtran.com/warranty](http://www.adtran.com/warranty).

A return material authorization (RMA) is required prior to returning equipment to ADTRAN. For service, RMA requests, training, or more information, use the contact information given below.

### Repair and Return

If you determine that a repair is needed, please contact our Customer and Product Service (CaPS) department to have an RMA number issued. CaPS should also be contacted to obtain information regarding equipment currently in house or possible fees associated with repair.

CaPS Department           (256) 963-8722

Identify the RMA number clearly on the package (below address), and return to the following address:

ADTRAN Customer and Product Service  
901 Explorer Blvd. (East Tower)  
Huntsville, Alabama 35806

RMA # \_\_\_\_\_

### Pre-Sales Inquiries and Applications Support

Your reseller should serve as the first point of contact for support. If additional pre-sales support is needed, the ADTRAN Support web site provides a variety of support services such as a searchable knowledge base, latest product documentation, application briefs, case studies, and a link to submit a question to an Applications Engineer. All of this, and more, is available at:

<http://support.adtran.com>

When needed, further pre-sales assistance is available by calling our Applications Engineering Department.

Applications Engineering   (800) 615-1176

**Post-Sale Support**

Your reseller should serve as the first point of contact for support. If additional support is needed, the ADTRAN Support web site provides a variety of support services such as a searchable knowledge base, updated firmware releases, latest product documentation, service request ticket generation and trouble-shooting tools. All of this, and more, is available at:

<http://support.adtran.com>

When needed, further post-sales assistance is available by calling our Technical Support Center. Please have your unit serial number available when you call.

Technical Support (888) 4ADTRAN

**Maintenance Support**

The ADTRAN Custom Extended Services (ACES) program offers multiple types and levels of maintenance services which allow you to choose the kind of assistance you need. This support is available at:

<http://www.adtran.com/aces>

For questions, call the ACES Help Desk.

ACES Help Desk (888) 874-ACES (2237)

**Training**

The Enterprise Network (EN) Technical Training Department offers training on our most popular products. These courses include overviews on product features and functions while covering applications of ADTRAN's product lines. ADTRAN provides a variety of training options, including customized training and courses taught at our facilities or at your site. For more information about training, please contact your Territory Manager or the Enterprise Training Coordinator.

Training Phone (800) 615-1176, ext. 7500

Training Fax (256) 963-6700

Training Email [training@adtran.com](mailto:training@adtran.com)



# Table of Contents

<b>Section 1</b>	<b>System Description</b> . . . . .	<b>11</b>
	This section of ADTRAN's TRACER 6420 System Manual is designed for use by network engineers, planners, and designers for overview information about the TRACER 6420 systems.	
<b>Section 2</b>	<b>Microwave Path Engineering Basics</b> . . . . .	<b>13</b>
	Explains the basics of analyzing a wireless microwave link or path. Defines significant parameters and makes several installation recommendations.	
<b>Section 3</b>	<b>Engineering Guidelines</b> . . . . .	<b>25</b>
	Provides information to assist network designers with incorporating the TRACER 6420 system into their networks.	
<b>Section 4</b>	<b>Network Turnup Procedure</b> . . . . .	<b>35</b>
	Provides shipment contents list, grounding instructions, mounting options, and specifics of supplying power to the unit.	
<b>Section 5</b>	<b>User Interface Guide</b> . . . . .	<b>43</b>
	Provides detailed descriptions of all menu options and configuration parameters available for the TRACER 6420.	
<b>Section 6</b>	<b>Detail Level Procedures</b> . . . . .	<b>71</b>
	DLP-1 Connecting a VT100 Terminal or PC to the CRAFT Port . . . . .	73
	DLP-2 Logging in to the TRACER 6420 . . . . .	75
	DLP-3 Setting IP Parameters for the TRACER 6420 . . . . .	77
	DLP-4 Verifying Communications Over an IP LAN . . . . .	81
	DLP-5 Updating the Firmware Using TFTP . . . . .	85
	DLP-6 Updating the Firmware Using XMODEM . . . . .	89
<b>Section 7</b>	<b>MIBs</b> . . . . .	<b>91</b>
	Provides a listing of SNMP Management Information Bases (MIBs) supported by the TRACER 6420. Traps supported for each MIB are also listed.	
<b>Section 8</b>	<b>Troubleshooting Guide</b> . . . . .	<b>103</b>
	Provides helpful information for troubleshooting common configuration problems for the TRACER 6420.	



# SYSTEM DESCRIPTION

*This section of ADTRAN's TRACER 6420 System Manual is designed for use by network engineers, planners, and designers for overview information about the TRACER 6420 systems.*

It contains general information and describes physical and operational concepts, network relationships, provisioning, testing, alarm status, and system monitoring. This section should be used in conjunction with Section 3, *Engineering Guidelines*, of this manual.

## CONTENTS

<b>System Overview</b> .....	<b>12</b>
<b>Features and Benefits</b> .....	<b>12</b>
Configuration and Management .....	12
Operational .....	12
Available Interface Modules .....	12

## 1. SYSTEM OVERVIEW

The TRACER 6420 provides license-free scalable connectivity for service providers and corporate networks. These radios feature two modular network interface ports that can accommodate various combinations of T1 and Ethernet option cards up to 8xT1 (16.384 Mbps). This flexibility provides customized TDM and packet solutions for voice and data applications in a single platform. The TRACER 6420 radios provide carrier class point-to-point connectivity up to thirty miles in the 5.8 GHz license-free Industrial, Science, and Medical (ISM) band.

Complete network management is supported via SNMP, Telnet access, and a VT100 craft port. SNMP traps are implemented for all RF link and T1/Ethernet alarm conditions, enabling remote installations to report outages without requiring a truck roll to diagnose problems. Version 2 standard MIBs are supported for all interface cards, while an enterprise-specific MIB is provided for radio functionality. Triple-DES security provides additional protection from unauthorized access without requiring any additional external security appliances. Encryption can also be disabled altogether. Future upgrades and enhancements can be added through FLASH firmware downloads via TFTP (on the Ethernet interface) or XMODEM on the craft port.

Receive sensitivity is optimized through the use of extensive forward error correction and high-performance receiver design techniques. Dynamic receive sensitivity allows the user to increase receiver performance by decreasing the delivered bandwidth. This feature maximizes link performance by customizing the delivered bandwidth to the specific needs of the installation. Three software selectable channel plans are supported to simplify frequency coordination at co-located sites. Channel plans are easily changed via any of the software management interfaces without the added expense of hardware upgrades or spare filter assemblies.

TRACER wireless solutions maximize equipment density through the combination of compact size (only 1U rack space required), low power consumption, and high thermal transfer. TRACER systems can be deployed at twice the density of other available wireless products.

## 2. FEATURES AND BENEFITS

The following is a brief list of the TRACER 6420 features and benefits:

### Configuration and Management

- Easy to use VT100 control port (RS-232 interface) for configuration and monitoring
- Remote configuration of both ends of the wireless link, from each end of the link

### Operational

- No license required per FCC Rules Part 15.247
- Frequency: 5.725 to 5.850 GHz
- Point-to-point, up to 30 miles
- 1-U high unit for easy rack-mounting

### Available Interface Modules

- Quad T1 Module (P/N 1280040L1)
- Quad Ethernet Switch Module (P/N 1280050L1)

# MICROWAVE PATH ENGINEERING BASICS

*Explains the basics of analyzing a wireless microwave link or path. Defines significant parameters and makes several installation recommendations.*

## CONTENTS

<b>Line-of-Sight</b> .....	<b>14</b>
Terminology .....	14
<b>Decibels</b> .....	<b>14</b>
<b>Calculating the Fade Margin</b> .....	<b>14</b>
<b>Receiver Power</b> .....	<b>15</b>
Antenna Gain .....	16
Transmitted Power (PT) .....	16
Carrier Wavelength (l) .....	17
Path Distance (d) .....	17
System Losses (L) .....	17
Path Loss (LP) .....	18
<b>Receiver Sensitivity</b> .....	<b>19</b>
<b>Antenna Information</b> .....	<b>20</b>
Antenna Alignment .....	20
TRACER RSSI Test Points .....	20
Antenna Beam Patterns .....	20
Fresnel Zones, Earth Curvature, and Antenna Heights .....	21
<b>Other Considerations</b> .....	<b>23</b>
Path Availability .....	23

## FIGURES

Figure 1. Example Microwave Path with Parameters .....	16
Figure 2. Typical Antenna Beam Pattern .....	21

## TABLES

Table 1. Antenna Gain for Given Dish Diameters .....	16
Table 2. Typical Coaxial Loss for Common Cable Types .....	18
Table 3. Path Loss for Given Path Lengths .....	19
Table 4. Receiver Sensitivity for the TRACER 6420 .....	19
Table 5. Minimum Antenna Height for Given Path Lengths .....	22

## 1. LINE-OF-SIGHT

The TRACER 6420 system is designed for operation in the license-free 5.725 GHz to 5.850 GHz industrial, scientific, and medical (ISM) band. Radio wave propagation in this band exhibits microwave characteristics which are ideally suited for point-to-point, line-of-sight communications. Line-of-sight requires that the transmitting antenna and receiving antenna are able to “see” each other, and that the straight-line path between the two antennas is free of obstructions such as buildings, trees, mountains, and in longer paths, even the curvature of the earth. For maximum signal strength, the area around the visual line-of-sight where microwave signals reflect (Fresnel zone) must also be free of obstructions. Fresnel zones are discussed in more detail on page 21.

### Terminology

Point-to-Point	Wireless communication from a single site to another individual site. Contrast with point-to-multipoint.
Line-of-Sight	An unobstructed, direct path exists between the transmitting and the receiving antennas.

## 2. DECIBELS

Understanding the decibel (dB) format is key when discussing microwave path engineering because the received signal power is often expressed in decibel format. In general, any quantity can be expressed in decibels. If the quantity  $x$  is a power level (in Watts), the decibel equivalent is defined as

$$x_{dB} = 10 \cdot \log_{10}(x) \quad (\text{dB})$$

If the quantity  $x$  is referenced to a milliwatt (mW), then the decibel-milliwatt (dBm) is used instead of a generic decibel.

$$x_{dBm} = 10 \cdot \log_{10}\left(\frac{x}{1mW}\right) \quad (\text{dBm})$$

Using the decibel format simplifies power calculations by reducing multiplication and division operations into addition and subtraction operations.

## 3. CALCULATING THE FADE MARGIN



*It is imperative to determine whether the proposed microwave path is suitable (at a minimum) for ideal, nondistorted signals before attempting installation.*

The fade margin ( $F$ ) is a value in decibels (dB) that represents the amount of signal reduction that can be tolerated before the link exceeds the specified bit error rate (BER). Fade margin is simply the difference between the available signal power at the receiver ( $P_R$ ) and the receiver sensitivity ( $P_{sens}$ ).

$$F = P_R - P_{sens} = P_T + G_T + G_R - L - L_P - P_{sens} \quad (\text{dB})$$

where the variables in the equations are defined as

$P_R$	received power (dBm)
$P_T$	transmitted power (adjustable up to 20 dBm maximum)
$G_T$	transmit antenna gain (decibels referenced to an isotropic source – dBi)
$G_R$	receive antenna gain (dBi)
$L$	other losses (RF coaxial cable, etc. – dB)
$L_P$	path loss (dB)

Higher levels of fade margin indicate stronger protection against signal fading and a more reliable link. For most applications, 20 to 30 dB of fade margin should ensure a reliable link.

The following sections further discuss the necessary power calculations and their components.

#### 4. RECEIVER POWER

The viability of a particular microwave path is determined by the power of the transmitted microwave signal, the transmit and receive antenna gain, distance, and accumulated system losses (such as RF coaxial cable losses and path loss).

The equation relating received signal power to the other microwave parameters is

$$P_R = \frac{P_T G_T G_R \lambda^2}{(4\pi)^2 d^2 L} \quad (\text{Watts, W})$$

or (in decibel notation)

$$P_R = P_T + G_T + G_R - L - L_P \quad (\text{decibels referenced to a milliwatt, dBm})$$


where the variables in the equations are defined as

$P_R$	received power (dBm)
$P_T$	transmitted power (adjustable up to 20 dBm maximum)
$G_T$	transmit antenna gain (decibels referenced to an isotropic source – dBi)
$G_R$	receive antenna gain (dBi)
$\lambda$	carrier wavelength (meters)
$d$	path distance (meters)
$L$	other losses (RF coaxial cable, etc. – dB)
$L_P$	path loss (dB)



*When using decibel notation, all quantities must be individually converted to decibels prior to performing addition and subtraction.*

Figure 1 illustrates a wireless link configuration containing all the parameters necessary for the power budget analysis.



**Figure 1. Example Microwave Path with Parameters**

The following sections further discuss the power budget analysis and its components.

### Antenna Gain

Actual transmit and receive antenna gain values depend strictly upon the physical characteristics of the antennas installed for each link. In other words, the size of the dish determines the antenna gain. Using a parabolic dish antenna results in the best performance. Antenna gains are specified in terms of decibels of gain referenced to an isotropic source (dBi). An isotropic source is a hypothetical antenna having equal radiation in all directions. Typical antenna gains are listed in Table 1; however, dish manufacturers can provide gains for specific types of antennas.

**Table 1. Antenna Gain for Given Dish Diameters**

Dish Diameter (in feet)	Gain at 5.8 GHz (in dBi)
2	28.5
4	34.2
6	37.5
8	40.7
10	42.5
12	44.2

### Transmitted Power ( $P_T$ )

The FCC specifies the maximum transmitter power used for antennae of a given gain. FCC Rules (Part 15, Subpart 247) allow for a maximum transmit power of 1 Watt (30 dBm). Since the TRACER 6420 maximum transmit power is 100 milliwatts, there is no reduction in transmitter output power required.



### Carrier Wavelength ( $\lambda$ )

The carrier wavelength is the physical wavelength of the main RF carrier being used for communication, and is usually approximated at the center frequency of the band (which is 5787.5 MHz for the TRACER 6420). The carrier wavelength calculations follow:

$$\lambda = c / f \text{ (meters)}$$

where

c = speed of light (in meters)

f = frequency (in Hz)

resulting in the following carrier wavelength:

$$\begin{aligned}\lambda &= 3.00 \times 10^8 / 5787.5 \times 10^5 \\ &= 0.0518 \text{ m or } 5.18 \text{ cm}\end{aligned}$$

### Path Distance ( $d$ )

The path distance is simply the physical distance between the transmit and receive antennas. For the TRACER 6420, these distances can range up to 30 miles.

### System Losses ( $L$ )

System losses are defined by RF coaxial cable loss, connector losses, and losses added from any additional lightning protection devices for the power budget analysis. Coaxial cable is required to attach the TRACER 6420 to the antenna. The length of the cable varies from a few feet to hundreds of feet, depending upon your application and the proximity of the TRACER 6420 to the antenna. Various grades of coaxial cable will work sufficiently well for connecting the TRACER 6420 unit to the antenna. A low-loss coaxial cable will minimize cable losses.

One end of the coaxial cable requires an N-type male connector (plug) to mate with the TRACER 6420 unit. The other end of the coaxial cable requires a connector compatible with the antenna chosen for the installation (usually an N-type male connector). Additionally, ADTRAN recommends that the outdoor connector on the coaxial cable be weatherproofed to prevent corrosion and electrical shorting.

#### **WARNING**

*In areas where lightning strikes are frequent, a lightning arrestor should be installed directly on the antenna coaxial cable. Installing lightning arrestors helps protect the RF electronics (including the TRACER 6420 unit) in the downstream path from damaging voltages and currents.*

Table 2 gives typical loss figures for some of the more common coaxial cable types (per 100 feet).

**Table 2. Typical Coaxial Loss for Common Cable Types**

Cable Type	5.8 GHz Loss/100 ft (in dB)
RG58	N/A
RG8 (air)	N/A
RG8 (foam)	N/A
1/4" Coax	11.36
3/8" Coax	9.65
1/2" Coax	6.49
5/8" Coax	4.90
7/8" Coax	N/A
1 1/4" Coax	N/A
1 5/8" Coax	N/A
5.8 GHz Elliptical Waveguide	1.23

### Path Loss ( $L_P$ )

Path loss is the estimated attenuation between the transmit and receive antennas caused by signal separation and scattering. The path loss is considered basic transmission loss over the microwave link. The following expression calculates path loss:

$$L_P = \left(\frac{4\pi d}{\lambda}\right)^2 = \left(\frac{4\pi d f}{c}\right)^2 \quad (\text{dB})$$

where

- $f$  carrier frequency (Hz)
- $\lambda$  carrier wavelength ( $c / f$ ) (meters)
- $d$  path distance (meters)
- $c$  speed of light, free-space (meters)

or

$$L_P = 96.6 + 20 \cdot \log_{10}(d) + 20 \cdot \log_{10}(f) \quad (\text{dB})$$

where  $d$  is expressed in miles and  $f$  in GHz

Path loss, as shown here, increases rapidly as either the path length increases or the carrier wavelength decreases (which happens as the carrier frequency increases). Therefore, longer microwave paths naturally experience more path loss than shorter paths. Likewise, higher frequency microwave communication experiences more path loss than lower frequency microwave communication.

Table 3 lists path loss values for various path lengths for the TRACER 6420 5.8 GHz system. Values not listed in the table can be interpolated from those listed.

**Table 3. Path Loss for Given Path Lengths**

Path Length (miles)	Path Loss (dB)
1	112
2	118
3	121
4	124
5	126
10	132
15	135
20	138
25	140
30	141
35	143

## 5. RECEIVER SENSITIVITY

Receiver sensitivity is a value expressed in decibels referenced to one milliwatt (dBm) that corresponds to the minimum amount of signal power needed at the receiver to achieve a given bit error rate (BER). Receiver sensitivity is usually a negative number of decibels, and smaller receiver sensitivity (higher quantity negative number) is better for a given BER. Several factors affect receiver sensitivity, including the data bandwidth of the wireless link and the amount of additional signal degradation introduced in the receiver electronics.

Receiver sensitivity of the TRACER 6420 is dynamic as a function of the desired bandwidth; receiver sensitivity improves as delivered bandwidth decreases. TRACER bandwidth is provided in the form of 8 channels available for mapping to the support modules. For T1 Modules, each channel mapped represents a single T1 interface. For Quad Ethernet Switch Modules, each channel mapped represents 2 Mb of switch data delivered to the module. In situations where 8-channel connectivity is not required, the delivered bandwidth can be decreased to 4 or 2 channels, and the receiver sensitivity will be improved as follows:

**Table 4. Receiver Sensitivity for the TRACER 6420**

Delivered Bandwidth	Receiver Sensitivity
8 Channels	-87 dBm
4 Channels	-90 dBm
2 Channels	-93 dBm



*Should an interferer be present nearby, three software selectable band plans are provided for frequency agility. Changing the TRACER 6420 band plan does not require additional components, or opening of the radio. See > RF Link Configuration > RF Band Plan on page 53 for additional details.*

## 6. ANTENNA INFORMATION

The overall wireless system is directly affected by the antenna selection and installation, discussed in the following sections.



*Verify the antenna installation meets all regulations specified in the National Electric Code (NEC) Article 810.*

### Antenna Alignment

With line-of-sight microwave communications, optimum system performance requires that the transmitting and receiving antennas are properly aligned. This ensures maximum received signal power at each receiver. Antenna alignment must be achieved in both azimuth (along a horizontal plane) and elevation (along a vertical plane). By ensuring maximum received signal strength, a received signal strength indicator (RSSI) helps the equipment installer to determine when alignment is maximized.

### TRACER RSSI Test Points


RSSI for the TRACER 6420 system is provided through the VT100 terminal menus accessed through the RS-232 interface, and it is presented as a series of bars indicating signal strength. More bars means more RSSI, which ensures greater received signal strength and better link performance.

If both the local and remote end of the system are operational, the remote TRACER 6420 receive power can be viewed from the local TRACER 6420 VT100 terminal menu interface.

An RSSI test point, located on the front panel, provides a DC voltage level (relative to the **GND** test point) that corresponds to the amount of signal being received from the far end's transmitter. The voltage at this test point can vary from approximately 0 to 5 VDC. An RSSI calibration sheet is shipped with the system to provide the installer a cross-reference between actual received signal level (in dBm) and RSSI voltage. This sheet is useful for verifying link budget calculations and ensuring proper equipment installation.

### Antenna Beam Patterns

Directly related to the subject of antenna alignment is the topic of antenna beam patterns. Antennas used with the TRACER 6420 system have a particular beam shape, determined in part by the physical construction and geometry of the antenna. The antenna beam patterns are characterized by a dominant main lobe, which is the preferred lobe to use for point-to-point communications, and several side lobes, as shown in Figure 2. When setting up a microwave link, antenna alignment is nothing more than steering the main lobes of both antennas until the main lobe of one transmitter is centered on the receiving element of the receiving antenna.



**Figure 2. Typical Antenna Beam Pattern**

Antennas are also designed to radiate RF energy efficiently for a specific range of frequencies. Please consult the data sheet for your particular antenna make and model to ensure that it is specified to operate in the 5725 MHz to 5850 MHz frequency band for the TRACER 6420 system.

### **Fresnel Zones, Earth Curvature, and Antenna Heights**

Fresnel zones correspond to regions in the microwave path where reflections of the intended signal occur and combine in both constructive and destructive manners with the main signal, thereby either enhancing or reducing the net power at the receiver.

In general, the odd numbered Fresnel zones (1, 3, 5, ...) add constructively at the receiver, while the even numbered Fresnel zones (2, 4, 6, ...) add destructively at the receiver.

The first Fresnel zone corresponds to the main lobe, 60% of which must be free of physical obstructions for the path calculations to be valid. Since the main lobe contains the vast majority of the microwave energy, this zone is typically used to determine proper antenna heights when placing antennas on towers or buildings.

The curvature of the Earth becomes a legitimate obstruction for path lengths of 7 miles or greater, and must also be accounted for when determining minimum antenna heights.

The aggregate expression for minimum antenna height that incorporates both the 60% first Fresnel zone and the Earth's curvature is given by

$$h = 72.1 \sqrt{\frac{d}{4f}} + 0.125d^2 \quad (\text{feet})$$

where  $f$  is in GHz and  $d$  is in miles.

Table 5 tabulates minimum antenna heights for given path lengths.

**Table 5. Minimum Antenna Height for Given Path Lengths**

<b>Path Length (miles)</b>	<b>Min. Antenna Height (ft)</b>
2	22
4	32
6	41
8	50
10	60
14	81
16	92
18	104
20	117
22	131
24	145
26	161
28	177
30	194
32	213
34	232
36	252

## 7. OTHER CONSIDERATIONS

### Path Availability

The path availability of a wireless link is a metric that expresses the fractional amount of time a link is available over some fixed amount of time, and depends on several factors. Path availability is expressed as

$$A = [1 - (2.5 \times 10^{-6})abfd^3(10^{-F/10})] \times 100\% \quad (\%)$$

where the parameters are

<i>a</i>	terrain factor
<i>b</i>	climate factor
<i>f</i>	carrier frequency (GHz)
<i>d</i>	path length (miles)
<i>F</i>	fade margin (dB)

### Terrain Factor (*a*)

The terrain factor is a quantity that compensates the link availability for different types of terrain. Generally speaking, the smoother an area's terrain is, the less availability a wireless link running over that terrain will have, primarily due to multipath reflections. In contrast, secondary microwave signals will be randomly dispersed over rough terrain and will not interfere with the main signal lobe as badly as in the smooth terrain case. The terrain factor values normally used are listed below:

Terrain	Terrain Factor	Description
Smooth	4	water, flat desert
Average	1	moderate roughness
Mountainous	1/4	very rough, mountainous

### Climate Factor (*b*)

The climate factor is a quantity that compensates the link availability for different types of climates (weather). In general, microwave links operating in areas with high humidity will have less availability than those in arid areas, primarily because water is a dispersive mechanism to microwave energy and causes the main signal lobe to refract and disperse away from the receiver location. The climate factor values normally used are listed below:

Climate	Climate Factor	Description
Very Dry	1/8	desert regions
Temperate	1/4	mainland, interior region
Humid	1/2	humid and coastal regions





# ENGINEERING GUIDELINES

Provides information to assist network designers with incorporating the TRACER 6420 system into their networks.

## CONTENTS

<b>Equipment Dimensions</b> .....	<b>26</b>
<b>Power Requirements</b> .....	<b>26</b>
<b>Reviewing the Front Panel Design</b> .....	<b>26</b>
RSSI Monitoring Interface .....	26
Front Panel LEDs .....	27
AUX RS232 Interface (RJ-45) .....	27
CRAFT Port (DB-9) .....	28
<b>Reviewing the TRACER 6420 Rear Panel Design</b> .....	<b>28</b>
MGMT 10/100BaseT/TX Connection (RJ-48C) .....	29
DC Power Connection (Plug-In Terminal Block) .....	30
Fuse .....	30
Alarm Contacts (Plug-In Terminal Block) .....	30
Antenna Interface (N-Type connector) .....	30
<b>Network Module Interfaces</b> .....	<b>31</b>
4xT1 Module .....	31
Quad Ethernet Switch Module .....	31
<b>At-A-Glance Specifications</b> .....	<b>32</b>

## LIST OF FIGURES

Figure 1. TRACER 6420 Front Panel Layout .....	26
Figure 2. TRACER 6420 Rear Panel .....	29

## LIST OF TABLES

Table 1. TRACER 6420 Front Panel Description .....	26
Table 2. TRACER 6420 LEDs .....	27
Table 3. AUX RS232 Pinout .....	27
Table 4. <b>CRAFT</b> Pinout .....	28
Table 5. Null-Modem Pinout .....	28
Table 6. Rear Panel Description .....	29
Table 7. MGMT 10/100BaseT/TX Interface Pinout .....	29
Table 8. DC Power Connector Pinout .....	30
Table 9. Alarm Contact Connector Pinout .....	30
Table 10. 4xT1 Module RJ-45 Connector Pinout .....	31
Table 11. Quad Ethernet Switch RJ-48C Connector Pinout .....	31
Table 12. At-A-Glance Specifications .....	32

## 1. EQUIPMENT DIMENSIONS

The TRACER 6420 integrated radio is 17.2" W, 11.4" D, and 1.7" H, weighs 7 lbs, and can be used in rackmount configurations.

## 2. POWER REQUIREMENTS

The TRACER 6420 radio has a maximum power consumption of 25 W and a maximum current draw of 1.2 A (at 21 VDC).

## 3. REVIEWING THE FRONT PANEL DESIGN

The front panel contains an **RSSI** monitoring interface, a **GND** interface for reference with RSSI, a **TEST** interface for viewing the QPSK constellation, a DB-9 **CRAFT** port for management and configuration, an **AUX RS232** interface (RJ-45) that provides an end-to-end serial port interface (at 9600 bps), and status LEDs to provide visual information about the TRACER 6420 system. Figure 1 identifies the various interfaces and the LEDs, and Table 1 provides a brief description of each interface.




Figure 1. TRACER 6420 Front Panel Layout

Table 1. TRACER 6420 Front Panel Description<sup>1</sup>

Name	Connector	Description
A RSSI	bantam	DC voltage indicating strength of the received signal at the antenna
B Status LEDs	N/A	Visual status information about the system
C GND	bantam	Ground reference for the RSSI interface
D TEST	3 conductor stereo jack	QPSK constellation (when connected to oscilloscope)
E AUX RS232	RJ-45	Serial interface for a 9600 bps connection between the local and remote systems over the RF link
F CRAFT PORT	DB-9	RS-232 interface for connection to a VT100 terminal or PC with terminal emulation software

<sup>1</sup> Detailed discussions (including pinouts) of front panel components (where applicable) follow the table.

### RSSI Monitoring Interface

The RSSI voltage is a function of the signal strength at the receiver and is used to measure the received signal strength. RSSI varies from approximately 0 to 5 VDC. An RSSI calibration sheet is shipped with the system to provide the installer a cross-reference between actual received signal level (in dBm) and RSSI voltage. This sheet is useful for verifying link budget calculations and ensuring proper equipment installation.

## Front Panel LEDs

With the TRACER powered-on, the front panel LEDs provide visual information about the status of the system. Table 2 provides detailed information about the LEDs.

**Table 2. TRACER 6420 LEDs**

For these LEDs...	This color light...	Indicates that...
<b>PWR</b>	Green (solid)	the TRACER is connected to a power source.
	Off	the TRACER is not currently powered up.
<b>TST</b>	Amber (flashes once)	power-up self-test is in progress. If the LED continuously flashes or remains on (solid) after 10 seconds, the unit has failed self-test.
<b>STATUS MOD1 and MOD2</b>	Green	the module is installed and functioning properly.
	Red (solid)	a port on the installed module is currently in alarm.
	Off	no module occupies the slot.
<b>PLAN A</b>	Green (solid)	the TRACER is transmitting on Frequency Plan A.
	Off	the TRACER is not transmitting on Frequency Plan A.
<b>PLAN B</b>	Green (solid)	the TRACER is transmitting on Frequency Plan B.
	Off	the TRACER is not transmitting on Frequency Plan B.
<b>RF LO</b>	Red (solid)	the RSSI level is below suggested minimum threshold (approximately 10 dBm above the minimum receive sensitivity).
<b>RF DWN</b>	Red (solid)	there is a communication problem between the local and remote TRACERs.

## AUX RS232 Interface (RJ-45)

The **AUX RS232** interface provides a female RJ-45 terminal connection (wired as a DCE interface), which is used for a 9600 bps point-to-point connection between the local and remote systems (over the RF link). Table 3 shows the pinout.

**Table 3. AUX RS232 Pinout**

Pin	Name	Source	Description
1	GND	Common	Signal ground
2	RTS	Attached Equipment	Request to send (unused)
3	TXDATA	Attached Equipment	Transmit data (from attached equipment)
4	DSR	TRACER	Data set ready
5	RXDATA	TRACER	Received data (to attached equipment)
6	CTS	TRACER	Clear to send
7	DTR	Attached Equipment	Data terminal ready (unused)
8	CD	TRACER	Carrier detect

### CRAFT Port (DB-9)

The **CRAFT** connector provides a female DB-9 terminal connection (wired as a DCE interface), which is used for terminal access to the TRACER system. Table 4 shows the pinout. A null modem cable is necessary for connecting the **CRAFT** port to a modem for remote dial-up access. Table 5 shows the pinout for a null modem cable.

**Table 4. CRAFT Pinout**

Pin	Name	Source	Description
1	CD	TRACER	Carrier detect
2	RXDATA	TRACER	Received data (to attached equipment)
3	TXDATA	Attached Equipment	Transmit data (from attached equipment)
4	DTR	Attached Equipment	Data terminal ready (unused)
5	GND	Common	Signal ground
6	DSR	TRACER	Data set ready
7	RTS	Attached Equipment	Request to send (unused)
8	CTS	TRACER	Clear to send
9	RI	TRACER	Ring indicator (unused)

**Table 5. Null-Modem Pinout**

Modem Pin	TRACER 6420 Pin
1 (CD)	unconnected
2 (RXD)	3 (TXD)
3 (TXD)	2 (RXD)
4 (DTR)	6 (DSR)
5 (GND)	5 (GND)
6 (DSR)	4 (DTR)
7 (RTS)	8 (CTS)
8 (CTS)	7 (RTS)
9 (RI)	unconnected

## 4. REVIEWING THE TRACER 6420 REAR PANEL DESIGN

Figure 2 on page 29 identifies the features of the TRACER rear panel, and Table 6 on page 29 provides a brief description of each interface.




Figure 2. TRACER 6420 Rear Panel

Table 6. Rear Panel Description<sup>1</sup>

Name	Connector	Description
<b>A</b> Network Module Slots	N/A	Dual network module slots for system flexibility (shown with a single 4xT1 Module and a Quad Ethernet Switch Module installed)
<b>B</b> MGMT	RJ-48C	10/100BaseT/TX Ethernet interface for Telnet access
<b>C</b> DC Power	Terminal Block	21-60 VDC power source connection (either polarity referenced to ground)
<b>D</b> Fuse	N/A	2A, 250 V, 2" slo-blo fuse
<b>E</b> Alarm	Terminal block	External alarm monitoring system connection
<b>F</b> Antenna	N-Type (female)	Antenna feedline cable connection
<b>G</b> Ground Lug	N/A	Earth ground connection

<sup>1</sup> Detailed discussions (including pinouts) of rear panel components (where applicable) follow the table.

### MGMT 10/100BaseT/TX Connection (RJ-48C)

The physical Ethernet interface is provided by a single RJ-48C jack (labeled **MGMT**) that delivers 10/100BaseT/TX for LAN connectivity. The **MGMT** port is used for Telnet, SNMP, and TFTP access and is not a router interface. The **MGMT** port has a green **LINK** LED to indicate a valid link and an amber **ACT** LED that flashes with data activity on the interface. Table 7 shows the pinout.

Table 7. MGMT 10/100BaseT/TX Interface Pinout

Pin	Name	Description
1	TX1	Transmit positive
2	TX2	Transmit negative
3	RX1	Receive positive
4,5	—	Unused
6	RX2	Receive negative
7, 8	—	Unused

### DC Power Connection (Plug-In Terminal Block)

The TRACER 6420 can operate from a supply between 21 and 60 VDC, with either polarity referenced to ground, and consumes less than 25 W. Power supplies should be able to provide up to 25 W at the selected voltage. Current required (in Amps) is determined by dividing the power consumed (in Watts) by the applied voltage (in Volts). For example, at 48 V, TRACER 6420 would draw approximately 0.52A (25 W/48 V).

**Table 8. DC Power Connector Pinout**

Pin	Name	Description
1	+/-	Voltage
2	GND	Ground

### Fuse

The fuse holder, accessible from the rear panel of the TRACER 6420, accepts a generic 2 A, 250 V, 2-inch slow-blo fuse.

### Alarm Contacts (Plug-In Terminal Block)

An RF link down condition is indicated with both normally open (**NO**) and normally closed (**NC**) alarm contacts on the rear panel of the TRACER 6420 system. In normal operation, the **NC** contact is electrically connected to the common contact (**COM**) and the **NO** contact is isolated. When the RF link drops, the **NC** contact becomes isolated and the **NO** is electrically connected to **COM**. This allows RF down conditions to be reported to external alarm monitoring systems. Table 9 provides the Alarm Contact pinout.

**Table 9. Alarm Contact Connector Pinout**

Pin	Name	Description
1	COM	Common Contact
2	NO	Normally-Open Contact
3	NC	Normally-Closed Contact

### Antenna Interface (N-Type connector)

The **ANTENNA** interface (N-Type connector) connects to the customer-supplied antenna using standard antenna feedline cable. When determining the cable specifications for your application, refer to Section 2, *Microwave Path Engineering Basics (System Losses (L)* on page 17) for a discussion on cable length and loss factors.

## 5. NETWORK MODULE INTERFACES

### 4xT1 Module

The 4xT1 Network Module has four T1 interfaces (through four RJ-45 ports) that provide the following functions:

- ANSI T1.403 and AT&T® 54016 and 62411 compliant
- AMI or B8ZS coding
- Extended Super Frame (ESF) and Super Frame (SF) framing support
- Manual line build out
- Network performance monitoring and reporting
- Test loopbacks (both Line and Link)

Table 10 provides the RJ-45 interface pinout for the 4xT1 Network Module.

**Table 10. 4xT1 Module RJ-45 Connector Pinout**

Pin	Name	Description
1	R	Transmit data (ring) towards the network
2	T	Transmit data (tip) towards the network
3, 6-8	UNUSED	—
4	R1	Receive data (ring) toward the network
5	T1	Receive data (tip) from the network

### Quad Ethernet Switch Module

The Quad Ethernet Switch Module has four 10/100BaseTX interfaces (through four RJ-48C ports) that provide the following functions:

- IEEE 802.3 and 802.3u compliant
- Auto MDI/MDIX crossover
- Backpressure flow control on all full-duplex interfaces
- Link and Activity LEDs for each port

Table 10 provides the RJ-48C interface pinout for the Quad Ethernet Switch Module.

**Table 11. Quad Ethernet Switch RJ-48C Connector Pinout**

Pin	Name	Source	Description
1	RX1	Attached Equipment	Receive Positive
2	RX2	Attached Equipment	Receive Negative
3	TX1	Module	Transmit Positive
4, 5	UNUSED	N/A	—
6	TX2	Module	Transmit Negative
7, 8	UNUSED	N/A	—

## 6. AT-A-GLANCE SPECIFICATIONS

Table 12 contains a list of specifications for the TRACER 6420 system.

**Table 12. At-A-Glance Specifications**

Hardware	Description	Specification	
<b>Transmitter</b>			
	Output Power	+20 dBm, max	
	Frequency Range	5725 to 5850 MHz	
<b>Receiver</b>			
	Receive Level, Minimum	-88 dBm @ 8xT1 -91 dBm @ 4xT1 -94 dBm @ 2xT1	
	Receive Level, Maximum	-30 dBm	
	Receive Level, Nominal	-55 dBm	
<b>Frequency Plan</b>			
	Plan A	<b>Channel Plan</b>	
		1	Tx 5.744 GHz, Rx 5.824 GHz
		2	Tx 5.747 GHz, Rx 5.827 GHz
	Plan B	<b>Channel Plan</b>	
		1	Tx 5.824 GHz, Rx 5.744 GHz
		2	Tx 5.827 GHz, Rx 5.747 GHz
		3	Tx 5.831 GHz, Rx 5.751 GHz
<b>Data Encryption</b>			
	Encryption Type	Symmetric Triple-DES (3DES)	
<b>User Interface</b>			
	Panel	Alarm LEDs	
	Diagnostics	RF link diagnostics and error history, transmit and receive packets history	
	Test Points	RSSI, Ground (GND), and Test (QPSK Constellation)	
	Alarms	Normally Open (NO) and Normally Closed (NC)	
	VT100 Terminal	Menu Driven User Interface, Control of the Remote End, Event History	
	Telnet Access	Menu Driven User Interface, Control of the Remote End, Event History	
	SNMP	Standard MIB support (T1 and Ether-like MIBs); Enterprise MIB support (ADTRAN TRACER)	



**Table 12. At-A-Glance Specifications (Continued)**

Hardware	Description	Specification
<b>VT100 Terminal Interface</b>		
	Data Rate	9600, 19200, 38400, 57600, 115200 bps
	Data Bits	8
	Parity	None
	Stop Bits	1
	Terminal Emulation	VT100
<b>Mechanical and Environmental</b>		
	Operating Temperature	-25° C to 65° C
	Size	1.7" H x 17.2" W x 11.4" D
	Humidity	95%, Non-condensing
	Weight	7 lbs
<b>Power</b>		
	Input Voltage	21 to 60 VDC, either polarity referenced to ground
	Power Consumption	≤ 25 W
	Connector	2 pin terminal block (DC)
	Fuse	2 A, 250 V slow-blo fuse (2-inch)
<b>Network Modules</b>		
Quad T1 Module	Connection	four RJ-45 interfaces
	Capacity	4xT1 (ANSI T1.403, AT&T® 54016 and 62411)
	Line Code	B8ZS (default), AMI
	Alarms	AIS, Red, Yellow, BPVs, LOS
Quad Ethernet Switch Module	Connection	four RJ-48C interfaces
	Interface Type	four 10BaseT/100BaseTX interfaces with auto MDI/MIDX crossover
	Flow Control	Back-pressure flow control on half-duplex interfaces Pause-frame flow control on full-duplex interfaces



# NETWORK TURNUP PROCEDURE

*Provides shipment contents list, grounding instructions, mounting options, and specifics of supplying power to the unit.*

## CONTENTS

<b>Introduction</b> .....	<b>36</b>
<b>Tools Required</b> .....	<b>36</b>
<b>Unpack and Inspect the System</b> .....	<b>36</b>
Contents of Shipment .....	36
Customer Provides .....	37
<b>Channel Selection</b> .....	<b>37</b>
<b>Grounding Instructions</b> .....	<b>38</b>
<b>Supplying Power to the Unit</b> .....	<b>39</b>
<b>Mounting Options</b> .....	<b>39</b>
<b>Installing Modules</b> .....	<b>41</b>
Instructions for Installing Network Modules .....	41
<b>Connecting the Module Interfaces</b> .....	<b>42</b>
4xT1 Module .....	42
Quad Ethernet Switch Module .....	42

## FIGURES

Figure 1. 5.8 GHz Bandwidth Division .....	37
Figure 2. 19-inch Rackmount Illustration .....	40
Figure 3. 23-inch Rackmount Illustration .....	40
Figure 4. TRACER 6420 Network Module Slot Designation .....	41

## 1. INTRODUCTION

This section discusses TRACER 6420 system installation.

### **WARNING**

*Changes or modifications not expressly approved by ADTRAN could void the user's authority to operate the equipment.*

## 2. TOOLS REQUIRED

The tools required for TRACER 6420 installation are:

- VT100 terminal or PC with terminal emulation software
- RS-232 (DB-9 male for TRACER 6420) cable for connecting to terminal



*To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.*

## 3. UNPACK AND INSPECT THE SYSTEM



*This system **MUST** be installed by qualified service personnel in a Restricted Access Location.*

Each TRACER 6420 is shipped in its own cardboard shipping carton. Open each carton carefully and avoid deep penetration into the carton with sharp objects.

After unpacking the unit, inspect it for possible shipping damage. If the equipment has been damaged in transit, immediately file a claim with the carrier; then contact ADTRAN Customer Service (see *Customer Service, Product Support Information, and Training* information in the front of this manual).

### Contents of Shipment

Your shipment of the base unit includes the following items:

- TRACER 6420 unit
- RJ-45 to DB-9 connector (ADTRAN P/N 3196ADPT001) for connection to the **AUX RS232** port
- 6' silver satin cable for
- Rackmount brackets
- Power and Alarm connectors
- TRACER 6420 Documentation CD

Your shipment of the Quad Ethernet Switch Module includes the following items:

- Quad Ethernet Switch Module
- Quad Ethernet Switch Module Quick Start Guide

Your shipment of the 4xT1 Network Module includes the following items:

- 4xT1 Network Module
- 4xT1 Network Module Quick Start Guide


### Customer Provides

The following items are necessary for the installation of the TRACER 6420 system and are not provided:

- 21 to 60 VDC power source either polarity referenced to ground
- DB-9 cable for VT100 access
- T1 cables for connecting external equipment to the T1 interfaces (4xT1 Module only)
- Ethernet cables for connected external equipment for the switch interfaces (Quad Ethernet Switch Module only)
- Ethernet cable (for Telnet access)

## 4. CHANNEL SELECTION

The FCC has allocated 125 MHz of spectrum in the 5.8 GHz band where the TRACER 6420 operates. Figure 1 illustrates the bandwidth division.



**Figure 1. 5.8 GHz Bandwidth Division**

To designate the utilization of the ISM bandwidth, there are two different channel plans, labeled A and B. The letter of each channel plan setting is preset by the factory and refers to the physical configuration of the diplexer filter inside the chassis. Each channel is then divided into three band plans (1, 2 or 3). The band plans must be the same for the local and remote TRACER 6420. For example, the transmitter at one end of the link will transmit in band plan 1 of channel A (the lower portion of the spectrum) and receive in band plan 1 of channel B (the upper portion). Consequently, the receiver at the other end should receive in band plan 1 of channel A (the lower portion) and transmit in band plan 1 of channel B (the upper portion).

The letter of the channel plan (A or B) must be different on both ends and the number of the band plan (1, 2, or 3) must be the same on both ends. The default band plan configuration for the TRACER 6420 is band plan 1.

The channel plan (A or B) of the unit may be changed in the field, if necessary, by rewiring the internal diplexer. Contact Technical Support for more information on this procedure.

## 5. GROUNDING INSTRUCTIONS

The following paragraphs provide grounding instruction information from the Underwriters' Laboratory UL60950 Standard for Safety of Information Technology Equipment Including Electrical Business Equipment, with revisions dated March 15, 2002.

An equipment grounding conductor that is not smaller in size than the ungrounded branch-circuit supply conductors is to be installed as part of the circuit that supplies the product or system. Bare, covered, or insulated grounding conductors are acceptable. Individually covered or insulated equipment grounding conductors shall have a continuous outer finish that is either green, or green with one or more yellow stripes. The equipment grounding conductor is to be connected to ground at the service equipment.

The attachment-plug receptacles in the vicinity of the product or system are all to be of a grounding type, and the equipment grounding conductors serving these receptacles are to be connected to earth ground at the service equipment.

A supplementary equipment grounding conductor shall be installed between the product or system and ground that is in addition to the equipment grounding conductor in the power supply cord.

The supplementary equipment grounding conductor shall not be smaller in size than the ungrounded branch-circuit supply conductors. The supplementary equipment grounding conductor shall be connected to the product at the terminal provided, and shall be connected to ground in a manner that will retain the ground connection when the product is unplugged from the receptacle. The connection to ground of the supplementary equipment grounding conductor shall be in compliance with the rules for terminating bonding jumpers at Part K or Article 250 of the National Electrical Code, ANSI/NFPA 70. Termination of the supplementary equipment grounding conductor is permitted to be made to building steel, to a metal electrical raceway system, or to any grounded item that is permanently and reliably connected to the electrical service equipment ground.

The supplemental grounding conductor shall be connected to the equipment using a number 8 ring terminal and should be fastened to the grounding lug provided on the rear panel of the equipment. The ring terminal should be installed using the appropriate crimping tool (AMP P/N 59250 T-EAD Crimping Tool or equivalent).



*The supplemental equipment grounding terminal is located on the rear panel of the TRACER 6420.*

## 6. SUPPLYING POWER TO THE UNIT

The TRACER 6420 can operate from a supply between 21 and 60 VDC, with either polarity referenced to ground. Power supplies should be able to provide up to 25 Watts at the selected voltage. A dual pin terminal plug accepts power at the rear panel of the unit, providing a voltage (+/-) and ground (**GND**) reference point.



- *This unit shall be installed in accordance with Article 400 and 364.8 of the NEC NFPA 70 when installed outside of a Restricted Access Location (i.e., central office, behind a locked door, service personnel only area).*
- *Power to the TRACER 6420 DC system must be from a reliably grounded 21-60 VDC UL Listed or CSA Certified ITE Power Supply with outputs meeting LPS requirements.*
- *A readily accessible disconnect device that is suitably approved and rated shall be incorporated in the field wiring.*

## 7. MOUNTING OPTIONS


Install the TRACER 6420 in a location that requires minimal antenna feedline length (the loss in this cable directly affects overall system performance). The TRACER 6420 is designed to be mounted in a rack. If multiple units are installed in one location, one half inch of spacing is recommended above and below the unit.

The TRACER 6420 systems are 1U high, rack-mountable units which can be installed into 19- (see Figure 2) or 23-inch (see Figure 3 on page 40) equipment racks using the supplied rackmount brackets (3265498@B). Follow these steps to mount the TRACER 6420 into a rack:


<b>Instructions for Rackmounting the TRACER 6420</b>	
1	Position the TRACER 6420 in a stationary equipment rack. This unit takes up 1U of space. To allow proper grounding, scrape the paint from the rack around the mounting holes where the TRACER 6420 will be positioned.
2	Have someone else hold the unit in position as you install two mounting bolts through the unit's brackets and into the equipment rack using a #2 Phillips screwdriver.



*Be careful not to compromise the stability of the equipment mounting rack when installing this product.*



**Figure 2. 19-inch Rackmount Illustration**



**Figure 3. 23-inch Rackmount Illustration**



## 8. INSTALLING MODULES

Figure 4 shows the slot numbering designation as viewed from the rear of the TRACER 6420. The functionally identical option slots only accept TRACER network modules.




Figure 4. TRACER 6420 Network Module Slot Designation

**WARNING** Access modules are intended to be serviced by qualified service personnel only

**CAUTION** Electronic modules can be damaged by static electrical discharge. Before handling modules, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place modules in antistatic packing material when transporting or storing. When working on modules, always place them on an approved antistatic mat that is electrically grounded.

### Instructions for Installing Network Modules

Individual access modules insert in the back of the chassis. Two Phillips-head screws hold the modules in place for added security. To install network modules, follow the steps outlined below.

Step	Action
1.	Remove power from the unit.
2.	Slide the network module into the network slot until the module is firmly seated against the front of the chassis.
3.	Secure the screws at both edges of the module.
4.	Connect the cables to the associated device(s).
5.	Restore power to the unit.

## 9. CONNECTING THE MODULE INTERFACES

### 4xT1 Module

The physical T1 interfaces are provided using four RJ-45 ports located on the module. Straight-through T1 interface cables can be used to interface to any standard T1 DTE device (not supplied).



*T1 crossover cables are needed when connecting two TRACER 6420 T1 ports in back-to-back operation.*

### Quad Ethernet Switch Module

The physical Ethernet interfaces are provided using four RJ-48C jacks. Ethernet cables are not supplied with your shipment. Connect any standard Ethernet device to one of the switch ports located on the rear of the unit.

# USER INTERFACE GUIDE

*Provides detailed descriptions of all menu options and configuration parameters available for the TRACER 6420.*

This section of the TRACER 6420 System Manual is designed for use by network administrators and others who will configure and provision the system. It contains information about navigating the VT100 user interface, configuration information, and menu descriptions.

## CONTENTS

<b>Navigating the Terminal Menu</b> .....	<b>45</b>
Terminal Menu Window .....	45
Navigating using the Keyboard Keys .....	46
<b>Menu and System Control</b> .....	<b>46</b>
Password Protection .....	46
<b>Menu Descriptions</b> .....	<b>47</b>
> System Status .....	47
> Main Menu .....	49
> System Configuration .....	50
> RF Link Configuration .....	52
> RF Link Performance History (Main Screen) .....	54
> RF Link Performance History .....	54
> RF Link Max/Min Received Power History .....	55
> RF Link Min/Max Received Signal Quality History .....	56
> Datapath Provisioning .....	57
> Ethernet Switch Module Configuration/Status/History (Main Screen) .....	58
> Ethernet Switch Configuration .....	58
> Ethernet Switch Status .....	59
> T1 Module Configuration/Status/History (Main Screen) .....	60
> T1x Status/Configuration/Loopback .....	61
> Management/Utilities (Main Screen) .....	65
> Ping Utility .....	67
> Firmware Upgrade Utility .....	68

## FIGURES

Figure 1. Main Menu Screen .....	45
Figure 2. TRACER 6420 System Status .....	47
Figure 3. TRACER 6420 Main Menu .....	49
Figure 4. TRACER 6420 System Configuration .....	50
Figure 5. RF Link Configuration (With Optional Triple-DES Encryption) .....	52
Figure 6. 5.8 GHz Bandwidth Division .....	53
Figure 7. RF Link Performance History (Main Screen) .....	54
Figure 8. RF Link Performance History .....	54
Figure 9. RF Link Max/Min Received Power History .....	55
Figure 10. RF Link Min/Max Received Signal Quality History .....	56
Figure 11. Datapath Provisioning .....	57
Figure 12. Ethernet Switch Module Configuration/Status/History (Main Screen) .....	58
Figure 13. Ethernet Switch Module Configuration .....	58

---

Figure 14.	Ethernet Switch Module Status . . . . .	59
Figure 15.	T1 Module Configuration/Status/History (Main Screen). . . . .	60
Figure 16.	T1x Status/Configuration/Loopback. . . . .	61
Figure 17.	T1 Local Link Loopback . . . . .	62
Figure 18.	T1 Remote Link Loopback . . . . .	63
Figure 19.	T1 Local Line Loopback . . . . .	63
Figure 20.	T1 Remote Line Loopback . . . . .	63
Figure 21.	T1x Link Performance History . . . . .	64
Figure 22.	Management/Utilities (Main Screen) . . . . .	65
Figure 23.	Management/SNMP Port Configuration. . . . .	65
Figure 24.	Ping Utility . . . . .	67
Figure 25.	Firmware Upgrade Utility . . . . .	68

## 1. NAVIGATING THE TERMINAL MENU

The TRACER 6420 menu system can be accessed with a VT100 compatible terminal that is connected to the **CRAFT PORT** (located on the front of the unit) and set to 9600 bits per second (default), 8 data bits, 1 stop bit, and no parity. Flow control on the serial interface should be configured to **NONE** for proper operation. Once a terminal is connected, press **<Enter>** to activate the login screen. The default password for the TRACER 6420 is **password**.



*All TRACER 6420 passwords are case-sensitive.*

### Terminal Menu Window

The TRACER 6420 uses a series of menu pages and a single Main menu page to access its many features. The Main menu page (see Figure 1) provides a link to all available configuration/status pages.



*After connecting a VT100 terminal to the TRACER 6420, press **<Ctrl + I>** or **<Ctrl + r>** to redraw the current screen.*




Figure 1. Main Menu Screen

## Navigating using the Keyboard Keys

You can use various keystrokes to move through the terminal menu, to manage a terminal menu session, and to configure the system.

### Moving Through the Menus

To do this...	Press this key...
Activate the Login screen (upon initial connection)	Enter (twice)
Refresh the screen	<Ctrl + L> <Ctrl + R>
Exit the menu system and return to the login screen	<Ctrl + Z>
Close the Telnet session (or toggle the modem signalling to hang up an attached modem)	<Ctrl + Z> (twice)
Move up to select items	Up Arrow p (Previous)
Move down to select items	Down Arrow n (Next)
Edit a selected menu item	Enter Spacebar
Scroll through configuration parameters for a menu item	Spacebar Left/Right Arrows p or n (Prev/Next)
Cancel an edit	Escape
Return to Main menu page	m
Back out to previous menu page	b Left Arrow
Go to System Status menu page	s

## 2. MENU AND SYSTEM CONTROL

### Password Protection

The TRACER 6420 provides password protection of the menu interface (via Terminal or Telnet access).



*All TRACER 6420 systems are shipped with a default password of **password**. (Passwords are case-sensitive.)*

### 3. MENU DESCRIPTIONS


The remainder of this section describes the TRACER 6420 menus and submenus.

**NOTE** *The menu structure of the TRACER 6420 system is depicted below as follows:*

- > **MENU PAGE**
- > **MENU PAGE > MENU SELECTION**
- > **MENU PAGE > MENU SELECTION > SUB-MENU**

#### > SYSTEM STATUS

Figure 2 shows the TRACER 6420 System Status menu page. The status of major system components for both sides of the RF link are displayed, but no configuration can be performed from this view.



**Figure 2. TRACER 6420 System Status**

#### A. Elapsed Time

The top of the TRACER 6420 System Status menu page displays the elapsed time the TRACER 6420 system has been operational since the last power reset.

#### B. Module Status

A visual status of the current installed modules. The modules are listed in the order they are installed (Slot 1 on top and Slot 2 on the bottom).

#### 4XT1 MODULE

A visual status of current errors/alarms on the T1 interfaces (for both the local and remote systems) is provided on the TRACER 6420 System Status menu page. The four available T1 interfaces on the module (A through D) are only displayed if the interface is mapped in the **DATAPATH PROVISIONING**; a – is displayed for inactive, unmapped interfaces. The interface displayed in reverse highlight indicates an active error or alarm condition on the specified interface (A through D). Individual T1 status pages (accessible from the main menu) provide detailed T1 information.

### QUAD ETHERNET SWITCH MODULE

A visual status of current errors/alarms on the Ethernet interfaces (for both the local and remote systems) is provided on the TRACER 6420 System Status menu page. The configured data rate (on the Datapath Provisioning page) is displayed. Individual status notations for the available Ethernet interfaces are available through the Quad Ethernet Switch Module Status page.

#### C. RF Status

A graphical indicator of the RF links is located beneath the Elapsed Time display. The status of the received radio link is indicated as **RF UP** or **RF DOWN** for each direction. This RF status display corresponds to the **RF DWN** LED on the front of the unit.

#### D. Remote System Status

The right portion of the TRACER 6420 System Status menu page reports the status of the remote TRACER 6420 (the system across the wireless link from the active terminal). If the RF link is down in either direction, **DATA NOT AVAILABLE** is displayed in place of the remote system status information.

#### E. Local System Status

The left portion of the TRACER 6420 System Status menu page reports the status of the local TRACER 6420 (the system where the active terminal is attached).

#### F. Frequency Plan

Displays the frequency plan (A or B) for the TRACER 6420 unit. For an operational TRACER 6420 system, you should have one A and one B frequency plan.

#### G. Rx Quality

Displays an indicator of receive signal quality that is not necessarily related to receive signal level (for both the local and remote units) using a series of symbols (#). The more symbols displayed, the better the signal quality. This indicator is related to signal-to-noise ratio and features a colon (:) marker to indicate  $10^{-6}$  bit error rate. This indicator is useful as a diagnostic tool to help identify interference, as the system may have high receive signal level and poor signal quality in situations where interference is an issue.

#### H. Rx Power

Displays the approximate receiver levels (for both the local and remote units) using a series of symbols (#). The more symbols (#) displayed, the stronger the signal. If the link is down in either direction and remote end data is unavailable, **DATA NOT AVAILABLE** is displayed in place of the symbols (#).

#### I. Tx Power

Displays the approximate transmitter levels (for both the local and remote units) using a series of symbols (#). The more symbols (#) displayed, the stronger the signal. If the link is down in either direction and remote end data is unavailable, **DATA NOT AVAILABLE** is displayed in place of the symbols (#).

#### J. Navigation Reminders

Displays system navigation reminders. For more details on system navigation, refer to *Navigating the Terminal Menu* on page 45.



## > MAIN MENU

The TRACER 6420 Main menu page provides access to all other configuration/status pages. Figure 3 shows the TRACER 6420 Main menu page.



*Installed Network Modules are displayed as menu options 5 (slot 1) and 6 (slot 2). Menu options for empty slots are not displayed.*

```
Telnet Connection
Session Edit Options Capture Help
Main Menu Tracer 6420 19:44:35 01/28/2000
=====
Rev: A.0.11 11:55:25 Nov 24 2004

    0) [System Status Page]
    1) System Configuration Menu
    2) RF Link Configuration
    3) RF Link Performance History
    4) Datapath Provisioning
    5) Switch Module 1 Configuration/Status/History
    6) 4xT1 Module 2 Configuration/Status/History
    7) Management/Utilities

                                     (Press Ctrl-Z to logout)
=====
Press Menu Number, or [arrow keys] - Move Up and Down, [space] - Select:
```

**Figure 3. TRACER 6420 Main Menu**

From the keyboard, use the up and down arrow keys to scroll through the available pages, or enter the number or letter of the selected page (to highlight the menu page) and press **<Enter>**.



*Press **<m>** from any menu in the TRACER 6420 menu structure to access the TRACER 6420 Main menu page.*

## > SYSTEM CONFIGURATION

Figure 4 shows the TRACER 6420 System Configuration menu page. System configuration parameters for both the local and remote TRACER 6420 units are available through this menu page.




Figure 4. TRACER 6420 System Configuration



Press <I> from any menu in the TRACER 6420 menu structure to access the System Configuration menu page.

### > SYSTEM CONFIGURATION > SITE NAME

Provides a user-defined alphanumeric description (up to 25 characters) for the TRACER 6420 system.

### > SYSTEM CONFIGURATION > SERIAL NUMBER

Displays the serial number for the unit. The serial number of the TRACER 6420 will automatically display in this field.

### > SYSTEM CONFIGURATION > SYSTEM TIME

Displays the current time, including seconds. To edit this field, place the cursor on the field and press <Enter>. Then, enter the time in a 24-hour format (such as 23:00:00 for 11:00 pm). Press <Enter> when you are finished to accept the change.

**> SYSTEM CONFIGURATION > SYSTEM DATE**

Displays the current date. To edit this field, place the cursor on the field and press <Enter>. Then, enter the date in mm-dd-yyyy format (for example, 10-30-1998). Press <Enter> when you are finished to accept the change.

**> SYSTEM CONFIGURATION > ELAPSED TIME**

Displays the length of time the TRACER 6420 system has been running. Each time you reset the system, this value resets to 0 days, 0 hours, 0 min, and 0 secs.

**> SYSTEM CONFIGURATION > CRAFT PORT BAUD**

Specifies the baud rate of the port. Select either **9600** (default), **19200**, **38400**, **57600**, or **115200** bps. If you are using the **CRAFT** port for modem access, ensure that the **CRAFT** port rate matches the modem baud rate.

**> SYSTEM CONFIGURATION > INACTIVITY LOGOUT**

This option defines the amount of time in minutes the user may stay connected without any activity on the **CRAFT** port before the user is automatically logged out of the system. Select one of the following: **5 MIN**, **10 MIN** (default), **15 MIN**, **30 MIN**, **45 MIN**, **60 MIN**, or **OFF**.



*Changes to the **INACTIVITY LOGOUT** setting do not apply to the current session. All changes take affect at the next login to the system menus.*

**> SYSTEM CONFIGURATION > PASSWORD**

Sets the password for password protection of the TRACER 6420 terminal interface. Enter up to 8 alphanumeric characters. The system password is case sensitive.



*The default password for the TRACER 6420 is **password**.*

**> SYSTEM CONFIGURATION > PERFORMANCE STATS (CLEAR)**

Resets all system error counters for the TRACER 6420.

**> SYSTEM CONFIGURATION > FACTORY DEFAULT**

Resets the system to the factory default settings. The configured **IP ADDRESS**, **SUBNET MASK**, and **DEFAULT GATEWAY** are not defaulted during a factory default.



*The **TOTAL ACTIVE CHANNELS** parameter (on the Datapath Provisioning page) is reset to the factory default value (**8**). Performing a factory default on any system with less than 8 active channels will result in an RF link loss.*

## > RF LINK CONFIGURATION

Figure 5 shows the TRACER 6420 RF Link Configuration screen, which contains the transmit and receive power settings and band plan configuration for both the local and remote units.




Figure 5. RF Link Configuration

### > RF LINK CONFIGURATION > RX POWER

Displays the approximate receiver levels (for both the local and remote units) using a series of symbols (#). The more symbols (#) displayed, the stronger the signal. If the link is down in either direction and remote end data is unavailable, **DATA NOT AVAILABLE** displays in place of the symbols (#). This parameter is display only.

### > RF LINK CONFIGURATION > TX POWER

Allows the transmitter levels (for both the local and remote units) to be adjusted. The current transmitter level is displayed using a series of symbols (#). The more symbols (#) displayed, the stronger the signal. If the link is down and remote end data is unavailable, **DATA NOT AVAILABLE** displays in place of the symbols (#). Pressing (+) on this field sets the **TX POWER** to full strength; pressing (-) reduces the **TX POWER** to the minimum.




*Reducing the transmitter power of the remote TRACER 6420 could cause the RF link to drop, requiring a technician to increase the transmit power by using the menu system at the remote site.*

### > RF LINK CONFIGURATION > RF BAND PLAN

Sets the band plan for the TRACER 6420. Each channel is divided into three band plans (1, 2, or 3). Both local and remote TRACER 6420 must be configured with the same band plan (1, 2, or 3) but different channel plans (Plan A or Plan B). For example, the transmitter at one end of the link will transmit in band plan 1 of channel A (the lower portion of the spectrum) and receive in band plan 1 of channel B (the upper portion). Consequently, the receiver at the other end should receive in band plan 1 of channel A (the lower portion) and transmit in band plan 1 of channel B (the upper portion). (Refer to Figure 6 for the division.) The TRACER 6420 comes factory programmed with RF band plan set to Band 1.



*When changing RF band plans on installed links, change the remote end first. If the local end is changed first, remote configuration capability is lost. In the event the local end is changed first and the link is dropped, reset the local end to the previous setting to restore the link.*



**Figure 6. 5.8 GHz Bandwidth Division**

### > RF LINK CONFIGURATION > LINK ENCRYPTION

The TRACER 6420 provides Triple-DES (3DES) encryption of the data passed over the RF Link. When **LINK ENCRYPTION** is set to **ENABLED**, the TRACER 6420 sequentially applies the three keys entered in the **SUBKEY 0**, **1**, and **2** fields to each 64-bit block of data transmitted over the RF link. The remote TRACER 6420 uses the same keys to decrypt each block. (The keys entered in the local and remote systems must be identical.)

### > RF LINK CONFIGURATION > SUBKEY (0-2)

The TRACER 6420 provides 3DES encryption of the data passed over the RF Link. When **LINK ENCRYPTION** is set to **ENABLED**, the TRACER 6420 sequentially applies the three keys entered in the **SUBKEY 0**, **1**, and **2** fields to each 64-bit block of data transmitted over the RF link. The remote TRACER 6420 uses the same keys to decrypt each block. (The keys entered in the local and remote systems must be identical.) Valid entries are numbers **0** through **9** and letters **a** through **f**.

> **RF LINK PERFORMANCE HISTORY (MAIN SCREEN)**

Figure 7 shows the TRACER 6420 RF Link Performance History main screen, which contains the transmit and receive power settings and band plan configuration for both the local and remote units.




Figure 7. RF Link Performance History (Main Screen)

> **RF LINK PERFORMANCE HISTORY**

Figure 8 shows the TRACER 6420 main RF Link Performance History menu page, which displays detailed error statistics for the RF link (from both the local and remote TRACER 6420 units) in 15-minute and 24-hour increments.




Figure 8. RF Link Performance History

Link errors (**LNK ERR**) represent errored seconds across the wireless link, and are generally an indication of path or interference problems.

The link error count and minimum received signal level for the most recent 24 hours are recorded in 15-minute increments and displayed on the right side of the page. The left side of the page displays the 24 hour totals for the most recent 7 days.

**NOTE** Press <n> to view the next 8 hours worth of 15-minute totals and <p> to view the previous 8 hours.

> RF LINK MAX/MIN RECEIVED POWER HISTORY

Figure 9 shows the TRACER 6420 RF Link Max/Min Received Power History page, which displays the available received power statistics from the system. Minimum and maximum received signal levels for the RF link (from both the local and remote TRACER 6420 units) in 15-minute and 24-hour increments are found on this screen.




Figure 9. RF Link Max/Min Received Power History


The received power level (**MIN** and **MAX**) represents the minimum and maximum values of received signal level in a 24-hour or 15-minute increment and is displayed as a numerical value from 0 to 100, with 0 corresponding to 0 V of RSSI and 100 corresponding to 5 V RSSI.

**NOTE** The minimum receive power level is recorded to aid in troubleshooting problem RF links. Radio links with high **MIN** numbers and intermittent performance are probably experiencing interference, while links with low **MIN** numbers have improperly engineered paths or excess system losses. A system with **MIN** numbers varying widely could indicate fading, reflections, or an intermittent installation problem such as loose connectors, damaged coax or lightning arrestors, or water contaminated feedlines.

**NOTE** Press <n> to view the next 8 hours worth of 15-minute totals and <p> to view the previous 8 hours.

## > RF LINK MIN/MAX RECEIVED SIGNAL QUALITY HISTORY

Figure 9 shows the TRACER 6420 RF Link Min/Max Received Signal Quality History menu page, which displays the available received signal quality statistics from the system. Minimum and maximum received signal quality levels for the RF link (from both the local and remote TRACER 6420 units) in 15-minute and 24-hour increments are found on this screen.



**Figure 10. RF Link Min/Max Received Signal Quality History**

The received power quality level (**MIN** and **MAX**) represents the minimum and maximum values of received signal quality levels in a 24-hour or 15-minute increment and is displayed as a numerical value from 0 to 100, with 0 corresponding to poor signal quality and 100 corresponding to exceptional signal quality.



*Radio links with consistently high **MIN** and **MAX** numbers should not experience interference. Radio links with a large difference between **MIN** and **MAX** numbers could be experiencing fading, reflections, or intermittent interference or installation problems such as loose connectors, damaged coax cable, water contaminated feedlines, or damaged lightning arrestors. Radio links with consistently low **MIN** and **MAX** numbers may be experiencing interference, low receive levels, or installation problems. If this is the case, examine the RF link MIN/MAX received power history. High received power numbers with low received signal quality numbers indicate interference, while low received power numbers with low received signal quality numbers indicate low receive levels or installation problems.*



*Press <n> to view the next 8 hours worth of 15-minute totals and <p> to view the previous 8 hours.*



## > DATAPATH PROVISIONING

Figure 11 shows the Datapath Provisioning menu page, which displays the active network interfaces for the installed modules (from both the local and remote TRACER 6420 units).




Figure 11. Datapath Provisioning

### > DATAPATH PROVISIONING > TOTAL ACTIVE CHANNELS

Defines the total number of channels active on the installed modules. Specify **2**, **4**, or **8** total active channels. After defining the total number of active channels, specify the actual active channels using the **CHANNEL SELECTION** menu.

### > DATAPATH PROVISIONING > MODULE 1/MODULE 2 CHANNELS

(Read Only) Displays the total number of active channels on the installed module.



*The number of active channels and the channel configuration on both the local and remote systems must match for the RF link to function properly. A discrepancy between the systems can result in unpredictable operation.*

### > DATAPATH PROVISIONING > CHANNEL SELECTION

Defines the active channels (**A**, **B**, **C**, **D**) on each installed T1 module or the bandwidth dedicated to the Quad Ethernet Switch Module (in 2 Mbps steps). To activate a channel, press **<Enter>** and use the spacebar or arrow keys to cycle through the available channel combinations until the desired combination displays. Press **<Enter>** again to make the channel combination change. If the specified channel selection is not valid, the TRACER 6420 automatically corrects the configuration and populates the field with a valid selection.



*The number of active channels and the channel configuration on both the local and remote systems must match for the RF link to function properly. A discrepancy between the systems can result in unpredictable operation.*

## > ETHERNET SWITCH MODULE CONFIGURATION/STATUS/HISTORY (MAIN SCREEN)

Figure 12 shows the Ethernet Switch Module Configuration/Status/History main screen, which contains access to the status, configuration, testing, and performance history parameters for the selected Ethernet Switch module.




Figure 12. Ethernet Switch Module Configuration/Status/History (Main Screen)

## > ETHERNET SWITCH CONFIGURATION

Figure 13 shows the Ethernet Switch Module Configuration screen, which contains access to the port configuration options for the available Ethernet interfaces on the selected module.



The following menus for the **ETHERNET SWITCH CONFIGURATION** apply to all four available Ethernet interfaces (1 through 4).




Figure 13. Ethernet Switch Module Configuration

## >ETHERNET SWITCH CONFIGURATION > PORT X

The Quad Ethernet Switch Module provides the capability to individually disable interfaces on the module. Selecting **DISABLE** from the **PORT X** menu disables the port, stopping all data passing through the interface.

## >ETHERNET SWITCH CONFIGURATION > SPEED/DUPLEX

Defines the speed and duplex for the selected Ethernet interface. Available options are: **100/FDX** (100 Mbps with full duplex operation), **100/HDX** (100 Mbps with half duplex operation), **10/FDX** (10 Mbps with full duplex operation), and **10/HDX** (10 Mbps with half duplex operation), and **AUTO** (automatically detects speed and duplex of the connection). The speed and duplex settings of the TRACER Ethernet port and the attached Ethernet equipment should be identical; if the TRACER is set to auto-negotiation the attached equipment should also be set for auto-negotiation. When the **SPEED/DUPLEX** is manually set, 802.3u auto-negotiation is disabled; the Ethernet equipment connected to the manual port must be manually set to the same speed/duplex settings. When set to **AUTO**, the actual negotiated speed and duplex of the system can be displayed on the Ethernet Switch Status page.

## > ETHERNET SWITCH STATUS

Figure 14 shows the Ethernet Switch Module Status screen, which displays the current speed and duplex operation for each switch interface (on both the local and remote systems) as well as transmit and receive data statistics for the Ethernet interface (from both the local and remote TRACER 6420 systems) and RF link.

Local Unit	Port 1 10/HDX	Port 2 10/HDX	Port 3 10/HDX	Port 4 100/FDX	Wan
Tx Packets	0	0	0	29234	21124
Tx Packets Dropped	0	0	0	0	0
Rx Packets	0	0	0	21124	29234
Rx Packets Dropped	0	0	0	0	0
Rx Packet Errors	0	0	0	0	1
Remote Unit	10/HDX	10/HDX	100/FDX	100/FDX	
Tx Packets	0	0	9503	24538	33739
Tx Packets Dropped	0	0	0	0	0
Rx Packets	0	0	0	33744	24538
Rx Packets Dropped	0	0	0	0	0
Rx Packet Errors	0	0	0	0	2

Press 'm' - Main Menu:

Figure 14. Ethernet Switch Module Status

## >ETHERNET SWITCH STATUS > TX PACKETS

Displays a counter of all data packets transmitted out the local and remote TRACER Ethernet interfaces. Use this data as an indicator for how many packets are being transmitted between the four Ethernet interfaces versus over the wireless link (WAN stats). The WAN statistics (Ethernet packets transmitted over the RF link) provide a quick way to determine Ethernet packet loss over the wireless link; the **RX PACKETS** on the local system should match the **TX PACKETS** on the remote side (and vice versa).

**>ETHERNET SWITCH STATUS > TX PACKETS DROPPED**

Displays a counter of all transmit data packets that were unable to be transmitted out the individual Ethernet interfaces (for both the local and remote TRACER units). Use this data as an indicator of congestion on the Ethernet network segments. Dropped packets on the WAN interface can indicate that the provisioned bandwidth for the switch module is insufficient.

**>ETHERNET SWITCH STATUS > RX PACKETS**

Displays a counter of all data packets received on the local and remote TRACER Ethernet interfaces and WAN (RF link). Use this data as an indicator for how many packets are being received on the four Ethernet interfaces versus being received over the wireless link.

**>ETHERNET SWITCH STATUS > RX PACKETS DROPPED**

Displays a counter of all received data packets that were unable to be processed due to congestion inside the TRACER 6420 switch (for both the local and remote TRACER 6420 units). Use this data as an indicator of congestion inside the TRACER 6420 switch.

**>ETHERNET SWITCH STATUS > RX PACKET ERRORS**


Displays a counter of all received data packets that are greater than or equal to 64 bytes in length and have either an FCS error or an alignment error (for both the local and remote TRACER units). **RX PACKET ERRORS** on the WAN interface (RF link) could indicate link degradation (due to interference, fading, etc.).



*If the RF link goes down, some packet errors may display. Once the TRACER 6420 system recognizes the link is down (an active RF Low alarm), packet errors will NOT increment.*

**> T1 MODULE CONFIGURATION/STATUS/HISTORY (MAIN SCREEN)**

Figure 15 shows the TRACER 6420 4xT1 Module Configuration main screen, which contains access to the status, configuration, testing, and performance history parameters for the selected T1 module.



**Figure 15. T1 Module Configuration/Status/History (Main Screen)**

> T1X STATUS/CONFIGURATION/LOOPBACK

**NOTE** *The following menus for the T1x Status/Configuration/Loopback apply to all four available T1 interfaces (A through D).*

Figure 16 on page 61 shows the T1x Status/Configuration/Loopback menu page, which displays a real-time graphical representation for the T1x link using data from both the local and remote TRACER 6420 units. T1x operational configuration parameters and testing functions are configured from this menu.




Figure 16. T1x Status/Configuration/Loopback

>T1X STATUS/CONFIGURATION/LOOPBACK > T1X INTERFACE ALARMS

Displays any active alarms on the T1 link (reported from both the local and remote TRACER 6420 units). These alarms include Red, Blue/AIS, Yellow, LOS, and bipolar violations (BPV). Table 1 briefly describes these alarms. See Section 8, *Troubleshooting Guide*, for more information on these alarms.

Table 1. T1 Interface Alarms

<b>RED</b>	Activates when no T1 signal is present from the connected T1 equipment. LOS is activated after receiving 192 consecutive zeros.
<b>BLUE/AIS</b>	Activates when an incoming remote alarm is received from a connected T1 device. An AIS signal is an unframed All One signal that replaces the normal traffic signal.
<b>YEL</b>	Activates when an incoming remote alarm is received from the T1 device indicating that a failure has occurred in the received direction.
<b>LOS</b>	Loss of sync occurs when the TRACER system cannot synchronize to the incoming T1 data stream.
<b>BPV</b>	Activates when the incoming T1 stream presents BPVs.

### > T1X STATUS/CONFIGURATION/LOOPBACK > ALARM REPORTING

Determines whether the TRACER 6420 unit will report active alarms. If set to **DISABLED**, no alarms will be displayed on this menu page. The **ALARM REPORTING** parameter is independently configured for the local and remote TRACER 6420 units. When set to **DISABLED**, the TRACER 6420 does not report active alarms via SNMP or the **CRAFT** port and the status LEDs are off. By default, alarm reporting is set to **ENABLED**.

### >T1X STATUS/CONFIGURATION/LOOPBACK > T1X LINE BUILD OUT

Configures the T1 for the appropriate line buildout, based on the distance to the T1 equipment. By default, the line buildout for the TRACER 6420 is **0 dB/133 FT.**

### > T1X STATUS/CONFIGURATION/LOOPBACK > SIGNALING

Configures the framing format for the T1 link for both the local and remote TRACER 6420 units. The TRACER 6420 transports T1 data across the link (as long as the T1 signal is properly timed). Configure the framing format (using the **SIGNALING** menu) to enable the TRACER 6420 to monitor incoming framing error events and indicate problems with the attached metallic service. The TRACER 6420 supports both extended superframe (**ESF**) and superframe (**D4**) framing formats. By default, the signaling method is set to **ESF**.

### > T1X STATUS/CONFIGURATION/LOOPBACK > LINE CODE

Sets the line coding for the T1 link. The TRACER 6420 supports bipolar eight-zero substitution (**B8ZS**) and alternate mark inversion (**AMI**) line coding. By default, the line code is set to **B8ZS**.

### > T1X STATUS/CONFIGURATION/LOOPBACK > LOOP/NORMAL STATE

Controls the loop status of the T1 link. Activates/deactivates loopback conditions for testing purposes.

### > T1X STATUS/CONFIGURATION/LOOPBACK > LOOP/NORMAL STATE > NORMAL

Defines the T1 link as normal data transport mode; there are no active loopbacks.

### > T1X STATUS/CONFIGURATION/LOOPBACK > LOOP/NORMAL STATE > LINK [LOCAL]


Activates a loopback at the local TRACER 6420 T1 framer towards the remote end of the wireless link (see Figure 17). Use the local **LINK** loopback to loop the data transmitted from the remote end of the link back across the radio link to the remote end of the link. This loopback tests the integrity of the radio link and all the associated digital and RF hardware.



Figure 17. T1 Local Link Loopback

**> T1X STATUS/CONFIGURATION/LOOPBACK > LOOP/NORMAL STATE > LINK [REMOTE]**


Activates a loopback at the remote TRACER 6420 T1 framer towards the local end of the wireless link (see Figure 18). Use the remote **LINK** loopback to loop the data transmitted from the local end of the link across the radio link to the local end of the link. This loopback tests the integrity of the radio link and all the associated digital and RF hardware.



**Figure 18. T1 Remote Link Loopback**

**> T1X STATUS/CONFIGURATION/LOOPBACK > LOOP/NORMAL STATE > LINE [LOCAL]**


Activates a loopback at the local TRACER 6420 T1 framer towards the connected T1 equipment (see Figure 19). Use the local **LINE** loopback to test data path integrity from the local TRACER 6420 unit to the connected T1 equipment.



**Figure 19. T1 Local Line Loopback**

**> T1X STATUS/CONFIGURATION/LOOPBACK > LOOP/NORMAL STATE > LINE [REMOTE]**

Activates a loopback at the remote TRACER 6420 T1 framer towards the connected T1 equipment at the remote end of the link (see Figure 20). Use the remote **LINE** loopback to test data path integrity from the remote TRACER 6420 unit to the T1 equipment connected at the remote end of the link.




**Figure 20. T1 Remote Line Loopback**

> T1X PERFORMANCE HISTORY

**NOTE** *The following menus for the T1x Performance History apply to all four available T1 interfaces (A through D).*

Figure 21 on page 64 shows the T1x Performance History menu page, which displays detailed error statistics for the T1 link (from both the local and remote TRACER 6420 units) in 15-minute and 24-hour increments.



**Figure 21. T1x Link Performance History**

T1 performance data is presented as Errored Seconds (ES) and Severely Errored Seconds (SES) on the T1 interface. The following events qualify as an ES—AIS, LOS or LOF Alarm Second, a single BPV, excessive zero event, or a single parity bit. An SES is caused by an AIS, LOS or LOF Alarm Second, excessive BPVs, or framed parity bit errors causing a line bit error rate (BER) of 10<sup>-6</sup>.

The error counts for the most recent 24 hours are recorded in 15-minute increments and displayed on the right side of the page. The left side of the page displays the 24-hour totals for the most recent 7 days.

**NOTE** *Press <n> to view the next 8 hours worth of 15-minute totals and <p> to view the previous 8 hours.*



## > MANAGEMENT/UTILITIES (MAIN SCREEN)

Figure 22 shows the TRACER 6420 Management/Utilities main screen, which contains access to the SNMP configuration, firmware upgrade options, and a ping utility for Ethernet testing.




Figure 22. Management/Utilities (Main Screen)

## > MANAGEMENT/SNMP PORT CONFIGURATION

Figure 23 shows the Management/SNMP Port Configuration menu page, which contains the configuration parameters for the 10/100BaseT **MGMT** Ethernet interface and SNMP configuration parameters (from both the local and remote TRACER 6420 units).




Figure 23. Management/SNMP Port Configuration

**> MANAGEMENT/SNMP PORT CONFIGURATION > IP ADDRESS**

Lists the address assigned to the 10/100BaseT **MGMT** Ethernet port. This address is in dotted decimal notation (four decimal numbers, each in the range of 0 to 255, separated by periods). This value is set to 192.168.0.1 by default. Obtain the correct IP address from your LAN administrator.

**> MANAGEMENT/SNMP PORT CONFIGURATION > NET MASK**

Defines which part of a destination IP address contains the network number. This address is in dotted decimal notation (four decimal numbers, each in the range of 0 to 255, separated by periods). This value is set to **255.255.255.0** by default. This part of the destination IP address is used along with the TRACER 6420 IP address to determine which nodes must be reached through the default IP gateway.

**> MANAGEMENT/SNMP PORT CONFIGURATION > DEFAULT GATEWAY**

Defines or changes the default gateway. You will need a default gateway if the LAN contains multiple segments. This address is in dotted decimal notation (four decimal numbers, each in the range of 0 to 255, separated by periods). This value is set to **192.168.0.254** by default. Contact your LAN administrator for the appropriate address.

**> MANAGEMENT/SNMP PORT CONFIGURATION > MAC ADDRESS**

(Read Only) Displays the system Ethernet Media Access Control (MAC) address.

**> MANAGEMENT/SNMP PORT CONFIGURATION > SNMP GET COMMUNITY**

Defines the community name for Get access (to poll the TRACER 6420 for status information). This value must match the Get name defined on the network management stations (NMS). Get access is read only access. The default name is **public**.

**> MANAGEMENT/SNMP PORT CONFIGURATION > SNMP PUT COMMUNITY**

Defines the community name for Set access (to change TRACER 6420 configuration parameters through SNMP). This value must match the Get or Set name defined on the NMS. The default name is **private**.

**> MANAGEMENT/SNMP PORT CONFIGURATION > SNMP TRAP COMMUNITY**

Defines the community name for trap destinations. This name must match the community name defined on the NMS. The default name is **SNMP\_trap**.

**> MANAGEMENT/SNMP PORT CONFIGURATION > SNMP TRAP HOST #0 - #4**

Identifies the IP address in dotted decimal notation of the NMS for the TRACER 6420 to send SNMP traps to. Up to five trap destinations can be entered.

## > PING UTILITY

Figure 24 shows the Ping Utility menu page, which contains the parameters for performing a ping test out of the 10/100BaseT **MGMT** Ethernet interface.




Figure 24. Ping Utility

### > PING UTILITY > PING ADDRESS

Specifies the IP address to ping (in dotted decimal notation).

### > PING UTILITY > NUMBER OF PACKETS

Specifies the number of ping packets to send to the IP address specified in the **PING ADDRESS** field. The default value is 4, and the maximum value is 99.

### > PING UTILITY > PACKET SIZE (BYTES)

Specifies the size (in bytes) of the data portion of the ping request. The default value is 64 bytes, and the maximum size is 1024 bytes.

### > PING UTILITY > TIMEOUT (MS)

Specifies the time (in milliseconds) to wait for a ping reply before timing out. The default timeout is 3 seconds (3000 milliseconds), and the maximum value is 10 seconds (10000 milliseconds).

### > PING UTILITY > PING COMMAND

Use this field to manually start (**START**) or stop (**ABORT**) a ping request, reset the ping statistics (**RESET STATS**), or return the ping configuration parameters to their default values (**DEFAULT VALUES**).

**> PING UTILITY > DELAY**

(Read Only) Displays the round trip time (in milliseconds) of the ping request/reply of the current set of pings and provides the following information:

<b>MINIMUM</b>	The minimum round trip time of the ping request/reply for the current set of pings.
<b>MAXIMUM</b>	The maximum round trip time of the ping request/reply for the current set of pings.
<b>AVERAGE</b>	The average round trip time of the ping request/reply for the current set of pings.

**>PING UTILITY > PACKETS**

(Read Only) Displays the packet statistics for the ping request/reply of the current set of pings and provides the following information:

<b>Tx</b>	The number of ping requests transmitted.
<b>Rx</b>	The number of ping replies received.
<b>LOST</b>	The number of ping requests that did not receive replies.

**> FIRMWARE UPGRADE UTILITY**

Figure 25 shows the Firmware Upgrade Utility menu page, which contains the parameters for performing a firmware upgrade for the local and remote systems.




Figure 25. Firmware Upgrade Utility

### > FIRMWARE UPGRADE UTILITY > FILE XFER METHOD

Lists the available transfer methods for updating the TRACER 6420 system. The following selections are available:

<b>TFTP LOCAL MGMT PORT</b>	Upgrade the firmware using a trivial file transfer protocol (TFTP) server that is located on the same Ethernet network as the local system. TFTP transfers files by specifying an appropriate server address and filename.
<b>TFTP REMOTE MGMT PORT</b>	Upgrade the firmware using a TFTP server that is located on the same Ethernet network as the remote system. TFTP transfers files by specifying an appropriate server address and filename.
<b>XMODEM</b>	Upgrade the firmware using XMODEM software on a terminal or PC that is connected to the <b>CRAFT</b> interface of the local system.

### > FIRMWARE UPGRADE UTILITY > TFTP SERVER

*(Available for TFTP transfers only.)* Configures the IP address of the TFTP server on which the update file resides. The TRACER 6420 uses this field to locate the network TFTP server and request the file transfer.

### > FIRMWARE UPGRADE UTILITY > TFTP FILENAME

*(Available for TFTP transfers only.)* Specifies the name of the update file to retrieve from the TFTP server. Enter the full filename for the file. Some TFTP servers require the full path name for any file not located in the default directory. Refer to the TFTP software documentation for more details.

### > FIRMWARE UPGRADE UTILITY > UPGRADE DESTINATION

Specify the unit to upgrade. The following options are available:

<b>LOCAL IDU</b>	Upgrade the local system.
<b>REMOTE IDU</b>	Upgrade the remote system. When upgrading the remote system, the upgrade file is first loaded into the local system and then transferred over the wireless link to the remote system. The actual upgrade process is not started on the remote system until the entire upgrade file has been received.

### > FIRMWARE UPGRADE UTILITY > COMMAND

Use this command to start (**START**) or stop (**ABORT**) a firmware upgrade. For XMODEM updates, cancel the process via the terminal emulation software (consult your documentation for the information on how to do this). For TFTP updates, you can cancel the process by selecting **ABORT** from this field.

### > FIRMWARE UPGRADE UTILITY > LOCAL CURRENT STATUS

*(Available for TFTP updates only.)* Indicates progress or problems encountered during the current upgrade of the local unit. The field displays **IDLE** if no update is in progress or when the update is successfully completed. At the end of a successful update, the contents of this field are copied into the Local Previous Status. For a detailed listing of these messages, please refer to DLP-5, *Updating the Firmware Using TFTP*.

**> FIRMWARE UPGRADE UTILITY > LOCAL PREVIOUS STATUS**

*(Available for TFTP updates only.)* Displays the status of the previous update of the local unit. Following a successful update, this field reads **UPGRADE FINISHED SUCCESSFULLY**. If an update was unsuccessful, the appropriate error message displays. Refer to DLP-5, *Updating the Firmware Using TFTP*, for more details on available error messages.

**> FIRMWARE UPGRADE UTILITY > REMOTE CURRENT STATUS**

*(Available for TFTP updates only.)* Indicates progress or problems encountered during the current upgrade of the remote unit. The field displays **IDLE** if no update is in progress or when the update is successfully completed. At the end of a successful update, the contents of this field are copied into the Local Previous Status. For a detailed listing of these messages, please refer to DLP-5, *Updating the Firmware Using TFTP*.

**> FIRMWARE UPGRADE UTILITY > REMOTE PREVIOUS STATUS**

*(Available for TFTP updates only.)* Displays the status of the previous update of the remote unit. Following a successful update, this field reads **UPGRADE FINISHED SUCCESSFULLY**. If an update was unsuccessful, the appropriate error message displays. Refer to DLP-5, *Updating the Firmware Using TFTP*, for more details on available error messages.

# DETAIL LEVEL PROCEDURES

- DLP-1 Connecting a VT100 Terminal or PC to the CRAFT Port. . . . . 73
- DLP-2 Logging in to the TRACER 6420 . . . . . 75
- DLP-3 Setting IP Parameters for the TRACER 6420 . . . . . 77
- DLP-4 Verifying Communications Over an IP LAN . . . . . 81
- DLP-5 Updating the Firmware Using TFTP. . . . . 85
- DLP-6 Updating the Firmware Using XMODEM . . . . . 89





## DLP-1 Connecting a VT100 Terminal or PC to the CRAFT Port

### **Introduction**

TRACER 6420 management and provisioning are facilitated by a series of intuitive menus that are accessible on a computer screen. Connecting either a VT100 terminal or a PC with terminal emulation software to the **CRAFT** interface (DB-9) on the front of the unit allows access to the menus and management features of the TRACER 6420. This section specifies how to connect the VT100 terminal or PC to the TRACER 6420.

### **Prerequisite Procedures**

The TRACER 6420 must be powered up for terminal communication to function.

### **Tools and Materials Required**

- A VT100 compatible terminal or PC with terminal emulation software
- An appropriate cable to connect the TRACER 6420 to a terminal

#### **WARNING**

*To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.*



#### **CAUTION**

*Electronic equipment can be damaged by static electrical discharge. Before handling it, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place equipment in antistatic packing material when transporting or storing. When working on equipment, always place it on an approved antistatic mat that is electrically grounded.*

---

**Perform one of the following steps:**

---

## 1. Connecting a VT100 terminal to the TRACER 6420:

- Set the parameters of the VT100 terminal or PC to:
  - 9600 baud rate
  - 8 data bits
  - No parity
  - 1 stop bit
  - No flow control
- If the terminal has a parallel setting, disable this setting and use the serial port.

**Using the CRAFT Port**

- Plug the DB-9 male end of the data cable into the TRACER 6420 **CRAFT** port on the front of the unit. Make the connection to the VT100 terminal as appropriate for your equipment.

## 2. Connecting a PC emulating a VT100 terminal to the TRACER 6420:

Most PCs or laptops can run communications software that emulates a VT100 terminal. Examples include Windows programs such as Terminal® or Hyperterminal®. However, there are many other adequate, commercially available software packages which will allow your PC or laptop to emulate a VT100 terminal.

- Set the parameters of the communications software to:
  - 9600 baud rate
  - 8 data bits
  - No parity
  - 1 stop bit
  - No flow control
- Set the PC for direct connect on the appropriate com port (instead of dial up connection).

**Using the CRAFT Port**

- Plug the DB-9 male end of the data cable into the TRACER 6420 **CRAFT** port on the front of the unit. Make connection to the PC or laptop as appropriate for your equipment.

You are now ready to log in to the TRACER 6420, as described in *DLP-2, Logging in to the TRACER 6420*.

## DLP-2 Logging in to the TRACER 6420

### **Introduction**

Once you are connected to the TRACER 6420, you must log in to the system to gain access to the management and provisioning functions. This DLP assumes you are connected to the TRACER 6420 and provides specific steps for logging into the system.

### **Prerequisite Procedures**

Complete DLP-1, *Connecting a VT100 Terminal or PC to the CRAFT Port*.

#### **WARNING**

*To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.*



*Electronic equipment can be damaged by static electrical discharge. Before handling it, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place equipment in antistatic packing material when transporting or storing. When working on equipment, always place it on an approved antistatic mat that is electrically grounded.*




*After the IP parameters have been provisioned (see DLP-3, *Setting IP Parameters for the TRACER 6420*), you can also log in via Telnet.*

---


**Perform the steps below in the order listed.**


---

1. After connecting to the system, press any key to display the **LOGIN** screen shown here. The flashing cursor at the **LOGIN** field indicates that a password must be entered.



2. Enter the password for the TRACER 6420 at the **LOGIN** field. The manufacturer's default password for the TRACER 6420 system is "**password**" in lowercase letters.
3. Upon entering the correct password, the TRACER 6420 **SYSTEM STATUS** page is displayed as shown below.



4. You are now logged in to the TRACER 6420 menu system.

## DLP-3 Setting IP Parameters for the TRACER 6420

### **Introduction**

If the TRACER 6420 is connected to an IP network for Telnet, TFTP, or SNMP management, several IP parameters must be set for the unit to communicate with the network. These parameters are described in this DLP along with the procedures for setting them.



*Please see your Network Administrator for the proper assignment of the following parameters: **IP ADDRESS**, **SUBNET MASK**, and **DEFAULT GATEWAY**.*

### **Prerequisite Procedures**

This procedure assumes that the TRACER 6420 unit is connected to an IP network and is powered up.



*To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.*




*Electronic equipment can be damaged by static electrical discharge. Before handling it, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place equipment in antistatic packing material when transporting or storing. When working on equipment, always place it on an approved antistatic mat that is electrically grounded.*

---


**Perform the steps below in the order listed.**

---


1. Log in to the system with maximum rights (details are in DLP-2).
2. Press **M** to activate the Main menu page. From the Main menu page, press **7** to select **MANAGEMENT/UTILITIES**.



3. From the **MANAGEMENT/UTILITIES** page, select the **MANAGEMENT/SNMP PORT CONFIGURATION** option and press <Enter>.



- From the Management/SNMP Configuration menu page, select the **IP ADDRESS** field and press <Enter>. Type the IP address provided by your network manager and press <Enter> to accept the change. Repeat the process for the **SUBNET MASK** and **DEFAULT GATEWAY** options.



The TRACER 6420 is now available for Telnet access. Complete the steps outlined in DLP-4, *Verifying Communications Over an IP LAN*.





## DLP-4 Verifying Communications Over an IP LAN

### **Introduction**

When the 10/100BaseT **MGMT** port is connected to a local area network (LAN), test steps must be performed on the TRACER 6420 to ensure that the unit is communicating properly over the network. This procedure outlines those steps.

### **Prerequisite Procedures**

Before beginning this procedure, the unit should be physically connected to the LAN and the provisioning tasks detailed in DLP-3, *Setting IP Parameters for the TRACER 6420*, should be complete.

### **Tools and Materials Required**

- Access to a PC or other computer connected to the LAN

#### **WARNING**

*To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.*



*Electronic equipment can be damaged by static electrical discharge. Before handling it, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place equipment in antistatic packing material when transporting or storing. When working on equipment, always place it on an approved antistatic mat that is electrically grounded.*

---

**Perform the following steps in the order listed.**

---

## 1. Verify the TRACER 6420 IP address.

If you do not already have the IP Address for the TRACER 6420, obtain it from the network administrator or manually check for the address on the **MANAGEMENT/SNMP CONFIGURATION** page. (Access the **MANAGEMENT/SNMP CONFIGURATION** page by pressing **7** and then **1** from the Main menu page.)

## 2. Ping the TRACER 6420 unit from a remote computer on the network.

Using a remote computer system connected to the LAN, perform an ICMP Ping on the IP Address of the TRACER 6420. Verify that the unit responds properly. If the TRACER 6420 fails to respond, try the following:

- Verify that the proper IP Address, Subnet Mask, and Default Gateway are provisioned in the unit (see DLP-3, *Setting IP Parameters for the TRACER 6420*, for details).
- Verify that the TRACER 6420 is properly cabled into the LAN and that the Ethernet cable is properly seated in the RJ-45 jack on the rear of the unit.
- If the TRACER 6420 is connected to a hub or other network device that provides a carrier sense light for each port, verify that the carrier sense light for the port to which the TRACER 6420 is connected is lit. If this light is not lit, check the cabling between the hub and the shelf. The connection may also be verified using the activity LED located on the rear of the unit (part of the 10/100BaseT **MGMT** RJ-45 connector).
- Verify the IP Address, Subnet Mask, and Default Gateway on the remote computer system.
- If none of these steps are successful, contact the LAN Administrator for assistance.



*Refer to the computer system's documentation if you are unsure how to perform a Ping command. Most computers running a networked version of Microsoft Windows™ or UNIX allow a Ping to be performed by typing **ping <IP Address>** at a command line prompt. Typically, the Ping program will respond by indicating that the remote IP Address has responded in a certain amount of time or that no response was received.*



*Some versions of Ping will continue running until you explicitly tell them to stop. If the program does not terminate on its own, type **<CTRL+C>** to stop the program.*

### 3. Telnet to the TRACER 6420.

From the same computer used in the previous step, Telnet to the TRACER 6420 and verify that the Telnet session is properly opened. Once the Telnet session is established, press <CTRL+Z> to logout of the session and return to the Login screen. Pressing <CTRL + Z> again closes the Telnet session.



*Refer to the documentation of the computer system if you are unsure how to initiate a Telnet session. Most computers running a networked version of Microsoft Windows™ or UNIX initiate a Telnet session by typing **telnet <IP Address>** at a command line prompt. The Windows XP HyperTerminal program also provides a Telnet client. Telnet is a utility common on many local area networks that allows remote access to another computer or piece of equipment.*



## DLP-5 Updating the Firmware Using TFTP

### **Introduction**

The TRACER 6420 supports firmware updates using TFTP or XMODEM. Use the 10/100BaseT **MGMT** Ethernet port and TFTP from a network server or XMODEM (if your Telnet client supports file transfers), or use XMODEM and the **CRAFT** interface. This DLP provides the steps for a successful firmware upgrade using the 10/100 BaseT **MGMT** Ethernet port and a TFTP server. (See DLP-6, *Updating the Firmware Using XMODEM*, for instructions on using XMODEM.)

### **Tools and Materials Required**

- A PC with Telnet client software
- A TFTP server accessible on the network

#### **WARNING**

*To prevent electrical shock, do not install equipment in a wet location or during a lightning storm.*



#### **CAUTION**

*Electronic equipment can be damaged by static electrical discharge. Before handling it, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place equipment in antistatic packing material when transporting or storing. When working on equipment, always place it on an approved antistatic mat that is electrically grounded.*

---

**Perform the following steps in the order listed.**


---

1. Connect to the TRACER 6420 using the 10/100BaseT **MGMT** interface.  
If you are not already connected to the unit's 10/100BaseT **MGMT** port using Telnet client software, use the procedure in DLP-3, *Setting IP Parameters for the TRACER 6420*, to connect to the unit.
2. Press **M** to go to the Main menu page.
3. Select the **MANAGEMENT/UTILITIES** menu and press <Enter>.
4. Select the **FIRMWARE UPGRADE UTILITY** menu and press <Enter>.
5. Go to the **FILE XFER METHOD** menu and select **TFTP**. The TRACER 6420 can use a TFTP server connected to the same Ethernet network as the local unit or a TFTP server connected to the same Ethernet network as the remote unit. Make the appropriate selection for your setup (choices are **TFTP-LOCAL MGMT PORT** or **TFTP-REMOTE MGMT PORT**).
6. Go to the **TFTP SERVER** field and enter the IP address of the network TFTP server.
7. Go to the **TFTP FILENAME** field and enter the filename of the firmware. TRACER 6420 firmware files have a .bin extension. When specifying the filename, include the full path if the firmware file is not located in the TFTP default location. For example, to use a firmware file in the c:\firmware folder on your local machine, enter **c:\firmware\myfirmware.bin** into the **TFTP FILENAME** field.
8. Select the **UPGRADE DESTINATION**. Using TFTP provides the capability to upgrade both sections of the local and remote units. Valid choices are **LOCAL IDU** and **REMOTE IDU**.

View **CURRENT UPDATE STATUS** to verify the progress of the current firmware update or to identify any errors encountered during the download.

During the TFTP upload, the following status messages display in **CURRENT UPDATE STATUS** to indicate the progress of the upload:

<b>IDLE</b>	No active firmware upgrade.
<b>IDU RESET</b>	Indicates the firmware file transfer to the IDU is complete and the system is rebooting to load the new firmware.
<b>UPGRADE ABORTED</b>	Indicates the firmware upgrade was manually aborted by selecting <b>ABORT</b> from the <b>COMMAND</b> field.
<b>CONTACTING TFTP SERVER</b>	Indicates communication with the TFTP network server is trying to be established with the specified server address in the <b>TFTP SERVER IP ADDRESS</b> field.
<b>REQUESTING TFTP OF FILENAME</b>	Indicates the TRACER 6420 is requesting TFTP access to the given update filename and path. Please verify appropriate user rights are selected for the specified path.
<b>TFTP TRANSFER IN PROGRESS</b>	Indicates communication with the TFTP network server has been established and the update file is being transferred between the TRACER 6420 and the TFTP network server.
<b>UPGRADE IMAGE IS VALID</b>	Indicates that the system image was verified as a valid image for the specified update. Before the firmware upgrade begins, the TRACER 6420 verifies that the image is valid. If it is not valid for the system, <b>UPGRADE IMAGE IS INVALID</b> displays.

<b>UPGRADE IMAGE IS INVALID</b>	Indicates that the system image was not verified as a valid image for the specified update. Before the firmware upgrade begins, the TRACER 6420 verifies that the image is valid. If it is not valid for the system, <b>UPGRADE IMAGE IS INVALID</b> displays.
<b>WAITING FOR SC TRANSFER TO BEGIN</b>	Indicates that the local system is waiting to transfer the firmware upgrade information to the remote system over the service channel. Service channel communications over the RF link allow a user connected to a local system to upgrade the firmware of a remote system. Before the remote system begins the firmware upgrade process, a complete copy of the new firmware image must be received and stored in the remote system. This is done automatically when the remote system is chosen from the <b>UPGRADE DESTINATION</b> field.
<b>RECEIVING SC TRANSFER</b>	Indicates that the system is receiving the firmware upgrade information from the remote system over the service channel. Service channel communications over the RF link allow a user connected to a local system to upgrade the firmware of a remote system. Before the remote system begins the firmware upgrade process, a complete copy of the new firmware image must be received and stored in the remote system. This is done automatically when the remote system is chosen from the <b>UPGRADE DESTINATION</b> field.
<b>READY TO BEGIN SENDING SC TRANSFER</b>	Indicates that the local system is ready to transfer the firmware upgrade information to the remote system over the service channel. Service channel communications over the RF link allow a user connected to a local system to upgrade the firmware of a remote system. Before the remote system begins the firmware upgrade process, a complete copy of the new firmware image must be received and stored in the remote system. This is done automatically when the remote system is chosen from the <b>UPGRADE DESTINATION</b> field.
<b>SENDING SC TRANSFER</b>	Indicates that the local system is sending the firmware upgrade information to the remote system over the service channel. Service channel communications over the RF link allow a user connected to a local system to upgrade the firmware of a remote system. Before the remote system begins the firmware upgrade process, a complete copy of the new firmware image must be received and stored in the remote system. This is done automatically when the remote system is chosen from the <b>UPGRADE DESTINATION</b> field.
<b>VERIFYING FLASH IMAGE</b>	Indicates that the system flash image is being verified as a valid image for the specified update. Before the new firmware is loaded into the local flash, the TRACER 6420 verifies that the flash image is valid for the new firmware. If it is not valid for the system, the firmware upgrade fails.
<b>ERASING FLASH</b>	Indicates that the system flash is being erased so the new firmware image can be loaded into the local flash. Before the new firmware is loaded into the local flash, the TRACER 6420 verifies that the flash image is valid for the new firmware. If it is not valid for the system, the firmware upgrade fails.
<b>PROGRAMMING FLASH</b>	Indicates that the new firmware image is being loaded into the local flash. Before the new firmware is loaded into the local flash, the TRACER 6420 verifies that the flash image is valid for the new firmware. If it is not valid for the system, the firmware upgrade fails.

---

<b>REQUIRED COMMUNICATIONS LINK IS DOWN</b>	Indicates that a remote system firmware upgrade cannot be completed due to a problem with either the RF link or the service channel. Before a firmware upgrade begins, the system verifies that communication between all required parts is operational. If this check fails, the firmware upgrade fails.
<b>UPGRADE FAILED</b>	Indicates that the firmware upgrade was unsuccessful.
<b>UPGRADE FINISHED SUCCESSFULLY</b>	Indicates that the firmware upgrade completed successfully and the new firmware should be loaded and running.

9. When the update has successfully completed, **IDLE** displays in the **CURRENT UPDATE STATUS** field and **UPGRADE FINISHED SUCCESSFULLY** displays in the **PREVIOUS UPDATE STATUS** field.

The TRACER 6420 will restart immediately and resume operation. During reset and initialization, the RF link between the units will not be operational.



## DLP-6 Updating the Firmware Using XMODEM

### **Introduction**

The TRACER 6420 supports firmware updates of the local and remote systems using TFTP or XMODEM. Use the 10/100BaseT **MGMT** port and TFTP from a network server or XMODEM (if your Telnet client supports file transfers), or use XMODEM and the **CRAFT** interface. This procedure outlines the steps for a successful firmware upgrade using the **CRAFT** interface and XMODEM software. The same XMODEM steps apply for file transfers through your Telnet client (refer to your Telnet client documentation for more details on file transfer specifics). (See DLP-5, *Updating the Firmware Using TFTP*, for instructions on using TFTP.)

### **Tools and Materials Required**

- VT100 terminal or PC with VT100 terminal emulation software
- XMODEM software

#### **WARNING**

*To prevent electrical shock, do not install equipment in a wet location or during a lightning storm*



*Electronic equipment can be damaged by static electrical discharge. Before handling it, put on an antistatic discharge wrist strap to prevent damage to electronic components. Place equipment in antistatic packing material when transporting or storing. When working on equipment, always place it on an approved antistatic mat that is electrically grounded.*

---

**Perform the following steps in the order listed.**

---

1. Connect to the TRACER 6420 using the front panel DB-9 **CRAFT** interface.  
If you are not already connected to the unit's **CRAFT** interface (either with a VT100 compatible terminal or with a PC running VT100 emulation software), follow the procedure in DLP-1, *Connecting a VT100 Terminal or PC to the CRAFT Port*. Connecting to the **CRAFT** interface limits the upgrade procedure to XMODEM only.
2. Log in to the unit (see DLP-2, *Logging in to the TRACER 6420* for details).
3. Press **M** to go to the Main menu page.
4. Select the **MANAGEMENT/UTILITIES** menu and press <Enter>.
5. Select the **FIRMWARE UPGRADE UTILITY** menu and press <Enter>.
6. Go to the **FILE XFER METHOD** menu and select **XMODEM**.
7. Select the **UPGRADE DESTINATION**. (Valid selections for XMODEM are **LOCAL IDU** and **LOCAL ODU**).
8. View **CURRENT UPDATE STATUS** to verify the progress of the current firmware update or to identify any errors encountered during the download.
9. Select **START** from the **COMMAND** menu to start the update.  
When the TRACER 6420 is ready to receive the XMODEM upload, the menu screen will clear and display **XMODEM waiting for start...<Ctrl-X> twice to Cancel**. If this does not appear, please review the steps above for possible configuration errors.
10. From the terminal emulation software, begin the XMODEM upload by using the appropriate command sequence. This may take several minutes.  
If necessary, refer to the terminal emulation software documentation for help. Also, when specifying the filename, ensure that the file transferred is the one provided by ADTRAN. Otherwise, the update will not complete successfully.  
Because XMODEM data is being transferred inband through the menu interface, the VT100 menus of the TRACER 6420 will be inoperable from the **CRAFT** interface. You can cancel the update at any time within the terminal emulation software. (Please consult the documentation provided by the terminal emulation software to determine how to do this).
11. When the update has successfully completed, **IDLE** displays in the **CURRENT UPDATE STATUS** field and **UPGRADE FINISHED SUCCESSFULLY** displays in the **PREVIOUS UPDATE STATUS** field.  
The TRACER 6420 will restart immediately and resume operation. During reset and initialization, the RF link between the units will not be operational.  
Alternatively, if the unit is part of a management cluster connected to the local network, you may use a PC connected to the network to Telnet into the unit. By using the 10/100BaseT **MGMT** port, the TRACER 6420 may be quickly upgraded using TFTP, provided there is a TFTP server on the local network. (See DLP-5, *Updating the Firmware Using TFTP* for more details.)

# MIBS

*Provides a listing of SNMP Management Information Bases (MIBs) supported by the TRACER 6420. Traps supported for each MIB are also listed.*

## CONTENTS

<b>MIBs Supported by the TRACER 6420</b> .....	<b>92</b>
<b>MIB Compilation Order</b> .....	<b>92</b>
<b>Traps Supported by the TRACER 6420</b> .....	<b>93</b>
<b>MIB Variables Supported by the TRACER 6420</b> .....	<b>95</b>

## TABLES

Table 1.	MIBs Supported by the TRACER 6420 .....	92
Table 2.	MIB Compilation Order .....	92
Table 3.	Traps Supported by the TRACER 6420 .....	93
Table 4.	MIB Variables for ad.mi2 .....	95
Table 5.	MIB Variables for ads1.mib .....	96
Table 6.	MIB Variables for TRACER.mib .....	97

## 1. MIBS SUPPORTED BY THE TRACER 6420

Table 1 lists the MIBs supported by the TRACER 6420.

**Table 1. MIBs Supported by the TRACER 6420**

<code>rfc2495.mib</code>	Standard – DS1 and E1 Interface Types
<code>rfc2863.mib</code>	IF MIB – updated MIB II
<code>rfc3418.mib</code>	SNMPv2 MIB
<code>rfc3595.mib</code>	PerfHist-TC-MIB needed for RFC 2495
<code>rfc3635.mib</code>	EtherLike MIB
<code>adtran.mib</code>	ADTRAN product MIB needed to locate the ADTRAN specific MIBs on the MIB node tree
<code>ianaif.mib</code>	IF MIB needed for RFC 2495
<code>ads1.mib</code>	ADTRAN DS1 MIB
<code>tracer.mib</code>	TRACER Modular MIB



*SNMPv2-SMI, SNMPv2-TC, and SNMPv2-CONF are not compiled, but the paths to these files are required by your MIB compiler during setup.*

## 2. MIB COMPILATION ORDER

MIBs are compiled in the order shown in Table 2.

**Table 2. MIB Compilation Order**

```
rfc3418.mib
ianaif.mib
rfc2863.mib
rfc3593.mib
rfc3635.mib
rfc2495.mib
adtran.mib
ads1.mib
tracer.mib
```

### 3. TRAPS SUPPORTED BY THE TRACER 6420

The TRACER 6420 supports the traps described in Table 3.

**Table 3. Traps Supported by the TRACER 6420**

MIB	Trap	This trap indicates that...
TRACER.mib	adTRACERColdStart	the unit has powered up.
	adTRACERYellow	a change in the YELLOW alarm state has occurred and the YELLOW alarm is now active.
	adTRACER AIS	a change in the Alarm Indication Signal (AIS) has occurred and the AIS alarm is active.
	adTRACERRedAlarm	a change in the RED alarm state has occurred and the RED alarm is now active.
	adTRACERLOS	a change in the Loss of Signal (LOS) state has occurred and the LOS alarm is active.
	adTRACERBPV	a change in the BiPolar Violation (BPV) state has occurred and the BPV alarm is active.
	adTRACERRA	a change in the Frame RA (Remote Alarm) state has occurred and the RA alarm is active.
	adTRACEROOF	a change in the Out Of Frame (OOF) state has occurred and the OOF alarm is active.
	adTRACERCV	a change in the Code Violation (CV) state has occurred and the CV alarm is active.
	adTRACERCRC	a change in the Cyclic Redundancy Check (CRC) state has occurred and the CRC alarm is active.
	adTRACERmfLOF	a change in the Loss of Multiframe (LOMF) state has occurred and the LOMF alarm is active.
	adTRACERmfLOS	a change in the Multiframe Loss of Signal (LOS) state has occurred and the Multiframe LOS alarm is active.
	adTRACERmfAIS	a change in the Multiframe Alarm Indication Signal (AIS) state has occurred and the Multiframe AIS alarm is active.
	adTRACERmfRA	a change in the Multiframe Remote Alarm (RA) has occurred and the Multiframe RA alarm is active.
	adTRACERlineLoopback	a change in the line loopback state has occurred and the line loopback is active.
	adTRACERlinkLoopback	a change in the link loopback state has occurred and the link loopback is active.
	adTRACERYellowOff	a change in the YELLOW alarm state has occurred and the YELLOW alarm is now inactive.
	adTRACER AISoff	a change in the Alarm Indication Signal (AIS) has occurred and the AIS alarm is inactive.
	adTRACERRedAlarmOff	a change in the RED alarm state has occurred and the RED alarm is now inactive.
	adTRACERLOSoff	a change in the Loss of Signal (LOS) state has occurred and the LOS alarm is inactive.

**Table 3. Traps Supported by the TRACER 6420 (Continued)**

<b>MIB</b>	<b>Trap</b>	<b>This trap indicates that...</b>
TRACER.mib	adTRACERBPVoff	a change in the BiPolar Violation (BPV) state has occurred and the BPV alarm is inactive.
	adTRACERRAoff	a change in the Frame RA (Remote Alarm) state has occurred and the RA alarm is inactive.
	adTRACEROOfoff	a change in the Out Of Frame (OOF) state has occurred and the OOF alarm is inactive.
	adTRACERCVoff	a change in the Code Violation (CV) state has occurred and the CV alarm is inactive.
	adTRACERCRCoff	a change in the Cyclic Redundancy Check (CRC) state has occurred and the CRC alarm is inactive.
	adTRACERmflOfoff	a change in the Loss of Multiframe (LOMF) state has occurred and the LOMF alarm is inactive.
	adTRACERmflOSoff	a change in the Multiframe Loss of Signal (LOS) state has occurred and the Multiframe LOS alarm is inactive.
	adTRACERmFAISoff	a change in the Multiframe Alarm Indication Signal (AIS) state has occurred and the Multiframe AIS alarm is inactive.
	adTRACERmFRAoff	a change in the Multiframe Remote Alarm (RA) has occurred and the Multiframe RA alarm is inactive.
	adTRACERlineLoopbackOff	a change in the line loopback state has occurred and the line loopback is inactive.
	adTRACERlinkLoopbackOff	a change in the link loopback state has occurred and the link loopback is inactive.
	adTRACERLinkDown	the RF link is down.
	adTRACERLinkUp	the RF link is up.
	adTRACERRFCLinkDown	the RFC link is down between the Indoor Unit (IDU) and Outdoor Unit (ODU).
	adTRACERRFCLinkUp	the RFC link is up between the IDU and ODU.
	adTRACERRxLow	the receive level is within 10 dB of sensitivity and the RF Low alarm is active.
	adTRACERRxLevel	a change in receive level has occurred and the receive level is within normal range.
	adTRACERcurrThrsESon	the threshold for current Errored Seconds (ES) has been exceeded.
	adTRACERcurrThrsESoff	the threshold for current ES has not been exceeded.
	adTRACERcurrThrsSESon	the threshold for current Severely Errored Seconds (SES) has been exceeded.
adTRACERcurrThrsSESoff	the threshold for current SES has not been exceeded.	

## 4. MIB VARIABLES SUPPORTED BY THE TRACER 6420

**Table 4. MIB Variables for ad.mi2**

ad

adProducts

adProductInfo

adProdName DisplayString RO

adProdPartNumber DisplayString RO

adProdCLEIcode DisplayString RO

adProdSerialNumber DisplayString RO

adProdRevision DisplayString RO

adProdSwVersion DisplayString RO

adProdPhysAddress PhysAddress RO

adProdProductID

adProdTransType DisplayString RO

adMgmt

adAdmin

adPerform

adShared

adIdentity

adIdentityShared

adAgentCapModule

adAgentCapProduct

adAgentCapShared

adConformance

adCompliances

**Table 5. MIB Variables for ads1.mib**

adDS1AlarmTable			
adDS1AlarmEntry			
adDS1AlarmIndex	Integer		RO
adDS1AlarmEnable	Integer		RW
adDS1LineEvent	Integer		RO
adDS1LineArm	Integer		RW
adDS1AlertTable			
adDS1AlertEntry			
adDS1AlertIndex	Integer		RO
adDS1AlertEnable	Integer		RW
adDS1CurrentAlert	Integer		RO
adDS1TotalAlert	Integer		RO
adDS1FarCurrentAlert	Integer		RO
adDS1FarTotalAlert	Integer		RO
adDS1CurrentArm	Integer		RW
adDS1TotalArm	Integer		RW
adDS1FarCurrentArm	Integer		RW
adDS1FarTotalArm	Integer		RW
adDS1CurrentThreshold			
adDS1CurrentThrsES	Integer		RW
adDS1CurrentThrsSES	Integer		RW
adDS1CurrentThrsSEFS	Integer		RW
adDS1CurrentThrsUAS	Integer		RW
adDS1CurrentThrsCSS	Integer		RW
adDS1CurrentThrsPCVsf	Integer		RW
adDS1CurrentThrsPCVesf	Integer		RW
adDS1CurrentThrsLES	Integer		RW
adDS1CurrentThrsLCV	Integer		RW
adDS1TotalThreshold			
adDS1TotalThrsES	Integer		RW
adDS1TotalThrsSES	Integer		RW
adDS1TotalThrsSEFS	Integer		RW
adDS1TotalThrsUAS	Integer		RW
adDS1TotalThrsCSS	Integer		RW
adDS1TotalThrsPCVsf	Integer		RW
adDS1TotalThrsPCVesf	Integer		RW
adDS1TotalThrsLES	Integer		RW
adDS1TotalThrsLCV	Integer		RW



**Table 6. MIB Variables for TRACER.mib**

adTRACER6420mg			
adTRACER6420status			
adTRACERRFlinkState	DisplayString	RO	
adTRACERRFClinkState	DisplayString	RO	
adTRACERrfLow	DisplayString	RO	
adTRACERRXquality	DisplayString	RO	
adTRACERRXLevel	DisplayString	RO	
adTRACERFrequencyPlan	DisplayString	RO	
adTRACERLEDStatus	DisplayString	RO	
adTRACERSlot1	DisplayString	RO	
adTRACERSlot2	DisplayString	RO	
adTRACER6420cfg			
adTRACERBaudRate	Integer	RW	
adTRACERBandPlan	Integer	RW	
adTRACERactiveChannels	Integer	RW	
adTRACERchannelSelect			
adTRACERdsx1ChannelSelectTable			
adTRACERdsx1ChannelSelectEntry			
AdTRACERdsx1ChannelSelectEntry			
adTRACERdsx1ChannelSelectIdx	Integer	RO	
adTRACERdsx1ChannelSelection	Integer	RW	
adTRACERswitchChannelSelectTable			
adTRACERswitchChannelSelectEntry			
AdTRACERswitchChannelSelectEntry			
adTRACERswitchChannelSelectIdx	Integer	RO	
adTRACERswitchChannelSelection	Integer	RW	
adTRACERTxPower	DisplayString	RW	
adTRACERalarmTable			
AdTRACERAlarmEntry			
adTRACERalarmEntry			
adTRACERalarmNumber	Integer	RO	
adTRACERalarmReporting	Integer	RW	
adTRACERClearHistory	Integer	RW	
adTRACERrfTrapEnable	Integer	RW	
adTRACERswitchModuleCfg			
adTRACERswitchPortCfgTable			
adTRACERswitchPortCfgEntry			
AdTRACERswitchPortCfgEntry			
adTRACERswitchPortIdx	Integer	RO	
adTRACERswitchPortEnable	Integer	RO	
adTRACERswitchPortSpeedDuplex	Integer	RW	

**Table 6. MIB Variables for TRACER.mib (Continued)**

adTRACERswitchModuleStatus			
adTRACERswitchPortStatusTable			
adTRACERswitchPortStatusEntry			
AdTRACERswitchPortStatusEntry			
adTRACERswitchPortStatusIdx	Integer		RO
adTRACERswitchPortTxPackets	Integer		RO
adTRACERswitchPortTxPacketsDrop	Integer		RO
adTRACERswitchPortRxPackets	Integer		RO
adTRACERswitchPortRxPacketsDrop	Integer		RO
adTRACERswitchPortRxPacketError	Integer		RO
adTRACERswitchWanStatusTable			
adTRACERswitchWanStatusEntry			
AdTRACERswitchWanStatusEntry			
adTRACERswitchWanStatusIdx	Integer		RO
adTRACERswitchWanTxPackets	Integer		RO
adTRACERswitchWanTxPacketsDrop	Integer		RO
adTRACERswitchWanRxPackets	Integer		RO
adTRACERswitchWanRxPacketsDrop	Integer		RO
adTRACERswitchWanRxPacketError	Integer		RO
adTRACER6420ip			
adTRACERIpAddress	IpAddress		RO
adTRACERSubnetMask	IpAddress		RO
adTRACERGatewayIp	IpAddress		RO
adTRACER6420trapIP			
adTRACERTrapIpHost1	IpAddress		RW
adTRACERTrapIpHost2	IpAddress		RW
adTRACERTrapIpHost3	IpAddress		RW
adTRACERTrapIpHost4	IpAddress		RW
adTRACERTrapIpHost5	IpAddress		RW
adTRACER6420current			
adTRACERCurrentRFs	Integer		RO
adTRACERCurrent24hRFs	Integer		RO
adTRACERCurrentRFCs	Integer		RO
adTRACERCurrent24hRFCs	Integer		RO
adTRACERCurrentRxLs	Integer		RO
adTRACERCurrentMaxRxLs	Integer		RO
adTRACERCurrent24hMaxRxLs	Integer		RO
adTRACERCurrentMinRxLs	Integer		RO
adTRACERCurrent24hMinRxLs	Integer		RO
adTRACERCurrentRxQs	Integer		RO
adTRACERCurrentMaxRxQs	Integer		RO

**Table 6. MIB Variables for TRACER.mib (Continued)**

adTRACERCurrent24hMaxRxQs	Integer	RO
adTRACERCurrentMinRxQs	Integer	RO
adTRACERCurrent24hMinRxQs	Integer	RO
adTRACERIntervalTable		
AdTRACERInteralEntry		
adTRACERIntervalEntry		
adTRACERIntervalNumber	Integer	RO
adTRACERIntevalRFs	Integer	RO
adTRACERIntervalRFCs	Integer	RO
adTRACERIntervalMaxRxLs	Integer	RO
adTRACERIntervalMinRxLs	Integer	RO
adTRACERIntervalMaxRxQs	Integer	RO
adTRACERIntervalMinRxQs	Integer	RO
adTRACERIntervalValidData	TruthValue	RO
adTRACERtotalTable		
AdTRACERtotalEntry		
adTRACERtotalEntry		
adTRACERtotalNumber	Integer	RO
adTRACERtotalRFs	Integer	RO
adTRACERtotalRFCs	Integer	RO
adTRACERtotalMaxRxLs	Integer	RO
adTRACERtotalMinRxLs	Integer	RO
adTRACERtotalMaxRxQs	Integer	RO
adTRACERtotalMinRxQs	Integer	RO
adTRACERtotalValidData	TruthValue	RO
adTRACER6420remoteStatus		
adTRACERremoteRFlinkState	DisplayString	RO
adTRACERremoteRFClinkState	DisplayString	RO
adTRACERremoteRFlow	DisplayString	RO
adTRACERremoteRXquality	DisplayString	RO
adTRACERremoteRXLevel	DisplayString	RO
adTRACERremoteFrequencyPlan	DisplayString	RO
adTRACERremoteLEDStatus	DisplayString	RO
adTRACERremoteSlot1	DisplayString	RO
adTRACERremoteSlot2	DisplayString	RO
adTRACER6420remoteCfg		
adTRACERremoteBaudRate	Integer	RW
adTRACERremoteBandPlan	Integer	RW
adTRACERremoteActiveChannels	Integer	RW
adTRACERremoteChannelSelect		

**Table 6. MIB Variables for TRACER.mib (Continued)**

adTRACERremoteDSX1ChannelSelectTable			
AdTRACERremoteDSX1ChannelSelectEntry			
adTRACERremoteDSX1ChannelSelectEntry			
adTRACERremoteDSX1ChannelSelectIdx	Integer		RO
adTRACERremoteDSX1ChannelSelection	Integer		RW
adTRACERremoteSwitchChannelSelectTable			
AdTRACERremoteSwitchChannelSelectEntry			
adTRACERremoteSwitchChannelSelectEntry			
adTRACERremoteSwitchChannelSelectIdx	Integer		RO
adTRACERremoteSwitchChannelSelection	Integer		RW
adTRACERremoteTxPower	DisplayString		RW
adTRACERremoteAlarmTable			
AdTRACERremoteAlarmEntry			
adTRACERremoteAlarmEntry			
adTRACERremoteAlarmNumber	Integer		RO
adTRACERremoteAlarmReporting	Integer		RW
adTRACERremoteSetPassword	DisplayString		RO
adTRACERremoteClearHistory	Integer		RW
adTRACERremoterfTrapEnable	Integer		RW
adTRACERremoteswitchModuleCfg			
adTRACERremoteswitchPortCfgTable			
adTRACERremoteswitchPortCfgEntry			
AdTRACERremoteswitchPortCfgEntry			
adTRACERremoteswitchPortIdx	Integer		RO
adTRACERremoteswitchPortEnable	Integer		RO
adTRACERremoteswitchPortSpeedDuplex	Integer		RW
adTRACERremoteswitchModuleStatus			
adTRACERremoteswitchPortStatusTable			
adTRACERremoteswitchPortStatusEntry			
AdTRACERremoteswitchPortStatusEntry			
adTRACERremoteswitchPortStatusIdx	Integer		RO
adTRACERremoteswitchPortTxPackets	Integer		RO
adTRACERremoteswitchPortTxPacketsDrop	Integer		RO
adTRACERremoteswitchPortRxPackets	Integer		RO
adTRACERremoteswitchPortRxPacketsDrop	Integer		RO
adTRACERremoteswitchPortRxPacketError	Integer		RO
adTRACERremoteswitchWanStatusTable			
adTRACERremoteswitchWanStatusEntry			
AdTRACERremoteswitchWanStatusEntry			
adTRACERremoteswitchWanStatusIdx	Integer		RO
adTRACERremoteswitchWanTxPackets	Integer		RO

**Table 6. MIB Variables for TRACER.mib (Continued)**

adTRACERremoteswitchWanTxPacketsDrop	Integer	RO
adTRACERremoteswitchWanRxPackets	Integer	RO
adTRACERremoteswitchWanRxPacketsDrop	Integer	RO
adTRACERremoteswitchWanRxPacketError	Integer	RO
adTRACER6420remoteTrapIP		
adTRACERremoteTrapIpHost1	IpAddress	RW
adTRACERremoteTrapIpHost2	IpAddress	RW
adTRACERremoteTrapIpHost3	IpAddress	RW
adTRACERremoteTrapIpHost4	IpAddress	RW
adTRACERremoteTrapIpHost5	IpAddress	RW
adTRACERremotecurrent		
adTRACERremoteCurrentRFs	Integer	RO
adTRACERremoteCurrent24hRFs	Integer	RO
adTRACERremoteCurrentRFCs	Integer	RO
adTRACERremoteCurrent24hRFCs	Integer	RO
adTRACERremoteCurrentRxLs	Integer	RO
adTRACERremoteCurrentMaxRxLs	Integer	RO
adTRACERremoteCurrent24hMaxRxLs	Integer	RO
adTRACERremoteCurrentMinRxLs	Integer	RO
adTRACERremoteCurrent24hMinRxLs	Integer	RO
adTRACERremoteCurrentRxQs	Integer	RO
adTRACERremoteCurrentMaxRxQs	Integer	RO
adTRACERremoteCurrent24hMaxRxQs	Integer	RO
adTRACERremoteCurrentMinRxQs	Integer	RO
adTRACERremoteCurrent24hMinRxQs	Integer	RO
adTRACERremoteIntervalTable		
AdTRACERremoteInteralEntry		
adTRACERremoteIntervalEntry		
adTRACERremoteIntervalNumber	Integer	RO
adTRACERremoteIntevalRFs	Integer	RO
adTRACERremoteIntervalRFCs	Integer	RO
adTRACERremoteIntervalMaxRxLs	Integer	RO
adTRACERremoteIntervalMinRxLs	Integer	RO
adTRACERremoteIntervalMaxRxQs	Integer	RO
adTRACERremoteIntervalMinRxQs	Integer	RO
adTRACERremoteIntervalValidData	TruthValue	RO
adTRACERremoteTotalTable		
AdTRACERremoteTotalEntry		
adTRACERremoteTotalEntry		
adTRACERremoteTotalNumber	Integer	RO

**Table 6. MIB Variables for TRACER.mib (Continued)**

adTRACERremoteTotalRFs	Integer	RO
adTRACERremoteTotalRFCs	Integer	RO
adTRACERremoteTotalMaxRxLs	Integer	RO
adTRACERremoteTotalMinRxLs	Integer	RO
adTRACERremoteTotalMaxRxQs	Integer	RO
adTRACERremoteTotalMinRxQs	Integer	RO
adTRACERremoteTotalValidData	TruthValue	RO

# TROUBLESHOOTING GUIDE

*Provides helpful information for troubleshooting common configuration problems for the TRACER 6420.*

## CONTENTS

<b>Overview</b> .....	<b>104</b>
<b>LED Indicators</b> .....	<b>104</b>
PWR LED .....	104
TST LED .....	104
RF DWN LED .....	104
RF LOW LED .....	105
T1 Interface Alarm LEDs .....	105
LAN LEDs .....	106
<b>RF Errors</b> .....	<b>106</b>
<b>Step-by-Step Troubleshooting</b> .....	<b>106</b>
<b>Installing/Troubleshooting the TRACER Hardware</b> .....	<b>107</b>
Installing/Configuring T1 Hardware .....	108
Installing/Configuring Ethernet Hardware .....	108

## 1. OVERVIEW

This troubleshooting guide provides recommended actions for various conditions of the TRACER 6420 system. The status LEDs (located on the front panel of the unit) provide information to help determine the necessary troubleshooting action. This guide contains recommended actions for resolving possible problems indicated by the status LEDs.

## 2. LED INDICATORS

### PWR LED

If the **PWR** LED is not **ON** and solid green, the TRACER 6420 is not receiving adequate DC power.

#### ***Recommended Actions:***

1. Verify that the power source is delivering between 21 and 60 VDC.
2. Check the polarity of the power connection (referenced to ground) of both the TRACER 6420 unit and the power source.
3. Check the internal fuse. The fuse is accessed from the rear panel of the unit. If this fuse is open, replace with a 2 A, 250 V (2-inch) slow-blo fuse.

### TST LED

The **TST** LED will flash once (amber) during power-up to indicate a self-test is in progress. If the **TST** LED is flashing or remains **ON** after 10 seconds, the TRACER 6420 unit has failed the self-test. This is an internal failure, and technical support should be contacted.

### RF DWN LED

If the **RF DWN** LED is **ON** (solid red), there is a problem with the RF receive path from the remote TRACER 6420.

#### ***Recommended Actions:***

1. Verify that one end of the link is configured as Plan A and the other end as Plan B.
2. Measure the RSSI voltage and consult the RSSI calibration sheet included with the unit. If the voltage level corresponds to a received signal power level that agrees with the calculated receive signal level, proceed with Step 7.
3. Check the RF coaxial cable connection.
4. Verify that the antenna polarization is the same at both ends of the RF signal transmit and receive path.
5. Verify the RF signal path is clear.
6. Check the integrity of the lightning arrestors.
7. Check for possible interference at both ends of the link. If necessary, change polarization and/or band plans at both ends.



## RF LOW LED

If the **RF LOW** LED is **ON** (solid red), the received signal is approaching 0 V of RSSI. This condition is typically indicative of a path or installation problem.

### **Recommended Actions:**

1. Verify the far-end transmitter power setting is the value that the link planning budget allows.
2. Check all coaxial cable connectors for solid connections. Check for water and corrosion around any of the connectors. If water is apparent in the coaxial connectors, replace the coaxial cable and the connectors, making sure to properly weatherproof the replacements.
3. Verify the RF signal path by verifying the antenna alignment.
4. Check the integrity of lightning arrestors.

## T1 Interface Alarm LEDs

If the **ALARM** LED is **ON** (solid red), it is an indication that the TRACER 6420 is detecting an active T1 alarm. To identify the T1 interface in alarm and the specific alarm present, display the **T1(x) STATUS** screens and check the **T1(x) INTERFACE ALARMS** field.

### **Recommended Actions:**

1. Display the **T1(x) STATUS** screen and check the **T1(x) INTERFACE ALARM** field to identify the active alarm.
2. Follow the steps below for the appropriate alarm.

### **LOS Alarm (Red Alarm)**

**LOS ALARM** is an indication that the TRACER 6420 may be unable to detect a viable T1 received signal from the connected T1 equipment. This error may be due to a degraded signal or no signal, or may be caused by improper framing.

### **Recommended Actions:**

1. Verify that the T1 cable is connected to the T1 interface on the TRACER 6420.
2. Verify the connections at the opposite end of the T1 cable.
3. Verify that the framing mode (D4 or ESF) is the same for both the TRACER 6420 and the T1 equipment.

### **Yellow Alarm**

A Yellow Alarm is generated by the attached equipment. When the attached equipment's T1 interface is in Red Alarm, the TRACER 6420 generates a Yellow Alarm.

### **Recommended Actions:**

1. Follow the troubleshooting steps for Red Alarm, but do so at the attached equipment.

### **Blue Alarm**

A remote alarm (alarm indication signal or AIS) is generated by the attached equipment. The root cause must be determined at the attached equipment. A typical cause of a blue alarm is a lack of input to a CSU.

### **Recommended Actions:**

1. Verify the input to any attached data equipment.

**BPV**

Bipolar violations (BPVs) indicate an improper configuration or faulty wiring.

**Recommended Actions:**

1. Verify the TRACER 6420 unit and the attached equipment are configured for the same line coding (**B8ZS** or **AMI**).
2. Verify the cable connections for the T1 interface are solid.

**LAN LEDs**

If the **LAN LED** is **OFF**, the TRACER 6420 is not able to detect an active Ethernet link on the particular 10/100BaseT/TX interface.

**Recommended Actions:**

1. Check all Ethernet cable connections to verify they are properly plugged in (making sure the tab on the connector snaps into place).
2. Connect the 10/100BaseT/TX interface to a “known good” Ethernet port to verify the TRACER port is functioning properly.
3. Try another Ethernet cable.

**3. RF ERRORS**

RF errors can range from a nonviable microwave path to loose RF connectors.

Nonviable path conditions could be caused by physical obstructions such as buildings, mountainous terrain, trees, etc., as well as other physical limitations such as excessive path distances and in-band RF interference. These types of errors are remedied by performing a detailed line-of-site microwave path study to determine whether a microwave link is feasible for the terrain and environment under consideration.

If after performing a microwave path study the system is still not operational, ensure that the antennas are properly aligned. Note that alignment must be achieved in both elevation and azimuth for optimal link performance. The TRACER 6420 can be used to aid in antenna alignment by looking at the **Rx POWER** “fuel gauge” on the System Status or System Option menu pages or by measuring the DC voltage (relative to ground) at the **RSSI** front panel test jack. Optimal antenna alignment is achieved by peaking the front panel **RSSI** voltage or the **Rx POWER** “fuel gauge” on the TRACER 6420 terminal display. Consult the ADTRAN TRACER Data Sheet included with the unit to verify that the actual receive signal level agrees with the calculated receive signal.

An **RSSI** test point, located on the front panel, provides a DC voltage level (relative to the **GND** test point) that corresponds to the amount of signal being received from the far end's transmitter. The voltage at this test point can vary from approximately 0 to 5 VDC. An RSSI calibration sheet is shipped with the system to provide the installer a cross-reference between actual received signal level (in dBm) and RSSI voltage. This sheet is useful for verifying link budget calculations and ensuring proper equipment installation.

**4. STEP-BY-STEP TROUBLESHOOTING**

The logical troubleshooting flow presented in this section can be used to set up your TRACER 6420 system, and also to diagnose a previously installed system. Please contact Technical Support at any stage during installation and/or troubleshooting if you require assistance.

## 5. INSTALLING/TROUBLESHOOTING THE TRACER HARDWARE

1. Perform a detailed path profile and link budget for each TRACER 6420 microwave link. A thorough path study can be used to estimate signal power budgets, estimate fade margins at each receiver, identify potential line-of-site obstacles, properly size antenna dishes, and determine minimum antenna dish heights above the earth.
2. Set up all of the TRACER 6420 hardware on a workbench. The actual cables used in the permanent installation should be used in the workbench setup. A rigorous workbench “simulation” of the link will help alleviate and avoid time-consuming errors.
3. Examine the **PLAN A** and **PLAN B** LEDs on the front panel of each unit. These LEDs indicate the frequency plan for each TRACER 6420 unit. Each TRACER link must have a Plan A radio on one side and a Plan B radio on the other.
4. Attach the RF coaxial cables to be used in the permanent installation to the N-type connectors on the back of the TRACER 6420 unit. Attach the other end of the coaxial cable(s) to an RF power meter or spectrum analyzer, if either is available. The power measured by the meter/analyzer will be the RF power available at the input of the antenna. The TRACER 6420 unit is programmed at the factory to output approximately 100 mW (20 dBm) of RF power. The actual power level measured by the meter/analyzer will be less than 100 mW due to RF losses through the coaxial cable, and is a function of the cable type and length being used. In any event, the power level at the output of the coaxial cable should be a significant fraction of 100 mW. A power meter/analyzer reading that is not on the order of at least tens-of-milliwatts could be an indication of unsuitable RF cable or faulty or unreasonably long coaxial cable, or a combination of these factors.
5. Resolve all RF coaxial cabling errors before proceeding.
6. Attach the RF coaxial cables to a high-quality attenuator, if possible. If you do not have an attenuator, attach the coaxial cables to the antennas to be used in the permanent installation. If the installation antennas are not available, small, inexpensive dipole or patch antennas can be used for verification purposes. If an adjustable attenuator is being used, dial in the amount of attenuation that corresponds to the path loss value expected for the microwave link in which the TRACER hardware will be installed. The path loss value can be calculated from a knowledge of the path length, or provided by a path study. Remember to subtract both antenna gain values from the attenuator level if these values have not already been accounted for.
7. After setting up the RF pieces, examine the **RF DOWN** LED on the front panel of each TRACER 6420 unit. If the **RF DOWN** LED is illuminated (red), the corresponding TRACER 6420 is not receiving a suitable RF signal from the other TRACER 6420 unit. In this case, the receiving TRACER 6420 is either receiving a very weak signal or no signal at all. If the **RF DOWN** LED is not illuminated, then the TRACER 6420 units are receiving a suitable RF signal. Suitable RF power levels for low error rate communication will range from -30 dBm to -88 dBm measured at the N-type connector input on the TRACER 6420 unit.
8. Resolve any signal level issues before proceeding.
9. Examine the **RF LOW** LED on the front panel of each TRACER 6420. If this LED is illuminated, then the TRACER 6420 is receiving a relatively weak signal; however, if the **RF DOWN** LED is not illuminated, then the received signal is being suitably processed by the TRACER 6420 system. If you are receiving a weak signal (**RF LOW** is **ON**), please verify that the weak signal is not being caused by a faulty cable, an insufficiently tightened cable, or some other installation-related problem. Also, make sure an unreasonably large attenuation value has not been selected if you are using an attenuator on a workbench setup.

Use the tables in Section 2, *Microwave Path Engineering Basics*, of this manual to select the proper free-space attenuation value (in dB) based on the estimated length of the microwave path. Remember to subtract both antenna gains (local and remote) from the attenuator setting.

10. Test the installed modules by performing the following:

#### 4xT1 Module

Initiate a line loopback on the local TRACER 6420 unit and run a test pattern from the connected T1 equipment. This will verify the connection between the T1 equipment and the local TRACER 6420 unit.

#### Quad Ethernet Switch Module

Connect a computer (or Ethernet test equipment) to the TRACER 6420 Ethernet interfaces. Perform a “ping” from one test station across the wireless link to another test station connected to the remote TRACER 6420. This will verify the data path between the test equipment and the TRACER 6420 unit.

11. Command a link loopback on the remote TRACER 6420 unit and run a test pattern from the connected T1 equipment. This will verify the data path across the RF link.



*External pattern generators are required to test data path integrity. An T1 BERT tester is suggested.*

## Installing/Configuring T1 Hardware

1. If possible, attach any or all of the intended T1 hardware to the TRACER 6420 units using the same workbench setup. This step offers the perfect opportunity to configure your T1 hardware for proper functioning with the TRACER 6420 hardware.
2. To significantly reduce the probability of an unsuccessful field installation, resolve any remaining T1 equipment-to-TRACER 6420 configuration issues before field installation. See *T1 Interface Alarm LEDs* on page 105 for more information on resolving T1 interface alarm conditions.

## Installing/Configuring Ethernet Hardware

1. If possible, attach any or all of the intended Ethernet hardware to the TRACER 6420 units using the same workbench setup. This step offers the perfect opportunity to configure your Ethernet hardware for proper functioning with the TRACER hardware.
2. To significantly reduce the probability of an unsuccessful field installation, resolve any remaining Ethernet equipment-to-TRACER 6420 configuration issues before field installation.