## The user manual

Know your mobile phone

## Column notice

Has not a call with the new information, will be at the top event notification message indicating bar display screens, a finger from the event notification indicating column slide down genthy, displays all the message, click the message, to view the new information or call. Drop-down a note, click in the top right corner of the icon to go in there is the mobile phone can be quick setup shortcut ion.

### Application menu

## Open and switching applications

- 1. If you want to open the application on your phone, please light click its icon on the main screen;
- 2. Return to the main screen: click the Home button:
- Switch to the other main screen: rapid slide your finger to the left or right. (to the first main screen, can gently press the Home button):
- You can quickly switch between applications are using; Multitasking also allows some applications running in the background:
- To view recently used application can long click the Home button for 3 seconds, the screen is displayed recently used applications.

#### Bun

- 1. Drag to move up or down to scroll the screen:
- 2. Drag to move finger to scroll will not select or activate any content on the screen.

### 1. dial

## Make and receive calls

## making a call

"Dial "button allows you to quickly access the upper screen: call log, contacts, and digit dialing the keyboard (for manual dialing) to dial" keyboard ", enter the number, then click "card 1/2" light can make a phone call

## answer calls

When there is a phone call, gently press "answer". If the machine has been locked, please move the slider. You can also press the center button on the headset to answer the call. Make calls mute: press "onloft" and "sleep/wake" button or any volume button.

## Contact

In "contacts" screen, quick to can make a phone call, to create a new E-mail message, find the position of the other, and perform more operations

## Call log

## All calls

Gently press "call" recently, "all calls are recorded all did not call, call, dial the phone. You can choose to call, send information, create a new contact and existing contacts.

## Received calls

"Call" is all records have a call. When you have already answered the phone, "phone" will show already call number.

#### Dialed numbers

Has dialed calls" is to record all have dial call. When you have had the phone, "phone" displays have dial the telephone

## Minned calls

Call\* is to record all the missed call. When you have not call, "phone" not call number will be shown.

## 2. backup and restore

Need to insert the T card to backups of data and application.

## 3. E-Mail

### Set up email account

In this machine can choose corresponding E-mail Settings.

### Check and read email

In the Mail, "mailbox" screen allows you to quickly access all of your email intox and other. When you open the mail, E-mail will retrieve and display the latest, and at the top of the screen shows the number of unread mail.

## 4. Browser

## View the web page

You can use the land scape pattern or rank to view web pages. Web page will turn with the rotation of the machine, and can automatically adjust to fit the page.

## Open website

according to the address bar, then type the url and gently press the "search". If the address bar is not visible, please slide the page to the top of the screen

## 5. music

With "music" application to enjoy music collection. According to the artist, album, song, playlist browsing the content of this machine.

### Add/remove music

Add repertoire: can copy the music from the computer to the SD card, can be in the "music" list add tracks. Delete repertoire: can direct access to delete the music file management, also can connect to your computers for delete the music from the computer, or long click the songs name will popup menu", added to the playlist, delete, search "may choose to delete to delete the menu."

## 6. Sound recorder

Select this feature, press the center button for the recording. Select options to enter:

>Quality: set to high or standard

>The recording mode: set to normal or meeting or distance of the recording

Recording: to record a new voice.

>Check the file: view the current recording file.

You can use this function to record audio files. Note: the recording time is decided by the residual capacity of mobile phone memory.

## Messaging

Send and receive messages

## Sond SMS

According to the lower left comer "information" loon, and then input the name or telephone number, or light according to the recipients of the "+" loon on the right, then choose your contacts from the address book list. Light according to the text above the keyboard, typing information or click on the ion on the left side of the text to add videol/mage, then gently press' send

### Cappdeliver

When you have unread messages, "messages" icon will be displayed on the main screen you haven't read number of text messages. When you enter the "text", after reading light according to enter the text messages.

## 8. Calendar

The "calendar" allows you to access your calendar, and events. You can view the calendar respectively, also can see several calendar at the same time. You can daily, monthly, or according to the list view events.

## View calendar

Light switch display mode: press the "day", "week", "month", "schedule".

By date show that slide up or down to see the one day of weekly events in views

View: gently by one day to see the weekly event

View: to one day to see the events of the month.

Schedule shows: all the dates and events will appear in the scrolling list.

## Add an Event

You can directly in the machine to create and update the calendar events. Click on add a new activity, enter any of the following title/pointoinstart time if it is a full-day event, please open the "day" liespeat time, on every day, every week, every two weeks, a month or a year lybe inviter (if your calendar server support) remind time (from five minutes to two days before the event).

## Gallery

Allows you to take photos and video, so that you can share with family, friends and colleagues. From PC sync photos and video, you can check with the machine photos and video and photos will be used for the vallappeer, and specify the photos to identify the telephone contracts. You can also send photos and video information by E-mail, use MMS send photos and video, with blustoch send your choice and video.

## Look at photos and video

Use the machine photos and video, photos and video from the PC synchronization, or from email or MMS storage of photos and video can see in the "gallery".

Look at photos and video: in the "gallery", you can choose you want to see the pictures or video light, can see the pictures or video. Local: enlarge photos even according to the location of the two do you want to enlarge. Even twice to shrink again. You can also open or closed two fingers to zoom in and out.

## Delete the photos and video

Gently press to select you want to delete the photo and video. "Delete" button will indicate the number of your choice.

#### lide show

You can put the album as a slide show to see the album as a slide show to watch, light light according to the photo album, and then press "slideshow".

## Share photos and video

You can put your photos and video, bluetooth, Mail sent to the information.

## Set as wallpaper

You can enter the gallery, choose you need to set up image, click on the "menu" will be a photo set as wallpaper.

## 10. camera

This machine is divided into front and back camera. Mainly on the back of the camera. You can use the screen to control the camera and view your photos or video.

take photo sand video s

## take photos

Use this machine on target, gently press photo. When you take photos or video begins to emit the shutter sound. If the ring/silent switch is set to mute, it couldn't hear the sound. Interface at the top of the "camera" icon in the order: flash light switches, options, camera before and after the switch

- I. Flash: if you are in the weak light, can open the flash.
- 2. Option: you can set the flash, white balance, storage location, photo mode, exposure, and so on-

## videos

Click on the video button to start video. "Camera" is in the video, the video button in red. Lightly press video button again to stop recording.

## loo kat photos and videos

In the "camera", the screen lightly in the lower right hand comer of the thumbnail. In the "galleny", according to the "camera" aburn. Light according to the left or right button, or slide your finger to the left or right quickly, to leaf through photographs and older.

## 11. video player

Can guickly into the view you need to find a video.

#### ideo view

Choose "video player" in the main interface, can manage their files into the video folder, enter the "video" you can choose the video file to watch the video you will see.

## 12. File Manager

Can view the phone and SD card storage file, insert the USB line, mobile phone can be stored and stored in the SD card files"

## 13. clock

You can view the world clock, alarm clock, stopwatch, timer

#### count down

Mobile phone built-in countdown function. Set a time, you can click on the bottom of the screen icon in the start the countdown, time arrives, the chone automatically.

## c loc k

### Add the alarm clock

Main screen click on the "clock", select "alarm interface" add ICONS and type you want to set up the content

## Delete the alarm clock

Gently press "alarm clock" and click "edit". Next to the clock and then lightly in "-", then press "delete" gently.

## seconds counter

Use a stopwatch to event timing: lightly press "stopwatch" select "start" to enable a stopwatch.

To record the time back and forth, back and forth in each light after press "would".

If you want to suspend a stopwatch, please press "stop" light. Gently press "start" to continue.

If a stopwatch is to be reset, please light when a stopwatch to suspend the press the "reset".

# 14. Calculator

Light according to the number and function in the "calculator", just like you use the standard calculator. To add, subtract, multiply or divide button, the button will twist, to let you know to perform operations. . Recorded voice memos, gently press "blav" button then oress "folk" to suscend olav.

## 15. Settings

To access the Settings menu: in the menu mode, choice: network

## Wireless networks

## SIM management

Can be set up single or double card master card and set the machine operation.

## #1-F1

ViFi: Open or close the WiFi function.

Network inform: setting equipment available in the open network for notification.

Add the wi-fi network: manually add WiFi access point

## Bluetooth

You can via bluetooth electronic equipment within 10 meters and set up a wireless connection. Bluetooth can be used to send pictures, video, dioital data, etc. Under the bluetooth interface, can make the following options:

- Open/close(sets) the Blue tooth status(open or closed).
- Paired device: the show has been paired device list record of success.
- · Search for equipmention search for the new device
- Setting: can be visible to the machine name, name of equipment, etc.

## Traffic usage

Traffic usage: set the SIM card flow cycle, the use of display using SIM card data connection into the application of flow.

## more

Wreless and Internet: flight mode: disable devices all wireless functions. Can only use a VPN network service: to set the lock screen PIN or credential storage password to use. Network sharing and postable hot: can open WIFI hatsport / Network sharing network sharing network sharing network sharing network mobile networks: can set card 1/2 mobile network Settings. USB Internet: Shared Windows PC via a ILISR list network.

## Audio profiles

You can select the desired scene mode according to need. Sone mode option: standard, silent, meeting, outdoor model, this factory has done several patterns and Settings, you can customize the Settings. In the scene mode interface, short press of the selected mode to pop up after the individual Settings to enter personal Settings, change model of the scenario specific Settings are as follows:

- L. Vibration: set later will not ring the bell
- 2. Volume: can be adjusted by rolling up and down the ball path to ring the bell and the volume of the sound.
- 3. Ringtone: to set the phone ring.
- 1. Notification ringtone: can be set to notify the bell
- 5. Choose sound: operation Settings screen to choose whether to play sounds
- 6. Prompt: screen lock lock and unlock the screen broadcast voice switch
- 7. To uch : If there is a touch switch can touch screen

## Display

Lock screen notification: open/close on the lock screen display/no unread message/phone call

Wallpaper: you can set the standby interface wallpaper for dynamic wallpaper/desktop wallpaper/video/image in the atlas of the wallpaper.

Automatic rotary screen: open the horizontal/vertical placement will follow swings to the phone's screen, shut down does not follow the rotating screen.

Luminance: the screen brightness will affect battery life. Reduce the screen brightness in order to prolong the using time of the battery, or use the "automatic brightness adjustment"

Font size: you can set the phone font size

Dormancy: the mobile phone is not operating in a set of time automatically cut off screen

### Storage

Show a mobile phone internal storage capacity and storage capacity of the SD card, can be executed on mobile phones and SD format

# Battery

Show a mobile phone battery has been used time and specific power consumption

## Apps

To manage your applications, to delete the machine application, mobile storage location.

# Personal

## Location information access

Can set access my location information

## positioning system

A virtual private network Settings, you can set up wireless network or using a GPS satellite. At the same time open A - GPS can quickly locate your current position.

## Security

Can screen lock: lock screen set to slide/voice unlocked/design/PIN/combination lock

Main information: edit the information, in the locked state displays edit content

Encryption mobile: set the encryption mobile phone every boot need input digital PIN or password to decrypt the mobile phone SIM card lock: set the SIM password every boot to input a SIM card password to boot

Show the password: open in the input password lock screen or password will show the password

The device manager view or stop using the device manager

Unknown sources: open allows installing applications from unknown sources, otherwise not

Certificate of the credential storage: can be installed from the SD card

## Language and input method

Can set the phone language and input method

## Backup \$ reset

Reset the DRm: delete all the DRm license

Restore the factory Settings: remove all the data on the phone

### Accounts

Background data: when binding Google account or company account, the application can be automatically synchronized calendar calendar, contacts, email in the Google account.

Automatic synchronization: when binding account application will synchronize data

E-mail: show email account

Add account: to add a new account

## Date & time

To automatically update the time and date set a time format

## Power-on by alarm

In: Set a specific time, when the time arrives, the phone automatically switched on

liff: Set a specific time, when the time arrives, the phone will be prompted whether to turn it off, after 30 seconds, if no choice, the phone automatically shut down

## Miscellaneous function

Can be set to mobile phone perform a uxiliary functions

Developer options

Can to the operation of the phone system, open the USB debugging plug USB connection peas/91 assistant downhad APK application etc.

## About phone

Show a mobile phone version of the system and hardware information

## 16. People

In the main menu, click the address book, enter the contact menu, and can give the address book contacts to make calls, send messages, etc.

### Create a contact

- 1. In the main screen, click the address book, enter the contact menu-
- 2. Press the "+" input contact information click on the corresponding items
- 3. Click finish after input to complete the related information, save the contact.

### Sear h contacts

You can search in the unit name, last name and company name in the contact.

Search contacts: in the "address book", gently press any contacts list at the top of the search bar, and then input search content

## 17. FM

Choose FM radio, will enter the radio broadcast interface (need to insert the headset to listen to).

Channel list: storage channel, can be to manually edit channel

Settings: set the background, cell phone speakers on or off; Can also set the recording format, sound quality, storage location and channel effects.

Collection list: into the list view collection channelsFi BOÔÔÂJVŒ/ÒT ÒÞV.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This confirment proceedings and if not installated and

reasonatione protection against namiful interherence in a reasonational ristatation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and or, the user is encouraged to try to correct theinterference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- --Increase the separation between the equipment and receiver.
- --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2)This device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. such modifications could void the user's authority to operate this equipment. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Ù]^8ää8kÁ02a•[;]cāj}ÁÜasz^ÁQÜOEÜDÁQ-{;{assāj}Á

Á