

Chapter 4 The HiveAP 340 Platform

The Aerohive HiveAP 340 is a high-performance and highly reliable 802.11n wireless access point. The HiveAP 340 provides dual concurrent 802.11b/g/n and 802.11a/n radios for 3x3 MIMO (Multiple In, Multiple Out) and dual 10/100/1000 Ethernet ports for link aggregation or link redundancy. Its power management system uses a concept called smart PoE (Power over Ethernet) to adjust its power consumption automatically in response to the available power in different environments. Smart PoE supports the IEEE 802.3af standard and the 802.3at pre-standard.

This chapter covers the following topics relating to the HiveAP:

- ["HiveAP 340 Product Overview" on page 46](#)
 - ["Ethernet and Console Ports" on page 48](#)
 - ["Status LEDs" on page 52](#)
 - ["Antennas" on page 52](#)
- ["Mounting the HiveAP 340" on page 56](#)
 - ["Ceiling Mount" on page 56](#)
 - ["Surface Mount" on page 58](#)
- ["Device, Power, and Environmental Specifications" on page 59](#)

HIVEAP 340 PRODUCT OVERVIEW

The HiveAP 340 is a multi-channel wireless access point. It is compatible with IEEE 802.11b/g/n (2.4 GHz) and IEEE 802.11a/n (5 GHz) standards and supports a variety of Wi-Fi (wireless fidelity) security protocols, including WPA (Wi-Fi Protected Access) and WPA2.

You can see the hardware components on the HiveAP in [Figure 1](#). Each component is described in [Table 1](#).

Figure 1 HiveAP 340 Hardware Components




Table 1 HiveAP 340 Component Descriptions

Component	Description
Status LEDs	The status LEDs convey operational states for system power, firmware, Ethernet interfaces, and radios. For details, see "Status LEDs" on page 52 .
Device Lock Slot	You can physically secure the HiveAP by attaching a lock and cable (such as a Kensington® notebook lock) to the device lock slot or by using the lock adapter that is included in the mounting kit and a padlock. For more information, see "Locking the HiveAP 340" on page 57 .
802.11a/b/g/n RP-SMA Connectors	You can connect up to six detachable single-band antennas to the male 802.11a/b/g/n RP-SMA (reverse polarity-subminiature version A) connectors. Connect the longer antennas, which support 2.4 GHz frequencies (for IEEE 802.11b/g/n), to the connectors on the side panel with the Ethernet ports. Connect the shorter antennas, which support 5 GHz frequencies (for IEEE 802.11a/n), to the connectors on the side panel with the device lock slot. For details, see "Antennas" on page 52 .

Component	Description
10/100/1000 Mbps PoE Ports	<p>The two 10/100/1000-Mbps Ethernet ports—ETH0 and ETH1—support IEEE 802.3af and 802.3at PoE (Power over Ethernet) and receive RJ-45 connectors. The HiveAP can receive power through one or both Ethernet connections from power sourcing equipment (PSE) that is compatible with the 802.3af standard and forthcoming 802.at standard. (If you connect the HiveAP to a power source through the power connector and PoE ports simultaneously, the device draws power through the power connector and automatically disables PoE.)</p> <p>You can configure ETH0 and ETH1 as two individual Ethernet interfaces, combine them into an aggregate interface to increase throughput, or combine them into a redundant interface to increase reliability. You can connect the HiveAP 340 to a wired network or to a wired device (such as a security camera) through these ports using bridging. They are compatible with 10/100/1000Base-T/TX and automatically negotiate half- and full-duplex connections with the connecting device. They are autosensing and adjust to straight-through and cross-over Ethernet cables automatically. For details, see "Ethernet and Console Ports" on page 48.</p>
Power Connector	<p>The 48-volt DC power connector (0.625 amps) is one of two methods through which you can power the HiveAP 340. To connect it to a 100 - 240-volt AC power source, use the AC/DC power adaptor that is available as an extra option. Because the HiveAP does not have an on/off switch, connecting it to a power source automatically powers on the device.</p>
Console Port	<p>You can access the CLI by making a serial connection to the RJ-45 console port. The management station from which you make a serial connection to the HiveAP must have a VT100 emulation program, such as Tera Term Pro[®] (a free terminal emulator) or Hilgraeve Hyperterminal[®] (provided with Windows[®] operating systems). The following are the serial connection settings: bits per second: 9600, data bits: 8, parity: none, stop bits: 1, flow control: none. For details, see "Ethernet and Console Ports" on page 48.</p>
Reset Button	<p>The reset button allows you to reboot the device or reset the HiveAP to its factory default settings. Insert a paper clip, or something similar, into the Reset pinhole and press the reset button. To reboot the device, hold the button down between 1 and 5 seconds. To return the configuration to the factory default settings, hold it down for at least 5 seconds. After releasing the button, the Power LED goes dark as the system reboots. Then it pulses green while the firmware loads and the system performs a self-test. After the software finishes loading, the Power LED glows steady green.</p> <p>To disable the reset button from resetting the configuration, enter this command: no reset-button reset-config-enable Pressing the button between 1 and 5 seconds will still reboot the HiveAP, but pressing it for more than 5 seconds will not reset its configuration.</p>


Note: The rear surface of the HiveAP 340 is used for heat dissipation to reduce the internal temperature. Consequently, it can become hot, so use caution when handling it.

Ethernet and Console Ports


There are three ports on the HiveAP 340: two RJ-45 10/100/1000Base-T/TX Ethernet ports and an RJ-45 console port.

The pin assignments in the PoE (Power over Ethernet) Ethernet ports follow the TIA/EIA-568-B standard (see [Figure 2](#)). The ports accept standard types of Ethernet cable—cat3, cat5, cat5e, or cat6—and can receive power over this cable from power sourcing equipment (PSE) that is 802.3af-compatible. If you use cat5, cat5e, or cat6 cables, the HiveAP 340 can also support 802.3at-compliant PSE. Such equipment can be embedded in a switch or router, or it can come from purpose-built devices that inject power into the Ethernet line en route to the HiveAP. Because the PoE ports have autosensing capabilities, the wiring termination in the Ethernet cable can be either straight-through or cross-over.

Figure 2 PoE Wire Usage and Pin Assignments



The PoE ports are auto-sensing and can automatically adjust to transmit and receive data over straight-through or cross-over Ethernet connections. Likewise, they can automatically adjust to 802.3af Alternative A and B power delivery methods. Furthermore, when the Alternative A method is used, the ports automatically allow for polarity reversals depending on their role as either MDI or MDI-X. In 802.3at, the 1/2 and 3/6 wire pairs connect to DC source 1 and 4/5 and 7/8 pairs to DC source 2 in PSE. Although the exact polarity depends on the PSE design, the HiveAP 340 Ethernet ports can support all possible options.



Smart PoE

The HiveAP 340 applies the Aerohive concept of smart PoE to adjust power consumption as necessitated by varying levels of available power. If the HiveAP needs more power than is available, it first disables the ETH1 interface. If it still needs more power, it switches from 3x3 MIMO (Multiple In, Multiple Out) to 2x3 (see ["MIMO" on page 53](#)). In rare cases when further power conservation is necessary, the HiveAP then reduces the speed on ETH0 from 10/100/1000 Mbps to 10/100 Mbps. Finally, in the event that there is a problem with the PoE switch or Ethernet cable, the HiveAP disables its wireless interfaces and returns its ETH0 and ETH1 interfaces to 10/100/1000 Mbps speeds. Through the application of smart PoE, the HiveAP 340 can make power usage adjustments so that it can continue functioning even when the available power level drops.

Aggregate and Redundant Interfaces

By default ETH0 and ETH1 act as two individual Ethernet interfaces. When both interfaces are connected to the network and are in backhaul mode, the HiveAP transmits broadcast traffic only through ETH0. The HiveAP transmits broadcast traffic through ETH1 only when ETH0 does not have network connectivity. When both Ethernet interfaces are connected to the network and are in access mode, then the HiveAP transmits broadcast traffic through all the access interfaces: ETH0, ETH1, and all wireless subinterfaces in access mode.

In addition to using ETH0 and ETH1 as individual interfaces, you can combine them into an aggregate interface (agg0) to increase throughput, or combine them into a redundant interface (red0) to increase reliability. The logical red0 and agg0 interfaces support all the settings that you can configure for Ethernet interfaces except those pertaining to physical link characteristics such as link speed. See the sections below for configuration information.

Aggregate Interface

You can increase throughput onto the wired network by combining ETH0 and ETH1 into a single logically aggregated interface called "agg0". The aggregate interface effectively doubles the bandwidth that each physical has when used individually. In this configuration, both Ethernet ports actively forward traffic, the HiveAP applying an internal scheduling mechanism based on the source MAC address of each packet to send traffic through the aggregate member interfaces. To configure an aggregate interface, enter the following commands:

```
interface eth0 bind agg0
interface eth1 bind agg0
```

In addition to configuring the HiveAP, you must also configure the connecting switch to support EtherChannel. For example, the following commands bind two physical Ethernet ports—0/1 and 0/2—to the logical interface port-channel group 1 on a Cisco Catalyst 2900 switch running Cisco IOS 12.2:

```
Switch#conf t

Switch(config)#interface port-channel 1
Switch(config-if)#switchport mode access
Switch(config-if)#spanning-tree portfast
Switch(config-if)#exit

Switch(config)#interface fastEthernet 0/1
Switch(config-if)#switchport mode access
Switch(config-if)#channel-group 1 mode on
Switch(config-if)#spanning-tree portfast
Switch(config-if)#exit
```

```
Switch(config)#int fastEthernet 0/2
Switch(config-if)#switchport mode access
Switch(config-if)#channel-group 1 mode on
Switch(config-if)#spanning-tree portfast
Switch(config-if)#exit
Switch(config)#exit

Switch#wr mem
```

Finally, you must cable the Cisco switch and the HiveAP together: Cisco 0/1 to HiveAP eth0, and Cisco 0/2 to HiveAP eth1.

Redundant Interface

If a single Ethernet link provides sufficient bandwidth and speed, such as a 1000 Mbps link, but you want to ensure link redundancy, you can connect the two Ethernet ports to the same switch—or to two different switches—and configure them to act as a redundant interface called "red0". In this mode, only one Ethernet interface is actively forwarding traffic at any one time. If eth0 is active and eth1 is passive and eth0 loses its connection, the HiveAP switches over to eth1. To configure a redundant interface, enter the following commands:

```
interface eth0 bind red0 primary
interface eth1 bind red0
```

The interface that you specify as primary is the one that the HiveAP uses when both interfaces have network connectivity. Because the HiveAP uses eth0 as the primary interface, it is unnecessary to specify "primary" in the first command above. However, it is included to make the role of eth0 as the primary interface obvious.

Note: No extra configuration is necessary on the connecting switch or switches to support a redundant interface.

Interface Selection for the Default Route


In cases where there are multiple active interfaces in backhaul mode, the HiveAP uses the following logic to choose which interface to use in its default route:

- If there is an Ethernet interface and a wireless interface in backhaul mode, the HiveAP uses the Ethernet interface in its default route.
- If there are multiple Ethernet interfaces in backhaul mode, the HiveAP chooses which one to use in its default route in the following order:
 - It uses red0 or agg0 if one of them has at least one member interface bound to it and its link state is UP.
 - It uses ETH0 if neither red0 nor agg0 has any member interfaces and the link state for ETH0 is UP.
 - It uses ETH1 if neither red0 nor agg0 has any member interfaces, the link state for ETH0 is DOWN, and the link state for ETH1 is UP.

Console Port


The pin-to-signal mapping in the RJ-45 console port is shown in [Figure 3](#).

Figure 3 Console Port Pin Assignments



To make a serial connection between your management system and the HiveAP, you can use the console cable that is available as an extra option. Insert the RJ-45 connector into the HiveAP 340 console port, and attach the DB-9 connector to the serial (or COM) port on your management system. The management system must have a VT100 terminal emulation program, such as Tera Term Pro[®] (a free terminal emulator) or Hilgraeve Hyperterminal[®] (provided with Windows[®] operating systems). If you want to make your own serial cable and adapter, refer to [Figure 3](#).

Figure 4 Wiring Details for Making a Serial Cable with an RJ-45-to-Female DB-9 Adapter



Console Port (HiveAP 340)	RJ-45-to-RJ-45 Rollover Cable		RJ-45-to-Female DB-9 Adapter		Management System
Signal	RJ-45 Pin	RJ-45 Pin	RJ-45 Pin	DB-9 Pin	Signal
RTS (Request to Send)	1	8	1	8	CTS (unused)
DTR (Data Terminal Ready)	2	7	2	6	DSR (unused)
TXD (Transmitted Data)	3	6	3	2	RXD
Ground	4	5	4	5	Ground
Ground	5	4	5	5	Ground
RXD (Received Data)	6	3	6	3	TXD
DSR (Data Set Ready)	7	2	7	4	DTR (unused)
CTS (Clear to Send)	8	1	8	7	RTS (unused)
-	-	-	-	9	RI (Ring Indicator, unused)

Status LEDs

The five status LEDs on the top of the HiveAP 340 indicate various states of activity through their color (dark, green, amber, and red) and illumination patterns (steady glow or pulsing). The meanings of the various color + illumination patterns for each LED are explained below.

Power

- Dark: No power
- Steady green: Powered on and the firmware is running normally
- Pulsing green: Firmware is booting up
- Steady amber: Alarm indicating a firmware issue has occurred
- Pulsing amber: Firmware is being updated
- Steady red: Alarm indicating a hardware issue has occurred

ETH0 and ETH1

- Dark: Ethernet link is down or disabled
- Steady green: 1000 Mbps Ethernet link is up but inactive
- Pulsing green: 1000 Mbps Ethernet link is up and active
- Steady amber: 10/100 Mbps Ethernet link is up but inactive
- Pulsing amber: 10/100 Mbps Ethernet link is up and active

WIFI0 and WIFI1


- Dark: Wireless interface is disabled
- Steady green: Wireless interface is in access mode but inactive
- Pulsing green: Wireless interface is in access mode and active
- Steady amber: Wireless interface is in backhaul mode but inactive
- Pulsing amber: Wireless interface is in backhaul mode and active
- Alternating green and amber: Wireless interface is in backhaul mode and is searching for other hive members

Antennas

The HiveAP 340 can accept up to six detachable dipole antennas. The three shorter antennas are designed for the 5 GHz band and have a 2-dBi gain. The three longer antennas are designed for the 2.4 GHz band and have a 4.9-dBi gain. These antennas are omnidirectional, providing fairly equal coverage in all directions in a toroidal (donut-shaped) pattern around each antenna (see [Figure 4 on page 28](#)). For greater coverage on a horizontal plane, it is best to orient the antennas vertically. So that you can easily do that whether the HiveAP chassis is mounted horizontally or vertically, the antennas hinge and swivel (see [Figure 5 on page 53](#).)

Although hive members automatically adjust their signal strength according to their environments, you can resize the area of coverage by increasing or decreasing the signal strength manually by entering the `interface { wifi0 | wifi1 } radio power <number>` command, where `<number>` can be from 1 to 20 and represents a value in dBm.


Figure 5 HiveAP 340 Antennas



MIMO

MIMO (Multiple In, Multiple Out) is a major WLAN advancement introduced in the IEEE 802.11n standard in which multiple RF links are formed on the same channel between the transmitter and receiver simultaneously. To accomplish this, the transmitter separates a single data stream into multiple spatial streams, one for each RF chain (an antenna + various digital signal processing modules linked to the antenna). The transmit antennas at the end of each RF chain then transmit their spatial streams. The recipient's receive antennas obtain streams from all the transmit antennas. In fact, due to multipath, they receive multiple streams from each transmit antenna. The receive antennas pass the spatial streams to the digital signal processors in their RF chains, which take the best data from all the spatial streams and reassemble them into a single data stream once again (see Figure 6).

Figure 6 2x2 MIMO (2 Transmit Antennas x 2 Receive Antennas)




In previous 802.11 standards, access points and clients each employed a single set of components, or RF chain, for transmitting or receiving. Although two antennas are often used for diversity, only the one with the best signal-to-noise ratio is used at any given moment, and that antenna makes use of the single RF chain while the other antenna remains inactive. A significant improvement that MIMO introduces is to permit each antenna to have its own RF chain and for all antennas to function simultaneously. For the HiveAP 340, you can connect up to three antennas per radio and configure the radio to use two or three transmit chains and two or three receive chains.¹ Using two or three transmit and receive chains simultaneously increases the amount of data that can flow across the WLAN and accelerates the processing of that data at each end of the wireless link.

Another major aspect of MIMO is how it turns multipath signals from a curse to a boon. As a radio signal moves through space, some objects reflect it, others interfere with it, and still others absorb it. The receiver can end up receiving multiple copies of the original signal, all kind of muddled together. However, the digital signal processors in the multiple receive chains are able to combine their processing efforts to sort through all the received data and reconstruct the original message. Furthermore, because the transmitter makes use of multiple RF chains, there is an even richer supply of signals for the receive chains to use in their processing. To set the transmit and receive RF chains for a radio profile, enter the following commands:

```
radio profile <name> transmit-chain { 2 | 3 }
radio profile <name> receive-chain { 2 | 3 }
```

There are two sets of antennas—three antennas per set—that operate concurrently in two different frequency ranges: 2.4 GHz (IEEE 802.11b/g/n) and 5 GHz (IEEE 802.11a/n). Using two different frequency ranges reduces the probability of interference that can occur when numerous channels operate within the same range. Conceptually, the relationship of antennas and radios is shown in [Figure 7](#).

Figure 7 Antennas and Radios



Cut-away view of the HiveAP 340 to show the relationship of the antennas and the two internal radios

The wlan0 interface links to radio 1 (frequency range = 2.4 GHz for IEEE 802.11b/g), and the wlan1 interface links to radio 2 (frequency range = 5 GHz for IEEE 802.11a). These interface-to-radio relationships are permanent.

When deciding how many antennas to use, consider the types of wireless clients—802.11n only, 802.11g/n, 802.11b/g/n, or 802.11a/n—the area needing coverage, and the RF environment.

1. The convention for presenting the configuration of transmitting and receiving MIMO RF chains is TxR. For example, a HiveAP 340 radio functioning in access mode might be configured to use two RF chains for transmitting and three for receiving. In that case, its configuration can be presented as "2x3". In general, the number of receive antennas is equal to or greater than the number of transmit antennas.

Using MIMO with Legacy Clients

In addition to supporting up to 300-Mbps throughput per radio for 802.11n clients, MIMO (Multiple In, Multiple Out) can improve the reliability and speed of legacy 802.11a/b/g client traffic. When an 802.11a/b/g access point does not receive acknowledgement that a frame it sent was received, it resends that frame, possibly at a somewhat lower transmission rate. If the access point must continue resending frames, it will continue lowering its transmission rate. As a result, clients that could get 54-Mbps throughput in an interference-free environment might have to drop to 48- or 36-Mbps speeds due to multipath interference. However, because MIMO technology makes better use of multipath, an access point using MIMO can continue transmitting at 54 Mbps, or at least at a better rate than it would in a pure 802.11a/b/g environment, thus improving the reliability and speed of 802.11a/b/g client traffic.

Although 802.11a/b/g client traffic can benefit somewhat from an 802.11n access point using MIMO, supporting such legacy clients along with 802.11n clients can have a negative impact on 802.11n client traffic. Legacy clients take longer to send the same amount of data as 802.11n clients. Consequently, legacy clients consume more airtime than 802.11n clients do, causing greater congestion in the WLAN and reducing 802.11n performance.

By default, the HiveAP 340 supports 802.11a/b/g clients. You can restrict access only to clients using the IEEE 802.11n standard. By only allowing traffic from clients using 802.11n, you can increase the overall bandwidth capacity of the access point so that there will not be an impact on 802.11n clients during times of network congestion. To do that, enter the following command:

```
radio profile <string> 11n-clients-only
```

You can also deny access just to clients using the IEEE 802.11b standard, which has the slowest data rates of the three legacy standards, while continuing to support 802.11a and 802.11g clients. To do that, enter the following command:

```
no radio profile <string> allow-11b-clients
```

By blocking access to 802.11b clients, their slower data rates cannot clog the WLAN when the amount of wireless traffic increases.

MOUNTING THE HIVEAP 340


Using the mounting plate and track clips, you can mount the HiveAP 340 to the tracks of a dropped ceiling grid. Using just the mounting plate, you can mount the HiveAP to any surface that can support its weight (3.3 lb., 1.5 kg).

Ceiling Mount

To mount the HiveAP 340 to a track in a dropped ceiling, you need the mounting plate, two track clips, and two Keps nuts that ship as an option with the HiveAP 340. You also need a wrench and—most likely—a ladder.

Nudge the ceiling tiles slightly away from the track to clear some space. Attach the track clips to the ceiling track, and then fasten the mounting plate to the clips, as shown in [Figure 8](#). When you have the mounting plate in the correct location, cut or drill a hole in the ceiling through which you can then pass the Ethernet and power cables.


Figure 8 Attaching the Track Clips and Mounting Plate to the Ceiling Track



Attach the HiveAP 340 to the mounting plate and connect the cables, as shown in [Figure 9](#) on page 57.

Note: You can tie the cables to the tie points (small arched strips) on the mounting plate to prevent them from being pulled out of their connections accidentally.

Figure 9 Attaching the HiveAP 340 to the Mounting Plate and Connecting Cables



When done, adjust the ceiling tiles back into their former position.

Locking the HiveAP 340


To lock the HiveAP 340 to the mounting plate, use either a Kensington lock or the lock adapter that is included with the mounting kit and a small padlock (not included).

To use a Kensington lock, loop the cable attached to the lock around a secure object, insert the T-bar component of the lock into the device lock slot on the HiveAP, and then turn the key to engage the lock mechanism.

To use the lock adapter :

1. Insert the T-shaped extension on the adapter into the device lock slot, and rotate it clockwise so that the curved section extends through the slot in the mounting plate (see [Figure 10](#)).

Figure 10 Locking the HiveAP 340 to the Mounting Plate



2. Link a padlock through the opening in the adapter and engage the lock to secure the HiveAP 340 to the mounting plate. The opening is 1/8" (0.3 cm) in diameter at its narrowest.


Surface Mount

You can use the mounting plate to attach the HiveAP 340 to any surface that supports its weight, and to which you can screw or nail the plate. First, mount the plate to the surface. Then, through one of the two large openings in the plate, make a hole in the wall so that you can pass the cables through to the HiveAP.

Note: You can tie the cables to the tie points on the mounting plate to prevent them from being pulled out of their connections accidentally.

Finally, attach the device to the plate, and connect the cables, as shown in [Figure 11](#).

Figure 11 Mounting the HiveAP on a Wall



DEVICE, POWER, AND ENVIRONMENTAL SPECIFICATIONS

Understanding the range of specifications for the HiveAP 340 is necessary for optimal deployment and device operation. The following specifications describe the physical features and hardware components, the power adapter and PoE (Power over Ethernet) electrical requirements, and the temperature and humidity ranges in which the device can operate.

Device Specifications

- Chassis dimensions: 8 3/8" W x 1 1/8" H x 8" D (21.3 cm W x 3 cm H x 20.3 cm D)
- Weight: 3 lb. (1.36 kg)
- Antennas: Three omnidirectional 802.11b/g/n antennas, and three omnidirectional 802.11a/n antennas
- Serial port: DB-9 (bits per second: 9600, data bits: 8, parity: none, stop bits: 1, flow control: none)
- Ethernet port: autosensing 10/100Base-T/TX Mbps, with IEEE 802.3af-compliant PoE (Power over Ethernet)

Power Specifications

- AC/DC power adapter:
 - Input: 100 - 240 VAC
 - Output: 48V/0.38A
- PoE nominal voltages:
 - Input: 48 V/0.35A
 - Output: 48 V/0.625A
- RJ-45 power input pins: Wires 4, 5, 7, 8 or 1, 2, 3, 6

Environmental Specifications

- Operating temperature: -4 to 131 degrees F (-20 to 55 degrees C)
- Storage temperature: -40 to 176 degrees F (-40 to 80 degrees C)
- Relative Humidity: Maximum 95%

Chapter 5 The HiveManager Platform

The HiveManager Network Management System provides centralized configuration, monitoring, and reporting for multiple HiveAPs. The following are a few of the many benefits that a HiveManager offers:

- Simplified installations and management of up to 500 HiveAPs
- Profile-based configurations that simplify the deployment of large numbers of HiveAPs
- Scheduled firmware upgrades on HiveAPs by location
- Exportation of detailed information on HiveAPs for reporting

This chapter covers the following topics related to the HiveManager platform:

- ["Product Overview" on page 62](#)
 - ["Ethernet and Console Ports" on page 63](#)
 - ["Status LEDs" on page 64](#)
- ["Rack Mounting the HiveManager" on page 65](#)
- ["Device, Power, and Environmental Specifications" on page 66](#)

PRODUCT OVERVIEW

The Aerohive HiveManager is a central management system for configuring and monitoring HiveAPs. You can see its hardware components in [Figure 1](#) and read a description of each component in [Table 1](#).

Figure 1 HiveManager Hardware Components




Table 1 HiveManager Component Descriptions


Component	Description
Mounting Brackets	The two mounting brackets allow you to mount the HiveManager in a standard 19" (48.26 cm) equipment rack. You can also move the brackets to the rear of the chassis if you need to reverse mount it.
Console Port	A male DB-9 serial port to which you can make a console connection using an RS-232 (or "null modem") cable. The pin assignments are the same as those on the HiveAP (see "Ethernet and Console Ports" on page 26). The management station from which you make a serial connection to the HiveManager must have a VT100 emulation program, such as Tera Term Pro [®] (a free terminal emulator) or Hilgraeve Hyperterminal [®] (provided with Windows [®] operating systems). The following are the serial connection settings: bits per second: 9600, data bits: 8, parity: none, stop bits: 1, flow control: none. The default login name is <i>admin</i> and the password is <i>aerohive</i> . After making a connection, you can access the Linux operating system.

Component	Description
USB Port	The USB port is reserved for internal use.
Status LEDs	The status LEDs convey operational states for the system power and hard disk drive. For details, see "Status LEDs" on page 64 .
MGT and LAN Ethernet Ports	The MGT and LAN Ethernet ports are compatible with 10/100/1000-Mbps connections, automatically negotiate half- and full-duplex mode with the connecting devices, and support RJ-45 connectors. They are autosensing and automatically adjust to straight-through and cross-over Ethernet cables. The two ports allow you to separate traffic between the HiveManager and its administrators from traffic between the HiveManager and the HiveAPs it manages.
System Fans	The two system fans maintain an optimum operating temperature. Be sure that air flow through the system fan vents is not obstructed.
Serial Number Label	The serial number label contains the FCC compliance stamp, model number, input power specifications, and serial number for the device.
AC Power Inlet	The three-prong AC power inlet is a C14 chassis plug through which you can connect a HiveManager to a 100 - 240-volt AC power source using the 10-amp/125-volt IEC power cord that ships with the product.
On/Off Switch	The on () and off (O) switch controls the power to the HiveManager.
Power Fan	The fan that maintains the temperature of the power supply.

Ethernet and Console Ports

The two 10/100/1000-Mbps Ethernet ports on the HiveManager labeled MGT and LAN use standard RJ-45 connector pin assignments that follow the TIA/EIA-568-B standard (see [Figure 2](#)). They accept standard types of Ethernet cable—cat3, cat5, cat5e, or cat6. Because the ports have autosensing capabilities, the wiring termination in the Ethernet cables can be either straight-through or cross-over.

Figure 2 Ethernet Port LEDs and Pin Assignments




The Ethernet ports are auto-sensing and can automatically adjust to transmit and receive data over straight-through or cross-over Ethernet connections. For a diagram showing T568A and T568B wiring, see ["Ethernet and Console Ports" on page 26](#).

Note: The default IP address/netmask for the MGT interface is 192.168.2.10/24. For the LAN interface, the default IP address/netmask is 192.168.3.10/24. The IP address of the default gateway is 192.168.2.1.

The pin assignments in the male DB-9 console port follow the EIA (Electronic Industries Alliance) RS-232 standard. To make a serial connection between your management system and the console port on the HiveManager, you can use a null modem serial cable, use another serial cable that complies with the RS-232 standard, or refer to the pin-to-signal mapping shown in Figure 3 to make your own serial cable. Connect one end of the cable to the console port on the HiveManager and the other end to the serial (or COM) port on your management system. The management system must have a VT100 terminal emulation program, such as Tera Term Pro[®] (a free terminal emulator) or Hilgraeve Hyperterminal[®] (provided with Windows[®] operating systems).

Figure 3 Console Port Pin Assignments




The serial connection settings are as follows:

- Bits per second: 9600
- Data bits: 8
- Parity: none
- Stop bits: 1
- Flow control: none

Status LEDs

The two status LEDs on the front of the HiveManager indicate various states of activity through their color (dark, green, amber) and illumination patterns (steady glow or blinking). The meanings of the various color + illumination patterns for each LED are shown in Figure 4.


Figure 4 Status LEDs



RACK MOUNTING THE HIVE MANAGER

You can mount the HiveManager in a standard 19" (48 cm) equipment rack with two rack screws—typically 3/4", 1/2", or 3/8" long with 10-32 threads. The HiveManager ships with mounting brackets already attached to its left and right sides near the front panel (see [Figure 1 on page 62](#)). In this position, you can front mount the HiveManager as shown in [Figure 5](#). Depending on the layout of your equipment rack, you might need to mount the HiveManager in reverse. To do that, move the brackets to the left and right sides near the rear before mounting it.

Figure 5 Mounting the HiveManager in an Equipment Rack



1. Position the HiveManager so that the holes in the mounting brackets align with two mounting holes in the equipment rack rails.
2. Insert a screw through a washer, the hole in one of the mounting brackets, and a hole in the rail.
3. Tighten the screw until it is secure.
4. Repeat steps 2 and 3 to secure the other side of the HiveManager to the rack.

DEVICE, POWER, AND ENVIRONMENTAL SPECIFICATIONS

Understanding the range of specifications for the HiveManager is necessary for optimal deployment and operation of the device. The following specifications describe the physical features and hardware components, the electrical requirements for the power supply and cord, and the temperature and humidity ranges in which the device can operate.

Device Specifications

- Form factor: 1U rack-mountable device
- Chassis dimensions: 16 13/16" W x 1 3/4" H x 15 13/16" D (42.7 cm W x 4.4 cm H x 40.2 cm D)
- Weight: 13.75 lb. (6.24 kg)
- Serial port: male DB-9 RS-232 port (bits per second:9600, data bits: 8, parity: none, stop bits: 1, flow control: none)
- USB port: standard Type A USB 2.0 port
- Ethernet ports: MGT and LAN – autosensing 10/100/1000Base-T Mbps

Power Specifications

- ATX (Advanced Technology Extended) autoswitching power supply with PFC (power factor corrector):
 - Input: 100 - 240 VAC
 - Output: 250 watts
- Power supply cord: Standard three conductor SVT 18AWG cord with an NEMA5-15P three-prong male plug and three-pin socket

Environmental Specifications

- Operating temperature: 32 to 140 degrees F (0 to 60 degrees C)
- Storage temperature: -4 to 176 degrees F (-20 to 80 degrees C)
- Relative Humidity: 10% - 90% (noncondensing)

Chapter 6 The High Capacity HiveManager Platform

The High Capacity HiveManager is a management system that provides centralized configuration, monitoring, and reporting for multiple HiveAPs. The following are a few of the many benefits that a HiveManager offers:

- Simplified installations and management of up to 5000 HiveAPs
- Profile-based configurations that simplify the deployment of large numbers of HiveAPs
- Scheduled firmware upgrades on HiveAPs by location
- Exportation of detailed information on HiveAPs for reporting
- Hot swappable power supplies
- Cold swappable hard disk drives

This chapter covers the following topics related to the High Capacity HiveManager platform:

- ["Product Overview" on page 68](#)
- ["Rack Mounting the High Capacity HiveManager" on page 70](#)
- ["Replacing Power Supplies" on page 73](#)
- ["Replacing Hard Disk Drives" on page 74](#)
- ["Device, Power, and Environmental Specifications" on page 75](#)

PRODUCT OVERVIEW

The Aerohive High Capacity HiveManager is a central management system for configuring and monitoring HiveAPs. You can see its hardware components in [Figure 1](#) and read a description of each component in [Table 1](#).

Figure 1 High Capacity HiveManager Hardware Components




Table 1 High Capacity HiveManager Component Descriptions

Component	Description
Hard Disk Drive Trays	The two hard disk drive trays contain first-level RAID (Redundant Array of Independent Drives) mirrored hard disk drives to provide fault tolerance, data reliability, and increased performance.
Front Mounting Brackets	When used with the rack mounting kit, the two front mounting brackets allow you to mount the High Capacity HiveManager in a standard 19" (48.26 cm) equipment rack. For rack mounting instructions, see "Rack Mounting the High Capacity HiveManager" on page 70.
USB Ports	The USB ports are reserved for internal use.

Component	Description
Console Port	<p>A male DB-9 serial port to which you can make a console connection using an RS-232 (or "null modem") cable. The pin assignments are the same as those on the HiveManager and on the HiveAP (see "Ethernet and Console Ports" on page 26).</p> <p>The management station from which you make a serial connection to the HiveManager must have a VT100 emulation program, such as Tera Term Pro[®] (a free terminal emulator) or Hilgraeve Hyperterminal[®] (provided with Windows[®] operating systems). The following are the serial connection settings: bits per second: 9600, data bits: 8, parity: none, stop bits: 1, flow control: none. The default login name is <i>admin</i> and the password is <i>aerohive</i>. After making a connection, you can access the Linux operating system.</p>
MGT and LAN Ethernet Ports	<p>The MGT and LAN Ethernet ports are compatible with 10/100/1000-Mbps connections, automatically negotiate half- and full-duplex mode with the connecting devices, and support RJ-45 connectors. They are autosensing and automatically adjust to straight-through and cross-over Ethernet cables. The two ports allow you to separate traffic between the HiveManager and its administrators from traffic between the HiveManager and the HiveAPs it manages. The wiring terminates the same way as that on the standard capacity HiveManager (see "Ethernet and Console Ports" on page 63).</p>
Reset Button	<p>The reset button allows you to reboot the High Capacity HiveManager. Insert a paper clip, or something similar, into the hole and press the reset button between 1 and 5 seconds. After releasing the button, the Power LED goes dark, and then glows steady amber while the software loads and the system performs a self-test. After the software finishes loading, the Power LED glows steady green.</p>
Power LED	<p>The power LED conveys the operational states for the system power: dark = no power; steady green = powered on.</p>
On/Off Switch	<p>The on and off switch controls the power to the HiveManager.</p>
Serial Number Label	<p>The serial number label contains the serial number for the device.</p>
System Fans	<p>The three system fans maintain an optimum operating temperature. Be sure that air flow through the system fan vents is not obstructed.</p>
Dual AC Power Supplies	<p>There are two power supplies. Each three-prong AC power inlet is a C14 chassis plug through which you can connect the HiveManager to a 100 - 240-volt AC power source using the 10-amp/125-volt IEC power cords that ship with the product. By cabling each power supply to a different source, they provide redundancy in the event of a single power failure. Each power supply has a fan that maintains its temperature. It is important that nothing obstructs the air flow to these fans so that the power supplies do not overheat.</p>

RACK MOUNTING THE HIGH CAPACITY HIVEMANAGER


Use the rack mounting kit to mount the High Capacity HiveManager in a standard 19" (48 cm) equipment rack. The rack mounting kit contains the following items:

- (2) slide sets (each consisting of an outer slide, inner slide, and chassis rail)
- (2) rear mounting brackets
- (4) bar nuts
- (4) locator pins
- (6) slot-head machine screws with 8-32 threads - for attaching the mounting brackets to the outer slides
- (14) cross-head machine screws with 10-32 threads - for attaching the chassis rails to the HiveManager, and the front and the rear mounting brackets to equipment rack rails with tapped holes or to the enclosed bar nuts when the rack rails have round holes

Note: Because of the weight of the device (34 lb./ 15.42 kg without rails) , two people are required to rack mount it safely.


1. After checking that the mounting kit contains the above parts, separate the chassis rails from each slide set, as shown in [Figure 2](#).

Figure 2 Separating the Chassis Rail from the Nested Slides




2. Position one of the chassis rails so that the slide stop is near the HiveManager mounting bracket near the front panel and the front and rear holes in the chassis rail align with the holes in the side of the HiveManager. Use three of the cross-head screws to secure the chassis rail to the HiveManager chassis as shown in [Figure 3](#) on [page 71](#).

Figure 3 Attaching the Chassis Rail to the HiveManager




3. Secure the other chassis rail to the other side of the HiveManager.
4. Use three slot-head screws to attach the rear mounting bracket to the outer slide. Insert the screws through the rounded slots in the outer slide into the threaded holes in the bracket and tighten them as shown in Figure 4.

Figure 4 Attaching the Rear Bracket to the Outer Slide




5. Use the remaining three slot-head screws to attach the other rear mounting bracket to the other outer slide.
6. Fasten the rear mounting brackets—and the slides attached to them—to the rear equipment rack rails. Depending on the type of holes in the equipment rack, use one of the following methods:
 - For tapped (threaded) holes, use two screws to fasten the brackets directly to the rack rails. Use the cross-head screws (with 10-32 threads) if they fit the holes in the rack.
 - For round holes, use the cross-head screws to fasten the brackets through the holes in the rack rails to the bar nuts. You can use the locator pins to help keep the bar nuts aligned to the holes. See Figure 5.

Figure 5 Fastening the Rear Mounting Brackets to the Rack Rails



7. From the front of the equipment rack, guide the chassis rails on the sides of the HiveManager into the inner slides. Then push the HiveManager into the rack until the front mounting brackets are flush against the front rack rails.
8. Using four screws—two for each of the front brackets—fasten the HiveManager to the equipment rack as shown in [Figure 6](#). If the rack has round holes, use the two remaining nut bars (and locator pins) and thread the screws through the rack rails into them.

Figure 6 Mounting the HiveManager in an Equipment Rack



The HiveManager is now securely mounted to the front and rear rails of the equipment rack.


REPLACING POWER SUPPLIES

The high capacity HiveManager has a pair of redundant, hot-swappable power supplies. If one of the power supplies fails, the other will continue to power the device. When a power supply fails, a continuous beeping alarm sounds and the power LED glows amber. To replace the failed power supply, do the following:

1. Disconnect the failed power supply from the power source.
2. Lower the handle to a horizontal position.
3. With your index finger, press the red release lever to the left.
4. While holding the release lever to the left, grip the handle between your thumb and second finger, and pull the power supply straight out. See [Figure 7](#).

Figure 7 Removing a Power Supply

Rear of High Capacity HiveManager (bird's eye view)




5. Insert a working power supply into the vacant bay and push it straight in until it is fully seated.
The red release automatically slides back to the right to secure the power supply in place.
6. Connect the power supply to the power source.

REPLACING HARD DISK DRIVES

To provide fault tolerance from disk errors and single disk failure, the high capacity HiveManager uses level 1 RAID (Redundant Array of Independent Drives) HDDs (hard disk drives). Each HDD holds identical data, the data that is written to one disk being mirrored to the other. The lower LEDs on the front of each HDD flash in unison to indicate that they are writing data to memory. The upper LEDs indicate that they have power. See [Figure 8](#).

Figure 8 Hard Disk Drive LEDs



If you notice that only one of the lower LEDs is flashing while the other is dark, then there is a HDD failure. Although the HiveManager can continue with just one operational HDD, you should replace the faulty HDD soon.

Note: HiveManager HDDs are not hot swappable. You must turn off the power before replacing a HDD.

1. Turn off the HiveManager.
2. Unlock the HDD tray door for the disk that you want to replace.
3. Pull the tab on the left side of the door, and open the door, swivelling it on the hinge along its right side.
As you open the door, the HDD tray automatically extends.
4. Remove the failed HDD and insert a replacement

Note: The replacement disk drive must be new or, if it has been used, there must not be a root file system on it. Also, it must be the same size as or bigger than the other disk drive.

5. Close the door and lock it again.
6. Connect a serial cable to the console port
7. Connect one end of an RS-232 serial cable to the male DB-9 console port on the HiveManager and other end to the serial port (or COM port) on your management system.
8. Start a serial connection as explained in "[Changing Network Settings](#)" on page 79.
9. Turn on the HiveManager.
10. While it is booting up, press and hold down the CTRL+A keys until the utility console appears.
11. From the main menu, select **Manage Arrays**. (An array is the logical representation of a physical HDD unit.)
12. From the list of arrays, select the one that you want to rebuild.
13. Press CTRL+R to rebuild it.

The rebuild process takes about 30 minutes. When done, the utility console notifies you with a message.

14. Confirm that the process is complete.

The HiveManager continues booting up with the new HDD replacement in operation.

DEVICE, POWER, AND ENVIRONMENTAL SPECIFICATIONS

Understanding the range of specifications for the high capacity HiveManager is necessary for the optimal deployment and operation of the device. The following specifications describe the physical features and hardware components, the electrical requirements for the power supply and cord, and the temperature and humidity ranges in which the device can operate.

Device Specifications

- Form factor: 2U rack-mountable device
- Chassis dimensions: 16 13/16" W x 3 1/2" H x 17" D (42.7 cm W x 8.9 cm H x 43.2 cm D)
- Weight: 34 lb. (15.42 kg)
- Serial port: male DB-9 RS-232 port (bits per second:9600, data bits: 8, parity: none, stop bits: 1, flow control: none)
- USB port: standard Type A USB 2.0 port
- Ethernet ports: MGT and LAN – autosensing 10/100/1000Base-T Mbps

Power Specifications

- Redundant ATX (Advanced Technology Extended) autoswitching power supplies with PFC (power factor corrector):
 - Input: 100 - 240 VAC
 - Output: 700 watts
- Power supply cords: Standard three conductor SVT 18AWG cords with an NEMA5-15P three-prong male plug and three-pin socket


Environmental Specifications

- Operating temperature: 32 to 140 degrees F (0 to 60 degrees C)
- Storage temperature: -4 to 176 degrees F (-20 to 80 degrees C)
- Relative Humidity: 10% - 90% (noncondensing)

Chapter 7 Using HiveManager

You can conceptualize the Aerohive cooperative control architecture as consisting of three broad planes of communication. On the data plane, wireless clients gain network access by forming associations with HiveAPs. On the control plane, HiveAPs communicate with each other to coordinate functions such as best-path forwarding, fast roaming, and automatic RF (radio frequency) management. On the management plane, HiveManager provides centralized configuration, monitoring, and reporting of multiple HiveAPs. These three planes are shown in [Figure 1](#).

Figure 1 Three Communication Planes in the Aerohive Cooperative Control Architecture



As you can see in [Figure 1](#), HiveManager operates solely on the management plane. Any loss of connectivity between HiveManager and the HiveAPs it manages only affects HiveAP manageability; such a loss has no impact on communications occurring on the control and data planes.

This chapter explains how to do the following basic tasks:

- Use the console port to change the network settings for the MGT and LAN interfaces
- Power on HiveManager and connect it to a network
- Make an HTTPS connection from your management system to HiveManager and log in to the GUI

It then introduces the HiveManager GUI and includes a summary of the configuration workflow. Finally, the chapter concludes with procedures for updating HiveManager software and HiveAP firmware. The sections are as follows:

- ["Installing and Connecting to the HiveManager GUI" on page 79](#)
- ["Introduction to the HiveManager GUI" on page 82](#)
 - ["Cloning Configurations" on page 83](#)
 - ["Multiselecting" on page 83](#)
 - ["Sorting Displayed Data" on page 84](#)
- ["HiveManager Configuration Workflow" on page 85](#)
- ["Updating Software on HiveManager" on page 86](#)
- ["Updating HiveOS Firmware" on page 87](#)
 - ["Updating HiveAPs in a Mesh Environment" on page 88](#)

INSTALLING AND CONNECTING TO THE HIVEMANAGER GUI

To begin using the HiveManager GUI, you must first configure the MGT interface to be accessible on the network, cable HiveManager and your management system (that is, your computer) to the network, and then make an HTTP connection from your system to the MGT interface and download the GUI application.

Note: HiveManager has two Ethernet interfaces—MGT and LAN. You can put just the MGT interface on the network and use it for all types of traffic, or you can use both interfaces—which must be in different subnets—and separate HiveManager management traffic (MGT) from HiveAP management traffic (LAN).

Besides HiveManager and your management system, you need two or three Ethernet cables and a serial cable (or "null modem"). The Ethernet cables can be standard cat3, cat5, cat5e, or cat6 cables with T568A or T568B terminations and RJ-45 connectors. The serial cable must comply with the RS-232 standard and terminate on the HiveManager end with a female DB-9 connector. (For more details, see ["Ethernet and Console Ports" on page 63.](#))

The GUI requirements for the management system are as follows:

- Minimum screen resolution of 1024 x 768 pixels
- Standard browser—Aerohive recommends Internet Explorer v7.0 or Mozilla Firefox v2.0.0 or later—with Flash v9.0 or later, which is required for viewing charts with dynamically updated HiveAP alarms and wireless client data

Your management system also needs a VT100 terminal emulation program, such as Tera Term Pro[®] (a free terminal emulator) or Hilgraeve Hyperterminal[®] (provided with Windows[®] operating systems).

Changing Network Settings

To connect HiveManager to the network, you must first set the IP address/netmask of its MGT interface so that it is in the subnet to which you plan to cable it. To do this, you can use the startup wizard that is available through the console port.

1. Connect the power cable to a 100 - 240-volt power source, and turn on HiveManager. The power switch is on the back panel of the device.
2. Connect one end of an RS-232 serial cable to the serial port (or COM port) on your management system.
3. Connect the other end of the cable to the male DB-9 console port on HiveManager.
4. On your management system, run a VT100 emulation program using the following settings:
 - Bits per second (baud rate): 9600
 - Data bits: 8
 - Parity: none
 - Stop bits: 1
 - Flow control: none
5. Log in by entering the default user name (*admin*) and password (*aerohive*).
6. The HiveManager CLI shell launches and offers several options. To change network settings, enter **1**
7. Follow the instructions to configure the IP address and netmask for the MGT (and LAN) interfaces, as well as the default gateway, host name and domain name of HiveManager, and its primary DNS server.

Note: The default IP address/netmask for the MGT interface is 192.168.2.10/24. For the LAN interface, it is 192.168.3.10/24. The default gateway IP address is 192.168.2.1. If you only use the MGT interface, change the LAN interface network settings to 0.0.0.0/0. Do not assign it an IP address and netmask.


When deciding to use one interface (MGT) or both (MGT and LAN), keep in mind that there are two main types of traffic to and from HiveManager:

- HiveManager management traffic for admin access and SCP (Secure Copy) uploads

- HiveAP management traffic for CAPWAP, SNMP monitoring and notifications, and SCP configuration, captive web portal file, and HiveOS firmware uploads to managed HiveAPs

When you enable both interfaces, HiveManager management traffic uses the MGT interface while HiveAP management traffic uses the LAN interface, as shown in Figure 2.

Figure 2 Using Both MGT and LAN Interfaces



Static Routes: HiveManager sends traffic destined for 10.1.6.0/24 to 10.1.2.1.


HiveManager sends traffic destined for 10.1.7.0/24 to 10.1.2.1.

Default Gateway: 10.1.1.1 (HiveManager sends traffic here when there are no specific routes to a destination.)

Note: To set static routes after you log in to the GUI, click HM Admin > HiveManager Settings > Routing > Add, set the destination IP address/netmask and gateway, and then click Apply.

When only the MGT interface is enabled, both types of management traffic use it. A possible drawback to this approach is that the two types of management traffic cannot be separated into two different networks. For example, if you have an existing management network, you would not be able to use it for HiveManager management traffic. Both HiveManager and HiveAP management traffic would need to flow on the operational network because HiveManager would need to communicate with the HiveAPs from its MGT interface (see Figure 3). However, if the separation of both types of traffic is not an issue, then using just the MGT interface is a simple approach to consider.

Figure 3 Using Just the MGT Interface



Default Gateway: 10.1.1.1 (HiveManager sends all traffic to the default gateway.)

8. After you finish configuring the network settings, return to the main menu, and reboot the HiveManager appliance by entering 5 (5 Reboot HM Appliance).

You can now disconnect the serial cable.


Connecting to the GUI through the MGT Interface

1. Connect Ethernet cables from the MGT interface and LAN interface—if you are using it—to the network.
2. Connect an Ethernet cable from your management system to the network so that you can make an HTTPS connection to the IP address that you set for the MGT interface.
3. Open a web browser and enter the IP address of the MGT interface in the address field. For example, if you changed the IP address to 10.1.1.8, enter this in the address field: `https://10.1.1.8`


Note: If you ever forget the IP address of the MGT interface and cannot make an HTTP connection to HiveManager, make a serial connection to its console port and enter this command: `ifconfig`. The output displays data about the MGT interface (internally called "eth0"), including its IP address. The serial connection settings are explained in "Changing Network Settings" on page 79.

A login prompt appears.

4. Type the default user name (*admin*) and password (*aerohive*) in the login fields, and then click **Login**.



5. If prompted to enter a license key, click **Browse**, navigate to and select the text file containing the license key that Aerohive provided when HiveManager was purchased, and then click **OK**.




You are now logged in to the HiveManager GUI. After logging in, you can check details about the license you installed on the HM Admin > License Management page.

INTRODUCTION TO THE HIVEMANAGER GUI

Using the HiveManager GUI, you can set up the configurations needed to deploy, manage, and monitor large numbers of HiveAPs. The configuration workflow is described in "HiveManager Configuration Workflow" on page 85. The GUI consists of several important sections, which are shown in Figure 4.

Figure 4 Important Sections of the HiveManager GUI




Some convenient aspects that the HiveManager GUI offers are the ability to clone configurations, apply configurations to multiple HiveAPs at once, and sort displayed information. Brief overviews of these functions are presented in the following sections.

Cloning Configurations

When you need to configure multiple similar objects, you can save time by configuring just the first object, cloning it, and then making slight modifications to the subsequent objects. With this approach, you can avoid re-entering repeated data.

Figure 5 Cloning a Hive

To clone an object, select it in an open window, and then click the **Clone** button. Retain the settings you want to keep, and modify those you want to change.




Multiselecting

You can select multiple objects to make the same modifications or perform the same operation to all of them at once.

Figure 6 Selecting Multiple New HiveAPs

Select the check boxes to select multiple noncontiguous objects, or shift-click to select check boxes for multiple contiguous objects.

Then click **Accept** to accept all the selected HiveAPs for HiveManager management, or click the **Modify** button to configure them with the same settings.



Here, you use the shift-click multiselection method to select a set of the topmost eight HiveAPs in the list; that is, you select the check box for the top HiveAP and hold down the SHIFT key while selecting the check box for the eighth HiveAP from the top.

Sorting Displayed Data


You can control how the GUI displays data in the main panel by clicking a column header. This causes the displayed content to reorder itself alphanumerically or chronologically in either ascending or descending order. Clicking the header a second time reverses the order in which the data is displayed.

Figure 7 Sorting Event Log Entries by HiveAP Host Name and then Chronologically

By default, displayed objects are sorted alphanumerically from the top by name. If you click the name again, the order is reversed; that is, the objects are ordered alphanumerically from the bottom.



By clicking the heading of a column, you can reorder the display of objects either alphanumerically or chronologically, depending on the content of the selected column. Here you reorder the data chronologically.




HIVEMANAGER CONFIGURATION WORKFLOW

Assuming that you have already installed your HiveAPs, uploaded maps (see ["Setting Up Topology Maps" on page 91](#)), accepted the HiveAPs for management, and decided on the features and settings you want to use, you are now ready to start configuring the HiveAPs through HiveManager¹. You can configure numerous objects, some of which might need to reference other objects. An efficient configuration strategy is to first define any objects that you will later need to use when configuring others. The typical workflow, shown in [Figure 8](#), proceeds like this:

1. Define network objects. You can then reference them when defining other parts of the configuration. If you do not plan to use network objects, you can skip this step.
2. Configure various features.
3. Define radio profiles (or use default settings).
- 4 and 5. Compile the features from step 2 into a WLAN policy, assign the radio profiles and WLAN policy to one or more HiveAPs, and then push the configurations to the physical devices on the network.

Figure 8 Configuration Workflow



1. When HiveAPs are in the same subnet as HiveManager, they can use CAPWAP (Control and Provisioning of Wireless Access Points) to discover HiveManager on the network. CAPWAP works within a layer-2 broadcast domain and is enabled by default on all HiveAPs. If the HiveAPs and HiveManager are in different subnets, then you can use one of several approaches to enable HiveAPs to connect to HiveManager. For information about these options, see ["How HiveAPs Connect to HiveManager" on page 95](#).

UPDATING SOFTWARE ON HIVEMANAGER

You can update the software running on HiveManager from either a local directory on your management system or an SCP (Secure Copy) server. If you download an image and save it to a local directory, you can load it from there. If you save the image to an SCP server, you can direct HiveManager to log in and load it from a directory there.

1. If you do not yet have an account on the Aerohive Support portal, send an email request to (support@aerohive.com) to set one up.
2. When you have login credentials, visit www.aerohive.com/support/login, and log in.
3. Navigate to the software image that you want to load onto HiveManager (Customer Support > Software Downloads > HiveManager software images) and download the file.
4. Save the HiveManager image file to a local directory or an SCP server.
5. Log in to HiveManager and navigate to **HM Admin > HiveManager Operations > Update Software**.
6. To load files from a directory on your local management system, choose either **Update and clear alarm and event logs** or **Full update** (to keep existing log entries after the upgrade), and then enter the following:
 - File from local host: (**select**); type the directory path and a file name; or click **Browse**, navigate to the software file, and select it.

or

To load a file from an SCP server:

- File from remote server: (**select**)
 - IP Address: Enter the IP address of the SCP server.
 - SCP Port: Enter the port number of the SCP server (the default port number for SCP is 22).
 - File Path: Enter the directory path and HiveManager software file name. If the file is in the root directory of the SCP server, you can simply enter the file name.
 - User Name: Type a user name with which HiveManager can access the SCP server.
 - Password: Type a password with which HiveManager can use to log in securely to the SCP server.
7. To save the new software and reboot HiveManager, click **OK**.

UPDATING HIVEOS FIRMWARE

HiveManager makes it easy to update HiveOS firmware running on managed HiveAPs. First, you obtain new HiveAP firmware from Aerohive Support and upload it onto HiveManager. Then you push the firmware to the HiveAPs and activate it by rebooting them.

Note: When upgrading both HiveManager software and HiveOS firmware, do so in this order:

- *Upgrade HiveManager (HiveManager can manage HiveAPs running the current version of HiveOS and also previous versions).*
- *Upload the new HiveOS firmware to the managed HiveAPs, and reboot them to activate it.*
- *Reload the HiveOS configurations to the managed HiveAPs—even if nothing in the configurations has changed—and reboot them to activate the configuration that is compatible with the new HiveOS image.*

1. Log in to the Aerohive Support portal to obtain a new HiveOS image.
2. Save the HiveOS image file to a directory on your local management system or network.
3. Log in to HiveManager and navigate to **Configuration > HiveAP File Management**.
4. On the HiveAP Files page, select **HiveOS Image** for the file type, enter one of the following—depending on how you intend to upload the HiveOS image file to HiveManager—and then click **OK**:

To load a HiveOS image file from a directory on your local management system:

- **Local File:** (select); type the directory path and image file name, or click **Browse**, navigate to the image file, and select it.

To load a HiveOS image file from an SCP server:

- **SCP Server:** (select) IP Address : Enter the IP address of the SCP server.
- **SCP Port:** Enter the port number of the SCP server (the default port number for SCP is 22).
- **File Path:** Enter the path to the HiveOS image file and the file name. If the file is in the root directory of the SCP server, you can simply enter the file name.
- **User Name:** Type a user name with which HiveManager can access the SCP server.
- **Password:** Type a password that HiveManager can use to log in securely to the SCP server.

*Note: To delete an old image file, select the file in the "Available Images" list, and then click **Remove**.*

5. Click **Access Points > Managed HiveAPs**.
6. In the Managed HiveAPs window, select one or more HiveAPs, and then click **Update > Upload and Activate SW Image**.

The Upload and Activate SW Image dialog box appears.

7. Enter the following, and then click **Upload**:
 - From the HiveOS Image drop-down list, select the image that you want to load onto managed HiveAPs.
 - In the Activation Time section, select one of the following options, depending on when you want to activate the software—by rebooting the HiveAPs—after HiveManager finishes loading it:
 - **Activate at:** Select and set the time at which you want the HiveAPs to activate the software. To use this option accurately, make sure that both HiveManager and managed HiveAP clocks are synchronized.
 - **Activate after:** Select to load the firmware on the selected HiveAPs and activate it after a specified interval. The range is 0 - 3600 seconds; that is, immediately to one hour. The default is 5 seconds.

- **Activate at next reboot:** Select to load the software and not activate it. The loaded software gets activated the next time the HiveAP reboots.

Note: When choosing which option to use, consider how HiveManager connects to the HiveAPs it is updating. See "Updating HiveAPs in a Mesh Environment".

- Select the check box for each HiveAP whose software you want to update.


Updating HiveAPs in a Mesh Environment

When updating hive members in a mesh environment, be careful of the order in which the HiveAPs reboot. If a portal completes the upload and reboots before a mesh point beyond it completes its upload—which most likely would happen because portals receive the uploaded content first and then forward it to mesh points—the reboot will interrupt the data transfer to the mesh point. This can also happen if a mesh point linking HiveManager to another mesh point reboots before the more distant mesh point completes its upload. As a result of such an interruption, the affected mesh point receives an incomplete firmware or configuration file and aborts the update.

Note: A mesh point is a hive member that uses a wireless backhaul connection to communicate with the rest of the hive. HiveManager manages mesh points through another hive member that acts as a portal, which links mesh points to the wired LAN.

Figure 9 HiveAPs in a Mesh Environment

When updating HiveAPs in a mesh environment, the HiveManager communicates with mesh points through their portal and, if there are any intervening mesh points, through them as well. While updating HiveAPs in such an environment, it is important to keep the path from the HiveManager to all HiveAPs clear so that the data transfer along that path is not disrupted. Therefore, when updating a firmware image or configuration on HiveAPs in a mesh environment, make sure that the portal or a mesh point closer to the portal does not reboot before the upload to a mesh point farther away completes.



To avoid the reboot of an intervening HiveAP from interfering with an ongoing upload to a mesh point beyond it, allow enough time for the firmware to reach the farthest mesh points before activating the firmware. After all the HiveAPs have the firmware, rebooting any HiveAPs between them and HiveManager becomes inconsequential.


Chapter 8 HiveManager Configuration Examples

The following examples in this chapter show how to install over 70 HiveAPs at three locations in a corporate network, use HiveManager to create configurations for them, and then push the configurations to them over the network. The high-level deployment scheme is as follows:

Headquarters - Building 1 (HQ-B1)	Headquarters - Building 2 (HQ-B2)	Branch Office (Branch1)
32 HiveAPs	32 HiveAPs	8 HiveAPs
1 Hive (hive1)	1 Hive (hive2)	1 Hive (hive3)
1 WLAN policy (WLANpolicy-hq1)	1 WLAN policy (WLANpolicy-hq2)	1 WLAN policy (WLANpolicy-branch1)

The general design of the deployment is shown in [Figure 1](#).

Figure 1 Deployment Overview



You can look at any of the following examples individually to study how to configure a specific feature or view all of them sequentially as a set to study the workflow for deploying large numbers of HiveAPs and configuring them through HiveManager.