

## 4 7390 LT software overview

### 4.1 General information

The purpose of this chapter is to **present** the different **screens** of the 7390 LT software supplied with the Base Station. The following chapters will make reference to this presentation each time the user needs to access the software for a particular action (commissioning, maintenance or evolution of the configuration). The same screen may apply for several types of action.

#### 4.1.1 Functionalities

The 7390 LT software enables:

- supervision of both the system assembly as a whole (the NE (Network Element)), and of its sub-assemblies (BS, NT);
- configuration of the sub-assemblies (DBS, RBS, etc.) (used when Commissioning, *Chapter 5 Commissioning the Base Station (7390BS)*);
- setting up services (E1 leased lines, T1 and X21, ISDN, IP cross-connection including VoIP, circuit emulation), (used when Commissioning, *Chapter 6 Operation and maintenance*);
- downloading, NE configuration back-up and restoration (used in Maintenance, *Chapter 6 Operation and maintenance*);
- display of the system redundancy state;
- management of external points.
- radio performances.





**Note:** *the 7390 LT software exchanges no information with the radio part of the terminal station (7390 RT). These generate no alarms, and therefore require no other configuration apart from the installation configuration.*

#### 4.1.2 Principles of the Man-Machine Interface (MMI) of the 7390 LT

The user of the 7390 LT software is expected to be familiar with the operation of software in the Windows NT<sup>MT</sup> environment. There follows a description of some of the basic principles of the Windows NT<sup>MT</sup> MMI along with others, more specific to the 7390 LT.

##### 4.1.2.1 Opening, closing and resizing a window

Here is a reminder of how the boxes at the top right of an active window are used:

Click on...	To.....
	... <b>minimize</b> the active window to place the application on the taskbar. Click on the taskbar icon to restore the window.
	... <b>maximize</b> the window to full-screen size.
	... <b>restore</b> a window which was in full-screen size to its original size.
	... <b>close</b> the active window.

#### 4.1.2.2 Entry fields



The **grayed out** fields are for **consultation only**: their content cannot be modified.






The **fields on a white background** can be **modified**: left-click to make the cursor appear inside the field, then enter the character string required.



According to the same principle, the buttons, icons and items in the pull-down menus become **grayed out** when they are **inactive**.

#### 4.1.2.3 Confirmation, closing a window, canceling an entry

In the lower part of the windows there may be **buttons** (which may or may not be active; cf. § 4.1.2.2 *Entry fields*), the principle of which is as follows:

Click on...	To.....
	... <b>confirm</b> the data entry, while keeping the window open.
	... <b>close</b> the active window, thereby cancelling any unconfirmed data entries.
	... <b>cancel</b> the data entry, while keeping the window open.

#### 4.1.2.4 Sorting and searching in a list

Some screens contain lists which may contain many lines; a sort and/or search tool is therefore available via the MMI, in order to facilitate data management:

Eqpt ID	Name	Terminal Station
2	NT #2	0
3	NT #3	0

Left-click once on any column **title** in order to **sort** the alphanumeric entries in **increasing order of magnitude**; click a **second time** to sort in the **opposite order** (and so on).

Eqpt ID	Name	Terminal Station

When the lists have **empty boxes above the titles**, it is possible to carry out a search to display the line required:

click on the box above the title under which to be searched, then enter the **first characters** of the sequence in question: the first line to correspond is selected.

#### 4.1.2.5 Selecting lines on a list

To select **a line**, click on it and it is highlighted in blue.

To select quickly **a zone**, click on the first line then select and hold down the 'Shift' key, then click on the last line of the desired zone. The zone becomes highlighted in blue.


To select **several non consecutive lines**, hold down the 'Ctrl' key then select line by line the desired elements.

#### 4.1.2.6 Title, menu, button and status message bars

The various information and functionalities of the 7390 LT are accessible in several forms of MMI:



**Title bars** (at the top of the main window): for information only; this is the title of the window.




**Menu bar** (below the title bar): each menu contains **items**. To access, open the pull-down menu by left-clicking on the title, then click on the desired item (for execution it must be active, cf. § 4.1.2.2 *Entry fields*).



**Button bar** (below the title bar): certain menu functionalities are also directly accessible by clicking on the buttons displayed at the top of the window.




**Message bar** (at the bottom of the active window): messages linked to current events are displayed on the fly in certain windows



**Status bar** (at the bottom of the 7390 LT main window), divided into 2 areas:

- on the left: global user's messages (states of progress, error messages, etc.)
- on the right: Local access: information about write access: cf. § 4.4.2 *Local access requests*
- Number of NTs: displays the number of NTs declared in the NE.
- Most critical alarm: displays the color of the most critical alarm (see alarm color codes, § 4.10.1.2 *Alarms color code*).

#### 4.1.2.7 Dynamic keys




Each time the cursor will stay a few seconds on a button (and on specific field), a textual key on a yellow background defining this button (or field) is displayed.

#### 4.1.3 Rearrangement of active windows


During the use of the 7390 LT software, several windows may be active simultaneously. The MMI allows you to rearrange them to optimize their visibility, in classic Windows fashion.

Access this function by opening the **Windows** pull-down menu:



- horizontal rearrangement: horizontal display of several windows
- vertical rearrangement: vertical juxtaposition of several windows
- cascade rearrangement: diagonal alignment of several windows
- list of active windows: select the particular one that you wish to display

## 4.1.4 Printing



**Note:** to know how to select lines in lists, see § 4.1.2.5 *Selecting lines on a list*.

## 4.2 Running and quitting the software

### 4.2.1 Installation of the 7390 LT software

The 7390 LT is either loaded on the PC which came with the BS, or comes on an installation medium (e.g., CD-ROM).

If you need to install the 7390 LT software, refer to the *Appendix 2 – Installation of 7390LT software*; otherwise, go directly to the next paragraph to run the already installed software.

	<b>ON THE ETHERNET PORT IT IS RECOMMENDED TO CONFIGURE ONLY ONE IP ADDRESS</b>
---	--

### 4.2.2 Accessing and running 7390 LT


To run 7390 LT, go to the Windows® taskbar and left-click on the «Start» button: the Start menu is displayed. Next, select the Programs menu followed by the line Craft\_Terminal.

or:



Click on the icon shown here which is on the Windows desktop.

To run the 7390 LT, the following screen is displayed:



Click here to **close** the *About* window and work on the main window of the 7390 LT. You can access it again by selecting the heading **About 7390 LT (Craft Terminal)** in the ? menu.

**Note: After NE connexion (cf. § 4.3.1 NE Connection), the database versions at the Manager and Agent sides must be identical.**

If the LT session cannot open, check if there is any other LT open session.

On the screen displayed, only **one** icon is **active**: the choice of language and the NE connection icon:




...click on this icon to access the **NE connection** (cf. comments in § 4.3.1 *NE Connection*)

### 4.2.3 Quitting the 7390 LT



To quit the 7390LT, open the **Management** pull-down menu and click on » *Quit*»

A confirmation dialog box is displayed:



Click here to **confirm** quitting the 7390LT


Click here to **cancel** the request to quit the 7390LT and return to the previous window

This operation includes the **NE disconnection** (cf. § 4.3.2 *Disconnecting the NE assembly*).

## 4.3 Connection and Disconnection

### 4.3.1 NE Connection

The NE connection process consists partly in the NE "Agent" identifying the "Manager" and partly in the retrieval of data for the NE assembly on the 7390 LT software by manual request: this involves the **updating of site information**.


	<p><b>ONLY ONE LT SESSION IS OPERATIONAL ON ONE NE. FOR EXAMPLE, A LOCAL LT CONNECTION AND A REMOTE LT CONNECTION AT THE SAME TIME ON THE SAME BS IS NOT POSSIBLE.</b></p>
---	--

There are two possible ways of accessing the **NE Connection**:



- click on the first button (provided that it is active; cf. § 4.1.2.2 *Entry fields*) of the main menu button bar,

or else,



- open the Management pull-down menu and select the first item: **NE Connection**.

The following screen is displayed:


**IP Address** of the **NE** to be connected: click in a byte field value (local IP default address value must be: 192.168.99.1)



**Connection type:** with data upload (default selection)

**Subject of supervision:** NE system or BS



**Network Type:** there are two types of network: **local** (LAN) or **remote** (WAN): check the button for the type of network corresponding to the system configuration



Click here to **run** the data update procedure

In case several interface boards are installed in the PC, the window offers you a choice of boards.


By default, the update is done via FTP. The next screens will be displayed:



**Note:** In order to start the FTP process, there must not be any other FTP service or application running in the PC. Windows NT includes a FTP service that is, by default, deactivated; if it were activated, the operator must stop it from the **Services** window through the Control Panel.

If there were any problem with the FTP process, the craft.ini file must be opened. Change the **UploadThruFTP** value, it must be: UploadThruFTP=No. Throughout the update, an animated display indicates to the user that data transmission is underway, with on-screen indication of the progress of the processed files. In this case, the next screen would be displayed:





Click here to **Cancel** the data update procedure

**Note:** While updating, if the database versions at the Manager and Agent sides are not identical, the animation stops and an error message is displayed to notify it. (cf. corrective actions in appendix Appendix 6 – Error messages and corrective actions).

Once the update is completed, two new windows are displayed:

- one screen providing a global view of the **base station** (cf. § 4.5 Base Station Supervision);
- and one screen summarising the **current alarms** (cf. § 4.10.1 Alarms).


### 4.3.2 Disconnecting the NE assembly

The NE disconnection process consists in closing the current session relating to a given NE in order to connect to another NE of the system.



To access the NE disconnection function, open the ***Management*** pull-down menu then select the item: ***Disconnect NE***.

A confirmation screen is displayed:



Click here to **confirm** the disconnection

Click here to **cancel** the request to disconnect and return to the previous window

## 4.4 Supervision Principles

The 7390 LT can be used for **supervising** the whole A7390 Network Element (NE) system.

The **NE** comprises of:

- a **Base Station (7390BS)** which mainly includes a Radio unit (**RBS**) and a MODEM rack (**DBS**),
- one or more **Terminal Stations (7390TS)** which mainly include a Radio unit (**RT**) and a User connection unit (**NT**). Nevertheless the 7390 LT software does not manage RT units.


The display allows system **control**; alarms are activated in particular to signify any intervention.

The **supervision** items themselves are, by definition, **grayed out** and therefore unmodifiable, whereas those reserved for **configuration** can be configured by the user: they will be used in the following chapters concerning commissioning (*Chapter 5 Commissioning the Base Station (7390BS)*), maintenance (*Chapter 6 Operation and maintenance*) and configuration evolution (*Chapter 7 Changes of configuration*). For the **modifications** to be taken into account, **writing** should be **enabled**: see § 4.4.2 *Local access requests*.

### 4.4.1 Data retrieval

According to the same principle as for starting up the 7390 LT (automatic data retrieval following connection), this update can be carried either for whole NE, or for each equipment: BS or NT.

To reach the **Data retrieval** function, two ways are possible:



- open the **Database** pull-down menu and choose the first item: **NE MIB Upload**,
- or click on one of the buttons in the screen of the equipment in question:

Click on.....

To.....



...**activate** the data recovery function for the NE, BS, and NT **respectively**.

**Note:** *These operations may take quite a long time (in particular for the NE) since they depend on the connection between NE and manager and on the round trip delay and the NE composition.*

### 4.4.2 Local access requests

The general status bar (cf. § 4.1.2.6 *Title, menu, button and status message bars*) displays in its central part the messages concerning write access rights on the NT configuration: "**Local Access : Denied / granted**". Where there are different system managers, these access rights are allocated by the OS manager, write access is authorized for the 7390 LT (local access set to granted) when no OS manager is connected to the NE (local access set to granted) when no OS manager is connected to the NE.

### 4.4.3 Administrative statuses


**Locking** the administrative status of sub-assemblies allows the maintenance operator to disable the sub-assembly manifesting an anomaly without disturbing the system.

**Unlocking** sub-assembly administrative status frees service use for the end user.

Operator is not able to modify the administrative state assembly. He can only change the ports and cross-connections.

## 4.5 Base Station Supervision

When the LT is started up for the first time, the Manager has to define the type of polarization used, in this «Co-polarization» type must be selected



**⚠ AFTER CLICKING ON THE «APPLY» BUTTON, A WARNING WINDOW WILL APPEAR SINCE THIS PROGRESS IS IRREVERSIBLE, EXCEPT THROUGH AN ANT RAM-REINITIALIZATION. ONCE ACCEPTED, THE 7390LT STARTS TO RECEIVE EVENTS FROM THE SYSTEM**

BS Supervision: cf.§ 4.5.1

Inhibit BS Alarms: cf.§ 4.5.1

BS Upload: cf.§ 4.4.1

Local IP addresses parameters: cf.§ 4.9.2.

Configuration of the **Network addresses**: cf.§.4.9.3

**ATM** parameters: cf.§.4.9.1.

Consultation of the **redundancy state**: cf.§.4.5.8

**Synchronization** parameters: cf.§.4.5.4

**Radio** parameters: cf.4.7.1§

IP Data traffic **configuration**: cf.§ 4.7.2

**On demand service** management: cf.§ 4.7.3§ .

Bandwidth allocation: cf.§ 4.7.4

List of **external points**: cf.§ 4.10.3

**NE time setting**: cf.§ 4.5.5.


**Memory** initialization: cf.§ 4.5.6

Actions of the **BS boards**: cf.§ 4.5.3

**RBS** display: cf.§. 4.5.7

**DBS** display: cf.§ 4.5.3

Become accessible when **"Name"** or **"Location"** fields are modified



## 4.5.1 Base Station Supervision

To **Start or Stop the supervision** of the Base Station:

Click on the icon to **start** the supervision of the Base Station.



Click on the icon to **stop** the supervision of the Base Station.



BS supervised means that the agent sends to the manager all the events related to the Base station.

When the **BS is supervised** the «*Start BS Supervision*» button is disabled.

When the **BS is not supervised** the «*Stop BS Supervision*» button is disabled and a red message in the status bar indicates to the operator that the equipment is not supervised. Besides, not supervised status implies that no action can be performed on the BS from the LT manager. Therefore, if the BS is not supervised then no alarm is sent to the BS element. So, not supervision state implies alarms not allowed (the «*Allow BS Alarms*» button is disabled).

To **Allow or Inhibit the alarms** of the Base Station:

Click on this icon to **allow** receiving the alarms of the Base Station.



Click on this icon to **inhibit** receiving the alarms of the Base Station.



BS Alarms allowed means that all the alarms present in the BS equipment will be reported to the LT manager.

When the **BS alarms are allowed**, the «*Allow BS Alarms*» button is disabled.

When the **BS alarms are inhibited**, the «*Inhibit BS alarms*» button is disabled. Moreover, all the status led boards in the BS appears in grey colour to indicate that it is unknown if the boards have or do not have alarms present.

## 4.5.2 General parameters

The left side of the **BS Details** screen shows the **characteristics** and associated **states**:

The screenshot shows the 'BS Details' screen with two main sections: 'Characteristics' and 'States'. The 'Characteristics' section contains the following fields:

- Eqpt ID: 1
- Name: (empty)
- Type: 7390DB
- Version: 2.2b
- Ethernet IP Address: 155.132.136.86
- ATM IP Address: 0.0.0.0
- Location: (empty)
- Time last update: 09/02/2001 16:20:34
- ASAP: ASAP BS
- Polarization Type: Co-Polarization

The 'States' section contains the following fields:


- Operational: Enabled
- Administrative: Unlocked
- Supervision: Supervised
- Alarm: Allowed

Callout boxes provide the following explanations:

- Identification No.:** 1 for the BS
- BS name:** click to enter the BS name: it will appear in the title bar
- BS manufacturer No.**
- BS version No.**
- IP address** of BS access via 10 BT Eth port
- IP address** of BS access via ATM port
- BS Location:** click to enter the town or geographical sector where the BS is located
- Last BS time setting** (cf. § 4.5.5) (by default date displayed is 01/01/1970 at 00:00:00)
- Name of the alarms **correspondence base:** cf. § 4.10.2
- BS Polarization type**
- Operational state** (enabled/disabled): indicates the technical availability status of the equipment with respect to service provision
- Administrative state unlocked for the BS:** indicates whether locked or unlocked for modification at the network management level
- Supervision state supervised for the BS**
- Alarm report state** (only authorized values appear in the system)

### 4.5.3 DBS

The central part of the **BS details** screen shows the rack and its sub-assemblies as detected by the 7390 LT:



On the **BS Detail** screen button bar:

Click on... To.....




...**access the details** of a selected sub-assembly (or **double-click** directly on one of the sub-assemblies)



...**delete** a selected sub-assembly



...**reset** a selected board.  
A confirmation screen is displayed:



Click here to **confirm** reset of the selected board.

Click here to **cancel** the reset request for the selected board.

**Symbols on the equipment representations:**

- **green spot:** no alarm is detected;
- **colored spot** (other than green): alarm detected: the color displayed corresponds to the most critical alarm level (cf. § 4.10.1.2 *Alarms color code*);
- **white board:** board physically present in the rack;
- **gray board:** board physically removed but still present in the system management.

Number of equipments in the rack:

Equipment designation	Maximum number of equipments managed by the system in 2.2	Maximum number of equipments that can be included in the BS
ANT board	2	2
TNT board	4	4
AMD board	8	8
CPL board	1	1
IBS board	8	8
Power Supply Unit	2	2
Ventilation subrack	1	1

**4.5.3.1 ANT board screen**

ANT (**A**TM **N**etwork **T**ermination): ATM interface board.



Board family ID No.

Board slot No.

Board type.

Click on this tab to display the screen relating to the hardware part of the board

Name of ANT integrated software

State of ANT integrated software

**Board states:** only these two states are defined for the boards: cf. § 4.5.1

Fields completed after downloading: cf. § 4.14.3

Click here to return to the **BS Details** screen



Board family ID No.

Board slot No.

Board type

Click on this tab to display the screen relating to the software part of the board

ANT board Part Number

Status change

ANT board Serial Number

Board states: only these two states are defined for the boards: cf. § 4.5.1

Click here to return to the **BS Details** screen

### 4.5.3.2 TNT board screen

TNT (TDM Network Termination): board providing the leased line service (E1, X21, T1, CES).



Click here to display the screen relating to the **TNT board ports wording configuration** (cf. following screen)

Click on this tab to display the screen relating to the **hardware** part of the board

Select the **Input type** used to supply the TNT board: either via the **TDM network** or via the **ATM network**

Name of TNT integrated software

State of TNT integrated software

cf. § 4.5.3.1

Parameters link with the circuit emulation mode

cf. § 4.5.3.1

Click here to return to the **BS Details** screen

Fields completed after downloading: cf. § 4.14.3

**Note:** This screen can be modified only if the **ATM** type Input/Output is ticked off.



Click here to enter the TNT board **port labels**

Port number

Index	Type	User Label	Operational State
1	G704		Enabled
2	G703		Disabled
3	G704		Enabled
4	G704		Disabled
5	G703		Disabled
6	G703		Disabled
7	E1		Disabled
8	E1		Disabled
9	E1		Disabled
10	E1		Disabled
11	E1		Disabled
12	E1		Disabled
13	E1		Disabled
14	E1		Disabled
15	E1		Disabled
16	E1		Disabled

Operational state of the port:  
Enabled/Disabled  
(cf. § 4.11.1)

Click here to **apply** the label modifications

Click here to **cancel** the label modifications

Click here to **close** the screen

#### 4.5.3.3 AMD board screen

AMD (ATM MODEM) : ATM modulator demolulator board.




AMD Details		Software	Hardware
<b>Characteristics</b>			
ID	1		
Slot	7		
Radio Link Index	1		
AMDType	Full Dynamic		
<b>States</b>			
Operational	Enabled		
Administrative	Unlocked		
		<b>Software 1</b>	
		Name	3CC10949ACAA71
		State	enabled
		Activated software	3CC10949ACAA71
		Committed software	3CC10949ACAA71
		<b>Software 2</b>	
		Name	3CC10949ACAA66
		State	unknown
		<input type="button" value="Close"/>	

No. of radio sector covered by the board

Type of the AMD board

Click here to return to the **BS details** screen




#### 4.5.3.4 CPL board screen

CPL (Coupler): network interface coupler board.



For the items on this screen, refer to the description of the ANT board (§ 4.5.3.1 ANT board screen).




#### 4.5.3.5 IBS board screen


IBS: (Intermediate frequency **B**ase **S**tation): IF board.



For the items on this screen, refer to the description of the ANT board (§ 4.5.3.1 ANT board screen).




#### 4.5.3.6 Ventilation



#### 4.5.3.7 PSU

PSU : Power Supply Unit.

For the items on this screen, refer to the description of the ANT board (§ 4.5.3.1 ANT board screen)



Click here to return to the **BS Details** screen.

#### 4.5.4 Clock synchronization parameters



To access the **synchronization** parameters, click on the button shown here (in the button bar of the **BS Details** screen).

This involves defining the setup rules for the synchronization sources used.

There is one default synchronization source (internal oscillator) and **six configurable sources**: ATM, external clock and the four TNT boards. The TNT boards have 16 ports and 4 can be used as synchronization ports: these are ports **1, 5, 9** and **13**.

The message indicates the **synchronization source currently** used (chosen automatically by the system from the source configurations shown below).

**Warning linked** to the circuit emulation service (see note below).

Grayed out – unavailable

**Priority** of the synchronization sources: see *Priority principle* below

**Operational state** of sources

	ATM Network Interface	External Clock	TNT Card #1	TNT Card #2 <b>CES Warning</b>	TNT Card #3 <i>Grayed out</i>	TNT Card #4
			<input type="checkbox"/> Channel 1 <input type="checkbox"/> Channel 5 <input type="checkbox"/> Channel 9 <input type="checkbox"/> Channel 13	<input type="checkbox"/> Channel 1 <input type="checkbox"/> Channel 5 <input type="checkbox"/> Channel 9 <input type="checkbox"/> Channel 13	<input type="checkbox"/> Channel 1 <input type="checkbox"/> Channel 5 <input type="checkbox"/> Channel 9 <input type="checkbox"/> Channel 13	<input type="checkbox"/> Channel 1 <input type="checkbox"/> Channel 5 <input type="checkbox"/> Channel 9 <input type="checkbox"/> Channel 13
PRIORITY	2	1	3	4	5	6
AUTHORIZED	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Operational State	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled

1. On each of the boards, choose the **reserved channels** to act as **potential** synchronization sources.

2. Allocate to each sub-assembly an **order of priority number** (chosen from pull-down list).

3. Check to boxes to **enable/ disable** the synchronization sources.


– *Priority principle:*

- the **order of priority** numbers take precedence, followed by the **channel numbers**, in increasing order of appearance.
- an **order number** must be **single** (one specific number per sub-assembly).
- Order number **one** is for the **highest level of priority**.

**Note:** Two sources cannot be assigned the same order of priority (the «Apply» button is not available).

**Note:** In the screen shown in the above example, the warning message under **TNT card N°2** is displayed because the type of input for the TNT 2 card has been set to ATM (see § 4.5.3.2 TNT board screen), this board is thus in Circuit Emulation mode.

#### 4.5.5 Sending time to the Agent

	<b>ONLY USE THIS UPDATE FUNCTION IF THE SNTP SERVER IS NOT ENABLED: (SEE § 4.14.4)</b>
---	--

This function allows to update time of the SNMP agent with the LT Windows Operating System (OS) time. It is specially necessary at the first installation, to initialize the time of the system or, when there is a big drift of the NE time in regards to that of the local PC (where the 7390 LT is running): see events log § 4.8 *NE management*.



To synchronize the time of the agent, click on the button of the **BS Details** screen button bar (see § 4.5 *Base Station Supervision*) shown here.


#### 4.5.6 Memory initialization

	<b>THIS FUNCTION, RESERVED TO MAINTENANCE OR FIRST START UP OF BASE STATION, WILL DELETE THE CURRENT CONFIGURATION.</b>
---	---




This function allows memory initialization by the SNMP agent located in ANT board.

The operator has to enter the password (Alcatel 7390), then to click on «OK» to validate this password and start the memory initialization.



### 4.5.7 RBS



On the right of the BS supervision screen are all the RBSs associated with the BS: **Double-click** on the **RBS** whose **details** you require, in order to display the following screen:

RBS identification Number

Click on the arrows to modify the Transmission power; this value indicates the output power in dBm (+7dBm to +17 dBm, by step of 1 dB)

Click on the arrow to open the list and to select the **cable type** (see note below)(automatic recovery for flat RBS)

Click here to enter the **actual cable length** (automatic recovery for flat RBS)

Click here **to take into account** the modifications

Click here **to cancel** the modifications

Click here to close the window and **to return** to the **RBS Details** screen

**Note:** Specifications of the available cables in the **RBS Details** screen:

Attenuation calculation is done with:  $A = K1 \times \sqrt{f} + K2 \times f$  ( $f$  frequency in MHz) in dB for 100 m length

- Filotex:  $K1 = 0,418$ ;  $K2 = 0,004$ ;  $Lmax = 200$  m
- Andrew:  $K1 = 0,22$ ;  $K2 = 0,0012$ ;  $Lmax = 300$  m



## 4.5.8 Redundancy state

### 4.5.8.1 Principle

Redundancy of the A7390 system corresponds to a **1+1** configuration and works in the "**cold redundancy**" mode. That means for **one active** entity, there is **one stand-by** entity and when the active entity has failed, the **switch over** to the stand-by entity provokes a **temporary service cut**.

Redundancy applies to the management part (ANT board) and to the radio part (radio links) of the system.

### 4.5.8.2 Access to redundancy state display



To access **consultation of the system redundancy state**, click on the icon shown here, that is in the button bar of the **BS Details** screen (§ 4.5 Base Station Supervision).

The screen below is displayed:

**Operational** state of the entities (enable / disable) See § 4.5.3.1 (ANT)

Redundancy on the **management** part (ANT board)

Click here on the first tab to display the redundancy state of the first radio link (up to 4 radio links)

**Operational** state of the entities (enable / disable): see § 4.5.3.3 (AMD), 4.5.3.5 (IBS) and 4.5.7 (RBS)

Redundancy on the **radio** part

Set of radio link: AMD board + IBS board + radio

Click here to **close** this consultation window and return to the **BS Details** screen

**Availability state** of the entity (on line / off duty / failed / not installed)

Symbol of the active entity

**Note:** The place of the boards into the DBS is directly linked to their role in redundancy (see § 4.5.8.3 Board and location in the cabinet according to their role in redundancy).

**Note:** The disponibility state on line corresponds to an active entity.

**Comments on radio link 2 as shown in the previous example:**

Radio link 2 initially consists of the **AMD 2** (slot 8), **IBS 2** (slot 18) and **RBS 2** triplet.

The **redundancy** capability of radio link 2 comes with the installation of the **AMD 6** (slot 12), **IBS 6** (slot 22) and **RBS 6** triplet.

The **BS Details** screen (§ 4.5 Base Station Supervision) allows the boards inserted in the cabinet and associated RBSs to be displayed, and also their role in redundancy. The operating entities may also be displayed with the operation symbol (double-arrow).


In the example, the AMD 2 card has been removed; it is thus reported as a critical alarm (red) (see § 4.10.1 Alarms). Triplet 1 is no longer operational: consequently, switch-over was to triplet 2, this is confirmed by the presence of the operation symbol on AMD 6 and IBS 6 cards and on RBS 6.

This information is grouped on the **Redundancy** screen (§ 4.5.8.2 Access to redundancy state display):

- **operational state** of the AMD2 card reported "disabled", (card withdrawn)
- **availability** of triplet 2= "Not installed",
- **availability** of triplet 6= "On line" with operation symbol present.

**Conclusion:** radio link 2 is available and operating via triplet 6.

Primary triplet belonging to radio link 2



**4.5.8.3 Board and location in the cabinet according to their role in redundancy**


ACTIVE PART		REDUNDANCY PART		Radio link
Board	Slot number into the DBS	Board	Slot number into the DBS	
ANT 1	1	ANT 2	2	-
AMD 1	7	AMD 5	11	1
AMD 2	8	AMD 6	12	2
AMD 3	9	AMD 7	13	3
AMD 4	10	AMD 8	14	4
IBS 1	17	IBS 5	21	1
IBS 2	18	IBS 6	22	2
IBS 3	19	IBS 7	23	3
IBS 4	20	IBS 8	24	4

In accordance with *Figure 57 – Place of the boards into the DBS.*

## 4.6 NT Supervision

The system manages 100 NTs maximum per BS, with 31 NTs maximum per upstream for 28 MHz channelization and 15 NTs for 14 MHz. The NT Supervision automatically begins as soon as the NE is connected.

To access the list of declared NTs associated with the BS:




click on the third button of the main menu button bar,


**or else,**

open the **Management** pull-down menu and choose the item: **View NT List**.

The screen belows is displayed:



Eqpt ID	Name	Terminal Station	Radio Link	Upstream	Type	Operational State	Administrative State	Supervision State	Alarms State
2	NT2 (RL#1_US#1)	0	1	1	NCA001	Enabled	Unlocked	Supervised	Allowed
3	NT3 (RL#1_US#1)	0	1	1	NCD001	Enabled	Unlocked	Supervised	Allowed
4	NT4 (RL#1_US#2)	0	1	2	NCA001	Enabled	Unlocked	Supervised	Allowed
5	NT5 (RL#1_US#3)	0	1	3	NCA001	Enabled	Unlocked	Supervised	Allowed
6	NT6 (RL#1_US#4)	0	1	4	NCA001	Enabled	Unlocked	Supervised	Allowed



**Note:** The "ID" column displays the color of the most critical alarm for the NT concerned.  
**Note:** The number of NTs present in the list corresponds to the "number of NTs" displayed perma-

nently on the main screen status bar (cf. § 4.1.2.6 Title, menu, button and status message bars).  
**Note:** Remember that it is possible to access a given NT rapidly from the list of all NTs via the sort and search functions (cf. § 4.1.2.4 Sorting and searching in a list).

### 4.6.1 NT Supervision

To **Start or Stop the supervision** of the NT:

Click on this icon to **start** the supervision of the NT.



Click on this icon to **stop** the supervision of the NT.



NT supervised means that the system sends to the manager all the events corresponding to that NT.

A given NT can be supervised only if the **BS** is supervised.

When a **NT is supervised**, the «*Start NT Supervision*» button is disabled.

When the **NT is not supervised** the «*Stop NT Supervision*» button is disabled. Then, no action can be applied over it, so all the «*Apply*» buttons are disabled. Therefore it implies that the alarms on this NT are not allowed (the «*Allow NT Alarms*» button is disabled).

To **Allow or Inhibit the alarms** of the NT:

Click on this icon to **allow** receiving the alarms of the NT.



Click on this icon to **inhibit** receiving the alarms of the NT.



NT Alarms allowed means that all the alarms present in the NT equipment will be reported to the LT manager.

Allowing or inhibiting alarms on NTs have to be done one by one. It is not possible to allow or inhibit alarms in all the NTs by one action.

When the **NT alarms are allowed**, the «*Allow NT Alarms*» button is disabled.

When the **NT alarms are inhibited**, the «*Inhibit NT Alarms*» button is disabled. When the alarms are inhibited on a given NT, the NT appears grey in the NT list screen to indicate that it is unknown if the NT has or does not have any alarm present.

## 4.6.2 Declaring a new NT



To add an NT, click on the button shown here (on the **NT** screen button bar).  
An input screen is displayed:

Click in the **fields** to enter the various information (described below)

Click on the **arrows** to display the list, then select:

- the radio sector (radio link),
- the upstream,
- the list of NT ASAP table (cf.4.10.2)

Mandatory NT characteristics to be entered	Optional NT characteristics to be entered
<p><b>Serial number</b> (of NT): see data supplied by planner and warning below</p> <p><b>Radio link:</b> corresponding radio sector from 1 to 4.</p> <p><b>Upstream:</b> Connected upstream number, from 1 to 4</p>	<p><b>Name</b> (of NT): by default displays NT#<i>Eqt Index</i></p> <p><b>Terminal Station link:</b> numerical entry supplied by the planner.</p> <p><b>Location:</b> town or geographical sector.</p> <p><b>ASAP:</b> name of alarms correspondence base.</p>

	When entering the <b>Serial Number</b> noted on the label, respect the above syntax: "----CU-serial number" (without space between characters).
--	---

	If several NTs are on same RT, the same <b>Upstream</b> must be declared for all NTs.
--	---

### 4.6.3 NT Details

To access the characteristics of an NT:



- **click** on the button shown here (NT screen button bar),
- or else,
- **double-click** directly on a line from the list of NTs.

A global screen is displayed in which (under **Characteristics**) the majority of the items in the § 4.6.2 *Declaring a new NT* are to be found:

Click on this button to **substitute the NT serial number**: cf.§ 4.6.6

Click on this button to **print the characteristics** of the NT that are displayed in this screen

Will be **automatically** filled in after declaration of the NTs

Click on this tab to display the **ports** characteristics

Click on this tab to display the **hardware** characteristics

Will be automatically filled in after the NTs enter the network

Click on the arrow to choose the ASAP table you want to assign to the NT (cf.4.10.2)

Click on this tab to display the **software** characteristics

1. NT ports:

Port	Type	User Label	Operational State
1	Ethernet		Enabled
2	Ethernet		Enabled
3	X21		Enabled
4	G704		Enabled

Ports **index**  
Ports **type**  
Ports **state**

Click on the fields to enter the **NT ports label**

Port	2 E1/2T1	1 E1 and X21
3	G703-1	X21
4	G703-2	G703-1

2. NT software:

**Name** of the software of the **first** storage zone  
**State** of the software of the **first** storage zone

Software 1  
Name: 3CC11032ACAA71  
State: enabled

Software 2  
Name: 3CC11032ACAA66  
State: unknown

Activated software: 3CC11032ACAA71  
Committed software: 3CC11032ACAA71

Name of the **activated** software  
Name of the software to be activated automatically after reset

Second software storage zone

**Note:** Software names are the same except in the case of download.

3. NT hardware:

Click on this tab to return to the NT **ports configuration**  
Click on this tab to return to the NT **software**

Mother board  
Part Number: 3CC09778AAAA  
ICS: 01  
Serial Number: ---CU-002105628

Daughter board  
Part Number: 3CC09739ACAA  
ICS: 01  
Serial Number: ---CU-001005863

Reference number of the mother board  
Status indication of the mother board  
Serial number of the mother board

Reference number of the daughter board  
Status indication of the daughter board  
Serial number of the daughter board




#### 4.6.4 NT deletion

To delete an NT :



- **click** on the NT in the list
- **click** on the button shown here (*NT* screen button bar).

A confirmation screen is displayed :



**Note:** You have to delete all cross-connections before deleting the NT.


#### 4.6.5 NT reset

To reset an NT:



- **click** on the NT in the list
- **click** on the button shown here (*NT* screen button bar).

A confirmation screen is displayed:



## 4.6.6 NT substitution



To substitute an NT, **click** on the button shown here (*NT Details* screen button bar).  
The following screen is displayed:

**Substitute NT Serial number**

Eqpt ID: 3

Current: ACACU991200001

New: [ ]

CAUTION:  
The NT unit must be changed  
The current NT will be rejected by the BS

Buttons: Apply, Cancel, Close

Annotations:

- NT **identification** number (points to Eqt ID)
- Current **serial number** (points to Current)
- Click here and enter the **new serial number** (points to New)
- Click here to **apply** the NT substitution. After this step the following confirmation screen is displayed. (points to Apply)
- Click here to **cancel** the NT substitution (points to Cancel)
- Click here to **return** to the NT details screen (points to Close)

**Substitution Confirmation**

Are you sure to substitute old NT serial number by new NT serial number?

Old: ACACU991200001  
New: ACACU991200002

Buttons: Yes, No

Annotations:

- Click here to **confirm** the NT substitution (points to Yes)
- Click here to **cancel** the NT substitution (points to No)

The NT substitution will be effective the first time when the "old" NT will have left the network. Then, the NT with the new serial number will be authorized to enter the network.

## 4.7 Radio supervision and parameters

### 4.7.1 Radio configuration



To access the supervision and parameters of the **Radio** link, click on the button shown here (**BS** screen button bar)

The **Radio Configuration** screen is displayed and presents the radio **characteristics**.

The screen displays as many "Radio link # ..." tabs as there are radio links in the system (4 maximum).

Click on the arrow to select the **bandwidth**: 14/4 Us\*3.5, 28/4 Us\*7 MHz (by default: not configured) - (see note 1 below)

No. of the **AMD** board associated with the sector.

Click here to enter the **central frequencies** of the **upstream** (reception) and **downstream** (emission) channels (see radio scheduler)

**Encryption** activation:  
No (see note 2 below)

Click here to **cancel** the modifications

Click here to **apply** the modifications

Click here to **return** to the **BS details** screen

Progression bar representing the **number of NTs** connected to the upstream channel N° 3 (see note 3 below)

Click here to **activate** the **upstream**. (see note 4 below)

**Note 1:** To change a bandwidth, refer to § 7.3.6 *Change of channelling*.

**Note 2:** Encryption: the data of service are systematically encoded, the management data are not encoded.

**Note 3:** NT number: move the mouse pointer onto a progression bar and a tooltip displays the ratio between the number of declared NTs and the max. number of managed NTs for a given channel.

**Note 4:** As long as there is data traffic on the upstream, you cannot deactivate it.



**IF YOU WANT TO CREATE AN IP SERVICE ON AN NT, THE UPSTREAM USED BY THIS NT MUST BE CONFIGURED. CF. § 4.7.2.**

## 4.7.2 Dynamic Traffic Configuration



To access the configuration of the IP data traffic, click on the button shown here (**BS Details** screen button bar).

The **Dynamic Traffic Configuration** screen is displayed:

**Maximum bandwidth compatible with the ATM link**

**Minimum free ATM bandwidth needed to use dynamic traffic**

**Progression bar representing the configured bandwidth used by the radio on the ATM maximum bandwidth**

**Click here to enter Yes to allow or No to forbid dynamic IP traffic (cf: notes below)**

**Click here to apply the modifications**

**Click here to cancel the modifications**

**Click here to return to the BS Details screen**

Radio Link	Upstream	Bandwidth [MHz]	Upstream Activate	Dynamic Traffic
1	1	7	Yes	Yes
1	2	7	Yes	Yes
1	3	7	Yes	Yes
1	4	7	Yes	Yes
2	1	7	No	No
2	2	7	No	No
2	3	7	No	No
2	4	7	No	No

**Note:** You can only **activate dynamic services** (Dynamic Traffic: Yes) if the **upstream is activated** (Upstream: Yes).  
(Cf. § 4.7.1 Radio configuration.)

**Note:** The authorization facility for Dynamic IP Traffic on any upstream is provided in order to avoid overloading of the ATM interface: the air bandwidth available to data traffic should never exceed the bandwidth available on the ATM interface ("Maximum Bandwidth" ≥ "Configured Bandwidth").

**Note:** The system controls the configured bandwidth according to the maximum bandwidth of the ATM interface and according to the overbooking configuration.

Services	Unit	Cell/s
Static IP	66.5 Kbps	157
Circuit Emulation (CES)	2 Mb/s (E1)	5447
	1.5 Mb/s (T1)	4107
Dynamic IP	66.5 Kbps	157

## 4.7.3 On-demand Service management

### 4.7.3.1 Introduction

Radio resources management consists of distributing system resources, for each upstream and downstream channel of each radio link, according to customer services to be created.

Customer services are available according to two types of radio traffic: **dynamic** (dynamic IP) and static (leased lines, static IP).

The bit rate available for each radio channel is given by the bandwidth defined in the **Radio Configuration** screen (see § 4.7.1 *Radio configuration*).

Radio resources management is carried out according to two operating principles (that can be jointly implemented): system **self-management** (default configuration) and **pre-configuration** (carried out by the operator).



- System self-management:  
In this case, the system **automatically** manages **the radio part** according to the following principles:;
  - by default, overbooking limit is 1. That means no overbooking is allowed.
  - CAG = Guaranteed MCR.
  - RRM Devices Enabled = Policing.

**Note:** *Circuit emulation always requires a leased line. Radio resources are implicitly dedicated to circuit emulation via the leased line.*

### 4.7.3.2 Access to the radio pre-configuration




To access **on-demand services** management and proceed with **radio** pre-configuration, click on the button shown here (in the button bar of the **BS Details** screen).

Click on these tabs to configure the other channels

Click here to select the strategy of **Call Admission Control**: Degraded MCR allowed or Guaranteed MCR - (See below)

Click on the arrow to enable **Service of RRM**. Policing or No Policing

**Current Overbooking** (Downstream or Upstream) for the selected radio-link- (See below)




Attribute configurable from the manager that **confines the possible overbooking** (Us/Ds) to this value for the selected radio-link

Click here to take into account **the system on-demand services allocation**

Click here to **cancel** the on-demand services management modifications

Click here to **exit** the on-demand services management window

– **Downstream channels**




**Policing:** is a buffer management function that implements intelligent discard mechanisms to prevent buffer overflows.

**Overbooking:**

- limit = 0 means that overbooking has no sense because in this upstream dynamic traffic is not allowed,
- limit = 1 means no overbooking is allowed,
- limit > 1 means it is possible to use more bandwidth than the physical one.

– Upstream channels



**Call Admission Control Strategy:**

- **Guaranteed MCR**, allows the CAC to deny connection to an RRM port if the current sum of the connected RRM ports does not allow to accept the new RRM port without exceeding the dynamic resources.

**Degraded MCR allowed:**

- allows the CAC to accept every connection request. In this case, congestion event may happen and the RRM scheduler will need to degrade the MCR contract parameter of each connected RRM port, up to its "maximum degraded MCR".

**4.7.4 Bandwidth allocation**

The 7390LT offers the capacity to display radio resources reserved for traffic and therefore potentially available to create customer services.


	<b>THE RADIO RESOURCES DISPLAYED CORRESPOND TO BANDWIDTH ALLOCATION AND NOT TO THE CURRENT TRAFFIC ON THE SERVICES CREATED.</b>
--	---



To **view** reserved **radio** resources, click on the button shown here (**BS Details** screen toolbar).

**Nota** : *The system always runs in self management mode, but pre-configuration is possible to avoid shutdown during static service creation; thus the system automatically returns to self management mode if the capabilities are exceeded*

Click on these tabs to display the radio resources of the other channels



**Meaning of the colors used to show the different parts of the bandwidth:**

The **blue** zone represents the bit rate allocated to **leased lines (LL)** type services.

The **yellow** zone represents the bit rate allocated to **static IP (IPstat)** type services.

The **light grey** zone represents the proportion of bit rate still **available** to create new **static services (FreeS)** without disturbing the dynamic zone.

The **dark grey** zone represents the proportion of bit rate still **available** to create new **dynamic services (FreeD)**.

The **green** zone represents the bit rate allocated to the **dynamic IP (IPdyn)** type services, as the physical limit of the system reserved to the dynamic services has not been reached (OF<1).

Once the bandwidth is filled, (maximum bit rate authorized by the system's physical limits), the zone is displayed in **orange** to warn the operator of the risk of dynamic service unavailability.

When the bit rate allocated to the dynamic services exceeds the booking factor limit (OFL), the zone changes to **red**.

	<p><b>IF THE ZONE IS ORANGE, CHECK THAT SIZE OF THE REMAINING DYNAMIC ZONE IS GREATER THAN THE LARGER DYNAMIC CROSS-CONNECTION IF IT'S NOT THE CASE THIS CONNECTION WILL BE UNAVAILABLE.</b></p>
--	--

The whole **bandwidth** is represented on a scale from **0 to 100%**.

It is divided into three zones: the **static LL zone**, the **static IP zone** and the **dynamic IP zone**.

The **static zone** represents the portion of the bandwidth allocated to **static services**, with display of both bit rate types: **leased line (LL)** and **static IP (ATM)** bit rate.

The **dynamic zone** represents the portion of the bandwidth allocated to the **dynamic services**: the dynamic IP services.




**Note :** The available bit rate depends on the traffic type allocated: leased lines, static or dynamic IP.

**Note :** The dynamic zone is the zone remaining available, corresponding to the total bandwidth minus the static zone; the static zone corresponds to the static IP service bit rate.

The **overbooking factor limit (OFL)** is a value **defined by the operator** (until 10 as maximum) and can be modified at any time depending on radio resource requirements: if the operator wishes to offer more services than the system can physically provide **simultaneously** on the available bandwidth, he defines this value which will represent a risk level of dynamic degraded service.


**Note :** When **OFL = 1** (default value), it corresponds to the system physical limit assigned to the dynamic zone (= width of bandwidth).

If **OFL = 2**, double the dynamic zone physical bandwidth can be used for dynamic IP services.



IP traffic is measured according to «ATM» Rate = 66.5 Kbps, whereas LL is measured with rate = 64 Kbps


Dotted overbooking: dynamic traffic is not allowed in this upstream, therefore the overbooking has not sense



Dotted upstream: it is not activated, then traffic is not possible in this upstream

Resources rate is calculated according to the total physical bandwidth.

When the dynamic traffic (green color) is overbooked, green is changed to orange (see next screen).



Orange zone: the available physical bandwidth has been exceeded. However, since overbooking limit > 1 has been defined, it is possible to use more bandwidth

## 4.8 NE management

As soon as the 7390LT is connected to the NE, it keeps a log of all the events taking place between the Agent (NE) and the Manager (7390 LT) for the corresponding part of the supervised NE. This supervision tool is mainly used as a log file to be used for maintenance purpose (see *Chapter 6 Operation and maintenance*).

### 4.8.1 NE Supervision


To **Start or Stop the supervision** of the NE:



Click on the icon to **start** the supervision of the NE.



Click on the icon to **stop** the supervision of the NE.



Or else, open the **NE Supervision** pull-down menu and choose the item **Start NE Supervision** or **Stop NE Supervision**.

NE supervised means that the agent sends to the manager all the events related to the network element. When the **NE is supervised**, the «*Start NE Supervision*» button is disabled.

When the **NE is not supervised**, the «*Stop NE Supervision*» button is disabled. The manager has lost its synchronization with the agent. BS and NT are not supervised and events are not received.

Starting the NE supervision implies a total NE upload, because it is the only way to align again the LT

and the MIB agent.

To **Allow or Inhibit the alarms** of the NE:



Click on this icon to **allow** receiving the alarms of the NE.



Click on this icon to **inhibit** receiving the alarms of the NE.



Or else, open the **NE Supervision** pull-down menu and choose the item **Allow Alarms NE** or **Inhibit Alarms NE**.

NE Alarms allowed means that all the alarms present in the NE equipment will be reported to the LT manager.

When the **NE alarms are allowed**, the «*Allow Alarms NE*» button is disabled.

When the **NE alarms are inhibited**, the «*Inhibit Alarms NE*» button is disabled. Moreover, neither alarm window is present in the 7390LT nor alarm code colour is showed in the main window.

## 4.8.2 Events log

**Note:** *the events log (in read only) is presented in reverse chronological order. The most recent event is at the top of the list. The circular list can contain up to 5000 events*



To access the **events log**:

- click on the button shown here (on the 7390 LT main screen),
- or, open the **Management** pull-down menu and choose **View Event Log**.

Click here to **print** the events log on the default printer (see § 4.1.4 Printing)

Index	Start Date	Trans. ID	Object	Type	Alarm ID	Probable Cause	Request Status
50912	03/01/1970 22:13:52	334	amdBoardEntry # 5	SC			OK
50911	03/01/1970 22:13:52	333	amdBoardEntry # 5	AI	59	Hardware failure	OK
50910	03/01/1970 22:13:51	332	ibsBoardEntry # 5	AVC			OK
50909	03/01/1970 22:13:51	331	ibsBoardEntry # 5	SC			OK
50908	03/01/1970 22:13:51	330	ibsBoardEntry # 5	AI	55	Communications	OK
50907	03/01/1970 22:13:51	329	amdBoardEntry # 5	SC			OK
50906	03/01/1970 22:13:51	328	amdBoardEntry # 5	AI	59	Hardware failure	OK
50905	03/01/1970 22:13:51	327	upstreamEntry # 5.4	SC			OK
50904	03/01/1970 22:13:51	327	upstreamEntry # 5.3	SC			
50903	03/01/1970 22:13:51	327	upstreamEntry # 5.2	SC			
50902	03/01/1970 22:13:51	327	upstreamEntry # 5.1	SC			
50901	03/01/1970 22:13:51	327	downstreamEntry # 5	SC			
50900	03/01/1970 22:13:51	327	upstreamConfigEntry # 1.4	AVC			
50899	03/01/1970 22:13:51	327	upstreamConfigEntry # 1.3	AVC			
50898	03/01/1970 22:13:51	327	upstreamConfigEntry # 1.2	AVC			
50897	03/01/1970 22:13:51	327	upstreamConfigEntry # 1.1	AVC			
50896	03/01/1970 22:13:51	327	downstreamConfigEntry # 1	AVC			
50895	03/01/1970 22:13:51	326	amdBoardEntry # 5	SC			OK
50894	03/01/1970 22:13:48	325	amdBoardEntry # 5	AVC			OK
50893	03/01/1970 22:13:48	325	amdBoardEntry # 5	AVC			
50892	03/01/1970 22:13:48	324	amdBoardEntry # 5	AI	59	Communications	OK

Key of the different event types (see § 4.8.4 Event log legend)

Click here to **quit** the events list

**Index:** this is the event number: an incremental cyclic counter is activated each time an event takes place.

**Start date:** time-stamping of the event (format: day/month/year, hour/minute/second).

**Trans ID:** transaction number allowing the action which occurred on the system and the different events resulting from it, to be linked; in the example above, the action corresponding to event number 294 corresponds to 5 events (see groups ID Trans. 165).

**Object:** indicates the part of the system affected by the event (format: designation#equipment ID followed by port number).

**Type:** abbreviation (which key is permanently displayed at the bottom of the window) of the event type: alarm, deletion, creation, etc.

**Alarm ID** (if the event **type** is an alarm): alarm identifier corresponding to its coming out number (chronological).

The line is displayed in the color related to the alarm: when the alarm ends, the same line will be displayed (with an incrementing **Index**) in green to symbolize the end of alarm.

**Probable cause** (field associated with the alarm): description of the cause of the problem from the ASAP (giving the severity for a given probable cause).

**Request status:** request status in the form of abbreviation whose legend is displayed at the bottom of the screen. This is to identify the way a group of events has been terminated (same ID Trans.); the transaction status of the **last** event of a same group is therefore **ok** if the action succeeded.

**Note:** ends of alarm are displayed in green.

### 4.8.3 Historical Event log

This function allows all or certain events, listed in the events log since the last connection, to be retrieved.

#### 4.8.3.1 Accessing the historical event log



To access the **historical event log**:

- click on the button shown here (in the **7390 LT** main screen),
- or, open the **Management** pull-down menu and select the **Historical Event Display** section.

The screen below is displayed:

Click here to access **search** of items to be retrieved from the historical event log (cf: § 4.8.3.2)

Click here to **refresh the historical display** of the event log according to the selection criteria displayed at the bottom of the screen

Click here to **print** the event list on the default printer (cf: § 4.1.4)

Click here to **save** the historical event log file (cf: § 4.8.3.3)

The screenshot shows the 'Historical Event Log' window. At the top, there are four icons: a magnifying glass (search), a circular arrow (refresh), a printer (print), and a floppy disk (save). Below these is a table titled 'Events List' with the following columns: Index, Start Date, Trans. ID, Object, Type, Alarm ID, Probable Cause, and Request Status. The table contains 20 rows of event data. Below the table, there is a 'Current Selection' section with a date range: 'From 01/01/1970 00:00:01; to 01/01/1970 00:10:00'. At the bottom of the window are two buttons: 'View Legend' and 'Close'.

Index	Start Date	Trans. ID	Object	Type	Alarm ID	Probable Cause	Request Status
328	01/01/1970 00:00:33	83	amdBoardEntry # 4	AI	35	Hardware failure	OK
327	01/01/1970 00:00:32	82	amdBoardEntry # 2	AI	33	Hardware failure	OK
326	01/01/1970 00:00:32	81	amdBoardEntry # 4	AVC			OK
325	01/01/1970 00:00:32	81	amdSoftwareEntry # 4.2	AVC			
324	01/01/1970 00:00:32	81	amdSoftwareEntry # 4.1	SC			
323	01/01/1970 00:00:32	81	amdSoftwareEntry # 4.1	AVC			
322	01/01/1970 00:00:32	81	amdBoardEntry # 4	AVC			
321	01/01/1970 00:00:32	80	amdBoardEntry # 4	AI	35	Version mismatch	OK
320	01/01/1970 00:00:32	79	amdBoardEntry # 3	AI	31	Hardware failure	OK
319	01/01/1970 00:00:32	78	amdBoardEntry # 4	AI	35	Hardware failure	OK
318	01/01/1970 00:00:31	77	amdBoardEntry # 2	AVC			OK
317	01/01/1970 00:00:31	77	amdSoftwareEntry # 2.2	AVC			
316	01/01/1970 00:00:31	77	amdSoftwareEntry # 2.1	SC			
315	01/01/1970 00:00:31	77	amdSoftwareEntry # 2.1	AVC			
314	01/01/1970 00:00:31	77	amdBoardEntry # 2	AVC			
313	01/01/1970 00:00:31	76	amdBoardEntry # 2	AI	34	Version mismatch	OK
312	01/01/1970 00:00:31	75	amdBoardEntry # 2	AI	33	Hardware failure	OK
311	01/01/1970 00:00:31	74	amdBoardEntry # 4	AI	35	Hardware failure	OK

Key of the different possible types of event (cf: § 4.8.4 )

Click here to **quit** the **Historical Event Log** screen

### 4.8.3.2 Searching for items in the historical event log



To access the events **search**, click on the button shown here (in the *Historical event log* screen).

The following screen is displayed:

Click here to **start searching** with the defined criteria

Click here to **cancel the search process** with the defined criteria

Click here to **close the events search window**

**Note:** The search process can take several minutes to start after launch depending on the number of events listed.

Two types of search criteria are available to retrieve the events in question from the entire historical event log since the last connection:

- event **attributes**: object, event type and transaction status linked with the event.

Click on the arrow to scroll down the object list, then select the event required from the list of objects available.


Click on the arrow to scroll down the available event type list, then select the **event type** desired.

Click on the arrow to scroll down the available request status list, then select the **transaction status** desired.

**Note:** The selection of a star in the "attribute selection" fields allows all the items of the list for the section concerned to be taken into account (no defined criteria).

– **Time periods.**

Click in these 3 fields to enter the **date from** which events must be considered:  
e.g.: 07 then, 02, then 2000 to begin on 2 July 2000.



Click in these 3 fields to enter the **last day** to consider events: e.g.: 07 then, 10, then 2000 to stop searching on 10 July 2000.

**Note:** By default, no date is selected: all dates are taken into account.  
The tabulation key also allows you to move from one field to another.

**Note:** The chosen selection criteria are permanently displayed at the bottom of the **Historical Event Log** screen.

**4.8.3.3 Historical event log item backup**



To perform backup of events corresponding to the defined search criteria (see § 4.8.3.2 *Searching for items in the historical event log*), click on the button shown here (in the **Historical Event Log** screen).

The following screen is displayed:

1- Click on the arrow to select the **disk** on which the event file is to be saved


Display of file names already present in the selected directory

2- Select the **directory** where the event file is to be saved

3- Click in this field to enter the backup file **name**

Click here to **start** the back up

Click here to **cancel** the backup




Check one of the 3 sections to define the backup content with regard to the history displayed in the **Historical Event Log** screen (cf: § 4.8.3.1). This filter is added to the previously defined criteria (cf: § 4.8.3.2)

#### 4.8.4 Event log legend



To access the legend of events listed in the **Event Log** screen, click on the button shown here (at the bottom of the **Event Log** and **Historical Event Log** screens).

The following legend is displayed:



Click here to **quit** the **Event Log Legend** screen



## 4.9 Interface parameters

### 4.9.1 ATM



To access the parameters of the **ATM** link, click on the button shown here (in the **BS details** screen toolbar).

The following screen is displayed:

For the **155 Mbit/s** version:

To make the ATM operational, click on the arrow to scroll down the list and select the **medium type** used for the ATM link: **sdh** or **sonet** (by default unknown)

The numbers of bytes respectively allow the Vci and the Vpi to be encoded (Vci bytes fixed to 10 and vpi bytes fixed to 6)

For the **34 MBit/s** version:

The numbers of bytes respectively allow the Vci and the Vpi to be encoded (Vci bytes fixed to 10 and vpi bytes fixed to 6)

**Note:** For the 34Mbit/s version, the Medium Type configuration cannot be modified.