



ANYWAVE

ATSC 1KW DTV Transmitter

User Manual

Version 1.6
February 12, 2014





Copyright Notice

Copyright © Anywave Communication Technologies, Inc. 2013, All rights reserved.
No part of this publication may be reproduced, translated, transcribed, stored in a retrieval system, or transmitted into any form or by any means, without the express written permission of Anywave Communication Technologies, Inc.

Disclaimer

Information provided by Anywave Communication Technologies is believed to be accurate and complete; however, no liability can be assumed for its use. The information contained in this publication is subject to change without notice.

Anywave Communication Technologies Inc.
300 Knightsbridge Parkway, Suite 150, Lincolnshire, IL 60069
Tel: +1 (847) 415-2258
Fax: +1 (847) 415-2112
<http://www.anywavecom.com/en/>




Contents

| | | |
|----|---|----|
| 1 | Overview | 4 |
| 2 | Specifications..... | 6 |
| 3 | TX Control Unit..... | 7 |
| 4 | ATSC ACT-5X Digital Exciter | 10 |
| 5 | 600W UHF Power Amplifier..... | 12 |
| 6 | TX System Interconnect | 15 |
| 7 | Theory of Operation | 16 |
| 8 | Quick Start Guide – to safely turning on your Transmitter | 18 |
| 9 | Local (Touch Screen) User Interface | 20 |
| 10 | Remote (Web) User Interface | 37 |




1 Overview

The ATSC 1000W DTV transmitter comes in single and dual exciter configurations, providing a control unit (with a front panel LCD and built-in preamp), two power amplifiers, a power splitter and combiner, and a power supply system.





A rear view of the cabinet (shown below - with the back panel removed) highlights the remaining system components – including the combiner, output coupler, reject load (with fan), AC distribution and output stack of the transmitter.





2 Specifications

- RF Output
 - ◆ Connector: 1 5/8", 50 Ω
 - ◆ Frequency: 470~860 MHz, in steps of 1 Hz
 - ◆ Rated Power: 1kW (rms)
 - ◆ Level Stability: < ± 0.2 dB
 - ◆ MER: > 35 dB
 - ◆ Amplitude Flatness: < ± 0.5 dB
 - ◆ Shoulder Level: < - 50 dB (after correction)
 - ◆ Return Loss: > 16 dB
- Environment
 - ◆ Operation Temperature: 0 $^{\circ}\text{C}$ ~ +40 $^{\circ}\text{C}$
 - ◆ Operation Humidity: < 95 % (non-condensing)
 - ◆ Atmospheric Pressure: 86 kPa ~ 106 kPa
- Power Supply
 - ◆ Voltage: 220/380 VAC, three phase 4-wire
 - ◆ Frequency: 50/60 Hz
 - ◆ Power Consumption: 5940 W @ 1170 W output (27 A / 220 V)
- Other
 - ◆ Cooling System: Forced air cooling
 - ◆ Control Interface: Front panel, Ethernet and RS232
 - ◆ Size (HxWxD): 1270 mm x 584 mm x 914 mm

Note

1. The electrical interface characteristics are measured under normal conditions. Values may vary.
2. Operating in abnormal conditions may result in damage to the equipment. Long operating hours in severe environments may reduce the reliability of the entire system, which may cause permanent damage to equipment. Make sure all electrical interface characteristics and environmental parameters are within the defined range listed above before operating this equipment.



3 TX Control Unit

The TX Control Unit consists of a pre-amp (1xBLF571 driving 2xBLF881 devices), a splitter and a powerful control system. It receives the RF inputs from the exciters, performs the pre-amplification, and finally sends 2 RF outputs (1x 0° and 1x 90) to the two PA modules. It also receives various RF signals for detection and monitoring.

Front panel

The front panel of Control Unit is shown below.



- Color touch screen
- NORMAL/EMERGENCY
 - **NORMAL:** It's the default mode of the transmitter for most of the operating time. In NORMAL mode, all protection mechanisms are enabled, including over-drive, high reflected power, high absorbed power, etc.
 - **EMERGENCY:** It's a mode to force a transmitter to send out TX power when it enters some protection mode and therefore shuts down its output in NORMAL mode. Twist the NORMAL/EMERGENCY switch 90 ° clockwise to switch from NORMAL to EMERGENCY. Please Note: In EMERGENCY mode, all protection mechanism is disabled.
- LED_NORMAL
 - If the green light is ON, then the transmitter is working in NORMAL mode.
- LED_EMERGENCY
 - If the yellow light is ON, then the transmitter is working in EMERGENCY mode.
- LED_ALARM
 - If there is any alarm, the red light is ON, and the transmitter will shut down its output. The most common alarms include: Over-drive/over-current of PA modules or Preamp, high reflected power of PA modules or Preamp, high absorbed power, over temperature of PA modules or Preamp, etc. Please refer to Status Bar and LOG from the touch screen of Control Unit for details.



Rear Panel

The rear panel of Control Unit is shown below:



- RF_MON: Loop out of RF_OUT1/RF_OUT2 for monitoring
- RF_IN_A/RF_IN_B
 - Connector: N
 - Impedance: 50 Ω
 - Note: To receive the RF_OUT signal from Exciter_A / Exciter_B
- RF_OUT_1/RF_OUT_2
 - Connector: N
 - Impedance: 50 Ω
 - Note: Sends pre amplified RF signal to the inputs of PA modules
- PR_IN (TX Reflected Power)
 - Connector: BNC
 - Impedance: 50 Ω
 - Note: To receive feedback signal from Directional Coupler for Reflected Power detection and monitoring.
- PF_IN (TX Forward Power)
 - Connector: BNC
 - Impedance: 50 Ω
 - Note: To receive feedback signal from Directional Coupler for Forward Power detection and monitoring.
- PL_IN (TX Load Reject Power)
 - Connector: BNC
 - Impedance: 50 Ω
 - Note: To receive feedback signal from Directional Coupler and Load for Absorbed Power detection and monitoring
- AUX_IN (reserved)
- GPRS (reserved)
- ERS485-A/ERS485-B: To be connected to REMOTE of Exciter_A/Exciter_B for internal communication between exciters and Control Unit.
- PRS485-1/PRS485-2: To be connected to RS485 of PA610-1/PA610-2 for internal communication between PA modules and Control Unit.
- RS232: To be connected to a computer for external serial protocol communication with Control Unit for remote control.



- LAN: 10M/100M Ethernet port for web-based remote control (ipaddress: 192.168.1.210)
- AC INPUT/FUSE: 100-240 VAC
- Power Switch: ON/OFF



4 ATSC ACT-5X Digital Exciter

Front Panel



LCD:

40×2 LCD with power saving backlight

6 Buttons :

Left, Right, Up, Down, OK, ESC

6 LEDs:

When in Exciter mode:

LED_TS1: Green light on indicates TS1 is selected and the input TS signal is OK

LED_TS2: Green light on indicates TS2 is selected and the input TS signal is OK

LED_TSErr: Red light on indicates the selected input signal has error

When in Translator mode:

LED_TS1: Green light on indicates the synchronization of input RF signal is OK

LED_TS2: Green light on indicates the equalization of input RF signal is OK

LED_TSErr: Red light on indicates there is synchronization error or equalization error

In both Exciter and Translator mode:

LED_GPS: Green light on indicates GPS connected and locked

LED_RFON: Green light on indicates system ready and RF on

LED_SysErr: A flashing red LED indicates the presence of a system error


A solid red LED indicates the unit is in "Local (LCL)" control mode, and when this LED is off, this indicates that the unit is in "Remote (RMT)" control mode

1 BNC connector:

RFMON: Reserved



Rear Panel



| | |
|------------------|---|
| RF_IN_A: | Feedback signal, sampled after the band-pass filter (-5 to -15dBm) |
| RF_IN_B: | Feedback signal, sampled before the band-pass filter (-5 to -15dBm) |
| AGC_IN: | Feedback DC voltage for AGC control (0-5VDC) |
| RF_MON: | Loop out of RF_OUT for monitoring (-25 dB below RF_OUT) |
| RF_OUT: | Main RF signal output of exciter, to be connected to RF_IN_A/RF_IN_B of Control Unit (nominal 0 dBm output) |
| DRYLOOP: | Dry loop for remote control |
| REMOTE: | To be connected to ERS485-A/ERS485-B of Control Unit for internal communication between excitors and Control Unit |
| REMOTE (RJ45-B): | 10M/100M Ethernet for remote control (ipaddress: 192.168.1.143) |
| TSoIP (RJ45-A): | Reserved |
| 10M_IN: | 10 MHz input from external GPS receiver |
| 1PPS_IN: | 1 PPS input from external GPS receiver |
| TS_IN_1: | The first port of TS inputs, DVB-ASI only |
| TS_OUT_1: | Loop out of [TS_IN_1] for monitoring |
| TS_IN_2: | The second port of TS inputs, DVB-ASI only |
| TS_OUT_2: | Loop out of [TS_IN_2] for monitoring |
| TUNER_IN: | Received RF signal input |

Note: Please refer to the ACT-5X Exciter User Manual for more details of operations.



5 600W UHF Power Amplifier

This TX is fitted with two UHF-610 PA modules to produce a total 1000W of output power after the BPF. Each module consists of two 2 pallets (a total of 4 BLF888A devices).

Front Panel

The front panel of PA UHF-610 is shown as below. The LED indicators and ports are listed below.



- LED_PWR
 - Green light will be on when the DC voltage of internal power supply is within the normal range (48 VDC ~ 52 VDC).
 - Green light will flash when the DC voltage of internal power supply is out of the normal range (48 VDC ~ 52 VDC).
 - Green light will be off when the external power supply is turned off, or internal power supply module does not work.
- LED_RS485
 - Green light will flash once per second when the internal communication is normal.
 - Green light will stay constantly on or off when the internal communication is abnormal.
- LED_FWD
 - Blue light will be on when TX power level is stable and higher than 10 W.
 - Blue light will flash once per second during the ramp up process and the TX power level is higher than 10 W.
 - Blue light will be off when the TX power level is less than 10 W, or it's turned off by configuration or for protection. There are several situations which will result in auto-protection mode, such as the input power is too high, the reflected power is too high, or the temperature is too high. When the transmitter reboots, the default setting of TX status is OFF.
- LED_ALARM
 - Red light will be on if there is any alarm and TX output will be shut down
 - Red light will be off if there is no alarm

**Note:**

- 1) The front fan covers can be removed to clean the air intake path. No screw driver is needed, and no disassembly of the PA is required.
- 2) When a warning occurs and the PA enters auto-protection mode, the only way to clear this state is to cycle power on the PA module once the problem(s) is resolved. Otherwise all warning LEDs will remain on even if the problem(s) no longer exists.

Rear Panel

The rear panel of PA UHF-610 is shown below with ports described as follows.



- **RF_IN**
 - Connector: N
 - Impedance: 50 Ω
 - Note: To receive RF signal from RFOUT1/RFOUT2 of Control Unit.
- **RF_OUT**
 - Connector: 7/16 DIN
 - Impedance: 50 Ω
 - Note: To send out RF signal to the input of Power Combiner (attached to the cabinet). It must always be connected to a load.
- **RF MON (loop out of RF_OUT)**
 - Connector: BNC female
 - Impedance: 50 Ω
 - Note: It is OK to leave this port open without load.
- **RS485**
 - Connector: DB9-M
 - Note: To be connected to PRS485-1/ PRS485-2 of Control Unit for internal communication between PA and Control Unit.
- **AC220V input:** To be connected with Power Supply System.




➤ Power Switch: ON/OFF

Note:

- 1) The back fan covers can also be removed to clean the air intake path. No screw driver is needed, and no disassembly of the PA is required.



The ATSC 1KW DTV transmitter is modular in its design. The diagram below shows the overall system interconnect and signal flow existing between the various modules.





7 Theory of Operation

The ATSC 1000W DTV transmitter is conceptually simple to understand and easy to operate.

The Transmitter operates on 3-phase 220V, 30A AC Mains service. An AC Mains Distribution compartment is located in the back rear floor of the TX. This compartment is shielded for personnel safety and provides the distribution of appropriate AC power to the various modules inside the TX cabinet.

A standard ATSC ASI input stream is provided to one of the BNC connectors located on the rear panel of the Exciter. The Exciter supports options for DVB-ASI and SMPTE310M stream formats as well as an RF off-air input via a built-in tuner and TSoIP support via an RJ-45 input. The Exciter performs the appropriate FEC and Signal Processing to modulate a standard 19.39 Mbps ATSC TS to produce an RF output at the desired channel frequency. Supported ATSC modulation standards include A/53 (Legacy), A/153 (MH), and A110:20011 (SFN).

The TX supports both Single and Dual Drive (DD) Exciter configurations, and manages the automatic and manual switchover between Exciters in a DD configuration. The modulated RF output signal from the Exciter(s) is(are) fed into the Control module which contains a 50W preamp driver (1xBLF571 device driving 2xBLF881 transistors in parallel). The output of the Controller preamp is then split and fed to the RF inputs of each of the PA modules.

The PA modules contain 4x BLF888A devices that amplify the RF signal to produce 600W of output power per PA. The amplified output signals of the two PAs are fed into a 2-way Hybrid Combiner and then into a Directional Coupler and finally out the top of the cabinet via a section of 1 5/8 transmission line.

The 1 5/8 output stack of the Transmitter is then fed into an inline 1 5/8 Harmonic Filter (if required) before entering a channel mask BPF. The output of the BPF connects to the Antenna feed to radiate the DTV signal on-air.

The Exciter receives two feedback signals from FWD and REV couplers located on the BPF. These before and after BPF feedback signals are used by the Exciter to provide automatic Linear and Non-Linear pre-correction of the ideal 8-VSB forward path signal.

Additional feedback signals are provided to the Control module, which monitors these samples to implement protective protocols including forward power reduction and shutting down the TX in the event of high reflected power or other unsafe operating conditions. System FWD and REV power samples are provided to the Control module from the Directional Coupler located directly after the 2-way power combiner. The Control module also receives a feedback sample from the Reject Load, enabling it to control the variable fan speed on the load.



The Control module is in constant communication with the Exciter and PA modules via an RS-485 serial bus. Each module has a unique ID on the bus, and the Control module is continually talking with the Exciter and PA modules to provide monitoring and control capabilities via its front panel touchscreen and built-in web user interfaces. Both the Control module and the Exciter provide RJ-45 Ethernet connections through which the user may remotely monitor and control the TX via their respective built-in web interfaces.



8 Quick Start Guide – to safely turning on your Transmitter

1 After unpacking, inspecting, and installing the transmitter components, connect all the cables as per the interconnect diagram inside the transmitter. Install and connect the Band Pass Filter. Install and connect the Band Pass Filter monitoring cables between the Band Pass Filter “N” Type connectors and their respective transmitter connections on the top of the transmitter cabinet.

2 Connect the antenna or a suitable station load BEFORE continuing any further.

3 Install and connect the 220-volt power cable to the terminal block located inside the AC Mains Distribution compartment on the floor of the transmitter. Connect the cable to the station power source.

4 Ensure all power switches and breakers are turned off on the front of the transmitter cabinet, and on the Power Amplifiers, Exciters, and Controller.

5 Apply power to the transmitter by energizing the AC mains to the transmitter. Turn on the breaker on the bottom front of the transmitter. Ensure that the AC Mains indication is illuminated.

6 Although the transmitter has fully been tested and calibrated at the factory, the major operating parameters should now be checked before attempting to make power with the transmitter. To do this, turn on the exciters ONLY and allow them to initialize.

7 Verify the operating frequency of the exciters by pressing the right arrow navigation button on each exciter to indicate the second status screen of the exciter. You should see an indication of the operating frequency in the following format: `FREQ:605`. This example indicates that the operating frequency would be set for a center frequency of 605Mhz.

8 If the operating frequency is incorrect, navigate to the Frequency Setting menu by pressing the Exciter LEFT and RIGHT navigation arrows simultaneously. Then move the cursor (shown as an asterisk *beside the current selection) to the Freq Menu then press enter. Disregard the RX Frequency for Transmitter operation as this is used for Translator Operations only. Move the cursor to the TX Frequency and select the correct frequency by using the UP or DOWN arrows. Once the correct frequency is selected, press the ENTER button to initiate the frequency change. Repeat this procedure for the remaining exciter.

9 Press the ESC button once. Move the cursor to the RF menu, press enter. Make a note of the exciter RF POWER output level (this level is typically somewhere between -6 and 0dB). Make sure that the Exciter AGC is turned OFF. Do this for the remaining exciter as well.

10 Connect the ASI transport stream to each exciter using the TS-1A input if ASI is being used. Use TS-2A input if SMPT-310M is being used (ACT-8X model). Verify that the corresponding TS 1 or TS 2 LED is illuminated on the front of the exciter that corresponds with the input group used.

11 Navigate to the Exciter RF submenu and turn RF ON. Do this for both exciters and verify that both exciters have the RF ON LED illuminated.

12 Power on the amplifier assemblies by turning on the breakers located on the rear of the assemblies, and the controller via the power switch located on the rear of the unit, in that order.

13 Locate the touch screen display on the TX Control Module. Find the red button on the main screen (this is the TX ON button). Press this button to turn the TX ON. The button will turn GREEN when the Controller turns On the transmitter.



14 Allow 45 to 50 seconds for the transmitter to ramp up power. The Controller will indicate output power in Watts in real time.

15 Allow 15 minutes of operation for the transmitter to warm up. Check operation parameters by viewing the main status screen of the on-air exciter for TSNR, LIMD, and UIMD.

16 For Dual Drive TX configurations, test the Exciter switchover behavior by pressing the A/B icon on the Controller touchscreen and initiating an Exciter Changeover by selecting EXCITER B, and confirming the changeover when asked. The power will drop and the exciter changeover will initiate. Once again, allow 45 to 50 seconds for the transmitter to reach operating power. Make the same performance checks as just outlined for Exciter A.

17 If additional Pre-Correction is needed, refer to the Anywave 1Kw Correction Procedure.




9 Local (Touch Screen) User Interface

1. Touch screen control interface

- a) Turn on the power supply and the TX enters the initialization process, as shown below.



- b) After 5 seconds, the TX enters the home screen. The home screen is divided into 4 parts: Title Bar (left column), Power Metering (upper right), Block Diagram (middle right) and Status Bar (lower right), as shown below.





2. Home Screen

- **Title Bar:** Shown in the picture above, the “Home” button is highlighted, indicating the Home screen is now displayed. This TX Control Unit screen is a touch screen. You may navigate to the other screens (Config, Log, Control, Help) by simply touching the corresponding button in the Title Bar.
- **Power Metering**
 - **ON/OFF (Green) Button :** Provides TX ON/OFF control. When GREEN (as shown above), this indicates the TX is ON. When RED, this indicates the TX is OFF.
Note: When there is an alarm, this button is always RED.
 - **FWD:** Forward Power Meter. Touching the white display box of FWD will toggle its display units between “dBm” and “W”.
 - **REFL:** Reflected Power Meter. Touching the white display box of REF will toggle its display units between “dBm” and “W”.
 - **VSWR:** Voltage Standing Wave Ratio
 - **REJT:** This is the system Reject Load Power Meter, derived from the REJT Load feedback sample. Displayed in units of “W” and cannot be changed.
- **Status Bar:** During normal operation, the default status is “RUNNING OK”. If there is any alarm, the alarm will show up in the Status Bar of each screen.
- **Block Diagram:** Press the “Exc A/B” graphic to navigate to the Dual Exciters Switching screen (shown below). This screen shows which exciter is currently on-air (highlighted GREEN) and allows you to manually change the on-air exciter. Press the “Amplifier” graphic to navigate to the home Amplifier Status Screens (shown below).




- a) **Dual Exciters - Switching Screen:** As mentioned above, pressing the “Exc A/B” icon will bring you to the Dual Exciters Switching Screen, as shown below.




- Manual Exciter Switchover: Exciter A is the default on-air exciter. The on-air exciter's status will be “GREEN”, as shown in the screen above, indicating that Exciter B is the current on-air exciter. Pressing the “Exciter A” or “Exciter B” button on this screen will cause a manual switch between exciters, that is if the Controller is “linked” to both exciters. (Note: In a dual drive configuration, both exciters are on at the same time, producing an RF output signal at the same time, and the Controller is considered “linked” with an exciter when the Controller detects an RF output present from the exciter as monitored inside the controller).
- Auto Exciter Switchover: In a Dual Drive configuration, the TX is set to automatically switch to the standby exciter in the event a problem occurs with the on-air exciter. The TX will not automatically switch back to the original Exciter as long as the standby Exciter is operating properly. However, the TX will automatically switch back to the original Exciter in the event of a problem with the on-air (standby) exciter. So the TX will continue to automatically switch indefinitely in the event of a problem with the on-air exciter.



- If neither of the exciters can be linked successfully (i.e. the Controller does not detect a valid RF output present from either exciter), a window will pop up, indicating “No Exciter Linked”, as shown below.



- If the manual switching is successful, a window will pop up indicating “Change succeed!”, as shown below.





- If the manual switching is not successful, a window will pop up indicating “Change failed!”, as shown below.





- b) Amplifier Status Screens:** As mentioned above, pressing the “Amplifier” icon on the Home page, will navigate to the Amplifier Status Screens.
- Title Bar: includes “PreAmp”, “Amp1” and “Amp2” (“Amp3 and more buttons are for higher power transmitters in the MPTV product line).
 - PreAmp Status Screen



- Fwd: Forward Power reading of the preamp
- Refl: Reflected Power reading of the preamp
- Pin: Input Power reading of the preamp (from Exciter)
- Tmp: Temperature of the preamp
- Cur: Current of the preamp
- V50: Reading of 50 V power supply
- V9: Reading of 9 V power supply
- V12: Reading of 12 V power supply
- GV1: Grid Voltage #1 of the preamp
- GV2: Grid Voltage #2 of the preamp



➤ Amp1/Amp2 Status Screen






- Fwd: Forward Power reading of the current amplifier
- Refl: Reflected Power reading of the current amplifier
- Fan1~Fan2: Fans' RPM of the current amplifier
- Tmp: Temperature of the current amplifier
- V50: Reading of 50 V power supply of the current amplifier
- Cur1~Cur4: Current of the current amplifier
- GV1~GV8: Grid Voltage of the current amplifier



3. Config Screen

Touching the Config button on Title Bar of the Home Screen, will navigate to the Config Screen, as shown below. The Config Screen has four functional sections on the right. Press any of these buttons to navigate to that config screen. The Network screen is used to configure all the TX networking parameters including IP, Mask, and Gateway. The Time screen is used to set the current time. The AGC screen is used to set turn the Controller AGC On/Off and to change the target AGC output power level. The AmpCf screen is for advanced users – to configure the TX configuration, including the number of exciters, alarm and fault thresholds, etc. as outlined below. Note: Modifying factory default configurations of certain parameters may lead to potential damage of the transmitter.






Network Screen: The User can check and set all the Contoller network information in this screen.

- Re-Default: Reset Default settings - This button is used to set all the network settings to the default values, as show below:

IP: 192.168.1.210

MASK: 255.255.255.0


GateWay: 192.168.1.1



- Set: There is a Set button for each bar in this screen. Pressing the Set button will lead to the corresponding configuration screen of IP or Mask or GateWay accordingly. Using the IP setting as example, Press any part of the white bar on the IP Setting Screen and the keyboard (shown below) will be enabled, turing from grey to yellow. The user can only set 3-digits of one bar at a time. When the configuration is finished, press OK to confirm. If the keyboard is enabled by mistake, press Cancel to exit the setting mode. Don't press Ok without entering a valid number, otherwise the system will fill it with all zeros instead.



Time Screen: This screen is used to check and adjust the current time settings. It's similar to the Network Settings.






AGC Screen: This screen is used to set the AGC Reference output power of the TX and to turn the Controller AGC ON/OFF.



AmpCf Screen: This screen is used to configure advanced settings of the TX.






ComCf Screen: This screen is used to configure the TX mainum operating thresholds to engage safety and protective power reduction and shutdown mechanisms.




PreAmpCf Screen: This screen is used to configure the Premap mainum operating thresholds to engage safety and protective power reduction and shutdown mechanisms.





PosID Screen: This screen is used to perform a query between the controller and all the other modules (having a unique RS-485 address) on the RS-485 bus inside the TX.



Amp1Cf/Amp2Cf Screens: These screens are used to configure the PA maximum operating thresholds to engage safety and protective power reduction and shutdown mechanisms.






Exciter Screen: This screen is used to configure the TX for single or dual exciters.



Bootset Screen: This screen is used to configure the number of attempts that the tX attempts to successfully reboot on a shutdown condition, after which it gives up and remainig off-air.







4. Log Screen

Pressing the Log button on Title Bar in the Home Screen will navigate to the Log Screen, as shown below. There are two pages of current alarm information as well as history alarms. Each page can show up to 5 alarm messages. The user can use the NextPage/PrePage button to switch between pages.

Please note: the Del-History button is used only to clear the status history of alarms. It will not clear any current active alarms which may require user intervention.



Pressing the Help button on Title Bar in the Home Screen, will navigate to the Help Screen, as shown below. The Help section is reserved for now and will be expanded upon in the future.





5. Control Screen

Pressing the Control button on Title Bar in the Home Screen, will navigate to the Control Screen, as shown below. The Control screen allow the user to switch between Local and Remote Control of the TX. In Local, the TX processes commands from the front panel touchscreen and ignores commands via the Controller web interface. In Remote comde, the TX processes commands from the Controller Remote Web interface. Note: be sure to switch the TX into Remote mode before leaving the TX site if Remote control of the TX is desired.






10 Remote (Web) User Interface

The TX Control module provides a built-in web interface that enables remote monitoring and control of the TX. This Control Module interface may be used for a variety of things, including turning the TX On/Off, manually switching between exciters (in a DD configuration), monitoring the voltages and currents of the PAs, etc. A built-in web interface also exists in the Exciter that may be used for such things as adjusting the TX output power, performing corrections, etc. (please reference the separate Exciter User Manual for a detailed description of the Exciter web interface). The Control Module communicates with the Exciter(s) and PAs inside the TX via an RS-485 bus network.

The Control Module built-in web interface is accessible via the rear panel LAN RJ-45 connection. Once networked to your PC, the built-in web interface may be accessed via a web browser (such as Internet Explorer or Firefox, etc.) by entering the IP address of the Controller (default 192.168.1.210, note: you can navigate to the Network setting under the Config menu to change the Controller IP address).

Launching a web browser and entering the Controller IP address (192.168.1.210) will bring up the following login window.





There are two tiers of web interface available. The first “guest” tier is limited in monitoring and control, allowing users to access only certain information. The guest account is accessed with a user name and password of "guest" and "guest" (case sensitive). The second “admin” tier provides full status and control of the Controller and is accessed with a username and password of "anywavecom" and "anywavecom" (case sensitive).

The screenshots below highlight the status and control available via the Controller web interface.

The screenshot displays the web interface for the 1000W ATSC-AMP. The browser address bar shows the URL http://192.168.1.100/com_status.shtml. The interface includes a sidebar with a menu of options: COM-STATUS, PRE-AMP-PARA, POST-AMP1-PARA, POST-AMP2-PARA, POST-AMP3-PARA, POST-AMP4-PARA, POST-AMP5-PARA, EXCITER-STATUS, NET&VERSION, COM&PRE-AMP-SET, POST-AMP-SET, and ADVANCE-SET. The main content area is divided into several sections:

- TX-STATUS-SET**: A table with one row showing TX-SET set to ON with a dropdown arrow and a Submit button.
- CTL-TYPE**: A table with one row showing CTL-TYPE set to LOCAL.
- COM-AMP-RUN-PARA**: A table with two rows of power and SWR data:

| | | | | | |
|---------|--------|---|----------|------|---|
| FWD-POW | 957.51 | W | REFL-POW | 2.02 | W |
| VSWR | 1.09 | | REJT-POW | 9.53 | W |
- COM-AMP-ALARM-INFO**: A table with two rows of alarm status:

| | | | |
|---------|----|----------|----|
| FWD-POW | OK | REFL-POW | OK |
| VSWR | OK | REJT-POW | OK |
- AGC-STATUS-SET**: A table with one row showing AGC-SET set to ON with a dropdown arrow and a Submit button.
- FWD-STANDARD**: A table with one row showing FWD-STANDARD set to 1050 and a Submit button.
- BOOT-SETTINGS**: A table with two rows showing boot settings:

| | | |
|----------------|----|--------|
| BOOT-SET | ON | Submit |
| BOOT-SET-TIMES | 3 | Submit |



AnyWave

1000W ATSC-AMP

COM-STATUS

PRE-AMP-PARA

POST-AMP1-PARA

POST-AMP2-PARA

POST-AMP3-PARA

POST-AMP4-PARA

POST-AMP5-PARA

EXCITER-STATUS

NET&VERSION

COM&PRE-AMP-SET

POST-AMP-SET

ADVANCE-SET

Anywave Communication
Copyright 2013

Tel: +1 (847) 415 2258

PRE-AMP-RUN-PARA

| | | | | | |
|----------|-------|-----|---------|-------|---|
| IN-POW | -2.99 | dBm | 50V-VOL | 49.93 | V |
| FWD-POW | 9.45 | W | 9V-VOL | 8.52 | V |
| REFL-POW | 8.62 | W | 12V-VOL | 11.73 | V |
| CUR | 5.61 | A | GV1 | 1.54 | V |
| AMP-TEMP | 83.09 | °F | GV2 | 1.64 | V |

PRE-AMP-ALARM-INFO

| | | | |
|----------|----|---------|----|
| IN-POW | OK | 50V-VOL | OK |
| FWD-POW | OK | CUR | OK |
| REFL-POW | OK | TEMP | OK |



Power Amplifier

http://192.168.1.100/amp1.shtml

File Edit View Favorites Tools Help

Google Amazon Webm... FTP Tele... Watt... X Adap... nons... Free... Rabb... FedEx

Page Safety Tgols

1000W ATSC-AMP

COM-STATUS

PRE-AMP-PARA

POST-AMP1-PARA

POST-AMP2-PARA

POST-AMP3-PARA

POST-AMP4-PARA

POST-AMP5-PARA

EXCITER-STATUS

NET&VERSION

COM&PRE-AMP-SET

POST-AMP-SET

ADVANCE-SET

Anywave Communication
Copyright 2013

Tel: +1 (347) 415 2258

AMP1-RUN-PARA

| | | | | | |
|------------|--------|-----|---------|-------|---|
| FWD-POW | 605.87 | W | 50V-VOL | 49.32 | V |
| REFL-POW | 13.8 | W | GV1 | 1.69 | V |
| VSWR | 1.35 | | GV2 | 1.69 | V |
| AMP-TEMP | 110.23 | °F | GV3 | 1.71 | V |
| CUR1 | 8.71 | A | GV4 | 1.7 | V |
| CUR2 | 9.18 | A | GV5 | 1.68 | V |
| CUR3 | 8.97 | A | GV6 | 1.68 | V |
| CUR4 | 8.9 | A | GV7 | 1.71 | V |
| FAN1-SPEED | 4380 | RPM | GV8 | 1.71 | V |
| FAN2-SPEED | 4440 | RPM | | | |

AMP1-ALARM-INFO

| | | | |
|----------|----|---------|----|
| FWD-POW | OK | 50V-VOL | OK |
| REFL-POW | OK | CUR1 | OK |
| VSWR | OK | CUR2 | OK |
| TEMP | OK | CUR3 | OK |
| FAN1 | OK | CUR4 | OK |
| FAN2 | OK | | |

100%



AnyWave

1000W ATSC-AMP

AMP2-RUN-PARA

| | | | |
|------------|-----|---------|---|
| FWD-POW | W | 50V-VOL | V |
| REFL-POW | W | GV1 | V |
| VSWR | | GV2 | V |
| AMP-TEMP | °F | GV3 | V |
| CUR1 | A | GV4 | V |
| CUR2 | A | GV5 | V |
| CUR3 | A | GV6 | V |
| CUR4 | A | GV7 | V |
| FAN1-SPEED | RPM | GV8 | V |
| FAN2-SPEED | RPM | | |

AMP2-ALARM-INFO

| | | | |
|----------|--|---------|--|
| FWD-POW | | 50V-VOL | |
| REFL-POW | | CUR1 | |
| VSWR | | CUR2 | |
| TEMP | | CUR3 | |
| FAN1 | | CUR4 | |
| FAN2 | | | |

AnyWave Communication
Copyright 2013
Tel: +1 (847) 415 2258



The screenshot displays the web interface for a 1000W ATSC-AMP. The browser address bar shows the URL <http://192.168.1.100/amp3.shtml>. The page title is "1000W ATSC-AMP". On the left, a navigation menu lists several sections: COM-STATUS, PRE-AMP-PARA, POST-AMP1-PARA, POST-AMP2-PARA, POST-AMP3-PARA (highlighted), POST-AMP4-PARA, POST-AMP5-PARA, EXCITER-STATUS, NET&VERSION, COM&PRE-AMP-SET, POST-AMP-SET, and ADVANCE-SET. The main content area is divided into two sections: AMP3-RUN-PARA and AMP3-ALARM-INFO.

AMP3-RUN-PARA

| | | | | | |
|------------|----|-----|---------|---|---|
| FWD-POW | 0 | W | 50V-VOL | 0 | V |
| REFL-POW | 0 | W | GV1 | 0 | V |
| VSWR | 0 | | GV2 | 0 | V |
| AMP-TEMP | 32 | °F | GV3 | 0 | V |
| CUR1 | 0 | A | GV4 | 0 | V |
| CUR2 | 0 | A | GV5 | 0 | V |
| CUR3 | 0 | A | GV6 | 0 | V |
| CUR4 | 0 | A | GV7 | 0 | V |
| FAN1-SPEED | 0 | RPM | GV8 | 0 | V |
| FAN2-SPEED | 0 | RPM | | | |

AMP3-ALARM-INFO

| | | | |
|----------|----|---------|----|
| FWD-POW | OK | 50V-VOL | OK |
| REFL-POW | OK | CUR1 | OK |
| VSWR | OK | CUR2 | OK |
| TEMP | OK | CUR3 | OK |
| FAN1 | OK | CUR4 | OK |
| FAN2 | OK | | |

Anywave Communication
Copyright 2013
Tel: +1 (847) 415 2258



Power Amplifier

http://192.168.1.100/exciter_status.shtml

File Edit View Favorites Tools Help

Google Amaz... Webm... FTP Tele... Watt... X(f Adap... nons... Free... Rabb... FedEx

AnyWave

COM STATUS

PRE-AMP-PARA

POST-AMP1-PARA

POST-AMP2-PARA

POST-AMP3-PARA

POST-AMP4-PARA

POST-AMP5-PARA

EXCITER-STATUS

NET&VERSION

COM&PRE-AMP-SET

POST-AMP-SET

ADVANCE-SET

Anywave Communication
Copyright 2013

Tel: +1 (847) 415 2258

1000W ATSC-AMP

REFRESH
OFF

DEVICE-TYPE-SET

| | | |
|--------------|------|-----|
| EXCITER-TYPE | ATSC | SET |
|--------------|------|-----|

EXCITER-BAND

| | | |
|------|----|-----|
| BAND | 6M | SET |
|------|----|-----|

EXCITER-FREQ

| | | |
|---------|------|-----|
| FREQ_6M | 473M | SET |
|---------|------|-----|

EXCITER_ID

| | | |
|------------|-----------|-----|
| EXCITER_ID | EXCITER_A | SET |
|------------|-----------|-----|

EXCITER_MODE

| | | |
|--------------|----------------|-----|
| EXCITER_MODE | DOUBLE EXCITER | SET |
|--------------|----------------|-----|



AnyWave

1000W ATSC-AMP

REFRESH
OFF

COM-STATUS

PRE-AMP-PARA

POST-AMP1-PARA

POST-AMP2-PARA

POST-AMP3-PARA

POST-AMP4-PARA

POST-AMP5-PARA

EXCITER-STATUS

NET&VERSION

COM&PRE-AMP-SET

POST-AMP-SET

ADVANCE-SET

Anywave Communication
Copyright 2013

Tel: +1 (847) 415 2258

NET-PARA-SET

| | | | | | |
|---------|-----|-----|-----|-----|-----|
| IP | 192 | 168 | 1 | 100 | SET |
| MASK | 255 | 255 | 255 | 0 | SET |
| GATEWAY | 192 | 168 | 1 | 101 | SET |

VERSION

| | |
|------------------------|----------|
| CONTROL-BOARD | 20140105 |
| PRE-AMP-COLLECT-BOARD | 20140105 |
| POST-AMP-COLLECT-BOARD | 20140105 |



Power Amplifier

AnyWave

1000W ATSC-AMP

REFRESH
OFF

COM-STATUS

PRE-AMP-PARA

POST-AMP1-PARA

POST-AMP2-PARA

POST-AMP3-PARA

POST-AMP4-PARA

POST-AMP5-PARA

EXCITER-STATUS

NET&VERSION

COM&PRE-AMP-SET

POST-AMP-SET

ADVANCE-SET

COM-AMP-PARA-SET

| | | | | | | | | |
|----------|------|---|--|---|-----------|------|--|---|
| FWD-MAX | 1500 | W | | S | FWD-PARA | 83.4 | | S |
| REFL-MAX | 100 | W | | S | REFL-PARA | 86 | | S |
| REJT-MAX | 100 | W | | S | REJT-PARA | 86 | | S |
| VSWR-MAX | 1.5 | | | S | | | | |

PRE-AMP-PARA-SET

| | | | | | | | | | |
|-----------|-----|-----|--|---|-----------|-------|---|--|---|
| ATT-PARA | 1.5 | dB | | S | CUR-MAX | 7 | A | | S |
| FWD-MAX | 100 | W | | S | ADJ-PARA | 90.7 | | | S |
| REFL-MAX | 10 | W | | S | IN-PARA | 10 | | | S |
| PA-IN-MAX | 10 | dBm | | S | DAC-VOL-1 | 2 | V | | S |
| TEMP-MAX | 130 | °F | | S | DAC-VOL-2 | 1.992 | V | | S |



Power Amplifier

AnyWave

COM-STATUS

PRE-AMP-PARA

POST-AMP1-PARA

POST-AMP2-PARA

POST-AMP3-PARA

POST-AMP4-PARA

POST-AMP5-PARA

EXCITER-STATUS

NET&VERSION

COM&PRE-AMP-SET

POST-AMP-SET

ADVANCE-SET

Anywave Communication
Copyright 2013

Tel: +1 (847) 415 2258

1000W ATSC-AMP

REFRESH
OFF

AVR_POS_ID

| | | |
|------------|---|-----|
| AVR_POS_ID | 0 | SET |
|------------|---|-----|

POST-AMP1-PARA-SET

| | | | | | | |
|----------|-----|---|-----|----------|-----|-----|
| FWD-MAX | 900 | W | SET | ADJ-PARA | 93 | SET |
| REFL-MAX | 50 | W | SET | TEMP-MAX | 130 | SET |
| VSWR-MAX | 5 | | SET | DAC-VOL | 1.9 | SET |
| CUR-MAX | 13 | A | SET | | | |

POST-AMP2-PARA-SET

| | | | | | | |
|----------|------|---|-----|----------|------|-----|
| FWD-MAX | 900 | W | SET | ADJ-PARA | 93.5 | SET |
| REFL-MAX | 50 | W | SET | TEMP-MAX | 130 | SET |
| VSWR-MAX | 2 | | SET | DAC-VOL | 1.9 | SET |
| CUR-MAX | 12.5 | A | SET | | | |

POST-AMP3-PARA-SET

| | | | | | | |
|----------|---|---|-----|----------|---|-----|
| FWD-MAX | 0 | W | SET | ADJ-PARA | 0 | SET |
| REFL-MAX | 0 | W | SET | TEMP-MAX | 0 | SET |
| VSWR-MAX | 0 | | SET | DAC-VOL | 0 | SET |
| CUR-MAX | 0 | A | SET | | | |

POST-AMP4-PARA-SET

| | | | | | | |
|----------|---|---|-----|----------|---|-----|
| FWD-MAX | 0 | W | SET | ADJ-PARA | 0 | SET |
| REFL-MAX | 0 | W | SET | TEMP-MAX | 0 | SET |

