



AT&T U-verse Advanced Series A10 Remote Control

NOTE:

The remote control will only control the device which is selected by the appropriate mode key (AT&T, TV, DVD, and AUX). The mode key light for the selected device flashes each time a valid key is pressed.

Controlling Other Devices

In order to control other devices with your 4:1 Universal Remote Control, you need to tell the remote control what types of devices you have. Sections A and B bring you through the steps needed to do this. The volume controls will work for the device mode you are in. If you want to change this, you should follow the steps in Section F.

Programming the remote to control other devices

To use the U-verse remote control for your other devices, you will need to set up the TV, DVD and AUX mode keys to control the devices (Section A).

Please refer to the code list for a list of supported brands and models. If you do not find the brand of your device on the supported code list, please refer to section B for the search function or you may use section C for instructions on the learning feature of your remote control. If you have an integrated or combination unit such as a TV/DVD, each component of the unit may require being set up separately by setting up both the TV and DVD mode keys.

NOTE: The DVD and AUX mode keys can be set up with any code. The TV mode key can only be set up with TV codes.

A. Manual Programming

Use the following steps to set up the TV, DVD or AUX mode keys:

1. Power on the device you want to program and locate the 4-digit code from the code list.
2. Press and hold the mode key (TV, DVD, or AUX) and while holding it pressed, press the OK key for one second.
3. Release both keys and all of the mode keys will flash then the selected mode key light will stay lit.
4. Enter the 4-digit code by pressing the numerical keys (0-9). The selected mode key light will blink for each digit entry and will remain off after the entry of the fourth digit - indicating a successful set up.
5. Point the remote control at the selected device and press the power key once. The device should turn off. If the device stayed on, repeat the steps 1 thru 4 trying each code for your brand until you find the correct code.

Repeat above steps to set up another device.

To use the remote control for your U-verse unit, press the AT&T mode key.

NOTE: If an invalid code is entered or no key is pressed at all for 30 seconds, the mode key light flashes for 3 seconds and turns off. The remote control returns to normal operation and you will need to start over from step A2 to set up the device.

B. Using the Search Function

To search for a particular device code for DVD or AUX e.g. VCR, use the Manual Programming for section A and program DVD or AUX with any VCR code prior to starting a search.

1. Turn on the device you want to control and point the remote at that device.
2. Press and hold the mode key (TV, DVD, or AUX) and while holding it pressed, press the OK key for one second.
3. Release both keys and all of the mode keys will flash then the selected mode key light will stay lit.

4. Press the power button repetitively until the selected device responds. Once your device has responded, press OK to save the code.
5. To indicate a successful set up, the selected mode key will turn off and you are ready to set up another device by following steps 1 thru 3 of this section.

C. Learning

If the code for your device is not found in the code list and the search feature does not work with your device, then the learning feature may be your best option. The learning feature lets you "learn" functions from your original remote control.

D-I. Learning Commands

1. Press and hold the mode key (TV, DVD, or AUX) and while holding it pressed, press the LEARN key for one second then release both keys.
2. All the mode keys will flash and the selected mode key light will stay on.
3. Press and release the LEARN key once. The mode key light blinks off.
4. Press and release the DELETE key. The mode key light turns off. All learned Commands under that mode are now cleared.

3. On your U-verse remote control, press and release the key that you want to teach.

4. While pointing your original remote at the bottom of your U-verse remote approximately 1 inch apart, press and hold the original remote key until the mode key light blinks once and stays on. (If there is a learning problem, the mode key light blinks for three seconds and stays on. If this happens, repeat the steps above.)



4. Press and release the DELETE key. The TV mode key light turns off. All learned Commands in the remote are now cleared.

E. Resetting the remote control to the Factory Default Settings

1. Press and hold the TV key and while holding it pressed, press the OK key for one second and release both keys at the same time.
2. All the mode keys will flash and the TV mode key light will stay on.
3. Press and hold the DELETE key for 3 seconds until the TV mode LED blinks and stays off. The remote control is now reset to factory default settings. If you want to use the remote control for your TV and other devices, you will need to set up the TV, DVD and AUX mode keys.

4. If no key is pressed within 30 seconds, the remote control times out. The selected mode key light flashes for 3 seconds and turns off. The remote control returns to normal operation and you will need to start over.

F. Volume Control Set Up Options

The volume controls will work for the device mode you are in, e.g. if AT&T mode is selected then volume controls your AT&T U-verse unit, if TV mode is selected then volume controls your TV, etc. If you'd like the volume commands to operate from just one device, e.g. always TV, then follow the instructions in Section F-I. If you'd like the volume commands to be sent to different devices depending which mode you are in (Factory Default), then follow the instructions in Section F-II.

F-I. Volume Always Controls the same Device

1. Press and hold the TV key and while holding it pressed, press the OK key for 1 full second.
2. Release both keys and all of the mode keys will flash followed by the TV mode key light remaining on.
3. Press and hold the MUTE key for 3 seconds until the TV mode key light briefly turns off then remains on. Press and release the mode key that you always want to operate the volume commands (AT&T, TV, DVD, and AUX). The selected mode key light will remain on.

4. Press and release the MUTE key to save the setting. The selected mode key light will turn off indicating a successful initial set up. The volume commands will be set up for the selected device despite what mode is selected. If the selected mode key light flashes for 3 seconds and turns off, then the selected mode will have no volume commands of its own and will need to start over from step 1 above and select a different mode to program the device.

F-II. Volume Control Depends on Device Selected (Factory Default)

1. Press and hold the mode key (TV, DVD, or AUX) and while holding it pressed, press the LEARN key for one second then release both keys.
2. All the mode keys will flash followed by the TV mode key light remaining on.
3. Press and hold the MUTE key for 3 seconds until the TV mode key light briefly turns off then stays on. The TV mode key light blinks off.

4. Release the MUTE key to save the setting. The TV mode key light will turn off indicating successful set up. The volume commands will now work for different devices.

NOTE:

If a programmed mode key has no volume commands of its own, then the volume control will normally operate the TV. If an invalid key is pressed, the selected mode key light flashes for 3 seconds and turns off. The remote control returns to normal operation and you will need to start over. If no key is pressed within 30 seconds, the remote control times out, the selected mode key light flashes for 3 seconds and turns off. The remote control returns to normal operation at which time you can start over.

G. Battery saving backlight cancellation feature

In order to extend the life of your battery between charges, your U-verse remote control has the ability to toggle between turning the backlight on or off. If you wish to use this feature, follow these instructions.

1. Press and hold both clock setting keys (+H and +M) at the same time for 3 seconds. The display shows the current ID, from 1 to 16 or ALL.
2. Press the +M key to cycle from 1 to 16 including a selection for all remotes in the household.
3. Then press the +H key to confirm the selection.

To set the remote to the same ID as the Charging Base, follow these instructions:

1. Press and hold the TV key and while holding it pressed, press the OK key for one second and release both keys at the same time.
 2. All the mode keys flash and the TV mode key light stays on.
 3. Press the GUIDE key and all back-lights will no longer turn on.
- To reverse this process so that the back-lights turn on when the remote control is being used, simply follow the same steps of this section one more time.

H. Charging Base setup

Connect the Charging Base to the back of your U-verse set top box via the supplied USB connector or by using the included plug-in power supply. Place the remote into the Charging Base to charge the rechargeable battery in the remote control. It takes approximately 12 hours to fully charge the battery in the remote but you will be able to use your new remote control within 30 minutes of charging. To ensure that you have placed the remote control on the charging base, the charging indicator located next to the clock will show that the battery is being charged.



H. Find feature

Never lose your remote again! If you have misplaced the remote control and can not locate it, simply press the AT&T globe on the Charging Base and the remote control will play the AT&T ring tone as well as flash several of the remote keys. This should help you locate your lost remote control.



H-I. Setting the Clock

Use the +H and +M buttons to set the Hours and Minutes for the clock. Both the +H and +M buttons are located at the bottom on your new Charging Base.

H-II. Finding more than one remote

If there is more than one remote and Charging Base, you can set each Charging Base to find only its own remote with 16 unique codes. With the first power up of the Charging Base, it will be set to find ALL remotes.

To set the Charging Base so that it finds a specific remote when there are multiple remote in the household, follow these instructions:

1. Press and hold both clock setting keys (+H and +M) at the same time for 3 seconds. The display shows the current ID, from 1 to 16 or ALL.
2. Press the +M key to cycle from 1 to 16 including a selection for all remotes in the household.
3. Then press the +H key to confirm the selection.

To set the remote to the same ID as the Charging Base, follow these instructions:

1. Press and hold the TV key and while holding it pressed, press the OK key for one second and release both keys at the same time.
2. All the mode keys flash and the TV mode key light stays on.
3. Press the GUIDE key and all back-lights will no longer turn on.

H-III. Dimming and brightening the clock on the Charging Base:

Simply pressing and holding the Charging Base find key while the remote is in the Charging Base causes the display to dim. Holding down the find key until fully dim followed by releasing the find key and holding it down again causes the clock to be brighter and return to its original illumination.

I. Troubleshooting Learning

You can only learn one device type under any one mode key. For example, only learn TV codes under the TV mode, DVD codes under the DVD mode, etc. If you are trying to learn from a "Universal" remote, it might have more than one code type stored under a mode.

- a. No functions may be stored under the LEARN key in the AT&T mode.
- b. Depending on the remote you are trying to learn, some keys may not be learnable.
- c. Only one original device type can be learned per individual mode.
- d. Use fresh batteries for your original remote, and make sure the batteries in your U-verse remote are fully charged.
- e. Keep at least three feet away from incandescent or low-energy lights when learning.
- f. Before learning, clear all learned commands (refer to Section D-II) then try learning 2 or 3 commands initially.

g. Point your original remote at the bottom end of your U-verse remote so the IR elements on both remotes are directly in line with each other (see diagram to the right). You may need to adjust the height of either remote to achieve this.

Caring for the environment by recycling

This symbol on an AT&T product means the product should not be disposed of with household waste.

Disposal of your charging base, power supply or remote control.

Please do not dispose of any of the items in this package with your household waste. These items should be disposed of according to the national collection and recycling schemes operated by your local or regional authority. Alternatively you may return unwanted items to any approved AT&T Service Center in your region.

Code List

	TV
Alex	0185
Acme	0010
Admiral	0020 0226 0001
Advent	0116 0176 0922
Adventure	0174
Aiko	0058
Aiva	0195 0196 0227 0269
Alleron	0051
Amark	0020
Amtron	0053
Akai	0105 0002 0077 1137
Anam National	0003 0003
	0025 0042 0193
AOC	0004 0005 0009 1009
	0014 0156 0175 0187
Apex	0214 0216 0215 1132
Aspect	0059
Audiovox	0053 1019 1117
Axion	0177
Bang & Olufsen	0190
Belcor	0004
Bell & Howell	0031 0049 0000 0001
Beng	0081 0083 0101
Bluesky	1155 0144
Bradford	0053
Broksonic	0147 0135 0310
Brokwood	0004
Candle	0004 0009 0174 0008
Capehart	0175
CCE	1153
Celera	0214
Celebrity	0002
Centrios	0169
Centurion	0009
Cetronic	0042
Changhong	0214 0401
Cineral	0058 0144
Citizen	0004 0009 0053 0105 0109
	0189 0135 0001 0008 0042 0058
Clairtone	0014
Classic	0214 0401 0042
Coby	1091 1124
Color Voice	0010
Colortyme	0004 0009 0010
Concerto	0004 0009
Conierge	0012 0121 0042
Contec/Comy	0053 0012 0121 0042
Cornea	0050
Craig	0053 0042
Crosley	0062
Crown	0053 0042
Curtis Mathes	0031 0105 0130 0004
	0009 0000 0049 0109 0358 0001 0015
CTX	0020
GXC	0053 0042
Cybervision	0144
Daewoo	0130 0004 0009 0100 0005
	0138 0043 0140 0039 0448 0080 0042
	0058 0017 0010 0126 0018 0127 0019
Dayton	0004 0009
Dell	0209 0028 0132
Diamond Vision	0210 0048 0092
Digitame	1017
Digistar	1019 0165 0118 0116
Dimensis	0167 0132 1020 1151 1152
	0031 0000

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.



