

Content

Getting started	3
1.1 Installing the SIM Cards and the Battery	3
1.2 Charging the Battery	3
1.3 Linking to the Network	4
Input method.....	4
1.4 To Shift Entry Methods	4
1.5 Numeric and English Input	4
1.6 Inserting a Symbol	4
Using the Menus.....	5
1.7 Messages	5
1.8 Fun and Games	5
1.9 Contacts.....	5
1.10 Multimedia.....	5
1.11 Call center	6
1.12 Organizer.....	7
1.13 Settings.....	7
1.14 File manager.....	10

Phone Specifications



- ✚ Dimensions (H×W×D): 119*49*14.3mm
- ✚ Weight: 65g/85g with battery
- ✚ Camera:0.3Mpixel
- ✚ Lithium battery
- ✚ Rated capacity: 3.7V 900 mAh
- ✚ Continuous standby duration: (Relates to network status)240 hours
- ✚ Continuous conversation duration: (Relates to network status) 500 min
- ✚ Please refer to their labels for other data related to the battery and the charger.

Getting started

1.1 Installing the SIM Cards and the Battery

A SIM card carries useful information, including your mobile phone number, PIN (Personal Identification Number), PUK (PIN Unlocking Key), IMSI (International Mobile Subscriber Identity), network information, contacts data, and short messages data.

1.2 Charging the Battery

The lithium battery delivered with the mobile phone can be put into use immediately after being unpacked. Your mobile phone can monitor and display the battery state.

- ◆ Normally the remaining energy of the battery is indicated by the battery level icon at the upper right corner of the display screen.
- ◆ When the battery energy is insufficient, the mobile phone prompts "Battery low". If you have set an alert tone, an alert tone will be given off when the battery level is too low.
- ◆ A charging animation appears when the battery is being charged. When the charging is complete, the animation disappears.
- ◆ It is normal of the battery to become hot during the charging period.
- ◆ The battery icon does no longer flicker when the charging process ends.
- ◆ Use only the battery provided by the vendor. Otherwise, damages or even injuries could be caused during the charging.
- ◆ Power off the mobile phone before removing the battery.
- ◆ The charging process lasts a longer time for a new battery or a battery not in use for long. If the battery voltage is too low to enable the mobile phone to be powered on, charge the battery for a longer time.
- ◆ During the charging, ensure the battery is placed in a room temperature environment or in an

environment close to room temperature.

Immediately stop using the battery if the battery produces odor, overheats, cracks, distorts or has other damage, or if the electrolyte leaks.

- ◆ The battery wears out with use. A longer charging time is required as the battery is put into use for a long time.

1.3 Linking to the Network

After the SIM card and the mobile phone are successfully unlocked, the mobile phone automatically searches for an available network.

Input method

This mobile phone provides multiple input methods, including English input (both upper and lower case), Es, ES and numeric input method.

1.4 To Shift Entry Methods

Press # key to switch between input methods.

1.5 Numeric and English Input

You can input numbers with the numeric input method. Press a number key to input the corresponding number. Switch to English input, press letter keys to input the English word.

.

1.6 Inserting a Symbol

Press the * key to enter the **Select symbol** interface and select a symbol you want.

Using the Menus

1.7 Messages

You can send and receive test message. If the short message memory is full, a blinking message icon appears on the top of the screen. While entering the Messaging interface, you will see the following menu options: Write message, Inbox, Drafts, Sent messages and SMS settings.

1.8 Fun and Games

Access this menu, it provides with an embedded game (Happy egg). For specific operation about game, please refer to 'Game help' option of the game.

1.9 Contacts

The mobile phone can store up to 200 telephone numbers.

1.10 Multimedia

Mobile TV

Use this function to search television program.

Camera

Use this function to capture pictures.

Image viewer

You can view the pictures or images through this function.

Video recorder

This function enables you to record dynamic pictures.

Video player

Use this function to play video files.

Audio Player

Use this function to play audio files. In audio player interface, you can press * or # key to tune volume.

Sound recorder

Use this function to record audio files. The phone supports WAV and AMR format.

FM Radio

You can use the application as a traditional FM radio with automatic tuning and saved channels. Tap * or # key to tune volume.

1.11

Call center

Call history

◆ **Missed Calls / Dialed Calls/ Received Calls/ Delete call logs/Call timers/Text msg.counter**

You can view a list of the above.

Call settings

■ **SIM Call settings**

Call waiting/ Call divert/ Call barring/Line switching.

You can browse a list of above.

■ **Advanced settings**

Through this function, you can set Call time reminder, Auto redial and Answer mode.

1.12 Organizer

Calendar

There is a monthly-view calendar for you to keep track of important appointments, etc.

Alarm

Five alarm clocks are set but deactivated by default. For each alarm clock, the date and time can be set with ringing alert.

Power tools

STK service is the tool kit of SIM card. This phone supports the service function. The specific items are depended by SIM card and network.

Bluetooth

You can use Bluetooth to transfer data and files after you pair your device with other device.

Calculator

This calculator provides limited precision and is only applicable to simple arithmetic calculation.

1.13 Settings

Dual SIM settings

- Only SIM 1 Open
- Only SIM 2 Open

➤ Dual SIM Open

Phone Settings

- ◆ **Date and time:** Set the date format, the time format, and detail time of the location.
- ◆ **Language:** Select the display language for the mobile phone.
- ◆ **Pref. Input method:** Select one of the input methods as the prior. So while you write SMS, it will automatically display the selected input method by default.
- ◆ **Display:** Users can access this item to set wallpaper and Show date and time.
- ◆ **Dedicated key:** Customize the shortcut functions of the Up, Left, and Right direction keys. In the standby interface, you can press a direction key (not including down navigation key) to directly enter the function menu corresponding to that direction key.
- ◆ **Flight mode:** Once you switch on Flight mode, your phone will have no service.
- ◆ **Misc. settings:** You can set LCD backlight here.

Network settings

You can search the network again. Select your favorite network and choose to register the network automatically or manually.

Preferred networks: You can set the preferred registered network for SIM card.

Security Settings

This function provides you with related settings about safety use.

◆ **SIM security**

PIN lock: The PIN (Personal identification number, 4 to 8 digits) code prevents your SIM card from being used by unauthorized people.

Change PIN: In general, the PIN is supplied with SIM card by the network operator. If PIN check is enabled,

you need to input the PIN each time when you power on your mobile phone. The SIM card will be locked if you input wrong PIN code for three times.

◆ **Phone security**

Phone lock: Set the phone lock, the password is 1122 by default.

Change password: You should firstly input initial password 1122, and input the desired new password.

◆ **Auto keypad lock**

You can set the keypad lock automatically after a specific time you set.

Connectivity

Data account: you can add data account. It depends on your SIM network operation.

Restore factory settings

Use this function to restore factory settings. The initial password is 1122.

User profiles

The mobile phone provides multiple user profiles, **General, Silent, Meeting and Outdoor.**

You can customize settings on profile and then activate corresponding profiles.

There is no option for activating the Headset mode on the screen. When you insert an earpiece to the mobile phone, the mobile phone automatically enters the Headset mode. For details on operation, refer to **General**. If you set **Call settings > Common call settings > Answer mode** to **Any key**, incoming calls will be automatically answered.

Shortcuts

Customize the shortcut functions and then go to Phone settings > Dedicated keys to define Up, Left and Right direction keys.

1.14

File manager

The phone provides a certain space for users to manage files and supports the Micro SD card. You can use the file manager to conveniently manage various directories and files on the phone and the Micro SD card.

FCC Regulations:

● This mobile phone complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

● This mobile phone has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Note: The country code selection is for non-US model only and is not available to all US model. Per FCC regulation, all WiFi product marketed in US must fixed to US operation channels only.

▶ **RF Exposure Information (SAR)**

This mobile phone meets the government's requirements for exposure to radio waves.

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. *Tests for SAR are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The highest SAR value for the model phone as reported to the FCC when tested for use at the ear is 0.603 W/kg and when worn on the body, as described in this user guide, is 0.604 W/kg (Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements.)

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid after searching on FCC ID: **YHLBLUJENNYTV**.

For body worn operation, this phone has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and the positions the handset a minimum of 1.5 cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the phone at the ear, position the handset a minimum of 1.5 cm from your body when the phone is switched on.

★ Warning

The operating temperature of this mobile phone is -10°C ~ +50°C.