

## Instruction Manual and Replacement Parts List

---

# Stationary Integrated Systems

## High Pressure Breathing Air System

UNICUS 4i - 25



November 6, 2017

2nd Edition, Rev. 0 Chg. 3  
© Bauer Compressors, Inc.

MNL-0021

This information is believed to be accurate by Bauer Compressors, Inc., as of it's date of publication, but Bauer offers NO WARRANTY regarding the accuracy, or continuing accuracy, of the information set forth herein. Bauer shall not be liable for inaccuracies in, or consequences resulting from, your use of this information. All information supplied is in connection with sales of Bauer's products, and is thus subject to Bauer's standard terms and conditions of sale. Bauer reserves the right to change this information and has no obligation to update these materials. This information is copyrighted by Bauer Compressors, Inc., and Bauer reserves to itself all rights to this publication. Bauer's customers have no right to reproduce, rewrite, modify, license or permit anyone else's use of this information, without the express written permission of Bauer Compressors, Inc.

**WARNING**

This Instruction Manual and Replacement Parts List contains safety information and instructions for the UNICUS 4i High Pressure Breathing Air System.  
You must read, understand and follow all safety precautions and instructions.

**1st Edition May 1993**

| Rev | Chg | Date      | Notes            | Auth |
|-----|-----|-----------|------------------|------|
| 1   | 0   | Aug. 1993 |                  |      |
| 2   | 0   | May 1997  |                  |      |
| 3   | 0   | Dec. 1999 | Area Code Change | JH   |

**2nd Edition; March 15, 2017**

| Rev | Chg | Date          | Notes                                          | Auth |
|-----|-----|---------------|------------------------------------------------|------|
| 0   | 0   | Mar. 15, 2017 | Converted from UN II 13, 19 & 25 to UN 4i - 25 | SS   |
| 0   | 1   | Mar. 30, 2017 | Added RFID Chapter, updated Electrical         | SS   |
| 0   | 2   | Apr. 26, 2017 | Updated Drive Chapter                          | SS   |
| 0   | 3   | Nov. 6, 2017  | Added and Reworded RFID Notes                  | SS   |

## **FCC Compliance Statement**

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this equipment.

This product meets the applicable FCC Part 15 rules and Industry Canada's license exempt RSSs. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent matériel est conforme aux CNR exempts de licence d'Industrie Canada. Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne peut pas provoquer d'interférences, et (2) cet appareil doit accepter toute interférence, y compris celles susceptibles de provoquer le fonctionnement du dispositif.

To limit RF exposure, please ensure 4 inches (10 cm) of separation from the transmitter antennas at all times.

# Table of Contents

## CHAPTER 1:- - - - - INTRODUCTION

|            |                                                    |   |
|------------|----------------------------------------------------|---|
| <b>1.1</b> | <b>HOW TO USE THIS MANUAL</b> .....                | 1 |
| 1.1.1      | Manual Safety Notices .....                        | 1 |
| <b>1.2</b> | <b>HOW TO USE THE REPLACEMENT PARTS LIST</b> ..... | 2 |
| <b>1.3</b> | <b>HOW TO USE THE APPENDIX</b> .....               | 3 |
| <b>1.4</b> | <b>UNIT SPECIFICATIONS</b> .....                   | 4 |
| 1.4.1      | UNICUS 4i - 25.....                                | 4 |
| 1.4.1.1    | Compressor Block.....                              | 4 |
| 1.4.1.2    | Compressor Drive.....                              | 4 |
| 1.4.1.3    | Purification System Applicability .....            | 4 |
| <b>1.5</b> | <b>COMPONENT LOCATIONS</b> .....                   | 5 |

## CHAPTER 2:- - - - - OPERATING INSTRUCTIONS

|            |                                     |    |
|------------|-------------------------------------|----|
| <b>2.1</b> | <b>EMERGENCY STOP BUTTON</b> .....  | 8  |
| <b>2.2</b> | <b>OPERATOR INTERFACE</b> .....     | 8  |
| 2.2.1      | Badge Screen .....                  | 8  |
| 2.2.2      | Admin. Main Menu Screen .....       | 9  |
| 2.2.2.1    | PERSONNEL .....                     | 10 |
| 2.2.2.2    | Cylinders.....                      | 11 |
| 2.2.2.3    | Settings.....                       | 12 |
| 2.2.2.3.1  | Setup .....                         | 13 |
| 2.2.2.3.2  | Parameters.....                     | 13 |
| 2.2.2.3.3  | Maintenance.....                    | 14 |
| 2.2.2.3.4  | Gas Sensor .....                    | 14 |
| 2.2.2.4    | Reports .....                       | 14 |
| 2.2.2.5    | Diagnose .....                      | 14 |
| 2.2.3      | Home Screen .....                   | 15 |
| 2.2.3.1    | Compressor Status .....             | 16 |
| 2.2.3.2    | Fill Cylinders .....                | 16 |
| 2.2.3.3    | Remote Fill .....                   | 17 |
| <b>2.3</b> | <b>FILL STATION OPERATION</b> ..... | 18 |
| 2.3.1      | Remote Fill Connection.....         | 19 |
| 2.3.1.1    | Connecting an Air Bottle.....       | 20 |
| 2.3.1.2    | Filling the Air Bottle.....         | 20 |
| 2.3.1.3    | Removing the Air Bottle.....        | 20 |

## CHAPTER 3:- - - - - IK 18.1 II COMPRESSOR BLOCK

|            |                            |    |
|------------|----------------------------|----|
| <b>3.1</b> | <b>DESCRIPTION</b> .....   | 21 |
| 3.1.1      | Component Location .....   | 21 |
| 3.1.2      | Air Flow Diagram.....      | 22 |
| 3.1.3      | Lubrication System.....    | 22 |
| 3.1.3.1    | Description.....           | 22 |
| 3.1.3.2    | Oil Level Check .....      | 23 |
| 3.1.3.3    | Oil Change Interval.....   | 23 |
| 3.1.3.4    | Oil Capacity .....         | 23 |
| 3.1.3.5    | Oil Change .....           | 23 |
| 3.1.3.6    | Venting the Oil Pump ..... | 25 |

|            |                                                          |           |
|------------|----------------------------------------------------------|-----------|
| 3.1.4      | Inlet Filter .....                                       | 25        |
| 3.1.4.1    | Description .....                                        | 25        |
| 3.1.4.2    | Maintenance .....                                        | 25        |
| 3.1.5      | Interstage Separators .....                              | 26        |
| 3.1.5.1    | Description .....                                        | 26        |
| 3.1.5.2    | Maintenance .....                                        | 27        |
| 3.1.6      | Compressor Valves and Valve Heads .....                  | 28        |
| 3.1.6.1    | Functional Description .....                             | 28        |
| 3.1.6.2    | Initial Operational Check of the Valves .....            | 29        |
| 3.1.6.3    | General Instructions for Changing the Valves .....       | 29        |
| 3.1.6.4    | Changing the 1st Stage Valves .....                      | 30        |
| 3.1.6.4.1  | Removal Procedure .....                                  | 30        |
| 3.1.6.4.2  | Installation Procedure .....                             | 30        |
| 3.1.6.5    | Changing the 2nd Stage Valves .....                      | 31        |
| 3.1.6.5.1  | Removal Procedure .....                                  | 31        |
| 3.1.6.5.2  | Installation Procedure .....                             | 31        |
| 3.1.6.6    | Changing the 3rd Stage Valves .....                      | 32        |
| 3.1.6.6.1  | Removal Procedure .....                                  | 32        |
| 3.1.6.6.2  | Installation Procedure .....                             | 32        |
| 3.1.6.7    | Changing the 4th/5th Stage Valves .....                  | 33        |
| 3.1.6.7.1  | Discharge Valve Removal Procedure .....                  | 33        |
| 3.1.6.7.2  | Discharge Valve Installation Procedure .....             | 34        |
| 3.1.6.7.3  | Inlet Valve Removal and Installation .....               | 34        |
| 3.1.7      | Repair and Troubleshooting .....                         | 35        |
| 3.1.7.1    | Repair .....                                             | 35        |
| 3.1.7.2    | Troubleshooting .....                                    | 36        |
| 3.1.8      | Replacement Parts List .....                             | 38        |
| <b>3.2</b> | <b>AUTOMATIC CONDENSATE DRAIN SYSTEM; ASY-4002 .....</b> | <b>65</b> |
| 3.2.1      | Description .....                                        | 65        |
| 3.2.2      | 120 IT Block Regulator Assembly .....                    | 66        |
| 3.2.2.1    | ACD Operation .....                                      | 66        |
| 3.2.2.2    | Start Unloading .....                                    | 67        |
| 3.2.2.3    | Standstill Drainage .....                                | 67        |
| 3.2.2.4    | Condensate Drain Separator .....                         | 67        |
| 3.2.3      | ACD Maintenance .....                                    | 67        |
| <b>3.3</b> | <b>CONDENSATE COLLECTOR .....</b>                        | <b>68</b> |
| 3.3.1      | ACD Replacement Parts List .....                         | 70        |
| 3.3.2      | Troubleshooting .....                                    | 76        |

## CHAPTER 4: - - - - - PURIFICATION SYSTEM

|            |                                                           |           |
|------------|-----------------------------------------------------------|-----------|
| <b>4.1</b> | <b>INTRODUCTION .....</b>                                 | <b>77</b> |
| 4.1.1      | General Purification System Procedures .....              | 77        |
| 4.1.2      | Chamber Safety Bore .....                                 | 77        |
| 4.1.3      | Manual Condensate Drainage .....                          | 78        |
| 4.1.4      | Model, Serial Number and Part Number Identification ..... | 78        |
| 4.1.4.1    | Compressor Data Plate .....                               | 78        |
| 4.1.4.2    | Purification System Data Plate .....                      | 79        |
| 4.1.4.3    | Cartridge Installation Data Plate .....                   | 79        |
| 4.1.5      | Purification System Configurations .....                  | 79        |
| 4.1.6      | Industrial Purification System Configurations .....       | 80        |
| 4.1.7      | Cartridge Operating Life .....                            | 80        |
| 4.1.7.1    | Calculating the Maximum Cartridge Operating Hours .....   | 81        |
| 4.1.7.2    | Calculating the Adjusted Cartridge Operating Hours .....  | 81        |

|            |                                                             |           |
|------------|-------------------------------------------------------------|-----------|
| 4.1.7.3    | Purification Cartridge Operating Hours Form .....           | 83        |
| <b>4.2</b> | <b>1P5S SECURUS II® PURIFICATION SYSTEM .....</b>           | <b>84</b> |
| 4.2.1      | 1P5S Securus II® Purification System Major Components ..... | 84        |
| <b>4.3</b> | <b>COMPONENT DESCRIPTION .....</b>                          | <b>85</b> |
| 4.3.1      | Oil and Water Separator .....                               | 85        |
| 4.3.2      | Chamber .....                                               | 85        |
| 4.3.3      | Cartridge .....                                             | 85        |
| 4.3.3.1    | Cartridge Construction .....                                | 85        |
| 4.3.3.2    | Cartridge Handling .....                                    | 86        |
| 4.3.4      | Condensate Drain Valve .....                                | 86        |
| 4.3.5      | Check Valves .....                                          | 86        |
| 4.3.6      | Bleed Valve .....                                           | 86        |
| 4.3.7      | Pressure Maintaining Valve .....                            | 86        |
| 4.3.8      | Safety Valve .....                                          | 86        |
| 4.3.9      | Securus II® Electronic Moisture Monitor System .....        | 86        |
| 4.3.9.1    | Securus II® Cartridge .....                                 | 86        |
| 4.3.9.2    | Securus II® Transmitter .....                               | 86        |
| <b>4.4</b> | <b>MAINTENANCE .....</b>                                    | <b>87</b> |
| 4.4.1      | Oil and Water Separator .....                               | 87        |
| 4.4.1.1    | Removal of the Securus II® Transmitter .....                | 89        |
| 4.4.2      | Cartridge Replacement .....                                 | 89        |
| 4.4.2.1    | Leaking at the Safety Bore .....                            | 90        |
| <b>4.5</b> | <b>REPLACEMENT PARTS LIST .....</b>                         | <b>91</b> |

## CHAPTER 5:- - - - - COMPRESSOR DRIVE; UNICUS 4I

|            |                                                    |           |
|------------|----------------------------------------------------|-----------|
| <b>5.1</b> | <b>VERTICAL COMPRESSOR DRIVE .....</b>             | <b>96</b> |
| <b>5.2</b> | <b>MAINTENANCE OF THE V-BELT AND SHEAVES .....</b> | <b>96</b> |
| 5.2.1      | Check The Sheaves .....                            | 96        |
| 5.2.2      | Check the V-belt .....                             | 97        |
| 5.2.3      | Replacing the Belt .....                           | 97        |
| 5.2.4      | Replacing the Sheave .....                         | 97        |
| <b>5.3</b> | <b>REPLACEMENT PART LIST .....</b>                 | <b>98</b> |

## CHAPTER 6:- - - - - -ELECTRICAL PANEL, ASY-1191

|            |                                           |            |
|------------|-------------------------------------------|------------|
| <b>6.1</b> | <b>OVERVIEW .....</b>                     | <b>99</b>  |
| <b>6.2</b> | <b>ELECTRICAL PANEL .....</b>             | <b>99</b>  |
| 6.2.1      | Wiring Diagram .....                      | 99         |
| 6.2.2      | Electrical Panel Interior Access .....    | 99         |
| <b>6.3</b> | <b>AC POWER REQUIREMENTS .....</b>        | <b>100</b> |
| <b>6.4</b> | <b>ELECTRICAL PANEL COMPONENTS .....</b>  | <b>100</b> |
| 6.4.1      | Programmable Logic Controller (PLC) ..... | 100        |
| 6.4.1.1    | Replacing the PLC .....                   | 101        |
| 6.4.1.2    | Installing a New Program .....            | 101        |
| 6.4.1.3    | Installing a Memory Card .....            | 102        |
| 6.4.2      | Hour Meter .....                          | 102        |
| 6.4.3      | Motor Starter .....                       | 102        |
| 6.4.4      | Overload Relay .....                      | 103        |
| 6.4.5      | Power Supply .....                        | 103        |
| <b>6.5</b> | <b>ALARMS .....</b>                       | <b>104</b> |
| 6.5.1      | Final Separator Warning .....             | 104        |

|       |                                   |     |
|-------|-----------------------------------|-----|
| 6.5.2 | Compressor High Temperature ..... | 104 |
| 6.5.3 | Compressor Low Oil Pressure ..... | 105 |
| 6.6   | REPLACEMENT PARTS LIST .....      | 106 |

## CHAPTER 7: - - - - -RFID OPTION

|       |                                             |     |
|-------|---------------------------------------------|-----|
| 7.1   | DESCRIPTION .....                           | 108 |
| 7.2   | COMPONENTS .....                            | 108 |
| 7.3   | FUNCTIONS .....                             | 109 |
| 7.3.1 | Assigning the Cylinder .....                | 109 |
| 7.3.2 | Filling the Cylinder with RFID Option ..... | 109 |
| 7.4   | REPLACEMENT PARTS LIST .....                | 110 |

## CHAPTER 8: - - - - -ENMET GAS MONITORS

|     |                          |     |
|-----|--------------------------|-----|
| 8.1 | DESCRIPTION .....        | 111 |
| 8.2 | OPERATION .....          | 111 |
| 8.3 | CALIBRATION .....        | 112 |
| 8.4 | SENSOR REPLACEMENT ..... | 113 |
| 8.5 | REPLACEMENT PARTS .....  | 114 |

## CHAPTER 9: - - - - -CFS III MAINTENANCE

|       |                                      |     |
|-------|--------------------------------------|-----|
| 9.1   | DESCRIPTION .....                    | 120 |
| 9.2   | FILL STATION AIR FLOW .....          | 120 |
| 9.3   | MAINTENANCE .....                    | 120 |
| 9.3.1 | General Maintenance .....            | 120 |
| 9.3.2 | Nonadjustable Valves .....           | 121 |
| 9.3.3 | Pressure Gauges .....                | 121 |
| 9.3.4 | Safety Valves .....                  | 121 |
| 9.3.5 | Pneumatic Connections .....          | 121 |
| 9.3.6 | Bearings for Bottle Door Pivot ..... | 122 |
| 9.3.7 | Pressure Hoses .....                 | 122 |
| 9.3.8 | Door Gas Spring .....                | 122 |
| 9.4   | REPLACEMENT PARTS LIST .....         | 123 |
| 9.4.1 | CFS III Assemblies .....             | 123 |
| 9.5   | FILL HOSE ASSEMBLIES .....           | 128 |

## CHAPTER 10: - - - - -UNICUS III HP AIR STORAGE

|          |                                                      |     |
|----------|------------------------------------------------------|-----|
| 10.1     | BOTTLE SPECIFICATIONS .....                          | 132 |
| 10.1.1   | ISO/ON; ISO 9809-PART 2 / United Nations .....       | 132 |
| 10.1.2   | ASME; American Society of Mechanical Engineers ..... | 132 |
| 10.2     | DESCRIPTION AND MAINTENANCE .....                    | 133 |
| 10.2.1   | Description .....                                    | 133 |
| 10.2.2   | Maintenance .....                                    | 134 |
| 10.2.2.1 | Storage Bottles .....                                | 134 |
| 10.2.2.2 | Pressure Gauges .....                                | 134 |
| 10.2.2.3 | Tube Connections .....                               | 135 |
| 10.2.2.4 | Safety Valve .....                                   | 135 |

|                                                     |            |
|-----------------------------------------------------|------------|
| 10.2.2.5 Pressure Hoses .....                       | 135        |
| <b>10.3 AUTOCASCADE SYSTEM .....</b>                | <b>136</b> |
| 10.3.1 General .....                                | 136        |
| 10.3.2 Electrical .....                             | 137        |
| 10.3.3 Filling the Storage Banks .....              | 137        |
| 10.3.4 Filling Bottles from the Storage Banks ..... | 137        |
| 10.3.5 Manual Bypass .....                          | 137        |

## CHAPTER 11: - - - - -APPENDIX

|                                                        |            |
|--------------------------------------------------------|------------|
| <b>11.1 SAFETY .....</b>                               | <b>138</b> |
| 11.1.1 General Safety Precautions .....                | 138        |
| 11.1.2 Safety Warning Labels .....                     | 140        |
| <b>11.2 UNPACKING, HANDLING AND INSTALLATION .....</b> | <b>141</b> |
| 11.2.1 Unpacking and Handling .....                    | 141        |
| 11.2.2 Installation of the Compressor Unit .....       | 142        |
| 11.2.2.1 General .....                                 | 142        |
| 11.2.2.2 Ventilation .....                             | 143        |
| 11.2.2.2.1 Outdoor Installation .....                  | 143        |
| 11.2.2.2.2 Indoor Installation .....                   | 143        |
| 11.2.2.2.3 Natural Ventilation .....                   | 143        |
| 11.2.2.2.4 Forced Ventilation .....                    | 144        |
| 11.2.3 Intake Gas .....                                | 144        |
| 11.2.3.1 Inside Gas Source .....                       | 144        |
| 11.2.3.2 Outside Gas Source .....                      | 145        |
| 11.2.4 Compressor Intake Piping .....                  | 145        |
| 11.2.5 Installation Procedures .....                   | 146        |
| 11.2.6 Electrical Installation .....                   | 146        |
| 11.2.6.1 Electric Drive .....                          | 146        |
| 11.2.6.2 Electrical Supply .....                       | 146        |
| 11.2.7 Pneumatic Leaks .....                           | 149        |
| <b>11.3 LONG TERM STORAGE .....</b>                    | <b>149</b> |
| 11.3.1 General .....                                   | 149        |
| 11.3.2 Preparations .....                              | 149        |
| 11.3.2.1 Unit Equipped with a Filter System .....      | 149        |
| 11.3.3 Preserving the Compressor .....                 | 149        |
| 11.3.4 Preventive Maintenance During Storage .....     | 150        |
| 11.3.5 Lubrication Oils for Preservation .....         | 150        |
| 11.3.6 Reactivating the Compressor Unit .....          | 150        |
| <b>11.4 REPRODUCIBLE FORMS .....</b>                   | <b>151</b> |
| 11.4.1 Scheduled Maintenance Form .....                | 151        |
| 11.4.2 Cartridge Operating Hours .....                 | 154        |
| 11.4.3 Record of Operating Hours .....                 | 155        |
| <b>11.5 REFERENCE DATA .....</b>                       | <b>156</b> |
| 11.5.1 Tightening Torque Values .....                  | 156        |
| 11.5.2 Torque Sequence Diagrams .....                  | 156        |
| 11.5.3 Conversion Formulas .....                       | 156        |
| 11.5.4 Approved Lubricants Chart .....                 | 157        |
| 11.5.5 Glossary of Abbreviations and Acronyms .....    | 157        |
| <b>11.6 ADDITIONAL DOCUMENTS .....</b>                 | <b>158</b> |
| 11.6.1 Diagrams and Drawings .....                     | 158        |
| 11.6.2 Other Documents .....                           | 158        |

## List of Figures

### CHAPTER 1: - - - - - INTRODUCTION

|            |                                 |   |
|------------|---------------------------------|---|
| Figure 1-1 | Compressor Identification Label | 3 |
| Figure 1-2 | UNICUS 4i                       | 5 |
| Figure 1-3 | UNICUS 4i Rear                  | 6 |
| Figure 1-4 | UNICUS 4i Front Panel           | 7 |

### CHAPTER 2: - - - - - OPERATING INSTRUCTIONS

|             |                         |    |
|-------------|-------------------------|----|
| Figure 2-1  | Control Panel           | 8  |
| Figure 2-2  | Initial Screen          | 9  |
| Figure 2-3  | Admin. Main Menu Screen | 9  |
| Figure 2-4  | Personnel               | 10 |
| Figure 2-5  | Add New                 | 11 |
| Figure 2-6  | Cylinders               | 11 |
| Figure 2-7  | Add New Cylinder        | 12 |
| Figure 2-8  | Settings                | 12 |
| Figure 2-9  | Setup                   | 13 |
| Figure 2-10 | Parameters              | 13 |
| Figure 2-11 | Reports                 | 14 |
| Figure 2-12 | Diagnostic              | 15 |
| Figure 2-13 | Home Screen, Operator   | 15 |
| Figure 2-14 | Compressor Status       | 16 |
| Figure 2-15 | Fill Cylinders          | 17 |
| Figure 2-16 | Bottle Riser            | 18 |
| Figure 2-17 | Bottle Valve Sequences  | 19 |

### CHAPTER 3: - - - - - IK 18.1 II COMPRESSOR BLOCK

|             |                                 |    |
|-------------|---------------------------------|----|
| Figure 3-1  | Compressor Block (Front View)   | 21 |
| Figure 3-2  | Five Stage Compressor Air Flow  | 22 |
| Figure 3-3  | Lubrication Oil System          | 23 |
| Figure 3-4  | Oil Sight Gauge                 | 23 |
| Figure 3-5  | Oil Sight Gauge & Drain         | 24 |
| Figure 3-6  | Removing the Oil Filter Cover   | 24 |
| Figure 3-7  | Replacing the Oil Filter        | 24 |
| Figure 3-8  | Intake Filter                   | 25 |
| Figure 3-9  | 2nd Stage Interstage Separator  | 27 |
| Figure 3-10 | 3rd Stage Interstage Separator  | 27 |
| Figure 3-11 | 4th Stage Interstage Separator  | 28 |
| Figure 3-12 | 1st Stage Valve Function        | 29 |
| Figure 3-13 | Valve Function                  | 29 |
| Figure 3-14 | 1st Stage Valve and Head        | 30 |
| Figure 3-15 | 2nd Valve Head and Valves       | 31 |
| Figure 3-16 | 3rd Stage Valve Head and Valves | 32 |

|             |                                           |    |
|-------------|-------------------------------------------|----|
| Figure 3-17 | 4th/5th Stage Valve and Head .....        | 33 |
| Figure 3-18 | Discharge Valve Removal .....             | 34 |
| Figure 3-19 | Assembly Tool .....                       | 34 |
| Figure 3-20 | Using Special Tool .....                  | 34 |
| Figure 3-21 | Crankcase Assembly .....                  | 38 |
| Figure 3-22 | Complete Crankshaft Assembly .....        | 40 |
| Figure 3-23 | 1st Stage Piston and Cylinder .....       | 41 |
| Figure 3-24 | 2nd & 4th Stage Piston and Cylinder ..... | 42 |
| Figure 3-25 | 3rd Stage Piston and Cylinder .....       | 44 |
| Figure 3-26 | 5th Stage Cylinder and Piston .....       | 45 |
| Figure 3-27 | 1st Stage Valve Head .....                | 46 |
| Figure 3-28 | 2nd Stage Valve Head .....                | 47 |
| Figure 3-29 | 3rd Stage Valve Head .....                | 48 |
| Figure 3-30 | 4th Stage Valve Head .....                | 49 |
| Figure 3-31 | 5th Stage Valve Head .....                | 50 |
| Figure 3-32 | Flywheel Drive Assembly .....             | 51 |
| Figure 3-33 | Intake Filter Assembly .....              | 52 |
| Figure 3-34 | 1st Stage Interfilter (Optional) .....    | 54 |
| Figure 3-35 | 2nd Stage Interstage Separator .....      | 56 |
| Figure 3-36 | 3rd Stage Interstage Separator .....      | 57 |
| Figure 3-37 | 4th Stage Interstage Separator .....      | 58 |
| Figure 3-38 | Cooling System Assembly .....             | 60 |
| Figure 3-39 | Lubricating System Assembly .....         | 62 |
| Figure 3-40 | Lubricating System .....                  | 63 |
| Figure 3-41 | Crankcase Venting .....                   | 64 |
| Figure 3-42 | Automatic Condensate Drain System .....   | 65 |
| Figure 3-43 | 120 IT Block Regulator Assembly .....     | 66 |
| Figure 3-44 | ACD Operator Diagrams .....               | 66 |
| Figure 3-45 | Condensate Collector .....                | 68 |
| Figure 3-46 | ASY-4002 Replacement Parts List .....     | 70 |
| Figure 3-47 | ACD Assembly, ASY-4001 .....              | 72 |
| Figure 3-48 | ACD O-Rings .....                         | 74 |
| Figure 3-49 | Regulator Assembly .....                  | 75 |

## CHAPTER 4:- - - - -PURIFICATION SYSTEM

|             |                                                       |    |
|-------------|-------------------------------------------------------|----|
| Figure 4-1  | Cartridge Safety Venting .....                        | 78 |
| Figure 4-2  | P0 & P31 Safety Venting .....                         | 78 |
| Figure 4-3  | Purification System Data Plates (typical) .....       | 78 |
| Figure 4-4  | Correction Factor for Cartridge Operating Hours ..... | 82 |
| Figure 4-5  | Example Record of Adjusted Operating Hours .....      | 82 |
| Figure 4-6  | PSS Securus H® Purification System .....              | 84 |
| Figure 4-7  | Oil and Water Separator Labels .....                  | 85 |
| Figure 4-8  | Oil and Water Separator .....                         | 88 |
| Figure 4-9  | Sintered Metal Filter Assembly .....                  | 88 |
| Figure 4-10 | Removal of the Securus H® Transmitter .....           | 89 |
| Figure 4-11 | Cartridge Replacement .....                           | 89 |

|             |                                                                 |    |
|-------------|-----------------------------------------------------------------|----|
| Figure 4-12 | P5 Purification System Parts List .....                         | 91 |
| Figure 4-13 | Oil and Water Separator Parts List .....                        | 92 |
| Figure 4-14 | 27" Chamber Assembly Parts List .....                           | 93 |
| Figure 4-15 | Securus II® Electronic Moisture Monitor System Parts List ..... | 94 |

## CHAPTER 5: - - - - - COMPRESSOR DRIVE; UNICUS 4I

|            |                                            |    |
|------------|--------------------------------------------|----|
| Figure 5-1 | Vertical Drive with Idler (typical) .....  | 96 |
| Figure 5-2 | Tensioning 1 .....                         | 97 |
| Figure 5-3 | Tensioning 2 .....                         | 97 |
| Figure 5-4 | UNICUS 4i, Vertical Drive with Idler ..... | 98 |

## CHAPTER 6: - - - - - ELECTRICAL PANEL, ASY-1191

|             |                                  |     |
|-------------|----------------------------------|-----|
| Figure 6-1  | ASY-1191 .....                   | 99  |
| Figure 6-2  | Electrical Panel Label .....     | 100 |
| Figure 6-3  | PLC, CNT-0104 .....              | 100 |
| Figure 6-4  | Connector Block Removal .....    | 101 |
| Figure 6-5  | Hour Meter .....                 | 102 |
| Figure 6-6  | Motor Starter (typical) .....    | 103 |
| Figure 6-7  | Overload Relay (typical) .....   | 103 |
| Figure 6-8  | Power Supply .....               | 103 |
| Figure 6-9  | High Temperature Switch .....    | 104 |
| Figure 6-10 | Pressure Sensor (Typical) .....  | 104 |
| Figure 6-11 | Electrical Panel, Exterior ..... | 106 |

## CHAPTER 7: - - - - - RFID OPTION

|            |                        |     |
|------------|------------------------|-----|
| Figure 7-1 | Components .....       | 108 |
| Figure 7-2 | Add New Cylinder ..... | 109 |
| Figure 7-3 | RFID Assembly .....    | 110 |

## CHAPTER 8: - - - - - ENMET GAS MONITORS

|            |                                          |     |
|------------|------------------------------------------|-----|
| Figure 8-1 | Regulator & Monitors .....               | 111 |
| Figure 8-2 | Basic Calibration Kit & Test Gases ..... | 112 |
| Figure 8-3 | Enmet Monitors .....                     | 112 |
| Figure 8-4 | Regulator and Monitors .....             | 114 |
| Figure 8-5 | Regulator .....                          | 116 |
| Figure 8-6 | Monitors & Replacement Parts .....       | 118 |
| Figure 8-7 | Calibration Components .....             | 119 |

## CHAPTER 9: - - - - - CFS III MAINTENANCE

|            |                              |     |
|------------|------------------------------|-----|
| Figure 9-1 | Safety Valves .....          | 121 |
| Figure 9-2 | Special Tool, 100-0020 ..... | 122 |
| Figure 9-3 | CFS III Assembly .....       | 123 |
| Figure 9-4 | Fill Whips & Brackets .....  | 124 |

|            |                                      |     |
|------------|--------------------------------------|-----|
| Figure 9-5 | C/S III Door Lock Assembly .....     | 125 |
| Figure 9-6 | Door Handle, Pivot and Bracket ..... | 126 |
| Figure 9-7 | C/S III Door Interlock .....         | 127 |
| Figure 9-8 | Standard Fill Hose Assemblies .....  | 128 |
| Figure 9-9 | Fill Whips with Options .....        | 130 |

---

**CHAPTER 10: - - - - - UNICUS III HP AIR STORAGE**

---

|             |                                  |     |
|-------------|----------------------------------|-----|
| Figure 10-1 | UNICUS III Storage Systems ..... | 134 |
| Figure 10-2 | Safety Valve, VAL-0022 .....     | 135 |
| Figure 10-3 | Autocascade System .....         | 136 |

---

**CHAPTER 11: - - - - - -APPENDIX**

---

|             |                                         |     |
|-------------|-----------------------------------------|-----|
| Figure 11-1 | Lifting Devices .....                   | 141 |
| Figure 11-2 | Leveling Feet .....                     | 142 |
| Figure 11-3 | Example of Gas Inlet Piping .....       | 146 |
| Figure 11-4 | Incoming Power Wiring Label .....       | 147 |
| Figure 11-5 | 6 Bolt and 4 Bolt Torque Sequence ..... | 156 |

## CHAPTER 1: INTRODUCTION

### 1.1 How To Use This Manual

This manual contains the operating and maintenance instructions for the Bauer Compressors, Inc. products listed on the front cover.

All instructions in this manual should be observed and carried out as written to prevent damage or premature wear to the product or the equipment served by it.

If your unit is equipped with nonstandard accessories and/or options, supplemental information is normally included in other documentation; i.e. OEM Manuals or additional Bauer Manuals.

While every effort is made to ensure the accuracy of the information contained in this manual, Bauer Compressors, Inc. will not, under any circumstances be held accountable for any inaccuracies or the consequences thereof.

### NOTICE

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this equipment.

This product meets the applicable FCC Part 15 rules. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

To limit RF exposure, please ensure 4 inches (10 cm) of separation from the transmitter antennas at all times.

#### 1.1.1 Manual Safety Notices

Important instructions concerning the endangerment of personnel, technical safety or operator safety will be specially emphasized in this manual by placing the information in the following types of safety notices.



### DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. This is limited to the most extreme situations.



### WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or injury.



## CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

## NOTICE


NOTE advise of technical requirements that require particular attention by the operator or the maintenance technician for proper maintenance and utilization of the equipment.

### 1.2 How to Use the Replacement Parts List

- A lozenge ♦ in the Item Number column indicates the part number for a complete assembly.
- a dagger (†) in the Qty column with or without an ellipse (...) in the Part Number column means the part is illustrated for assembly purposes only and is not available for sale as an individual component. This part can be obtained by ordering the complete assembly.
- AR in the Qty column means that the item is cut or manufactured to the size which the customer specifies.
- A dash (—) in the Item Number column indicates that there is more than one part number applicable to the preceding Item Number.
- The letters in the columns labeled Kit indicate the number of operating hours when the part is to be replaced; a replaced every 1,000 hours, b replaced every 2,000 hours and c replaced every 4,000 hours.
- NS in the Item Number column indicates the part is not illustrated but is available.

When placing an order for spare parts, please provide the following information to ensure delivery of the correct parts. The model number, date of manufacture and serial number can be found of the compressor unit identification plate on the compressor unit frame.

| Information            |  | Example  |
|------------------------|--|----------|
| Model Number           |  | UN 4i 25 |
| Serial Number          |  | 196156   |
| Date of Manufacture    |  | 02 2017  |
| Part Number            |  | VAL-0169 |
| Part Description       |  | Valve    |
| Part Quantity Required |  | 1        |

**Figure 1-1** Compressor Identification Label**WARNING**

The use of repair parts other than those included in the Bauer Replacement Parts Lists may create unsafe conditions over which Bauer has no control. Such unsafe conditions can lead to accidents that may be life-threatening, cause substantial bodily injury, and/or result in damage to the equipment. Therefore, Bauer Compressors, Inc. can bear no responsibility for equipment in which unapproved repair parts are installed.

**1.3 How to Use the Appendix**

Information contained in the Appendix to this manual includes the following.

- The safety instructions applicable to this product. They must be read, understood and complied with prior to operating the product.
- The instructions for installing this product. They must be read, understood and complied with prior to operating the product.
- Reproducible Forms
- Reference Data
  - Torque Values
  - Torque Sequence
  - Conversion Formulas
  - Approved Lubricants
  - Glossary of Abbreviations & Acronyms
- Additional Documents

## 1.4 Unit Specifications

All specifications are subject to change without prior notice.

### 1.4.1 UNICUS 4i - 25

|                           |                                    |
|---------------------------|------------------------------------|
| Medium                    | air                                |
| Charging Rate             | 25.2 scfm (714 l/min) <sup>1</sup> |
| Free Air Delivery         | 21.0 scfm (595 l/min) <sup>2</sup> |
| Inlet pressure            | atmospheric                        |
| Operating pressure, max.  | 6,000 psig (420 bar)               |
| Ambient temperature range | 40 - 115 °F (5 - 45 °C)            |
| Weight                    | approximately 1,550 lb.(2,064 kgs) |

#### 1.4.1.1 Compressor Block,

|                                            |                                    |
|--------------------------------------------|------------------------------------|
| IK 18,1 II                                 | Mod. 8                             |
| No. of stages                              | 5                                  |
| No. of cylinders                           | 4                                  |
| Cylinder bore, 1st stage                   | 5.92 in. (130 mm)                  |
| Cylinder bore, 2nd stage                   | 3.465/2.367 in. (88/60 mm)         |
| Cylinder bore, 3rd stage                   | 1.26 in. (32 mm)                   |
| Cylinder bore, 4th stage                   | 0.709 in. (18 mm)                  |
| Cylinder bore, 5th stage                   | 0.394 in. (10 mm)                  |
| Piston Stroke                              | 1.969 in. (50 mm)                  |
| Intermediate pressure, 1st stage           | 45 - 60 psig (3 - 4 bar)           |
| Safety valve setting, 1st stage            | 85 psig (6.0 bar)                  |
| Intermediate pressure, 2nd stage           | 195 - 225 psig (13.5 - 15.5 bar)   |
| Safety valve setting, 2nd stage            | 350 psig (24 bar)                  |
| Intermediate pressure, 3rd stage           | 625 - 640 psig (43 - 44 bar)       |
| Safety valve setting, 3rd stage            | 1,160 psig (80 bar)                |
| Intermediate pressure, 4th stage           | 1,930 - 2,145 psig (133 - 148 bar) |
| Safety valve setting, 4th stage            | 2,610 psig (180 bar)               |
| Direction of rotation when facing flywheel | CCW                                |
| Oil capacity                               | 6 1/3 qts (6 liters)               |
| Oil Pressure                               | 60 - 85 psig (4 - 6 bar)           |
| Recommended oil (Synthetic)                | BAUER OP.-0024                     |
| Maximum Inclination                        | 10° in all directions              |

#### 1.4.1.2 Compressor Drive

|     | Voltage       | Frequency | Phase | Power | RPM   | Type |
|-----|---------------|-----------|-------|-------|-------|------|
| -E3 | 208 - 460 VAC | 60 Hz     | 3Φ    | 20 Hp | 3,600 | ODP  |

#### 1.4.1.3 Purification System Applicability

The Bauer P5 Purification System with Securus II® Electronic Moisture Monitoring is the standard purification system supplied.

<sup>1</sup> Based on charging in 30 cubic feet tank from 500 to 3000 PSIG

<sup>2</sup> Referenced to standard inlet conditions of 58°F and 36% humidity at 14.70 psia


## 1.5 Component Locations

**Figure 1-2** UNICUS 4E



1. Lab On Locale (LOL)
2. Electronic Auto Cascade
3. Electrical Enclosure
4. HP Hose Reel
5. Drain Valves for ASME Storage Cylinders


6. Containment Fill Station Controls
7. 12" Touch Screen Monitor
8. Purification
9. Containment Fill Station

**Figure 1-3** UNICUS 4i Rear

1. Air Compressor

2. Automatic Condensate Drain Assembly

3. HIP Storage (ASME or ISO/UN)

**Figure 1-4 UNICUS 4i Front Panel**


1. Hose Reel Fill Valve  
2. CFS Fill Valves

3. Emergency Stop Push Button  
4. Touch Screen Control Monitor

## CHAPTER 2: OPERATING INSTRUCTIONS

The following instructions apply to the Unicus 4i. The monitor for this unit is a 15" graphic touch screen and uses a Windows 7, 64 bit operating system.

**Figure 2-1** Control Panel



The electrical panel assembly & PLC will provide logical control and safety shutdowns for the compressor equipment. All necessary time delays, counters, shutdowns, sequencing and safety features are incorporated into a proprietary software program permanently saved into PLC memory. The software program is based on the pressure and use of the compressor. The operator uses the touchscreen interface to communicate with the PLC which is located within the electrical enclosure.

### 2.1 Emergency Stop Button


A normally closed switch when pulled out, when the E-Stop button is pressed in, it disconnects the main power source, turning off the compressor, draining the ACD system and stopping air delivery to the consuming devices. This button is to be used in case of emergency. Normal operational stops should be accomplished using the operator interface.

### 2.2 Operator Interface

The operator interface is a 15 inch, graphic, touchscreen operation monitor. The operator interface is the input/output device for normal operation of the compressor unit. The compressor system is ready and able to operate after the emergency stop switch is pulled out.

#### 2.2.1 Badge Screen

The initial screen after startup is the badge screen. The administrator must enter their badge number and password to have access to the compressor. Enter the badge number and press the check mark for OK. Then Enter the password and press the check mark to log onto the unit.

**Figure 2-2** Initial Screen


### 2.2.2 Admin. Main Menu Screen


**Figure 2-3** Admin. Main Menu Screen


Once an administrative user has logged in they will be presented with the Admin. Main Menu screen. Along the right side are navigation keys. The **HOME** button presents the operator Home page, this is used to operate the unit. The **LIGHT** button toggles on and off the LED light above the control panel. The **HELP** button presents an explanation of the present screen. The **LOGOUT** button logs the present user out. The interlocking gear logo tells if the compressor is **RUNNING**, **OFF**, or in **STANDBY** mode. The **GO STOP** button allows the user to turn the compressor **ON** or **OFF**.

Along the left side of the screen are the following buttons which allow administrator to perform essential tasks.

### 2.2.2.1 PERSONNEL


The personnel button will take the administrator to a page where they can ADD, DELETE, or EDIT the files for each person in the database. The buttons across the top sort the listed users as ALL (deleted and active), ACTIVE, or DELETED.



When the ADD NEW button is pressed (See Figure 2-5), a screen appears for input of new personnel information. Required information are the Badge number, Given name and the Family name. Under Members of is a drop down box, USERS or ADMINISTRATORS and be chosen. Users only have the ability to operate the unit. Administrators can add or delete personnel and cylinders as well as change settings on the unit. If Administrator is chosen a password or pin of 4 - 20 digits must be chosen. Status also has a drop down box where Active or Deleted can be chosen. Once the new personnel's information is entered press the check mark to accept. The left facing arrow takes the user to the previous page without entering the information.


The EDIT button allows the administrator to make changes to an already existing personnel file and the DELETE button allows the administrator to change a file from active to deleted.

**Figure 2-5** Add New



### 2.2.2.2 Cylinders

**Figure 2-6** Cylinders



| ID | Serial Number | Name             | Serial No. (last 4 digits) | Inlet Date | Next Maint. | Expiry Date |
|----|---------------|------------------|----------------------------|------------|-------------|-------------|
| 1  | 80000         | Serial No. 80000 | 0000                       | 01/01/2020 | 01/01/2020  | 01/01/2020  |
| 2  | 80000         | Serial No. 80000 | 0000                       | 01/01/2020 | 01/01/2020  | 01/01/2020  |
| 3  | 80000         | Serial No. 80000 | 0000                       | 01/01/2020 | 01/01/2020  | 01/01/2020  |

The cylinders button takes the administrator to a page similar to the personnel page however this page is for the cylinders database. Here the administrator can ADD, DELETE, or EDIT the files for each cylinder. The buttons across the top of the listed cylinders sort the entries as ALL (active and expired), ACTIVE or EXPIRED.

The EDIT button allows the administrator to edit an already existing cylinder record. The DELETE button deletes an already existing record.

The ADD NEW button opens the add new cylinder screen(See Figure 2-7).


**Figure 2-7** Add New Cylinder

|                                                                   |              |                 |        |
|-------------------------------------------------------------------|--------------|-----------------|--------|
| SCBA Serial #                                                     | Initial Date | Next Hydro Date | Status |
| <input type="text"/>                                              | 3/7/2017     | 3/17/2017       | ACTIVE |
| RFID Serial #                                                     | Expire Date  |                 |        |
| <input type="text"/>                                              | 3/17/2017    |                 |        |
| Max Pressure Setpoint                                             |              |                 |        |
| <input type="text"/> PSI                                          |              |                 |        |
| <input type="button" value="←"/> <input type="button" value="✓"/> |              |                 |        |

The SCBA Serial # and MAX Pressure Setpoint must be entered. The Initial Date, Next Hydro Date, and Expire Date will self fill with the present date. To change the date press the icon to the right of the box and enter the correct date. STATUS can be left as Active or changed to Expired by use of the drop down box. If the cylinder has a RFID serial number that should be entered in the appropriate box.

Once all information for the cylinder is entered press the check mark button for OK. The left facing arrow will take the administrator back to the cylinders list.


### 2.2.2.3 Settings

**Figure 2-8** Settings


The settings button takes the user to the settings page (See Figure 2-8). The choices on this page are SETUP, PARAMETERS, MAINTENANCE, and GAS SENSORS.

### 2.2.2.3.1 Setup


**Figure 2-9** Setup



the SETUP button allows the administrator to adjust the display of pressure as PSI or BAR and the Temperature as Fahrenheit or Celsius. On the Setup page the administrator can see the display of unit's serial number, PLC program version and the monitor's program version. Also on the setup page the administrator can set the current date, and allow guest to use the compressor. If this feature is enabled, instead of having to submit a badge number, a user can simply press the Guest button on the initial screen. The guest will only be allowed to use the unit, not change any settings or add personnel or cylinders.

### 2.2.2.3.2 Parameters

**Figure 2-10** Parameters



The Parameters screen displays multiple fields that dictate how the unit works, changing these settings will change the operation of the unit. For this reason only qualified personnel should be given administrative privileges.

### 2.2.2.3.3 Maintenance


The maintenance screen lists the maintenance schedule by working hours, and calendar days. Also displayed here are the Total run time of the unit and when the last maintenance was performed.

### 2.2.2.3.4 Gas Sensor

The final button on the settings page is the gas sensor setup. This screen will walk the administrator through the steps to zero and calibrate the gas sensor if your unit is equipped with one. For more information on the gas sensor see Chapter 7.

### 2.2.2.4 Reports

Back to the Administrative main menu screen another option is reports.



The reports screen allows the administrator to view reports on User Activity, Session History, Alarms, Warnings or All Events


### 2.2.2.5 Diagnose

Pressing the Diagnose button takes the administrator to a diagnostic screen used to troubleshoot the unit. This page is used to force input signals to the PLC or output signals from the PLC. Also from the diagnostic screen, the analog button can be pressed to view the actual voltage reading from the sensors.

**Figure 2-12** Diagnostic


### 2.2.3 Home Screen

The HOME button at the top of the screen on the right hand side takes the administrator to the home screen that a user or guest would initially see after logging in.


**Figure 2-13** Home Screen, Operator


This screen displays the pressure of each storage bank, the compressor's oil pressure and final pressure. On the upper left side is a button labeled ADMIN which will return to the administrators main menu page.

### 2.2.3.1 Compressor Status

Under the ADMIN button is the COMPRESSOR STATUS button. This button takes the user to the status page.

**Figure 2-14** Compressor Status




The compressor status page displays the following

- ▶ Compressor Status
- ▶ Total Run Time
- ▶ Security Frequency
- ▶ Discharge Pressure
- ▶ Oil Pressure
- ▶ Final Separator Count
- ▶ Current Run Time
- ▶ Maintenance Due in
- ▶ Shutdown Pressure
- ▶ Restart Pressure
- ▶ Previous ACD Cycle

### 2.2.3.2 Fill Cylinders

On the HOME screen in the lower left is an icon to fill cylinders. If the operator wants to fill cylinders using the Containment Fill Station (CFS), press this button.

**Figure 2-15** Fill Cylinders


See Paragraph 2.3 for information on mechanical aspects of filling cylinders.

On the fill cylinders screen, for each cylinder to be filled, use the drop down box for each fill position to select the cylinder's SCBA number<sup>1</sup>. In the block SCBA Filling Pressure select the pressure the cylinder is to be filled, or select custom and enter the desired pressure,



## WARNING

This system is capable of operating with pressures in excess of the normal bottle fill pressure. It is important not to overfill bottles as explosive forces may be released if the bottle fails

If filling only from the storage, connect the cylinders as described below and press the green Start button in the upper right corner. The pressure reading in the storage banks will drop as the pressure reading of the cylinders will rise. Once all cylinders are filled press the Stop button.

If filling will require the compressor or you wish to fill the storage banks as you fill the SCBA cylinders, press the green compressor start button in the lower right. First, then the green filling start button in the upper right.

### 2.2.3.3 Remote Fill

To use the remote fill option press the remote fill icon. Select the desired pressure or Custom and enter the desired pressure. Press the green start button in the upper right to fill. If the compressor will be needed press the green compressor start button in the lower right of the screen.

<sup>1</sup> If this unit is equipped with RFID option and the cylinder has a RFID tag, this field will automatically populate.

### 2.3 Fill Station Operation.



#### WARNING

Every bottle is stamped with a maximum pressure and the last inspection date. Do not fill a bottle with an outdated inspection stamp.



#### WARNING

Visually inspect each bottle and valve for signs of damage before filling. Do not fill any bottles which appear to be damaged. See ASME and UN regulations and manufacturer's recommendations for damage criteria. Be sure the fill pressure and safety valves are properly set.

1. Unlock the fill station door by pushing the fill station door handle down and pulling the door open.
2. Insert the bottle riser, supplied with your system, into the bottom of the bottle holder. Adjust the bottle riser height by lifting the bottle riser and rotating it to one of the two predetermined positions which are noted by the numbers 1 and 2 on the top of the bottle riser. (See Figure 2-16). Different SCBA bottles have different lengths. A proper height adjustment will leave the bottle valve slightly below the top of the bottle holder.

**Figure 2-16** Bottle Riser



#### CAUTION

Minimum bend radius for the fill hose is 1 ½ inches. Less than this will cause damage to or failure of the fill hose. Place the bottle so that the bend radius of the hose is greater than 1 ½ inches.


3. Place the bottles to be filled into the holder and connect the fill adapters to the bottles valve using a fill hose with the CGA-346 fill adapter for 2,216 psi bottles, a CGA-347 adapter for 4,500 psi bottles or a SCUBA yoke for SCUBA bottles. The CGA-347 fill adapter seals on 4,500 psi rated bottle valves, but vents on lower rated pressure bottles
4. CGA valves should be hand tightened only.
5. Close the hose bleed valves and open the bottle valves.
6. Close and lock the fill station door by pushing the fill station door closed, allowing the door lock bar to drop into position.

### NOTICE

The Containment Fill Stations will not fill the bottles unless the door is closed and locked.

7. By closing the door, the bottle holders are returned to their upright position.
8. Set the fill pressures to the appropriate amount.
9. Open the fill valves to fill the bottles.
10. The pressure indication on the fill pressure gauge will drop while bottles are filling. Filling is completed when the fill pressure gauge reaches the desired pressure.
11. Close the fill valves.
12. Unlock the fill station door by pushing the door handle down.
13. Open the fill station door. The bottles are now in a tilted position.
14. Close the bottle valves and open the fill hose bleed valves.
15. Remove the fill adapters from the filled bottles and place them in the hose holders.

**Figure 2-17** Bottle Valve Sequences



#### 2.3.1 Remote Fill Connection

The optional remote fill connection is rated for up to 6,000 psig service. The remote fill hose reel is located on the left side of the unit.

**2.3.1.1 Connecting an Air Bottle**

Connect to the air bottle valve using a fill hose with the CGA-346 fill adapter for 2,216 psi bottles, a CGA-3/7 adapter for 4,500 psi bottles or a SCUBA yoke for SCUBA bottles. The CGA-347 fill adapter seals on 4,500 psi rated bottle valves, but vents on lower rated pressure bottles. CGA valves should be hand tightened only.

**2.3.1.2 Filling the Air Bottle**

1. Close the bleed valve on the fill hose (1) (See Figure 2-17).
2. Open the bottle valve (2).
3. Adjust the regulator on the fill panel to the desired pressure.
4. Open the filling valve on the fill panel to the filling position. The bottle will fill.

**2.3.1.3 Removing the Air Bottle**


1. After reaching the desired bottle pressure, close the fill valve located on the fill panel.
2. After the fill valve is closed, close the bottle valve.
3. Open the bleed valve (2) to vent the residual pressure in the fill hose.
4. Disconnect the fill adapter from the air bottle valve.

## CHAPTER 3: IK 18.1 II COMPRESSOR BLOCK


### 3.1 Description

The IK 18.1 II compressor is used to compress air up to 6,000 psi. This compressor is a four cylinder, five stage air cooled, oil lubricated reciprocating compressor. The 4th stage cylinder is lubricated by means of the forced feed lubrication system, while the other cylinders are splash lubricated. The cylinders are arranged 90° apart, with the 1st and 2nd stage, and the 3rd and 4th stage opposite each other. This compressor block is particularly suitable for continuous operation because of their rugged design and corrosion resistant interstage filter and cooler assemblies.

#### 3.1.1 Component Location



### 3.1.2 Air Flow Diagram



### 3.1.3 Lubrication System

#### 3.1.3.1 Description.


The compressor is provided with forced-feed lubrication. The oil pressure is produced by a low revving gear pump. The oil pressure is between 44 psi and 87 psi (3 to 6 bar).

|                                                                                                                                                            |                |
|------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|
|                                                                         | <b>CAUTION</b> |
| <p>This oil pump must be operated in the correct direction of rotation, other wise no oil pressure will be built up and the compressor may be damaged.</p> |                |

(See Figure 3-3) The oil pump (1) is coupled to and driven by the crankshaft. It pumps oil from the crankcase through an oil filter (3) and the oil pressure regulating valve (4) to the 4th stage cylinder. The oil is then distributed by the guide piston of the 4th stage and lubricates all the moving parts of the compressor

block. The oil pressure sensor (2) allows mounting for an optional oil pressure gauge or electronic pressure monitoring.

**Figure 3-3** Lubrication Oil System



- |                        |                                  |
|------------------------|----------------------------------|
| 1. Oil Pump Housing    | 4. Oil Pressure Regulating Valve |
| 2. Oil Pressure Sensor | 5. Injection Line to Final Stage |
| 3. Oil Filter Housing  |                                  |

**Figure 3-4** Oil Sight Gauge



### 3.1.3.2 Oil Level Check

Check the oil level at the oil filler sight gauge on the compressor block every day before putting the compressor into operation. Oil level must never be below the minimum mark molded into the sight gauge as this will cause severe damage due to lack of lubrication. Overfilling is prevented by the design of the filler neck; i.e. oil should be filled right to the edge of the opening.

### 3.1.3.3 Oil Change Interval

The synthetic oil should be changed every 2,000 operating hours or biennially, whichever is reached first.

### 3.1.3.4 Oil Capacity


The oil capacity is approximately 6.5 quarts (6.0 liters). The amount of oil between the minimum and maximum marks is approximately 1.7 quarts (1.6 liters).

### 3.1.3.5 Oil Change



## CAUTION

Replace the oil filter at every oil change, otherwise when the filter becomes clogged a bypass valve opens and the oil circulates without being filtered.

**Figure 3-5 Oil Sight Gauge & Drain**

1. Oil Fill Cap
2. Oil Drain Valve

**Figure 3-6 Removing the Oil Filter Cover****Figure 3-7 Replacing the Oil Filter**

1. Run the compressor until it is warm.
2. Remove cap from Oil Filler Sight Gauge.
3. (See Figure 3-5) Drain the Oil into a suitable container by opening the Oil Drain Valve (2)
4. After oil has stopped draining, close Oil Drain Valve.
5. (See Figure 3-6) Remove two bolts (1) with a 13 mm wrench. Remove cover (2).
6. (See Figure 3-7) Remove the Oil Filter (1) from the rubber gasket at the cover.
7. Mount a new filter element and replace and fasten cover.

8. Fill new oil through filler neck to the Maximum mark on the Oil Fill Sight Gauge.
9. Pour oil in slowly, wait until the level settles then replace cap in the Oil Fill Sight Gauge.
10. Return the unit to operation.

### 3.1.3.6 Venting the Oil Pump




## CAUTION

To avoid damage after maintenance the following measures should be strictly adhered to.

(See Figure 3-7). If after the start of the compressor no oil pressure builds up, venting the oil pump may be necessary, especially after maintenance and repair work. It may also be necessary if the unit has been operated in the wrong direction of rotation.

1. With the unit running, open the condensate drain valves.
2. Open Oil Pump Vent Plug (2) and wait until oil comes out bubble free.
3. Replace Oil Vent Plug.

### 3.1.4 Intake Filter



#### 3.1.4.1 Description

(See Figure 3-8). A dry micronic filter is used to filter intake air in breathing air units. Nitrogen compressors use a separate inlet regulation system.

#### 3.1.4.2 Maintenance

The vacuum in the intake filter is monitored by the Service Indicator (1). When the preset vacuum pressure is reached the indicator changes to red and the Filter Element (3) should be replaced as follows.

1. Open clips on Filter Housing (4) and remove Cover (2).
2. Remove the Filter Element (3).
3. Clean the inside of the Filter Housing with a damp cloth. Take care to prevent any dust from entering the intake manifold.
4. Replace the Filter Element (3).
5. Mount the Cover (1) and fasten with the clips.
6. Reset the Service Indicator (1) by pressing the button.

**WARNING**

The rapid de-pressurizing and re-pressurizing of an interstage separator during condensate draining subjects it to metallurgical stresses. To prevent catastrophic failure with the possibility of damage, injury or death the interstage separator must be replaced after 85,000 load cycles. A load cycle equals one de-pressurization- repressurization. The Bauer recommended frequency of condensate draining is every fifteen minutes and is a balance between maximizing the life of the separator chamber and maintaining the quality of the delivered air.

### 3.1.5 Interstage Separators


#### 3.1.5.1 Description

Three interstage separators are mounted on the compressor, one after the 2nd stage and another after 3rd stage and the last after the 4th stage. These separators are designed to remove oil and water which accumulates due to the cooling of the air after the compression process. Separation is achieved by means of centrifugal action. In the 2nd stage separator the design of the filter head provides this action. In the 3rd and 4th stage separators the centrifugal action is provided by a vortex plate additionally a sintered metal filter is provided to remove dirt contamination.

### 3.1.5.2 Maintenance


The interstage Separators require no maintenance.

**Figure 3-9** 2nd Stage Interstage Separator




- |                   |                 |
|-------------------|-----------------|
| 1. Separator Body | 5. Insert       |
| 2. Separator Head | 6. Gasket       |
| 3. Knurled Nut    | 7. Fitting      |
| 4. O-ring         | 8. Safety Valve |

**Figure 3-10** 3rd Stage Interstage Separator



- |                       |                 |
|-----------------------|-----------------|
| 1. Vortex Plate       | 5. Knurled Nut  |
| 2. Hollow Screw       | 6. Gasket       |
| 3. Center Insert-ring | 7. Fitting      |
| 4. O-ring             | 8. Safety Valve |





### 3.1.6 Compressor Valves and Valve Heads

#### 3.1.6.1 Functional Description

The valve heads of the individual stages form the upper part of the cylinders. The inlet and pressure valves are fitted inside the valve heads.

When the piston moves downwards, the resultant vacuum in the piston cylinder opens the inlet valve. When the piston moves upwards, the inlet valve is closed and the pressure valve opened by the pressure created in the compression process. See Figure 3-13.

The Intake and Pressure Valve of the 1st Stage are combined in a Plate Valve under the Valve Head. See Figure 3-12.

**Figure 3-12** 1st Stage Valve Function**Figure 3-13** Valve Function**3.1.6.2 Initial Operational Check of the Valves**

After roughly half an hour of operation, the valves should be checked. The outlet piping should be hot if the valves are operating properly. Note that the inlet line to the valve heads should be warm to the touch.

**WARNING**

Do not touch the outlet piping with bare hands, use a thermometer.

**3.1.6.3 General Instructions for Changing the Valves**


Please observe the following instructions for valve maintenance:

1. Always replace valves as a complete set.
2. Carefully clean dirty valves. Never use a sharp tool for this purpose. Soak the valves in Varsol and clean with a soft brush.
3. Check the individual components for excessive wear. If the valve seat or valve discs are dented, replace the valves.
4. Check the valve space in the valve heads for dirt, and clean if necessary.
5. Use only satisfactory gaskets and O-rings during reassembly.
6. Observe the correct sequence when reassembling.
7. After finishing all maintenance work on the valves, turn the compressor manually using the fly-wheel and check whether all items have been correctly installed.
8. 30 minutes after restarting the compressor, stop the unit, let it cool down to ambient temperature, and re-tighten valve studs and cap nuts. Otherwise the gasket set may cause a leak.

9. Remove and check the valves every 1000 operating hours.
10. Replace the valves every 2000 operating hours to avoid fatigue failure.
11. Use an assembly tool (Bauer P/N: 011365) for all work on valve heads (See Figure 3-19).

#### 3.1.6.4 Changing the 1st Stage Valves.

See Figure 3-14



##### 3.1.6.4.1 Removal Procedure.


1. Unscrew and remove cap nuts (4) and washers (3).
2. Remove Valve Head Assembly (1) from studs in cylinder.
3. Remove Valve (2) and unscrew and remove center screw (6) and washer (5).

##### 3.1.6.4.2 Installation Procedure

1. Fasten new Valve (2) with center screw (6) and washer (5).
2. Place assembled Valve Head (1) on studs in the cylinder.
3. Install washers (3) and cap nuts (4) and tighten to the torque value listed in the Appendix.

### 3.1.6.5 Changing the 2nd Stage Valves

**Figure 3-15 2nd Valve Head and Valves**



#### 3.1.6.5.1 Removal Procedure

See Figure 3-15

1. Unscrew and remove Hex Nut (1).
2. Remove Cap Holder (2).
3. Insert two screwdrivers into the Extraction Grooves of the Valve Caps (3) and lift out the Valve Caps with O-Rings (5).
4. Check and replace O-Rings if required.
5. Take out Valves (6 & 9).
6. Check the Valve Gaskets (7) and replace if required.

#### 3.1.6.5.2 Installation Procedure

1. Fit valves(6 & 9) with gaskets (7) and replace.
2. Fit valve caps (3) with O-Rings (5) and replace.
3. Replace cap holder (2) in the proper position.



### CAUTION

The valve cap for the inlet valve protrudes 0.98 in (2.5 mm) out of the valve head more than the valve cap for the discharge valve. The cap holder is designed accordingly.