



Quick Installation Guide


Model:BL-WDR3750

750Mbps Wireless Dual Band 11AC Router


1.Connecting the device

! **Note: Please use wired network connections only to configure the Router.**


- 1** Connect the WAN port on your Router to the Modem's LAN port with an Ethernet cable.
(If Modem is not available, please connect the incoming cable to the WAN port of the router directly) .



- 2** Connect your computer to the Port labeled 1~4 on the Router with an Ethernet cable.









- 3** To plug the router, please connect one end of the adapter to the power jack on the back of the router while plugging the other end to a standard socket.



- 4 To enable the touter, please make sure the indicator lights work as same as it shows below.



	→ Power:solid light
	→ 2.4G WLAN:Flashing
	→ 5G WLAN:Flashing
	→ WPS:Trigger Flashing
	→ WAN:might appears either flashing or solid depending on the connection of the corresponding port.
	→ LAN:might appears either flashing or solid depending on the connection of the corresponding port.



Note: If any of the LED indicators appear inconsistently, please make sure that the connection works as it supposes to.

2. Configuring the device



Note: First of all, please configure your computer's IP address to automatically obtain, if not clear, please refer to FAQ3.

1 Login

Open your web browser, input **192.168.16.1** in the address field and press **Enter**.


User name: **admin**
Password: **admin**

Click **Login**



A consequent management page appears afterward.

Select a connection type



Note:

1. Make sure that the cable is plugged into the WAN port properly before the detecting process.
2. If the connection type for the ISP is either PPTP or L2TP, please head to "Network settings-WAN" for additional configuration.

How to select a connection type?

The Internet parameters provided by ISP when users apply for Internet access	Connection type
No parameters, don't use any router and don't do any setting	DHCP
A static IP address, subnet mask, gateway and DNS server Static IP address	Static
User name and password	PPPoE

A Configuration for DHCP

The page will appear automatically.

Select **DHCP**

Please create an unique and memorable account for the wireless network. You might be able to keep default settings as long as you want.

To create a password, one should keep in mind that at least eight characters are required.

Click **Apply**

The screenshot shows the DHCP configuration page. At the top, there are three radio buttons: **DHCP** (selected), **Static**, and **PPPoE**. Below this is the **Wireless Settings** section, which includes the following fields:

Field	Value
2.4G Network Name(SSID)	B-LINK-2.4G_XXXXXX
2.4G Password	12345678
5G Network Name(SSID)	B-LINK-5G_XXXXXX
5G Password	12345678

At the bottom of the page, there are two buttons: **Apply** and **Advanced** with a right-pointing arrow.

B Configuration for Static

The page will appear automatically.

Select **Static**

Enter the **IP address, Subnet Mask, Default Gateway, DNS** provided by your ISP manually.

Create a unique and easy-to-remember name for your wireless network. You can also keep default settings.

To create a password, one should keep in mind that at least eight characters are required.

Click **Apply**

The screenshot shows the Static configuration page. At the top, there are three radio buttons: **DHCP**, **Static** (selected), and **PPPoE**. Below this is the **WAN Settings** section, which includes the following fields:

Field	Value
IP address	0.0.0.0
Subnet Mask	0.0.0.0
Default Gateway	0.0.0.0
Preferred DNS Server	

Below the WAN settings is the **Wireless Settings** section, which includes the following fields:

Field	Value
2.4G Network Name(SSID)	B-LINK-2.4G_XXXXXX
2.4G Password	12345678
5G Network Name(SSID)	B-LINK-5G_XXXXXX
5G Password	12345678

At the bottom of the page, there are two buttons: **Apply** and **Advanced** with a right-pointing arrow.

C Configuration for PPPoE

The page will appear automatically.

Select **PPPoE**

Enter the **Username** and **Password** provided by your ISP.

Create a unique and easy-to-remember name for your wireless network. You can also keep default settings.

To create a password, one should keep in mind that at least eight characters are required.

Click **Apply**

The screenshot shows a router configuration interface. At the top, there are three radio buttons: 'DHCP', 'Static', and 'PPPoE'. The 'PPPoE' button is selected and highlighted with a red box. Below this, the 'WAN Settings' section contains three input fields: 'Username', 'Password', and 'Service Name(optional)'. The 'Username' and 'Password' fields are highlighted with red boxes. Below the WAN settings is the 'Wireless Settings' section, which contains four rows of settings: '2.4G Network Name(SSID)' with the value 'B-LINK-2.4G_XXXXXX', '2.4G Password' with the value '12345678', '5G Network Name(SSID)' with the value 'B-LINK-5G_XXXXXX', and '5G Password' with the value '12345678'. Each of these four rows is highlighted with a red box. At the bottom of the page, there are two buttons: 'Apply' and 'Advanced'. The 'Apply' button is highlighted with a red box.




Note: Till here, the setting for the router has been completed, which means that the internet is now available. If not, please head to the Troubleshooting (make a page number)

3. Troubleshooting

FAQ1: What should I do if I forget the user name and password?

(How to restore the router's configuration to its factory default settings.)

Answer: If you forget the user name and password, the only way to solve this problem is to reset the router. Press and hold the RESET button on the rear panel for 5 to 8 seconds before releasing it. (when it is power on)



Hold for **5 to 8** seconds

FAQ2: What can I do if I cannot access the Internet?


1. Check whether each of the connections including the telephone line, Ethernet cables and power adapter is well performed.
2. Unplug the router then connect the computer directly into the Modem. If it still does not work, please contact your ISP or your Modem manufacturer. If it works, please reconnect your Modem, router and your computer. Next steps might help you.
3. Make sure that you are connected to the Router with the computer that was originally connected to your modem, then login to the web-based management page and browse to "Network Setting > MAC Clone", click "Fill my MAC" and then click "Apply". Reboot the Router and try to access the Internet from your computer.

FAQ3: How to configure the IP address of the computer?


For Windows XP OS

Go to **Start > Control Panel**, you will then see the following page.


Click **Network and Internet Connections**



For Windows XP OS




Click **Network Connections**





Right-click **Local Area Connection**

Click **Properties**



Double-click **Internet Protocol (TCP/IP)**


For Windows XP OS




For Windows 7 OS

Go to **Start > Control Panel**, you will then see the following page.


Click **View network status and tasks**



Click **Change adapter settings**




Right-click **Local Area Connection**




Click **Properties**

For Windows 7 OS



Double-click **Internet Protocol Version 4 (TCP/IPv4)**


Click **OK**



Select **Obtain an IP address automatically**

Select **Obtain DNS server address automatically**

Click **OK**




For Windows 8 OS


Press the Keyboard WIN()+X to pop up the menu on the Win8 Desktop, then select **Control Panel**





Click **View network status and tasks**





Click **Change adapter settings**



For Windows 8 OS



For Windows 8 OS




SHENZHEN BILIAN ELECTRONIC CO., LTD

LB-LINK is the registered trademark of Shenzhen BILIAN Electronic CO.,Ltd.All the products and product names mentioned here are the trademarks or registered trademarks of their respective holders.Specifications are subject to change without notice.
Copyright © 2012 **LB-LINK** All Rights Reserved.

<http://www.lb-link.cn>

Ver 1.0



This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF warning:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.