

# Integrated Service Access Point Product Description

## User Guide

Version: 1.0  
Date: March 08

## Table of Contents

<b>1</b>	<b>Introduction</b>	<b>4</b>
1.1	Welcome	4
1.2	Safety notes	5
1.2.1	General safety warnings	5
1.2.2	Important warnings for use of device	5
1.3	About this document	6
1.4	Regulatory information	7
1.5	Delivery content	8
<b>2</b>	<b>Technical Data</b>	<b>9</b>
<b>3</b>	<b>Components</b>	<b>10</b>
3.1	Access Point	10
3.1.1	LED functions	11
3.1.2	Antenna connectors	12
3.1.3	Reset button	12
3.1.4	LAN connector	12
3.1.5	USB connector	12
3.1.6	AC connector	13
3.2	Antennas	13
3.3	Mounting plate and installation kit	14
3.4	Accessories	14
3.4.1	Power cord	14
3.4.2	LAN cable	14
<b>4</b>	<b>Unpacking and Installation</b>	<b>15</b>
4.1	Unpacking instructions	15
4.2	Installation location	15
4.3	Mounting instructions	16
4.3.1	Fixing mounting plate	17
4.3.2	Placing ISAP on mounting plate	18
4.3.3	Connecting cables	20
4.3.4	Removing ISAP from mounting plate	20
<b>5</b>	<b>Registration, Configuration and Operation</b>	<b>21</b>
5.1	Registration of ISAP	21
5.1.1	Automatic registration	21
5.1.2	Manual registration	21
5.2	Configuration and operation	21
5.2.1	Configuration	21
5.2.2	Channel scanning	21
<b>6</b>	<b>Maintenance</b>	<b>23</b>
6.1	Status information	23
6.2	Cleaning ISAP	23
6.3	Cable state	23
6.4	Replacing a defective cable	23
6.5	Replacing antennas	23
6.6	Reset to factory settings	24

---

6.7	Replacing ISAP for maintenance purposes .....	25
7	<b>Troubleshooting</b> .....	26
8	<b>Terms and Abbreviations</b> .....	28
9	<b>References</b> .....	29
10	<b>List of Figures</b> .....	30

Preliminary

# 1 Introduction

## 1.1 Welcome

The Integrated Service Access Point (ISAP) is a wireless communication device developed by EB (Elektrobit Corporation) and optimized for BMW ITOOLS application. The Integrated Service Access Point is referred as "ISAP" later on in this User Guide.

The ISAP operates at 2.4GHz and 5GHz WLAN band frequencies. It is designed to operate in the 802.11n WLAN mode. The ISAP is a device utilizing latest technologies not necessarily familiar to all users. Therefore it is strongly recommended that this guide be read through carefully. Before operating the ISAP, the safety notes described in the following chapters must be understood and followed.

The main advantages of ISAP are:

- Very high wireless performance compared to older standards (802.11abg)
- Robust design with high reliability
- Easy administration via Workshop System Management (WSM)
- AC power feed
- Diagnostics for wireless traffic
- Supports remote firmware downloads



**Figure 1-1: Integrated Service Access Point (ISAP)**

## 1.2 Safety notes

This part introduces the different signs that will be used all along this user guide and the important warnings to remember at all times when using the device.

### 1.2.1 General safety warnings

	<b>Danger!</b> Means that by not following the instruction there is a possibility of death and/or serious injury.
	<b>Warning!</b> Means that by not following the instruction there is a possibility of serious injury and/or damage in ISAP and/or surrounded materials.
	<b>Attention!</b> Means that not following the instruction can cause damages to the device or data.
	<b>Info!</b> Tips and hints for easier operation.

### 1.2.2 Important warnings for use of device

Please pay careful attention to the following remarks.

	<b>Danger!</b> Do not use damaged equipment and/or accessories such as damaged power cord.
	<b>Danger!</b> Do not use any other accessories than those provided with the device. The use of any other parts will cause danger and void the warranty.
	<b>Danger!</b> Never try to open the device. By trying to open the device you will be exposed to a risk of death or injury.
	<b>Danger!</b> Do not use this product during thunderstorm, floods and other dangerous climate events susceptible to cause serious harm to persons.
	<b>Danger!</b> Never operate ISAP near open fuel tanks. There is a risk of fire or explosion.
	<b>Warning!</b> Read this user guide carefully before mounting, installing and operating the device.
	<b>Warning!</b> Do not use extension cord for power cable, use only the power cable delivered with the device.

	<b>Warning!</b> Never unplug equipment from the electrical outlet by holding the cord only, always disconnect the cable by applying force directly to the plug.
	<b>Warning!</b> Ensure sufficient air cooling when installing ISAP.
	<b>Warning!</b> Do not apply any forces with any tools to the antenna connectors' threads when connecting or disconnection the antennas. The antennas shall be connected and fixed by hand only.
	<b>Warning!</b> Do not operate the device in any other environmental conditions than it is designed for.
	<b>Warning!</b> Do not open the housing of the ISAP. There are no serviceable parts inside!

### 1.3 About this document

This document provides instructions regarding the installation, the set up and the operation of the device.

- Chapter one gives general information regarding the product safety and legal notifications. It is very important that this chapter is read carefully before operating ISAP.
- Chapter two provides information on technical details and environmental restrictions of the access point.
- Chapter three describes in detail the components delivered with the ISAP.
- Chapter four presents all needed steps in order to install the access point.
- Chapter five gives hints on registration, configuration and operation of the ISAP.
- Chapter six covers maintenance.
- Chapter seven is a troubleshooting guide in case of unexpected behavior.

## 1.4 Regulatory information

Regulatory Information	
Product Name:	ISAP
Product Type:	IP40 version
Further Description:	As described in this document
meets the requirements for EMC and Electrical Safety according to	
CE-Directives	1999/5/EC, Radio and Telecommunications Terminal Equipment (R&TTE)
	2004/108/EC, Electromagnetic Compatibility (EMC)
	2006/95/EC, Low Voltage Directive (LVD)
	2002/95/EC, Restriction of Hazardous Substances Directive (RoHS)
	2002/96/EC, Waste Electrical and Electronic Equipment (WEEE), <b>Note 1</b>
UL listed	E 319085



### **Note 1)** Waste Electrical and Electronic Equipment (WEEE) Directive 2002/96/EC

This product complies with the WEEE Directive (2002/96/EC) marking requirements. The affixed product label (see beside) indicates that you must not discard this electronic product in domestic household waste. This mark on the product, the packaging or the relevant documentation indicates that this product may not be treated as ordinary household garbage. Please contact first level support on how to organize disposal at your country.

**FCC Statement:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules and with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.



### Warning!

Changes or modifications made to this equipment not expressly approved by

manufacturer may void the authorization to operate this equipment.

## 1.5 Delivery content

It is highly recommended that the package content be checked immediately after receiving it. The package contains the following items:



**Figure 1-2: Delivery content**

1. ISAP with attached Antennas
2. 20m Ethernet cable (Cat5e)
3. 4.5m power cable (country specific)
4. Printed documentation and certificates
5. Documentation CD
6. Mounting plate
7. Wall mounting kit

	<b>Attention!</b> If any of the parts listed above is missing or damaged, please contact first level help desk immediately.
	<b>Info!</b> Read section 2 & 3 for further technical details about ISAP components

## 2 Technical Data

<b>Name</b>	Integrated Service Access Point, ISAP
<b>Functionality</b>	Wireless communication device for industrial applications
<b>Physical dimensions</b>	Approximately 220 x 170 x 36 mm, without antennas
<b>Weight</b>	Approximately 1.5 kg
<b>Environmental protection</b>	IP40
<b>Operating temperature range</b>	-10...+50 °C
<b>Operating altitude range</b>	0...3048 m
<b>Power feed</b>	100...240 VAC, 50...60 Hz, 0.2A max., class II (reinforced insulation)
<b>Wireless standards supported</b>	IEEE 802.11b, 802.11g, 802.11a, 802.11n Draft 2
<b>Frequency range</b>	2.400..2.4835 GHz 5.150..5.250 GHz
<b>Occupied channel bandwidth</b>	According to the IEEE 802.11n Draft 2
<b>Data rates supported</b>	802.11b: 1Mbit/s, 2, 5.5 & 11Mbit/s 802.11g & 802.11a: 6Mbit/s, 9, 12, 18, 24, 36, 48 & 54 Mbit/s 802.11n 20MHz BW: 1 NSS: 65(72.2)Mbps max. 2 NSS: 130(144.444)Mbit/s max. 802.11n 40MHz BW: 1 NSS: 135(150)Mbit/s max. 2 NSS: 270(300)Mbit/s max.
<b>RF transmission power (ERP)</b>	+5...+18 dBm, Settable in 1 dB steps
<b>RF antenna interfaces</b>	Three Antennas, MIMO
<b>Receiver sensitivity in specified operating temperature range</b>	802.11b: -92 dBm (1 Mbit/s), -89, -86, -84 dBm (11 Mbit/s) 802.11g: -90 dBm (6 Mbit/s), -88, -86, -84, -81, -78, -73, -70 dBm (54 Mbit/s) 802.11a: -90 dBm (6 Mbit/s), -88, -86, -84, -81, -78, -73, -70 dBm (54 Mbit/s) 802.11n: HT20 -68.8 dBm (300 Mbit/s), HT40 -65.8 (300 Mbit/s)
<b>Security</b>	WEP, WPA, WPA2, 802.1x, EAP-(T)TLS
<b>Ethernet interface</b>	802.3ab, 10/100/1000 Base-T
<b>Ethernet routing / networking</b>	DHCP Client, NAT Router, VLAN Support, Multi BSSID, Roaming SSH server, NTP client
<b>USB interface</b>	USB 2.0
<b>Device management</b>	HTTP- with user authentication, remote update for device settings and firmware CLI (Command Line Interface) through SSH session
<b>Connectors</b>	RF Antenna Connectors: 3* SMA-RP Ethernet Connector: RJ45 Power Feed: IEC-C8
<b>LED indicators</b>	READY, LAN, USB, ERR
<b>Performance</b>	Up to 150 Mbit/s TCP payload throughput
<b>Technical platform</b>	Processor: Atheros AR7161 Wireless LAN : Atheros AR9160, AR9106 Memories : 512Mb SDRAM, 64Mb FLASH LAN interface: Based on Marvell Alaska 88E1111 Phy transceiver
<b>Certificates</b>	UL E319085, CE, CB-Report For other national approvals, see certification list
<b>Important Note</b>	National restrictions on frequencies, power levels and operating modes may apply

### 3 Components

#### 3.1 Access Point



Figure 3-1: Integrated Service Access Point




Figure 3-2: ISAP front view and markings




Figure 3-3: ISAP connectors' side and markings

Description of connectors and LEDs:

<b>1. ERR LED</b>	<b>5. RESET switch</b>
<b>2. LAN LED</b>	<b>6. AC connector</b>
<b>3. USB connector and LED</b>	<b>7. LAN connector</b>
<b>4. READY LED</b>	<b>8. Antenna connectors</b>

### 3.1.1 LED functions

Four LEDs are located on both side of the device, on the front side and on the connectors' side. Note that the LAN led at the connectors' side is integrated into the LAN connector.

Start-up: note that there are three kinds of errors indicated during start-up:

- a) The LAN connection is broken or not connected: the LAN led will remain unlit.
- b) The registration of ISAP with Workshop System Management (WSM) has not been able to start: the READY led will stay yellow, which should alert the user.
- c) The registration of ISAP with Workshop System Management (WSM) started, but a problem occurred during the connection to WSM: the YELLOW READY led will blink, which should alert the user to check the status of Workshop System Management (WSM).

**Table 3-1: LED names and functions**

LED Name	Status of LED	Description	Trigger
READY		No light: the ISAP is not powered	
		Yellow: the ISAP is switched on and the power up process is ongoing	Power applied, power cable connected to AC feed
		Yellow flashing: the registration on Workshop System Management (WSM) is ongoing	ISAP Registration process started
		Green: the ISAP is operational	Device powered, LAN active, ISAP registered and WLAN activated
		Green flashing: the firmware upgrade procedure is ongoing	Upgrade process started
LAN		No light: LAN is not operational	
		Green: LAN is linked up	Ethernet cable physically and successfully connected to ISAP
USB		No light: no USB device connected	
		Green light: USB device connected	USB device connected to ISAP
ERR		No light: no errors detected	Built-in self-test (BIST) passed successfully
		Red: an error or warning is pending, details are available in WSM	BIST failed due to high temperature, voltage warning or services down

### 3.1.2 Antenna connectors

The ISAP has three sub-miniature version A (SMA) male reverse-polarity antenna connectors for three external antennas. All three antennas must be connected for correct ISAP operation and performance. The antennas need to be properly attached.

	<b>Warning!</b> No dust or dirt should get into the connectors.
	<b>Info!</b> It is highly recommended to keep the antennas connected in all situations, as they will provide needed protection against dust and dirt.
	<b>Info!</b> The ISAP is delivered with mounted antennas. The user would need to replace the antennas only for maintenance purpose when necessary.
	<b>Warning!</b> Do not apply any forces with any tools to the antenna connectors' threads when connecting or disconnection the antennas. The antennas shall be connected and fixed by hand only.

### 3.1.3 Reset button

The reset button is a push button, which allows user to reset the ISAP configuration to factory settings. Resetting the configuration factory parameters is necessary when moving the ISAP to a new location, or for ITOOLS fault analysis and recovery purposes of ISAP maintenance. Please refer to chapter 5.6 for details on how to restore the factory settings by using reset button.

	<b>Info!</b> Please reset ISAP only if first level support instructs you to do so. There will be additional steps to be done by you in order to transfer ISAP configuration from server ISIS each time you reset ISAP.
---	---

### 3.1.4 LAN connector

ISAP utilizes Ethernet networking topology to connect to the backbone. The connector is RJ45 type and enables 10/100/1000 Mbit connections. The LAN connector LED will be lit green in order to indicate connection of LAN cable.

### 3.1.5 USB connector

There is one Type A USB connector located on the ISAP connector panel (see Figure 3-3).

The USB connector is planned to be used for connecting ITOOLS extension to the infrastructure. The USB connector's protecting rubber cover should be kept on unless the USB connector is connected to ITOOLS extension equipment. This prevents dust and dirt to get into the connector.

	<b>Warning!</b> The USB connector shall not be used for anything else than specified ITOOLS extension devices. Details will be provided by BMW AG as soon as they will be available.
---	---

### 3.1.6 AC connector

The connector used for ISAP is an IEC60320-C8 power plug. The power supply module is integrated into the ISAP and can be connected to mains voltages of 100...240 VAC, 50...60Hz with the power cable provided.

	<b>Danger!</b> Do not use any other power cord than the one delivered with the device. The use of any other cord will cause danger and void the warranty.
	<b>Warning!</b> Do not use extension cord for power cable, use only the power cable delivered with the device.

## 3.2 Antennas

ISAP includes external WLAN Tri-band small diameter antennas, which cover frequencies from 2.4 to 6 GHz. Omni-directional patterns with gain in upper frequencies give optimal coverage for workshop environment. The antenna has a gain of 2.1 dBi at 2.45 GHz and 2.5 dBi at 5.875 GHz. The antennas should be placed so that they are pointing all into different directions. The performance of ISAP is maximized when antennas create as different (i.e. non-correlating) spatial streams as possible. See Figure 3-4 below for example how to point antennas.



Figure 3-4: Example of antenna directions

	<b>Warning!</b> Do not push the antennas to the angles which the flexible joint doesn't easily allow. Otherwise you might break the joints.
	<b>Warning!</b> Use only the antennas which are delivered with the device – changes to antenna configuration void operating permission and certificates.

### 3.3 Mounting plate and installation kit

A metal mounting plate is delivered with the ISAP. It enables mounting the ISAP vertically on a wall, made from concrete. Always use the delivered mounting plate for fixing the ISAP. It is designed to enable efficient cooling of the ISAP and proper mounting and holding. The installation kit includes the required screws and dowels for fixing the mounting plate on the wall.

### 3.4 Accessories

#### 3.4.1 Power cord

A 4.5 meter long power cord is delivered with the ISAP, with improved resistance to media normally found in the workshop environment. Depending on the AC wall adapters used in each country, one or more of the cables is supplied with each ISAP

	<b>Danger!</b>  Do not use any other power cord than the one provided with the device. The use of any other cord will result in danger and void the warranty. In some countries using a different power cord than the one supplied may also void ISAP type approvals.
	<b>Warning!</b>  Do not use any extension cord, use only the power cable delivered with the device.
	<b>Warning!</b>  Never unplug equipment from the electrical outlet by holding the cord only, always disconnect the cord by applying force directly to the plug.

#### 3.4.2 LAN cable

A 20 meter long LAN cable is delivered with the ISAP. This is a Cat5e shielded cable with RJ45 connectors on both ends.

	<b>Warning!</b>  Do not use any extension cables, use only the LAN cable delivered with the device. In some countries using a different LAN cable than the one supplied may also void ISAP type approvals.
---	--

## 4 Unpacking and Installation



### Warning!

Only installation by a professional is allowed.

### 4.1 Unpacking instructions

The ISAP delivery box is made of carton which can be recycled through standard process used for carton materials. However, the box has been approved with logistical experts and should be kept in safe in case there will be need to send ISAP back to another location or to repair.

The content is packed in two separate spaces. The ISAP main device is packed directly inside the package with two carton parts which hold it in correct place. The other material can be found from the internal carton box below ISAP main device.

1. Open and remove the first outside cover carton box
2. Open the second cover carton box and lift up the ISAP main device
3. Open the internal box which include all the other delivery content
4. Check that the delivery content is according to chapter 1.5

### 4.2 Installation location

If there were no problems with previous the Access Point in Workshop, it is a good idea to consider mounting the ISAP to the place where the previous generation Access Point has been mounted before. For best performance the following notes should be considered and mounting locations should be selected based on given hints:

1. The mounting location should be selected so that it is central for assumed ITOOLS operations:
  - o Mount the ISAP near to the place where wireless networks will be mostly used
  - o Allow a line of sight contact between the ISAP and the workplace where ITOOLS will be used
  - o Installing ISAP high on the wall typically allows best radio coverage and optimum operation, minimum height of 2 meters is recommended
2. Select the mounting location so that it is free from unnecessary obstacles, or removing obstacles nearby ISAP installation location
  - o Obstacles, such as metal surfaces in desks, filing cabinets, bookshelves, and wastebaskets close to the ISAP may degrade the performance
3. Mounting location distance from the Workshop LAN backbone (ISIS)
  - o ISAP is connected to ISIS backbone with a 20 meters Ethernet cable
  - o ISAP mounting point shall be selected so that the supplied 20 meters cable can connect the ISAP to the ISIS backbone without any cable extension. The Ethernet connection cable should be installed and fixed in a way that cable does not cause

problems for workshop operations. The cable should be fixed at a safe distance from any moving tools, vehicles, etc. In order to connect the ISAP to the ISIS, please use the ISIS Gigabit switch or Layer-2-switch. If you use a router instead, make sure that it is configured correctly. For detailed information please refer to the special information on workshop cabling and installation provided by your market.

- Observe local regulations regarding cable installation!

4. The distance to other operational wireless networks should be maximized.

5. Interference from other wireless networks may be eliminated or reduced by:

- Changing the channel of ISAP operation by using Workshop System Management (WSM) or changing the operational channels of surrounding wireless networks. You should consider using the built-in Channel Scanning feature of the ISAP. This feature will help you to detect other wireless networks in surrounding environment and will help you to select an appropriate channel to minimize disturbances and interferences from other transmitters. Please refer to Chapter 5.2 for more details on Channel Scanning.
- Adjusting the power levels of other wireless networks nearby. Please check with your IT responsible person on the preconditions of WLAN operation.

### 4.3 Mounting instructions

	<b>Warning!</b> Do not use any other mounting equipment than those provided with the device. Using other mounting equipment may cause damage to the device, personnel or surrounding environment.
	<b>Warning!</b> The total weight of the ISAP is almost 2 kg. The wall must be made from appropriate material to be able to handle the weight of the ISAP through the four mounting screws.

#### 4.3.1 Fixing mounting plate

Before fixing the mounting plate, ensure that there are no electrical lines or water lines in the wall at that location.

- ISAP mounting plate is fixed with 4 screws, delivered as part of ISAP fixing kit
- ISAP can be mounted on a wall made from concrete or stone
- Using the delivered plastic dowels is mandatory

1. Mark the holes placement with the help of mounting plate, as illustrated in Figure 4-1. Note the installation direction.
2. Drill four 5 mm diameter and 35 mm deep holes in to the wall, as illustrated in Figure 4-2





Figure 4-1: Example of hole marking



Figure 4-2: Drilling holes

3. Insert the 4 dowels into the holes.



Figure 4-3: Inserting dowels

4. Fix the mounting plate with four screws as in Figure 4-4. The locking mechanism must point upwards as in Figure 4-5.




Figure 4-4: Fixing the plate



Figure 4-5: Example of finished fixed plate

#### 4.3.2 Placing ISAP on mounting plate

1. Place the ISAP on the mounting plate. The screws at the cooling fins of the ISAP should go into the openings on the mounting plate, see Figure 4-6 below. Place the ISAP horizontally, antennas must point up, like in Figure 4-7.




Figure 4-6: Openings for ISAP



Figure 4-7: Placing on ISAP horizontally

2. Place the ISAP first from below, Figure 4-8. The ISAP will be locked by the locking mechanism (Figure 4-9) at the mounting plate .




**Figure 4-8: Place on first from below**



**Figure 4-9: Locking mechanism**

3. Push the entire ISAP towards the wall so that the locking mechanism in the mounting plate moves backwards, allowing the ISAP to reach also the upper openings of the mounting plate. Simultaneously push the ISAP to the wall and tire down until the locking mechanism locks clicks and locks the ISAP. Figure 4-10.



**Figure 4-10: Pushing and locking**

4. Try to lift the ISAP upwards and make sure that the locking mechanism is fully visible, and the ISAP has gone under the locking edge. Figure 4-11.



Figure 4-11: Example of fixed plate

#### 4.3.3 Connecting cables

1. Fix the power cable and LAN cables on the wall and connect into the ISAP. Do not leave cables hanging, but make proper fixings into the wall or ceiling. Set the antennas like in the Figure 4-12.



Figure 4-12: Example of fixed ISAP

#### 4.3.4 Removing ISAP from mounting plate

In order to remove ISAP from Mounting plate e.g. for maintenance reason, do the following:

1. Disconnect all cables
2. Push the locking mechanism inside, see Figure 4-13
3. Simultaneously lift the ISAP upwards until it releases itself from the mounting plate



Figure 4-13: Unlocking ISAP

## 5 Registration, Configuration and Operation

### 5.1 Registration of ISAP

Every ISAP must be registered before the wireless operation is possible. This chapter provides an overview of ISAP registration.

#### 5.1.1 Automatic registration

Most of the workshops have live connection to BMW AG backend systems. In this normal use case, the registration of the ISAP is done automatically through Workshop System Management (WSM) within the first start-up. For further information please refer to the WSM User Guide [1].

#### 5.1.2 Manual registration

In case the workshop does not have a live connection to the workshop database, the registration of ISAP must be done manually through a registration fax. For further information please refer to the WSM User Guide [1].

### 5.2 Configuration and operation

#### 5.2.1 Configuration

The ISAP is configured through Workshop System Management (WSM) software. Please refer to the WSM User Guide [1] for details on how to configure the ISAP.

#### 5.2.2 Channel scanning

In the workshops there might be no professional site survey available during initial ITOOLS installation. Therefore the existing other WLAN band activities and users are not necessary known. In many cases this is not assumed to be a problem, as workshop is normally relatively well controlled environment. Additional to the disturbances from the workshop there can potentially be other WLAN Networks from uncontrollable environments close to the workshop, i.e. from other companies. These devices might be causing disturbances to ITOOLS Wireless Network operation.

Due to these issues it is highly beneficial that ITOOLS operation is adjusted based on the environment radio operating conditions. Optimally selected radio frequency channel will improve the ITOOLS operation quality, performance, and service availability.

Channel Scanning introduces a possibility to analyze the installation environment for potential problems during configuration and also later on- one of causes for problems is the use of shared radio channels, and the fact that other surrounding networks may change they operation without notifying for ITOOLS administration. For this reason ISAP is able to provide information about channel allocation.

Channel Scanning can be activated through Workshop System Management (WSM), in order to get the channel scan information from ISAP.

	<b>Info!</b> In Workshop System Management (WSM) channel scanning is referred to as the Channel Wizard. It can be started via the Device Details tab in WSM.
	<b>Caution!</b> Normal operation of the ISAP is deactivated for the channel scan.

The Channel Scan operation is based on reporting all Radio Frequency (RF) signal strength values for the least used channels, taking into account the other surrounding networks. As a result channel scan will deliver one recommended channel in 2.4 GHz band as well as one recommended channel in the 5 GHz band. It will also deliver some least used channels for each of the two bands. For more details on using channel scanning please refer to the WSM User Guide [1].

Preliminary

## 6 Maintenance

### 6.1 Status information

The status information of the ISAP can be seen in the Workshop System Management (WSM) graphical user interface. More information about the queries of the ISAP status is available in the WSM User Guide [1].

### 6.2 Cleaning ISAP

The ISAP is not designed to be in direct contact with dust, dirt or other generally harmful substances. The media found in workshops, such as oils, acids and cleaners are especially dangerous when applied directly to the ISAP. In addition, the vapors of such substances are harmful, an adequate air circulation is recommended. Due to these restrictions, it is highly recommended that the ISAP and the nearby environment of the ISAP are kept clean of substances mentioned above.

Use only a moist cloth to clean the device. Do not use petroleum based substances or solvents as this may cause corrosion of the surface of the ISAP.

### 6.3 Cable state

There are two cables delivered with the ISAP: the LAN cable and the power cable. It is recommended that the user periodically check the condition of these cables. A simple visual check is adequate. The cable shall not have any visible cut or scratches. If any damage is visible, the broken cable must be replaced with a new one.

	<b>Danger!</b> Be careful when checking the power cable. The cable must be disconnected from the power outlet prior to the checking to avoid the risk of an electric shock.
---	--

### 6.4 Replacing a defective cable

Replacement parts can be ordered through the first level helpdesk. Disconnect the ISAP from power outlet before replacing a defective cable.

### 6.5 Replacing antennas

The antennas might be replaced for maintenance purposes. The replacement of the antennas might be ordered through first level helpdesk. To replace an antenna, proceed with the following steps:

1. Unplug the ISAP power cable
2. Unscrew the antenna(s)
3. Attach the new antenna(s) by hand

	<b>Warning!</b> Do not use any tools when attaching or detaching antennas. Applying an excessively high momentum force may destroy the connectors. Fixing the antennas by hand is sufficient.
---	--

## 6.6 Reset to factory settings

A reset to factory settings can be issued by the user with external hardware operation as described below. The user configuration file will be overwritten with the factory default values. A new configuration with Workshop System Management (WSM) will be necessary. Please refer to the WSM User Guide [1] for more information about the configuration of ISAP. Please reset the ISAP only if first level supports tells you to do so.





Figure 6-2: Reset button

Figure 6-1: Reset to factory settings

Follow these steps to reset the ISAP to the factory settings:

1. Preferred: unplug the power cable, wait 5 seconds, reattach the power cable.  
*Alternative: if the ISAP is operational, push the reset button (see Figure 6-2) for at least 2 seconds, this will also reboot the ISAP.*
2. Push the Reset button (see Figure 6-2) again and hold it down approximately 40 seconds until ALL the LEDs of the ISAP flash several times.
3. The flashing of all LEDs indicates that the ISAP is set back to factory settings. Release the reset button now.

	<b>Info!</b>  After resetting to factory settings, the ISAP must be configured initially again through Workshop System Management (WSM).
	<b>Info!</b>  In case the READY LED did not switch over to constant yellow, the reset to factory settings has failed; please try again.

## 6.7 Replacing ISAP for maintenance purposes

- Remove the defective ISAP as described in chapter 4.3.4.
- Install the new ISAP device as described in chapters 4.3.2 and 4.3.3.
- In case you plan to use same location for reinstalling ISAP, you may leave the mounting plate installed on the wall.

Preliminary

## 7 Troubleshooting

	<b>Warning!</b> Do not open the housing of the ISAP. There are no serviceable parts inside!
---	--

Problem description	Solution
Nothing happens even when the power cord is connected.	Please check that the power outlet connection has 100...240VAC connected and that all fuses / circuit breakers are intact.
The READY led stays YELLOW after startup for a very long time.	Is the LAN led green? If not, then check the LAN cable connection. If yes, then wait 10 minutes, if READY led doesn't start flashing or turns to green, contact first level support. <b>Note:</b> When started in cold temperatures, it is normal that the start-up procedure takes longer.
The READY LED is flashing yellow for a very long time.	There is problem with the registration process to WSM, please check the LAN connection and the check the status of WSM.
The wireless network is no longer functional.	Check the status of the ISAP from the WSM User Interface. Reboot the ISAP by disconnecting and reconnecting the power cord. Check the status of other ITOOLS. Is their wireless communication functional?
The wireless network connection is not stable.	Try and run the Channel Wizard at WSM to optimize the used channel.
ERR LED is on	There is a problem in ISAP, please check ISAP Status from WSM user interface, see WSM User Guide [1]
READY LED is flashing green.	ISAP is performing a Firmware update, do not disconnect the power because ISAP will restart itself after update is finished
ISAP is not responding	Please check the ISAP status from the WSM user interface, see WSM User Guide [1]. Is radar detected? If not please try rebooting the ISAP by reattaching the power cable. If the problem is not solved please contact support.
“Temperature warning” at WSM ISAP Status	Check operating conditions of ISAP. Make sure that the ambient temperature around ISAP is not exceeding +50 °C. Contact support if the warning doesn't disappear.
“Services not running” at WSM ISAP Status	Please reboot ISAP, by re-attaching the power cable. Check that all services at WSM are running, see WSM User Guide [1]. Contact support in case the warning doesn't disappear.
“Hardware failure” at WSM ISAP Status	Please contact support.
“Interface problem” at WSM ISAP Status	Check validity of ISAP settings in WSM user interface, see WSM User Guide [1].

“Radar detected” at WSM ISAP Status

You are using the 5GHz band, radar has been detected and selection of new channel is ongoing. Please wait 2 minutes until the new channel has been selected and the ISAP is allowed to operate further.

Preliminary

## 8 Terms and Abbreviations

Abbreviation	Name
BIST	<b>B</b> uild <b>I</b> n <b>S</b> elf <b>T</b> est
CLI	<b>C</b> ommand <b>L</b> ine <b>I</b> nterface
EMC	<b>E</b> lectro <b>M</b> agnetic <b>C</b> ompatibility
ICOM	<b>I</b> ntegrated <b>C</b> ommunication <b>O</b> ptical <b>M</b> odule
IEEE	<b>I</b> nstitute of <b>E</b> lectrical and <b>E</b> lectronics <b>E</b> ngineers
IMIB	<b>I</b> ntegrated <b>M</b> easurement <b>I</b> nterface <b>B</b> ox
ISAP	<b>I</b> ntegrated <b>S</b> ervice <b>A</b> ccess <b>P</b> oint
ISID	<b>I</b> ntegrated <b>S</b> ervice <b>I</b> nformation <b>D</b> isplay
LAN	<b>L</b> ocal <b>A</b> rea <b>N</b> etwork
LED	<b>L</b> ight <b>E</b> mitting <b>D</b>
MAC-Address	<b>M</b> edia <b>A</b> ccess <b>C</b> ontrol – <b>A</b> ddress = <b>H</b> ardware address
R&TTE	<b>R</b> adio <b>a</b> nd <b>T</b> elecommunications <b>T</b> erminal <b>E</b> quipment <b>D</b> irective
ROHS	<b>R</b> estriction <b>o</b> f <b>H</b> azardous <b>S</b> ubstances <b>D</b> irective
USB	<b>U</b> niversal <b>S</b> erial <b>B</b> us; for linking a computer to external devices
VAC	<b>V</b> olt <b>A</b> lternating <b>C</b> urrent
VGA	<b>V</b> ideo <b>G</b> raphics <b>A</b> rray is a graphical computer standard
WEEE	<b>W</b> aste <b>E</b> lectric and <b>E</b> lectronic <b>E</b> quipment
WLAN	<b>W</b> ireless <b>L</b> ocal <b>A</b> rea <b>N</b> etwork
WSM	<b>W</b> orkshop <b>S</b> ystem <b>M</b> anagement
Nss	<b>N</b> umber of <b>S</b> patial <b>S</b> treams

## 9 References

#	"Title", Author, Place, Year
[1]	"WSM User Guide", BMW, February 2008

Preliminary

## 10 List of Figures

Figure 1-1: Integrated Service Access Point (ISAP) .....	4
Figure 1-2: Delivery content .....	8
Figure 3-1: Integrated Service Access Point.....	10
Figure 3-2: ISAP front view and markings.....	10
Figure 3-3: ISAP connectors' side and markings.....	10
Figure 3-4: Example of antenna directions .....	13
Figure 4-1: Example of hole marking .....	17
Figure 4-2: Drilling holes .....	17
Figure 4-3: Inserting dowels.....	17
Figure 4-4: Fixing the plate.....	18
Figure 4-5: Example of finished fixed plate .....	18
Figure 4-6: Openings for ISAP .....	18
Figure 4-7: Placing on ISAP horizontally.....	18
Figure 4-8: Place on first from below .....	19
Figure 4-9: Locking mechanism .....	19
Figure 4-10: Pushing and locking.....	19
Figure 4-11: Example of fixed plate .....	20
Figure 4-12: Example of fixed ISAP .....	20
Figure 4-13: Unlocking ISAP .....	20
Figure 6-1: Reset to factory settings .....	24
Figure 6-2: Reset button.....	24