



# Easy Series

ICP-EZM2



**BOSCH**



# Table of Contents

|          |  |           |
|----------|--|-----------|
| <b>1</b> | <b>Overview</b>  | <b>6</b>  |
| 1.1      | Installation Workflow  | 6         |
| 1.2      | System Components and Wiring                                       | 6         |
| 1.3      | Phone Menus  | 10        |
| 1.3.1    | Installer Phone Menu   | 10        |
| 1.3.2    | User Phone Menu  | 11        |
| <b>2</b> | <b>System Installation and Configuration</b>                       | <b>12</b> |
| 2.1      | Plan the Installation  | 12        |
| 2.2      | Install System Components  | 13        |
| 2.2.1    | Install the wLSN Hub   | 13        |
| 2.2.2    | Install the Control Panel Enclosure                                | 13        |
| 2.2.3    | Install the Control Center   | 14        |
| 2.2.4    | Route Power-limited Wiring   | 15        |
| 2.2.5    | Install the ITS-DX4020-G Communicator and Antenna                  | 15        |
| 2.2.6    | Install the DX2010 Input Expander                                  | 16        |
| 2.2.7    | Connect the Conettix DX4020 Network Interface Module               | 16        |
| 2.2.8    | Connect Supervised Points  | 16        |
| 2.3      | Apply System Power   | 17        |
| 2.4      | Initial System Startup   | 18        |
| 2.5      | Perform the RFSS Site Test using the wLSN Installation Tool        | 18        |
| 2.5.1    | Prepare the wLSN Hub for Site Testing and RFSS Mode                | 19        |
| 2.5.2    | wLSN Installation Tool Mode 1                                      | 19        |
| 2.5.3    | wLSN Installation Tool Mode 2                                      | 20        |
| 2.5.4    | wLSN Installation Tool Mode 3                                      | 21        |
| 2.6      | Install wLSN Devices   | 22        |
| 2.7      | Configure the System from the Installer Phone Menu                 | 22        |
| 2.7.1    | Upgrade the Control Panel (Optional)                               | 22        |
| 2.7.2    | Initiate a Phone Session from the Control Panel                    | 22        |
| 2.7.3    | Configure Required Control Panel Settings                          | 22        |
| 2.7.4    | Discover Wireless Devices  | 23        |
| 2.7.5    | Add Users, Tokens, and Key Fobs                                    | 24        |
| 2.8      | Configure the ITS-DX4020-G Communicator                            | 25        |
| 2.8.1    | Configure the Control Panel for Cellular Communication             | 25        |
| 2.8.2    | Configure the ITS-DX4020-G   | 25        |
| 2.8.3    | Test ITS-DX4020-G Communications                                   | 27        |
| <b>3</b> | <b>Point Expansion</b>   | <b>28</b> |
| 3.1      | Perform a RFSS Site Test with the Hub and the Device               | 28        |
| 3.2      | Establishing the Wireless Network and Configuring Wireless Devices | 28        |
| 3.2.1    | Discover a New System  | 29        |
| 3.2.2    | Establish and Configure the Wireless Network                       | 29        |
| 3.2.3    | Configure Devices  | 30        |
| 3.3      | Wireless Maintenance   | 31        |
| 3.3.1    | Wireless Configuration Menu  | 31        |
| 3.3.2    | Assigning Points 1 to 8 as Wireless Points                         | 32        |

|          |   |           |
|----------|---|-----------|
| 3.3.3    | Recovering the Wireless Network                       | 32        |
| 3.3.4    | Wireless System Messages                              | 32        |
| <b>4</b> | <b>Programming Access Options</b>                     | <b>33</b> |
| 4.1      | System Access by Phone                                | 33        |
| 4.2      | RPS   | 34        |
| 4.2.1    | RPS Connection Methods                                | 34        |
| 4.3      | Programming Keys                                      | 36        |
| <b>5</b> | <b>Programming</b>                                    | <b>37</b> |
| 5.1      | Basic Programming                                     | 38        |
| 5.1.1    | Enter Basic Programming                               | 38        |
| 5.1.2    | Points  | 39        |
| 5.1.3    | Report Configuration                                  | 40        |
| 5.1.4    | Outputs   | 41        |
| 5.2      | Expert Programming                                    | 42        |
| 5.2.1    | ROM Firmware Version Items                            | 43        |
| 5.2.2    | System Programming Items                              | 43        |
| 5.2.3    | Communicator Programming Items                        | 47        |
| 5.2.4    | RPS Configuration Items                               | 49        |
| 5.2.5    | Route Reporting Options                               | 50        |
| 5.2.6    | Point Programming Items                               | 52        |
| 5.2.7    | Output Programming Items                              | 54        |
| 5.2.8    | Control Center Programming Items                      | 55        |
| 5.2.9    | User Programming Items                                | 56        |
| 5.2.10   | Factory Default                                       | 57        |
| 5.3      | Exit Programming                                      | 57        |
| <b>6</b> | <b>Control Panel Event Codes (SIA and Contact ID)</b> | <b>58</b> |
| <b>7</b> | <b>Default the System</b>                             | <b>60</b> |
| 7.1      | Default the Control Panel and the wLSN Hub            | 60        |
| 7.2      | Default wLSN Devices                                  | 60        |
| <b>8</b> | <b>System Test and Maintenance</b>                    | <b>61</b> |
| 8.1      | Test the System                                       | 61        |
| 8.2      | Maintain the System                                   | 61        |
| 8.3      | Installer History Event Announcements                 | 61        |
| 8.4      | Event Messages  | 61        |
| <b>9</b> | <b>ITS-DX4020-G Communicator Configuration</b>        | <b>62</b> |
| 9.1      | ITS-DX4020-G Communicator Overview                    | 62        |
| 9.2      | Short Message Service (SMS) Configuration             | 63        |
| 9.3      | Accessing the User Interface and Logging On Using USB | 65        |
| 9.3.1    | Downloading the ITS-DX4020-G USB Driver               | 65        |
| 9.3.2    | Installing the ITS-DX4020-G USB Driver                | 65        |
| 9.3.3    | USB Main Menu   | 67        |

|           |   |            |
|-----------|---|------------|
| 9.3.4     | USB Option Menu                                 | 68         |
| 9.4       | Upgrading the ITS-DX4020-G Software             | 70         |
| 9.4.1     | Downloading the Latest Software                 | 70         |
| 9.4.2     | Installing the Software with Hyper Terminal     | 70         |
| 9.4.3     | Installing the Software with Tera Term          | 71         |
| <b>10</b> | <b>Device Specifications and Overview</b>       | <b>72</b>  |
| 10.1      | Control Panel                                   | 72         |
| 10.1.1    | Standby Battery Calculation                     | 74         |
| 10.2      | Control Center                                  | 75         |
| 10.3      | DX2010 Input Expander                           | 78         |
| 10.4      | Conettix DX4020 Network Interface Module        | 79         |
| 10.5      | ITS-DX4020-G Communicator                       | 79         |
| 10.6      | wLSN Installation Tool                          | 80         |
| 10.7      | wLSN Hub  | 81         |
| 10.8      | wLSN PIR and Dual Motion Detectors              | 82         |
| 10.9      | wLSN Door-Window Contact                        | 83         |
| 10.10     | wLSN Recessed Door-Window Contact               | 83         |
| 10.11     | wLSN Mini Door-Window Contact                   | 84         |
| 10.12     | wLSN Inertia Detector                           | 85         |
| 10.13     | wLSN Key Fob                                    | 87         |
| 10.14     | wLSN Relay Module                               | 89         |
| 10.15     | wLSN Indoor Siren                               | 90         |
| 10.16     | wLSN Outdoor Siren                              | 91         |
| 10.17     | wLSN Smoke and Heat Detectors                   | 92         |
| 10.18     | wLSN Glassbreak Detector                        | 95         |
| 10.19     | wLSN Water Sensor/Low-temperature Sensor        | 100        |
| <b>11</b> | <b>Programming Details and Defaults</b>         | <b>102</b> |
| 11.1      | Programming Item Programming Details            | 102        |
| 11.2      | Country Codes                                   | 107        |
| 11.3      | Country Code Specific Default Programming Codes | 108        |
| <b>12</b> | <b>Agency Approvals and Requirements</b>        | <b>112</b> |
| 12.1      | Certifications and Approvals                    | 112        |
| 12.2      | FCC   | 113        |
| 12.3      | Industry Canada                                 | 114        |
| 12.4      | SIA   | 114        |
| 12.5      | Underwriters Laboratories (UL)                  | 116        |
| 12.6      | PD6662 and DD243 Requirements                   | 118        |
| 12.7      | EN50131 Requirements                            | 119        |
| 12.8      | INCERT  | 120        |
| 12.9      | cUL   | 120        |
| 12.10     | NF A2P  | 120        |

# 1 Overview

This document contains instructions for a trained installer to properly install, configure, and operate the Easy Series control panel, and all optional peripheral devices. You will install and configure the system using the figures starting in *Section 1.2 System Components and Wiring*, page 6 and the information in *Section 2 System Installation and Configuration*, page 12. The sections following Sections 1 and 2 provide supporting details for installation, configuration, testing, and support.

## 1.1 Installation Workflow


To properly install, configure, and test the system, use the following workflow:

| Step                      | Description   | Page    |
|---------------------------|---|---------|
| 1. Plan the Installation  | Identify suitable locations for system component in the installation site.                                      | Page 12 |
| 2. Install the Hardware   | Install all system components.  | Page 13 |
| 3. Perform RFSS Site Test | Perform radio frequency signal strength (RFSS) test.  | Page 18 |
| 4. Configure the System   | Enroll wireless devices into the system, perform basic programming for the system, and add users to the system. | Page 22 |
| 5. Program the System     | Update the system with expert programming.  | Page 33 |
| 6. Test the System        | Perform a full system test. Ensure that the central monitoring station received test reports.                   | Page 61 |










**Table 1.1** Installation Workflow


## 1.2 System Components and Wiring

Refer to *Figure 1.1* through *Figure 1.3* for overviews of the system components and wiring.




**Figure 1.1** System Component Wiring Overview

| Callouts for Figure 1.2, Page 8                             |  |  |  |
|---|--|--|--|
| 1   | <b>Control Center</b><br> | Mount within 3 m of control panel, Use CAT5 cable (twisted pair) for audio bus, Set data bus address (1 - 4), up to 4 controls max   |  |
| 2   | <b>wLSN Hub</b><br>       | S1   | S2   |
|   |  | 1  | 0 = Normal Operation   |
|   |  | 9  | 2 = RFSS Mode  |
|   |  | 9  | 8 = Default Hub (refer to Page 60)   |
|   | <b>DX2010 Point Expander</b>   |   | Data Bus Adr 102: Points 9 - 16  |
|   |  |   | Data Bus Adr 103: Points 17 - 24   |
|   |  |   | Data Bus Adr 104: Points 25 - 32   |
| 4   | <b>DX4020 Network Interface Module</b>   | Data Bus Adr 134<br>   | 1 - On<br>2 - Off  |
| 5   | <b>ITS-DX4020-G</b>  | Data Bus Adr 134 (Fixed)   |  |
| 6   | <b>Supervised Points (single EOL)</b>  | Normally open and normally closed options (2.2k Ω)   |  |
| 7   | <b>Supervised Points (dual EOL)</b>  | Normally closed (2.2k Ω)   |  |
| 8   | <b>Keyswitch Options (single and dual EOL) ((2.2k Ω)</b>   |  |  |
| 9   | <b>Prog Output (PO) 1 Options</b>  | Switched 12v   | Switched Ground  |
|   |  |    |    |
|   |  |  |  |
| 10  | <b>Prog Outputs 2 - 4</b>  | NF A2P requires that sirens have a backup battery. When this siren requires a 14,1V to 14,4V supply, use the optional board EZPS-FRA or the auxiliary power supply IPP-PSU-2A5. Set the output as interior burglary alarm. |  |
| 11  | <b>2-wire Smoke Detector Option</b>  | EOL resistor (P/N: 25899) required.  |  |
| 12  | <b>4-wire Smoke Detector Option</b>  | EOL resistor (P/N: 25899) and Bosch EOL relay module required  |  |
| Note: The system uses a 12 VDC battery, connected as shown. |  |  |  |



**Figure 1.2** Overview of the System Component Location for the ICP-EZM2-R Enclosure




**Figure 1.3** Overview of the System Component Location for the ICP-EZM2-EU Enclosure



| <b>Callouts for Figure 1.2 Page 8 and Figure 1.3, Page 8</b> |   |
|--|---|
| 1  | <b>Port for ICP-EZRU-V3 ROM Update Key and Programming Key</b>  |
| 2  | <b>Enclosure Cover and Wall Tamper Switch</b>   |
| 3  | <b>Ground connection</b><br>Connect ground wire from enclosure to enclosure door.   |
| 4  | <b>Module mounting location</b><br>ITS-DX4020-G shown.  |
| 5  | <b>Module mounting location</b><br>DX2010 shown.  |
| 6  | <b>System test button</b><br>When the system is completely installed and programmed, press the system test button to start a full system test.        |
| 7  | <b>Port for ICP-EZVM voice module</b>   |
| 8  | <b>Enclosure terminal cover</b> (ICP-EZM2-R Enclosure only)<br>Shipped in hardware bag. Install over terminals when power supply wiring is completed. |

# 1.3 Phone Menus


## 1.3.1 Installer Phone Menu



= The system’s arming status (on or off) and Expert Programming Item Number 142 setting of (0 or 1) determines the availability of these menu items. Refer to *Section 5.2.2 System Programming Items*, Page 43.

**When recording any description (point, output, user, or custom message), do not press any buttons on your phone until prompted by the system.**

### 1.3.2 User Phone Menu



- 1 Only a user passcode (Users 1 to 21) can access the User Menu.
  - 2 If the system is on, the System Maintenance option is not available.
  - 3 Only the master user can add, change, or delete users. Users 2 to 21 can only change their own passcodes. User voice descriptions are stored in the voice module and are not transferred to the control panel with programming data.
  - 4 Option 6 allows the master user (User 1) to enable the Installer Passcode. Refer to Expert Programming Item Number 142 in Section 5.2.2 System Programming Items, Page 43.
- Availability of the menu items shown above depends on the system's status.
- When recording any description (point, output, user, or custom message), do not press any buttons on your phone until prompted by the system.**

## 2 System Installation and Configuration

### 2.1 Plan the Installation

When planning the installation, identify suitable locations for the control panel, control center, hub, and wireless devices before installing any system components. When identifying these locations, ensure that the following considerations are addressed.

| Task   | Considerations   |
|--|--|
| 1. Identify the location for the control panel.  | <ul style="list-style-type: none"> <li>– Only use authorized service personnel to install this system.</li> <li>– Plan to install the control panel in a centrally located room that is near the AC Power MAINS.</li> <li>– Plan to install the control panel in a location with a good earth ground.</li> <li>– Because the control panel is permanently connected equipment, a readily accessible disconnect device must be included into the building installation wiring.</li> </ul>   |
| 2. Test for GSM signal strength.                 | <p>Use your cell phone to identify an area with good GSM signal strength by monitoring the signal strength on your mobile phone.</p> <p><b>If the intended location of the control panel has poor GSM signal strength, find a new location for the control panel.</b></p>  |
| 3. Identify the location for the control center. | Plan to install the control center near the primary entry and exit door.   |
| 4. Identify the location for the wLSN Hub.       | Plan to install the wLSN Hub in a location with good radio-frequency (RF) characteristics and within 100 m of the control panel.   |
| 5. Identify the location for the wLSN devices.   | <ul style="list-style-type: none"> <li>– wLSN devices are intended only for indoor, dry applications. Avoid installing the devices where excessive humidity or moisture, or temperatures outside of the acceptable operating range, exist.</li> <li>– Mount wLSN devices on flat, rigid surfaces. For more information, refer to each device's installation instructions.</li> <li>– Avoid mounting wLSN devices in areas with large metallic objects, electrical panels or electric motors. They might reduce the (RF) range of a wLSN device.</li> </ul> |

**Table 2.1** Installation Considerations

## 2.2 Install System Components

**NOTICE!**

- Use proper anchor and screw sets when installing the enclosure on non-load-bearing surfaces, such as drywall.
- Follow anti-static procedures when handling the control panel board. Touch the earth ground terminal on the control panel board to discharge any static charge before working on the control panel board.
- If you install more than one control center, mount them at least 1.2 m apart.
- Do not install the wLSN Hub within 15 cm (6 in) of the control centers metal enclosure.

**NOTICE!**

Refer to *Figure 1.2, Page 8* or *Figure 1.3, Page 8* throughout this section for the location to install each of the hardware components in the enclosure.

### 2.2.1

#### Install the wLSN Hub

1. Separate the wLSN Hub from its base.
2. Set the wLSN Hub's rotary switches to enable RFSS mode: S1 = 9, S2 = 2, S3 = 0. This is the setting required for the RFSS site test. Refer to *Figure 1.1, Page 6*.
3. Connect the wLSN Hub's data bus to the control panel's data bus. The wLSN Hub's terminal block is removable.
  - **Wire Gauge:** 0.14 mm to 1.5 mm (18 AWG to 24 AWG)
  - **Wire Length (sLSN Hub to control panel):** <= 100 m
4. Reconnect the wLSN Hub and base, and then lock the wLSN Hub.
5. Mount the wLSN Hub temporarily in the desired location. You might need to relocate the wLSN Hub if it does not pass RFSS testing.


### 2.2.2

#### Install the Control Panel Enclosure

1. Remove the desired knockouts from the control panel enclosure and optional mounting skirt.
2. Attach the optional mounting skirt to the enclosure.
3. Route the wires through the desired knockouts.
4. Mount the enclosure to the desired surface. Use proper anchor and screw sets when you install the enclosure on non-load-bearing surfaces, such as drywall.

### 2.2.3 Install the Control Center

1. Unlock the control center and separate it from the base.
2. If you install more than one control center, each control center must have a unique address. Valid address are 1 to 4. Refer to *Figure 2.1* for the location of the address switch.



**Figure 2.1** Control Center Address Switch

|   |                                   |
|---|-----------------------------------|
| 1 | Control Center’s front cover      |
| 2 | Address switch’s default settings |

3. Mount the control center base to the desired surface using the appropriate mounting holes. Use the built-in level in the control center base as a guide.



**NOTICE!**

Mount the base to a non-metallic surface that is near the primary entry/exit door. If you install more than one control center, ensure that there is at least 1.2 m between each control center.


Avoid mounting the control center near existing phone lines.

Avoid mounting the control center near other electronic devices.

4. Connect the control center data bus terminals to the control panel data bus terminals. Refer to *Figure 1.1*, Page 6.
5. Connect the control center audio bus terminals to the control panel audio bus terminals. Twisted pair wiring is recommended for audio bus terminals. Refer to *Figure 1.1*, Page 6.
6. Reconnect the control center and base, and then lock the control center. Refer to Section Control Center Display States, Page 75 for an overview of the various control center display states.

## 2.2.4 Route Power-limited Wiring

All wiring except primary AC power and standby battery is power-limited. Separate primary AC power and standby battery wires from other wires by at least 6.4 mm (¼ in.), and secure to enclosure to prevent movement. Primary AC power and standby battery wiring cannot share the same conduit, conduit fittings, or conduit knockouts with any other wiring. Refer to *Figure 2.2*, Page 15.



**Figure 2.2** Power-limited Wire Routing

## 2.2.5 Install the ITS-DX4020-G Communicator and Antenna

The ITS-DX4020-G is powered from the bus.



### NOTICE!

When using the ITS-DX4020-G GSM channel for communications, do not permanently connect a telephone to the Easy Series house phone terminals.

Refer to *Figure 1.1*, Page 6 for wiring instructions.

1. Install the ITS-DX4020-G SIM card.
  - a) Hold the ITS-DX4020-G communicator in the orientation shown in *Figure 9.1*, Page 62.
  - b) Slide the SIM cardholder door upward to unlock it, and then open the door.
  - c) Hold the SIM card in the orientation shown in *Figure 9.1*, Page 62, and then Insert the SIM card into the cardholder door; the notched edge is away from the hinge.
  - d) Close the cardholder door, and then slide the door downward to lock it.
2. Mount the communicator into the control panel's enclosure using the side wall mounting location.
3. Place the magnetic antenna on the panel enclosure (on top recommended for vertical polarization). The antenna must be placed on a metal surface for proper operation.
4. Connect the antenna cable to the communicator.
5. Connect the audio terminals on the ITS-DX4020-G to the control panel's inside phone terminal block.
6. Connect the communicator option bus molex connector to the to the communicator and connect the bus wires to the option bus terminals on the control panel. If preferred, the terminal screws on the communicator can be used instead of the molex connection.
7. Install the configuration jumper on the CONFIG MODE (J200) pins. Refer to *Figure 9.1*, Page 62 for the jumper location.

## 2.2.6 Install the DX2010 Input Expander

The control panel supports up to three DX2010 Input Expanders for Points 9 to 32. Refer to the *DX2010 Installation Instructions* (P/N: 49533) for more information.

1. Set the DX2010's DIP switches.
2. Mount the DX2010 into the control panel's enclosure (back wall or either side wall), or other suitable enclosure.
3. Connect the DX2010 to the control panel. Refer to *Figure 1.1*, Page 6.  
Connect a wire jumper to the TMPR and COM terminals to disable the DX2010's tamper input. For point wiring options, refer to *Section 2.2.8 Connect Supervised Points*, Page 16. To disable the tamper input on the DX2010, connect a wire jumper between the TMPR and COM terminals.



### NOTICE!

In an NF A2P certified installation, mount the DX2010 module on one side of the panel housing, or on one side of the auxiliary power supply (PP-PSU-2A5).

## 2.2.7 Connect the Conettix DX4020 Network Interface Module

The control panel supports one DX4020 for wired network communication. Refer to the *DX4020 Installation Instructions* (P/N: F01U045288) for more information.

1. Set the DX4020's DIP switches to Address 134 for network communication.
2. Mount the DX4020 into the control panel's enclosure using the back wall or side wall mounting location.
3. Connect the DX4020 to the control panel. Refer to *Figure 1.1*, Page 6.

## 2.2.8 Connect Supervised Points

For wiring diagrams, refer to *Figure 1.1*, Page 6.

### Fire Point Wiring

Supervised Point 1 supports two- and four-wire smoke detectors.

Supervised Points 2 to 32 support only four-wire smoke detectors.

To program supervised points as fire points, refer to *Section 5.1.2 Points*, page 39.

For intrusion point configuration, refer to *Section Intrusion Point Wiring*, Page 16.

When using an output to supply power to a four-wire smoke detector, program the output function for System Reset. Refer to *Section 5.1.4 Outputs*, page 41.

### Intrusion Point Wiring

You can wire Supervised Points 1 to 32 as wired or wireless intrusion points.

To program Supervised Points 1 to 32 as intrusion points, refer to *Section 5.1.2 Points*, page 39.



## 2.3 Apply System Power




### NOTICE!

Because the control panel is permanently connected equipment, a readily accessible disconnect device must be included into the building installation wiring.

An external earth ground is required to ensure safe and proper system operation. Failure to ground the system can cause personal injury and degraded system performance, such as problems with tokens or noise on the control center.

1. Connect battery power to the control panel. Refer to *Figure 1.1*, Page 6.
2. Use a cable tie to secure the incoming AC wires to the enclosure, where required. Refer to *Figure 2.3*, Page 17.







**Figure 2.3** Cable tie for MAINS to Power Supply

3. Place the terminal cover over the power supply terminals.

## 2.4 Initial System Startup

1. Apply AC power to the system.
2. Refer to *Table 2.2* for the Initial System Startup sequence.

| Stage | Time Interval | Control Center  | wLSN Hub                         |
|-------|---------------|---|----------------------------------|
| 1     | 0-15 sec      |  | Intermittent flashing green icon |
| 2     | 15-45 sec     |  | Flashing amber circle            |
| 3     | 45-75 sec     |  | Single rotating amber segment    |
| 4     | 75 sec        |  | Solid green circle               |

**Table 2.2** Initial System Startup Sequence (No wLSN devices discovered)

## 2.5 Perform the RFSS Site Test using the wLSN Installation Tool

The wLSN Installation Tool communicates signal strength levels, noise levels, signal-to-noise ratio (SNR), and packet success rates. Use it to determine the best locations for wLSN device installation.



### NOTICE!

Before permanently installing any wLSN device, verify that the radio-frequency signal strength (RFSS) between the planned device location and the planned wLSN Hub location is acceptable.



### CAUTION!

If you have wireless devices that you will not immediately install, reinsert the battery tabs or remove the batteries to prevent battery depletion.



### NOTICE!

You can perform the RFSS site test using the wLSN Hub and the specific device you wish to test. However, you must use the Installation Tool with the wLSN Smoke Detector. You cannot determine RFSS with the detector itself. Refer to *Section 3.1 Perform a RFSS Site Test with the Hub and the Device*, page 28 for instructions.

### 2.5.1 Prepare the wLSN Hub for Site Testing and RFSS Mode

1. Unlock the wLSN Hub and separate it from its base.
2. Set Switch S1 to 9 and Switch S2 to 2 to enable RFSS mode. This disables normal operation. Refer to *Figure 1.1*, Page 6.
3. Set Switch S3 to a value of 0 to 4, based upon the RF power level or EN50131 security grade you wish to use. Refer to *Table 2.3*.

| Switch 3 Setting | RF Power (EN50131 Security Grade)           |
|------------------|---|
| 0                | Maximum power                               |
| 1                | 3 dB lower than maximum (Security Grade 1)  |
| 2                | 6 dB lower than maximum (Security Grade 2)  |
| 3                | 9 dB lower than maximum (Security Grade 3)  |
| 4                | 12 dB lower than maximum (Security Grade 4) |

**Table 2.3** wLSN Hub RF Power/EN Settings  
Refer to individual device's specification for their EN50131 classification.



**NOTICE!**

You must test the devices at the same EN50131 Security Grade at which the control panel discovers the devices.

4. Find a suitable location for the hub base and apply power by either connecting it to the control panel (refer to the control panel's installation instructions), or temporarily connecting a 9 VDC to 12 VDC battery.
5. Reconnect the wLSN Hub and base, and then lock the wLSN Hub.

### 2.5.2 wLSN Installation Tool Mode 1

Mode 1 identifies if a device location has acceptable or unacceptable RFSS.

To test the wireless devices with the Installation Tool in Mode 1:

1. Verify that the wLSN Hub rotary switch is set to S1 = 9, S2 = 2, S3 = 0. Refer to *Figure 1.1*, Page 6. The wLSN Hub's LED flashes slowly.
2. Go to the first device location, and then press and hold [\*][#] on the Installation Tool for 2 sec.
3. Press [1] for Mode 1.
4. Place the Installation Tool in an upright position at the first device location, or hold it in the location, if necessary.
5. Wait 10 sec and then review the display.

– Acceptable RFSS Display:

M O D E 1 : + + + O K + + +

– Unacceptable RFSS Display:

M O D E 1 : - N O T O K -

If the location tests:

- **OK:** Confirm that the location is OK by testing it with the actual wireless device for this location.
- **Not OK:** Test a different location.

### 2.5.3 wLSN Installation Tool Mode 2







To test the wireless devices with the Installation Tool in Mode 2:

1. Verify that the wLSN Hub rotary switch is set to S1 = 9, S2 = 2, S3 = 0. Refer to *Figure 1.1*, Page 6. The wLSN Hub's LED flashes slowly.
2. Go to the first device location, and then press and hold [\*][#] on the Installation Tool for 2 sec.
3. Press [2] for Mode 2.
4. Place the Installation Tool in an upright position at the first device location, or hold it in the location, if necessary.
5. Wait 10 sec and then review the display.

M O D E 2 :  

 P A C K E T S = 3

The Mode 2 display shows power bars on the left and the number of packets received on the right. The bars indicate the signal strength. The Installation Tool shows the number of packets received: 1, 2, or 3.

| Power Bars  | Signal to Noise Ratio | Packets | Signal Strength            |
|---|-----------------------|---------|----------------------------|
|    | < 9 dB                | ≤2      | Unacceptable               |
|    | 9 dB                  | ≥2      | Marginal (not recommended) |
|   | 13 dB                 | ≥2      | Acceptable                 |
|  | 16 dB                 | ≥2      | Good                       |
|  | 20 dB                 | ≥2      | Very good                  |
|  | 22 dB                 | ≥2      | Excellent                  |

**Table 2.4** Mode 2 Display Data

If the location tests:

- **OK:** Confirm that the location is OK by testing it with the actual wireless device for this location.
- **Not OK:** Test a different location.

### 2.5.4 wLSN Installation Tool Mode 3

When you perform the RFSS Site Test record the highest and lowest SNR readings because you may need to compare them.

If the results for SNR fluctuate significantly, the location is:

- **OK** if you subtract the dB difference between the highest (H) result and the lowest (L) result, and the number equals more than 13 dB. Confirm the location is OK by testing with the actual wireless device for this location.  $(L - (H - L) \geq 13 \text{ dB} = \text{OK})$
- **Not OK** if you subtract the dB difference between the highest (H) result and the lowest (L) result and the number equals less than 13 dB. In this case, select a new location to test.  $(L - (H - L) \leq 13 \text{ dB} = \text{Not OK})$

To test the wireless devices with the Installation Tool in Mode 3:

1. Verify that the wLSN Hub rotary switch is set to S1 = 9, S2 = 2, S3 = 0. Refer to *Figure 1.1*, Page 6. The wLSN Hub's LED flashes slowly.
2. Go to the first device location, and then press and hold [\*][#] on the Installation Tool for 2 sec.
3. Press [3] for Mode 3.
4. Place the Installation Tool in an upright position at the first device location, or hold it in the location, if necessary.
5. Wait 10 sec and then review the display.

In the Mode 3 display, "SNR yy" refers to the signal to noise ratio in dB and "x" is the RFSS value in dBm.

The Mode 3 display shows the signal to noise ratio (SNR) at the test spot. S refers to the signal strength of the incoming message from the wLSN Hub to the Installation Tool. N refers to the ambient noise level that exists at the location. The signal must be greater than the noise (S>N). The higher the SNR, the stronger the location's signal at that location. Dashes, appearing on both the S and N lines, indicate unacceptable signal strength.

```

M   O   D   E           3   :           S   -   x   x   x   d   B   m
S   N   R   Y           N   -   x   x   x   d   B   m
    
```

6. Note the readings for the location, especially the SNR values.
7. Refer to *Table 2.5* to interpret the results based on the lowest and highest readings. If one or more of the results for SNR falls below 13 dB, the location is Not OK.

| Signal to Noise Ratio | Signal Strength            |
|-----------------------|----------------------------|
| < 9 dB                | Unacceptable               |
| 9 dB                  | Marginal (not recommended) |
| 13 dB                 | Acceptable                 |
| 16 dB                 | Good                       |
| 20 dB                 | Very good                  |
| 22 dB                 | Excellent                  |

**Table 2.5** Signal to Noise Ratio Data

If the location tests:

- **OK:** Confirm that the location is OK by testing it with the actual wireless device for this location.
- **Not OK:** Test a different location.

## 2.6 Install wLSN Devices

1. If RFSS is **OK**:
  - Install the device's base and continue to the next location.
 If RFSS is **Not OK**:
  - Determine what is preventing acceptable RFSS and re-test.
  - Move the device to a new location and re-test, or
  - Move the wLSN Hub to a new location and re-test.
2. Repeat Steps 5 through 10 in *Section 2.5 Perform the RFSS Site Test using the wLSN Installation Tool* on Page 18 until all locations are tested and all bases installed.
3. Press and hold [\*][#] to exit from the test mode.  
The Installation Tool powers down from the main menu 30 sec after the last key press.
4. Remove power from the system.
5. Set the wLSN Hub's rotary switches to: S1 = 1, S2 = 0, S3 = 0.
6. Reapply power to the system.

## 2.7 Configure the System from the Installer Phone Menu



### NOTICE!

You can configure a control panel using pre-configured program data stored on a programming key. For more information, refer to *Section 4.3 Programming Keys*, page 36.

### 2.7.1 Upgrade the Control Panel (Optional)

Insert the ICP-EZRU-V3 ROM update key.

The upgrade is complete (after 5 to 10 min), when the green (√) LED on the control panel flashes. Remove the green upgrade programming key.

### 2.7.2 Initiate a Phone Session from the Control Panel

1. Connect a phone set to the test posts or to the phone terminals. Refer to *Figure 1.1*, Page 6.
2. Press and hold the System Test button for approximately 15 sec. *Figure 1.2*, Page 8 for the location of the Test button.
3. When prompted, use the phone set to enter the installer passcode (default is 5432[11]) for the Installer Menu, or the master user passcode (default is 1234[55]) for the User Menu. For the following two procedures, enter the installer passcode.



### NOTICE!

For more information on default passcodes, refer to *Section 4.1 System Access by Phone*, page 33.

### 2.7.3 Configure Required Control Panel Settings

1. From the Installer menu, if prompted to set the panel date and time, press [1][1]. When finished following the prompts, press [#][#] to return to the Installer Menu.
2. If prompted to set the Country Code, press [3][4]. Refer to *Section 11.2 Country Codes*, page 107 for the appropriate Country Code. When finished following the prompts, press [#] to return to the Installer Menu.

### 2.7.4 Discover Wireless Devices

Discovery is the process through which the wLSN Hub identifies and includes new devices into a system.

1. From the Installer Menu (refer to *Section 2.7.2 Initiate a Phone Session from the Control Panel*, page 22), press [1][6] to start the Discovery Process.
2. Mask all motion detectors. (The optional ISW-BMASK-10 may be used.)
3. When the system announces, "Install all batteries," install the batteries or remove the battery tabs from the wireless devices.
4. Press [1] to continue. The system then says, "Discovering devices, please wait." During this time, the system finds all the undiscovered wireless devices. This process takes approximately 6 min.

**NOTICE!**



Point numbers are assigned to wireless devices in the order that the devices first communicate to the system (tampered, faulted, low battery). If specific point numbers are preferred for wireless devices, ensure that the wireless devices communicate in the appropriate order. Otherwise, the system assigns the lowest available point number to the first tested wireless device. With motion detectors, unmask only the detector you want to test.

5. The system announces, "Wireless devices: xx. Test all points." "xx" = the number of wireless devices discovered, but not yet tested.
6. Test each point. If specific point numbers are preferred, test points in the appropriate order.  
Refer to *Table 2.6* for instructions on testing each wireless device.

| Device   | To Test   |
|--|---|
| Motion Detectors   | Walk across the detector's coverage pattern.  |
| Smoke Detector   | Press and release the detector's test button, or blow smoke into the detector's chamber to cause an alarm. Restore the alarm.   |
| Relay Module   | <b>Input and Output:</b> Fault and restore the supervised loop.<br><b>Output Only:</b> Tamper the device.   |
| Inertia Detector   | <b>Magnetic Switch:</b> Open and then close the switch.<br><b>Inertia Only:</b> Cause an alarm and then restore the alarm <sup>1</sup> , or tamper the detector. <sup>3</sup> |
| Glass Break Detector                                     | Cause an alarm and then restore the alarm, or tamper the detector. <sup>3</sup>   |
| Mini Door/Window Contact<br>Recessed Door/Window Contact | Open and then close the magnetic switch.  |
| Door/Window Contact                                      | Open and then close the magnetic switch, or fault and then restore the supervised loop. Perform both tests only if both the magnetic switch and supervised loop are used.     |
| Indoor Siren   | Tamper the device.  |
| Outdoor Siren  | Tamper the device. To configure the device, refer to <i>Section 10.16 wLSN Outdoor Siren</i> , page 91.   |

| Device   | To Test   |
|--|---|
| Water Sensor/Low-temperature Sensor  | <p><b>Water Sensor:</b> Select one of the following methods:</p> <ul style="list-style-type: none"> <li>– Short the water probe pins for at least 5 sec.</li> <li>– Submerge the water probe in water for at least 5 sec.</li> </ul> <p><b>Low-temperature Sensor:</b> Short the "T" pads for at least 5 sec.</p> |
| <p><sup>1</sup> To test the inertia detector, create a shock to cause an inertia alarm, and then restore alarm.</p> <p><sup>2</sup> To test the glass break detector, use a special tool to cause a glass break alarm, and then restore the alarm.</p> <p><sup>3</sup> If you tamper the detector, the control panel enrolls the detector, but does not test it. You must create the appropriate alarm and restore the alarm to test the detector.</p> |   |

**Table 2.6** Wireless Device Test Procedures

After each successful point test, the system announces "Point xx was tested."

If you test a point and the system only announces "Point xx," the point number is assigned, but has not been tested:

- If you prefer specific point numbers, do not continue. Fix any issue with the device and re-test until the system announces "Point xx was tested."
  - If you do not prefer specific point numbers, you can test them later through the Installer Menu. When the system completes the testing, the system announces "Wireless devices not configured."
7. The system says, "System test complete."

## 2.7.5

### Add Users, Tokens, and Key Fobs

1. From the User Phone Menu (refer to *Section 2.7.2 Initiate a Phone Session from the Control Panel*, page 22), press [4] to enter the User Menu.
2. From the User Phone Menu, press [4] to enter the User Menu.
3. Press [1] to add a new user. After you add a new user, you can also assign a token, passcode, and key fobs to that user.
4. Repeat Step 4 to add more users.
5. Press [#] to return to the User Menu.



#### NOTICE!

If you plan to use a programming key to copy control panel data for back up or use on another system, back up the data now. Refer to *Section 4.3 Programming Keys*, page 36.



## 2.8 Configure the ITS-DX4020-G Communicator

### 2.8.1 Configure the Control Panel for Cellular Communication

You must enable GSM dialing, and set the format used and the destination IP address and port number or phone number. You can also configure anti-replay and other parameters. To do so:

1. Enable GSM dialing using Expert Programming Item 202.
2. For the primary and backup destinations, configure the control panel options as desired. Refer to *Table 2.7*, Page 25 for an example of a typical configuration and the corresponding Expert Programming Items.

|                          | Format     | IP Address/Phone Number | Port | Anti-replay |
|--------------------------|------------|-------------------------|------|-------------|
| Route 1 Primary (GPRS)   | Network    | 192.168.121.195         | 7700 | 1           |
| Item Number to Configure | 211        | 206                     | 241  | 289         |
| Route 1 Backup (GSM)     | Contact ID | 1.585.223.4060          | N/A  | N/A         |
| Item Number to Configure | 212        | 207                     |      |             |

**Table 2.7** Example Configuration for Cellular Communications

### 2.8.2 Configure the ITS-DX4020-G

Ensure that the configuration jumper is installed on the CONFIG MODE (J200) pins. Refer to *Section 2.2.5 Install the ITS-DX4020-G Communicator and Antenna*, page 15 for proper installation.

1. Observe the LEDs to check for signal strength. Refer to *Table 2.8*, Page 25. Refer to *Figure 9.1*, Page 62 for LED locations.

| Strength/Comments  | LED State |         |       |       |       |       |     |
|--|-----------|---------|-------|-------|-------|-------|-----|
|  | STATUS    | CELL IP | AUDIO | SS1   | SS2   | SS3   | BUS |
| Unacceptable—No reading available (modem is resetting or registering). | ⊗         | ⊗       | ⊗     | Off   | Off   | Off   | ⊗   |
| Attempting to register on the GSM network.                             | ⊗         | ⊗       | ⊗     | Flash | Off   | Off   | ⊗   |
| Unacceptable: < -89 dBm.   | ⊗         | ⊗       | ⊗     | On    | Off   | Off   | ⊗   |
| Acceptable: -89 dBm to -83 dBm.  | ⊗         | ⊗       | ⊗     | On    | Flash | Off   | ⊗   |
| Good: -83 dBm to -77 dBm.  | ⊗         | ⊗       | ⊗     | On    | On    | Off   | ⊗   |
| Very good: -77 dBm to -69 dBm.   | ⊗         | ⊗       | ⊗     | On    | On    | Flash | ⊗   |
| Excellent: > -69 dBm.  | ⊗         | ⊗       | ⊗     | On    | On    | On    | ⊗   |

Key: → = Scrolling LEDs, from left to right. ⊗ = LED's status does not matter.  
 Shifting flash = Every other LED flashes simultaneously, creating the shifting flash pattern.

**Table 2.8** ITS-DX4020-G Signal Strength LEDs

2. Call the central monitoring station (CMS) and provide the account number (may be known as NNC number at the CMS), and control panel polling rate.
3. Observe the BUS LED. The LED stays on steady when the communicator has permission to be configured. Refer to *Figure 9.1*, Page 62 for LED locations. Refer to row 2 in *Table 2.9*, Page 26.
4. Observe the SS1 LED to confirm the ITS-DX4020-G is registered and has sufficient signal strength to configure it by SMS. The SS1 LED must be On to continue. Refer to *Figure 9.1*, Page 62 for LED locations. Refer to *Table 2.8*, Page 25 for the LED states.
5. Use the SMS configuration template to send the SMS to the installed SIM card phone number. For detailed SMS configuration information, refer to *Section 9.2 Short Message Service (SMS) Configuration*, page 63.

6. Observe the LEDs to confirm that the communicator received a valid configuration SMS. Valid SMS configurations should be received within 5 min. Refer to row 4 in *Table 2.9*, Page 26.

|   | State/Comments  | LED State |         |       |                     |       |       |       |
|---|---|-----------|---------|-------|---------------------|-------|-------|-------|
|   |   | STATUS    | CELL IP | AUDIO | SS1                 | SS2   | SS3   | BUS   |
| 1 | No control panel authorization received.  | →         | →       | →     | GSM Signal Strength |       |       | Off   |
| 2 | Installer is authorized for Configuration mode, or authorization is not required. | →         | →       | →     | GSM Signal Strength |       |       | On    |
| 3 | Received invalid SMS.   | →         | →       | →     | Flash               | Flash | Flash | Flash |
| 4 | Received valid SMS authorizing configuration.                                     | →         | →       | →     | →                   | →     | →     | →     |

Key: → = Scrolling LEDs, from left to right. ⊗ = LED's status does not matter.  
Shifting flash = Every other LED flashes simultaneously, creating the shifting flash pattern.

**Table 2.9** Configuration Mode (J200 Jumper Installed) LED States

**NOTICE!**



If the LEDs indicate an invalid SMS, remove the configuration jumper and then repeat the steps in *Section 2.8.2 Configure the ITS-DX4020-G*, page 25.

If the LEDs continue to indicate an invalid SMS, the SMS template might be incorrect. Confirm the SMS template format and settings and try again, or use a USB connection to configure the ITS-DX4020-G.

7. Remove the configuration jumper. The communicator reboots.
8. Ensure that the ITS-DX4020-G can communicate with the D6600/DX6600i. Refer to *Table 2.10*, Page 26.

| CELL IP | Status  |
|---------|---|
| Off     | ITS-DX4020-G is not connected to the GPRS network.                                      |
| Flash   | ITS-DX4020-G is connected to the GPRS network, but not connected to the Bosch receiver. |
| On      | ITS-DX4020-G is connected to the Bosch receiver through the GPRS network.               |

**Table 2.10** D6600 Connection Status

### 2.8.3

#### Test ITS-DX4020-G Communications

1. Configure the control panel for cellular communication, if necessary. Refer to *Section 2.8.1 Configure the Control Panel for Cellular Communication*, page 25.
2. Send a test alarm using the GPRS network route, and then verify receipt of the alarm at the CMS.
3. For systems using a ITS-DX4020-G with *Network* as the Primary Format (GPRS) and *Contact ID* or *SIA* as the Backup Format (GSM), program and use a Manual Communicator Test using Programming Item Number 362 (refer to *Section System Report and Restoral Routing*, page 51). Then, send a test report using the PTSN using GSM destination and observe the LEDs. Refer to *Section 2.8.3 Test ITS-DX4020-G Communications*, page 27 for configuration information. To use the Manual Communicator Test:
  - a) Set the Format for Route 2 Primary Destination (Programming Item Number 213) the same as the Format for Route 1 Backup Destination (Programming Item Number 212)
  - b) Set the Route 2 Primary Destination (Programming Item Number 208) the same as the Route 1 Backup Destination (Programming Item Number 207).
  - c) Set Programming Item Number 362 to 2 (Route 2 only).
  - d) Set Programming Item Number 202 to 1.
4. If incoming GSM calling is enabled, initiate a phone call into the control panel voice menu.

## 3 Point Expansion

### 3.1 Perform a RFSS Site Test with the Hub and the Device

You can use the wLSN Hub and the wLSN device to perform an RFSS site test, or use the wLSN Installation Tool (refer to *Section 2.5 Perform the RFSS Site Test using the wLSN Installation Tool*, page 18).

1. Take the device being tested to its planned mounting location.
2. Remove and re-insert the device's batteries, then quickly press and release the tamper switch button four times to enter RFSS mode.
3. Hold the device at the planned mounting location.
4. Determine if the RF signal strength is acceptable by observing the device's LED flash pattern. The flash pattern appears for 10 min. Refer to Table 3.1, Page 28.

| LED Flash Pattern                   |  |
|-------------------------------------|--|
| Flashes at 1 sec intervals          | No packets received or unacceptable signal strength condition. |
| Flashes rapidly (0.2 sec intervals) | Acceptable signal strength.                                    |

**Table 3.1** wLSN Device LED Flash Patterns in RFSS Mode




#### NOTICE!

To cause a device to exit RFSS mode, remove the device's batteries and re-insert them. Devices automatically exit RFSS mode after 10 min of inactivity.

### 3.2 Establishing the Wireless Network and Configuring Wireless Devices

In order for the wireless network to operate properly, the following process must occur as shown below.



### 3.2.1 Discover a New System

Discovery is the process through which the wireless hub identifies and includes new (undiscovered) devices into the system.

**NOTICE!**

You can only perform the new system discovery process once. To update an existing wireless system, refer to *Section 3.3 Wireless Maintenance*, Page 31.

There are two ways to start the discovery process on a new system: point test, and the Wireless Configuration Menu: Point Test and the Wireless Configuration Menu.

**Point Test**

The device discovery process automatically starts at the beginning of the Point Test.

To start a point test from the System Test Button:

1. Ensure that all devices have exited RFSS Mode, including the wLSN Hub. Ensure the wLSN Hub is in normal operating mode (LED is on steady).
2. Press the System Test button for one second.

To start a point test from the Phone Menu:

From the Installer Menu of a phone session (refer to *Section 2.7.2 Initiate a Phone Session from the Control Panel*, Page 22):

- Press [1], and then press [2] to select Full System Test.

**OR**

- Press [1], and then press [3] to select System Test Menu. From the System Test Menu, press [5] to select Point Test.

**Wireless Configuration Menu**

1. Enter the Installer Menu of a phone session (refer to *Section 2.7.2 Initiate a Phone Session from the Control Panel*, Page 22).
2. Press [1][6] to select System Maintenance Wireless Configuration. The device discovery process automatically starts.

### 3.2.2 Establish and Configure the Wireless Network

The wLSN Hub automatically establishes and configures the wireless network.

The wLSN Hub evaluates each available radio frequency (RF) for noise, RF signal strength, and other adjacent wireless systems. The wLSN Hub then selects the frequency with the lowest amount of noise and least amount of traffic for network operation.

To configure the wireless network, the wLSN Hub selects the best channel for broadcasting. Once a channel is selected, the wLSN Hub then configures all discovered devices to operate on the selected frequency. This process takes several minutes.

### 3.2.3 Configure Devices

#### Input and Output Devices

**NOTICE!**

The ISW-BMC1-S135X Door/Window Contact and the ISW-BIN1-S135X Inertia Detector have a magnetic switch as an input. If the magnetic switch is not used, remove the magnet from the device before starting the Point Test.

Once the network is established and configured, the system announces "Test all points." Test the wireless devices in this order: input devices, output devices, and relay modules.

**NOTICE!**

Do not exit the Point Test until all intended wireless devices are tested. Otherwise, you must manually add devices to the system.

If extra wireless devices not intended for installation are within the wireless hub's range, the wLSN Hub might also discover these devices. To exclude any unused devices from the system, press [#] (or [5] from the control center) to exit the Point Test. The wLSN Hub returns all unused devices to the undiscovered state.

When you restore the device, the system announces the assigned device number.

**Test Devices**

Point numbers are assigned to wireless devices in the order that the devices first communicate to the system (tampered, faulted, low battery). If specific point numbers are preferred for wireless devices, ensure that the wireless devices communicate in the appropriate order. Otherwise, the system assigns the lowest available point number to the first tested wireless device. With motion detectors, unmask only the detector you want to test. Refer to *Table 2.6* on Page 24 for wLSN device testing instructions.

**Key Fobs**

1. After the last wireless device is configured and the Point Test ends, press [#] repeatedly until you exit the Installer Menu and end the phone session.
2. Start a new phone session, or press and hold [3] on the control center, and enter the master user (User 1) passcode.
3. Press [4] [1].
4. Enter a passcode, and then re-enter the passcode.
5. Press [4] to add a key fob. Token assignment and voice description are optional.
6. Repeat Steps 4 to 7 to add more users and key fobs, or press [#] repeatedly to end the phone session.

To create a key fob-only system (no wireless input or output devices installed), start at Step 2. In a key fob-only system, adding the first key fob might take several minutes to complete as the wireless network is established and configured. Subsequent key fob additions take less time.

## 3.3 Wireless Maintenance

### 3.3.1 Wireless Configuration Menu

Use the Wireless Configuration Menu to:

- Add new wireless devices to an existing wireless system
- Add wireless devices that were not discovered when the wireless network was first discovered
- Replace or delete wireless devices from an existing wireless system

To access the Wireless Configuration menu from the Installer Menu of a phone session (refer to *Section 2.7.2 Initiate a Phone Session from the Control Panel, Page 22*), press [1] [6] for Wireless Configuration.

Menu options are only available after the initial device discovery and point test is completed.

| Button Press | Menu Option                                   | Description  |
|--------------|---|--|
| [1]          | Replace a Device                              | Use this option to replace a known device with a new device. <ul style="list-style-type: none"> <li>- Press [1] to replace a point, or [3] to replace an output. For a relay module, select either the input or output, and then enter the appropriate number in Step 2.</li> <li>- Enter the desired point number or output number. The device discovery process starts.</li> <li>- When the system announces "Test all points," activate the new device. The new device replaces the current device. If other devices were discovered in Step 2, they are returned to the undiscovered state.</li> </ul>                                 |
| [2]          | Add a Device                                  | Use this option to add more devices to the wireless network. When you press [2] to select this option, the device discovery process starts. When the system announces "Test all points," activate all of the new devices. If other devices were discovered but not activated, they are returned to the undiscovered state.   |
| [3]          | Delete a Device                               | Use this option to delete a known device from the system: <ul style="list-style-type: none"> <li>- Press [1] to delete a point, or [3] to delete an output.</li> <li>- Enter the desired point number or output number. If the selected point number corresponds with a relay module, both the input and output are deleted from the system. If you only want to delete the input or the output, you must disable the corresponding function through programming.</li> <li>- Press [1] to delete the device. The wireless hub deletes the device from the system, and the point type or output function is set to 0 (Disabled).</li> </ul> |
| [4]          | Transfer Wireless Data (control panel-to-hub) | If you replace a hub, select this option to send wireless data from the control panel to the wireless hub.   |
| [5]          | Transfer Wireless Data (hub-to-control panel) | If you replace the control panel, select this option to send wireless data from the wireless hub to the control panel. This option deletes key fobs.   |

| Button Press | Menu Option                 | Description   |
|--------------|-----------------------------|---|
| [6]          | Erase and Discover          | If the wireless data in the control panel does not match the wireless data in the hub (Bus Device Trouble 50), use this option to erase the wireless data in both the control panel and hub, and rediscover all devices.<br>This option is only available if the wireless data does not match in the control panel and hub. |
| [#]          | Exit Wireless Configuration | Select this option to return to the System Maintenance options.   |

**Table 3.2** Wireless Configuration Menu Options

### 3.3.2 Assigning Points 1 to 8 as Wireless Points

To assign an on-board point (1 to 8) as a wireless point, disable the point in programming before starting the device discovery process. You can individually assign Points 1 to 8 as wireless points.

### 3.3.3 Recovering the Wireless Network

Expert Programming Item Number 9999 restores the control panel to its factory default settings. All wireless network data in the control panel is lost, but is retained in the wireless hub.

To recover wireless network data from the wireless hub:

1. From the Installer Menu of a phone session (refer to *Section 2.7.2 Initiate a Phone Session from the Control Panel*, Page 22), press [1] to select System Maintenance.
2. Press [6][5] to transfer wireless data from the hub to the control panel.  
This option deletes key fob assignments. You must reassign all key fobs.

### 3.3.4 Wireless System Messages

Refer to the following table for a description of system messages that pertain to the wireless network.

| System Message                     | Description  |
|------------------------------------|--|
| "Wireless devices not configured." | Point Test was exited before all wireless points were tested.  |
| "Extra device ignored."            | An attempt was made to add a device to a system that already contains the maximum number of points or outputs.   |
| "Point x was tested."              | A point was tested. RFSS is acceptable.  |
| "Point x low."                     | A point was tested. RFSS is unacceptable.  |
| "Please wait."                     | The wireless network is busy, or the control panel is waiting for the wireless network to respond. The control center might show a single rotating segment of the circle of protection with this message.          |
| "Wireless error."                  | The wireless hub is jammed, missing, or experiencing a trouble condition.  |
| "Wireless devices x."              | "x" = the number of devices that are discovered, but not tested.   |
| "Wireless devices not tested x."   | "x" = the number of devices that are discovered, but not yet configured.   |
| "Point x not tested."              | The control panel assigned a point number to the device, but the device was not tested (faulted, or tampered, and restored).<br>"x" = the voice description.<br>By default, the system announces the point number. |

**Table 3.3** Wireless System Messages



## 4 Programming Access Options

You can access the system to make programming changes using:

- The Phone Menu
- Remote Programming Software (RPS)
- A Programming Key (using programming copied from a control panel previously programmed using the Phone Menu or RPS)

### 4.1 System Access by Phone



**NOTICE!**

Once you configure a control panel using the Phone Menus, you can copy the programming from the control panel to a programming key for use on another control panel, or for backup. Refer to *Section 4.3 Programming Keys*, page 36.

The Installer Phone Menu and User Phone Menu provide access to system functions such as testing the system, programming the system, and adding or changing users.

The Installer Phone Menu requires the installer passcode.

The User Phone Menu requires either the master user (User 1) passcode for full menu access, or a user passcode for limited menu access.

If the passcode length = four digits:

- The default installer passcode is 5432
- The default master user passcode is 1234

If the passcode length = six digits:

- The default installer passcode is 543211
- The default master user passcode is 123455

To access the system menus, select one of the options shown in *Table 4.1, Page 33*.

| Options                 | Steps   |
|-------------------------|---|
| House Phone             | <ul style="list-style-type: none"> <li>- Press [#][#][#].</li> <li>- Listen for the voice prompt to enter a passcode.</li> <li>- Enter the installer passcode to access the installer menu, or a user passcode to access the user menu.</li> </ul>  |
| Outside Phones          | <ul style="list-style-type: none"> <li>- Call the premises phone number.</li> <li>- After the call is answered by a person or by a telephone answering device, press [*][*][*] to disconnect the answering party and access the system.</li> <li>- Listen for the voice prompt to enter a passcode.</li> </ul> <p>If the phone is not answered by a person or telephone answering device, the system answers after a programmed number of rings. Refer to Expert Programming Item Number 222 listed in on <i>Section Route Destination Items</i>, page 47.</p> <ul style="list-style-type: none"> <li>- Enter the installer passcode to access the installer menu, or a user passcode to access the user menu.</li> </ul> |
| Installer Quick Connect | <p>Select this option if a phone line is not available, or a local connection is required. The system must be off to use this option.</p> <ul style="list-style-type: none"> <li>- Connect a phone set to the test posts or to the phone terminals.</li> <li>- Press and hold the System Test button for approximately 15 sec.</li> <li>- Listen for the voice prompt to enter a passcode.</li> <li>- Enter the installer passcode to access the Installer Menu, or a user passcode to access the User Menu.</li> </ul>   |

**Table 4.1** Phone System Access Options

**NOTICE!**

For an overview of the Installer Phone Menu and User Phone Menu, refer to *Section 1.3 Phone Menus*, page 10.

For detailed Phone Menu programming options, refer to *Section 5 Programming*, page 37.

**4.2****RPS**

RPS (Remote Programming Software) is a Windows-based account management and control panel programming utility designed to remotely set up and program specific control panels. You can use RPS to program the control panel from a laptop or PC that is on-site or off-site from the control panel.

For complete installation and operation instructions, refer to the *RPS Installation and Operation Guide* (P/N: 4998141259) that is available on the RPS CD-ROM.

**NOTICE!**

Once you configure a control panel using RPS, you can copy the programming from the control panel to a programming key for use on another control panel, or for backup. Refer to *Section 4.3 Programming Keys*, page 36.

**4.2.1****RPS Connection Methods**

You connect to the Easy Series Control Panel to make changes interactively.

To connect RPS to the control panel:

1. Open the control panel account by double-clicking the account, or select the account and click **Open**.
2. Click **Connect**. The **Panel Communication** window opens.
3. Select a connection method from the **Connect Via** menu that best meets the system's needs for remote programming. Refer to the following sections for descriptions of each connection method.

**Automatic**

This option is the primary method to use for establishing a connection between RPS and the control panel.

Connect the internal modem on the RPS PC, or an external modem, to the control panel.

**Manual Dial**

1. Either the installer or RPS operator establishes a phone connection between the control panel and RPS:
  - The installer dials the RPS phone number using the house phone, or connects a test telephone to the control panel's test posts,

**OR**

- From the RPS site, the RPS operator uses a telephone connected in parallel to the RPS modem and manually dials the house phone number.
2. The RPS operator selects **Manual Dial** as the connection option on the RPS Panel Communication window.
  3. To answer the incoming call, the RPS operator clicks the **Connect** button on the RPS Panel Communication window to establish a remote connection between RPS and the control panel.

**Modem Dial**


The RPS operator uses a telephone connected in parallel to the RPS modem and clicks the **Connect To** button in the RPS Panel Communication Window to dial the premises phone number.

1. Connect the internal modem on the RPS PC, or an external modem, to the control panel.
2. When the control panel answers the incoming call, the system announces "Enter your passcode."
3. When you hear the control panel modem tones, press the **Connect To** button on the RPS Panel Communication window. RPS then sends the DTMF tone to connect to the control panel.

**Direct Connect**

Select this method to establish a local, on-site connection between the RPS PC (or laptop) and the control panel.

1. On the Telco side of the phone line, ensure that Tip and Ring are disconnected.
2. Connect the internal modem on the RPS PC, or an external modem, to the control panel. Refer to *Figure 4.1*, Page 35.



**Figure 4.1** Modem Connections

|   |  |
|---|--|
| 1 | Connection using internal modem                                  |
| 2 | Connection using external modem                                  |
| 3 | 270 Ω to 330 Ω, ¼ W resistor (for Direct Connection option only) |

3. If the first communication attempt fails, connect a 270 Ω to 330 Ω, ¼ W resistor in series with the Tip House side. Refer to *Figure 4.1*, Page 35.


**Network**

Select this method to establish a network connection between the RPS PC (or laptop) and the control panel using the ITS-DX4020-G or the DX4020.

### 4.3 Programming Keys

After you program a control panel using the Phone Menus or RPS, you can use a programming key to transfer data from that control panel to another control panel. You can also use a programming key to back up control panel data.

1. If the system is on, turn it off.
2. Place the key's lock switch in the desired position. Refer to *Figure 4.2*.



**Figure 4.2** Programming Key Lock Positions

|   |                                     |
|---|-------------------------------------|
| 1 | Send data from control panel to key |
| 2 | Send data from key to control panel |

3. Insert the key into the control panel board.
  - **Auto Transfer:** If Expert Programming Item Number 123 = 1 (refer to Programming Key Auto Transfer in *Section 5.2.2 System Programming Items*, page 43), the programming key automatically transfers data depending on the position of the lock switch.
  - **Manual Transfer:** If Expert Programming Item Number 123 = 0, you must use the Installer Menu to access the programming key.  
The control center announces when data transfer is completed.
4. When the (✓) LED flashes green, data transfer is successful.  
If the (✓) LED flashes red, the data transfer is unsuccessful. Remove and reinstall the key.

## 5 Programming

| Method             | Description  |
|--------------------|--|
| Basic Programming  | Basic Programming consists of a voice menu that contains the essential programming items. Generally, finishing this programming section is usually all that is required for a complete system. |
| Expert Programming | Expert Programming allows access to all programming categories for full system configuration. Only use expert programming if you have a special programming requirement.                       |

**Table 5.1** System Programming Methods



**NOTICE!**

You can program control panels using the remote programming software RPS. Like Expert Programming, RPS allows access to all programming categories. For more information on RPS and how to use a programming key to streamline a multiple-panel install, refer to *Section 4 Programming Access Options*, page 33.




**NOTICE!**

For additional instructions and information for select programming items, refer to *Section 11 Programming Details and Defaults*, page 102. For country code specific defaults for programming items, refer to *Section 11.3 Country Code Specific Default Programming Codes*, page 108.

## 5.1 Basic Programming

### 5.1.1 Enter Basic Programming


1. Select a system access option. Refer to *Section 4.1 System Access by Phone*, Page 33.
2. Enter the installer passcode to enter the Installer Phone Menu. Refer to *Section 2.7 Configure the System from the Installer Phone Menu*, page 22.
3. Press [3] to enter Basic Programming. Refer to the figure below for the Basic Programming Menu options.



### 5.1.2 Points

|               |   |   |  |
|---------------|---|---|--|
| <b>Points</b> | Enter a point number from 1 to 32.  |   |  |
| <b>1</b>      | <p><b>Record Point Description</b><br/>                 For example, if Point 1 is located at the building's front door, say "Front Door" at the tone.<br/> <b>When recording your description, do not press any buttons on your phone until prompted.</b><br/>                 Press [1] to continue programming the selected point.<br/>                 Press [2] to re-record your current point description.</p> |   |  |
| <b>2</b>      | <p><b>Set Point Type</b> (Refer to <i>Point Type</i> table)<br/>                 Press [1] to select the current option.<br/>                 Press [2] to hear more options.<br/>                 Press [#] to exit Point Type.</p>  | <p><b>Point Types:</b></p> <ul style="list-style-type: none"> <li>- Disabled</li> <li>- Perimeter (Entry or Exit)</li> <li>- Interior (Follower)</li> <li>- Perimeter Instant</li> <li>- 24-Hour</li> <li>- Fire Verified</li> <li>- Fire Verified</li> <li>- Fire Instant</li> </ul> | <p><b>Point Types (cont.):</b></p> <ul style="list-style-type: none"> <li>- Silent Panic</li> <li>- Interior Walkthrough</li> <li>- Perimeter Exit Cancel</li> <li>- Momentary Keyswitch</li> <li>- Maintained Keyswitch</li> <li>- 24-Hour Trouble</li> <li>- User Emergency</li> </ul> |
| #             | <p><b>Exit Points</b><br/>                 Return to the Installer Menu.</p>  |   |  |

### 5.1.3 Report Configuration



| Account Number Entries   |            | Phone Number/IP Address Entries |                     |
|--|------------|---------------------------------|---------------------|
| Entry  | Key Press  | Entry                           | Key Press           |
| 0 to 9   | [0] to [9] | 0 to 9                          | [0] to [9]          |
| B  | [*][1]     | *                               | [*][*]              |
| C  | [*][2]     | #                               | [*][#]              |
| D  | [*][3]     | .                               | [*] <sup>1</sup>    |
| E  | [*][4]     | Pause                           | [#]                 |
| F  | [*][5]     | Exit with Save                  | [#][#] <sup>2</sup> |
|  |            | Disable phone number            | [0][#]              |
|  |            | Disable IP address              | 240.0.0.0           |
| <sup>1</sup> [*] = . between each IP address notation.<br><sup>2</sup> Press [#] twice within two seconds to exit without saving your entry. |            |                                 |                     |

**Table 5.2** Account Number and Phone Number/IP Address Entries



### 5.1.4 Outputs

Output devices consist of horns, bells, strobes, or sirens.

|                |  |   |  |
|----------------|--|---|--|
| <b>Outputs</b> | Enter an output number from 1 to 8   |   |  |
| <b>1</b>       | <p><b>Set Output Function</b></p> <ul style="list-style-type: none"> <li>- Press [1] to select the current option.</li> <li>- Press [2] to hear more options.</li> <li>- Press [#] to exit Output Function.</li> </ul> | <p><b>Output Functions:</b></p> <ul style="list-style-type: none"> <li>- Disabled</li> <li>- Intrusion</li> <li>- Intrusion Latching</li> <li>- Fire</li> <li>- Fire Latching</li> <li>- Intrusion and Fire</li> <li>- Intrusion and Fire Latching</li> <li>- System Reset</li> </ul> | <p><b>Output Functions (cont.):</b></p> <ul style="list-style-type: none"> <li>- System On</li> <li>- System Ready</li> <li>- Key Fob On/Off</li> <li>- Key Fob 2-sec Pulse</li> <li>- User Controlled</li> <li>- Interior Intrusion and Fire</li> <li>- System On (Unoccupied)</li> </ul> |
| <b>#</b>       | <p><b>Exit Points</b><br/>Return to Installer Menu.</p>  |   |  |

**NOTICE!**



When the installer PIN is entered at the keypad or phone, a 3 sec time window starts. During that time window, a tamper alarm activates the interior siren for only 1 sec. Open the enclosure door during this time to silence the sirens during maintenance. Once the enclosure is closed, tamper alarm is restored after a 3 min delay. Tamperers are logged and reported.

**WARNING!**




If you modify system parameters you are responsible for maintaining the system within the scope of the standard and regulations that apply to the hardware and/or the system in which it is used. In a NF A2P compliant installation, use only NF A2P listed components, and check that each parameter is in the authorized range.

## 5.2 Expert Programming

Each category consists of several related programming items. Each programming item is assigned a three- or four-digit number.

For No. 4 in the next figure, perform these steps:

1. Enter an expert programming item number. For example, 201, Phone Line Supervision.
2. Enter the desired value using your phone's keypad. For example, press [1] to enable phone line supervision.
3. Repeat Steps 1 and 2 to configure other programming items, or press [#] to exit Expert Programming.



The following sections list programming items, item numbers, possible selections, and default values. Record custom values in the Entry column next to the respective default value.

### 5.2.1 ROM Firmware Version Items

| Programming Item                  | Item Number | Description   |
|-----------------------------------|-------------|---|
| Control Panel Firmware Version    | 090         | System announces the control panel's firmware version.  |
| Control Center 1 Firmware Version | 091         | System announces the control center's firmware version. |
| Control Center 2 Firmware Version | 092         |   |
| Control Center 3 Firmware Version | 093         |   |
| Control Center 4 Firmware Version | 094         |   |

### 5.2.2 System Programming Items

| Programming Item                                   | Item Number | Selections   | Manuf. Default |
|--|-------------|--|----------------|
| Country Code (refer to Section 11.2 Country Codes) | 102         | 00 to 65   | 58             |
| Enclosure Tamper Enabled                           | 103         | 0 = Disabled<br>1 = Enabled  | 1              |
| Fire Bell Cut-Off Time                             | 107         | 0 to 90 min  | 5              |
| Intrusion Bell-Cut off Time                        | 108         | 0 to 90 min  | 5              |
| Intrusion Abort Window                             | 110         | 15 to 45 sec   | 30             |
| Fire Alarm Cancel Window                           | 111         | 0 to 10 min  | 0              |
| Intrusion Cancel Window                            | 112         | 5 to 10 min  | 5              |
| Chime Tone Select                                  | 114         | 1 = Chime door bell<br>2 = Single chime<br>3 = Standard door bell  | 1              |
| Chime Mode Operation After System Off              | 115         | 0 = Off<br>1 = On<br>2 = Follows previous setting  | 0              |
| Automatic Test Report Frequency                    | 116         | 0 = None<br>1 = Daily<br>2 = Weekly<br>3 = Monthly   | 0              |
| Access Code  | 119         | 6 digits, using 0 to 9   | 999999         |
| Daylight Saving Time Operation                     | 121         | 0 = None<br>1 = North America (before 2007)<br>2 = Europe and Asia<br>3 = Tasmania, Australia<br>4 = Rest of Australia<br>5 = New Zealand<br>6 = Cuba<br>7 = South America and Antarctica<br>8 = Namibia, Africa<br>9 = USA after 2006 | 1              |
| Installer Passcode Override Enabled                | 122         | 0 = Disabled<br>1 = Enabled  | 1              |

| Programming Item                    | Item Number | Selections   | Manuf. Default |
|-------------------------------------|-------------|--|----------------|
| Programming Key Auto Transfer       | 123         | 0 = Enable the programming key from the Installer Menu.<br>1 = Programming key automatically sends or receives stored programming data.  | 1              |
| Point Alarm Verification            | 124         | 0 = None<br>1 = Cross zone<br>2 = Intelligent threat assessment<br>3 = Confirmed alarms 1<br>4 = Confirmed alarms 2  | 0              |
| Faulted Points Allowed Threshold    | 125         | 0 to 8   | 3              |
| Exit Delay                          | 126         | 45 to 255 sec  | 60             |
| Entry Delay                         | 127         | 30 to 255 sec  | 30             |
| Exit Time Restart                   | 128         | 0 = User cannot reset Exit Delay timer<br>1 = User can reset Exit Delay timer one time   | 1              |
| Recent Close Enabled                | 129         | 0 = Report not sent<br>1 = Report sent   | 1              |
| Swinger Bypass Count                | 131         | 0-15   | 1              |
| Auto Protection Level               | 132         | 0 = System turns on (unoccupied).<br>1 = System only turns on (unoccupied) if a perimeter point is faulted during Exit Delay.  | 1              |
| System On Order Options             | 133         | 1 = "Stay," "Leave," "Custom"<br>2 = "Stay," "Custom," "Leave"<br>3 = "Leave," "Stay," "Custom"<br>4 = "Leave," "Custom," "Stay"<br>5 = "Custom," "Leave," "Stay"<br>6 = "Custom," "Stay," "Leave";            | 1              |
| Cross Zone Timer                    | 134         | 60 to 3600 sec   | 120            |
| Clear Alarm Memory                  | 136         | 0 = By user, 1 = By master user  | 0              |
| Latching Point and Enclosure Tamper | 137         | 0 = Any user can clear condition<br>1 = Only the installer can clear condition   | 0              |
| Latching System Device Tamper       | 138         | 0 = Any user can clear condition<br>1 = Only the installer can clear condition   | 0              |
| Verbose System Test Enabled         | 139         | 0 = Test results announced only at end of all tests<br>1 = Test results announced after each test  | 1              |
| Demo Mode                           | 140         | 0 = Telephone messages heard only on phone<br>1 = Telephone messages heard on phone and control centers<br>2 = Turn announcement of telephone messages over the control center on or off at the control center | 0              |
| Restrict Installer Passcode         | 142         | 0 = Master user not needed<br>1 = Master user needed   | 0              |
| Test Report Hour                    | 143         | 0 to 23  |                |
| Test Report Minute                  | 144         | 0 to 59  | 0              |
| Test Report Day of Week             | 145         | 0 to 6, where 0 = Sunday and 6 = Saturday  | 0              |

| Programming Item                    | Item Number | Selections   | Manuf. Default |
|-------------------------------------|-------------|--|----------------|
| Test Report Day of Month            | 146         | 1 to 28  | 1              |
| Clear Confirmed Alarm Memory        | 147         | 0 = User can clear a confirmed alarm<br>1 = Only the installer can clear a confirmed alarm   | 0              |
| Arming Beeps/Graduated Annunciation | 148         | 0 = No arming beeps or outputs during Entry Delay<br>1 = Outputs activate during Entry Delay, but no arming beeps occur.<br>2 = Sound arming beeps, but outputs do not activate during Entry Delay<br>3 = Sound arming beeps, and outputs activate during Entry Delay  | 0              |
| Wireless Jam Detect Level           | 150         | 0 to 15  | 12             |
| Key Fob Arming                      | 153         | 0 = Do not turn system on if there are faulted points<br>1 = Force arm faulted points if the number of faulted points is within the range set in Expert Programming Item Number 125<br>2 = Force arm faulted points even if the number of faulted points exceeds the range set in Expert Programming Item Number 125 | 0              |
| Two-Way Voice Session Configuration | 158         | 0 = Allow at any time<br>1 = Allow only during alarm conditions  | 0              |
| Start Arming with Faulted Points    | 159         | 0 = Force arm all faulted points<br>1 = Exit Delay starts with faulted points  | 1              |
| Speak Active Faults                 | 160         | 0 = "Call for Service" announced<br>1 = Fault condition announced  | 0              |
| Wireless Transmission Attenuation   | 161         | Temporary attenuation for installation and maintenance only. Not intended for normal operation.<br>0 = None (normal operation)<br>1 = 3 dB<br>2 = 6 dB<br>3 = 9 dB<br>4 = 12 dB  | 0              |
| Missing Wireless Device Conditions  | 162         | 0 = Creates a tamper condition (required for EN50131-compliant countries).<br>1 = Creates a trouble condition.   | 0              |
| Silence Trouble Tones               | 163         | 0 = All trouble tones announced<br>1 = Fire and 24-Hour trouble tones announced  | 0              |
| System Inactivity Time (Hours)      | 164         | 0 to 255   | 0              |
| System Inactivity Time (Days)       | 165         | 0 to 255   | 0              |
| System Inactivity Time (Weeks)      | 166         | 0 to 255   | 0              |
| Force Arm/Exit Error                | 167         | 0 = Off-normal points create an Exit Error at the end of Exit Delay<br>1 = Off-normal points are force armed at the end of Exit Delay  | 0              |

| Programming Item  | Item Number | Selections   | Manuf. Default |
|---|-------------|--|----------------|
| Audio Verification Command Set  | 168         | 0 = Complies with SIA AV-01-1997.11<br>1 = Use alternate verification command set                    |                |
| Key Fob Duress  | 601         | 0 = Duress event disabled<br>1 = Duress event enabled  | 0              |
| Key Fob Button Configuration  | 616         | 0 = Status request only<br>1 = Turn system on (occupied)   | 0              |
| Key Fob Button Configuration  | 626         | 2 = Turn system on (custom protection)<br>3 = Turn output on or off<br>4 = Turn output on for 2 sec. | 0              |
| Default = Country-specific default. Select this programming item to hear the updated default value, or refer to <i>Section 11.3 Country Code Specific Default Programming Codes</i> , page 108. |             |  |                |

## 5.2.3 Communicator Programming Items



### NOTICE!

To enable reporting, configure the following programming items:

- Account Number (Expert Programming Item Number 100)
- Route 1 Primary Destination (Expert Programming Item Number 206)
- Format for Route 1 Primary Destination (Expert Programming Item Number 211)

### Route Destination Items

| Programming Item                       | Item Number | Selections   | Manuf. Default |
|--|-------------|--|----------------|
| Account Number                         | 100         | 4 or 6 digits, using 0 to 9 and B to F.<br>Refer to <i>Table 5.2</i> , Page 40 for account number, phone number, and IP address entry instructions.  | 000000         |
| Phone Line Supervision                 | 201         | 0 = Unsupervised.<br>1 = Supervised.   | 0              |
| PSTN or GSM Connection                 | 202         | 0 = PSTN telephone line<br>1 = ITS-DX4020-G Wireless Phone using GSM   |                |
| Voice Format Repeat Count              | 203         | 1 to 15  | 3              |
| Voice Format Message Delivery Attempts | 204         | 1 to 5 in increments of 5 sec  | 1              |
| Dial Tone Detect                       | 205         | 0 = Do not wait for dial tone.<br>1 = Wait for dial tone.  | 1              |
| Route 1 Primary Destination            | 206         | Enter a phone number (up to 32 digits) or IP address (000.000.000.000 to 255.255.255.255) for each destination:<br>0 to 9 = [0] to [9]<br>* = [*][*]<br># = [*][#]<br>Pause = [*][1]<br>Exit with save = [#]<br>Exit without save = [#][#]<br>Press [#] twice within two seconds to exit without saving your entry.<br>Disable phone number = [0][#]<br>Disable IP address = 240.0.0.0 | 0              |
| Route 1 Backup Destination             | 207         |  | 0              |
| Route 2 Primary Destination            | 208         |  | 0              |
| Route 2 Backup Destination             | 209         |  | 0              |
| SMS Service Provider Number            | 210         | Up to 32 digits.   | 0              |
| Format for Route 1 Primary Destination | 211         | 0 = Disabled<br>1 = Contact ID<br>2 = SIA<br>3 = Voice<br>4 = SMS Text<br>5 = Fast Format<br>6 = Network (requires a 4-digit account number)   | 0              |
| Format for Route 1 Backup Destination  | 212         |  | 0              |
| Format for Route 2 Primary Destination | 213         |  | 0              |
| Format for Route 2 Backup Destination  | 214         |  | 0              |
| Call Waiting Disable                   | 215         | Enter a 3-digit string.<br>* = [*][*]; # = [*][#]  | 0              |
| Emergency Call Override Number         | 216         | Enter a 3-digit emergency number, such as 911.   | 000            |
| Emergency Call Override Number Delay   | 217         | 0 to 60 min  | 5              |

| Programming Item  | Item Number | Selections   | Manuf. Default |
|---|-------------|--|----------------|
| Auto Detect Pulse Dial  | 218         | 0 = Tone dialing only<br>1 = Auto Detect Pulse or Tone     | 0              |
| Phone Answer Ring Count   | 222         | 1 to 255 rings<br>Enter 11 to bypass an answering machine. | 10             |
| Bell Test   | 223         | 0 = Disabled<br>1 = Enabled                                | 0              |
| Default = Country-specific default. Select this programming item to hear the updated default value, or refer to <i>Section 11.3 Country Code Specific Default Programming Codes</i> , page 108. |             |  |                |

#### Alternate Communication Items

| Programming Item   | Item Number | Selections                     | Manuf. Default |
|--|-------------|--------------------------------|----------------|
| Port Number for Route Destination:<br>Route 1 Primary = 241<br>Route 1 Backup = 242<br>Route 2 Primary = 243<br>Route 2 Backup = 244           | 241         | 0 to 65535                     | 7700           |
|  | 242         |                                | 7700           |
|  | 243         |                                | 7700           |
|  | 244         |                                | 7700           |
| Heartbeat for Route Destination:<br>Route 1 Primary = 281<br>Route 1 Backup = 282<br>Route 2 Primary = 283<br>Route 2 Backup = 284             | 281         | 0 = Disabled<br>1 to 65535 min | 0              |
|  | 282         |                                | 0              |
|  | 283         |                                | 0              |
|  | 284         |                                | 0              |
| Acknowledge Wait Time for Route Destination<br>Route 1 Primary = 285<br>Route 1 Backup = 286<br>Route 2 Primary = 2887<br>Route 2 Backup = 288 | 285         | 5 to 255 sec                   | 15             |
|  | 286         |                                | 15             |
|  | 287         |                                | 15             |
|  | 288         |                                | 15             |
| Anti-Replay for Route Destination:<br>Route 1 Primary = 289<br>Route 1 Backup = 290<br>Route 2 Primary = 291<br>Route 2 Backup = 292           | 289         | 0 = Disabled<br>1 = Enabled    | 1              |
|  | 290         |                                | 1              |
|  | 291         |                                | 1              |
|  | 292         |                                | 1              |
| Heartbeat Attempt for Route Destination:<br>Route 1 Primary = 293<br>Route 1 Backup = 294<br>Route 2 Primary = 295<br>Route 2 Backup = 296     | 293         | 1 to 99                        | 5              |
|  | 294         |                                | 5              |
|  | 295         |                                | 5              |
|  | 296         |                                | 5              |
| Extend Heartbeat Period  | 297         | 0 = Disabled<br>1 to 255 min   |                |



### 5.2.4 RPS Configuration Items

| Programming Item                          | Item Number | Selections   | Manuf. Default |
|---|-------------|--|----------------|
| RPS Passcode                              | 118         | 6 digits, using 0 to 9 and A to F.   | 123456         |
| RPS Automatic Call In Frequency           | 224         | 0 = Never<br>1 = Daily<br>2 = Weekly<br>3 = Monthly  |                |
| RPS Automatic Call In Time (Hours)        | 225         | 0 to 23  |                |
| RPS Automatic Call in Time (Minutes)      | 226         | 0 to 59  |                |
| RPS Automatic Call in Time (Day of Week)  | 227         | 0 to 6, where 0 = Sunday and 6 = Saturday  |                |
| RPS Automatic Call in Time (Day of Month) | 228         | 1 to 28  |                |
| RPS Automatic Call in Phone Number        | 229         | Enter a phone number (up to 32 digits) or IP address (000.000.000.000 to 255.255.255.255) for each destination:<br>0 to 9 = [0] to [9]<br>* = [*][*]<br># = [*][#]<br>Pause = [*][1]<br>Exit with save = [#]<br>Exit without save = [#][#]<br>Press [#] twice within two seconds to exit without saving your entry.<br>Disable phone number = [0][#]<br>Disable IP address = 240.0.0.0 |                |
| RPS Automatic Call in Method              | 245         | 0 = Phone number<br>1 = IP address   |                |
| RPS Port Number                           | 246         | 0 to 65535   | 7750           |

## 5.2.5 Route Reporting Options

### Point Report and Restoral Routing

| Programming Item                   | Item Number | Manuf. Default | Programming Item                    | Item Number | Manuf. Default |
|------------------------------------|-------------|----------------|-------------------------------------|-------------|----------------|
| Point Reports and Restorals (all)* | 301         | 3              | Fire Trouble                        | 328         | 3              |
| Intrusion Alarm                    | 307         | 3              | Fire Trouble Restoral               | 329         | 3              |
| Intrusion Alarm Verified           | 308         | 3              | 24-Hour Trouble                     | 331         | 3              |
| Intrusion Alarm Unverified         | 309         | 3              | 24-Hour Trouble Restoral            | 332         | 3              |
| Intrusion Alarm 24-hr              | 310         | 3              | Point Missing                       | 333         | 3              |
| Intrusion Alarm 24-hr Restoral     | 311         |                | Point Missing Restoral              | 334         | 3              |
| Intrusion Alarm Restoral           | 312         | 3              | Supervisory Alarm                   | 335         | 3              |
| Duress                             | 313         | 3              | Supervisory Alarm Restoral          | 336         | 3              |
| Fire Alarm                         | 315         | 3              | Wireless Point Low Battery          | 360         | 3              |
| Fire Alarm Unverified              | 316         | 3              | Wireless Point Low Battery Restoral | 361         | 3              |
| Fire Alarm Restoral                | 317         | 3              | Fire Cancel                         | 371         | 3              |
| Panic                              | 318         | 3              | Point Tamper                        | 388         | 3              |
| Cancel                             | 323         | 3              | Point Tamper Restoral               | 397         | 3              |
| Intrusion Trouble                  | 324         | 3              | Cross Zone Trouble                  | 393         | 3              |
| Intrusion Trouble Restoral         | 325         | 3              | Alarm Recent Close                  | 394         | 3              |
| Intrusion Zone Bypass              | 326         | 3              | Panic Restoral                      | 399         | 3              |
| Intrusion Zone Bypass Restoral     | 327         | 3              | Cross Zone Trouble Restoral         | 400         | 3              |

\*Enter a value to globally set all of the following reports to the same value.  
To modify one a specific report, enter a value in that report's item number:  
0 = Neither route  
1 = Route 1 only; Primary and Backup  
2 = Route 2 only; Primary and Backup  
3 = Both routes; Primary and Backup

### System On and Off Report Routing

| Programming Item                                     | Item Number | Manuf. Default | Programming Item          | Item Number | Manuf. Default |
|--|-------------|----------------|---------------------------|-------------|----------------|
| System On and Off*<br>(open and close) Reports (all) | 302         | 3              | Open                      | 341         | 3              |
| Exit Error   | 314         | 3              | Open Keyswitch            | 342         | 3              |
| Recent Closing                                       | 330         | 3              | Open Remote               | 343         | 3              |
| Close (System On) Unoccupied                         | 337         | 3              | Close (System On) Custom  | 344         | 3              |
| Close (System On) Occupied                           | 338         | 3              | Opening by Guard Code     | 386         | 3              |
| Close Keyswitch                                      | 339         | 3              | Partial Close (System On) | 403         | 3              |
| Close Remote   | 340         | 3              |                           |             | 3              |

\*Enter a value to globally set all of the following reports to the same value.  
To modify only a specific report, enter a value in that report's item number.  
0 = Neither route  
1 = Route 1 only; Primary and Backup  
2 = Route 2 only; Primary and Backup  
3 = Both routes; Primary and Backup

### System Report and Restoral Routing

| Programming Item                                | Item Number | Manuf. Default | Programming Item                    | Item Number | Manuf. Default |
|---|-------------|----------------|-------------------------------------|-------------|----------------|
| System Reports and Restorals (all) <sup>1</sup> | 303         | 3              | Communication Restoral              | 352         | 3              |
| User Emergency <sup>2</sup>                     | 319         | 3              | Control Center Supervision Fail     | 353         | 3              |
| User Fire <sup>3</sup>                          | 320         | 3              | Control Center Supervision Restoral | 354         | 3              |
| User Fire Restoral                              | 321         | 3              | Control Center Tamper               | 355         | 3              |
| User Panic                                      | 322         | 3              | Control Center Tamper Restoral      | 356         | 3              |
| AC Fail   | 345         | 3              | System Inactive                     | 385         | 3              |
| AC Fail Restoral                                | 346         | 3              | Watchdog Reset                      | 390         | 3              |
| Auto System Test Normal                         | 347         | 3              | Passcode Tamper                     | 391         | 3              |
| Auto System Test Off-Normal                     | 348         | 3              | Date/Time Changed                   | 410         | 3              |
| Auxiliary Power Fault                           | 349         | 3              | Network Fail                        | 413         | 3              |
| Auxiliary Power Restoral                        | 350         | 3              | Network Restoral                    | 414         | 3              |
| Communication Fail                              | 351         | 3              |                                     |             | 3              |
| Local Programming Success*                      | 357         | 3              | Bus Device Trouble                  | 373         | 3              |
| Low Battery                                     | 358         | 3              | Bus Device Trouble Restoral         | 374         | 3              |
| Low Battery Restoral                            | 359         | 3              | ROM Fault                           | 375         | 3              |
| Communication Test, Manual                      | 362         | 3              | Bell Trouble                        | 376         | 3              |
| Phone Line Fault                                | 363         | 3              | Bell Restoral                       | 377         | 3              |
| Phone Line Fault Restoral                       | 364         | 3              | Walk Test End                       | 378         | 3              |
| Remote Programming Failure                      | 365         | 3              | Walk Test Start                     | 379         | 3              |
| Remote Programming Success                      | 366         | 3              | Bus Device Missing                  | 380         | 3              |
| Wireless Receiver Jammed                        | 367         | 3              | Bus Device Missing Restoral         | 381         | 3              |
| Wireless Receiver Jammed Restoral               | 368         | 3              | Battery Missing                     | 382         | 3              |
| Bus Device Tamper                               | 369         | 3              | Battery Missing Restoral            | 383         | 3              |
| Bus Device Tamper Restoral                      | 370         | 3              | RAM Checksum Failed                 | 384         | 3              |

<sup>1</sup> Enter a value to globally set all of the following reports to the same entry.

<sup>2</sup> To modify only a specific report, enter a value in that report's item number.

0 = Neither route

1 = Route 1 only; Primary and Backup

2 = Route 2 only; Primary and Backup

3 = Both routes; Primary and Backup

<sup>3</sup>To enable the control center's emergency buttons, set Expert Programming Items 889, 888, and 890.

### Global Report Routing Items

| Programming Item              | Item Number | Selections   | Manuf. Default |
|-------------------------------|-------------|--|----------------|
| Communicator Disable          | 304         | 0 = Enable reporting<br>1 = Disable reporting (local-only system)    | 0              |
| Route Attempts                | 305         | 1 to 20  | 10             |
| Send Reports During Walk Test | 306         | 0 = No reports<br>1 = Only Walk Test Start and Walk Test End reports | 0              |

Default = Country-specific default. Select this programming item to hear the updated default value, or refer to *Section 11.3 Country Code Specific Default Programming Codes*, page 108.

### 5.2.6 Point Programming Items

| Programming Item Number<br>(bold digits = Point Number)              | Programming Item             | Selections   |
|--|------------------------------|--|
| <b>9011, 9021, 9031, 9041...</b><br><b>9101...9151...9201...9321</b> | Point Type                   | 0 = Disabled<br>1 = Perimeter<br>2 = Interior<br>3 = Perimeter Instant<br>4 = 24-Hour<br>5 = Fire Verified*<br>6 = Fire Instant<br>7 = Silent Panic<br>8 = Interior Walkthrough<br>9 = Perimeter Exit Cancel<br>11 = Momentary Keyswitch<br>12 = Maintained Keyswitch<br>13 = 24-Hour Trouble<br>14 = User Emergency |
| <b>9012, 9022, 9032, 9042...</b><br><b>9102...9152...9202...9322</b> | Circuit Style                | 0 = Dual 2.2 k $\Omega$ alarm and tamper circuit<br>2 = Single 2.2 k $\Omega$ alarm circuit  |
| <b>9013, 9023, 9033, 9043...</b><br><b>9103...9153...9203...9323</b> | Include in Custom Protection | 0 = Point not included<br>1 = Point included   |
| <b>9014, 9024, 9034, 9044...</b><br><b>9104...9154...9204...9324</b> | Cross Zone/Exit Route        | 0 = Cross zoning disabled, point is on the exit route.<br>1 = Cross zoning enabled, point is on the exit route<br>2 = Cross zoning disabled, point is <b>not</b> on the exit route (must force arm).<br>3 = Cross zoning enabled, point is <b>not</b> on the exit route.   |
| <b>9015, 9025, 9035, 9045...</b><br><b>9105...9155...9205...9325</b> | Response Time                | 1 to 10 in 50 ms increments  |

| Programming Item Number<br>(bold digits = Point Number) | Programming Item              | Selections  |
|---|-------------------------------|---|
| 9016, 9026, 9036, 9046...<br>9101...9151...9201...9321  | Alarm Verification            | 0 = Disable alarm verification<br>1 = Enable alarm verification   |
| 9018, 9028, 9038, 9048...<br>9108...9158...9208...9328  | Wireless Detector Sensitivity | <b>Motion Detector (PIR and dual)</b><br>0 = Standard<br>4 = Intermediate<br><b>Inertia Detector: Gross Attack Options</b><br>0 = Tap off, low sensitivity<br>1 = Tap off, low/medium sensitivity<br>2 = Tap off, medium/high sensitivity<br>3 = Tap off, high sensitivity<br><b>Inertia Detector: Minor Attack Options</b><br>8 = Tap on, 8 taps, low sensitivity<br>9 = Tap on, 8 taps, low/medium sensitivity<br>10 = Tap on, 8 taps, medium/high sensitivity<br>11 = Tap on, 8 taps, high sensitivity<br>12 = Tap on, 4 taps, low sensitivity<br>13 = Tap on, 4 taps, low/medium sensitivity<br>14 = Tap on, 4 taps, medium/high sensitivity<br>15 = Tap on, 4 taps, high sensitivity |

|   |
|---|
| <b>Point Type (9011 ... 9321):</b> Point 1 = 6, Points 2 - 5 = 1, Points 6 - 8 = 2, Points 9 - 32 = 0 |
| <b>Circuit Style (9012 ... 9322):</b> Points 1 - 32 = 2   |
| <b>Custom Protection (9013 ... 9323):</b> Points 1 - 32 = 0   |
| <b>Cross Zone Enabled (9021 ... 9321):</b> 1  |
| <b>Response Time (9015 ... 9085):</b> Points 1 - 8 only = 6   |
| <b>Wireless Sensitivity (9018 ... 9328):</b> Points 1 - 32 = 0  |
| <b>Alarm Verification (9016 ... 9326):</b> Points 1 - 32 = 0  |

**Table 5.3** Manuf. Default for Point Programming Items

## 5.2.7 Output Programming Items

| Programming Item  | Item Number | Selections  | Manuf. Default |
|---|-------------|---|----------------|
| Fire Output Cadence   | 600         | 0 = Temporal Code 3 cadence<br>1 = Pulse cadence<br>(two-sec on, two-sec off)   | 0              |
| Output 1 Function (wired)   | 611         | 0 = Disabled<br>1 = Intrusion<br>2 = Intrusion Latching<br>3 = Fire<br>4 = Fire Latching<br>5 = Intrusion and Fire<br>6 = Intrusion and Fire Latching<br>7 = System Reset<br>8 = System On<br>9 = System Ready<br>10 = Key Fob On/Off<br>11 = Key Fob 2-sec Pulse<br>13 = User Controlled<br>14 = Interior Intrusion and Fire<br>15 = System On (Unoccupied)<br>16 = Intrusion and Fire 2 | 5              |
| Output 2 Function (wired)   | 621         |   | 5              |
| Output 3 Function (wired)   | 631         |   | 5              |
| Output 4 Function (wired)   | 641         |   | 7              |
| Output 5 Function (wireless)  | 651         |   | 5              |
| Output 6 Function (wireless)  | 661         |   | 0              |
| Output 7 Function (wireless)  | 671         |   | 0              |
| Output 8 Function (wireless)  | 681         |   | 0              |
| Output 4 Supervised Speaker Driver (wired)  | 642         | 0 = Supervised 8 $\Omega$ speaker driver<br>1 = Unsupervised open collector   | 0              |
| Default = Country-specific default. Select this programming item to hear the updated default value, or refer to <i>Section 11.3 Country Code Specific Default Programming Codes</i> , page 108. |             |   |                |



### NOTICE!

When programming a wireless output (for example, a siren or relay module), do not select an output function that requires the output to activate for an extended period (for example System Ready).

## 5.2.8 Control Center Programming Items

### Speech Configuration Items

| Programming Item                    | Item Number | Selections   | Manuf. Default |
|-------------------------------------|-------------|--|----------------|
| Alarm Message Minimum Repeat Time   | 880         | (1 to 255 hrs).  | 12             |
| "No Alarm Report Sent" Announcement | 883         | 0 = Announcement disabled.<br>1 = Announcement enabled.                                  | 1              |
| "Cancel Report Sent" Announcement   | 884         |  | 1              |
| Time Format                         | 887         | 0 = Determined by voice module<br>1 = Always use 12-hr mode<br>2 = Always use 24-hr mode | 0              |

### Global Control Center Items

These programming items affect all control centers connected to the control panel.

To send a user fire, emergency (medical) or panic report, the appropriate control center button and report must be enabled. Refer to *Section 5.2.5 Route Reporting Options* on Page 50 to enable reports.

Check the appropriate box in the Easy Series User Guide (P/N: F01U0xxxxx) to identify which buttons are enabled.

| Programming Item               | Item Number | Selections   | Manuf. Default |
|--------------------------------|-------------|--|----------------|
| Fire Button Alarm              | 888         | 0 = Disabled.<br>1 = Enabled.  | 0              |
| Medical Button Alarm           | 889         | 0 = Disabled.<br>1 = Enabled   | 0              |
| Panic Button Alarm             | 890         | 0 = Disabled.<br>1 = Enabled (audible).<br>2 = Enabled (silent).                               | 0              |
| One Button Arming<br>[i]       | 891         | 0 = Disabled (token or passcode required).<br>1 = Enabled (token or passcode is not required). | 0              |
| Invalid Passcode Attempt Limit | 892         | 3 to 8.  | 3              |
| Control Center Lockout Time    | 893         | 1 to 30 min.   | 3              |

### Individual Control Center Items

| Programming Item  | Item Number           | Selections  | Manuf. Default      |
|---|-----------------------|---|---------------------|
| Control Center Brightness   | Control Center 1: 811 | 1 (dim) to 5 (bright).  | Control Center 1: 5 |
|   | Control Center 2: 821 |   | Control Center 2: 5 |
|   | Control Center 3: 831 |   | Control Center 3: 5 |
|   | Control Center 4: 841 |   | Control Center 4: 5 |
| Control Center Backlight Extinguish Mode  | Control Center 1: 814 | 0 = Always on.<br>1 = Dim until user presence is detected.<br>2 = Off until user presence is detected.<br>3 = Off until user presents token or enters passcode. | Control Center 1: 0 |
|   | Control Center 2: 824 |   | Control Center 2: 0 |
|   | Control Center 3: 834 |   | Control Center 3: 0 |
|   | Control Center 4: 844 |   | Control Center 4: 0 |
| Default = Country-specific default. Select this programming item to hear the updated default value, or refer to <i>Section 11.3 Country Code Specific Default Programming Codes</i> , page 108. |                       |   |                     |

### 5.2.9 User Programming Items

| Programming Item  | Item Number | Selections  | Manuf. Default |
|---|-------------|---|----------------|
| Passcode Length   | 861         | Set the length of all passcodes (4 or 6 digits).  | 4              |
| Installer Passcode (User 0)   | 7001        | Four-digit Range: 1111 to 5555<br>Six-digit Range: 111111 to 555555   | 5432           |
| Master User Passcode (User 1)   | 7011        |   | 1234<br>123455 |
| Duress User (User 22) Enabled   | 862         | 0 = Duress user disabled<br>1 = Duress user enabled<br>2 = Guard code enabled<br>Duress User passcode:<br>Six digits: 111111<br>Four digits: 1111 | 0              |
| RFID Token Password   | 863         | Use this item to prevent unauthorized copying of tokens (00000000 to FFFFFFFF).   | 123456<br>78   |
| Default = Country-specific default. Select this programming item to hear the updated default value, or refer to <i>Section 11.3 Country Code Specific Default Programming Codes</i> , page 108. |             |   |                |



#### CAUTION!

Do not change the RFID Token Passwords item once tokens are added to the system.



### 5.2.10 Factory Default

| Programming Item | Item Number | Selections  |
|------------------|-------------|---|
| Factory Default  | 9999        | Enter 9999 to restore all factory default values. All programming items, except for the country code, are reset when you restore the factory default values. This item also deletes all wireless data, but does not default the wireless hub. |

**WARNING!**

For NF A2P installations, once the panel is configured, check that all parameters are within the range of authorized values. Refer to *Section 12.7 EN50131 Requirements*, page 119.

## 5.3 Exit Programming

Press [#] repeatedly until the system says "goodbye." This ends the phone session.

## 6 Control Panel Event Codes (SIA and Contact ID)

| Event                               | SIA | Report                          | Contact ID | Report                                     |
|-------------------------------------|-----|---------------------------------|------------|--|
| Intrusion Alarm                     | BA  | Burglary Alarm                  | 1 130      | Burglary                                   |
| Intrusion Alarm Verified            | BV  | Burglary Alarm Verified         | 1 139      | Burglary                                   |
| Intrusion Alarm Unverified          | BG  | Unverified Event Burglary       | 1 130      | Burglary                                   |
| Intrusion Alarm 24-hr               | BA  | Burglary Alarm                  | 1 133      | 24 Hour (Safe)                             |
| Intrusion Alarm 24-hr Restoral      | BH  | Burglary Alarm Restore          | 3 133      | Restoral                                   |
| Intrusion Alarm Restoral            | BR  | Burglary Restoral               | 3 130      | Burglary                                   |
| Duress                              | HA  | Hold Up Alarm                   | 1 121      | Duress                                     |
| Exit Error                          | EA  | Exit Alarm                      | 1 374      | Exit Error (zone)                          |
| Fire Alarm                          | FA  | Fire Alarm                      | 1 110      | Fire                                       |
| Fire Alarm Unverified               | FG  | Unverified Event-Fire           | 1 110      | Fire                                       |
| Fire Alarm Restoral                 | FH  | Fire Alarm Restore              | 3 110      | Fire                                       |
| Panic                               | HA  | Holdup Alarm                    | 1 120      | Panic                                      |
| Panic Restoral                      | HH  | Holdup Alarm Restore            | 3 120      | Panic                                      |
| User Emergency (Medical)            | QA  | Emergency Alarm                 | 1 101      | Personal Emergency                         |
| User Fire                           | FA  | Fire Alarm                      | 1 110      | Fire                                       |
| User Fire Restoral                  | FH  | Fire Alarm Restore              | 3 110      | Fire                                       |
| User Panic                          | HA  | Holdup Alarm                    | 1 120      | Panic                                      |
| Cancel                              | BC  | Burglary Cancel                 | 1 406      | Cancel                                     |
| Intrusion Trouble                   | BT  | Burglary Trouble                | 1 380      | Sensor Trouble                             |
| Intrusion Trouble Restoral          | BJ  | Burglary Trouble Restore        | 3 380      | Sensor Trouble                             |
| Intrusion Point Bypass              | BB  | Burglary Bypass                 | 1 570      | Zone/Sensor bypass                         |
| Intrusion Point Bypass Restoral     | BU  | Burglary Unbypass               | 3 570      | Zone/Sensor bypass                         |
| Fire Trouble                        | FT  | Fire Trouble                    | 1 373      | Fire Trouble                               |
| Fire Trouble Restoral               | FJ  | Fire Trouble Restore            | 3 373      | Fire Trouble                               |
| Recent Closing                      | CR  | Recent Closing                  | 1 459      | Recent Closing                             |
| Close (System On) Unoccupied        | CL  | Closing Report                  | 3 401      | Unoccupied Arm by User                     |
| Close (System On) Occupied          | CL  | Closing Report                  | 3 441      | Occupied Arm by User                       |
| Close (System On) Custom            | CL  | Closing Report                  | 3 441      | Custom Arm by User                         |
| Close (System On) Partial           | CL  | Closing Report                  | 3 456      | Partial Arm by User                        |
| Close (System On) Keyswitch         | CS  | Closing Keyswitch (User 255)    | 3 409      | Keypad O/C (User 255)                      |
| Open (System Off)                   | OP  | Opening Report                  | 1 401      | O/C by User                                |
| Open (System Off) Keyswitch         | OS  | Opening Keyswitch (User 255)    | 1 409      | Keypad O/C (User 255)                      |
| AC Fail                             | AT  | AC Trouble                      | 1 301      | AC Loss                                    |
| AC Fail Restoral                    | AR  | AC Restoral                     | 3 301      | AC Loss                                    |
| Auto System Test (Normal)           | RP  | Automatic Test                  | 1 602      | Period Test Report (User 0)                |
| Auto System Test (Off-Normal)       | RY  | Test Off Normal                 | 1 608      | Period Test Report, System Trouble Present |
| Auxiliary Power Fault               | IA  | Equipment Failure Condition     | 1 310      | Ground Fault                               |
| Auxiliary Power Restoral            | IR  | Equipment Fail Restoral         | 3 310      | Ground Fault                               |
| Communication Fail                  | YC  | Communications Fail             | 3 310      | Failure to communicate event               |
| Communication Restoral              | YK  | Communications Restoral         | 3 354      | Failure to communicate event               |
| Control Center Supervision Fail     | EM  | Expansion Device Missing        | 1 333      | Expansion module failure                   |
| Control Center Supervision Restoral | EN  | Expansion Missing Restore       | 3 333      | Sensor Trouble                             |
| Control Center Tamper               | ES  | Expansion Device Tamper         | 1 341      | Expansion Device Tamper                    |
| Control Center Tamper Restoral      | EJ  | Expansion Device Tamper Restore | 3 341      | Expansion Device Tamper                    |
| Local Programming                   | LX  | Local Programming Ended         | 1 628      | Program mode exit                          |
| Low Battery                         | YT  | System Battery Trouble          | 1 302      | Low System Battery                         |
| Low Battery Restoral                | YR  | System Battery Restoral         | 3 302      | Low System Battery                         |
| Communication Test                  | RX  | Manual Test                     | 1 601      | Manual trigger test report                 |
| Phone Line Fault                    | LT  | Phone Line Trouble              | 1 351      | Telco 1 fault                              |

| Event                               | SIA | Report                       | Contact ID | Report                     |
|-------------------------------------|-----|------------------------------|------------|----------------------------|
| Phone Line Fault Restoral           | LR  | Phone Line Restoral          | 3 351      | Telco 1 fault              |
| ROM Fault                           | YF  | Parameter Checksum Fail      | 1 304      | ROM Checksum Bad           |
| Bell Trouble                        | YA  | Bell Fault                   | 1 320      | Sounder/ Relay             |
| Bell Restoral                       | YH  | Bell Restored                | 3 320      | Sounder/ Relay             |
| Walk Test Start                     | TS  | Test Start                   | 1 607      | Walk Test Mode             |
| Walk Test End                       | TE  | Test End                     | 3 607      | Walk Test Mode             |
| Bus Device Missing                  | EM  | Expansion Device Missing     | 1 333      | Exp. Module Failure        |
| Bus Device Missing Restoral         | EN  | Expansion Missing Restore    | 3 333      | Exp. Module Failure        |
| Battery Missing                     | YM  | System Battery Missing       | 1 311      | Battery Missing/Dead       |
| Battery Missing Restoral            | YR  | System Battery Restoral      | 3 311      | Battery Missing/Dead       |
| RAM Checksum Failed                 | YF  | Parameter Checksum Fail      | 1 303      | RAM Checksum bad           |
| Point Tamper                        | TA  | Tamper Alarm                 | 1 137      | Tamper                     |
| Point Tamper Restoral               | TH  | Tamper Alarm Restoral        | 3 137      | Tamper Restoral            |
| Cross Zone Trouble                  | BG  | Unverified Event - Burglary  | 1 378      | Cross-zone Trouble         |
| Cross Zone Trouble Restoral         | BR  | Burglary Restoral            | 3 378      | Cross-zone Trouble         |
| Point Missing                       | UY  | Untyped Missing Trouble      | 1 381      | Loss of Supervision - RF   |
| Point Missing Restoral              | UJ  | Untyped Trouble Restore      | 3 381      | Loss of Supervision - RF   |
| Wireless Point Low Battery          | XT  | Transmitter Battery Trouble  | 1 384      | RF Low Battery             |
| Wireless Point Low Battery Restoral | XR  | Transmitter Battery Restoral | 3 384      | RF Low Battery             |
| Wireless Receiver Jammed            | XQ  | RF Interference              | 1 344      | RF Receiver Jam Detect     |
| Wireless Receiver Jammed Restoral   | XH  | RF Interference Restoral     | 3 344      | RF Receiver Jam Detect     |
| Bus Device Tamper                   | XS  | RF Receiver Tamper           | 1 341      | Exp Module Tamper          |
| Bus Device Tamper Restoral          | XJ  | RF Receiver Tamper Restoral  | 3 341      | Exp Module Tamper          |
| Bus Device Trouble                  | ET  | Expansion Trouble            | 1 330      | System Peripheral Trouble  |
| Bus Device Trouble Restoral         | ER  | Expansion Restoral           | 3 330      | System Peripheral Trouble  |
| Remote Programming Success          | RS  | Remote Program Success       | 1 628      | Program mode exit          |
| Remote Programming Failure          | RU  | Remote Program Fail          | 1 628      | Program mode exit          |
| 24-Hour Trouble                     | UA  | Untyped Zone Alarm           | 1 150      | 24-Hour Non-Burglary       |
| 24-Hour Trouble Restoral            | UR  | Untyped Zone Restoral        | 3 150      | 24-Hour Non-Burglary       |
| Opening by Guard Code               | OR  | Disarm From Alarm            | 1 450      | Exception Open/Close       |
| System Inactive                     | CI  | Fail to Close                | 1 454      | Failed to Close            |
| Network Fail                        | NT  | Network Failure              | 1 350      | Communication Trouble      |
| Network Restoral                    | NR  | Network Restoral             | 3 350      | Communication Trouble      |
| Passcode Tamper                     | JA  | User Code Tamper             | 1 461      | Wrong Code Entry           |
| Firmware Updated                    | YZ  | Service Completed            | 1 412      | Successful Download/Access |
| Watchdog Reset                      | YW  | Watchdog Reset               | 1 305      | System Reset               |
| Date/Time Change                    | JT  | Time Changed                 | 1 625      | Time/Date Reset            |

## 7 Default the System

### 7.1 Default the Control Panel and the wLSN Hub

To restore the control panel to its factory settings, including programming data, and erase the wireless network:

1. Remove all power to the system.
2. Remove the wLSN Hub from its base. Refer to *Figure 1.1*, Page 6.
3. Record the current switch settings, then set the switches as follows: **S1** = 9, **S2** = 8, **S3** = 7. Refer to *Figure 1.1*, Page 6.
4. Reconnect the wLSN Hub to the base.
5. Reapply all power to the system.
6. Wait for the green LED on the wLSN Hub to turn on and then off (approximately 5 sec).
7. Remove all power to the system.
8. Disconnect the wLSN Hub from the base again, and reset the switches to their previous settings. **Do not** reconnect the wLSN Hub to the base yet.
9. Reapply all power to the system.
10. Default the control panel from the Installer Menu of a phone session (*Section 2.7.2 Initiate a Phone Session from the Control Panel*, Page 22), press [4] to select Expert Programming.
11. Press [9][9][9][9] to restore all factory default values.
12. Remove all power to the system.
13. Reconnect the wLSN Hub to the base.
14. Reapply all power to the system.
15. Default all wLSN devices.

### 7.2 Default wLSN Devices

Defaulting a wLSN device returns it to an undiscovered state.

To default a wLSN device:

1. Remove the batteries.
2. Press and hold the tamper switch.
3. Reinsert the batteries while holding the tamper switch.  
Continue to hold the tamper switch for at least 3 sec. The device's LED turns on.
4. Release the tamper switch within 5 sec. after the device's LED turns on.  
The device's LED briefly turns off and then on, indicating that the device was returned to an undiscovered state.

For specific instructions for defaulting each wLSN device, refer to the *wLSN Reference Guide* (P/N F01U009440).

## 8 System Test and Maintenance

### 8.1 Test the System

Test the system for proper operation when installation and configuration are complete.

1. Press the System Test button on the control panel board for one sec. The system provides instructions throughout the test. Follow all instructions.
2. Contact the central monitoring station (CMS) to verify that all necessary test reports were received, including test reports from all installed input and output devices.

### 8.2 Maintain the System

Bosch Security Systems, Inc. recommends testing the system regularly, and inspecting it according to local code or law.

### 8.3 Installer History Event Announcements

The Installer Menu (refer to *Section 2.7 Configure the System from the Installer Phone Menu*, page 22), speaks the event report status for each event.

After the event entry and its parameters (if any) are spoken, the system will beep and then speak the status using two numbers. The first number indicates the route 1 event status. The second number indicates the route 2 event status.

The numbers in each announcement indicate the status as follows:

- 0 = The event was logged only
- 1 = The event was successfully transmitted for this route
- 2 = The transmission of this event failed for this route
- 3 = The event is still pending for this route

Refer to the following table for a history event announcement example.

| Entry        | Event     | Tone | Route 1 Status | Route 2 Status |
|--------------|-----------|------|----------------|----------------|
| Announcement | “AC Fail” | Beep | “One”          | “Zero”         |

### 8.4 Event Messages

The following table shows:

- Non-standard event messages that appear in the history log, and
- Event messages for SMS Text and Voice formats


| Event            | History Log Entry   | SMS Text Format            | Voice Format  |
|------------------|---|----------------------------|---|
| Tamper Enclosure | Tamper 0  | Point Trouble 0            | Tamper 0  |
| Duress           | Duress; System Off User 22  | Intrusion Alarm System Off | Duress System Off User 22   |
| Quick Arm        | System On Occupied User System On Unoccupied User 0 System On Custom User 0 | System On User 0           | System On Occupied User 0 System On Unoccupied User 0 System On Custom User 0 |
| Keyswitch On     | System On Unoccupied 255  | System On User 255         | System On Unoccupied 255  |
| Keyswitch Off    | System Off 255  | System Off User 255        | System Off 255  |
| Recent Close     | Recent Close User X   | Intrusion Alarm            | Recent Close User X   |

## 9 ITS-DX4020-G Communicator Configuration

### 9.1 ITS-DX4020-G Communicator Overview

The ITS-DX4020-G provides wireless communications between the control panel and the central monitoring station (CMS). You can configure the ITS-DX4020-G using one of two methods:

- Short Message Service (SMS)
- Terminal Interface on a PC connected using a USB port



**Figure 9.1** ITS-DX4020-G Communicator

|   |                                |    |                                    |
|---|--------------------------------|----|------------------------------------|
| 1 | Mini USB Port                  | 8  | Signal Strength 1 (SS1) LED        |
| 2 | Antenna Connector              | 9  | Signal strength 2 (SS2) LED        |
| 3 | CONFIG MODE (J200) Jumper Pins | 10 | Signal strength 2 (SS2) LED        |
| 4 | LED DIS (J201) Jumper Pins     | 11 | Bus LED                            |
| 5 | STATUS LED                     | 12 | SIM Cardholder                     |
| 6 | CELL IP LED                    | 13 | SIM Card In Cardholder (Door Open) |
| 7 | AUDIO ACT LED                  |    |                                    |



#### NOTICE!

To conserve power, install the LED disabling jumper to the LED DIS jumper pins when the LEDs are not being observed.

When LED DIS jumper pins are shorted for the first time, the STATUS LED flashes the firmware version.

## 9.2 Short Message Service (SMS) Configuration

The ITS-DX4020-G supports configuration by SMS. The installer can send the SMS via mobile phone to the ITS-DX4020-G. To ensure delivery of SMS data, keep each message to a maximum of 160 characters in length with a maximum of 3 messages. The CONFIG MODE jumper pins must be shorted together with a plug to allow the receipt of SMS data. Refer to *Table 2.9, Page 26*, for LED activity. If the CONFIG MODE jumper pins are not shorted together, incoming SMS data is discarded. If the shorting plug is removed from the CONFIG MODE jumper pins before the ITS-DX4020-G receives the complete set of incoming SMS data, all incoming SMS data is discarded.

When the ITS-DX4020-G receives a complete set of incoming SMS data, it saves the values and then displays a distinct pattern across the on-board LEDs indicating that the values were saved (refer to *Table 2.9, Page 26* for LED locations). At this time, remove the plug from the CONFIG jumper pins to restart the ITS-DX4020-G. The ITS-DX4020-G does not send out SMS data. *Table 9.1* shows the typical SMS format. Refer to *Table 9.6, Page 69*, and *Table 9.7, Page 69*, for descriptions of each parameter ID in the SMS format.

| Format  | Character  | Description   |
|---|------------|---|
| %SMS sequence number<LF><br><id> = <value><LF><br><id> = <value><LF><br><id> = <value><LF><br>! | <LF>       | If there are multiple SMS messages, the SMS sequence number indicates the order of the messages and identifies the starting point for the parameter IDs in each message.<br>Separate each id/value pair with a line feed (<LF>), carriage return (<CR>), or semi-colon (;).<br>To allow spanning of configuration across multiple messages, each SMS starts with the sequence number followed by the line feed character. |
|   | id=<value> | id/value pairs program each parameter on the ITS-DX4020-G. id/value pairs are not split between multiple SMS parts. If an SMS message contains id/value pairs with duplicate content, only the value in the last duplicated pair is used.   |
|   | !          | The final part of a single (or multi-) SMS configuration has an exclamation mark at the end.  |

**Table 9.1** ITS-DX4020-G SMS Format



**NOTICE!**

To reduce message size, configuration items are designated with numbers, and only the configuration items that must be changed are sent.

The configuration SMS string consists of a maximum of three SMS messages. When the ITS-DX4020-G receives the final valid part of an SMS message, it accepts the configuration. The communicator waits as long as the CONFIG jumper is on. When the CONFIG jumper is removed, all incomplete configurations will be deleted.

*Table 9.2* shows an example of a single SMS message.

| SMS Line No.                             | Description                   | Sample SMS   |
|--|-------------------------------|--|
| %1<LF>                                   | SMS sequence number           | %1<br>1=4020G<br>2=secret123<br>3=123456,4343<br>10=basic.m2m<br>11=user@telco.com<br>12=password<br>15=1<br>16=010203040506070809010111213141516<br>14=134<br>! |
| 1=4020G<LF>                              | Current password              |  |
| 2=secret123<LF>                          | New password (case sensitive) |  |
| 3=123456,4343<LF>                        | PUK and new PIN to set in SIM |  |
| 10=basic.m2m<LF>                         | APN                           |  |
| 11=user@telco.com<LF>                    | GPRS username                 |  |
| 12=password<LF>                          | GPRS password                 |  |
| 15=1<LF>                                 | Enable AES encryption         |  |
| 16=010203040506070809010111213141516<LF> | Sample AES key                |  |
| 14=134<LF>                               | Option bus address            |  |
| !  | End of configuration          |  |

**Table 9.2** Single SMS Example

*Table 9.3 and Table 9.4 show an example of a double SMS message split into two parts.*

| SMS Line No.                             | Description                   | Sample SMS  |
|--|-------------------------------|---|
| %1<LF>                                   | SMS sequence number           | %1<br>1=4020G<br>2=secret123<br>3=123456,4343<br>10=basic.m2m<br>11=user@telco.com<br>12=password<br>15=1<br>16=010203040506070809010111213141516 |
| 1=4020G<LF>                              | Current password              |   |
| 2=secret123<LF>                          | New password (case sensitive) |   |
| 3=123456,4343<LF>                        | PUK and new PIN to set in SIM |   |
| 10=basic.m2m<LF>                         | APN                           |   |
| 11=user@telco.com<LF>                    | GPRS username                 |   |
| 12=password<LF>                          | GPRS password                 |   |
| 15=1<LF>                                 | Enable AES encryption         |   |
| 16=010203040506070809010111213141516<LF> | Sample AES key                |   |

**Table 9.3** Double SMS Example, Part 1

| SMS Line No. | Description          | Sample SMS        |
|--------------|----------------------|-------------------|
| %2<LF>       | SMS sequence number  | %2<br>14=134<br>! |
| 14=134<LF>   | Option bus address   |                   |
| !            | End of configuration |                   |

**Table 9.4** Double SMS Example, Part 2



## 9.3 Accessing the User Interface and Logging On Using USB

### 9.3.1 Downloading the ITS-DX4020-G USB Driver

Before you can access the USB user interface, you must download and install the **ITS-DX4020-G.inf** file on the target PC or laptop. You only need to install this file once on the target PC or laptop.

1. From your Internet browser, go to <http://www.boschsecurity.us/en-us/> to open the US Bosch web site.
2. Under **Online Catalogs**, click **Intrusion Alarm Systems**.
3. Under **Download Library**, click **Software**.
4. Under **Software**, click **Intrusion Alarm Systems**.
5. Under **Intrusion Alarm Systems**, click **Conettix - Information Transport Solutions**.
6. To the right of **ITS-DX4020-G.INF**, click **EN**.

The **File Download** window opens.




Figure 9.2 File Download Window

7. Click **Save** to save the file to the target PC or laptop.

### 9.3.2 Installing the ITS-DX4020-G USB Driver

If the target PC or laptop only has one USB port, you only need to install the USB driver once. If the target PC or laptop has multiple USB ports, you must install the USB driver each time the ITS-DX4020-G is connected to a new USB port.


1. Ensure that the supplied jumper plug is covering the CONFIG jumpers. Refer to *Figure 9.1*, Page 62, *Callout 3*.
2. Supply power to the ITS-DX4020-G (12 VDC) and connect it to the target PC or laptop, using a USB-to-mini-USB (5-pin mini-B connector) cable (not supplied).

The **Found New Hardware Wizard** opens.



Figure 9.3 Found New Hardware Wizard

3. Select **Install from a list or specific location (Advanced)**, and click **Next**.  
The **Search and Installation Options** window opens.



**Figure 9.4** Search and Installation Options Window

4. Under **Search for the best driver in these locations**, click the **Include this location in the search** option, and then click **Browse**.  
The **Browse for Folder** window opens.



**Figure 9.5** Browse For Folder Window

5. In the file directory, go to the location where you saved the **ITS-DX4020-G.inf** file.  
Click **OK** and then click **Next**.  
The **Found New Hardware Finish** window opens.



**Figure 9.6** Found New Hardware Finish Window

6. Click **Finish** to complete the installation of the ITS-DX4020-G USB driver.

### 9.3.3 USB Main Menu

1. From Windows, start a terminal session (launch Hyper Terminal if you are running Windows XP or earlier, or download Tera Term if you are running Windows Vista). Set up a connection on the new virtual serial COM port using the following settings:
  - **Bit rate:** 9600
  - **Data bits:** 8
  - **Parity:** None
  - **Stop bits:** 1
  - **Flow control:** None
2. Press [Enter].  
The ITS-DX4020-G USB login screen opens.




Figure 9.7 ITS-DX4020-G USB Login Screen

3. Enter a valid password to log on. The default password is **4020G** (all uppercase). The user interface allows three attempts to correctly enter the password. After three failed attempts, you must reset the ITS-DX4020-G by removing the jumper plug from the CONFIG jumpers.
4. Press [Enter] to continue. The USB main menu opens.



Figure 9.8 ITS-DX4020-G USB Main Menu

The USB main menu appears:

- after successfully entering a password
- every time the user presses [Enter] without first selecting an option from the main screen
- on returning from a sub-screen

The main menu shows all current configuration settings first. An asterisk in front of a configuration item indicates that its setting has been changed during the current session. The content of the main menu constantly scrolls. When a user performs a new action, any resulting response from the user interface appears at the end of the menu.

### 9.3.4 USB Option Menu

Refer to *Table 9.5* for a description of the USB option menu items.

To see the USB option menu, refer to *Figure 9.8*, Page 67.

| Option                       | Press to Select | Description  |
|------------------------------|-----------------|--|
| 1 Change password            | 1               | To change the login password, enter the old password first, and then enter the new password twice. The second entry is to confirm the new password.<br>Passwords must be 4-15 characters long, and they are case-sensitive. 0-9, A-Z, a-z, and special characters are allowed. |
| 2 Change log level           | 2               | Change the debugging level shown on the View Log screen.   |
| 3 View log                   | 3               | View the debugging log. Press any key to exit.   |
| 4 Exit without Save          | 4               | Return to the user interface login screen. All configuration changes that were made are lost and are replaced with the default values.   |
| 5 Restore Factory defaults   | 5               | Select <b>Yes</b> to restore all factory default configurations.<br>When prompted, remove the plug from the CONFIG jumper pins to restart the ITS-DX4020-G.  |
| 6 Save and Reboot            | 6               | Select <b>Yes</b> to save all configuration changes.<br>When prompted, remove the plug from the CONFIG jumper pins to restart the ITS-DX4020-G.  |
| 7 Upgrade Software           | 7               | Select this option to upgrade the software in the ITS-DX4020-G.<br>Refer to <i>Section 9.4 Upgrading the ITS-DX4020-G Software</i> , page 70.  |
| 8 Change Basic parameters    | 8               | To change a basic parameter:<br>1. Select the parameter.<br>2. Enter the desired value and press [Enter].<br>Refer to <i>Table 9.6</i> , Page 69 for basic parameters.   |
| 9 Change Advanced parameters | 9               | Select to change advanced parameters.<br>Refer to <i>Table 9.7</i> , Page 69 for advanced parameters.  |

**Table 9.5** ITS-DX4020-G Menu Options

At a configuration screen, items are presented one at a time with the current value inside [ ] brackets. If you press [Enter] without entering a new value, the current value is unchanged.

To go to a specific menu option, enter the appropriate menu item number and press [Enter].

| ID | Parameter          | Default | Values                                      | Description   |
|----|--------------------|---------|---|---|
| 1  | Current Password   | 4020G   | 4 to 15 characters                          | Mandatory and case sensitive.   |
| 2  | New Password       | none    | 4 to 15 characters                          | New password, as desired. Case sensitive  |
| 3  | SIM PUK,PIN        | none    | Maximum 10 numeric digits each              | Sets the PIN into the SIM and the ITS-DX4020-G  |
| 4  | SIM PIN            | No PIN  | 4 numeric digits                            | Sets the PIN in the ITS-DX4020-G.   |
| 10 | GPRS APN           | <blank> | 1 to 63 characters                          | Access point name.  |
| 11 | GPRS username      | none    | 1 to 63 characters                          | Username for wireless service provider (not always required).   |
| 12 | GPRS password      | none    | 1 to 63 characters                          | Password for wireless service provider (not always required).   |
| 13 | Src port           | 7700    | 1 to 65535 characters                       | Sets the port for the ITS-DX4020-G.   |
| 14 | Bus Address        | 134     | SDI: 80, 88<br>Option Bus: 134              | Sets the option bus address for communication with the control panel. For Easy Series, use Address 134. |
| 15 | AES Encryption     | 0       | 0 = Disabled<br>1 = Enabled                 | Security encryption on/off; must match encryption settings in the receiver.                             |
| 16 | AES Encryption Key | <blank> | 32 characters max.<br>0-9, A-F, a-f allowed | Key must match encryption key in the receiver.  |

**Table 9.6** ITS-DX4020-G Basic Parameters

| ID | Parameter                                 | Default | Values  | Description  |
|----|---|---------|---|--|
| 50 | DTMF digit timeout                        | 500     | 100 to 3000 ms                                      | Acceptable time between dialled DTMF digits from the panel.                          |
| 51 | GPRS ACK timeout                          | 10      | 6 to 120 secs                                       | GPRS restarts if there is no response by the entered time.                           |
| 52 | GPRS Transmit buffer lifetime             | 15      | 6 to 120 secs                                       | Duration the panel messages are buffered in the communicator before being discarded. |
| 53 | GSM CODEC setting                         | 0       | 0 = Full Rate (FR)<br>1 = Adaptive Multi-rate (AMR) | Set to Full Rate when GSM is being used.   |
| 54 | GSM transmit gain                         | 5       | 0 to 10   | Gain on transmitted GSM signals  |
| 55 | GSM receive gain                          | 5       | 0 to 10   | Gain on received GSM signals.  |
| 56 | Enable incoming GSM calls where supported | 1       | 0 = Disabled<br>1 = Enabled                         | Enables/Disables incoming GSM calls.   |

**Table 9.7** ITS-DX4020-G Advanced Parameters

## 9.4 Upgrading the ITS-DX4020-G Software

To upgrade the software in the ITS-DX4020-G, you must download the latest ITS-DX4020-G binary file from the Bosch website to the target PC or laptop, and then use either Hyper Terminal or Tera Term to install the binary file on the ITS-DX4020-G.


### 9.4.1 Downloading the Latest Software

1. From your Internet browser, go to <http://www.boschsecurity.us/en-us/> to open the US Bosch web site.
2. Under **Online Catalogs**, click **Intrusion Alarm Systems**.
3. Under **Download Library**, click **Software**.
4. Under **Software**, click **Intrusion Alarm Systems**.
5. Under **Intrusion Alarm Systems**, click **Conettix - Information Transport Solutions**.
6. To the right of **ITS-DX4020-G\_x.x.x.bin**, click **EN**.  
The **File Download** window opens.
7. Click **Save** to save the file to the target PC or laptop.

### 9.4.2 Installing the Software with Hyper Terminal

Microsoft® includes Hyper Terminal with the Windows XP® operating system, and earlier operating systems.

1. In Windows, click **Start**→**All Programs** →**Accessories** →**Communications** →**Hyper Terminal**.
2. From the Hyper Terminal menu, click **Transfer**→**Send File**.  
The **Send File** window opens.



**Figure 9.9** Hyper Terminal Send File Window

3. Click **Browse** and go to the location where you downloaded the ITS-DX4020-G binary file.
4. In **Protocol**, select **Xmodem**.
5. Click **Send** to start the software upgrade.
6. When the software upgrade is complete, close Hyper Terminal, and remove the jumper plug from the CONFIG jumpers on the ITS-DX4020-G. The ITS-DX4020-G restarts.

### 9.4.3 Installing the Software with Tera Term

If you are using Microsoft® Vista®, you must download and install a communication utility, such as Tera Term, on the target PC or laptop.

1. Start Tera Term.
2. Select **File**→**Transfer**→**XMODEM**→**Send**.




Figure 9.10 Tera Term File Menu Path

3. In the **XMODEM Send** window, use the **Look in:** menu to find the location where you downloaded the ITS-DX4020-G binary file.
4. Click **Open** to start the software upgrade.




Figure 9.11 Tera Term XMODEM Send Window

5. When the software upgrade is complete, close Tera Term, and remove the jumper plug from the CONFIG jumpers on the ITS-DX4020-G. The ITS-DX4020-G restarts.

# 10 Device Specifications and Overview

## 10.1 Control Panel

|   |  |
|---|--|
| <b>Enclosure</b>                        |  |
| Dimensions (H x W x D):                 | 37 cm x 31.8 cm x 8.5 cm (14.5 in x 12.5 in x 3.25 in)   |
| Construction Material:                  | Cold-rolled steel, zinc seal, 0.36 mm thick (20 Ga.)   |
| <b>Environmental Considerations</b>     |  |
| Relative Humidity:                      | 93% at 32°C ±2°C (89.6°F 35.6°F)   |
| Operating Temperature:                  | -10°C to +49°C (14°F to +120°F)<br><b>CE:</b> -10°C to +40°C (+14°F to +104°F)<br><b>NF A2P:</b> -10°C +55°C (+14°F to +131°F)   |
| Storage Temperature:                    | -10°C to +55°C (+14°F to +131°F)   |
| Protection Level                        | IP 30 - IK 04  |
| <b>Supervised Points</b>                |  |
| On-board Hardwire:                      | 8<br>Single or dual end-of-line (2.2 k EOL) tamper point support<br>Point 1 supports two-wire smoke detectors<br>All points support four-wire smoke detectors<br>Enclosure tamper input (does not reduce point capacity)<br>Reaction time lower than 250ms           |
| <b>Programmable Outputs (PO)</b>        |  |
| On-board:                               | 4<br><b>PO 1 only:</b> Configurable relay<br><b>PO 2 to PO 4:</b> Configurable solid state<br><b>PO 4 only:</b> Internal supervised speaker driver option  |
| PO 1 Relay Rating:                      | <b>Contacts:</b> 2 A with no jumper installed; resistive loads only; in a NF A2P certified installation: 1 A<br><b>Output:</b> 1.2 A with jumper installed; resistive loads only; in a NF A2P certified installation 1 A<br><b>Operating Voltage:</b> 30 VDC maximum |
| PO 2 to PO 4 Rating:                    | 400 mA current sink  |
| <b>Number of...</b>                     |  |
| Users:                                  | 22<br><b>User 1:</b> Master user<br><b>Users 2 to 21:</b> System users<br><b>User 22:</b> Duress user  |
| Events:                                 | 500 history events, stamped with time and date   |
| Tokens and Key Fobs:                    | One per user (User 22 does not receive a token or key fob)   |
| <b>Phone Line</b>                       |  |
| Phone line trouble voltage              | Trouble condition occurs when the phone line voltage is between 1.10 V and 4.75 V  |
| <b>Control Panel Power Requirements</b> |  |



|                                       |   |
|---------------------------------------|---|
| AC Input Line Voltage                 | Use a UL Listed 18 V Class 2 transformer (22 VAC, VA 50/60 Hz), or the EZPS Power Supply<br>In an NF A2P certified installation, use the EZPS power supply delivered with the panel   |
| Total Alarm Power:                    | 1.4 A (AC power and standby battery; intrusion applications only).<br>With a 7.0 Ah battery, the following current draws apply to all outputs and devices connected to the system: <ul style="list-style-type: none"> <li>– Up to 170 mA for 24 hr for fire and combined fire/burglary applications</li> <li>– Up to 1.2 A for other applications</li> </ul>  |
| Auxiliary Power:                      | 12 VDC, 1.0 A maximum. Includes 110 mA for each control center connected to the system, and up to 400 mA for the programmable outputs.  |
| Current Draw:                         | 85 mA standby; 160 mA alarm with all outputs activated  |
| Voltage:                              | 12 VDC nominal (11.2 VDC to 12.3 VDC)<br>The control panel stops processing point faults when the voltage drops below 9.5 VDC.  |
| Battery:                              | D126 (7 Ah) or D1218 (18 Ah) sealed, lead acid rechargeable<br>1.7 A maximum recharging current<br>Low battery condition occurs when battery drops below 12 VDC<br>If AC power fails and the battery drops below 9.5 VDC, the control panel stops processing point faults. Disconnect the battery under these conditions.<br>Maximum auxiliary current to recharge standby battery within 72 hours: <ul style="list-style-type: none"> <li>– <b>12 V, 7 Ah Battery:</b> 400 mA</li> <li>– <b>12 V, 18 Ah Battery:</b> 900 mA</li> </ul> In an NF A2P certified installation, use a battery Yuasa NP17-12IFR |
| <b>EZPS Power Supply Requirements</b> |   |
| AC Input:                             | <b>AC Input Voltage:</b> 100 VAC to 240 VAC<br><b>Line Voltage Frequency:</b> 47 Hz to 63 Hz<br><b>Maximum Input Current:</b> 0.5 A<br><b>Power Factor:</b> Approximately 0.65 at full load   |
| DC Output:                            | <b>Nominal Output Voltage under AC line input:</b> 18 VDC<br><b>Output Voltage Range under AC line input:</b> 16 VDC to 20 VDC<br><b>Continuous Rated Output Current:</b> 1.25 A<br><b>Output Current Limit:</b> Approximately 1.75 A to 2.5 A<br><b>Periodic and Random Deviation (PARC):</b> Less than 250 mV   |

### 10.1.1 Standby Battery Calculation

Use the following formula to calculate standby battery capacity for 24 hr of standby power:

(Total B \_\_\_\_ x 24 hr) + (Total C \_\_\_\_ x 0.067 hr) + 10% reserve = Total battery Ah required

If the Column C total exceeds 1.4 A, use an external power supply.






| Model  | Qty Used | A<br>AC Power On Normal Current |                |            | B<br>AC Power Off Minimum Current |                |            | C<br>In Alarm Maximum Current |                |            |
|--|----------|---------------------------------|----------------|------------|-----------------------------------|----------------|------------|-------------------------------|----------------|------------|
|  |          | Each Unit (mA)                  |                | Total (mA) | Each Unit (mA)                    |                | Total (mA) | Each Unit (mA)                |                | Total (mA) |
| Control Panel  |          | 85                              | x1             | 85         | 85                                | x1             | 85         | 160                           | x1             | 160        |
| Control Center   |          | 110                             | x Qty          |            | 110                               | xQty           |            | 165                           | xQty           |            |
| Wireless Hub (IWT-WSN-N!-86)                                       |          | 30                              | x Qty          |            | 30                                | x Qty          |            | 30                            | xQty           |            |
| DX2010   |          | 35                              | x Qty          |            | 35                                | x Qty          | 0          | 35                            | xQty           |            |
| <b>Sounders Connected to PO 4</b>                                  |          |                                 |                |            |                                   |                |            |                               |                |            |
| D118 8 Ω Speaker   |          | 0                               | xQty           | 0          | 0                                 | xQty           | 0          | 330                           | xQty           |            |
| <b>Ratings of other devices in system that are not shown above</b> |          |                                 |                |            |                                   |                |            |                               |                |            |
|  |          |                                 | x Qty          |            |                                   | x Qty          |            |                               | x Qty          |            |
|  |          |                                 | x Qty          |            |                                   | x Qty          |            |                               | x Qty          |            |
|  |          |                                 | x Qty          |            |                                   | x Qty          |            |                               | x Qty          |            |
|  |          |                                 | x Qty          |            |                                   | x Qty          |            |                               | x Qty          |            |
|  |          |                                 | x Qty          |            |                                   | x Qty          |            |                               | x Qty          |            |
|  |          |                                 | <b>Total A</b> |            |                                   | <b>Total B</b> |            |                               | <b>Total C</b> |            |




## 10.2 Control Center

### Control Center Specifications








| Control Center                |   |
|-------------------------------|---|
| Dimensions (H x W x D):       | 12 cm x 17.7 cm x 2.5 cm (4.7 in. x 7 in. x 1 in.)  |
| Total Number Supported:       | 4   |
| Recommended Mounting Surface: | Non-metallic surface  |
| Minimum Mounting Distance:    | 1.2 m (4 ft) between each control center  |
| Current Draw:                 | 110 mA standby; 165 mA alarm  |
| Minimum Wire Length:          | 3 m (10 ft)   |
| Maximum Wire Length:          | <b>Total:</b> 400 m (1312 ft) using 0.8 mm (22 AWG) wire;<br><b>Single run:</b> 100 m (328 ft) using 0.8 mm (22 AWG) wire   |
| Data Bus Wire Type Options:   | 1 four-conductor, power-limited 1.2 mm (18 AWG) or 0.8 mm (22 AWG) wire<br>At least 0.6 mm (24 AWG) twisted pair CAT5 wire.<br>UL installations require power-limited wiring.   |
| Audio Bus Wire Type Options:  | 1 two-conductor or 1 four-conductor, power-limited 1.2 mm (18 AWG) or 0.8 mm (22 AWG) wire. Only two conductors are used.<br>At least 0.6 mm (24 AWG) twisted pair CAT5 wire.<br>UL installations require power-limited wiring.<br>Unless using CAT5 cable, audio bus connections require a dedicated wire. |
| CAT5 Wire Requirements:       | Refer to <i>Section 2.2.3 Install the Control Center</i> , page 14.   |
| Protection Level              | IP 30 - IK 04   |

### Control Center Display States








| Display   | Color                                    | Description   |
|---|--|---|
|  | Green circle                             | No alarm or trouble conditions exist.<br>You can turn on the system.  |
|  | Flashing green circle                    | System trouble exists. You can still turn on the system.<br>Alarm memory active.                                      |
|   | Flashing amber circle                    | System trouble exists. You cannot turn on the system.<br>Alarm memory active.   |
|  | Broken green circle                      | Wired point(s) are faulted. Turn on the system to bypass faulted point(s).<br>Chime point faulted. Chime tone sounds. |
|   | Broken amber circle                      | Wired point(s) are faulted. You cannot turn on the system.  |
|  | Broken red circle;<br>flashing red icons | Fire or intrusion alarm occurred.   |
|  | Single rotating segment                  | Alarm memory announcement. Add or change user token.<br>Waiting for information from wireless network.                |

| Display   | Color                  | Description   |
|---|------------------------|---|
|  | Green circle and icons | Add or change user passcode. Outside icon appears for first passcode entry.<br>Inside icon appears for second passcode entry. |
|  | Green or amber         | Point walk test.<br>Green single circle segments represent tested points.   |
|  | Green flashing icons   | Control center test. Icons alternately flash.   |

**Table 10.1** System Off Display States

| Display   | Color                                    | Description   |
|---|--|---|
|    | Flashing red icon                        | Exit Delay in progress. Circle segments turn on, one at a time, to provide a visual status of Exit Delay.   |
|    | Red                                      | System is on (occupied or custom protection).   |
|  | Flashing icon<br>(amber then red)        | Entry Delay in progress. Circle segments turn off, one at a time, to provide a visual status of Entry Delay.<br><b>Amber icon:</b> First half of Entry Delay.<br><b>Red icon:</b> Second half of Entry Delay. |
|  | Broken red circle;<br>flashing red icons | Fire or intrusion alarm occurred.   |
|  | Flashing red circle                      | Active alarm memory (if system is on).<br>System trouble exists.  |
|  | Single red rotating segment              | Alarm memory announcement (if system is on).  |
|  | Broken red circle                        | At least one point is faulted or bypassed; no trouble exists.   |

**Table 10.2** System On (Occupied or Custom Protection) Display States

| Display   | Color                                    | Description   |
|---|--|---|
|    | Flashing red icon                        | Exit Delay in progress.   |
|    | Red                                      | System is on (unoccupied).  |
|    | Flashing icon<br>(amber then red)        | Entry Delay in progress.<br><b>Amber icon:</b> First half of Entry Delay.<br><b>Red icon:</b> Second half of Entry Delay. |
|    | Broken red circle;<br>flashing red icons | Fire or intrusion alarm occurred.   |
|    | Flashing red circle                      | Active alarm memory (if system is on).  |
|    | Single red rotating segment              | Alarm memory announcement (if system is on).  |
|  | Broken red circle                        | At least one point is faulted or bypassed; no trouble exists.   |

**Table 10.3** System On (Unoccupied) Display States

## 10.3 DX2010 Input Expander



### NOTICE!

If Points 9 to 32 contain wired and wireless points, install all required DX2010 Input Expanders before adding any wireless points to the system.

The DX2010 Input Expander connects directly to the data bus of a compatible control panel. Each expander adds eight input loops.

| DX2010 Input Expander           |   |
|---------------------------------|---|
| Operating Voltage:              | 8 VDC to 14 VDC   |
| Current Draw:                   | 35 mA standby; 135 mA maximum with connected accessories  |
| Outputs:                        | 100 mA, 12 VDC supervised output for accessories  |
| Sensor Loop Terminal Wire Size: | 0.8 mm (22 AWG) to 1.8 mm (14 AWG)  |
| Wire Length:                    | <p><b>Control panel to DX2010 (DX2010 auxiliary output not used):</b></p> <ul style="list-style-type: none"> <li>– 0.8 mm (22 AWG) = 305 m (1000 ft)</li> <li>– 1.2 mm (1.2 mm) = 610 m (2000 ft)</li> </ul> <p><b>Control panel to DX2010 (DX2010 auxiliary output supplying 100 mA):</b></p> <ul style="list-style-type: none"> <li>– 0.8 mm (22 AWG) = 30 m (100 ft)</li> <li>– 1.2 mm (1.2 mm) = 76 m (250 ft)</li> </ul> |
| Operating Temperature:          | 0°C to +50°C (+32°F to +122°F)  |
| Relative Humidity:              | 5% to 85% at +30°C (+86°F)  |
| Sensor Loop Resistance:         | 60 Ω maximum  |
| Sensor Loop:                    | Up to eight inputs; input contacts can be normally open (NO) or normally closed (NC) with appropriate EOL resistors for supervision.  |

### Add a DX2010 Before Adding Wireless Points

The control panel supports up to three DX2010 modules. Each module occupies a group of eight points.

The DX2010's DIP switch address determines which group of points the DX2010 occupies:

- Address 102: DX2010 occupies Points 9 to 16
- Address 103: DX2010 occupies Points 17 to 24
- Address 104: DX2010 occupies Points 25 to 32

Refer to on *Section 2.2.6 Install the DX2010 Input Expander*, page 16, for more DIP switch settings.

As each DX2010 module is added to the system, it occupies the next available group of points.

For Points 9 to 32, wireless points also occupy points in the same groups of eight as the DX2010 modules:

- If you add two DX2010 modules using Addresses 102 (Points 9 to 16) and 103 (Points 17 to 24), wireless points can only occupy Points 25 to 32.
- If you add three DX2010 modules, wireless points can only occupy Points 1 to 8.
- If you add a DX2010 module using address 102 (Points 9 to 16), wireless points can only occupy Points 17 to 32.

### Add a DX2010 After Adding Wireless Points

If you add a DX2010 module after wireless points are added, based on its DIP switch address, the DX2010 replaces the conflicting group of wireless points.

For example, if wireless points occupy Points 9 to 24, and you need Points 17 to 24 as wired points, a DX2010 module with Address 103 replaces the wired points occupying Points 17 to 24.

If the next point grouping is available, for this example, Points 25 to 32, the control panel retains all point programming except for voice descriptions, and moves the conflicting wireless points to the next point grouping. You must re-record voice descriptions for the points that were moved.

If the next point grouping is not available, the control panel deletes the conflicting wireless points from the system.

## 10.4 Conettix DX4020 Network Interface Module

The Conettix DX4020 Ethernet Network Interface Module creates two-way communications over Ethernet networks for compatible control panels.

| DX4020 Network Interface Module |   |
|---------------------------------|---|
| Operating Voltage:              | 12 VDC nominal  |
| Current Draw:                   | <b>10Base-T:</b> 110 mA maximum; <b>100Base-T:</b> 135 mA maximum |
| Operating Temperature:          | 0°C to +50°C (+32°F to +122°F)                                    |
| Relative Humidity:              | 5% to 85% at +30°C (+86°F)  |

## 10.5 ITS-DX4020-G Communicator

The Conettix ITS-DX4020-G Communicator is a multi-function, dual-path security communicator that communicates with Bosch Security Systems, Inc. Conettix receivers. It is compatible with DX4020 protocols, and it provides a cellular (GSM/GPRS) modem.

| ITS-DX4020-G GPRS/GSM Communicator |                                  |
|------------------------------------|----------------------------------|
| Operating Voltage:                 | 12 VDC nominal, 10 VDC to 15 VDC |
| Current Draw:                      | Standby: 70mA, Alarm: 400mA      |
| Operating Temperature:             | -10°C to +55°C (+14°F to +131°F) |
| Relative Humidity:                 | 5% to 95%                        |
| Ripple/Noise:                      | 200 mVpp maximum                 |

## 10.6 wLSN Installation Tool


Use the wLSN Installation Tool to determine the best locations for wLSN device installation. The Installation Tool communicates signal strength and packet success ratios through an LCD display.

### Specifications

|           |  |   |
|-----------|--|---|
| 868 MHz   | ISW-BIT1-HAX, ISW-BIT1-HBX, ISW-BIT1-HCX |   |
| 915 MHz   | ISW-BIT1-HCX                             |   |
| Power     | Docked                                   | 12 VDC nominal, 6 VDC to 14 VDC   |
|           | Batteries                                | 3 AAA NiMH rechargeable batteries that require an initial charge of at least 7 hours of charging.<br>Operating Life: Up to 50 hours of continuous use on a single charge. |
| EN50131-1 | Environmental Class II                   |   |

### LED Displays

The crescent-shaped LED indicates charging status when placed in a docking station. Refer to *Figure 10.1* on Page 80 and *Table 10.4* on Page 80.



**Figure 10.1** wLSN Installation Tool

|   |                     |
|---|---------------------|
| 1 | Power Indicator     |
| 2 | Charging Status LED |

| LED (Green)              | Status                                       |
|--------------------------|--|
| On                       | Batteries fully charged                      |
| Off                      | Installation Tool operation on battery only. |
| Flashing                 | Batteries charging                           |
| Flashing power indicator | Low battery                                  |

**Table 10.4** wLSN Installation Tool LED Status



## 10.7 wLSN Hub Specifications

|               |   |
|---------------|---|
| 868 MHz       | ISW-BHB1-WX   |
| 915 MHz       | ISW-BHB1-WY   |
| Wire Gauge    | 0.14 mm to 1.5 mm   |
| Wire Length   | 100 m   |
| Power/Voltage | 12 VDC nominal, 7 to 14 VDC                               |
| Current Draw  | 60 mA maximum   |
| Compliance    | EN50131-1 Security Grade 2 Type C, Environmental Class II |

The wLSN Hub monitors and coordinates two-way communications between the control panel and the detectors.

Rotary switches (S1, S2, and S3) configure device operation and enable special diagnostic modes.

An LED on the front provides device status.

### General Operation

Refer to *Table 10.5* on Page 81 and *Table 10.6* on Page 81 for an overview on wLSN Hub LEDs and switch settings.

| Operation                      | LED Display   |
|--------------------------------|---|
| Self Test and Hardware Failure | LED flashes twice per sec. This indicates failure. The wLSN Hub does not operate. |
| Standard Operation             | LED on.   |
| Configuring Network            | LED flashes once every 2 sec.   |
| RFSS Mode                      | LED flashes once every 4 sec.   |

**Table 10.5** wLSN Hub LED Displays

| Function         | Switches |    |    |
|------------------|----------|----|----|
|                  | S1       | S2 | S3 |
| Normal Operation | 1        | 0  | 0  |
| RFSS Mode        | 9        | 2  | 0  |
| Default Mode     | 9        | 8  | 7  |

**Table 10.6** wLSN Hub Switch Settings

## 10.8 wLSN PIR and Dual Motion Detectors

The PIR Motion Detector (ISW-BPR1-W13PX) uses an infrared sensor. The Dual Motion Detector uses (ISW-BPR1-W13PGX) both PIR and microwave technology.

A cover-and-wall tamper switch transmits a tamper signal when the cover is removed from its base, or when the unit is pulled away from the wall.

An LED provides status for Walk Test, RFSS, and Discovery Modes.

### Specifications

|  |  |
|--|--|
| 868 MHz                                | <b>PIR:</b> ISW-BPR1-W13PX<br><b>Dual:</b> ISW-BDL1-W11PGX, ISW-BDL1-W11PHX, ISW-BDL1-W11PKX |
| 915 MHz                                | <b>PIR:</b> ISW-BPR1-W13PY<br><b>Dual:</b> ISW-BDL1-W11PGY, ISW-BDL1-W11PHY, ISW-BDL1-W11PKY |
| PIR Motion Detector Power/<br>Voltage  | Four AA 1.5 V alkaline batteries   |
| Dual Motion Detector Power/<br>Voltage | Six AA 1.5 V alkaline batteries  |
| EN50131-1                              | Security Grade 2, Environmental Class II   |

### Sensitivity Settings

Sensitivity settings are set at the control panel. Refer to the control panel's documentation for detailed information.

1. **Standard Sensitivity**  
Use this setting when pets are present in the area to be monitored. Standard sensitivity provides excellent detection performance and is the least sensitive to false alarms.
2. **Intermediate Sensitivity**  
Only use this setting in non-pet installations where environmental disturbances are minimal. Intermediate sensitivity provides the highest level of detection performance.



### NOTICE!

The Dual Motion Detector's microwave motion sensor is factory adjusted to sense motion to at least 11 m.

3. **Setting the Dual Motion Detector's Microwave Range Adjustment**
  - a. If the microwave coverage needs adjustment (red or yellow LED does not light), increase or decrease the microwave range as needed (using the back of the device).
  - b. Repeat the Walk Test.
  - c. Repeat Steps a and b until the required coverage is met.

## 10.9 wLSN Door-Window Contact

The wLSN Door-Window Contact is a magnetic reed switch and wireless transceiver used for monitoring doors, windows, and other dry contact devices.

A cover-and-wall tamper switch transmits a tamper signal when the cover is removed from its base, or when the unit is pulled away from the wall.

An LED provides status for RFSS and Discovery Modes.

### Specifications

|  |   |
|--|---|
| 868 MHz                                    | ISW-BMC1-S135X  |
| 915 MHz                                    | ISW-BMC1-S135Y  |
| Maximum Distance Between Sensor and Magnet | <12,7 mm, the magnet can be placed on either side.<br>The base is marked to indicate the magnet position. |
| Wire Gauge                                 | 0.14 mm (22 AWG) to 1.5 mm (16 AWG)   |
| Power/Voltage                              | Two AA batteries, 1.5 V alkaline  |
| Terminal Block                             | For connecting other dry contact devices such as another magnetic reed switch. (2.2k EOL)                 |
| EN50131-1                                  | Security Grade 2, Environmental Class II  |

### Supported Wiring Configurations

The wLSN Door-Window Contact provides a supervised point for monitoring external devices. Refer to Section 2.2.7 Connect Supervised Points on page 19 for supported wiring options when using the supervised point.

## 10.10 wLSN Recessed Door-Window Contact

The wLSN Recessed Door-Window Contact is a wireless transceiver used for monitoring doors and windows. A cover tamper switch transmits a tamper signal when the cover is removed from its base.

An LED provides status for RFSS and Discovery Modes.



### NOTICE!


Mounting the wLSN Recessed Door-Window Contact in a metal door or window frame could degrade the RF signal strength.

### Specifications

|   |   |
|---|---|
| 868 MHz   | ISW-BMC1-R135X  |
| 915 MHz   | ISW-BMC1-R135Y  |
| Power/Voltage                                   | One CR2 lithium battery, 3 VDC  |
| Maximum Distance Between Reed Switch and Magnet | <12,7 mm  |
| Drill Tools                                     | Requires the use of a 19 mm (3/4 in.) drill bit and 22 mm (7/8 in.) spade bit |
| Circuit Board Removal                           | Needle nose pliers are recommended  |
| EN50131-1                                       | Security Grade 2, Environmental Class II                                      |

### Tamper Switch Location

Refer to *Figure 10.2* on Page 84 for the location of the device's tamper switch and LED.



**Figure 10.2** Recessed Door-Window Contact

|   |  |
|---|--|
| 1 | Mounting slots for printed circuit board |
| 2 | Tamper switch                            |
| 3 | LED for RFSS Mode and Discovery Mode     |

## 10.11

### wLSN Mini Door-Window Contact

Similar to the wLSN Door-Window Contact, the wLSN Mini Door-Window Contact is a wireless transceiver device used for monitoring doors and windows.

A cover-and-wall tamper switch transmits a tamper signal when the cover is removed from its base, or when the unit is pulled away from the wall.


An LED provides status for RFSS, and Discovery Modes.

#### Specifications

|   |  |
|---|--|
| 868 MHz   | ISW-BMC1-M82X  |
| 915 MHz   | ISW-BMC1-M82Y  |
| Power/Voltage                                   | One CR2 lithium battery, 3 VDC   |
| Maximum Distance Between Reed Switch and Magnet | <12,7 mm (1/2 in.)<br>The magnet can be placed on either side of the detector. |
| EN50131-1                                       | Security Grade 2, Environmental Class II                                       |

### Tamper Switch Location

Refer to *Figure 10.3* on Page 84 for the location of the device's tamper switch.



**Figure 10.3** Mini Door-Window Contact Tamper Switch

## 10.12 wLSN Inertia Detector

The wLSN Inertia Detector is a vibration detector combined with a wireless transceiver used for monitoring doors or windows.

A cover-and-wall tamper switch transmits a tamper signal when the cover is removed from its base, or when the unit is pulled away from the wall.


An LED provides status for Test, RFSS, and Discovery Modes.

### Specifications

|  |   |
|--|---|
| 868 MHz                                      | ISW-BIN1-S135X  |
| 915 MHz                                      | ISW-BIN1-S135Y  |
| Maximum Distance Between Detector and Magnet | <12,7 mm (1/2 in.)<br>The magnet can be placed on either side of the detector.  |
| Power/Voltage                                | 2 AA batteries, 1.5 V alkaline  |
| Sensor Adjustment                            | Adjust the position of the sensor element, so the arrow always points up by removing and replacing the element to accommodate the possible placement positions (refer to <i>Figure 10.4</i> on Page 85).<br>Route the wiring from the sensor element so it does not make contact with the tamper spring (refer to <i>Figure 10.4</i> on Page 85). |
| EN50131-1                                    | Security Grade 2, Environmental Class II  |

### Sensor Adjustment

Proper sensor element orientation is critical to the operation of the device. The arrow, embossed on the body of this sensor, must always point up. Refer to *Figure 10.4* on Page 85 for arrow and for proper wire routing when reinserting the sensor element.



**Figure 10.4** Sensor Adjustment

|   |  |
|---|--|
| 1 | Remove sensor element                    |
| 2 | Turn sensor element as desired           |
| 3 | Ensure arrow on sensor element points up |
| 4 | Proper wire routing                      |

### Sensitivity Settings

All sensitivity settings are programmed at the control panel (refer to *Section 5.2.6 Point Programming Items*, page 52). The sensor element has two settings:

- Gross Attack
- Minor Attack

Gross Attack is always enabled. The Minor Attack setting is very sensitive and can be disabled.



### NOTICE!

A single tap such as a branch in the wind lightly brushing a window can start the minor attack timer and tap count. To avoid false alarms, do not use the Minor Attack setting where there is potential for stray vibrations.

---

### Test Mode

The unit is automatically in Test mode for the first 10 minutes after power up.

The green LED flashes:

- Once to indicate initialization is complete and the unit is in Test mode
- Twice to indicate a Minor Attack test
- Three times to indicate a Gross Attack test

## 10.13 wLSN Key Fob


The wLSN Key Fob is a two-way personal transmitter carried by the user. Use it to remotely arm or disarm a security area.

### Specifications

|               |   |
|---------------|---|
| 868 MHz       | ISW-BKF1-H5X  |
| 915 MHz       | ISW-BKF1-H5Y  |
| Power/Voltage | Two CR2032 lithium batteries, 3 VDC                             |
| Gaskets       | Interchangeable; for multiple users, different colors available |
| EN50131-1     | Security Grade 2, Environmental Class II                        |






### Key Fob User Interface



Refer to *Figure 10.5* on Page 87, *Table 10.7* on Page 88, and *Table 10.8* on Page 88 for key fob LED and button functions.







**Figure 10.5** wLSN Key Fob Button and LED Locations

|   |                      |
|---|----------------------|
| 1 | High intensity LED   |
| 2 | Status LED           |
| 3 | Disarm button        |
| 4 | Arm button           |
| 5 | Programmable buttons |

| LED/Button         | Function   |
|--------------------|--|
| High intensity LED | Suitable for use as a flashlight. Press  to operate.  |
| Status LED         | Refer to <i>Table 10.8</i> on Page 88 for status indications.  |
| Disarm button      | Press  to turn the system off.<br>Press and hold  for 1 sec to create a panic alarm.   |
| Arm button         | Press  to turn the system on (unoccupied).<br>Press and hold  to create a panic alarm. |

| LED/Button                | Function  |
|---------------------------|---|
| Programmable buttons      | To operate the programmable buttons, press and hold  or  for at least one sec. Program these buttons at the control panel to control lights, garage doors, and so on. Refer to Expert Programming Items 616 and 626 on page 56. |
| High intensity LED button | Press [FIG] to operate the high intensity LED.  |

**Table 10.7** wLSN Key Fob LEDs and Buttons

| Status                               | Description   |
|--------------------------------------|---|
| Alternating red and green            | A key fob button was pressed. The LED either stops flashing, or one of the other status indicators in this table occurs. This display lasts approximately for 15 sec.   |
| Red fast flash                       | The system is in alarm, or silent panic feature was used.   |
| Red slow flash                       | Exit delay in progress (system occupied or unoccupied).   |
| Red on steady                        | The system is on (occupied or unoccupied).  |
| Green fast flash                     | An error occurs while turning the system on. The system does not turn on as expected.   |
| Green slow flash                     | The system is not ready to turn on. A button programmed for system status also shows this status.   |
| Green on steady                      | The system is off and is ready to turn on. The button programmed for system status also shows this status.  |
| Green on steady and slow amber flash | Either  or  was pressed to turn an output on or off.              |
| Red on steady and slow amber flash   | Either  or  was pressed to turn an output on for two seconds. |
| Red blip                             | If the LED flashes red once every 5 sec when the key fob is not in use, replace the batteries.  |

**Table 10.8** wLSN Key Fob LED Status



## 10.14 wLSN Relay Module

The wLSN Relay Module allows the control panel to control external devices through a Form C relay. This module also provides a supervised point for monitoring external devices.

Auxiliary power input terminals are also provided to supplement battery power when relay use is high.

A cover-and-wall tamper switch transmits a tamper signal when the cover is removed from its base, or when the unit is pulled away from the wall.

An LED provides status for RFSS and Discovery Modes.

### Specifications

|                                  |  |  |
|----------------------------------|--|--|
| 868 MHz                          | ISW-BRL1-WX                              |  |
| 915 MHz                          | ISW-BRL1-WY                              |  |
| Wire Gauge                       | 0.14 mm to 1.5 mm                        |  |
| Power                            | Four AA batteries, 1.5 V alkaline        |  |
| External Power Source (optional) | 12 VDC nominal, 6 VDC to 14 VDC          |  |
| Terminal Blocks                  | DC+ and DC -                             | External power source, 12 VDC nominal, 6 VDC to 14 VDC |
|                                  | PT + and PT - (input)                    | Input, supervised sensor loop                          |
|                                  | NO, C, NC (output)                       | Relay output for control of external devices.          |
| Relay Output                     | 2A at 30 VDC (resistive load)            |  |
| EN50131-1                        | Security Grade 2, Environmental Class II |  |



### NOTICE!

The external power option is intended to be used as a supplemental (secondary) source of power only. Do not operate the Relay Module without the batteries.

## 10.15 wLSN Indoor Siren

The wLSN Indoor Siren provides auxiliary power input terminals are also provided to supplement battery power when siren use is high.

A cover-and-wall tamper switch transmits a tamper signal when the cover is removed from its base, or when the unit is pulled away from the wall.

An LED provides status for RFSS and Discovery Modes.

### Specifications

|                                  |  |
|----------------------------------|--|
| 868 MHz                          | ISW-BSR1-WX  |
| 915 MHz                          | ISW-BSR1-WY  |
| Wire Gauge                       | 0.14 mm to 1.5 mm                                      |
| Power                            | Four AA batteries, 1.5 V alkaline                      |
| External Power Source (optional) | 12 VDC nominal, 6 VDC to 14 VDC                        |
| DC+ and DC - Terminal Blocks     | External power source, 12 VDC nominal, 6 VDC to 14 VDC |
| Sounder                          | 85 dB at 3 m   |
| EN50131-1                        | Security Grade 2, Environmental Class II               |



### NOTICE!

The external power option is intended to be used as a supplemental (secondary) source of power only. Do not operate the Indoor Siren without the batteries.


## 10.16 wLSN Outdoor Siren

### Specifications

|                    |                                     |
|--------------------|-------------------------------------|
| 868 MHz            | ISW-BSR1-WOX                        |
| Wire Gauge         | 0.14 mm to 1.5 mm                   |
| Power              | Two 2 x 13Ah (3.6 VCC nominal)      |
| Outdoor Modulation | 1400 – 1600 Hz, excursion of 200 Hz |
| Sounder            | 90 to 105 dB at 1m                  |
| EN50131-1          | EN Environmental class IV outdoor   |

### Configuration

Use the Outdoor Siren DIP switches to configure the siren for compliance with the laws of the installation country. Refer to *Figure 10.6*, Page 91.



**Figure 10.6** Outdoor Siren Configuration Switches

Refer to the following table for configurations allowed by the DIP Switch Settings.

| Configuration | Region   | DIP Switches | Configuration  |
|---------------|----------|--------------|--|
| OFF/OFF       | Default  |              | <ul style="list-style-type: none"> <li>– Siren is limited to 90 sec.</li> <li>– Flashes every 1.5 sec from 0 - 90 sec of the alarm.</li> <li>– Flashes every 3 sec from 90 sec - 30 min of the alarm.</li> <li>– Flash stopped after 30 min.</li> </ul>  |
| ON/OFF        | Spain    |              | <ul style="list-style-type: none"> <li>– Siren is activated for 60 sec, then 30 sec of silence, and then activated for 60 more sec.</li> <li>– Flashes every 1.5 sec from 0 - 150 sec of the alarm.</li> <li>– Flashes every 3 sec from 150 sec - 30 min of the alarm.</li> <li>– Flash stopped after 30 min.</li> </ul> |
| ON/ON         | Belgium  |              | <ul style="list-style-type: none"> <li>– Siren is limited to 90 sec.</li> <li>– Flashes every 1.5 sec from 0 - 90 sec of the alarm.</li> <li>– Flashes every 3 sec from 90 sec - 30 min of the alarm.</li> <li>– Flashes every 20 sec from 30 min of the alarm until the siren is turned off.</li> </ul>                 |
| OFF/ON        | Reserved |              | Reserved for future use.   |

**Table 10.9** Outdoor Siren DIP Switch Settings

## 10.17 wLSN Smoke and Heat Detectors

The ISW-BSM1-SX (868 MHz) is a wireless smoke detector.

The ISW-BSM1-SY (915 MHz) is a wireless smoke and heat detector that provides fixed temperature and rate-of-rise sensors.

Under normal conditions, the red LED flashes once every 8 sec while the sensor monitors the surrounding environment. When the sensor detects smoke, the LED changes from flashing to steady on and the sounder produces a loud continuous tone.

A self-diagnostic feature monitors detector sensitivity and operational status.

A cover tamper switch transmits a tamper signal when the cover is removed from its base, or when the unit is pulled away from the wall.

The optical chamber is removable for easy maintenance.


### Specifications

|  |   |
|--|---|
| 868 MHz                                    | ISW-BSM1-SX   |
| 915 MHz                                    | ISW-BSM1-SY   |
| Power/Voltage                              | Two lithium batteries; 3 VDC                          |
| Fixed Temperature Sensor (ISW-BSM1-SY)     | +57°C ± 3°C (+135°F ± 5°F)                            |
| Rate-of-Rise Sensor (ISW-BSM1-SY)          | +8.3°C/min > +41°C (+15°F > +105°F)                   |
| Photoelectric Beam Obscuration Sensitivity | 0.14 ± 0.04 dB/m                                      |
| Drift Compensation Adjustment              | 1.64%/m (0.5%/ft) maximum                             |
| Average Alarm Current                      | 70 mA   |
| Sounder                                    | 85 dBA at 3 m   |
| Self-diagnostics Feature                   | Monitors detector sensitivity and operational status. |
| EN14604                                    | ISW-BSM1-SX   |

### Battery Replacement

The LED normally flashes every 8 sec. Replace batteries when the LED stops flashing and the sensor chirps every 45 sec.

The low battery trouble chirps can be silenced for 24 hours by pushing the Test/Silence Button. Refer to *Figure 10.7* on Page 92 for the location of the Test/Silence Button.



**Figure 10.7** wLSN Smoke Detector

|   |                     |
|---|---------------------|
| 1 | High intensity LED  |
| 2 | Test/Silence Button |

**Smoke Test**

Test smoke detectors annually using a listed aerosol smoke tester to simulate an alarm. Follow the instructions on the can.

The LED should remain on while the detector provides a continuous tone. The detector automatically resets when smoke is no longer present. A detector that fails to activate with the Smoke test might require cleaning or replacement.



**NOTICE!**

To avoid a fire department dispatch, contact the central monitoring station or put the system into Test mode before activating the detector using this method.

**Sensitivity Test**



**NOTICE!**

Test mode is seen by the control panel as a test. It does not send an alarm.

The detector includes a Sensitivity Level Test mode for determining the detector's sensitivity:

1. Press and hold the Test/Silence button for 4 sec. The LED flashes 1 to 9 times and the sounder activates.
2. Count the number of LED flashes and use *Table 10.10* on Page 93 to determine the status of the detector's sensitivity and the action to take.

| Flashes | Action Recommended   |
|---------|--|
| 1       | Return device for service or replacement.  |
| 2 to 3  | Clean the detector and re-test. If error persists, replace the detector.               |
| 4 to 7  | Normal.  |
| 8 to 9  | Confirm that the smoke chamber is snapped down securely. Clean the sensor and re-test. |

**Table 10.10** wLSN Smoke Detector Sensitivity Conditions

**Silence an Alarm**

Press the Test/Silence Button (refer to *Figure 10.7* on Page 92) to silence the sounder during an alarm. If smoke is still present after a few minutes, the sounder and alarm resume.

**LEDs**

| LED      | Status   |
|----------|--|
| Flashing | Normal.  |
| On       | Detects smoke (heat), sending an alarm.  |
| Off      | Replace the batteries, clean the detector, or replace the optical chamber as required. |


**Table 10.11** wLSN Smoke Detector LED Statuses

### Cleaning the Detector and Replacing the Optical Chamber

Clean the detector cover with a dry or damp cloth as needed to keep it free from dust and dirt. Clean the detector interior at least once a year, or as needed.

To clean the detector:

1. Rotate the detector counter-clockwise to remove it from the mounting base.
2. Remove the batteries.
3. Slide a flat head screwdriver in the slot on the detector cap and gently push down to pry the cap off. Squeeze the optical chamber where indicated and pull it up and away from the detector. Refer to *Figure 10.8* on Page 94.



**Figure 10.8** Remove the Detector Cap and the Chamber

|   |                     |
|---|---------------------|
| 1 | Remove detector cap |
| 2 | Smoke Chamber Base  |
| 3 | Optical Chamber     |
| 4 | Alignment Arrows    |

4. Use compressed air or a soft-bristled brush to remove dust and dirt from the smoke chamber base.
5. Align the new optical chamber with the base and snap into place.
6. To attach the detector cap, line the cap up with the detector, press the cap onto the detector, and turn the cap clockwise to snap it firmly into place.
7. Observing the proper polarity, install the batteries and the battery cover. If the batteries are not installed, the detector does not properly fit onto the mounting base.
8. Mount the detector onto the mounting base.
9. Test the detector's sensitivity.

Refer to *Section Sensitivity Test* on Page 93.

## 10.18 wLSN Glassbreak Detector

### Specifications

The wLSN Glassbreak Detector is a wireless transmitter used for detecting breaking glass. A cover-and-wall tamper switch transmits a tamper signal when the cover is removed from its base, or when the unit is pulled away from the wall.

### Specifications

|                       |  |   |                    |
|-----------------------|--|---|--------------------|
| 868 MHz               | ISW-BGB1-SAX                             |   |                    |
| 915 MHz               | ISW-BGB1-SAY                             |   |                    |
| Power/Voltage         | 2 AA batteries, 1.5 V alkaline           |   |                    |
| Acoustic Capabilities | Glass types and thicknesses              | <b>Type</b>   | <b>Thickness</b>   |
|                       |  | Plate   | 0,24 cm to 0,95 cm |
|                       |  | Tempered  | 0,32 cm to 0,95 cm |
|                       |  | Laminated*  | 0,32 cm to 1,43 cm |
|                       |  | Wired   | 0,64 cm            |
|                       |  | * Protected only if both panes of glass are broken. |                    |
|                       | Minimum pane size for all types of glass | 28 cm x 28 cm                                       |                    |
|                       | Range                                    | Maximum 7.6 m; no minimum range                     |                    |

### General Overview




Figure 10.9 wLSN Glassbreak Detector Front Layout

|    |  |
|----|--|
| 1  | Service door tamper switch                           |
| 2  | AA batteries   |
| 3  | Service door   |
| 4  | Test Mode pads                                       |
| 5  | Sensitivity DIP switches                             |
| 6  | Event LED  |
| 7  | Alarm LED  |
| 8  | LED enable switch (off position)                     |
| 9  | Housing screw  |
| 10 | RFSS Mode LED (remove housing screw and cover piece) |

**Installation Considerations**



**NOTICE!**

Glassbreak detectors are intended only as a component of a perimeter protection system. You should always use a motion detector in conjunction with a glassbreak detector.

For the best detector performance, select a mounting location that is:


- within 7.6 m of the protected glass.
- within clear view of the protected glass.
- at least 2 m from the floor.
- at least 1 m from forced-air ducts.
- at least 1 m from sirens or bells greater than 5 cm in diameter.
- on a window frame if any heavy window covering is present.

Avoid mounting the detector:

- in a corner.
- on the same wall as the protected glass.
- on free-standing posts or pillars.
- in rooms with noisy equipment such as air compressors, bells, and power tools.

**Sensitivity Settings**

1. If the front housing is attached, carefully open the service door (Item 3, *Figure 10.9* on Page 95).
2. Enable the LEDs for test purposes by sliding the LED ENABLE switch (Item 8, *Figure 10.9* on Page 95) in the direction the arrow points (above the switch). An orange flag protrudes from the side of the detector.  
Refer to *Figure 10.10* on Page 96.



**Figure 10.10** wLSN Glassbreak Sensitivity Switches

|   |                      |
|---|----------------------|
| 1 | Test pads            |
| 2 | Sensitivity switches |



3. Determine the sensitivity setting for your application.  
Refer to *Table 10.12*.


| Sensitivity | SENS1 | SENS2 | Approximate Range |
|-------------|-------|-------|-------------------|
| Maximum     | OFF   | OFF   | 7,6 m             |
| Medium      | ON    | OFF   | 4,6 m             |
| Low         | OFF   | ON    | 3 m               |
| Lowest      | ON    | ON    | 1,5 m             |

**Table 10.12** wLSN Glassbreak Detector Sensitivity Settings

4. Use a small screwdriver to move the sensitivity switches. Use the settings determined in Step 3.
5. Turn on any sources of noise (such as machinery, office, or audio equipment) in the area.
6. Observe the green event LED (Item 6, *Figure 10.9* on Page 95) for approximately 1 min. If the green LED flashes, relocate the unit or reduce the sensitivity by adjusting the sensitivity switch.
7. Repeat Steps 3 through 6 until you achieve the best sensitivity level.
8. After setting the sensitivity, slide the LED enable switch (Item 8, *Figure 10.9* on Page 95) to the OFF position.

**Testing**

Test the detector at least once each year. Test the detector with the 13-332 Sound Sensor Tester.



**Figure 10.11** 13-332 Sound Sensor Tester

|   |                      |
|---|----------------------|
| 1 | Activate/Test switch |
| 2 | Start button         |
| 3 | Flex/Man switch      |

### Entering Test Mode

Place the detector in Test Mode. In Test Mode, the detector's LED disable switch (Item 8, *Figure 10.9* on Page 95) is overridden. You can enter the Test Mode locally or remotely.

To enter the Test Mode locally:

1. Carefully open the service door of the detector.
2. Insert a screwdriver into the slot next to the sensitivity switches that contains the test pads (Item 1, *Figure 10.9* on Page 95).
3. Momentarily short both test pads together with the tip of the screwdriver, or other metallic conductive object.

The Event LED (green) (Item 6, *Figure 10.9* on Page 95) flashes once per sec. If the green LED does not flash, repeat Steps 10 and 11.



### DANGER!

The 13-332 Sound Sensor Tester produces extremely loud sounds and can be hazardous to hearing when used at close range. Do not point the 13-332 towards someone's head.

To enter the Test Mode remotely:

1. Stand within 3 m of the detector.
2. Move the switches on top of the 13-332 Tester to ACTIVATE and to MAN modes (Items 1 and 3, *Figure 10.9* on Page 95).
3. Point the front of the tester towards the detector and press the red Start button on top (Item 2, *Figure 10.9* on Page 95).

The tester buzzes and the green LED on the detector flashes once per sec. If the green LED does not flash, move closer to the detector and repeat the procedure.

### Testing

#### Testing the Detector (Flex and Audio Signals)

1. Set the 13-332 Tester switches to the TEST and FLEX positions (Items 1 and 3, *Figure 10.9* on Page 95).
2. Press the red Start button (Item 2, *Figure 10.9* on Page 95). The tester activates and starts an eight-sec armed period.
3. If window coverings are present, close them fully.
4. Hold the 13-332 Tester near the point on the glass farthest from the detector. If window coverings are present, hold the tester between the glass and window coverings.
5. Carefully strike the glass with a cushioned tool. The 13-332 Tester responds by producing a burst of glass break audio.

If the detector receives both the flex and audio signals properly, its red Alarm LED lights for 3 sec.

If the red LED does not light, return to Section 9.0 RFSS Site Testing on page 81 to reposition the detector.

**Exiting Test Mode**

To exit the Test Mode locally:

1. Carefully open the service door of the detector.
2. Insert a screwdriver into the slot next to the sensitivity switches that contains the test pads (Item 1, *Figure 10.9* on Page 95).
3. Momentarily short both test pads together with the tip of the screwdriver, or other metallic conductive object.

When the detector exits Test Mode, the green Event LED (Item 6, *Figure 10.9* on Page 95) stops flashing. If the Event LED continues to flash, repeat Steps 2 and 3.

To exit the Test Mode remotely:

1. Stand within 3 m of the detector.
2. Move the switches on top of the 13-332 Tester to ACTIVATE and to MAN modes (Items 1 and 3, *Figure 10.9* on Page 95).
3. Point the front of the tester towards the detector and press the red Start button on top (Item 2, *Figure 10.9* on Page 95).


The tester buzzes.

**Entering RFSS Mode with the Wall Tamper Removed**

To enter RFSS Mode if the wall tamper tab is removed:

1. Remove and reinsert the batteries.
2. Press and hold the wall tamper switch.

Refer to *Figure 10.12* on Page 99.



**Figure 10.12** Wall and Cover Tamper Switches

|   |  |
|---|--|
| 1 | Wall tamper switch (back of detector)    |
| 2 | Cover tamper switch (inside of detector) |

3. Quickly press and release the cover tamper switch four times within 10 sec of reinserting the batteries. Refer to *Figure 10.12* on Page 99. The detector enters RFSS Mode.

**Low Battery Indication**

The detector indicates a low battery condition in two ways:

- If the LEDs are enabled, both flash simultaneously every sec.
- A low battery status indication is sent to the control panel.

The LED flashing and a low battery indication at the control panel are independent of each other and do not necessarily occur at the same time. Receiving either condition indicates a low battery.

## 10.19 wLSN Water Sensor/Low-temperature Sensor

The wLSN Water Sensor/Low-temperature Sensor detects water spilled or leaking onto a solid surface. It can also be used to monitor temperature to warn of potential water pipe freezing. If temperatures fall below +7°C (+45°F) for more than 30 sec. the sensor sends a signal to the wLSN Hub.

### Specifications

|                         |                                      |
|-------------------------|--------------------------------------|
| 868 MHz                 | ISW-BWL1-SX                          |
| 915 MHz                 | ISW-BWL1-SY                          |
| Power/Voltage           | Two AA batteries, 2.3 VDC to 3.0 VDC |
| Relative Humidity       | Up to 95%, non-condensing            |
| Temperature (operating) | -10°C to +55°C (+14°F to +131°F)     |
| Temperature (alarm)     | <+7°C (+45°F)                        |
| EN50131-1               | Environmental Class II               |

### Installation Considerations

The wLSN Water Sensor/Low-temperature Sensor is not intended to:

- monitor water levels in storage tanks or other liquids
- be permanently submerged in water
- detect absence of water

### Test and Enable wLSN Water Sensors/Low-temperature Sensors

Test each newly discovered device during the Point Test to enable the device. If specific point numbers are preferred, test devices in the appropriate order.

#### Testing and Enabling When Both Sensors are Required

1. During the Point Test, test the low-temperature sensor first. Refer to *Table 10.13*, Page 100 for instructions.  
The system announces "Point xx was tested."
2. Test the water sensor. Refer to Table 2 for instructions.

#### Testing and Enabling When Only the Water Sensor is Required

During the Point Test, test the water sensor. Refer to *Table 10.13*, Page 100 for instructions. The system announces "Point xx was tested."

#### Testing and Enabling When Only the Low-temperature Sensor is Required


During the Point Test, test the low-temperature sensor. Refer to *Table 10.13*, Page 100 for instructions.

The system announces "Point xx was tested."

Do not connect the water sensor probe.

| Sensor          | To Test  |
|-----------------|--|
| Water           | Select one of the following methods: <ul style="list-style-type: none"> <li>– Short the water probe pins for at least 5 sec. Refer to <i>Figure 10.13</i>, Page 101.</li> <li>– Submerge the water probe in water for at least 5 sec.</li> </ul> |
| Low-temperature | Short the "T" pads for at least 5 sec. Refer to <i>Figure 10.13</i> , Page 101.  |

**Table 10.13** Water Sensor/Low-temperature Sensor Test and Enable Procedures



**Figure 10.13** Enabling the Water Probe and Low-Temperature Functions

|   |                        |
|---|------------------------|
| 1 | Water sensor           |
| 2 | Low-temperature sensor |

# 11 Programming Details and Defaults

This section defines the primary function of the major programming items.

This section also lists the programming defaults for the most frequently used country codes.

## 11.1 Programming Item Programming Details

### 102. Country Code

Select the appropriate code for country-specific operation.

### 107. Fire Bell Cut-off Time

Enter how long the fire alarm sounds at bell outputs and at the control center.

### 108. Intrusion Bell Cut-off Time

Enter how long the intrusion alarm sounds at bell outputs and at the control center.

### 110. Intrusion Abort Window

Enter how long the control panel waits to send an alarm report after an alarm occurs.

### 111. Fire Alarm Cancel Window

Enter how long a user has to cancel a fire alarm report after the system sends the report to the central station. If a fire alarm is acknowledged during the cancel window, the system sends a cancel report to the central station. An entry of 0 disables this feature.

### 112. Intrusion Cancel Window

Enter how long a user has to cancel an intrusion alarm report after the system sends the report to the central station.

### 115. Chime Mode Operation after System Off

Determines Chime Mode operation after the system is turned off.

### 116. Automatic Test Report Frequency

Determines how often the control panel sends the automatic test report.

### 118. RPS Passcode

Enter the 6-digit passcode that allows access to the control panel from RPS.

### 124. Point Alarm Verification

Determines the level of alarm verification required by point before generating an intrusion alarm condition.

### 125. Faulted Points Allowed Threshold

Determines the maximum number of faulted points that are disabled while the system is on.

### 126. Exit Delay

Enter how long the user has to exit the building before the system turns on.

### 127. Entry Delay

Enter how long the user has to enter the building and turn off the system before an alarm condition occurs.

### 131. Swinger Bypass Count

Enter the number of alarm reports allowed from a point while the system is on before the point is bypassed.

### 133. System On Order Options

Determines the order that system-on options are announced to the user.

### 134. Cross Zone Timer

Enter how long the system waits for at least two Cross Zone points to be faulted before the control panel sends a Verified Alarm report to the central station.

**140. Demo Mode**

Demo Mode controls how telephone messages are announced by the system: either only over the telephone, or over the telephone and through all idle control centers (control centers that are not currently engaged in a command). Set Demo Mode to **2** (Demo Mode Auto On/Off). Enter the telephone menu.

On an idle control center, press the [i] button to either turn on or off the announcement of telephone messages through all idle control centers. When you exit the telephone menu and end the phone session, the system turns Demo Mode off.

**142. Restrict Installer Passcode**

If set to 0, the Master User must enable the Installer passcode before a person logged in with the Installer passcode can perform any tasks through the phone menu or RPS; enabling the Installer passcode grants it Level 3 access. The Installer passcode remains at Level 3 until an exit delay.

If set to 0, and the Installer is granted access while the control panel is armed, the programming items are limited.

To enable the Installer Passcode:

1. From the control center, the Master User enables enters the passcode. When the validation for the Master User passcode expires, the Installer passcode is enabled.
2. Using a token, the Master User presents the token several times until the control center speaks "Turning your system off". If the Master User token is presented again, the Installer passcode is disabled.
3. From the phone interface, the Master User enters the passcode, then presses [3] for System Maintenance, [3] for System Test menu, and then [6] to enable the Installer's passcode.

**145. Test Report Day of Week**

Select the day that the control panel sends the test report.

**146. Test Report Day of Month**

Enter the day of the month that the control panel sends the test report.

**148. Arming Beeps/Graduated Annunciation**

Select whether the Intrusion and Intrusion and Fire Output Function types beep when the key fob is used to arm or disarm the control panel.

**150. Wireless Jam Detect Level**

Configure the jam detect level of the wireless devices.

**163. Silence Trouble Tones**

Silence annunciation of trouble tones.

**164. System Inactivity Time (Hours)**

Enter the number of hours that the system must be turned off before it sends the System Inactive report.

**165. System Inactivity Time (Days)**

Enter the number of days that the system must be turned off before it sends the System Inactive report.

**166. System Inactivity Time (Weeks)**

Enter the number of weeks that the system must be turned off before it sends the System Inactive report.

**168. Audio Verification Command Set**

Select the command set that the control panel uses for internal alarm verification. Press the [\*] key on the phone to enable the microphone on the control centers. This allows the central station operator to hear noise on the premises. This option only effects the button presses on the phone while an audio verify session is active between the control panel and the central station operator.

**224. RPS Automatic Call In Time (Hours)****202. PSTN or GSM Connection**

Select the type of telephone connection the system will use to send reports to the central station.

**203. Voice Format Repeat Count**

Enter the number of times the system repeats a voice report during the phone call.

**204. Voice Format Message Delivery Attempts**

Enter how many times the system attempts to deliver a voice format message.

**217. Emergency Call Override Number Delay**

Enter the amount of time the system waits before sending reports if an emergency number is dialed.

**222. Phone Answer Ring Count**

Enter the number of rings before the system answers an incoming call.

**223. Bell Test**

This programming item applies to all Intrusion output functions and to all arming modes.

0 = No closing ring-back or bell test; 1 = Enabled

If closing reports are disabled, the outputs turn on for 1 sec at the end of Exit Delay.

If closing reports are enabled, the outputs turn on for 1 sec when the control panel receives a closing report acknowledgement from the central station.

Select the hour when the control panel calls RPS.

**225. RPS Automatic Call in Time (Minutes)**

Select the minute when the control panel calls RPS.

**227. RPS Automatic Call in Time (Day of Week)**

Select the day of the week when the control panel calls RPS.

**228. RPS Automatic Call in Time (Day of Month)**

Select the day of the month when the control panel calls RPS.

**229. RPS Automatic Call in Phone Number**

Enter the phone number that the control panel uses to call RPS.

**245. RPS Automatic Call in Method**

Select whether the control panel uses a phone number or an IP address to call RPS.

**246. RPS Port Number**

Enter the port number for contacting RPS when the automatic call in occurs over a network connection.

**305. Route Attempts**





Enter the number of times the system attempts each destination in the selected route if the first attempt fails.

**601. Key Fob Duress**

Select whether or not a wireless key fob sends a Duress event when the Arm and Disarm buttons are pressed and held together.



### 611. Output 1 Type

- **Disabled:** Output is disabled.
- **Intrusion:** Output turns on when intrusion alarm occurs. To turn off output, turn off system, or wait until end of intrusion bell cut-off time.
- **Fire:** Output turns on when a fire alarm occurs. To turn off output, turn off system if it is already on, or wait until end of fire bell cut-off time.
- **Fire Latching:** Output turns on when a fire alarm occurs. To turn off output, turn off system if it is already on, or acknowledge alarm if system is off.
- **Intrusion and Fire:** Output turns on when an intrusion or fire alarm occurs. To turn off output, turn off system, or wait until end of bell cut-off time. Fire alarms take priority over intrusion alarms.
- **Intrusion and Fire Latching:** Output turns on when an intrusion or fire alarm occurs. To turn off output, turn off system if it is already on, or acknowledge alarm if system is off. Fire alarms take priority over intrusion alarms.
- **System Reset:** Output is normally on. Output turns off for approximately 10 sec when system is reset. Use this function to supply power to devices such as four-wire smoke detectors that require power interruption to reset a latching alarm condition
- **System On:** Output turns on when the system is turned on, and remains on until system is turned off.
- **System Ready:** Output turns on when the system is ready to turn on (no faulted points or system troubles exist).
- **Key Fob On/Off:** Output turns on or off when the user presses the key fob's  or  key.
- **Key Fob 2-sec Pulse:** Output turns on for two seconds when the user presses the key fob's  or  key.
- **User Controlled:** Output turns on or off when a user or the installer uses the Operate Outputs option from the phone menus.
- **Interior Intrusion and Fire:** Output turns on when an interior intrusion or fire alarm occurs. To turn off output, turn off system, or wait until end of bell cut-off time. Fire alarms take priority over intrusion alarms.
- **System On (Unoccupied):** Output turns on when the system is turned On (Unoccupied) and there are no bypassed or force-armed points.
- **Intrusion and Fire:**
  - Output turns on when any alarm (Intrusion or Fire) occurs. To turn off the output, turn off the system, or wait until the end of the bell cut-off time.
  - When a fire alarm occurs, this output function provides only a steady output (no Temporal Code 3 or Pulsed cadence).
  - Fire alarms take priority over Intrusion alarms.

### 880. Alarm Message Minimum Repeat Time

Enter how long the control center waits between alarm message announcements before repeating the message even if the control center's proximity sensor detects motion.

### 9xx1. Point Types

- **Disabled:** Point is disabled.
- **Perimeter (Entry or Exit):** If faulted and the system is on, Entry Delay starts. An alarm occurs if the system is not turned off when Entry Delay ends.
- **Interior (Follower):** If the system is on occupied, it ignores these points. If the system is on unoccupied, a faulted interior point starts an alarm. These points are ignored during Exit and Entry Delay times.
- **Perimeter Instant:** If faulted when the system is on, a local alarm occurs
- **24-Hour:** If faulted, an alarm always occurs. To restore a 24-hour point, turn the system off if it is on, or acknowledge the alarm if the system is off.
- **Fire Verified:** If faulted, fire verification occurs. If a second fire event occurs during the two-min. wait period, a fire alarm occurs. If no second fire event occurs, the system returns to normal.
- **Fire Instant:** If faulted, a fire alarm always occurs.
- **Silent Panic:** If faulted, an alarm always occurs. There is no visual or audio indication of the alarm.
- **Interior Walkthrough:** If faulted and the system is on custom protection, Entry Delay starts. If the system is on occupied or unoccupied, this point functions as an interior point.
- **Perimeter Exit Cancel:** If faulted and restored during Exit Delay, Exit Delay stops and the system immediately turns on.
- **Momentary Keyswitch:** Turn the system on or off using a momentary keyswitch.
- **Maintained Keyswitch: Turn the system on or off using a maintained keyswitch.**
- **24-Hour Trouble:** If faulted, a trouble condition always occurs. To restore a 24-hour trouble point, turn the system off if it is on, or acknowledge the alarm if the system is off.
- **User Emergency, 24-hour supervisory point type:**
  - If the point's circuit style = **0**, an open or shorted circuit creates a tamper condition. An off-normal circuit creates an alarm condition.
  - If the point's circuit style = **1**, an open or shorted circuit creates an alarm condition.
  - Refer to Circuit Style on page 68 for more information.
  - If User Emergency is assigned to a wireless detector, any off-normal alarm condition creates an alarm condition.
  - To restore a user emergency point, turn the system off if it is on, or acknowledge the alarm if the system is off.

### 9xx6. Alarm Verification

Select whether or not the central station can verify the alarm when it receives an alarm report from the point and the report is acknowledged.

## 11.2 Country Codes

The country code sets the control panel to the appropriate country-specific defaults for your installation.

| Country        | Code | Country              | Code |
|----------------|------|----------------------|------|
| Argentina      | 01   | Israel               | 63   |
| Australia      | 02   | Italy                | 25   |
| Austria        | 03   | Japan                | 26   |
| Belarus        | 62   | Lithuania            | 29   |
| Belgium        | 04   | Luxembourg           | 20   |
| Bosnia         | 65   | Malaysia             | 32   |
| Brazil         | 05   | Mexico               | 34   |
| Bulgaria       | 06   | Netherlands          | 35   |
| Canada         | 07   | New Zealand          | 36   |
| China          | 08   | Norway               | 38   |
| Croatia        | 10   | Poland               | 41   |
| Czech Republic | 12   | Portugal             | 42   |
| Denmark        | 13   | Romania              | 43   |
| Egypt          | 14   | Russian Federation   | 44   |
| Finland        | 16   | Spain                | 51   |
| France         | 17   | Sweden               | 52   |
| Germany        | 18   | Taiwan               | 54   |
| Greece         | 19   | Thailand             | 55   |
| Hong Kong      | 20   | Turkey               | 56   |
| Hungary        | 21   | Ukraine              | 62   |
| India          | 22   | United Arab Emirates | 65   |
| Indonesia      | 23   | United Kingdom       | 57   |
| Ireland        | 24   | United States        | 58   |

## 11.3 Country Code Specific Default Programming Codes

| Prog Item# ↓ | Country Codes |     |     |     |     |     |     |     |     |     |     |     |     |     |
|--------------|---------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|              | 3             | 4   | 6   | 10  | 12  | 13  | 14  | 16  | 17  | 18  | 19  | 21  | 24  | 25  |
| 107          | 5             | 3   | 5   | 5   | 1   | 3   | 5   | 5   | 3   | 5   | 7   | 5   | 15  | 3   |
| 108          | 5             | 3   | 5   | 5   | 1   | 3   | 5   | 5   | 3   | 5   | 7   | 5   | 15  | 3   |
| 125          | 0             | 3   | 3   | 3   | 3   | 0   | 3   | 3   | 3   | 0   | 3   | 3   | 0   | 3   |
| 126          | 60            | 60  | 60  | 60  | 30  | 45  | 60  | 30  | 45  | 60  | 60  | 60  | 45  | 30  |
| 127          | 30            | 30  | 30  | 30  | 30  | 45  | 30  | 25  | 30  | 30  | 30  | 30  | 45  | 20  |
| 133          | 1             | 1   | 1   | 1   | 1   | 3   | 1   | 3   | 3   | 1   | 1   | 3   | 3   | 1   |
| 136          | 0             | 1   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   |
| 137          | 0             | 0   | 0   | 0   | 0   | 1   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   |
| 138          | 0             | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   |
| 204          | 3             | 3   | 1   | 1   | 3   | 3   | 1   | 2   | 3   | 3   | 5   | 3   | 3   | 5   |
| 211          | 0             | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 5   | 3   |
| 212          | 0             | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 5   | 3   |
| 213          | 0             | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 5   | 3   |
| 214          | 0             | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 4   | 3   |
| 216          | 110           | 112 | 000 | 112 | 112 | 112 | 000 | 112 | 112 | 110 | 000 | 112 | 999 | 113 |
| 306          | 0             | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   |
| 9011         | 6             | 1   | 6   | 6   | 1   | 6   | 6   | 6   | 1   | 6   | 6   | 6   | 1   | 1   |
| 9021         | 1             | 3   | 1   | 1   | 2   | 1   | 1   | 1   | 2   | 1   | 1   | 1   | 8   | 3   |
| 9031         | 1             | 3   | 1   | 1   | 2   | 3   | 1   | 2   | 2   | 1   | 3   | 1   | 3   | 3   |
| 9041         | 1             | 3   | 1   | 1   | 2   | 3   | 1   | 2   | 2   | 1   | 3   | 1   | 3   | 3   |
| 9051         | 1             | 3   | 1   | 1   | 2   | 3   | 1   | 3   | 3   | 1   | 2   | 1   | 3   | 2   |
| 9061         | 2             | 3   | 2   | 2   | 2   | 2   | 2   | 3   | 3   | 2   | 2   | 2   | 3   | 2   |
| 9071         | 2             | 3   | 2   | 2   | 2   | 2   | 2   | 4   | 3   | 2   | 2   | 2   | 2   | 2   |
| 9081         | 2             | 3   | 2   | 2   | 2   | 2   | 2   | 3   | 4   | 2   | 4   | 2   | 2   | 4   |
| 9012         | 2             | 0   | 2   | 2   | 2   | 2   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9022         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9032         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9042         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9052         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9062         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9072         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9082         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9092         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9102         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9112         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9122         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9132         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9142         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9152         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9162         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9172         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9182         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |
| 9192         | 2             | 0   | 2   | 2   | 2   | 0   | 2   | 2   | 0   | 2   | 2   | 2   | 0   | 0   |

| Prog Item# ↓ | Country Codes |   |   |    |    |    |    |    |    |    |    |    |    |    |
|--------------|---------------|---|---|----|----|----|----|----|----|----|----|----|----|----|
|              | 3             | 4 | 6 | 10 | 12 | 13 | 14 | 16 | 17 | 18 | 19 | 21 | 24 | 25 |
| 9202         | 2             | 0 | 2 | 2  | 2  | 0  | 2  | 2  | 0  | 2  | 2  | 2  | 0  | 0  |
| 9212         | 2             | 0 | 2 | 2  | 2  | 0  | 2  | 2  | 0  | 2  | 2  | 2  | 0  | 0  |
| 9222         | 2             | 0 | 2 | 2  | 2  | 0  | 2  | 2  | 0  | 2  | 2  | 2  | 0  | 0  |
| 9232         | 2             | 0 | 2 | 2  | 2  | 0  | 2  | 2  | 0  | 2  | 2  | 2  | 0  | 0  |
| 9242         | 2             | 0 | 2 | 2  | 2  | 0  | 2  | 2  | 0  | 2  | 2  | 2  | 0  | 0  |
| 9252         | 2             | 0 | 2 | 2  | 2  | 0  | 2  | 2  | 0  | 2  | 2  | 2  | 0  | 0  |
| 9262         | 2             | 0 | 2 | 2  | 2  | 0  | 2  | 2  | 0  | 2  | 2  | 2  | 0  | 0  |
| 9272         | 2             | 0 | 2 | 2  | 2  | 0  | 2  | 2  | 0  | 2  | 2  | 2  | 0  | 0  |
| 9282         | 2             | 0 | 2 | 2  | 2  | 0  | 2  | 2  | 0  | 2  | 2  | 2  | 0  | 0  |
| 9292         | 2             | 0 | 2 | 2  | 2  | 0  | 2  | 2  | 0  | 2  | 2  | 2  | 0  | 0  |
| 9302         | 2             | 0 | 2 | 2  | 2  | 0  | 2  | 2  | 0  | 2  | 2  | 2  | 0  | 0  |
| 9312         | 2             | 0 | 2 | 2  | 2  | 0  | 2  | 2  | 0  | 2  | 2  | 2  | 0  | 0  |
| 9322         | 2             | 0 | 2 | 2  | 2  | 0  | 2  | 2  | 0  | 2  | 2  | 2  | 0  | 0  |
| 814          | 0             | 1 | 0 | 0  | 1  | 1  | 0  | 0  | 1  | 0  | 0  | 0  | 2  | 0  |
| 824          | 0             | 1 | 0 | 0  | 1  | 1  | 0  | 0  | 1  | 0  | 1  | 0  | 2  | 2  |
| 834          | 0             | 1 | 0 | 0  | 1  | 1  | 0  | 0  | 1  | 0  | 1  | 0  | 2  | 2  |
| 844          | 0             | 1 | 0 | 0  | 1  | 1  | 0  | 0  | 1  | 0  | 1  | 0  | 2  | 2  |
| 861          | 4             | 6 | 4 | 4  | 4  | 4  | 4  | 6  | 6  | 4  | 4  | 6  | 4  | 4  |
| 611          | 5             | 5 | 5 | 5  | 5  | 5  | 5  | 5  | 14 | 5  | 5  | 5  | 5  | 5  |
| 621          | 5             | 5 | 5 | 5  | 5  | 5  | 5  | 5  | 5  | 5  | 5  | 5  | 5  | 6  |
| 631          | 5             | 6 | 7 | 7  | 7  | 7  | 7  | 7  | 6  | 5  | 7  | 7  | 1  | 8  |
| 641          | 5             | 7 | 5 | 5  | 5  | 6  | 5  | 5  | 7  | 5  | 5  | 5  | 9  | 5  |
| 642          | 0             | 1 | 0 | 0  | 1  | 1  | 0  | 0  | 1  | 0  | 0  | 0  | 0  | 1  |
| 121          | 2             | 2 | 2 | 2  | 2  | 2  | 8  | 2  | 2  | 2  | 2  | 2  | 2  | 2  |
| 600          | 0             | 1 | 1 | 1  | 1  | 1  | 1  | 1  | 1  | 0  | 1  | 1  | 1  | 1  |
| 115          | 0             | 2 | 2 | 0  | 2  | 2  | 0  | 0  | 2  | 0  | 0  | 0  | 0  | 2  |
| 116          | 0             | 0 | 0 | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 1  | 0  | 0  |
| 128          | 1             | 1 | 0 | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  |
| 132          | 0             | 0 | 1 | 1  | 1  | 0  | 1  | 0  | 0  | 0  | 1  | 1  | 1  | 0  |
| 147          | 0             | 0 | 0 | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 1  | 0  |
| 153          | 1             | 1 | 1 | 1  | 1  | 0  | 1  | 1  | 1  | 1  | 1  | 1  | 0  | 1  |
| 159          | 0             | 1 | 1 | 1  | 1  | 1  | 1  | 1  | 1  | 0  | 1  | 1  | 1  | 0  |
| 160          | 1             | 1 | 1 | 1  | 1  | 1  | 0  | 1  | 1  | 1  | 1  | 1  | 1  | 1  |
| 344          | 3             | 3 | 3 | 3  | 3  | 3  | 3  | 3  | 3  | 3  | 3  | 3  | 3  | 3  |
| 403          | 3             | 3 | 3 | 3  | 3  | 3  | 3  | 3  | 3  | 3  | 3  | 3  | 3  | 3  |
| 9015         | 6             | 6 | 6 | 6  | 6  | 6  | 6  | 5  | 4  | 6  | 6  | 6  | 6  | 6  |
| 9025         | 6             | 6 | 6 | 6  | 6  | 6  | 6  | 5  | 4  | 6  | 6  | 6  | 6  | 6  |
| 9035         | 6             | 6 | 6 | 6  | 6  | 6  | 6  | 5  | 4  | 6  | 6  | 6  | 6  | 6  |
| 9045         | 6             | 6 | 6 | 6  | 6  | 6  | 6  | 5  | 4  | 6  | 6  | 6  | 6  | 6  |
| 9055         | 6             | 6 | 6 | 6  | 6  | 6  | 6  | 5  | 4  | 6  | 6  | 6  | 6  | 6  |
| 9065         | 6             | 6 | 6 | 6  | 6  | 6  | 6  | 5  | 4  | 6  | 6  | 6  | 6  | 6  |
| 9075         | 6             | 6 | 6 | 6  | 6  | 6  | 6  | 5  | 4  | 6  | 6  | 6  | 6  | 6  |
| 9085         | 6             | 6 | 6 | 6  | 6  | 6  | 6  | 5  | 4  | 6  | 6  | 6  | 6  | 6  |
| 163          | 1             | 0 | 1 | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  |
| 168          | 0             | 0 | 0 | 0  | 0  | 0  | 0  | 0  | 1  | 0  | 0  | 0  | 0  | 0  |

| Prog Item# ↓ | Country Codes |     |     |     |     |     |     |     |     |     |     |     |     |
|--------------|---------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
|              | 29            | 30  | 35  | 38  | 41  | 42  | 43  | 44  | 51  | 52  | 53  | 56  | 57  |
| 107          | 5             | 3   | 3   | 5   | 5   | 2   | 5   | 5   | 2   | 5   | 5   | 5   | 15  |
| 108          | 5             | 3   | 3   | 5   | 5   | 2   | 3   | 5   | 2   |     | 5   | 5   | 15  |
| 125          | 3             | 3   | 3   | 3   | 3   | 8   | 3   | 3   | 3   | 3   | 0   | 3   | 0   |
| 126          | 60            | 60  | 60  | 60  | 60  | 30  | 30  | 60  | 30  | 60  | 60  | 60  | 45  |
| 127          | 30            | 30  | 20  | 30  | 30  | 30  | 15  | 45  | 20  | 30  | 30  | 30  | 45  |
| 133          | 1             | 1   | 3   | 3   | 1   | 3   | 1   | 3   | 3   | 3   | 1   | 1   | 4   |
| 136          | 0             | 0   | 0   | 0   | 0   | 0   | 1   | 0   | 0   | 0   | 0   | 0   | 0   |
| 137          | 0             | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   |
| 138          | 0             | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   |
| 204          | 1             | 3   | 3   | 3   | 1   | 2   | 1   | 1   | 3   | 3   | 3   | 1   | 3   |
| 211          | 0             | 0   | 0   | 0   | 0   | 3   | 0   | 1   | 1   | 0   | 0   | 0   | 5   |
| 212          | 0             | 0   | 0   | 0   | 0   | 0   | 0   | 1   | 1   | 0   | 0   | 0   | 5   |
| 213          | 0             | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 5   |
| 214          | 0             | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   | 0   |
| 216          | 000           | 112 | 000 | 112 | 000 | 112 | 000 | 000 | 000 | 112 | 110 | 000 | 000 |
| 306          | 0             | 0   | 0   | 0   | 0   | 0   | 0   | 1   | 0   | 0   | 0   | 0   | 0   |
| 9011         | 6             | 1   | 6   | 6   | 6   | 6   | 6   | 6   | 6   | 6   | 6   | 6   | 1   |
| 9021         | 1             | 3   | 1   | 1   | 1   | 1   | 1   | 1   | 1   | 1   | 1   | 1   | 8   |
| 9031         | 1             | 3   | 1   | 2   | 1   | 2   | 1   | 2   | 2   | 2   | 1   | 1   | 3   |
| 9041         | 1             | 3   | 1   | 2   | 1   | 2   | 1   | 2   | 2   | 2   | 1   | 1   | 3   |
| 9051         | 1             | 3   | 1   | 2   | 1   | 2   | 1   | 2   | 2   | 2   | 1   | 1   | 3   |
| 9061         | 2             | 3   | 2   | 2   | 2   | 2   | 2   | 2   | 2   | 2   | 2   | 2   | 3   |
| 9071         | 2             | 3   | 2   | 2   | 2   | 2   | 2   | 2   | 2   | 2   | 2   | 2   | 2   |
| 9081         | 2             | 3   | 2   | 2   | 2   | 2   | 2   | 2   | 2   | 2   | 2   | 2   | 2   |
| 9012         | 2             | 0   | 2   | 2   | 2   | 2   | 2   | 2   | 0   | 2   | 2   | 2   | 0   |
| 9022         | 2             | 0   | 0   | 0   | 2   | 2   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9032         | 2             | 0   | 0   | 0   | 2   | 2   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9042         | 2             | 0   | 0   | 0   | 2   | 2   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9052         | 2             | 0   | 0   | 0   | 2   | 2   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9062         | 2             | 0   | 0   | 0   | 2   | 2   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9072         | 2             | 0   | 0   | 0   | 2   | 2   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9082         | 2             | 0   | 0   | 0   | 2   | 2   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9092         | 2             | 0   | 0   | 0   | 2   | 0   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9102         | 2             | 0   | 0   | 0   | 2   | 0   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9112         | 2             | 0   | 0   | 0   | 2   | 0   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9122         | 2             | 0   | 0   | 0   | 2   | 0   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9132         | 2             | 0   | 0   | 0   | 2   | 0   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9142         | 2             | 0   | 0   | 0   | 2   | 0   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9152         | 2             | 0   | 0   | 0   | 2   | 0   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9162         | 2             | 0   | 0   | 0   | 2   | 0   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9172         | 2             | 0   | 0   | 0   | 2   | 0   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9182         | 2             | 0   | 0   | 0   | 2   | 0   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |
| 9192         | 2             | 0   | 0   | 0   | 2   | 0   | 2   | 2   | 0   | 0   | 2   | 2   | 0   |

| Prog Item# ↓ | Country Codes |    |    |    |    |    |    |    |    |    |    |    |    |
|--------------|---------------|----|----|----|----|----|----|----|----|----|----|----|----|
|              | 29            | 30 | 35 | 38 | 41 | 42 | 43 | 44 | 51 | 52 | 53 | 56 | 57 |
| 9202         | 2             | 0  | 0  | 0  | 2  | 0  | 2  | 2  | 0  | 0  | 2  | 2  | 0  |
| 9212         | 2             | 0  | 0  | 0  | 2  | 0  | 2  | 2  | 0  | 0  | 2  | 2  | 0  |
| 9222         | 2             | 0  | 0  | 0  | 2  | 0  | 2  | 2  | 0  | 0  | 2  | 2  | 0  |
| 9232         | 2             | 0  | 0  | 0  | 2  | 0  | 2  | 2  | 0  | 0  | 2  | 2  | 0  |
| 9242         | 2             | 0  | 0  | 0  | 2  | 0  | 2  | 2  | 0  | 0  | 2  | 2  | 0  |
| 9252         | 2             | 0  | 0  | 0  | 2  | 0  | 2  | 2  | 0  | 0  | 2  | 2  | 0  |
| 9262         | 2             | 0  | 0  | 0  | 2  | 0  | 2  | 2  | 0  | 0  | 2  | 2  | 0  |
| 9272         | 2             | 0  | 0  | 0  | 2  | 0  | 2  | 2  | 0  | 0  | 2  | 2  | 0  |
| 9282         | 2             | 0  | 0  | 0  | 2  | 0  | 2  | 2  | 0  | 0  | 2  | 2  | 0  |
| 9292         | 2             | 0  | 0  | 0  | 2  | 0  | 2  | 2  | 0  | 0  | 2  | 2  | 0  |
| 9302         | 2             | 0  | 0  | 0  | 2  | 0  | 2  | 2  | 0  | 0  | 2  | 2  | 0  |
| 9312         | 0             | 1  | 0  | 0  | 0  | 1  | 0  | 0  | 0  | 0  | 0  | 0  | 2  |
| 9322         | 0             | 1  | 0  | 0  | 0  | 1  | 0  | 0  | 0  | 0  | 0  | 0  | 2  |
| 814          | 0             | 1  | 0  | 0  | 0  | 1  | 0  | 0  | 0  | 0  | 0  | 0  | 2  |
| 824          | 0             | 1  | 0  | 0  | 0  | 1  | 0  | 0  | 0  | 0  | 0  | 0  | 2  |
| 834          | 0             | 1  | 0  | 0  | 0  | 1  | 0  | 0  | 0  | 0  | 0  | 0  | 2  |
| 844          | 4             | 6  | 4  | 4  | 4  | 4  | 4  | 4  | 4  | 4  | 4  | 4  | 4  |
| 861          | 5             | 5  | 5  | 5  | 5  | 5  | 5  | 1  | 5  | 5  | 5  | 5  | 5  |
| 611          | 5             | 5  | 5  | 5  | 5  | 5  | 5  | 3  | 5  | 5  | 5  | 5  | 5  |
| 621          | 7             | 6  | 5  | 7  | 7  | 7  | 7  | 7  | 7  | 7  | 5  | 7  | 1  |
| 631          | 5             | 7  | 5  | 6  | 5  | 8  | 5  | 5  | 5  | 6  | 5  | 5  | 5  |
| 641          | 0             | 1  | 1  | 1  | 0  | 1  | 0  | 1  | 1  | 1  | 0  | 0  | 0  |
| 642          | 2             | 2  | 2  | 2  | 2  | 2  | 2  | 2  | 2  | 2  | 2  | 2  | 2  |
| 121          | 1             | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 0  | 1  | 1  |
| 600          | 0             | 2  | 0  | 0  | 0  | 0  | 0  | 2  | 0  | 0  | 0  | 0  | 0  |
| 115          | 0             | 0  | 0  | 0  | 0  | 0  | 1  | 1  | 2  | 0  | 0  | 0  | 0  |
| 116          | 1             | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  |
| 128          | 1             | 0  | 0  | 0  | 1  | 1  | 1  | 0  | 0  | 0  | 0  | 1  | 0  |
| 132          | 0             | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 1  |
| 147          | 1             | 1  | 0  | 0  | 1  | 1  | 1  | 0  | 1  | 1  | 1  | 1  | 0  |
| 153          | 1             | 1  | 1  | 1  | 1  | 1  | 1  | 0  | 1  | 1  | 0  | 1  | 1  |
| 159          | 1             | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  |
| 160          | 3             | 3  | 3  | 3  | 3  | 3  | 3  | 1  | 3  | 3  | 3  | 3  | 0  |
| 344          | 3             | 3  | 3  | 3  | 3  | 3  | 3  | 1  | 3  | 3  | 3  | 3  | 3  |
| 403          | 6             | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  |
| 9015         | 6             | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  |
| 9025         | 6             | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  |
| 9035         | 6             | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  |
| 9045         | 6             | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  |
| 9055         | 6             | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  |
| 9065         | 6             | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  |
| 9075         | 6             | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  |
| 9085         | 6             | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  | 6  |
| 163          | 1             | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  | 1  |
| 168          | 0             | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 0  | 0  |

# 12 Agency Approvals and Requirements

## 12.1 Certifications and Approvals

Compliance with specific standards, such as SIA CP-01 and DD243, reduces false alarms and is required in many locations.

The Easy Series Intrusion Control Panel is designed to comply with the following certifications, approvals, and standards:

|   |  |
|---|--|
| <ul style="list-style-type: none"> <li>- ANSI/SIA CP-01 False Alarm Immunity</li> <li>- <b>CE</b></li> <li>- EN50131-1 Security Grade 2, Environmental Class II*</li> <li>- EN 50131-3, EN 50131-5-3, EN 50131-6, IP30 - IK04 (EN50529 - EN50102 )</li> <li>- DD243*</li> <li>- PD6662*</li> <li>- CCC*</li> <li>- UL Standards:             <ul style="list-style-type: none"> <li>- UL365, Police Station Burglar Alarm Units and systems</li> <li>- UL609, Local Burglar Alarm Units and Systems</li> <li>- UL985, Household Fire Warning System Units</li> <li>- UL1023, Household Burglar-alarm System Units</li> <li>- UL1076, Proprietary Burglar Alarm Units and Systems</li> </ul> </li> </ul> | <ul style="list-style-type: none"> <li>- cUL Standards:             <ul style="list-style-type: none"> <li>- CAN/ULC-S545, Residential Fire Warning System Control Units</li> <li>- CAN/ULC-S545, Residential Fire Warning System Control Units</li> <li>- CAN/ULC-S303, Local Burglar Alarm Units and Systems</li> <li>- C1076, Proprietary Burglar Alarm Units and Systems</li> <li>- C1023, Household Burglar Alarm Units</li> </ul> </li> <li>- FCC</li> <li>- Industry of Canada (IC)</li> <li>- A-Tick*</li> <li>- C-Tick*</li> <li>- TBR21 for PSTN*</li> <li>- INCERT (Belgium) *</li> <li>- CSFM Listing - Control Unit Household</li> <li>- Japan Approvals Institute for Telecommunications Equipment (JATE) *</li> </ul> |
|---|--|

\* Not investigated by Underwriters Laboratories, Inc.



**NOTICE!**

The ITS-DX4020-G has not been tested by UL.



## 12.2

### FCC

#### Part 15

This equipment was tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy. If this equipment is not installed and used according to this document, it might cause harmful interference to radio communications.

Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user must correct the interference.

#### Part 68

This equipment complies with Part 68 of FCC rules. A label contains, among other information, the FCC registration number and ringer equivalency number (REN). If requested, this information must be provided to the telephone company.

The Bosch Security Systems Easy Series Intrusion Control Panel is registered for connection to the public telephone network using an RJ38X or RJ31X jack.

The REN determines the number of devices that can be connected to the telephone line. Excessive REN's on the telephone line might result in the devices not ringing in response to an incoming call. In most, but not all areas, the sum of the REN's should not exceed five. To determine the number of devices that can be connected to the telephone line, contact the telephone company for the maximum REN for the calling area.

The telephone company notifies you if this equipment harms the telephone network. If advance notice is not practical, the telephone company notifies the customer as soon as possible. Also, you are advised of your right to file a complaint with the FCC if you believe it is necessary to do so.

The telephone company might make changes in its facilities, equipment, operation, or procedures that could affect the operation of this equipment. If this happens, the telephone company provides advance notice so you can make the necessary modifications for maintaining uninterrupted service.

If you experience trouble with the Easy Series Intrusion Control Panel, contact Bosch Security Systems Customer Service for repair and warranty information. If the trouble harms the telephone network, the telephone company might request that you remove the equipment from the network until the problem is resolved. User repairs must not be made, and doing so voids the user's warranty.

This equipment cannot be used on public coin service provided by the telephone company. Connection to party line service is subject to state tariffs. Contact your state public utilities commission for more information.

- **FCC Registration Number:** US:ESVAL00BEZ1; **Ringer Equivalence:** 0.0B
- **Service Center:** Contact your Bosch Security Systems, Inc. representative for the location of your service center.

## 12.3 Industry Canada

This product meets the applicable Industry Canada technical specifications. The ringer equivalence number (REN) for this terminal equipment is 0.0. The REN assigned to each terminal equipment indicates the maximum number of terminals allowed to be connected to a telephone interface. The termination of an interface can consist of any combination of devices subject only to the requirement that the sum of the REN of all devices does not exceed five.

## 12.4 SIA

### Programming Requirements

To comply with ANSI/SIA CP-01 False Alarm Reduction, set these programming items as follows:

| Programming Item        | Item Number | Default | Section Starting Page |
|-------------------------|-------------|---------|-----------------------|
| Intrusion Abort Window  | 110         | 30 sec  | Page 43               |
| Intrusion Cancel Window | 112         | 5 min   |                       |
| Exit Delay              | 126         | 60 sec  |                       |
| Entry Delay             | 127         | 30 sec  |                       |
| Swinger Bypass Count    | 131         | 1       |                       |
| Auto Protection Level   | 132         | 1       |                       |

To comply with ANSI/SIA CP-01 False Alarm Reduction, by default, this system:

- Sends Intrusion Alarm Verified and Exit Error reports
- Sends a Recent Closing report for any alarm that occurs within two min of the end of Exit Delay
- Includes a Fire Verified point type option that is disabled by default

## Quick Reference

Refer to the following table for programmable features, shipping defaults, and recommended programming that comply with the ANSI/SIA CP-01 False Alarm Reduction standard.

The system test button tests all points, all outputs, the control panel, and the communicator.

Refer to *Section 8.1 Test the System*, page 61 for more information.

| Paragraph Number in ANSI/SIA CP-01 | Feature   | Requirement                             | Range  | Shipping Default             | Recommended Programming <sup>1</sup>     |
|------------------------------------|---|---|--|------------------------------|--|
| 4.2.2.1                            | Exit Time   | Required (programmable)                 | For full or auto arming: 45 sec to 2 min (255 sec max)                   | 60 sec                       | 60 sec                                   |
| 4.2.2.2                            | Progress Annunciation/ Disable for Silent Exit              | Allowed                                 | Individual control centers can be disabled.                              | All control centers enabled. | All control centers enabled.             |
| 4.2.2.3                            | Exit Time Restart   | Required Option                         | For re-entry during Exit Time  | Enabled                      | Enabled                                  |
| 4.2.2.5                            | Auto Stay Arm on Unvacated Premises                         | Required option (except for remote arm) | If no exit after full arm  | Enabled                      | Enabled                                  |
| 4.2.4.4                            | Exit Time and Progress Annunciation/ Disable for Remote Arm | Allowed option (for remote arm)         | Can be disabled for remote arm   | Enabled                      | Enabled                                  |
| 4.2.3.1                            | Entry Delay(s)  | Required (programmable)                 | 30 sec to 4 min <sup>2</sup>   | 30 sec                       | At least 30 sec <sup>2</sup>             |
| 4.2.5.1                            | Abort Window for Non-fire Zones                             | Required option                         | Can be disabled by zone or zone type                                     | Enabled                      | Enabled (all zones)                      |
| 4.2.5.1                            | Abort Window Time for Non-fire Zones                        | Required (programmable)                 | 15 sec to 45 sec <sup>2</sup>  | 30 sec                       | At least 15 sec <sup>2</sup>             |
| 4.2.5.1.2                          | Abort Annunciation  | Required option                         | Annunciate that no alarm was transmitted                                 | Enabled                      | Enabled                                  |
| 4.2.5.4.1                          | Cancel Annunciation   | Required option                         | Annunciate that a Cancel was transmitted                                 | Enabled                      | Enabled                                  |
| 4.2.6.1 and 4.2.6.2                | Duress Feature  | Allowed Option                          | No 1+ derivative of another user code; no duplicates of other user codes | Disabled                     | Disabled                                 |
| 4.3.1                              | Cross Zoning  | Required Option                         | Programming needed   | Disabled                     | Enabled and two or more zones programmed |
| 4.3.1                              | Programmable Cross Zoning Time                              | Allowed                                 | Can program  | Per manufacturer             | Per walk path in protected premises      |
| 4.3.2                              | Swinger Shutdown  | Required (programmable)                 | For all non-fire zones, shut down at one or two faults                   | One fault                    | One fault                                |
| 4.3.2                              | Swinger Shutdown Disable                                    | Allowed                                 | For non-police response zones  | Enabled                      | Enabled (all zones)                      |

| Paragraph Number in ANSI/SIA CP-01  | Feature                 | Requirement     | Range                                | Shipping Default | Recommended Programming <sup>1</sup>   |
|---|-------------------------|-----------------|--------------------------------------|------------------|--|
| 4.3.3   | Fire Alarm Verification | Required option | Depends on control panel and sensors | Disabled         | Enabled unless sensors can self-verify |
| 4.5   | Call Waiting Cancel     | Required option | Depends on user phone line           | Disabled         | Enabled if user has call waiting       |
| <sup>1</sup> Programming at installation site might be subordinate to other UL requirements for the intended application.<br><sup>2</sup> Combined Entry Delay and Abort Window should not exceed 1 minute.<br><sup>3</sup> If the cross zone timer ends and a second cross zone point is not faulted, the system sends an intrusion alarm unverified report. |                         |                 |                                      |                  |  |

## 12.5 Underwriters Laboratories (UL)

### Household Fire Warning System

- Install at least one UL Listed four-wire latching type smoke detector rated to operate over the voltage range of 11.2 VDC to 12.3 VDC. The maximum smoke detector load is 50 mA.
- Install one UL Listed 85 dB audible device rated to operate over the range of 11.2 VDC to 12.3 VDC as required for this application. Program the bell cut-off time for at least four minutes. Refer to Programming Item 107 in *Section 5.2.2 System Programming Items*, page 43.
- Install end-of-line resistor P/N: 47819 after last smoke detector.
- Do not use a printer interface module.
- Where two-wire addressable devices are used, do not place fire and intrusion devices on the same zone.
- The system must be able to operate for at least 24 hr, and generate a full alarm output for at least 4 min without AC power.

### Household Burglar Alarm Unit

- Install at least one UL Listed 85 dB audible device rated to operate over the voltage range of 11.2 VDC to 12.3 VDC.
- Install at least one IUI-EZ1 Control Center.
- Program all zones to use end-of-line supervision.
- Install intrusion initiating devices rated to operate over the voltage range of 11.2 VDC to 12.3 VDC.
- Program all intrusion zones for audible notification.
- Do not exceed 60 sec when programming Exit Delay. Refer to Programming Item 126 in *Section 5.2.2 System Programming Items*, page 43. Do not exceed 45 sec when programming Entry Delay. Refer to Programming Item 127 in *Section 5.2.2 System Programming Items*, page 43. Program the bell cut-off time for at least of four minutes. Refer to Programming Item 108 in *Section 5.2.2 System Programming Items*, page 43.
- The system must be able to operate for at least 24 hr, and generate a full alarm output for at least 4 min without AC power.

### **Commercial Burglary, Local**

- Use the D8108A Attack Resistant Enclosure with the D2402 Mounting Skirt.
- Install at least one UL Listed 85 dB audible device rated to operate over the voltage range of 11.2 VDC to 12.3 VDC. All wiring connections between the control panel and device must be in conduit.
- Do not exceed 60 sec when programming Exit Delay. Refer to Programming Item 126 in *Section 5.2.2 System Programming Items*, page 43. Do not exceed 60 sec when programming Entry Delay. Refer to Programming Item 127 in *Section 5.2.2 System Programming Items*, page 43.
- Install a tamper switch to protect the enclosure door.
- Set Programming Item 116 to 1 (Daily) to ensure the automatic test report is sent on a daily basis. Refer to *Section 5.2.2 System Programming Items*, page 43.
- Ensure that the integrated communicator is enabled (Programming Item 304 = 0; refer to *Section Global Report Routing Items*, page 52). Ensure that the system can send low battery reports (Programming Item 358 = 1, 2, or 3; refer to *Section System Report and Restoral Routing*, page 51).
- Install at least one IUI-EZ1 Control Center.
- Program the bell cut-off time for at least 15 minutes. Refer to Programming Item 108 in *Section 5.2.2 System Programming Items*, page 43.
- This system was not evaluated for Bank Safe and Vault applications.
- The system must be able to operate for at least 24 hr, and generate a full alarm output for at least 15 min without AC power.

### **Commercial Burglary, Police Station Connected Protected Premises\***

- Refer to *Section Commercial Burglary, Local*, page 117 for installation requirements.
- Ensure that the integrated communicator is enabled (Programming Item 304 = 0; refer to *Section Global Report Routing Items*, page 52).

\* Systems are approved for Encrypted Line Security when used in conjunction with the C900V2 Conettix IP Dialer Capture Module and communicating over a packet-switched data network (PSDN).

### **Commercial Burglary, Proprietary\***

- The integrated communicator is enabled (Programming Item 304 = 0; refer to *Section Global Report Routing Items*, page 52).
- The system has one owner.
- The system must be able to operate without AC power for at least 24 hours. The central station receiver must be able to receive reports without AC power for at least 24 hours.

\* Systems are approved for Encrypted Line Security when used in conjunction with the C900V2 Conettix IP Dialer Capture Module and communicating over a packet-switched data network (PSDN).

## 12.6 PD6662 and DD243 Requirements

To comply with PD6662 and DD243, you must meet all of the EN50131-3 requirements and the following requirements:

- **Maintenance:** A qualified technician must check the system at least twice a year.
- **AC Power Supply:**
  - **Type:** A
  - **Rated Voltage:** 230 V
  - **Rated Input Frequency:** 50 Hz
  - **Rated Input Current:** 250 mA maximum
  - **Fuse Rating:** 0.25 A, 250 V Slow Blow
- **Construction Materials:** Enclosures and housings for the control panel, control center, DX2010, wireless hub, and wireless devices are made from materials that are durable, secure, and resistant to attack by hand-held tools.
- **Confirmed Alarms:** Set Expert Programming Item Number 124 to either Option 3 or 4.  
Refer to *Section 5.2.2 System Programming Items*, page 43 for more information.

The Easy Series Intrusion Control Panel is designed to comply with PD6662:2004 as a Grade 2 system that supports Notification Options A, B, C, or X with the appropriate notification devices installed (devices not included with system).

## 12.7 EN50131 Requirements

The Easy Series Intrusion Control Panel is designed to comply with EN50131-1 Security Grade 2, Environmental Class II.

|   |
|---|
| <b>Installation, Programming, and Maintenance</b>   |
| <b>Installation:</b> Refer to <i>Section 2.2 Install System Components</i> , page 13.   |
| <b>Programming:</b> Refer to <i>Section 5 Programming</i> , page 37.  |
| <b>Testing:</b> Refer to <i>Section 8 System Test and Maintenance</i> , page 61.  |
| <b>Maintenance:</b> Refer to <i>Section 8 System Test and Maintenance</i> , page 61.  |
| <b>Power Supply (AC and Standby Battery)</b>  |
| <b>AC Power Supply:</b> Refer to <i>Section 10.2 Control Center</i> , page 75.  |
| <b>Standby Battery:</b> Refer to <i>Section 10.2 Control Center</i> , page 75.  |
| <b>Automatic Inhibit</b>  |
| <b>Intruder Alarm and Fault Signal or Message:</b> Set <i>Expert Programming Item Number 131</i> to a value between 1 and 3. Refer to <i>Section 5.2.2 System Programming Items</i> , page 43 for more information. |
| <b>Authorization Code:</b> Set <i>Expert Programming Item Number 892</i> to a value between 3 and 8. Refer to <i>Section 5.2.8 Control Center Programming Items</i> , page 55 for more information.                 |
| <b>Logical and Physical Keys</b>  |
| <b>Minimum Number of Combinations per User:</b>   |
| – <b>Passcodes:</b> 15,625 (passcode length must be six digits)   |
| – <b>Tokens:</b> 42,000,000,000   |
| – <b>Key Fobs:</b> 2,800,000,000,000,000  |
| <b>Method Used to Determine Number of Combinations:</b>   |
| – <b>Passcodes:</b> Digits 1 to 5 are allowed. For a six-digit passcode, all combinations are allowed.  |
| – <b>Tokens:</b> 32 bits. All combinations are allowed.   |
| – <b>Key Fobs:</b> 56 bits (48 serialized during manufacturing, 8 remain static)  |
| <b>Operating Temperature Range</b>  |
| Refer to <i>Environmental Considerations</i> on Page 72.  |
| <b>Control Panel and Control Center Current Consumption</b>   |
| <b>Control Panel:</b> Refer to <i>Section 10.1 Control Panel</i> , page 72.   |
| <b>Control Center:</b> Refer to <i>Section 10.1 Control Panel</i> , page 72.  |
| <b>Output Current Rating</b>  |
| Refer to <i>Programmable Outputs</i> on Page 72.  |

To comply with EN50131-1, set these programming items as follows:

| Programming Item                | Item Number | Setting                           | Section Starting Page |
|---------------------------------|-------------|-----------------------------------|-----------------------|
| Programming Key Auto Transfer   | 123         | Select Option 0                   | Page 43               |
| Entry Delay                     | 127         | Set to 45 sec or less             |                       |
| Swinger Bypass Count            | 131         | Select Option 3                   |                       |
| Restrict Installer Passcode     | 142         | Select Option 1                   |                       |
| RPS Automatic Call In Frequency | 224         | Select Option 0                   | Page 49               |
| Passcode Length                 | 861         | Set passcode length to six digits | Page 56               |

## 12.8 INCERT

To comply with INCERT, set these programming items as follows:

| Programming Item   | Item Number | Default  | Section Starting Page |
|--|-------------|----------|-----------------------|
| Restrict Installer Passcode  | 142         | 1        | Page 43               |
| Passcode Length  | 861         | 6 digits |                       |
| Invalid Passcode Attempt   | 892         | 3*       |                       |
| Control Center Lockout Time  | 893         | 3*       | Page 56               |
| * To comply with INCERT, set these programming items to 3 or higher. |             |          |                       |

## 12.9 cUL

For Canadian installations, install systems according to ULC-S302. Systems that use the C900V2 Conettix IP Dialer Capture Module meet Level 3 Line Security when communicating over a packet-switched data network (PSDN).

## 12.10 NF A2P

If you modify system parameters you are responsible for maintaining the system within the scope of the standard and regulations that apply to the hardware and/or the system in which it is used. In a NF A2P compliant installation, use only NF A2P listed components, and check that each parameter is in the authorized range.

### Accessories Authorized in a Certified Installation

| Part            | Description                                  |
|-----------------|--|
| IUI-EZ1         | Control Center                               |
| NP17-12IFR      | 17AH Yuasa Battery                           |
| ICP-EZPK        | Flash memory                                 |
| EZPS-FRA        | Power supply for motion detectors and sirens |
| IPP-PSU-2A5     | Supervised Auxiliary power supply            |
| ICP-EZVM-FRF    | Voice module in French                       |
| ISW-BHB1-WXFR   | wLSN Hub                                     |
| ISW-BK-F1-H5X   | wLSN keyfob                                  |
| ISW-BDL1-W11PHX | wLSN Tri-tech motion detector 11 x 11 m      |
| ISW-BPR1-W13PX  | PIR wLSN motion detector 12 x 12 m           |
| ISW-BMC1-S135X  | wLSN magnetic contact wLSN                   |
| ISW-BMC1-M82X   | wLSN mini contact                            |
| ISW-BMC1-R135X  | wLSN recessed contact                        |
| ISW-BIN-S135X   | wLSN Choc and magnetic contact               |
| ISW-BSM1-SX     | wLSN smoke detector                          |
| ISW-BGB1-SAX    | wLSN Glass break detector                    |
| ISW-BSR1-WX     | wLSN sounder                                 |
| ISW-BRL1-WX     | wLSN output relay                            |
| DX2010          | 8 wire zones expansion board                 |



### Siren Wiring in a NF A2P Certified Installation

Use only sirens with backup battery. Sirens which require a primary voltage of 14.4V can be powered by the optional module EZPS-FRA, or the auxiliary power supply IPP-PSU-2A5. Bring the hold-on +12V through panel PO1, set it as the interior siren, as shown on the siren installation guide. Depending on the current requirement of the siren battery, the hold-on + voltage can be taken from the orange terminal, white terminal, +14.4V of the siren power output of optional board EZPS-FRA, or one of the outputs of auxiliary power supply IPP-PSU-2A5.



**NOTICE!**

In a NF A2P certified installation, the power supply used to feed the battery of the siren shall not be used to feed the motion detectors.

### Motion Detectors Wiring in a NF A2P Certified Installation

Power for motion detectors shall be separated from power for sirens. Power for motion detectors can either come from the white terminal + and -, or by the optional board EZPS-FRA when the number of motion detector requires separate power lines, or by the auxiliary power supply IPP-PSU-2A5.

### Panel Configuration in a NF A2P Certified Installation

Check that each parameter is in the range of authorized values for NF A2P certified installations.

### Current Chart in a NF A2P Type 2 Certified Installation

To meet the 36 hours of backup power, check that the current required by all the equipments used in the system is lower than the backup current available:

- Max current in idle state: 465 mA (i.e. 270 mA of current for the panel , with one control center)
- Max current in alarm: 1000 mA (i.e. 675 mA of current for the panel, with one control center)

Refer to the chart below.

| Module   | Max Current in Idle State |       | Max Current In Alarm State |        |              |
|--|---------------------------|-------|----------------------------|--------|--------------|
|  | I Max                     |       | Total                      | I Max  | Total        |
| Easy Series Control Panel  | 85 mA                     | x1    | 85 mA                      | 160 mA | x1 160 mA    |
| Current for the panel: <b>A</b>                                  |                           |       | ....mA                     |        | ...mA        |
| IUI-EZ1 Control Center (at least 1)                              | 110 mA                    | x Qty |                            | 165 mA | xQty         |
| Current on the option bus: <b>B</b>                              |                           |       | ....mA                     |        | ....mA       |
| Motion detector(s)   |                           | x Qty |                            |        | x Qty        |
| Siren(s)   |                           | x Qty |                            |        | x Qty        |
| (Autre)  |                           | x Qty |                            |        | x Qty        |
| Total aux current: <b>C</b>                                      |                           |       | ...mA                      |        | ...mA        |
| <b>Total A + B + C</b>   |                           |       | <b>...mA</b>               |        | <b>...mA</b> |
| Max backup current available, with a 17 AH battery (type 2, 36H) |                           |       | 465 mA                     |        | 1000 mA      |

## Current Chart of the Aux Power Supply IPP-PSU-2A5

When the current required by additional components is higher than the backup current available from the panel with the 17AH battery, add one or several auxiliary power supply IPP-PSU-2A5.

The IPP-PSU-2A5 provides also the 14.5V output required by the siren batteries.

| Module  | Max Current in Idle State |       | Max Current In Alarm State |                      |       |              |
|---|---------------------------|-------|----------------------------|----------------------|-------|--------------|
|   | I Max                     |       | Total                      | I Max                | Total |              |
| IPP-PSU-2A5   | 55 mA                     | x1    | 55 mA                      | 55 mA                | x1    | 55 mA        |
| Detector(s)   |                           | x Qty |                            |                      | xQty  |              |
| Siren(s)  |                           | x Qty |                            |                      | x Qty |              |
| Control Center(s)   |                           | x Qty |                            |                      | x Qty |              |
| Total aux current: <b>C</b>   |                           |       | ...mA                      |                      |       | ...mA        |
| Total in Idle State   |                           |       | <b>...mA</b>               | Total in alarm state |       | <b>...mA</b> |
| Max backup current available, with a 17 AH battery  |                           |       | 465 mA                     |                      |       | 750 mA       |
| <p>The IPP-PSU-2A5 auxiliary power supply provide a protection against the deep discharge of the battery (active at idle state) and status LEDs. This current has to be taken into account in the current chart.</p> <p>Max. available current in idle state: 465 mA.</p> <p>Max. current in alarm: 750 mA.</p> |                           |       |                            |                      |       |              |

### NOTICE!



For Aux power supply supervision, use an input from the panel or from a DX2010, with a two resistors wiring (alarm and tamper)

- Connect the output relay "trouble" from the aux power supply to a 24hr/24hr input.  
Record the zone name with a text meaning "AC loss aux power supply"
- On the tamper zone, connect the tamper contact of the aux power supply enclosure

### Controller Recorder Wiring

To connect a controller / recorder, connect the coil inpu of the recorder to + and - of PO2, PO3 and/or PO4.

Set the output as follows:

- To record the state "arm unoccupied", set the output to "armed unoccupied"
- To record the state "alarm", set the corresponding output to "intrusion and fire 2" (reversed level)

### Programming Items

To comply with NF A2P, set these programming items as follows:

| Programming Item                    | Item Number | NF A2P Approved Range   | Section Starting Page |
|-------------------------------------|-------------|-------------------------|-----------------------|
| Country Code                        | 102         | 17                      | Page 43               |
| Enclosure Tamper Enabled            | 103         | 1                       |                       |
| Fire Bell Cut-off Time              | 107         | 2 or 3                  |                       |
| Intrusion Bell Cut-off Time         | 108         | 2 or 3                  |                       |
| Intrusion Abort Window              | 110         | 0                       |                       |
| Point Alarm Verification            | 124         | 0                       |                       |
| Entry Delay                         | 127         | Shorter than Exit Delay |                       |
| Auto Protection Level               | 132         | 0                       |                       |
| Latching Point and Enclosure Tamper | 137         | 1                       |                       |
| Latching System Device Tamper       | 138         | 1                       |                       |
| Restrict Installer Passcode         | 142         | 1                       |                       |
| Start Arming With Faulted Points    | 159         | 0                       |                       |
| Passcode Length                     | 861         | 6                       | Page 56               |
| Circuit Style                       | 9xx2*       | 0                       | Page 52               |
| Response Time                       | 9xx5*       | 4 or 5                  |                       |

\* The middle digits = the point number. For example, "01" = Point 1, and "32" = Point 32.

**Table 12.1** NF A2P Certified Configuration Values




**NOTICE!**

For supervised points (dual EOL), 2.2k Ω EOL resistors (P/N: 47819) required.

### Seal the Enclosure

1. Open the pre-opened hole which is on the right of the enclosure.
2. Pass the sealing wire through this hole, and bring the two wires in the corresponding hole of the enclosure door.
3. Seal the sealing lead as near as possible from the enclosure.



**Figure 12.1** Enclosure Sealing

|   |                               |
|---|-------------------------------|
| 1 | Enclosure                     |
| 2 | Sealing Location (pre-opened) |
| 3 | Right side of the enclosure   |
| 4 | Right side of the door        |
| 5 | Sealing lead                  |



**Bosch Security Systems, Inc.**

130 Perinton Parkway

Fairport, NY 14450

(800) 289-0096

**[www.boschsecurity.com](http://www.boschsecurity.com)**

© Bosch Security Systems, Inc., 2008