




## Folded Brochure



BACK

### PRODUCT OVERVIEW



### TF (MICRO SD) CARD

1. Slide the OFF/ON switch to the ON position.
2. Insert TF (Micro SD) card into the TF (Micro SD) Card slot. Sound message "Play by TF Card" is voiced and music will stream automatically.
3. Long press **▶/+** or **◀/-** button to increase or decrease the volume.
4. Press **▶/+** or **◀/-** to move forward or backward on your playlist.
5. Press **▶/-** to play or pause a track.

### "AUX-IN" JACK

1. Slide the OFF/ON switch to the ON position.
2. Plug the 3.5mm AUX-in jack to AUX port of the speaker and another side to the audio device (such as phone / computer / tablet / etc.).
3. You hear sound message "AUX mode".
4. Select your favourite song from the source device.

**Note:** While using AUX-in, all functions such as Skip Forward/Backward and Volume control will operate from your audio device.

Long press **▶/+** or **◀/-** button to increase or decrease the volume.

### FM RADIO

1. Slide the OFF/ON switch to the ON position.
2. Plug the USB charging cord (included) to the DC 5V charging port of the speaker; **this serves as FM Antenna as well**.
3. Short press **Mode** button until you hear sound message "FM mode".
4. Press **▶/-** button once and the device will automatically search and store all the FM Radio stations.
5. Long press **▶/+** or **◀/-** button to increase or decrease the volume.
6. Short press **▶/+** or **◀/-** to change the FM Radio station.

## BLUETOOTH SPEAKER PRODUCT MANUAL

*This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference & (2) this device must accept any interference received, including interference that may cause undesired operation.*

*Note: changes or modifications not expressly approved which could void the user's authority to operate this equipment.*

### FEATURES

- Battery Voltage:3.7V Capacity: 400mAh S/N:85Db
- Range: Up to 33ft(10m)
- Charging Time: 1 hour
- Play Time: 2 hours @ 50% Volume

### SPECIFICATION

- AUX Input Plug makes it easy to listen to music from your PC or iPod/iPhone.
- Bluetooth Handsfree works using Bluetooth connectivity for wireless communication.
- Stereo Bluetooth Speaker supports A2DP/AVRCP, allowing you to enjoy quality wireless music.

### IMPORTANT NOTES

- This product is not a toy.
- Do not drop or damage the speaker.
- Do not use in humid or extreme temperatures.
- Do not place the speaker near an open flame.
- Do not block the sound of the speaker while it is in use.
- Do not use the unit if it has been dropped or damaged in any way.
- If damaged, do not attempt to repair or disassemble the speaker.

### BLUETOOTH PAIRING

1. Slide the OFF/ON switch to the ON position.
2. You will hear the indication tone with sound message "Bluetooth Mode"; speaker is now in pairing mode.
3. Place the speaker and Bluetooth device (phone or music device) so that they are no further than 1 meter apart.
4. Activate the Bluetooth function on your Bluetooth device (phone or music device). Please refer to the manufacturer's instruction manual to enable Bluetooth on your device.
5. Select the speaker "Light-Up BT Speaker" from the list of available Bluetooth devices.

### FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### MULTI FUNCTION BUTTONS

**Mode** A long press of this button will reject calls. In AUX mode this button will be AUX exchange.

**◀/-** In Bluetooth mode, press this button to skip to the previous song. This does not work in AUX mode. Hold this button down for longer to decrease the volume.

**▶/-** In Bluetooth mode, press this button to: Play / Pause / Answer / End / Cancel Dial.

**▶/+** In Bluetooth mode, press this button to skip to the next song. This does not work in AUX mode. Hold this button down for longer to increase the volume.

### TIPS

1. Press **Mode** button to switch different functions of the speaker. Order of the functions is: Bluetooth / FM Radio.

2. Turn **OFF** the device when not in use to save power.

### CHARGING

The speaker includes a built in rechargeable battery. It is recommended to charge the battery fully prior to first use.

Connect the USB cable to a computer or other USB charging port and the Mini USB plug into the charging port of the speaker.