



CURRENTAUDIO®



SB800

SB650

SB500

Instruction Manual

Safety Instructions

1. Read these instructions completely prior to use or hook-up.
2. Keep these instructions for future reference. Record Model Number_____ and Serial Number _____
3. Understand and heed all warnings.
4. Follow all instructions.
5. Do not use soundbar or subwoofer near water, rain or high moisture.
6. Clean only with a dry cloth. Never use solvents. A microfiber cloth is recommended.
7. Do not block any of the ventilation openings. See Instructions.
8. Do not install near heat sources such as stoves, radiators and amplifiers.
9. Use only with supplied power sources, with polarized power cord.
10. Protect power cord from being walked on or pinched. Do not have cord stretched taut.
11. Use only connections and auxiliary equipment suggested by manufacturer.
12. Unplug this system during lightning storms or when left unattended for extended periods.
13. Use an ILS-120 to protect from surges, over/under voltages and lightning strikes.
14. Refer service to qualified service personnel.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operation or maintenance instructions.



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of non insulated dangerous voltages within the product's enclosure that may be sufficient magnitude to constitute a risk of electric shock to people.

WARNING
TO REDUCE THE RISK OF
ELECTRIC SHOCK, DO NOT
EXPOSE THIS EQUIPMENT
TO RAIN OR MOISTURE

CAUTION
TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER OR BACK. NO
USER-SERVICABLE PARTS INSIDE. REFER TO
QUALIFIED SERVICE PERSONNEL.

Thank you for purchasing the Current Audio Home Theater Soundbar.

Please read this manual thoroughly before making any connections or applying AC power. This manual applies to the SB800, SB650 and SB500 Soundbar Systems. Follow the instructions in this manual. It will allow you to obtain the maximum performance and listening pleasure from your new soundbar. Please retain this manual to use as a future reference.

Supplied accessories

The boxes include the following equipment and accessories:

- (1) Soundbar
- (1) 100 - 240VAC to 18VDC power supply
- (1) RCA stereo audio cable
- (1) 3.5mm stereo audio cable
- (1) Hand held remote control unit
- (1) 2.4GHz wireless MegaBass unit with power cord
- (1) Wall mounting brackets with screws
- (2) Table Top Mounting feet
- (1) Instruction Manual

Specifications

Soundbar Power	60 Watts RMS	120 Watts Peak
Subwoofer Power	80 Watts RMS	180 Watts Peak
Total Power	140 Watts RMS	300 Watts Peak
SPL	103.6dB	
Sound Mode	3 Enhanced DSP Surround Modes	
Speakers	8 Speakers. 6 2.5" Midrange Drivers and 2 1.25" Tweeters	
Subwoofer	2.4GHz 8" Long Throw Ported Woofer	
BLUETOOTH®	Connectivity for iPhone, Android, MP3 and PC	
Audio Inputs	Digital Optical, Digital Coaxial RCA, 3.5mm	
Frequency Response	20 Hz to 20 kHz	
Soundbar Dimensions (weight)	39 ⁹ / ₁₆ " (1005mm) x 3 ¹ / ₂ " (89mm) x 3 ⁵ / ₁₆ " (84mm) 9lbs	
Subwoofer Dimensions (weight)	17 ¹ / ₈ " (435mm) x 8 ¹¹ / ₁₆ " (221mm) x 14 ¹ / ₄ " (362mm) 21 lbs	


Soundbar SB800, SB650 and SB500 by Current Audio

The SB800, SB650 and SB500 Soundbar describes the latest digital technology in amplified speaker sound bars with a powerful wireless amplified subwoofer by Current Audio. The powerful subwoofer can be located anywhere in the room. This is the perfect Home Theater System with a wide sound stage. The system comes with a handheld remote to control power, switch inputs and adjust sound fields. The slim depth and sleek design blends with all flat LED/LCD TV models.

Features and Connections for Soundbar

Rear panel of Soundbar

1. RCA - analog inputs, left and right analog stereo input
2. COAXIAL digital input - supports 2 channel or PCM bitstreams
3. OPTICAL digital input - supports 2 channel or PCM bitstreams (SB800/SB650 models only)
4. AUX IN - 3.5mm audio jack for TV, MP3, computers, mobile devices, etc
5. Power switch - rear panel switch to cut power for service or hook-up
6. Input power jack - connect the 18VDC power supply here



INSTALLATION

Getting started

Soundbar placement

Where to locate Soundbar

Either mount the soundbar on a flat horizontal surface centered in front of the TV or surface wall mount the soundbar on the wall via the key hole slots. Use proper wall anchors to support the weight of the soundbar.



Where to locate subwoofer

Install the wireless subwoofer preferably near the front wall next to an electrical outlet. The power cord is the only wire needed for hook-up. Corner placement will give an added bass boost.


Making connections

Caution: All connections and switching should be done with the AC power switched OFF.

The final connection should be the power cords.

INPUTS

The inputs are located on the back of the soundbar. They include 18VDC power, analog RCA, Digital Optical, Digital Coaxial and 3.5mm jack



Connecting source equipment to analog inputs on the soundbar:

- RCA inputs, using the supplied RCA cables, connect the source equipment to the soundbar. Connect red cable end to red jack, white cable end to white jack.
- Aux input, use a 3.5mm male plug to connect to the jack on the back of the soundbar.
- Using analog inputs is the easiest manner to connect source equipment to the soundbar. In most instances (check the manufacturer's manual) you can connect all source equipment to a television using HDMI, digital coax, digital optical or RCA connections and the 3.5mm or RCA output of the TV will be an analog 2 channel signal. No menu changes on source equipment will be necessary. If you are having trouble using the optical or coax digital inputs on the soundbar use one of the analog inputs. They are very low noise and very high quality, in most instances it is difficult to notice a difference in sound quality.

INSTALLATION

Making connections (cont.)

Connecting with BLUETOOTH® devices:

- Press the BLUETOOTH® button on the remote control until the blue LED on the soundbar is visible.
- Take the BLUETOOTH® active device (laptop, phone, tablet, etc) and turn on the BLUETOOTH® function.
- Scan for devices and you will find the soundbar.
- Pair or connect with the soundbar.
- Play the music as desired.

Connecting the soundbar with the wireless subwoofer:

- In most cases this is not necessary. The subwoofer is paired with the soundbar from the factory. However, if necessary take the following steps to connect the soundbar to the subwoofer wirelessly.
- Continuously press the Match button on the remote control until the LED is visibly blinking on the soundbar.
- While the LED is still blinking on the soundbar, continuously press the button on the rear of the subwoofer next to the blue LED until the LED starts to blink. Use of a paper clip or similar item will be necessary to access the button.
- When the LED on the subwoofer blinks and the LED is still blinking on the soundbar, release the button on the subwoofer and the two will connect to each other.
- It may take a few seconds for this connection to be made. Repeat the process as necessary to make the connection.

Connecting source equipment to an Optical or Coax Digital input on the soundbar:

- Both digital optical and digital coax inputs on the soundbar support 2 channel or PCM digital bitstreams.
- All source equipment must be set to either 2 channel or PCM output.
- No sound will be present on the soundbar if this setting is not made when the digital optical or digital coax input is used on the soundbar.
- If you connect your equipment (satellite/cable box, BluRay player, etc) to your TV via HDMI cables and then connect the TV to the soundbar via digital coax or digital optical connection you must set each source device to 2 channel or PCM output.
- Shown below are some examples of setting source equipment to 2 channel or PCM mode. Most equipment is similar, please consult your owner's manual for exact instructions.
- DirecTV satellite receivers:
 - Select the menu button on the remote control
 - Select settings
 - Select audio settings
 - Under audio settings select Dolby Digital and Select OFF
 - Press exit on the remote


INSTALLATION

Making connections (cont.)

- Dish Network satellite receivers:
 - Select the menu button on the remote control
 - Select settings
 - Select audio settings
 - Select PCM Only
 - Press save
 - Press exit on the remote
- Most common cable box receivers:
 - Select the menu button on the remote control
 - Select settings
 - Select audio settings
 - Select stereo output
 - Select exit
 - If there is no option for audio settings use the RCA or 3.5mm inputs
 - Please consult your cable box receiver manufacturer's manual if the information above is not correct
- Most common BluRay players:
 - Without a disc in the player select the home button or main menu button on the remote control. You want to choose the setup menu for the player not a disc
 - In most cases you will use the arrow keys on the remote control to navigate to a settings icon or menu selection
 - Select audio setup
 - Select PCM audio or 2 channel output
 - If the BluRay player has an option to select PCM down sampling mode then press ON or YES to allow PCM down sampling
 - If the BluRay player has an option to select down-mixing mode then select normal stereo mode
 - Please consult your BluRay player manufacturer's manual if the information above is no correct
- Most common televisions:
 - Select the menu button on the remote control
 - Select settings
 - In some instances select speaker settings or TV sound output
 - Turn off the TV speakers. Some manufacturers will not allow sound to be output from the TV outputs when the TV speakers are actively playing
 - Select audio, audio format or sound settings. The names vary by manufacturer
 - Ensure that the audio format for digital output or the SPDIF output is set to 2 channel or PCM mode
 - Press exit or the menu again to return to the home screen
 - If there is no sound from the soundbar when using the digital output from the TV use the RCA or 3.5mm inputs to connect to the soundbar
 - Please consult your television manufacturer's manual if the information above is not correct

INSTALLATION

Remote control functions



Universal remote codes:

The soundbar is compatible with many different universal remote controls supplied with satellite receivers, cable box receivers, AV receivers, televisions. Please refer to the on-line link for further information.

Trouble	Possible Cause	Possible Solution
No sound	Unit not plugged into AC power	Check that the rear power switch on the soundbar is turned on. The LED lights on the soundbar and on the power supply for the soundbar should be visible.
	Audio cable not properly connected	Check cable connections. Replace cable. Check if connected to proper inputs.
	Audio cable not properly connected	Connect a phone or other similar device to the 3.5mm jack on the rear of the soundbar. If sound is present check all cables, connectors and source devices. Fault may be with one of them. If the problem is with the coaxial or optical digital input then try to use an analog input. If the analog input works then check the menu settings in the equipment for 2 channel or PCM operation.
	Master power switch on rear	Place master power switch to on.
	Front power switch	Switch from standby to on
	Change to proper input	Change from any input back to desired input.
	Optical input has 2 channel signal	Insure TV/DVD is set to 2 channel audio out.
	No audio from subwoofer	Soundbar and subwoofer not matched
Volume turned down		Turn up sub volume
Remote control not responding correctly	Remote not directed to receive window	Aim remote to receive window on soundbar.
	Remote too far from soundbar	Move to within 8 meters of soundbar
	Remote batteries weak or dead	Change batteries

For further assistance please contact us at:
USA 1-866-927-7181



This product conforms to all EU Directive requirements as applicable by law. The complete Declaration of Conformity can be found at compliance.currentaudio.com

Limited 1 Year Warranty

Current Audio, LLC soundbars are warranted to be free from defects in materials and/or workmanship to the original retail purchaser for a period of 1 year, provided the equipment was purchased and installed from a Current Audio authorized dealer or distributor.

In the event of defective materials and/or workmanship, Current Audio, LLC will repair or replace, at its option, the defective product at no charge to the purchaser. In order to make claim under this warranty and to obtain performance of any obligation under warranty, please contact Current Audio, LLC or your authorized distributor. Instructions will be given on how to return the defective product to Current Audio, LLC. Returned products must be shipped prepaid. Proof of purchase must be provided with the product.

The warranty does not apply to damage not resulting from defective materials and or workmanship while in the possession of the original consumer or due to unreasonable use by the original owner, which includes but not limited to improper installation, negligence, unauthorized repair or modification, or aesthetic deterioration from the environment. Products purchased by internet or unauthorized sources will void the warranty and not be honored.

Current Audio, LLC is not liable for any incidental or consequential damages, so the above limitations or inclusion may not apply to you. This warranty gives you specific legal rights, and you may have other rights, which vary from state to state within the United States.

FCC Certification Requirements

Caution: Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**