



Cisco TelePresence Multipoint Switch Release 1.1 Administration Guide

August 4, 2008

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Customer Order Number:
Text Part Number: OL-12586-02

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

CCDE, CCENT, Cisco Eos, Cisco StadiumVision, the Cisco logo, DCE, and Welcome to the Human Network are trademarks; Changing the Way We Work, Live, Play, and Learn is a service mark; and Access Registrar, Aironet, AsyncOS, Bringing the Meeting To You, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, CCVP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Collaboration Without Limitation, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Event Center, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, iQuick Study, IronPort, the IronPort logo, LightStream, Linksys, MediaTone, MeetingPlace, MGX, Networkers, Networking Academy, Network Registrar, PCNow, PIX, PowerPanels, ProConnect, ScriptShare, SenderBase, SMARTnet, Spectrum Expert, StackWise, The Fastest Way to Increase Your Internet Quotient, TransPath, WebEx, and the WebEx logo are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0803R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

Cisco TelePresence Multipoint Switch Release 1.1 Administration Guide
© 2008 Cisco Systems, Inc. All rights reserved.



CONTENTS

| | |
|--|-----|
| General Description | 1-5 |
| New in CTMS Release 1.1 | 1-6 |
| Increase in the Number of Supported Segments | 1-6 |
| Cisco TelePresence Interoperability With Legacy Video Conferencing Devices | 1-6 |
| System Requirements | 1-6 |
| <i>CTMS Administration Guide</i> Organization | 1-6 |
| Obtaining Documentation, Obtaining Support, and Security Guidelines | 1-7 |

Using CTMS Administration Software 1-9

| | |
|----------------------|------|
| Contents | 1-9 |
| Overview | 1-9 |
| Administrative Roles | 1-10 |
| User Interface | 1-10 |
| Header | 1-11 |
| System Status | 1-11 |
| Navigation Pane | 1-12 |
| Content Area | 1-12 |
| System Information | 1-12 |

Configuring Cisco Unified Communications Manager for CTMS 2-13

| | |
|--|------|
| Contents | 2-13 |
| Overview | 2-13 |
| Prerequisites | 2-14 |
| Logging into the Unified CM Administration Application | 2-14 |
| Creating a SIP Trunk Security Profile | 2-14 |
| Creating a SIP Trunk | 2-15 |
| Configuring a Route Pattern | 2-16 |

Installing CTMS Administration Software 3-17

| | |
|---|------|
| Contents | 3-17 |
| Prerequisites | 3-17 |
| Installing the CTMS Administration Software | 3-18 |

Configuring CTMS Administration Software 4-21

| | |
|----------|------|
| Contents | 4-21 |
|----------|------|

| | |
|---|------|
| Overview | 4-21 |
| System Settings | 4-22 |
| Editing IP Settings | 4-22 |
| Editing Access Settings | 4-23 |
| Configuring and Editing QoS Settings | 4-24 |
| Configuring and Editing Resource Management | 4-28 |
| Configuring and Editing SNMP Settings | 4-29 |
| Restarting CTMS | 4-31 |
| Importing and Exporting Files | 4-32 |
| Cisco Unified Communications Manager Settings | 4-32 |
| Configuring and Editing Unified CM Settings | 4-33 |
| Configuring and Editing SIP Profile Settings | 4-33 |
| Configuring and Editing Cisco TelePresence Manager Settings | 4-35 |
| Configuring and Editing Access Management | 4-36 |
| Upgrading Software Version | 4-40 |
| Interface Failover | 4-41 |

Managing Meetings 5-43

| | |
|--|------|
| Contents | 5-43 |
| Overview | 5-43 |
| Defining and Editing Default Settings | 5-43 |
| Creating and Editing Static Meetings | 5-45 |
| Ad Hoc Meetings | 5-49 |
| Creating and Editing Ad Hoc Meetings | 5-49 |
| Creating and Editing Meeting Templates | 5-51 |
| Viewing Scheduled Meetings | 5-54 |
| Viewing and Editing Active Meetings | 5-55 |

Troubleshooting the CTMS System 6-59

| | |
|---|------|
| Contents | 6-59 |
| Overview | 6-59 |
| Viewing CTMS Alarms and System Error Messages | 6-60 |
| Configuring the Severity Level of System Error Messages | 6-62 |
| Filtering the Log File Table Listings | 6-63 |
| Downloading Log Files | 6-64 |
| Troubleshooting Specific Issues | 6-64 |

Monitoring CTMS System Processes 7-67

[Contents 7-67](#)

[Overview 7-67](#)

[Monitoring System Status 7-68](#)

[Monitoring and Restarting System Processes 7-69](#)

[Viewing Call Statistics 7-70](#)

[Room Testing 7-72](#)

Interoperability with Legacy Video Conferencing Devices 8-75

[Contents 8-75](#)

[Overview 8-75](#)

[How Cisco TelePresence Interoperability Works 8-75](#)

[Benefits 8-77](#)

[Caveats 8-77](#)

[Prerequisites 8-78](#)

[Configuring Cisco TelePresence Interoperability 8-79](#)

[Configuring Unified CM for Cisco TelePresence Interoperability 8-79](#)

[Creating a SIP Trunk Security Profile 8-79](#)

[Creating a SIP Trunk 8-80](#)

[Configuring a Route Pattern 8-80](#)

[Configuring CUVC for Cisco TelePresence Interoperability 8-81](#)

[Configuring CTMS for Cisco TelePresence Interoperability 8-85](#)

[Creating Static Meetings in CTMS for Interoperability 8-85](#)

[Troubleshooting Cisco TelePresence Interoperability 8-88](#)

Command Line Interface (CLI) Commands A-1

[Tables of Contents A-1](#)

[Introduction A-1](#)

[Starting a CLI Session A-1](#)

[CLI Command Basics A-2](#)

[Ending a CLI Session A-2](#)

[CTMS CLI Commands A-2](#)



Preface

Initial Release: May 5, 2008, OL-12586-02
Last Revised: August 4, 2008

General Description

The Cisco TelePresence Multipoint Switch (CTMS) is designed to support multipoint (multi-location) Cisco TelePresence meetings for up to 48 table segments (48 single-screen systems, 16 three-screen systems, or a mix of both) in a single meeting. [Table 1](#) summarizes some of the features of the CTMS:

Table 1 *CTMS Features*

| Feature | Benefit |
|--|---|
| Scalability | CTMS is designed to support small workgroup applications to large Cisco TelePresence multipoint meetings. Up to 48 table segments are supported. |
| Simple scheduling and “one-button-to-push” dialing | CTMS and integration to Cisco TelePresence System Manager (CTS-Manager) allows scheduling through the enterprise calendar (for example, Microsoft Outlook) and easy one-button-to-push call launch for both point-to-point and multipoint meetings. |
| Scheduled and non-scheduled meeting support | During an active meeting, the conference manager can add another party using the CTMS Administration software. |
| Audio add-on | Audio only participants can be added to any multipoint meeting using the audio add-on feature supported by CTS endpoints. |
| Video switching | Voice-activated site and segment video switching supported. |
| Video announce | Upon joining the meeting, Cisco TelePresence rooms will be shown to all other rooms for two seconds. This prevents a muted room from joining without being noticed. |
| Comprehensive diagnostics | Diagnostics features include system status information, alarms, downloadable error logs and Simple Network Management Protocol (SNMP) support. |
| Call detail records | Call records provide meeting beginning and ending information as well as meeting participant details. |

New in CTMS Release 1.1

Increase in the Number of Supported Segments

CTMS Release 1.1 now supports up to 48 table segments (48 single-screen systems, 16 three-screen systems, or a mix of both) in a single Cisco TelePresence conference.

Cisco TelePresence Interoperability With Legacy Video Conferencing Devices

Cisco TelePresence is based on open standards, including SIP, H.264, AAC-LD and G.711. With Cisco TelePresence System (CTS) Release 1.3 and CTMS Release 1.1, Cisco TelePresence now supports interoperability between Cisco TelePresence systems and traditional video conferencing/video telephony endpoints using the Cisco Unified Video Conferencing 3500 series MCU (CUVC).

System Requirements

- Cisco MCS-7845-H2 or MCS-7845-I2 Media Convergence Server
- Cisco TelePresence Manager, Release 1.3
- Cisco Unified Communications Manager (Unified CM), Release 6.0 or later
- Cisco TelePresence System software, Release 1.3
- CTS-1000 and/or CTS-3000 systems

CTMS Administration Guide Organization

The *CTMS Administration Guide* is organized into the following chapters:

- Chapter 1: “Using CTMS Administration Software”
This section provides information about the CTMS Administration software interface
- Chapter 2: “Configuring Cisco Unified Communications Manager for CTMS”
This section provides instructions on how to configure Cisco Unified Communications Manager (Unified CM) so that it supports CTMS functionality.
- Chapter 3: “Installing CTMS Administration Software”
This section describes how to install the CTMS administration software on the Cisco MCS-7800 Series Media Convergence Server.
- Chapter 4: “Configuring CTMS Administration Software”
This section provides information about configuring the initial CTMS system settings.
- Chapter 5: “Managing Meetings”
This section describes how to set up and administer static and ad hoc meetings using CTMS Administration software.
- Chapter 6: “Monitoring CTMS System Processes”
This section describes how to monitor the CTMS system processes using the tools available in CTMS.

- Chapter 7: “Troubleshooting the CTMS System”
This section describes how to view and categorize system error messages and alerts, and how to filter and download log files.
- Chapter 8: “Interoperability with Legacy Video Conferencing Devices”
This section describes how to configure settings in Unified CM ,CTMS and Cisco Unified Video Conferencing MCUs (CUVC) to support Cisco TelePresence Interoperability.
- Appendix A: “Command Line Interface (CLI) Commands:
This section includes CLI commands that can be used to configure CTMS.

Obtaining Documentation, Obtaining Support, and Security Guidelines

For information on obtaining documentation, obtaining support, providing documentation feedback, security guidelines, and also recommended aliases and general Cisco documents, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>



CHAPTER 1

Using CTMS Administration Software

Initial Release: May 5, 2008, OL-12586-02
Last Revised: August 4, 2008

Contents

- [Overview, page 1-9](#)
- [User Interface, page 1-10](#)
- [System Information, page 1-12](#)

Overview

Administrators use the CTMS Administration software to configure, to maintain, to monitor and to troubleshoot multipoint switching. Administrative tasks include the following:

- **Configuring system settings.** These tasks include configuring general system settings, Cisco TelePresence Manager (CTS-Manager) settings, and access management settings (such as administrative roles). System settings tasks are described in “Chapter 4: Configuring CTMS Administration Software.”
- **Managing meetings.** These tasks include defining meeting templates, defining static and ad hoc meetings and managing active meetings, as well as being able to observe information about scheduled meetings. Meeting management tasks are described in “Chapter 5: Managing Meetings.”
- **Monitoring the system.** These tasks include restarting the system and monitoring a variety of system processes. System monitoring tasks are described in “Chapter 6: Monitoring CTMS System Processes.”
- **Troubleshooting the system.** These tasks include monitoring system errors and log files to determine the causes of system errors. Troubleshooting is described in “Chapter 7: Troubleshooting the CTMS System.”

Prior to configuring CTMS Administration software, you must configure Cisco Unified Communications Manager (Unified CM) to support multipoint switching. Unified CM for CTMS configuration tasks are described in “Chapter 2: Configuring Cisco Unified Communications Manager for CTMS.”

Installing CTMS Administration software is described in “Chapter 3: Installing CTMS Administration Software.”

Administrative Roles

CTMS administration software recognizes three different administrative roles; access to task folders is dependent on defined administrative roles.

- **Administrators:** Administrators have the authority to perform all tasks associated with CTMS, including configuring system settings, managing multipoint meetings, maintaining, monitoring and troubleshooting CTMS. Administrators have access to all folders in CTMS Administration software.
- **Meeting Scheduler:** Meeting Schedulers have the authority to perform multipoint meeting management tasks, such as defining meeting templates, and setting up (and breaking down, as necessary) ad hoc, static and scheduled meetings. Meeting Schedulers have access to the Meeting Management folder in CTMS Administration software.
- **Diagnostic Technicians:** Diagnostic Technicians have the authority to perform CTMS monitoring and troubleshooting tasks. Diagnostic Technicians have access to the Troubleshooting and Monitoring folders in CTMS Administration software.

Administrative role configuration is described in “Chapter 4: Configuring CTMS Administration Software.”

User Interface

CTMS Administration software user interface is similar to the interface used in Cisco TelePresence System Administration software and Cisco TelePresence Manager software. The user interface is organized as follows:

- [Header, page 1-11](#)
- [System Status, page 1-11](#)
- [Navigation Pane, page 1-12](#)
- [Content Area, page 1-12](#)

[Figure 1-1](#) shows an example of the CTMS Administration software user interface.

Figure 1-1 CTMS Administration Software User Interface

Header

The header at the top of all CTMS Administration windows lists the name of the software application and provides links for the following functions:

- **Admin**—Roll your cursor over “Admin” to display the name of the user current logged in to CTM Administration.
- **Logout**—Click to log out of the system.
- **Help**—Click to display online help for using the CTMS Administration.
- **About**—Click to display software version and licensing information.

System Status

System status is always in view in the lower left corner of the CTMS Administration window. The system status is updated every 60 seconds. Click the **Refresh** button in the upper right corner of the box to obtain an immediate update.

The system status box shows the following information:

- **Active meetings:** Shows the number of meetings currently in progress.
- **Errors:** Shows the total number of system errors that are defined as either CRIT or ERROR. If the total number of system errors is 0, a green check is displayed. If the total number of system errors is more than 0, a red cross is displayed. System errors are described in “Chapter 7: Troubleshooting the CTMS System.”

- **Warnings:** Shows the total number of system errors defined as WARN. If the total number of system errors is 0, a green check is displayed. If the total number of system errors is more than 0, a red cross is displayed. System warnings are described in “Chapter 7: Troubleshooting the CTMS System.”
- **Status:** Shows the current state of all system processes. If all system processes are in the RUNNING state, a green check is displayed. If one or more processes are in the STOPPED state, a red check is displayed. System processes are described in “Chapter 6: Monitoring CTMS System Processes.”

Navigation Pane

In the navigation pane at the left side of the CTMS Administration window, the System Configuration, Meeting Management, Troubleshooting, and Monitoring folders display lists of tasks associated with CTMS. Lists of tasks are also displayed in the content area of the window when you click any folder in the navigation pane. Click the task name or the arrows in the left panel, or click the highlighted name in the content area to navigate to tasks.

Content Area

The right frame is the content area. When you select a folder or a task from the navigation pane, the content associated with that item displays in the content area. The gray bar above the content area shows the navigational path so you can quickly identify where you are at any time.

System Information

Choose **System Information** from the Navigation Pane to view information about the Cisco TelePresence Multipoint Switch. The information displayed under System Information is configured during CTMS software installation.

- **SKU**
- **Hostname:** Hostname of the CTMS.
- **IP Address:** IP address of the Cisco TelePresence Multipoint Switch.
- **Hardware Model:** Cisco MCS 7800 Series Media Convergence Server on which the Cisco TelePresence Multipoint Switch is running.
- **Software Version:** Version of CTMS Administration software currently installed.



CHAPTER 2

Configuring Cisco Unified Communications Manager for CTMS

Initial Release: May 5, 2008, OL-12586-02
Last Revised: August 4, 2008

Contents

- [Overview, page 2-13](#)
- [Prerequisites, page 2-14](#)
- [Logging into the Unified CM Administration Application, page 2-14](#)
- [Creating a SIP Trunk Security Profile, page 2-14](#)
- [Creating a SIP Trunk, page 2-15](#)
- [Configuring a Route Pattern, page 2-16](#)
- [Configuring a Route Pattern, page 2-16](#)

Overview

Before installing the CTMS Administration software on your Cisco MCS-7845 Media Convergence Server, you need to perform the following configuration tasks in Cisco Unified Communications Manager (Unified CM):

- Create a SIP security profile. This security profile will be used on the SIP trunk between CTMS and Unified CM.
- Create a Session Initiation Protocol (SIP) trunk. The SIP trunk is used for communication between Unified CM and CTMS.
- Create route patterns. A route pattern comprises a string of digits (an address) and a set of associated digit manipulations that route calls to a route list or a gateway. Route patterns are used for routing conferences numbers to the CTMS.

Prerequisites

Before starting the tasks in this chapter, make sure that the following conditions are met or that you understand the following information:

- Unified CM is running and using version 6.0 or later software.
- Cisco TelePresence System is running version 1.2.3 or later software. For interoperability with legacy video conferencing devices, Cisco TelePresence System must be running version 1.3 or later software.

For additional information about configuring Unified CM for Cisco TelePresence System, refer to the *Cisco Unified Communications Manager Installation Guide for the Cisco TelePresence System*.

Logging into the Unified CM Administration Application

To log into the Unified CM Administration application:

-
- Step 1** Open a web browser.
- Step 2** Access a web browser that is supported by the Unified CM Administration application from any user PC in your network. In the address bar of the web browser, enter the following URL:

`https://CUCM-server-name`

where *CUCM-server-name* is the name or IP address of the server.



Note You may need to specify the address of the server where Unified CM is installed. If your network uses DNS services, you can specify the hostname of the server. If your network does not use DNS services, you must specify the IP address of the server.

- Step 3** Log in with your assigned administrative privileges.
- Step 4** Select **Cisco Unified Communications Manager Administration** in the **Navigation** field at the upper right corner of the page and click **Go** to return to the Cisco Unified Communications Manager Administration home page.
-

Creating a SIP Trunk Security Profile

To create a SIP trunk security profile:

-
- Step 1** Click **System**. Under **Security Profile**, click **SIP Trunk Security Profile**.
- Step 2** Click the **Add New** button at the bottom of the page or click the **+ sign** at the top of the page.

- Step 3** Enter the settings as indicated in [Table 2-1](#) to configure the SIP trunk security profile. Leave default settings for fields not included in [Table 2-1](#).

Table 2-1 SIP Trunk Security Profile Settings

| Field | Required | Setting |
|-------------------------|----------|--|
| Name | Yes | Enter a text string identifying this SIP trunk security profile. |
| Description | — | Enter a text string describing this SIP trunk security profile. |
| Device Security Mode | Yes | Select <i>Non Secure</i> . |
| Incoming Transport Type | Yes | Select <i>TCP+UDP</i> . |
| Outgoing Transport Type | Yes | Select <i>TCP</i> . |
| Incoming Port | Yes | Enter <i>5060</i> . |

- Step 4** Click the *Save* button at the bottom of the page.

Creating a SIP Trunk

To create a SIP trunk:

- Step 1** Click *Device*. Click *Trunk*.
- Step 2** Click the *Add New* button at the bottom or click the + *sign* at the top of the Trunk Configuration page.
- Step 3** Select *SIP Trunk* from the **Trunk Type** pull-down menu, then click *Next*.
- Step 4** Enter the settings as indicated in [Table 2-2](#) to configure the SIP trunk. Leave default settings for fields not included in [Table 2-2](#).

Table 2-2 SIP Trunk Settings

| Field | Required | Setting |
|----------------------------|----------|--|
| Device Information | | |
| Device Name | Yes | Enter a text string identifying this SIP trunk. |
| Description | — | Enter a text string describing this SIP trunk. |
| Device Pool | Yes | Select <i>Default</i> . |
| SIP Information | | |
| Destination Address | Yes | Enter the IP address of the CTMS. |
| SIP Trunk Security Profile | Yes | Select the SIP trunk security profile that you created for CTMS. |
| SIP Profile | Yes | Select <i>Standard SIP Profile</i> . |

Step 5 Click the *Save* button at the bottom of the page.


Configuring a Route Pattern

A route pattern allows a Unified CM-managed device to access another device by dialing its number. Such devices may include gateways, Cisco TelePresence Multipoint Switch (CTMS) systems, or Cisco Unified Video Conferencing (CUVC) MCUs. Each device requires its own unique route pattern.

To configure a route pattern:

- Step 1** Click *Call Routing*. Under **Route/Hunt**, click *Route Pattern*.
- Step 2** Click the *Add New* button at the bottom or click the + *sign* at the top of the Route Pattern Configuration page.
- Step 3** Enter the settings as indicated in [Table 2-3](#) to configure the SIP trunk. Leave default settings for fields not included in [Table 2-3](#).

Table 2-3 *Route Pattern Configuration Settings*

| Field | Required | Setting |
|---------------------------|----------|--|
| Pattern Definition | | |
| Route Pattern | Yes | Enter the route pattern, including numbers and wildcards (do not use spaces); for example, for NANP, enter 9.@ for typical local access, or 8XXX for a typical private network numbering plan. The uppercase characters A, B, C, and D are valid characters.  Note See the “Wildcards and Special Characters in Route Patterns and Hunt Pilots” section in the <i>Cisco CallManager System Guide</i> for more information about wildcards. |
| Description | — | Enter a text string describing this route pattern. |
| Gateway/Route List | Yes | Select the SIP trunk that you created for CTMS. |
| Call Classification | Yes | Select <i>OnNet</i> . |

Step 4 Click the *Save* button at the bottom of the page.



CHAPTER 3

Installing CTMS Administration Software

Initial Release: May 5, 2008, OL-12586-02
Last Revised: August 4, 2008

Contents

- [Prerequisites, page 3-17](#)
- [Installing the CTMS Administration Software, page 3-18](#)

Prerequisites

Before you install the Cisco TelePresence Multipoint Switch (CTMS) Administration software system files, you need the following equipment and information:

- Cisco TelePresence System (CTS)-1000 Release and/or CTS-3000 assembled and configured to support TelePresence conferencing. For more information, refer to the following guides:
 - *Cisco TelePresence System Release 1.3 Administrator's Guide*
 - *Cisco TelePresence 3000 Assembly, Use & Care, and Field Replacement Unit Guide*
 - *Cisco TelePresence 1000 Assembly, Use & Care, and Field Replacement Unit Guide*
- Cisco MCS-7845-H2 or MCS-7845-I2 Media Convergence Server, installed and connected to a Domain Name System (DNS) server and your network.
- Console able to access the Cisco MCS-7845-H2 Series Media Convergence Server.
- DVD that contains the CTMS Administration software application.
- Cisco Unified Communications Manager (Unified CM) 6.0 or higher configured to support CTS Release 1.3 and integrated to work with CTMS, meaning that a SIP security profile, SIP trunk, and route pattern specific to CTMS have been created. For more information about Unified CM for CTS configuration, refer to *Cisco Unified Communications Manager Installation Guide for the Cisco TelePresence System*.

Installing the CTMS Administration Software

To install the CTMS Administration software application:

-
- Step 1** Insert the CTMS Administration software application DVD into the appropriate drive in the Cisco MCS-7800 Series Media Convergence Server and boot up the host.
- Step 2** **Media Check:** The system asks if you wish to perform a media check on the inserted DVD. Select *Yes* or *No* and press the Enter key. If you select *No*, the system bypasses the media check. If you select *Yes*, the system performs a checksum to make sure that the media on the DVD is intact. When the checksum has successfully completed, select *Okay* and press the Enter key.



Note If the checksum fails, it could be because of a problem with either the DVD or the DVD drive. The DVD or the DVD drive could need cleaning; the DVD data could be corrupted; or the software image you are trying to load could be the wrong image.

- Step 3** **Hard Drive Check:** The system then checks the status of the hard drives in the server. When cued to update BIOS, press the Enter key to continue.
- Step 4** **Platform Installation Wizard:** Select *Proceed* and press the Enter key to continue.
- Step 5** **Automatic Negotiation of Ethernet NIC Speed and Duplex:** Select *Yes* and press the Enter key to continue.
- Step 6** **DHCP:** Cisco Systems recommends that you use a static IP address instead of DHCP. Select *No* to define a specific static IP address and press the Enter key. Enter the following information:
- Hostname: Hostname of the CTMS server
 - IP Address: IP address of the CTMS server
 - IP Mask: Subnet mask for the CTMS server IP address
 - Gateway Address: IP address for the gateway to the CTMS server
- Select *Okay* and press the Enter key to continue.
- Step 7** **DNS Client:** Select *Yes* and press the Enter key. Enter the following information:
- Primary DNS: IP address of the primary DNS server
 - Secondary DNS: IP address of the secondary DNS server
 - Domain: Domain name for your company
- Select *Okay* and press the Enter key to continue.
- Step 8** **Platform Administrator Username and Password:** Enter the following information:
- Administration ID
 - Password
 - Confirm Password
- Select *Okay* and press the Enter key to continue.
- Step 9** **Certificate Information:** Enter the following information:
- Organization
 - Unit
 - Location

- State
- Country

Select **Okay** and press the Enter key to continue.

Step 10 Network Time Protocol (NTP) Client Information: Enter the following information:

- NTP Server 1: IP address of the primary NTP server
- NTP Server 2: IP address of the secondary NTP server
- NTP Server 3 through 5: IP addresses of additional NTP servers

Select **Okay** and press the Enter key to continue.



Note The NTP servers identified must be the same for CTMS, CTS and CTM. It is recommended that you provide at least three NTP servers.

Step 11 Platform Configuration Confirmation: Select **Okay** to continue with installation. select **Back** to go to previous screens in the installation procedure, or **Cancel** to abort the installation. When you have made your selection, press the Enter key. If you select **Okay**, platform and application installation takes approximately 30 to 45 minutes. During installation, allow the default selection for the custom kernel to proceed.

Step 12 After the CTMS Administration software application files have been installed, the system automatically reboots. The system then performs a check of the network connectivity and setup. If the system determines that any of the information you entered during the preceding steps is incorrect, a message is displayed on the console, giving the you the following options:

- **Retry:** Select this option (and press the Enter key) to retry the installation procedure.
- **Review:** Select this option (and press the Enter key) if you need to change any of the data you entered during the preceding installation steps. If you select this option, navigate to the appropriate installation data entry screen, re-enter the data, and then proceed to the **Platform Configuration** screen to re-initiate installation.
- **Halt:** Select this option (and press the Enter key) if you need to abort installation.
- **Ignore:** Select this option (and press the Enter key) to ignore the system warning.

Step 13 After the network connectivity and setup check, the system reboots again. Following this reboot, the CTMS Administration software log-on screen is displayed. Enter your username and password to continue with CTMS Administration software configuration.



CHAPTER 4

Configuring CTMS Administration Software

Revised: June 6, 2008, OL-12586-02
Last Revised: August 4, 2008

Contents

- [Overview, page 4-21](#)
- [System Settings, page 4-22](#)
 - [Editing IP Settings, page 4-22](#)
 - [Editing Access Settings, page 4-23](#)
 - [Configuring and Editing QoS Settings, page 4-24](#)
 - [Configuring and Editing Resource Management, page 4-28](#)
- [Cisco Unified Communications Manager Settings, page 4-32](#)
 - [Configuring and Editing Unified CM Settings, page 4-33](#)
 - [Configuring and Editing SIP Profile Settings, page 4-33](#)
- [Configuring and Editing Cisco TelePresence Manager Settings, page 4-35](#)
- [Configuring and Editing Access Management, page 4-36](#)
- [Upgrading Software Version, page 4-40](#)
- [Interface Failover, page 4-41](#)

Overview

The following sections describe the System Configuration parameters for the Cisco TelePresence Multipoint Switch (CTMS). System Configuration is divided into the following areas:

- [System Settings, page 4-22](#)
- [Cisco Unified Communications Manager Settings, page 4-32](#)
- [Configuring and Editing Cisco TelePresence Manager Settings, page 4-35](#)
- [Configuring and Editing Access Management, page 4-36](#)

System Settings


System Settings are initially configured during Cisco TelePresence Multipoint Switch (CTMS) Administration software set up. Use the System Settings to make changes to these initial settings. System Settings consists of four configuration areas:

- [Editing IP Settings, page 4-22](#)
- [Editing Access Settings, page 4-23](#)
- [Configuring and Editing QoS Settings, page 4-24](#)
- [Configuring and Editing Resource Management, page 4-28](#)

Editing IP Settings

Figure 4-1 shows the IP Settings screen.

Figure 4-1 IP Settings




To edit IP settings:

- Step 1** Click *System Settings* under the **System Configuration** folder in the Navigation Pane.
- Step 2** Click the *IP Settings* tab. IP Settings screen displays a table providing the IP Settings fields. Most of the settings displayed on the IP Settings screen are configured during initial installation of the CTMS Administration software. Only three fields can be configured on this screen:
 - IP Address
 - Subnet Mask
 - Default Gateway

Edit settings (as needed) as described in [Table 4-1](#)

Table 4-1 **IP Settings**


| Field or Button | Setting |
|-----------------|---|
| MAC Address | (View only) MAC address of the MCU device on which the Cisco TelePresence Multipoint Switch is located. |
| Hostname | (View only) Hostname configured for the MCU device on which the Cisco TelePresence Multipoint Switch is located. |
| Domain Name | (View only) Domain name in which the MCU device on which the Cisco TelePresence Multipoint Switch is located. |
| Primary DNS | (View only) IP address of the primary DNS for the MCU device on which the Cisco TelePresence Multipoint Switch is located. |
| Secondary DNS | (View only) IP address of the secondary DNS for the MCU device on which the Cisco TelePresence Multipoint Switch is located. |
| Ethernet Card | (View only) Ethernet card being used on the MCU server to connect to the network. |
| IP Address | IP address of the Cisco TelePresence Multipoint Switch.  Note After changing the IP address, close your browser window, then log into CTMS again using your new IP address. |
| Subnet Mask | Subnet mask of the Cisco TelePresence Multipoint Switch. |
| Default Gateway | Default gateway IP address for the Cisco TelePresence Multipoint Switch. |

- To register new or modified settings, click **Apply**.
- To restore the original settings, click **Reset**.

Editing Access Settings

Figure 4-2 shows the Access Settings screen.

Figure 4-2 Access Settings



To edit Access settings:

- Step 1

Click *System Settings* under the **System Configuration** folder in the Navigation Pane.
- Step 2

Click the *Access Settings* tab. Access Settings displays a table providing the Access Settings configuration fields. All of the settings on the Access Screen are derived from settings you configured in Cisco Unified Communications Manager (Unified CM).
Edit settings (as needed) as described in [Table 4-2](#)


Table 4-2 Access Settings

| Field or Button | Setting |
|---------------------|--|
| Route Pattern Start | Defines the first number in your defined route pattern as configured in Unified CM. |
| Route Pattern End | Defines the last number in your defined route pattern as configured in Unified CM. |
| Access Number | Displays the first number in the route pattern as defined in Unified CM. CTMS Administration software (CTMSA) automatically selects that number as the access number. That number is used for scheduled meetings and cannot be used for static meetings. |
| Access Name | Descriptive name for the access number. Maximum number of characters is 20. |

- To register new or modified settings, click *Apply*.
- To restore the original settings, click *Reset*.

Configuring and Editing QoS Settings

[Figure 4-3](#) shows the QoS Settings screen.

Figure 4-3 QoS Settings

To configure or edit QoS settings:

- Step 1** Click *System Settings* under the **System Configuration** folder in the Navigation Pane to open the **System Settings** window.
- Step 2** Click the *QoS Settings* tab. QoS Settings displays a table providing the QoS Settings configuration fields.

Enter or edit settings (as needed) as described in [Table 4-3](#)

Table 4-3 QoS Settings

| Field or Button | Setting |
|-----------------|--|
| DSCP for Media | <p>Traffic marking values for voice and video traffic used for network queuing. Available settings are:</p> <ul style="list-style-type: none"> • AF11 DSCP (001010) • AF12 DSCP (001100) • AF13 DSCP (001110) • AF21 DSCP (010010) • AF22 DSCP (010100) • AF23 DSCP (010110) • AF31 DSCP (011010) • AF32 DSCP (011100) • AF33 DSCP (011110) • AF41 DSCP (100010) • AF42 DSCP (100100) • AF43 DSCP (100110) • CS1 (precedence 1) DSCP (001000) • CS2 (precedence 2) DSCP (010000) • CS3 (precedence 3) DSCP (011000) • CS4 (precedence 4) DSCP (100000) • CS5 (precedence 5) DSCP (101000) • CS6 (precedence 6) DSCP (110000) • CS7 (precedence 7) DSCP (111000) • Default DSCP (000000) • EF DSCP (101110) <p>The default value for this field is CS4 (precedence 4) (100000). It is recommended that you use the default value for this field.</p> |

Table 4-3 QoS Settings

| Field or Button | Setting |
|--------------------|--|
| DSCP for Signaling | <p>Traffic queuing techniques that define per-hop behavior based on the Differentiated Services Code Point (DSCP) value in the IP header of a packet. control stream</p> <p>Available settings are:</p> <ul style="list-style-type: none"> • AF11 DSCP (001010) • AF12 DSCP (001100) • AF13 DSCP (001110) • AF21 DSCP (010010) • AF22 DSCP (010100) • AF23 DSCP (010110) • AF31 DSCP (011010) • AF32 DSCP (011100) • AF33 DSCP (011110) • AF41 DSCP (100010) • AF42 DSCP (100100) • AF43 DSCP (100110) • CS1 (precedence 1) DSCP (001000) • CS2 (precedence 2) DSCP (010000) • CS3 (precedence 3) DSCP (011000) • CS4 (precedence 4) DSCP (100000) • CS5 (precedence 5) DSCP (101000) • CS6 (precedence 6) DSCP (110000) • CS7 (precedence 7) DSCP (111000) • Default DSCP (000000) • EF DSCP (101110) <p>The default value for this field is CS3 (precedence 3) (011000). It is recommended that you use the default value for this field.</p> |

- To register new or modified settings, click **Apply**.
- To restore the original settings, click **Reset**.


**Note**

We recommend that you use the same Quality settings for CTSM that you have configured in Cisco Unified Communications Manager for Cisco TelePresence Systems endpoints.

Configuring and Editing Resource Management

Figure 4-4 shows the Resource Management Settings screen.

Figure 4-4 Resource Management Settings



To configure or edit Resource Management settings:

- Step 1



Click *System Settings* under the **System Configuration** folder in the Navigation Pane.
- Step 2

Click the *Resource Management* tab. Resource Management displays a table providing the Resource Management Settings configuration fields.
- Enter or edit settings (as needed) as described in [Table 4-4](#)

Table 4-4 Resource Management Settings

| Field or Button | Setting |
|------------------|---|
| Maximum Segments | Defines the total number of table segments (individual video displays) this CTMS handles. Maximum number is 48. |

Table 4-4 Resource Management Settings (continued)

| Field or Button | Setting |
|----------------------|--|
| Adhoc Segments | <p>Defines the maximum number of table segments available for impromptu meetings. By defining the number of table segments available for adhoc meetings, you ensure that there will be sufficient table segments available for scheduled meetings. Maximum number is 48.</p> <p> Note Combined total for Schedulable Table Segments and Ad hoc Table Segments cannot exceed 48.</p> <p> Note In Interop calls (meaning that the teleconference includes both CTS and legacy teleconferencing (Cisco Unified Video Conferencing (CUVC)), CUVC occupies one segment per call. Segment use is dependant on the number of Interop calls; for example, if there are three on-going Interop calls, then three CTMS segments will be used to establish calls to CUVC.</p> |
| Schedulable Segments | (View only) This field displays the number of table segments available at any one time for scheduled meetings; CTMS automatically derives this value by subtracting the defined number of Ad Hoc Table Segments from the defined number of Maximum Table Segments. |

**Note**

If you do not have Cisco TelePresence Manager installed, all table segments must be ad hoc.

- To register new or modified settings, click **Apply**.
- To restore the original settings, click **Reset**.

Configuring and Editing SNMP Settings

The Simple Network Management Protocol (SNMP) is an application layer protocol that facilitates the exchange of management information between network devices; it enables network administrators to manage network performance, find and solve network problems, and plan for network growth by analyzing information gathered using MIBs.

With SNMP for CTMS, you first enable (or disable) SNMP; when you enable SNMP, you turn on the SNMP daemon so CTMS is registered with SNMP (so that SNMP can begin monitoring CTMS and gathering data). You can also designate a particular server where SNMP trap messages are gathered and stored. Both of these configuration steps require separate username and password authentication.

By default, SNMP service is disabled. Once SNMP is enabled, the following default SNMP settings are also enabled:

- One SNMP username set to “admin”. This name cannot be changed.

- SNMP service password set to “snmppassword”. The password should be changed.
- No trap receiver configured. Use the Trap Receiver Configuration fields in this window to configure a trap receiver. The fields collect trap receiver username, password, authentication algorithm, hostname or IP address, and port.

Figure 4-5 shows the SNMP Settings screen.

Figure 4-5 *SNMP Settings*

The screenshot shows the Cisco TelePresence Multipoint Switch Administration web interface. The top navigation bar includes the Cisco logo, the title 'Cisco TelePresence Multipoint Switch Administration', and links for 'admin', 'Logout', 'Help', and 'About'. The left sidebar shows a 'Host: ctms-hp3' and a 'System Configuration' menu with options like System Information, System Settings, Import/Export Files, CUCM Settings, CTM Settings, Access Management, Software Upgrade, Meetings Management, Troubleshooting, and Monitoring. The main content area is titled 'System Configuration > System Settings' and contains several tabs: IP Settings, Access Settings, QoS Settings, Resource Management, **SNMP Settings**, and Restart CTMS. The SNMP Settings tab is active, displaying the following configuration fields:

- Engine ID:** 0x80001f803001c04eaf408
- SNMP:** ☒ Enable ☐ Disable
- Configuration:**
 - User Name:** admin (with a 'Change...' button)
 - Current Password:** *****
- Trap Receiver Configuration:**
 - ☐ Yes ☒ No
 - User Name:** null (with a 'Change...' button)
 - Current Password:** ****
 - Authentication Algorithm:** MD5 (dropdown menu)
 - Host:** null (text input field)
 - Port:** null (text input field)

At the bottom right of the configuration area are 'Apply' and 'Reset' buttons. A vertical text '203621' is visible on the right edge of the screenshot.

To edit SNMP settings:

- Step 1** Click *System Settings* under the **System Configuration** folder in the Navigation Pane.
- Step 2** Click the *SNMP Settings* tab. SNMP Settings displays a table providing the SNMP Settings configuration fields.

Edit settings (as needed) as described in [Table 4-5](#)

Table 4-5 *SNMP Settings*

| Field or Button | Setting |
|-----------------|--|
| Engine ID | (View only) The engine ID for the SNMP agent on this Cisco TelePresence Multipoint Switch. This number is usually based on the CTMS MAC address. If you configure the trap receiver, this engine ID is used to create a trap user on the trap receiver system and to compute the security digest for authenticating and encrypting packets sent to a user on the remote host. |
| SNMP | Enable or disable SNMP for CTMS. Click the appropriate radio button to select. When SNMP is enabled, supply a password for the SNMP server in the Configuration area. |
| Configuration | |
| User Name | SNMP server username. |

Table 4-5 *SNMP Settings*

| Field or Button | Setting |
|-----------------------------|--|
| Current Password | SNMP server password. The password must be 8 characters long. Enter it twice for verification. |
| Trap Receiver Configuration | To select whether to use an SNMP trap receiver, click the Yes or No radio button, as appropriate. When a trap receiver is used, supply login information for the trap receiver in the following fields. |
| User Name | Trap receiver username. |
| Current Password | Trap receiver password. The password must be 8 characters long. Enter it twice for verification. |
| Authentication Algorithm | Choose Message Digest 5 (MD5) or Secure Hash Algorithm (SHA) for authentication. |

- To register new or modified settings, click **Apply**.
- To restore the original settings, click **Reset**.

Restarting CTMS

Figure 4-6 shows the Restart CTMS screen.

Figure 4-6 *Restart CTMS Settings*

To restart CTMS or to shutdown CTSM:

- Step 1** Click **System Settings** under the **System Configuration** folder in the Navigation Pane.
- Step 2** Click the **Restart CTMS** tab.
- Step 3** Click **Restart** to restart—meaning shutdown and then reboot—CTMS.


Step 4 Click *Shutdown* to completely shutdown CTMS.

Importing and Exporting Files

Import/Export Files enables you to reuse previously defined user and configuration files (such as meeting templates) when upgrading to a new version of CTMS Administration Software. To reuse previously defined user and configuration files, you must first export the files to a secure location, upgrade to the new version of CTMS Administration software, and then import the files.

Figure 4-7 shows the Restart CTMS screen.

Figure 4-7 *Import/Export Files Settings*



To import or export files:

- Step 1** Click *Import/Export Files* under the **System Configuration** folder in the Navigation Pane.
- Step 2** Click *Export Files* to import defined user and configuration files. Click *Browse* to select the exported user and configuration files, then click *Install Config Files* to unzip and install the files.
- Step 3** Click *Import Files* to import defined user and configuration files. Click *Browse* to select the exported user and configuration files, then click *Install Config Files* to unzip and install the files.

Cisco Unified Communications Manager Settings


Cisco Unified Communications Manager Settings (Unified CM) consists of two configuration areas:

- [Configuring and Editing Unified CM Settings, page 4-33](#)
- [Configuring and Editing SIP Profile Settings, page 4-33](#)

Configuring and Editing Unified CM Settings

Figure 4-8 shows the Unified CM Settings screen.


Figure 4-8 Unified CM Settings



To configure or edit Unified CM settings:

- Step 1** Click *Unified CM Settings* under the **System Configuration** folder in the Navigation Pane.
- Step 2** Click the *Unified CM Settings* tab. Unified CM Settings displays a table providing the Unified CM Settings configuration fields. Enter settings (as needed) as described in [Table 4-6](#)

Table 4-6 Unified CM Settings

| Field or Button | Setting |
|------------------------|---|
| Unified CM 1 through 5 | Hostnames or IP address(es) of the Cisco Unified Communications Manager (Unified CM) server. |
| |  Note It is important to add all Unified CM servers in the cluster. |
| SIP Port | Port number for Cisco Unified SIP IP Phones that are using UDP to listen for SIP messages from Unified CM. The default setting equals 5060. |

- To register new or modified settings, click *Apply*.
- To restore the original settings, click *Reset*.

Configuring and Editing SIP Profile Settings

Figure 4-9 shows the SIP Profile Settings screen.

Figure 4-9 SIP Profile Settings

The screenshot displays the Cisco TelePresence Multipoint Switch Administration web interface. The top navigation bar shows the host as 'ctms-hp3' and the current page as 'System Configuration > CUCM Settings'. The left sidebar contains a tree view with 'System Configuration' expanded, showing sub-items like 'System Settings', 'Import/Export Files', 'CUCM Settings', 'CTM Settings', 'Access Management', 'Software Upgrade', 'Meetings Management', 'Troubleshooting', and 'Monitoring'. The main content area is titled 'CUCM Settings' and 'SIP Profile Settings'. It contains a table of configuration fields:

| Field | Value | Required |
|---|-------|----------|
| Retry Count for SIP Invite: | 6 | * |
| Retry Count for SIP non Invite Request: | 10 | * |
| SIP Expires Timer: | 1800 | * |
| SIP Timer T1: | 500 | * |
| SIP Timer T2: | 4000 | * |
| Start Media Port: | 16384 | * |
| Stop Media Port: | 32766 | * |
| Transport Layer Protocol: | TCP | |

At the bottom right of the configuration area are 'Apply' and 'Reset' buttons. A vertical text '209620' is visible on the far right edge of the screenshot.

To configure or edit SIP Profile settings:


- Step 1** Click *Unified CM Settings* under the **System Configuration** folder in the Navigation Pane to open the **Unified CM Settings** window.
- Step 2** Click the *SIP Profile Settings* tab. SIP Profile Settings displays a table providing the SIP Profile Settings configuration fields.

Enter or edit settings (as needed) as described in [Table 4-7](#)

Table 4-7 SIP Profile Settings

| Field or Button | Setting |
|--|---|
| Retry Count for SIP Invite | Specifies the number of times that Cisco Unified Communications Manager (Unified CM) will re-send the INVITE message. This is a required field. Minimum is 1. Maximum is 10 Default is 6. |
| Retry Count for SIP non-Invite Request | Specifies the number of times that Unified CM will re-send the non-INVITE message. This is a required field. Minimum is 1. Maximum is 10 Default is 6. |
| SIP Expires Timer | Specifies the maximum time that an INVITE message remains valid. If Unified CM has not received an answer before this timer expires, Unified CM tears down the call. This is a required field. Minimum is 60000 (msec). Maximum is 300000 (msec). Default is 180000 (msec). |
| SIP Timer T1 | Specifies the lowest value, in milliseconds, of the retransmission timer for SIP messages. Valid values include any positive number. Default specifies 500. |
| SIP Timer T2 | Specifies the highest value, in milliseconds, of the retransmission timer for SIP messages. Valid values include any positive number. Default specifies 4000. |
| Start Media Port | Designates the start real-time protocol (RTP) port for media. Media port ranges from 16384 to 32766. Default specifies 16384. |

Table 4-7 SIP Profile Settings


| Field or Button | Setting |
|--------------------------|---|
| Stop Media Port | Designates the stop real-time protocol (RTP) port for media. Media port ranges from 16384 to 32766. Default specifies 32766. |
| Transport Layer Protocol | Select TCP or UDP for this field. Both transport types are supported. TCP is the recommended transport type. |
| |  <p>Note Whenever the transport type is modified in CTMS, the corresponding transport type for the Unified CM trunk setting must be changed to match the CTMS transport type.</p> |

- To register new or modified settings, click **Apply**.
- To restore the original settings, click **Reset**.

Configuring and Editing Cisco TelePresence Manager Settings

These setting are used to register CTMS with Cisco TelePresence Manager (CTS-Man) for scheduled meetings.

Figure 4-10 shows the Cisco TelePresence Manager Settings screen.



Figure 4-10 Cisco TelePresence Manager Settings


The screenshot displays the 'Cisco TelePresence Multipoint Switch Administration' web interface. The top navigation bar shows 'admin | Logout | Help | About'. The left sidebar lists various system configuration options, with 'CTM Settings' highlighted. The main panel, titled 'System Configuration > CTM Settings', contains a form with the following fields: 'Description' (text input, marked with a red asterisk), 'Time Zone' (dropdown menu), 'User' (text input, marked with a red asterisk), 'Password' (text input, marked with a red asterisk), 'Host' (text input, marked with a red asterisk), and 'Registration Status' (displaying 'Not yet registered'). A legend indicates that '*' denotes required fields. 'Apply' and 'Reset' buttons are located at the bottom right of the form area.

To configure or edit CTS-Manager settings:

- Step 1** Click **CTM Settings** under the **System Configuration** folder in the Navigation Pane to open the **CTM Settings** window.
- Step 2** CTM Settings displays a table providing the Cisco TelePresence Manager Settings configuration fields. Enter or edit settings (as needed) as described in [Table 4-8](#)

Table 4-8 Cisco TelePresence Manager Settings

| Field or Button | Setting |
|---------------------|--|
| Description | Text describing or identifying this particular CTMS. The maximum number of characters for this field is 62 characters. |
| Time Zone | Indicates the time zone in which the CTMS is located. Click “Time Zone” to display the list of available time zone options. Click option to highlight and select. |
| User | <p>Username with which CTMS web services communicates with CTS Manager.</p> <p>Note Usernames must be at least 5 characters, but not more than 64 characters in length, and can contain upper and lower case alphanumeric characters and the underscore and dash characters. The following usernames are not allowed: apache, daemon, nobody, operator, and shutdown.</p> <p> Note User name and password configured on the CTMS and CTS-Man need to be the same.</p> |
| Password | <p>Password with which CTMS web services communicates with CTS Manager.</p> <p>Note Passwords must be at least 5 characters, but not more than 64 characters in length, and can contain upper and lower case alphanumeric characters and the underscore and dash characters. The following usernames are not allowed: apache, daemon, nobody, operator, and shutdown.</p> <p> Note User name and password configured on the CTMS and CTS-Man need to be the same.</p> |
| Host | Host is the IP address or host name of the CTS-Man. |
| Registration Status | (View only) Registration state of the CTMS and CTS-Man. |

- To register new or modified settings, click **Apply**.
- To restore the original settings, click **Reset**.

Configuring and Editing Access Management

CTMS administration software recognizes three different administrative roles; access to task folders is dependent on defined administrative roles. So, administrative roles are considered a form of access management and are defined using Access Management settings.

Figure 4-11 shows the Access Management screen.

Figure 4-11 Access Management

| User-Name | Administrator | Meeting Scheduler | Diagnostic Technician |
|-----------|---------------|-------------------|-----------------------|
| admin | ✓ | ✓ | ✓ |
| diagstech | ✗ | ✗ | ✓ |
| ramesh | ✗ | ✗ | ✓ |
| scheduler | ✗ | ✓ | ✗ |

To configure or edit Access Management settings:

- Step 1** Click **Access Management** under the **System Configuration** folder in the Navigation Pane to open the **Access Management** window.
- Step 2** Access Management initially displays a table providing the following information about already-defined users as described in [Table 4-9](#).

Table 4-9 Access Management Table Field Descriptions

| Field | Description |
|-----------------------|---|
| Username | Username of a specific CTMS user. |
| Administrator | Administrators have the authority to perform all tasks associated with CTMS, including configuring system settings, managing multipoint meetings, maintaining, monitoring and troubleshooting CTMS. Administrators have access to all folders in CTMS Administration software. A green check in this field indicates that the selected user has been designated as an administrator. |
| Meeting Scheduler | Meeting Schedulers have the authority to perform multipoint meeting management tasks, such as defining meeting templates, and setting up (and breaking down, as necessary) ad hoc, static and scheduled meetings. Meeting Schedulers have access to the Meeting Management folder in CTMS Administration software. A green check in this field indicates that the selected user has been designated as a meeting scheduler. |
| Diagnostic Technician | Diagnostic Technicians have the authority to perform CTMS monitoring and troubleshooting tasks. Diagnostic Technicians have access to the Troubleshooting and Monitoring folders in CTMS Administration software. A green check in this field indicates that the selected user has been designated as a diagnostic technician. |

- To delete one of the defined administrators, click the radio button to the left of the table entry, and then click **Delete**.

- To edit one of the defined administrators, click the radio button to the left of the table entry, and then click *Edit*.
- To define a new administrator, click *New*,

Step 3 When you click *New* from the Access Management screen, CTMS Administration software takes you to the New User Settings table as shown in [Figure 4-12](#).


Figure 4-12 *New User Settings*

Step 4 Enter settings as described in [Table 4-10](#)

Table 4-10 *New User Settings*

| Field or Button | Setting |
|-----------------|---|
| Username | Username identifying a defined role as selected from the Role field. Note Usernames must be at least 5 characters, but not more than 64 characters in length, and can contain upper and lower case alphanumeric characters and the underscore and dash characters. The following usernames are not allowed: apache, daemon, nobody, operator, and shutdown. |
| Password | Password for the username indicated in the Username field. Note Passwords must be at least 5 characters, but not more than 64 characters in length, and can contain upper and lower case alphanumeric characters and the underscore and dash characters. The following usernames are not allowed: apache, daemon, nobody, operator, and shutdown. |

Table 4-10 **New User Settings**

| Field or Button | Setting |
|-----------------|--|
| Verify Password | Re-enter the password defined for this user. |
| Role | <p>Defines a specific user role. In CTMS Administration software, there are three possible roles, each with specific levels of administrative access:</p> <ul style="list-style-type: none"> Administrator: Administrators have access to all screens and configuration tasks in CTMS Administration software. Conference Scheduler: Conference-Schedulers have access only to the Meeting Management screens and associated configuration tasks in CTMS Administration software. Diagnostic Technician: Diagnostic Technicians have access only to Monitoring and Troubleshooting screens and one task (system restart) in CTMS Administration software. <p> Note A single user can have more than one role.</p> <p>Click the appropriate radio button to select.</p> |

- To register new or modified settings, click **Apply**.
- To close this window without applying settings, click **Close**.

Step 5 To edit an existing user profile, click the radio button to the left of the table entry to select the user, and then click **Edit**. When you click **Edit** from the Access Management screen, CTMS Administration software takes you to the Edit User Settings table. Enter settings (as needed) as described in [Table 4-11](#)

Table 4-11 **Edit User Settings**

| Field or Button | Setting |
|---------------------|---|
| User | (View only.) Defined role. |
| Password | <p>Password for the username indicated in the Username field.</p> <p>Note Passwords must be at least 5 characters, but not more than 64 characters in length, and can contain upper and lower case alphanumeric characters and the underscore and dash characters. The following usernames are not allowed: apache, daemon, nobody, operator, and shutdown.</p> |
| Verify New Password | Re-enter the password defined for this user. |

- To register new settings, click **Save**.
- To close this window without applying settings, click **Close**.


Upgrading Software Version

There are also two functions to assist you in maintaining the system software, as follows:

- **Switch Version:** The hard drive on the server on which CTMS is installed is partitioned into two areas. Each area can contain a system image. Switch Version allows you to switch the location of two stored versions of the system software.
- **Upgrade Software:** CTMS provides a patch file for upgrading system software. The Cisco-supplied patch file can be stored on a CD-ROM or a Secure FTP (SFTP) host network. A wizard displays dialog boxes to prompt you through the process.

Figure 4-13 shows the Software Upgrade screen.

Figure 4-13 **System Upgrade Screen**



To switch software versions:

- Click the Switch Version button.

The system will swap the software versions and reboot. Screens will describe activity.

The active partition in the server hard drive contains the active system image. The software versions that are loaded will be displayed in the Active Version and Inactive Version fields.

To upgrade software:

Step 1 To start the software upgrade process, click the Upgrade Software button.

The Source Selection dialog box appears.

If you need to stop the software installation, click the Cancel button when the button is active.

Step 2 Click the CD-ROM or Network radio button to choose the location of the patch file.

If you chose CD-ROM, click Next to go to the File Selection window.

If you chose Network, provide the hostname, login username, password, and the path to the patch file. By default, port 22 is used to access the server; supply the correct port number, if required. Click Next to go to the File Selection window.

Step 3 At the File Selection window, choose the file to load by clicking its radio button. Then click Next.

- Step 4** The Patch File Preparation window appears. Watch this window to monitor the progress of the file download. Buttons will be inactive until the patch file is loaded.
- Once the file is loaded, the window displays a Confirmation message.
- The software wizard displays the software versions that are installed and provides active Yes and No radio buttons so you can choose to switch the newly loaded software to the active partition.
- Step 5** Click Yes or No to make your choice. Then click Next to finish the software upgrade task.
- The install wizard displays a dialog window that logs the progress of the update.
- Step 6** When the log indicates that the files have been switched, click Finish to complete this task.
-

Interface Failover

Interface failover provides a backup mechanism for Ethernet adapters. When enabled, the secondary adapter handles all network traffic if the primary adapter or its connection fails.

To enable interface failover:

- Step 1** Make sure that the primary Ethernet adapter (Ethernet interface 0) is connected to the network and that its static IP address and gateway parameters were correctly configured during system installation.
- Step 2** Connect the secondary Ethernet cable (Ethernet interface 1) to a network switch. The connection port can be on the same switch as Ethernet interface 0 or on a different switch but both Ethernet interface 0 and Ethernet interface 1 must be on the same gateway.
- Step 3** From the *Interface Failover* window, click the **Enable** button, then click **Apply**.



Note If the **Enable** button is grayed out, check your network connection.

To disable interface failover:

- Step 1** With no active meetings in progress, click the **Disable** button.
- Step 2** Click **Apply**. Your network adapters will be configured and restarted and the interface failover disabled.



CHAPTER 5

Managing Meetings

Initial Release: May 5, 2008, OL-12586-02
Last Revised: August 4, 2008

Contents

- [Overview, page 5-43](#)
- [Defining and Editing Default Settings, page 5-43](#)
- [Creating and Editing Static Meetings, page 5-45](#)
- [Ad Hoc Meetings, page 5-49](#)
 - [Creating and Editing Ad Hoc Meetings, page 5-49](#)
 - [Creating and Editing Meeting Templates, page 5-51](#)
- [Viewing Scheduled Meetings, page 5-54](#)
- [Viewing and Editing Active Meetings, page 5-55](#)

Overview

This chapter describes how to set up and administer static (reservationless) and ad hoc meetings using the CTMS Administration software.

Defining and Editing Default Settings

Default settings are those that the CTMS Administration software automatically assigns to meeting profiles unless you configure specific settings for ad hoc and static meetings.

[Figure 5-1](#) shows the Default Settings screen.

Figure 5-1 **Default Settings**

Meetings Management > Default Settings

| | |
|--|---|
| Switching Policy: | <input checked="" type="radio"/> Site <input type="radio"/> Segment |
| Maximum Rooms: | 10 * |
| Video Announce: | <input checked="" type="radio"/> Yes <input type="radio"/> No |
| Quality: | Highest Detail, Best Motion: 1080p ▼ |
| Allow Downspeed: | <input checked="" type="radio"/> Yes <input type="radio"/> No |
| Idle Meeting Termination Enabled: | <input checked="" type="radio"/> Yes <input type="radio"/> No |
| Idle Meeting Termination Time (minutes): | 10 * |

Apply Reset

203608

To define default settings:

- Step 1** Click *Default Settings* under the **Meetings Management** folder in the Navigation Pane.
- Step 2** Default Settings displays a table providing the following configuration fields:

Table 5-1 **Default Settings**

| Field or Button | Setting |
|------------------|--|
| Switching Policy | <p>Defines how CTMS calls are displayed during a meeting. CTMS displays active speakers on screen. There are two active speaker display options:</p> <ul style="list-style-type: none"> • Segment: With segment switching, each individual table segment (defined as a display and a camera) is displayed on the screen as that segment becomes the active speaker. • Site: When you select “site,” all table segments for a particular room are displayed on screen when any segment in that room is the active speaker. <p>Click the appropriate radio button to select.</p> |
| Maximum Rooms | <p>Defines the maximum number of Cisco TelePresence rooms allowed to dial into in a static multi-point meeting. The range is from 1 to 48.</p> |
| Video announce | <p>If this option is selected, when a new attendee joins the meeting, the new attendee is displayed for 2 seconds. Options are Yes and No. Click the appropriate radio button to select.</p> |

Table 5-1 **Default Settings**

| Field or Button | Setting |
|---|---|
| Quality | <p>This field sets the system bandwidth and screen resolution. A higher bandwidth increases video quality, but may also cause packets to be dropped and video to be interrupted. Choices:</p> <ul style="list-style-type: none"> • Highest Detail, Best Motion: 4Mbps 1080p • Highest Detail, Better Motion: 3.5Mbps, 1080p • Highest Detail, Good Motion: 3Mbps, 1080p • High Detail, Best Motion: 3Mbps, 720p • High Detail, Better Motion: 2Mbps, 720p • High Detail, Good Motion: 1Mbps, 720p <p>Default is Highest Detail, Best Motion: 4Mbps 1080p.</p> |
| Allow Downspeed | <p>When selected, if an endpoint joins the meeting with a lower Quality value than other endpoints, the endpoint is allowed to join the meeting and all other endpoints downgrade their Quality to match the lower value. If this option is not selected, endpoints with a lower Quality value are not allowed to join the meeting.</p> <p>Options are Yes and No. Click the appropriate radio button to select.</p> |
| Idle Meeting Termination Enabled: | <p>When selected, the meeting is terminated if the system does not detect an active speaker for the value set in the Idle Meeting Termination Time field.</p> <p>Options are Yes and No. Click the appropriate radio button to select.</p> |
| Idle Meeting Termination Time (minutes) | <p>If the Idle Meeting Termination Enabled field is set to “Yes,” this field defines the number of minutes before a meeting is terminated (if the system does not detect an active speaker).</p> <p>Possible values range from 1 to 59 minutes. The default is 10 minutes.</p> |

- To register new or modified settings, click **Apply**.
- To restore the original settings, click **Reset**.

Creating and Editing Static Meetings


Static meetings are meetings that are permanently available after they have been configured. Each static meeting has its own associated meeting number; meetings attendees dial into that specific number when attending a static meeting. You can also add participants to a static meeting through the Active Meetings page.



Note

Static meetings use ad hoc meeting resources.

Figure 5-2 shows the Static Meetings screen.

Figure 5-2 **Static Meetings**

To create or edit a static meeting:

- Step 1** Click **Static Meetings** under the **Meetings Management** folder in the Navigation Pane.
- Step 2** The Static Meetings setting screen initially displays a table providing the following information about already defined static meetings:

Table 5-2 **Static Meetings Table Field Descriptions**

| Field | Description |
|------------------|--|
| Access Number | Displays the access number that rooms call to attend this meeting. |
| Description | Displays the defined description for this static meeting. |
| Switching Policy | Displays the defined switching policy (site or segment) for this static meeting. |
| Max Rooms | Displays the maximum number of sites that can participate in this static meeting. |
| Quality | Sets the maximum bit rate and video resolution to be used for the meeting. |
| Interop | A green check indicates that this particular Cisco TelePresence multipoint meeting supports Cisco Unified Video Conferencing (CUVC) systems (interoperability mode). A red "X" indicates that this meeting is not configured to cascade with CUVC systems. |
| CUVC Number | (Optional) Number dialed to CUVC for interoperability meetings. |

- To delete one of the defined static meetings, click the radio button to the left of the table entry, and then click **Delete**.
- To edit one of the defined static meetings, click the radio button to the left of the table entry, and then click **Edit**.

- To define a new static meeting, click *New*.

Step 3 When you click *Edit* or *New*, CTMS Administration software takes you to the Static Meeting Settings table. [Figure 5-3](#) shows the New Static Meetings Settings screen.

Figure 5-3 *New Static Meetings Settings*

Step 4 Enter settings as described in [Table 5-3](#):

Table 5-3 *Static Meeting Settings*

| Field or Button | Setting |
|---------------------|---|
| Access Number | Defines the telephone number that participants call to attend this static meeting. |
| Meeting Description | Text describing or identifying this static meeting. The maximum number of characters for this field is 62 characters. |

Table 5-3 Static Meeting Settings



| Field or Button | Setting |
|------------------|--|
| Switching Policy | <p>Defines how CTMS calls are displayed during a meeting. CTMS displays active speakers on screen. There are two active speaker display options:</p> <ul style="list-style-type: none"> • Segment: (Speaker) With segment switching, each individual table segment (defined as a display and a camera) is displayed on the screen as that segment becomes the active speaker. • Site: (Room) When you select “site,” all table segments for a particular room are displayed on screen when any segment in that room is the active speaker. <p>Click the appropriate radio button to select.</p> <div>  <p>Note If you are running CTS 1.3 or later, you can control how Cisco TelePresence calls are displayed from the Cisco TelePresence phone interface. Press the Speaker softkey to display the active segment; press the Room softkey to display all segments from a particular site.</p> </div> |
| Maximum Rooms | Defines the maximum number of Cisco TelePresence rooms allowed to dial into in a static multi-point meeting. The range for this setting is from 1 to 48. |
| Video Announce | If this option is selected, when a new room joins the meeting, the new room is displayed on-screen for 2 seconds. Options are Yes and No . Click the appropriate radio button to select. |
| Hosted Meeting | <p>Hosted meetings mean that one particular room is identified as the host for a meeting; other meeting rooms will not be added to the meeting until the host room dials in. If you have selected “Video announce,” then each meeting room will be displayed in 2-second intervals in the order that they joined the meeting.</p> <p>Options are Yes and No. Click the appropriate radio button to select.</p> |
| Host Room Number | Defines the host Cisco TelePresence System room number. |
| Quality | <p>This field sets the system bandwidth and screen resolution. A higher bandwidth increases video quality, but may also cause packets to be dropped and video to be interrupted. Choices:</p> <ul style="list-style-type: none"> • Highest Detail, Best Motion: 4Mbps 1080p • Highest Detail, Better Motion: 3.5Mbps, 1080p • Highest Detail, Good Motion: 3Mbps, 1080p • Highest Detail, Best Motion: 3Mbps, 720p • Highest Detail, Better Motion: 2Mbps, 720p • Highest Detail, Good Motion: 1Mbps, 720p <p>Default is Highest Detail, Best Motion: 4Mbps 1080p.</p> |

Table 5-3 Static Meeting Settings

| Field or Button | Setting |
|-----------------|--|
| Interop | Determines whether this particular Cisco TelePresence multipoint meeting should automatically dial out to legacy Cisco Unified Video Conferencing (CUVC) systems (interop). Options are Yes and No . Click the appropriate radio button to select. |
| CUVC Number | Defines the number that CTMS dials to establish contact with CUVC. Each CUVC number must be unique for each CTMS conference. The CUVC number consists of the service prefix and then the remaining dialed digits. The service prefix can be the same for different meetings. The remaining digits in the dialed number designate the CUVC meeting instance. Each CTMS conference requires its own CUVC meeting instance.  Note This number must start with the CUVC service prefix defined during CUVC configuration. |

- To register new or modified settings, click **Apply**.
- To restore the original settings, click **Reset**.

Ad Hoc Meetings

Ad Hoc meetings are impromptu meetings. Unlike static meetings (which, after they are defined, stay active indefinitely), Ad Hoc meetings begin when they are configured, and end when the last meeting room disconnects from the meeting, or when the administrator or conference-scheduler ends the meeting. With Ad Hoc meetings, the CTMS dials meeting rooms invited to attend the meeting; after the start of a meeting, the administrator can add rooms through the Active Meetings page.

If you have meetings that regularly include a particular set of meeting rooms, you can create meeting templates; meeting templates are predefined groups of CTMS meeting room (end points).


Note

Ad Hoc meeting do not support interoperability meetings in CTMS Release 1.1.

Ad Hoc Meeting configuration is divided into two separate tasks:

- [Creating and Editing Ad Hoc Meetings, page 5-49](#)
- [Creating and Editing Meeting Templates, page 5-51](#)

Creating and Editing Ad Hoc Meetings

[Figure 5-4](#) shows the Ad Hoc Meetings screen.

Figure 5-4 **Ad Hoc Meetings**


To create or edit an ad hoc meeting:

- Step 1** Click *Ad Hoc Meetings* under the **Meetings Management** folder in the Navigation Pane to open the **Ad Hoc Meeting** window.
- Step 2** CTMS Administration software displays the New Ad Hoc Meeting Settings table. Enter settings as described in [Table 5-4](#):

Table 5-4 **New Ad Hoc Meetings Settings**

| Field | Description |
|---------------------|---|
| Meeting Template | This field allows you to select a predefined meeting template. (Meeting templates are predefined groups of CTMS end points.) Click the down arrow to display the available meeting templates; double click a particular template to select. |
| Rooms | Defines the meeting room number of the CTMS end points invited to attend this ad hoc meeting. When entering multiple meeting room numbers, separate each room number with a carriage return by pressing Enter . |
| Meeting Description | Text describing or identifying this particular meeting. The maximum number of characters for this field is 62 characters. |

Table 5-4 **New Ad Hoc Meetings Settings**

| Field | Description |
|-----------------------|--|
| Switching Policy | <p>Defines how CTMS calls are displayed during a meeting. CTMS displays active speakers on screen. There are two active speaker display options:</p> <ul style="list-style-type: none"> • Segment: (Speaker) With segment switching, each individual table segment (defined as a display and a camera) is displayed on the screen as that segment becomes the active speaker. • Site: (Room) When you select “site,” all table segments for a particular room are displayed on screen when any segment in that room is the active speaker. <p>Click the appropriate radio button to select.</p> <div>  <p>Note If you are running CTS 1.3 or later, you can control how Cisco TelePresence calls are displayed from the Cisco TelePresence phone interface. Press the <i>Speaker</i> softkey to display the active segment; press the <i>Room</i> softkey to display all segments from a particular site.</p> </div> |
| Video Announce | When selected, if a new attendee joins the meeting, the attendee is displayed on-screen for 2 seconds. Options are Yes and No . Click the appropriate radio button to select. |
| Quality (per Display) | <p>This field sets the system bandwidth and screen resolution. A higher bandwidth increases video quality, but may also cause packets to be dropped and video to be interrupted. Choices:</p> <ul style="list-style-type: none"> • Highest Detail, Best Motion: 4Mbps 1080p • Highest Detail, Better Motion: 3.5Mbps, 1080p • Highest Detail, Good Motion: 3Mbps, 1080p • High Detail, Best Motion: 3Mbps, 720p • High Detail, Better Motion: 2Mbps, 720p • High Detail, Good Motion: 1Mbps, 720p <p>Default is Highest Detail, Best Motion: 4Mbps 1080p.</p> |

- To register new or modified settings, click **Apply**.
- To restore the original settings, click **Reset**.

Creating and Editing Meeting Templates

The Meeting Template setting screen initially displays a table providing the following information about already defined meeting templates. [Figure 5-5](#) shows the Meeting Templates screen.

Figure 5-5 Meeting Templates

To create or edit a meeting template:


- Step 1** Click *Ad Hoc Meetings* under the **Meetings Management** folder in the Navigation Pane to open the **Ad Hoc Meetings** window.
- Step 2** Click the *Meeting Template* tab to display the **Meeting Template** page.
- Step 3** The Meeting Template setting screen initially displays a table providing the following information about already defined meeting templates, as described in [Table 5-5](#).

Table 5-5 Meeting Template Table Field Descriptions

| Field | Description |
|-------------|--|
| ID | Name identifying this particular meeting template. |
| Description | Text describing this particular meeting template. |

- To display a defined number of table rows, click the down arrow next to **Rows per page**. Click to highlight and select predetermined amounts.
 - To delete one of the defined meeting templates, click the radio button to the left of the table entry, and then click *Delete*.
 - To edit one of the defined meeting templates, click the radio button to the left of the table entry, and then click *Edit*.
 - To define a new meeting template, click *New*.
- Step 4** When you click *Edit* or *New*, CTMS Administration software displays the Meeting Templates Settings table. Enter settings as described in [Table 5-6](#):

Table 5-6 Meeting Templates Settings

| Field | Description |
|---------------------|---|
| Description | Name identifying this particular meeting template. This name appears in the drop-down list of defined meeting templates. The maximum number of characters for this field is 62 characters |
| Rooms | Defines the meeting room number of the CTMS end points invited to attend this ad hoc meeting. When entering multiple meeting room numbers, separate each room number with a carriage return by pressing “enter.” |
| Meeting Description | Text describing this particular meeting template. The maximum number of characters for this field is 62 characters |
| Switching Policy | <p>Defines how CTMS calls are displayed during a meeting. CTMS displays active speakers on screen. There are two active speaker display options:</p> <ul style="list-style-type: none"> • Segment: (Speaker) With segment switching, each individual table segment (defined as a display and a camera) is displayed on the screen as that segment becomes the active speaker. • Site: (Room) When you select “site,” all table segments for a particular room are displayed on screen when any segment in that room is the active speaker. <p>Click the appropriate radio button to select.</p>  <p>Note If you are running CTS 1.3 or later, you can control how Cisco TelePresence calls are displayed from the Cisco TelePresence phone interface. Press the Speaker softkey to display the active segment; press the Room softkey to display all segments from a particular site.</p> |
| Quality | <p>This field sets the system bandwidth and screen resolution. A higher bandwidth increases video quality, but may also cause packets to be dropped and video to be interrupted. Choices:</p> <ul style="list-style-type: none"> • Highest Detail, Best Motion: 4Mbps 1080p • Highest Detail, Better Motion: 3.5Mbps, 1080p • Highest Detail, Good Motion: 3Mbps, 1080p • High Detail, Best Motion: 3Mbps, 720p • High Detail, Better Motion: 2Mbps, 720p • High Detail, Good Motion: 1Mbps, 720p <p>Default is Highest Detail, Best Motion: 4Mbps 1080p.</p> |


- To register new or modified settings, click Apply.
- To restore the original settings, click Reset.

Viewing Scheduled Meetings

Scheduled Meetings lists all of the meetings scheduled using CTS-Man.

Figure 5-6 shows the Scheduled Meetings screen.

Figure 5-6 Scheduled Meetings



To view information about scheduled meetings:

- Step 1** Click *Scheduled Meetings* under the **Meetings Management** folder in the Navigation Pane to open the **Scheduled Meetings** window.
- Step 2** The Scheduled Meetings setting screen initially displays a table providing the following information about already scheduled meetings, as described in [Table 5-7](#)

Table 5-7 Scheduled Meetings Table Field Descriptions


| Field | Description |
|------------------|---|
| ID | Meeting IDs for the scheduled meetings. Click the arrow to change the order (descending, ascending based on Meeting IDs) in which the scheduled meetings are displayed. |
| Description | Displays the defined meeting description. |
| Start Time GMT-8 | Displays the start time (Greenwich Mean Time, Pacific Standard Time) for this scheduled meeting. Click the arrow to change the order (descending, ascending based on meeting start time) in which the scheduled meetings are displayed. |
| End Time GMT-8 | Displays the end time (Greenwich Mean Time, Pacific Standard Time) for this scheduled meeting. Click the arrow to change the order (descending, ascending based on meeting end time) in which the scheduled meetings are displayed. |

- Click the radio button to the left of a table entry to select a specific scheduled meeting.
- Click **Details** to display additional information about the selected scheduled meeting.
- Click **Refresh** to refresh the Schedule Meetings table displayed.
- To display a defined number of table rows, click the down arrow next to **Rows Per Page**. Click to highlight and select predetermined amounts.
- If there are multiple pages listing log files, click the **First**, **Previous**, **Next**, or **Last** button to navigate to the desired page.

Viewing and Editing Active Meetings

Active Meetings is where you either view information about an active meeting, or edit meetings that are currently in progress. Figure 5-7 shows the Active Meetings screen.

Figure 5-7 Active Meetings Screen



To view or edit an active meeting:

- Step 1** Click **Active Meetings** under the **Meetings Management** folder in the Navigation Pane to open the **Active Meetings** window.
- Step 2** The Active Meetings setting screen displays a table listing all currently active meetings. Meetings are listed in the table by Meeting ID number.
 - To display a defined number of table rows, click the down arrow next to **Rows Per Page**. Click to highlight and select predetermined amounts.
 - If there are multiple pages, click the **First**, **Previous**, **Next**, or **Last** button to navigate to the desired page.

- Click **Refresh** to refresh the Active Meetings table displayed.
- Step 3** To use the filter at the top of the table to find a particular meeting, enter either the Meeting ID number or the Meeting Room number in the appropriate field and then click **Filter**.
- Step 4** Click the radio button to the left of a table entry to select a particular meeting. Click **Edit** to display the Active Meetings setting table. Active Meeting management tasks (and information about active meetings) are described in [Table 5-8](#)

Table 5-8 Active Meetings Settings



| Field | Description |
|---------------------|--|
| Meeting ID | Displays the Meeting ID Number of the meeting selected. To delete this meeting (in other words, end this meeting), click the Delete Meeting radio button. Click Apply to end the meeting. |
| Meeting Description | Displays the defined description for this meeting. |
| Meeting Type | Displays the defined meeting type. Meeting types are static and ad hoc. |
| Room1, Room2... | Lists the CTS end points (meeting rooms) attending this meeting. To delete a particular CTS end point, click the Delete Room radio button for that particular room. Click Apply to remove that room from the meeting. |
| |  <p>Note For interoperability meetings, the CUVC connection is shown as one room in the Maximum Rooms setting.</p> |
| Add Room(s) | Defines additional meeting room numbers (CTMS end points) to attend this meeting. When entering multiple meeting room numbers, separate each room number with a carriage return by pressing “Enter.” |
| |  <p>Note An interoperability connection cannot be dynamically added to a conference. It must be configured in the Static Meeting definition.</p> |

Table 5-8 Active Meetings Settings


| Field | Description |
|------------------|--|
| Switching Policy | <p>Defines how CTMS calls are displayed during a meeting. CTMS displays active speakers on screen. There are two active speaker display options:</p> <ul style="list-style-type: none"> • Segment: (Speaker) With segment switching, each individual table segment (defined as a display and a camera) is displayed on the screen as that segment becomes the active speaker. • Site: (Room) When you select “site,” all table segments for a particular room are displayed on screen when any segment in that room is the active speaker. <p>Click the appropriate radio button to select.</p> <div>  <p>Note If you are running CTS 1.3 or later, you can control how Cisco TelePresence calls are displayed from the Cisco TelePresence phone interface. Press the Speaker softkey to display the active segment; press the Room softkey to display all segments from a particular site.</p> </div> |
| Video Announce | <p>When selected, if a new attendee joins the meeting, the attendee is displayed on-screen for 2 seconds. Options are Yes and No. Click the appropriate radio button to select.</p> |
| Quality | <p>This field sets the system bandwidth and screen resolution. A higher bandwidth increases video quality, but may also cause packets to be dropped and video to be interrupted. Choices:</p> <ul style="list-style-type: none"> • Highest Detail, Best Motion: 4Mbps 1080p • Highest Detail, Better Motion: 3.5Mbps, 1080p • Highest Detail, Good Motion: 3Mbps, 1080p • High Detail, Best Motion: 3Mbps, 720p • High Detail, Better Motion: 2Mbps, 720p • High Detail, Good Motion: 1Mbps, 720p <p>Default is Highest Detail, Best Motion: 4Mbps 1080p.</p> |
| VIP Mode | <p>When selected, one endpoint is defined as the “VIP.” A VIP is broadcast to all other meeting attendees for the entire meeting. The VIP’s endpoint continues to switch between endpoints with active speakers. Only one VIP can be defined per meeting.</p> <p>Options are “Yes” and “No.” Click the appropriate radio button to select.</p> |
| Lock | <p>Locking the meeting means that no settings can be changed for this meeting. Options are Yes and No. Click the appropriate radio button to select.</p> |

Table 5-8 **Active Meetings Settings**

| Field | Description |
|---------------------|--|
| VIP Source | <p>Defines how the VIP is displayed to all endpoints. Options are:</p> <p>Room: If selected, all segments for the CTS endpoint identified as “VIP” are displayed.</p> <p>Center Segment: If selected (and the CTS endpoint identified as “VIP” is a CTS-3000), then only the center segment is displayed.</p> <p>Click the appropriate radio button to select.</p> |
| <Meeting Attendees> | <p>Defines roles for participants if VIP mode is selected. Options are:</p> <p>VIP: This attendee is broadcast to all other meeting attendees for the entire meeting. The VIP’s endpoint continues to switch between endpoints with active speakers. Only one VIP can be defined per meeting.</p> <p>Viewer: The VIP is broadcast to this attendee.</p> <p>NA: The attendee is neither a viewer or a VIP. The NA’s endpoint continues to switch between end points with active speakers.</p> <p>Click the appropriate radio button to select.</p> |

- To register new or modified settings, click **Save**.
- To exit and return to the Active Meetings list, click **Close**.



CHAPTER 6

Troubleshooting the CTMS System

Initial Release: May 5, 2008, OL-12586-02
Last Revised: August 4, 2008

Contents

- [Overview, page 6-59](#)
- [Viewing CTMS Alarms and System Error Messages, page 6-60](#)
- [Configuring the Severity Level of System Error Messages, page 6-62](#)
- [Filtering the Log File Table Listings, page 6-63](#)
- [Downloading Log Files, page 6-64](#)
- [Troubleshooting Specific Issues, page 6-64](#)


Overview

The Troubleshooting folder contains tools that enable you to do the following:

- View the latest CTMS alarms and system error messages
- Configure the severity level of system level error messages and alarms for specific process areas
- Filter the Log File table listings.

[Figure 6-1](#) shows the main Troubleshooting window,

Figure 6-1 Troubleshooting Window




Viewing CTMS Alarms and System Error Messages

You can view CTMS alarms, systems error and system warning messages in one of two ways:

- Click **System Errors** under the **Troubleshooting** folder in the Navigation Pane. You will see a list of all warning and error messages.
- From the **System Status** bar, click the icon for **Warnings** or **Errors**.
 - If you click the icon for **Warnings**, you will see endpoint alert information. Warnings are issued every 20 seconds when an endpoint crosses its packet loss threshold. If congestion continues for more than 40 seconds, the endpoint will be dropped.
 - If you click the icon for **Errors**, you will see endpoint drop information. Whenever an endpoint drops from high packet loss, an error is issued with the error code “CONGESTION.”

Whether you select System Errors under Troubleshooting, or click Error or Warning icons, messages are displayed in the following tabular format as shown in Figure 6-2.

Figure 6-2 **System Errors Screen****Table 6-1** **System Error Table Field Descriptions**

| Field | Description |
|--------------|---|
| Time (GMT-8) | Displays the time at which this error occurred. Click the arrow to change the order (descending, ascending based on time) in which the errors are displayed. |
| Symbol | Text string (name) of the error message or alarm. |
| Level | <p>Indicates the severity level of the error message or alarm. There are eight severity levels as follows:</p> <ul style="list-style-type: none"> • OFF • CRIT • ERROR • WARN • INFO • DEBUG • DEBUG2 • DEBUG3 <p>Click the arrow to change the order (descending, ascending based on level) in which the errors are displayed.</p> |
| Source | Indicates the CTMS system process associated with this alarm or error message. Click the arrow to change the order (descending, ascending based on source) in which the errors are displayed. |
| Message | Message describing the error or alarm. |

- To display a defined number of table rows, click the down arrow next to **Rows Per Page**. Click to highlight and select predetermined amounts.
- If there are multiple pages listing log files, click the **First**, **<Previous**, **Next>**, or **Last** button to navigate to the desired page.
- To delete one of the error messages, click the radio button to the left of the table entry, and then click **Clear**.
- To delete all error messages displayed, click **Clear All**.

Configuring the Severity Level of System Error Messages

To configure the severity level of system level error messages and alarms for specific process areas:

- Step 1** Click **Log Files** under the **Troubleshooting** folder in the Navigation Pane to open the **Log Files** window. [Figure 6-3](#) shows the Log File Screen.

Figure 6-3 Log Files Screen

The screenshot shows the 'Log Files' screen in the Cisco TelePresence Multipoint Switch Administration interface. The left navigation pane shows 'Log Files' selected under 'Troubleshooting'. The main content area has a header 'Troubleshooting > Log Files'. Below this, there are dropdown menus for selecting severity levels for different processes: CCS, Conference Manager, Execution Manager, Media Processor, and Switching, all set to 'INFO'. There are 'Apply' and 'Reset' buttons. Below this is a 'Log Files' section with a 'Process' dropdown set to 'All' and a 'Filter' button. A table displays log files with columns: Filename, Process, Last Modified (GMT-8), and Size (KB). The table shows 22 records, with the first 10 displayed. The log files listed are: web_ui.log (Web-UI, 59.44 KB), rtp.log (Media-Processor, 19.51 KB), snmp_state.log (N.A, 0.01 KB), users-roles_bak.xml (N.A, 1.07 KB), switching.log (Switching, 0.18 KB), logcfg.xml (N.A, 3.46 KB), ctms_sysop.log (CTMS-Sysop, 0.07 KB), alarm.log (Alarm-Logs, 0.21 KB), dhinit.log (N.A, 0.35 KB), and exemar.log (Execution-Manager, 1.82 KB). At the bottom, there are navigation buttons: First, < Previous, Next >, Last, and a 'Rows Per Page' dropdown set to 10. A 'Download All' button is also present.

- Step 2** At the top of the Log Files screen, there is a table listing the following CTMS system processes:

- CCS
- Conference Manager
- Execution Manager
- Media Processor
- Switching

To the left of each process is a drop-down list, listing the following severity levels:

- OFF

- CRIT
- ERROR
- WARN
- INFO
- DEBUG
- DEBUG2
- DEBUG3

Click the down arrow to display the drop-down list of defined levels of severity, and then click to highlight and select a specific severity level for all error messages and alarms associated a particular CTMS system process.

**Note**

Log levels create varying amounts of data; for example, DEBUG creates more log entries than CRIT. Because verbose logs can impact system performance, use verbose logs only to track a problem.

Filtering the Log File Table Listings

To filter the log files displayed in the Log File Table:

-
- Step 1** Click **Log Files** under the **Troubleshooting** folder in the Navigation Pane to open the **Log Files** window.
- Step 2** At the middle of the Log Files screen, click the down arrow to the right of **Processes** to display a list of CTMS process areas, then click to highlight and select a specific process area on which to filter log files. Choices are:
- All
 - CCS
 - Conference Manager
 - Execution Manager
 - Media Processor
 - Switching
 - SIP
 - Web-UI
 - CDR Logs
 - Core
 - Alarm Logs
- Step 3** Click the **Filter** button to display the logs files associated with the selected process area in the Log Files table.
-

Downloading Log Files

To download log files from the Log File table:

- Step 1** Click *Log Files* under the **Troubleshooting** folder in the Navigation Pane to open the **Log Files** window.
- Step 2** At the bottom of the Log Files screen is the Log File table, which lists the available log files. The table is organized as follows:

Table 6-2 **Log Table Field Descriptions**

| Field | Description |
|-----------------------|--|
| Filename | Filename of the log file. Click the arrow to change the order (descending, ascending based on alphabetical order of the filenames) in which the log files are displayed. |
| Process | CTMS system process area. Click the arrow to change the order (descending, ascending based on alphabetical order of the processes) in which the log files are displayed. |
| Last Modified (GMT-8) | Time (Greenwich Mean Time, Pacific Standard Time) at which the log file was collected. Click the arrow to change the order (descending, ascending based on time) in which the log files are displayed. |
| Size | Size (in kilobytes) of the compressed log file. |

- Step 3** To display a defined number of table rows, click the down arrow next to **Rows per Page**. Click to highlight and select predetermined amounts. If there are multiple pages listing log files, click the **First**, **Previous**, **Next**, or **Last** button to navigate to the desired page.
- Step 4** Click the filename of a log file to download that file. Click the **Download All** button to download all log files listed.

Troubleshooting Specific Issues

Table 6-3 describes some specific problems and possible solutions.

Table 6-3 **Specific Problems and Possible Solutions**

| Problem | Possible Solutions |
|--|--|
| Unable to connect to static meetings or to initiate ad hoc meetings | <ol style="list-style-type: none"> 1. Verify network connectivity. 2. Verify IP address of the CTMS configured on Unified CM SIP trunk. |
| Unable to connect to static meetings but able to connect to ad hoc meetings | <ol style="list-style-type: none"> 1. Verify the that static number being dialed is a valid number. 2. Verify that SIP Trunk security profile “Outbound transport type” is set to “UDP.” 3. Verify that all Unified CM servers are entered in Unified CM settings. |
| Unable to connect to ad hoc meetings but able to connect to static meetings | <ol style="list-style-type: none"> 1. Verify that the CTS endpoints numbers are entered correctly. 2. Verify that rooms are available. |
| Scheduled meetings don’t connect | <ol style="list-style-type: none"> 1. Check the registration status of the CTMS on the CTM page. 2. Verify that the scheduled meeting is listed on the CTMS (under Scheduled Meetings). |
| Cisco TelePresence Interoperability: Unified CM sends an error message of “Service not available” to CTMS when CTMS tries to establish call to CUVC. | <ol style="list-style-type: none"> 1. Check to see if there are sufficient ports. Unified CM delivers a “Service not available” message when CTMS places a call to CUVC and there are an insufficient number of ports available. 2. Verify the number dialed for the CUVC connection is defined to Unified CM as a SIP trunk, and is correctly configured. |



CHAPTER 7

Monitoring CTMS System Processes

Initial Release: May 5, 2008, OL-12586-02
Last Revised: August 4, 2008


Contents

- [Overview, page 7-67](#)
- [Monitoring System Status, page 7-68](#)
- [Monitoring and Restarting System Processes, page 7-69](#)
- [Viewing Call Statistics, page 7-70](#)
- [Room Testing, page 7-72](#)

Overview

The Monitor folder contains tools that enable you to monitor the overall CTMS system state and the running state of individual processes. [Figure 7-1](#) shows the initial Monitoring window.

Figure 7-1 **Monitoring Window**




203612

Monitoring System Status

To view the status of CTMS system processes:

- Step 1** Click *System Status* under the **Monitoring** folder in the Navigation Pane to open the **System Status** window. [Figure 7-2](#) shows the System Status screen.

Figure 7-2 *System Status*



- Step 2** System Status shows snapshots of the following CTMS system processes:

- Active CPU Load Percentage
- Active CPU Load Average Value
- Traffic Analysis for <interface>
- Packet Discards for <interface>
- Free Memory
- Free Swap + Real Memory
- Root Disk / Usage %
- Open TCP Connections

Click each snapshot to reveal daily, weekly, monthly and yearly averages.


Monitoring and Restarting System Processes

Process Status lists all processes currently running; the information on this page automatically refreshes every 10 seconds.

To monitor or restart system processes:

- Step 1** Click **Process Status** under the **Monitoring** folder in the Navigation Pane to open the **Process Status** window. [Figure 7-3](#) shows the Process Status screen.

Figure 7-3 *Process Status Screen*



- Step 2** The Process Status screen initially displays a table providing the following information:

Table 7-1 *Process Status Table Field Descriptions*

| Field | Description |
|---------|------------------------------------|
| Process | Process name |
| Status | Status of this particular process. |

- Step 3** To display a defined number of table rows, click the down arrow next to “Rows per page.” Click to highlight and select predetermined amounts. If there are multiple pages listing log files, click the **First**, **Previous**, **Next**, or **Last** button to navigate to the desired page.

- Step 4** Click “Restart” to restart all of the processes.



Warning

When you restart CTMS system processes, all active meetings are dropped. Check for active meetings before using this command.


Viewing Call Statistics

Use Call Statistics to view detailed RTP information about all call segments for active CTMS meetings.

To view call statistics:

- Step 1** Click *Call Status* under the **Monitoring** folder in the Navigation Pane to open the **Call Statistics** window. [Figure 7-4](#) shows the Call Statistics screen.

Figure 7-4 *Call Statistics Screen*



- Step 2** The initial Call Statistics screen displays a table providing the following information, listing all currently active meetings by ID numbers:

Table 7-2 *Call Statistics Table Field Descriptions*

| Field | Description |
|-------------|--|
| Meeting ID | ID number uniquely identifying an active meeting. |
| Description | Text describing the active meeting. |
| Type | Displays the defined meeting type. Meeting types are static and ad hoc. |
| Rooms | Lists the CTS end points (meeting rooms) attending this meeting. |
| Duration | Length of time this meeting has been active, listed in hours, minutes and seconds. |
| Segments | Total number of segments for all rooms attending this meeting. |

- Step 3** To use the filter at the top of the table to find a particular meeting, enter either the Meeting ID number or the Room number in the appropriate field and then press “Filter.”

- Step 4** To display a defined number of table rows, click the down arrow next to “Rows per page.” Click to highlight and select predetermined amounts. If there are multiple pages, click the *First*, *Previous*, *Next*, or *Last* button to navigate to the desired page.
- Step 5** Click *Refresh* to refresh the active meetings displayed.
- Step 6** Click the radio button to the left of a table entry to select a particular meeting. Click *View Details* to display an abbreviated view of RTP statistics for the selected meeting. To see all RTP call statistics details for a particular meeting, click *Details* from the abbreviated view.
- Step 7** Click *View All Endpoint Details* to display a subset of audio and video RTP statistics for all active meetings. To see all RTP call statistics details for all meeting, click *Details* from the abbreviated view.
- Complete RTP statistic details include the following information for each CTMS call segment:

Audio Statistics

- SSRC (Receive)
- SSRC (Transmit)
- Max Jitter (Period)
- Max Jitter (Call)
- Mean Jitter (Period)
- Mean Jitter (Call)
- Jitter Standard Deviation (Period)
- Jitter Standard Deviation (Call)
- Jitter Spike (Period)
- Jitter Spike (Call)
- Jitter Spike Rate % (Period)
- Jitter Spike Rate % (Call)
- Total Packets (Receive)
- Total Packets (Transmit)
- Lost Packet Rate % (Receive)
- Lost Packet Rate (Transmit)
- Duplicate Packets
- Out of Order Packets
- Total Switching (Call)
- Max Switching (Period)

Video Statistics

- SSRC (Receive)
- SSRC (Transmit)
- Max Jitter (Period)
- Max Jitter (Call)
- Mean Jitter (Period)
- Mean Jitter (Call)


- Jitter Standard Deviation (Period)
 - Jitter Standard Deviation (Call)
 - Jitter Spike (Period)
 - Jitter Spike (Call)
 - Jitter Spike Rate % (Period)
 - Jitter Spike Rate % (Call)
 - Total Packets (Receive)
 - Total Packets (Transmit)
 - Lost Packet Rate % (Receive)
 - Lost Packet Rate (Transmit)
 - Duplicate Packets
 - Out of Order Packets
 - Total Switching (Call)
 - Max Switching (Period)
 - Feedback Packets Dropped
 - Total NAKs
 - Max Frame Window (Period)
 - Max Frame Window (Call)
 - Frame Window Spikes (Period)
 - Frame Window Spikes (Call)
 - Frame Window Spike Rate % (Period)
 - Frame Window Spike Rate % (Call)
 - IDR Packets (Received)
 - IDR Packets (Transmit)
-

Room Testing

Use Room Testing to perform loopback or force switch testing.

To perform loopback or force switch testing:

-
- Step 1** Click **Room Testing** under the **Monitoring** folder in the Navigation Pane to open the **Room Testing** window. [Figure 7-5](#) shows the Room Testing screen.

Figure 7-5 Room Testing Screen

Step 2 The initial Room Testing screen displays a table providing the following information, listing all currently active meetings by ID numbers:

Table 7-3 Room Testing Table Field Descriptions

| Field | Description |
|-------------|--|
| Meeting ID | ID number uniquely identifying an active meeting. |
| Description | Text describing the active meeting. |
| Type | Displays the defined meeting type. Meeting types are static and ad hoc. |
| Rooms | Lists the CTS end points (meeting rooms) attending this meeting. |
| Duration | Length of time this meeting has been active, listed in hours, minutes and seconds. |
| Segments | Total number of segments for all rooms attending this meeting. |

Step 3 To use the filter at the top of the table to find a particular meeting, enter either the Meeting ID number or the Room number in the appropriate field and then press “Filter.”

Step 4 To display a defined number of table rows, click the down arrow next to “Rows per page.” Click to highlight and select predetermined amounts. If there are multiple pages, click the **First**, **Previous**, **Next**, or **Last** button to navigate to the desired page.

Step 5 Click “Refresh” to refresh the active meetings displayed.

Step 6 Click the radio button to the left of a table entry to select a particular meeting. Click “Details” to display the Room Testing screen for the rooms in that meeting.

- a. Click “Loopback” to display the transmitted camera image (image is looped-back so that attendees see themselves) in each of the rooms for the selected meeting.

- b. Click “Force Switch” to force site switching between all of the rooms in the selected meeting.
 - c. Click “Close” to return to the Room Testing active meeting listing screen.
-



CHAPTER 8

Interoperability with Legacy Video Conferencing Devices

Initial Release: May 5, 2008, OL-12586-02
Last Revised: August 4, 2008

Contents

- [Overview, page 8-75](#)
 - [How Cisco TelePresence Interoperability Works, page 8-75](#)
 - [Benefits, page 8-77](#)
 - [Caveats, page 8-77](#)
- [Prerequisites, page 8-78](#)
- [Configuring Cisco TelePresence Interoperability, page 8-79](#)
 - [Configuring Unified CM for Cisco TelePresence Interoperability, page 8-79](#)
 - [Configuring CUVC for Cisco TelePresence Interoperability, page 8-81](#)
 - [Configuring CTMS for Cisco TelePresence Interoperability, page 8-85](#)

Overview


Cisco TelePresence is based on open standards, including SIP, H.264 and G.711. With Cisco TelePresence System (CTS) Release 1.3 and CTMS Release 1.1, Cisco TelePresence now supports interoperability between Cisco TelePresence systems and standard definition video conferencing/video telephony using the Cisco Unified Video Conferencing 3500 series MCU (CUVC).

How Cisco TelePresence Interoperability Works

As shown in [Figure 8-1](#), CTS endpoints send a copy of their audio in G.711 format to the CTMS server. CTMS then determines which CTS segment is emitting the most dominant audio and requests that segment to send a copy of that segment's video in Common Intermediate Format (CIF) resolution. CTMS

mixes the G.711 channels for all CTS endpoints into a single G.711 audio and switches CIF and G.711 to CUVC. As the dominant audio segment changes throughout the meeting, CTMS switches the CIF video stream accordingly. Audio-only participants on the CUVC side can join directly into the CUVC.

Figure 8-1 Cisco TelePresence Interoperability: From CTS/CTMS to CUVC




As shown in [Figure 8-2](#), audio and video coming from CUVC to CTMS is switched to all CTS endpoints when the audio coming from CUVC is deemed to be the most dominant segment. The CIF image from CUVC is presented on the left screen of each CTS-3000 surrounded by black borders. With the CTS-1000, the CIF image is displayed when CTMS senses that the CUVC participant is the active speaker. The incoming 352x288 CIF image is stretched to 4CIF when displayed on either the CTS-1000 or CTS3000 high-definition plasma screen.



Note

If you wish to see more than one CUVC participant displayed at one time, you can customize the CUVC MCU layout configuration to display up to 16 CUVC participants. We recommend the 1x1 layout for consistency with the Telepresence experience.

Figure 8-2 Cisco TelePresence Interoperability: From CUVC to CTS/CTMS

Benefits

Cisco TelePresence Interoperability maintains the immersive experience for Cisco TelePresence meeting participants. It also provides standards-based interoperability with minimal additional hardware (CUVC 3500 Series MCU) requirements. CTS and CTMS software upgrades are available at no charge.

Caveats

- Cisco TelePresence Interoperability increases the required amount of bandwidth to and from each CTS by an additional 704 kbps to transmit and receive the CIF and 64 kbps to transmit and receive G.711 streams.
- The interoperability segment is limited to CIF resolution video at 768 kbps and G.711 audio in CTMS Release 1.1.
- CUVC is the only supported MCU in this release. CUVC requires software version 5.5.0.0.54 or later.

- CUVC participants will not experience the spatial audio generated by CTS. CUVC participants hear all Cisco TelePresence participants mixed together in G.711.
- CUVC as an SCCP conference resource managed by Unified CM is not a supported option. The CUVC must be defined as a SIP trunk (and optionally an H.323 gateway) to Unified CM.
- CTS participants hear CUVC participants mixed together in G.711; audio will be heard from the same segment as that which is showing the CIF video.
- CTS and CUVC participants are not able to share slides or documents using H.239. Use another application for document sharing between CTS and CUVC, such as MeetingPlace or WebEx.
- Far End Camera Control (FECC) is not available to CTS participants during an interoperability call.
- Each interop conference uses one CTMS port and one CUVC port for each conference because each meeting utilizes a port for the cascade link. For example, CTMS normally can support 48 segments, and CUVC-3515-24 can support up to 24 participants. During interop meetings, CTMS supports a maximum of 47 segments and CUVC supports a maximum of 23 participants.
- Encryption is not supported for CTMS, Release 1.1, including interoperability calls.

Prerequisites

Interoperability between traditional video conferencing devices and CTS requires three components:

- CTMS
- Cisco Unified Communications Manager (Unified CM)
- CUVC MCU

The software and hardware requirements for Cisco TelePresence Interoperability are as follows:

CUVC Software and Hardware Requirements

- CUVC MCU Release 5.5.0.0.54:MP or later
- CUVC EMP Release 5.5.2.0.2:EMP or later

For additional information about configuring CUVC, refer to the *Configuration Guide for the Cisco Unified Videoconferencing 3545 MCU Release 5.5*.

Unified CM Software Requirements

- Unified CM Software Release 6.0 or later

For additional information about configuring Unified CM for Cisco TelePresence System, refer to the *Cisco Unified Communications Manager Installation Guide for the Cisco TelePresence System*.

For information about configuring Unified CM, refer to *Cisco Unified Communications Manager Version 6.0* and *Cisco Unified Communications Manager Version 6.1*.

CTS Endpoint Software Requirements

- CTS Software Release 1.3 or later

For more information about CTS Administration Software, refer to the *Cisco TelePresence System Release 1.3 Administrator's Guide*.

Configuring Cisco TelePresence Interoperability

To configure Cisco TelePresence Interoperability, you must complete the following configuration tasks:

- Configure Unified CM to support Cisco TelePresence Interoperability
- Configure CUVC to support Cisco TelePresence Interoperability
- Add at least one static meeting to CTMS with interoperability enabled

Configuring Unified CM for Cisco TelePresence Interoperability

To configure Unified CM for Cisco TelePresence Interoperability, you must create a SIP trunk security profile and a SIP trunk using the same configuration parameters as you would in defining a SIP trunk for CTMS. Then you must add a new route pattern in Unified CM that points to the CUVC. CTMS dials the CUVC using the number defined in the “CUVC number” field of the CTMS meeting definition when the first CTS participant joins the meeting.

Creating a SIP Trunk Security Profile

To create a SIP trunk security profile:

- Step 1** Click *System*. Under **Security Profile**, click *SIP Trunk Security Profile*.
- Step 2** Click the *Add New* button at the bottom of the page or click the + *sign* at the top of the page.
- Step 3** Enter the settings as indicated in [Table 8-1](#) to configure the SIP trunk security profile. Leave default settings for fields not included in [Table 8-1](#).

Table 8-1 SIP Trunk Security Profile Settings

| Field | Required | Setting |
|-------------------------|----------|--|
| Name | Yes | Enter a text string identifying this SIP trunk security profile. |
| Description | — | Enter a text string describing this SIP trunk security profile. |
| Device Security Mode | Yes | Select <i>Non Secure</i> . |
| Incoming Transport Type | Yes | Select <i>TCP+UDP</i> . |
| Outgoing Transport Type | Yes | Select <i>TCP</i> . |
| Incoming Port | Yes | Enter <i>5060</i> . |

- Step 4** Click the *Save* button at the bottom of the page.



Note

Use the same SIP Trunk Security Profile settings for the CTMS SIP trunk and the CUVC SIP trunk.

Creating a SIP Trunk

To create a SIP trunk for CTMS calls to the CUVC:

-
- Step 1** Click *Device*. Click *Trunk*.
 - Step 2** Click the *Add New* button at the bottom or click the + *sign* at the top of the Trunk Configuration page.
 - Step 3** Select *SIP Trunk* from the **Trunk Type** pull-down menu, then click *Next*.
 - Step 4** Enter the settings as indicated in [Table 8-2](#) to configure the SIP trunk. Leave default settings for fields not included in [Table 8-2](#).

Table 8-2 SIP Trunk Settings

| Field | Required | Setting |
|----------------------------|----------|--|
| Device Information | | |
| Device Name | Yes | Enter a text string identifying this SIP trunk. |
| Description | — | Enter a text string describing this SIP trunk. |
| Device Pool | Yes | Select <i>Default</i> . |
| SIP Information | | |
| Destination Address | Yes | Enter the IP address of the CUVC. |
| SIP Trunk Security Profile | Yes | Select the SIP trunk security profile that you created for CTMS. |
| SIP Profile | Yes | Select <i>Standard SIP Profile</i> . |

-
- Step 5** Click the *Save* button at the bottom of the page.
-

Configuring a Route Pattern



A route pattern allows a Unified CM-managed device to access another device by dialing its number. Such devices may include gateways, Cisco TelePresence Multipoint Switch (CTMS) systems, or Cisco Unified Video Conferencing (CUVC) units. Each device requires its own unique route pattern.

To configure a route pattern:

-
- Step 1** Click *Call Routing*. Under **Route/Hunt**, click *Route Pattern*.
 - Step 2** Click the *Add New* button at the bottom or click the + *sign* at the top of the Route Pattern Configuration page.

- Step 3** Enter the settings as indicated in [Table 8-3](#) to configure the SIP trunk. Leave default settings for fields not included in [Table 8-3](#).

Table 8-3 Route Pattern Configuration Settings

| Field | Required | Setting |
|---------------------------|----------|---|
| Pattern Definition | | |
| Route Pattern | Yes | <p>Enter the route pattern, including numbers and wildcards (do not use spaces); for example, for NANP, enter 9.@ for typical local access, or 8XXX for a typical private network numbering plan. The uppercase characters A, B, C, and D are valid characters.</p> <p> Note The portion of the route pattern's digit string sent to the CUVVC must begin with a valid service prefix as defined on the CUVVC.</p> <p> Note See the “Wildcards and Special Characters in Route Patterns and Hunt Pilots” section in the <i>Cisco CallManager System Guide</i> for more information about wildcards.</p> |
| Description | — | Enter a text string describing this route pattern. |
| Gateway/Route List | Yes | Select the SIP trunk that you created for CUVVC. |
| Call Classification | Yes | Select <i>OnNet</i> . |

- Step 4** Click the *Save* button at the bottom of the page.


Configuring CUVVC for Cisco TelePresence Interoperability

After basic CUVVC configuration has been completed and the unit has been connected to the host network, you need to perform the following tasks to configure the CUVVC for Cisco TelePresence Interoperability:

- Verify that the MCU and EMP are running the correct software version.
 - Log into the CUVVC Administration console and click the *Media Processing* tab.
 - Verify that the MCU is running Version 5.5.0.0.54:MP.
 - Verify that all EMPs are running Version 5.5.2.0.2:EMP.
- EMP resources must be available and the MCU service must be defined to use HD/SD Continuous Presence with a Max Call Rate of 768 kbps or greater. “HD Switch Mode” is not supported. If you choose a service configuration such as “HD Switched Video,” the cascade connection between CTMS and CUVVC will fail to connect.

- Enable SIP signaling on the CUVVC. A SIP proxy is not required for interoperability.
 - From the **Protocols** tab, click **SIP**. Click the **Enable SIP Protocol** box as shown in Figure 8-3.


Figure 8-3 SIP Configuration Screen



Note


SIP must be enabled on the CUVVC. CTMS must connect to CUVVC using SIP. When CTMS dials the CUVVC number, it sends a SIP INVITE to Unified CM for that number. Unified CM must be configured to route that number to CUVVC using a SIP trunk. CUVVC can connect to legacy video conferencing participants using either SIP or H.323.

- (Optional) Disable the SCCP protocol to save ports.
 - From the **Protocols** tab, click **SCCP** as shown in Fix XX. Click the **Disable SCCP Protocol** box.
- Enable H.323 signaling on the CUVVC.
 - From the **Protocols** tab, click **H.323** and the click the **Enable H.323 Protocol** box as shown in Figure 8-4.

Figure 8-4 H.323 Configuration Screen

- If you are using an H.323 Gatekeeper, define the Gatekeeper IP address and the Gatekeeper Port as 1719.
- If you are using an MCU as an H.323 trunk in Unified Communications, go to **Advanced H.323 Settings** on the CUVC Protocols configuration page and record the RAS port number and Signaling Port parameter value. Use the Signaling Port value for the Unified Communications H.323 Trunk Port definition.
- Configure CUVC meeting characteristics for Cisco TelePresence Interoperability. CUVC meeting characteristics are configured individually using the service prefix. Service prefixes define the CUVC meeting characteristics, and are defined on the CUVC Administration page under **Services**. From the **Automatic Service Definitions** page under **Services** as shown in [Figure 8-5](#), configure the following attributes:
 - Max Call Rate: 768 Kbps
 - Max layout: 1x1
 - Supported image size up to: CIF

Figure 8-5 Automatic Service Definition Screen



Click the **Advanced Management and Security** button under **Automatic Services** to open the Management and Security Screen. Click the **Port Reservation and Limits** tab. Configure the following attributes:

- Define the minimum number of guaranteed ports for interoperability conferences.
- Check the *Allow conference to grow over guaranteed value* box.
- Click **OK**.

From the **Advanced Audio Settings** page under **Automatic Services**, configure the following attributes:

- Verify that G.711 is in the supported codecs list; select **G.711**.

From the **Advanced Video Settings** page under **Automatic Services**, configure the following attributes:

- Check *Enable “No Self See”* box.
- Verify that H.264 is in the supported codecs list; select **H.264**.
- Click **Settings** to enter welcome text as required.

Click **Upload** for these changes to take effect.



Note

The route pattern created for CUV in Unified CM should match the CUV number and service prefix configured in CUV.

- Suppress reflected video for the initial caller. When a caller joins the CUVVC as the first participant of a Cisco Telepresence conference, the default behavior is for that caller to see his or her own image. To have that initial caller see a black screen instead, you must suppress reflected video. To suppress the reflected video:
 - From the MCU configuration page, select the *Settings* tab, then click *Advanced*. The page refreshes and displays a *Command* button.
 - Click *Commands*. The Advanced Commands window appears.
 - In the Commands field, enter: **mc:notselfseeefirstpart**
 - In the Parameter field, enter the service prefix number followed by either **0** (to deactivate) or **1** (activate) suppressed reflection.
 - Click *Send* to issue request to the CUVVC. If the command is successful, the response field indicates “OK.”
- Network Configuration: The CUVVC MCU and EMP cards each have their own Ethernet cables and IP addresses. Make sure that the switch to where the two cables attach is defined to allow QoS to be passed through to the network as a trusted device. This requirement applies to all video devices including CTS and CTMS. Configuration example is as follows:

```
interface TenGigabitEthernet 4/2
  description ===connection to telepresence gateway 2===
  ip address 10.xx.xx.xx 255.255.255.252
  ip pim sparse-dense-mode
  mls qos trust dscp end
```

For general information about the CUVVC configuration tasks, refer to the *Configuration Guide for the Cisco Unified Videoconferencing 3545 MCU Release 5.5*.

Configuring CTMS for Cisco TelePresence Interoperability

The next step is to configure a static meeting in CTMS in “interop mode.” When the first CTS caller joins the teleconference, CTMS dials out to the CUVVC using the Interoperability number configured in the CTMS meeting definition. CTMS dials out to the CUVVC using the SIP trunk defined in Unified CM. CTMS cannot use H.323 signaling for this connection. When configuring the SIP trunk, specify a device pool with a region configured for a video bandwidth of 768 kbps or higher.

Creating Static Meetings in CTMS for Interoperability

To create a static meeting:

-
- Step 1** Click *Static Meetings* under the **Meetings Management** folder in the Navigation Pane.
 - Step 2** The Static Meetings setting screen initially displays a table providing the following information about already defined static meetings.

Table 8-4 **Static Meetings Table Field Descriptions**

| Field | Description |
|---------------|--|
| Access Number | Displays the access number that rooms call to attend this meeting. |
| Description | Displays the defined description for this static meeting. |

Table 8-4 Static Meetings Table Field Descriptions

| Field | Description |
|------------------|--|
| Switching Policy | Displays the defined switching policy (site or segment) for this static meeting. |
| Max Rooms | Displays the maximum number of sites that can participate in this static meeting. |
| Quality | Sets the maximum bit rate and video resolution to be used for the meeting. |
| Interop | A green check indicates that this particular Cisco TelePresence multipoint meeting supports Cisco Unified Video Conferencing (CUVC) systems (interoperability mode). A red “X” indicates that this meeting is not configured to cascade with CUVC systems. |
| CUVC Number | (Optional) Number dialed to CUVC for interoperability meetings. |

- To delete one of the defined static meetings, click the radio button to the left of the table entry, and then click **Delete**.
- To edit one of the defined static meetings, click the radio button to the left of the table entry, and then click **Edit**.
- To define a new static meeting, click **New**.

Step 3 When you click **Edit** or **New**, CTMS Administration software takes you to the Static Meeting Settings table. Enter settings as described in [Table 8-5](#):

Table 8-5 Static Meeting Settings



| Field or Button | Setting |
|---------------------|--|
| Access Number | Defines the telephone number that participants call to attend this static meeting. |
| Meeting Description | Text describing or identifying this static meeting. The maximum number of characters for this field is 62 characters. |
| Switching Policy | <p>Defines how CTMS calls are displayed during a meeting. CTMS displays active speakers on screen. There are two active speaker display options:</p> <ul style="list-style-type: none"> • Segment: (Speaker) With segment switching, each individual table segment (defined as a display and a camera) is displayed on the screen as that segment becomes the active speaker. • Site: (Room) When you select “site,” all table segments for a particular room are displayed on screen when any segment in that room is the active speaker. <p>Click the appropriate radio button to select.</p> <div>  <p>Note If you are running CTS 1.3 or later, you can control how Cisco TelePresence calls are displayed from the Cisco TelePresence phone interface. Press the Speaker softkey to display the active segment; press the Room softkey to display all segments from a particular site.</p> </div> |

Table 8-5 Static Meeting Settings

| Field or Button | Setting |
|------------------|--|
| Maximum Rooms | Defines the maximum number of Cisco TelePresence rooms allowed to dial into in a static multi-point meeting. The range for this setting is from 2 to 48. |
| Video Announce | If this option is selected, when a new room joins the meeting, the new room is displayed on-screen for 2 seconds. Options are Yes and No . Click the appropriate radio button to select. |
| Hosted Meeting | Hosted meetings mean that one particular room is identified as the host for a meeting; other meeting rooms will not be added to the meeting until the host room dials in. If you have selected “Video announce,” then each meeting room will be displayed in 2-second intervals in the order that they joined the meeting. Options are Yes and No . Click the appropriate radio button to select. |
| Host Room Number | Defines the host Cisco TelePresence System room number. |
| Quality | This field sets the system bandwidth and screen resolution. A higher bandwidth increases video quality, but may also cause packets to be dropped and video to be interrupted. Choices: <ul style="list-style-type: none"> • Highest Detail, Best Motion: 4Mbps 1080p • Highest Detail, Better Motion: 3.5Mbps, 1080p • Highest Detail, Good Motion: 3Mbps, 1080p • Highest Detail, Best Motion: 3Mbps, 720p • Highest Detail, Better Motion: 2Mbps, 720p • Highest Detail, Good Motion: 1Mbps, 720p Default is Highest Detail, Best Motion: 4Mbps 1080p. |
| Interop | Determines whether this particular Cisco TelePresence multipoint meeting accepts legacy Cisco Unified Video Conferencing (CUVC) systems (interop). Options are Yes and No . Click the appropriate radio button to select. |
| CUVC Number | Defines the number that CTMS dials to establish contact with CUVC. Each CUVC number must be unique for each CTMS conference. The CUVC number consists of the service prefix and then the remaining dialed digits. The service prefix can be the same for different meetings. The remaining digits in the dialed number designate the CUVC meeting instance. Each CTMS conference requires it owns CUVC meeting instance. |
| |  <p>Note This number must start with the CUVC service prefix defined during CUVC configuration.</p> |

- To register new or modified settings, click **Apply**.
- To restore the original settings, click **Reset**.

Troubleshooting Cisco TelePresence Interoperability

Table 8-6 describes some specific problems and possible solutions.

Table 8-6 *Specific Problems and Possible Solutions*

| Problem | Possible Solutions |
|---|---|
| Unified CM sends an error message of “Service not available” to CTMS when CTMS tries to establish call to CUVC. | <ul style="list-style-type: none"> • Check to see if there are sufficient ports. Unified CM delivers a “Service not available” message when CTMS places a call to CUVC and there are an insufficient number of ports available. • Disable SCCP on the CUVC. |
| | |



APPENDIX **A**

Command Line Interface (CLI) Commands

Initial Release: August 4, 2008, OL-12586-02

Tables of Contents

- [“Introduction” section on page A-1](#)
- [“Starting a CLI Session” section on page A-1](#)
- [“CLI Command Basics” section on page A-2](#)
- [“Ending a CLI Session” section on page A-2](#)
- [“CTMS CLI Commands” section on page A-2](#)

Introduction

This chapter explains how to use Cisco TelePresence Multipoint Switch (CTMS) Command Line Interface (CLI) commands.

Starting a CLI Session

You can access the CTMS CLI through the physical console or remotely. If accessing the CTMS CLI remote, use Secure Shell (SSH) from a personal computer or workstation to connect securely to CTMS.

Before you begin, be sure that you have the following information:

- CTMS IP address
- Admin ID and password

You will need this information to log into CTMS.



Note

The admin ID and password can be changed from the default in the Cisco Unified Communications Manager (Unified CM) for CTMS device page.

To start a CLI session:

Step 1 From a remote system, use SSH to connect securely to CTMS. In the SSH client, enter the following information: `ssh adminname@IP Address`

- `adminname` is the Admin ID
- `IP Address` is the IP address of CTMS

Step 2 When the system prompts you, enter the password.

Step 3 The CLI prompt (`admin`) displays. You can now enter any CLI command.



Note The prompt will always be “`admin`.”

CLI Command Basics

- Enter the beginning of a command and press **Tab** to have the system complete the command for you.
- Enter a full command and press **Tab** to display all commands or subcommands that are available. If you press **Tab** and the current command line repeats, no additional expansions are available.
- To get detailed help, enter **help** *command name* at the CLI prompt.
- To get command syntax for a particular command, enter *command name*? at the CLI prompt

Ending a CLI Session

To end a CLI session:

Step 1 At the CLI prompt, enter **quit**.

CTMS CLI Commands

The following CLI commands are used with Cisco TelePresence Multipoint Switch:

- [confmgmt](#), page A-5
- [media GetDSCP](#), page A-6
- [set bad_ep_detect](#), page A-7
- [set commandcount](#), page A-8
- [set conferencetermination](#), page A-9
- [set cuvc dialrepeatinterval](#), page A-10
- [set cuvc dialrepeattime](#), page A-11
- [set damping](#), page A-12
- [set feedbackwaitbasetime](#), page A-13

- [set holdresume, page A-14](#)
- [set lateendmins, page A-15](#)
- [set logging, page A-16](#)
- [set network dns, page A-17](#)
- [set network ip eth0, page A-18](#)
- [set password admin, page A-19](#)
- [set timezone, page A-20](#)
- [show account, page A-21](#)
- [show active conference, page A-22](#)
- [show badep, page A-23](#)
- [show conferencetermination, page A-24](#)
- [show cuvdialrepeatinterval, page A-25](#)
- [show cuvdialrepeattime, page A-26](#)
- [show damping, page A-27](#)
- [show details, page A-28](#)
- [show dscp packet, page A-29](#)
- [show feedbackwaittime, page A-30](#)
- [show feedbackwaitbasetime, page A-31](#)
- [show firewall list, page A-32](#)
- [show hardware, page A-35](#)
- [show holdresume, page A-36](#)
- [show lateendmins, page A-37](#)
- [show logins, page A-38](#)
- [show myself, page A-39](#)
- [show network all, page A-40](#)
- [show network eth0, page A-42](#)
- [show network failover, page A-43](#)
- [show network ip_conntrack, page A-44](#)
- [show network max_ip_conntrack, page A-45](#)
- [show network route, page A-46](#)
- [show network status, page A-47](#)
- [show packages, page A-48](#)
- [show rtpsleep, page A-49](#)
- [show statistics, page A-50](#)
- [show status, page A-53](#)
- [show threshold, page A-55](#)
- [show timezone, page A-56](#)
- [show version, page A-58](#)

- [show workingdir](#), page A-59
- [utils remote_account](#), page A-60
- [utils remote_account create](#), page A-61
- [utils remote_account status](#), page A-62
- [utils system restart](#), page A-63
- [utils system shutdown](#), page A-64
- [utils system switch-version](#), page A-65

confmgmt

confmgmt {listconf | listconfdetail}

Syntax Description

| | |
|-----------------------|--|
| listconf | Displays the active conference identification number. |
| listconfdetail | Lists conference details by conference identification number or participant identification number. |

Command Modes

Admin

Command History

| Release | Modifications |
|---------|------------------------------------|
| 1.1 | This command was first documented. |

Usage Guidelines

Use this command to obtain an active CTMS conference identification number or to display conference details for a given conference ID or participant ID.

Examples

```
admin:confmgmt listconf
```

Related Commands

| Command | Description |
|---------|-------------|
| None | |

media GetDSCP

media GetDSCP

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| | | |
|------------------------|----------------|------------------------------------|
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |

| | |
|-------------------------|---|
| Usage Guidelines | Use this command to obtain DSCP values being inserted into media packets. |
|-------------------------|---|

| | |
|-----------------|---|
| Examples | <pre>admin:media GetDSCP Current DSCP value:128</pre> |
|-----------------|---|

| | | |
|-------------------------|----------------|--------------------|
| Related Commands | Command | Description |
| | None | |

set bad_ep_detect

set bad_ep_detect {enable | disable}

| | | |
|--------------------|--|---|
| Syntax Description | enable | Enables bad endpoint detection feature; if detected, CTMS will drop a bad endpoint from conferences |
| | disable | Disables bad endpoint detection feature. |
| Command Modes | Admin | |
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |
| Usage Guidelines | Use this command to either enable or disable the bad endpoint detection feature. If this command is set to enable , bad source endpoints will be dropped from conferences; if set to disable , the bad endpoint will be kept in the meeting. | |
| Examples | admin:set bad_ep_detect disable Telepresence Multipoint Switch; drop bad endpoint: disable | |
| Related Commands | Command | Description |
| | show badep | Displays whether bad endpoint detection has been enabled or disabled |

set commandcount

set commandcount {enable | disable}

| | | |
|---------------------------|---|---|
| Syntax Description | enable | Enables command count feature. Using enable changes the CLI command prompt so that it displays a numeric value showing how many CLI commands have been executed |
| | disable | Disables command count feature. Using disable changes the CLI command prompt so that it stops displaying a numeric value showing how many CLI commands have been executed. |
| Command Modes | Admin | |
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |
| Usage Guidelines | Use this command to either enable or disable the command count feature. This command changes the CLI command prompt so that it displays a numeric value showing how many CLI commands have been executed. This setting is valid for current session only. | |
| Examples | <pre>admin:set commandcount enable admin 0005:</pre> | |
| Related Commands | Command | Description |
| | set logging | Enables or disables logging feature |

set conferencetermination

set conferencetermination {true | false}

| Syntax Description | true | Enables conference termination for scheduled conferences. |
|--------------------|-------|--|
| | false | Disables conference termination for scheduled conferences. |

| Command Modes | Admin |
|---------------|-------|
|---------------|-------|

| Command History | Release | Modifications |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| Usage Guidelines | Use this command to either enable or disable conference termination for scheduled conferences. |
|------------------|--|
|------------------|--|



| Note | This command takes effect when CTMS is registered with Cisco TelePresence Manager but not supported by Cisco TelePresence Manager. |
|------|--|
|------|--|

| Examples | admin:set conferencetermination true |
|----------|--------------------------------------|
|----------|--------------------------------------|

| Related Commands | Command | Description |
|------------------|----------------------------|--|
| | show conferencetermination | Displays list of conferences with enabled or disabled conference termination |

set cuvc dialrepeatinterval

set cuvc dialrepeatinterval *number*

| | | |
|---------------------------|--|---|
| Syntax Description | <i>number</i> | Length of time, in seconds, that the CTMS system waits between redialing the CUVC. The default is 30. |
| Command Modes | Admin | |
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |
| Usage Guidelines | Use this command to configure the time (in seconds) for CTMS to redial a CUVC participant. | |
| Examples | admin: set cuvc dialrepeatinterval 30 | |
| Related Commands | Command | Description |
| | set cuvc dialrepeattime | Configures the number of times CTMS redials a CUVC participant |

set cuvc dialrepeattime

set cuvc dialrepeattime *number*

| | | |
|---------------------------|--|---|
| Syntax Description | <i>number</i> | Number of times CTMS will redial a CUVC meeting participant. The default is 50. |
| Command Modes | Admin | |
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |
| Usage Guidelines | Use this command to configure the number of times CTMS will redial a CTMS meeting participant. | |
| Examples | admin: set cuvc dialrepeattime 10 | |
| Related Commands | Command | Description |
| | set cuvc dialrepeatinterval | Configures the time (in seconds) for CTMS to redial a CUVC participant |

set damping

set damping {s | l | b | o} {fast | medium | slow}

| | | |
|---------------------------|---------------|---|
| Syntax Description | s | Switching mode; switching damping refers to how long people must talk to be switched in as active speaker. |
| | l | Lecture mode; lecture damping refers to how long somebody other than the lecturer must talk to take the conference out of lecture mode. |
| | b | Bounce mode; bounce damping refers to how long somebody must talk to override a bounceback source. |
| | o | Override mode; override damping refers to how long, after being overridden, a bounceback source is switched back in. |
| | fast | Fast mode speed: .5 to 1.5 seconds |
| | medium | Medium mode speed: 1.5 to 2.5 seconds |
| | slow | Slow mode speed: 2.5 to 3.5 seconds |

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| | | |
|------------------------|----------------|------------------------------------|
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |

| | |
|-------------------------|---|
| Usage Guidelines | Use this command to set damping values for switching. |
|-------------------------|---|

| | |
|-----------------|----------------------------------|
| Examples | admin: set damping s fast |
|-----------------|----------------------------------|

| | | |
|-------------------------|---------------------|---|
| Related Commands | Command | Description |
| | show damping | Displays damping speeds for configured damping modes. |

set feedbackwaitbasetime

set feedbackwaitbasetime *value*

Syntax Description

| | |
|--------------|--|
| <i>value</i> | Sets RTP feedback base wait time in milliseconds. Values are from 30 to 400. Default is 150. |
|--------------|--|

Command Modes

Admin

Command History

| Release | Modifications |
|---------|------------------------------------|
| 1.1 | This command was first documented. |

Usage Guidelines

Use this command to set RTP feedback base wait time in milliseconds. Real feedback wait time is equal to the maximum latency value plus the feedback wait base time.

Examples

```
admin:set feedbackwaitbasetime 200
```

Related Commands

| Command | Description |
|---------------------------|--|
| show feedbackwaitbasetime | Displays RTP feedback base wait time in milliseconds |

set holdresume

set holdresume {true | false}

| | | |
|---------------------------|--------------|--|
| Syntax Description | true | Enables server side hold/resume feature for static and scheduled conferences. (User sees an hour glass icon on the display.) |
| | false | Disables server side hold/resume feature for static and scheduled conferences. (User sees a blank screen.) |

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| | | |
|------------------------|----------------|------------------------------------|
| Command History | Release | Modification |
| | 1.1 | This command was first documented. |


| | |
|-------------------------|---|
| Usage Guidelines | Use this command to enable or disable server side hold/resume feature for static and scheduled conferences. |
|-------------------------|---|

| | |
|-----------------|-----------------------------------|
| Examples | admin: set holdresume true |
|-----------------|-----------------------------------|

| | | |
|-------------------------|------------------------|---|
| Related Commands | Command | Description |
| | show holdresume | Retrieves current server side hold/resume settings for static and scheduled conferences |

set lateendmins

set lateendmins *value*

| | | |
|---------------------------|---|--|
| Syntax Description | <i>value</i> | Number of minutes after which a conference will be terminated when the meeting exceeds the scheduled end time. |
| Command Modes | Admin | |
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |
| Usage Guidelines | Use this command to define the number of minutes after which a conference will be terminated when the meeting exceeds the scheduled end time. | |
| |  Note This command takes effect when CTMS is registered with Cisco TelePresence Manager but not supported by Cisco TelePresence Manager. | |
| Examples | admin: set lateendmins 3 | |
| Related Commands | Command | Description |
| | None | |

set logging

set logging {enable | disable}

Syntax Description

| | |
|----------------|-------------------|
| enable | Enables logging. |
| disable | Disables logging. |

Command Modes

Admin

Command History

| Release | Modifications |
|---------|------------------------------------|
| 1.1 | This command was first documented. |

Usage Guidelines

Use this command to either enable or disable logging.

Examples

```
admin:set logging enable
```

Related Commands

| Command | Description |
|-------------------------|---|
| set commandcount | Enables or disables command count feature |

set network dns

set network dns {*primary address* | *secondary address*}

Syntax Description

| | |
|--------------------------|--|
| primary address | Defines a new address for the primary DNS server. Values for <i>address</i> are valid dotted decimal IP addresses. |
| secondary address | Defines a new address for the secondary DNS server. Values for <i>address</i> are valid dotted decimal IP addresses. |

Command Modes

Admin

Command History

| Release | Modifications |
|---------|------------------------------------|
| 1.1 | This command was first documented. |

Usage Guidelines

Use this command to define new IP addresses for primary or secondary DNS servers.

This command causes a temporary loss of network connectivity. If you want to continue with defining a new address for the DNS server, type **Yes**. Otherwise, click any other key to abort.

Examples

```
admin:set network dns primary 1.2.3.4
*** WARNING ***
This will cause the system to temporarily lose network connectivity
Do you want to continue?
Enter "yes" to continue or any other key to abort
yes
```

Related Commands

| Command | Description |
|----------------------------|---|
| set network ip eth0 | Defines a new IP address and subnet mask for Ethernet 0 |

set network ip eth0

set network ip eth0 *address*

Syntax Description

| | |
|----------------|---|
| <i>address</i> | Defines a new IP address and subnet mask for Ethernet 0. Values for <i>address</i> are valid dotted decimal IP addresses followed by subnet mask value. |
|----------------|---|

Command Modes

Admin

Command History

| Release | Modifications |
|---------|------------------------------------|
| 1.1 | This command was first documented. |

Usage Guidelines

Use this command to define a new IP address and subnet mask for Ethernet 0. The system automatically reboots after you execute this command.

Examples

```
admin:set network ip eth0 192.168.1.5 255.255.255.0
*** WARNING ***
This will cause the system to restart - Do you want to continue?
Enter "yes" to continue and restart or any other key to abort
yes
```

Related Commands

| Command | Description |
|------------------------|---|
| set network dns | Defines new IP addresses for primary or secondary DNS servers |

set password admin

set password admin

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| | | |
|------------------------|----------------|------------------------------------|
| Command History | Command | Modifications |
| | 1.1 | This command was first documented. |

| | |
|-------------------------|---|
| Usage Guidelines | Use this command to set a new administrator password. |
| | Note Passwords must be at least 6 characters, but not more than 64 characters in length, and can contain upper and lower case alphanumeric characters and the underscore and dash characters. The following usernames are not allowed: apache, daemon, nobody, operator, and shutdown. |

| | |
|-----------------|---|
| Examples | admin: set password admin |
| | Please enter the old password: ***** |
| | Please enter the new password: ***** |
| | Re-enter new password to confirm: ***** |

| | | |
|-------------------------|----------------|--------------------|
| Related Commands | Command | Description |
| | None | |

set timezone

set timezone *timezone*

Syntax Description

| | |
|-----------------|--|
| <i>timezone</i> | Enter the appropriate text string or timezone code for the zone you want to configure. Use the show timezone list command to display a complete list of available timezone codes. |
|-----------------|--|

Command Modes

Admin

Command History

| Release | Modifications |
|---------|------------------------------------|
| 1.1 | This command was first documented. |

Usage Guidelines

Use this command to set a new timezone value. This sets system time on CTMS server

Examples

```
admin: set timezone Pac
```

Related Commands

| Command | Description |
|-----------------------------|---------------------------------------|
| show timezone config | Displays the current timezone setting |
| show timezone list | Displays a list of valid timezones |

show account

show account

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| | | |
|------------------------|----------------|------------------------------------|
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |

| | |
|-------------------------|--|
| Usage Guidelines | Use this command to display a list of all administrative accounts except for the master administrator account. |
|-------------------------|--|

| | |
|-----------------|--|
| Examples | <pre>admin:show account Name = test, Privilege = 1</pre> |
|-----------------|--|

| | | |
|-------------------------|----------------|--------------------|
| Related Commands | Command | Description |
| | None | |

show active conference

show active conference

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| | | |
|------------------------|----------------|------------------------------------|
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |

| | |
|-------------------------|---|
| Usage Guidelines | Use this command to display a list of active conference identification numbers. |
|-------------------------|---|

| | |
|-----------------|--|
| Examples | admin: show active conference 9059578056 |
|-----------------|--|

| | | |
|-------------------------|----------------|--------------------|
| Related Commands | Command | Description |
| | None | |

show badep

show badep

| | |
|--------------------|------|
| Syntax Description | None |
|--------------------|------|

| | |
|---------------|-------|
| Command Modes | Admin |
|---------------|-------|

| Command History | Release | Modifications |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| | |
|------------------|--|
| Usage Guidelines | Use this command to display whether bad endpoint detection is enabled or disabled. |
|------------------|--|

| | |
|----------|--|
| Examples | <pre>admin:show badep Current setting to drop bad endpoint: enable</pre> |
|----------|--|

| Related Commands | Command | Description |
|------------------|-------------------|--|
| | set bad_ep_detect | Enables or disabled bad endpoint detection |

show conferencetermination

show conferencetermination

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| Command History | Release | Modifications |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| | |
|-------------------------|--|
| Usage Guidelines | Use this command to display a list of conferences with enabled or disabled conference termination. |
|-------------------------|--|

| | |
|-----------------|--|
| Examples | admin: show conferencetermination |
|-----------------|--|

| Related Commands | Command | Description |
|------------------|----------------------------------|--|
| | set conferencetermination | Enables or disables conference termination for scheduled conferences |

show cuvc dialrepeatinterval

show cuvc dialrepeatinterval

| | |
|--------------------|------|
| Syntax Description | None |
|--------------------|------|

| | |
|---------------|-------|
| Command Modes | Admin |
|---------------|-------|

| Command History | Release | Modifications |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| | |
|------------------|---|
| Usage Guidelines | Use this command to view the CUVC redial time in seconds. |
|------------------|---|

| | |
|----------|--|
| Examples | admin: show cuvc dialrepeatinterval |
|----------|--|

| Related Commands | Command | Description |
|------------------|---------------------------------|---|
| | show cuvc dialrepeattime | Displays configured CUVC redial retries |

show cuvc dialrepeattime

show cuvc dialrepeattime

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| | | |
|------------------------|----------------|------------------------------------|
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |

| | |
|-------------------------|--|
| Usage Guidelines | Use this command to view configured CUVC redial retry value. |
|-------------------------|--|

| | |
|-----------------|--|
| Examples | <pre>admin:show cuvc dialrepeattime cvc retry time is 50</pre> |
|-----------------|--|

| | | |
|-------------------------|------------------------------|--|
| Related Commands | Command | Description |
| | show cuvc dialrepeatinterval | Displays the CUVC redial time in seconds |

show damping

show damping {s | l | b | o}

| Syntax Description | s | Switching mode; switching damping refers to how long people must talk to be switched in as active speaker. |
|--------------------|----------|---|
| | l | Lecture mode; lecture damping refers to how long somebody other than the lecturer must talk to take the conference out of lecture mode. |
| | b | Bounce mode; bounce damping refers to how long somebody must talk to override a bounceback source. |
| | o | Override mode; override damping refers to how long, after being overridden, a bounceback source is switched back in. |

| Command Modes | Admin |
|---------------|-------|
|---------------|-------|

| Command History | Release | Modifications |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| Usage Guidelines | Use this command to display damping speeds for defined damping modes. |
|------------------|---|
|------------------|---|

| Examples | <pre>admin:show damping s Damping time is currently set to medium admin:show damping l Lecture damping time is currently set to medium</pre> |
|----------|--|
|----------|--|

| Related Commands | Command | Descriptions |
|------------------|--------------------|------------------------------------|
| | set damping | Sets damping values for switching. |

show details

show details {conference | participant}

Syntax Description

| | |
|--------------------|------------------------------------|
| conference | Conference identification number |
| participant | Participant identification number. |

Command Modes

Admin

Command History

| Release | Modifications |
|---------|------------------------------------|
| 1.1 | This command was first documented. |

Usage Guidelines

Use this command to list conference details either by conference identification number or by participant identification number.

Examples

```
admin:show details conference 9059578056
Conference Id: 9059578056
Conference type: Immediate
Participant list: 11080, 11081, 11082
Conference description: TESTING
Switching policy: SITE
AutoLecture Mode: false
Video Announce: true
Total segments: 3
Resolution & Bandwidth: 1080p 4MBps
IsLocked: false
```

Related Commands

| Command | Description |
|---------|-------------|
| None | |

show dscp packet

show dscp packet

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| Command History | Release | Modifications |
|------------------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| | |
|-------------------------|---|
| Usage Guidelines | Use this command to display configured DSCP values being inserted in media packets. |
|-------------------------|---|

| | |
|-----------------|--|
| Examples | <pre>admin:show dscp packet Current DSCP value:128</pre> |
|-----------------|--|

| Related Commands | Command | Description |
|-------------------------|---------|-------------|
| | None | |

show feedbackwaittime

set feedbackwaittime confid *number*

| | | |
|---------------------------|---|--|
| Syntax Description | confid <i>number</i> | Conference identification number |
| Command Modes | Admin | |
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |
| Usage Guidelines | Use this command to return feedback wait time information for a conference in milliseconds. Feedback wait time is equal to maximum latency per conference plus feedback wait base time. | |
| Examples | <pre>admin:show feedbackwaittime 9059578056 FBWaitTime=254</pre> | |
| Related Commands | Command | Description |
| | set feedbackwaitbasetime | Set RTPs feedback base wait time in milliseconds |
| | show feedbackwaitbasetime | Displays RTP feedback base wait time in milliseconds |

show feedbackwaitbasetime

show feedbackwaitbasetime

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| Command History | Release | Modifications |
|------------------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| | |
|-------------------------|--|
| Usage Guidelines | Use this command to display RTP feedback base wait time in milliseconds. |
|-------------------------|--|


| | |
|-----------------|--|
| Examples | <pre>admin:show feedbackwaitbasetime Current Feedback wait base time is 250 ms</pre> |
|-----------------|--|

| Related Commands | Command | Description |
|-------------------------|--------------------------|--|
| | set feedbackwaitbasetime | Set RTPs feedback base wait time in milliseconds |

show firewall list

show firewall list [detail | page | file *name*]

Syntax Description

| | |
|---|---|
| detail | Shows details |
| page | Pauses input after one page |
| file <i>name</i> | Outputs the information to the indicated file name. |
|  Note The file will be saved in platform/cli/fname.txt. <i>Name</i> should not contain periods. | |

Command Modes

Admin

Command History

| Release | Modifications |
|---------|------------------------------------|
| 1.1 | This command was first documented. |

Usage Guidelines

Use this command to display a list of current firewall port information.

Examples

```
admin:show firewall list
Chain INPUT (policy ACCEPT)
target    prot opt source                destination
DROP      all  --  localhost             anywhere
ACCEPT    udp  --  anywhere              anywhere      udp dpt:syslog
DROP      udp  --  anywhere              anywhere      udp dpt:syslog
ACCEPT    ipv6-crypt-- anywhere             anywhere
ACCEPT    icmp --  anywhere              anywhere      icmp echo-request limit: avg
10/sec burst 5
LOG        icmp --  anywhere              anywhere      icmp echo-request limit: avg
1/min burst 5 LOG level warning prefix `ping flood '
DROP      icmp --  anywhere              anywhere      icmp echo-request
DROP      tcp  --  anywhere              anywhere      tcp dpt:ftp
DROP      udp  --  anywhere              anywhere      udp dpt:ftp
DROP      tcp  --  anywhere              anywhere      tcp dpt:telnet
DROP      udp  --  anywhere              anywhere      udp dpt:telnet
DROP      tcp  --  anywhere              anywhere      tcp dpt:tftp
DROP      tcp  --  anywhere              anywhere      tcp dpt:gopher
DROP      udp  --  anywhere              anywhere      udp dpt:gopher
DROP      tcp  --  anywhere              anywhere      tcp dpt:finger
DROP      udp  --  anywhere              anywhere      udp dpt:finger
DROP      udp  --  anywhere              anywhere      udp dpt:http
DROP      tcp  --  anywhere              anywhere      tcp dpt:rtelnet
DROP      udp  --  anywhere              anywhere      udp dpt:rtelnet
DROP      tcp  --  anywhere              anywhere      tcp dpt:pop2
DROP      udp  --  anywhere              anywhere      udp dpt:pop2
DROP      tcp  --  anywhere              anywhere      tcp dpt:pop3
DROP      udp  --  anywhere              anywhere      udp dpt:pop3
DROP      tcp  --  anywhere              anywhere      tcp dpt:sunrpc
```

```

DROP      udp  --  anywhere      anywhere      udp  dpt:sunrpc
DROP      tcp  --  anywhere      anywhere      tcp  dpt:uucp-path
DROP      udp  --  anywhere      anywhere      udp  dpt:uucp-path
DROP      tcp  --  anywhere      anywhere      tcp  dpt:imap
DROP      udp  --  anywhere      anywhere      udp  dpt:imap
DROP      tcp  --  anywhere      anywhere      tcp  dpt:xdmcp
DROP      udp  --  anywhere      anywhere      udp  dpt:xdmcp
DROP      tcp  --  anywhere      anywhere      tcp  dpt:nextstep
DROP      udp  --  anywhere      anywhere      udp  dpt:nextstep
DROP      tcp  --  anywhere      anywhere      tcp  dpt:irc
DROP      udp  --  anywhere      anywhere      udp  dpt:irc
DROP      tcp  --  anywhere      anywhere      tcp  dpt:imap3
DROP      udp  --  anywhere      anywhere      udp  dpt:imap3
DROP      tcp  --  anywhere      anywhere      tcp  dpt:faterv
DROP      udp  --  anywhere      anywhere      udp  dpt:faterv
DROP      udp  --  anywhere      anywhere      udp  dpt:https
DROP      tcp  --  anywhere      anywhere      tcp  dpt:saft
DROP      udp  --  anywhere      anywhere      udp  dpt:saft
DROP      tcp  --  anywhere      anywhere      tcp  dpt:shell
DROP      udp  --  anywhere      anywhere      udp  dpt:syslog
DROP      tcp  --  anywhere      anywhere      tcp  dpt:printer
DROP      udp  --  anywhere      anywhere      udp  dpt:printer
DROP      tcp  --  anywhere      anywhere      tcp  dpt:uucp
DROP      udp  --  anywhere      anywhere      udp  dpt:540
DROP      tcp  --  anywhere      anywhere      tcp  dpt:klogin
DROP      tcp  --  anywhere      anywhere      tcp  dpt:kshell
DROP      tcp  --  anywhere      anywhere      tcp  dpt:remotefs
DROP      tcp  --  anywhere      anywhere      tcp  dpt:ipp
DROP      udp  --  anywhere      anywhere      udp  dpt:ipp
DROP      tcp  --  anywhere      anywhere      tcp  dpt:676
DROP      udp  --  anywhere      anywhere      udp  dpt:676
DROP      tcp  --  anywhere      anywhere      tcp  dpt:rsync
DROP      udp  --  anywhere      anywhere      udp  dpt:rsync
DROP      tcp  --  anywhere      anywhere      tcp  dpt:telnets
DROP      udp  --  anywhere      anywhere      udp  dpt:telnets
DROP      tcp  --  anywhere      anywhere      tcp  dpt:imaps
DROP      udp  --  anywhere      anywhere      udp  dpt:imaps
DROP      tcp  --  anywhere      anywhere      tcp  dpt:pop3s
DROP      udp  --  anywhere      anywhere      udp  dpt:pop3s
DROP      tcp  --  anywhere      anywhere      tcp  dpt:nfs
DROP      udp  --  anywhere      anywhere      udp  dpt:nfs
DROP      tcp  --  anywhere      anywhere      tcp  dpt:x11
DROP      tcp  --  anywhere      anywhere      tcp  dpt:6001
DROP      tcp  --  anywhere      anywhere      tcp  dpt:6002
DROP      tcp  --  anywhere      anywhere      tcp  dpt:6003
DROP      tcp  --  anywhere      anywhere      tcp  dpt:6004
DROP      tcp  --  anywhere      anywhere      tcp  dpt:6005
DROP      tcp  --  anywhere      anywhere      tcp  dpt:6006
DROP      tcp  --  anywhere      anywhere      tcp  dpt:6007
DROP      tcp  --  anywhere      anywhere      tcp  dpt:6008
DROP      tcp  --  anywhere      anywhere      tcp  dpt:6009
DROP      tcp  --  anywhere      anywhere      tcp  dpt:xfs
ACCEPT    tcp  --  anywhere      anywhere      tcp  dpt:https
ACCEPT    tcp  --  anywhere      anywhere      tcp  dpt:http
ACCEPT    tcp  --  anywhere      anywhere      tcp  dpt:1500
DROP      tcp  --  anywhere      anywhere      tcp  dpt:1500
ACCEPT    udp  --  anywhere      anywhere      udp  dpt:1500
DROP      udp  --  anywhere      anywhere      udp  dpt:1500
ACCEPT    tcp  --  anywhere      anywhere      tcp  dpt:1501
DROP      tcp  --  anywhere      anywhere      tcp  dpt:1501
ACCEPT    udp  --  anywhere      anywhere      udp  dpt:1501
DROP      udp  --  anywhere      anywhere      udp  dpt:1501
ACCEPT    tcp  --  anywhere      anywhere      tcp  dpt:1502
DROP      tcp  --  anywhere      anywhere      tcp  dpt:1502

```

```
Chain FORWARD (policy ACCEPT)
target      prot opt source                destination

Chain OUTPUT (policy ACCEPT)
target      prot opt source                destination
```

A-34

show hardware

show hardware

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| Command History | <table border="1"> <thead> <tr> <th>Release</th> <th>Modifications</th> </tr> </thead> <tbody> <tr> <td>1.1</td> <td>This command was first documented.</td> </tr> </tbody> </table> | Release | Modifications | 1.1 | This command was first documented. |
|------------------------|--|---------|---------------|-----|------------------------------------|
| Release | Modifications | | | | |
| 1.1 | This command was first documented. | | | | |

| | |
|-------------------------|--|
| Usage Guidelines | Use this command to retrieve basic hardware information. |
|-------------------------|--|

| | |
|-----------------|--|
| Examples | <pre>admin:show hardware HW Platform : 7845I2 Processors : 2 Type : Intel(R) Xeon(R) CPU 5140 @ 2.33GHz CPU Speed : 2333 Memory : 4096 MBytes Object ID : 1.3.6.1.4.1.9.1.587 OS Version : UCOS 2.0.1.0-41 RAID Details : Controllers found: 1 ----- Logical drive information ----- Logical drive number 1 Logical drive name : Drive 1 RAID level : 1 Status of logical drive : Okay Size : 69890 MB Read-cache mode : Enabled Write-cache mode : Enabled (write-back) Write-cache setting : Enabled (write-back) Number of chunks : 2 Drive(s) (Channel,Device) : 0,0 0,1 Press <enter> for 1 line, <space> for one page, or <q> to quit</pre> |
|-----------------|--|

| Related Commands | <table border="1"> <thead> <tr> <th>Command</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>None</td> <td></td> </tr> </tbody> </table> | Command | Description | None | |
|-------------------------|---|---------|-------------|------|--|
| Command | Description | | | | |
| None | | | | | |

show holdresume

show holdresume

| | |
|--------------------|------|
| Syntax Description | None |
|--------------------|------|

| | |
|---------------|-------|
| Command Modes | Admin |
|---------------|-------|

| Command History | Release | Modifications |
|-----------------|---------|-----------------------------------|
| | 1.1 | The command was first documented. |

| | |
|------------------|---|
| Usage Guidelines | Use this command to retrieve current server side hold/resume settings for static and scheduled conferences. |
|------------------|---|

| | |
|----------|---|
| Examples | <pre>admin:show holdresume server side hold_resume is enabled</pre> |
|----------|---|

| Related Commands | Command | Description |
|------------------|----------------|--|
| | set holdresume | Enables or disables server side hold/resume feature for static and scheduled conferences |

show lateendmins

show lateendmins

Syntax Description

None

Command Modes

Admin

Command History

| Release | Modifications |
|---------|-----------------------------------|
| 1.1 | The command was first documented. |

Usage Guidelines

Use this command to show the defined number of minutes after which a conference will be terminated when the meeting exceeds the scheduled end time.

Examples

admin:show lateendmins

Related Commands

| Command | Description |
|-----------------|---|
| set lateendmins | Defines the number of minutes after which a conference will be terminated when the meeting exceeds the scheduled end time |

show logins

show logins [*number*]

| Syntax Description | <i>number</i> | The optional parameter can be used to specify the number of displayed logins. A value of 0 will display all previously saved logins. The default is 20. |
|--------------------|---------------|---|
|--------------------|---------------|---|

| Command Modes | Admin |
|---------------|-------|
|---------------|-------|

| Command History | Release | Modifications |
|-----------------|---------|-----------------------------------|
| | 1.1 | The command was first documented. |

| Usage Guidelines | Use this command to display platform administrator logins. |
|------------------|--|
|------------------|--|

| Examples | <pre>admin:show logins</pre> <pre> admin pts/0 dhcp-171-71-227- Wed Aug 6 22:09 still logged in admin pts/1 dhcp-171-70-12-1 Wed Aug 6 21:52 - 21:55 (00:02) admin pts/0 dilkrish-lnx2.ci Wed Aug 6 21:50 - 22:09 (00:19) dhroot pts/24 tsbu-lnx-3.cisco Wed Aug 6 19:09 - 19:48 (00:39) admin pts/24 tsbu-lnx-3.cisco Wed Aug 6 19:09 - 19:09 (00:00) dhroot pts/21 tsbu-lnx-3.cisco Wed Aug 6 18:54 - 19:10 (00:16) dhroot pts/20 tsbu-lnx-3.cisco Wed Aug 6 18:54 - 19:10 (00:16) dhroot pts/17 tsbu-lnx-3.cisco Wed Aug 6 18:54 - 19:10 (00:16) dhroot pts/16 tsbu-lnx-3.cisco Wed Aug 6 18:54 - 19:10 (00:16) admin pts/19 tsbu-lnx-3.cisco Wed Aug 6 18:54 - 18:54 (00:00) admin pts/18 tsbu-lnx-3.cisco Wed Aug 6 18:54 - 18:54 (00:00) admin pts/17 tsbu-lnx-3.cisco Wed Aug 6 18:54 - 18:54 (00:00) admin pts/16 tsbu-lnx-3.cisco Wed Aug 6 18:54 - 18:54 (00:00) dhroot pts/14 tsbu-lnx-3.cisco Wed Aug 6 18:53 - 19:47 (00:54) dhroot pts/11 tsbu-lnx-3.cisco Wed Aug 6 18:53 - 19:47 (00:54) dhroot pts/10 tsbu-lnx-3.cisco Wed Aug 6 18:53 - 19:47 (00:54) dhroot pts/7 tsbu-lnx-3.cisco Wed Aug 6 18:53 - 19:47 (00:54) dhroot pts/6 tsbu-lnx-3.cisco Wed Aug 6 18:53 - 19:47 (00:54) admin pts/10 tsbu-lnx-3.cisco Wed Aug 6 18:53 - 18:53 (00:00) admin pts/9 tsbu-lnx-3.cisco Wed Aug 6 18:53 - 18:53 (00:00) </pre> |
|----------|--|
|----------|--|

| Related Commands | Command | Description |
|------------------|---------|-------------|
| | None | |

show myself

show myself

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| Command History | Release | Modifications |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| | |
|-------------------------|---|
| Usage Guidelines | Use this command to show information about the current account. |
|-------------------------|---|

| | |
|-----------------|---|
| Examples | <pre>admin:show myself Machine Name : tsbu-sr2 account name : admin privilege level : 4 output setting : disabled logging setting : disabled</pre> |
|-----------------|---|

| Related Commands | Command | Description |
|------------------|---------|-------------|
| | None | |

show network all

show network all

Syntax Description None

Command Modes Admin

| Command History | Release | Modifications |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

Usage Guidelines Use this command to display all **show network** command information.

Examples

```
admin:show network all
Ethernet 0
DHCP      : disabled          Status      : up
IP Address : 172.28.68.76     IP Mask    : 255.255.252.0
Link Detected: yes          Mode        : Auto enabled, Full, 1000MB/s
Duplicate IP : no

DNS
Primary    : 171.70.168.183   Secondary   : 171.68.226.120
Options     : timeout:5 attempts:2
Domain      : cisco.com
Gateway     : 172.28.68.1 on Ethernet 0
172.28.68.0/22 dev eth0 proto kernel scope link src 172.28.68.76
169.254.0.0/16 dev eth0 scope link
default via 172.28.68.1 dev eth0

Active Internet connections (w/o servers)
Proto Recv-Q Send-Q Local Address           Foreign Address          State
tcp      0      0 localhost:12101          localhost:42806          ESTABLISHED
tcp      0      0 localhost:9500           localhost:35897          TIME_WAIT
tcp      0      0 localhost:9500           localhost:35896          TIME_WAIT
tcp      0      0 tsbu-dhsr-76.cisco.co:35612 tsbu-ccm-b19.cisco.com:5060 ESTABLISHED
tcp      0      0 localhost:12101          localhost:42752          ESTABLISHED
tcp      0      0 localhost:9000           localhost:32795          ESTABLISHED
tcp      0      0 tsbu-dhsr-76.cisco.com:5060 tsbu-ccm-b19.cisco.co:33559 ESTABLISHED
tcp      0      0 localhost:32795          localhost:9000           ESTABLISHED
tcp      0      0 localhost:12101          localhost:44268          ESTABLISHED
tcp      0      0 localhost:12101          localhost:40958          ESTABLISHED
tcp      0      0 localhost:12101          localhost:44278          ESTABLISHED
tcp      0      0 tsbu-dhsr-76.cisco.com:ssh dhcp-171-71-227-202.ci:2316 ESTABLISHED
tcp      0      0 tsbu-dhsr-76.cisco.com:8443 dhcp-171-70-12-166.cis:4069 ESTABLISHED
tcp      0      0 tsbu-dhsr-76.cisco.com:8443 dhcp-171-70-12-166.cis:4068 ESTABLISHED

Active UNIX domain sockets (w/o servers)
Proto RefCnt Flags       Type       State      I-Node Path
unix   14      [ ]        DGRAM          5112 /dev/log
unix    2      [ ]        DGRAM          8829728
unix    3      [ ]        STREAM        CONNECTED    8803057
```

```

unix 3      [ ]      STREAM    CONNECTED  8803056
unix 2      [ ]      DGRAM          28107
unix 2      [ ]      DGRAM          28101
unix 2      [ ]      DGRAM          28084
unix 2      [ ]      DGRAM          14227
unix 2      [ ]      DGRAM          11947
unix 2      [ ]      DGRAM          10619
unix 2      [ ]      DGRAM          10548
unix 2      [ ]      DGRAM          10443
unix 2      [ ]      STREAM    CONNECTED  9469
unix 2      [ ]      DGRAM          5334
unix 2      [ ]      DGRAM          5302
unix 2      [ ]      DGRAM          5275
unix 2      [ ]      DGRAM          5121

```

Related Commands

| Command | Description |
|-------------------------------------|--|
| show network eth0 | Displays basic Ethernet 0 platform network information |
| show network failover | Displays NIC Teaming network fault tolerance information |
| show network ip_conntack | Retrieves the current utilization of ip_conntack |
| show network max_ip_conntack | Retrieves the current ip_conntack_max information |
| show network route | Displays basic network route information |
| show network status | Displays basic network status information |

show network eth0

show network eth0

Syntax Description None

Command Modes Admin

| Command History | Release | Modification |
|-----------------|---------|-----------------------------------|
| | 1.1 | The command was first documented. |

Usage Guidelines Use this command to display basic Ethernet 0 platform network information.

Examples

```
admin:show network eth0
Ethernet 0
DHCP      : disabled           Status      : up
IP Address : 172.28.68.76      IP Mask    : 255.255.252.0
Link Detected: yes           Mode       : Auto enabled, Full, 1000MB/s
Duplicate IP : no

DNS
Primary    : 171.70.168.183    Secondary   : 171.68.226.120
Options    : timeout:5 attempts:2
Domain     : cisco.com
Gateway    : 172.28.68.1 on Ethernet 0
```

| Related Commands | Command | Description |
|------------------|-------------------------------|--|
| | show network all | Displays all show network command information |
| | show network failover | Displays NIC Teaming network fault tolerance information |
| | show network ip_conntrack | Retrieves the current utilization of ip_conntrack |
| | show network max_ip_conntrack | Retrieves the current ip_conntrack_max information |
| | show network route | Displays basic network route information |
| | show network status | Displays basic network status information |

show network failover

show network failover

| | |
|--------------------|------|
| Syntax Description | None |
|--------------------|------|

| | |
|---------------|-------|
| Command Modes | Admin |
|---------------|-------|

| Command History | Release | Modification |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| | |
|------------------|--|
| Usage Guidelines | Use this command to display NIC Teaming network fault tolerance information. |
|------------------|--|

| | |
|----------|---|
| Examples | <pre>admin:show network failover Network Fault Tolerance is not configured.</pre> |
|----------|---|

| Related Commands | Command | Description |
|------------------|-------------------------------|--|
| | show network all | Displays all show network command information |
| | show network eth0 | Displays basic Ethernet 0 platform network information |
| | show network ip_conntrack | Retrieves the current utilization of ip_conntrack |
| | show network max_ip_conntrack | Retrieves the current ip_conntrack_max information |
| | show network route | Displays basic network route information |
| | show network status | Displays basic network status information |

show network ip_conntrack

show config all [page]

Syntax Description None

Command Modes Admin

| Command History | Release | Modifications |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

Usage Guidelines Use this command to retrieve the current utilization of ip_conntrack.

Examples

```
admin:show network ip_conntrack
```

56

| Related Commands | Command | Description |
|------------------|-------------------------------|--|
| | show network all | Displays all show network command information |
| | show network eth0 | Displays basic Ethernet 0 platform network information |
| | show network failover | Displays NIC Teaming network fault tolerance information |
| | show network max_ip_conntrack | Retrieves the current ip_conntrack_max information |
| | show network route | Displays basic network route information |
| | show network status | Displays basic network status information |

show network max_ip_conntrack

show network max_ip_conntrack

| | |
|--------------------|------|
| Syntax Description | None |
|--------------------|------|

| | |
|---------------|-------|
| Command Modes | Admin |
|---------------|-------|

| Command History | Release | Modifications |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| | |
|------------------|--|
| Usage Guidelines | Use this command to retrieve the current ip_conntrack_max information. |
|------------------|--|

| | |
|----------|-------------------------------------|
| Examples | admin:show network max_ip_conntrack |
| | 256000 |

| Related Commands | Command | Description |
|------------------|---------------------------|--|
| | show network all | Displays all show network command information |
| | show network eth0 | Displays basic Ethernet 0 platform network information |
| | show network failover | Displays NIC Teaming network fault tolerance information |
| | show network ip_conntrack | Retrieves the current utilization of ip_conntrack |
| | show network route | Displays basic network route information |
| | show network status | Displays basic network status information |

show network route

show network route

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| Command History | Release | Modifications |
|------------------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| | |
|-------------------------|--|
| Usage Guidelines | Use this command to display basic network route information. |
|-------------------------|--|

| | |
|-----------------|---|
| Examples | admin:show network route 10.94.150.0/24 dev eth0 proto kernel scope link src 10.94.150.94 169.254.0.0/16 dev eth0 scope link default via 10.94.150.1 dev eth0 |
|-----------------|---|

Example with failover (NFT) enabled:

```
admin:show network route
10.94.150.0/24 dev bond0 proto kernel scope link src 10.94.150.98
10.94.150.0/24 dev eth0 proto kernel scope link src 10.94.150.98
10.94.150.0/24 dev eth1 proto kernel scope link src 10.94.150.98
169.254.0.0/16 dev bond0 scope link
default via 10.94.150.1 dev bond0
```

| Related Commands | Command | Description |
|-------------------------|--------------------------------------|--|
| | show network all | Displays all show network command information |
| | show network eth0 | Displays basic Ethernet 0 platform network information |
| | show network failover | Displays NIC Teaming network fault tolerance information |
| | show network ip_conntrack | Retrieves the current utilization of ip_conntrack |
| | show network max_ip_conntrack | Retrieves the current ip_conntrack_max information |
| | show network status | Displays basic network status information |

show network status

show network status [*search name*]

| Syntax Description | search <i>name</i> | Optional search feature |
|--------------------|--------------------|---|
| | <i>name</i> | Text string indicating network. String cannot contain spaces or tabs and is case insensitive. |

| Command Modes | Admin |
|---------------|-------|
|---------------|-------|

| Command History | Release | Modifications |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| Usage Guidelines | Use this command to retrieve basic network route information. |
|------------------|---|
|------------------|---|

Examples

```
admin:show network status
```

Active Internet connections (w/o servers)

| Proto | Recv-Q | Send-Q | Local Address | Foreign Address | State |
|-------|--------|--------|--------------------------|-----------------------------|-------------|
| tcp | 0 | 0 | vv1-rush.cisco.com:40266 | vv1-rush.cisco:vv1_rush_ccm | ESTABLISHED |
| tcp | 0 | 0 | localhost:32824 | localhost:8001 | ESTABLISHED |

Example with optional **search name**:

```
admin:show network status search cisco.com
```

| | | | | | |
|-----|---|---|--------------------------|-----------------------------|-------------|
| tcp | 0 | 0 | vv1-rush.cisco.com:38775 | vv1-rush.cisco:vv1_rush_ccm | ESTABLISHED |
| tcp | 0 | 0 | vv1-rush.cisco.com:ssh | philly.cisco.com:48528 | ESTABLISHED |
| tcp | 0 | 0 | vv1-rush.cisco.com:46993 | vv1-rush.cisco.com:32812 | TIME_WAIT |

| Related Commands | Command | Description |
|------------------|--------------------------------------|--|
| | show network all | Displays all show network command information |
| | show network eth0 | Displays basic Ethernet 0 platform network information |
| | show network failover | Displays NIC Teaming network fault tolerance information |
| | show network ip_conntrack | Retrieves the current utilization of ip_conntrack |
| | show network max_ip_conntrack | Retrieves the current ip_conntrack_max information |
| | show network route | Displays basic network route information |

show packages

show packages {*active name* | **active ***} | {*inactive name* | **inactive ***}

| | | |
|---------------------------|-----------------------------|--|
| Syntax Description | active <i>name</i> | Retrieves the version number for a specific package on the active partition. |
| | active * | Retrieves the version numbers for all package on the active partition. |
| | inactive <i>name</i> | Retrieves the version number for a specific package on the inactive partition. |
| | inactive * | Retrieves the version number for all packages on the inactive partition. |

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| | | |
|------------------------|----------------|------------------------------------|
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |

| | |
|-------------------------|---|
| Usage Guidelines | Use this command to retrieve the version number for one or more packages on the active or inactive partition. |
|-------------------------|---|

| | |
|-----------------|---|
| Examples | <pre>admin:show packages active kernel Active Side Package(s): for kernel package(s) tg3-kernel-update-2.4.21-47.ELsmp kernel-smp-2.4.21-47.EL kernel-pcmcia-cs-3.1.31-19 kernel-2.4.21-47.EL kernel-utils-2.4-8.37.15 kernel-2.4.2149.ELcustom-1</pre> |
|-----------------|---|

| | | |
|-------------------------|----------------|--------------------|
| Related Commands | Command | Description |
| | None | |

show rtpsleep

show rtpsleep

| | |
|--------------------|------|
| Syntax Description | None |
|--------------------|------|

| | |
|---------------|-------|
| Command Modes | Admin |
|---------------|-------|

| Command History | Release | Modifications |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| | |
|------------------|--|
| Usage Guidelines | Use this command to get current RTP thread sleep time. |
|------------------|--|

| | |
|----------|--|
| Examples | <pre>admin:show rtpsleep Current RTP thread sleep time is 1 ms</pre> |
|----------|--|

| Related Commands | Command | Description |
|------------------|---------|-------------|
| | None | |

show statistics

show statistics {all | conference *confid*}

| | | |
|---------------------------|---------------------------------|---|
| Syntax Description | all | Shows statistics for all conferences. |
| | conference <i>confid</i> | Shows statistics for a specific conference, identified by conference identification number. |

Command Modes Admin

| | | |
|------------------------|----------------|------------------------------------|
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |

Usage Guidelines Use this command to display statistics for all conferences or a specific conference.

Examples

```
admin:show statistics all
[Media Statistics:2008/8/6 22:42:13.073588 UTC]

EndPoint[0]:ipaddr:172.20.233.55 confid:17 callid:217 epid:50 muxVersion:3 audio
port:16384 video port:16386 audio latency(ms):0 video latency(ms):0
epid type rxssrc txssrc state pmaxj cmaxj pjs cjs rxtl rxls txtl txls
dupl ooo srsw pmxsg cmxsg pmxpg cmxpg cmj
50 A a784011 16ca4111 1:1:1 7 7 0 0 147602 0:0 147592 0:0
0 0 1:1 0 0 26 26 0.85
50 A 0 5ae26112 0:0:1 6 8 0 0 0 0:0 147268 0:0
0 0 1:1 0 0 25 27 0.75
50 A 0 0 0:0:0 0 0 0 0 0 0:0 0 0:0
0 0 0:0 0 0 0 0 0.00
50 A 0 0 0:0:0 0 0 0 0 0 0:0 0 0:0
0 0 0:0 0 0 0 0 0.00
50 A 0 0 0:0:0 0 0 0 0 0 0:0 0 0:0
0 0 0:0 0 0 0 0 0.00
epid type rxssrc txssrc state pmaxj cmaxj pmaxd cmaxd pjs cjs pds cds rxtl
rxls txtl txls iIDR oIDR nak fbIs dupl ooo srsw pmxsg cmxsg pmxpg
cmxpg cmj
50 V a784011 16ca4011 1:0:1 2 3 32 34 0 0 0 0 0 2027
0:0 1352920 0:0 2 5 0 0 0 0 2:1 0 5 22
33 0.57
50 V 0 0 0:0:0 0 0 0 0 0 0 0 0 0
0:0 0 0:0 0 0 0 0 0 0:0 0 0 0
0 0.00

EndPoint[1]:ipaddr:172.20.233.69 confid:17 callid:218 epid:1 muxVersion:3 audio port:16384
video port:16386 audio latency(ms):0 video latency(ms):0
epid type rxssrc txssrc state pmaxj cmaxj pjs cjs rxtl rxls txtl txls
dupl ooo srsw pmxsg cmxsg pmxpg cmxpg cmj
1 A 16ca4011 5ae26111 1:1:1 6 8 0 0 147602 0:0 147268 0:0
0 0 1:1 0 0 25 27 0.75
```

```

1   A   0       a784112 0:0:1 4   7   0   0   0       0:0   147266 0:0
0   0   1:1   0       0       21  24   2.22
1   A   0       0       0:0:0 0   0   0   0   0       0:0   0       0:0
0   0   0:0   0       0       0   0   0.00
1   A   0       0       0:0:0 0   0   0   0   0       0:0   0       0:0
0   0   0:0   0       0       0   0   0.00
1   A   0       0       0:0:0 0   0   0   0   0       0:0   0       0:0
0   0   0:0   0       0       0   0   0.00
epid type rxssrc   txssrc   state pmaxj cmaxj pmaxd cmaxd pjs   cjs   pds   cds   rxrtl
rxls      txtl      txls      iIDR oIDR nak   fbIs dupl ooo   srsW   pmxsg cmxsg pmxpg
cmxpg cmj
1   V   16ca4011 5ae26011 1:1:1 2   5   33   34   0   0   0   0   1350788
0:0      1347710 0:0      2   4   0   0   0   0   3:3 0   16   16
33      0.55
1   V   0       0       0:0:0 0   0   0   0   0   0   0   0   0
0:0      0       0:0      0   0   0   0   0   0   0:0 0   0   0
0       0.00

```

EndPoint[2]:ipaddr:172.20.233.82 confid:17 callid:219 epid:2 muxVersion:3 audio port:16384
video port:16386 audio latency(ms):0 video latency(ms):0

```

epid type rxssrc   txssrc   state pmaxj cmaxj pjs   cjs   rxrtl   rxls      txtl      txls
dupl ooo   srsW   pmxsg cmxsg pmxpg cmxpg cmj
2   A   5ae26011 16ca4111 1:1:1 7   7   0   0   147604 0:0   147567 0:0
0   0   1:1   0       0       26  26   0.85
2   A   0       a784112 0:0:1 4   7   0   0   0       0:0   147266 0:0
0   0   1:1   0       0       21  24   2.22
2   A   0       0       0:0:0 0   0   0   0   0       0:0   0       0:0
0   0   0:0   0       0       0   0   0.00
2   A   0       0       0:0:0 0   0   0   0   0       0:0   0       0:0
0   0   0:0   0       0       0   0   0.00
2   A   0       0       0:0:0 0   0   0   0   0       0:0   0       0:0
0   0   0:0   0       0       0   0   0.00
epid type rxssrc   txssrc   state pmaxj cmaxj pmaxd cmaxd pjs   cjs   pds   cds   rxrtl
rxls      txtl      txls      iIDR oIDR nak   fbIs dupl ooo   srsW   pmxsg cmxsg pmxpg
cmxpg cmj
2   V   5ae26011 16ca4011 1:1:1 3   4   32   34   0   0   0   0   1347866
0:0      1352810 0:0      4   4   1   0   0   0   2:1 0   1   22
33      1.38
2   V   0       0       0:0:0 0   0   0   0   0   0   0   0   0
0:0      0       0:0      0   0   0   0   0   0   0:0 0   0   0
0       0.00

```

admin:show statistics conference 9059578056

[Media Statistics:2008/8/6 22:43:18.905158 UTC]

EndPoint[0]:ipaddr:172.20.233.55 confid:17 callid:217 epid:50 muxVersion:3 audio
port:16384 video port:16386 audio latency(ms):0 video latency(ms):0

```

epid type rxssrc   txssrc   state pmaxj cmaxj pjs   cjs   rxrtl   rxls      txtl      txls
dupl ooo   srsW   pmxsg cmxsg pmxpg cmxpg cmj
50  A   a784011 16ca4111 1:1:1 6   7   0   0   150894 0:0   150883 0:0
0   0   1:1   0       0       25  26   0.85
50  A   0       5ae26112 0:0:1 5   8   0   0   0       0:0   150559 0:0
0   0   1:1   0       0       25  27   0.77
50  A   0       0       0:0:0 0   0   0   0   0       0:0   0       0:0
0   0   0:0   0       0       0   0   0.00
50  A   0       0       0:0:0 0   0   0   0   0       0:0   0       0:0
0   0   0:0   0       0       0   0   0.00
50  A   0       0       0:0:0 0   0   0   0   0       0:0   0       0:0
0   0   0:0   0       0       0   0   0.00
epid type rxssrc   txssrc   state pmaxj cmaxj pmaxd cmaxd pjs   cjs   pds   cds   rxrtl
rxls      txtl      txls      iIDR oIDR nak   fbIs dupl ooo   srsW   pmxsg cmxsg pmxpg
cmxpg cmj

```

show statistics

```

50 V a784011 16ca4011 1:0:1 2 3 32 34 0 0 0 0 2027
0:0 1383047 0:0 2 5 0 0 0 0 2:1 0 5 23
33 0.57
50 V 0 0 0:0:0 0 0 0 0 0 0 0 0 0
0:0 0 0:0 0 0 0 0 0 0 0:0 0 0 0
0 0.00

```

EndPoint[1]:ipaddr:172.20.233.69 confid:17 callid:218 epid:1 muxVersion:3 audio port:16384
video port:16386 audio latency(ms):0 video latency(ms):0

```

epid type rxssrc txssrc state pmaxj cmaxj pjs cjs rxrtl rxls txtl txls
dupl ooo srsr pmxsg cmxsg pmxpg cmxpg cmj
1 A 16ca4011 5ae26111 1:1:1 5 8 0 0 150893 0:0 150559 0:0
0 0 1:1 0 0 25 27 0.77
1 A 0 a784112 0:0:1 4 7 0 0 0 0:0 150558 0:0
0 0 1:1 0 0 21 24 2.22
1 A 0 0 0:0:0 0 0 0 0 0 0:0 0 0:0
0 0 0:0 0 0 0 0 0.00
1 A 0 0 0:0:0 0 0 0 0 0 0:0 0 0:0
0 0 0:0 0 0 0 0 0.00
1 A 0 0 0:0:0 0 0 0 0 0 0:0 0 0:0
0 0 0:0 0 0 0 0 0.00
epid type rxssrc txssrc state pmaxj cmaxj pmaxd cmaxd pjs cjs pds cds rxrtl
rxls txtl txls iIDR oIDR nak fbIs dupl ooo srsr pmxsg cmxsg pmxpg
cmxpg cmj
1 V 16ca4011 5ae26011 1:1:1 2 5 33 34 0 0 0 0 1380914
0:0 1377800 0:0 2 4 0 0 0 0 3:3 0 16 12
33 0.55
1 V 0 0 0:0:0 0 0 0 0 0 0 0 0 0
0:0 0 0:0 0 0 0 0 0 0:0 0 0 0
0 0.00

```

EndPoint[2]:ipaddr:172.20.233.82 confid:17 callid:219 epid:2 muxVersion:3 audio port:16384
video port:16386 audio latency(ms):0 video latency(ms):0

```

epid type rxssrc txssrc state pmaxj cmaxj pjs cjs rxrtl rxls txtl txls
dupl ooo srsr pmxsg cmxsg pmxpg cmxpg cmj
2 A 5ae26011 16ca4111 1:1:1 6 7 0 0 150895 0:0 150858 0:0
0 0 1:1 0 0 25 26 0.85
2 A 0 a784112 0:0:1 4 7 0 0 0 0:0 150558 0:0
0 0 1:1 0 0 21 24 2.22
2 A 0 0 0:0:0 0 0 0 0 0 0:0 0 0:0
0 0 0:0 0 0 0 0 0.00
2 A 0 0 0:0:0 0 0 0 0 0 0:0 0 0:0
0 0 0:0 0 0 0 0 0.00
2 A 0 0 0:0:0 0 0 0 0 0 0:0 0 0:0
0 0 0:0 0 0 0 0 0.00
epid type rxssrc txssrc state pmaxj cmaxj pmaxd cmaxd pjs cjs pds cds rxrtl
rxls txtl txls iIDR oIDR nak fbIs dupl ooo srsr pmxsg cmxsg pmxpg
cmxpg cmj
2 V 5ae26011 16ca4011 1:1:1 3 4 32 34 0 0 0 0 1377955
0:0 1382937 0:0 4 4 1 0 0 0 2:1 0 1 23
33 1.38
2 V 0 0 0:0:0 0 0 0 0 0 0 0 0 0
0:0 0 0:0 0 0 0 0 0 0:0 0 0 0
0 0.00

```

Related Commands

| Command | Description |
|---------|-------------|
| None | |

show status

show status

Syntax Description None

Command Modes Admin

| Command History | Release | Modifications |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

Usage Guidelines Use this command to retrieve basic platform status information.

Examples

```
admin:show status
Host Name      : testsys
Date           : Tue Dec 13, 2005 12:46:57
Time Zone      : UTC
Locale         : en_US.UTF-8
Product Ver    : 1.0.0.0-6
Platform Ver   : 2.0.0.0-1

Resources
CPU           Idle: 100.00%   System: 00.00%   User: 00.00%

Memory        Total          Free          Used
Disk/active   3020140K        1580608K        1286116K (45%)
Disk/inactive 3020172K        2833924K        32828K (2%)

admin:show status

Host Name      : tsbu-dhsr-76
Date           : Wed Aug 6, 2008 22:44:36
Time Zone      : UTC
Locale         : en_US.UTF-8
Product Ver    : 1.1.1.0-30
Platform Ver   : 2.0.0.1-1

Uptime:
22:44:37 up 5:02, 1 user, load average: 0.00, 0.00, 0.00

CPU Idle: 97.44% System: 00.51% User: 01.28%
IOWAIT: 00.00% IRQ: 00.00% Soft: 00.77% Intr/sec: 2998.98

Memory Total: 4087680K
Free: 3190292K
Used: 897388K
Cached: 262320K
Shared: 0K
```

■ show status

```

        Buffers:          68972K

                        Total      Free      Used
Disk/active             4032124K   2117232K   1710064K (45%)
Disk/inactive           4032092K   1857492K   1969776K (52%)
Disk/logging            70438620K   63214064K   3646484K (6%)

```

Related Commands

| Command | Description |
|---------|-------------|
| None | |

show threshold

show threshold

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| | | |
|------------------------|----------------|------------------------------------|
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |

| | |
|-------------------------|---|
| Usage Guidelines | Use this command to get current maximum burst packet threshold. |
|-------------------------|---|

| | |
|-----------------|--|
| Examples | admin: show threshold Current max burst packet threshold is 20 |
|-----------------|--|

| | | |
|-------------------------|----------------|--------------------|
| Related Commands | Command | Description |
| | None | |

show timezone

show timezone {config | list}

Syntax Description

| | |
|---------------|--|
| config | Displays the current timezone setting. |
| list | Lists all available timezones. |

Command Modes

Admin

Command History

| Release | Modifications |
|---------|------------------------------------|
| 1.1 | This command was first documented. |

Usage Guidelines

Use this command to display the current timezone settings or to display a list of all available timezones in long format.



Note

The first value is the timezone index, which may be used to set a new timezone using the set timezone command. You can also use the timezone name.

Examples

admin:**show timezone list**

```
0 - (GMT-12:00) Eniwetok, Kwajalein
1 - (GMT-11:00) Midway Island, Samoa
2 - (GMT-10:00) Hawaii
```

```
Current timezone: (GMT+10:00) Canberra, Melbourne, Sydney
Current timezone: (GMT+10:00) Canberra, Melbourne, Sydney
```

The numbers in first column 0, 1, 2 represent index that can be used in set timezone command

```
0 - (GMT-12:00) Eniwetok, Kwajalein
1 - (GMT-11:00) Midway Island, Samoa
2 - (GMT-10:00) Hawaii
3 - (GMT-09:00) Alaska
4 - (GMT-08:00) Pacific Time (US & Canada)
5 - (GMT-07:00) Arizona
6 - (GMT-07:00) Mountain Time (US & Canada)
7 - (GMT-06:00) Central Time (US & Canada)
8 - (GMT-06:00) Central America
9 - (GMT-06:00) Saskatchewan
10 - (GMT-06:00) Mexico City
11 - (GMT-05:00) Bogota, Lima, Quito
12 - (GMT-05:00) Indiana (East)
13 - (GMT-05:00) Eastern Time (US & Canada)
14 - (GMT-04:00) Atlantic Time (Canada)
15 - (GMT-04:00) Caracas, La Paz
16 - (GMT-04:00) Santiago
```

```
17 - (GMT-03:30) Newfoundland
18 - (GMT-03:00) Brasilia
19 - (GMT-03:00) Greenland
20 - (GMT-03:00) Buenos Aires, Georgetown
21 - (GMT-02:00) Mid-Atlantic
22 - (GMT-01:00) Azores
Press <enter> for 1 line, <space> for one page, or <q> to quit
```

Related Commands

| Command | Description |
|--------------|------------------------|
| set timezone | Defines a new timezone |

show version

show version {active | inactive}

Syntax Description

| | |
|-----------------|--|
| active | Displays the version number of the software on the active partition. |
| inactive | Displays the version number of the software on the inactive partition. |

Command Modes

Admin

Command History

| Release | Modifications |
|---------|------------------------------------|
| 1.1 | This command was first documented. |

Usage Guidelines

Use this command to display information about the version number of the software on the inactive or active partition.

Examples

```
admin:show version active
Active Master Version: 1.1.1.0-30

Active Version Installed Software Options:
No Installed Software Options Found.
```

Related Commands

| Command | Description |
|---------|-------------|
| None | |

show workingdir

show workingdir

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| | | |
|------------------------|----------------|------------------------------------|
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |

| | |
|-------------------------|--|
| Usage Guidelines | Use this command to display the current working directories for activelog, inactivelog, and the tftp system directories. |
|-------------------------|--|

| | |
|-----------------|--|
| Examples | <pre>admin:show workingdir activelog : <not set, using default path> inactivelog : <not set, using default path> tftp : <not set, using default path></pre> |
|-----------------|--|

| | | |
|-------------------------|----------------|--------------------|
| Related Commands | Command | Description |
| | None | |

utils remote_account

utils remote_account {enable | disable}

Syntax Description

| | |
|----------------|--|
| enable | Enables an already-created remote account so that Cisco Technical Support can access the system. |
| disable | Removes remote account. |

Command Modes

Admin

Command History

| Release | Modifications |
|---------|------------------------------------|
| 1.1 | This command was first documented. |

Usage Guidelines

Use this command to enable already-created remote accounts so that Cisco Technical Support can access the system, and to remove remote accounts.

Examples

```
admin:utils remote_account enable
```

Related Commands

| Command | Description |
|------------------------------------|---|
| utils remote_account create | Creates a remote account |
| utils remote_account status | Shows status of an already-created remote account |

utils remote_account create

utils remote_account create *name*

| Syntax Description | <i>name</i> | Identifier for remote account |
|--------------------|-------------|-------------------------------|
|--------------------|-------------|-------------------------------|

| Command Modes | Admin |
|---------------|-------|
|---------------|-------|

| Command History | Release | Modifications |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| Usage Guidelines | Use this command to create remote accounts so that Cisco Technical Support can access the system. |
|------------------|---|
|------------------|---|

| Examples | <pre>admin:utils remote_account create ciscotech 1 Account Successfully created Account : ciscotech Passphrase : 7RZT7ARZK5 Expiry : 12-14-2005:15:50:21 (MM-DD-YYYY:Hr:Min:Sec)</pre> |
|----------|---|
|----------|---|

| Related Commands | Command | Description |
|------------------|------------------------------------|--|
| | utils remote_account | Enables or removes already-created remote accounts |
| | utils remote_account status | Shows status of an already-created remote account |

utils remote_account status

utils remote_account status

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| | | |
|------------------------|----------------|------------------------------------|
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |

| | |
|-------------------------|---|
| Usage Guidelines | Use this command to retrieve status information for remote accounts used by Cisco Technical Support to access the system. |
|-------------------------|---|

| | |
|-----------------|--|
| Examples | <pre>admin:utils remote_account status Remote Support Status : enabled Decode Version : 1 Account : dhroot Passphrase : BDLHBP4JMY Expiry : 8-24-2008:20:00:00 (MM-DD-YYYY:Hr:Min:Sec)</pre> |
|-----------------|--|

| | | |
|-------------------------|-----------------------------|--|
| Related Commands | Command | Description |
| | utils remote_account | Enables or removes already-created remote accounts |
| | utils remote_account create | Creates a remote account |

utils system restart

utils system restart

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| Command History | Release | Modifications |
|-----------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| | |
|-------------------------|--------------------------------------|
| Usage Guidelines | Use this command to reboot the CTMS. |
|-------------------------|--------------------------------------|

| | |
|-----------------|--|
| Examples | <pre>admin:utils system restart Do you really want to restart ? Enter "yes" to restart or any other key to abort</pre> |
|-----------------|--|

| Related Commands | Command | Description |
|------------------|-----------------------------|--|
| | utils system shutdown | Powers off CTMS |
| | utils system switch-version | Switches to another software version installed on CTMS |

utils system shutdown

utils system shutdown

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| | | |
|------------------------|----------------|------------------------------------|
| Command History | Release | Modifications |
| | 1.1 | This command was first documented. |

| | |
|-------------------------|-------------------------------------|
| Usage Guidelines | Use this command to power off CTMS. |
|-------------------------|-------------------------------------|

| | |
|-----------------|---|
| Examples | <pre>admin:utils system shutdown Do you really want to shutdown ? Enter "yes" to shutdown or any other key to abort</pre> |
|-----------------|---|

| | | |
|-------------------------|-----------------------------|--|
| Related Commands | Command | Description |
| | utils system restart | Restarts CTMS |
| | utils system switch-version | Switches to another software version installed on CTMS |

utils system switch-version

utils system switch-version

| | |
|---------------------------|------|
| Syntax Description | None |
|---------------------------|------|

| | |
|----------------------|-------|
| Command Modes | Admin |
|----------------------|-------|

| Command History | Release | Modifications |
|------------------------|---------|------------------------------------|
| | 1.1 | This command was first documented. |

| | |
|-------------------------|---|
| Usage Guidelines | Use this command to switch to another software version installed on CTMS. |
|-------------------------|---|

Examples

```
admin:utils system switch-version
Do you really want to switch versions ?
Enter "yes" to switch-version or any other key to abort
```



Note

If any other response is entered, the procedure will be aborted.

| Related Commands | Command | Description |
|-------------------------|-----------------------|-----------------|
| | utils system restart | Restarts CTMS |
| | utils system shutdown | Powers off CTMS |

■ `utils system switch-version`