



EFT DRAFT - CISCO CONFIDENTIAL










Cisco Unified IP Phones 8961, 9951, and 9971 User Guide for Cisco Unified Communications Manager 7.1(3) (SIP)

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

Common Phone Tasks

Place a call	Go off-hook before or after dialing a number.
Redial a number	Press Redial softkey.
Switch to handset during a call	Pick up the handset.
Switch to speaker or headset during a call	Press  or  , then hang up the handset.
Mute and un-mute your phone	Press  .
View your call history	Press  > Call History .
Hold and resume a call	Press  to hold. Press the Resume softkey to resume the held call.
Transfer call to new number	Press  , enter the number, and then press it again.
Place an intercom call	Press the Intercom button and then enter a number if necessary. Speak after you hear the tone.
Start a standard conference call	Press  , dial the participant, and then press it again.
Silence the ring for an incoming call	Press the Volume button down once.



Cisco, Cisco Systems, the Cisco logo, and the Cisco Systems logo are registered trademarks or trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries. All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0705R)

© 2009 Cisco Systems, Inc. All rights reserved.

OL-19474-01



QUICK REFERENCE





Cisco Unified IP Phones 8961, 9951, and 9971 for Cisco Unified Communications Manager 7.1(3) (SIP)












Softkeys
Phone Screen Icons
Buttons
Common Phone Tasks

Softkeys

All Calls	List all calls.
Answer	Answer a call.
Apply	Confirm the edited and nonedited settings in that screen.
Call	Initiate a call.
CallBack	Receive notification when a busy extension becomes available.
Cancel	Cancel an action or exit a screen without applying changes.
Clear List	Remove all entries in a list or category.
Conference	Use when Conference feature is activated.
Delete	Delete an entry in a category, such as from Call History.
Details	In Call History or Accessories, select a call-history record or an accessory to view selection details.
Dial	Dial a selected number.
Divert	Send or redirect a call to voicemail or to a predetermined phone number.
Edit	Modify an item, such as a name.
EditDial	Edit a number before calling.
End Call	Disconnect the current call or the current intercom call.
Exit	Return to the previous screen.
Forward All/ Forward Off	Set up or cancel call forwarding.
Log Out	Sign out of Personal Directory.
Missed Calls	List all missed calls.
More	Display additional softkeys.








New Call	Make a new call.
Park	Store a call.
Phones	Displays the phone information for a personal contact.
Play	Play ringtone.
Redial	Redial the most recently dialed number.
Remove	Remove a conference participant or an entry.
Resume	Resume a call on hold.
Revert	Revert back to the last applied set of settings (for that screen).
Save	Save the chosen settings.
Search	Search for a directory listing.
Select	Select the highlighted option.
Set	Set an option, such as a ringtone.
Setup	Configure an accessory.
Show Details	Show details about the current call.
Speed Dial	Dial a number using a speed-dial code.
Swap	For a Transfer or Conference, toggle between two existing calls.
Transfer	Use when Transfer feature is activated.
Update	Update an entry in Personal Directory.
	Backspace to delete characters.
	Back.




Phone Screen Icons

	Off-hook
	On-hook
	Connected call
	Incoming call
	Missed call
	Placed call
	Received call
	Call forwarding enabled
	Call on hold
	Toggle on
	Message waiting
















Feature Icons

(If available on your phone)

	All Calls
	Common tasks such as Answer, CallBack, and Speed Dial.
	Bluetooth connected
	Do Not Disturb (DND) is in-use
	One-way intercom call (whisper)
	Two-way intercom call (connected)
	Line Status indicator-monitored line is in-use

	Line Status indicator-monitored line is ringing (Call Pickup only)
	Line Status indicator-monitored line is in do not disturb (DND)
	Mobility

Buttons

	Applications
	Contacts
	Messages
	Headset
	Speakerphone
	Mute
	Back
	Release
	Navigation pad and Select button
	Transfer
	Conference
	Hold
	Volume
	Feature button (left side of the screen)
	Session button (right side of the screen)

For the Cisco Unified IP Phones 8961, 9951, and 9971 Quick Start Guides, go to this URL:

TBD

Contents

Your Phone	1
Cisco Unified IP Phone 8961	1
Phone Connections	1
Footstand	4
Phone Display Viewing Angle	5
Buttons and Hardware	5
Phone Screen	9
Phone with Single Line	10
Phone with Multiple Lines	11
Phone with Answer Button	14
Phone Screen Navigation and Item Selection	15
Power-Save Mode	17
Handset Rest	18
Cisco Unified IP Phone 9951	19
Phone Connections	19
Footstand	22
Phone Display Viewing Angle	23
Buttons and Hardware	23
Phone Screen	27
Phone with Single Line	28
Phone with Multiple Lines	29
Phone with Answer Button	32
Phone Screen Navigation and Item Selection	33
Power-Save Mode	35
Handset Rest	36
Cisco Unified IP Phone 9971	37
Phone Connections	37
Wireless Connection	40
Footstand	40

- Phone Display Viewing Angle **41**
- Buttons and Hardware **41**
- Phone Screen **45**
 - Phone with Single Line **46**
 - Phone with Multiple Lines **47**
 - Phone with Answer Button **49**
 - Phone Screen Navigation and Item Selection **50**
- Power-Save Mode **52**
- Phone Display Cleaning **52**
- Handset Rest **52**

Applications 55

- Phone Applications **55**
 - Call History **55**
 - View Call History **56**
 - View Call Record Details **56**
 - Filter Call History **56**
 - Dial From Call History **56**
 - Edit Number From Call History **57**
 - Clear Call History **57**
 - Delete Call Record From Call History **57**
 - Preferences **57**
 - Ringtones **58**
 - Wallpaper **58**
 - Brightness **58**
 - Bluetooth **59**
 - Accessories **59**
 - View Accessories List **59**
 - View Accessory Details **60**
 - Set Up Wideband for Analog Headset **60**
 - Add Bluetooth Accessory **60**
 - Delete Bluetooth Accessory **61**
 - Connect Bluetooth Accessory **61**
 - Disconnect Bluetooth Accessory **62**
- Running Applications **62**
 - View Running Applications **62**

- Switch to a Running Application 62
- Close Running Application 62
- Phone Information 63
 - View Phone Information 63
- Administrator Settings 63

- Contacts 65**
 - Phone Contacts 65
 - Corporate Directory 65
 - Search for and Dial a Contact 65
 - Search for and Dial a Contact While on a Call 66
 - Personal Directory 66
 - Personal Directory Options 66
 - Fast-Dial Codes with Personal Directory 68

- Messages 71**
 - Voice Messages 71
 - Personalize Your Voicemail 71
 - Check for Voice Messages 71
 - Listen to Voice Messages 72

- Calling Features 73**
 - Feature Buttons and Softkeys 73
 - All Calls 74
 - View All Calls on Your Phone 74
 - Answer 75
 - Answer Your Oldest Call First 75
 - Auto Answer 75
 - Auto Answer with Your Headset 75
 - Auto Answer with Your Speakerphone 75
 - Barge 75
 - Add Yourself to a Call on a Shared Line 75
 - Call Back 76
 - Set Up a Call Back Notification 76
 - Call Forward All 76

- Forward Calls on Your Phone **77**
- Call Park **77**
 - Park and Retrieve a Call Using Park **78**
 - Park and Retrieve a Call Using Assisted Directed Call Park **78**
 - Park and Retrieve a Call Using Manual Directed Call Park **78**
- Call Pickup **79**
 - Answer a Call Using Pickup **80**
 - Answer a Call Using Group Pickup and a Group Pickup Number **80**
 - Answer a Call Using Group Pickup and a Phone Number **80**
 - Answer a Call Using Other Pickup **80**
- Call Waiting **81**
 - Respond to a Call Waiting Notification **81**
- Conference **81**
 - Add Another Party to Your Call to Create a Conference **81**
 - Join Calls Together in a Conference **82**
 - Swap Between Calls Before Completing a Conference **82**
 - View Conference Participants **82**
 - Remove Conference Participants **82**
- Divert **82**
 - Divert a Call **83**
- Do Not Disturb **83**
 - Turn DND On and Off **83**
- Extension Mobility **84**
 - Enable Extension Mobility **84**
- Fast Dial **84**
 - Place a Call with a Fast-Dial Button **84**
- Hold **85**
 - Hold and Resume a Call **85**
 - Swap Between Holding and Active Calls **85**
 - Put a Call on Hold by Answering a New Call **85**
 - Determine if a Shared Line is on Hold **85**
- Remote Hold **86**
- Hold Reversion **86**
 - Respond to a Hold Reversion Notification **86**

Hunt Groups	86
Sign In and Out of a Hunt Group	86
Intercom	87
Place a Dedicated Intercom Call	87
Place a Dialable Intercom Call	87
Receive an Intercom Call	87
Line Status	88
Line Status Indicators	88
Malicious Call Identification	89
Trace a Suspicious Call	89
Meet Me	89
Host a Meet-Me Conference	89
Join a Meet-Me Conference	89
Mobile Connect	90
Turn On or Off Mobile Connect to All Your Remote Destinations From Your Desk Phone	90
Switch an In-Progress Call on Your Desk Phone to a Mobile Phone	90
Switch an In-Progress Call From a Mobile Phone to Your Desk Phone	91
Mute	91
Mute Your Phone	91
On-hook Dialing	91
Dial a Number On-hook	91
Privacy	92
Enable Privacy on a Shared Line	92
Quality Reporting Tool	92
Report Problems on Your Phone	92
Redial	92
Redial a Number	93
Shared Lines	93
Speed Dial	94
Place a Call with a Speed-Dial Button	94
Place a Call with a Speed-Dial Code	94
Use a Speed-Dial Code On-hook	94
Use a Speed-Dial Code Off-hook	94
Transfer	95

- Transfer a Call to Another Number **95**
- Swap Between Calls Before Completing a Transfer **95**
- Web Dialer **95**
 - Use Web Dialer with Cisco Directory **96**
 - Use Web Dialer with Another Online Corporate Directory **96**
 - Set Up, View, or Change Web Dialer Preferences **96**
 - Sign Out of Web Dialer **97**
- User Options 99**
 - User Options Web Pages **99**
 - Sign In and Out of User Options Web Pages **99**
 - Device **100**
 - Select a Device From the User Options Web Pages **100**
 - Customize Do Not Disturb Options **100**
 - Line Settings **101**
 - Set Up Call Forwarding Per Line **101**
 - Change the Voice Message Indicator Setting Per Line **101**
 - Change the Audible Voice Message Indicator Setting Per Line **102**
 - Change the Ring Settings Per Line **102**
 - Change or Create a Line Text Label for Your Phone Display **102**
 - Customize Do Not Disturb Options **103**
 - Speed Dial on the Web **103**
 - Set Up Speed-Dial Buttons **103**
 - Set Up Speed-Dial Codes **104**
 - Phone Services **104**
 - Subscribe to a Service **104**
 - Search for Services **105**
 - Change or End Services **105**
 - Change a Service Name **105**
 - Add a Service to an Available Programmable Feature Button **105**
 - User Settings **106**
 - Change Your Browser Password **106**
 - Change Your PIN **106**
 - Change the Language for Your User Options Web Pages **106**
 - Change the Language for Your Phone Display **106**

- Directory **107**
- Personal Address Book **107**
 - Add a New PAB Entry **107**
 - Search for a PAB Entry **107**
 - Edit a PAB Entry **108**
 - Delete a PAB Entry **108**
 - Assign a Feature Button for Personal Address Book **109**
- Fast Dials **109**
 - Assign a Feature Button for Fast Dial **109**
 - Assign a Fast Dial Code to a PAB Entry **110**
 - Assign a Fast Dial Code to a Phone Number Without Using a PAB Entry **110**
 - Search for a Fast Dial Entry **110**
 - Edit a Fast Dial Phone Number **110**
 - Delete a PAB Entry **111**
- Mobility Settings **111**
 - Add a New Remote Destination **111**
 - Create an Access List **112**
- Plugins **112**
 - Access Plugins **113**
- Accessories 115**
- Phone Accessories **115**
 - Cisco Unified IP Color Key Expansion Module **115**
 - Features of the Cisco Unified IP Color Key Expansion Module **116**
 - Place a Call on the Expansion Module **118**
 - Configure Buttons **119**
 - Adjust the Brightness **119**
 - Bluetooth Headsets **119**
- FAQs and Troubleshooting 121**
- Frequently Asked Questions **121**
- Troubleshooting Tips **123**
 - Personal Directory **124**
 - User Options **124**

Product Safety, Security, Accessibility, and Related Information 125

Safety and Performance Information 125

Power Outage 125

External Devices 125

Cisco Product Security 126

Accessibility Features 126

Vision Impaired and Blind Accessibility Features 126

Hearing Impaired Accessibility Features 130

Mobility Impaired Accessibility Features 133

Additional Information 135

Warranty 137

Cisco One-Year Limited Hardware Warranty Terms 137

Your Phone

Revised: August 21, 2009


Cisco Unified IP Phone 8961

The Cisco Unified IP Phone 8961 provides these features:

- Phone connections
- Footstand
- Phone display viewing angle
- Buttons and hardware
- Phone screen
- Power-save mode
- Handset rest

Phone Connections

For your phone to work, it must be connected to the corporate IP telephony network. Your system administrator can help you connect your phone.



276320

1	DC adaptor port (DC48V)	5	Computer port (10/100/1000 PC) connection
2	AC-to-DC power supply (optional)	6	Handset connection
3	AC power wall plug (optional)	7	Analog headset connection (optional)
4	Network port connection (10/100/1000 SW) with IEEE 802.3af and 802.3at power enabled	8	Anti-theft security lock connector (lock optional)




276321

1	USB port	2	Cisco Unified IP Color Key Expansion Module connector
----------	----------	----------	---

Footstand

If your phone is placed on a table or desk, connect the footstand to the back of the phone.



1 Insert the curved connectors into the lower slots.	2 Lift the footstand until the connectors snap into the upper slots.
---	---


Phone Display Viewing Angle










The phone display viewing angle can be adjusted according to your preference.













Buttons and Hardware

Your phone provides quick access to your phone lines, features, and call sessions. Use the feature buttons (on the left) to view calls on a line or access features such as speed dial or All Calls. Use the call session buttons (on the right) to perform tasks such as making a call, answering a call, or resuming a held call.



1	Phone screen	Shows information about your phone, including directory number, call information (for example caller ID, icons for an active call or call on hold) and available softkeys.
2	Session buttons 	<p>Each represents a call session and takes the default action for that session. For example, pressing the session button for a ringing call answers the call, while pressing the session button for a held call resumes the call.</p> <p>Color LEDs reflect the call state. LEDs can <i>flash</i> (blink on and off rapidly), <i>pulse</i> (alternately dim and brighten), or appear <i>solid</i> (glow without interruption).</p> <ul style="list-style-type: none"> • Flashing amber —Ringing call. Pressing this button answers the call. • Solid green —May be a connected call or an outgoing call that is not yet connected. If the call is connected, pressing this button displays the call details or the participants of a conference call. If the call is not yet connected, pressing this button ends the call. • Pulsing green —Held call. Pressing this button resumes the held call. • Solid red —Shared line in-use remotely. Pressing this button allows you to barge in on the call (if Barge is enabled). • Pulsing red —Shared line call put on hold remotely. Pressing this button resumes the held call. <p>Icons next to the session buttons indicate an action for that session. For example, pressing the session button with a Missed Calls icon displays your missed calls, and pressing the session button with a Voicemail icon accesses your voice messaging system.</p> <p>(The position of session buttons may be reversed with that of programmable feature buttons on phones using a locale with a right-to-left reading orientation, such as Hebrew and Arabic.)</p>
3	Softkey buttons 	Allow you to access the softkey options (for the selected call or menu item) displayed on your phone screen.
4	Back button 	Returns to the previous screen or menu.
5	Release button 	Ends a connected call or session.

6	Navigation pad and Select button 	<p>The four-way Navigation pad allows you to scroll through menus, highlight items, and move within a text input field.</p> <p>The Select button (center of the Navigation pad) allows you to select a highlighted item.</p> <p>The Select button is lit (white) when the phone is in power-save mode.</p>
7	Conference button 	Creates a conference call.
8	Hold button 	Places a connected call on hold.
9	Transfer button 	Transfers a call.
10	Keypad	Allows you to dial phone numbers, enter letters, and choose menu items (by entering the item number).
11	Speakerphone button 	<p>Selects the speakerphone as the default audio path and initiates a new call, picks up an incoming call, or ends a call. During a call, the button is lit green.</p> <p>The speakerphone audio path does not change until a new default audio path is selected (for example, by picking up the handset).</p> <p>If external speakers are connected, the Speakerphone button selects them as the default audio path.</p>
12	Mute button 	Toggles the microphone on or off during a call. When the microphone is muted, the button is lit red.
13	Headset button 	<p>Selects the wired headset as the default audio path and initiates a new call, picks up an incoming call, or ends a call. During a call, the button is lit green.</p> <p>A headset icon  in the phone screen header line indicates the headset is the default audio path. This audio path does not change until a new default audio path is selected (for example, by picking up the handset).</p>
14	Volume button 	<p>Controls the handset, headset, and speakerphone volume (off-hook) and the ringer volume (on-hook).</p> <p>Silences the ringer on the phone if an incoming call is ringing.</p>
15	Messages button 	Auto-dials your voicemail system (varies by system).