

Preface

This manual provides information related to the installation and operation of this device. The individual reading this manual is presumed to have a basic understanding of telecommunications terminology and concepts.

If you find the product to be inoperable or malfunctioning, please contact technical support for immediate service by email at INT-support@comtrend.com

For product update, new product release, manual revision, or software upgrades, please visit our website at <http://www.comtrend.com>

Important Safety Instructions

With reference to unpacking, installation, use, and maintenance of your electronic device, the following basic guidelines are recommended:

- Do not use or install this product near water, to avoid fire or shock hazard. For example, near a bathtub, kitchen sink or laundry tub, or near a swimming pool. Also, do not expose the equipment to rain or damp areas (e.g. a wet basement).
- Do not connect the power supply cord on elevated surfaces. Allow it to lie freely. There should be no obstructions in its path and no heavy items should be placed on the cord. In addition, do not walk on, step on, or mistreat the cord.
- Use only the power cord and adapter that are shipped with this device.
- To safeguard the equipment against overheating, make sure that all openings in the unit that offer exposure to air are not blocked.
- Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightening. Also, do not use the telephone to report a gas leak in the vicinity of the leak.
- Never install telephone wiring during stormy weather conditions.

CAUTION:

- To reduce the risk of fire, use only No. 26 AWG or larger telecommunication line cord.
- Always disconnect all telephone lines from the wall outlet before servicing or disassembling this equipment.



WARNING

- Disconnect the power line from the device before servicing.
- Power supply specifications are clearly stated in [Appendix C – Specifications](#).

Copyright

Copyright©2014 Comtrend Corporation. All rights reserved. The information contained herein is proprietary to Comtrend Corporation. No part of this document may be translated, transcribed, reproduced, in any form, or by any means without prior written consent of Comtrend Corporation.

This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see <http://www.gnu.org/licenses/>

NOTE: This document is subject to change without notice.

Protect Our Environment



This symbol indicates that when the equipment has reached the end of its useful life, it must be taken to a recycling centre and processed



separate from domestic waste.

The cardboard box, the plastic contained in the packaging, and the parts that make up this router can be recycled in accordance with regionally established regulations. Never dispose of this electronic equipment along with your household waste; you may be subject to penalties or sanctions under the law. Instead, please be responsible and ask for disposal instructions from your local government.

Table of Contents

CHAPTER 1 INTRODUCTION.....	6
1.1 FEATURES	7
CHAPTER 2 INSTALLATION.....	8
2.1 HARDWARE SETUP.....	8
2.2 HARDWARE SETUP.....	8
2.3 LED INDICATORS.....	10
CHAPTER 3 WEB USER INTERFACE.....	12
3.1 DEFAULT SETTINGS	12
3.2 IP CONFIGURATION.....	13
3.3 LOGIN PROCEDURE.....	15
CHAPTER 4 DEVICE INFORMATION.....	17
4.1 WAN	19
4.2 STATISTICS.....	20
4.2.1 LAN Statistics.....	20
4.2.2 WAN Service	21
4.2.3 XTM Statistics.....	22
4.2.4 xDSL Statistics	23
4.3 ROUTE	28
4.4 ARP.....	29
4.5 DHCP.....	29
4.6 NAT SESSION	31
4.7 IGMP PROXY	32
4.8 IPV6	33
4.8.1 IPv6 Info	33
4.8.2 IPv6 Neighbor	34
4.8.3 IPv6 Route	35
4.9 NETWORK MAP	36
4.10 WIRELESS	37
4.10.1 Station Info	37
4.10.2 Site Survey	38
CHAPTER 5 BASIC SETUP.....	39
5.1 WAN SETUP	40
5.1.1 WAN Service Setup	41
5.2 NAT	42
5.2.1 Virtual Servers	42
5.2.2 Port Triggering	44
5.2.3 DMZ Host	46
5.2.4 IP Address Map	47
5.2.5 IPSEC ALG.....	49
5.2.6 SIP ALG.....	50
5.3 LAN.....	51
5.3.1 LAN IPv6 Autoconfig.....	54
5.3.2 Static IP Neighbor	57
5.3.3 UPnP	58
5.4 WIRELESS	59
5.4.1 Basic	59
5.4.2 Security.....	61
5.5 PARENTAL CONTROL.....	64
5.5.1 Time Restriction.....	64
5.5.2 URL Filter.....	65
5.6 HOME NETWORKING.....	67
5.6.1 Print Server	67
5.6.2 DLNA.....	67
5.6.3 Storage Service.....	68

CHAPTER 6 ADVANCED SETUP.....	69
6.1 AUTO-DETECTION SETUP	69
6.2 SECURITY	74
6.2.1 IP Filtering	74
6.2.2 MAC Filtering.....	77
6.3 QUALITY OF SERVICE (QoS).....	79
6.3.1 QoS Queue Setup.....	80
6.3.2 QoS Policer	82
6.3.3 QoS Classification	84
6.4 ROUTING	86
6.4.1 Default Gateway.....	86
6.4.2 Static Route	87
6.4.3 Policy Routing	88
6.4.4 RIP.....	89
6.5 DNS.....	90
6.5.1 DNS Server	90
6.5.2 Dynamic DNS.....	91
6.5.3 DNS Entries	92
6.5.4 DNS Proxy/Relay.....	93
6.6 DSL.....	94
6.7 DSL BONDING.....	96
6.8 INTERFACE GROUPING	97
6.9 IP TUNNEL.....	100
6.9.1 IPv6inIPv4.....	100
6.9.2 IPv4inIPv6.....	101
6.10 CERTIFICATE.....	102
6.10.1 Local.....	102
6.10.2 Trusted CA.....	104
6.11 POWER MANAGEMENT	105
6.12 MULTICAST.....	106
6.13 WIRELESS	108
6.13.1 Basic.....	108
6.13.2 Security.....	110
6.13.3 WPS	113
6.13.4 MAC Filter.....	114
6.13.5 Wireless Bridge.....	116
6.13.6 Advanced.....	117
CHAPTER 7 DIAGNOSTICS.....	120
7.1 DIAGNOSTICS – INDIVIDUAL TESTS	120
7.2 FAULT MANAGEMENT.....	121
7.3 UPTIME STATUS	122
7.4 PING	122
7.5 TRACE ROUTE	123
7.6 SYSTEM UTILIZATION	124
CHAPTER 8 MANAGEMENT	125
8.1 SETTINGS.....	125
8.1.1 Backup Settings.....	125
8.1.2 Update Settings.....	126
8.1.3 Restore Default	126
8.2 SYSTEM LOG	127
8.3 SNMP AGENT	129
8.4 TR-069 CLIENT	130
8.5 INTERNET TIME	132
8.6 ACCESS CONTROL	133
8.6.1 Passwords.....	133
8.6.2 Service Access.....	135
8.6.3 IP Address.....	136
8.7 UPDATE SOFTWARE	137
8.8 REBOOT.....	138

CHAPTER 9 LOGOUT	139
APPENDIX A - FIREWALL	140
APPENDIX B - PIN ASSIGNMENTS	143
APPENDIX C – SPECIFICATIONS	144
APPENDIX D - SSH CLIENT	146
APPENDIX E - CONNECTION SETUP	147
APPENDIX F - WPS OPERATION	179
APPENDIX G - PRINTER SERVER	184

Chapter 1 Introduction

The NexusLink 3112u Multi DSL Bonded Router is a single box solution for triple play applications. It features dual xDSL bonded ports that provide twice the xDSL bandwidth (ADSL2+ in both ATM/PTM modes and VDSL2 PTM 8a/8b/8c/8d/12a/12b/17a profiles) over comparable single-port models. With PTM mode supported, it can provide better performance than a regular ATM mode router. The NexusLink 3112u is equipped with three Fast Ethernet ports, one Gigabit port and 802.11n WLAN Access Point (AP). It goes above and beyond with high level features such as QoS, VPN and remote management (with TR-069 support).

1.1 Features

- Integrated 802.11n AP (802.11b/g backward-compatible)
- Automatically switches to ADSL2+/VDSL2 according to the port setting of DSLAM
- Supports bonded xDSL lines
- VDSL2 12a/12b profile support
- Per-VC packet level QoS
- WPA and 802.1x
- WPS 2.0
- RADIUS client
- Up to VDSL2 17a Profile
- US0
- □PhyR and G.INP
- G.Vector
- Static routing & RIP/RIP v2
- NAT/PAT
- IGMP Snooping/Proxy and fast leave
- Supports remote administration
- Web-based management
- Configuration backup and restoration
- Up to 16 PVCs and Up to 8 PTM flows
- IPv6 compliant
- Printer Server (IPP)
- Firmware upgrade and configuration
- Auto PVC configuration
- UPnP
- IP/MAC address filtering
- Dynamic IP assignment
- Parental Control
- DHCP Server/Client
- DNS Relay/Proxy
- FTP/TFTP server
- USB mass-storage and file sharing (Samba)
- Embedded SNMPv2 agent
- HTTPS/HTTP server
- TR-069/TR-098/TR-111

Chapter 2 Installation

2.1 Hardware Setup

Follow the instructions below to complete the hardware setup.



DO NOT STACK

Non-stackable


This device is not stackable – do not place units on top of each other, otherwise damage could occur.

2.2 Hardware Setup

Follow the instructions below to complete the hardware setup.

BACK PANEL

The figure below shows the back panel of the device.



Power ON

Press the power button to the OFF position (OUT). Connect the power adapter to the power port. Attach the power adapter to a wall outlet or other AC source. Press the power button to the ON position (IN). If the Power LED displays as expected then the device is ready for setup (see section [2.3 LED Indicators](#) for details).

Caution 1: If the device fails to power up, or it malfunctions, first verify that the power cords are connected securely and then power it on again. If the problem persists, contact technical support.

Caution 2: Before servicing or disassembling this equipment, disconnect all power cords and telephone lines from their outlets.

Reset Button

Restore the default parameters of the device by pressing the Reset button for 10 seconds. After the device has rebooted successfully, the front panel should display as expected (see section [2.3 LED Indicators](#) for details).

NOTE: If pressed down for more than 60 seconds, the NexusLink 3112u will go into a firmware update state (CFE boot mode). The firmware can then be updated using an Internet browser pointed to the default IP address.

GB ETH Port

Use RJ45 straight through or crossover MDI/X cable to connect to Ethernet WAN.

Ethernet (LAN) Ports

Use 10/100 BASE-T RJ-45 cables to connect up to four network devices (as the GB ETH port can also be used). These ports are auto-sensing MDI/X; so either straight-through or crossover cable can be used.

USB Host Port (Type A)

This port can be used to connect the router to the print server.

DSL Port

Connect to a VDSL with this RJ14 Port. This device contains a micro filter which removes the analog phone signal. If you wish, you can connect a regular telephone to the same line by using a POTS splitter.

FRONT PANEL

The Wi-Fi & WPS buttons are located on the bottom-left of the front panel, as shown.



WiFi Switch

Press this button to enable/disable the wireless LAN (WLAN).

WPS Button

Press this button to begin searching for WPS clients. These clients must also enable WPS push button mode (see [Appendix F - WPS OPERATION](#) for instructions).

2.3 LED Indicators

The front panel LED indicators are shown below and explained in the following table. This information can be used to check the status of the device and its connections.



LED	Color	Mode	Function
POWER	Green	On	The device is powered up.
		Off	The device is powered down.
	Red	On	POST (Power On Self Test) failure or other malfunction. A malfunction is any error of internal sequence or state that will prevent the device from connecting to the DSLAM or passing customer data.
GB ETH	Green (for 1000 Base-T)	On	Powered device connected to the associated port.
		Off	No activity, modem powered off, no cable or no powered device connected to the associated port.
		Blink	Traffic is passing.
	Yellow (for 10/100 Base-T)	On	Powered device connected to the associated port.
		Off	No activity, modem powered off, no cable or no powered device connected to the associated port.
		Blink	Traffic is passing.
ETH 1-3	Green	On	An Ethernet Link is established.
		Off	An Ethernet Link is not established.
		Blink	Data transmitting or receiving over Ethernet.
WPS	Green	On	WPS enabled.
		Off	WPS disabled.
		Blink	The router is searching for WPS clients.
WiFi	Green	On	The wireless module is ready. (i.e. installed and enabled).
		Off	The wireless module is not ready. (i.e. either not installed or disabled).
		Blink	Data transmitting or receiving over WLAN.
DSL1	Green	On	The DSL1 link is established.
		Off	The device is powered down.
		Blink	DSL1 attempting sync:

			<ul style="list-style-type: none"> Flashing at 2 Hz with a 50% duty cycle when trying to detect carrier signal flashing at 4 Hz with a 50% duty cycle when the carrier has been detected and the modem is trying to train.
DSL2	Green	On	The DSL2 link is established.
		Off	The device is powered down.
		Blink	DSL2 attempting sync: <ul style="list-style-type: none"> Flashing at 2 Hz with a 50% duty cycle when trying to detect carrier signal flashing at 4 Hz with a 50% duty cycle when the carrier has been detected and the modem is trying to train.
INTERNET	Green	On	IP connected and no traffic detected. If an IP or PPPoE session is dropped due to an idle timeout, the light will remain green if an VDSL connection is still present.
		Off	Modem power off, modem in bridged mode or VDSL connection not present. In addition, if an IP or PPPoE session is dropped for any reason, other than an idle timeout, the light is turned off.
		Blink	IP connected and IP Traffic is passing thru the device (either direction)
	Red	On	Device attempted to become IP connected and failed (no DHCP response, no PPPoE response, PPPoE authentication failed, no IP address from IPCP, etc.)

Chapter 3 Web User Interface

This section describes how to access the device via the web user interface (WUI) using an Internet browser such as Internet Explorer (version 5.0 and later).

3.1 Default Settings

The factory default settings of this device are summarized below.

- LAN IP address: 192.168.1.1
- LAN subnet mask: 255.255.255.0
- Administrative access (username: **root**, password: **12345**)
- User access (username: **user**, password: **user**)
- Remote (WAN) access (username: **support**, password: **support**)
- WLAN access: **enabled**

Technical Note

During power on, the device initializes all settings to default values. It will then read the configuration profile from the permanent storage section of flash memory. The default attributes are overwritten when identical attributes with different values are configured. The configuration profile in permanent storage can be created via the web user interface or telnet user interface, or other management protocols. The factory default configuration can be restored either by pushing the reset button for more than ten seconds until the power indicates LED blinking or by clicking the Restore Default Configuration option in the Restore Settings screen.

3.2 IP Configuration

DHCP MODE

When the NexusLink 3112u powers up, the onboard DHCP server will switch on. Basically, the DHCP server issues and reserves IP addresses for LAN devices, such as your PC.


To obtain an IP address from the DHCP server, follow the steps provided below.

NOTE: The following procedure assumes you are running Windows XP. However, the general steps involved are similar for most operating systems (OS). Check your OS support documentation for further details.

STEP 1: From the Network Connections window, open Local Area Connection (*You may also access this screen by double-clicking the Local Area Connection icon on your taskbar*). Click the **Properties** button.

STEP 2: Select Internet Protocol (TCP/IP) **and click the Properties** button.

STEP 3: Select Obtain an IP address automatically as shown below.



STEP 4: Click **OK** to submit these settings.

If you experience difficulty with DHCP mode, you can try static IP mode instead.

STATIC IP MODE

In static IP mode, you assign IP settings to your PC manually.


Follow these steps to configure your PC IP address to use subnet 192.168.1.x.

NOTE: The following procedure assumes you are running Windows XP. However, the general steps involved are similar for most operating systems (OS). Check your OS support documentation for further details.

STEP 1: From the Network Connections window, open Local Area Connection (*You may also access this screen by double-clicking the Local Area Connection icon on your taskbar*). Click the **Properties** button.

STEP 2: Select Internet Protocol (TCP/IP) **and click the** Properties button.

STEP 3: Change the IP address to the 192.168.1.x ($1 < x < 255$) subnet with subnet mask of 255.255.255.0. The screen should now display as shown below.



STEP 4: Click **OK** to submit these settings.

3.3 Login Procedure

Perform the following steps to login to the web user interface.

NOTE: The default settings can be found in section [3.1 Default Settings](#).

STEP 1: Start the Internet browser and enter the default IP address for the device in the Web address field. For example, if the default IP address is 192.168.1.1, type <http://192.168.1.1>.

NOTE: For local administration (i.e. LAN access), the PC running the browser must be attached to the Ethernet, and not necessarily to the device. For remote access (i.e. WAN), use the IP address shown on the [Device Information](#) screen and login with remote username and password.

STEP 2: A dialog box will appear, such as the one below. Enter the default username and password, as defined in section [3.1 Default Settings](#).



Click **OK** to continue.

NOTE: The login password can be changed later (see section [8.6.1 Passwords](#)).

STEP 3: After successfully logging in for the first time, you will reach this screen.

The screenshot displays the Comtrend web management interface. At the top, there is a navigation menu with icons for Device Info, Basic Setup, Advanced Setup, Diagnostics, Management, and Logout. The main content area is divided into three sections: Device, LAN, and Wireless.

Device

Model	NexusLink 3112u
Board ID	963168MB-1861N
Serial Number	13B3112UXF-AA000095
Firmware Version	WA31-412CTU-C03_R01.A2pvbF039j.d25c
Bootloader (CFE) Version	1.0.38-112.118-19
Up Time	9 mins:34 secs

LAN

Network interface status: GBETH (grey), ETH1 (grey), ETH2 (grey), ETH3 (green).

LAN IPv4 Address	192.168.1.1
LAN Subnet Mask	255.255.255.0
LAN MAC Address	f8:8e:85:b3:3d:8d
DHCP Server	Enabled
LAN IPv6 ULA Address	

Wireless

Driver Version	5.100.138.2008.cpe4.12L068.4
Primary SSID	Comtrend3D8D
Status	Enabled
Channel	11
Secure	Secure
Primary Encryption	WPA2-PSK TKIP+AES
Primary Passphrase/Key	•••••••• <input type="button" value="Show"/>

WAN

WAN interface status: DOWN

Traffic Type	Inactive
Upstream Rate (Kbps)	0
Downstream Rate (Kbps)	0
Default Gateway	
Primary DNS Server	0.0.0.0
Secondary DNS Server	0.0.0.0
Default IPv6 Gateway	

You can also reach this page by clicking on the following icon located at the top of the screen.



Chapter 4 Device Information

You can reach this page by clicking on the following icon located at the top of the screen.




The web user interface window is divided into two frames, the main menu (at left) and the display screen (on the right). The main menu has several options and selecting each of these options opens a submenu with more selections.

NOTE: The menu items shown are based upon the configured connection(s) and user account privileges. For example, if NAT and Firewall are enabled, the main menu will display the NAT and Security submenus. If either is disabled, their corresponding menu(s) will also be disabled.

Device Info is the first selection on the main menu so it will be discussed first. Subsequent chapters will introduce the other main menu options in sequence.

The Device Info Summary screen displays at startup.




Device Info Basic Setup Advanced Setup Diagnostics Management Logout

Device

Model	NexusLink 3112u
Board ID	963168MB-1861N
Serial Number	13B3112UXXF-AA000095
Firmware Version	WA31-412CTU-C03_R01.A2pvbF039j.d25c
Bootloader (CFE) Version	1.0.38-112.118-19
Up Time	9 mins:34 secs


Wireless


Driver Version	5.100.138.2008.cpe4.12L068.4
Primary SSID	Comtrend3D8D
Status	Enabled
Channel	11
	Secure
Primary Encryption	WPA2-PSK TKIP+AES
Primary Passphrase/Key	•••••••• Show

LAN


GBETH


ETH1


ETH2


ETH3

LAN IPv4 Address	192.168.1.1
LAN Subnet Mask	255.255.255.0
LAN MAC Address	f8:8e:85:b3:3d:8d
DHCP Server	Enabled
LAN IPv6 ULA Address	

WAN


DOWN

Traffic Type	Inactive
Upstream Rate (Kbps)	0
Downstream Rate (Kbps)	0
Default Gateway	
Primary DNS Server	0.0.0.0
Secondary DNS Server	0.0.0.0
Default IPv6 Gateway	

This screen shows hardware, software, IP settings and other related information.

4.1 WAN

Select WAN from the Device Info submenu to display the configured PVC(s).

Heading	Description
Interface	Name of the interface for WAN
Description	Name of the WAN connection
Type	Shows the connection type
VlanMuxId	Shows 802.1Q VLAN ID
IPv6	Shows WAN IPv6 status
IGMP	Shows Internet Group Management Protocol (IGMP) status
MLD	Shows Multicast Listener Discovery (MLD) status
NAT	Shows Network Address Translation (NAT) status
Firewall	Shows the status of Firewall
Status	Lists the status of DSL link
IPv4 Address	Shows WAN IPv4 address
IPv6 Address	Shows WAN IPv6 address

4.2 Statistics

This selection provides LAN, WAN, ATM and xDSL statistics.

NOTE: These screens are updated automatically every 15 seconds.
Click **Reset Statistics** to perform a manual update.

4.2.1 LAN Statistics

This screen shows data traffic statistics for each LAN interface.

Summary
WAN
Statistics
LAN
WAN Service
xTM
xDSL
Route
ARP
DHCP
NAT Session
IGMP Proxy
IPv6

COMTREND

Device Info Basic Setup Advanced Setup Diagnostics Management Logout

Statistics -- LAN

Interface	Received				Transmitted			
	Bytes	Pkts	Errs	Drops	Bytes	Pkts	Errs	Drops
GBETH	0	0	0	0	0	0	0	0
ETH1	947881	7900	0	0	3248206	13849	0	0
ETH2	0	0	0	0	0	0	0	0
ETH3	0	0	0	0	0	0	0	0
wl0	0	0	0	0	0	0	0	0

Reset Statistics

Heading	Description
Interface	LAN interface(s)
Received/Transmitted:	<ul style="list-style-type: none"> - Bytes - Pkts - Errs - Drops
	<ul style="list-style-type: none"> Number of Bytes Number of Packets Number of packets with errors Number of dropped packets


4.2.2 WAN Service

This screen shows data traffic statistics for each WAN interface.

Heading	Description
Interface	WAN interfaces
Description	WAN service label
Received/Transmitted	<ul style="list-style-type: none"> - Bytes - Pkts - Errs - Drops
	<ul style="list-style-type: none"> Number of Bytes Number of Packets Number of packets with errors Number of dropped packets

4.2.3 XTM Statistics

The following figure shows ATM (Asynchronous Transfer Mode)/PTM (Packet Transfer Mode) statistics.



XTM Interface Statistics

Heading	Description
Port Number	ATM PORT (0-3)
In Octets	Number of octets received over the interface
Out Octets	Number of octets transmitted over the interface
In Packets	Number of packets received over the interface
Out Packets	Number of packets transmitted over the interface
In OAM Cells	Number of OAM Cells received over the interface
Out OAM Cells	Number of OAM Cells transmitted over the interface.
In ASM Cells	Number of ASM Cells received over the interface
Out ASM Cells	Number of ASM Cells transmitted over the interface
In Packet Errors	Number of packets in Error
In Cell Errors	Number of cells in Error

4.2.4 xDSL Statistics

The xDSL Statistics screen displays information corresponding to the xDSL type. The two examples below (VDSL & ADSL) show this variation.

VDSL

COMTREND
 Device Info Basic Setup Advanced Setup Diagnostics Management Logout

Summary
 WAN
 Statistics
 LAN
 WAN Service
 xTM
xDSL
 Route
 ARP
 DHCP
 NAT Session
 IGMP Proxy
 IPv6
 Wireless


Statistics -- xDSL

Bonding Line Selection: DSL1

Mode:	VDSL2			
Traffic Type:	PTM			
Status:	Up			
Link Power State:	L0			
	Downstream	Upstream		
PhyR Status:	Off	Off		
Line Coding(Trellis):	On	On		
SNR Margin (0.1 dB):	190	251		
Attenuation (0.1 dB):	41	0		
Output Power (0.1 dBm):	175	46		
Attainable Rate (Kbps):	64717	19387		
	Path 0		Path 1	
	Downstream	Upstream	Downstream	Upstream
Rate (Kbps):	40005	10012	0	0
B (# of bytes in Mux Data Frame):	239	239	0	0
M (# of Mux Data Frames in an RS codeword):	1	1	0	0
T (# of Mux Data Frames in an OH sub-frame):	64	55	0	0
R (# of redundancy bytes in the RS codeword):	0	0	0	0
S (# of data symbols over which the RS code word spans):	0.1909	0.7622	0.0000	0.0000
L (# of bits transmitted in each data symbol):	10056	2519	0	0
D (interleaver depth):	1	1	0	0
I (interleaver block size in bytes):	240	120	0	0
N (RS codeword size):	240	240	0	0
Delay (msec):	0	0	0	0
INP (DMT symbol):	0.00	0.00	0.00	0.00
OH Frames:	0	0	0	0
OH Frame Errors:	496	0	0	0
RS Words:	0	4086342	0	0
RS Correctable Errors:	0	0	0	0
RS Uncorrectable Errors:	0	0	0	0
HEC Errors:	361	0	0	0
OCD Errors:	0	0	0	0
LCD Errors:	0	0	0	0
Total Cells:	311884080	0	0	0
Data Cells:	538	0	0	0
Bit Errors:	0	0	0	0
Total ES:	14	0		
Total SES:	11	0		
Total UAS:	181	170		

xDSL BER Test Reset Statistics Draw Graph

ADSL



COMTREND

Device Info Basic Setup Advanced Setup Diagnostics Management Logout

Summary
WAN
Statistics
LAN
WAN Service
xTM
xDSL
Route
ARP
DHCP
NAT Session
IGMP Proxy
IPv6
Wireless

Statistics -- xDSL

Bonding Line Selection

Mode:	ADSL2+			
Traffic Type:	ATM			
Status:	Up			
Link Power State:	L0			
	Downstream		Upstream	
PhyR Status:	Off	Off		
Line Coding(Trellis):	On	On		
SNR Margin (0.1 dB):	73	68		
Attenuation (0.1 dB):	15	28		
Output Power (0.1 dBm):	156	120		
Attainable Rate (Kbps):	25372	1215		
	Path 0		Path 1	
	Downstream	Upstream	Downstream	Upstream
Rate (Kbps):	25646	1219	8128	2400
MSGc (# of bytes in overhead channel message):	62	11	0	0
B (# of bytes in Mux Data Frame):	254	75	0	0
M (# of Mux Data Frames in FEC Data Frame):	1	1	0	0
T (Mux Data Frames over sync bytes):	3	2	0	0
R (# of check bytes in FEC Data Frame):	0	0	0	0
S (ratio of FEC over PMD Data Frame length):	0.3177	1.9804	0.0000	0.0000
L (# of bits in PMD Data Frame):	6420	307	0	0
D (interleaver depth):	1	1	0	0
Delay (msec):	0	0	0	0
INP (DMT symbol):	0.00	0.00	0.00	0.00
Super Frames:	0	0	0	0
Super Frame Errors:	3585	0	0	0
RS Words:	0	1156907	0	0
RS Correctable Errors:	0	0	0	0
RS Uncorrectable Errors:	0	0	0	0
HEC Errors:	410	0	0	0
OCD Errors:	0	0	0	0
LCD Errors:	0	0	0	0
Total Cells:	34707351	1643988	0	0
Data Cells:	5858	5711	0	0
Bit Errors:	0	0	0	0
Total ES:	25	0		
Total SES:	22	0		
Total UAS:	247	225		

Click the **Reset Statistics** button to refresh this screen.

Field	Description
Mode	VDSL, VDSL2
Traffic Type	ATM, PTM
Status	Lists the status of the DSL link

Field	Description
Link Power State	Link output power state.
Line Coding (Trellis)	Trellis On/Off
SNR Margin (0.1 dB)	Signal to Noise Ratio (SNR) margin
Attenuation (0.1 dB)	Estimate of average loop attenuation in the downstream direction.
Output Power (0.1 dBm)	Total upstream output power
Attainable Rate (Kbps)	The sync rate you would obtain.
Rate (Kbps)	Current sync rates downstream/upstream

In VDSL mode, the following section is inserted.

B	Number of bytes in Mux Data Frame
M	Number of Mux Data Frames in a RS codeword
T	Number of Mux Data Frames in an OH sub-frame
R	Number of redundancy bytes in the RS codeword
S	Number of data symbols the RS codeword spans
L	Number of bits transmitted in each data symbol
D	The interleaver depth
I	The interleaver block size in bytes
N	RS codeword size
Delay	The delay in milliseconds (msec)
INP	DMT symbol

OH Frames	Total number of OH frames
OH Frame Errors	Number of OH frames received with errors
RS Words	Total number of Reed-Solomon code errors
RS Correctable Errors	Total Number of RS with correctable errors
RS Uncorrectable Errors	Total Number of RS words with uncorrectable errors

HEC Errors	Total Number of Header Error Checksum errors
OCD Errors	Total Number of Out-of-Cell Delineation errors
LCD Errors	Total number of Loss of Cell Delineation
Total Cells	Total number of ATM cells (including idle + data cells)
Data Cells	Total number of ATM data cells
Bit Errors	Total number of bit errors


Total ES	Total Number of Errored Seconds
Total SES	Total Number of Severely Errored Seconds
Total UAS	Total Number of Unavailable Seconds

xDSL BER TEST

Click **xDSL BER Test** on the xDSL Statistics screen to test the Bit Error Rate (BER). A small pop-up window will open after the button is pressed, as shown below.




Click **Start** to start the test or click **Close** to cancel the test. After the BER testing is complete, the pop-up window will display as follows.




xDSL TONE GRAPH

Click **Draw Tone Graph** on the xDSL Statistics screen and a pop-up window will display the xDSL bits per tone status, as shown below.



4.3 Route

Choose **Route** to display the routes that the NexusLink 3112u has found.



COMTREND

Device Info Basic Setup Advanced Setup Diagnostics Management Logout

Summary
WAN
Statistics
Route
ARP
DHCP

Device Info -- Route

Flags: U - up, I - reject, G - gateway, H - host, R - reinstate
D - dynamic (redirect), M - modified (redirect).

Destination	Gateway	Subnet Mask	Flag	Metric	Service	Interface
192.168.1.0	0.0.0.0	255.255.255.0	U	0		br0

Field	Description
Destination	Destination network or destination host
Gateway	Next hop IP address
Subnet Mask	Subnet Mask of Destination
Flag	U: route is up !: reject route G: use gateway H: target is a host R: reinstate route for dynamic routing D: dynamically installed by daemon or redirect M: modified from routing daemon or redirect
Metric	The 'distance' to the target (usually counted in hops). It is not used by recent kernels, but may be needed by routing daemons.
Service	Shows the WAN connection label
Interface	Shows connection interfaces

4.4 ARP

Click **ARP** to display the ARP information.

IP address	Flags	HW Address	Device
192.168.1.2	Complete	00:25:11:af:fd:f8	br0

Field	Description
IP address	Shows IP address of host pc
Flags	Complete, Incomplete, Permanent, or Publish
HW Address	Shows the MAC address of host pc
Device	Shows the connection interface

4.5 DHCP


Click **DHCP** to display all DHCP Leases.

Hostname	MAC Address	IP Address	Expires In
----------	-------------	------------	------------

Field	Description
IPv6 Address	Shows IP address of device/host/PC
MAC Address	Shows the Ethernet MAC address of the device/host/PC
IP Address	Shows IP address of device/host/PC
Expires In	Shows how much time is left for each DHCP Lease









Device Info Basic Setup Advanced Setup Diagnostics Management Logout

Summary
WAN
Statistics
Route
ARP
DHCP
DHCPv4
DHCPv6

Device Info -- DHCPv6 Leases

IPv6 Address	MAC Address	Duration	Expires In
--------------	-------------	----------	------------

Field	Description
IPv6 Address	Shows IP address of device/host/PC
MAC Address	Shows the Ethernet MAC address of the device/host/PC
Duration	Shows leased time in hours
Expires In	Shows how much time is left for each DHCP Lease

4.6 NAT Session

COMTREND

Device Info Basic Setup Advanced Setup Diagnostics Management Logout

Summary
WAN
Statistics
Route
ARP
DHCP
NAT Session

NAT Session

Press "Show All" will show all NAT session information.

Source IP	Source Port	Destination IP	Destination Port	Protocol	Timeout
-----------	-------------	----------------	------------------	----------	---------

Refresh Show All

Click the "Show All" button to display the following.

NAT Session

Press "Show Less" will show NAT session information on WAN side only.

Source IP	Source Port	Destination IP	Destination Port	Protocol	Timeout
192.168.1.3	4233	192.168.1.1	80	tcp	73
192.168.1.3	4211	192.168.1.1	80	tcp	25
192.168.1.3	4230	192.168.1.1	80	tcp	53
192.168.1.3	4251	192.168.1.1	80	tcp	103
192.168.1.3	4260	192.168.1.1	80	tcp	104
192.168.1.3	17500	255.255.255.255	17500	udp	29
192.168.1.3	4241	192.168.1.1	80	tcp	83
192.168.1.3	4225	192.168.1.1	80	tcp	48
192.168.1.3	4255	192.168.1.1	80	tcp	103
192.168.1.3	17500	192.168.1.255	17500	udp	29
192.168.1.3	4239	192.168.1.1	80	tcp	83
192.168.1.3	4221	192.168.1.1	80	tcp	48
192.168.1.3	4261	192.168.1.1	80	tcp	104
192.168.1.3	4263	192.168.1.1	80	tcp	431999

Refresh Show Less

Field	Description
Source IP	The source IP from which the NAT session is established
Source Port	The source port from which the NAT session is established
Destination IP	The IP which the NAT session was connected to
Destination Port	The port which the NAT session was connected to
Protocol	The Protocol used in establishing the particular NAT session
Timeout	The time remaining for the TCP/UDP connection to be active

4.7 IGMP Proxy

The screenshot shows the Comtrend web interface. At the top, there is a navigation bar with the Comtrend logo and several menu items: Device Info, Basic Setup, Advanced Setup, Diagnostics, Management, and Logout. Below the navigation bar, there is a sidebar on the left with a list of menu items: Summary, WAN, Statistics, Route, ARP, DHCP, NAT Session, and IGMP Proxy (which is highlighted in blue). The main content area is titled 'List of IGMP Proxy Entries' and contains a table with the following columns: Interface, WAN, Groups, Member, and Timeout.

Field	Description
Interface	The Source interface from which the IGMP report was received
WAN	The WAN interface from which the multicast traffic is received
Groups	The destination IGMP group address
Member	The Source IP from which the IGMP report was received
Timeout	The time remaining before the IGMP report expires

4.8 IPv6

4.8.1 IPv6 Info

The screenshot shows the COMTREND web interface. The navigation menu on the left includes: Summary, WAN, Statistics, Route, ARP, DHCP, NAT Session, IGMP Proxy, IPv6, **IPv6 Info**, IPv6 Neighbor, and IPv6 Route. The main content area displays 'IPv6 WAN Connection Info' with a table for interface details and a 'General Info' section with a table for IPv6 configuration.

Interface	Status	Address	Prefix

General Info

Device Link-local Address	fe80::fa8e:85ff:feb3:3d8d/64
Default IPv6 Gateway	
IPv6 DNS Server	

Field	Description
Interface	WAN interface with IPv6 enabled
Status	Connection status of the WAN interface
Address	IPv6 Address of the WAN interface
Prefix	Prefix received/configured on the WAN interface
Device Link-local Address	The CPE's LAN Address
Default IPv6 Gateway	The default WAN IPv6 gateway
IPv6 DNS Server	The IPv6 DNS servers received from the WAN interface / configured manually

4.8.2 IPv6 Neighbor

The screenshot shows the Comtrend web interface. At the top, there is a navigation bar with the Comtrend logo and several icons representing different sections: Device Info, Basic Setup, Advanced Setup, Diagnostics, Management, and Logout. Below the navigation bar, there is a sidebar on the left with a list of menu items: Summary, WAN, Statistics, Route, ARP, DHCP, NAT Session, IGMP Proxy, IPv6, IPv6 Info, **IPv6 Neighbor**, and IPv6 Route. The main content area displays the title "Device Info -- IPv6 Neighbor Discovery table" and a table with the following columns: IPv6 address, Flags, HW Address, and Device.

Field	Description
IPv6 Address	Ipv6 address of the device(s) found
Flags	Status of the neighbor device
HW Address	MAC address of the neighbor device
Device	Interface from which the device is located

4.8.3 IPv6 Route

COMTREND

Device Info Basic Setup Advanced Setup Diagnostics Management Logout


Summary
WAN
Statistics
Route
ARP
DHCP
NAT Session
IGMP Proxy
IPv6
IPv6 Info
IPv6 Neighbor
[IPv6 Route](#)

Device Info -- IPv6 Route

Destination	Gateway	Metric	Interface
-------------	---------	--------	-----------

Field	Description
Destination	Destination IP Address
Gateway	Gateway address used for destination IP
Metric	Metric specified for gateway
Interface	Interface used for destination IP

4.9 Network Map



The network map feature provides an illustration of connected devices on the router.


The current wan status (firewall on/off) is displayed on the left side.

Detailed information of PC/USB connected to the router is shown on the right side.

4.10 Wireless

4.10.1 Station Info

This page shows authenticated wireless stations and their status. Click the **Refresh** button to update the list of stations in the WLAN.




The screenshot shows the Comtrend web interface. At the top, there is a navigation bar with the Comtrend logo and several icons representing different settings: Device Info, Basic Setup, Advanced Setup, Diagnostics, Management, and Logout. Below the navigation bar, there is a sidebar menu on the left with options like Summary, WAN, Statistics, Route, ARP, DHCP, NAT Session, IGMP Proxy, IPv6, Network Map, Wireless, Station Info (highlighted), and Site Survey. The main content area is titled 'Wireless -- Authenticated Stations' and contains a sub-header 'Wireless -- Authenticated Stations' and a description: 'This page shows authenticated wireless stations and their status.' Below this, there is a table with five columns: MAC, Associated, Authorized, SSID, and Interface. A 'Refresh' button is located below the table.







Consult the table below for descriptions of each column heading.

Field	Description
MAC	Lists the MAC address of all the stations.
Associated	Lists all the stations that are associated with the Access Point, along with the amount of time since packets were transferred to and from each station. If a station is idle for too long, it is removed from this list.
Authorized	Lists those devices with authorized access.
SSID	Lists which SSID of the modem that the stations connect to.
Interface	Lists which interface of the modem that the stations connect to.

4.10.2 Site Survey

The graph displays wireless APs found in your neighborhood by channel.



Summary

WAN

Statistics

Route

ARP

DHCP

NAT Session

IGMP Proxy

IPv6

Network Map

Wireless


Station Info

Site Survey

Wireless -- Channel Graph

The following graph displays wireless APs found in your neighborhood by channel.










Your broadband router is transmitting on channel 11.



Channel	Your Broadband Router	Neighboring APs
1	0	1
2	0	1
3	0	1
4	0	1
8	0	2
10	0	1
11	1	9
170	0	0


Wireless -- Site Survey

List of wireless APs found in your neighborhood.


Signal Strength	SSID	BSSID	Channel
	CT_HomeGateway	00:E0:4C:81:96:C1	11
	Inet	00:1A:2B:66:49:53	11
	CTMIS-INT	80:1F:02:57:22:34	1
	30ACSTest	80:1F:02:07:E3:4C	2
	P-5872u-C0E9_G	00:1D:20:FF:C8:E9	3
	PI	F8:8E:85:82:19:06	11
	ComtrendF4E	F8:8E:85:84:F4:EB	11
	ComtrendF4	F8:8E:85:84:F4:DC	11
	YL-N	C8:D3:A3:2C:4B:8A	11







Chapter 5 Basic Setup

You can reach this page by clicking on the following icon located at the top of the screen.



This will bring you to the following screen.



 Device Info
  **Basic Setup**
 Advanced Setup
  Diagnostics
  Management
  Logout

[WAN Setup](#)

NAT

LAN

Wireless

Parental Control

Home Networking

LAN

GBETH
ETH1
ETH2
ETH3


LAN IPv4 Address	192.168.1.1
LAN Subnet Mask	255.255.255.0
LAN MAC Address	f8:8e:85:b3:3d:8d
DHCP Server	Enabled
LAN IPv6 ULA Address	

WAN

DOWN

Traffic Type	Inactive
Upstream Rate (Kbps)	0
Downstream Rate (Kbps)	0
Default Gateway	
Primary DNS Server	0.0.0.0
Secondary DNS Server	0.0.0.0
Default IPv6 Gateway	

Wireless

Driver Version	5.100.138.2008.cpe4.12L068.4
Primary SSID	Comtrend3D8D
Status	Enabled
Channel	11
	Secure
Primary Encryption	WPA2-PSK TKIP+AES
Primary Passphrase/Key	<div style="display: flex; align-items: center;"> •••••••• <input type="button" value="Show"/> </div>

5.1 Wan Setup

Add or remove ATM, PTM and ETH WAN interface connections here.

Click **Add** to create a new ATM interface (see [Appendix E - Connection Setup](#)).

NOTE: Up to 8 ATM interfaces can be created and saved in flash memory.

To remove a connection, select its Remove column radio button and click **Remove**.

5.1.1 WAN Service Setup

This screen allows for the configuration of WAN interfaces.

Step 2: Wide Area Network (WAN) Service Setup

PPP Redirect: Disable Enable

Interface	Description	Type	Vlan8021p	VlanMuxId	Icmp	NAT	Firewall	IPv6	Mld	Remove	Edit

Click the **Add** button to create a new connection. For connections on ATM or ETH WAN interfaces see [Appendix E - Connection Setup](#).

To remove a connection, select its Remove column radio button and click **Remove**.

Heading	Description
Interface	Name of the interface for WAN
Description	Name of the WAN connection
Type	Shows the connection type
Vlan8021p	VLAN ID is used for VLAN Tagging (IEEE 802.1Q)
VlanMuxId	Shows 802.1Q VLAN ID
IGMP	Shows Internet Group Management Protocol (IGMP) status
NAT	Shows Network Address Translation (NAT) status
Firewall	Shows the Security status
IPv6	Shows the WAN IPv6 address
MLD	Shows Multicast Listener Discovery (MLD) status
Remove	Select interfaces to remove

To remove a connection, select its Remove column radio button and click **Remove**.

NOTE: ETH and ATM service connections cannot coexist. In Default Mode, up to 8 WAN connections can be configured; while VLAN Mux Connection Mode supports up to 16 WAN connections.

NOTE: Up to 16 PVC profiles can be configured and saved in flash memory. Also, ETH and PTM/ATM service connections cannot coexist.

5.2 NAT

To display this option, NAT must be enabled in at least one PVC. *NAT is not an available option in Bridge mode.*

5.2.1 Virtual Servers

Virtual Servers allow you to direct incoming traffic from the WAN side (identified by Protocol and External port) to the internal server with private IP addresses on the LAN side. The Internal port is required only if the external port needs to be converted to a different port number used by the server on the LAN side. A maximum of 32 entries can be configured.



COMTREND

Device Info Basic Setup Advanced Setup Diagnostics Management Logout

WAN Setup
NAT
Virtual Servers
Port Triggering
DMZ Host
IP Address Map
IPSEC ALG
SIP ALG


NAT -- Virtual Servers Setup

Virtual Server allows you to direct incoming traffic from WAN side (identified by Protocol and External port) to the Internal server with private IP address on the LAN side. The Internal port is required only if the external port needs to be converted to a different port number used by the server on the LAN side. A maximum 32 entries can be configured.

Add Remove

Server Name	External Port Start	External Port End	Protocol	Internal Port Start	Internal Port End	Server IP Address	WAN Interface	NAT Loopback	Remove

To add a Virtual Server, click **Add**. The following will be displayed.



COMTREND

Device Info Basic Setup Advanced Setup Diagnostics Management Logout

WAN Setup
NAT
Virtual Servers
Port Triggering
DMZ Host
IP Address Map
IPSEC ALG
SIP ALG
LAN
Wireless
Parental Control

Select the service name, and enter the server IP address and click "Apply/Save" to forward IP packets for this service to the specified server. **NOTE: The "Internal Port End" cannot be modified directly. Normally, it is set to the same value as "External Port End". However, if you modify "Internal Port Start", then "Internal Port End" will be set to the same value as "Internal Port Start".**
Remaining number of entries that can be configured:32

Choose All Interface
 Choose One Interface

Use Interface:

Service Name:

Select a Service:
 Custom Service:

Server IP Address:

Enable NAT Loopback

Apply/Save

External Port Start	External Port End	Protocol	Internal Port Start	Internal Port End
		TCP		
		TCP		
		TCP		
		TCP		

Apply/Save

Consult the table below for field and header descriptions.

Field/Header	Description
Choose All Interface	Virtual server rules will be created for all WAN interfaces.
Choose One Interface Use Interface	Select a WAN interface from the drop-down box.
Select a Service Or Custom Service	User should select the service from the list. Or User can enter the name of their choice.
Server IP Address	Enter the IP address for the server.
Enable NAT Loopback	Allows local machines to access virtual server via WAN IP Address
External Port Start	Enter the starting external port number (when you select Custom Server). When a service is selected, the port ranges are automatically configured.
External Port End	Enter the ending external port number (when you select Custom Server). When a service is selected, the port ranges are automatically configured.
Protocol	TCP, TCP/UDP, or UDP.
Internal Port Start	Enter the internal port starting number (when you select Custom Server). When a service is selected the port ranges are automatically configured
Internal Port End	Enter the internal port ending number (when you select Custom Server). When a service is selected, the port ranges are automatically configured.

5.2.2 Port Triggering

Some applications require that specific ports in the firewall be opened for access by the remote parties. Port Triggers dynamically 'Open Ports' in the firewall when an application on the LAN initiates a TCP/UDP connection to a remote party using the 'Triggering Ports'. The Router allows the remote party from the WAN side to establish new connections back to the application on the LAN side using the 'Open Ports'. A maximum 32 entries can be configured.

To add a Trigger Port, click **Add**. The following will be displayed.

Click Save/Apply to save and apply the settings.

Consult the table below for field and header descriptions.

Field/Header	Description
Use Interface	Select a WAN interface from the drop-down box.
Select an Application Or Custom Application	User should select the application from the list. Or User can enter the name of their choice.
Trigger Port Start	Enter the starting trigger port number (when you select custom application). When an application is selected, the port ranges are automatically configured.
Trigger Port End	Enter the ending trigger port number (when you select custom application). When an application is selected, the port ranges are automatically configured.
Trigger Protocol	TCP, TCP/UDP, or UDP.
Open Port Start	Enter the starting open port number (when you select custom application). When an application is selected, the port ranges are automatically configured.
Open Port End	Enter the ending open port number (when you select custom application). When an application is selected, the port ranges are automatically configured.
Open Protocol	TCP, TCP/UDP, or UDP.

5.2.3 DMZ Host

The DSL router will forward IP packets from the WAN that do not belong to any of the applications configured in the Virtual Servers table to the DMZ host computer.



The screenshot shows the COMTREND router's web interface. At the top, there is a navigation bar with icons and labels for 'Device Info', 'Basic Setup', 'Advanced Setup', 'Diagnostics', 'Management', and 'Logout'. The 'Basic Setup' icon is highlighted. On the left side, there is a sidebar menu with options: 'WAN Setup', 'NAT', 'Virtual Servers', 'Port Triggering', 'DMZ Host' (highlighted), 'IP Address Map', 'IPSEC ALG', 'SIP ALG', and 'LAN'. The main content area is titled 'NAT -- DMZ Host' and contains the following text: 'The Broadband Router will forward IP packets from the WAN that do not belong to any of the applications configured in the Virtual Servers table to the DMZ host computer.' Below this, it says: 'Enter the computer's IP address and click 'Apply' to activate the DMZ host.' and 'Clear the IP address field and click 'Apply' to deactivate the DMZ host.' There is a text input field labeled 'DMZ Host IP Address:'. Below the input field is a checkbox labeled 'Enable NAT Loopback'. At the bottom right of the form is a 'Save/Apply' button.

To **Activate** the DMZ host, enter the DMZ host IP address and click **Save/Apply**.

To **Deactivate** the DMZ host, clear the IP address field and click **Save/Apply**.

Enable NAT Loopback allows PC on the LAN side to access servers in the LAN network via the router's WAN IP.

5.2.4 IP Address Map

Mapping Local IP (LAN IP) to some specified Public IP (WAN IP).

Field/Header	Description
Rule	The number of the rule
Type	Mapping type from local to public.
Local Start IP	The beginning of the local IP
Local End IP	The ending of the local IP
Public Start IP	The beginning of the public IP
Public End IP	The ending of the public IP
Remove	Remove this rule

Click the Add button to display the following.

Select a Service, then click the **Save/Apply** button.

One to One: mapping one local IP to a specific public IP

Many to one: mapping a range of local IP to a specific public IP

Many to many(Overload): mapping a range of local IP to a different range of public IP

Many to many(No Overload): mapping a range of local IP to a same range of public IP

5.2.5 IPSEC ALG

IPSEC ALG provides multiple VPN passthrough connection support, allowing different clients on LAN side to establish a secured IP Connection to the WAN server.




The screenshot shows the Comtrend router's web interface. At the top left is the Comtrend logo. To its right is a navigation menu with icons and labels: Device Info (line graph), Basic Setup (CD/DVD), Advanced Setup (gears), Diagnostics (stethoscope), Management (person), and Logout (person running). Below the navigation menu is a sidebar on the left with a list of configuration options: WAN Setup, NAT, Virtual Servers, Port Triggering, DMZ Host, IP Address Map, IPSEC ALG (highlighted in blue), and SIP ALG. The main content area is titled 'IPSEC ALG settings' and contains the following text: 'This page allows you to enable / disable IPSEC ALG.' followed by a note: 'NOTE: This configuration doesn't take effect until router is rebooted.' Below this is a checkbox labeled 'Enable IPSEC ALG.' which is checked. At the bottom right of the main content area is a 'Save' button.

To enable IPSEC ALG, tick the checkbox and click the **Save** button.

5.2.6 SIP ALG

This page allows you to enable / disable SIP ALG.



The screenshot displays the Comtrend web management interface. At the top left is the Comtrend logo. A navigation bar contains icons and labels for: Device Info, Basic Setup, Advanced Setup, Diagnostics, Management, and Logout. On the left side, a vertical menu lists: WAN Setup, NAT, Virtual Servers, Port Triggering, DMZ Host, IP Address Map, IPSEC ALG, SIP ALG (highlighted in blue), and LAN. The main content area is titled "SIP ALG settings" and contains the following text: "This page allows you to enable / disable SIP ALG." followed by a bolded note: "NOTE: This configuration doesn't take effect until router is rebooted." Below this is a checked checkbox labeled "Enable SIP ALG." and a "Save" button.

5.3 LAN

Configure the LAN interface settings and then click **Apply/Save**.

The screenshot shows the 'Local Area Network (LAN) Setup' configuration page. The 'IP Address' is set to 192.168.1.1 and the 'Subnet Mask' is 255.255.255.0. Under 'IGMP Snooping mode', 'Blocking Mode' is selected, and 'Enable Enhanced IGMP' is checked. The 'DHCP Server' is enabled, with a 'Start IP Address' of 192.168.1.2, an 'End IP Address' of 192.168.1.254, and a 'Leased Time (hour)' of 24. The 'Ethernet Media Type' is set to 'Auto' for all ports (GBETH, ETH1, ETH2, ETH3). An 'Apply/Save' button is located at the bottom right of the configuration area.

Consult the field descriptions below for more details.

GroupName: Select an Interface Group.

1st LAN INTERFACE

IP Address: Enter the IP address for the LAN port.

Subnet Mask: Enter the subnet mask for the LAN port.

IGMP Snooping:

Standard Mode: In standard mode, multicast traffic will flood to all bridge ports when no client subscribes to a multicast group – even if IGMP snooping is enabled.

Blocking Mode: In blocking mode, the multicast data traffic will be blocked and not flood to all bridge ports when there are no client subscriptions to any multicast group.

Enable Enhanced IGMP: Enable by ticking the checkbox . IGMP packets between LAN ports will be blocked.

Enable LAN side firewall: Enable by ticking the checkbox .

DHCP Server: To enable DHCP, select **Enable DHCP server** and enter Start and End IP addresses and the Leased Time. This setting configures the router to automatically assign IP, default gateway and DNS server addresses to every PC on your LAN.

Setting TFTP Server: Enable by ticking the checkbox . Then, input the TFTP server address or an IP address.

Static IP Lease List: A maximum of 32 entries can be configured.

MAC Address	IP Address	Remove	WOL
<input type="button" value="Add Entries"/>		<input type="button" value="Remove Entries"/>	

To add an entry, enter MAC address and Static IP address and then click **Apply/Save**.

DHCP Static IP Lease

Enter the Mac address and Static IP address then click "Apply/Save" .

MAC Address:

IP Address:

Enable Wake On Lan.

To remove an entry, tick the corresponding checkbox in the Remove column and then click the **Remove Entries** button, as shown below.

MAC Address	IP Address	Remove	WOL
12:34:56:78:90:12	192.168.1.33	<input checked="" type="checkbox"/>	Disable
<input type="button" value="Add Entries"/>		<input type="button" value="Remove Entries"/>	

2ND LAN INTERFACE

To configure a secondary IP address, tick the checkbox outlined (in RED) below.

<input checked="" type="checkbox"/>	Configure the second IP Address and Subnet Mask for LAN interface
IP Address:	<input type="text"/>
Subnet Mask:	<input type="text"/>

IP Address: Enter the secondary IP address for the LAN port.

Subnet Mask: Enter the secondary subnet mask for the LAN port.

Ethernet Media Type:

Configure auto negotiation, or enforce selected speed and duplex mode for the Ethernet ports.

Auto	▼
Auto	
10Mbps-Half	
10Mbps-Full	
100Mbps-Half	
100Mbps-Full	

5.3.1 LAN IPv6 Autoconfig

Configure the LAN interface settings and then click **Save/Apply**.

COMTREND Device Info Basic Setup Advanced Setup Diagnostics Management Logout

WAN Setup
NAT
LAN
IPv6 Autoconfig
Static IP Neighbor
UPnP
Wireless
Parental Control
Home Networking

IPv6 LAN Auto Configuration

Note: Stateless DHCPv6 is supported based on the assumption of prefix length less than 64. Interface ID does NOT support ZERO COMPRESSION "::". Please enter the complete information. For example: Please enter "0:0:0:2" instead of "::2".

LAN IPv6 Link-Local Address Configuration

EUI-64
 User Setting

Interface Identifier:

Static LAN IPv6 Address Configuration

Interface Address (prefix length is required):

IPv6 LAN Applications

Enable DHCPv6 Server

Stateless
Refresh Time (sec):

Stateful
Start interface ID:
End interface ID:
Leased Time (hour):

Static IP Lease List: (A maximum 32 entries can be configured)

MAC Address	Interface ID	Remove
-------------	--------------	--------

Enable SLAAC (RADVD)

RA interval Min(sec):
RA interval Max(sec):
Reachable Time(ms):
Default Preference:

MTU (bytes):
 Enable Prefix Length Relay

Enable Configuration Mode

Enable ULA Prefix Advertisement

Randomly Generate
 Statically Configure

Prefix:
Preferred Life Time (hour):
Valid Life Time (hour):

Enable MLD Snooping

Standard Mode
 Blocking Mode

Consult the field descriptions below for more details.

LAN IPv6 Link-Local Address Configuration

Heading	Description
EUI-64	Use EUI-64 algorithm to calculate link-local address from MAC address
User Setting	Use the Interface Identifier field to define a link-local address

Static LAN IPv6 Address Configuration

Heading	Description
Interface Address (prefix length is required):	Configure static LAN IPv6 address and subnet prefix length

IPv6 LAN Applications

Heading	Description
Stateless	Use stateless configuration
Refresh Time (sec):	The information refresh time option specifies how long a client should wait before refreshing information retrieved from DHCPv6
Stateful	Use stateful configuration
Start interface ID:	Start of interface ID to be assigned to dhcpv6 client
End interface ID:	End of interface ID to be assigned to dhcpv6 client
Leased Time (hour):	Lease time for dhcpv6 client to use the assigned IP address

Static IP Lease List: A maximum of 32 entries can be configured.

MAC Address	IP Address	Remove
<input type="button" value="Add Entries"/> <input type="button" value="Remove Entries"/>		

To add an entry, enter MAC address and Interface ID and then click **Apply/Save**.

DHCP Static IP Lease

Enter the Mac address and Static Interface ID then click "Apply/Save" .

MAC Address:

Interface ID:

To remove an entry, tick the corresponding checkbox in the Remove column and then click the **Remove Entries** button, as shown below.

MAC Address	Interface ID	Remove
00:11:22:33:44:55	0:0:0:2	<input checked="" type="checkbox"/>

Heading	Description
Enable RADVD	Enable use of router advertisement daemon
RA interval Min(sec):	Minimum time to send router advertisement
RA interval Max(sec):	Maximum time to send router advertisement
Reachable Time(ms):	The time, in milliseconds that a neighbor is reachable after receiving reachability confirmation
Default Preference:	Preference level associated with the default router
MTU (bytes):	MTU value used in router advertisement messages to insure that all nodes on a link use the same MTU value
Enable Prefix Length Relay	Use prefix length receive from WAN interface
Enable Configuration Mode	Manually configure prefix, prefix length, preferred lifetime and valid lifetime used in router advertisement
Enable ULA Prefix Advertisement	Allow RADVD to advertise Unique Local Address Prefix
Randomly Generate	Use a Randomly Generated Prefix
Statically Configure Prefix	Specify the prefix to be used
Statically Configure	The prefix to be used
Preferred Life Time (hour)	The preferred life time for this prefix
Valid Life Time (hour)	The valid life time for this prefix
Enable MLD Snooping	Enable/disable IPv6 multicast forward to LAN ports

5.3.2 Static IP Neighbor



Click the Add button to display the following.



Click **Apply/Save** to apply and save the settings.

Heading	Description
IP Version	The IP version used for the neighbor device
IP Address	Define the IP Address for the neighbor device
MAC Address	The MAC Address of the neighbor device
Associated Interface	The interface where the neighbor device is located

5.3.3 UPnP

Select the checkbox provided and click **Apply/Save** to enable UPnP protocol.



The screenshot displays the Comtrend web management interface. At the top, the Comtrend logo is on the left, and a navigation menu includes icons for Device Info, Basic Setup, Advanced Setup, Diagnostics, Management, and Logout. On the left side of the main content area, a sidebar menu lists WAN Setup, NAT, LAN, IPv6 Autoconfig, Static IP Neighbor, and UPnP (which is highlighted in blue). The main content area is titled 'UPnP Configuration' and contains a note: 'NOTE: UPnP is activated only when there is a live WAN service with NAT enabled.' Below the note, there is a checked checkbox labeled 'Enable UPnP'. At the bottom right of the configuration area, there is an 'Apply/Save' button.

5.4 Wireless

5.4.1 Basic

The Basic option allows you to configure basic features of the wireless LAN interface. Among other things, you can enable or disable the wireless LAN interface, hide the network from active scans, set the wireless network name (also known as SSID) and restrict the channel set based on country requirements.

Wireless -- Basic

This page allows you to configure basic features of the wireless LAN interface. You can enable or disable the wireless LAN interface, hide the network from active scans, set the wireless network name (also known as SSID) and restrict the channel set based on country requirements. Click "Apply/Save" to configure the basic wireless options.

- Enable Wireless
- Hide Access Point
- Clients Isolation
- Disable WMM Advertise
- Enable Wireless Multicast Forwarding (WMF)
- Enable WiFi Button

SSID:

BSSID:

Country:

Max Clients:

Wireless - Guest/Virtual Access Points:

Enabled	SSID	Hidden	Isolate Clients	Disable WMM Advertise	Enable WMF	Max Clients	BSSID
<input type="checkbox"/>	<input type="text" value="wl0_Guest1"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	16	N/A
<input type="checkbox"/>	<input type="text" value="wl0_Guest2"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	16	N/A
<input type="checkbox"/>	<input type="text" value="wl0_Guest3"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	16	N/A

Click **Apply/Save** to apply the selected wireless options.

Consult the table below for descriptions of these options.

Option	Description
Enable Wireless	A checkbox <input checked="" type="checkbox"/> that enables or disables the wireless LAN interface. When selected, a set of basic wireless options will appear.

Option	Description
Hide Access Point	Select Hide Access Point to protect the access point from detection by wireless active scans. To check AP status in Windows XP, open Network Connections from the start Menu and select View Available Network Connections . If the access point is hidden, it will not be listed there. To connect a client to a hidden access point, the station must add the access point manually to its wireless configuration.
Clients Isolation	When enabled, it prevents client PCs from seeing one another in My Network Places or Network Neighborhood. Also, prevents one wireless client communicating with another wireless client.
Disable WMM Advertise	Stops the router from 'advertising' its Wireless Multimedia (WMM) functionality, which provides basic quality of service for time-sensitive applications (e.g. VoIP, Video).
Enable Wireless Multicast Forwarding	Select the checkbox <input checked="" type="checkbox"/> to enable this function.
Enable WiFi Button	Select the checkbox <input checked="" type="checkbox"/> to enable the WiFi button.
SSID [1-32 characters]	Sets the wireless network name. SSID stands for Service Set Identifier. All stations must be configured with the correct SSID to access the WLAN. If the SSID does not match, that user will not be granted access.
BSSID	The BSSID is a 48-bit identity used to identify a particular BSS (Basic Service Set) within an area. In Infrastructure BSS networks, the BSSID is the MAC (Media Access Control) address of the AP (Access Point); and in Independent BSS or ad hoc networks, the BSSID is generated randomly.
Country	A drop-down menu that permits worldwide and specific national settings. Local regulations limit channel range: US= worldwide, Japan=1-14, Jordan= 10-13, Israel= 1-13
Max Clients	The maximum number of clients that can access the router.
Wireless - Guest / Virtual Access Points	<p>This router supports multiple SSIDs called Guest SSIDs or Virtual Access Points. To enable one or more Guest SSIDs select the checkboxes <input checked="" type="checkbox"/> in the Enabled column. To hide a Guest SSID select its checkbox <input checked="" type="checkbox"/> in the Hidden column.</p> <p>Do the same for Isolate Clients and Disable WMM Advertise. For a description of these two functions, see the previous entries for "Clients Isolation" and "Disable WMM Advertise". Similarly, for Enable WMF, Max Clients and BSSID, consult the matching entries in this table.</p> <p>NOTE: Remote wireless hosts cannot scan Guest SSIDs.</p>

5.4.2 Security

The following screen appears when Wireless Security is selected. The options shown here allow you to configure security features of the wireless LAN interface.

Click **Apply/Save** to implement new configuration settings.

WIRELESS SECURITY

Setup requires that the user configure these settings using the Web User Interface (see the table below).

Select SSID	
Select the wireless network name from the drop-down box. SSID stands for Service Set Identifier. All stations must be configured with the correct SSID to access the WLAN. If the SSID does not match, that client will not be granted access.	
Network Authentication	
This option specifies whether a network key is used for authentication to the wireless network. If network authentication is set to Open, then no authentication is provided. Despite this, the identity of the client is still verified.	
Each authentication type has its own settings. For example, selecting 802.1X authentication will reveal the RADIUS Server IP address, Port and Key fields. WEP Encryption will also be enabled as shown below.	
Network Authentication:	802.1X
RADIUS Server IP Address:	0.0.0.0
RADIUS Port:	1812
RADIUS Key:	
WEP Encryption:	Enabled
Encryption Strength:	128-bit
Current Network Key:	2
Network Key 1:	1234567890123
Network Key 2:	1234567890123
Network Key 3:	1234567890123
Network Key 4:	1234567890123
Enter 13 ASCII characters or 26 hexadecimal digits for 128-bit encryption keys Enter 5 ASCII characters or 10 hexadecimal digits for 64-bit encryption keys	
<input type="button" value="Apply/Save"/>	

The settings for WPA authentication are shown below.

Network Authentication:	WPA
WPA Group Rekey Interval:	3600
RADIUS Server IP Address:	0.0.0.0
RADIUS Port:	1812
RADIUS Key:	
WPA/WAPI Encryption:	TKIP+AES
WEP Encryption:	Disabled
<input type="button" value="Apply/Save"/>	

The settings for WPA-PSK authentication are shown next.

Network Authentication:	WPA-PSK
WPA/WAPI passphrase:	●●●●●●●●●● Click here to display
WPA Group Rekey Interval:	3600
WPA/WAPI Encryption:	TKIP+AES
WEP Encryption:	Disabled
<input type="button" value="Apply/Save"/>	

WEP Encryption

This option specifies whether data sent over the network is encrypted. The same network key is used for data encryption and network authentication. Four network keys can be defined although only one can be used at any one time. Use the Current Network Key list box to select the appropriate network key.

Security options include authentication and encryption services based on the wired equivalent privacy (WEP) algorithm. WEP is a set of security services used to protect 802.11 networks from unauthorized access, such as eavesdropping; in this case, the capture of wireless network traffic.

When data encryption is enabled, secret shared encryption keys are generated and used by the source station and the destination station to alter frame bits, thus avoiding disclosure to eavesdroppers.

Under shared key authentication, each wireless station is assumed to have received a secret shared key over a secure channel that is independent from the 802.11 wireless network communications channel.

Encryption Strength

This drop-down list box will display when WEP Encryption is enabled. The key strength is proportional to the number of binary bits comprising the key. This means that keys with a greater number of bits have a greater degree of security and are considerably more difficult to crack. Encryption strength can be set to either 64-bit or 128-bit. A 64-bit key is equivalent to 5 ASCII characters or 10

hexadecimal numbers. A 128-bit key contains 13 ASCII characters or 26 hexadecimal numbers. Each key contains a 24-bit header (an initiation vector) which enables parallel decoding of multiple streams of encrypted data.

Please see [6.13](#) for MAC Filter, Wireless Bridge and Advanced Wireless features.