

PLEASE READ IMPORTANT SAFETY INSTRUCTIONS BEFORE USE

Congratulations! You have purchased a 2.4GHz Analog Cordless Telephone with Type II Call Waiting Caller ID and Digital Answering System that has been manufactured to the highest standards of SOUTHWESTERN BELL FREEDOM PHONE® Retail Sales.

BEFORE INSTALLING AND OPERATING THIS TELEPHONE, IT IS **VERY IMPORTANT THAT YOU READ THIS OWNER'S MANUAL.**

IMPORTANT SAFETY INSTRUCTIONS

BEFORE USING YOUR TELEPHONE EQUIPMENT, BASIC SAFETY

PRECAUTIONS SHOULD ALWAYS BE FOLLOWED TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK AND INJURY TO PERSONS, INCLUDING THE FOLLOWING:

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on the product.
3. Unplug this product from the wall telephone jack and power outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
4. Do not use this product near water, for example, near a bathtub, washbasin, kitchen sink, laundry tub, swimming pool, or in a wet basement.
5. Do not place this product on an unstable cart, stand or table. The product may fall, causing serious damage.
6. Slots or openings in the cabinet, back and bottom are provided for ventilation, to protect equipment from overheating. These openings must not be blocked or covered. Do not place the product on a bed, or other similar surface where the openings could be blocked. Never place this product near or over a radiator or heat register.
7. Operate this product using only the type of power source indicated on the marking label. If you are not sure of the type of power supply in your home, consult your dealer or local power company.
8. Do not allow anything to rest on the power cord. Do not place this product where it could be stepped on and damaged.
9. Do not overload wall outlets and extension cords, as this can result in fire or electric shock.

10. Never push objects of any kind into this product through cabinet slots, as they may touch dangerous voltage points or short circuit parts. This could result in fire or electric shock. Never spill liquid of any kind on the product.
11. To reduce the risk of electric shock, do not disassemble this product. Instead, when service or repair work is required, take it to a qualified service technician. Opening or removing covers may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the appliance is subsequently used.
12. Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - a. When the power supply cord or plug is damaged or frayed.
 - b. If liquid has been spilled into the product.
 - c. If the product has been exposed to rain or water.
 - d. If the product has been dropped or the cabinet has been damaged.
 - e. If the product exhibits a distinct change in performance. If the product does not operate normally and proper operating instructions have been followed, adjust only those controls that are covered by the operating instructions. Improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
13. Avoid using a telephone (other than a cordless type) during an electrical storm.

There may be a remote risk of electric shock from lightning.
14. Do not use the telephone to report a gas leak if you are in the vicinity of the leak.
15. Danger of explosion if battery is incorrectly replaced. Replace battery pack only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer instructions.

Safety Instructions for Batteries

Handset Battery Pack

CAUTION:

Use only a Southwestern Bell Freedom Phone approved battery pack in the handset of your GH3150 Analog Cordless Telephone. To reduce the risk of fire or injury, always do the following when replacing, discarding or charging batteries.

- a. When handling the batteries, be careful not to short circuit the battery with conducting materials such as rings, bracelets, and keys. The battery or conducting material may overheat and cause burns.
- b. Use only the following type and size batteries in the cordless phone:
- c. Self-contained 3-cell Nickel-Cadmium rechargeable the battery type should be AA 3.6V 600mAh.

Do not dispose of the battery pack in a fire. The cell may explode. Check with local codes for possible special disposal instructions.
- d. Do not attempt to open or mutilate the battery pack. The chemicals are dangerous and may cause damage to the eyes or skin, and may be toxic if swallowed.
- e. Follow the charging instructions outlined in this manual.

Save These Instructions

Handset Battery Caution

CAUTION:

To Reduce the risk of fire or injury to persons, read and follow these instructions.

1. Use only the following type and size batteries in the cordless phone: Self-contained 3-cell Nickel-Cadmium rechargeable battery type should be AA 3.6V 600mAh.

2. Do not dispose of the battery (ies) in a fire. The cell may explode. Check with local codes for possible special disposal instructions.
3. Do not open or mutilate the battery (ies). Released electrolyte is corrosive and may cause damage to the eyes or skin. It may be toxic if swallowed.
4. Handle batteries carefully in order to prevent short-circuiting the battery with conducting material such as rings, bracelets, and keys. The battery or conductor may overheat and cause burns.
5. Charge the battery (ies) provided with or identified for use with this product only in accordance with the instructions and limitations specified in this manual.
6. Do not mix old and new batteries in this product (applies to products employing more than one user replaceable second battery).
7. Do not mix batteries of different sizes or from different manufacturers in this product. (applies to products employing more than one user replaceable secondary battery).
8. Do not attempt to recharge the battery (ies) provided with or identified for use with this product. The batteries may leak corrosive electrolyte or explode.
9. Do not attempt to rejuvenate the battery (ies) provided with or identified for use with this product by heating them. Sudden release of the battery electrolyte may occur, causing burns or irritation to the eyes or skin.
10. When inserting batteries into this product, the proper polarity or direction must be observed. Reverse insertion of batteries can cause charging, and that may result in leakage or explosions. (Applies to product employing more than one separately replaceable primary battery).
11. Remove the batteries from this product if the product will not be used for a long period of time (several months or more), since during this time the battery could leak into the product.
12. Discard “dead” batteries as soon as possible since “dead”

- batteries are more likely to leak into a product.
13. Do not store this product, or the batteries provided with or identified for use with this product, in high temperature areas. Batteries that are stored in a freezer or refrigerator for the purpose of extending shelf life should be protected from condensation during storage and defrosting. Batteries should be stabilized at room temperature, prior to use after cold storage.




NOTE: The RBRC seal on the battery used in your Southwestern Bell Freedom Phone production indicates that we are participating in a program to collect and recycle Nickel Cadmium batteries throughout the United States. Pls. contact your local recycling center.


CONTENTS

IMPORTANT SAFETY INSTRUCTIONS 3
 Handset Battery Pack 4
 Handset Battery Caution 5
 Handset Diagram 8
 Base Diagram 9
 Traits of Cordless Telephones 10
 Installation 11
 Box Contents 11
 Preliminary Preparation Telephone Line Installation 11
 Modular Outlet 11
 Wall Mounting 12
 Handset Battery Charging 12
 Setup 13
 Telephone Operation 14
 Making a Call 14
 Receiving a Call Through the Handset 14
 Memory Features 14
 To Program Frequently Called Numbers: 14
 To Delete a Memory Location: 15
 To Dial Number Stored in Memory: 15
 Redial 16
 Flash 16
 Receiver Volume Control 16
 Page/Handset Locator 16
 Low Battery Warning 16
 Caller ID Operation 17
 Receiving a Call 17
 Reviewing Calls 17
 To Store Caller ID Record: 17
 Caller ID Redial 17
 Caller ID Erase 18
 Answering System Operation 19
 Base Control Operation 19
 Handset Remote Operation 21
 Line Remote Operation 22
 Belt Clip 22
 Optional Handset 22
 FCC Wants You To Know 23
 Product Care 24
 Additional Information 24
 Service 25
 Limited Warranty 25

Handset Diagram



Base Diagram



Traits of Cordless Telephones

- A. Cordless telephones offer convenience and mobility during telephone conversations. The use of cordless phones is dependent upon the availability of AC power. Any disruption of electrical power at your location will prevent the placing or receiving of telephone calls. It is recommended that a cordless telephone should not be installed as the only phone at your location.
- B. The usable range of the cordless handset away from the base is dependent upon many factors. The telephone base is like a radio transmitter in that it transmits telephone line signals via radio waves to the handset. Therefore, the location of the base is important in order to maximize the usable range. For example, installing the base on the second floor, in some locations, will provide longer range than a ground floor installation. Pick a location that gives you the clearest signal. The following can adversely affect usable range:
- * Aluminum siding
 - * Insulation with foil backing
 - * Any metal construction which could shield radio signals

Atmospheric conditions also play an important role in the performance of your cordless telephone.

Interference can be caused by placing the base near:

- * Fluorescent lights
- * Appliances that generate electrical noise, including:
 - * Microwaves
 - * Televisions
 - * VCRs
 - * Baby monitors
 - * Computers

- C. For maximum performance, always keep the battery pack fully charged.
- D. Plug your AC adaptor directly into an outlet, not an extension cord.
- E. Do not plug other appliances into the outlet or have the outlet controlled by a wall switch.
- F. If you want to use more than one cordless telephone in your home, the telephones must operate on different channels. Press the channel key to select a channel that provides the clearest communication.

Installation

Box Contents

Before installing your phone, check the shipping carton to be sure you have the following:

- * Base Unit
- * AC Adaptor
- * Owner's Manual
- * Belt Clip
- * Long Telephone Line Cord
- * Remote Access Card
- * Handset with Rechargeable Battery
- * Registration Card


Notes:

- a. Keep the shipping carton and packaging, in case you need to ship your phone.
- b. If there is visible damage, do not use this equipment. Contact your shipping agent or return the telephone to the place of purchase.

Preliminary Preparation Telephone Line Installation

1. Never install telephone jack during a lightning storm.
2. Never install telephone jack in wet location unless the jack is specifically designed for wet locations.
3. Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.

- 4. Use caution when installing or modifying telephone lines.



Modular Outlet

The GH3150 Cordless Telephone operates from a standard 110/120 volt AC outlet. The handsets are powered by a rechargeable battery pack. Batteries are charged automatically when the handset is placed in the cradle of the base unit or charging unit.

Installation

- A. Plug one end of the long telephone line cord into the back of the unit and connect the other end to a modular wall jack. Press until locking lever clicks.
- B. Connect the DC Adaptor into the back of the unit. Plug the other end into a standard 110/120 volt AC outlet.
- C. Place the handset into the base unit. The IN USE/ CHARGE LED will light. The LCD display will show "Charging" for 2 minutes and then return to standby mode. During these 2 minutes, user can pick up the phone and operate it in standby mode.

NOTE: BATTERY PACK MUST BE CHARGED FOR 16 HOURS BEFORE INITIAL OPERATION.

Handset Battery Charging

The battery pack in the handset must be fully charged for about 16 hours before using the telephone.

Note:

- When the battery gets low while the phone in use, there will be a low-battery beep from the handset. The handset will also display “LOW BATTERY” on the second line of the LCD.
- If the battery becomes low while you are on a call terminate the call quickly and put handset in the base to recharge the battery.
- The battery will hold its charge for several days out of the cradle, depending on use.

To Replace Batteries


- Remove battery cover
- Remove old battery
- Install new battery
- Close battery cover.
- Place the handset on the base unit.
- Charge 16 hours before first use.

Note: Use only the battery type that is recommended for use with this phone.

Note: To maximize your battery’s life, periodically drain the battery fully and then recharge it. To do this, unplug the phone line cord from your wall phone jack. Remove Handset from Base/Charger unit and press the TALK button. Handset Batteries must then be recharged for a full 16 hours.

Setup**To set Language:**

- After installing the FULLY CHARGED handset battery, the hand set display will light and will show “NEW CALL 00”.
- Press “PROG/FLASH” to enter the program menu.
- You can choose to see your display in 1ENG (English), 2FRA (French) or 3ESP (Spanish). Press VOL/CID “▲” or “▼” button or 1,2 or 3 on the keypad to choose the desired language.




- Press the “PROG/FLASH” key to confirm the display language and press “EXIT/*” to leave the program menu.

To set Ring Tone:

This telephone offers 3 standard ring tones for user to select.


- Press “PROG/FLASH” 2 times to enter the program menu ringer tone setting.
- You can choose from ringer tones 1-3 by pressing VOL/CID “▲” or “▼” button or 1,2 or 3 by keypad for changing the option.



- Press “PROG/FLASH” to confirm the ringer melody and press “EXIT/*” to leave the program menu.

To set Tone/Pulse

- Press “PROG/FLASH” 3 times to enter the program menu.
- Press VOL/CID “▲” or “▼” button or press 1 or 2 by keypad to select the TONE/PULSE item.



- Press the “PROG/FLASH” again to enter the TONE/PULSE setting item.
- Press “PROG/FLASH” to confirm the setting and press EXIT to leave the program menu.

To set Default

This telephone allows you to restore the phone setup options back to factory default. The default setting will reset Menu Language back to English, Ringer Tone back to 01, and Tone/Pulse back to Tone.

1. Press the “PROG/FLASH” 4 times to enter the program \ menu default setting mode.
2. Press VOL/CID “▲” or “▼” button to select to return to DEFAULT setting or not.



3. Press “PROG/FLASH” to confirm the setting and press “EXIT/*” to leave the program menu.

Telephone Operation

Making a Call

1. Lift the handset and press the “TALK” button to connect to the telephone line.
2. After hearing a dial tone, dial the desired number. If you misdial, simply press the “TALK” button. Wait for a couple of seconds, and press the “TALK” button again for a new dial tone.
3. After the conversation has been completed, press the “TALK” button once to disconnect the line, or return the handset to the base. The IN USE/Charge LED, will now be ‘charging’.

Receiving a Call Through the Handset

Press the “TALK” button on the handset.


Memory Features

Your GH3150 is equipped with 10 memories for programming your most frequently dialed telephone numbers. You can store up to 24 digits in each of the memory locations 1 through 10, by following the steps outlined below.


To Program Frequently Called Numbers:

1. Press the “MEM” button on the handset, and the right hand corner display will show “MEM # - -” with “- -” representing the memory location that is currently displayed.

2. Press the VOL/CID “▲” or “▼” or a digit to select the memory location where the telephone number is to be stored. You can choose from MEM 1-10.



3. Press “MEM” to confirm the location.
Note: If you do not want to confirm the memory location, press “EXIT” to return to standby mode.
If the selected memory location is not empty and you do not want to replace the content, press “EXIT/*” to keep the previous memory record and return to standby mode.
4. Edit the name (Up to 15 characters) by using the telephone keypad buttons (1-9).



Note: Successively pressing the number 2 key quickly allows you to select between letters A. B. or C. This also applies to letters on dialing keys 3-9. To add a space in the name, press the 1 key. If you enter any letters incorrectly, press the delete key to delete one character at a time. To repeat the same letter allow one second in between key presses.

5. Press “MEM” to confirm the name.
6. Enter the telephone number you wish to store, using the handset keypad.


Note: If you accidentally press a 25th digit, an error tone will sound, and you must reprogram the number.

Note: To enter a pause in the dialing sequence press the “#/Pause” button. To delete a particular digit that has already been entered, press the “DELETE/CHAN” button. The digit last entered will be deleted. To delete all of the digits, press the “EXIT” button.

7. Press the “MEM” button to confirm the entered telephone number.

To Delete a Memory Location:

1. Press the “MEM” button on the handset, and the display will show “MEM# -” with “-” representing the memory location that is currently displayed.
2. Press VOL/CID “▲” or “▼” or a digit to find the memory you want to delete.
3. Press the “DELETE” button on the handset.
4. The unit will ask you to delete the selected telephone number and the LCD Display will show “DELETE ?”



5. Press the “DELETE” button again to delete. The LCD Display will show “**DELETED**” and return to the standby mode.

Note: Press “EXIT” key on the handset to terminate the deletion process and return to standby mode.

To Dial Number Stored in Memory:

WHEN THE TALK BUTTON IS OFF:

1. Press the “MEM” button on the handset, and the display will show “MEM# -” with “-” representing the memory location that is currently displayed.
2. Press VOL/CID “▲” or “▼”, or a digit to select the memory location where the telephone number is to be redialed. You can choose from 1-10.
3. Press the “TALK” button. The number will scroll across the screen from left to right as it is dialed.

WHEN THE TALK BUTTON IS ON:

1. Press the “MEM” button on the handset.
2. Press the desired memory location (1 through 10).
3. Press “TALK” button to dial out the numbers.

Redial

Your GH3150 remembers the last number (up to 32 digits) dialed. This is a convenient feature when trying to place a call to a phone number that is not being answered or is continuously busy.

DO NOT PRESS THE TALK BUTTON.

1. Press the “REDIAL” button, and the display will show the last telephone number dialed.
2. If you want to delete this displayed telephone number, press the “DELETE” button once for each digit shown.
3. Press the “TALK” button. The number will scroll across the screen from left to right as it is dialed.

Flash

You can use your cordless telephone with special services such as Call Waiting or Three Way Conference (Special subscription from your local telephone company is required). During a telephone conversation, you may hear a tone or click, which indicates that you are receiving another call. To speak to the second caller and put the first call on Hold, press the “Flash” button. Press “Flash” again to return to the original call. You may also press the “Flash” button to obtain a new dial tone.

Receiver Volume Control

Your GH3150 allows you to adjust the handset volume to a more comfortable listening level. Press VOL/CID “▲” or “▼” keys on the handset to increase or decrease volume, while handset is in the Talk On mode. The volume status will show on LCD.




Page/Handset Locator

You can send a page signal from the base to the handset. Press the “PAGE” button on the BASE once, and the handset will beep for 2 minutes. Press the “TALK” button on the handset to stop the handset from beeping, and return to standby mode.

Low Battery Warning

- * When the handset battery voltage level is low, the handset LCD Display shows
- * “Low Battery” as follows:



- * Return the handset on the BASE unit for charging.

Caller ID Operation

Receiving a Call

1. After first ring, the caller’s name and telephone number will display on the handset.
2. The Caller ID information (of up to 40 callers) will be stored in the handset display in the order received. If the received call information is the same as any of the new calls, the unit will display the “REPT” icon to indicate a repeat call. If the unit receives more than 40 calls, the oldest Caller ID information will be erased.

Reviewing Calls

Reviewing New Call Records


1. When the handset is in standby mode, press the VOL/CID “▲” or “▼” keys on the handset to display the information
Note: You can review up to 40 new caller ID calls from the handset.
2. Continue pressing the VOL/CID “▲” or “▼” keys on the handset to review all new call records in the order the calls were received.

When a name received exceeds 15 characters, the first 15 characters will be shown.

When a telephone number exceeds 15 characters, the last 15 characters will be shown.

To Store Caller ID Record:

1. When the handset display is in standby mode, press the VOL/CID “▲” or “▼” side key on the handset to select the Caller ID record you want to store.
2. Press the “MEM” button on the handset.
3. The display will show “MEM#” as follows:



4. Enter the desired memory location.

Note: If the selected memory location is not empty, “REPLACE MEM?” will display on the LCD. Press “MEM” button to confirm the replacement. You will hear a confirmation beep. If you do not want to confirm the replacement, press “EXIT” to keep the previous record and return to standby mode.

Caller ID Redial

The GH3150 allows you to redial a phone number in the caller ID memory.

1. When the handset is in standby mode, press the VOL/CID “▲” or “▼” keys to select the Caller ID record that you want to dial.

Note: You can review and redial up to 40 Caller ID calls from the handset.

2. Press the “TALK” button on the handset. The number will scroll across the screen from left to right as it is dialed.

Note: If you review the Caller ID call from the handset, you will need to redial the call from the handset (by pressing the “TALK” button).

- With current Telecom redialing situations, there are 2 redial options: (1) 10 digits without a 1 prefix and (2) 10 digits with a 1 prefix.

10 digits without a 1: In some areas of the country, the area code must be included, even when dialing a local call. In this situation, simply press “TALK” button to dial out. You can press the FORMAT key to add a “1” prefix and your long distance call will be dialed out.

Caller ID Erase

To Erase a Caller ID Record:

1. When the handset is in standby mode, press the VOL/CID “▲” or “▼” keys to select the Caller ID record you want to erase.
2. Press the “DELETE” button to erase the call record; the display will show “DELETE CALL ID”
3. Press the “DELETE” button again; the Caller ID record will be deleted and the display will show the next call message.

Note: If the current displayed message is the last message to come in, then the display will show “NO CALLS”.

To Erase all Caller ID Records:

1. When the current display shows the handset name or handset number, press the VOL/CID “▲” or “▼” keys to review the Caller ID record.
2. Press and hold “DELETE” button to erase all call records; the display will show “DELETE ALL”
3. Press “DELETE” button again; all the Caller ID records will be deleted.

Answering System Operation

Base Control Operation

To turn Answering System ON

Press the ANSWER ON/OFF button on the base to turn on the answering system. The message counter on the base will turn on and the base unit will say “Answer On”. The message counter will display the current message number to indicate the system is in Answer ready mode.

Note: The first time the answering machine is connected to A/C power it will announce “Press Back Key for setup instructions.” You can press this key for setup help.

To turn Answering System OFF

Press the ANSWER ON/OFF button on the base to turn off the answering system. You will hear “Answer Off”, and the message counter on the base will turn off.

To check the DAY and TIME setting

1. Press and Release the DAY/CHECK button. The DAY and TIME setting will be announced.



To Set Day

1. Press and Hold the DAY/CHECK button until “Monday” is announced.
2. Continue to hold down the DAY/CHECK button, and the Days of the week will be announced one by one.
3. Release the button when the correct day is announced. The new day setting will repeat.

To Set Hour

1. Press the HOUR button until “12AM” is announced.
2. Continue to press the HOUR button and the hours will be announced in one hour increments (12PM, 1AM, 2AM, etc.)
3. Release HOUR button when the current hour AM/PM is announced.
4. The new setting will repeat.

To Set Minute

1. Press the MIN button until “00” is announced.
2. Press and hold MIN button to increase the minutes by increments of 5 (:05, :10, :15....:05).
Press and release MIN button to increase the minutes by increments of 1 (:00, :01, :02....:00).
3. Release MIN button when the new TIME setting is announced to confirm the setting.

To Set Remote Access Code

Remote access allows you to call in and listen to your messages from an outside line. The default remote access code is 123, but we recommend that you create your own code for security purposes. Follow these easy steps to set your own code.

1. Press “REMOTE/FORMAT” button on the handset
2. Press “*” button.
3. Key in your desired 3-digit security code.
4. Press “*” button again to confirm the code.
5. The new code you have set will be announced.

Recording Outgoing Greeting

Your system comes with a prerecorded outgoing greeting; “Please leave your message after the tone.”

1. Press and hold down the “Greeting” button.
2. After you hear one beep, speak clearly into microphone (located on front of the base). You have a maximum of 1 minute to record your greeting. Your recording time should not be less than 2 seconds.
3. When finished, release the “Greeting” button.
Note: If the unit beeps while you are recording your greeting, you have exceeded the 1 minute time limit. Record a shorter greeting.
4. Unit will beep once, playback your recorded outgoing greeting, and then reset to answer incoming calls.

Checking Your Outgoing Greeting

1. Press and release the “Greeting” button.
2. Your outgoing greeting will be played back to you, beep once, then reset to answer incoming calls.
3. Press and release the VOL/CID “▲” or “▼” button on the base to set the speaker to the desired sound level. You can check the current volume level in the base message counter.

Recording a Memo

1. Press and hold the “MEMO” button.
2. After the beep, record your message (up to 1 minute) through the microphone in the front of the base.
3. When your message is completed, release the “MEMO” button. The Base display message counter will indicate the revised message count. When a MEMO is recorded, your unit considers it as a standard message and will include it in the Base message count.
Note: When memory is full during recording, the unit will announce: “Memory is full.”

Ring Select

You can select the number of rings in which a call will be answered. Set the Ring Select switch (on the back of the base) to 2 or 6 rings, **Voice Activated Recording (VOX)**

Your GH3150 records messages for up to 1 minute as long as the caller speaks. To avoid unnecessary pauses due to hang-ups and to save message capacity, your unit will automatically stop recording after 7 seconds.

Message Playback Incoming Messages

The GH3150 can record up to 12 minutes of incoming messages. The maximum recording time for each incoming message is 1 minute. When the answering system is on and is ready to answer the calls, the base display will show the number of new messages and the total number of messages in memory (up to 99).

Note: The machine hangs up and resets to answer the next call in the following cases: the caller hangs up, the message length exceeds 1 minute, there are more than 7 seconds of silence or there is a steady tone (dial tone) for 7 seconds.

To Hear Your Messages

1. Press and release the “PLAY/STOP” button once.
The unit will playback the incoming or MEMO messages in the order they were received.
2. The day and time will be heard at the end of each message.
3. After all the messages have been played back, the unit will say “End of Message .” To erase all messages press and hold the “ERASE” button.
4. Unit will reset to answer incoming calls.

To Stop Playback of Incoming Messages

Press and release the “PLAY/STOP” button during message playing. Your unit will reset to answer incoming calls and will save all messages except those marked for deletion.

To Repeat the Current Message

During playback, press and quickly release BACK button.

To Playback the Previous Message

During playback, press and quickly release BACK button TWICE


To Skip to the Next Message

During playback, press the SKIP button once to skip to the next message.

Remote Handset Operation

To access your messages from the handset press the “ANS/FORMAT” key on the handset.

After entering the remote handset mode, the handset display will show:



The voice-prompted menu will give you the following options:

- 1) Press 7 to review the voice menu
- 2) Press 2 to play message and press 2 again to stop
- 3) Press 0 while playing a message to erase
- 4) Press 1 to review the previous message
- 5) Press 3 to skip message
- 6) Press 4 to turn the answering machine on/off
- 7) Press “EXIT/*” to disconnect/connect the answering machine

Line Remote Operation

To access your answering machine messages from an outside phone line, dial your phone number. After listening to the greeting, enter your 3-digit remote access code.

The voice-prompted menu will give you the following options:

- 1) Press 7 to review the prompted voice menu
- 2) Press 2 to play message and press 2 again to stop
- 3) Press 0 while playing a message to erase
- 4) Press 1 to review the previous message
- 5) Press 3 to skip message
- 6) Press 4 to turn the answering machine off

Belt Clip

You can hang the handset on your belt or pocket using the belt clip.

Optional Headset

Plugging an optional headset into the handset allows hands-free phone conversation.

When a headset is connected to the handset, be sure to speak into the headset microphone. If you want to return to normal conversation using the handset, then disconnect the headset.

For servicing or replacement, you can purchase a suitable headset through our service center or your local retailer.

For more information, contact the place of purchase, call Southwestern Bell Freedom Phone help line at 1-800-366-0937 or visit our website at <http://www.swbfreedomphone.com>.

Troubleshooting Guide

If you have followed the instructions in this manual, and have difficulty operating your Southwestern Bell Freedom Phone® Cordless Telephone, locate the PROBLEM ACTION columns to locate and remedy the problem.

Troubleshooting Guide (Cont.)

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
The unit will not operate.	Improper installation.	Recheck all plug connections. Also, check the DC adaptor for proper connection to wall outlet and phone base.
	The digital security code has been lost due to a power loss while the handset was away from the base.	Reset the digital security code by returning the handset to the base. A new code is set.
	The battery is not charged.	Charge the battery for about 10-14 hours before initial use or when the battery handset beeps in talk mode.
No dial tone.	See the above mentioned possible causes.	See above corrective actions.
	The handset is being used too far away from base.	Move the handset closer to the base.
Difficulty placing or receiving calls.	You may have lost the security code. The handset can no longer communicate with its base. The loss of the code can occur if the battery is drained and needs recharging, the DC adaptor is disconnected, a power loss occurred, or there is electrical interference from other cordless phones, baby monitors, microwaves, etc. Even a momentary power interruption could erase your cordless phone's security code.	1. Return the handset to the base unit for 5-10 seconds to reset code. If that doesn't work. 2. Check to make sure the DC adaptor is connected. 3. Unplug DC adaptor from power source, disconnect handset battery for 5 seconds, then reconnect, place handset back on base, then replug the DC adaptor.

Troubleshooting Guide (Cont.)

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Can't make outgoing calls.	Tone/Pulse setting is not set correctly.	Set the Tone/Pulse setting to proper position for your type of service.
	The digital security code has been lost.	Reset the security code returning the handset to the base.
Battery pack is not recharging.	The base and handset battery contacts are not in contact with each other.	Make certain the battery contacts in the handset and base make contact when handset rests in the base. The base IN USE/CHARGE LED will be lit.
	Battery pack needs to be replaced.	Replace the battery pack at least every year.
Noise or interference is being heard during your conversation.	Current channel is not the clearest choice.	Press the channel button to switch from one channel to another. This will allow you to choose the clearest of 40 channels.
During a conversation a loud static noise is heard.	The handset is being used too far away from the base.	Move the handset closer to the base station.
The handset only works close to the base.	The base antenna is not fully upright.	Make sure the base antenna is fully upright for the best result.
The incoming call's signal is intermittent or fades.	The battery is not charged.	Recharge the battery.
	The handset is being used too far away from the base.	Move the handset closer to the base.

Troubleshooting Guide (Cont.)

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Answering system will not operate.	You may have had a power failure.	Proceed with a unit reset (page28)
No answer	Unit is in the "ANSWER OFF" mode.	Check to verify the base display shows "A" or the message count. If not, press the ANSWER ON/OFF button to turn the unit on, until you hear "Answer ON".
	DC adaptor is disconnected from wall outlet or back of unit.	Reconnect DC adaptor into wall outlet and back of unit.
	Power to electrical outlet may be off.	Check to see if electrical outlet is controlled by a light switch and power is on. Wall outlet may not be functioning; try connecting to a different wall outlet.
	Telephone line is not connected to wall jack.	Connect telephone line into wall jack. Telephone wall jack may not be functioning; try connecting unit into a different telephone wall jack.
No incoming messages recorded.	Unit is in the "ANSWER OFF" mode.	Check to verify the base display shows the message count. If not, press the ANSWER ON/OFF button to turn the unit on, until you hear "Answer On".
	DC adaptor is disconnected from wall outlet or back of unit.	Reconnect unit into wall outlet or back of unit. Try connecting to a different wall outlet.
	Power to electrical outlet may be off.	Check to see if electrical outlet is controlled by a light switch and power is on.
	Telephone line is not connected to wall jack.	Connect telephone line into wall jack. Try connecting unit into a different telephone wall jack.

Troubleshooting Guide (Cont.)

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
No remote operation	DC adaptor is disconnected from wall outlet or back of unit.	Reconnect unit into wall outlet or back of unit. Try connecting to a different wall outlet.
	Power to electrical outlet may be off.	Check to see if electrical outlet is controlled by a light switch and power is on.
	The telephone you are calling from is not a standard touch-tone.	Try calling from a different location (e.g. pay phone).
	Telephone line is not connected to wall jack.	Connect telephone line into wall jack. Try connecting into a different telephone wall jack.
	Security code not entered correctly.	3 digit remote security code must be entered within ten seconds of the beep at the end of your outgoing greeting. Press and hold each digit for 2 seconds, allowing a minimum of 2 seconds between digits.
	Remote security code being used differs from the code you have set.	Press the "CH" buttons on the GH3150 handset to check the current set security code. (see page29)
The machine is cutting off incoming messages.	The outgoing greeting you are recording is too long.	Record a shorter outgoing greeting (between 2 and 60 seconds.)
	Incoming messages are too long.	Maximum recording time for incoming messages is 60 seconds.
	Caller may be pausing for more than 7 seconds.	Caller must speak continuously without any long pauses.

Troubleshooting Guide (Cont.)

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
Your telephone rings but the GH3150 doesn't show any Caller ID records.	The telephone line is not connected properly to the unit.	Connect the telephone line into the back of the unit. Check with your local telephone company to be sure Caller ID service is being provided on your telephone line. Also, if you pick up the phone before the first complete ring, the caller ID information will not be completely received.
You cannot redial a call record.	Your local area code is not programmed.	If the display does not indicate 7 digits for local incoming calls, reprogram the local area code.
	The number display is incorrect.	Verify the number displayed during redial. Data received were possibly corrupted during the transmission through the telephone lines. Dial the telephone number manually on your telephone.
You can't receive call waiting messages.	This service is not available.	You must subscribe to Caller ID, Call Waiting, as well as Call Waiting Caller ID service from your local phone company. The phone must be off-hook to hear the call waiting Caller ID alert signal.
The display screen is dim or blank.	The display contrast is set to too low of a level.	Press the handset "FLASH" and then the "▲*" or "#▼" button to adjust the handset contrast level.

FCC Wants You To Know

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXX. If requested, this number must be provided to the telephone company. You must, upon request, provide this information to your telephone company.

FCC compliant telephone cord and modular plug are provided with this equipment. This equipment is designed to be connected to the telephone network or premise wiring using a compatible modular jack which is Part 68 compliant. See installation instructions for details.

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five(5.0). To be certain of the number of devices that may be concerned to a line, as determined by the total RENs, contact the local telephone company. [For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.]

If your telephone equipment causes harm to the telephone network, the telephone company may discontinue your service temporarily. If possible, they will notify you in advance. But if advance notice isn't practical, you will be notified as soon as possible. You will be informed of your right to file a complaint with the FCC.

Your telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the proper functioning of your equipment. If they do, you will be notified in advance to give you an opportunity to maintain uninterrupted telephone service. If you experience trouble with this telephone equipment, disconnect from the network until the problem has been corrected or

until you are sure that the equipment is not malfunctioning.

This equipment may not be used on coin service provided by the telephone company.

Connection to party lines is subject to state tariffs.

This equipment is hearing aid compatible.

An applicable certification jacks Universal Service Order Codes (USOC) for the equipment is provided (i.e., RJ11C) in the packaging with each piece of approved terminal equipment.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTICE: If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this [GH3150] does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- * Reorient or relocate the receiving antenna.
- * Increase the separation between the equipment and receiver.
- * Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- * Consult the dealer or an experienced radio TV technician for help.

Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Privacy of communications may not be ensured when using this phone.

Product Care

- A. Avoid putting cordless phones near heating appliances and devices that generate electrical noise (motors, fluorescent lamps, etc.)
- B. Avoid rough treatment of the phone by placing the handset gently into the base when hanging up. Avoid dropping the handset.
- C. Clean your cordless telephone only with a soft cloth slightly dampened with water or mild hand soap. Do not use any type of solvent or abrasive cleaner. Before cleaning, always unplug the phone from the wall outlet.
- D. Retain the original packaging should you need to ship the phone at a later date.

Additional Information

- A. Connecting this telephone to a coin operated telephone or party line is prohibited by law.
- B. If it is determined that your telephone is malfunctioning, the FCC requires that it be disconnected from the modular outlet until the problem has been corrected.
For immediate answers to all your questions regarding the operation of your Southwestern Bell Freedom Phone, call the Customer Hotline, toll-free at (800)366-0937.

Service

According to FCC regulations, this equipment, which has been certified and registered by the FCC, may only be repaired by authorized persons. If repairs or adjustments are made by an unauthorized person, the FCC certification may be voided. Should you encounter any problems, please call the Southwestern Bell Freedom Phone® toll-free Customer Help Line for assistance: 1-800-366-0937, Monday - Friday 8:30 am - 9:00 pm, and Saturday 8:30 am - 12:30 pm. You can also visit our website at <http://www.swbfreedomphone.com>.

FOR IN-WARRANTY SERVICE:

Package your complete unit (including all adaptors, line cords, and other accessories) and ship the unit postage prepaid* and insured (for your protection) to:

SOUTHWESTERN BELL FREEDOM PHONE®

DEPT.:Warranty Repair 7475 N. Glen Harbor Blvd., Glendale, AZ 85307.

Be sure to include your return address, proof of purchase, a daytime phone number, \$9.50 for postage and handling*, and a brief explanation of your difficulties.

* NOTE: California residents need only provide proof of purchase and should call 1-800-366-0937 for shipping instructions.

FOR OUT-OF-WARRANTY SERVICE:

You may call our toll-free Help Line for the price of a replacement before returning your unit. Please follow all instructions for In-Warranty service (above) to return your unit, and mark the package: DEPT.: Out-of-Warranty.

If you have called and know the cost of your replacement, please include this information with your unit for prompt service.

Questions?

STOP...DON' T TAKE ME BACK TO THE STORE
LOOK...FOR THE TOLL-FREE "HELP" TELEPHONE

NUMBER.

LISTEN...AS THE EXPERTS TALK YOU THROUGH THE
PROBLEM.

For immediate answers to your questions regarding operation,
missing parts or installation, call the

SOUTHWESTERN BELL FREEDOM PHONE® HELP

LINE AT:

1-800-366-0937

<http://www.swbfreedomphone.com>

Limited Warranty

This Southwestern Bell Freedom Phone® is warranted to the original purchaser to be free from defects in materials and workmanship under normal installation, use, and service for a period of one(1) year from the date of purchase as shown on the purchaser's receipt.

The obligation of Southwestern Bell Freedom Phone Retail Sales under this warranty shall be limited to repair or replacement (at our option) during the warranty period of any part which proves defective in material or workmanship under normal installation, use, and service, provided the product is returned to Southwestern Bell Freedom Phone Retail Sales (address below) TRANSPORTATION CHARGES PREPAID (California residents call 1-800-366-0937 for shipping instructions). Products returned to us or to an Authorized Service Center must be accompanied by a copy of the purchase receipt.

In the absence of such purchase receipt, the warranty period shall be one (1) year from the date of manufacture. To obtain service under this warranty, return the defective product to the service center nearest you, together with your sales slip and \$9.50 for postage and han-

dling (California residents need only provide proof of purchase). You may also have other warranty rights which vary from state to state.

This warranty shall be invalid if the product is damaged as a result of defacement, misuse, abuse, neglect, accident, destruction, or alteration of the serial number, improper electrical voltages or currents, repair alteration or maintenance by any person or party other than our own service facility or an authorized Service Center, or any use in violation of instructions furnished by us.

This warranty is also rendered invalid if this product is removed from the country in which it was purchased, if it is used in a country in which it is not registered for use, and/or if it is used in a country for which it was not designed. Due to variations in telephone systems and communications laws, this product may be illegal for use in some countries. Southwestern Bell Freedom Phone Retail Sales assumes no responsibility for damages or penalties incurred resulting from the use of this product in a manner or location other than that from which it is intended.

This one-year limited warranty is in lieu of all other expressed warranties, obligations, or liabilities. ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE ONE-YEAR DURATION OF THIS WRITTEN LIMITED WARRANTY. SOME STATES DONOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

IN NO EVENT SHALL WE BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, WHATSOEVER.