

# emerald TS100/200/300

# Installation Manual

#### Notice

The information in this manual was current when published. The manufacturer reserves the right to revise and improve its products. All specifications are therefore subject to change without notice.

#### Copyright

Under copyright laws, the contents of this manual may not be copied, photocopied, reproduced, translated or reduced to any electronic medium or machine-readable form, in whole or in part, without prior written consent of © 2013 Tyco Security Products. All Rights Reserved.

#### Trademarks

The trademarks, logos, and service marks displayed on this document are registered in the United States (or other countries). Any misuse of the trademarks is strictly prohibited and Tyco Security Products will aggressively enforce its intellectual property rights to the fullest extent of the law, including pursuit of criminal prosecution wherever necessary. All trademarks not owned by Tyco Security Products are the property of their respective owners, and are used with permission or allowed under applicable laws.

Product offerings and specifications are subject to change without notice. Actual products may vary from photos. Not all products include all features. Availability varies by region. Contact your sales representative for more information.

#### Licence information

Your use of this product is governed by certain terms and conditions.

#### Support

If you require technical assistance using CEM products, please contact the CEM Support team using the following telephone number:

Telephone:+44(0)2890 456656

Email: cem.support@tycoint.com

- Please provide our support engineers with as much information as possible. This may include:
- Site name
- Product name and model
- CEM software version
- · Description of the problem

#### **Publication Date**

31st May 2014

#### Warning

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures

#### Warning

#### English

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### French

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada.

Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### Warning - For FCC Labelled emerald Terminals

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept an interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be colocated or operating in conjunction with any other antenna or transmitter.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Installation of this device shall be performed by a qualified person in accordance to all local regulations.

This system must be installed within the protected premise in accordance with the National Electrical Code (NFPA70), and the local authorities having jurisdiction.

Equipment changes or modifications without the approval of the party responsible for compliance could void the user's authority to operate the equipment and could create a hazardous condition.

CHAPTER 1 :

## Contents

1. Introduction	
Terminal specifications	
CEM emerald product codes	2
Terminal dimensions	
Part ratings	
Onboard memory	4
Terminal key component parts	
Simplified AC2000 Network Topology	6
Hardware Installation Process	
2. Mounting the Terminal	9
Preparing for mounting	9
Recommended tools	9
Opening the terminal	
Mounting the terminal back casing	11
3. Wiring the Terminal	13
Cabling requirements	
Ethernet host	
The Front Board	14
The Input/Output Board	
Wiring locks	
Wiring a voltage provided lock (internal power)	
Wiring a voltage not provided lock (external power)	
Output power switch	
Inputs not in use	
Terminal with Request to Exit Switch	
Configuration information	
Terminal with 3rd Party Wiegand Read Head	
Configuration information	
Terminal with S610s Exit Reader	
Configuration information	

Terminal with DILL 210	24
	25
	26
	27
PoE+ Terminal with S610s Exit Reader	28
	20
Tamper Detection on Reader Inputs	
Wiring the resistor network	
	30
Re-assembling the terminal	
4. Reader Network Configuration	
Checking emerald's Network Status	
Accessing the Configuration Menu	
Setting the terminal IP address, gateway and subnet mask	34
Network routing - (advanced users)	35
Testing the connection with the AC2000 server	35
5. AC2000 Software Configuration	37
Reader Addressing	37
Adding the device to AC2000	
Configuring a 3rd party read head	
Configuring Device Inputs	40
Adding an input alarm	40
Configuring 4 state tamper inputs	40
Editing emerald Entries in AC2000	41
Editing device properties	41
Editing a device input	
Deleting a device input	11
Input alarms	
Input alarms	
Input alarms	

	Assigning a remote application group to users45
	Next Steps
6.	The System Configuration Menu47
	Menu Overview
	Navigation
	Accessing the system configuration menu
	Device settings menu
	System Information menu
	Tests menu
-	
1.	Door Modes
	Door Mode
	Door mode timings
	Multi-swipe access
	Control Post Mode
	Software configuration for control post mode60
	Passenger Mode
	Configuring passenger mode in the software61
	The passenger mode cycle
	Lobby mode
	Interlock
	Wiring two terminals for interlock
	The interlock process in door mode
	The interlock process in passenger mode65
	Image on Swipe
	Enabling Image on swipe
	Configuring Image on swipe options
	Random checks
	Checking the firmware version of the terminal73
	Loading the firmware onto the terminal(s)73
	Updating the terminal
Ap	opendix I: Device Settings Remote Application
	Using the Application

Configuring the options
Appendix II: Broadcast and Timezone Priorities
Appendix III: Loading Card Definitions83
Appendix IV: Configuring a Third Party Reader as a Master
Appendix V: User Defined Logo
Licensing the emerald logo change function
Enabling the emerald logo change function on the CDC
Uploading a user defined Card Logo in AC2000 WEB

# Chapter 1 Introduction

emerald (TS100/200/300) is an intelligent access terminal that provides secure door control with optional intercom and Remote Applications for reporting and configuration.

Used as part of the AC2000 system, emerald controls access to restricted areas while giving the user a wide choice of information tools and applications at the door.



Figure 1 Photograph of the emerald terminal



### 1.1 Terminal specifications

emerald is available in three models; the TS100, TS200 and TS300.

Feature	TS100	TS200	TS300
Door access reader	✓	✓	✓
Maintenance information point	✓	✓	✓
Intercom		✓	✓
Remote Applications terminal			✓
Table	1: Terminal features		
Door access reader	Configured on an A access control at th nputs and triggerin	C2000 system to be door, including g alarms.	provide full monitoring
Maintenance information point	View terminal information including software version, network settings, door mode and database details.		
Intercom t	This facility provides a voice link between the terminal and AC2000 workstation via Voice over IP.		
Remote Applications terminal	Remote Applicatior nclude terminal, ca These Applications with appropriate pe	ns run on the AC2 ard swipe and ala can be accessed missions.	2000 server and rm reports. d by cardholders

### 1.1.1 CEM emerald product codes

Contact CEM sales for further information.

Card technology	TS100	TS200	TS300	Available in FCC/IC approved model
Mifare CSN	TSR/100/105	TSR/200/105	TSR/300/105	FCC: QABTSR105V910 IC: 12009A-TSR105V910
CEM Desfire	TSR/100/107	TSR/200/107	TSR/300/107	FCC: QABTSR105V910 IC: 12009A-TSR105V910
iClass/iClass SE	TSR/100/108	TSR/200/108	TSR/300/108	FCC: QABTSR608V930 IC: 12009A-TSR608V930
PicoPass	TSR/100/106	TSR/200/106	TSR/300/106	-
multi smart card reader	TSR/100/608	TSR/200/608	TSR/300/608	FCC: QABTSR608V930 IC: 12009A-TSR608V930

Table 2: List of CEM emerald product codes

#### Note

The typical read range for the internal 13.56Mhz head is 3 – 5cm



The appropriate card definitions must be loaded onto the CEM Central Database Computer (CDC). See Loading Card Definitions on page 83. If using Desfire EV1 cards not provided by CEM, please refer to the User Defined Keys manual to configure card keys.

### Using Desfire EV1

There are two different types of Desfire EV1 card. CEM can provide a personalised Desfire EV1 card, with pre-defined attributes or non-personalised Desfire EV1 cards can be used. If using non-personalised cards, the user should refer to the User Defined Keys manual to configure card keys.

### 1.1.2 Terminal dimensions



Figure 2 Illustration of emerald including dimensions

### 1.1.3 Part ratings

emerald has been tested and will work within the ranges specified in the table below.

Part	Rating	
emerald terminal	-20° to 70°C (-4° to 158°F) flame retardant polycarbonate, rated to IP65	
DC power (unit only)	12V nominal (10V – 14V) @500mA peak. (typically 300 - 400mA) <sup>a</sup>	
Power over Ethernet (PoE+)	15W - power to the terminal only. Lock and/or exit reader power should be supplied separately.	
Inputs	Four analog inputs - voltage supplied	
Comms to exit reader	RS485 serial comms	
Comms to system host	10/100 Base-T TCP/IP CAT5/5e/6	
Dry contact outputs	30vDC @ 5a	
Table 3: Table of part ratings		

a. If the power supply is less than 12V @ 500 mA a separate PSU is required to power the lock

### 1.1.4 Onboard memory

128MB RAM, 256MB NAND Flash

- Up to 250,000 cardholder records (off-line)
- Up to 50,000 transactions (off-line)

### 1.1.5 Terminal key component parts



Figure 3 Illustration of the key component parts

### Note

All emerald models use the same component parts.

### 1.2 Simplified AC2000 Network Topology



Figure 4 Basic illustration of a typical AC2000 network including emerald configurations

Important

The emerald terminal is only available as an ethernet device.

### 1.3 Hardware Installation Process



Figure 5 Hardware installation flow chart

#### CHAPTER 1: Introduction

# **Chapter 2** Mounting the Terminal

The emerald terminal can be mounted on a variety of standard electrical back boxes:

- UK single back box
- US single back box
- UK double back box mounted vertically
- 75mm VESA mount

### 2.1 Preparing for mounting

Care must be taken with the internal components when disassembling the terminal.

### 2.1.1 Recommended tools

- 3 mm flat head screwdriver for input / output connections and DC power
- Wire cutters and strippers
- Security hex screwdriver

Product	CEM Product Code
Security screw driver handle	HTO/000/001
Security screw driver bit	HTO/000/000

Table 4: Security screwdriver product codes

### 2.1.2 Opening the terminal



Take care not to strain the ribbon cable connecting the two halves of the terminal.



Figure 6 Opening the terminal

- 1. Set the terminal on a stable, level surface to reduce the risk of the front of the terminal falling when it is disconnected.
- 2. Remove the four screws using a security hex screwdriver.
- 3. Carefully lift the top casing away from the back of the terminal, pivoting as shown.
- 4. Disconnect the ribbon cable from the I/O board before commencing wiring.

### 2.1.3 Mounting the terminal back casing

To access the mounting screw positions of the terminal the Input/Output board must first be removed from the back box.



Figure 7 Exploded view illustration of the back casing and I/O board

- 1. Remove the four screws and spacers using a star head screwdriver.
- 2. Lift the I/O board away from the mountings.
- 3. Drill the back outer casing as required for cable access and back box mounting. (see Figure 8)
- 4. Fit the back casing to the back box.
- 5. Re-attach the input/output PCB to the back casing ensuring to replace the spacers.

### Drilling the back casing



Figure 8 emerald back casing drill hole dimensions

Mounting hole	Description
A	Generic positions for wall mounting. These holes are accessible when the I/O board is in place.
В	UK single back box.
С	US Single back box.
D	UK double back box mounted vertically.
E	75mm VESA mount.

Table 5: emerald mounting descriptions

# **Chapter 3** Wiring the Terminal

### 3.1 Cabling requirements

Table 6 on page 13 outlines recommended cabling requirements for each of the connectors on the emerald terminal.

Purpose	Recommended Cable	Connector
Power over Ethernet & ethernet comms	Cat 5/5e/6	RJ45
12V power supplied separately	Recommend using a CEM Door Interface Unit 210/230	14AWG Screw Terminal
Inputs	Belden 95XX or equivalent (XX = the number of pairs from 01 - 50)	14AWG Screw Terminal
Outputs	Belden 9462 or equivalent	14AWG Screw Terminal
Connection with exit reader or DIU	Belden 8723 (AWG22 shielded twisted 2-pair) or equivalent	14AWG Screw Terminal
Wiegand	Belden 9514 (7 x 22AWG), Alpha 1229C(9 x 22AWG) or equivalent	14AWG Screw Terminal

Table 6: Terminal installation cabling requirements

### 3.1.1 Ethernet host

Ethernet communications should be cabled & terminated for 100Base-T operation according to IN ANSI/TIA/EIA-568-A / TIA/EIA-568-B.

Туре	Cable	Connector	Location
Host	CAT5/CAT5e/CAT6 (PoE)	RJ45 Socket	Terminal board
Table 7: Ethernet host			

Due to limited space, additional care should be taken when using CAT6 connectors or CAT5 connectors with a strain relief boot at the terminal. There should be enough spare cable left within the enclosure/back box to allow a service engineer to open the terminal case without straining the RJ45 connector. Where the cable is subject to movement or vibration, stranded ethernet cable (and appropriate connectors) should be used.

### 3.2 The Front Board

The front PCB contains the main electronic components of the reader; it is also where ethernet communications must be connected.



Figure 9 Illustration of the front board

Component	Description
A. Reset button	Used to hard reboot the terminal.
B. PoE Indicator LED	Green indicates that the terminal is using PoE.
C. Optional DC12V	12V power can be supplied to the terminal using this connector, however it is recommended that power be supplied via the I/O board.
D. RJ45 connector	Used to ethernet communications and also for Power over Ethernet when being used.
E. Ribbon connector	Links the front PCB to the I/O PCB.
F. 12V power LED	Red indicates DC12V power is being supplied to the board
G. Battery backed clock link	This link is fitted at the factory. If the link is removed the reader will not store the current time & date; card transactions may fail die to a mismatch in time/date.
H. Ethernet activity LED	Flashing green indicates ethernet activity
I. Network link LED	Orange indicates 100baseT connection speed. Unlit indicates 10baseT connection speed.
J Tamper switch	Used to trigger an alarm when the case is opened.
	Table 8: Description of front board components

### 3.3 The Input/Output Board

The input/output board provides connections points for terminal power, inputs, outputs,3rd party Wiegand read heads, communications with exit readers and door interface units.



#### Figure 10 Illustration of the Input/Output board

Component	Description	
A. Wiegand interface	Interface for third party exit heads using Wiegand protocol.	
B. Output 0 switch	Switches output 0 between internal 12V provided and voltage not provided relay that uses external power.	
C. DC12V	12V power, either from a CEM Door Interface Unit or an appropriate power source is supplied via this connector.	
D. Output 0	Lock output, either 12V provided by the terminal or 12/24V provided externally via the relay.	
E. Ribbon connector	Links the I/O PCB to the front PCB.	
F. Output 1	Spare output. The output is also used when configuring the reader in interlock mode.	
G. Output 1 switch	Switches output 1 between internal 12V provided and voltage not provided relay that uses external power.	
H. Comms to exit/DIU	Serial communications to a CEM exit reader such as the S610s or a Door Interface Unit	
I. Input connectors	Connection points for monitored inputs such as door position, lock sense and request to exit switches.	
	Table 9: Description of I/O board components	

CEM SYSTEMS

### 3.4 Wiring locks

The terminal supports lock types rated 12-24V at 1.5A max current if using an external power supply. It is recommended that the lock is powered by an external power supply as this provides the most flexibility. However if required, internal power to a lock can be provided at 12V, 650mA max current.

### 3.4.1 Wiring a voltage provided lock (internal power)

Only12V locks can be wired to be powered internally by the terminal. When internal power is utilised it is possible to connect locks in a fail safe or fail secure configuration.

#### Note

The maximum current that can be supplied is 1.5A using an external power supply or 650mA from the internal supply.

#### Fail safe lock

The fail safe configuration means that in the event of a power loss to the terminal the lock will open allowing free access. A lock that is constantly powered such as a maglock must be used.



Figure 11 Illustration of wiring for a fail safe lock

#### Fail secure lock

The fail secure configuration means that in the event of a power loss to the terminal the lock will remain secure. A lock that requires power to open such as a shear lock must be used.



Figure 12 Illustration of wiring for a fail secure lock

### 3.4.2 Wiring a voltage not provided lock (external power)



When using 24V power for a lock, it is imperative that the switch position is set to **EXT**. Setting the switch to **INT** will result in 24V being supplied to the terminal which may cause irreversible damage.

This is the recommended wiring configuration when locks require 24V or more than 650mA.



Figure 13 Illustration of wiring for lock with external power provided

### 3.4.3 Output power switch

Each of the two outputs has a switch that allows power to be provided to the output from the terminal's internal power circuit or by an external power source.

#### External power

When the switch is set to **EXT** a separate DC12 - 24V power source must be used to provide power for any locks or other devices such as sounders attached to the output.

#### Internal power

When the switch is set to **INT**, DC12V 650mA max current in total is provided to the lock or other devices attached to the outputs from the terminal's internal power circuitry.



The terminal's 12V connectors all link to the same circuit, powering the terminal and any outputs set to **INT**. It is imperative that before attaching 24V to power an output checks should be made that the relevant output switch is set to **EXT**. Applying 24V to an output with the switch set to **INT** will result in 24V being supplied to the common power circuitry, potentially damaging the terminal.

### 3.4.4 Inputs not in use

Some inputs must be linked out when not in use, to prevent alarms being generated on the system. These are:

- Input 0 door position sensor
- Fire input on a Door Interface Unit
- Tamper input on a Door Interface Unit
- Break Glass input on a Door Interface Unit







Figure 14 emerald master terminal with REX wiring diagram

### 3.6 Configuration information

Wiring an emerald terminal with a request to exit switch is the most basic wiring configuration and is not recommended for use on high security doors.

#### Input configuration

The table below illustrates the configuration and operation of the inputs on the terminal when configured with a Request to Exit switch.

Input number	Input function	Default input trigger state change
0	Door position	short => open
1	Lock position	short => open
2	Request to exit	switch open => momentary short => open
3	Spare/Interlock	short => open

Table 10: emerald and request to exit switch input configuration

#### Note

Wiring diagram is for the installation of the emerald terminal in **Door Mode**.





Figure 15 emerald master terminal with Wiegand read head wiring

### 3.8 Configuration information

The emerald terminal facilitates the use of a third party exit Wiegand head with three LEDs.

### Supported third party read heads

CEM support the use of HID R10 heads for reading Mifare and iClass cards.

Product	CEM Product Code
HID iClass SE R10 SmartCard Reader	HDS/053/010
HID iClass SE R30 SmartCard Reader	HDS/053/030
HID iClass SE R40 SmartCard Reader	HDS/053/040

Table 11: Read head product code

#### Note

The sounder functionality of third party read heads is not supported.

#### Typical Wiegand read head wiring

For specific read head wiring consult the third party manufacturer.

I/O board connection	Typical HID colour
GND	Black
Sounder	Not Supported
Green LED	Orange
Amber LED	Not fitted
Red LED	Brown
Data 1	White
Data 0	Green
Head 12V	Red

Table 12: Typical Wiegand head wiring



For proper regulatory compliance, the drain wire should be disconnected at the power supplied end of the cable.

#### Input configuration

The table below illustrates the configuration and operation of the inputs on the terminal when configured with a third party Wiegand read head.

Input number	Input function	Default input trigger state change
0	Door position	short => open
1	Lock position	short => open
2	Request to exit	switch open => momentary short => open
3	Spare / Interlock	short => open

Table 13: emerald and 3rd party read head input configuration

#### Note

To configure a Slave reader as the Master reader, refer to the Appendix on page 85.

### 3.9 Terminal with S610s Exit Reader



Figure 16 emerald master terminal with S610s exit reader

### 3.9.1 Configuration information

Using a CEM S610s exit reader provides a higher level of security at the door than using a third party read head.

Product	CEM Product Code
S610s Card Reader (Mifare CSN)	RDR/612/105
S610s Card Reader (DESfire)	RDR/612/107
S610s Card Reader (iClass)	RDR/612/108
S610s Card Reader (Pico Pass)	RDR/612/106

Table 14: S610s product code

### Input configuration

The S610s reader has four inputs and two relay outputs which are spare in this configuration.

Input number	Input location	Input function	Default input trigger state change
0	Master terminal	Door position	short => open
1	Master terminal	Lock position	short => open
2	Master terminal	Request to exit	switch open => momentary short => open
3	Master terminal	Spare / Interlock	short => open
4	S610s exit	Spare	normally open
5	S610s exit	Spare	normally open
6	S610s exit	Spare	normally open
7	S610s exit	Spare	normally open

Table 15: emerald and S610s exit reader input configuration







### 3.10.1 Configuration information

Using a CEM DIU210 provides the highest level of security at a door, removing power for the lock and input monitoring away from the door reader.

Product	CEM Product Code
DIU 200 (Compact board only DIU module)	DIU/700/200
DIU 210 Full DIU incl Enclosure/PSU (Does not include backup batteries)	DIU/700/210

Table 16: Door Interface Units product code



The DIU210 uses mains electricity and should only be installed by qualified personnel.

#### Input configuration

When a DIU210 is used with a terminal, the DIU controls the main CEM reserved inputs and the inputs on the readers become spare. The exception to this is input three on the terminal (input B in Table 6 on page 13) which maintains its status as being used for interlock mode.

Input number	Input location	Input function	Default input trigger state change
0	DIU	Door position	short => open
1	DIU	Lock position	short => open
2	DIU	Request to exit	switch open => momentary short => open
3	DIU	Break glass	short => open
4	DIU	Fire	short => open
5	DIU	Mains power fail	Internally triggered
6	DIU	Battery low	Internally triggered
7	DIU	DIU tamper	short => open
8	Master terminal	Spare	short => open
9	Master terminal	Spare	short => open
A	Master terminal	Spare	short => open
В	Master terminal	Spare / Interlock	short => open
С	Exit reader	Spare	normally open
D	Exit reader	Spare	normally open
E	Exit reader	Spare	normally open
F	Exit reader	Spare	normally open

Table 17: emerald and DIU210 input configuration



If a decision has been made not to connect a fire and break glass units to the DIU the inputs must be linked out to ensure that the DIU functions normally. The tamper input must also be linked out when not in use to prevent alarms being generated on AC2000.

### 3.11 Terminal with DIU 230



Figure 18 emerald terminal with DIU 230 wiring

### 3.11.1 Configuration information

Using a CEM DIU230 provides the highest level of security at a door, removing power for the lock and input monitoring away from the door reader. The DIU is a PoE+ device and does not require specialist electrical qualifications to install.

Product	CEM Product Code
DIU 230 PoE+ (board only)	DIU/700/230
DIU 230 PoE+ (with enclosure)	DIU/700/231

Table 18: DIU230 product codes

#### Input configuration

When a DIU230 is used with a emerald terminal, the DIU controls the main CEM reserved inputs and the inputs on the readers become spare. The exception to this is input three on the emerald terminal (input B in the table below) which maintains its status as being used for interlock mode..

Input number	Input location	Input function	Default input trigger state change
0	DIU	Door position	short => open
1	DIU	Lock position	short => open
2	DIU	Request to exit	switch open => momentary short => open
3	DIU	Fire	short => open
4	DIU	Breakglass	short => open
5	DIU	Mains power fail	Internally triggered
6	DIU	Battery low	Internally triggered
7	DIU	DIU tamper	short => open
8	Master terminal	Spare	short => open
9	Master terminal	Spare	short => open
A	Master terminal	Spare	short => open
В	Master terminal	Spare / Interlock	short => open
С	Exit reader	Spare	normally open
D	Exit reader	Spare	normally open
E	Exit reader	Spare	normally open
F	Exit reader	Spare	normally open

Table 19: emerald and DIU230 input configuration



If a decision has been made not to connect a fire and break glass units to the DIU the inputs must be linked out to ensure that the DIU functions normally. The tamper input must also be linked out when not in use to prevent alarms being generated on AC2000.



### 3.12 PoE+ Terminal with S610s Exit Reader

Figure 19 PoE emerald with S610s exit reader wiring
# 3.12.1 Configuration



When powering the emerald terminal using PoE+, the total peak current draw of the attached door furniture must not exceed 840mA.

Using a CEM S610s exit reader provides a higher level of security at the door than using a third party read head.

Product	CEM Product Code
S610s Card Reader (Mifare CSN)	RDR/612/105
S610s Card Reader (DESfire)	RDR/612/107
S610s Card Reader (iClass)	RDR/612/108
S610s Card Reader (Pico Pass)	RDR/612/106

Table 20: S610s product code

### Input configuration

The S610s reader has four inputs and two relay outputs which are spare in this configuration.

Input number	Input location	Input function	Default input trigger state change
0	Master terminal	Door position	short => open
1	Master terminal	Lock position	short => open
2	Master terminal	Request to exit	switch open => momentary short => open
3	Master terminal	Spare / Interlock	short => open
4	S610s exit	Spare	normally open
5	S610s exit	Spare	normally open
6	S610s exit	Spare	normally open
7	S610s exit	Spare	normally open

Table 21: emerald and S610s exit reader input configuration

# 3.13 Tamper Detection on Reader Inputs

Terminal inputs can be monitored for four state tampering, open, close, tamper short and tamper cut. If an input is tampered with an alarm will be triggered in the AC2000 software. The alarm is a universal tamper alarm and does not distinguish between the four different states. In order to monitor inputs for tamper short and tamper cut, a resistor network must be installed on the input sensor wiring and the AC2000 software configured to monitor the input.

## 3.13.1 Wiring the resistor network



Figure 20 Illustration of the resistor network for four state tamper detection on inputs

# Important

It is imperative that the tamper resistor network is wired as close to the sensor as possible.

### 3.13.2 Configuring software for tamper detection

- 1. From the Floatbar select Device Configuration | Devices.
- 2. Select the device on which inputs are to be configured for four state tamper detection.
- 3. Select the **Configuration** tab.
- 4. Select the Input Config tab.
- 5. Select each input element to be configured for four state and tick the 4 state checkbox.
- 6. Click Save.

## 3.13.3 Re-assembling the terminal

- 1. Ensure that there is adequate cable length available to reach the connectors comfortably for each of the following:
  - 12vDC
  - Cat5e/6 cable for communications and / or PoE
  - Output wiring for lock
  - Wiring for inputs e.g. door position sensor, lock sense

# Important

To maintain the terminal's IP65 rating, the cable access hole should be adequately sealed before completing the installation process.

- 2. Attach the front pane of the terminal via the ribbon connector.
- 3. Attach the front of the terminal to the back casing and fix in places with the screws.
- 4. Attach the protective side panels to the terminal.

### Note

If the terminal needs to be open after installation, the side panels can be removed by inserting a 5 mm flat head screwdriver into the slot under the centre of the panel and sliding along the length of the panel.



This page is intentionally blank.

# **Chapter 4** Reader Network Configuration

The network settings are accessed via the installer configuration menu on the terminal.

# 4.1 Checking emerald's Network Status

1. Tap the Reader Address. The network status indicator is displayed for eight seconds.



Figure 21 Checking the network status

Each section of the status indicator represents a different aspect of the network connectivity. The presence or absence of a block indicates whether or not the connection is good.



Figure 22 The network status indicator

# 4.2 Accessing the Configuration Menu

- 1. Slowly swipe a finger across the date/time from left to right.
- 2. When prompted to enter passcode type 67679999.



Figure 23 Accessing the configuration menu

### Note

Once the terminal has received a configuration from the server this passcode will be changed to 67670000. The final four digits of this PIN are configurable for the terminal in the **Devices** application, see section 6.3 Accessing the system configuration menu on page 48.

### 4.2.1 Setting the terminal IP address, gateway and subnet mask

1. From the **Config Menu** press **Device settings | Network**.



Figure 24 Configuring the terminal network settings

- 2. Press the IP address field, type the address and press OK.
- 3. Press the SubNet mask field, type address and press OK.
- 4. Press the Gateway field, type the address and press OK.
- 5. Press Done to close the Network menu.

Don

4

8

<x

^

## 4.2.2 Network routing - (advanced users)

The emerald terminal needs to be able to communicate with the Central Database Computer (CDC) and the Real Time Computer (RTC). If a network is fragmented, and the reader, CDC and RTC are on different parts of the network it may be necessary to route communications to the RTC. In this situation contact the site network administrator.

TSR settings	Done
🖄 Device settings	۸
🎠 Routing	Λ
Network	
SubNet mask	
Gateway	

- 1. From the **Configuration Menu** press **Device Settings | Routing**.
- 2. Press the **Network** field, type the network IP address and touch **OK**.
- 3. Press the **SubNet mask** field, type address and touch **OK**.
- 4. Press the **Gateway** field, type the address and press **OK**.
- 5. Touch **Done** to close the menu.

Figure 25 The routing menu

## 4.2.3 Testing the connection with the AC2000 server

The terminal can be used to test the connectivity with the AC2000 server via a PING utility.

- 1. From the Configuration Menu press Tests | Network tests
- 2. Press the **Ping address** field below **Ping Other**.

TSR settings	Done		TSR se	ttings	
🧼 Tests	۸		V Te	sts	
Setwork tests	٨			etwork	test
Ping Intercom			Pi	ng Interco	m
Ping any			Pi	ng any	
Ping address			Ping a	ddress	172
			1	2	3
			5	6	7
			9	0	
			ок	Can	

Figure 26 Testing the connection with the AC2000 server

- 3. Type the IP address of the AC2000 server (CDC/RTC) and press OK.
- 4. Press Ping Any.
  - i. If a response is received from the pinged address the **Ping Any** button will turn green.
  - ii. If no response is received from the address the Ping Any button will turn red.
- 5. The PING utility can be used to check connectivity to any device on the network.

This page is intentionally blank.

# Chapter 5 AC2000 Software Configuration

This section of the manual focuses on the initial addition and configuration of the device and input alarms. All other advanced configuration options will be covered in the relevant function sections. The emerald terminal is added to the AC2000 system and configured using the **Devices** application.

### Note

This manual assumes access to the necessary AC2000 applications and should be performed by person(s) trained in its use.

## 5.1 Reader Addressing

The AC2000 system communicates with all devices on the access control network using the CEM reader addressing system.

All devices are allocated a five digit reader address, the address is displayed in the top right of the terminal display.



Figure 27 Location of the reader address on the screen

Each digit of the reader address signifies a position on the Devices application hierarchy.



Figure 28 Illustration describing AC2000 reader addressing

# 5.2 Adding the device to AC2000

- 1. From the AC2000 Floatbar open Device Configuration | Devices.
- 2. Select the controller and device group to which the device is to be added.
- 3. Right click the device group and select **Add Device**.

Settings		
Device type	TS300 •	Maintenance mode 🗌
Configuration mode	TS300 •	Restricted reader
Device number	1 -	Device address 00110
Device location	Back door	
	Priorit	y of alarms (0 - 8999) 0
extended properties		
MAC address	00:30:46:A1:22:ED	
IP address	172.21.166.22	
Offline Database	Card Number, Timezone, Status, Pin	•
Threat level propertie	s	
Threat group	(none) 🔻	

Figure 29 The add device dialogue with example terminal information

- 4. Select the **Device Type** TS100, TS200 or TS300 from the drop down menu.<sup>1</sup>
- 5. Select the **Configuration Mode** TS 100/200/300 from the dropdown list.<sup>2</sup>
- 6. Select a **Device Number** for the device.
- 7. Enter a unique Device Location description for the device
- 8. Where a slave device has been included in the Device Type, enter a unique **Slave Location** description for the Slave device.
- 9. Enter the unique Mac Address of the device.
  - This is found in the System information | Network on the emerald terminal.
- 10. Enter the unique IP address of the device.
- 11. Click Add. The terminal is now added to the AC2000 system.

#### Note

Threat groups are only used if threat levels have been activated on AC2000. For further information consult the **AC2000 Threat Levels** manual.

<sup>1.</sup>If an exit or auxiliary device is added to the master reader, ensure to select the correct type, i.e. A TS100 device with an Exit Reader would have a Device Type of TS100+Slave. This will configure the Master device with an attached slave device.

Any exit reader added to a master will appear as a child node in the Overview Pane of the master reader it is associated with.

<sup>2.</sup> The configuration mode contains default settings, however these can be user defined. To create a configuration mode refer to the AC2000 User Guide.

## 5.2.1 Configuring a 3rd party read head

After following the instructions in Adding the device to AC2000 on page 38, a **Slave** added to a master reader is configured as slave reader by default. To configure the **Slave** to be a read head only, perform the following steps:

1. From the AC2000 Floatbar, open Device Configuration | Devices.



Configuration tab

Slave reader enabled

Figure 30 3rd party read head configuration

- 2. Select the device (with associated slave) to be configured.
- 3. Select the Configuration tab.
- 4. Select the **Common** tab.
- 5. Select Slave Settings from the list in the main pane.
- 6. In the **Options** pane at the bottom of the interface, make sure that the **Slave reader enabled** checkbox is not ticked.
- 7. Select Save.

The Slave associated with the master device is now configured as a 3rd party read head and not a Slave reader.

# 5.3 Configuring Device Inputs

If inputs are to be used to trigger alarms or events in the AC2000 software they must be first be configured in the **Devices** application.

## 5.3.1 Adding an input alarm

- 1. From the AC2000 Floatbar select Device Configuration | Devices.
- 2. Select the device to configure from the overview pane.
- 3. Select the **Inputs** tab at the top of the **main pane**.
- 4. Click Add in the main pane.

1	Add input				~
	Input 0	Open state			
puts –	Input 1	Location			
	Input 2	Back door			
I	Input 3	Broadcast	Туре	Pulse time	
		(none)	• (none)	- (secs)	
		Alarm			
larm –		Door forced	•		
pe		Close state			
•		Location			
		Back door			
		Broadcast	Туре	Pulse time	
		(none)	• (none)	··· (secs)	
		Alarm			
		Door closed	•		
		Tamper state Location			
		Broadcast	Туре	Pulse time	
		(none)	* (none)	(secs)	
		Alarm			
		C			

Figure 31 Adding inputs dialog with example input 0 configuration

- 5. Select the **Input** from the list on the left which is to be configured.
- 6. Check the box next to the **State name**, this will enable the associated fields.
- 7. Select the Alarm which will be triggered on the change of state.
- 8. Click **Save** to save the Device Inputs configuration.

### 5.3.2 Configuring 4 state tamper inputs

- 1. Select the Configuration tab.
- 2. Select the Input Config tab.
- 3. Select each input element to be configured for four state and tick the 4 state checkbox.
- 4. Click Save.

# 5.4 Editing emerald Entries in AC2000

The following instructions are only required if the settings need to be edited during or after terminal installation.

## 5.4.1 Editing device properties

- 1. Select the master device in the **overview pane**.
- 2. Make the required changes and click **Save**.

## 5.4.2 Editing a device input

- 1. Select the Input and the Input State that is to be edited from the Device Inputs
- 2. Click **Save** when changes have been completed.

### Note

Save is only displayed when a change has been made.

## 5.4.3 Deleting a device input

- 1. Select the input from the **Device Inputs** list.
- 2. Click Delete.

### Note

Care should be taken when deleting an input as no warning message will appear.

### 5.4.4 Input alarms

The following section contains input tables describing the set-up for each of the emerald configurations outlined in this manual, including the AC2000 alarms that should be selected for each sensor state where appropriate:

Input table for emerald with REX and emerald with third party read head:

Input number	Input function	Sensor state	AED alarm
0	Door position	Open	Door forced
		Closed	Door closed
1	Lock position	Open	Lock not engaged
		Closed	Lock engaged
2	Request to exit		No default
3	Spare / interlock		No default

Table 22: emerald and REX / Third party read head input alarms



Input number	Input function	Sensor state	AED alarm
0	Door position	Open	Door forced
		Closed	Door closed
1	Lock position	Open	Lock not engaged
		Closed	Lock engaged
2	Request to exit		No default
3	Spare / interlock		No default
4	Spare		No default
5	Spare		No default
6	Spare		No default
7	Spare		No default

Input table for emerald with S610s exit reader:

Table 23: emerald and S610s exit reader input alarms

Input table for emerald with DIU210 and S610s exit reader:

Input number	Input function	Sensor state	AED alarm
0	Door position	Open	Door forced
		Closed	Door closed
1	Lock position	Open	Lock not engaged
		Closed	Lock engaged
2	Request to exit		No default
3	Break glass	Open	Breakglass
		Closed	Breakglass reset
4	Fire	Open	Fire alarm
		Closed	Fire alarm reset
5	Mains power fail	Open	Mains power fail
		Closed	Mains OK
6	Battery low	Open	DIU battery low
7	DIU tamper switch	Open	DIU tamper
8	Spare		No default
9	Spare		No default
A	Spare		No default
В	Spare / interlock		No default
С	Spare		No default
D	Spare		No default
E	Spare		No default
F	Spare		No default

Table 24: emerald and DIU210 input alarms

Input number	Input function	Sensor state	AED alarm
0	Door position	Open	Door forced
		Closed	Door closed
1	Lock position	Open	Lock not engaged
		Closed	Lock engaged
2	Request to exit		No default
3	Fire	Open	Fire alarm
		Closed	Fire alarm reset
4	Break glass	Open	Break glass
		Closed	Break glass reset
5	Mains power fail	Open	Mains power fail
		Closed	Mains OK
6	Battery low	Open	DIU battery low
7	DIU tamper switch	Open	DIU tamper
8	Spare		No default
9	Spare		No default
A	Spare		No default
В	Spare / interlock		No default
С	Spare		No default
D	Spare		No default
E	Spare		No default
F	Spare		No default

Input table for emerald with DIU230 and S610s exit reader:

Table 25: emerald with DIU230 and S610s input alarms

Input table for four state tamper configuration:

Input number	Input function	Sensor state	AED alarm
0	Door position	Open	Door forced
		Closed	Door closed
		Tamper	Input Tamper
1	Lock position	Open	Lock not engaged
		Closed	Lock engaged
		Tamper	Input Tamper

Table 26: Input table for four state tamper configuration

# 5.5 Assigning Remote Applications (TS300 model only)

To assign Remote Applications to users open **AC2000 WEB** by typing the IP address of the AC2000 CDC into a browser and select **System | Utilities | Remote Apps Allocation** 

Three steps must be taken in order to assign Remote Applications. First, a group or groups are created by user type and then Remote Applications are added to the group. The final step is to select the cardholder's record in the **AC2000 Personnel** application and assign the Remote Application Group to the user.

#### Note

For further information about setting up Remote Applications on the terminals consult the **AC2000 Web** manual.

### 5.5.1 Creating groups

To create a Group of Remote Applications:

- 1. Select the Add Group button.
- In the text box enter a Group Name and click the ADD button. (A Group Name could refer to user types, e.g, Support, Managers, Engineers.) If appropriate tick the Default Group check box to make the group the default setting in the Personnel Application.
- 3. Press the Return button.

### 5.5.2 Adding remote applications to groups

To add Remote Applications to a group ensure the group name is selected in the **Group** drop down list.



Figure 32 Adding Remote Applications to groups

- 1. Select a Remote Application or Applications by clicking on them in the blue pane (this moves it to the grey pane, placing it in the selected **Group**).
- 2. Click Save.

## 5.5.3 Assigning a remote application group to users

To assign a Remote Application Group to a cardholder:

- 1. Open AC2000SE | Enrolment | Personnel
- 2. Edit the cardholder's record and select the appropriate listing from the **Remote App. Group** drop down list.

Card Details	User Fields	Curronnac	
	Remote App Group	(none)	
Badge Name	Fred Baker	CARDHOLDER	Remote
Card Format *	Staff Card Format	ENGINEER SECURITY	App Group
Access Level *	Manager Access Level	ALL THE TIME	drop down
Has Extra Access	Has Limited Usage Creation Date	10 February 2014	list
Start Date *	10 February 2014 Expiry Date *	09 February 2015	
Parking Exemption	Exemption Date	Card Parked	
PIN *	7308 Special Usage Card Status *	Current	
Last Device	Last Time Statu	s Options <options></options>	

Figure 33 Assigning Remote Application Group in Personnel

### Note

If the **Remote App Group** drop down list is not visible in the **Personnel** interface, the option has not yet been enabled. To enable this option, open the **Configured** application and scroll to **remote\_app\_group\_enabled** in the main pane. Type **Y** in the **Value** field and click **Save**. The Remote App Group will now display as an option in Personnel records.

3. Click **Save Changes** button. The cardholder can now access the Remote Applications on the terminal.

## 5.6 Next Steps

Congratulations! The emerald terminal is now fully installed. The remainder of the manual details how to perform more advanced, complex tasks with the terminal including:

- Using the system configuration menu to view maintenance information and perform terminal tests
- Configuring the terminal in additional modes such as passenger mode and control post.
- Upgrading terminal firmware
- Configuring device settings using the Device Settings Remote Application



Advanced configuration of the terminal should only be carried out by users that have completed CEM AC2000 installer training.

This page is intentionally blank.

# Chapter 6

# The System Configuration Menu

emerald utilises an intuitive Graphical User Interface to access terminal functionality. At the basic level, the screen is used to display meaningful messages regarding the current card swipe transaction. The more advanced options allow the user to access information and reports that are relevant to them.

The emerald touch screen is a high quality capacitive screen, which is highly responsive in multiple weather conditions. The reader interface provides access to a variety of tools, reports and information such as:

- Terminal configuration options
- Diagnostics and tests
- Software and hardware versions
- User specific Remote Applications

## 6.1 Menu Overview



Figure 34 Overview of the system configuration menu

# 6.2 Navigation

Menus on the Touchscreen terminal are accessed by touching the menu option to expand.

• Menus are expanded and closed by pressing the menu name or the arrow.



Figure 35 Expanding and closing reader menus

# 6.3 Accessing the system configuration menu

To access the configuration menu:

- 1. Slowly swipe a finger across the date/time from left to right.
- 2. When prompted to enter passcode type 6767000.

#### Note

See Accessing the Configuration Menu on page 34 for more details on passcodes..







### Configuring the passcode

The final four digits of the passcode can be changed to a site or reader specific code.

1. Open the **Device** application and select the reader.

- 2. Select Configuration | Other | Diagnostic Pin.
- 3. Type the new PIN into the text field.
- 4. Click Save.

The system configuration menu has three sub-menus, each of which contains specific terminal maintenance functions.



Figure 37 The system configuration menu

## 6.3.1 Device settings menu

The **Device Settings** menu is used to configure network and LCD settings.



Figure 38 The device settings menu

### Network

The Network menu is used to configure the network settings for the terminal.



Figure 39 The Network menu

### Routing

The emerald terminal needs to be able to communicate with the Central Database Computer (CDC) and the Real Time Computer (RTC). If a network is fragmented and the reader, CDC and RTC are on different parts of the network, it may be necessary to route communications to the RTC. In this situation, contact the site network administrator.



Figure 40 The Routing menu

### Options

The **Options** menu is used to change the LCD brightness and update the terminal's onboard cardholder database.



Figure 41 The Options menu



## 6.3.2 System Information menu

This menu contains information about the device including network, firmware version, database and configuration.



When contacting CEM support with any issues, this information may be asked for.



### Network

The Network information section details all of the terminal network settings.

Info	Description
CEM address	The CEM reader address of the terminal.
IP address	The IP address of the terminal.
Subnet mask	The subnet mask of the network hosting the terminal.
Default gateway	The IP address of the gateway server.
MAC address	The MAC address of the terminal.
RTC address	The IP address of the RTC controlling the terminal.
VOIP server	The IP address of the VOIP server for intercom functionality.
VOIP help station	Intercom station number. This number is used to allow an intercom workstation to communicate with the terminal.

Table 27: Terminal network information descriptions

### Versions

The Versions information section details all hardware and software versions of the terminal.

Eirmware version
User interface version
Date of last firmware update
Time of last firmware update on the S/W Date
Version of the terminal hardware
Serial number of the terminal
Linux kernel version, including date and time.
Version of Qt library used by the UI.

Table 28: Terminal versions information descriptions

### Database

The Database information section details the information about the onboard card database.

Info	Description
CEM address	The CEM reader address of the terminal.
Coldstart count	Record of the number of times the terminal has been coldstarted.
Last coldstarted	Date and time of the terminal's last coldstart.
Card count	Number of active cards held on the reader.
Last updated	Date and time of the last database update from the server.
Trans all count	Displays the number of buffered transactions and alarm events (in offline mode). This is cleared when the terminal next goes online.
Trans card count	Displays the number of buffered transactions only (in offline mode). This is cleared when the terminal next goes online.
Last configured	Displays the date and time that the terminal last received configuration data from the server.

Table 29: Terminal database information descriptions

### Configuration

The **Configuration** menu provides information about terminal door modes.

Info	Description
Door mode	Indicates the current door mode of the terminal. <b>Standard Door</b> , <b>Control Post</b> , or <b>Passenger</b> mode.
PIN only TZ	Displays a number to indicate which timezone is allocated as a PIN only timezone.
Card only TZ	Displays a number to indicate which timezone is allocated as a Card only timezone
Door override TZ	Displays a number to indicate which timezone is allocated as a Door override timezone
Locked out TZ	Displays a number to indicate which timezone is allocated as a Locked out timezone
	Table 30: Terminal configuration information descriptions

### Unit information

The Unit information section provides information regarding the status of the terminal.

Info	Description
Tamper sensor	Describes the status of the internal tamper switch.
Run time	Information about the running time and load of the terminal.
Main comms	Indicates the status of the main comms.
Database engine	Indicates the status of the database engine.
Local inputs	Indicates the status of the local inputs such as door position, lock sense etc.
Main reader	Indicates the status of the emerald master terminal.
Door interface	Indicates whether a door interface unit is currently connected to the emerald terminal.
2nd reader	Indicates whether an exit reader is currently connected to the terminal.

Table 31: Terminal unit information descriptions

## 6.3.3 Tests menu

The emerald terminal has built in tests that can be performed to check specific functionality.



When contacting CEM support with any issues, these tests may be requested.



Figure 42 The tests menu

### Input tests

The default **Input tests** screen displays the four terminal input states. When peripherals such as an exit reader or door interface unit are attached to the terminal, their inputs will also be displayed on the screen.



Figure 43 The input tests screen

#### Two state input test

When an input has been wired in a 2 state open and closed configuration only the **Open** and **Short** tests can be administered.

Open - The input is opened.

Short - The input is closed.

#### Four state input test

When an input has been wired in a 4 state configuration as described in section 3.13.1 on page 30, all four input state tests can be administered.

**Open** - Indicates a tamper cut condition.

Opened - The input is open.

Closed - The input is closed.

Short - Indicates a tamper short condition.

### Network tests

The **Network tests** screen provides PING tests to check connectivity with the intercom server and with any other provided IP address.



Figure 44 Terminal network tests

There are two possible responses for the ping utilities:

- Red: No response received
- Green: Response received

# Chapter 7 Door Modes

The emerald terminal can be configured to function in different modes other than the standard door mode described in the main section of the manual. The door modes are:

- Door mode including:
  - Interlock
  - Multi-swipe
- Control post
- Passenger mode including:
  - Interlock

## 7.1 Door Mode

Door mode is the normal terminal configuration that is described in the main installation section of this manual. It allows a terminal to control access to a door and monitor specific inputs associated with that door.

### 7.1.1 Door mode timings

When a valid card is presented at a terminal in door mode, a chain of events takes place which is dictated by specific settings in the **Devices** application. These timings are configurable in the **Devices** application and also on the terminal itself.

The door open cycle.



#### Figure 45 Illustration of typical door timings

- 1. The card is swiped at the terminal and access granted.
- 2. Lock power is dropped for a period of time known as **Lock open time**. (Five second default) If the door is not opened by the end of this time, the lock re-engages.
- 3. After the door is opened by the cardholder the lock power remains off for a period of time to prevent the lock re-engaging and closing the door before it is fully opened. This is the **Lock open time 2**. (One second default)
- 4. The door is closed. If the door remains open longer than the **Door close after** time a door held alarm will be generated on the terminal and the AC2000 system. (Default 15 seconds)

Configuring the timings in the devices application

- 1. From the Floatbar open Device Configuration | Devices.
- 2. Select the terminal from the list and open the **Configuration** panel.
- 3. Open the **Common** panel.

	Properties Inputs Configur	ation		Edit Mode				
	Common Input Config Ir	put Levels Other Outputs	Time Zones All					
<b>0 1 1 1</b>	Element	Default	Current					
Select the	Lock open time	5	5					
timing which _	Door close after	15	15					
is to be	Passenger time	3	3					
amended	Lock open time 2	1	1					
	Master PIN enable							
	Slave settings							
	Door mode							
	Remote Apps							
	Workstation Group	0	0					
	Lock open time	Lock open time						
	Time lock is opened for on	Time lock is opened for on valid transaction						
	Current value 5	Current value 5 (1 - 32767)						
	Options							
	<ul> <li>Options</li> </ul>				seconds			
	Options				seconds			
	~ Options				seconds			
	← Options ───				seconds			
	~ Options				seconds			
	Options				seconds			
	- Options			Save Cancel	seconds			

Figure 46 Updating the door cycle timings

### Note

Configuration of other timings is covered in the appendices of this manual.

### 7.1.2 Multi-swipe access

The emerald terminal can be configured to require swipes from up to five valid cards before granting access. This is configured using the **Device** application. Once this setting is

configured, an initial valid swipe will prompt a request for further valid swipes on the screen before opening the door. Once all valid cards are swiped the terminal will grant access.



Figure 47 Multi-swipe request screen and access granted screen

The multi-card swipe screen will show the number of valid cards required to grant access, up to a maximum of five cards. As each valid card is swiped a card image will move into the box until all the required cards are swiped and access is granted.

Software configuration for multi-swipe access

- 1. From the Floatbar open Device Configuration | Devices.
- 2. Select the terminal from the list and open the Configuration panel.
- 3. Open the Other panel.

ſ	00010 - Entrance				
	Properties Inputs Configura	ation		Edit Mode	
	Common Input Config In	put Levels Other Outp	outs Time Zones All		
	Element	Default	Current		
	Configuration status				
	Backlight timeout				
	LED on time	4	4		
	PIN time	5	5		
	Alarm time	9	9	=	
	Debounce time	1	1		
	Second swipe action				
	Close time	3	3		
	Global PIN	1234	1234		
Select Multi	Pre Alarm	3	3		
swine mode	Multi swipe mode			-	
Swipe mode	Multi cwino modo				
	Multi swipe mode				Place a tick
Select the	Current value 2562	Fnable options			in Enable
maximum					ontions
	Options				options
wait time	10 seconds	<ul> <li>3 swipes</li> </ul>	•		
between					
swipes					
-					
				Save Cancel	
		Select th of swipes to open -	l e number s required · max 5	Click Save	

Figure 48 Configuring multi-swipe access

# 7.2 Control Post Mode

Control post mode places the terminal into a state where cards are swiped at a terminal with no door equipment present. The terminal acknowledges the card but performs no other action.

Transaction logs are still maintained and all events can be observed in real time via the **Rolling Transaction Display** application.

Note

All inputs may still be used as general purpose inputs and can be configured to trigger alarms on the AC2000 software.

### 7.2.1 Software configuration for control post mode

- 1. From the Floatbar open Device Configuration | Devices.
- 2. Select the terminal from the list and open the **Configuration** panel.
- 3. Open the **Common** panel.

	00010 - Entrance				
	Properties Inputs Config	uration		Edit Mode	
	Common Input Config	Input Levels Other Out	puts Time Zones All		
	Element	Default	Current		
	Lock open time	5	5		
	Door close after	15	15		
	Passenger time	3	3		
	Lock open time 2	1	1		
	Master PIN enable				
elect Door	Slave settings				
	Door mode				
lode	Remote Apps				
	Workstation Group	0	0		
Select Control post	Door mode Door mode Current value O Options Control post	✓ Enable options-			Place — in Er optio
				Save Cancel	

Figure 49 Configuring control post mode

# 7.3 Passenger Mode

Passenger mode enables a door to stay open for a longer period of time when swiped with a special usage card. This configuration is frequently used in airports to allow the free access of passengers through the door.

### 7.3.1 Configuring passenger mode in the software

The terminal must be configured in passenger mode and cardholders allocated special usage.

Configuring the terminal as a passenger mode terminal

- 1. From the Floatbar open Device Configuration | Devices.
- 2. Select the terminal from the list and open the **Configuration** panel.
- 3. Select the **Common** tab.

	00010 - Entr	ance					
	Properties Inpu	uts Configuration				Edit Mode	
	Common Inp	out Config Input Le	evels Other Output	s Time Zones A	All		
	E	lement	Default	Cu	rrent		
	Lock open tin	ne	5	5			
	Door close af	ter	15	15			
	Passenger tin	ne	3	3			
	Lock open tin	ne 2	1	1			
	Master PIN e	nable					
Select Door	Slave settings	;					
mode i	Door mode						
	Remote Apps						
	Workstation	Group	0	0			
	Door mode						
	Door mode						Place a tick
	Current value	5	Enable options				in Enable
Select	Options						options
Bassanger -	Passenger		-				•
Fassenger	(russenger						
					Save	Cancel	
					Click Save	•	

Figure 50 Configuring passenger mode

Adding special access to a cardholder

- 1. From the Floatbar open Enrolment | Personnel.
- 2. Search for the cardholder to which the special access is to be applied.
- 3. Click the Edit button.



Figure 51 Adding special usage to a cardholder record

- 4. Place a tick in Special Usage.
- 5. Click Save.

## 7.3.2 The passenger mode cycle



Figure 52 Illustration of passenger mode timing

- 1. A card with special usage allocated is swiped at a passenger mode terminal.
- 2. The terminal prompts whether **Staff Access** is required or **Passenger ops**. Selecting staff access causes the terminal to act as in **Door Mode**.
- 3. Cardholder selects Passenger ops.



Figure 53 Pressing the passenger ops button

- 4. Lock power is dropped for a period of time known as **Lock open time**. (Five sec default) If the door is not opened by the end of this time the lock re-engages.
- After the door is opened the lock power remains off for a period of time to prevent the lock re-engaging and closing the door before it is fully opened. This is the Lock open time 2. (One sec default)
- 6. The terminal now enters **Passenger Mode** and the door may be held open for the period of time as defined in the **Passenger time** before an alarm sounds. (Three min default)
- 7. **Passenger Mode** is deactivate by either: closing the door or swiping a valid special usage card and selecting **Cancel Access**. This places the terminal back into **Door Mode**.

## 7.3.3 Lobby mode

Lobby mode is a combination of passenger mode and interlocking terminals. Two terminals may be interlocked directly or more than two terminals may be interlocked via a third party logic controller or interposing relays.

In lobby mode, as long as one door is open in passenger mode, interlocked doors will be locked down to passengers but may be accessed with a valid card swipe.

# 7.4 Interlock

Interlocking terminals are linked together so that only one terminal will open its door at any given time. This is achieved using a combination of wiring and software configuration. Interlocking between two terminals is achieved using a simple wiring configuration, however interlocking more than two terminals requires the use of a third party logic controller or interposing relay system.



Figure 54 Wiring two terminals for interlock

Software configuration for interlock

- 1. From the Floatbar open Device Configuration | Devices.
- 2. Select the terminal from the list and open the Configuration panel.

3. Open the Input Config panel.

	00010 - Entrance			
	Properties Inputs Configuratio	n		Edit Mode
	Common Input Config Input	Levels Other Outputs Time 2	Zones All	
	Element Input 0 - Config Input 1 - Config	Default	Current	
Select Input 3 - Config (Input B	Input 2 Config Input 3 - Config Input 3 - Config Input inversion			
with DiO)	Input 3 - Config Output configuration for input			
	Current value 67 Options	Enable options		Remove the
	✓ Local output disabled	Remote output disabled	Normal input	check from Normal Input
			Save	Cancel
			Click Sav	е

Figure 55 Configuring input 3 for interlock

4. Open the **Other** tab.

	00010 - Entrance			
	Properties Inputs Configurati	on		Edit Mode
	Common Input Config Inpu	ut Levels Other Outputs	Time Zones All	
Select Second – swipe action	Element Configuration status Backlight timeout LED on time PIN time Alarm time Debounce time Second swipe action Close time Global PIN Pre Alarm Multi swipe mode Second swipe action Action to be taken on a secon	Default           4           5           9           1           3           1234           3           dswipe	Current 4 5 9 1 3 1234 3	
Place a tick in Make relay <u></u> 0 active	Current value 132 Coptions Ignore card swipes Make relay 0 active No passenger mode on exit	No access on inter	lock Do not end mo or mode Fire R1 on faile	ide on close d access
	Place a	a tick in No on Interlock	Click	Save

Figure 56 Configuring interlock functionality
# 7.4.2 The interlock process in door mode

Interlock is configured and works the same way in **Passenger Mode** and **Door Mode**, with only a slight change to end functionality.



- 1. The spare outputs of terminals are linked to input 3 of the other interlocked terminals.
- 2. When input 3 of the terminal is closed the terminal remains idle.
- 3. When a valid card is swiped at an interlocked terminal, both outputs on the terminal change to the open state. This drops lock power at the swiped terminal and simultaneously opens input 3 on any interlocked terminals.
- 4. Interlocked terminals lock down and display the lockdown message.
- 5. The interlock function ends when the original swiped door is closed.

Figure 57 Interlock locked down display message in door mode

# 7.4.3 The interlock process in passenger mode

- 1. The spare outputs of terminals are linked to input 3 of the other interlocked terminals.
- 2. When input 3 of the terminal is closed the terminal remains idle.
- 3. When a valid card is swiped at an interlocked terminal, both outputs on the terminal change to the open state. This drops lock power at the swiped terminal and simultaneously opens input 3 on any interlocked terminals.



 The swiped terminal displays a countdown screen showing the time that the doors will remain interlocked. (Passenger time in the Devices application)

Figure 58 Passenger mode countdown on the swiped terminal



Figure 59 Interlock no passenger access message in passenger mode



If using a third party logic controller to control multiple doors, the interlock principles remain the same. The spare output opens on a valid special usage swipe and input 3 is opened on interlock terminals to trigger lock down.

5. The interlocked terminals with input 3 now open will lock down, preventing access until the swiped door is closed or the mode ended. Interlocked terminals will display a no passenger access message. Normal card access is allowed.

# 7.5 Image on Swipe

**Image on swipe** is enabled/disabled within **Pre Door Mode** configuration. When a cardholder swipes a card on an emerald reader which has **Image on swipe** enabled, the cardholder's image is displayed on the screen. A security guard monitoring the reader will confirm if the image on screen resembles the cardholder and select the green tick button to authorise access or the red X button to deny access.



If Image on swipe and Checklists are both enabled, Checklists can no longer be used.

## 7.5.1 Enabling Image on swipe

From the AC2000 Floatbar select Device Configuration | Devices.

- 1. Select the device from the list on the left that is to be configured.
- 2. <u>Select the Configuration tab.</u>
- 3. <u>Select the Common tab.</u>
- 4. Select Pre Door Mode from the list.



#### Image on swipe option

Figure 60 Enabling/disabling Pre Door Mode

5. In the Configuration panel, select the Enable options tick box to enable Pre Door Mode.

#### Note

Enabling Pre Door Mode activates the associated Options.

- 6. From the Options, select the Image on swipe checkbox.
- 7. Press Save to save all changes.

# 7.5.2 Configuring Image on swipe options

When **Image on swipe** is enabled and a cardholder presents a valid card at the emerald reader, their cardholder details are displayed below the image. The details displayed are determined by settings in the **Configured** application in AC2000.

1. From the AC2000 floatbar select Advanced Configuration | Configuration.



Figure 61 Configuring Image on swipe settings

- 2. Select the **image\_on\_swipe\_image\_time** field. This is the length of time the image will display on the emerald reader and it is counted in milliseconds.
- 3. Type a Value e.g. 2500 (2.5 seconds).
- 4. Select the **image\_on\_swipe\_max\_size** field. This is the maximum image size in MB that can be uploaded to display on the emerald reader. If the image is larger than this value, an image placeholder is displayed. To ensure the image displays correctly, use a lower value on slower network connections.
- 5. Type a **Value** e.g. 100000
- 6. Select the **image\_on\_swipe\_options** field.
- 7. Type a **Value**. The default value is 01011111. The following table displays an example of the default **Value** for the **Image\_on\_swipe\_options** field. If a value is enabled it will display when the user swipes a card at the emerald reader. If the value is disabled it will not appear on the reader when a card is swiped.

RC	COMP	EXP	JOB	FN	SN	YN	IMG
Random check	Company	Expiry date	Job title	First name	Surname	Confirmation buttons (Yes/No)	lmage display
0	1	0	1	1	1	1	1
Disabled	Enabled	Disabled	Enabled	Enabled	Enabled	Enabled	Enabled

Example of the deafult value for the Image\_on\_swipe\_options field

Table 32: Example of the default value for the Image\_on\_swipe\_options field

#### Note

For more information on random checks, see section 7.5.2 Random Checks in this manual.

- 8. Select the **image\_on\_swipe\_random\_msg** field. This is the message that is displayed when the cardholder swipes a valid card on the emerald reader when they have been selected for a random check.
- 9. Type a **Value** e.g. send for drugs test.

The next time that a card is swiped on the reader which has had the **Image on Swipe** function activated, the image associated with that card will display on the emerald screen. Tapping the green tick on the screen indicates that the image on screen resembles the cardholder and access is granted. Tapping the red X indicates that the image does not resemble the cardholder and access is denied.



Figure 62 Image on Swipe display on screen

#### Viewing cardholder details

There are several options available for viewing the cardholder information on the emerald screen. Use a sequence of tapping the image to view the information as described below:

- To view the image and cardholder details, tap the image once
- To view a smaller image and a larger text display, tap the image twice
- To view a larger image and minimal text display tap the image three times
- To view more cardholder details in the list below the image, press and hold your finger on the screen and drag the text area in a scrolling motion

# 7.5.3 Random checks

In certain situations, it may be necessary to perform other checks in addition to authenticating a cardholder's card and confirming their identity as previously described. If appropriate, your system administrator should implement this procedure and configure the system accordingly.

Example: A system administrator configures the system to prompt security guards using an emerald reader that some cardholders need to be tested for drugs. When a cardholder who has been selected for a random check swipes on a reader, a message will display on the emerald screen stating the required action.

#### Note

The prompt displayed can be configured to read something other than **Drugs test**. For example a construction site may prompt a security guard to **Check PPE** (Personal protective equipment) for adherence to company policy, or an airport might use the **Search** prompt to manage search ratios. The system administrator will advise you regarding procedures for the configured prompts.

#### Confirming the random check completion

When a cardholder is selected to receive a random check, the date when they are selected is displayed in the **Spare date1** field in the cardholder's records in **Personnel**. A new set of cardholders are selected for a random check every day and the date entry on the personnel file indicates the date that each cardholder was selected.

	4 Personnel							
	File Export Person	nel View Card Biometric Help						
	式 Extra Access	🛱 Limit Urage 💆 🛛 Unpark 🕡 Pi	irk History	Validate 😽	Notes	Permits R	Trace 📇	Print Pass
			Add Mode					
	Personnel Deta	ils: (" denotes compulsory field)				System Inform	mation:	
	Sumame*	SMITH	Forenames	BARRY		- Per Serial		
	Address 1	125 AIRPORT ROAD WES	Date of Birth	18 July 1984		- Ste	HOME - Home site	2 V
Dereenal	Address 2	BELFAST	Payroll Num	123456		- Partition	Default partition	×
Personner	Address 3		Job Title	SUPPORT ENINGIN	EER	Traced	□ Referred	Г
record	Postcode	8765 7PQ	Contact Num	02838123654		<ul> <li>BIO Captured</li> </ul>	Permits	
record	Company*	CEM - CEM SYSTEMS	*	Gender	Male	<ul> <li>Home Site Info</li> </ul>	emation	
dotaile	Department	SUPPORT	Email BASME	THØCEM.COM		Home Senal		
uetalis			Added by	cem		Company		
	Card Details	User Fields				Card Format	1	
	Spare Text1		Spare Text2			-		
	Source Text 2		Source Textal			_		
			apart four					
Spare Date1	Spare Date1	10 June 2014	Spare Date2			-		
	Space Num1		Searce Num?	_				
			open courts					
	A Partition Number: 1	: Name: Default partition			1	Server:CDC0	User.cem	22:54

Figure 63 Personnel record dislaying Spare Date1

The person who executes the random check (ie. security guard or medical nurse) must have access to the **Personnel** application in AC2000 so that this date field can be cleared, upon successful completion of the random check. Failure to do so will cause the random check prompt to be displayed every time the cardholder swipes their card from that point in time on.

To clear the message prompt following successful completion of the random check:

- 1. Open a workstation and log in to AC2000.
- 2. From the Floatbar, select Enrolment | Personnel.
- 3. Locate the cardholder:
  - a. Select Search.
  - b. Enter any appropriate search criteria (eg. name).
  - c. Select Query Database.

- d. If no search criteria is entered, acknowledge the warning message that is displayed by selecting **Ignore**.
- e. Use the navigation arrows to locate the correct cardholder record from results returned from the search (if required).
- 4. From the Database Toolbar, select **Edit**.
- 5. Click on the User Fields tab.
- 6. Delete the date entry in the **Spare date1** field.
- 7. Select Save.

The random check prompt has now been cleared from the cardholder's **Personnel** record.

This page is intentionally blank.

# **Appendix I: Updating Firmware**

Updating the emerald terminal firmware (device defrosting) is accomplished by using the AC2000 web pages to load the firmware pack on to the terminal and then manually updating the terminal.



This process should only be carried out by an AC2000 administrator with relevant permissions.

# Checking the firmware version of the terminal

Press and hold the reader address

The firmware version is displayed for as long as the press is held on the reader address



Figure 64 Checking the terminal firmware version

### Loading the firmware onto the terminal(s)

- 1. Obtain the firmware pack from CEM and save to an accessible location on the network.
- 2. Log into the web pages by opening a web browser.
- 3. Enter the Server IP Address, e.g.

#### https://192.168.1.10

If the IP address has been changed from the default, enter the new IP address.

- 4. Enter the username and password.
- 5. Click Login.
- 6. Select AC2000 WEB | Reader Setup | Device Defrost
- 7. Click **Browse** and select the device image file (.pak) that is to be loaded.

#### Note

This image will be provided by CEM support and should be saved in a secure location.

- 8. Click Upload
- 9. Click OK.



	Select the firmware image	
Firmware File	tsr0_14_01.pak -	
Device Type	TS100/200/300 👻	Select the device type to be
Devices	00010 - Main Entrance 00100 - Rear Entrance 00400 - Support server room	firmware file type
	00A20 - Support Back Exit 00A20 - Support ACT TS	Select the devices to be defrosted.
		Hold Ctrl + click multiple devices if required.
		Ensure that the selected devices are of the correct type.
	DEFROST	

Click defrost to complete the process

Figure 65 Selecting devices to defrost

A message will appear similar to the following:

Initiating defrost to device:XXXX with firmware file:<filename>

# Updating the terminal

Once the terminal has received the firmware file, the reader address will be displayed in cyan instead of white.



Figure 66 Cyan reader address

- 1. Access the terminal System Configuration menu.
- 2. Open Device settings | Options.
- 3. Press Upgrade.



**Figure 67** Upgrading the terminal firmware The reader will update and reboot.

#### Note

The reader will go offline momentarily whilst the upgrade takes place.

# Appendix II: Device Settings Remote Application

The **Device Settings** Remote Application is used to adjust specific terminal settings that would ordinarily be carried out in the **Devices** application of AC2000.

#### Note

For information about configuring Remote Applications see the emerald User Guide.

### Using the Application

- 1. Using a card which has the relevant permissions to access the **Device Settings** Remote Application, press the **Remote Applications** icon and swipe the card when requested.
- 2. Press the **Device Settings** icon to open the application.

The configurable options are displayed in a two page list. The user can navigate between pages by tapping the **Next page** or **Previous page** buttons. The number of pages in the list are indicated by the number of dots between the **Next page** and **Previous page** buttons. The filled dot represents the one currently in view on the screen.



Figure 68 The device settings remote application

- 3. Tap the option to be adjusted to open settings editor mode
- 4. Configure the settings as required (See Configuring the options).
- 5. Press the **Save** button to save changes made to each setting.

#### Note

In settings editor mode, a **Save changes** button is displayed at the top of the screen and the symbol on the back button becomes red to indicate that going back without pressing **Save changes** will cause any changes made to be lost.

# Configuring the options

There are nine options that may be configured via this application. All changes made on the terminal are saved on the AC2000 server. After changes are made, press the save button.

#### Lock open time

Lock open time sets the length of time in seconds that the lock power will drop when a valid card is swiped.

Figure 69 Configuring the lock open time



#### Door close after

Door close after time sets the length of time in seconds that the door may be held open after a valid card swipe before a door held alarm is generated.





#### **Passenger time**

Passenger time sets the length of time in minutes that the door may be held open in passenger mode before a door held alarm is generated.



Figure 71 Configuring the passenger time

#### Lock open time 2

Lock open time 2 sets the length of time in seconds that the lock power remains off after the door is opened to prevent the lock accidentally re-engaging.





#### Second swipe action

Second swipe action is used to enable an alternative action within a door mode e.g. If a reader is in **Passenger mode** and **Disable special door mode is enabled**, using a special card as a second swipe will disable interlock mode and the door will remain open for the specified time.

✓ indicates that the setting is enabled

X indicates that the setting is disabled



Figure 73 Configuring second swipe action

#### **Master PIN enable**

Enable the PIN controlled access at the terminal.

- ✓ indicates that the setting is enabled
- X indicates that the setting is disabled

Master PIN enable	/-	- Ta
	🗸 🖌	ΡI
Keypad enabled	V -	-Ta
	📈 🗸	tei
Scramble keypad	¥ -	_Ta
	- 👗 🖌	sc

Tap to enable/disable master PIN settings Tap to enable/disable the terminal keypad Tap to enable/disable a scrambled keypad as an additional security measure

Figure 74 Configuring the master PIN settings

#### **Slave settings**

Toggle settings for any connected slave devices.

✓ indicates that the setting is enabled

X indicates that the setting is disabled



Figure 75 Configuring the slave settings

#### Door mode

The door mode option is used to toggle between the available door modes:

- Door mode
- Control post
- Passenger mode

✓ indicates that door setting mode is enabled

X indicates that door setting mode is disabled



Figure 76 Configuring the door mode setting

#### **Remote Applications**

The Remote Applications option is used to enable/disable Remote Application functionality for the terminal.

✓ indicates that the setting is enabled

**X** indicates that the setting is disabled

the terminal



Figure 77 Configuring the remote applications setting

#### Workstation group

The workstation group option is used to assign an intercom workstation group to the terminal. The terminal intercom function can only communicate with workstations assigned the same workstation group number.



Figure 78 Configuring the workstation number setting

#### Pre Door Mode

The Pre Door Mode option is used to enable/disable Pre Door Mode functionality for the terminal, including Image on Swipe.

 $\checkmark$  indicates that the setting is enabled

X indicates that the setting is disabled



Figure 79 Configuring the Pre Door Mode setting



# Appendix III: Broadcast and Timezone Priorities

A state machine is used to determine the priority that different events such as broadcast and timezone changes have on the terminal. The order is listed below in descending priority:

- 1. Broadcast open
- 2. Interlock input
- 3. Locked out TZ (timezone)
- 4. Door override TZ (timezone)
- 5. Card only TZ (timezone)
- 6. PIN only TZ (timezone)

#### Example

If there is an overlap between the **Locked out TZ** and the **Card only TZ**, the **Locked out TZ** will take priority due to it being higher up the list. Once the **Locked out TZ** ends the **Card only TZ** will take over.

Regardless of which state the terminal is in, a **Broadcast open** will open the door, overriding all other options.

#### Note

For more information on **Timezones** consult the **AC2000 Setup Guide**, and for information about **Broadcasts** consult the **AC2000 Operator Guide**.



# **Appendix IV: Loading Card Definitions**

In order for AC2000 to correctly process the information encoded on the smart cards the correct card definitions must be loaded onto the CDC. These are loaded via the AC2000 Web pages.

- 1. Log into the AC2000 client software. This is done to allow access to the definition files on the CDC.
- 2. Log into the web pages by opening a web browser.
- 3. Enter the Server IP Address, e.g.

#### https://192.168.1.10

If the IP address has been changed from the default, enter the new IP address.

- 4. Enter the username and password.
- 5. Click Login.
- 6. Select AC2000 WEB |System | Software Update
- 7. Click Browse and navigate to Z:\\card\_defs\patches.
- 8. Select the device image file (.cpio.bz) that is to be loaded.



Figure 80 Card definition file list

- 9. Click Upload
- 10. Click OK.

# Appendix V: Configuring a Third Party Reader as a Master

It is possible to configure an emerald with a third party read head as a master reader. This configuration may be used in a system where two card technologies are in use and it is necessary to have two read head technologies on the same side of a door. An exit request (REX) switch may be used to control egress via the same door.



Figure 81 Possible system configurations

#### Hardware installation

For detailed wiring information, please refer to the following sections:

- Terminal with 3rd Party Wiegand Read Head on page 20
- Terminal with Request to Exit Switch on page 18

#### Software configuring

- 1. From the Floatbar open Device Configuration | Devices.
- 2. Follow the procedure for adding a TS100/TS200/TS300 device as described in Adding the device to AC2000 on page 38.

#### Note

In the **Configuration** tab, ensure that the **Door mode** is set to **Control Post**.

- 3. Once the device is added, select it from the list and open the **Configuration** panel.
- 4. Open the **Common** panel.

	Common panel		Configura panel	ation				
A Devices						1	- D @ x	
🥹 Exit 🔂 Action	🦒 Templates 🍕 Batch	update 🔎 Search 🍕 B	atch import		0	Device licer	nses 🕢 Help	
AC2000     AC2000     AC2000     Device group     Device group     Device group     Device group	RTC00 ON CDC	00200 - Reception In Properties Inputs Broadcast	Configuration Notes				Erowse Mode	
III 0020-1     III 0020-1     IIII 0020-1     IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII	inception In 9 3 9 4 9 5 9 9 9 9 9 9 9 0 9 0 9 0 9 0 9 0	Common and a set of the set	0 creater Contra Conjust Default 5 15 3 1 0 0 ○ Enable options Slave reader enable	S 15 3 1	Current	teypad enabled	d	- Slave settings
<u>.</u>		Use Slave as Master checkbox				Save	}	

Figure 82 Setting slave as master reader

- 5. Select **Slave settings** from the panel list.
- 6. Check the option Use Slave as Master.

#### Note

If **Use Slave as Master** does not appear in the **Options** pane, please contact CEM Support to obtain the relevant CDC patch file, which after application, will cause the **Use Slave as Master** option to be displayed.

7. Click **Save** to save all changes made.

# **Appendix F: User Defined Logo**

The **Card Logo** function is used to display a user defined logo on the emerald terminal. This logo replaces the default CEM logo that appears on the dancing card on the main emerald screen.



Figure 83 Replacing existing dancing card logo with a user defined logo

To display a Card Logo on the emerald terminal, it must be uploaded using AC2000 WEB.

## Licensing the emerald logo change function

- 1. Log into AC2000 Web.
- 2. Navigate to AC2000 Setup | Licensing.



Figure 84 Licensing code entry field

#### Note

If you do not have a license, contact CEM quoting your **System ID** number to receive a emerald logo change license code. The **System ID** is displayed at the top right of the **Licensing** application interface. (See Figure 85)

- 3. In the Licensing application, type the four part license code and click Add.
- 4. Once the license code has been applied, scroll the list of licenses to check that '**Yes**' is displayed beside the **emerald Logo Change** option.



Figure 85 emerald Logo Change license added to the CDC



# Enabling the emerald logo change function on the CDC

To enable the integration on the CDC:

- 5. Open an interface with the server, by either:
  - i. Remotely opening a SSH terminal emulator connection (such as Putty) with the CDC.
  - ii. Or, directly accessing the CDC console.
- 6. Login as user: root
- 7. Type I in the command line and press return to display the Integrations menu.

Integrations menu:	
1)AD Video	2) AD TVR
3) AD Hybrid DVR	4) AD NTLX and VE
5) Airport Edition	6) BACnet or Minerva MX Fire panels
7)Bosch	8)Contact ID Interface
9) DSC PowerSeries	10) FFTCams3
11) Galaxy	12) Genetec Security Center
13)Genetec Omnicast	14) IndigoVision SMS4
15)MatriVideo	16)Milestone
17) Pelco	18)Salto SHIP
19)Satel Integra	20) Victor
21)emerald Logo Change	22) exacqVision
23)API	24) Portables subsystem
25)Audio Recording	
Select Integration to Set Up(or	X to eXit):

Figure 86 Integrations menu in a terminal emulator

- 8. Type the option number corresponding with **emerald Logo Change** (21 in the example displayed in Figure 86) and press **Return**.
- 9. Press Return when prompted, to display the integrations menu again.
- 10. Type x and press **Return** to exit integrations menu.
- 11. Type  $\ \ L$  and press **Return** to log out of terminal emulator session.

### Uploading a user defined Card Logo in AC2000 WEB

- 12. Log in to AC2000 WEB.
- 13. Select emerald Configuration | File Upload.
- 14. From the main File Upload page select the file Type as DISPLAY.



15. Select a **Group** from the list. For more information on **Groups**, see Creating a Group in the AC2000 WEB manual.

#### 16. Click ADD CONTENT.

	Transmission	) Content	Confirm	
Upload -	Upload File Choose File No file chosen Files must be CSV			Browse to file
	FLIGHT INFO / TERMINAL 1: Existing Slideshows: No Files			
			BACK SEND	
		Retu	rn to previous pag	je

Figure 88 Uploading a logo

- 17. Click Browse.
- 18. Locate the required file and click **Open**.

#### Note

The image must be in PNG format. The recommended size is 287 pixels high by 143 pixels wide and the maximum file size is 90kB.

- 19. Click UPLOAD.
- 20. Type a name for the logo in the **content name** field.
- 21. Click OK.

	Transmission	Content			Confirm	
Logo ——— uploaded successfull	Summer_Schedule Upload File Choose File No file chosen Files must be CSV					۷
	FLIGHT INFO / TERMINAL 1: Existing Slideshows: No Files					
		 	(	Васк		SEND

Figure 89 Verifying logo is uploaded

22. Click SEND.



Add additional logo

Figure 90 Confirming logo is ready to be displayed on the emerald terminal

23. Click **OK** when the confirmation prompt is displayed (See Figure 90). This displays a confirmation message that the image has been sent to all emerald readers on the system.

#### Note

The logo will only update on each reader, following a car swipe.

The uploaded logo will replace the existing logo on the dancing card display on the emerald terminal. To add an additional logo, click **ANOTHER**.

emerald TS100/200/300 Installation Manual





CEM Systems 195 Airport Road West Belfast BT3 9ED United Kingdom Tel: +44(0)2890 456767