




Instruction Manual EC-366

Thank you for purchasing the EC-366 Spa Massage Chair. Before using your massage chair, please read the contents of this instruction manual and refer to it when needed.

Table of Contents

Spa Features	2
Safety Precautions	3-4
Chair Components	5-6
Chair Installation & Moving	7-12
Chair Specifications	13
Operation Guide	14-22
Troubleshooting & Product Maintenance	23
Warnings	24
COZZIA Consumer Warranty	25-27
Warranty Card (Attachment)	

EC-366 Spa Massage Chair

The Spa Massage Chair is controlled by a microcomputer that performs a variety of intelligent massage techniques and combinations that are designed to soothe sore muscles, alleviate stress and fatigue, increase metabolism and energy, and improve blood circulation.

01 Spa Features

Spa massage includes: Shiatsu (acupressure), kneading, rolling, clapping, tapping, stretch, Swedish, heating, vibration, dual-action and traction techniques.


- An exclusive SPA massage treatment initiated through combined massage functions.
- Wonderful stretching adjustment for calves.
- Innovative auto scanning technology in backrest automatically or manually customizes a personal massage specifically for each user.
- Invigorating air pressure system in back, seat, armrest and footrest.
- Heated backrest in lower lumbar area.
- Six or pre-programmed massage sessions with customizable strength, speed and intensity.
- Ability to customize massage by controlling speed, adjusting rollers and choosing partial massage areas.
- Three partial massage options in upper, middle and lower back.
- Narrow or wide back massage adjustment.
- Extended footrest automatically adjusts to fit user's height.
- Automatic angle adjustment in back and footrest.
- Programmable timer with 5-30 minutes automatic shut-off and pause mode.
- User-friendly LCD remote control with graphic interface.
- Ergonomically designed for optimum comfort.

02 Safety Precautions

When using the massage chair, basic precautions should always be followed to reduce the risk of electric shock, burns, fire or injury to persons. Please read the following precautions before using the massage chair.

- Make sure the power plug is securely inserted into a proper electrical outlet to reduce the risk of short-circuit and fire.
- Always unplug the massage chair from the electrical outlet immediately after using and before cleaning.
- DO NOT use the massage chair in areas where the humidity is high such as a sauna or steam room.
- DO NOT use the massage chair outdoors and avoid areas with direct sunlight.
- If the electricity is off, turn the power switch to the OFF position and unplug the massage chair from the electrical outlet to prevent any damages to the chair when the electricity comes back on.
- Never plugging/unplug the power cord plug socket with wet hands.
- Close and continuous supervision is necessary when the massage chair is used by or on near children or disabled persons.
- No more than one person should use the massage chair at a time.
- The massage chair is intended for use as described in the Instruction Manual. Do not use any attachments other than those recommended by COZZIA.
- DO NOT attempt to stand or sit on the backrest, armrest or footrest in order to prevent accident, injury or damage to the chair.
- Avoid falling asleep while using the massage chair.
- Always keep the massage chair clean, and never insert any objects into or around the parts of the massage chair.
- DO NOT move the massage chair by pulling on the power supply cord.
- Make sure there are no children, pets or other obstacles behind or underneath the massage chair.
- If you find any rips or tears in the fabric of the massage chair contact the COZZIA service department and stop using the chair immediately.

Warranty Card



WARRANTY REGISTRATION FORM

Product Serial No. (located on product): _____

Purchase Price: _____ Model: _____

Date Purchased: _____

First Name: _____ Last Name: _____

Address: _____

City: _____ State: _____ Zip: _____

Phone: _____

Email: _____

Please mail to: COZZIA USA LLC
1102 John Reed Court
CITY of Industry, CA, 91745
Tel: 1-877-977-0656
Fax: 1-800-521-4171

03 Chair Components

- Fading, wear and piling of fabrics occurs naturally and does not constitute a defect under this warranty.
- Natural markings, grain and dye variations in leather do not constitute a defect under this warranty.
- Warranties do not cover any loss or damage resulting from improper installation, unauthorized repairs or modifications. Improper use of electrical/power supply, loss of power, dropped product, a malfunction or damage of an operating part from failure to provide manufacturer's recommended maintenance, transportation damage, theft, abuse, misuse, neglect, vandalism or environmental conditions (fire, floods, rust, corrosion, sand, dirt, windstorm, hail, earthquake or exposure to weather conditions), loss of use during the period the product is at a repair facility, or otherwise awaiting parts or repair.
- Damage due to shipping and handling does not constitute a defect under this warranty.
- Under no circumstance shall COZZIA or its representatives be liable for indirect, consequential, or incidental damages (including damages for lost profits, business interruption, bodily injury, medical and the like), even if any business has been advised of the possibility of such damages.
- Warranties are non-transferable and shall be in lieu of any other warranty, express or implied, including but not limited to any implied warranty of merchantability or fitness for particular use.
- COZZIA's sole liability and the purchaser's exclusive remedy shall be for the repair, or at COZZIA's option, the replacement of the defective part. Notwithstanding the above, if replacements parts for defective materials are not available, COZZIA reserves the right to make substitutions in lieu of repair or replacement.
- All warranties begin on the DATE OF PURCHASE, or allowance or extension is offered for delivery and/or installation.
- Warranties do not apply to rental, business, commercial, institutional or other use.

03 Chair Components

- This massage chair is designed for household use and should not be used in non-residential settings.
- Please consult your doctor if you are in doubt as to whether or not you should use this massage chair.
- Please consult a doctor before using the massage chair if you are pregnant, undergoing any medical treatment, using a medical electronic device such as a pacemaker, or are experiencing any of the following: Malignant tumor, heart disease, back pain, abnormal or curved back bone, osteoporosis or acute illness.
- If you experience pain while using the massage chair, stop using the chair immediately and consult your doctor.
- Never use a massage function on swollen or inflamed parts of the body.
- DO NOT use the massage chair for more than 30 minutes at a time.
- DO NOT use the massage chair where aerosol (spray) products are being used or where oxygen is being administered.
- This massage chair is a non-professional product designed to provide a comfortable massage and should not be substituted for appropriate medical treatment.
- Never operate the appliance with the air openings blocked. Keep the air openings free of dirt, hair, and the wires like during operation and avoid hitting the buttons with hard objects.
- Temperatures sufficiently high to cause burns may occur regardless of the control setting. Do not use on an invalid or on a sleeping or unconscious person. Check the skin in contact with the heated area of the appliance frequently to reduce the risk of blister.
- Burns may result from improper use.
- Do not crush-avoid sharp folds.
- Keep children away from extended foot support (or other similar parts.)
- DO NOT use the chair with any electrical plug.
- NEVER REMOVE COVER.

03 Chair Components

- Fading, wear and piling of fabrics occurs naturally and does not constitute a defect under this warranty.
- Natural markings, grain and dye variations in leather do not constitute a defect under this warranty.
- Warranties do not cover any loss or damage resulting from improper installation, unauthorized repairs or modifications. Improper use of electrical/power supply, loss of power, dropped product, a malfunction or damage of an operating part from failure to provide manufacturer's recommended maintenance, transportation damage, theft, abuse, misuse, neglect, vandalism or environmental conditions (fire, floods, rust, corrosion, sand, dirt, windstorm, hail, earthquake or exposure to weather conditions), loss of use during the period the product is at a repair facility, or otherwise awaiting parts or repair.
- Damage due to shipping and handling does not constitute a defect under this warranty.
- Under no circumstance shall COZZIA or its representatives be liable for indirect, consequential, or incidental damages (including damages for lost profits, business interruption, bodily injury, medical and the like), even if any business has been advised of the possibility of such damages.
- Warranties are non-transferable and shall be in lieu of any other warranty, express or implied, including but not limited to any implied warranty of merchantability or fitness for particular use.
- COZZIA's sole liability and the purchaser's exclusive remedy shall be for the repair, or at COZZIA's option, the replacement of the defective part. Notwithstanding the above, if replacements parts for defective materials are not available, COZZIA reserves the right to make substitutions in lieu of repair or replacement.
- All warranties begin on the DATE OF PURCHASE, or allowance or extension is offered for delivery and/or installation.
- Warranties do not apply to rental, business, commercial, institutional or other use.

03 Chair Components

- This massage chair is designed for household use and should not be used in non-residential settings.
- Please consult your doctor if you are in doubt as to whether or not you should use this massage chair.
- Please consult a doctor before using the massage chair if you are pregnant, undergoing any medical treatment, using a medical electronic device such as a pacemaker, or are experiencing any of the following: Malignant tumor, heart disease, back pain, abnormal or curved back bone, osteoporosis or acute illness.
- If you experience pain while using the massage chair, stop using the chair immediately and consult your doctor.
- Never use a massage function on swollen or inflamed parts of the body.
- DO NOT use the massage chair for more than 30 minutes at a time.
- DO NOT use the massage chair where aerosol (spray) products are being used or where oxygen is being administered.
- This massage chair is a non-professional product designed to provide a comfortable massage and should not be substituted for appropriate medical treatment.
- Never operate the appliance with the air openings blocked. Keep the air openings free of dirt, hair, and the wires like during operation and avoid hitting the buttons with hard objects.
- Temperatures sufficiently high to cause burns may occur regardless of the control setting. Do not use on an invalid or on a sleeping or unconscious person. Check the skin in contact with the heated area of the appliance frequently to reduce the risk of blister.
- Burns may result from improper use.
- Do not crush-avoid sharp folds.
- Keep children away from extended foot support (or other similar parts.)
- DO NOT use the chair with any electrical plug.
- NEVER REMOVE COVER.

09 COZZIA Consumer Warranty

COZZIA products have the following warranty: COZZIA's massage chairs, motion upholstery and home theater massage seating provide a one year in-home service warranty and a two-year parts warranty. COZZIA customer service will not issue Return Material Authorizations (RMAs) for products. COZZIA products will be either repaired by the consumer or by an in-home technician. COZZIA will not issue Return Material Authorizations (RMAs) for buyer's remorse.

SERVICE AND TECHNICAL SUPPORT

Consumers may contact COZZIA's customer service department at 1-877-977-0656 between 9:00 am and 5:00 pm PST, Monday through Friday for warranty or service issues.

Consumers are required to provide the unit serial number and dated proof of purchase (sales receipt) whenever they contact the COZZIA customer service regarding a repair.

A COZZIA customer service representative will attend to most consumer inquiries, but in some cases a technical service specialist will provide advanced support.


Non-warranty repair is provided on a "per incident" basis. COZZIA customer service will verify that the unit has failed and provide instructions for repairing a unit. All applicable repairs, parts, shipping, handling, local travel and a "per incident" fee will be charged for non-warranty repairs and support calls.

Proof of purchase (original receipt) is required for all warranty repairs or service.

PRODUCT REPAIRS


Many COZZIA product repairs may be performed by the consumer in their own home with parts and instructions supplied by COZZIA such as remote controller replacements that don't require a technician.

MASSAGING POSITION



04 Chair Installation


Step 1: When setting up the chair, make sure there is at least three feet of space behind the backrest and three feet of space in front of the footrest.



Step 2: Press the backrest, then lower the backrest into the back brackets. Securely lock the flat head bolts into sides of the seat.

Note: Carefully unwrap the armrest to avoid scratching during installation.


A: Flat Head Bolt (on the backrest)
B: Holder (on the seat part)



08 Warnings

- Do not use water and other cleaning detergents on the massage chair.
- Do not kick, stab, slit or harshly pull on the surface of the massage chair.
- Gently press the buttons during operation and avoid hitting the buttons with hard objects.
- Pull out the power supply plug after each use.
- Do not use the massage chair for more than 30 minutes at a time.
- DO NOT position any body part in between the gaps of the leg rest when the automatic leg extension feature is in operation as demonstrated PIC 1, in order to prevent pinch to you.
- Note: If you are unable to position any body part in between the gaps of the leg rest, please press PAUSE button to stop and then get your body part out rapidly as demonstrated PIC 2.
- DO NOT attempt to press the ON/OFF button to stop, as when you press this button, the footrest will automatically shrink its original position and may cause much tighter pinch.
- If you have to rise from the chair to stop accident, injury or damage to others by you, you want to put your feet and calves out when the automatic leg extension feature is in operation, please press PAUSE button to stop and stop the massage. The footrest will gradually inflate in some seconds and then quickly get your foot and calves out and rise. Note: This way is as above mentioned just in case of emergencies.

Please bear in mind that always return the footrest to its original length and restore it to its original position, then rise from the chair in order to prevent accident, injury or damage to yourself and chair.




07 Troubleshooting & Product Maintenance

This massage chair is controlled by a microcomputer and is susceptible to power surges of +10% to -10%.




The following situations may display in the event of a power surge:

Situation	Solution
The massage chair is connected to a power supply but is not functioning.	1. Check to see that the plug is well connected and working. 2. Make sure that the massage chair switch is turned to the "I" position.
The remote control works, but the massage chair is not functioning.	The massage chair may have overheated due to prolonged use. Turn off the power and allow the chair to cool for 30-50 minutes.
Both the remote control and the massage chair are not functioning.	1. Make sure the chair is plugged into a working outlet. 2. Turn the power OFF and then ON again.

Use the diagonal pliers to cut off the cable tie which binds the stopper of the backrest, and take down the packing material of the backrest actuator.




Attach the connecting rod and the U stay fork of the reclining actuator with a flat be adjusted to the user's leg rest length for a more effective massage. Every time the button is pressed, the Auto function will detect the best massage length.




Step 3: Insert the wire plugs into the seat as demonstrated in PIC 3.

Note: Insert backrest to black and gray to gray, otherwise damage to the chair may result.



Step 4: Unfold the backrest until you hear a "click" sound.



Setting Seat Vibration

42. Vibration
Vibration Function Start/Stop Control Button-2 modes (SEAT VIBRATION 1 SEAT VIBRATION 2) - 4 levels of speed.
Press this button once to activate the vibration function for seat.
Press the button again to stop the vibration massage function.
Note: Press the SEAT VIBRATION 1 or the SEAT VIBRATION 2 button to select the mode desired.


43. Stop ()

Press this button to stop all massage functions. The massage rollers will resume their original position.
Press the power button on the chair to the "O" position and disconnect the power cord plug from the electrical outlet.

Seat Raising Button (optional)

There is a red button on the side of the right armrest. This button only is used after the user presses the ON/OFF button and stops the massage. Press this button and the seat will be raised slowly to help the user stand up. Please be patient as it may take about 30 seconds. This function is built-in especially for the elderly or for those suffering from osteoarthritis. After the seat is raised fully, it will return slowly to the original position. Switch the power button again to stop the spot massage function and to resume the full back massage from the electrical outlet.

Note: When press this button, the power switch should be "I" position for idle mode.



36. Shiatsu

Rolling Function Start/Stop Control Button-2 modes (SHIATSU 1/ SHIATSU 2) - 3 levels of width (narrow, medium, wide), 4 levels of speed.
Press this button once to activate the Shiatsu massage function for a full back massage. Press the button again to stop the Shiatsu massage function.

Note: Before the Backlight function is activated, pressing any function button will activate the Shiatsu 1 or the SHIATSU 2 button to select the mode desired.

37. Rolling

Rolling Function Start/Stop Control Button-3 levels of width (narrow, medium, wide). Press this button once to activate the Shiatsu massage function for a full back massage. Press the button again to stop the rolling massage function.

Note: Tapping, clapping, Shiatsu, Swedish and spot functions cannot be combined with the Rolling function.

38. Strength

Kneading Speed Adjustment Control Button
Press this button to adjust the speed when the kneading function is activated.

39. Speed

Speed Adjustment Control Button
Press this button to adjust the speed when the tapping, clapping and Shiatsu functions are activated.

40. Width


Width Adjustment Control Button
Press this button to adjust the width when the tapping, clapping, Shiatsu and rolling functions are activated.

Waist Heating Function


41. Heating

Heating Function Start/Stop Control Button
Press this button once to activate the heat function for the waist.
Press the button again to stop the heating function.


Step 5: Install the right arm massage components by tightening the screws (short ones) and insert the air hose to the arm-rest.




Step 6: Install the right arm massage cover by tightening the screws (short ones) as demonstrated in PIC 5, then cover the screws with the rectangle cap.



Step 7: Repeat Step 5 to install left arm massage components.




Install the remote controller stand by tightening the screws (45 degrees. This adjustment request is set when you let go of the button and the manual adjustment is achieved.



Step 8: (Optional)

Remove the spare pad located in backrest cover for a deeper massage.
Note: The spare pad has been inserted into the backrest cover. If strong massage is desired, remove the spare pad from the cover to strengthen the massage. If milder massages are desired, insert the spare pad into the cover to lessen the strength of the massage.



Manual Back Massage

13. Vibration

Vibration Function Start/Stop Control Button
Press this button once to activate the vibration for a full back massage. Press the button again to stop the vibration massage function.

13. Stretch

Stretch Function Start/Stop Control Button
Press this button once to activate the stretch function. The air bags of calves and legs will inflate to stretch out and draw back (pace up and down). Press the button again to stop the spot massage function and to resume the full back massage from the electrical outlet.

13. Kneading

Kneading Function Start/Stop Control Button-2 modes (KNEADING1/ KNEADING2) - 4 levels of speed.
Press this button once to activate the kneading function for a full back massage at medium intensity.
Press the button again to stop the kneading massage function.

Note: This function can be combined with Tapping, clapping and Shiatsu to enjoy multi-massage functions.

14. Tapping

Tapping Function Start/Stop Control Button - 2 modes (TAPPING 1/ TAPPING 2) - 3 levels of width (narrow, medium, wide), 4 levels of speed.
Press this button once to activate the tapping function for a full back massage at medium intensity.
Press the button again to stop the tapping massage function.

Note: The TAPPING 1 or the TAPPING 2 button to select the mode desired.

15. Clapping

Clapping Function Start/Stop Control Button - 2 modes (CLAPPING 1/ CLAPPING 2) - 3 levels of width (narrow, medium, wide), 4 levels of speed.
Press this button once to activate clapping function for a full back massage at medium intensity.
Press the button again to stop the clapping massage function.

Note: The CLAPPING 1/ CLAPPING 2 button to select the mode desired.

Setting Air Squeeze

25. AUTO

Auto Air Squeeze Control Button
Press this button once to activate the seat, back, arms, feet and calves auto air squeeze function. Press the button again to stop the auto air squeeze function.

26. Intensity

Air Squeeze Intensity Adjustment Control Button - 4 levels of intensity.
Press this button to adjust the intensity of the air squeeze function while the air squeeze functions are activated.

27. Arms

Arms Air Squeeze Start/Stop Control Button
Press this button once to activate the arms air squeeze function.
Press the button again to stop the arms air squeeze function.

28. Back/Seat

Back and Seat Air Squeeze Start/Stop Control Button
Press this button once to activate the back and seat air squeeze functions.
Press the button again to stop the back and seat air squeeze functions.

29. Feet

Feet Air Squeeze Start/Stop Control Button
Press this button once to activate the feet air squeeze function.
Press the button again to stop the feet air squeeze function.

30. Calves

Calves Air Squeeze Start/Stop Control Button
Press this button once to activate the calves air squeeze function.
Press the button again to stop the calves squeeze function.


Note: All air squeeze control buttons have two mode selects. Press again if you want to change the mode.

Moving the chair


1. Restore the footrest to its original position.
2. Decline the chair to tilt approximately 45 degrees. Move the chair using the wheels as the fulcrum.

Note: Always return the footrest to its original length and restore it to its original position before moving the chair. Otherwise, injury during movement may result.

3. Place a mat on the floor and gently roll the chair over to avoid damaging the floor.



Step 1



Step 2

05 Chair Specifications

Description	Specifications
Model Name	EC-366
Rated Voltage	110V ~
Rated Frequency	60Hz
Rated Power Consumption	280W/ Max
Timer	5, 10, 15, 20, 25, 30 minutes
Max Time Rate	60 minutes