SRAM control port		
I/O address 866H.		
Bit	Function	
Bit0, 4	Change SRAM page 0~4	
Bit6	Enable/disable SRAM write protect	

Please refer our example codes to know how to setup and access GPIO.

Windows CE Example Codes

```
#include "stdafx.h"
unsigned char inp(int addr)
{
  __asm
 {
   push edx
  mov edx, DWORD PTR addr
  in al, dx
  and eax, 0xff
  pop edx
 }
}
void outp(int addr, unsigned char val)
{
  __asm
 {
  push edx
  mov edx, DWORD PTR addr
  mov al, BYTE PTR val
  out dx, al
  pop edx
 }
}
void main()
{
 outp(0x2e, 0x87); /* unlock W83697UF configuration registers */
 outp(0x2e, 0x87);
 outp(0x2e, 0x2a); /* select GP2-5 device */
 outp(0x2f, 0x00);
 outp(0x2e, 0x2b); /* select GP80-83 device & enable COM3 */
 outp(0x2f, 0x7c);
 outp(0x2e, 0x2c); /* enable COM4 */
 outp(0x2f, 0x55);
 outp(0x2e, 0x07); /* select device 9, GP2-4 */
 outp(0x2f, 0x09);
 outp(0x2e, 0x30); /* active GP2-4 */
 outp(0x2f, 0x07);
 outp(0x2e, 0xf0); /* set GP2 as output mode */
 outp(0x2f, 0x00);
 outp(0x2e, 0xf3); /* set GP3 as input mode */
 outp(0x2f, 0xff);
 outp(0x2e, 0xf6); /* set GP4 as input mode */
 outp(0x2f, 0xff);
```

```
outp(0x2e, 0x60); /* map to I/O address 610H */
outp(0x2f, 0x06);
outp(0x2e, 0x61);
outp(0x2f, 0x10);
outp(0x2e, 0x07); /* select device F, GP8 */
outp(0x2f, 0x0F);
outp(0x2e, 0x30); /* active GP8 */
outp(0x2f, 0x01);
outp(0x2e, 0xf0); /* set GP8 as output mode */
outp(0x2f, 0x00);
outp(0x2e, 0x60); /* map to I/O address 400H */
outp(0x2f, 0x04);
outp(0x2e, 0x61);
outp(0x2f, 0x00);
outp(0x2e, 0xaa); /* lock W83697UF configuration registers */
outp(0x2f, 0xaa);
/* After those code, programmer can access port 2/3/4/8 now */
/* output data to port 2 */
out(0x610, 0x55);
/* read data from port 3 */
inp(0x610)
/* read data from port 4 */
inp(0x611)
/* output data to port 8 */
out(0x610, 0xaa)
```

Technical Support

}

For more technical support, please visit http://www.dmp.tw/tech or mail to tech@dmp.tw

End-of-Using GPIO on AVL

Using GPIO on AVL | 2006-04-25

10.3. AVL Power Management Command Set

The power management of AVL is performed by a micro-p via I2C interface. The power management commands are divided into two parts: setup and query commands. This document will show programmer those commands and use our AVL library to do power management on AVL.

Setup Commands

Power ON setup command sequence is **one command byte + one time data byte**.

Command	Hex.	Description	
SET_OFF	81H	Turn power off	
SET_Ring	82H	Wake on modem	
SET_After	83H	Power on after define time	
SET_Every	84H	Power on every define time	
SET_GPI_ALL	8FH	Wake on one of GPI pins	
SET_GPI0	90H	Wake on GPI0	
SET_GPI1	91H	Wake on GPI1	
SET_GPI2	92H	Wake on GPI2	
SET_GPI3	93H	Wake on GPI3	
SET_Clear	85H	Clear all trigger events. Time data will	
		be ignored	

Power ON Condition Commands

Time Data Byte

Bit	Description
7	1: in hour
	0: in minute
6-0	Time value in hour or minute.

• Set all bits to 0 indicate right now.

• Set all bits to 1 indicate disabled.

Command	Hex.	Description
SET_OFF	81H	Turn power off

Example	Command
Turn off power right now	81H + 00H
Turn off power after 10 minutes	81H + 0AH
Turn off power after 2 hours	81H + 82H
Disable turn off power setting	81H + FFH
Programmer can use 05H comma	and to verify setting.

Note: Before using SET_Ring command, please make sure that GPRS is power on and supports wake on ring mode.

Command	Hex.	Description
SET_Ring	82H	Wake on modem

Example	Command
Wake on ring right now	82H + 00H
Wake on ring after 10 minutes	82H + 0AH
Wake on ring after 2 hours	82H + 82H
Disable Wake on ring	82H + FFH

Programmer can use 05H command to verify setting.

Command	Hex.	Description
SET_After	83H	Power on after define time

Example	Command
Wake on AVL right now	83H + 00H
Wake on AVL after 10 minutes	83H + 0AH
Wake on AVL after 2 hours	83H + 82H
Disable this command	83H + FFH
Programmer can use 05H comm	hand to verify setting.

Command	Hex.	Description
SET_Every	84H	Power on every define time

Example	Command	
Wake on AVL right now	84H + 00H	
Wake on AVL every 10 minutes	84H + 0AH	
Wake on AVL every 2 hours	84H + 82H	
Disable this command	84H + FFH	
Programmer can use 05H command to verify setting.		

Command	Hex.	Description
SET_GPI_ALL	8FH	Wake on one of GPI pins

Example	Command
Turn on AVL power right now while one of GPIO is triggered	8FH + 00H
Disable this command	8FH + FFH
The valid time data bytes for this command are 00H and FFH	

Command	Hex.	Description
SET_GPI0	90H	Wake on GPI0

Example

Command

Turn on AVL power right now while GPI0 is triggered 90H + 00H 90H + FFH Disable this command The valid time data bytes for this command are 00H and FFH.

Command	Hex.	Description
SET_GPI1	91H	Wake on GPI1

Example

Example	Command
Turn on AVL power right now while GPI1 is triggered	91H + 00H
Disable this command	91H + FFH
The valid time data bytes for this command are 00H a	nd FFH.

Command	Hex.	Description
SET_GPI2	92H	Wake on GPI2

Example	Command
Turn on AVL power right now while GPI2 is triggered	92H + 00H
Disable this command	92H + FFH
The valid time data bytes for this command are 00H a	nd FFH.

Command	Hex.	Description
SET_GPI3	93H	Wake on GPI3

Example	Command
Turn on AVL power right now while GPI3 is triggered	93H + 00H
Disable this command	93H + FFH
The valid time data bytes for this command are 00H a	nd FFH.

Command	Hex.	Description
SET_Clear	85H	Clear all trigger events. Time data will be ignored

ExampleCommandClear all trigger events93H + 00H

Query Commands

Power ON status query command is to send one query command and client will return one time date byte.

Time Data Byte

Bit	Description
7	1: in hour
	0: in minute
6-0	Time value in hour or minute.

"00H" indicates right now. "FFH" is to disable time setting.

Voltage Data Bytes

The voltage is a 12-bit data.		
Bit	Description	
Bit 7~0 of byte1	Bit 7~0 of voltage data.	
Bit 3~0 of byte2	Bit 11~0 of voltage data.	

Status Query	Commands
--------------	----------

Command	Hex.	Description	Retur	'n		
GET_OFF	01H	Turn power off.	Time data byte.			
GET_Ring	02H	Wake on modem.	Time	data byte.		
GET_After	03H	Power on after define time.	Time	data byte.		
GET_Every	04H	Power on every define time.	Time	data byte.		
GET_EStatus	05H	Query events status.	For G byte.	ET_EStatus query comman It will return all events status	id, clie (0 is d	ent will not return time data lisabled and 1 is enabled):
			Bit	Description	Bit	Description
			7	SET_OFF is enabled.	3	SET_GPI3 is enabled.
			6	SET_Ring is enabled.	2	SET_GPI2 is enabled.
			5	SET_After is enabled.	1	SET_GPI1 is enabled.
			4	SET_Every is enabled.	0	SET_GPI0 is enabled.
GET_Voltage	40H	Get current voltage.	Retur -> 12.	n a 12-bits voltage data in 10 8V.	mV ur	nit. Ex: return 500H = 1280
GET_OFF2	41H	Get remainder	Time	data byte.		
		time to power off.				

GET_IStatus	42H	Get input pins status.	For GET status of	ISTatus query command input pins (0 is low and 1	d, client w is high):	ill return a byte to indicate
			Bit	Description	Bit	Description
			7	Reserved	3	GPI3
			6	Reserved	2	GPI2
			5	Reserved	1	GPI1
			4	Ring	0	GPI0
GET_Trigger	43H	Get the event to	For GET	Trigger query comman	nd, client	will return the event to
		ungger power on.	Bit De		Bit	Description
			7 In	out voltage event to trigge	er 3	SET GPI3 is triggered
			6 SE	ET Rina is triagered.	2	SET GPI2 is triggered.
			5 SE	ET After is triggered.	1	SET GPI1 is triggered.
			4 SE	ET Every is triggered.	0	SET GPI0 is triggered.
				_ ,		
GET_Diag	44H	Return the second	It will be	a second data byte after	r GET_Di	ag command. Return the
		byte.	second b	yte to make sure it works	properly.	
Get_Version	45H	Return PIC version.	Return 1	in this version.		
Get VSwitch	47H	Return voltage	Bit 1~0 o	f return byte indicate the	switch sta	tus for power on voltage
_		detection switch.	detection	. Default trigger voltage is	S:	
			Bit 1/0	Description		
			00	13.0V		
			01	13.3V		
			10	13.6V		
			11	13.9V		
			If input vo	oltage > 18V, the trigger v	oltage is:	
			Bit 1/0	Description		
			00	26.0V		
			10	20.6V		
			10	27.2V 27.9\/		
				21.0V		

Command	Hex.	Description	Return
GET_OFF	01H	Turn power off.	Time data byte.

Example	Send Command	Read Response
Turn off power after 10 minutes	81H + 0AH	
Query GET_OFF command setting	01H	0AH
Turn off power after 2 hours	81H + 82H	
Query GET_OFF command setting	01H	82H

Command	Hex.	Description	Return
GET_Ring	02H	Wake on modem.	Time data byte.

Example	Send Command	Read Response
Wake on ring after 10 minutes	82H + 0AH	
Query GET_Ring command setting	02H	0AH
Wake on ring after 2 hours	82H + 82H	
Query GET_Ring command setting	02H	82H

Command	Hex.	Description	Return
GET_After	03H	Power on after define time.	Time data byte.

Example
Wake on AVL after 10 minutes
Query GET_Ring command setting
Wake on AVL after 2 hours
Query GET_Ring command setting

Send Command Read Response 83H + 0AH 0 03H 0AH 83H + 82H 0 03H 82H

Command	Hex.	Description	Return
GET_Every	04H	Power on every define time.	Time data byte.

Example	Send Command	Read Response
Query GET_Ring command setting	04H	0AH
Query GET_Ring command setting	84H + 82H 04H	82H

Command	Hex.	Description	Retur	n				
GET_EStatus	05H	Query events	For GET_EStatus query command, client will not return time data byte.					
		status.	It will r	It will return all events status (0 is disabled and 1 is enabled):				
			Bit	Description	Bit	Description		
			7	SET_OFF is enabled.	3	SET_GPI3 is enabled.		
			6	SET_Ring is enabled.	2	SET_GPI2 is enabled.		
			5	SET_After is enabled.	1	SET_GPI1 is enabled.		
			4	SET_Every is enabled.	0	SET_GPI0 is enabled.		
			· · · · · · · · · · · · · · · · · · ·	· ·	•	·		

Example

Wake on AVL every 10 minutes84HQuery event status05HWake on ring after 2 hours82HQuery GET_Ring command setting05H

 Send Command
 Read Response

 84H + 0AH
 05H

 05H
 10H

 82H + 82H
 50H

Command	Hex.	Description	Return
GET_Voltage	40H	Get current voltage.	Return a 12-bits voltage data in 10mV unit. Real voltage (V) = (X $*$ 1.221) / 1000 $*$ 6 + 0.3.

ExampleSend CommandRead ResponseQuery voltage of car04H05H + FEHReal voltage = (5FEH * 1.221) / 1000 * 6 + 0.3 = 11.538084V

Command	Hex.	Description	Return
GET_OFF2	41H	Get remainder time to power off.	Time data byte.

Example	Send Command	Read Response
Turn off power after 10 minutes	81H + 0AH	
Get remainder time to power off	41H	0AH
Turn off power after 2 hours	81H + 82H	
Get remainder time to power off	41H	82H

Command	Hex.	Description	Return				
GET_IStatus	42H	Get input pins status.	For GET_ISTatus query command, client will return a byte to indicate status of input pins (0 is low and 1 is high):				
			Bit	Description	Bit	Description	
			7	Reserved	3	GPI3	
			6	Reserved	2	GPI2	
			5	Reserved	1	GPI1	
			4	Ring	0	GPI0	
					-		

ExampleSend CommandRead ResponseGet input status41H02H (GPI1 is high, other pins are low)

Command	Hex.	Description	Return			
GET_Trigger	43H	Get the event to	For C	SET_Trigger query command,	clien	t will return the event to
		trigger power on.	trigge	er power on:		
			Bit	Description	Bit	Description
			7	Input voltage event to	3	SET_GPI3 is
				trigger.		triggered.
			6	SET_Ring is triggered.	2	SET_GPI2 is
						triggered.
			5	SET_After is triggered.	1	SET_GPI1 is
						triggered.
			4	SET_Every is triggered.	0	SET_GPI0 is
						triggered.

Example

Send Command Read Response 84H + 0AH

Wake on AVL every 10 minutes84HTurn off power right now81HAVL will wake on after 10 minutes81HGet the event to trigger power on43H

81H + 00H

10H

Command	Hex.	Description	Return
GET_Diag	44H	Return the second	It will be a second data byte after GET_Diag command. Return the
		byte.	second byte to make sure it works properly.

Example	Send Command	Read Response
Run diagnostic	44H + 55H	55H
Run diagnostic	44H + AAH	AAH

Command	Hex.	Description	Return
Get_Version	45H	Return PIC version.	Return 1 in this version.

Example	Send Command	Read Response
0.00	 4 - 1 - 1	0.411

Get firmware version 45H

01H

Command	Hex.	Description	Return		
Get_VSwitch	47H	Return voltage	Bit 1~0 of return byte indicate the switch status for power on		
		detection switch.	voltage d	etection. Defau	It trigger voltage is:
			Bit 1/0	Description	
			00	13.0V	
			01	13.3V	
			10	13.6V	
			11	13.9V	
			If input vo	oltage > 18V, th	e trigger voltage is:
			Bit 1/0	Description	
			00	26.0V	
			01	26.6V	
			10	27.2V	
			11	27.8V	

Example	Send Command	Read Response
Get DIP switch status	47H	01H (switch 1 is on and switch 0 is off)

AVL Power Management Command Set | 2006-04-11

End-of-AVL Power Management Command Set

10.4. AVL Power Management Programming Reference

The power management functions on AVL is handled by a PIC via I2C interface. This document will show programmers our demo codes.

Here is the definition on AVL Windows CE example code according power management commands:

#define AVL_POWER_WAKE_ON_RING	0	// wake on ring
<pre>#define AVL_POWER_WAKE_ON_1_TIME</pre>	1	// power on after define time
<pre>#define AVL_POWER_WAKE_ON_EVERY_TIME</pre>	2	// power on every define time
#define AVL_POWER_WAKE_ON_ALL_GPI	3	// wake on one of GPI pins
<pre>#define AVL_POWER_WAKE_ON_GP_0</pre>	4	// wake on when gp0 is trigged
#define AVL_POWER_WAKE_ON_GP_1	5	// wake on when gpl is trigged
#define AVL_POWER_WAKE_ON_GP_2	6	// wake on when gp2 is trigged
#define AVL POWER WAKE ON GP 3	7	// wake on when gp3 is trigged

Before using AVL power management functions, programmer has to enable I2C interface. Call AVL_POWER_init():

bool AVL_POWER_init();
// init AVL power module, you have to run this function first
// return false if init fail

To disable I2C interface and power management function, call AVL_POWER_close():

void AVL_POWER_close();
// close power library

char *AVL_POWER_version();
// return the AVL POWER Library version string

char *AVL_POWER_build_date();
// return the AVL POWER Library build date.

bool AVL_POWER_get_pic_version(BYTE &val);

// get the Power module PIC version

// !! return false if pic is busy for execute command !!

bool AVL_POWER_power_off(int h_m, int t);

// set power off command, // !! this function will return false when any argument error !! // !! and do not execute command. !! // !! return false if pic is busy for execute command !! // h_m : means the t field in hour or minutes type, 0 for minutes, others for hour // t : how many hours(or minutes) to power off, 0 = power off right now // : value from 0 ~ 126

bool AVL_POWER_clear_power_off();
// diable the power off command,
// after you issue the power off command, you can use this function
// to cancel it.

To perform wake on AVL by trigger event, programmer can use this function:

bool AVL_POWER_wake_on_event(int event_type, int h_m, int t)
// !! this function will return false when any argument error !!

// !! and do not execute command. 11 // $\,$!! return false if pic is busy for execute command 11 // event_type : power on event type, defined in AVL_POWER_WAKE_ON_* // h_m : means the t field in hour or minutes type, 0 for minutes, others for hour // t : how many hours (or minutes) to power on, 0 = power on when event trigged 11 : other values means delay [t] hours (or minutes) then power on. 11 : value from 0 $^{\sim}$ 126 bool AVL_POWER_disable_wake_on_event(int event_type); // clear the power on event // !! this function will return false when any argument error !! // !! and do not execute command. 11 // !! return false if pic is busy for execute command 11 // event type : power on event type, defined in AVL POWER WAKE ON * bool AVL POWER_clear_all_wake on event(); // clear all power on event // !! return false if pic is busy for execute command 11 bool AVL POWER get power off timer(int &h m, int &t); // get power off timer setted before // !! return false if pic is busy for execute command 11 // h m : means the t field in hour or minutes type, 0 for minutes, others for hour // t : how many hours (or minutes) to power on, 0 = power on when event trigged 11 : other values means delay [t] hours (or minutes) then power on. 11 : value from 0 $^{\sim}$ 126 bool AVL_POWER_get_wake_on_timer(int event_type, int &h m, int &t); // get event wake on timer setted before // $\,$!! this function will return false when any argument error !! // !! and do not execute command. 11 // !! return false if pic is busy for execute command 11 // event_type : power on event type, defined in AVL_POWER_WAKE_ON_* // h m : means the t field in hour or minutes type, 0 for minutes, others for hour // t : how many hours (or minutes) to power on, 0 = power on when event trigged : other values means delay [t] hours (or minutes) then power on. // 11 : value from 0 $^{\sim}$ 126 bool AVL_POWER_get_event_status(AVL_POWER_Event_Status *event_status); // get event status, // !! return false if pic is busy for execute command 11 // see struct AVL POWER Event Status for more information bool AVL_POWER_get_input_status(AVL_POWER_Input_Status *input_status); // get input status, // see struct AVL_POWER_Input_Status for more information bool AVL_POWER_get_power_on_type (AVL_POWER_Power_On_Event_Type *power_on_type); // get power up event type

// see struct AVL_POWER_Power_On_Event_Type for more information

```
bool AVL_POWER_get_current_voltage(float &val);
// get current voltage data
// !! return false if pic is busy for execute command !!
bool AVL_POWER_get_remainder_time_to_power_off(int &h_m, int &t);
// get remainder time to power off
// !! return false if pic is busy for execute command !!
// h_m : means the t field in hour or minutes type, 0 for minutes, others for hour
// t : how many hours(or minutes) to power on, 0 = power on when event trigged
// : other values means delay [t] hours(or minutes) then power on.
// : value from 0 ~ 126
bool AVL_POWER_get_sw_setting(BYTE &val);
// get the DIP SWITCH SETTING
```

// get the bit outfold obting // !! return false if pic is busy for execute command !!

Examples

AVL_POWER_init(); // power off AVL right now AVL_POWER_power_off(0, 0); // power off AVL after 10 minutes AVL_POWER_power_off(0, 10); // power off AVL after 1 hour AVL_POWER_power_off(1, 1); // wake on ring AVL_POWER_wake_on_event(AVL_POWER_WAKE_ON_RING, 0, 0); // disable wake on ring AVL_POWER_disable_wake_on_event(AVL_POWER_WAKE_ON_RING);

Technical Support

AVL_POWER_close();

For more technical support, please visit http://www.dmp.tw/tech or mail to tech@dmp.tw

AVL Power Management Programming Reference | 2006-04-25

End-of-AVL Power Management Programming Reference

Chapter 11

11. AVL COMMUNICATION BOARDS

DMP offers two different models of AVL75 computer system namely: (1)the AVL Basic system and (2)AVL Basic+OBD-II system. The AVL75 Basic system comes with 128MB System memory + 32MB DOM. Depending on the memory capacity requirement of your development in AP software + O/S, the IDE flash memory (DOM) can be upgraded to 64MB, 128MB, 256MB and 512MB. The AVL Basic system consists of an x86 CPU board with the GPS & GPRS function. AVL75 was designed with the intention to provide the AVL software developers the proper hardware platform and tool in creating the required application software for its vehicle tracking market.

The AVL75 was designed using the modular concept in providing the BASIC unit system and the OPTION add-on modules. Listed below is the summary of AVL75 different modules and part numbers:

AVL module no.	Device	Function description
AVL-1	GPS	Tracking and Positioning
AVL-2 & AVL-3	GPRS	Data Transmission &
		Communication
AVL-5	OBD-II	Car networking and control

Hereafter, we are delighted to share the subassembly of the add-on modules with it's corresponding interface cards. Please refer to the section of your desired assembly instruction or removal procedure.

Operational Procedure

- 11.1. Uncovering your AVL75
- 11.2. Removing your GPRS Modem card
- 11.2.1. Adding the GPRS add-on Modem card
- 11.3. Removing your OBD-II module
- 11.3.1. Adding the OBD-II card

11.1 **Uncovering your AVL75**

Software developers may open your AVL75 to check the necessary hardware components for its needed application. Below please find the disassembly operation.







3

4

- 1. Prepare the following tools & things:
 - Philips type (+) and Slotted type screwdrivers.
 - Long nose tweezers.
 - A small papercup (to put your screws and nuts).
 - Two clean towels for cushion (you may • use an anti-static bubble plastic bag too).
- 2. Separate and put the 2 clean towels (cushion) on the flat surface of your working desk.
- 3. Then put your AVL750MWB computer system on one cushion.
- 4. The AVL75 system is made up of 2-C shape chassis, top cover and base chassis are adjacent to each other.
- 5. Prepare to unlock the 8 screws of your AVL75 system: 4 screws are behind the top cover, and 2 each at the front panel and rear backplane All screws are Philips (+) type.
- 6. Take your Philips screwdriver to unlock the 4 screws behind the top cover of your AVL75 system.







8. And then unlock the remaining 2 screws at the rear backplane.

- Rotate your AVL75 system in a 180-degrees direction (rear panel facing you). Hold your AVL 75 system with both hands, your thumbs atop the systems and four fingers beneath the device.
- 10. Uphold your AVL75 system away, one feet (30 cm) from the working desk, depress the top cover with both thumbs, until the top cover comes off the base chassis as seen in the next photo.





11.2 Removing your GPRS Modem card









1. Using a long nose tweezers or a hex cone driver, unlock and remove the 2 nuts from the Siemens MC55 Modem card (as seen on the left photo).

2. The 2 nuts are located diagonally on the edges of the MC55 modem card. Unlock the first nut.

3. Unlock the second nut of the MC55 modem card.

4. Rotate your AVL75 system 90-degrees clockwise. Hold the diagonal edges of your MC55 modem card with one hand, and slowly jiggle the card until it is free from the bottom connector.









5. Turn over the MC55 modem card to look for the antenna connection.

6. Remove the antenna connection by pulling the clip pin upwards from it's socket on the MC55 modem card.

7. After releasing the MC55 modem card from AVL-2 module, now remove two each of a plastic and paper spacers from the AVL-2 module.

8. Turn the AVL75 unit in a 90-degrees counter clockwise. Start removing the four screws of AVL-2 module with a Philips screw driver.



 The connector is located at the right side of your AVL-1 main board. Slightly lifting one edge of the right side of your AVL-2 module with a slotted (-) screwdriver. Avoid damaging the connector and socket, do not use force intrusion.



- 10. Then do the same by slightly lifting the opposite edge of the connector of your AVL-2 module with a slotted screwdriver.
- 11. Then slowly jiggle (shake) the AVL-2 module until it is free from the bottom socket.

11.2.1. Adding the GPRS add-on Modem card

- 1. To install the GPRS modem card, do the reverse procedure.
- 2. Locate J16 of your AVL-1 main board in your AVL75 system, and plug on the AVL-2 daughter board. Note: J16 (AVL-1) is a 22x2 pin 2.0mm pitch box connector.
- 3. Secure the 4 screws on the edges of the AVL MC55/56 GPRS modem add-on module (AVL-2).
- 4. Install the MC55 modem card onto AVL-2, you may contact DMP or our nearest sales office to purchase the add-on module & MC55/56 modem card.

11.3 Removing your OBD-II module









1. Locate and unlock one screw of your AVL-5 with a Philips screwdriver.

2. Viewing the photo on the left side, there is only one screw used for locking the OBD-II card (AVL-5).

3. Hold the edges and then slowly jiggle (and shake) the OBD-II card until it is free from the bottom connector.

4. Now you have remove all three option cards (WIFI card, MC55 GPRS card & AVL-5) and its' corresponding two expansion cards (AVL-2 & AVL-3).

11.3.1. Adding the OBD2 card

- 1. To install the OBD-II card, do the reverse procedure.
- 2. Locate J10 of your AVL-1 main board in your AVL75 system, and plug on the AVL-5 daughter board. Note: J10 (AVL-1) is a 10x2 pin 2.0mm pitch box connector.
- 3. To install OBD-II card, secure one screw on top of the OBD-II card (AVL-5) to AVL-1 main board..
- 4. You may contact DMP nearest sales office to purchase the OBD-II card.

<End>

APPENDIX A: REAR CONNECTOR PIN ASSIGNMENT SUMMARY

Herewith is the visible Rear Connector, this is the version with DVI connector.



Looking at the above figure A1, starting from the top-to-bottom and left-to-right. You can find the pin assignment of each connector.

GPRS ANT

AVL-2 / Modem Interface Module (Daughter Board)

J1 (DM39) /22x2 pin -2.0mm \oslash Pin header connector (male)

J16 (DM38) : COM4 /22x2 pin –2.0mm Ø Pin header connector (male)

PIN#	Signal Name	PIN#	Signal Name	PIN#	Signal Name	PIN#	Signal Name	1 🖬
1	DCD4\	12	GND	23	PORT35	34	SIM-RST	000
2	RXD4\	13	VSUS4V	24	PORT25	35	SIM-GND	
3	TXD4\	14	VSUS4V	25	PORT36	36	SIM-CLK	1000
4	DTR4\	15	NC (USB2-)	26	NC (PORT26)	37	GND	
5	GND	16	NC (USB+)	27	PORT37	38	GND	
6	DSR4\	17	RING\	28	NC (PORT27)	39	LINL	題 44
7	RTS4\	18	VXX	29	GND	40	LOUTL1	
8	CTS4\	19	MODEM-LED	30	GND	41	GND	
9	RI4\	20	NC (PCIRST-)	31	NC (SIM-VPP)	42	GND	
10	VCC	21	PORT34	32	SIM-VCC	43	LINR	
11	GND	22	PORT24	33	SIM-IO	44	LOUTR1	





FIGURE A2 : AVL-2 / Modem Interface Module



FIGURE A3 : MC55 GPRS Modem Card (GPRS ANT connector : SMA female)

GPS ANT

J9 (DM38): COM3 / GN-80-V GPS / GN-80-V Connector (INTERNAL)

PIN#	Signal Name	PIN#	Signal Name	
1	NC	2	GND	
3	RXD3	4	TXD3	
5	1PPS	6	PCIRST-	
7	VXX	8	GND	
9	VCC3	10	VCC	
11	G1 (GND)	12	G2 (GND)	
13	G3 (GND)	14		

GPS ANT connector: SMA female



OBD-II & COM2

AVL-1 / Selectable On-board diagnostic & Serial port (COM2)

J10 (DM38): OBD-II & COM2 signals / 10x2 pin - 2.0mm Ø Pin header connector (male)

PIN#	Signal Name	PIN#	Signal Name	
1	TXD2	2	PORT54	
3	RXD2	4	PORT55	
5	PCIRST-	6	PORT56	1 🗔
7	OBD-LED	8	PORT57	
9	GND	10	GND	
11	ISO9141/K	12	ISO9141/L	
13	J1850/VPWN+	14	J1850/PWM-	單 20
15	CAN+	16	CAN-	
17	GND	18	GND	
19	OBD-PWR	20	OBD-PWR	

AVL-1 / On-board diagnostic

J12 (DM38): OBD-II (Option 1) / 9-pin Dsub Connector

PIN#	Signal Name	Signal Name	
1	GND	DCD2	
2	GND	RXD2	
3	CAN+	TXD2	
4	ISO9141/K	DTR2	
5	CAN-	GND	
6	J1850/VPWN-	DSR2	
7	J1850/VPWN+	RST2	
8	ISO9141/L	CTS2	
9	OBD-PWR	RI2	

J12 (DM38) : OBD-II (Option 1) / 9-pin D-Sub connector



AVL-1 / RS232 Serial port

J10 (DM38): COM2 (Option 2) / 9-pin Dsub Connector

PIN#	Signal Name	Signal Name	
1	GND	DCD2	
2	GND	RXD2	
3	CAN+	TXD2	
4	ISO9141/K	DTR2	
5	CAN-	GND	
6	J1850/VPWN-	DSR2	<u> </u>
7	J1850/VPWN+	RST2	
8	ISO9141/L	CTS2	
9	OBD-PWR	RI2	

J11 (DM38) : COM2 / Serial port (Option 2) / 9-pin D-Sub connector

Pin #	Signal Name	Pin #	Signal Name	-
1	DCD1	2	RXD1	
3	TXD1	4	DTR1	0\00000
5	GND	6	DSR1	6 9
7	RTS1	8	CTS1	0 0
9	RI1			

DVI & VGA

AVL-1 / Selectable DVI & VGA

J2 (DM38) : DVI_1 (Option 1) / 29-pin DVI Connector

PIN#	Signal Name	PIN#	Signal Name	PIN#	Signal Name	
1	TX2-	9	TX1-	17	TXO-	
2	TX2+	10	TX1+	18	TX0+	
3	GGND	11	GGND	19	GGND	
4	USB1-	12	USB+	20	TXD1	
5	NC	13	NC	21	RXD1	TREEPERE
6	DC1CLK	14	VCC	22	GGND	
7	DC1DATA	15	GND	23	TXC+	
8	V-SYNC	16	NC	24	TXC-	
C1	R-OUT	C5	GGND	C3	B-OUT	
C2	G-OUT	C6	GGND	C4	HSYNC	

55 (DWS0) . VOA (Option 2) / Tox2 pin - 2.0mm @ Fin header connector						
Pin #	Signal Name	Pin #	Signal Name			
1	ROUT	2	GND			
3	GOUT	4	GND			
5	BOUT	6	GND			
7	HSYNC	8	GND			
9	VSYNC	10	GND			

J3 (DM38) : VGA (Option 2) / 10x2 pin - 2.0mm \emptyset Pin header connector (male)

DVI or COM1

J8: COM1 / 9-pin Dsub Connector

Pin #	Signal Name	Pin #	Signal Name	1 5
1	DCD1	2	RXD1	
3	TXD1	4	DTR1	@ <u>66666</u> Ø
5	GND	6	DSR1	6 9
7	RTS1	8	CTS1	
9	RI1			

DC-IN: 12V/24V

AVL-1 / Power-GPIO-Temperature Input/Output

J18: Power-GPIO-Temperature / Wafer 7x2C-4.2Ømm-90-degrees

PIN#	Signal Name	PIN#	Signal Name	
1	DC-IN	8	GND	
2	OUTO	9	INO	
3	OUT1	10	IN1	
4	OUT2	11	IN2	
5	OUT3	12	IN3	
6	GND	13	GND	
7	TEMP-	14	TEMP+	

Note: DC-IN for $\pm 12V/\pm 24V$

USB

J6: USB-90 / 4-pin USB Type 1 Connector (USB-90 / Vertical Type)

Pin #	Signal Name	4 - 10
1	VCC	4 ត្រា
2	-DATAO	
3	+ DATAO	1 世
4	GND	EC 864 586
5	GGND	
6	GGND	
7	GGND	
8	GGND	
		l

Power Button (switch) S2: TACT-SW-90 / 2-pole TACT-SW-90

Action	Status	
Push	ON	\circ
No push	Stay As Is	

APPENDIX B: AVL POWER MANAGEMENT

Pin#	Signal Name	Status		Voltage Selection	
		VS1	VS2	±12V	±24V
1	GND	OFF	OFF	13V	26V
2	GND	OFF	ON	13.2V	26.4V
3	VS1	ON	OFF	13.4V	26.8V
4	VS2	ON	ON	13.6V	27.2

Status	Description		
1	Auto Detect 12V/24V Volt Power On		
2	Switch Power On/Off		
3	Temperature Sensor Input		
4	Battery Volt Detect		
5	Isolate Input Detect x4		
6	Wake On Timer Counter		
7	Wake On / Ring (GPRS)		
8	Wake On Isolate Input x4		
9	LED Display Wake Up Status		
10	DIP Switch Select Power On Volt Detect Level		
11	Software Control Power Off		
12	I2C Interface Communication		

APPENDIX C: SIM CARD HOLDER



Note: The SIM card holder for GSM is situated and can be found beneath the encasing. Flip-up the system upside down, on the upper right position of the case, unlock a stamp plate.

TABLE D1 : Pin numbers of Molex SIM card holder on DSB45 Support Box

J16: SIM CARD HOLDER 3x2-2.54mm

PIN#	Signal Name
1	SIM-VCC
2	SIM-RST
3	SIM-CLK
4	SIM-GND
5	SIM-VPP
6	SIM-IO



Note: Pins 1 through 8 (except for 5) are the minimum requirement according to the GSM Recommendations, where pins 7 and 8 are needed for SIM card tray detection through the CCIN pin.

Table D2 : Other reference Pin assignment of Molex SIM card holder

Status	Signal name	1/0	Function
1	CCVCC.	I	Supply voltage for SIM card, generated by the GSM engine
2	CCRST	I	Chip card reset prompted by the GSM engine
3	CCCLK	I	Chip card clock
4	CCGND	-	Individual ground line for the SIM card to improve EMC
5	CCVPP	-	Not connected
6	CCIO	1/0	Serial data line, bi-directional
7	CCDET1	-	Connect to CCVCC
8	CCDET2	_	Connects to the CCIN input of the GSM engine. Serves
			to recognize whether a SIM card is in the holder.

Limited Warranty

Terms and Conditions

The warranty terms for AVL75 SYSTEM are 12 months beginning on the date of invoice. During the warranty period, DMP will repair replace the commodity covered under this limited warranty.

DMP warrants the hardware and software COMMODITIES are manufactured and produced to be free from defects in the materials and workmanship for one year following the date of shipment from DMP. This warranty is limited to the original purchaser of product and is not transferable.

The warranty does not apply to:

- Product that has been installed incorrectly, this specifically includes but is not limited to cases where electrical short circuit is caused.
- Product that has been altered or repaired except by the manufacturer (or with the manufacturer's consent).
- Product that has subjected to misuse, accidents, abuse, negligence or unusual stress whether physical or electrical.
- Ordinary wear and tear.

Service and Support

DMP provides the technical support for software and hardware problems with your system throughout the warranty period. The technical support service is limited to configuration and operation of AVL75 COMMODITY sold by DMP. The technical support service does not offer software tutoring or training.

During the one-year warranty period, DMP will repair or replace, at its option, any defective products or parts at no additional charge, provided that the product is returned, shipping prepaid, to DMP. All replaced parts and products become the property of DMP. Before returning any product for repair, customers are required to contact the factory for an RMA number.

This Limited Warranty does not extend to any products which have been damaged as a result of accident, misuse, abuse (such as: use of incorrect input voltages, improper or insufficient ventilation, failure to follow the operating instructions that are provided by DMP, "acts of God" or other contingencies beyond the control of DMP), or as a result of service or modification by anyone other than DMP. Except as expressly set forth above, no other warranties are expressed or implied, including, but not limited to, any implied warranties of merchantability and fitness for a particular purpose, and DMP expressly disclaims all warranties not stated herein. All implied warranties, including implied warranty. In the event the product is not free from defects as warranted above, the purchaser's sole remedy shall be repair or replacement as provided above, under no circumstances will DMP be liable to the purchaser or any user for any damages, including any incidental or consequential damages, expenses, lost profits, lost savings, or other damages arising out the use or inability to use the product.

Limitation of Liability

The manufacturer's liability for damages to customer or others resulting from the use of any product supplied hereunder shall in no event exceed the purchase price of said product.

Return Policy

Return Merchandise Authorization(RMA)policy

If DMP's technical support staff determines that a part is defective. Purchaser must call our technical support service to obtain an RMA number before attempting to return any part.

To obtain an RMA number, Purchaser must follow procedures as below :

- 1. Complete the DMP's standard RMA Form and fax back to the RMA Department.
- 2. The RMA Number must be used within 7 DAYS
- 3. The RMA Number must be shown clearly on your shipping label.
- 4. DMP must receive all Returns before a replacement will be sent.
- 5. The repair cost depends on the parts, the damage reasons, and whether under warranty period...etc. The Seller will charge the Purchaser in a reasonable price.
- 6. A copy of the invoice for the RMA product(s) will also be shipped to Purchaser.
- 7. The freight of return to DMP is charge to the Purchaser account and accompanied by an RMA number. Any Returns with freight collect will be refused and returned to you. After Repairing, the cost of freight will be paid by Seller.
- 8. DMP must receive all returned goods within the warranty period.

Shipping Policy

The Purchaser must pre-pay the shipping cost for any defective system or parts returned under the warranty. DMP shall not be liable for risk of loss or damage during shipment of your returned system or parts if you fail to insure the shipment.

All products must be shipped back to DMP in original or equivalent packaging. DMP will shipped the repaired or replacement product(s) to Purchaser by freight prepaid. Purchaser assumes the risk of loss. DMP shall not be responsible for failure of the delivery service to make on-time delivery.

Ship the package to:

ATTN: DMP ELECTRONICS INC.

TO: 8F, No.12, Wu-Quan 7 Rd., Wu Gu Industrial Park, Wu Gu Xiang, Taipei #248, TAIWAN, R.O.C.

RMA xxxxxxx

Attention: Failure to follow this return procedure will almost always delay repair! Please help us expedite your repair by following this procedure.

WEBSITE

www.avl.tw Specifications subject to change without notice Technical Guide for AVL75 v0r7.doc © DMP Electronics Inc. 2006 First issued date: 30 March, 2006, Last issued date: 21 June, 2007

CONTACT DETAILS

DMP has offices in Asia, Europe and USA with corresponding internet site: Please check with <u>macarios@avl.tw</u> for assistance.