

Lynx™ BT
REFERENCE MANUAL



DATALOGIC

DATALOGIC S.p.A.
Via Candini 2
40012 - Lippo di Calderara di Reno
Bologna - Italy

Lynx™ BT

Ed.: 09/2005

This manual refers to software version 1.00 and later.

ALL RIGHTS RESERVED

Datalogic reserves the right to make modifications and improvements without prior notification.

Datalogic shall not be liable for technical or editorial errors or omissions contained herein, nor for incidental or consequential damages resulting from the use of this material.

Product names mentioned herein are for identification purposes only and may be trademarks and or registered trademarks of their respective companies.

© Datalogic S.p.A. 2005

CONTENTS

GENERAL VIEW	ix
COMPLIANCE.....	xi
FCC Compliance.....	xii
OM-1000 BT	xii
Radio Compliance.....	xii
WEEE Compliance	xii
Laser Safety.....	xiii
LED Illuminator	xiii
Aiming System.....	xiii
OM-1000 BT Power Supply	xvi
Bluetooth® Approval	xvi
1 INTRODUCTION	1
1.1 Lynx™ BT Description	1
1.2 Lynx™ BT Batteries	2
1.3 Configuration Methods.....	3
1.3.1 Reading Configuration Barcodes	3
1.3.2 Using VisualSetup	4
1.4 Bluetooth® Definitions	4
2 INSTALLATION.....	5
2.1 Operating Lynx™ BT with OM-1000 BT	5
2.1.1 OM-1000 BT Interface Cable Connections	6
RS232 Connection.....	7
Wedge	8
USB Connection	9
2.2 Operating Lynx™ BT with Bluetooth® Device	10
2.2.1 Lynx™ BT as Slave	11
2.2.2 Lynx™ BT as Master	12
2.2.3 Data Transmission	13
2.2.4 Wedge Emulation Utility.....	13
3 USING LYNX™ BT.....	14
3.1 Aiming System	14
3.2 Normal Operation.....	15
3.3 Image Capturing	15
3.3.1 Basic Configuration Parameters	16
3.3.2 Advanced Configuration Parameters	17
3.4 Autoscanning	18
3.4.1 Normal Mode	18
3.4.2 Pattern Mode	18

3.5	Camera Control.....	19
3.6	Defining Data Formatting	20
3.6.1	Concatenation	21
	One Code Per Scan.....	21
	All Codes Per Scan.....	21
4	INITIAL SETUP	22
4.1	Setting Up Lynx™ BT with OM-1000 BT.....	22
4.1.1	RS232 Interface Selection	24
4.1.2	Wedge Interface Selection	24
4.1.3	USB Configuration and Selection.....	25
4.2	Setting Up Lynx™ BT with Bluetooth Device	27
4.2.1	Setup for Lynx™ BT Slave.....	27
4.2.2	Setup for Lynx™ BT Master.....	28
5	CONFIGURATION.....	29
5.1	Changing Default Settings	30
	RS232 INTERFACE	31
	Baud Rate	31
	Parity.....	31
	Data Bits	32
	Stop Bits.....	32
	ACK/NACK Protocol	32
	Handshake.....	32
	USB	33
	USB COM Emulation	33
	Handshake.....	33
	Ack/Nack Protocol.....	33
	USB KB Emulation.....	34
	Keyboard Nationality.....	34
	WEDGE INTERFACE.....	35
	Caps Lock	35
	Caps Lock Auto-Recognition.....	35
	Num Lock.....	35
	Keyboard Nationality	36
	Keyboard Setting	37
	Extended Header/Terminator Keys	40
	Set Custom Extended Header/Terminator Keys	41
	DATA FORMAT.....	44
	Set Headers.....	44
	Headers	44
	Set Terminators	45
	Terminators.....	45

CAMERA CONTROL	46
Exposure Mode	46
Camera Calibration	46
DATA FORMAT.....	47
Data Format Default.....	47
Symbology Independent Parameters.....	47
Code Identifier.....	47
Code Length	48
Set Headers	48
Headers	48
Set Terminators	49
Terminators.....	49
Address Stamping.....	49
Address Delimiter.....	50
Symbology Dependent Parameters	50
Custom Code Identifier	50
Symbology Specific Format	51
Symbology Headers.....	51
Headers	52
Symbology Terminators	52
Terminators.....	52
Symbology Character Substitution	53
Character Substitution	53
Symbology Character Deletion	53
Character Deletion	54
Symbology Specific Format Default	54
Concatenation	54
Define Concatenation	54
Concatenation Enable/Disable.....	54
Concatenation Options	55
First Concatenated Code Length	55
Second Concatenated Code Length	55
Third Concatenated Code Length	55
Fourth Concatenated Code Length.....	55
Concatenation with Intercode Delay	56
Concatenation Failure Transmission.....	56
Concatenation Timeout.....	56
Transmission After Timeout.....	56
Concatenation Result Code ID.....	57
POWER SAVE.....	58
Illumination System Power.....	58
CODE SELECTION	59
Linear Symbologies	59

Composite Code Selection.....	59
Discard Linear Part	59
UPC/EAN/JAN Family.....	60
Code 39 Family.....	60
Code 32 Family.....	62
Interleaved 2 of 5 Family.....	62
Codabar Family.....	63
Code 128 Family.....	64
Code 93 Family.....	65
RSS Family.....	66
2D Symbologies.....	67
PDF417.....	67
Micro PDF417.....	68
DataMatrix Family.....	68
QR Family.....	69
Postal Codes Family.....	69
Maxicode Family.....	70
READING PARAMETERS	72
Trigger Mode.....	72
Trigger Type.....	72
Flash Mode	72
Beeper Tone	73
Beeper Volume	73
Beeper Duration.....	73
Read per Cycle	74
Scan Timeout.....	74
User Defined Beeper	74
User Defined Beeper Tone	74
User Defined Beeper Volume	75
User Defined Beeper Duration	75
Test User Defined Beeper.....	75
Code Ordering and Selection.....	76
Code per Scan.....	76
Central Code Transmission.....	76
Order By Code Length	76
Order By Code Symbology	77
Autoscan	77
Autoscan Mode.....	77
Autoscan Aiming System	78
Autoscan Hardware Trigger	78
Autoscan Illumination System	78
Safety Time.....	78
Safety Time Duration	79
CAPTURE IMAGE.....	80

ADVANCED IMAGE CAPTURE.....	81
Image Preset 1.....	81
Image Format – preset 1.....	81
Resolution – preset 1.....	81
JPEG Quality Factor – preset 1.....	82
Window Dimensions – preset 1.....	82
Brightness – preset 1.....	83
Contrast – preset 1.....	83
Zoom – preset 1.....	84
Color Depth – preset 1.....	85
Image Preset 2.....	86
Image Format – preset 2.....	86
Resolution – preset 2.....	86
JPEG Quality Factor – preset 2.....	86
Window Dimensions – preset 2.....	87
Brightness – preset 2.....	88
Contrast – preset 2.....	88
Zoom – preset 2.....	89
Color Depth – preset 2.....	90
Image Preset 3.....	91
Image Format – preset 3.....	91
Resolution – preset 3.....	91
JPEG Quality Factor – preset 3.....	91
Window Dimensions – preset 3.....	92
Brightness – preset 3.....	93
Contrast – preset 3.....	93
Zoom – preset 3.....	94
Color Depth – preset 3.....	95
Image Preset 4.....	96
Image Format – preset 4.....	96
Resolution – preset 4.....	96
JPEG Quality Factor – preset 4.....	96
Window Dimensions – preset 4.....	97
Brightness – preset 4.....	98
Contrast – preset 4.....	98
Zoom – preset 4.....	99
Color Depth – preset 4.....	100
RADIO PARAMETERS	101
Radio RX Timeout.....	101
Radio Ack/Nack Protocol.....	101
Power Off Timeout when Connected.....	101
Power Off Timeout when Not Connected.....	101
User-Friendly Name.....	102
Restore Factory User-Friendly Name.....	102
Encryption.....	102

	Batch Mode.....	103
	ACK/NACK From Host.....	103
	Radio Protocol Timeout	103
	CONFIGURATION EDITING COMMANDS.....	104
	Cradle Enter and Exit Commands.....	104
	Gun Enter and Exit Commands	104
	Other Editing Commands.....	104
5.2	Advanced Data Format	106
5.2.1	Format Definition.....	107
	Method 1 - Extracting Information from Barcode.....	108
	Method 2 - Manipulating the Barcode Data.....	113
5.2.2	Match Conditions	124
5.2.3	Format Enable/Disable	126
5.2.4	Mismatch Result	127
6	REFERENCES	128
6.1	dATA fORMAT	128
6.1.1	Headers and Terminators	128
7	SYSTEM MANAGEMENT COMMANDS.....	129
	Power Off.....	129
	Unbind	129
	Software Reset	129
8	TEST BARCODE SYMBOLS	130
9	MAINTENANCE	133
9.1	Maintenance	133
10	TECHNICAL FEATURES.....	134
10.1	Indicators	138
10.1.1	LED Indicators	138
10.1.2	Beeper	138
A	PROGRAMMING FOR EXPERT USERS.....	139
	Function Description	139
B	CODE IDENTIFIER TABLE.....	144
C	HEX AND NUMERIC TABLE	146

GENERAL VIEW

LYNX™ BT



OM-1000 BT / C-1000




Aiming System ON/
Wrong Read LED
(red)




Good Read LED/
Bluetooth connection
(green)

Lynx™ BT LEDs

COMPLIANCE



Lynx™ BT Product Labels



OM-1000 BT Product Label

FCC COMPLIANCE

Modifications or changes to this equipment without the expressed written approval of Datalogic could void the authority to use the equipment.

This device complies with PART 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference which may cause undesired operation.

OM-1000 BT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RADIO COMPLIANCE

Contact the competent authority responsible for the management of radio frequency devices of your country to verify the eventual necessity of a user license.

Refer to the web site <http://europa.eu.int/comm/enterprise/rtte/spectr.htm> for further information.



WEEE COMPLIANCE



LASER SAFETY

The Lynx™ BT hand-held reader is a Class 1 LED product regarding its Illuminator and a Class 2 laser product regarding its Aiming System.


LED Illuminator

The use of an illuminator in the Lynx™ BT hand-held reader is a Class 1 LED product:

ILLUMINATORE LED CLASSE 1
 AUSLEUCHTER LED KLASSE 1
 ILLUMINATEUR A LED DE CLASSE 1
 ILUMINADOR LED DE CLASE 1

Aiming System

The Lynx aiming system meets the requirements for laser safety.



I	D	F	E
LA LUCE LASER È VISIBILE ALL'OCCHIO UMANO E VIENE EMESSA DALLA FINESTRA INDICATA NELLA FIGURA.	DIE LASER-STRAHLUNG IST FÜR DAS MENSCHLICHE AUGE SICHTBAR UND WIRD AM STRAHLAUS-TRITTSFENSTER AUSGESENDET (SIEHE BILD)	LE RAYON LASER EST VISIBLE À L'OEIL MU ET IL EST ÉMIS PAR LA FENÊTRE DÉSIGNÉE SUR L'ILLUSTRATION DANS LA FIGURE	A LUZ LÁSER ES VISIBLE AL OJO HUMANO Y ES EMITIDA POR LA VENTANA INDICADA EN LA FIGURA.
LUCE LASER NON FISSARE IL FASCIO APPARECCHIO LASER DI CLASSE 2 MASSIMA POTENZA D'USCITA: LUNGHEZZA D'ONDA EMESSA: CONFORME A EN 60825-1 (2001)	LASERSTRAHLUNG NICHT IN DEN STRAHL BLICKEN PRODUKT DER LASERKLASSE 2 MAXIMALE AUSGANGSLEISTUNG: WELLENLÄGE: ENTSPR. EN 60825-1 (2001)	RAYON LASER EVITER DE REGARDER LE RAYON APPAREIL LASER DE CLASSE 2 PUISSANCE DE SORTIE: LONGUER D'ONDE EMISE: CONFORME A EN 60825-1 (2001)	RAYO LÁSER NO MIRAR FIJO EL RAYO APARATO LÁSER DE CLASE 2 MÁXIMA POTENCIA DE SALIDA: LONGITUD DE ONDA EMITIDA: CONFORME A EN 60825-1 (2001)


ENGLISH

The following information is provided to comply with the rules imposed by international authorities and refers to the correct use of your terminal.

STANDARD LASER SAFETY REGULATIONS

This product conforms to the applicable requirements of both CDRH 21 CFR 1040 and EN 60825-1 at the date of manufacture.

For installation, use and maintenance, it is not necessary to open the device.



The product utilizes a low-power laser diode. Although staring directly at the laser beam momentarily causes no known biological damage, avoid staring at the beam as one would with any very strong light source, such as the sun. Avoid that the laser beam hits the eye of an observer, even through reflective surfaces such as mirrors, etc.


ITALIANO

Le seguenti informazioni vengono fornite dietro direttive delle autorità internazionali e si riferiscono all'uso corretto del terminale.

NORMATIVE STANDARD PER LA SICUREZZA LASER

Questo prodotto risulta conforme alle normative vigenti sulla sicurezza laser alla data di produzione: CDRH 21 CFR 1040 e EN 60825-1.

Non si rende mai necessario aprire l'appa-recchio per motivi di installazione, utilizzo o manutenzione.



Il prodotto utilizza un diodo laser a bassa potenza. Sebbene non siano noti danni riportati dall'occhio umano in seguito ad una esposizione di breve durata, evitare di fissare il raggio laser così come si eviterebbe qualsiasi altra sorgente di luminosità intensa, ad esempio il sole. Evitare inoltre di dirigere il raggio laser negli occhi di un osservatore, anche attraverso superfici riflettenti come gli specchi.


DEUTSCH

Die folgenden Informationen stimmen mit den Sicherheitshinweisen überein, die von internationalen Behörden auferlegt wurden, und sie beziehen sich auf den korrekten Gebrauch vom Terminal.

NORM FÜR DIE LASERSICHERHEIT

Dies Produkt entspricht am Tag der Herstellung den gültigen EN 60825-1 und CDRH 21 CFR 1040 Normen für die Lasersicherheit.

Es ist nicht notwendig, das Gerät wegen Betrieb oder Installations-, und Wartungsarbeiten zu öffnen.



Der Produkt benutzt eine Laserdiode. Obwohl zur Zeit keine Augenschäden von kurzen Einstrahlungen bekannt sind, sollten Sie es vermeiden für längere Zeit in den Laserstrahl zu schauen, genauso wenig wie in starke Lichtquellen (z.B. die Sonne). Vermeiden Sie es, den Laserstrahl weder gegen die Augen eines Beobachters, noch gegen reflektierende Oberflächen zu richten.


FRANÇAIS

Les informations suivantes sont fournies selon les règles fixées par les autorités internationales et se réfèrent à une correcte utilisation du terminal.

NORMES DE SECURITE LASER

Ce produit est conforme aux normes de sécurité laser en vigueur à sa date de fabrication: CDRH 21 CFR 1040 et EN 60825-1.

Il n'est pas nécessaire d'ouvrir l'appareil pour l'installation, l'utilisation ou l'entretien.



Le produit utilise une diode laser. Aucun dommage aux yeux humains n'a été constaté à la suite d'une exposition au rayon laser. Eviter de regarder fixement le rayon, comme toute autre source lumineuse intense telle que le soleil. Eviter aussi de diriger le rayon vers les yeux d'un observateur, même à travers des surfaces réfléchissantes (miroirs, par exemple).


ESPAÑOL

Las informaciones siguientes son presentadas en conformidad con las disposiciones de las autoridades internacionales y se refieren al uso correcto del terminal.

NORMATIVAS ESTÁNDAR PARA LA SEGURIDAD LÁSER


Este aparato resulta conforme a las normativas vigentes de seguridad láser a la fecha de producción: CDRH 21 CFR 1040 y EN 60825-1.

No es necesario abrir el aparato para la instalación, la utilización o la manutención.



El aparato utiliza un diodo láser a baja potencia. No son notorios daños a los ojos humanos a consecuencia de una exposición de corta duración. Eviten de mirar fijo el rayo láser así como evitarían cualquiera otra fuente de luminosidad intensa, por ejemplo el sol. Además, eviten de dirigir el rayo láser hacia los ojos de un observador, también a través de superficies reflectantes como los espejos.

This device must be opened by qualified personnel only.



OM-1000 BT POWER SUPPLY

This device is intended to be supplied by a UL Listed or CSA Certified Power Unit marked "Class 2" or "LPS" output rated 12 V, minimum 0.75 A which supplies power directly to the unit via the jack connector.

BLUETOOTH® APPROVAL

This product is equipped with the following certified Bluetooth module:

Product Name	Bluetooth ID
Panasonic Serial Port Module	B01839

1 INTRODUCTION

1.1 LYNX™ BT DESCRIPTION

The Lynx™ BT Hand-Held Reader packs a lot of performance into an attractive, rugged, hand-held device. It operates in commercial and industrial environments as well as the front office.

Omnidirectional Operating To read a symbol you simply aim the reader and pull the trigger. Since the orientation of the symbol is not important, the Lynx™ reader is a powerful, omni-directional device.

Decoding Thanks to powerful algorithms, Lynx™ reliably decodes all major 1D (linear) barcodes, 2D stacked codes (such as PDF417), 2D matrix symbols (such as DataMatrix), postal codes (such as POSTNET, PLANET). The data stream — acquired from decoding a symbol — is rapidly sent to the host. The reader is immediately available to read another symbol.

FLASH MEMORY Flash technology allows to upgrade the Lynx™ reader as new symbologies are supported or as improved decoding algorithms become available.

Lynx™ BT communicates in the 2.4 GHz ISM band and uses the Serial Port Profile (SPP). Thanks to a Bluetooth® device, such as a Bluetooth® dongle, the reader can send data to a remote Host such as a PC, PDS, printer, etc.

The OM-1000 BT cradle is provided in the package to build a Cordless Reading System for the collection, decoding and transmission of barcoded data. It can be connected to a Host PC through a USB, RS232 or Wedge emulation cable. The OM-1000 BT also allows charging the Lynx™ BT batteries.

1.2 LYNX™ BT BATTERIES

To begin using your Lynx™ BT you must charge its batteries using the OM-1000 cradle or the C-1000 battery charger as described in the following paragraph. You can install Li-Ion batteries in the Lynx™ BT.

Battery Charging

The first operation to perform is to connect the OM-1000 or the C-1000 to the power converter and firmly insert the Lynx™ BT into the cradle to charge the batteries. The red Charging LED will light. A full charge takes about 3.5 hours. The Batt. Full LED will light when charging is completed. Press the reader trigger to turn it on.



Figure 1 – OM-1000 BT Charging Batteries

The LEDs positioned on the cradle signal the status, as described in the following table:

LED	STATUS
Pwr/Data	Yellow On = cradle is powered Yellow Blinking = cradle receives commands from Host
Charging	Red On = the battery charge is in progress
Batt Full	Green On = the battery is completely charged

Replacing Lynx™ BT Batteries

To change the batteries in the Lynx™ BT, unscrew the battery cover screw, replace the old battery pack with a new one of the same type, then insert the cover onto the handle and screw it back into place. See the following figures.

To turn on the reader, press the trigger.



Battery Cover Screw



WARNING

Risk of explosion if the battery is replaced by an incorrect type. Dispose of the batteries as required by the relevant laws in force.

1.3 CONFIGURATION METHODS

1.3.1 Reading Configuration Barcodes

This manual can be used for complete setup and configuration. If you wish to change the default settings, you can configure the Lynx™ BT reader by reading the programming barcode symbols in this manual. Configuration commands and their relative arguments are read individually using the symbols in this manual. See chapter 4, and Appendix C.

1.3.2 Using VisualSetup

The Datalogic VisualSetup program, available on the CD-ROM provided, allows programming the reader by selecting configuration commands or printing them through a user-friendly graphical interface running on the PC. These commands are sent to the reader over the current communication interface; or they can be printed to be read.

1.4 BLUETOOTH® DEFINITIONS

Bluetooth® address:	a unique 12-character hexadecimal, IEEE 48-bit address (BT_ADDR) that represents a Bluetooth® device.
Bluetooth® controller:	a sub-system containing Bluetooth® RF, baseband, resource controller, link manager, device manager, and Bluetooth® HCI.
Bluetooth® device:	a device that is capable of short-range wireless communication using the Bluetooth® system.
BT:	abbreviation for Bluetooth®. Bluetooth® protocol is a predefined rule that sets out a specific system for devices to communicate with each other and a protocol stack is the layering of the protocols that are used in a specific technology. The Bluetooth® Radio protocol operates in the 2.4GHz ISM band.
Remote Bluetooth® device:	any Bluetooth® device the reader can communicate with.
SPP:	Serial Port Profile. Bluetooth® profile creating an RS232 cable replacement.
Master:	the first Bluetooth® device initiating the radio connection (Discovery procedure).
Slave:	a Bluetooth® device which can only wait for a Bluetooth® Master device to initiate a connection with it.
User-Friendly name:	a human-readable name to set for a Lynx™ BT to make it easily recognizable when operating together with other Bluetooth® devices.
Piconet:	Bluetooth® device network where a Master can communicate with up to 7 Slaves.

For further information about Bluetooth technology see the website:

<https://www.bluetooth.org/>

2 INSTALLATION

Lynx™ Bt can operate according to two different installations:

- Lynx™ BT paired with OM-1000 BT cradle (see par. 2.1);
- Lynx™ BT communicating with a Bluetooth® device as Master or as Slave (see par. 2.2).

The green LED and / or the beeper always indicate the reader radio connection status (see par. 10.1):

- the radio connection is signaled by the green LED through a single blink at regular intervals, while if the reader radio is disconnected the LED emits two short blinks at regular intervals;
- during the initialization procedure, if the radio connection attempt is successful, the reader emits four ascending tones;
- the radio disconnection is signaled by four descending tones.

2.1 OPERATING LYNX™ BT WITH OM-1000 BT

To begin using your Lynx™ BT reader you must charge the Lynx™ BT battery using OM-1000™ BT as described in par. 1.2. A full charge takes about 3.5 hours with Li-Ion batteries.

The Lynx™ BT, paired with an OM-1000 BT cradle, builds a Cordless Reading System for the collection, decoding and transmission of barcoded data.

2.1.1 OM-1000 BT Interface Cable Connections

The OM-1000™ can be connected to a Host by means of an RS232, Wedge or USB cable which must be simply plugged into the Host connector, visible on the rear panel of the cradle.

To disconnect the cable, insert a paper clip or other similar objects into the hole corresponding to the Host connector on the body of the cradle. Push down on the clip while unplugging the cable. Refer to the following figure:




Figure 2 – Connecting/Disconnecting the Cable

RS232 Connection

**CAUTION**

Connections should always be made with both PC and Cradle power off!

The OM-1000 cradle requires the RS232 interface cable and the AC/DC power adapter to be connected.

To install your cradle to your host system, follow these instructions (see Figure 3 below).

1. After charging the batteries (see par. 1.2), bind the Lynx™ BT to the OM-1000 BT by following the procedure given in par. 4.1.1;
2. Insert the RS232 cable into the OM-1000 cradle;
3. Connect the RS232 interface cable to the proper port on the host terminal;
4. Connect the power cord to the OM-1000 cradle;
5. Connect the AC/DC power adapter at the wall outlet;
6. Upon OM-1000 power up, wait for the series of beeps indicating Bluetooth connection.
7. Read the RS232 interface code in par. 4.1.1.
8. Power up your PC.



Figure 3 - RS232 Connection

Wedge

**CAUTION**

Connections should always be made with both PC and Cradle power off!

The OM-1000 cradle requires the Wedge interface cable and the AC/DC power adapter to be connected.

To install your cradle to your host system, follow these instructions (see Figure 4 below).

1. After charging the batteries (see par. 1.2), bind the Lynx™ BT to the OM-1000 BT by following the procedure given in par. 4.1.2;
2. Insert the Wedge cable into the OM-1000 cradle;
3. Connect the power cord to the OM-1000 cradle;
4. Connect the AC/DC power adapter at the wall outlet;
5. Upon OM-1000 power up, wait for the series of beeps indicating Bluetooth connection.
6. BEFORE CONNECTING THE WEDGE CABLE TO THE PC AND KEYBOARD, read the Wedge IBM AT interface code in par. 4.1.2.
7. Connect the WEDGE interface cable between the keyboard and the host terminal.
8. Power up your PC.

Wedge AT is the default interface set at the factory.




Figure 4 - Wedge Connection

**CAUTION**

When not using the OM-1000 cradle remember to disconnect the Wedge interface from the PC before disconnecting the power cord.

**NOTE**

It is always necessary to use an external power supply connected to the OM-1000 cradle.

USB Connection

The OM-1000 cradle requires the USB interface cable and the AC/DC power adapter to be connected.

To install your cradle to your host system, follow these instructions (see Figure 5 below).

1. After charging the batteries (see par. 1.2), bind the Lynx™ BT to the OM-1000 BT by following the procedure given in par. 4.1.3;
2. Insert the USB cable into the OM-1000 cradle;
3. Connect the USB cable to the PC;
4. Connect the power cord to the OM-1000 cradle;
5. Connect the AC/DC power adapter at the wall outlet.
6. Upon OM-1000 power up, wait for the series of beeps indicating Bluetooth connection.
7. Read the correct USB interface code for your application in par. 4.1.3.
8. Connect the USB interface cable to a free USB port. The PC automatically recognizes the device and asks to install the device driver.
9. Install the USB driver on your PC (the first time only) to complete the connection.
 - For USB COM the relevant files and drivers must be installed from the USB Device Installation software which can be downloaded from the web site <http://www.datalogic.com>.
 - For USB Keyboard the correct USB driver is included in the Host Operating System and will either be loaded automatically or will be suggested by the O.S. and should therefore be selected from the dialog box.




Figure 5 – USB Connection



NOTE

The OM-1000 cradle is a USB self-powered device.

2.2 OPERATING LYNX™ BT WITH BLUETOOTH® DEVICE

During typical operation a physical radio channel is shared by a group of devices that are synchronized to a common clock and frequency hopping pattern. One device provides the synchronization reference and is known as the Master. All other devices are known as Slaves. A group of devices synchronized in this fashion form a piconet.

Most Bluetooth® devices can be both Master or Slave. The Master will be the first unit to initiate the connection (page procedure).

Some devices can only be Slaves (i.e. printers). They can only wait for a Bluetooth® Master device to initiate a connection with them.

Lynx™ BT can be either Master or Slave. As Master it can initiate a connection with only one Slave device.

2.2.1 Lynx™ BT as Slave

Once set as Slave, a Lynx™ BT reader requires no particular configuration for communication, however some radio parameters can be set to increase system performance and data transmission security. At startup the reader can only wait for the Master to initialize the radio communication.

The following is a general procedure recommended for Lynx™ BT Slave applications:

1. Power up the remote Bluetooth® Master device (example Laptop or PC).
2. Power up the Lynx™ BT reader within radio range (10 meters).
Any modifications to the radio configuration should be made at this time before the radio connection takes place.
3. From the remote Bluetooth® Master device, execute the Discovery procedure, (according to the procedure given in the documentation of the Bluetooth® Master device), to recognize the Lynx™ BT reader(s) within radio range.
4. Check that "**Lynx BTx00** " is shown among the discovered devices.
5. Request to open an SPP connection with Lynx™ BT, making sure to disable any required PIN and/or pairing parameters. Lynx™ BT is always discoverable and connectable without any required PIN.



NOTE

If the PIN of the Bluetooth® Master device cannot be disabled, use the PIN "1234". The Lynx™ BT Slave will emit four ascending tones indicating radio connection.

After the Lynx™ BT reader(s) indicate radio connection (see also par. 10.1), you can start sending barcodes.

The following figure shows an example Lynx™ BT Slave application.




Figure 1 - Lynx™ BT Slave Application

If the Master Bluetooth® device can support a **piconet**, the communication can be established with up to **7 seven Slave** readers at the same time.

2.2.2 Lynx™ BT as Master

Once set as Master, a Lynx™ BT reader must be configured with the address of the Slave device to which it wants to communicate.

By default, at startup the reader initializes the communication with the Slave. If the connection is successful, the reader can send barcodes to the Slave device. Radio connections can also be managed manually as described in pars., **Errore. L'origine riferimento non è stata trovata.** and **Errore. L'origine riferimento non è stata trovata.**

During the request of radio connection or disconnection with a remote Bluetooth® Slave device, the reader emits a series of ticks and short blinks of the green LED.

The following figure shows an example Lynx™ BT Master application.



Figure 2 - Lynx™ BT Master Application

2.2.3 Data Transmission

The transmission of data can be transparent (no ACK/NACK protocol), when each character is read and immediately sent to the Host (default value). Otherwise, data transmission can be with flow control (with ACK/NACK protocol), when, after each reading, Lynx™ BT waits for an acknowledge that the remote Host received the data before reading and sending the following code.

2.2.4 Wedge Emulation Utility

This utility is provided on the CD-ROM. When using the Wedge Emulation Utility, it is advised to correctly set the terminators depending on the expected format for the program in which the data will be collected.

3 USING LYNX™ BT

3.1 AIMING SYSTEM

The LYNX™ reader uses an intelligent aiming system similar to those on cameras. The aiming system creates a field of view where the code is to be positioned:




Figure 6 - Aiming System

When you pull the trigger completely a red beam illuminates the code. If the aiming system is centered and the entire symbology is within the aiming system, you will get a good read. The field of view changes size as you move the reader closer or farther away from the code.




Figure 7 - Relative Size and Location of Aiming System Pattern

The field of view created by the aiming system will be smaller when the Lynx™ is closer to the code and larger when it is farther from the code. Symbologies with smaller bars or elements (mil size) should be read closer to the unit. Symbologies with larger bars or elements (mil size) should be read farther from the unit. (See chapter 7 for further details).

3.2 NORMAL OPERATION

Lynx™ normally functions by capturing and decoding codes.

Point the reader at the target and pull the trigger partially to enable the aiming system. Then, pull it completely to capture and decode the image. The reader will repeatedly flash until the symbol is decoded or timeout is reached. In between the flashes of the reader, the aiming system keeps on showing the field of view on the target (see Figure 7).

As you are reading code symbols, adjust the distance at which you are holding the reader.



NOTE

The LYNX™ hand-held reader aiming system is designed for general reading and decoding of 1D and 2D symbols. Some variation in reading distance will occur due to narrow bar width and other factors.

3.3 IMAGE CAPTURING

Lynx™ can also function as a camera by capturing images of labels, signatures, and other items.

In order to capture an image, the user should read a Capture Image code (see par 0), then point at the image subject and pull the trigger. This way, the image will be captured and sent to the host PC. Lynx™ then returns to normal operation. To capture another image you must read another Capture Image Code of the same or a different Preset Configuration.

You can use the aiming system to position the reader from the object (ensure the reader is about centered over the target). Adjust the distance at which you are holding the reader (see Figure 7).

If the RS232 interface has been selected, the image will be transferred to the host PC via XMODEM_1K protocol.

**NOTE**

Image capturing is not available in Wedge and USB Keyboard Emulation interfaces and is not compatible with Autoscanning nor when the Software trigger type is selected.

Up to four different and independent Image Presets can be defined (see par. 0). For each Image Preset you may set up to three Basic Configuration Parameters, and up to five Advanced Configuration Parameters. Therefore an image is processed before being sent to the Host, according to a preset group of parameters.

3.3.1 Basic Configuration Parameters


The Image file formats supported are: BMP, TIFF, JPEG (default).

Two resolution options are available: VGA Resolution (640 x 480 pixels) (default), and CIF Resolution (320 x 240 pixels). The lower resolution setting yields smaller file sizes, so the transfer time decreases.

For JPEG images it is possible to define the Image Quality level to address tradeoff between image file size and quality.

3.3.2 Advanced Configuration Parameters

An image portion (Window), instead of an entire image, can be captured. This parameter is generally used for particular fixed reading position applications.



An Image Window may either be as large as the image itself or smaller (10 x 10 pixels minimum), and is defined by its origin (the coordinate X_0, Y_0), its width (number of pixels along the X Axis) and its height (number of pixels along the Y Axis).

By default, for all Image Presets, the window has its origin coordinates equal to zero, its width equal to 640 pixels and its height to 480 pixels.

It is possible to perform Zooming of the image. The zoom range varies from 20% up to 200% in steps of 20%, so ten different settings are available. Default is 100% (no zoom).

In addition to Windowing and Zoom you can adjust Brightness and Contrast levels.

Brightness Adjustment is available in the range from -100% up to 100%, in steps of 1%. Positive values shift the luminance up so that the image will result brighter. Default value is 0%, meaning that no brightness adjustment is performed.

The same range of values (–100% up to 100%, in steps of 1%) is available for Contrast Adjustment. Positive values will increase the contrast, so that dark and bright objects inside the image will be better distinguishable. Default value is 0%, which means that no contrast adjustment is performed.

You can set the Image Color Depth by selecting 256 gray levels (default), 16 gray levels, or 2 gray levels. Higher color depths yield larger image files. This option is ignored if the JPEG format is selected,(256 gray levels only).

3.4 AUTOSCANNING

3.4.1 Normal Mode

Lynx™ provides an **autoscan** command (see par. 0), which when enabled, causes the reader to scan continuously and to monitor the central zone of its reading area. In this way, Lynx™ is ready to capture any image (containing a potential code) positioned on a uniform background.

The aiming system can be enabled to indicate the reading area of the potential code to be captured. The illumination system can also be enabled when the ambient light conditions are not sufficient to autodetect the potential code to be captured; furthermore, the illumination system increases in intensity for an instant when capturing and decoding an image. A safety time may be defined to prevent Lynx™ from reading the same code repeatedly.

If the decoding is completed successfully, the reader starts monitoring the reading area again. In case of decoding failure, Lynx™ keeps on decoding until a potential code is present in the central zone of the reading area.

3.4.2 Pattern Mode

The Autoscan pattern mode is particularly advised when reading barcodes positioned on a non-uniform background. In these cases Lynx™ may perceive some elements of the background as barcodes and start the decoding. To avoid this undesired effect, the Autoscan Pattern Code is placed in the Lynx™ reading area which prevents decoding. Using this code as the background, code reading takes place normally by presenting desired codes to be read over the Pattern Code. Between each code read, the Pattern Code must be represented to Lynx™.

The Pattern Code can be printed from the file of the manual (Appendix C) available on the CD-ROM.

In case of low ambient light conditions, Lynx™ automatically activates the illumination system. If desired, the illumination system can be enabled so that it is always active.

3.5 CAMERA CONTROL

Exposure and Calibration

Two different control modes are available for managing the camera: automatic mode and fixed mode.

The automatic mode provides three different options to get the best tuning of the image to be captured:

- Automatic based on entire image: camera control mode based on the analysis of the whole image. This mode works well in most standard applications. It is the default setting.
- Automatic based on central image: camera control mode based on the analysis of a restricted area positioned in the central zone of the image. This mode is suggested when reading small codes positioned in a dark and extensive background.
- Automatic for highly reflective surfaces: camera control mode allowing to read codes on highly reflective surfaces. This mode is suggested, for example, when reading codes positioned on plastic or metal surfaces.

The fixed mode is particularly suggested for expert users. It requires a camera calibration to adjust the acquisition parameters to the ambient light conditions. The defined values will always be used when working with a fixed exposure.

These values are permanently saved in the reader memory.

Refer to par. 0 for configuration barcodes.

Aiming System Calibration

The factory-defined Lynx™ aiming system is already correctly and precisely calibrated to the Lynx™ focus distance and therefore works for the most typical applications. However, it is possible to modify the aiming system precision for the following condition:

when a fixed reading distance different from the Lynx™ focus distance is used.
The Lynx™ focus distance is 115 mm for Lynx™ D432, and 65 mm for Lynx™ D432E.

Refer to the VisualSetup software program for performing the aiming system calibration.

3.6 DEFINING DATA FORMATTING



CAUTION

Headers and terminators can be set for both cradle and reader. If working with a Lynx™ BT paired with an OM-1000, the cradle headers and terminators have the priority while the reader's ones are ignored (refer to par. 5.1 and par. 6.1.1).

The string of a decoded code to be sent to the host may be formatted as follows:

- defining simple **data formatting** (see "Data Format" in par. 5.1);
- defining **advanced data formatting** giving complete flexibility in changing the format of data (see par. 5.2).

When both simple and advanced data formatting are selected the info is processed in the following order:

1. the string of the decoded code is processed according to the advanced formatting rules;
2. the resulting string is processed according to the selection type rules of the simple data formatting;
3. character substitution is performed on the resulting string;
4. character deletion is performed on the resulting string;
5. code concatenation is performed;
6. code ID is attached to the resulting string;
7. global headers and terminators are attached to the resulting string;

The codes to be sent to the host may also be selected or ordered depending on the following two conditions:

- **one code per scan:** Lynx™ sends the code being closest to the image center. If the "Central Code Transmission" command is enabled, only the code containing the image center will be transmitted (see "Reading Parameters" in par. 5.1);
- **all codes per scan:** the codes to be sent to the host may be ordered either by length or by symbology starting from the code being closest to the image center (see par. "Reading Parameters" in par. 5.1). When enabling both these criteria, codes belonging to the same symbology are sent to the host depending on their length.

3.6.1 Concatenation

It is possible to concatenate up to 4 different codes, set their length and enable the intercode delay between them (the intercode delay is set in the specific interface parameters in pars. 5.1). When enabling the delay one or more global headers and terminators are added to the decoded data. The concatenation procedure may occur in different ways depending on the number of codes to be decoded per image:

One Code Per Scan

- If the code resulting from the single decoding of an image belongs to one of the code families to be concatenated, it is saved to the Lynx™ memory waiting for other codes to complete the concatenation.
- If the code belongs to the same family of a code previously saved, it overwrites the old one.
- If the code resulting from the decoding does not belong to one of the code families to be concatenated, it causes the concatenation failure and clears the temporary memory. If the "Concatenation Failure Transmission" command is set to "Tx codes causing failure", this code will be sent in the output message.

All Codes Per Scan

- All codes resulting from the decoding of an image and belonging to one of the families to be concatenated are saved to the Lynx™ memory waiting for other codes to complete the concatenation.
- If one or more codes resulting from the decoding belong to the same family of codes previously saved, they overwrite the old ones.

When the image contains no code to be concatenated, the concatenation fails and the reader temporary memory is cleared. If the "Concatenation Failure Transmission" command is set to "Tx codes causing failure", the codes causing the concatenation failure will be sent in the output message.

4 INITIAL SETUP

This procedure allows setting up the reader to operate with the default settings.

Two different procedures are available according to the type of application you are working with:

- Lynx™ BT paired to the OM-1000 BT (follow procedure in par. 4.1);
- Lynx™ BT communicating with a Bluetooth® device (follow procedure in par. 4.2).

Whenever you need to change the default values refer to par. 5.1.

4.1 SETTING UP LYNX™ BT WITH OM-1000 BT

Follow the given procedure to make Lynx™ BT communicating with OM-1000 BT.

1. Read the restore default parameters code below.

Restore Lynx™ BT Default



2. Read the **Bind** code to pair the Lynx™ BT to the OM-1000 BT cradle.
The reader is dedicated to the cradle. Any previously **bound** reader will be excluded.

Bind



The green LED on the Lynx™ BT will blink; the reader is ready to be inserted into the cradle.

3. Firmly insert the reader into the OM-1000 BT cradle within 4 seconds, a series of beeps will be emitted, signaling that the OM-1000 BT cradle has been paired to the Lynx™ BT, and the green LED on the reader will go off.



4. Complete the desired installation procedure referring to par. 2.1.1;
5. Configure the OM-1000 BT cradle. Refer to the following procedures depending on the interface selection code required for your application:
 - RS232 Interface (par. 4.1.1)
 - Wedge Interface (par. 4.1.2)
 - USB Interface (par. 4.1.3)

4.1.1 RS232 Interface Selection

1. Read the OM-1000 BT restore default parameter code below.

Restore OM-1000 BT Default



2. Read the RS232 interface selection code:

RS232



4.1.2 Wedge Interface Selection

1. Read the OM-1000 BT restore default parameter code below.

Restore OM-1000 BT Default



2. Read the interface selection code for your application:

Wedge - IBM AT



4.1.3 USB Configuration and Selection

The USB interface is compatible with:

Windows 98 (and later)	IBM POS for Windows
Mac OS 8.0 (and later)	4690 Operating System


USB START-UP

As with all USB devices, upon connection, the Host performs several checks by communicating with the OM-1000 BT. Before the OM-1000 BT is ready, the correct USB driver must be loaded.

For all systems, the correct USB driver for the default USB-KBD interface is included in the Host Operating System and will either be loaded automatically or will be suggested by the O.S. and should therefore be selected from the dialog box (the first time only).

You can now read codes with the associated Lynx™ BT reader. At this point you can read the USB interface configuration code according to your application. Load drivers from the O.S. (if requested). When configuring the USB-COM interface, the relevant files and drivers must be installed from the USB Device Installation software which can be downloaded from the web site: <http://www.datalogic.com>.

The OM-1000 BT is ready.



Successive start-ups will automatically recognize the previously loaded drivers.

USB INTERFACE SELECTION

USB-KBD (default)



USB-COM¹



¹ When configuring USB-COM, the relevant files and drivers must be installed from the USB Device Installation software which can be downloaded from the web page (see <http://www.datalogic.com>). If resetting to the USB-COM interface, check the RX Timeout selection in the [Radio Parameters](#) group.

4.2 SETTING UP LYNX™ BT WITH BLUETOOTH DEVICE

Follow one of the following two procedures to set up Lynx™ BT as Slave or as Master according to your application.

4.2.1 Setup for Lynx™ BT Slave

1.

Restore Lynx™ BT Default



2.

Set Lynx™ BT as Slave



3.

Reset Lynx™ BT



YOUR READER IS NOW READY TO BE DISCOVERED (CONNECTED VIA RADIO) BY A BLUETOOTH® MASTER DEVICE AND READ BARCODES.

To change the defaults see par. 5.1.

4.2.2 Setup for Lync™ BT Master

1. **Restore Lync™ BT default**



2. **Set Lync™ BT as Master**



3. **Enter configuration**



4. **Set Remote Bluetooth® Device Address (slave)**



+

12 characters for the remote Bluetooth® device address specified in each Bluetooth® device.

5. **Exit and Save configuration**



6. **Request Radio Connection with Slave**



If the connection is not successful, you can attempt a connection manually by double-clicking the reader trigger.

YOUR READER IS NOW READY TO READ BARCODES.

5 CONFIGURATION

This section describes the programming method of using configuration barcode symbols to program your reader. By using the Lynx™ BT reader to read/decode these special configuration symbols, you can configure, and obtain information from its system software.

When you are reading configuration barcode symbols, carefully aim the 2D reader to avoid reading adjacent symbols.

The configuration barcode symbols in this chapter are divided into logical sections according to the type of configuration required, (RS232 configuration, Code selection, etc.). On top of each section it is indicated the device (Lynx™ Bt reader or OM-1000 BT cradle) to be configured through the selected parameter group, see the example:





Figure 8 – Configuration Page Example

If arguments are required with a command, you can read additional barcode labels (typically digits) from Appendix A.



NOTE *During configuration be careful that the selected section contains parameters configuring the device you are working with.*

5.1 CHANGING DEFAULT SETTINGS

Once your reader is setup, you can change the default parameters to meet your application needs. Refer to the preceding paragraphs for initial configuration in order to set the default values and select the interface for your application.

In this manual, the configuration parameters are divided into logical groups making it easy to find the desired function based on its reference group.

The first three groups are for Cradle parameter configuration:

- **RS232**
- **USB**
- **WEDGE**
- **DATA FORMAT**

The following parameter groups are for Gun parameter configuration :

DATA FORMAT parameters regard the messages sent to the Host system.

CAMERA CONTROL parameters regard the control mode managing the camera.

POWER SAVE parameters manage overall current consumption in the reading device.

CODE SELECTION parameters allow configuration of a personalized mix of codes, code families and their options.

READING PARAMETERS control various operating modes and indicator status functioning.

CAPTURE IMAGE parameters activate image capturing.

ADVANCED CAPTURE IMAGE parameters define options of the image to capture.

RADIO PARAMETERS allow configuration of radio control parameters.

ADVANCED DATA FORMAT parameters allow advanced formatting of messages towards the Host.

Enter Cradle Configuration



CRADLE
RS232

Exit and Save Cradle Configuration



RS232 INTERFACE

BAUD RATE

9600 baud



38400 baud



57600 baud



115200 baud



PARITY

None



Odd



Even



Enter Cradle Configuration



CRADLE
RS232

Exit and Save Cradle Configuration



DATA BITS

7 Bits



8 Bits



STOP BITS

1 Bit



2 Bits



ACK/NACK PROTOCOL

Disabled



Enabled



HANDSHAKE

None



XON/XOFF



RTS/CTS



Enter Cradle Configuration



CRADLE
USB

Exit and Save Cradle Configuration



USB

USB COM Emulation

HANDSHAKE

None



XON/XOFF



RTS/CTS



ACK/NACK PROTOCOL

Disabled



Enabled



Enter Cradle Configuration



CRADLE
USB

Exit and Save Cradle Configuration



USB KB Emulation

KEYBOARD NATIONALITY

This parameter default value is restored through the Interface Selection code and not Restore Default.

Belgian



English



French



German



Italian



Japanese



Spanish



Swedish



USA



Enter Cradle Configuration



**CRADLE
WEDGE**

Exit and Save Cradle Configuration



WEDGE INTERFACE

CAPS LOCK

Caps Lock Off



Caps Lock On



CAPS LOCK AUTO-RECOGNITION

Disabled



Enabled



Note: Caps lock manual configuration is ignored when Caps Lock Auto-Recognition is enabled

NUM LOCK

Num Lock Off



Num Lock On



Enter Cradle Configuration



**CRADLE
WEDGE**

Exit and Save Cradle Configuration



KEYBOARD NATIONALITY

This parameter default value is restored through the Interface Selection code and not Restore Default.

Belgian



English



French



German



Italian



Japanese



Spanish



Swedish



USA



Enter Cradle Configuration



**CRADLE
WEDGE**

Exit and Save Cradle Configuration



KEYBOARD SETTING

This parameter values are restored through the Interface Selection code and not Restore Default.

Set Alphanumeric Keys



The reader can be used with terminals or PCs with various keyboard types and nationalities through a simple keyboard setting procedure.

Keyboard setting consists of communicating to the reader how to send data corresponding to the keyboard used in the application. The keys must be set in a specific order.

Press and release a key to set it.

Some characters may require more than one key pressed simultaneously during normal use (refer to the manual of your PC or terminal for keyboard use). The exact sequence must be indicated to the reader in this case pressing and releasing the different keys.

Example:

If one has to press the "Shift" and "4" keys simultaneously on the keyboard to transmit the character "\$" to the video, to set the "\$", press and release "Shift" then press and release "4".

Each pressed and released key must generate an acoustic signal on the reader, otherwise repress the key. Never press more than one key at the same time, even if this corresponds to the normal use of your keyboard.

Press "Backspace" to correct a wrong key entry. In this case the reader emits 2 beeps.

Note: "CAPS LOCK" and "NUM LOCK" must be off before starting the keyboard setting procedure. "SHIFT" must be repressed for each character and cannot be substituted by "CAPS LOCK".

1. Read the "Set Alphanumeric Keys" code.
2. Press the keys shown in the following table according to their numerical order:

Enter Cradle Configuration



**CRADLE
WEDGE**

Exit and Save Cradle Configuration



Some ASCII characters may be missing as this depends on the type of keyboard: these are generally particular characters relative to the various national symbologies. In this case:

- **The first 4 characters (Shift, Alt, Ctrl, and Backspace) can only be substituted with keys not used, or substituted with each other.**
- Characters can be substituted with other single symbols (e.g. "SPACE") even if not included in the barcode set used.
- Characters can be substituted with others corresponding to your keyboard.

The reader signals the end of the procedure with 2 beeps indicating the keys have been registered.

01 : Shift		
02 : Alt		
03 : Ctrl		
04 : Backspace		
05 : SPACE	28 : 7	51 : N
06 : !	29 : 8	52 : O
07 : "	30 : 9	53 : P
08 : #	31 : :	54 : Q
09 : \$	32 : ;	55 : R
10 : %	33 : <	56 : S
11 : &	34 : =	57 : T
12 : '	35 : >	58 : U
13 : (36 : ?	59 : V
14 :)	37 : @	60 : W
15 : *	38 : A	61 : X
16 : +	39 : B	62 : Y
17 : ,	40 : C	63 : Z
18 : -	41 : D	64 : [
19 : .	42 : E	65 : \
20 : /	43 : F	66 :]
21 : 0	44 : G	67 : ^
22 : 1	45 : H	68 : _ (underscore)
23 : 2	46 : I	69 : `
24 : 3	47 : J	70 : {
25 : 4	48 : K	71 :
26 : 5	49 : L	72 : }
27 : 6	50 : M	73 : ~
		74 : DEL

Enter Cradle Configuration



CRADLE
WEDGE

Exit and Save Cradle Configuration



Acoustic Signals

Four types of acoustic signals are associated with the following steps:

1. Enter keyboard setup
2. Exit keyboard setup
3. SHIFT, ALT, CTRL, BACKSPACE keys
4. Keyboard keys (SHIFT, ALT, CTRL, BACKSPACE excluded)

These signals facilitate the selection of those characters requiring more than one key pressed simultaneously.

Example

The transmission of the "%" character implies two different steps:

1. Press the SHIFT key
2. Press the "5" key

The different tones produced by the reader indicate that both steps have been successful and that the character has been transmitted.

Enter Cradle Configuration



**CRADLE
WEDGE**

Exit and Save Cradle Configuration



EXTENDED HEADER/TERMINATOR KEYS

For the WEDGE interface, the following extended keyboard values can also be configured:

These values are restored through the Interface Selection code and not Restore Default.

EXTENDED KEYBOARD TO HEX CONVERSION	
	IBM AT
HEX	KEY
83	ENTER
84	TAB
85	F1
86	F2
87	F3
88	F4
89	F5
8A	F6
8B	F7
8C	F8
8D	F9
8E	F10
8F	F11
90	F12
91	HOME
92	END
93	PG UP
94	PG DOWN
95	↑
96	↓
97	←
98	→
99	ESC
9A	CTRL (Right)
9B	Euro

Enter Cradle Configuration



**CRADLE
WEDGE**

Exit and Save Cradle Configuration



SET CUSTOM EXTENDED HEADER/TERMINATOR KEYS

Set Extended Keys



The extended Header/Terminator keys for **Wedge Interface users** can be customized by defining them through a simple keyboard setting procedure.

For example, the Numeric Keypad keys can be set for use as Headers or Terminators by substituting the default extended keys during this procedure.

Press and release a key to set it.

Some characters may require more than one key pressed simultaneously during normal use (refer to the manual of your PC or terminal for keyboard use). The exact sequence must be indicated to the reader in this case pressing and releasing the different keys.

Example:

If one has to press the "Shift" and "4" keys simultaneously on the keyboard to transmit the character "\$" to the video, to set the "\$", press and release "Shift" then press and release "4".

Each pressed and released key must generate an acoustic signal on the reader, otherwise repress the key. Never press more than one key at the same time, even if this corresponds to the normal use of your keyboard.

Press "Backspace" to correct a wrong key entry. In this case the reader emits 2 beeps.

Note: "CAPS LOCK" and "NUM LOCK" must be off before starting the keyboard setting procedure. "SHIFT" must be repressed for each character and cannot be substituted by "CAPS LOCK".

1. Read the "Set Extended Keys" code.
2. Press the first 4 keys indicated in the following table.
3. Define all keys from 5 to 28 in the following table.

Enter Cradle Configuration



**CRADLE
WEDGE**

Exit and Save Cradle Configuration



If the first 4 KEYS (Shift, Alt, Ctrl, and Backspace) are not available on your keyboard, you can only substitute them with keys not used, or substitute them with each other.

The reader signals the end of the procedure with 2 beeps indicating the keys have been registered.

CUSTOM EXTENDED KEYBOARD SETTING TABLE		
		Custom
Order	HEX	KEY
01	-	Shift
02	-	Alt
03	-	Ctrl
04	-	Backspace
05	83	
06	84	
07	85	
08	86	
09	87	
10	88	
11	89	
12	8A	
13	8B	
14	8C	
15	8D	
16	8E	
17	8F	
18	90	
19	91	
20	92	
21	93	
22	94	
23	95	
24	96	
25	97	
26	98	
27	99	
28	9A	

Enter Cradle Configuration



CRADLE
WEDGE

Exit and Save Cradle Configuration



Acoustic Signals

Four types of acoustic signals are associated with the following steps:

1. Enter keyboard setup
2. Exit keyboard setup
3. SHIFT, ALT, CTRL, BACKSPACE keys
4. Keyboard keys (SHIFT, ALT, CTRL, BACKSPACE excluded)

These signals facilitate the selection of those characters requiring more than one key pressed simultaneously.

Example

The transmission of the "%" character implies two different steps:

1. Press the SHIFT key
2. Press the "5" key

The different tones produced by the reader indicate that both steps have been successful and that the character has been transmitted.

Enter Cradle Configuration



CRADLE DATA FORMAT

Exit and Save Cradle Configuration



DATA FORMAT

SET HEADERS

Set Headers



1. Set the number of characters in the range **00-10**.
2. Read the corresponding characters as Hex values from the Hex/Numeric table. Valid values are in the range:
00-7F for RS232, USB BULK, USB COM, USB Generic HID
00-9B for Wedge and USB Keyboard
3. Read the following code to enable the configuration you have set.

HEADERS

Disabled



Enabled



Enter Cradle Configuration



CRADLE
DATA FORMAT

Exit and Save Cradle Configuration



SET TERMINATORS

Set Terminators



1. Set the number of characters in the range **00-10**.
2. Read the corresponding characters as Hex values from the Hex/Numeric table. Valid values are in the range:
00-7F for RS232, USB BULK, USB COM, USB Generic HID
00-9B for Wedge and USB Keyboard
3. Read the following code to enable the configuration you have set.

TERMINATORS

Disabled



Enabled



Enter Gun Configuration



GUN
CAMERA CONTROL

Exit and Save Gun Configuration



CAMERA CONTROL

EXPOSURE MODE

Fixed



Automatic (Entire Image)



Automatic (Central Part of Image)



Automatic for Highly
Reflective Surfaces



See par. 3.5 for details.

CAMERA CALIBRATION

Calibrate



Calibrates the correct exposure parameter values when using fixed exposure. The parameters defined will be permanently saved in the reader memory (see par. 3.5 for details).

Enter Gun Configuration



GUN
DATA FORMAT

Exit and Save Gun Configuration



DATA FORMAT

With the exception of the Symbology Independent Header and Terminator selections, the parameters of this group can be restored to their default values using the following default code settings:

- 1) the general “Restore Default” code restores all the configuration parameter groups to their default values;
- 2) the “Data Format Default” code restores the Data Format Symbology Independent and Symbology Dependent parameters to their default values and disables the defined concatenation by resetting all its parameters.

The default values of the Symbology Independent Header and Terminator selections are set when reading the interface selection.

DATA FORMAT DEFAULT

Data Format Default



Symbology Independent Parameters

CODE IDENTIFIER

Disabled



Custom Code ID



Enter Gun Configuration



GUN
DATA FORMAT

Exit and Save Gun Configuration



AIM Standard Code ID



CODE LENGTH

Disabled



Enabled



SET HEADERS

Set Headers



3. Set the number of characters in the range **00-10**.
4. Read the corresponding characters as Hex values from the Hex/Numeric table. Valid values are in the range:
00-7F for RS232, USB BULK, USB COM, USB Generic HID
00-9B for Wedge and USB Keyboard
4. Read the following code to enable the configuration you have set.

HEADERS

Disabled



Enabled



Enter Gun Configuration



GUN
DATA FORMAT

Exit and Save Gun Configuration



SET TERMINATORS

Set Terminators



3. Set the number of characters in the range **00-10**.
4. Read the corresponding characters as Hex values from the Hex/Numeric table. Valid values are in the range:
00-7F for RS232, USB BULK, USB COM, USB Generic HID
00-9B for Wedge and USB Keyboard
4. Read the following code to enable the configuration you have set.

TERMINATORS

Disabled



Enabled



ADDRESS STAMPING

Disabled



Enabled



Enter Gun Configuration



GUN
DATA FORMAT

Exit and Save Gun Configuration



ADDRESS DELIMITER

**Disable Reader Address
Delimiter**



**Enable Reader Address
Delimiter**



Read 2 HEX character in the
range **00-FE**.

Symbology Dependent Parameters

The “Symbology Specific Format Default” code on page 54 allows restoring the symbology dependent parameters related to a specific code family to the default values.

CUSTOM CODE IDENTIFIER

Custom Code Identifier



1. Select a Datalogic Standard Code Identifier from the Code Identifier Table in Appendix B.
2. Set the number of characters in the range **0-3**, where **0** = Code ID disabled.
3. Read the corresponding characters as Hex values from the Hex/Numeric table. Valid values are in the range **00-7F**.

Enter Gun Configuration



GUN
DATA FORMAT

Exit and Save Gun Configuration



SYMBOLGY SPECIFIC FORMAT

Symbology Specific Format



1. Select a Datalogic Standard Code Identifier from the Code Identifier Table in Appendix B.
2. Formatting:
 - 0 = select all - Stop
 - 1 = select right - followed by Step 3
 - 2 = select left - followed by Step 3
 - 3 = select middle - followed by a number in the range **000-999** for the starting character and then, by Step 3
 - 4 = discard right - followed by Step 3
 - 5 = discard left - followed by Step 3
 - 6 = discard middle - followed by a number in the range **000-999** for the starting character and then, by Step 3
3. Set the number of characters to select/discard in the range **000-999**.

SYMBOLGY HEADERS

Symbology Headers



1. Select a Datalogic Standard Code Identifier from the Code Identifier Table in Appendix B.
2. Set the number of characters in the range **0-5**.
 5. Read the corresponding characters as Hex values from the Hex/Numeric table. Valid values are in the range:
00-7F for RS232, USB BULK, USB COM, USB Generic HID
00-9B for Wedge and USB Keyboard
5. Read the following code to enable the configuration you have set.

Enter Gun Configuration



Exit and Save Gun Configuration



GUN
DATA FORMAT

HEADERS

Headers



1. Select a Datalogic Standard Code Identifier from the Code Identifier Table in Appendix B.
2. 0 = disabled
1 = enabled

SYMBOLGY TERMINATORS

Symbology Terminators



1. Select a Datalogic Standard Code Identifier from the Code Identifier Table in Appendix B.
2. Set the number of characters in the range **0-5**.
3. Read the corresponding characters as Hex values from the Hex/Numeric table. Valid values are in the range:
00-7F for RS232, USB BULK, USB COM, USB Generic HID
00-9B for Wedge and USB Keyboard
5. Read the following code to enable the configuration you have set.

TERMINATORS

Terminators



1. Select a Datalogic Standard Code Identifier from the Code Identifier Table in Appendix B.
2. 0 = disabled
1 = enabled

Enter Gun Configuration



GUN
DATA FORMAT

Exit and Save Gun Configuration



SYBOLOGY CHARACTER SUBSTITUTION

Symbology Character Substitution



1. Select a Datalogic Standard Code Identifier from the Code Identifier Table in Appendix B.
2. Read the corresponding character as Hex value from the Hex/Numeric table which identifies the character to be substituted. Valid value is in the range **00-7F**.
3. Read the corresponding character as Hex value from the Hex/Numeric table which identifies the new substituting character. Valid value is in the range **00-7F**.
4. Read the following code to enable the configuration you have set.

CHARACTER SUBSTITUTION

Character Substitution



1. Select a Datalogic Standard Code Identifier from the Code Identifier Table in Appendix B.
2. 0 = disabled
1 = enabled

SYBOLOGY CHARACTER DELETION

Symbology Character Deletion



1. Select a Datalogic Standard Code Identifier from the Code Identifier Table in Appendix B.
2. Read the corresponding character as Hex value from the Hex/Numeric table which identifies the character to be deleted. Valid value is in the range **00-7F**.
3. Read the following code to enable the configuration you have set.

Enter Gun Configuration



Exit and Save Gun Configuration



GUN
DATA FORMAT

CHARACTER DELETION

Character Deletion



1. Select a Datalogic Standard Code Identifier from the Code Identifier Table in Appendix B.
2. 0 = disabled
1 = enabled

SYMBOLGY SPECIFIC FORMAT DEFAULT

Symbology Specific Format
Default



Select a Datalogic Standard Code Identifier from the Code Identifier Table in Appendix B.

Concatenation

DEFINE CONCATENATION

Define Concatenation



1. Select the number of codes to concatenate in the range **2-4**.
2. Select the Datalogic Standard Code Identifier for each code to concatenate (repeat for same code types) from the table in Appendix B.
3. Read the following Code to enable the configuration you have set.

CONCATENATION ENABLE/DISABLE

Disabled



Enabled



Enter Gun Configuration



GUN
DATA FORMAT

Exit and Save Gun Configuration



Concatenation Options

FIRST CONCATENATED CODE LENGTH

Set First Concatenated Code Length



Read the number in the range
000-255.
000 = any code length

SECOND CONCATENATED CODE LENGTH

Set Second Concatenated Code Length



Read the number in the range
000-255.
000 = any code length

THIRD CONCATENATED CODE LENGTH

Set Third Concatenated Code Length



Read the number in the range
000-255.
000 = any code length

FOURTH CONCATENATED CODE LENGTH

Set Fourth Concatenated Code Length



Read the number in the range
000-255.
000 = any code length

Enter Gun Configuration



GUN
DATA FORMAT

Exit and Save Gun Configuration



CONCATENATION WITH INTERCODE DELAY

Disabled



Enabled



This parameter is enabled with concatenation activated (see par. 3.6.1 for details).

CONCATENATION FAILURE TRANSMISSION

TX Codes Causing Failure



No Code TX



See par. 3.6.1 for details

CONCATENATION TIMEOUT

Concatenation Timeout



05-99 = timeout from 5 to 99 seconds.

TRANSMISSION AFTER TIMEOUT

No Code Transmission



First Code Transmission



Second Code Transmission



Third Code Transmission



Enter Gun Configuration



GUN
DATA FORMAT

Exit and Save Gun Configuration



CONCATENATION RESULT CODE ID

No Code Identifier



Use First Code Identifier



Use Second Code Identifier



Use Third Code Identifier



Use Fourth Code Identifier



Enter Gun Configuration



GUN
POWER SAVE

Exit and Save Gun Configuration



POWER SAVE

ILLUMINATION SYSTEM POWER

Illumination System OFF



Low Power



Intermediate Power



Maximum Power



Enter Gun Configuration



GUN
CODE SELECTION
Linear Symbologies

Exit and Save Gun Configuration



CODE SELECTION

Disable All Symbologies



Disable All Linear Symbologies



Disable All 2D Symbologies



Linear Symbologies

COMPOSITE CODE SELECTION

Enabled



Disabled



DISCARD LINEAR PART

Enabled



Disabled



Enter Gun Configuration



GUN
CODE SELECTION
Linear Symbologies

Exit and Save Gun Configuration



UPC/EAN/JAN FAMILY

EAN/UPC/JAN Disabled



EAN/UPC/JAN Enabled



Add-On Disabled



Add-On Enabled



UPCE Expansion Disabled



UPCE Expansion Enabled



CODE 39 FAMILY

Code 39 Std - Disabled



Code 39 Std - No Check Digit
Control



Code 39 Std - Check Digit
Control without Transmission



Code 39 Std - Check Digit
Control and Transmission



Enter Gun Configuration



GUN
CODE SELECTION
Linear Symbologies

Exit and Save Gun Configuration



Code 39 Full ASCII - Disabled



Code 39 Full ASCII- Enabled



Code Length Check - Disabled



Code Length Check - Enabled



Minimum Code Length



Read the number in the range
001-255.

Maximum Code Length



Read the number in the range
001-255.

**Start-Stop Character
Transmission - Disabled**



**Start-Stop Character
Transmission - Enabled**



Enter Gun Configuration



GUN
CODE SELECTION
Linear Symbologies

Exit and Save Gun Configuration



CODE 32 FAMILY

Disabled



Enabled



INTERLEAVED 2 OF 5 FAMILY

Disabled



Enabled - No Check Digit
Control



Enabled - Check Digit Control
and without Transmission



Enabled - Check Digit Control
and Transmission



Code Length Check - Disabled



Code Length Check - Enabled



Minimum Code Length



Read the number in the range
001-255.

Enter Gun Configuration



GUN
CODE SELECTION
Linear Symbologies

Exit and Save Gun Configuration



Maximum Code Length



Read the number in the range
001-255.

CODABAR FAMILY

Disabled



**Enabled - No Check Digit
Control**



**Enabled - Check Digit Control
without Transmission**



**Enabled - Check Digit Control
and Transmission**



Code Length Check - Disabled



Code Length Check - Enabled



Minimum Code Length



Read the number in the range
001-255.

Enter Gun Configuration



GUN
CODE SELECTION
Linear Symbologies

Exit and Save Gun Configuration



Maximum Code Length



Read the number in the range
001-255.

CODE 128 FAMILY

Code 128 - Disabled



Code 128 - Enabled



Code Length Check - Disabled



Code Length Check - Enabled



Code 128 - Min. Code Length



Read the number in the range
001-255.

Code 128 - Max. Code Length



Read the number in the range
001-255.

EAN 128 - Disabled



EAN 128 - Enabled



Enter Gun Configuration



GUN
CODE SELECTION
Linear Symbologies

Exit and Save Gun Configuration



EAN 128 - Code Length Check Disabled



EAN 128 - Code Length Check Enabled



EAN 128 - Min. Code Length



Read the number in the range
001-255.

Maximum Code Length



Read the number in the range
001-255.

CODE 93 FAMILY

Disabled



Enabled



Code Length Check - Disabled



Code Length Check - Enabled



Minimum Code Length



Read the number in the range
001-255.

Enter Gun Configuration



GUN
CODE SELECTION
Linear Symbologies

Exit and Save Gun Configuration



Maximum Code Length



Read the number in the range
001-255.

RSS FAMILY

Disable RSS Expanded



Enable RSS Expanded



Disable RSS Limited



Enable RSS Limited



Disable RSS 14 and RSS 14
Truncated



Enable RSS 14 and RSS 14
Truncated



Disable RSS Expanded Stacked



Enable RSS Expanded Stacked



Disable RSS 14 Stacked and
RSS 14 Stacked
Omnidirectional



Enable RSS 14 Stacked and
RSS 14 Stacked
Omnidirectional



Enter Gun Configuration



GUN
CODE SELECTION
2D Symbologies

Exit and Save Gun Configuration



2D Symbologies

PDF417

Disabled



Enabled



PDF417 OPTIONS

Macro PDF417 Unbuffered Mode



Macro PDF417 Buffered Mode



The following command carries out its specific function.

**Abort Macro PDF417 Buffered
Mode**



It stops buffering the read codes at any time. All the buffered codes will not be saved.

Enter Gun Configuration



GUN
CODE SELECTION
2D Symbologies

Exit and Save Gun Configuration



MICRO PDF417

Disabled



Enabled



DATAMATRIX FAMILY

Disabled



Enabled



Minimum Code Length



Read the number in the range
0001-3600.

Maximum Code Length



Read the number in the range
0001-3600.

Rectangular Style – Disabled



Rectangular Style - Enabled



Enter Gun Configuration



GUN
CODE SELECTION
2D Symbologies

Exit and Save Gun Configuration



QR FAMILY

Disabled



Enabled



POSTAL CODES FAMILY

All Disabled



Australian Post - Enabled



Japan Post - Enabled



PLANET - Enabled



POSTNET - Enabled



POSTNET with B and B' -
Enabled



POSTNET and PLANET -
Enabled



POSTNET with B and B' and
PLANET - Enabled



Enter Gun Configuration



GUN
CODE SELECTION
2D Symbologies

Exit and Save Gun Configuration



KIX Code - Enabled



Royal Mail Code (RM4SCC) -
Enabled



MAXICODE FAMILY

Maxicode Mode 0 - Disabled



Maxicode Mode 0 Enabled



Maxicode Mode 1 - Disabled



Maxicode Mode 1 - Enabled



Maxicode Mode 2 - Disabled



Maxicode Mode 2 - Enabled



Maxicode Mode 3 - Disabled



Maxicode Mode 3 - Enabled



Enter Gun Configuration



GUN
CODE SELECTION
2D Symbologies

Exit and Save Gun Configuration



Maxicode Mode 4 - Disabled



Maxicode Mode 4 - Enabled



Maxicode Mode 5 - Disabled



Maxicode Mode 5 - Enabled



Maxicode Mode 6 - Disabled



Maxicode Mode 6 - Enabled



Enter Gun Configuration



GUN
READING
PARAMETERS

Exit and Save Gun Configuration



READING PARAMETERS

TRIGGER MODE

Trigger Level



Trigger Pulse



TRIGGER TYPE

Normal Trigger



Software Trigger



FLASH MODE

Flash ON Duration



Read a number in the range **01-99**, which corresponds to a max 9.9 seconds duration.

Flash OFF Duration



Read a number in the range **01-99**, which corresponds to a max 9.9 seconds duration.

Enter Gun Configuration



GUN
READING
PARAMETERS

Exit and Save Gun Configuration



BEEPER TONE

Tone 1



Tone 2



Tone 3



Tone 4



BEEPER VOLUME

Beeper OFF



Low Volume



Medium Volume



High Volume



BEEPER DURATION

Beeper Duration



Read a number in the range **01-99**, which corresponds to a max 99 ms duration.

Enter Gun Configuration



GUN
READING
PARAMETERS

Exit and Save Gun Configuration



READ PER CYCLE

One Read per Cycle



More Reads per Cycle



SCAN TIMEOUT

Define Timeout



Read a number in the range **01-99**, which corresponds to a max 99 seconds duration. The timeout is activated when the decoding fails.

User Defined Beeper

USER DEFINED BEEPER TONE

Tone 1



Tone 2



Tone 3



Tone 4



Enter Gun Configuration



GUN
READING
PARAMETERS

Exit and Save Gun Configuration



USER DEFINED BEEPER VOLUME

Beeper OFF



Low Volume



Medium Volume



High Volume



USER DEFINED BEEPER DURATION

Set Duration



Read a number in the range **01-99**, which corresponds to a max 990 ms duration.

TEST USER DEFINED BEEPER

The following command carries out its specific function.

Test User Defined Beeper



See par. 10.1.2 for details.

Enter Gun Configuration



GUN
READING
PARAMETERS

Exit and Save Gun Configuration



Code Ordering and Selection

CODE PER SCAN

One Code per Scan



All Codes per Scan



CENTRAL CODE TRANSMISSION

The following command is available when working in "one code per scan".

Disabled



Enabled



See par. 3.6 for details.

ORDER BY CODE LENGTH

The following commands are available when working in "all codes per scan".

Disabled



Enabled - Increasing Order



Enabled - Decreasing Order



Enter Gun Configuration



GUN
READING
PARAMETERS

Exit and Save Gun Configuration



ORDER BY CODE SYMBOLOGY

The following commands are available when working in "all codes per scan".

Set Order



1. Select the number of codes in the range **0-9**.
2. Select the Datalogic Standard Code Identifier for each above defined code from the table in Appendix B.

See par. 3.6 for details.

Autoscan

AUTOSCAN MODE

Disabled



Enabled in Normal Mode



Enabled in Pattern Mode



See par. 3.4 for details.

Enter Gun Configuration



GUN
READING
PARAMETERS

Exit and Save Gun Configuration



AUTOSCAN AIMING SYSTEM

Disabled



Enabled



AUTOSCAN HARDWARE TRIGGER

Disabled



Enabled



AUTOSCAN ILLUMINATION SYSTEM

Disabled



Enabled



The following commands can be activated when it is possible to read one code per image only.

SAFETY TIME

Disabled



Enabled



Valid only with software trigger or autoscan enabled.

Enter Gun Configuration



GUN
READING
PARAMETERS

Exit and Save Gun Configuration



SAFETY TIME DURATION

Set Duration



Read a number in the range **01-99**, where 01 corresponds to 100 ms and 99 to 9.9 seconds.

CAPTURE IMAGE

In order to capture an image, you should read one of these codes (for further details see. par 3.3), then point at the image subject and pull the trigger. The image will be captured and sent to the host PC according to the Preset Configuration.

Capture Image using Preset 1



Capture Image using Preset 2



Capture Image using Preset 3



Capture Image using Preset 4



Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



ADVANCED IMAGE CAPTURE

Image Preset 1

Basic Configuration

IMAGE FORMAT – PRESET 1

Bitmap Format



JPEG Format



TIFF Format



RESOLUTION – PRESET 1

Full Resolution (640 x 480)



Quarter Resolution (320 x 240)



Enter Gun Configuration



GUN
**ADVANCED IMAGE
CAPTURE**

Exit and Save Gun Configuration



JPEG QUALITY FACTOR – PRESET 1

JPEG Quality Factor



Set the JPEG compression level
in the range **000-100**.

Advanced Configuration

WINDOW DIMENSIONS – PRESET 1

Origin along X Axis



Read a number in the range
0-630

Origin along Y Axis



Read a number in the range
0-470

Width



Read a number in the range
10-640

Height



Read a number in the range
10-480

Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



BRIGHTNESS – PRESET 1

Increase



Read a number in the range
0-100

Decrease



Read a number in the range
0-100

CONTRAST – PRESET 1

Increase



Read a number in the range
0-100

Decrease



Read a number in the range
0-100

Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



ZOOM – PRESET 1

20%



40%



60%



80%



100%



120%



140%



160%



180%



200%



Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



COLOR DEPTH – PRESET 1

2 Grey Levels*



16 Grey Levels*



256 Grey Levels



* only for TIFF and BMP Images.

Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



Image Preset 2

Basic Configuration

IMAGE FORMAT – PRESET 2

Bitmap Format



JPEG Format



TIFF Format



RESOLUTION – PRESET 2

Full Resolution (640 x 480)



Quarter Resolution (320 x 240)



JPEG QUALITY FACTOR – PRESET 2

JPEG Quality Factor



Set the JPEG compression level
in the range **000-100**.

Enter Gun Configuration



GUN
**ADVANCED IMAGE
CAPTURE**

Exit and Save Gun Configuration



Advanced Configuration

WINDOW DIMENSIONS – PRESET 2

Origin along X Axis



Read a number in the range
0-630

Origin along Y Axis



Read a number in the range
0-470

Width



Read a number in the range
10-640

Height



Read a number in the range
10-480

Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



BRIGHTNESS – PRESET 2

Increase



Read a number in the range
0-100

Decrease



Read a number in the range
0-100

CONTRAST – PRESET 2

Increase



Read a number in the range
0-100

Decrease



Read a number in the range
0-100

Enter Gun Configuration



GUN
**ADVANCED IMAGE
CAPTURE**

Exit and Save Gun Configuration



ZOOM – PRESET 2

20%



40%



60%



80%



100%



120%



140%



160%



180%



200%



Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



COLOR DEPTH – PRESET 2

2 Grey Levels*



16 Grey Levels*



256 Grey Levels



* only for TIFF and BMP Images.

Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



Image Preset 3

Basic Configuration

IMAGE FORMAT – PRESET 3

Bitmap Format



JPEG Format



TIFF Format



RESOLUTION – PRESET 3

Full Resolution (640x 480)



Quarter Resolution (320 x 240)



JPEG QUALITY FACTOR – PRESET 3

JPEG Quality Factor



Set the JPEG compression level
in the range **000-100**.

Enter Gun Configuration



GUN
**ADVANCED IMAGE
CAPTURE**

Exit and Save Gun Configuration



Advanced Configuration

WINDOW DIMENSIONS – PRESET 3

Origin along X Axis



Read a number in the range
0-630

Origin along Y Axis



Read a number in the range
0-470

Width



Read a number in the range
10-640

Height



Read a number in the range
10-480

Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



BRIGHTNESS – PRESET 3

Increase



Read a number in the range
0-100

Decrease



Read a number in the range
0-100

CONTRAST – PRESET 3

Increase



Read a number in the range
0-100

Decrease



Read a number in the range
0-100

Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



ZOOM – PRESET 3

20%



40%



60%



80%



100%



120%



140%



160%



180%



200%



Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



COLOR DEPTH – PRESET 3

2 Grey Levels*



16 Grey Levels*



256 Grey Levels



* only for TIFF and BMP Images.

Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



Image Preset 4

Basic Configuration

IMAGE FORMAT – PRESET 4

Bitmap Format



JPEG Format



TIFF Format



RESOLUTION – PRESET 4

Full Resolution (640 x 480)



Quarter Resolution (320 x 240)



JPEG QUALITY FACTOR – PRESET 4

JPEG Quality Factor



Set the JPEG compression level
in the range **000-100**.

Enter Gun Configuration



GUN
**ADVANCED IMAGE
CAPTURE**

Exit and Save Gun Configuration



Advanced Configuration

WINDOW DIMENSIONS – PRESET 4

Origin along X Axis



Read a number in the range
0-630

Origin along Y Axis



Read a number in the range
0-470

Width



Read a number in the range
10-640

Height



Read a number in the range
10-480

Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



BRIGHTNESS – PRESET 4

Increase



Read a number in the range
0-100

Decrease



Read a number in the range
0-100

CONTRAST – PRESET 4

Increase



Read a number in the range
0-100

Decrease



Read a number in the range
0-100

Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



ZOOM – PRESET 4

20%



40%



60%



80%



100%



120%



140%



160%



180%



200%



Enter Gun Configuration



GUN
ADVANCED IMAGE
CAPTURE

Exit and Save Gun Configuration



COLOR DEPTH – PRESET 4

2 Grey Levels*



16 Grey Levels*



256 Grey Levels



- only for TIFF and BMP Images.

Enter Gun Configuration



GUN
RADIO
PARAMETERS

Exit and Save Gun Configuration



RADIO PARAMETERS

RADIO RX TIMEOUT

Radio RX Timeout



Read a number in the range **00-99**, where:
00 = disabled
01-99 = timeout from 1 to 99 secs

RADIO ACK/NACK PROTOCOL

Disabled



Enabled



POWER OFF TIMEOUT WHEN CONNECTED

Power Off Timeout



Read a number in the range **001-255**, which corresponds to a max 255 minute timeout (during which the reader is not used) before it powers off automatically.

POWER OFF TIMEOUT WHEN NOT CONNECTED

Power Off Timeout



Read a number in the range **001-255**, which corresponds to a max 255 minute timeout (during which the reader is not used) before it powers off automatically.

Enter Gun Configuration



**GUN
RADIO
PARAMETERS**

Exit and Save Gun Configuration



USER-FRIENDLY NAME

Choose User-Friendly Name



1. Enter 50 characters max. to define the desired user-friendly name;
2. Read the following code to validate the name you have entered.

Validate User-Friendly Name



RESTORE FACTORY USER-FRIENDLY NAME

**Restore Factory User-Friendly
Name**



ENCRYPTION

Disabled



Enabled



After changing this parameter, read the Software Reset code in chapter 7.

This parameter is not effected by the Restore Default code.

Enter Gun Configuration



GUN
RADIO
PARAMETERS

Exit and Save Gun Configuration



BATCH MODE

Disabled



Enabled



This parameter is not effected by the Restore Default code.

ACK/NACK FROM HOST

Disabled



Enabled



RADIO PROTOCOL TIMEOUT

Radio Protocol Timeout



Read a number in the range
03-19, where:
03-19 = timeout from 3 to 19 secs

CONFIGURATION EDITING COMMANDS

Cradle Enter and Exit Commands

Enter Cradle Configuration



Exit and Save Cradle
Configuration



Gun Enter and Exit Commands

Enter Gun Configuration



Exit and Save Gun
Configuration



Other Editing Commands

Restore Lynx™ BT Default



Restore OM-1000 BT Default



CONFIGURATION EDITING COMMANDS

The following three commands carry out their specific function and then exit the configuration environment.

**Show Lynx™ BT Software
Release**



**Show OM-1000 Software
Release**




5.2 ADVANCED DATA FORMAT

Advanced data format has been designed to offer you complete flexibility in changing the format of barcode data **before** transmitting it to the host system.

Up to 5 advanced code management formats can be defined by completing the four given procedures following the desired order:

- Format Definition
- Mismatch Result
- Enable/Disable Format
- Match Conditions

The formats defined will be restored to default values when reading the general "Restore Lynx™ BT Default" code.



5.2.1 Format Definition

STEP 1	FORMAT DEFINITION
---------------	--------------------------

Define Format 1



Define Format 2



Define Format 3



Define Format 4



Define Format 5




STEP 2 FORMAT DEFINITION**Method 1 - Extracting Information from Barcode**

Method 1 allows extracting one or more fields by position or by characters from the decoded barcode. These fields are sent to the host computer as data of the output message, while the characters not included in the formatting procedure will be deleted and not inserted in the output message.

These two kinds of extraction (by position / by character) can be used together within the same format definition; furthermore, it is possible to complete the new format by adding a new string of characters. Since there is no fixed rule, the procedures can be freely put in order and repeated according to your requirement.


The only limit is determined by the size of the internal reserved memory used to define the format.



Example Method 1 Extracting Information from Barcode







Decoded code: <DATALOGICproduct>

Formatting procedure: Add new string + Extract field by position + Add new string + Extract field by character + Add new string



Output message: <21DAT21OGICpr21>

FIELD EXTRACTION BY CHARACTER

- a) Define Field Starting Character(s)**
- Field Starting Character(s)
- 
- Read the Hex value from the Hex/Numeric table identifying the starting character(s) of the field to be extracted. Valid values are in the range **00-7F**.
- b) Define Field Ending Character(s)**
- Field Ending Character(s)
- 
- Read the Hex value from the Hex/Numeric table identifying the ending character(s) of the field to be extracted. Valid values are in the range **00-7F**.
- c) Field Delimiter Selection**
- | | | |
|---|----|---|
| <p>Include Start/End Characters</p>  | OR | <p>Discard Start/End Characters</p>  |
|---|----|---|
- d) EITHER Add Field or String**
- Add
- 
- To add other fields selected by characters read the code and repeat this procedure from step **a** for each field to be selected;
 - To add a new string of characters read the barcode and follow the procedure described on page 111 ;
 - To add the procedure selecting new fields by position read the code and follow the description given on page 110.
- OR
- End Format Definition**
- End Format Definition
- 
- Read the code to end the format definition.

FIELD EXTRACTION BY POSITION

a)

Define Field Starting Position

Field Starting Position



Read a number corresponding to the field starting position.

b)

Define Field Ending Position

Field Ending Position



Read a number corresponding to the field ending position.

Last Position



Read this code to set the field ending position to the last position of the code:

OR

c)

End Field Selection

End Selection



Read the code to end the field selection.

d)

EITHER

Add Field or String

Add



- To add other fields selected by position read the code and repeat this procedure from step a for each field to be selected;
- To add a new string of characters read the barcode and follow the procedure described on page 111;
- To add the procedure selecting new fields by characters read the code and follow the description given on page 110.

OR

End Format Definition

End Format Definition



Read the code to end the format definition.

ADD NEW STRING

a)

Define New String

String Character(s)



Read the Hex value from the Hex/Numeric table identifying the character(s). Valid values are in the range **00-7F**.

b)

End String

End String



Read the code to end the string defined in step a.

c)

EITHER**Add Procedure**

Add



- To add the procedure extracting fields by characters follow the steps given on page 110;
- To add the procedure extracting fields by position follow the steps given on page 110;

OR**End Format Definition**

End Format Definition



Read the code to end the format definition.

Method 2 - Manipulating the Barcode Data

Method 2 allows modifying the barcode data by means of one of the following procedures:

- String insertion;
- String deletion;
- String substitution;
- Field deletion.


Once the data has been modified, it is sent to the host computer as data of the output message.

Unlike Method 1 this method does not allow associating different procedures together. This means that each format definition corresponds to a single procedure. Despite this, it is possible to add a new string of characters to the beginning or ending part of the formatted barcode.

The only limit is determined by the size of the internal reserved memory used to define the format.

STRING INSERTION


To complete this procedure proceed as follows:



Example

Decoded code: <DATALOGICproduct>

Formatting procedure: Add new string + Insert String



Output message: <17DATA123LOGICproduct>

String Insertion Procedure

a)

Insert String

Insert String



Read the Hex value from the Hex/Numeric table identifying the characters to be inserted. Valid values are in the range **00-7F**.

b)

Define String Position

String Position



Read a number corresponding to the string position within the barcode.

c)

End Selection

End Selection



Read the code to end the field selection.

d)

EITHER

Add String

Add



To add a new string of characters read the barcode and follow the procedure described on page 122;

OR

End Format Definition


End Format Definition



Read the code to end the format definition.

STRING DELETION


To complete this procedure proceed as follows:



Example

Decoded code: <DATALOGICproduct>

Formatting procedure: Delete First String + Delete Second String + Add New String.



Output message: <DATAGICpruct31>

String Deletion Procedure

a)

Delete String

Delete



Read the Hex value from the Hex/Numeric table identifying the string character(s) to be deleted. Valid values are in the range **00-7F**.

b)

(optional)

Select Other Strings to be Deleted

Loop



Read the code above and repeat the procedure from step a.

c)

End Selection

End Selection



Read the code to end the selection.

d)

EITHER

Add String

Add



To add a new string of characters read the barcode and follow the procedure described on page 122;

OR

End Format Definition


End Format Definition



Read the code to end the format definition.

STRING SUBSTITUTION


To complete this procedure proceed as follows:



Example

Decoded code: <DATALOGICproduct>


Formatting procedure: Add new string + String substitution + Add new string.



Output message: <43D7T7LOGICproduct43>

FIELD DELETION


To complete this procedure proceed as follows:



Example

Decoded code: <DATALOGICproduct>

Formatting procedure: Delete First Field + Delete Second Field + Add New String.



Output message: <DGICct51>

Field Deletion Procedure

a)

Delete Field

Delete



Read the code to enable the command deleting the field.

b)

Define Field Starting Character

Field Starting Character



Read the Hex value from the Hex/Numeric table identifying the starting characters. Valid values are in the range **00-7F**.

c)

Define Field Ending Character

Field Ending Character



Read the Hex value from the Hex/Numeric table identifying the ending character/s. Valid values are in the range **00-7F**.

d)

End Field Selection

End Selection



Read the code to end the field selection.

e)

(optional)

Select Other Fields to be Deleted

Loop



Read the following code and repeat the procedure from step **b** for each field to be deleted:

f)

EITHER

Add String

Add

To add a new string of characters read the barcode and follow the procedure described on page 122;

OR**End Format Definition****End Format Definition**

Read the code to end the format definition.

ADD NEW STRING

a)

Define New String

String Character



Read the Hex value from the Hex/Numeric table identifying the starting characters. Valid values are in the range **00-7F**.

b)

End String and Define Procedure

End String Plus Procedure



Read the code to end the string selection and continue defining a new procedure belonging to Method 1.

OR**End String and Format**

End String & Format



Read the code to end the string and the format definition.

5.2.2 Match Conditions

By setting one or more of the following conditions it is possible to select the codes to be formatted. Follow the given steps to define the desired condition:

MATCH WITH PREDEFINED SUBSTRING

Define Matching Substring

Match with Substring



Read the above code and:

1. read a number in the range **1-5** corresponding to the desired format number;
2. set the number of characters defining the matching string in the range **00-10**;
3. read the corresponding character as Hex value from the Hex/Numeric table identifying the substring character/s. Valid values are in the range **00-7F**.

(optional)

Define Substring Position

Matching Substring Position



Read the above code and:

1. read a number in the range **1-5** corresponding to the desired format number;
2. read the number corresponding to the substring position in the range **0-255**;

AND/OR

MATCH CODE LENGTH

Define Code Length

Match Code Length



Read the above code and:

1. read a number in the range **1-5** corresponding to the desired format number;
2. read the number in the range **0-255**;

AND/OR**MATCH SYMBOLOGY****Define Code Symbology****Match Symbology**

Read the above code and:

1. read a number in the range **1-5** corresponding to the desired format number;
2. set the number of the matching code symbologies in the range **0-4**;
3. select the Datalogic Standard Code Identifier from the Code Identifier Table in Appendix B.

5.2.3 Format Enable/Disable

Format 1



0 = disabled
1 = enabled

Format 2



0 = disabled
1 = enabled

Format 3



0 = disabled
1 = enabled

Format 4



0 = disabled
1 = enabled

Format 5



0 = disabled
1 = enabled

Disable All Formats



6 REFERENCES

6.1 DATA FORMAT

6.1.1 Headers and Terminators

If setting headers and terminators for both the Lynx™ BT and the OM-1000 Bt, those configured for the reader are ignored and only the cradle headers/terminators will be transmitted.

7 SYSTEM MANAGEMENT COMMANDS

These are complete commands that do not require reading an Enter or Exit Configuration code.

POWER OFF

Power Off



UNBIND

Unbind



After reading this code, read the Software Reset code below.

SOFTWARE RESET

Software Reset



8 TEST BARCODE SYMBOLS

Use these test 1D and 2D symbols to check that the reader is imaging and decoding properly, according to your configuration.

UPC-A



UPC-E



EAN-8



EAN-13



Code 39 (Normal)



Code 39 (Full ASCII)



Codabar




Code 128



Interleaved 2 of 5



PDF417



QR



DATA MATRIX NORMAL



INVERSE DATA MATRIX



9 MAINTENANCE

9.1 MAINTENANCE

You do not need to perform regular preventative maintenance on the LYNX™ reader.

Do not try to open the case, because you might damage the interior electronic components and such action voids the warranty.

You can keep your reader in good operating condition by:

- periodically cleaning the reading window using water or a mild detergent solution and a soft cloth or tissue.
- watching for any damage to the housing.



CAUTION

Do not use abrasive cleaning agents on the reader's window to avoid scratches. Do not use solvents on the housing or window to avoid damage. Do not submerge the reader in water. It is not waterproof.

10 TECHNICAL FEATURES

OM-1000 BT

Electrical Features	
Operating Voltage	12 V
Power Consumption (Typical)	
@ 12V No Charging	110 mA
@ 12V Charging	580 mA
Communications Features	
Standard Interfaces	RS232, Keyboard emulation AT IBM, , USB COM emulation, USB Keyboard emulation
Indicators	Power/Data LED, Charging LED, Batt. Full LED
Radio Features	
Bluetooth® Profile Supported	IEEE 802.15, (class 2), version 1.2 Serial Port Profile
Environmental Features	
Operating Temperature	0° to+ 55 °C (+32° to +131 °F)
Storage Temperature	-20° to +70 °C (-4° to +158 °F)
Humidity	0 to 95% NC
Mechanical Features	
Dimensions	185 x 115 x 104 mm / 7.2 x 4.5 x 4 in
Weight	

LYNX™ BT432 / BT432E Common Features

Electrical Features	
Power Source	Li-Ion battery
Radio Features	
Bluetooth® Profile Supported	IEEE 802.15, (class 2), version 1.2 Serial Port Profile

Environmental Features	
Operating Temperature	0° to+ 55 °C (+32° to +131 °F)
Storage Temperature	-20° to +70 °C (-4° to +158 °F)
Humidity	0 to 95% NC
Shock resistance	IEC 68-2-32 Test ED – 1,8 m.
Mechanical Features	
Dimensions	203 x 117 x 69 mm (8 x 4.6 x 2.7 inches)
Weight	225 g without cable
Decoding Capability	
1D	Interleaved 2 of 5, Code39, Code32, Code128, EAN 128, Code93, UPC/EAN/JAN, Codabar, RSS
2D	PDF417, DataMatrix (ECC200)
Postal Codes	POSTNET, PLANET, Japan Post, Australia Post, KIX Code, Royal Mail Code (RM4SCC), Micro PDF417, Maxicode
Imaging Option	
Image	640 x 480 pixel format (VGA)
	320 x 240 pixel format (CIF);
Graphic Format	JPEG, 256 gray levels
	BMP, 2, 16, 256 gray levels
	TIFF, 2, 16, 256 gray levels

LYNX™ BT432 / BT432E Common Features

Optical Features	
Sensor	640 x 480 pixel element, 2D CMOS Array
Illuminator	LED array
Wavelength	In the range 630 ~ 670 nm
Max. LED Output Power	0.896 mW
LED Safety Class	Class 1 to EN 60825-1
Aiming System	Visible Laser Diode
Wavelength	650 nm
Laser Safety Class	Class 2 - EN 60825-1; Class II CDRH
Ambient light	0 - 100000 lux

LYNX™ BT432

Optical Features			
Focus distance	115 mm		
Field of view	21.8° (H) x 16.7° (V)		
Horizontal field of view at distance (d) in mm	0.4 d + 12		
Vertical field of view at distance (d) in mm	0.3 d + 9		
Max Resolution	Linear codes - mm (mils)	Datamatrix – mm (mils)	
	0.10 (4)	0.17 (6.6)	
Depth of field*			
1D (linear):	X-dimension mm (mils)	Symbol size cm (in)	DOF cm (in)
Code39	0.13 (5)	1.2 (0.47)	8.0 to 15.0 (3.15 to 5.90)
	0.5 (20)	3.2 (1.26)	8.0 to 33.0 (3.15 to 12.99)
EAN13	0.33 (13)	3.1 (1.22)	7.5 to 24.5 (2.95 to 9.65)
2D:	X-dimension mm (mils)	Symbol size cm (in)	DOF cm (in)
POSTNET	0.5 (20)	4.0 x 0.4 (1.57 x 0.16)	11.5 to 30.0 (4.53 to 11.81)
PDF417	0.13 (5)	1.1 x 0.9 (0.43 x 0.35)	8.5 to 15.5 (3.35 to 6.10)
	0.17 (6.6)	1.4 x 1.2 (0.55 x 0.47)	7.0 to 19.0 (2.76 to 7.48)
	0.25 (10)	2.2 x 1.8 (0.86 x 0.71)	4.5 to 24.0 (1.77 to 9.45)
DataMatrix	0.19 (7.5)	0.8 x 0.8 (0.31 x 0.31)	9.0 to 13.0 (3.54 to 5.12)
	0.25 (10)	0.8 x 0.8 (0.31 x 0.31)	7.5 to 16.5 (2.95 to 6.50)
	0.38 (15)	1.0 x 1.0 (0.39 x 0.39)	6.0 to 22.0 (2.36 to 8.66)
Skew	±40°		
Pitch	±35°		
Rotation	360°		
Print Contrast (Min.)	23%		

* Reading distances are measured from the nose of the reader.

LYNX™ BT432E

Optical Features			
Focus distance	65 mm		
Field of view	20° (H) x 15° (V)		
Horizontal field of view at distance (d) in mm	0.32 d + 8.67		
Vertical field of view at distance (d) in mm	0.24 d + 6.50		
Max Resolution	Linear codes - mm (mils)	Datamatrix – mm (mils)	
	0.05 (2.0)	0.10 (4.0)	
Depth of field*			
1D (linear):	X-dimension mm (mils)	Symbol size cm (in)	DOF cm (in)
Code39	0.076 (3)	1.2 (0.47)	5.0 to 7.5 (1.96 to 2.95)
	0.13 (5)	1.2 (0.47)	4.0 to 9.5 (1.57 to 3.74)
2D:	X-dimension mm (mils)	Symbol size cm (in)	DOF cm (in)
PDF417	0.76 (3)	0.65 x 0.55 (0.26 x 0.22)	5.0 to 8.0 (1.96 to 3.15)
	0.25 (10)	2.2 x 1.8 (0.86 x 0.71)	4.0 to 13.3 (1.57 to 5.24)
DataMatrix	0.13 (5)	0.5 x 0.5 (0.20 x 0.20)	5.0 to 7.5 (1.96 to 2.95)
	0.25 (10)	0.8 x 0.8 (0.31 x 0.31)	4.5 to 10.5 (1.77 to 4.13)
Skew	±40°		
Pitch	±35°		
Rotation	360°		
Print Contrast (Min.)	27%		

* Reading distances are measured from the nose of the reader.

10.1 INDICATORS

10.1.1 LED Indicators

The following LED indicators signal the reader functions.

LED	Behavior	
	Reader Power On	Normal Functioning
Red (Figure A,1)	blinks briefly, then a beep occurs. Then, it turns off.	lights when a wrong read occurs. lights briefly when the aiming system is enabled.
Green (Figure A,2)		lights when a symbol has been read and decoded. Single blink every 2 seconds when BT connection is active. Double blink every 2 seconds when BT connection is not active.

10.1.2 Beeper

The Lynx™ BT basic software provides beeper signals for power on, good/wrong reading and BT connection activation/deactivation.

A PROGRAMMING FOR EXPERT USERS

This document is addressed to expert users who are familiar with software programming languages and want to define a personalized code formatting. The provided programming language allows creating either simple or complex formatting expressions by means of the basic functions connected together through the following operators: (,), -, +.

The syntax to be used to transmit the expressions to the Lynx™ is the following:

\$+ELB<n>formatting expression<ETX>\$-

where:

- <n> is a number in the range 1-5 corresponding to the format to be defined;
- <ETX> is the conventional character used as terminator of the command;
- the formatting expression uses ASCII characters when containing text strings. For this reason, the string must be inserted between two quotation marks. The following example shows the ASCII conversion of the "ABC" string:

`$+ELB1"414243"+#DS^C$-`

FUNCTION DESCRIPTION

All the functions and conventions to be used within the formatting expressions are listed below:

FUNCTION NAME	DESCRIPTION
FSTR	Searches for a defined substring by its starting and ending string.
FLSTR	Searches for a defined substring by its starting string and its length.
SSTR	Extracts a defined substring from the original string.
FPOS	Searches for a position of a defined substring within the original string.
LSTR	Returns a string length.
ISTR	Insert a substring in the original string.
RSTR	Substitutes a defined substring contained in the original string with a new one.

CONVENTIONS	DESCRIPTION
+	Concatenates two strings or fields.
-	Deletes a substring or a field from the original string.
#DS	Returns the string which has been decoded by the library.
#F<n>	Returns the result of a format which has been previously defined. The <n> value is in the range 1-4.

FindStringByStarting&EndingChar (FSTR)

This function has the following syntax:

FSTR<source_string, string_start, string_stop, mode>⇒string

This function searches for a substring having a defined starting character ("string_start") and a defined ending character ("string_stop") within the "source_string". It returns the string you searched for, or an empty one in case of failure.

If searching for a substring having characters already known, the "string_start" and "string_stop" arguments must share the same value.

The "mode" argument allows managing the starting character ("string_start") and the ending character ("string_stop"):

- 0 = include both starting and ending character
- 1 = include only starting character
- 2 = include only ending character
- 3 = discard both starting and ending character

FindStringByStartingChar&Len (FLSTR)

This function has the following syntax:

FLSTR<source_string, string_start, len, mode>⇒string

This function searches for a substring having a defined starting character ("string_start") and a defined length ("len") within the "source_string". It returns the string you searched for, or an empty one in case of failure.

If searching for a substring having a length already known, the "string_start" and "string_stop" arguments must share the same number.

The "mode" argument allows managing the starting character ("string_start"):

- 0 = include starting character
- 1 = discard starting character

SelectString (SSTR)

This function has the following syntax:

SSTR<source_string, pos_start, pos_end>⇒string

It extracts a substring whose characters are between "pos_start" and "pos_end" from the "source_string".

If "pos_end" is longer than the "source_string" length, no error will be generated since the exceeding characters are ignored.

The first character of every string is in position 1.

FindPosition (FPOS)

This function has the following syntax:

FPOS<source_string, search_string>⇒position

This function searches for a defined substring within the "source_string" and returns its position. If the substring is not found, the returned value is 1.

StringLength (LSTR)

This function has the following syntax:

LSTR<string>⇒length

This function returns the length of the defined string.

StringConcatenation

This function has the following syntax:

string1 + string2⇒string

This function allows concatenating two different strings in order to get a single string as result.

StringDiscard

This function has the following syntax:

string1 - string2⇒string

This function discards all the strings having the same value as "string2" which can be found in "string1". If no "string2" is found within "string1", the result returns "string1".

InsertString (ISTR)

This function has the following syntax:

ISTR<source_string, string1, position>⇒string

This function inserts a new string ("string1") within the "source_string" and places it in the defined "position".

If the value of the "position" argument is longer than "source_string" length, "string1" will be placed after the last character of the source string.

ReplaceString (RSTR)

This function has the following syntax:

RSTR<source_string, string1, string2>⇒string

This function searches for "string1" within the "source_string". All the strings having the same value as "string1" within the "source_string" will be replaced by "string2". If no "string1" is found in the "source_string", the result returns the "source_string".

Examples

The string transmitted is "12345abcdef3790" and corresponds to the #DS function, as defined in the programming language.

- 1) expression \Rightarrow **SSTR<#DS,1,5> + SSTR<#DS,11,15> + SSTR<#DS,6,9>**
result \Rightarrow **"12345f3790abcd"**
- 2) expression \Rightarrow **FSTR<#DS, "616263", "616263", 0> + SSTR<#DS,LSTR<#DS>-3, LSTR<#DS>**
result \Rightarrow **"abc3790"**
- 3) expression \Rightarrow **FSTR<#DS, "616272", "616261", 0>**
result \Rightarrow **" null string"**
- 4) expression \Rightarrow **#DS - FSTR<#DS, "616263", "6566", 0>**
result \Rightarrow **"123453790"**

During the format definition the decoded string represented by #DS does not change.

Using Format Output in Format Definition

The input used by the above functions to define the code formatting usually corresponds to the decoded code (#DS). Actually, the formatting expression of each function can also format the result (output) produced by a preceding code formatting. The format output is represented as follow:

#F<n>, where:

<n> = format number in the range 1-4

#F = format output

Being Format 5 not included in other format expression, the format number is in the range 1-4. Furthermore, since a format expression operates upon the output of the preceding formats, the expression defining Format 1 will never contain the result of another format.

Example

The following expression is used to define Format 3:

#DS + FSTR<#F2, "6173", "6263", 0>

The expression input consists of the decoded code and the result produced by Format 2 (#F2).

The FSTR function searches for a defined substring within the #F2 result; then, it concatenates this substring and the decoded code. The result corresponds to #F3 output

B CODE IDENTIFIER TABLE

EAN/UPC



CODABAR



CODE 128



EAN 128



CODE 93



CODE 32



CODE 39



INTERLEAVED 2 OF 5



PDF417



MICRO PDF417



DATAMATRIX



MAXICODE



QR



AUSTRALIA POST



JAPAN POST



POSTNET



PLANET



RSS



KIX CODE



RM4SCC



C HEX AND NUMERIC TABLE

CHARACTER TO HEX CONVERSION TABLE								
char	decimal	hex	char	decimal	hex	char	decimal	hex
NUL	000	00	*	042	2A	U	085	55
SOH	001	01	+	043	2B	V	086	56
STX	002	02	,	044	2C	W	087	57
ETX	003	03	-	045	2D	X	088	58
EOT	004	04	.	046	2E	Y	089	59
ENQ	005	05	/	047	2F	Z	090	5A
ACK	006	06	0	048	30	[091	5B
BEL	007	07	1	049	31	\	092	5C
BS	008	08	2	050	32]	093	5D
HT	009	09	3	051	33	^	094	5E
LF	010	0A	4	052	34	~	095	5F
VT	011	0B	5	053	35	a	096	60
FF	012	0C	6	054	36	b	097	61
CR	013	0D	7	055	37	c	098	62
SO	014	0E	8	056	38	d	099	63
SI	015	0F	9	057	39	e	100	64
DLE	016	10	:	058	3A	f	101	65
DC1	017	11	;	059	3B	g	102	66
DC2	018	12	<	060	3C	h	103	67
DC3	019	13	=	061	3D	i	104	68
DC4	020	14	>	062	3E	j	105	69
NAK	021	15	?	063	3F	k	106	6A
SYN	022	16	@	064	40	l	107	6B
ETB	023	17	A	065	41	m	108	6C
CAN	024	18	B	066	42	n	109	6D
EM	025	19	C	067	43	o	110	6E
SUB	026	1A	D	068	44	p	111	6F
ESC	027	1B	E	069	45	q	112	70
FS	028	1C	F	070	46	r	113	71
GS	029	1D	G	071	47	s	114	72
RS	030	1E	H	072	48	t	115	73
US	031	1F	I	073	49	u	116	74
SPACE	032	20	J	074	4A	v	117	75
!	033	21	K	075	4B	w	118	76
"	034	22	L	076	4C	x	119	77
#	035	23	M	077	4D	y	120	78
\$	036	24	N	078	4E	z	121	79
%	037	25	O	079	4F	{	122	7A
&	038	26	P	080	50		123	7B
'	039	27	Q	081	51	}	124	7C
(040	28	R	082	52	~	125	7D
)	041	29	S	083	53	DEL	126	7E
			T	084	54		127	7F



C

LYNX™ BT

5



6



7



8



9



