

**MOSAIC WATER FIREFLY®**  
**USER TRAINING GUIDE**  
(Operators Manual)

**MOSAIC 1.1 / ROUTESTAR MVP 3.10 / ROADRUNNER 3.27**

Datamatic meter reading products are covered under one or more of the following patents:

**AXIOMETRIC, LLC**  
U.S. Patent No. 7,782,804

**ICH INC.**  
U.S. Patent No. 7,248,181

**IPCO, LLC**  
U.S. Patent No. 6,044,062; U.S. Patent No. 6,249,516; U.S. Patent No. 7,054,271; U.S. Patent No. 7,089,125

**PINE TREE HOLDINGS, INC.**  
U.S. Patent No. 6,710,721; U.S. Patent No. 6,755,148; U.S. Patent No. 6,798,352; U.S. Patent No. 7,042,368; U.S. Patent No. 7,315,257

**SIPCO, LLC**  
U.S. Patent No. 7,103,511; U.S. Patent No. 6,914,893; U.S. Patent No. 6,891,838; U.S. Patent No. 5,714,931; U.S. Patent No. 6,233,327; U.S. Patent No. 7,397,907; U.S. Patent No. 6,618,578; U.S. Patent No. 7,079,810; U.S. Patent No. 7,295,128; U.S. Patent No. 7,263,073; U.S. Patent No. 7,480,501; U.S. Patent No. 6,437,692; U.S. Patent No. 7,468,661; U.S. Patent No. 7,053,767; U.S. Patent No. 7,650,425; U.S. Patent No. 7,739,378; U.S. Patent No. 7,697,492

MOSAIC™ regulations and Warranty information .....	5
FCC Regulations.....	6
Introduction .....	9
Equipment.....	10
ROADRUNNER Handheld.....	10
MOSAIC FIREFLY.....	10
Lid Lock .....	12
Remote Shutoff Valve.....	14
Installation Considerations .....	15
Installation Supplies .....	16
Basic Supplies .....	16
Water Sensor-end FIREFLY Installation Supplies .....	17
Water Wire-end FIREFLY Installation / Pit Splice Supplies .....	18
Basement Splice Supplies .....	20
FIREFLY Menu Screen.....	21
Programming MOSAIC FIREFLYs .....	23
Pre-Installation Setup .....	23
Installing the Sensor-end MOSAIC FIREFLY .....	25
Programming the Sensor-end MOSAIC FIREFLY .....	27
Installing Wire-end MOSAIC FIREFLYs.....	33
Programming Wire-end MOSAIC FIREFLY .....	39
Connecting and Programming the Remote Shutoff Valve.....	44
Connecting the Remote Shutoff Valve.....	44
Programming the Remote Shutoff Valve.....	44
Extract Profile Data .....	47
Program GPS Coordinates .....	48
Options .....	49
Operate RSV .....	50
Set Phy Fram.....	53
Set FF To Ship Mode.....	54
Upgrade Firmware .....	55
Set FF Date/Time .....	59
View Mesh Neighbors.....	60
Set Radio Port .....	61
Using a FIREFLY as a Repeater.....	62
Joining the MESH Network/LED Status .....	63
General LED Information .....	63
MOSAIC FIREFLYs Connected to an Encoded Meter (Mesh Mode) .....	64
MOSAIC FIREFLYs Connected to a Pulse Meter (Mesh Mode) .....	64
MOSAIC Sensor-end FIREFLYs (Mesh Mode) .....	64
MOSAIC FIREFLYs as Repeaters (Mesh Mode) .....	65
MOSAIC FIREFLYs in Non-Mesh Mode.....	65
MOSAIC FIREFLYs on Encoded Meters (Non-Mesh Mode).....	65
MOSAIC FIREFLYs on Pulse Meters (Non-Mesh Mode) .....	65
MOSAIC FIREFLYs (D411X only) Connected to Remote Shutoff Valves .....	65
Troubleshooting Procedures.....	66
MOSAIC FIREFLY Codes .....	66
Connection Troubleshooting .....	66
Unread Meters Troubleshooting.....	66
Red Light is Not Solid After Installation.....	67
Troubleshooting Sensor FIREFLYs .....	68

Making Adjustments for Inaccurate Sensor-end FIREFLYs .....	70
Manually Calibrating the Sensor-end FIREFLY .....	70
Mounting the MOSAIC FIREFLY .....	71
Basic Install Information: .....	71
Wall Mount / Basement Splice Mount.....	71
Lid Lock Mount .....	72
Vault Mount .....	72
FAQ's.....	73
Contacting Datamatic .....	83
Support.....	83
Consumables.....	86
Return Material Authorizations (RMAs) .....	88
Training and Support.....	94

## **MOSAIC™ regulations and Warranty information**

The MOSAIC System is intended to be operated to manufacturer's specifications. As such, Customer understands that electronic communication between Datamatic and your MOSAIC System is required to provide software updates, to conduct support activities and to validate proper configuration and operation. Any blocking or prevention of such access may prevent the System from operating as intended and may void coverage under your Maintenance Agreement and/or your Warranty.

Any change to RF settings, other than by a Datamatic Administrator, may void your MOSIAC FIREFLY Warranty. Do not change RF communication settings without consulting Datamatic first.

## FCC Regulations



*FCC Part 15 requires that the Manual include the following statement:*

“Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.”

“NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To comply with FCC RF exposure compliance requirements, the antenna used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operate in conjunction with any other antenna or transmitter.



**FCC ID: VE4-GW2C-AC, VE4-GW2-D, ODYD4000, ODYD4100, and ODYD4111G**  
**Datamatic, Ltd.**

*This device complies with Part 15 of the FCC Rules.*

*Operation is subject to the following two conditions:*

- 1) This device may not cause harmful interference, and*
- 2) This device must accept any interference received, including interference that may cause undesired operation.*

**WARNING: These devices operate under Part 15 of the FCC rules. Modifications to these devices not expressly authorized by Datamatic, Ltd. may affect your ability to legally operate these devices.**



**Electrostatic Discharge (ESD) Warning**

Electrostatic Discharge (ESD) is the enemy of electronic devices. You should always take precautions to eliminate any electrostatic charge from your body and clothing before touching any semiconductor device or card by using an electrostatic wrist strap and/or rubber mat.

Static electricity can harm system boards. Perform installation at an ESD workstation and follow proper ESD precautions to reduce the risk of damage to devices. Datamatic strongly encourages you to follow proper ESD procedure, which can include wrist straps and smocks, when servicing equipment.

You can also take the following steps to prevent damage from electrostatic discharge (ESD):

- When unpacking a static-sensitive device from its shipping carton, do not remove the device's anti-static packaging material until you are ready to install the device. Just before unwrapping the anti-static packaging, be sure you are at an ESD workstation or grounded.
- When transporting a sensitive device, first place it in an antistatic container or packaging.
- Handle all sensitive devices at an ESD workstation. If possible, use anti-static floor pads and workbench pads.

Handle devices and boards with care. Don't touch the devices or contacts on a board. Hold a board by its edges or by its metal mounting bracket.

## Introduction


The Datamatic MOSAIC Mesh System is an automatic meter reading system designed for reading meter data remotely and wirelessly. This is accomplished using the Datamatic MOSAIC Mesh system that forms a mesh network with neighboring MOSAIC FIREFLYs and reports data to the MOSAIC Software Interface through strategically placed MOSAIC Gateway devices.

MOSAIC FIREFLYs can be deployed using walk-by, mobile, and/or MOSAIC Mesh collection platforms.

The main benefits of using The Datamatic MOSAIC Mesh system are:

- Real time access to meter reading data
- Built in logging of up to 320 days of hourly consumption data
- Meter lids do not have to be removed for reads
- Meter pits do not have to be dug out or pumped out for reads
- Safer meter reading procedure
- Visiting the site is not necessary for data collection

Please consult the MOSAIC Software Guide for user instructions regarding data access, configuring or upgrading the MOSAIC Mesh FIREFLY System. After reviewing this guide you should be able to successfully deploy the MOSAIC FIREFLYs for your system.



# Equipment

## ROADRUNNER Handheld

The ROADRUNNER Radio Frequency Receiving Unit (RFRU) receives and buffers radio readings, then downloads them to the ROADRUNNER handheld unit when interrogated using the "I" key.

The ROADRUNNER RFRU is an integrated, internal unit, powered by a rechargeable NiCad battery pack.



## MOSAIC FIREFLY

The MOSAIC FIREFLY tracks and transmits meter reading data. Each MOSAIC FIREFLY records up to 320 days of hourly consumption readings, thereby enabling the resolution of billing disputes. The MOSAIC FIREFLY signal includes the meter reading, leak indicators and trouble codes upon detection. (Refer to the troubleshooting section)

- **Batteries:** Dual 3.6-volt lithium-thionyl chloride D-cell
- **Material:** Polycarbonate
- **Construction:** silicon-lubricated gasket sealed tourqued to 12' lbs
- **Operating Temperature Range:** -40 F to 185 F
- **Radio Communication Frequency:** 902-928 MHz frequency hopping spread spectrum

## Unique Features

- Use existing meters
- Maintain the freedom to choose meters without the constraints of a proprietary AMR system
- Internally potted, gasket sealed and designed to withstand constant submersion
- Supports direct-read, pulse and encoded registers
- Leak Detection
- Tamper Detection
- Battery Status Indicator
- Above ground or through the lid installation

**Wire-end MOSAIC FIREFLY****Sensor-end MOSAIC FIREFLY****Nicor-end MOSAIC FIREFLY**

Nicor-end FIREFLYs are connected to a Nicor-end register as follows:

Insert the pins from the FIREFLY's Nicor connector into the connector on the register side. Be careful not to force the pins. Bent pins are not covered by the FIREFLY Warranty, so pay attention to proper alignment to ensure a clean connection.

## Lid Lock

The preferred installation method in a water pit environment is to use the Lid Lock system. The Lid Lock adapters hold the MOSAIC FIREFLY securely and allow the MOSAIC FIREFLY to be easily screwed into the Lid Lock. There are two types of adapters available (as shown below).



Lid Lock Adapter for Dome Lid (MOSAIC)

Datamatic Product ID: 540018-0001



Lid Lock Adapter, MOSAIC A-Frame

Datamatic Product ID: USCMI5TWATRLOCKAFR




MOSAIC FIREFLY with Lid Lock Adapter for Dome Lid (MOSAIC)



MOSAIC FIREFLY with Lid Lock Adapter, MOSAIC A-Frame

**NOTE:** To properly remove the MOSAIC A-Frame Lid Lock Adapter from a FIREFLY:

- 1 – Press outward on the feet of the adapter and slide the “feet” off of the FIREFLY tabs
- 2 – Lift the tab on the back of the adapter using a flat head screwdriver and slide the adapter off the neck of the FIREFLY



## Remote Shutoff Valve

The Remote Shutoff Valve (RSV) is used in conjunction with the MOSAIC FIREFLY (D411X only) to control water service termination, providing utilities with a convenient method to deploy water shut-off service. The FIREFLY can issue commands to the RSV to Open, Close, or report its current status (open or closed).

There are three software/firmware components to the RSV system. These are ROADRUNNER software, radio firmware, and the FIREFLY firmware. To ensure proper functionality of any RSV, the units should be loaded with the minimum software/firmware listed below:

- ROADRUNNER CE 3.26.4
- Radio firmware 1.3.20
- FIREFLY D4110 firmware 1.5.2

- **Batteries:** lithium battery pack with an output of 3.6V
- **Construction:** brass plated ball-valve with a non-corroding compound; able to operate at a 150 psi pressure and compliant with AWWA Standard C700-02, section 4.2.9
- **Operating Temperature Range:** -1 C to +60 C



## Installation Considerations

- Signal distance varies depending on the location of the MOSAIC FIREFLY. Those installed above ground or through plastic lids generally transmit the greatest distance.
- The material of a pit or vault lid greatly affects the transmission range. For example, a transmitter has a greater range sending from a pit with a plastic lid than a cast iron lid. A FIREFLY mounted under any type of lid is subject to flooding. Since water impedes RF transmission it is best to mount through the lid using a Lid Lock.
- Lids with holes of a diameter of roughly 1 ¾ inches make it possible to mount the MOSAIC FIREFLY through the lid. This can increase transmission range significantly and protect against loss of signal due to flooded pits. It is not recommended to install FIREFLYs under iron or metal lids as RF performance is degraded.
- Complete field installation of a MOSAIC FIREFLY takes five to ten minutes, depending on the meter location and mounting application.
- If the lid has a hole for the unit, use the Lid Lock, Lid Lock adapter, and appropriate washer. Ensure that enough space exists between the meter box lid and the ground for the MOSAIC FIREFLY to fit. If not, remove some of the dirt from the bottom of the meter. Do not over-tighten Lid Locks.
- Some meters may be located in such a manner that they require the addition of repeaters to reach the mesh.
- Some areas of your service territory may not have the density to warrant the use of the mesh - your project manager will alert you to these areas where units can be placed into a drive-by mode.
- Profile data uses more mesh bandwidth and as such can require the use of additional repeaters and/or Gateways.
- The system requires ongoing maintenance - make sure to have the proper equipment and training to maintain the system after your installation contractor leaves.
- Do not attempt to repair or trouble-shoot equipment without the proper equipment and training.

# Installation Supplies

## Basic Supplies

- Klein Crimping Tool – Part No. D2346
- Wire Stripper
- Zip ties, White 14”
- 4 lb pull telescoping magnet
- Lid Lock
- 3M IDC Connector



## Water Sensor-end FIREFLY Installation Supplies

### Basic Supplies:

*Below is an illustration of materials used with Sensor-end installations:*



Work Out Waterless Hand Cleaner



Lint Free Cotton Squares



99% Isopropyl Rubbing Alcohol



Wire Cutter (for cutting zip ties)



Razor blade tool or chisel (for cleaning meter faces)



Plumber's Goop Adhesive #15112 (Purple Tube)



DOW CORNING 111 Compound  
Unit of Measure: 5.3 oz. Tube



Sensor flaps



3M Adhesive Replacements



Zip Ties—14"

Additional supplies: Cloth Rags,  $\frac{3}{4}$ " PVC pipe; sch. 40

## Water Wire-end FIREFLY Installation / Pit Splice Supplies

Following is a list of materials required to install a wire-end MOSAIC FIREFLY using the Water Pit Splice technique:


### UY Connectors

- 3M IDC Connector – Yellow Part No. 34-7035-9854-9  
(use only approved crimping tool - Klein Crimping Tool – Part No. D2346)



### Burial Pod


- 3M Direct Burial Splice Pod – Part No. 054007



### DOW CORNING

Valve lubricant (for direct-connect only)

- MFG. Model # 111




Grainger Industrial Supply [www.grainger.com](http://www.grainger.com) Call toll-free at 1-888-361-8649, 24 hours a day, 7 days a week.

## Basement Splice Supplies

Following is a list of materials required to install a wire-end MOSAIC FIREFLY using the Basement Splice technique:

### UY Connectors

- 3M IDC Connector – Yellow Part No. 34-7035-9854-9  
(use only approved crimping tool - Klein Crimping Tool – Part No. D2346)



### 3M Scotch 2200 Vinyl Mastic Pads

- [www.3m.com](http://www.3m.com) (to locate local distributor)



*Note:* Supplies for installation can be purchased from:

Grainger Industrial Supply [www.grainger.com](http://www.grainger.com) Call toll-free at 1-888-361-8649, 24 hours a day, 7 days a week.

## FIREFLY Menu Screen

Select the FF Menu key on the ROADRUNNER CX to access these options:

<b>1. Define Templates</b> (Setting this up saves time during the programming process. Please see Appendix A – F for details.)
<b>2. Program by Template</b> (Use to program the FIREFLY. Please see Programming the Sensor-end MOSAIC FIREFLY and Programming Wire-end MOSAIC FIREFLY sections below.)
<b>3. Program by Parameter</b> (Use to reprogram a FIREFLY's individual parameters settings.)
<b>4. View Settings</b> (Allows the user to view all current parameters of that FIREFLY.)
<b>5. Extract Profile Data</b> (Extracts reading, saves consumption. This is the FIREFLY's history. Please see the Extract Profile Data section below.)
<b>6. Set Reading Mode</b> (Determines the way you will read the FIREFLYs. Please see the Pre-Installation Setup section below.)
<b>7. Program GPSCoords</b> (Use to program GPS coordinates to a FIREFLY or Gateway. Please see the Program GPS Coordinates section below.)
<b>8. Capture Config</b> (To manually capture configuration 'programming' data at any time.)
<b>9. Options</b> (Use to set options for the ROADRUNNER. Please see the Options section below for details.)
<b>A. Operate RSV</b> (Use to operate a Remote Shutoff Valve connected to a FIREFLY. Please see the Operate RSV section below for details.)
<b>B. Set Phy Fram</b> (Sets the phy fram value)
<b>C. Define AutoCAL Rules</b> (Use to set rules the FIREFLY must meet during AutoCAL. Please see the Pre-Installation Setup section below.)
<b>D. Set FF To Ship Mode</b> (Sets the FIREFLY to Ship mode. Please see the Set FF To Ship Mode section below for details.)

<b>E.</b>	<b>Clear Flags</b> (Use to clear flags in the FIREFLY.)
<b>F.</b>	<b>Upgrade Firmware</b> (Use to load firmware images to the FIREFLY and OREO. Please see the Upgrade Firmware section below for details.)
<b>G.</b>	<b>Set FF Date/Time</b> (Set the FIREFLY date and time. Please see the Set FF Date/Time section below for details.)
<b>H.</b>	<b>View MESH Neighbors</b> (Please see the View MESH Neighbors section below for details.)
<b>I.</b>	<b>Set Radio Port</b> (Please see the Set Radio Port section below for details.)
<b>X.</b>	<b>Exit</b> (Exit out of the FIREFLY Menu.)

## Programming MOSAIC FIREFLYs

### Pre-Installation Setup

#### #1 Verify the ROADRUNNER Date / Time / and Time Zone settings are correct

*Refer to the ROADRUNNER Pocket Guide for step-by-step instructions.*

#### #2 [F5-1] Set your FIREFLY Template:

*See Appendix A through F for specific Template parameters*

The “Desired Firmware” template option can be utilized to specify the version of firmware that should be loaded to each FIREFLY being programmed. When setup, this feature will automatically detect the current FIREFLY firmware version and load the “Desired Firmware” version during FIREFLY programming if the two values do not match.

#### #3 [F5-6] Set the Reading Mode

Set the FIREFLY mode to **Verify FF Read**

**Set Reading Mode options include the following:**

“**Single FF Read**” allows the user to interrogate a single non-mesh FIREFLY (selected on the ROADRUNNER) during the time it is configured to accept reading requests.

“**Verify FF Read**” allows the user to Read Verify the physical meter reading against the non-mesh FIREFLY reading during the time the non-mesh FIREFLY is configured to accept reading requests.

“**Multi FF Read**” allows the user to interrogate all non-mesh FIREFLYs (in the current route on the ROADRUNNER) during the time they are configured to accept reading requests.

**NOTE:** After a read is taken in Multi FF Read mode, the FIREFLY enters a dormant state for 10 minutes. This is done to reduce the amount of RF traffic. The FIREFLY will not respond to commands during this dormant time.

#### #4 [F5-9] Check the Options Screen

(Please see the Options section below for an explanation of all Options.)

Check the options screen from the FIREFLY Menu for the following:

- 1) FIREFLY Support Mode = MOSAIC Mode
- 2) Capture Data = Enabled
- 3) Delta Warning = 2
- 4) Truncation = Enabled
- 5) Connection ID Method = Serial Number (\*NOTE\* the first time a FIREFLY is programmed, the connection method must be set to serial number)

- 6) Radio Communication Mode = \_\_\_\_\_  
(Mesh or Non-Mesh / FNCTN [blue key] + C to toggle)
- 7) GPS Format = \_\_\_\_\_
- 8) GPS Longitude Location = \_\_\_\_\_
- 9) GPS Latitude Location = \_\_\_\_\_
- 10) Radio Data Mode = Binary
- 11) Gas Read View = DISREGARD
- 12) Multi-Read Sleep Int. = \_\_\_\_\_
- 13) Firmware Update Method = RLOAD
- 14) Image File Naming Convention = \_\_\_\_\_

### **#5 [F5-B] Check the Phy Fram setting**

The Phy Fram is the setting the radio inside the ROADRUNNER uses to communicate with the FIREFLY. The radio and FIREFLY must be on the same setting to communicate. The default Phy Fram for all FIREFLYs is B4D2B4D2. If you are not sure what your phy fram value is, please contact Datamatic Customer Support.

### **#6 [F5-C] Check the AutoCAL Rules (applies to Sensor-end FIREFLYs only)**

Check the AutoCAL Rules screen for the following:

- 1) Minimum Dip – 18
- 2) Minimum Background – 60
- 3) Maximum Background – 225
- 4) Primer Threshold – 10
- 5) Maximum Threshold – 50
- 6) Dip Multiplier – 43%

## Installing the Sensor-end MOSAIC FIREFLY

The Datamatic Sensor FIREFLY for water meter applications relies on pulses of infra-red light emitted by the sensor head four times a second and are directed at the face of the register dial. Sensors in the head then read the infra-red light pulses reflected off the register face to determine if the needle has passed underneath the sensor head. The successful sensing of the needle passage then depends on the unrestricted light transmission from the light-emitting source in the sensor, through the air between the source and the register lens, the register lens, the atmosphere in the register, the reflectance of the register dial face and the reflected light's transmission back through those elements to the sensor. The performance of the Datamatic Sensor FIREFLY for water meter applications could be affected unless the following requirements are maintained:

- Register lens face must be free of scratches to allow for a permanent, water-tight seal with the sensor.
- Register lens material must be clear, free of cloudy imperfections or milky tones, etc.
- Register must have a solid colored, radius-type needle (no full-diameter needles).
- Register must be permanently sealed, with a completely dry register cavity - no water, moisture or dirt or humidity fogging can be present in the register.
- Register conditions must allow for the Datamatic Sensor FIREFLY to generate a minimum background value of 100.

Note - There will be a percentage of meter registers in every system, depending on age and condition of meters, which may require replacement based on failures of above in order to support the Sensor FIREFLY. You should incorporate these requirements in your ongoing water meter maintenance program.

### The 4 P's of Installation

1. Preparation
2. Placement
3. Pressure
4. Programming

#### **#1 Preparation of the Meter**

- a) Remove meter box lid and check for meter serial number.
- b) Survey the meter, checking lid, hole depth, and overall cleanliness.
- c) Check for meter disqualification. Enter the corresponding skip code if necessary.
- d) Place sensor flap onto FIREFLY cable.
- e) Flip lid back and pre-clean meter face/lens using Work Out Waterless Hand Cleaner or Fast Orange non-pumice cleaner and a cloth or cotton swab to remove residue.
- f) Clean meter face/lens with 99% isopropyl alcohol and a NEW lint-free cotton swab.
- g) Re-wipe the surface of the meter lens with a clean, new cotton swab each time until the swab comes up clean, and the clean lens squeaks when wiped.
- h) After cleaning, ensure that the lens is *completely dry*; allow time for the alcohol to evaporate.

**NOTE:** Only use isopropyl rubbing alcohol marked “**99% by volume**”. Lower concentrations, such as the commonly available 91%, do not clean or evaporate well and adversely affect sensor-to-meter bond.

## #2 Placement of the Sensor

- a) Insert sensor cable through sensor flap.
- b) Remove the adhesive backing from the high-bond tape on the optic sensor face.
- c) Orient the sensor so the water meter needle approaches the sensor from the cable side and perpendicular to the cable. There are marks on each side of the sensor base that are to be in line with the needle when it passes. Do not place the sensor over any moving part or the sweep hand of the register. Normally, place sensor along outer edge of register.

*Here is an example of correct Sensor Placement*



## #3 Pressure – To the Sensor on the Meter







**NOTE:** Since the 3M tape provides a **pressure sensitive seal**, the installer must apply 15 lbs. of pressure to the **FIREFLY** optical sensor immediately after attaching to the lens surface for a minimum of 60 seconds.

- a) **Very Important:** Press the adhesive down for **60+ seconds** using **15 lbs of pressure**. Allow 24-96 hours to cure.
- b) Fasten the cable to the register with a zip tie.
- c) Place DOW CORNING 111 Compound or Goop-Plumber's Adhesive #15112 (purple tube) around the edge of the sensor and under the tail of the sensor. Do not squirt the adhesive UNDER the 3M seal. The goal is to provide a temporary water barrier between the meter face and the edge of the sensor, so that the 3M adhesive can cure properly.
- d) Position the flap at the base of the sensor so that it folds over and “hangs” above the register to try to keep most of the stray light out while it processes through AutoCAL. The flap will be “pulled” over the sensor snuggly lying flatter on the meter during the Read and Verify procedure that will be discussed later.







## #4 Programming (see below)






## Programming the Sensor-end MOSAIC FIREFLY

Mesh Mode	Non-Mesh Mode
<p><b>FFSN</b></p> <p><b>Configure FIREFLY</b></p> <p><b>FFSN:</b></p> <p>Serial Number 10008467</p>	<p><b>Configure FIREFLY</b></p> <p><b>FFSN:</b></p> <p>Serial Number 10008467</p>
<p><b>Register Brand</b></p> <p><b>Auto Configuration</b></p> <p><b>Register Brand</b></p> <p>ABB AMCO Badger ADE Badger HG Rcdall Badger New Rcdall Badger Old Rcdall</p>	<p><b>Auto Configuration</b></p> <p><b>Register Brand</b></p> <p>ABB AMCO Badger ADE Badger HG Rcdall Badger New Rcdall Badger Old Rcdall</p>
<p><b>Register Size</b></p> <p><b>Auto Configuration</b></p> <p><b>Register Size</b></p> <p>1 5 10 50 100 500</p>	<p><b>Auto Configuration</b></p> <p><b>Register Size</b></p> <p>1 5 10 50 100 500</p>

Mesh Mode	Non-Mesh Mode
<b>Constant</b> 	<b>Constant</b> 
<b>Target Background</b> 	<b>Target Background</b> 
<b>Meter ID</b> 	<b>Meter ID</b> 
<b>Rollover</b> 	<b>Rollover</b> 

Mesh Mode	Non-Mesh Mode
<b>Profile Interval</b>	
<p>Auto Configuration</p> <p>Profile Interval</p> <p>Old Value</p> <p>60</p> <p>New Value</p> <input type="text" value="60"/>	<p>Auto Configuration</p> <p>Profile Interval</p> <p>Old Value</p> <p>60</p> <p>New Value</p> <input type="text" value="60"/>
<b>Primer Threshold</b>	
<p>Auto Configuration</p> <p>Primer Threshold</p> <p>Old Value</p> <p>50</p> <p>New Value</p> <input type="text" value="10"/>	<p>Auto Configuration</p> <p>Primer Threshold</p> <p>Old Value</p> <p>50</p> <p>New Value</p> <input type="text" value="10"/>
<b>Reading</b>	
<p>Auto Configuration</p> <p>Reading</p> <p>Old Value</p> <p>7</p> <p>New Value</p> <input type="text" value="10"/>	<p>Auto Configuration</p> <p>Reading</p> <p>Old Value</p> <p>7</p> <p>New Value</p> <input type="text" value="10"/>
<b>Read Truncation</b>	
<p>Auto Configuration</p> <p>Read Truncation</p> <p>Old Value</p> <p>0</p> <p>New Value</p> <input type="text" value="0"/>	<p>Auto Configuration</p> <p>Read Truncation</p> <p>Old Value</p> <p>0</p> <p>New Value</p> <input type="text" value="0"/>

Mesh Mode	Non-Mesh Mode
<b>Optic Read Delay</b>	
	
<b>Leak Duration (Bins)</b>	
	
<b>Select Time Zone</b>	
	
<b>Drive by Schedule</b>	
<p>Drive by Schedule is not required for Mesh FIREFLYs.</p>	

Mesh Mode	Non-Mesh Mode
<b>Conservation Zone</b> 	<b>Conservation Zone</b> is a Mesh function at this time. Please contact Datamatic Project Management to discuss this option.
<b>GPS Coordinates</b> 	<b>GPS Coordinates</b> for Mtr# 10505 
<b>Enter AutoCAL</b> 	<b>Enter AutoCAL</b> 

Mesh Mode	Non-Mesh Mode																																																																														
<b>MIU Info</b>																																																																															
<table border="1"> <thead> <tr> <th>MIU Info</th> <th>MIU Settings</th> </tr> </thead> <tbody> <tr> <td> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Primary FWV</td> <td>1.5.16</td> </tr> <tr> <td>Secondary FWV</td> <td>0.0.0</td> </tr> <tr> <td>Bootloader</td> <td>1.0.0</td> </tr> <tr> <td>Date</td> <td>10/14/2011</td> </tr> <tr> <td>Time</td> <td>11:13:35</td> </tr> <tr> <td>Time Zone</td> <td>-6</td> </tr> </tbody> </table> </td><td> <table border="1"> <thead> <tr> <th>MIU Info</th> <th>MIU Settings</th> </tr> </thead> <tbody> <tr> <td> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Primary FWV</td> <td>1.5.16</td> </tr> <tr> <td>Secondary FWV</td> <td>0.0.0</td> </tr> <tr> <td>Bootloader</td> <td>1.0.0</td> </tr> <tr> <td>Date</td> <td>10/14/2011</td> </tr> <tr> <td>Time</td> <td>11:13:35</td> </tr> <tr> <td>Time Zone</td> <td>-6</td> </tr> </tbody> </table> </td></tr> </tbody> </table> </td><td> <table border="1"> <thead> <tr> <th>MIU Info</th> <th>MIU Settings</th> </tr> </thead> <tbody> <tr> <td> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table> </td><td> <table border="1"> <thead> <tr> <th>MIU Info</th> <th>MIU Settings</th> </tr> </thead> <tbody> <tr> <td> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table> </td></tr> </tbody> </table> </td></tr> </tbody> </table> </td></tr></tbody></table>	MIU Info	MIU Settings	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Primary FWV</td> <td>1.5.16</td> </tr> <tr> <td>Secondary FWV</td> <td>0.0.0</td> </tr> <tr> <td>Bootloader</td> <td>1.0.0</td> </tr> <tr> <td>Date</td> <td>10/14/2011</td> </tr> <tr> <td>Time</td> <td>11:13:35</td> </tr> <tr> <td>Time Zone</td> <td>-6</td> </tr> </tbody> </table>	Parameter	Value	Primary FWV	1.5.16	Secondary FWV	0.0.0	Bootloader	1.0.0	Date	10/14/2011	Time	11:13:35	Time Zone	-6	<table border="1"> <thead> <tr> <th>MIU Info</th> <th>MIU Settings</th> </tr> </thead> <tbody> <tr> <td> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Primary FWV</td> <td>1.5.16</td> </tr> <tr> <td>Secondary FWV</td> <td>0.0.0</td> </tr> <tr> <td>Bootloader</td> <td>1.0.0</td> </tr> <tr> <td>Date</td> <td>10/14/2011</td> </tr> <tr> <td>Time</td> <td>11:13:35</td> </tr> <tr> <td>Time Zone</td> <td>-6</td> </tr> </tbody> </table> </td></tr> </tbody> </table>	MIU Info	MIU Settings	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Primary FWV</td> <td>1.5.16</td> </tr> <tr> <td>Secondary FWV</td> <td>0.0.0</td> </tr> <tr> <td>Bootloader</td> <td>1.0.0</td> </tr> <tr> <td>Date</td> <td>10/14/2011</td> </tr> <tr> <td>Time</td> <td>11:13:35</td> </tr> <tr> <td>Time Zone</td> <td>-6</td> </tr> </tbody> </table>	Parameter	Value	Primary FWV	1.5.16	Secondary FWV	0.0.0	Bootloader	1.0.0	Date	10/14/2011	Time	11:13:35	Time Zone	-6	<table border="1"> <thead> <tr> <th>MIU Info</th> <th>MIU Settings</th> </tr> </thead> <tbody> <tr> <td> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table> </td><td> <table border="1"> <thead> <tr> <th>MIU Info</th> <th>MIU Settings</th> </tr> </thead> <tbody> <tr> <td> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table> </td></tr> </tbody> </table> </td></tr> </tbody> </table>	MIU Info	MIU Settings	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table>	Parameter	Value	Reading	10	Register Number	11007138	Serial Number	11007138	Meter Type	Optic	Optic Gain	3	Optic Threshold	25	Constant	1	-----	-----	<table border="1"> <thead> <tr> <th>MIU Info</th> <th>MIU Settings</th> </tr> </thead> <tbody> <tr> <td> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table> </td></tr> </tbody> </table>	MIU Info	MIU Settings	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table>	Parameter	Value	Reading	10	Register Number	11007138	Serial Number	11007138	Meter Type	Optic	Optic Gain	3	Optic Threshold	25	Constant	1	-----	-----
MIU Info	MIU Settings																																																																														
<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Primary FWV</td> <td>1.5.16</td> </tr> <tr> <td>Secondary FWV</td> <td>0.0.0</td> </tr> <tr> <td>Bootloader</td> <td>1.0.0</td> </tr> <tr> <td>Date</td> <td>10/14/2011</td> </tr> <tr> <td>Time</td> <td>11:13:35</td> </tr> <tr> <td>Time Zone</td> <td>-6</td> </tr> </tbody> </table>	Parameter	Value	Primary FWV	1.5.16	Secondary FWV	0.0.0	Bootloader	1.0.0	Date	10/14/2011	Time	11:13:35	Time Zone	-6	<table border="1"> <thead> <tr> <th>MIU Info</th> <th>MIU Settings</th> </tr> </thead> <tbody> <tr> <td> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Primary FWV</td> <td>1.5.16</td> </tr> <tr> <td>Secondary FWV</td> <td>0.0.0</td> </tr> <tr> <td>Bootloader</td> <td>1.0.0</td> </tr> <tr> <td>Date</td> <td>10/14/2011</td> </tr> <tr> <td>Time</td> <td>11:13:35</td> </tr> <tr> <td>Time Zone</td> <td>-6</td> </tr> </tbody> </table> </td></tr> </tbody> </table>	MIU Info	MIU Settings	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Primary FWV</td> <td>1.5.16</td> </tr> <tr> <td>Secondary FWV</td> <td>0.0.0</td> </tr> <tr> <td>Bootloader</td> <td>1.0.0</td> </tr> <tr> <td>Date</td> <td>10/14/2011</td> </tr> <tr> <td>Time</td> <td>11:13:35</td> </tr> <tr> <td>Time Zone</td> <td>-6</td> </tr> </tbody> </table>	Parameter	Value	Primary FWV	1.5.16	Secondary FWV	0.0.0	Bootloader	1.0.0	Date	10/14/2011	Time	11:13:35	Time Zone	-6	<table border="1"> <thead> <tr> <th>MIU Info</th> <th>MIU Settings</th> </tr> </thead> <tbody> <tr> <td> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table> </td><td> <table border="1"> <thead> <tr> <th>MIU Info</th> <th>MIU Settings</th> </tr> </thead> <tbody> <tr> <td> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table> </td></tr> </tbody> </table> </td></tr> </tbody> </table>	MIU Info	MIU Settings	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table>	Parameter	Value	Reading	10	Register Number	11007138	Serial Number	11007138	Meter Type	Optic	Optic Gain	3	Optic Threshold	25	Constant	1	-----	-----	<table border="1"> <thead> <tr> <th>MIU Info</th> <th>MIU Settings</th> </tr> </thead> <tbody> <tr> <td> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table> </td></tr> </tbody> </table>	MIU Info	MIU Settings	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table>	Parameter	Value	Reading	10	Register Number	11007138	Serial Number	11007138	Meter Type	Optic	Optic Gain	3	Optic Threshold	25	Constant	1	-----	-----			
Parameter	Value																																																																														
Primary FWV	1.5.16																																																																														
Secondary FWV	0.0.0																																																																														
Bootloader	1.0.0																																																																														
Date	10/14/2011																																																																														
Time	11:13:35																																																																														
Time Zone	-6																																																																														
MIU Info	MIU Settings																																																																														
<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Primary FWV</td> <td>1.5.16</td> </tr> <tr> <td>Secondary FWV</td> <td>0.0.0</td> </tr> <tr> <td>Bootloader</td> <td>1.0.0</td> </tr> <tr> <td>Date</td> <td>10/14/2011</td> </tr> <tr> <td>Time</td> <td>11:13:35</td> </tr> <tr> <td>Time Zone</td> <td>-6</td> </tr> </tbody> </table>	Parameter	Value	Primary FWV	1.5.16	Secondary FWV	0.0.0	Bootloader	1.0.0	Date	10/14/2011	Time	11:13:35	Time Zone	-6																																																																	
Parameter	Value																																																																														
Primary FWV	1.5.16																																																																														
Secondary FWV	0.0.0																																																																														
Bootloader	1.0.0																																																																														
Date	10/14/2011																																																																														
Time	11:13:35																																																																														
Time Zone	-6																																																																														
MIU Info	MIU Settings																																																																														
<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table>	Parameter	Value	Reading	10	Register Number	11007138	Serial Number	11007138	Meter Type	Optic	Optic Gain	3	Optic Threshold	25	Constant	1	-----	-----	<table border="1"> <thead> <tr> <th>MIU Info</th> <th>MIU Settings</th> </tr> </thead> <tbody> <tr> <td> <table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table> </td></tr> </tbody> </table>	MIU Info	MIU Settings	<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table>	Parameter	Value	Reading	10	Register Number	11007138	Serial Number	11007138	Meter Type	Optic	Optic Gain	3	Optic Threshold	25	Constant	1	-----	-----																																							
Parameter	Value																																																																														
Reading	10																																																																														
Register Number	11007138																																																																														
Serial Number	11007138																																																																														
Meter Type	Optic																																																																														
Optic Gain	3																																																																														
Optic Threshold	25																																																																														
Constant	1																																																																														
-----	-----																																																																														
MIU Info	MIU Settings																																																																														
<table border="1"> <thead> <tr> <th>Parameter</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Reading</td> <td>10</td> </tr> <tr> <td>Register Number</td> <td>11007138</td> </tr> <tr> <td>Serial Number</td> <td>11007138</td> </tr> <tr> <td>Meter Type</td> <td>Optic</td> </tr> <tr> <td>Optic Gain</td> <td>3</td> </tr> <tr> <td>Optic Threshold</td> <td>25</td> </tr> <tr> <td>Constant</td> <td>1</td> </tr> <tr> <td>-----</td> <td>-----</td> </tr> </tbody> </table>	Parameter	Value	Reading	10	Register Number	11007138	Serial Number	11007138	Meter Type	Optic	Optic Gain	3	Optic Threshold	25	Constant	1	-----	-----																																																													
Parameter	Value																																																																														
Reading	10																																																																														
Register Number	11007138																																																																														
Serial Number	11007138																																																																														
Meter Type	Optic																																																																														
Optic Gain	3																																																																														
Optic Threshold	25																																																																														
Constant	1																																																																														
-----	-----																																																																														

## Installing Wire-end MOSAIC FIREFLYs

Connect the wires with the MOSAIC FIREFLY and meter using the wiring scheme below:

If the meter you wish to use does not appear on this list, please contact your Datamatic Project Manager.

MOSAIC-Class FIREFLY ENCODED WIRING				
Brand	Model	FF Wires	Meter Wires	Meter Type
Actaris	Cyble Coder	Red	Red	3 or 17
		Green	Green	
		Black	Black	
ABB/AMCO/Kent	Scancoder	Red	Green	2
		Green	Red	
		Black	Black	
AMCO	InVision	Red	Green	3, 14, or 17
		Green	Red	
		Black	Black	
Badger	ADE	Red	Red	3
		Green	Green	
		Black	Black	
Hersey	Translator	Red	Red	16
		Green	White or Green	
		Black	Black	
Master	BL	Red	Red	3
		Green	Green	
		Black	Black	
Metron	Hawkeye OER	Black	Black	3
		Red	Red	
		Green	Green	
Neptune/Schlumberger	ARB V	Red	Black	9 (4 digit) 10 (5 digit) 11 (6 digit)
		Green	Red	
		Black	Green	
Neptune/Schlumberger	ARB VI PRO	Red	Black	15*
		Green	Red	
		Black	Green	
Neptune/Schlumberger	AUTO	Red	Black	15*
		Green	Red	
		Black	Green	
Neptune	E-coder	Red	Black	13 or 15
		Green	Red	
		Black	Green	
Sensus/Rockwell/Invensys	SR II / ICE (TR-PL)	Red	Red	3
		Green	Green	
		Black	Black	
Sensus/Rockwell/Invensys	Touchread/SR II (TR-PL)	Red	Red	1
		Green	Green	
		Black	Black	
Sensus/Rockwell/Invensys	PMM/AMR System (TR-PL)	Red	Red	3
		Green	Green	
		Black	Black	

\*Previously installed FIREFLYs may report a Meter Type of 12

MOSAIC-Class FIREFLY PULSE WIRING					
Brand	Model	FF Wires	Meter Wires	Note	Meter Type
Actaris	Cyble Sensor	Black	White	FF Red and Green shorted together	4
		Blue	Brown		
AMCO	Digital Pulse	Black	Red		5
		Green	Green		
Badger	RTR	Blue	Black	FF Red and Green shorted together	4
		Black	Black		
Badger	RTR (Pulse with tamper)	Blue	Red		5
		Green	Green		
Corona	Pulsar (Pulse with tamper)	Green	Green		5
		Black	Brown		
Corona	Pulsar	Blue	White	FF Red and Green shorted together	4
		Black	Brown		
Hendey Performance	HPM PMN 05 Nitro 1	Blue	Green	FF Red and Green shorted together	4
		Black	Black		
Hendey Performance	PMN PMN 05 Nitro 1	Blue	Green	FF Red and Green shorted together	4
		Black	Black		
Kent/Elster	V100	Black	Blue	FF Red and Green shorted together	4
		Blue	Red		
Master	Logical Switch	Black	Black	FF Red and Green shorted together	4
High Glass		Blue	Red		
Master	Pulse	Black	Black	FF Red and Green shorted together	4
		Blue	Red		
MOSAIC-Class FIREFLY REPEATER WIRING					
All models except D4000 & D4110	Red		FF Red and Blue shorted together	253	
	Blue				
MOSAIC-Class FIREFLY to Remote Shutoff Valve WIRING					
	FF Wires	RSV Wires	FF Red and Blue shorted together	19	
	Green	Green			
	Yellow	White			
	Black	Brown			
MOSAIC-Class FIREFLY to PermaLog WIRING					
	FF Wires	PLOG Wires		3, 16, or 17	
	Red	Red			
	Green	Green			
	Black	Black			

**Schematics: Write in the Wire Color Combinations Below**

**MOSAIC FIREFLY**

**Meter**

**Schematics: Write in the Wire Color Combinations Below**

**MOSAIC FIREFLY**

**Meter**

**Schematics: Write in the Wire Color Combinations Below**


**MOSAIC FIREFLY**

**Meter**

**Schematics: Write in the Wire Color Combinations Below**

**MOSAIC FIREFLY**

**Meter**



### Crimping UY connectors

Be careful not to nick any individual wires when removing the insulated covering from the wires.

Connect the wires using UY gel cap connectors. If the wires are stripped, cut off the stripped ends. Wires must have un-striped ends for use in gel cap connectors. Use the Klein crimping tool to secure the gel cap connectors. Do not use standard pliers to crimp UY connectors.

Make sure wires are fully seated – pull gently to verify that there is a secure connection.



### MOSAIC FIREFLY with UY gel cap connectors to register

*Note:* Once connected to the encoded register, test the MOSAIC FIREFLY connections by swiping the magnet under the LED's to activate the MOSAIC FIREFLY.



After swiping, the MOSAIC FIREFLY will indicate a good connection to an encoded register by displaying a solid red LED. Note, if the red LED does not go solid after attaching to an encoded register the FIREFLY may not be connected correctly or the register cannot be read.

Pulse output registers do not provide instant feedback from the register after programming. A Read Verification will need to be performed after installation to verify the meter is pulsing to the FIREFLY properly. It is crucial to be sure the wires are connected properly prior to inserting them into the burial pod.

After swiping, the MOSAIC FIREFLY will indicate a successful connection to a pulse register by displaying a fast-blinking red LED. Insert the connections into the 3M burial pod.



**MOSAIC FIREFLY with burial pod connecting to the register**

### Splice Methods

#### Water Pit Splice Method for Direct Register Connections:

- Strip the wires back.
- Cut excess wires and direct connect to meter according to wire connections guide per register type.
- Fill the wire connection reservoir on the meter with DC-111.

Each register terminal and wire connection must be protected from moisture utilizing the Electrical Insulating Compound Specified below:



**DOW CORNING**  
**MFG. Model # 111**

#### Basement Splice:


- Space the connections out so that the Mastic Pad will cover the entire connection.
- The 3M Scotch Vinyl Mastic Pad can be cut so that one pad covers 2-3 installations depending on the number of wires needed and type of connectors used.
- Be sure there is enough pad to completely cover the connections.
- Due to the nature of the Mastic Adhesive, this installation cannot be completed in temperatures below 45 degrees Fahrenheit.
- Once the Mastic Adhesive is placed over the splice, it must be squeezed together and molded around the splice to insure a watertight seal.



**Mastic Pad**








## Nicor Connections

Nicor-end FIREFLYs are connected to a Nicor-end register as follows:









Insert the pins from the FIREFLY's Nicor connector into the connector on the register side. Be careful not to force the pins. Bent pins are not covered by the FIREFLY Warranty, so pay attention to proper alignment to ensure a clean connection.






## Programming Wire-end MOSAIC FIREFLY

Mesh Mode	Non-Mesh Mode
<b>FFSN</b> 	<b>Configure FIREFLY</b> <b>FFSN:</b> 
<b>Register Brand</b> 	<b>Auto Configuration</b> <b>Register Brand</b> 
<b>Register Size</b> 	<b>Auto Configuration</b> <b>Register Size</b> 
<b>Constant</b> 	<b>Auto Configuration</b> <b>Constant</b> 

Mesh Mode	Non-Mesh Mode
<b>Meter ID</b>	
<p>Auto Configuration</p> <p><b>Meter ID</b> Old Value 7303076166 <b>New Value</b> <input type="text" value="18123015"/></p>	<p>Auto Configuration</p> <p><b>Meter ID</b> Old Value 7303076166 <b>New Value</b> <input type="text" value="18123015"/></p>
<b>Rollover</b>	
<i>**NOTE: Rollover applies to pulse style meters ONLY**</i>	
<p>Auto Configuration</p> <p><b>Rollover</b> Old Value 6 <b>New Value</b> <input type="text" value="6"/></p>	<p>Auto Configuration</p> <p><b>Rollover</b> Old Value 6 <b>New Value</b> <input type="text" value="6"/></p>
<b>Profile Interval</b>	
<p>Auto Configuration</p> <p><b>Profile Interval</b> Old Value 60 <b>New Value</b> <input type="text" value="60"/></p>	<p>Auto Configuration</p> <p><b>Profile Interval</b> Old Value 60 <b>New Value</b> <input type="text" value="60"/></p>

Mesh Mode	Non-Mesh Mode
<b>Pulse Ratio</b>	
<b>**NOTE: Pulse Ratio applies to pulse style meters ONLY**</b>	
	
<b>Reading</b>	
Enter the meter reading, or press Esc to allow the encoder reading to post (for Encoded meters only).	
	
<b>Read Truncation</b>	
	

Mesh Mode	Non-Mesh Mode																																						
<b>Leak Duration (Bins)</b>																																							
<p>Auto Configuration</p> <p>Leak Duration (Bins)</p> <p>Old Value</p> <p>48</p> <p>New Value</p> <p>24</p>	<p>Auto Configuration</p> <p>Leak Duration (Bins)</p> <p>Old Value</p> <p>48</p> <p>New Value</p> <p>24</p>																																						
<b>Select Time Zone</b>																																							
<p>Select Time Zone</p> <table border="1"> <thead> <tr> <th>Offset</th> <th>Time Zone</th> </tr> </thead> <tbody> <tr><td>-11:00</td><td>Samoa Standard Time</td></tr> <tr><td>-10:00</td><td>Hawaiian Standard Time</td></tr> <tr><td>-9:00</td><td>Alaskan Standard Time</td></tr> <tr><td>-8:00</td><td>Pacific Standard Time</td></tr> <tr><td>-7:00</td><td>Mountain Standard Time</td></tr> <tr><td>-7:00</td><td>Mountain Standard Time ..</td></tr> <tr><td>-7:00</td><td>US Mountain Standard Time</td></tr> <tr><td><b>-6:00</b></td><td><b>Central Standard Time</b></td></tr> <tr><td>-5:00</td><td>Central Standard Time ..</td></tr> </tbody> </table>	Offset	Time Zone	-11:00	Samoa Standard Time	-10:00	Hawaiian Standard Time	-9:00	Alaskan Standard Time	-8:00	Pacific Standard Time	-7:00	Mountain Standard Time	-7:00	Mountain Standard Time ..	-7:00	US Mountain Standard Time	<b>-6:00</b>	<b>Central Standard Time</b>	-5:00	Central Standard Time ..	<p>Select Time Zone</p> <table border="1"> <thead> <tr> <th>Offset</th> <th>Time Zone</th> </tr> </thead> <tbody> <tr><td>-11:00</td><td>Samoa Standard Time</td></tr> <tr><td>-10:00</td><td>Hawaiian Standard Time</td></tr> <tr><td>-9:00</td><td>Alaskan Standard Time</td></tr> <tr><td>-8:00</td><td>Pacific Standard Time</td></tr> <tr><td>-7:00</td><td>Mountain Standard Time</td></tr> <tr><td>-7:00</td><td>Mountain Standard Time ..</td></tr> <tr><td><b>-6:00</b></td><td><b>Central Standard Time</b></td></tr> <tr><td>-5:00</td><td>Central Standard Time ..</td></tr> </tbody> </table>	Offset	Time Zone	-11:00	Samoa Standard Time	-10:00	Hawaiian Standard Time	-9:00	Alaskan Standard Time	-8:00	Pacific Standard Time	-7:00	Mountain Standard Time	-7:00	Mountain Standard Time ..	<b>-6:00</b>	<b>Central Standard Time</b>	-5:00	Central Standard Time ..
Offset	Time Zone																																						
-11:00	Samoa Standard Time																																						
-10:00	Hawaiian Standard Time																																						
-9:00	Alaskan Standard Time																																						
-8:00	Pacific Standard Time																																						
-7:00	Mountain Standard Time																																						
-7:00	Mountain Standard Time ..																																						
-7:00	US Mountain Standard Time																																						
<b>-6:00</b>	<b>Central Standard Time</b>																																						
-5:00	Central Standard Time ..																																						
Offset	Time Zone																																						
-11:00	Samoa Standard Time																																						
-10:00	Hawaiian Standard Time																																						
-9:00	Alaskan Standard Time																																						
-8:00	Pacific Standard Time																																						
-7:00	Mountain Standard Time																																						
-7:00	Mountain Standard Time ..																																						
<b>-6:00</b>	<b>Central Standard Time</b>																																						
-5:00	Central Standard Time ..																																						
<b>Drive by Schedule</b>																																							
Drive by Schedule is not required for Mesh FIREFLYs.	<p>Drive by Schedule</p> <p>Old Value</p> <table border="1"> <thead> <tr> <th>Mon</th> <th>Tue</th> <th>Wed</th> <th>Thu</th> <th>Fri</th> <th>Sat</th> <th>Sun</th> </tr> </thead> <tbody> <tr><td>Y</td><td>Y</td><td>Y</td><td>Y</td><td>Y</td><td>Y</td><td>N</td></tr> </tbody> </table> <p>06:00 20:00</p> <table border="1"> <thead> <tr> <th>Mon</th> <th>Tue</th> <th>Wed</th> <th>Thu</th> <th>Fri</th> <th>Sat</th> <th>Sun</th> </tr> </thead> <tbody> <tr><td>Y</td><td>Y</td><td>Y</td><td>Y</td><td>Y</td><td>Y</td><td>N</td></tr> </tbody> </table> <p>Start <input type="button" value="6:00"/> End Hour <input type="button" value="20:00"/></p>	Mon	Tue	Wed	Thu	Fri	Sat	Sun	Y	Y	Y	Y	Y	Y	N	Mon	Tue	Wed	Thu	Fri	Sat	Sun	Y	Y	Y	Y	Y	Y	N										
Mon	Tue	Wed	Thu	Fri	Sat	Sun																																	
Y	Y	Y	Y	Y	Y	N																																	
Mon	Tue	Wed	Thu	Fri	Sat	Sun																																	
Y	Y	Y	Y	Y	Y	N																																	

Mesh Mode	Non-Mesh Mode
<b>Conservation Zone</b> 	<b>Conservation Zone</b> is a Mesh function at this time. Please contact Datamatic Project Management to discuss this option.
<b>GPS Coordinates</b> 	<b>GPS Coordinates</b> 
<b>Auto Configuration</b> 	<b>Auto Configuration</b> 

## Connecting and Programming the Remote Shutoff Valve

### Connecting the Remote Shutoff Valve

Connect the RSV wires with the MOSAIC FIREFLY using the wiring scheme below:

FIREFLY Wire	Remote Shutoff Valve Wire	FIREFLY
Green	Green	Blue
Yellow	White	Red
Black	Brown	Shorted together


See **Installation Procedures** section for detailed instructions and approved splicing methods.

NOTE: Remote Shutoff Valves should only be installed by a licensed plumber.

### Programming the Remote Shutoff Valve


From the FIREFLY Menu, select option 3. Program by Parameter.

Enter FIREFLY Serial number and press Enter.




Select option 2. Meter ID. Verify that the Register/Meter number is correct that you are programming into the FIREFLY:


The Meter ID can be up to 10 alphanumeric characters (16 characters may be used only if employing the RS3 Import/Export record layouts).



Enter the Register/Meter (or FIREFLY Serial Number) number and press Enter.



Go to “Done” at the bottom of the screen and press Enter



Go to E. Save & Exit and press Enter




The software will return to the MIU Settings screen. Press “Enter” to be returned to the FIREFLY menu. Press ESC to be returned to the account screen.

Press the ‘I’ Key to initialize the RF Receiver and read the FIREFLY.

**NOTE FOR FIREFLYs IN NON-MESH MODE:**

By default, all FIREFLYs are programmed with a default active window of 6:00 am to 8:00 pm, CST. You must program the FIREFLY according the to instructions above in order to load it with the offset value required for the FIREFLY to be active between 6:00 am and 8:00 pm in your local time zone.

Please verify that the time zone is correctly set on your ROADRUNER by accessing Control Panel via the Windows desktop. Once in Control Panel, select View: Supervisor Mode. Enter the password 'YIWT' and press Enter. Select the Date / Time icon and use the drop down box to select your correct Time Zone setting. Press Apply then OK (in the top right-hand corner) to save the settings.




## Extract Profile Data

NOTE: Profile extraction is available for FIREFLYs in Non-Mesh Mode only.

From the FIREFLY Menu, select option 5. Extract Profile Data.

Enter the Serial Number of the FIREFLY you are extracting Profile data from.



During extraction, the following screen will display:

```
Profile Extraction

Retrieving profile data
From FIREFLY.
F/W Vers: 1.7.28 {4100}

10045295

Transfer Status: 256 xfr'd
Please Wait...
```

When profile data extraction is complete, the following screen will display:


```
=====
Profile extraction completed
successfully

=====
```


## Program GPS Coordinates

From the FIREFLY Menu, select option 7. Program GPS Coords.

Enter the FIREFLY or Gateway serial number.



Enter Latitude and Longitude and press Enter.



OR

NOTE: When using the software on the ROADRUNNER, GPS coordinates can be entered either by Degrees/Minutes/Seconds, or by Decimal Degrees (select by using the drop-down in the Entry Format dialog box. Please be certain that the GPS device you are using is on one of these two formats when collecting the data.

For example, on an etrex Garmin GPS device the Decimal Degree collection option displays as hddd.ddddd° and the Degrees/Minutes/Seconds collection option displays as hddd°mm'ss.s

Please be sure that you are entering in the same format into the ROADRUNNER as you are viewing on your GPS device (such as a Garmin).

Press Enter to continue or End to return to the main menu.

## Options


From the FIREFLY Menu, select option 9. Options to set options for the ROADRUNNER.

1. FIREFLY Support Mode	1. Legacy Support 2. MOSAIC Support
2. Capture Data	1. Enable 2. Disable
3. Delta Warning	Value
4. Truncation	1. Enable 2. Disable
5. Connection ID Method	1. Meter Number 2. Serial Number 3. User Selects
6. Radio Communication Mode	1. NON-MESH 2. MESH
7. GPS Format	1. Decimal 2. Degrees/Minutes/Seconds
8. GPS Longitude Location	1. Western Hemisphere 2. Eastern Hemisphere
9. GPS Latitude Location	1. Northern Hemisphere 2. Southern Hemisphere
A. Radio Data Mode	1. Binary 2. Text
B. Gas Read View	1. Cubic Feet 2. 100 Cubic Feet
C. Multi-Read Sleep Int.	_____ Minutes
D. Firmware Update Method	1. TFTP 2. RLOAD = Default
E. Image File Naming Convention	1. Account Number 2. Meter Number 3. Address

## Operate RSV

From the FIREFLY Menu, select option A. Operate RSV to program and control Remote Shutoff Valves.

Enter FIREFLY Serial number and press Enter.




---


NOTE: When communicating with FIREFLYs in Mesh Mode, it is necessary to swipe the FIREFLY with a magnet before initializing communications.

---

The RSV Control Menu will display indicating the serial number and current status of the RSV device.



Select the command you wish to execute.



Press “Enter” to execute the selected command.

```
RSV Close
NAME UNKNOWN
ADDRESS UNKNOWN
FFSN 10015341
=====
Press Enter to
Close RSV

Alarm Conditions:

Press ESC key to go back
```

“Status: WORKING” and “Checking RSV State” message indicate the ROADRUNNER is actively communicating with the FIREFLY and RSV.

```
RSV Close
NAME UNKNOWN
ADDRESS UNKNOWN
FFSN 10015341
=====
Press Enter to
Close RSV
STATUS: WORKING...
Alarm Conditions:

Press ESC key to go back
```

```
RSV Close
NAME UNKNOWN
ADDRESS UNKNOWN
FFSN 10015341
=====
Press Enter to
Close RSV
Checking RSV State...
Alarm Conditions:

Press ESC key to go back
```

When a command is successfully completed, the ROADRUNNER will display a message indicating success and the user will be prompted to “Press ESC to go back”.

```
RSV Close
NAME UNKNOWN
ADDRESS UNKNOWN
FFSN 10015341
=====
Press Enter to
Close RSV
RSV CLOSED
Alarm Conditions:
None

Press ESC key to go back
```

The alarm conditions that can be detected for the RSV are:

- Failed
- Stuck
- Low Battery
- Tamper


When the 'Failed' flag is reported, the software will display 'Stuck' since the valve is stuck in the wrong position. It is possible that the FIREFLY can report one or more of these conditions. In the cases where more than one condition is reported, commas will separate the conditions.

Once the FIREFLY reports a stuck valve, in order for that condition to be cleared, the valve must successfully be cycled between opened, closed, and then opened again before it will clear the stuck status.

## Set Phy Fram

The Phy Fram is the setting the radio inside the ROADRUNNER uses to communicate with the FIREFLY. The radio and FIREFLY must be on the same setting to communicate. The default Phy Fram for all FIREFLYs is B4D2B4D2. If you are not sure what your phy fram value is, please contact Datamatic Customer Support.

From the FIREFLY Menu, select option B. Set Phy Fram and enter the desired phy fram value.



Press Enter to update the phy fram value.

```
=====
The OREO PHY FRAM has been
changed.




Press any key to continue.

=====
```

## Set FF To Ship Mode


From the FIREFLY Menu, select option D. Set FF To Ship Mode.

Enter the FIREFLY serial number and press Enter.



## Upgrade Firmware


From the FIREFLY Menu, select option F. Upgrade Firmware.



If the user is loading a firmware image from one type to another type, i.e. from Non-Mesh to MESH or from MESH to Non-Mesh, if the image is being loaded into the primary image location, the software will temporarily switch the radio mode to match the new expected mode when the firmware image loading process has completed. This will allow the software to verify that the image loaded correctly. When the user exits the firmware loading dialogs, the software will switch the radio mode back to the original settings (if necessary) prior to the firmware image loading operation.


### Radio Firmware

Select option 1. Radio Firmware to update the OREO radio firmware.




The Update Firmware dialog box will list only OREO images. Select an image to send to the OREO from the Available Firmware Images area at the top of the dialog box.

Press 'L' to load the selected firmware image to the radio. Select the target destination and press Enter.




Press 'C' to copy firmware currently loaded to the radio. Copy options are:

1. Primary to Secondary
2. Secondary to Primary
3. Exit




When OREO radio firmware is loaded to both the Primary and Secondary locations, and additional option to "Swap" is available. Press 'S' to swap the Primary and Secondary firmware versions.



## FIREFLY Firmware

Select option 2. FIREFLY Firmware to update the FIREFLY firmware.


Enter the FIREFLY serial number and press “Enter”.




The Update Firmware dialog box will list “Available Firmware Images” at the top of the screen and “Current Firmware Images” at the bottom of the screen. Select an image to send to the FIREFLY from the Available Firmware Images area at the top of the screen.

Press ‘L’ to load the selected firmware image to the FIREFLY. Select the target destination and press Enter.

NOTE: It is recommended to always load FIREFLY firmware to the Secondary location, then swap to Primary.




Press ‘S’ to swap the Primary and Secondary firmware versions.



Press 'C' to copy firmware currently loaded to the radio. Copy options are:


1. Primary to Secondary
2. Secondary to Primary
3. Exit



## Set FF Date/Time

From the FIREFLY Menu, select option G. Set FF Date/Time.

Enter the FIREFLY serial number and press Enter.



The ROADRUNNER will display the current ROADRUNNER time and the current FIREFLY time.



Press "Set Time" to apply the ROADRUNNER date/time to the FIREFLY. Press "Done" to quit.

=====

**FIREFLY Clock Update Successful**




=====

Press "Enter" to return to the FIREFLY Menu.

## View Mesh Neighbors

From the FIREFLY Menu, select option H. View MESH Neighbors.

Enter the FIREFLY serial number and press Enter.




MESH Neighbor Data			
MESH Neighbor Summary		Mesh Neighbor Data	
Neighbor	RSSI	RFLQ	
300064	-77	100	
12523367	-80	100	
12515129	-80	100	
12017708	-80	100	
12509098	-85	100	
12515582	-85	50	
10098916	-85	100	
12507735	-85	100	
10002001	-85	100	

## Set Radio Port


From the FIREFLY Menu, select option I. Set Radio Port.

If the radio com port has not yet been detected, the following screen should display:



Arrow down to highlight Com 3 and press Enter. The software will attempt to detect the OREO radio com port.

If the radio com port has been detected, the following screen should display:



In most cases, the Select Radio Type screen will display the following values:

1 = CRADLE


2 = LEMO

3 = Radio

4 = GPS

7 = USB

Another way to verify that the OREO radio com port has been detected by the software is to access the Communications screen (press F3 from within a route) and the Radio F/W value should be displayed as illustrated below:



## Using a FIREFLY as a Repeater

You will need a repeater in situations where there is excess distance between installed units. Repeaters help 'lighten the load' in passing data to the MOSAIC Gateway in dense installation areas and areas with excessive RF obstructions.

- Wire red & blue together and swipe with the magnet to activate the MOSAIC FIREFLY as a repeater.



Repeaters are ideally placed above ground with the antenna in a vertical position. When using FIREFLYs as repeaters, they can be placed in pits, but a resulting loss of RF performance should be anticipated. For best results and maximum coverage mount the repeater similar to the picture above.

## Joining the MESH Network/LED Status

### General LED Information



#### LED Key:

Slow blink = on and off once per second

Fast blink = on and off four times per second

 = Meter Indicator

 = Mesh Indicator

Swipe the magnet in the box area surrounding the lights. After a successful magnet swipe, the green light will be solid for a *very short period* of time to confirm that the MOSAIC FIREFLY is initializing.

If the green light is fast blinking with no red light activity, there is a possibility that the real time clock (RTC) has stopped and the FIREFLY will need to be returned via RMA.

A solid GREEN LED indicates that the MOSAIC FIREFLY has received a valid message from the mesh. Confirmation that the MOSAIC FIREFLY has successfully transmitted to the mesh is indicated by the appearance of the FF in the MOSAIC software.

Generally, in mesh mode the GREEN LED indicates the status of MOSAIC FIREFLY communications with the mesh. The RED LED indicates the status of MOSAIC FIREFLY communications with the meter.

After a certain amount of time, the LEDs will go out during normal operation. This is a power-save mode. The MOSAIC FIREFLYs will be performing normally, but not exhibiting LED behavior. When MOSAIC FIREFLYs are in “ship mode” they are literally turned off and can be reactivated by following normal installation procedures.

MOSAIC FIREFLYs in non-mesh mode do not communicate via the mesh. The RED LED indicates the status of the MOSAIC FIREFLY's communications with the meter. The RED and GREEN LEDs flash in unison every 5 seconds to indicate that the MOSAIC FIREFLY is functioning in non-mesh mode.

## **MOSAIC FIREFLYs Connected to an Encoded Meter (Mesh Mode)**

After a successful initial swipe, the GREEN LED will flash slowly as the MOSAIC FIREFLY searches for the mesh. When communication has been established with a node already connected to the mesh (MOSAIC Gateway, Repeater or another MOSAIC FIREFLY) the GREEN LED will go solid.

Additionally, the RED LED will flash slowly until it detects the encoder. If the MOSAIC FIREFLY successfully connects to the encoder, the RED LED will go solid.

If the RED LED flashes quickly, the MOSAIC FIREFLY has detected its connection to a meter, but has not received an acknowledgement that verifies it is connected to a supported encoder. In this scenario, the wires may not be connected correctly or the encoder may not be supported in the current MOSAIC FIREFLY firmware.

If the RED LED flashes slowly, the MOSAIC FIREFLY is searching for an acknowledgement from a meter, but has not received any. The MOSAIC FIREFLY will continue to wait for an acknowledgement, but will eventually go into ship mode if none is received.

The MOSAIC FIREFLY is successfully connected to an encoded meter and the mesh when both the GREEN and RED LEDs are solid.

## **MOSAIC FIREFLYs Connected to a Pulse Meter (Mesh Mode)**

After a successful initial swipe, the RED LED will blink slowly until it detects a connection with a pulse meter. NOTE: this happens very quickly.

Once the MOSAIC FIREFLY detects the connection to a pulse meter, the RED LED blinks quickly until 5 meter pulses are detected. Once 5 pulses are detected, the RED LED will go solid.

If the MOSAIC FIREFLY is not wired correctly, the RED LED will continue blink slowly, or the MOSAIC FIREFLY could go back into ship mode (meaning the RED LED will go off after the magnet swipe).

## **MOSAIC Sensor-end FIREFLYs (Mesh Mode)**

After a successful magnet swipe, the RED LED will blink slowly as the FIREFLY attempts to achieve the Target Background. Once the RED LED begins a fast blink then goes solid, the FIREFLY has achieved the target background.

Additionally, the GREEN LED will flash slowly as the MOSAIC FIREFLY searches for the mesh. When communication has been established with a node already connected to the mesh (MOSAIC Gateway, Repeater or another MOSAIC FIREFLY) the GREEN LED will go solid.

If both the RED LED and the GREEN LED blink slowly, then go off. The FIREFLY was unable to achieve the target background. Reprogramming should be attempted.

## **MOSAIC FIREFLYs as Repeaters (Mesh Mode)**

When wired as a repeater, after a successful initial swipe, the RED LED will go solid and the GREEN LED will flash slowly as the MOSAIC FIREFLY searches for the mesh. When communication has been established with a node already connected to the mesh (MOSAIC Gateway, Repeater or another MOSAIC FIREFLY) the GREEN LED will go solid.

## **MOSAIC FIREFLYs in Non-Mesh Mode**

After a successful magnet swipe, the green light will be solid for a *very short period* of time to confirm that the MOSAIC FIREFLY is initializing. There is no other GREEN LED behavior on MOSAIC FIREFLYs in non-mesh mode until programming is complete. When MOSAIC FIREFLYs in non-mesh mode are working correctly, the RED and GREEN LEDs will flash in unison every 5 seconds.

## **MOSAIC FIREFLYs on Encoded Meters (Non-Mesh Mode)**

After a successful initial swipe, the RED LED will flash slowly until it detects the encoder. If the MOSAIC FIREFLY successfully connects to the encoder, the RED LED will go solid.

If the RED LED flashes quickly, the MOSAIC FIREFLY has detected its connection to a meter, but has not received an acknowledgement that verifies it is connected to a supported encoder. In this scenario, the wires may not be connected correctly or the encoder may not be supported in the current MOSAIC FIREFLY firmware.

If the RED LED flashes slowly, the MOSAIC FIREFLY is searching for an acknowledgement from a meter, but has not received any. The MOSAIC FIREFLY will continue to wait for an acknowledgement, but will eventually go into ship mode if none is received.

## **MOSAIC FIREFLYs on Pulse Meters (Non-Mesh Mode)**

After a successful initial swipe, the RED LED will blink slowly until it detects a connection with a pulse meter. NOTE: this happens very quickly.

Once the MOSAIC FIREFLY detects the connection to a pulse meter, the RED LED blinks quickly until 5 meter pulses are detected. Once 5 pulses are detected, the RED LED will go solid.

If the MOSAIC FIREFLY is not wired correctly, the RED LED will continue to blink slowly, or the MOSAIC FIREFLY could go back into ship mode (meaning the RED LED will go off after the magnet swipe).

## **MOSAIC FIREFLYs (D411X only) Connected to Remote Shutoff Valves**

The Remote Shutoff Valve (RSV) controls a water valve remotely. The RSV is connected to a FIREFLY. The ROADRUNNER or MOSAIC communicates to the FIREFLY to control the RSV. The ROADRUNNER is able to control the RSV with or without a route loaded. There are 3 functions that can be performed on a RSV; Open RSV, Close RSV, and get current status of RSV (Open or Closed).

# Troubleshooting Procedures

## MOSAIC FIREFLY Codes

Code	Description	Meaning	Onsite visit Y or N?	Steps To Resolve
BA10	Battery	Battery is low	Yes	RMA for battery replacement
Ta40	Tamper	System recorded En70 48 times	Yes	Perform <i>Connection Troubleshooting*</i> below
Le60	Leak	25 hours of continual consumption	Yes	Check for leak
EN70	Encoder Not Read	Did not receive reading	Yes	Perform <i>Connection Troubleshooting*</i> below
EN80	Encoder Invalid	“Other” message. System received “garbled” data from meter	No	Should get a reading at next scheduled reading time. Check register if the message is being transmitted frequently.
MESH	Mesh Alarm	Hardware Alarm	Yes	Remove & Replace immediately
Pr11	Primary Image	Loading primary image	No	Should not affect reading
Se13	Secondary Image	Loading secondary image	No	Should not affect reading

## Connection Troubleshooting

1. Check for physical damage to the MOSAIC FIREFLY wire.
2. Check for physical damage to the Register.
3. If possible, test the register head.

**NOTE:** Water FIREFLY Firmware Version 1.8.22 and greater will no longer re-auto detect when mag swiped. Instead, the **red** LED behavior when encoders are not exiting from ship mode has been modified. Now, slow blink **red** means **‘no communication with encoder’** and fast blink **red** means **‘good encoder read.’** The LED functionality when exiting out of ship mode and/or non-encoded registers remains the same.

4. If there is no physical damage detected resplice and reswipe the MOSAIC FIREFLY.
  - a. Repeat step several times if necessary.
  - b. If the red light goes solid, report the MOSAIC FIREFLY and continue to monitor.
  - c. Request an RMA if the issue persists.

## Unread Meters Troubleshooting

1. Research in the MOSAIC Software Interface to determine when the last read was and check for possible patterns.

2. If the MOSAIC FIREFLY is unable to join the network:
  - a. Verify that the MOSAIC FIREFLY is installed and mounted properly in the meter pit
  - b. Swipe the meter & refer to the LED Operational States for verification of functional status Mesh (light will slow blink green). Go to the nearest neighboring MOSAIC FIREFLY and swipe.
  - c. Check the unread MOSAIC FIREFLY for solid green light (this process can take several attempts). Before swiping both units must be “asleep” (no LED lights) before attempting to swipe again.
3. Continue monitoring in MOSAIC Software & replace unread MOSAIC FIREFLY if the issue persists.
4. If after all troubleshooting is complete & you are unable to achieve a solid green light the MOSAIC FIREFLY should be replaced.
  - a. If there is no LED response within 5 seconds of magnet swipe retry several times. If the unit in question continues to be unresponsive it should be replaced.

### **Red Light is Not Solid After Installation**


The MOSAIC FIREFLY has been wired but the red light never changes to solid upon installation.

1. Check the wire connections, it is likely there is a wiring problem.
2. Verify that the register head is working.

NOTE: When connected to a pulse meter, the red light will fast-blink until 5 pulses are received.

## Troubleshooting Sensor FIREFLYs

Press the FFMNU key (F5 key) bring up the MOSAIC FIREFLY Config Menu.



Select item 4 (View Settings) to display Current Settings of the FIREFLY.

MIU Info		MIU Settings	Diagnostics
Parameter	Value		
Primary FWV	1.5.16		
Secondary FWV	0.0.0		
Bootloader	1.0.0		
Date	10/14/2011		
Time	11:30:27		
Time Zone	-6		

MIU Info		MIU Settings	Diagnostics
Parameter	Value		
Reading	10		
Register Number	11007138		
Serial Number	11007138		
Meter Type	Optic		
Optic Gain	3		
Optic Threshold	25		
Constant	1		

Parameter	Value
Background	119
ACAL Prm Threshld	10
ACAL Max Bkgrd	225
ACAL Min Bkgrd	60
Last Sensor Max	169
Last Sensor Min	113

Select item 3 (Program by Parameter) to view the Individual Parameters of the FIREFLY.

**Program Individual Parameter**  
**FFSW: 11007138**

<b>1. Reading</b>	= 10
<b>2. Meter ID</b>	= 11007138
<b>3. Constant</b>	= 1
<b>4. Rollover</b>	= 6
<b>5. Read Truncation</b>	= 0

## Making Adjustments for Inaccurate Sensor-end FIREFLYs

Symptom	By a small “Delta” <100
Over-counting	Raise Threshold one level
Under-counting	Drop Threshold one level

## Manually Calibrating the Sensor-end FIREFLY

To manually calibrate the FIREFLY, access the Program Individual Parameters screen on the ROADRUNNER.

- Check the Reading, and Optic Threshold parameters. Correct these values as needed. (Optic Threshold range is 6 – 50.) Be sure the FIREFLY reading accurately matches the reading of the meter.
- Check to make sure all other parameters were entered correctly.
- Select Done. This will update the parameters.

## Mounting the MOSAIC FIREFLY

### Basic Install Information:

- Mount the MOSAIC FIREFLY in the meter box with the neck/antenna pointing up.
- Mounting can be accomplished by attaching the MOSAIC FIREFLY to a wall, stake, through the hole in the meter box/vault lid, or with Lid Lock, adapter and spacers.
- When utilizing a Lid Lock, make certain to not over-tighten the MOSAIC FIREFLY within the lock.
- Check for lid clearance; be sure to never rest the weight of the meter lid on the MOSAIC FIREFLY.
- Secure the lid back on the pit.




### Wall Mount / Basement Splice Mount

- Make sure the antenna points up.
- Secure the MOSAIC FIREFLY to the wall.

## Lid Lock Mount

- Verify that you have a Lid Lock Adapter Spacer Ring.
- Never rest the lid on the MOSAIC FIREFLY.
- Do not over tighten the lid lock.
- Both clips should be inserted fully into the MOSAIC FIREFLY.



## Vault Mount

- Mount the MOSAIC FIREFLY as high as possible.

## FAQ's

**Can I use both MOSAIC Gateway backhaul types in a single installation?**

Yes.

**Will I see a difference as far as data collection between the two MOSAIC Gateway backhaul configurations?**

No, you will not see a difference.

**Why would I need to use GPRS in an installation?**

GPRS works well in areas where other types of backhaul coverage are not available.

**How many MOSAIC FIREFLYs can mesh together?**

Typically 1-24 MOSAIC FIREFLYs can communicate directly with each other. The minimum number of MOSAIC FIREFLY connections needed to continue the mesh is 1. The total number of MOSAIC FIREFLYs per MOSAIC Gateway is optimal at 750-850.

**What is the output power of a MOSAIC FIREFLY?**

Transmissions are rated at 250mW.

**What is the range of a MOSAIC FIREFLY?**

Above ground = approximately ¾ mile (line of sight). Pit mounted (through lid) = 500' – 750' (depending on lid material). Many variables affect range, including topography, meter lid material and height of the MOSAIC Gateway.

**Are the new MOSAIC FIREFLYs compatible with previous legacy FIREFLYs?**

No, the transmission frequencies and messages scheme are different; thus a new radio is needed for handheld, mobile and mesh readings.

**Do the MOSAIC FIREFLYs read via the ROADRUNNER MOBILE product?**

Yes, a mobile reading mode is available with the same hardware used for Mesh reading.

**Will I need different MOSAIC FIREFLYS for Mesh and Mobile functionality?**

No, the same hardware used for mobile mode will work with both.

**How do I program an MOSAIC FIREFLY?**

MOSAIC FIREFLYs are programmed via 2-way radio communications from a handheld programmer. New schedules, profile requests and firmware are also loaded via the Mesh.

**What does your handheld programming tool look like?**

The handheld programmer is a Datamatic, LTD ROADRUNNER CX unit with a MOSAIC 2-way radio.

**What is the battery life for the MOSAIC FIREFLY?**

When run at a 20 minute mesh interval, 10 plus years.

**Is the battery pack replaceable?**

Yes, the battery pack can be replaced at Datamatic.

**What frequency does the MOSAIC product use?**

We use a Frequency Hopping Spread Spectrum (FHSS) over the 902-928 MHz band. 50 separate frequencies are utilized.

**Do you use a licensed frequency?**

The radio frequency that Datamatic, LTD uses operates on the ISM band, which is unlicensed.

**Does your product provide profiling?**

Yes the battery operated MOSAIC FIREFLYS have 320 days of hourly profile data on board.

**How do you get the profiling?**

Profile data is extracted in two ways, the MOSAIC FIREFLY can be programmed via the mesh to send an hourly profile packet along with its midnight read, or you can use the RR programmer to extract the profile data on demand (in development). Keep in mind that requesting profile data over the Mesh in large quantities will take time and network resources.

**How often do I get reads via the Mesh?**

Battery powered MOSAIC FIREFLYS send in daily readings by default, with the ability to send in up to hourly.

**Is the system 2-way?**

Yes, the MOSAIC FIREFLYS can send data and receive commands from the MOSAIC Gateway, which in turn communicates with the back office utility. MOSAIC FIREFLYS can also communicate 2-way with a handheld programmer.

**What can I do with the 2-way functionality?**

Update schedules, configurations, extract profile or other data, and more. Communications can be broadcast to an entire Mesh or directed to an individual MOSAIC FIREFLY.

**Does the MOSAIC system have repeaters?**

Yes, low cost repeaters are utilized to bridge the gap between distant MOSAIC FIREFLYS to reduce network congestion at unavoidable Mesh network bottlenecks or to reduce latency.

**How do the MOSAIC FIREFLY repeaters work?**

Each MOSAIC FIREFLY already acts as a repeater. Units wired and dedicated as a MOSAIC FIREFLY repeater utilize the same firmware but do not read a meter and therefore only repeat readings upstream that they receive.

**What is the MOSAIC FIREFLY repeater battery life?**

It works similar to that of a MOSAIC FIREFLY.

**Do you support cellular backhaul from the MOSAIC Gateway?**

Yes, via GPRS only at this time.

## Appendix A

### ROADRUNNER CX with Sensor-end FF in Mesh Mode



**FIREFLY** Template for \_\_\_\_\_

Parameter	Prompt Type	Value	Suggested Value
1. Reading	Normal	Normal	Depends on meter/billing units
2. Meter ID	Normal	Normal	Normal
3. Constant	Default		Depends on meter/billing units
4. Rollover	Default		Depends on meter/billing units
5. Read Truncation	N/A		
6. Target Background	Default		100
7. Optic Read Delay	Default		5
8. Profile Interval	N/A		
9. Primer Threshold	Default		10
A. Leak Duration (Bins)	Default		24
B. Time Zone			
C. GPS Coordinates			
D. Desired Firmware			
E. Conservation Zone			
<b>X. Save and Exit</b>	<b>Save</b>	<b>Your</b>	<b>Template</b>

## Appendix B

### ROADRUNNER CX with Sensor-end FF in Non-Mesh Mode



**FIREFLY** Template for \_\_\_\_\_

Parameter	Prompt Type	Value	Suggested Value
1. Reading	Normal	Normal	Depends on meter/billing units
2. Meter ID	Normal	Normal	Normal
3. Constant	Default		Depends on meter/billing units
4. Rollover	Default		Depends on meter/billing units
5. Read Truncation	Default		Depends on meter/billing units
6. Target Background	Default		100
7. Optic Read Delay	Default		5
8. Profile Interval	Default		60
9. Primer Threshold	Default		10
A. Leak Duration (Bins)	Default		24
B. Time Zone			
C. Drive-by Schedule			
D. GPS Coordinates			
E. Desired Firmware			
<b>X. Save and Exit</b>	<b>Save</b>	<b>Your</b>	<b>Template</b>

\*The schedule defined as the default value in the Template will be used

## Appendix C

### ROADRUNNER CX with Wire-end FF in Mesh Mode on Encoded Meter



**FIREFLY Template for** \_\_\_\_\_

Parameter	Prompt Type	Value	Suggested Value
1. Meter ID	Normal	Normal	Normal
2. Constant	Default		Depends on meter/billing units
3. Read Truncation	N/A		
4. Profile Interval	N/A		
5. Leak Duration (Bins)	Default		24
6. Time Zone			
7. GPS Coordinates			
8. Desired Firmware			
9. Conservation Zone			
<b>X. Save and Exit</b>	<b>Save</b>	<b>Your</b>	<b>Template</b>

## Appendix D

### ROADRUNNER CX with Wire-end FF in Non-Mesh Mode on Encoded Meter



#### FIREFLY Template for \_\_\_\_\_

Parameter	Prompt Type	Value	Suggested Value
1. Meter ID	Normal	Normal	Normal
2. Constant	Default		Depends on meter/billing units
3. Read Truncation	Default		Depends on meter/billing units
4. Profile Interval	Default		60
5. Leak Duration (Bins)	Default		24
6. Time Zone			
7. Drive-by Schedule			
8. GPS Coordinates			
9. Desired Firmware			
<b>X. Save and Exit</b>	<b>Save</b>	<b>Your</b>	<b>Template</b>

\*The schedule defined as the default value in the Template will be used

## Appendix E

### ROADRUNNER CX with Wire-end FF in Mesh Mode on Pulse Meter



**FIREFLY Template for** \_\_\_\_\_

Parameter	Prompt Type	Value	Suggested Value
1. Reading	Normal	Normal	Depends on meter/billing units
2. Meter ID	Normal	Normal	Normal
3. Constant	Default		Depends on meter/billing units
4. Rollover	Default		Depends on meter/billing units
5. Read Truncation	N/A		
6. Profile Interval	N/A		
7. Leak Duration (Bins)	Default		24
8. Pulse Ratio			
9. GPS Coordinates			
A. Time Zone			
B. Desired Firmware			
C. Conservation Zone			
<b>X. Save and Exit</b>	<b>Save</b>	<b>Your</b>	<b>Template</b>

## Appendix F

### ROADRUNNER CX with Wire-end FF in Non-Mesh Mode on a Pulse Meter



**FIREFLY** Template for \_\_\_\_\_

Parameter	Prompt Type	Value	Suggested Value
1. Reading	Normal	Normal	Depends on meter/billing units
2. Meter ID	Normal	Normal	Normal
3. Constant	Default		Depends on meter/billing units
4. Rollover	Default		Depends on meter/billing units
5. Read Truncation	Default		Depends on meter/billing units
6. Profile Interval	Default		60
7. Leak Duration (Bins)	Default		24
8. Pulse Ratio			
9. GPS Coordinates			
A. Time Zone			
B. Drive-by Schedule			
C. Desired Firmware			
<b>X. Save and Exit</b>	<b>Save</b>	<b>Your</b>	<b>Template</b>

\*The schedule defined as the default value in the Template will be used

## Appendix G

The ROADRUNNER software provides Hot Keys to perform certain functions. Please see below for the current list.

FNCTN (blue key) + C = Change communication mode

# Contacting Datamatic

## Support

Datamatic offers the following benefits to its customers under the terms of a Maintenance Agreement.

- 24-hour telephone support
- In-house depot hardware repairs
- Software updates

## System Support during Business Hours

Support for your Datamatic system can be accomplished by:

1. Visiting the Datamatic website at [www.datamatic.com](http://www.datamatic.com)
2. Visiting the MOSAIC website at [www.datamaticmosaic.com](http://www.datamaticmosaic.com) (MOSAIC customers only – with login password)
3. Sending an email to [support@datamatic.com](mailto:support@datamatic.com)
4. Contacting Customer Support at 888-326-5032

## Datamatic Website – Customer Support

To access the Datamatic Customer Support web page, use your browser (e.g. Internet Explorer) and visit [www.datamatic.com](http://www.datamatic.com). Put your mouse cursor over “Services” located in the top banner area, then click on “>>Support” in the drop down box as shown below:





For the timeliest response, contact Customer Support at (888) 326-5032 between 7:30am and 5:30pm CST, Monday thru Friday, excluding holidays. If you call after hours, you can leave a message and a representative will be notified. In this case, you will be contacted within two (2) hours. Do not use email or form-based support requests for emergency issues.

**Current customers may contact  
Customer Support via:**

Toll-free: 888/326-5032  
Phone: 214/540-5200  
Fax 214/540-5027  
support@datamatic.com

Or, you may submit your request with our  
**support request form.**

Click this for non-emergency issues. Fill out and submit the Support Request Form (pictured below) and you will receive a response back from Customer Support within one business day.

## MOSAIC Website – Customer Support

You must have a login for access to the Datamatic MOSAIC website [www.datamaticmosaic.com](http://www.datamaticmosaic.com) . Once logged in, use the **Go To:** master navigation menu to access the ‘Support’ page.



From the MOSAIC Support page you can click on the [support@datamatic.com](mailto:support@datamatic.com) link to send an email. Or dial the Toll-free number to contact Datamatic Customer Support. From the MOSAIC Support page, you can also download the latest User Guides and Software Release Notes for the MOSAIC Software and FIREFLYs:



### System Support after Business Hours

- Customers requiring assistance after Datamatic business hours can leave a message for the appropriate group. Emergency assistance is available 24 hours a day.
- If this is an emergency and can't wait for the next business day, call the 888-326-5032 phone number and then Press **[2]** to leave an emergency message. You always have the option to email [support@datamatic.com](mailto:support@datamatic.com) and your request will be processed the following business day. If paging, please leave your name, number, and message at the prompt to page a Customer Support Representative.
- A customer support representative should return your call within 2 hours.

## Consumables


To order consumables for your ROADRUNNER handheld devices (e.g. batteries, hand straps, etc.) or field installation supplies for your FIREFLYs, then you can best accomplish this through our Customer-only support page at [www.datamatic.com](http://www.datamatic.com). Note that this requires a user name and password, so you will need to contact Customer Support at 888-326-5032 the first time.

Go to the Services >> Support page and click on the “Secure Customer Area” link in the lower right hand corner.

Enter your username and password. If you have trouble or need a new login, then contact Customer Support at 888-326-5032 or email us at [support@datamatic.com](mailto:support@datamatic.com).

Click here to access our  
secure Customer area.


After clicking on this link you will be taken to the secure customer area. Click “Yes” in the message below.



You will be taken to a page that looks similar to the one below, and you will be able to access these options after you have used your supplied username and password.



After a successful login, you will have access to the Consumable Order Form, RMA Request Form, and FIREFLY RMA Request Form.



Select the Consumable Order Form link and fill in all required fields to submit your Consumable Order. An email will be sent to [support@datamatic.com](mailto:support@datamatic.com) and a Datamatic representative will contact you. Datamatic requires a Purchase Order number and/or a signed Sales Quote to process the order. Unfortunately, Datamatic does not accept credit cards.

## Return Material Authorizations (RMAs)


### Non-FIREFLY RMA Request Form

All equipment identified within your Maintenance Agreement can be returned to Datamatic for maintenance and/or repair. Typical equipment included in this category includes ROADRUNNER handhelds and cradles. Check your Maintenance Agreement to be sure. This equipment is maintained and repaired by Datamatic on a best efforts basis. Below is a sample of what might be included and excluded:

- Inclusions – Datamatic shall keep the Hardware and Software in good working order. Maintenance services shall include:
  - A. Preventive Hardware maintenance as is generally provided by the equipment manufacturers.
  - B. Software maintenance, including providing Licensee with such revisions in the Software as Datamatic generally makes available to licensees of the Software at no charge; and
  - C. Remedial maintenance of both the Hardware and Software
- Exclusions – Maintenance and repair services shall not apply to the following:
  - A. FIREFLY Meter Interface Units, Batteries, straps, power supplies, carrying cases, cabinets and mounting equipment or any other consumable supply item.
  - B. Electrical work external to the Hardware or maintenance of accessories, alterations, attachments, or other devices not furnished by Datamatic
  - C. Repair of damages or increases in telephone support or service time caused by accident, transportation, neglect, misuse, Purchaser's employee turnover or alterations (which shall include, but not be limited to, any deviation from circuit or structural machine design as provided by Datamatic)
  - D. Repair or damages or increases in telephone support or service time attributable to the use of the System for purposes for other than which it was designed
  - E. Furnishing supplies or accessories; painting or refinishing the Hardware or furnishing material therefore; making specification changes or performing services connected with relocation of machines; or adding or removing accessories, attachments or other devices
  - F. Software upgrades, releases, enhancements, functionality or products that Datamatic separately licenses or charges for outside of Support and Maintenance.

If there is physical damage or trauma to any ROADRUNNER equipment there will be a \$150.00 damage assessment fee required in advance of any analysis or repair. In these cases, repairs will be done on a time and materials basis and a Purchase Order is required to proceed in all cases.

The Non FIREFLY RMA Request Form allows you to submit an electronic RMA request for ROADRUNNERS, cradles, etc. Fill in all required fields to submit your RMA request:



The screenshot shows the Datamatic website with a banner featuring a woman wearing a headset. The main menu includes COMPANY PROFILE, PRODUCTS, SERVICES, PRESS ROOM, EVENTS, EVENTS, and ABOUT US. A sidebar on the right lists categories: RO, UTIL, PRO, FE, SC, AND, CR, and CU. The 'SUPPORT' section is highlighted. Below it, a 'REQUEST FORM' for 'DATAMATIC'S EQUIPMENT RETURN' is shown. A note states: 'Note: This form is used to submit an RMA request on ROADRUNNER(s), Cradle(s) and/or Controller(s) only. If you need to request an RMA on any other type of equipment, please contact Datamatic. If you have any questions, please contact Datamatic at 888/326-5032.' A note below says 'Fields Marked with \* are required.' A 'Customer Information' section is partially visible at the bottom.

## FIREFLY RMA Request Form

### Warranty Claim Exclusions for Water FIREFLYs

This section describes the Warranty Claim Exclusions for FIREFLY units. If you have any questions about this process, please contact the Datamatic Customer Support Center at 888-326-5032.

Warranty Claims will be processed according to the following progression:

1. Is the unit still within its Warranty period? If yes, then proceed to #2. Do not ship any units that are outside their warranty period to Datamatic. See your Warranty documentation for more details.
2. Is the unit free of physical damage and permanent markings such that it can be repaired and used as intended? If yes, then proceed to #3. Do not ship any units with physical damage to Datamatic. Please dispose of damaged FIREFLYs properly using a local recycling facility.
3. Did the unit fail to function for any of the following reasons, in progression? Please use the claim code tables below as a guide for submitting a FIREFLY RMA claim. Make sure to use blue painter's tape and note the appropriate code. (See picture examples below)

<b>D3 (Legacy/Single-Frequency) Failure Claim Codes – Use Painter's Tape on Back of Unit and Mark Accordingly</b>	
Claim Code	Diagnosis
DEAD	Will not communicate via PPU
NO RF	Will not read via RF signal
FBAT	Low Battery Trouble Code
COUNT	Won't 1) read encoder*, 2) pick up pulse* or 3) achieve sensor background*

\* assumes register or connection issues are eliminated as cause

<b>D4 (MOSAIC) Failure Claim Codes – WATER – Use Painter's Tape on Back of Unit and Mark Accordingly</b>	
Claim Code	Diagnosis
DEAD	No Lights after Mag Swipe - Neither Red nor Green Light Up
NO RF	Lights Work (Red and Green) but No RF with HH via FF SN
FBAT	FBAT Flag in HH Current Settings or in MOSAIC
HDWR	D41xx: HDWR Flag in HH Current Settings or in MOSAIC D4000: HDWR Flag with TEMP, RTC, FLSH, CAL or BLO in HH Current Settings or in MOSAIC
COUNT	Won't 1) read encoder*, 2) pick up pulse* or 3) achieve sensor background*
CLOCK	Fast Flashing Green but No Red At All (No Clock)
FW	Fast Flashing Red but No Green At All (No Firmware)
Other	Call Customer Support - Do Not Ship Without Approval and Full Description

\* assumes register or connection issues are eliminated as cause

<b>D4 (MOSAIC) Failure Claim Codes - GAS - Use Painter's Tape on Back of Unit and Mark Accordingly</b>	
Claim Code	Diagnosis
NO RF	No RF with HH via FF SN after Mag Swipe
FBAT	FBAT Flag in HH Current Settings or in MOSAIC
HDWR	HDWR Flag in HH Current Settings or in MOSAIC
COUNT	Inaccurate despite confirmed programming and properly functioning index*
Other	Call Customer Support - Do Not Ship Without Approval and Full Description


\* assumes index or connection issues are eliminated as cause

<b>D4 (MOSAIC) Failure Claim Codes – REPEATERS - Use Painter's Tape on Back of Unit and Mark Accordingly</b>	
Claim Code	Diagnosis
DEAD	No Mesh or Receive/Transmit LEDs
NO RF	No RF with HH via SN
FBAT	FBAT Flag in HH Current Settings or in MOSAIC
CLOCK	Date not set, date won't set, or won't communicate with Gateway
Other	Call Customer Support - Do Not Ship Without Approval and Full Description

<b>Failure Claim Codes – GATEWAY – Use Painter's Tape on Back of Unit and Mark Accordingly</b>	
<b>Failure Claim Codes for ENET and GPRS Gateways will be determined by Datamatic Customer Support after appropriate troubleshooting</b>	
Claim Code	Diagnosis
DEAD	No Mesh, Receive / Transmit, or socket modem lights at power up
NO RF	Lights Work (Red, Green, or Amber) but No RF comms with HH or neighbor table entries. If problem is backhaul, see No Backhaul below
NO BACKHAUL	Unable to establish Backhaul, but Gateway / Repeater does communicate to the Mesh
SOCMODEM	No socket modem LEDs light up when applying AC (GPRS) or POE (ENET) connection
FBAT	FBAT Flag reported and not able to be cleared by Datamatic
SD CARD	SD Card Flag reported and not able to be cleared by Datamatic
CLOCK	Date no set, date won't set, or won't communicate with collector
Other	Datamatic has determined that the failure is not a standard failure

To properly mark a claimed failure, use blue painter's tape on the back of the FIREFLY and write the failure code (below) on the tape.

Examples:



**Only units that are within their Warranty Period and that are without physical damage and that have failed for one or more of the above reasons may be covered under Warranty. Do not ship any FIREFLY units with physical damage to Datamatic. Please dispose of damaged FIREFLYs properly using a local recycling facility.**

Specific Warranty exclusions include (but are not limited to) the following:


1. The Sensor Head is broken or damaged.



2. The FIREFLY's cable is cut less than 18 inches from the base of the unit or if it is damaged such that reliable reading may be compromised.



3. The Logical Switch collar is broken on a Logical Switch FIREFLY.



4. The pins inside a Nicor connector are damaged, bent, twisted or missing.



5. The unit is permanently marked and/or painted (see examples below). To properly mark a FIREFLY for RMA, please place a piece of blue painter's tape on the FIREFLY and write the failure code on the tape.



- Package Water FIREFLYs in an original (or similar) shipping box that includes dividers, serial number side up.
- Package Electric FIREFLYs in static bags and bubble wrap. Remove back-up batteries from Electric FIREFLYs.
- Package Gas FIREFLY MIU and gear drive only (index cover, battery and screws not needed). If there is a defect in the gas battery screw (for Legacy Gas FIREFLY only), draw an arrow on the battery pointing to the insert with the permanent marker. Package gas batteries separately (detached) from the FIREFLY. Mark all bad batteries with a Red "X".

If you have any questions about your FIREFLY Warranty or the proper return process, please contact Customer Support at 888-326-5032 or email [Support@Datamatic.com](mailto:Support@Datamatic.com)

The FIREFLY RMA Request Form allows you to submit an electronic RMA request for FIREFLYs.

Fill in all required fields to submit your FIREFLY RMA Request.

**Datamatic**  
WE READ YOU

Adv  
Meter Reading

COMPANY PROFILE PRODUCTS SERVICES PRESS ROOM EVENTS EVENTS ABOUT US

SUPPORT

**DATAMATIC'S FIREFLY RETURN REQUEST FORM**

[back to control panel](#)

Note: This form is used to submit a FIREFLY RMA request on FIREFLYs only. If you want to request a return form for the ROADRUNNER(s), Cradle(s) and/or Controller(s), please use Datamatic's Return Request Form or click here. If you have any questions about your FIREFLY Warranty or the proper return process, please contact Customer Support at 888/326-5032.

Fields Marked with \* are required.

**Customer Information**

## Training and Support

At Datamatic, we strive to provide excellent training and support because they are the foundations of customer satisfaction.

### Training

Training services include onsite training for a reasonable fee plus travel expenses. When a customer is new to Datamatic, their sales order should include a specified amount of onsite training days or sessions. This initial training is required to teach end users how to set up, operate, maintain, and efficiently use their new hardware and/or software systems. Customers are strongly encouraged to have more than one employee attend the training and to cross-train with other employees.

Supplemental training is available onsite or via telephone. Typically, this occurs when there is utility employee turnover or when their responsibilities change. In many cases, users want a refresher or to be able to dig deeper into the use and care of their system. Additional fees apply, so contact Customer Support at 888-326-5032 for more information.

### Telephone Support

Support services include telephone assistance, return material authorizations (RMA), and consumable sales.

Technical phone support is provided to help answer questions or address specific issues with trained end users. New users should take advantage of the opportunity to have focused one-on-one or group training.

Customers can also contact technical support to request a return material authorization (RMA) for equipment repair per the terms of a Maintenance Agreement.

Technical support also handles purchases of small consumable items such as hand straps or batteries for the hand held devices.

*Please send an email to support@datamatic.com or call 888-326-5032 for technical assistance, RMA requests, and consumable orders.*

Additional Datamatic Training Guides can be downloaded through the secure customer access area of our website.



## Document Revisions

*Do Not Print*

Team Members:	Deena Duffy
Date:	6/10/08
Revision:	A
Revision Log:	Starting from last draft, added: updated wiring connections Non-mesh read functionality Re-worked LED behavior explanations Changed MOSAIC-Class FIREFLY references to MOSAIC FIREFLY per Andy Kercher

Team Members:	Deena Duffy
Date:	06/17/08
Revision:	B
Revision Log:	Completed updates per 06.04.08 approvals

Team Members:	Deena Duffy
Date:	July 1, 2008
Revision:	C
Revision Log:	Dd added new Support page

Team Members:	Deena Duffy
Date:	September 10, 2008
Revision:	D
Revision Log:	Dd added RSV control instructions

Team Members:	Deena Duffy
Date:	September 11, 2008
Revision:	E
Revision Log:	Dd added sensor-end install and programming instructions

Team Members:	Deena Duffy
Date:	September 15, 2008
Revision:	F
Revision Log:	Dd added sensor-end light behavior and wire-end programming instructions and formatted for review

Team Members:	Deena Duffy
Date:	October 15, 2008
Revision:	G
Revision Log:	Dd updated wiring connections to match last approved version of the laminated wire connections card

Team Members:	Amy Fair and Deena Martin
Date:	January and February, 2009
Revision:	H
Revision Log:	Updated for RR 3.26.3 and 3.26.4

Team Members:	Deena Martin
Date:	February 24, 2009 – March 19, 2009
Revision:	I
Revision Log:	Misc. general updates per emails, etc.

Team Members:	Deena Martin
Date:	April 20, 2009 – May 4, 2009
Revision:	J
Revision Log:	Updates related to CXMI 1.2 release; new Installation Considerations added by AK

Team Members:	Deena Martin
Date:	July 6, 2009 – July 17, 2009
Revision:	K
Revision Log:	Updates related to CXMI 1.3 release

Team Members:	Deena Martin
Date:	August 14, 2009
Revision:	L
Revision Log:	Added Work out Waterless Hand Cleaner

Team Members:	Deena Martin
Date:	November 23 – January 12, 2010
Revision:	M
Revision Log:	Added functionality related to CXMI 1.3.2

Team Members:	Deena Martin
Date:	February 4, 2010
Revision:	N
Revision Log:	Added images and verbiage re: Nicor-end FFs per Andy K.

Team Members:	Deena Martin
Date:	January 24, 2011
Revision:	O
Revision Log:	Added DC-111 to sensor install procedures

Team Members:	Deena Martin
Date:	February 15-25, 2011
Revision:	P
Revision Log:	Updated Mesh/Fence Rollover max values; added new Contacting Datamatic section; added sensor troubleshooting notes

Team Members:	Deena Martin
Date:	03/21/11
Revision:	Q
Revision Log:	Updated Meter Type for Permalog and AMCO InVision

Team Members:	Deena Martin
---------------	--------------

Date:	05/17/11 – 05/23/11
Revision:	R
Revision Log:	Updated programming wire-end FFs in Mesh mode sections; updated GPS programming instructions; updated Training Guides pricing section

Team Members:	Deena Martin
Date:	06/13/11
Revision:	S
Revision Log:	Added A-Frame Lid Lock Adapter

Team Members:	Deena Martin
Date:	July 11, 2011
Revision:	T
Revision Log:	Added patent information per Phil M.

Team Members:	Deena Martin
Date:	September 23 – October 14, 2011
Revision:	U (DRAFT to specific customers)
Revision Log:	Re-organized and updated all sections to reflect changes in RR 3.27

Team Members:	Deena Martin
Date:	January 4 – 5, 2012
Revision:	V
Revision Log:	Added Time Zone to programming and templates section (added after last version was released as a draft to specific customers)

Team Members:	Deena Martin
Date:	February 9-14, 2012
Revision:	W
Revision Log:	Added new Contacting Datamatic section

Team Members:	Deena Martin
Date:	June 21, 2012
Revision:	X
Revision Log:	Added new Contacting Datamatic section; added instructions to remove A-Frame lid lock adapters; added MFFW FW 1.8.22 note

Team Members:	Deena Martin
Date:	August 24, 2012
Revision:	Y
Revision Log:	Added FCC IDs to p 7 per Product Development (Ken D)