

# **DCS800**

**Quick guide**  
**DCS800 Drives (20 A to 5200 A)**



# DCS800 QUICK GUIDE

<b>english</b>	<b>Contents</b>
DC Drives Worldwide Service Network .....	3
DCS800 Drive Manuals .....	4
DCS800 DC Drives.....	5
Brief instructions for CD and documents overview .....	7
Notes on EMC.....	8
Standard function assignments for the terminals.....	10
Connection example.....	11
Fan power connection.....	13
Terminal locations on the converter.....	14
Notes For North American Installations.....	15
Safety and operating instructions .....	17
Installing the DCS800 PC tools on Your computer.....	18
Commissioning.....	19
DCS800 Control Panel .....	20
Dimensions, drilling patterns and weights .....	77
Fault / Alarm list .....	79
Diagnosis messages.....	88
Macro & Firmware structure.....	93
Declaration of conformity.....	106
Certificate of manufacture .....	107

<b>deutsch</b>	<b>Inhalt</b>
DC Drives Worldwide Service Network .....	3
DCS800 Drive Manuals .....	4
DCS800 Gleichstromantriebe .....	21
Kurzanzweisung CD und Documentations[bersicht .....	23
EMV Filter .....	24
Digitaler und analoger E-A/Anschluss von SDCS-CON-4..	26
Anschlussbeispiel .....	27
Lüfterkühlung .....	29
Klemmen- und Steckeranordnung des Stromrichters.....	30
Sicherheits- und Anwendungshinweise.....	31
Installation der DCS800 Programme auf dem PC .....	32
Inbetriebnahme .....	33
DCS800 Steuertafel.....	34
Abmessungen, Bohrbild und Gewichte .....	77
Fehler- und Alarmliste .....	79
Diagnose.....	88
Macro & Firmware Struktur.....	93
Declaration of conformity.....	106
Herstellerbescheinigung .....	107

<b>italiano</b>	<b>Indice</b>
DC Drives Worldwide Service Network .....	3
DCS800 Drive Manuals / DCS800 Manuali Drive .....	4
DCS800 DC Drives.....	35
Brevi istruzioni CD e documentazione.....	37
Note sulle EMC.....	38
Assegnazione funzioni standard per i morsetti .....	40
Esempi schemi di collegamento.....	41
Fan power connection.....	43
Terminal locations on the converter.....	44
Istruzioni per la sicurezza e il funzionamento .....	45
Installa i DCS800 PC tools sul Tuo computer .....	46
Messa in servizio .....	47
Descrizione display .....	48
Disegni dimensionali .....	77
Fault / Alarm list .....	79
Diagnosis messages.....	88
Struttura macro & firmware.....	93
Dichiarazione di conformità.....	106
Certificato del costruttore .....	107

<b>español</b>	<b>Contenido</b>
Red de atención mundial de convertidores de CC .....	3
Manuales de convertidores DCS800.....	4
Convertidores de CC DCS800 .....	49
Instrucciones para la descripción del CD y documentación	51
Notas acerca de EMC .....	52
Asignaciones de funciones estándar para los terminales...	54
Ejemplo de conexión .....	55
Conexión de alimentación del ventilador .....	57
Ubicación de los terminales en el convertidor .....	58
Instrucciones de seguridad.....	59
Cómo instalar las herramientas para PC del DCS800 .....	60
Puesta en funcionamiento .....	61
Panel de control del DCS800 .....	62
Dimensiones, patrones de taladrado y pesos.....	77
Lista de fallos/alarmas .....	79
Mensajes de diagnóstico .....	88
Estructura del macro & firmware.....	93
Declaración de conformidad.....	106
Certificate of manufacture.....	107

<b>français</b>	<b>Sommaire</b>
DC Drives Worldwide Service Network .....	3
Manuels du DCS800 (originaux anglais).....	4
Variateurs à courant continu DCS800 .....	63
Documentation technique .....	65
Compatibilité électromagnétique (CEM) .....	66
Raccordement standard des signaux d'E/S.....	68
Exemple de schéma de câblage.....	69
Câblage du ventilateur.....	71
Emplacement des bornes sur le convertisseur .....	72
Consignes de sécurité et d'exploitation.....	73
Installation des outils logiciels du DCS800 sur votre PC....	74
Mise en service.....	75
Micro-console DCS800 .....	76
Dimensions, perçages et poids .....	77
Liste des défauts / alarmes .....	79
Messages de diagnostic.....	88
Structure du logiciel macro & système .....	93
Déclaration de conformité.....	106
Certificat du fabricant .....	107

**ABB Drive Service EN**

In order to offer the same after sales service to our customer around the world, ABB has created the DRIVE SERVICE CONCEPT.

ABB's after sales service is globally consistent due to common targets, rules, and the way of operation. This means for our customers:

Please visit the ABB *drive service homepage*

[www.abb.com/drivesservices](http://www.abb.com/drivesservices)

**ABB Drive Service FR**

Pour offrir la même qualité de service à tous nos clients, ABB a créé DRIVE SERVICE CONCEPT.

Dans le monde entier, les équipes de service proposent les mêmes prestations aux mêmes conditions avec les mêmes objectifs.

Pour en savoir plus, connectez-vous sur ABB *drive service homepage*

[www.abb.com/drivesservices](http://www.abb.com/drivesservices)

**ABB Drive Service DE**

Um jedem Kunden rund um die Welt die gleiche Service Dienstleistung anbieten zu können, hat ABB das DRIVE SERVICE CONCEPT entwickelt.

Durch die Definition von einheitlichen Zielen, Regeln, und Arbeitsvorschriften kann ABB die Dienstleistungs Produkte weltweit auf gleichwertig hohem Qualitätsniveau anbieten. Für unsere Kunden bedeutet dies:

Bitte besuchen Sie die ABB-Homepage *Service für Antriebe*

[www.abb.com/drivesservices](http://www.abb.com/drivesservices)

**ABB Drive Service IT**

ABB ha creato il DRIVE SERVICE CONCEPT, con lo scopo di offrire ai nostri clienti lo stesso servizio post vendita in tutto il mondo.

Attraverso la definizione di obiettivi comuni, ruoli e modo di operare, le attività post vendita di ABB offrono servizi coerenti nella loro globalità. Per i nostri clienti questo significa:

Vi invitiamo a visitare la homepage ABB *drive service*

[www.abb.com/drivesservices](http://www.abb.com/drivesservices)


**ABB Drive Service ES**

Para poder ofrecer el mismo servicio posventa a nuestros clientes en todo el mundo, ABB ha creado el CONCEPTO DE SERVICIO DE CONVERTIDORES.

El servicio posventa de ABB está mundialmente consolidado gracias a unos objetivos y normas comunes, así como a su funcionamiento. Esto significa para nuestros clientes:

Visiten el portal de *convertidores de ABB*

[www.abb.com/drivesservices](http://www.abb.com/drivesservices)



## DC Drives Worldwide Service Network

Country	Local ABB Service	Town	Service Phone No.
Argentina	<a href="#">Asea Brown Boveri S.A.</a>	BUENOS AIRES	+54 (0) 12 29 55 00
Australia	<a href="#">ABB</a>	NOTTING HILL	+61 (0) 3 85 44 00 00
Austria	<a href="#">ABB AG</a>	WIEN	+43 1 60 10 90
Belgium	<a href="#">ABB N.V.</a>	ZAVENTEM	+32 27 18 64 86 +32 27 18 65 00 - 24h service
Brazil	<a href="#">ABB Ltda.</a>	OSASCO	+55 (0) 11 70 84 91 11
Canada	<a href="#">ABB Inc.</a>	SAINT-LAURENT	+1800 865 7628
China	<a href="#">ABB China Ltd</a>	BEIJING	+86 40 08 10 88 85 - 24h service
Czech Republic	<a href="#">ABB S.R.O.</a>	PRAHA	+42 02 34 32 23 60
Finland	<a href="#">ABB Oy Service</a>	KUUSANKOSKI	+35 8 10 22 51 00
Finland	<a href="#">ABB Oy Product Service</a>	HELSINKI	+35 8 10 22 20 00
Finland	<a href="#">ABB Oy Service</a>	NOKIA	+35 8 10 22 51 40
France	<a href="#">ABB Automation</a> <a href="#">ABB Process Industry</a>	MONTLUEL	from abroad France +33 1 34 40 25 81 +0810 02 00 00
Germany	<a href="#">ABB Process Industries</a>	MANNHEIM	+49 18 05 22 25 80
Greece	<a href="#">ABB SA</a>	METAMORPHOSSIS	+30 69 36 58 45 74
Ireland	<a href="#">ABB Ireland Ltd.</a>	TALLAGHT	+35 3 14 05 73 00
Italy	<a href="#">ABB</a>	MILAN	+39 02 90 34 73 91
Korea, Republic	<a href="#">ABB Ltd., Korea</a>	CHONAN	+82 (0) 4 15 29 22
Malaysia	<a href="#">ABB Malaysia Sdn. Bhd.</a>	KUALA LUMPUR	+60 3 56 28 42 65
Mexico	<a href="#">ABB Sistemas S.A. DE C.V.</a>	TLALNEPANTLA	+52 53 28 14 00
Netherlands	<a href="#">ABB B.V.</a>	ROTTERDAM	+31 1 04 07 88 66
New Zealand	<a href="#">ABB Service Ltd</a>	AUCKLAND	+64 92 76 60 16
Poland	<a href="#">ABB Centrum IT Sp.zo.o</a>	WROCLAW LODZ	+48 42 61 34 96 2 +48 42 29 93 91 39 5
Russia	<a href="#">ABB Automation LLC</a>	MOSCOW	+74 95 96 0
Switzerland	<a href="#">ABB AG</a>	DÄTTWIL	+41 5 85 86 87 86
Singapore	<a href="#">ABB Industry Pte Ltd.</a>	SINGAPORE	+65 67 76 57 11
Slovakia	<a href="#">ABB Elektro s.r.o.</a>	BANSKA BYSTRICA	+42 19 05 58 12 78
South Africa	<a href="#">ABB South Africa (Pty) Lt</a>	JOHANNESBURG	+27 1 16 17 20 00
Spain	<a href="#">ABB Automation Products</a>	BARCELONA	+34 9 37 28 73 00
Taiwan	<a href="#">ABB Ltd.</a>	TAIPEI 105	+88 62 25 77 60 90
Thailand	<a href="#">ABB Limited</a>	SAMUTPRAKARN	+66 27 09 33 46
Turkey	<a href="#">ABB Elektirk Sanayi A.S</a>	ISTANBUL	+90 2 16 36 52 90
USA	<a href="#">ABB Industrial Products</a>	NEW BERLIN	+1 26 27 85 32 00 +1 262 435 7365
Venezuela	<a href="#">ABB S.A.</a>	C R C S	+58 (0) 22 38 24 11 / 12

# DCS800 Drive Manuals

	Public. number	Language						
		E	D	I	ES	F	CN	RU
<b>DCS800 Quick Guide</b>	3ADW000191	x	x	x	x	x		
<b>DCS800 Tools &amp; Documentation CD</b>	3ADW000211	x						
<b>DCS800 Converter module</b>								
Flyer DCS800	3ADW000190	x	x	x	x	x	x	x
Technical Catalogue DCS800	3ADW000192	x	x	x	x	x	x	x
Hardware Manual DCS800	3ADW000194	x	x	p	x	x	x	x
Hardware Manual DCS800 update DCF503B/DCF504B	3ADW000194Z0301	x						
Firmware Manual DCS800	3ADW000193	x	x	p	x	p	x	x
Installation according to EMC	3ADW000032	x						
Technical Guide	3ADW000163	x						
Service Manual DCS800	3ADW000195	x	x					
12-Pulse Manual	3ADW000196	x						
CMA-2 Board	3ADW000136	p						
Flyer Hard - Parallel	3ADW000213	x						
<b>Drive Tools</b>								
DriveWindow 2.x - User's Manual	3BFE64560981	x						
DriveOPC 2.x - User's Manual	3BFE00073846	x						
Optical DDCS Communication Link	3AFE63988235	x						
DDCS Branching Units - User's Manual	3BFE64285513	x						
<b>DCS800 Applications</b>								
PLC Programming with CoDeSys	CoDeSys_V23	x	x			x		
61131 DCS800 target +tool description - Application Program	3ADW000199	x						
<b>DCS800 Crane Drive</b>								
DCS800 Crane Drive Manual suppl.	3AST004143	x						
DCS800 Crane Drive Product note	PDC5 EN REVA	p						
<b>DCS800 Winder ITC</b>								
DCS800 Winder Product note	PDC2 EN	x						
DCS800 Winder description ITC	3ADW000308	x						
Winder Questionnaire	3ADW000253z	x						
<b>DCS800-E Panel Solution</b>								
Flyer DCS800-E Panel solution	3ADW000210	x						
Hardware Manual DCS800-E	3ADW000224	x						
<b>DCS800-A Enclosed Converters</b>								
Flyer DCS800-A	3ADW000213	x						
Technical Catalogue DCS800-A	3ADW000198	x						
Installation of DCS800-A	3ADW000091	p						
<b>DCS800-R Rebuild System</b>								
Flyer DCS800-R	3ADW000007	x	x					
DCS800-R Manual	3ADW000197	x						
DCS500/DCS600 Size A5...A7, C2b, C3 and C4 Upgrade Kits	3ADW000256	x						
<b>Extension Modules</b>								
RAIO-01 Analogue IO Extension	3AFE64484567	x						
RDIO-01 Digital IO Extension	3AFE64485733	x						
AIMA R-slot extension	3AFE64661442	x						
<b>Serial Communication</b>								
Drive specific serial communication								
NETA Remote diagnostic interface	3AFE64605062	x						
Fieldbus Adapter with DC Drives RPBA- (PROFIBUS)	3AFE64504215	x						
Fieldbus Adapter with DC Drives RCAN-02 (CANopen)								
Fieldbus Adapter with DC Drives RCNA-01 (ControlNet)	3AFE64506005	x						
Fieldbus Adapter with DC Drives RDNA- (DeviceNet)	3AFE64504223	x						
Fieldbus Adapter with DC Drives RMBA (MODBUS)	3AFE64498851	x						
Fieldbus Adapter with DC Drives RETA (Ethernet)	3AFE64539736	x						
x -> existing p -> planned								
Status 10.2008								

DCS800 Drive Manuals-List\_h.doc





**Standard Features**

- compact
- highest power ability
- simple operation
- comfortable assistants, e.g. for autotuning or commissioning
- scalable to all applications
- free programmable by means of integrated IEC61131-PLC

# DCS800 DC Drives

## Technical data

Mains supply volt.	230...1,200 V, +/-10%, 3~
Frequency	50...60 Hz, +/-5 Hz
Electronics supply	115...230 V, -15% / +10%, 1~
DC Output current	20...5,200 A
Overload capability	200%

## Ambient conditions

Ambient temperat.	0° ... +40° C 40° ... 55° C with reduction
Storage temperat.	-40° ... +55° C
Transport temper.	-40° ... +70° C
Relative humidity	5 ... 95%, not condensing (max. 50% betw. 0°...5° C)
Pollution degree	Class 2
Protection class	IP 00
Altitude	< 1,000 m height above sea level: nominal Current > 1,000 m height above sea level: with reduction

## I/O

**Digital inputs:** 8 standard, up to 14 optional  
**Digital outputs:** 8 standard, up to 12 optional  
**Analog inputs:** 4 standard +/-10 V; 0/2...10 V, up to 8 optional +/- 20 mA; 0/4...20 mA  
**Analog outputs:** 3 standard (1x I<sub>act</sub>) +/-10 V; 0/2...10 V, up to 7 optional -20 mA; 0/4...20 mA

## PC-Tools

**DriveWindow Light:** free of charge with every converter, Standard RS232 PC-connection  
**DriveWindow:** Real-time optical connection  
**ControlBuilder DCS800:** IEC61131 programming tool  
**DriveSize:** Converter- and motor dimensioning

## Maintenance / Diagnosis

Remote diagnosis with any Internet-PC worldwide  
 • with internet browser / internet explorer  
 • or with DriveWindow full drive control via OPC

## Approvals



## Adaptive Programming

pre-defined drive-specific function blocks, e.g.  
 • Free process controller (PI-Controller)  
 • I/O- and digital Operations  
 With control panel or PC-Tool, no need for additional hardware

## Speed Feedback

EMF  
 Analogue tacho  
 Encoder  
 2nd Encoder possible (RTAC)

## Communication

Serial communication  
 • Ethernet • Profibus  
 • CANopen • DeviceNet  
 • ControlNet • DDCS  
 • Modbus • AF100  
 • CS31 • Selma2  
 Industrial IT® enabled

## DCSLink Peer-to-Peer

• up to 800 kBaud, < 2.5 ms  
 • Master-Follower  
 • Armature-fieldconverter  
 • Free selectable data

## High Current Solutions

• 12-pulse up to 20,000 A, serial and parallel  
 • Hard parallel and sequential  
 • up to 1,500 V

## Protections

Speed feedback monitoring •  
 Temperature • Overload • Over speed • Motor stalled • Motor over current • Motor over voltage • Field over current • Field over voltage • Minimum field current • Zero speed • Armature current ripple • Mains over- and under voltage

## Integrated IEC 61131-PLC

• Open standard programming tool ControlBuilder DCS800  
 • Support of all five IEC-languages  
 • Drive-specific function blocks  
 • Saving of program and source in Memory Card  
 • Online debugging and forcing

## Current ratings, dimensions

Unit size	2-Q rated Current DCS800-01 I <sub>DC</sub> [A]	4-Q rated Current DCS800-02 I <sub>DC</sub> [A]	Supply voltage [V <sub>AC</sub> ]							max. field current internal [A <sub>DC</sub> ]	Dimensions	
			400	525	600	690	800	990	1200		h x w x d [mm]	h x w x d [inch]
D1	20	25	●	●					6	370 x 270 x 200	14.56 x 10.65 x 7.90	
	45	50	●	●								
	65	75	●	●								
	90	100	●	●								
	125	140	●	●								
D2	180	200	●	●				15	370 x 270 x 270	14.56 x 10.65 x 10.65		
	230	260	●	●								
D3	315	350	●	●	● <sup>3)</sup>			20	459 x 270 x 310	18.07 x 10,65 x 12,25		
	405	450	●	●								
	470	520	●	●								
D4	610	680	●	●	● <sup>3)</sup>			25	644 x 270 x 345	25.35 x 10.65 x 13.60		
	740	820	●	●								
	900	1000	●	●								
D5	900	900	●	●	●	●		25	1050 x 510 x 410	41.35 x 20.10 x 16.15		
	1200	1200	●	●								
	1500	1500	●	●	●	●						
	2000	2000	●	●	● <sup>1)</sup>	● <sup>1)</sup>						
D6	1900	1900		●	●	●	●	external field 35A, 1~/3~ 50/60A, 1~ 520A, 3~	1750 x 460 x 410	68.90 x 18.15 x 16.15		
	2050	2050		●	●	●						
	2500	2500	●	●	●	●						
	3000	3000	●	●	●	●						
D7	2050	2050		●	●	●	●	external field 35A, 1~/3~ 50/60A, 1~ 520A, 3~	1750 x 760 x 570	68.90 x 29.95 x 22.45		
	2600	2600		●	●	●	● <sup>2)</sup>					
	3300	3300	●	●	●	●	● <sup>2)</sup>					
	4000	4000	●	●	●	●						
	4800	4800	●	●	●	●						
	5200	5200	●	●								

●<sup>1)</sup> only available as 2-Q drive

●<sup>2)</sup> on request

●<sup>3)</sup> 600V

2-Q -> 290 A / 590 A  
 4-Q -> 320 A / 650 A

# Brief instructions for CD and documents overview

We appreciate that you purchased an ABB DC drive power converter and thank you for the trust you put in our products.

This brochure was put together to make sure that you continue to be satisfied with our product. It is intended to provide you with a brief overview of the product's key data, EMC notes, typical applications, start-up and trouble-shooting.

If you need more information about the product you are provided with a **CD-ROM** in addition to this brief documentation. The CD-ROM is part of this document and features the following contents:

## Documentation

Our documentation is basically structured according to the following system:

### Technical catalogue (3ADW000192)

as comprehensive information to engineer complete DC drive systems.

### Hardware manual (3ADW000194)

as detailed information, with all important particulars about the individual components, like module dimensions, electronic boards, fans and auxiliary components. Information for mechanical and electrical installation are also included.

### Firmware Manual (3ADW000193)

detailed information with all important issues about firmware and setting of parameters. The manual includes information for start-up and maintenance of the entire drive, in detailed form.

This manual also includes Fault and Alarm codes and information for trouble shooting.

### Service Manual (3ADW000195)

for maintenance and repair of the converters.

## Applications

DCS800 DC Drive can include application software e.g. cranes, winders. In such case following procedures and assistants can be blocked or not completed. Please check for further documentation and manuals (check parameter 4.03, 83.01).

Additional **information about applications** (e.g. 12-pulse) and **technical accessories** (e.g. Hardware extension or Field bus interfaces) are handled by separate manuals. See table *DCS800 Drive manuals*.

## System requirements to use the CD-ROM

- Operating system WINDOWS 2000, XP
- ADOBE READER 4.0 is sufficient (we recommend 8.0 - included on the CD-ROM)



In case the CD ROM does not start automatically please double-click on **Setup.exe**.

## Further support

In addition we offer further support, since we can only be satisfied when you, as our customer, are satisfied with us and our products.

### Internet

On the ABB homepage under

[www.abb.com/dc](http://www.abb.com/dc)

you'll find abundant information for

- DC products
- service support
- the latest updates
- tools
- downloads, etc.

Please don't hesitate to visit us.

### Contacts

If you require any further information, please contact your nearest **ABB Drives** office or send an email to:

[DC-Drives@de.abb.com](mailto:DC-Drives@de.abb.com)

Please give us your name, your company address and phone number. We immediately put you in contact with our specialist.

# Notes on EMC

You will find further information in publication:

**Technical Guide chapter: EMC Compliant Installation and Configuration for a Power Drive System**

The paragraphs below describe selection of the electrical components in conformity with the EMC Guideline.

The aim of the EMC Guideline is, as the name implies, to achieve electromagnetic compatibility with other products and systems. The guideline ensures that the emissions from the product concerned are so low that they do not impair another product's interference immunity.

In the context of the EMC Guideline, two aspects must be borne in mind:



- the product's interference immunity
- the product's actual emissions

The EMC Guideline expects EMC to be taken into account when a product is being developed; however, EMC cannot be designed in, it can only be quantitatively measured.

## Note on EMC conformity

The conformity procedure is the responsibility of both the power converter's supplier and the manufacturer of the machine or system concerned, in proportion to their share in expanding the electrical equipment involved.

<b>First environment (residential area with light industry) with PDS category C2</b>	
<b>Not applied, since category C1 (general distribution sales channel) excluded</b>	
<b>Not applicable</b>	<b>satisfied</b>
<b>satisfied</b>	



For compliance with the protection objectives of the German EMC Act (EMVG) in systems and machines, the following EMC standards must be satisfied:

**Product Standard EN 61800-3**

**EMC standard for drive systems (PowerDrive-System), interference immunity and emissions in residential areas, enterprise zones with light industry and in industrial facilities.**  
This standard must be complied with in the EU for satisfying the EMC requirements for systems and machines!

For emitted interference, the following apply:

- EN 61000-6-3** Specialised basic standard for emissions in **light industry** can be satisfied with special features (mains filters, screened power cables) in the lower rating range \*(EN 50081-1).
- EN 61000-6-4** Specialised basic standard for emissions in **industry** \*(EN 50081-2)


For interference immunity, the following apply:

- EN 61000-6-1** Specialised basic standard for interference immunity in **residential areas** \*(EN 50082-1)
- EN 61000-6-2** Specialised basic standard for interference immunity in **industry**. If this standard is satisfied, then the EN 61000-6-1 standard is automatically satisfied as well \*(EN 50082-2).


\* The generic standards are given in brackets

			Standards
Second environment (industry) with PDS categories C3, C4			EN 61800-3
Not applicable			EN 61000-6/3
satisfied	on customer's request	satisfied	EN 61000-6/3
satisfied			EN 61000-6-2 EN 61000-6-1

**PDS category C3**



**PDS category C4**



**Classification**

The following overview utilises the terminology and indicates the action required in accordance with Product Standard

**EN 61800-3**

For the DCS800 series, the limit values for emitted interference are complied with, provided the measure indicated is carried out. PDS of category C2 (formerly restricted distribution in first environment) is intended to be installed and commissioned only by a professional (person or organization with necessary skills in installing and/or commissioning PDS including their EMC aspects).

For power converters without additional components, the following warning applies:

This is a product of category C2 under IEC 61800-3:2004. In a domestic/residential environment this product may cause radio interference in which case supplementary mitigation measures may be required.


The field supply is not depicted in this overview diagram. For the field current cables, the same rules apply as for the armature-circuit cables.

**Legend**

	Screened cable
	Unscreened cable with restriction



# Standard function assignments for the terminals



Resolution [bit]	Input/output values Hardware	Scaling by	Common mode range	Remarks
15 + sign	±90...±270 V ±30...±90 V ±8...±30 V	① Firmware	±15 V	
15 + sign	-10...0...+10 V	Firmware	±15 V	
15 + sign	-10...0...+10 V	Firmware	±15 V	
15 + sign	-10...0...+10 V	Firmware	±15 V	
15 + sign	-10...0...+10 V	Firmware	±15 V	
15 + sign	-10...0...+10 V	Firmware	±15 V	
			<b>Power</b>	
	+10 V		≤ 5 mA	for ext. use e.g. refer. pot.
	-10 V		≤ 5 mA	
11 + sign	-10...0...+10 V	Firmware	≤ 5 mA	
11 + sign	-10...0...+10 V	Firmware	≤ 5 mA	
	-10...0...+10 V	Firmware+ Hardware	≤ 5 mA	8 V -> min. of 325% of [99.03] or 230% of [4.05]

Encoder supply	Remarks
	Inputs not isolated Impedance = 120 Ω, if selected max. frequency ≤ 300 kHz
5 V 24 V	≤ 250 mA ≤ 250 mA
	Sense lines for GND and supply to correct voltage drops on cable (only if 5 V encoder is in use).

Input value	Signal definition by	Remarks
0...7.3 V 7.5...50 V	Firmware	-> "0" status -> "1" status

Output value	Signal definition by	Remarks
50 * mA 22 V at no load	Firmware	Current limit for all 7 outputs = 160 mA Do not apply any reverse voltages!


\* short circuit protected

① gain can be varied in 15 steps between 1 and 4 by software parameter

# Connection example

## Converters D1...D4 drive configuration using 'OnBoard' field exciter

Terminal selection according FACTORY macro (default)



further information see the following page


## START, STOP and E-STOP control

The relay logic can be split into three parts:

a: Generation of the ON/OFF and START/STOP command:

The commands represented by K20 and K21 (latching interface relay) can be e.g. generated by a PLC and transferred to the terminals of the converter either by relays, using galvanic isolation or directly via 24V signals.

These commands can be as well transferred via serial communication. Even a mixed solution can be realized by selecting different possibilities for the one or the other signal (see parameter group 11).



b: Generation of control and monitoring signals:

The main contactor K1 for the armature circuit is controlled by a dry contact (DO 8) located on the SDCS-PIN-4. Status of fans and fans klixon can be monitored by means of fan ack signals: MotFanAck (10.06) and ConvFanAck (10.20).

c: OFF2, OFF3 Stop function:

Beside ON/OFF and START/STOP, the drive is equipped with two additional stop functions, OFF2 and OFF3, according to Profibus standard. OFF3 is a scalable stop function (rampstop, max torque stop, dynamic braking ...) to perform stop category 1. This function should be connected to the E-STOP button without any time delay. In case of ramp stop selection, the K 15 timer relay must be set longer than the EStopRamp (22.04). For COAST selection, the drive opens the main contactor immediately.



OFF2 switches off DC current as fast as possible and prepares the drive for opening main contactor or drop down mains supply. For a normal DC motor load the time to switch OFF the DC current is below 20 ms. This function should be connected to all signals and safety functions opening the main contactor. This function is important for 4-quadrant drives. Do not open main contactor during regenerative current.

The correct sequence is

1. switch off regenerative current
2. then open the main contactor

In case of the E-STOP is hit, the information is transferred to the converter via digital input 5. In case of rampstop, or max torque selection the converter will decelerate the motor and then open main contactor.

If the drive has not finished the function within the K15 timer setting, the drive must get the command to switch OFF the current via K16. After K16 timer set has elapsed the main contactor is opened independent of the drives status.






# Fan power connection

## Fan assignment for DCS800


Converter type	Model	Configuration	Fan voltage
DCS800-S01-0020-04/05... DCS800-S02-0025-04/05	D1	-	no fan
DCS800-S0x-0045-04/05... DCS800-S0x-0140-04/05	D1	1	115 or 230 VAC
DCS800-S0x-0180-04/05... DCS800-S0x-0260-04/05	D2	1	115 or 230 VAC
DCS800-S0x-0315-04/05... DCS800-S0x-0350-04/05	D3	1	115 or 230 VAC
DCS800-S0x-0405-04/05... DCS800-S0x-0520-04/05	D3	2	115 or 230 VAC
DCS800-S0x-0610-04/05... DCS800-S0x-0820-04/05	D4	3	230 VAC
DCS800-S0x-0610-04/05... DCS800-S0x-0820-04/05	D4 Pluscode S171	3	115 VAC
DCS800-S0x-0900-04/05... DCS800-S0x-1000-04/05	D4	3	230 VAC
DCS800-S0x-0900-04/05... DCS800-S0x-1000-04/05	D4 Pluscode S171	3	115 VAC

## Fan connection for DCS800


Terminals on top of converter housing



Configuration 1  
D1- D3



Configuration 2  
D3



DCS8 fan conn D1-D4.dsf

Configuration 3  
D4



# Notes For North American Installations

1. **EMC conformity** is not usually required in North America. In most cases, the section “Notes on EMC” can be bypassed. In this manual, you will see references to DIN, EN and VDE standards. These are European standards and, generally, do not apply to North America. It is, however, the responsibility of the user to determine which standards need to be followed.

2. **If using a DC contactor**, you must connect an **auxiliary contact** to a digital input of your choice and set para. *MainContAck* accordingly. Set the following parameters:

- MainContAck* (10.21) = **DI-1** (or any input you choose for the DC cont. auxiliary contact)
- DO8BitNo* (14.16) = **10**
- MainContCtrlMode* (21.16) = **DCcontact** (3)

Set these parameters **AFTER** macros are loaded but **BEFORE** the drive is commissioned.


**Digital output 8 (DO-8) must be used to turn the DC contactor on and off.**

**DC contactor US:**

DC contactor US K1.1 is a special designed contactor with 2x NO contacts for C1 and D1 connection and 1x NC contact for connection of Dynamic Brake resistor RB.

The contactor should be controlled by signal 6.03 Bit 10. The acknowledge can be connected to parameter:

- 10.21 *MainContAck*
- 10.23 *DCBreakAck*



3. **If using Dynamic Braking**, the drive allows you to select the stopping method under three different situations. Parameters 21.02, 21.03 and 21.04 select the stopping method for loss of the OnOff, run command (StartStop, Jog1, Jog2, etc.), and E-Stop input, respectively.

Each can be set to:

- RampStop
- TorqueLimit
- CoastStop
- DynBraking

In order to command the drive to perform a DB stop, one or more of these parameters must be set to DynBraking. Most users will want the drive to ramp stop when OnOff or a run command (StartStop, Jog1, Jog2, etc.) input is cleared, and dynamically brake when the E-Stop input is cleared. In that case, use the following settings:

- Off1Mode (21.02) = RampStop
- StopMode (21.03) = RampStop
- E StopMode (21.04) = DynBraking

However, any case is allowed and the final decision is left to the user.

Other parameters control stops during faults.

See:

- LocalLossCtrl* (30.27) *ComLossCtrl* (30.28)
- FaultStopMode* (30.30) *SpeedFbFitMode* (30.36)

If using **EMF feedback** with dynamic braking, set:

- *DynBrakeDly* (50.11) = t
- Where: t = the time (sec) it normally takes the motor to stop during dynamic braking

## Overview of the Installation and Commissioning Process

### Step 1:

Check converter for damage. Contact ABB Technical Support if damage is found. In North America, call **1-800-435-7365 (1-800-HELP-365)**

This is to protect the motor and converter if a commutation fault should occur. NOTE: DC output fuses are the same type and size as AC line fuses.

### Step 2:

Select supporting hardware for the converter:

#### Line reactor:

All thyristor-based dc converters cause notching in the AC line due to motor commutation. A properly sized line reactor will mitigate the effect on the line. Unless the converter uses a dedicated isolation transformer, each converter requires its own line reactor.

*For specific recommendations for fuses, reactors, and contactors, see the DCS800 hardware manual or technical catalog.*

#### Circuit breaker or disconnect:

$$\begin{aligned} \text{Current rating} &= I_{dc} * 0.816 * 1.25 \text{ (min)} \\ &= I_{dc} * 0.816 * 2.50 \text{ (max)} \end{aligned}$$

Where:  $I_{dc}$  = nominal DC motor current

#### AC or DC contactor:

A contactor is required to safely disconnect the motor from the incoming power when the converter is off. The contactor can be installed between the line and the converter (an AC contactor) or between the converter and the motor (a DC contactor). Do not use both.

#### Fuses:

**AC Line Fuses:** To properly protect the converter, semi-conductor fuses on the incoming AC power line are required in all cases.

**IMPORTANT: Other equipment may be necessary depending on application and local codes.**

**DC Output Fuses:** Fuses between the motor and the converter are required for all regenerative (4-Q) converters.

**Step 3:**

Mount and wire the converter and supporting hardware inside an industrial enclosure with adequate cooling (DCS800 modules have rating of NEMA type OPEN).

The following control and signal wiring is required:

- o If using an AC contactor, we recommend wiring an auxiliary contact to the digital input you have designated as *MainContAck* (10.21) or *Start/Stop* (10.16).
- o If using a DC contactor, you must wire an auxiliary contact from the contactor to the digital input you have designated as *MainContAck* (10.21).
- o Wire 115 or 230 Vac 1-phase power to terminal block 99 for converter control power.
- o Wire 1-phase power to converter for cooling fans. See table and wiring diagrams in this manual.
  - D1 – D3 frames: 115/230 Vac selectable. Fan terminal X2 is on top of the converter.
  - D4 frame: If type code includes +S171, use 115 Vac; otherwise use 230 Vac. Fan terminal X2 is on top of the converter.
- o Wire tachometer or encoder to terminal block X3 (tacho) or X5 (encoder).
- o Wire analog inputs (e.g., speed reference) and outputs (e.g., meters for motor voltage, current) to terminal block X3 and/or X4.
- o Wire high speed serial interface if needed. (Requires optional fieldbus interface board.)
- o The DCS800 allows you to choose the usage of each digital and analog input and output. The converter has factory default settings which can be changed by loading a macro, but some designations are universal. They include:
  - Digital input 5: Estop
  - Digital input 6: Fault reset
  - Digital input 7: On/Off (maintained) or On-Start (pulsed)
  - \*Digital input 8: Start/Stop (maintained) or Off-Stop (pulsed)
  - Digital output 8: Main Contactor On (3 Amps max. at 115 – 230 Vac)
 \*except Hand/Auto macro
- o Other signals may be required depending on your application (e.g., motor fan acknowledge input, Off2 input, fan-on output, brake output).

- o You will select the macro and/or choose the configuration for digital and analog inputs and outputs in step 2 of the commissioning process, or by updating group 10 and 14 parameters.
- o Check all wire terminations (with continuity tester) before proceeding to the next step.

**Step 4:**

Connect the drive system to incoming power and the motor to the converter (both field and armature) as well as accessory equipment (motor fan, thermal switch, brake, etc.).

- o See hardware manual for typical cable size and tightening torque recommendations.
- o **IMPORTANT: Be sure all safety equipment is properly sized for your application**

**Step 5:**

**Apply control power to the converter.**

- o **IMPORTANT: See section “Safety and Operating Instructions” in this manual before proceeding.**
- o Apply power to terminal block 99 and X2. The keypad should light up and show the menu screen. The converter fans should start to run (if converter has fans).

**Step 6:**

**Commission the converter using Drive Windows Light (preferred) or the control panel.**

- o **IMPORTANT: See safety alerts and general instructions in the section “Commissioning” before proceeding.**
- o Install the DCS800 PC tools on your computer. Instructions are in this manual. Use DriveWindow Light to commission your converter.
- o If no PC is available, commission your drive using the control panel as follows:
  - On the control panel, press the softkey to select MENU.
  - Using the down arrow, select ASSISTANTS. Then press ENTER.
  - Starting with “name plate data,” press SEL. Change the value with the arrow keys. Then press SAVE.
  - Repeat above with other parameters. Follow directions on the screen.

## Configuring and Displaying analog and digital I/O

HINT: To see if the drive is responding to an “on” or “run” command, view signal 8.08.

**Control Panel:**

- o Digital Status: View signal 8.05 (DI's) or 8.06 (DO's). Display is in hexadecimal.
- o Configure digital inputs with Group 10.
- o Analog Status: View signal 5.03 (AI1) or 5.11 (AO1). Display is in Volts.
- o Configure analog speed ref. with Group 11.

**DriveWindow Light:**

- o Connect to the DCS800 and go on line by clicking on File, then New Online Drive.
- o Click on Wizard, at left side of the screen.
- o Click on Advanced.
- o Check the box for “I/O assistant,” then click on Next.
- o Click on “edit parameters” in the appropriate section (analog or digital inputs or outputs).

# Safety and operating instructions



## for drive converters DCS / DCF / DCR

(in conformity with the low-voltage directive 73/23/EEC)

### 1. General

In operation, drive converters, depending on their degree of protection, may have live, uninsulated, and possibly also moving or rotating parts, as well as hot surfaces.

In case of inadmissible removal of the required covers, of improper use, wrong installation or maloperation, there is the danger of serious personal injury and damage to property.

For further information, see documentation.

All operations serving transport, installation and commissioning as well as maintenance are to be carried out by skilled technical personnel (Observe IEC 364 or CENELEC HD 384 or DIN VDE 0100 and IEC 664 or DIN/VDE 0110 and national accident prevention rules!).

For the purposes of these basic safety instructions, "skilled technical personnel" means persons who are familiar with the installation, mounting, commissioning and operation of the product and have the qualifications needed for the performance of their functions.

### 2. Intended use

Drive converters are components designed for inclusion in electrical installations or machinery.

In case of installation in machinery, commissioning of the drive converter (i.e. the starting of normal operation) is prohibited until the machinery has been proved to conform to the provisions of the directive 89/392/EEC (Machinery Safety Directive - MSD). Account is to be taken of EN 60204.

Commissioning (i.e. the starting of normal operation) is admissible only where conformity with the EMC directive (89/336/EEC) has been established.

The drive converters meet the requirements of the low-voltage directive 73/23/EEC. They are subject to the harmonized standards of the series prEN 50178/DIN VDE 0160 in conjunction with EN 60439-1/ VDE 0660, part 500, and EN 60146/ VDE 0558.

The technical data as well as information concerning the supply conditions shall be taken from the rating plate and from the documentation and shall be strictly observed.

### 3. Transport, storage

The instructions for transport, storage and proper use shall be complied with.

The climatic conditions shall be in conformity with prEN 50178.

### 4. Installation

The installation and cooling of the appliances shall be in accordance with the specifications in the pertinent documentation.

The drive converters shall be protected against excessive strains. In particular, no components must be bent or isolating distances altered in the course of transportation or handling. No contact shall be made with electronic components and contacts.

Drive converters contain electrostatic sensitive components which are liable to damage through improper use. Electric components must not be mechanically damaged or destroyed (potential health risks).

### 5. Electrical connection

When working on live drive converters, the applicable national accident prevention rules (e.g. VBG 4) must be complied with. The electrical installation shall be carried out in accordance with the relevant requirements (e.g. cross-sectional areas of conductors, fusing, PE connection). For further information, see documentation.

Instructions for the installation in accordance with EMC requirements, like screening, earthing, location of filters and wiring, are contained in the drive converter documentation. They must always be complied with, also for drive converters bearing a CE marking. Observance of the limit values required by EMC law is the responsibility of the manufacturer of the installation or machine.

### 6. Operation

Installations which include drive converters shall be equipped with additional control and protective devices in accordance with the relevant applicable safety requirements, e.g. Act respecting technical equipment, accident prevention rules etc. Changes to the drive converters by means of the operating software are admissible.

After disconnection of the drive converter from the voltage supply, live appliance parts and power terminals must not be touched immediately because of possibly energized capacitors. In this respect, the corresponding signs and markings on the drive converter must be respected.

During operation, all covers and doors shall be kept closed.

### 7. Maintenance and servicing

The manufacturer's documentation shall be followed.

**Keep safety instructions in a safe place!**

# Installing the DCS800 PC tools on Your computer

After inserting the DCS800 CD all programs and documentation necessary to work with the DCS800 will be automatically installed. This includes:

1. DriveWindow Light for parameterization, commissioning and service
2. Hitachi FDT 2.2 for firmware download
3. Installation CD of DCS800 Drive for e.g. DWL Wizard, ABB documents
4. CoDeSys for 61131 application programming


## Attention:

If You do not want to install a certain program just skip it by using Cancel at the beginning of the program's wizard.



## If the installation routine does not start automatically:

- Go to Start/Run and browse for setup.exe on the CD. Now start the installation by confirming with OK
- Compact installation for DriveWindow Light + Commissioning Wizard + DriveWindow Light AP is recommended



## Steps to connect Drive to PC

- The documentation can be found under **C:\ABB\DCS800\Docu**
- Remove design cover from the converter module




Remove the DCS800 Control Panel if present. Depress the locks to remove the cover




Connect drive (X34) to your PC COM port

- Start DriveWindow Light PC tool  
Check the communication setting of your COM port



If You use USB to COM port interface or PCMCIA / COM adapters double check the active COM enabled  
Start => Settings => Control Panel => System => Hardware => Device Manager



COM address of USB interface **can** change after the next boot procedure or after disconnecting and reconnecting of the USB interface.

## Note:

PCMCIA to COM Port provide a stable and faster drive interface.

Utilize DriveWindow Light or DCS800 Panel Wizard continue with chapter *Commissioning* in this manual.

For commissioning by DriveWindow find a workspace description in the DCS800 Firmware manual.

# Commissioning



**Danger! High voltage:** this symbol warns of high voltages which may result in injuries to persons and/or damage to equipment. Where appropriate, the text printed adjacent to this symbol describes how risk of this kind may be avoided.



**General warning:** this symbol warns of non-electrical risks and dangers which may result in serious or even fatal injuries to persons and/or damage to equipment. Where appropriate, the text printed adjacent to this symbol describes how risk of this kind may be avoided.



**Warning of electrostatic discharge:** this symbol warns you against electrostatic discharges which may damage to unit. Where appropriate, the text printed adjacent to this symbol describes how risk of this kind may be avoided.

## NEC motor overload protection

The DCS800 provides a solid-state motor overload protection in accordance with the NEC. The overload protection (e.g. protection level in percent of full-load motor current) can be adjusted by parameters in group 31 and group 99.

The instructions can be found in chapter *Motor thermal model* of the *DCS800 Firmware manual*.

## General instructions

- This short commissioning refers to *Chapter 5 Connection examples* of this publication.
- *Safety and operating instructions* - see *chapter 6* of this publication.
- Recommendations for motor and field voltages see *Technical catalogue*.
- In accordance with DIN 57 100 Part 727 / VDE 0100 Part 727, precautions must be taken to enable the drive to be shut down, e.g. in the event of danger. The unit's digital inputs or the control panel are not sufficient as the sole measure for this purpose!

## Preparations

- Check unit for any damage!
- Install unit and wire it up
- Supply voltage level / Rated value correct for electronics and fan?
- Supply voltage level / Rated value correct for armature-circuit converter?
- Supply voltage level / Rated value correct for field supply?
- Wiring / cross-sections, etc. correct?
- EMERGENCY STOP functioning properly?
- COAST STOP functioning properly?

## Commissioning DriveWindow Light

Start the wizard in DriveWindow Light:


For basic commissioning press the *Start* button or select a specific assistant:

For more information about the wizard, parameters faults and alarms press the *Help* button!



# DCS800 Control Panel

The following table summarizes the button functions and displays of the DCS800 Control Panel (DCS CP).



DCS800 QG pan\_ov\_a.ds#f

With USISel (16.09) it is possible to limit the amount of displayed parameters!

## General display features

Following modes are available in the MAIN MENU:

1. Parameters mode
2. Start-up assistants mode
  - a. Name plate data
  - b. Macro assistant
  - c. Autotuning field current controller
  - d. Autotuning armature current controller
  - e. Speed feedback assistant (Tacho fine tuning not available)
  - f. Autotuning speed controller
  - g. Field weakening assistant (only used when maximum speed is higher than base speed)
3. Macros mode (currently not used)
4. Changed parameters mode (compare to default and display changed parameters)
5. Fault logger mode (Display fault history)
6. Clock set mode
7. Parameter backup mode
  - copy active parameter set from the drive into the DCS800 Control Panel (only in local mode)
  - copy parameter set from DCS800 Control Panel into the drive (only in local mode)
8. I/O settings mode (currently not used)

## Parameters entered by assistant

99.02	Motor 1 nominal Voltage
99.03	Motor 1 nominal current
99.04	Motor 1 base speed
20.01	Motor 1 minimum speed
20.02	Motor 1 maximum speed
99.11	Motor 1 nominal field current
30.09	Armature over current level
30.16	Motor 1 over speed
99.10	Nominal mains voltage
99.12	Motor 1 used fex type
20.05	Torque maximum
20.06	Torque minimum
20.12	Motor 1 current limit bridge 1
20.13	Motor 1 current limit bridge 2
50.04	Motor 1 encoder pulse number, if selected
50.02	Motor 1 encoder measured mode, if selected
50.13	Motor 1 tacho volt, only DWL
50.12	Motor 1 tacho adapt, only DWL
20.03	Zero speed limit
22.01	Acceleration time 1
22.02	Deceleration time 1
30.12	Motor 1 field minimum trip
44.01	Field control mode



# Dimensions, drilling patterns and weights – Abmessungen, Bohrbild und Gewichte – Dimensioni, schemi di foratura e pesi – Dimensiones, patrones de taladrado y pesos – Dimensions, perçages et poids

## Module D1

DCS800-S01-0020  
DCS800-S01-0045  
DCS800-S01-0065  
DCS800-S01-0090  
DCS800-S01-0125

DCS800-S02-0025  
DCS800-S02-0050  
DCS800-S02-0075  
DCS800-S02-0100  
DCS800-S02-0140

## Module D2

DCS800-S01-0180  
DCS800-S01-0230

DCS800-S02-0200  
DCS800-S02-0260


## Module D3

DCS800-S01-0315  
DCS800-S01-0405  
DCS800-S01-0470

DCS800-S02-0350  
DCS800-S02-0450  
DCS800-S02-0520

## 600 V types

DCS800-S01-0290  
DCS800-S02-0320



Dimensions in mm  
Maße in mm  
Dimensioni in mm  
Dimensiones en mm  
Dimensions en mm

**1** Installation direction  
Air direction

Montagerichtung  
Luftrichtung

Direzione di installazione  
Direzione aria

Modo de instalación  
Dirección del aire

Sens de montage  
Sens de circulation de l'air

Size	A	B	C	D	E	F	G	H	Weight
D1	370	350	142	200	67	98	145	M6	ca. 11kg
D2	370	350	209	267	121,5	163,5	212	M10	ca. 16kg
D3	459	437,5	262,5	310	147,5	205	252	M10	ca. 25kg


Data for converters with more than 1000 A (D5) see *Hardware manual*

Daten für Stromrichter mit mehr als 1000 A (D5) siehe *Hardware Handbuch*

Dati per convertitori di potenza da oltre 1000 A (D5), si veda *Hardware manual*

Datos para convertidores de más de 1.000 A (D5), véase *Hardware manual*

Données pour variateurs supérieurs à 1000 A (D5), cf. *Manuel d'installation*



## Module D4

DCS800-S01-0610

DCS800-S01-0740

DCS800-S01-0900

DCS800-S02-0680

DCS800-S02-0820


DCS800-S02-1000

## 600 V types

DCS800-S01-0590

DCS800-S02-0650

Weight appr. 38 kg



Power terminal: Busbar 40x5 mm  
Weight appr. 38 kg

**1** Installation direction  
Air direction

Montagerichtung  
Luftrichtung

Direzione di installazi-  
one  
Direzione aria

Modo de instalaci3n  
Direcci3n del aire

Sens de montage  
Sens de circulation de  
l'air


Data for converters with  
more than 1000 A (D5)  
see *Hardware manual*

Daten f3r Stromrichter  
mit mehr als 1000 A  
(D5) siehe *Hardware  
Handbuch*

Dati per convertitori di  
potenza da oltre 1000  
A (D5), si veda *Hardware  
manual*

Datos para convertido-  
res de m3s de 1.000 A  
(D5), véase  
*Hardware manual*

Donn3es pour variateurs  
sup3rieurs 3 1000 A (D5),  
cf. *Manuel d'installation*



D4\_dim\_b.dsf

## Fault / Alarm list • Fehler- / Alarmliste / ital ??? / Diagrama de la estructura del firmware / Liste des défauts et alarmes

LED	Fault	Word	Text on DCS800 Panel, DriveWindow Light and DriveWindow	Definition EN	Text in DCS800 Panel, DriveWindow Light und DriveWindow	Beschreibung D	Testo DCS800 Pannello, DriveWindow Light e DriveWindow	Descrizione IT	Texto en el DCS800 Panel, DriveWindow Light y DriveWindow	Definición SP	Texte dans la DCS800 Microconsole, DriveWindow Light et DriveWindow	Description FR
F501	9.01	Bit 0	Auxiliary undervoltage, terminal X99 on SDCS-PIN-4 and SDCS-POW-4	AuxUnderVolt Auxiliary undervoltage, terminal X99 on SDCS-PIN-4 and SDCS-POW-4	AuxUnderVolt Hilfs-Unterspannung, Klemme X99 auf SDCS-PIN-4 und SDCS-POW-4	AuxUnderVolt Guasto tensione ausiliaria	AuxUnderVolt Fallo de tensión auxiliar (Subtension auxil.)	AuxUnderVolt Défaut tension auxiliaire	AuxUnderVolt Fallo de tensión auxiliar (Subtension auxil.)	AuxUnderVolt Défaut tension auxiliaire	AuxUnderVolt Défaut tension auxiliaire	AuxUnderVolt Défaut tension auxiliaire
F502	9.01	Bit 1	Armature overcurrent, ArmOvrCurLev (30.09)	ArmOverCur Armature overcurrent, ArmOvrCurLev (30.09)	ArmOverCur Überstrom Anker, ArmOvrCurLev (30.09)	ArmOverCur Sovracorrente, ArmOvrCurLev (30.09)	ArmOverCur Sovracorrente, ArmOvrCurLev (30.09)	ArmOverCur Sovracorrente, ArmOvrCurLev (30.09)	ArmOverCur Sovracorrente, ArmOvrCurLev (30.09)	ArmOverCur Sovracorrente, ArmOvrCurLev (30.09)	ArmOverCur Sovracorrente, ArmOvrCurLev (30.09)	ArmOverCur Sovracorrente, ArmOvrCurLev (30.09)
F503	9.01	Bit 2	Armature overvoltage (DC), ArmOvrVoltLev (30.08)	ArmOverVolt Armature overvoltage (DC), ArmOvrVoltLev (30.08)	ArmOverVolt Überspannung Gleichstromkreis (DC), ArmOvrVoltLev (30.08)	ArmOverVolt Sovratensione d'indotto (circuito c.c.), ArmOvrVoltLev (30.08)	ArmOverVolt Sovratensione d'indotto (circuito c.c.), ArmOvrVoltLev (30.08)	ArmOverVolt Sovratensione d'indotto (circuito c.c.), ArmOvrVoltLev (30.08)	ArmOverVolt Sovratensione de inducido (circuito de C.C.), ArmOvrVoltLev (30.08)	ArmOverVolt Sovratensione de inducido (circuito de C.C.), ArmOvrVoltLev (30.08)	ArmOverVolt Sovratensione d'indotto (circuito c.c.), ArmOvrVoltLev (30.08)	ArmOverVolt Sovratensione d'indotto (circuito c.c.), ArmOvrVoltLev (30.08)
F504	9.01	Bit 3	Converter overtemperature, MaxBridgeTemp (4.17)	ConvOverTemp Converter overtemperature, MaxBridgeTemp (4.17)	ConvOverTemp Übertemperatur Stromrichter, MaxBridgeTemp (4.17)	ConvOverTemp Sovratemperatura sezione di potenza, MaxBridgeTemp (4.17)	ConvOverTemp Sovratemperatura sezione di potenza, MaxBridgeTemp (4.17)	ConvOverTemp Sovratemperatura en la sección de potencia, MaxBridgeTemp (4.17)	ConvOverTemp Sovratemperatura en la sección de potencia, MaxBridgeTemp (4.17)	ConvOverTemp Sovratemperatura en la sección de potencia, MaxBridgeTemp (4.17)	ConvOverTemp Echauffement anormal du pont de puissance, MaxBridgeTemp (4.17)	ConvOverTemp Echauffement anormal du pont de puissance, MaxBridgeTemp (4.17)
F505	9.01	Bit 4	Residual current detection (Σ I differs from zero), ResCurDetectSel (30.05)	ResCurDetect Residual current detection (Σ I differs from zero), ResCurDetectSel (30.05)	ResCurDetect Summenstromüberwachung (Σ I ungleich Null), ResCurDetectSel (30.05)	ResCurDetect Guasto a terra (Σ I diverso da zero), ResCurDetectSel (30.05)	ResCurDetect Guasto a terra (Σ I diverso da zero), ResCurDetectSel (30.05)	ResCurDetect Fallo a tierra (Σ I distinto a cero), ResCurDetectSel (30.05)	ResCurDetect Fallo a tierra (Σ I distinto a cero), ResCurDetectSel (30.05)	ResCurDetect Fallo a tierra (Σ I distinto a cero), ResCurDetectSel (30.05)	ResCurDetect Défaut de terre (Σ I différent de zéro), ResCurDetectSel (30.05)	ResCurDetect Défaut de terre (Σ I différent de zéro), ResCurDetectSel (30.05)
F506	9.01	Bit 5	M1OverTemp Motor 1 measured overtemperature, M1FaultLimTemp (31.07)	M1OverTemp Motor 1 measured overtemperature, M1FaultLimTemp (31.07)	M1OverTemp Motor 1 gemessene Übertemperatur, M1FaultLimTemp (31.07)	M1OverTemp Motore 1 sovratemperatura, M1FaultLimTemp (31.07)	M1OverTemp Motore 1 sovratemperatura, M1FaultLimTemp (31.07)	M1OverTemp Motor 1 sobretemperatura, M1FaultLimTemp (31.07)	M1OverTemp Motor 1 sobretemperatura, M1FaultLimTemp (31.07)	M1OverTemp Motor 1 sobretemperatura, M1FaultLimTemp (31.07)	M1OverTemp Moteur 1 echauffement anormal, M1FaultLimTemp (31.07)	M1OverTemp Moteur 1 echauffement anormal, M1FaultLimTemp (31.07)
F507	9.01	Bit 6	M1OverLoad Motor 1 calculated overload, M1FaultLimLoad (31.04)	M1OverLoad Motor 1 calculated overload, M1FaultLimLoad (31.04)	M1OverLoad Motor 1 berechnete Überlast, M1FaultLimLoad (31.04)	M1OverLoad Motore 1 sovraccarico, M1FaultLimLoad (31.04)	M1OverLoad Motore 1 sovraccarico, M1FaultLimLoad (31.04)	M1OverLoad Motor 1 sobrecarga, M1FaultLimLoad (31.04)	M1OverLoad Motor 1 sobrecarga, M1FaultLimLoad (31.04)	M1OverLoad Motor 1 sobrecarga, M1FaultLimLoad (31.04)	M1OverLoad Moteur 1 surcharge, M1FaultLimLoad (31.04)	M1OverLoad Moteur 1 surcharge, M1FaultLimLoad (31.04)
F508	9.01	Bit 7	I/O board not found or faulty, see groups 94 and 98	I/OBoardLoss I/O board not found or faulty, see groups 94 and 98	I/OBoardLoss E/A-Karte nicht gefunden oder fehlerhaft, s. Gruppe 94 und 98	I/OBoardLoss Tarjetas E/S no encontradas o faltan, comprobar parámetros gr. 94 y 98.	I/OBoardLoss Tarjetas E/S no encontradas o faltan, comprobar parámetros gr. 94 y 98.	I/OBoardLoss Tarjetas E/S no encontradas o faltan, comprobar parámetros gr. 94 y 98.	I/OBoardLoss Tarjetas E/S no encontradas o faltan, comprobar parámetros gr. 94 y 98.	I/OBoardLoss Tarjetas E/S no encontradas o faltan, comprobar parámetros gr. 94 y 98.	I/OBoardLoss I/OBoardLoss	I/OBoardLoss I/OBoardLoss
F509	9.01	Bit 8	M2OverTemp Motor 2 measured overtemperature, M2FaultLimTemp (49.37)	M2OverTemp Motor 2 measured overtemperature, M2FaultLimTemp (49.37)	M2OverTemp Motor 2 gemessene Übertemperatur, M2FaultLimTemp (49.37)	M2OverTemp Motore 2 sovratemperatura, M2FaultLimTemp (49.37)	M2OverTemp Motore 2 sovratemperatura, M2FaultLimTemp (49.37)	M2OverTemp Motor 2 sobretemperatura, M2FaultLimTemp (49.37)	M2OverTemp Motor 2 sobretemperatura, M2FaultLimTemp (49.37)	M2OverTemp Motor 2 sobretemperatura, M2FaultLimTemp (49.37)	M2OverTemp Moteur 2 echauffement anormal, M2FaultLimTemp (49.37)	M2OverTemp Moteur 2 echauffement anormal, M2FaultLimTemp (49.37)
F510	9.01	Bit 9	M2OverLoad Motor 2 calculated overload, M2FaultLimLoad (49.34)	M2OverLoad Motor 2 calculated overload, M2FaultLimLoad (49.34)	M2OverLoad Motor 2 berechnete Überlast, M2FaultLimLoad (49.34)	M2OverLoad Motore 2 sovraccarico, M2FaultLimLoad (49.34)	M2OverLoad Motore 2 sovraccarico, M2FaultLimLoad (49.34)	M2OverLoad Motor 2 sobrecarga, M2FaultLimLoad (49.34)	M2OverLoad Motor 2 sobrecarga, M2FaultLimLoad (49.34)	M2OverLoad Motor 2 sobrecarga, M2FaultLimLoad (49.34)	M2OverLoad Moteur 2 surcharge, M2FaultLimLoad (49.34)	M2OverLoad Moteur 2 surcharge, M2FaultLimLoad (49.34)
F511	9.01	Bit 10	ConvFanCur Current converter fan not within limits, ConvTempDly (97.05)	ConvFanCur Current converter fan not within limits, ConvTempDly (97.05)	ConvFanCur Geräteüfuerstrom nicht innerhalb der Grenzen, ConvTempDly (97.05)	ConvFanCur La corrente del ventilatore del convertitore non rientra nei limiti, ConvTempDly (97.05)	ConvFanCur La corrente del ventilatore del convertitore non rientra nei limiti, ConvTempDly (97.05)	ConvFanCur Intensidad en ventilador del convertidor fuera de los límites, ConvTempDly (97.05)	ConvFanCur Intensidad en ventilador del convertidor fuera de los límites, ConvTempDly (97.05)	ConvFanCur Intensidad en ventilador del convertidor fuera de los límites, ConvTempDly (97.05)	ConvFanCur Courant du ventilateur du convertisseur hors limites, ConvTempDly (97.05)	ConvFanCur Courant du ventilateur du convertisseur hors limites, ConvTempDly (97.05)
F512	9.01	Bit 11	MainsLowVolt Mains low (under-) voltage (AC), UneMin1 (30.22)	MainsLowVolt Mains low (under-) voltage (AC), UneMin1 (30.22)	MainsLowVolt Netz-Unterspannung (AC), UneMin1 (30.22)	MainsLowVolt Minima tensione di alimentazione di rete (c.a.), UneMin1 (30.22)	MainsLowVolt Minima tensione di alimentazione di rete (c.a.), UneMin1 (30.22)	MainsLowVolt Tensión Baja de red (C.A.), UneMin1 (30.22)	MainsLowVolt Tensión Baja de red (C.A.), UneMin1 (30.22)	MainsLowVolt Tensión Baja de red (C.A.), UneMin1 (30.22)	MainsLowVolt Sous-tension réseau (c.a.), UneMin1 (30.22)	MainsLowVolt Sous-tension réseau (c.a.), UneMin1 (30.22)

LED	Fault	Word	Text on DC5800 Panel, DriveWindow Light and DriveWindow	Text in DC5800 Panel, DriveWindow Light und DriveWindow	Testo DC5800 Pannello, DriveWindow Light e DriveWindow	Texto en el DC5800 Panel, DriveWindow Light y DriveWindow	Texte dans la DC5800 Microconsole, DriveWindow Light et DriveWindow
			Definition EN	Beschreibung D	Descrizione IT	Definición SP	Description FR
F513	9.01	Bit 12	MainsOverVolt Mains overvoltage (AC), > 1.3 * NomMainsVolt (99.10)	MainsOverVolt Netz-Überspannung (AC), > 1.3 * NomMainsVolt (99.10)	MainsOverVolt Sovratensione alimentazione di rete (c.a.), > 1.3 * NomMains Volt (99.10)	MainsOverVolt Sobretensión de red (C.A.), > 1.3 * NomMainsVolt (99.10)	MainsOverVolt Surtension réseau (c.a.), > 1.3 * NomMainsVolt (99.10)
F514	9.01	Bit 13	MainsNotSync Mains not in synchronism (AC), DevLimPLL (97.13)	MainsNotSync Netz nicht synchronisiert (AC), DevLimPLL (97.13)	MainsNotSync Guasto di sincronizzazione (c.a.), DevLimPLL (97.13)	MainsNotSync Fallo de sincronización (C.A.), DevLimPLL (97.13)	MainsNotSync Défaut de synchronisation (c.a.), DevLimPLL (97.13)
F515	9.01	Bit 14	MIFexOverCur Motor 1 field exciter overcurrent, M1FldOvrCurLev (30.13)	MIFexOverCur Motor 1 Überstrom Feldversorgung, M1FldOvrCurLev (30.13)	MIFexOverCur Motore 1 Sovraccorrente ECCITATRICE DI CAMPO, M1FldOvrCurLev (30.13)	MIFexOverCur Motor 1 Sobrecorriente de la EXCITACIÓN, M1FldOvrCurLev (30.13)	MIFexOverCur Moteur 1 Surintensité EXCITATION, M1FldOvrCurLev (30.13)
F516	9.01	Bit 15	MIFexCom Motor 1 field exciter communication loss, FexTimeOut (94.07)	MIFexCom Motor 1 Kommunikationsverlust Feldversorgung, FexTimeOut (94.07)	MIFexCom Motore 1 Errore di comunicazione ECCITATRICE DI CAMPO, FexTimeOut (94.07)	MIFexCom Motor 1 Error de comunicación con la excitación, FexTimeOut (94.07)	MIFexCom Moteur 1 Erreur de communication EXCITATION, FexTimeOut (94.07)
F517	9.02	Bit 0	ArmCurRipple Armature current ripple, CurRippleSel(30.18)	ArmCurRipple Welligkeit Ankerstrom, CurRippleSel (30.18)	ArmCurRipple Ondulazione della corrente d'indotto, CurRippleSel (30.18)	ArmCurRipple Rizado de la corriente (intensidad) del inducido, CurRippleSel (30.18)	ArmCurRipple Ondulation courant d'induit, CurRippleSel (30.18)
F518	9.02	Bit 1	M2FexOverCur Motor 2 field exciter overcurrent, M2FldOvrCurLev (49.09)	M2FexOverCur Motor 2 Überstrom Feldversorgung, M2FldOvrCurLev (49.09)	M2FexOverCur Motore 2 Sovraccorrente ECCITATRICE DI CAMPO, M2FldOvrCurLev (49.09)	M2FexOverCur Motor 2 Sobrecorriente de la EXCITACIÓN, M2FldOvrCurLev (49.09)	M2FexOverCur Moteur 2 Surintensité EXCITATION, M2FldOvrCurLev (49.09)
F519	9.02	Bit 2	M2FexCom Motor 2 field exciter communication loss, FexTimeOut (94.07)	M2FexCom Motor 2 Kommunikationsverlust Feldversorgung, FexTimeOut (94.07)	M2FexCom Motore 2 Errore di comunicazione ECCITATRICE DI CAMPO, FexTimeOut (94.07)	M2FexCom Motor 2 Error de comunicación con la excitación, FexTimeOut (94.07)	M2FexCom Moteur 2 Erreur de communication EXCITATION, FexTimeOut (94.07)
F521	9.02	Bit 4	FieldAck Selected motor, field acknowledge missing, Mot1FexStatus (6.12)	FieldAck Ausgewählter Motor, Rückmeldung Feldversorgung fehlt, Mot1FexStatus (6.12)	FieldAck Nessuna conferma di campo dall' ECCITATRICE DI CAMPO, Mot1FexStatus (6.12)	FieldAck EXCITACIÓN no detectada), Mot1FexStatus (6.12)	FieldAck Absence de signal retour de l'EXCITATION, Mot1FexStatus (6.12)
F522	9.02	Bit 5	SpeedFb Selected motor, speed feedback, M1SpeedFbSel (50.03)	SpeedFb Ausgewählter Motor, Drehzahlrückmeldung, M1SpeedFbSel (50.03)	SpeedFb Retroazione (misura) di velocità, M1SpeedFbSel (50.03)	SpeedFb Fallo en la lectura de la velocidad, M1SpeedFbSel (50.03)	SpeedFb Défaut retour vitesse (mesure), M1SpeedFbSel (50.03)
F523	9.02	Bit 6	ExtFanAck External fan acknowledge missing, MotFanAck (10.06)	ExtFanAck Rückmeldung externer Lüfter fehlt, MotFanAck (10.06)	ExtFanAck Nessuna conferma dal VENTILATORE del motore, MotFanAck (10.06)	ExtFanAck Sin reconocimiento del VENTILADOR del motor, MotFanAck (10.06)	ExtFanAck Absence de signal retour du VENTILATEUR du moteur, MotFanAck (10.06)
F524	9.02	Bit 7	MainContAck Main contactor acknowledge missing, MainContAck (10.21)	MainContAck Rückmeldung Hauptschutz fehlt, MainContAck (10.21)	MainContAck Manca conferma dal contattore principale, MainContAck (10.21)	MainContAck Falta reconocimiento contactor principal, MainContAck (10.21)	MainContAck Absence de signal retour du contacteur principal, MainContAck (10.21)
F525	9.02	Bit 8	TypeCode Type code mismatch, TypeCode (97.01)	TypeCode Fehlanspassung Stromrichtertyp, TypeCode (97.01)	TypeCode Guasto di codifica tipo (convertitore), TypeCode (97.01)	TypeCode Fallo de identificación de Convertidor (Codificación de tipo) , TypeCode (97.01)	TypeCode Erreur d'identification du type de variateur, TypeCode (97.01)
F526	9.02	Bit 9	ExternalDI External fault via binary input, ExtFaultSel (30.31)	ExternalDI Externer Fehler an binärem Eingang, ExtFaultSel (30.31)	ExternalDI Guasto esterno su ingresso digitale, ExtFaultSel (30.31)	ExternalDI Fallo externo en la entrada digital, ExtFaultSel (30.31)	ExternalDI Défaut extérieur à l'entrée digitale, ExtFaultSel (30.31)

LED	Fault	Word	Text on DCS800 Panel, DriveWindow Light and DriveWindow	Definition EN	Beschreibung D	Texto DCS800 Pannello, DriveWindow Light e DriveWindow	Descrizione IT	Definición SP	Texto en el DCS800 Panel, DriveWindow Light y DriveWindow	Description FR
F527	9.02	Bit 10	Converter Fan acknowledge missing, ConvFanAck (10.20)	ConvFanAck Converter Fan acknowledge missing, ConvFanAck (10.20)	Rückmeldung Stromrichterlüfter fehlt, ConvFanAck (10.20)	ConvFanAck Manca conferma alimentazione da VENTILATORE CONVERTITORE, ConvFanAck (10.20)	ConvFanAck Manca conferma alimentazione da VENTILATORE CONVERTITORE, ConvFanAck (10.20)	ConvFanAck Sin reconocimiento de la alimentación del VENTILADOR DEL CONVERTIDOR, ConvFanAck (10.20)	ConvFanAck Absence de signal retour du VENTILATEUR du VARIATEUR, ConvFanAck (10.20)	Texte dans la DCS800 Microconsole, DriveWindow Light et DriveWindow Description FR
F528	9.02	Bit 11	Fieldbus communication loss, ComLossCtrl (30.28), TimeOut (30.35)	FieldBusCom Fieldbus communication loss, ComLossCtrl (30.28), TimeOut (30.35)	Kommunikationsfehler Feldbus, ComLossCtrl (30.28), TimeOut (30.35)	FieldBusCom Guasto comunicazione con bus di campo, ComLossCtrl (30.28), TimeOut (30.35)	FieldBusCom Guasto comunicazione con bus di campo, ComLossCtrl (30.28), TimeOut (30.35)	FieldBusCom Fallo de comunicación con el bus de campo, ComLossCtrl (30.28), TimeOut (30.35)	FieldBusCom Défaut communication avec bus de terrain, ComLossCtrl (30.28), TimeOut (30.35)	FieldBusCom Défaut communication avec bus de terrain, ComLossCtrl (30.28), TimeOut (30.35)
F529	9.02	Bit 12	MIFexNotOK Motor 1 field exciter not okay, hardware failure fieldexciter	MIFexNotOK Motor 1 field exciter not okay, hardware failure fieldexciter	Motor 1 Feldversorgung nicht OK, Hardwarfehler Feldversorgung	MIFexNotOK Motore 1 lo stato dell'ECCITATRICE DI CAMPO (alimentazione di campo) non è O.K.	MIFexNotOK Motore 1 lo stato dell'ECCITATRICE DI CAMPO (alimentazione di campo) non è O.K.	MIFexNotOK Motor 1: Mal estado de la unidad de EXCITACIÓN (campo)	MIFexNotOK Moteur 1 défaut EXCITATION	MIFexNotOK Moteur 1 défaut EXCITATION
F530	9.02	Bit 13	M2FexNotOK Motor 2 field exciter not okay, hardware failure fieldexciter	M2FexNotOK Motor 2 field exciter not okay, hardware failure fieldexciter	Motor 2 Feldversorgung nicht OK, Hardwarfehler Feldversorgung	M2FexNotOK Motore 2 lo stato dell'ECCITATRICE DI CAMPO (alimentazione di campo) non è O.K.	M2FexNotOK Motore 2 lo stato dell'ECCITATRICE DI CAMPO (alimentazione di campo) non è O.K.	M2FexNotOK Motor 2: Mal estado de la unidad de EXCITACIÓN (campo)	M2FexNotOK Moteur 2 défaut EXCITATION	M2FexNotOK Moteur 2 défaut EXCITATION
F531	9.02	Bit 14	Motor stalled, StallTime (30.01)	MotorStalled Motor stalled, StallTime (30.01)	Motor blockiert, StallTime (30.01)	MotorStalled Motore in stallo, StallTime (30.01)	MotorStalled Motore in stallo, StallTime (30.01)	MotorStalled Motor bloqueado, StallTime (30.01)	MotorStalled Moteur (Rotor) bloqué, StallTime (30.01)	MotorStalled Moteur (Rotor) bloqué, StallTime (30.01)
F532	9.02	Bit 15	Motor overspeed, M1OvrSpeed (30.16)	MotorOvrSpeed Motor overspeed, M1OvrSpeed (30.16)	Überdrehzahl Motor, M1OvrSpeed (30.16)	MotorOvrSpeed Sovravelocità motore, M1OvrSpeed (30.16)	MotorOvrSpeed Sovravelocità motore, M1OvrSpeed (30.16)	MotorOvrSpeed Sobrevelocidad del motor, M1OvrSpeed (30.16)	MotorOvrSpeed Survitesse moteur, M1OvrSpeed (30.16)	MotorOvrSpeed Survitesse moteur, M1OvrSpeed (30.16)
F533	9.03	Bit 0	Reversal time is elapsed, ZeroCurTimeOut (97.19), RevDly (43.14)	ReversalTime Reversal time is elapsed, ZeroCurTimeOut (97.19), RevDly (43.14)	Zeit Stromrichtungswechsel abgelaufen, ZeroCurTimeOut (97.19), RevDly (43.14)	ReversalTime Inversione direzione della corrente non O.K., ZeroCurTimeOut (97.19), RevDly (43.14)	ReversalTime Inversione direzione della corrente non O.K., ZeroCurTimeOut (97.19), RevDly (43.14)	ReversalTime Défaut d'inversion du sens du courant, ZeroCurTimeOut (97.19), RevDly (43.14)	ReversalTime Défaut d'inversion du sens du courant, ZeroCurTimeOut (97.19), RevDly (43.14)	ReversalTime Défaut d'inversion du sens du courant, ZeroCurTimeOut (97.19), RevDly (43.14)
F534	9.03	Bit 1	12-pulse current difference, DiffCurLim (47.02)	12PcurDiff 12-pulse current difference, DiffCurLim (47.02)	12-Puls Stromistwertabweichung, DiffCurLim (47.02)	12PcurDiff Differenza in retroazione di corrente (deviazione), DiffCurLim (47.02)	12PcurDiff Differenza in retroazione di corrente (deviazione), DiffCurLim (47.02)	12PcurDiff Diferencia en la realimentación de la intensidad en 12 pulsos, DiffCurLim (47.02)	12PcurDiff Ecart de retour du courant entre l'entraînement, DiffCurLim (47.02)	12PcurDiff Ecart de retour du courant entre l'entraînement, DiffCurLim (47.02)
F535	9.03	Bit 2	12-pulse communication, 12P TimeOut (94.03)	12PCom 12-pulse communication, 12P TimeOut (94.03)	12-Puls Kommunikation, 12P TimeOut (94.03)	12PCom No hay comunicación 12-pulsos, 12P TimeOut (94.03)	12PCom No hay comunicación 12-pulsos, 12P TimeOut (94.03)	12PCom No hay comunicación 12-pulsos, 12P TimeOut (94.03)	12PCom 12P TimeOut (94.03)	12PCom 12P TimeOut (94.03)
F536	9.03	Bit 3	12-pulse slave failure. 12-pulse master is tripped by a fault of the 12-pulse slave	12PSlaveFail 12-pulse slave failure. 12-pulse master is tripped by a fault of the 12-pulse slave	Fehler 12-Puls Slave. 12-Puls Master wurde wegen Fehler im 12-Puls Slave abgeschaltet	12PSlaveFail Guasto slave a 12-impulsi. Scatto del master a 12-impulsi per guasto slave a 12-impulsi	12PSlaveFail Guasto slave a 12-impulsi. Scatto del master a 12-impulsi per guasto slave a 12-impulsi	12PSlaveFail Fallo 12 pulsos esclavo. El Master es disparado por fallo en el esclavo	12PSlaveFail Défaut d'esclave 12-pulse. Maître 12-pulse déclenché dû au défaut d'esclave 12-pulse	12PSlaveFail Défaut d'esclave 12-pulse. Maître 12-pulse déclenché dû au défaut d'esclave 12-pulse
F537	9.03	Bit 4	MIFexRdyLost Motor 1 field exciter lost ready-for-operation	MIFexRdyLost Motor 1 field exciter lost ready-for-operation	Motor 1 Feldversorgung hat die Betriebsbereitschaft verloren	MIFexRdyLost _ La excitación del motor 1 ha perdido estado de listo para funcionamiento	MIFexRdyLost _ La excitación del motor 1 ha perdido estado de listo para funcionamiento	MIFexRdyLost _ La excitación del motor 1 ha perdido estado de listo para funcionamiento	MIFexRdyLost _ La excitación del motor 1 ha perdido estado de listo para funcionamiento	MIFexRdyLost _ La excitación del motor 1 ha perdido estado de listo para funcionamiento
F538	9.03	Bit 5	M2FexRdyLost Motor 2 field exciter lost ready-for-operation	M2FexRdyLost Motor 2 field exciter lost ready-for-operation	Motor 2 Feldversorgung hat die Betriebsbereitschaft verloren	M2FexRdyLost La excitación del motor 2 ha perdido estado de listo para funcionamiento	M2FexRdyLost La excitación del motor 2 ha perdido estado de listo para funcionamiento	M2FexRdyLost La excitación del motor 2 ha perdido estado de listo para funcionamiento	M2FexRdyLost La excitación del motor 2 ha perdido estado de listo para funcionamiento	M2FexRdyLost La excitación del motor 2 ha perdido estado de listo para funcionamiento

LED	Fault	Word	Definition EN	Text in DC5800 Panel, DriveWindow Light and DriveWindow	Beschreibung D	Texto DC5800 Pannello, DriveWindow Light e DriveWindow	Descrizione IT	Definición SP	Texto en el DC5800 Panel, Microconsole, DriveWindow Light et DriveWindow	Description FR
F539	9.03	Bit 6	FastCurRise Actual armature current rises faster than allowed, ArmCurRiseMax (30.10)	Text in DC5800 Panel, DriveWindow Light und DriveWindow	FastCurRise Ankerstromistwert steigt schneller als erlaubt, ArmCurRiseMax (30.10)	Testo DC5800 Pannello, DriveWindow Light y DriveWindow	FastCurRise Variazione della corrente effettiva più rapida del consentito, ArmCurRiseMax (30.10)	FastCurRise La intensidad actual ha cambiado más rápido de lo permitido, ArmCurRiseMax (30.10)	FastCurRise Le courant réel varie plus vite qu'autorisé, ArmCurRiseMax (30.10)	DriveWindow Light et DriveWindow Description FR
F540	9.03	Bit 7	COMeFaulty SDCS-COM-8 faulty or not found, SysComBoard (98.16)	Text in DC5800 Panel, DriveWindow Light und DriveWindow	COMeFaulty SDCS-COM-8 fehlerhaft oder nicht gefunden, SysComBoard (98.16)	Testo DC5800 Pannello, DriveWindow Light e DriveWindow	COMeFaulty Guasto scheda SDCS-COM-8, SysComBoard (98.16)	COMeFaulty Fallo de tarjeta SDCS-COM-8 o no encontrada, SysComBoard (98.16)	COMeFaulty Défaut de la carte SDCS-COM-8, SysComBoard (98.16)	DriveWindow Light et DriveWindow Description FR
F541	9.03	Bit 8	M1FexLowCur Motor 1 field exciter low current, M1FidMinTrip (30.12)	Text in DC5800 Panel, DriveWindow Light und DriveWindow	M1FexLowCur Motor 1 Unterstrom Feldversorgung, M1FidMinTrip (30.12)	Testo DC5800 Pannello, DriveWindow Light e DriveWindow	M1FexLowCur Motore 1 Sovraccorrente ECCTATRICE DI CAMPO, M1FidMinTrip (30.12)	M1FexLowCur Motor 1 Sobrecorriente de la EXCITACIÓN, M1FidMinTrip (30.12)	M1FexLowCur Moteur 1 Surintensité EXCITATION, M1FidMinTrip (30.12)	DriveWindow Light et DriveWindow Description FR
F542	9.03	Bit 9	M2FexLowCur Motor 2 field exciter low current, M2FidMinTrip (49.08)	Text in DC5800 Panel, DriveWindow Light und DriveWindow	M2FexLowCur Motor 2 Unterstrom Feldversorgung, M2FidMinTrip (49.08)	Testo DC5800 Pannello, DriveWindow Light e DriveWindow	M2FexLowCur Motore 2 Sovraccorrente ECCTATRICE DI CAMPO, M2FidMinTrip (49.08)	M2FexLowCur Motor 2 Sobrecorriente de la EXCITACIÓN, M2FidMinTrip (49.08)	M2FexLowCur Moteur 2 Surintensité EXCITATION, M2FidMinTrip (49.08)	DriveWindow Light et DriveWindow Description FR
F543	9.03	Bit 10	COMeCom Communication between SDCS-COM-8 and overriding control respectively master-follower link, Ch0ComLossCtrl (70.05), Ch2ComLossCtrl (70.15)	Text in DC5800 Panel, DriveWindow Light und DriveWindow	COMeCom Kommunikation zwischen SDCS-COM-8 und übergeordneter Steuerung bzw. Master-Follower Verbindung, Ch0ComLossCtrl (70.05), Ch2ComLossCtrl (70.15)	Testo DC5800 Pannello, DriveWindow Light e DriveWindow	COMeCom Pérdida comunicación en el lazo SDCS COM-8, PLC y Maestro Esclavo, Ch0ComLossCtrl (70.05), Ch2ComLossCtrl (70.15)	COMeCom Pérdida comunicación en el lazo SDCS COM-8, PLC y Maestro Esclavo, Ch0ComLossCtrl (70.05), Ch2ComLossCtrl (70.15)	COMeCom →, Ch0ComLossCtrl (70.05), Ch2ComLossCtrl (70.15)	DriveWindow Light et DriveWindow Description FR
F544	9.03	Bit 11	P2PandMFCom Peer to peer respectively master-follower link communication, ComLossCtrl (30.28)	Text in DC5800 Panel, DriveWindow Light und DriveWindow	P2PandMFCom Kommunikation Peer to Peer bzw. Master - Follower Verbindung, ComLossCtrl (30.28)	Testo DC5800 Pannello, DriveWindow Light e DriveWindow	P2PandMFCom Pérdida en la comunicación punto a punto Maestro Esclavo, ComLossCtrl (30.28)	P2PandMFCom Pérdida en la comunicación punto a punto Maestro Esclavo, ComLossCtrl (30.28)	P2PandMFCom ComLossCtrl (30.28)	DriveWindow Light et DriveWindow Description FR
F545	9.03	Bit 12	APPLoadFail Application load failure (ControlBuilder), Diagnosis (9.11)	Text in DC5800 Panel, DriveWindow Light und DriveWindow	APPLoadFail Fehler beim Laden der Applikation (ControlBuilder), Diagnosis (9.11)	Testo DC5800 Pannello, DriveWindow Light e DriveWindow	APPLoadFail Fallo en la carga de la aplicación Control Builder, Diagnosis (9.11)	APPLoadFail Fallo en la carga de la aplicación Control Builder, Diagnosis (9.11)	APPLoadFail Diagnosis (9.11)	DriveWindow Light et DriveWindow Description FR
F546	9.03	Bit 13	LocalCmLoss Communication fault with panel (X33), DriveWindow (CH3) or DriveWindow Light (X34), LocalLossCtrl (30.27)	Text in DC5800 Panel, DriveWindow Light und DriveWindow	LocalCmLoss Kommunikationsfehler mit Panel (X33), DriveWindow (CH3) oder DriveWindow Light (X34), LocalLossCtrl (30.27)	Testo DC5800 Pannello, DriveWindow Light e DriveWindow	LocalCmLoss Guasto comunicazione con pannello (X33), DriveWindow (CH3) o DriveWindow Light (X34), LocalLossCtrl (30.27)	LocalCmLoss Fallo de comunicación con el Panel (X33), DriveWindow (CH3) o DriveWindow Light (X34), LocalLossCtrl (30.27)	LocalCmLoss Défaut communication avec la micro - console (X33), DriveWindow (CH3) ou DriveWindow Light (X34), LocalLossCtrl (30.27)	DriveWindow Light et DriveWindow Description FR
F547	9.03	HWFailure	HWFailure Hardware failure, Diagnosis (9.11)	Text in DC5800 Panel, DriveWindow Light und DriveWindow	HWFailure Hardwarefehler, Diagnosis (9.11)	Testo DC5800 Pannello, DriveWindow Light e DriveWindow	HWFailure Guasto hardware, Diagnosis (9.11)	HWFailure Fallo hardware, Diagnosis (9.11)	HWFailure Défaut circuits, Diagnosis (9.11)	DriveWindow Light et DriveWindow Description FR
F548	9.03	FwFailure	FwFailure Firmware failure, Diagnosis (9.11)	Text in DC5800 Panel, DriveWindow Light und DriveWindow	FwFailure Firmwarefehler, Diagnosis (9.11)	Testo DC5800 Pannello, DriveWindow Light e DriveWindow	FwFailure Guasto software, Diagnosis (9.11)	FwFailure Fallo software, Diagnosis (9.11)	FwFailure Défaut programme, Diagnosis (9.11)	DriveWindow Light et DriveWindow Description FR
F549	9.04	ParComp	ParComp Parameter Compatibility, Diagnosis (9.11)	Text in DC5800 Panel, DriveWindow Light und DriveWindow	ParComp Parameter Kompatibilität, Diagnosis (9.11)	Testo DC5800 Pannello, DriveWindow Light e DriveWindow	ParComp Compatibilidad de parámetros, Diagnosis (9.11)	ParComp Compatibilidad de parámetros, Diagnosis (9.11)	ParComp Diagnosis (9.11)	DriveWindow Light et DriveWindow Description FR
F550	9.04	ParMemRead	ParMemRead Parameter Memory Card read	Text in DC5800 Panel, DriveWindow Light und DriveWindow	ParMemRead Lesen Parameter Memory Card	Testo DC5800 Pannello, DriveWindow Light e DriveWindow	ParMemRead Lectura de parámetros de la Memory Card	ParMemRead Lectura de parámetros de la Memory Card	ParMemRead ParMemRead	DriveWindow Light et DriveWindow Description FR

LED	Fault	Word	Text on DCS800 Panel, DriveWindow Light and DriveWindow	Definition EN	Beschreibung D	Testo DCS800 Pannello, DriveWindow Light e DriveWindow	Descrizione IT	Definición SP	Texto en el DCS800 Panel, DriveWindow Light y DriveWindow	Texte dans la DCS800 Microconsole, DriveWindow Light et DriveWindow
F551	9.04	Bit 2	AIRange Analog input range, A/ Mon4mA (30.29)	AIRange Unterschreitung Analogeingangsbereich, A/ Mon4mA (30.29)	AIRange Analogeingangsbereich, A/ Mon4mA (30.29)	AIRange Rango de la entrada analógica, A/ Mon4mA (30.29)	AIRange Mon4mA (30.29)	AIRange Rango de la entrada analógica, A/ Mon4mA (30.29)	AIRange Rango de la entrada analógica, A/ Mon4mA (30.29)	AIRange Mon4mA (30.29)
F552	9.04	Bit 3	MechBrake Selected motor, mechanical brake, BrakeFaultFunc (42.06)	MechBrake Ausgewählter Motor, mechanische Bremse, BrakeFaultFunc (42.06)	MechBrake Ausgewählter Motor, mechanische Bremse, BrakeFaultFunc (42.06)	MechBrake Freno mecánico del motor, BrakeFaultFunc (42.06)	MechBrake BrakeFaultFunc (42.06)	MechBrake Freno mecánico del motor, BrakeFaultFunc (42.06)	MechBrake Freno mecánico del motor, BrakeFaultFunc (42.06)	MechBrake BrakeFaultFunc (42.06)
F553	9.04	Bit 4	TachPolarity Selected motor, tacho polarity, polarity of analog tacho signal incorrect	TachPolarity Ausgewählter Motor, Tachopolarität, analoger Tacho verpolt	TachPolarity Ausgewählter Motor, Tachopolarität, analoger Tacho verpolt	TachPolarity Polaridad de la señal de taco incorrecta,	TachPolarity	TachPolarity Polaridad de la señal de taco incorrecta,	TachPolarity	TachPolarity
F554	9.04	Bit 5	TachRange Selected motor, tacho range, terminals X3:1 to X3:4 on SDCS-CON-4	TachRange Ausgewählter Motor, Überschreitung Tachobereich, Klemmen X3:1 bis X3:4 auf SDCS-CON-4	TachRange Ausgewählter Motor, Überschreitung Tachobereich, Klemmen X3:1 bis X3:4 auf SDCS-CON-4	TachRange Rango de la taco erróneo en los terminales X3:1 a X3:4 de la SDCS-CON-4	TachRange	TachRange Rango de la taco erróneo en los terminales X3:1 a X3:4 de la SDCS-CON-4	TachRange	TachRange
F556	9.04	Bit 7	TorqueProving Selected motor, torque proving, acknowledge signal is missing	TorqueProving Ausgewählter Motor, Drehmomentprüfung, Rückmeldesignal fehlt	TorqueProving Ausgewählter Motor, Drehmomentprüfung, Rückmeldesignal fehlt	TorqueProving Prueba de Par_	TorqueProving	TorqueProving Prueba de Par_	TorqueProving	TorqueProving

LED	Alarm Word	Definition EN	Beschreibung DE	Descrizione IT	Definición SP	Description FR
A101	9.06 Bit 0	Text on DCS800 Panel, DriveWindow Light and DriveWindow	Text in DCS800 Panel, DriveWindow Light und DriveWindow	Testo DCS800 Pannello, DriveWindow Light e DriveWindow	Texto en el DCS800 Panel, DriveWindow Light y DriveWindow	Texte dans la DCS800 Microconsole, DriveWindow Light et DriveWindow
A102	9.06 Bit 1	Off2 (Emergency Off / Coast stop) pending via binary input, Off2 (10.08)	Off2 (Notaus / Austrudeln) ist am einem binären Eingang aktiv, Off2 (10.08)	Off2 (10.08)	Configuración Entradas Digitales (Emergency Off / Coast stop), Off2 (10.08)	Off2 (10.08)
A103	9.06 Bit 2	Off3 (E-stop) pending via digital input, E Stop (10.09)	Off3 (Nothalt) ist am einem binären Eingang aktiv, E Stop (10.09)	Off3 (10.09), E	Configuración Entradas Digitales (E-stop), E Stop (10.09)	Off3 (10.09), E
A104	9.06 Bit 3	DCBreakAck Selected motor, DC-Breaker acknowledge missing, DCBreakAck (10.23)	DCBreakAck Ausgewählter Motor, Rückmeldung Gleichstromschnellschalter fehlt, DCBreakAck (10.23)	DCBreakAck DCBreakAck (10.23)	DCBreakAck Interruptor CC no reconocido, DCBreakAck (10.23)	DCBreakAck DCBreakAck (10.23)
A105	9.06 Bit 4	ConvOverTemp Converter overtemperature, MaxBridge Temp (4.17), ConvFanAck (10.20)	ConvOverTemp Übertemperatur Stromrichter, MaxBridge Temp (4.17), ConvFanAck (10.20)	ConvOverTemp Sovratemperatura sezione di potenza, MaxBridge Temp (4.17), ConvFanAck (10.20)	ConvOverTemp Sobretemperatura en la sección de potencia, MaxBridge Temp (4.17), ConvFanAck (10.20)	ConvOverTemp Echauffement anormal du pont de puissance, MaxBridgeTemp (4.17), ConvFanAck (10.20)
A106	9.06 Bit 5	DynBrakeAck Selected motor, dynamic braking is still pending via digital input, DynBrakeAck (10.22)	DynBrakeAck Ausgewählter Motor, Wiederstandsbremmung ist am einem digitalen Eingang aktiv, DynBrakeAck (10.22)	DynBrakeAck (10.22)	DynBrakeAck (10.22)	DynBrakeAck (10.22)
A107	9.06 Bit 6	M1OverTemp Motor 1 measured overtemperature, M1AlarmLimTemp (31.06)	M1OverTemp Motor 1 gemessene Übertemperatur, M1AlarmLimTemp (31.06)	M1OverTemp Motore 1 sovratemperatura, M1AlarmLimTemp (31.06)	M1OverTemp Motor 1 sobretemperatura, M1AlarmLimTemp (31.06)	M1OverTemp Moteur 1 échauffement anormal, M1AlarmLimTemp (31.06)
A108	9.06 Bit 7	M1OverLoad Motor 1 calculated overload, M1AlarmLimLoad (31.04)	M1OverLoad Motor 1 berechnete Überlast, M1AlarmLimLoad (31.04)	M1OverLoad Motore 1 sovraccarico, M1AlarmLimLoad (31.04)	M1OverLoad Motor 1 sobrecarga, M1AlarmLimLoad (31.04)	M1OverLoad Moteur 1 surcharge, M1AlarmLimLoad (31.04)
A109	9.06 Bit 8	M2OverTemp Motor 2 measured overtemperature, M2AlarmLimTemp (49.36)	M2OverTemp Motor 2 gemessene Übertemperatur, M2AlarmLimTemp (49.36)	M2OverTemp Motore 2 sovratemperatura, M2AlarmLimTemp (49.36)	M2OverTemp Motor 2 sobretemperatura, M2AlarmLimTemp (49.36)	M2OverTemp Moteur 2 échauffement anormal, M2AlarmLimTemp (49.36)
A110	9.06 Bit 9	M2OverLoad Motor 2 calculated overload, M2AlarmLimLoad (49.33)	M2OverLoad Motor 2 berechnete Überlast, M2AlarmLimLoad (49.33)	M2OverLoad Motore 2 sovraccarico, M2AlarmLimLoad (49.33)	M2OverLoad Motor 2 sobrecarga, M2AlarmLimLoad (49.33)	M2OverLoad Moteur 2 surcharge, M2AlarmLimLoad (49.33)
A111	9.06 Bit 10	MainsLowVolt Mains low (under-) voltage (AC), UnetMin1 (30.22)	MainsLowVolt Netz-Unterspannung (AC), UnetMin1 (30.22)	MainsLowVolt Minima tensione di alimentazione di rete (c.a.), UnetMin1 (30.22)	MainsLowVolt Bajatenion de red (C.A.), UnetMin1 (30.22)	MainsLowVolt Sous-tension réseau (AC), UnetMin1 (30.22)
A112	9.06 Bit 11	P2FanDiffCom Peer to peer respectively master-follower link communication, ComLossCtrl (30.28)	P2FanDiffCom Kommunikation Peer to Peer bzw. Master - Follower Verbindung, ComLossCtrl (30.28)	P2FanDiffCom ComLossCtrl (30.28)	P2FanDiffCom Pérdida en la comunicación punto a punto Maestro Esclavo, ComLossCtrl (30.28)	P2FanDiffCom ComLossCtrl (30.28)
A113	9.06 Bit 12	COM8Com Communication between SDCS-COM-8 and overriding control respectively master-follower link, Ch0ComLossCtrl (70.05), Ch2ComLossCtrl (70.15)	COM8Com Kommunikation zwischen SDCS-COM-8 und überordneter Steuerung bzw. Master-Follower Verbindung, Ch0ComLossCtrl (70.05), Ch2ComLossCtrl (70.15)	COM8Com ComLossCtrl (70.05), Ch2ComLossCtrl (70.15)	COM8Com Pérdida comunicación en el lazo SDCS COM-8, PLC y Maestro Esclavo, Ch0ComLossCtrl (70.05), Ch2ComLossCtrl (70.15)	COM8Com ComLossCtrl (70.05), Ch2ComLossCtrl (70.15)



LED Alarm Word	Text on DCS800 Panel, DriveWindow Light and DriveWindow Definition EN	Text in DCS800 Panel, DriveWindow Light und DriveWindow Beschreibung DE	Testo DCS800 Pannello, DriveWindow Light e DriveWindow Descrizione IT	Texto en el DCS800 Panel, DriveWindow Light y DriveWindow Definición SP	Texte dans la DCS800 Microconsole, DriveWindow Light et DriveWindow Description FR
A114	9.06 Bit 13 Armature current deviation, MotCur (1.06), CurRefUsed (3.12)	Ankerstrom-Abweichung, MotCur (1.06), CurRefUsed (3.12)	Deviazione corrente d'indotto, MotCur (1.06), CurRefUsed (3.12)	Desviación intensidad del inducido, MotCur (1.06), CurRefUsed (3.12)	Écart de courant d'induit, MotCur (1.06), CurRefUsed (3.12)
A115	9.06 Bit 14 TachoRange Selected motor, tacho range, terminals X3:1 to X3:4 on SDCS-CON-4	Ausgewählter Motor, Überschreitung Tachobereich, Klemmen X3:1 bis X3:4 on SDCS-CON-4	TachoRange Fattore di scala vel. fuori range, Diagnosis (9.11)	Rango de la tacho erroneo en los terminales X3:1 a X3:4 de la SDCS-CON-4	TachoRange
A116	9.06 Bit 15 BrakeLongFalling Selected motor, mechanical brake, acknowledge signal is missing	Ausgewählter Motor, mechanische Bremse, Rückmeldesignal fehlt	BrakeLongFalling Fallo eliminado, FaultMask (30.25)	Falta señal de reconocimiento	BrakeLongFalling
A117	9.07 Bit 0 ArmCurRipple Armature current ripple One or several thyristors may carry no current, CurRippleSel (30.18)	Welligkeit Ankerstrom Ein oder mehrere Thyristor(en) führen wahrscheinlich keinen Strom, CurRippleSel (30.18)	ArmCurRipple Ondulazione della corrente d'indotto Uno o più tiristori non conducono corrente, CurRippleSel (30.18)	Freno mecánico Rizado de la corriente de inducido 1 ó varios tiristores no conducen, CurRippleSel (30.18)	ArmCurRipple Ondulation courant d'induit Défaut d'allumage thyristor(s), CurRippleSel (30.18)
A118	9.07 Bit 1 FoundNewApp1 Found new application on Memory Card, ParSave (16.06)	Neue Applikation auf der Memory Card gefunden, ParSave (16.06)	FoundNewApp1 ParSave (16.06)	Nueva aplicación en la Memory Card, ParSave (16.06)	FoundNewApp1 ParSave (16.06)
A119	9.07 Bit 2 AppIDiff Application on drive and Memory Card are different, ParSave (16.06)	Applikationen auf Antrieb und Memory Card sind unterschiedlich, ParSave (16.06)	AppIDiff ParSave (16.06)	Aplicación del drive y de la Memory Card no corresponden, ParSave (16.06)	AppIDiff ParSave (16.06)
A120	9.07 Bit 3 OverVoltProt Overvoltage protection active, OvrVoltProt (10.13)	Überspannungsschutz aktiv, OvrVoltProt (10.13)	OverVoltProt Protezione da sovratensione attiva, OvrVoltProt (10.13)	Protección de sobretensión activa, OvrVoltProt (10.13)	OverVoltProt Protection de surtension est active, OvrVoltProt (10.13)
A121	9.07 Bit 4 AutoTuneFail Autotuning failed, Diagnosis (9.11)	Selbsteinstellung abgebrochen, Diagnosis (9.11)	AutoTuneFail Diagnosis (9.11)	Fallo durante el Autotuning, Diagnosis (9.11)	AutoTuneFail Diagnosis (9.11)
A122	9.07 Bit 5 MechBrake Selected motor, mechanical brake, BrakeFaultFunc (42.06)	MechBrake Ausgewählter Motor, mechanische Bremse, BrakeFaultFunc (42.06)	MechBrake Diagnosis (9.11)	Freno mecánico, BrakeFaultFunc (42.06)	MechBrake Diagnosis (9.11)
A123	9.07 Bit 6 FaultSuppres Fault suppressed, FaultMask (30.25)	Fehler unterdrückt, FaultMask (30.25)	FaultSuppres FaultMask (30.25)	Fallo eliminado, FaultMask (30.25)	FaultSuppres FaultMask (30.25)
A124	9.07 Bit 7 SpeedScale Speed scaling out of range, Diagnosis (9.11)	Drehzahlnormierung außerhalb des erlaubten Bereiches, Diagnosis (9.11)	SpeedScale Fattore di scala vel. fuori range, Diagnosis (9.11)	Escalado interno de revoluciones fuera del rango permitido, Diagnosis (9.11)	SpeedScale Étalonnement de vitesse hors de l'étendue permise, Diagnosis (9.11)
A125	9.07 Bit 8 SpeedFb Selected motor, speed feedback, M1SpeedFbSel (50.03)	Ausgewählter Motor, Drehzahlrückmeldung, M1SpeedFbSel (50.03)	SpeedFb Retroazione (misura) di velocità, M1SpeedFbSel (50.03)	Fallo de realimentación (medición) de velocidad, M1SpeedFbSel (50.03)	SpeedFb Défaut retour vitesse (mesure), M1SpeedFbSel (50.03)
A126	9.07 Bit 9 ExternalDI External alarm via binary input, ExtAlarmSel (30.32)	Externer Alarm am binären Eingang, ExtAlarmSel (30.32)	ExternalDI Allarme esterno su ingresso digitale, ExtAlarmSel (30.32)	ExternalDI Allarme externo en la entrada digital, ExtAlarmSel (30.32)	ExternalDI Allarme extérieur à l'entrée digitale, ExtAlarmSel (30.32)

**Faults & Alarms / Diagnosis**

LED	Alarm	Word	Definition EN	Beschreibung DE	Descrizione IT	Definición SP	Description FR
A127	9.07	Bit 10	Text on DC5800 Panel, DriveWindow Light and DriveWindow	Text in DC5800 Panel, DriveWindow Light und DriveWindow	Testo DC5800 Pannello, DriveWindow Light e DriveWindow	Texto en el DC5800 Panel, DriveWindow Light y DriveWindow	Texte dans la DC5800 Microconsole, DriveWindow Light et DriveWindow
			Definition EN	Beschreibung DE	Descrizione IT	Definición SP	Description FR
A127	9.07	Bit 10	AIRange Analog input range, AI (30.29)	AIRange Unterschreitung Analogeingangsbereich, AI (30.29)	AIRange Mon4mA (30.29)	AIRange Rango de la entrega analógica, AI Mon4mA (30.29)	AIRange Mon4mA (30.29)
A128	9.07	Bit 11	FieldBusCom Fieldbus communication loss, ComLossCtrl (30.28), TimeOut (30.35)	FieldBusCom Kommunikationsfehler Feldbus, ComLossCtrl (30.28), TimeOut (30.35)	FieldBusCom Guasto comunicazione con bus di campo, ComLossCtrl (30.28), TimeOut (30.35)	FieldBusCom Pérdida de comunicación con el bus de campo, ComLossCtrl (30.28), TimeOut (30.35)	FieldBusCom Défaut communication avec bus de terrain, ComLossCtrl (30.28), TimeOut (30.35)
A129	9.07	Bit 12	ParRestored Parameter restored	ParRestored Parameter wiederhergestellt (zurückgespeichert)	ParRestored Ripristino parametri	ParRestored Parámetro restaurado	ParRestored Recupération des paramètres
A130	9.07	Bit 13	LocalCmdLoss Communication fault with panel (X33), DriveWindow (CH3) or DriveWindow Light (X34), LocalLossCtrl (30.27)	LocalCmdLoss Kommunikationsfehler mit Panel (X33), DriveWindow (CH3) oder DriveWindow Light (X34), LocalLossCtrl (30.27)	LocalCmdLoss Guasto comunicazione con panello (X33), DriveWindow (CH3) o DriveWindow Light (X34), LocalLossCtrl (30.27)	LocalCmdLoss Fallo de comunicación con el Panel (X33), DriveWindow (CH3) o DriveWindow Light (X34), LocalLossCtrl (30.27)	LocalCmdLoss Défaut communication avec la micro - console (X33), DriveWindow (CH3) ou DriveWindow Light (X34), LocalLossCtrl (30.27)
A131	9.07	Bit 14	ParAdded Parameter added, Diagnosis (9.11)	ParAdded Parameter hinzugeführt, Diagnosis (9.11)	ParAdded Aggiunta parametri, Diagnosis (9.11)	ParAdded Parámetros añadidos, Diagnosis (9.11)	ParAdded Paramètres ajoutés, Diagnosis (9.11)
A132	9.07	Bit 15	ParConflict Parameter settings conflict, Diagnosis (9.11)	ParConflict Konflikt Parametereinstellung, Diagnosis (9.11)	ParConflict Konflikt Parametri, Diagnosis (9.11)	ParConflict Conflicto en la configuración de los parámetros, Diagnosis (9.11)	ParConflict RetainInv
A133	9.08	Bit 0	RetainInv Retain data invalid, backup data loaded	RetainInv Retaindaten ungültig, Backupdaten wurden geladen	RetainInv RetainInv	RetainInv Datos inválidos	RetainInv
A134	9.08	Bit 1	ParComp Parameter Compatibility, Diagnosis (9.11)	ParComp Parameter Kompatibilität, Diagnosis (9.11)	ParComp Compatibilidad de parámetros, Diagnosis (9.11)	ParComp Compatibilidad de parámetros, Diagnosis (9.11)	ParComp
A135	9.08	Bit 2	ParUPDownLoad Parameter up / download failed, try again	ParUPDownLoad Parameter Up / Download gescheitert, nochmals versuchen	ParUPDownLoad Parameter Up / Download fallido, volver a intentarlo	ParUPDownLoad Fallo durante la Carga/Descarga de parámetros	ParUPDownLoad
A136	9.08	Bit 3	NoAPTTaskTime Adaptive program task time not set, TimeLevSel (83.04)	NoAPTTaskTime Adaptive Program Taskzeit nicht gesetzt, TimeLevSel (83.04)	NoAPTTaskTime TimeLevSel (83.04)	NoAPTTaskTime Programa Adaptativo, TimeLevSel (83.04)	NoAPTTaskTime TimeLevSel (83.04)
A137	9.08	Bit 4	SpeedNotZero Speed not zero, ZeroSpeedLim (20.03)	SpeedNotZero Drehzahl ist ungleich Null, ZeroSpeedLim (20.03)	SpeedNotZero ZeroSpeedLim (20.03)	SpeedNotZero Velocidad diferente a cero, ZeroSpeedLim (20.03)	SpeedNotZero ZeroSpeedLim (20.03)
A138	9.08	Bit 5	Off2FieldBus Off2 (Emergency Off / Coast stop) pending via MainCtrlWord (7.01)	Off2FieldBus Off2 (Notaus / Austrudeln) ist am MainCtrlWord (7.01) aktiv	Off2FieldBus Off2 Configuración Bus de Campo (Emergency Off / Coast stop), MainCtrlWord (7.01)	Off2FieldBus Off2 Configuración Bus de Campo (Emergency Off / Coast stop), MainCtrlWord (7.01)	Off2FieldBus
A139	9.08	Bit 6	Off3FieldBus Off3 (E-stop) pending via MainCtrlWord (7.01)	Off3FieldBus Off3 (Nothalt) ist am MainCtrlWord (7.01) aktiv	Off3FieldBus Off3 Configuración Bus de Campo (E-stop), MainCtrlWord (7.01)	Off3FieldBus Off3 Configuración Bus de Campo (E-stop), MainCtrlWord (7.01)	Off3FieldBus

LED	Alarm	Word	Text on DCS800 Panel, DriveWindow Light and DriveWindow	Definition EN	Text in DCS800 Panel, DriveWindow Light und DriveWindow	Beschreibung DE	Testo DCS800 Pannello, DriveWindow Light e DriveWindow	Descrizione IT	Definición SP	Texto en el DCS800 Panel, DriveWindow Light y DriveWindow	Texte dans la DCS800 Microconsole, DriveWindow Light et DriveWindow	Description FR
A140	9.08	Bit 7	Illegal fieldbus settings, see group 51	Illegal fieldbus settings, see group 51	Illegale Feldbuseinstellung, s. Gruppe 51	Illegale Feldbuseinstellung, s. Gruppe 51	Illegale fieldbus settings, see group 51	Illegale fieldbus settings, see group 51	Illegale fieldbus settings, see group 51	Illegale fieldbus settings, see group 51	Illegale fieldbus settings, see group 51	Illegale fieldbus settings, see group 51
A141	9.08	Bit 8	SDCS-COM-8 firmware version conflict, FirmwareVer (4.01), Com8SwVersion (4.11)	SDCS-COM-8 firmware version conflict, FirmwareVer (4.01), Com8SwVersion (4.11)	SDCS-COM-8 Konflikt Firmwareversion, FirmwareVer (4.01), Com8SwVersion (4.11)	SDCS-COM-8 Konflikt Firmwareversion, FirmwareVer (4.01), Com8SwVersion (4.11)	SDCS-COM-8 firmware version conflict, FirmwareVer (4.01), Com8SwVersion (4.11)	SDCS-COM-8 firmware version conflict, FirmwareVer (4.01), Com8SwVersion (4.11)	SDCS-COM-8 firmware version conflict, FirmwareVer (4.01), Com8SwVersion (4.11)	SDCS-COM-8 firmware version conflict, FirmwareVer (4.01), Com8SwVersion (4.11)	SDCS-COM-8 firmware version conflict, FirmwareVer (4.01), Com8SwVersion (4.11)	SDCS-COM-8 firmware version conflict, FirmwareVer (4.01), Com8SwVersion (4.11)
A142	9.08	Bit 9	Memory Card missing, ParSave (16.06)	Memory Card missing, ParSave (16.06)	Memory Card fehlt, ParSave (16.06)	Memory Card fehlt, ParSave (16.06)	Memory Card missing, ParSave (16.06)	Memory Card missing, ParSave (16.06)	Memory Card missing, ParSave (16.06)	Memory Card missing, ParSave (16.06)	Memory Card missing, ParSave (16.06)	Memory Card missing, ParSave (16.06)
A143	9.08	Bit 10	Memory Card failure, ParSave (16.06)	Memory Card failure, ParSave (16.06)	Fehler Memory Card, ParSave (16.06)	Fehler Memory Card, ParSave (16.06)	Memory Card failure, ParSave (16.06)	Memory Card failure, ParSave (16.06)	Memory Card failure, ParSave (16.06)	Memory Card failure, ParSave (16.06)	Memory Card failure, ParSave (16.06)	Memory Card failure, ParSave (16.06)

# Diagnosis messages • Diagnose • Diagnostic 9.11

Signal	Diagnosis messages Definition EN	Diagnosemeldungen Beschreibung DE	Diagnosis messages Description IT	Diagnosis messages Definition SP	Diagnosis messages Description FR
0	no message Firmware default setting of parameters wrong	keine Meldung Firmware die Grundeinstellung der Parameter ist falsch	nessun messaggio Firmware impostazione errata dei parametri di default	no hay ningún mensaje Firmware ajuste por defecto de parámetros incorrecto	aucun message Firmware erreur pré réglage paramètres
1	parameter flash image too small for all parameters	Parameter-Flash-Image ist für alle Parameter zu klein	parameter /flash image troppo piccola per tutti i parametri	la imagen Flash de los parámetros es demasiado pequeña para todos los parámetros	image flash des paramètres trop petite pour tous les paramètres
3	reserved	reserviert	riservato	reservado	réservé
4	illegal write attempt on a write-protected parameter	???	tentativo di scrittura illecito o parametro protetto alla scrittura	???	???
5	reserved	reserviert	riservato	reservado	réservé
6	wrong type code	falscher Typenschlüssel	tipo codice errato	tipo de código incorrecto	code type erroné
7	an un-initialized interrupted has occurred	Unterbrechung aufgetreten	e avvenuto un interrupt non inizializzato	se ha producido una interrupción no inicializada	interruption non-initialisée
8,9	reserved	reserviert	riservato	reservado	réservé
10	wrong parameter value	falscher Parameterwert	valore parametro errato	valor de parámetro incorrecto	erreur valeur paramètre
11	autotuning aborted by fault or removing the Run command [UsedMCW (7.04) bit 3]	Selbsteinstellung durch Fehler oder Wegnahme des Run-Befehls [UsedMCW (7.04) Bit 3] abgebrochen	<b>Autotatura:</b> autotatura bloccata da un guasto o dalla rimozione del comando RUN [UsedMCW (7.04) bit 3]	<b>Autoajuste</b> autoajuste cancelado por fallo o al cancelar el comando Run [UsedMCW (7.04), bit 3]	<b>Autocalibrage</b> échec autocalibrage en raison d'un défaut ou de la disparition de la commande Marche [MCPUtilisé (7.04) bit 3]
12	autotuning timeout, RUN command [UsedMCW (7.04) bit 3] is not set in time	Selbsteinstellung Zeitüberschreitung, Run-Befehl [UsedMCW (7.04) Bit 3] wurde nicht rechtzeitig gesetzt	tempo di autotatura scaduto, comando di RUN non è attivato in tempo [UsedMCW (7.04) bit 3]	final de espera de autoajuste, no se ha ajustado el tiempo del comando RUN [UsedMCW (7.04), bit 3]	expiration du délai d'autocalibrage, la commande Marche [MCPUtilisé (7.04) bit 3] n'a pas été donnée à temps.
13	motor is still turning, no speed zero indication	Motor dreht, keine Null Drehzahlanzeige	il motore sta ancora girando, nessuna indicazione di velocità zero	el motor continúa girando y no hay indicación de velocidad cero	le moteur encore en rotation, aucune indication de vitesse nulle
14	armature current not zero	Feldstrom nicht Null	corrente di campo non a zero	la intensidad de campo no es cero	courant d'excitation non nul
15	armature voltage measurement circuit open (e.g. not connected) or interrupted	Ankerspannungsmesskreis offen (z.B. nicht angeschlossen) oder unterbrochen, auch die Strom- und Drehmomentgrenzen prüfen	circuito di misura della tensione d'armatura aperto (es. non collegato) o interrotto, controllare anche i limiti di corrente e di coppia	la intensidad de inducido no es cero	ouverture du circuit de mesure de la tension d'induit (ex., pas connecté) ou interrompu
16	check also current and torque limits			límites de intensidad y par	Vérifier également les limites de courant et de couple
17	armature circuit and/or armature voltage measurement circuit wrongly connected	Ankerstromkreis und/oder Ankerspannungsmesskreis falsch angeschlossen	collegamento errato del circuito d'armatura e/o del circuito di misura della tensione d'armatura	conexión incorrecta del circuito de inducido o el circuito de medición de la tensión de inducido	erreur connexion circuit d'induit et/ou circuit de mesure de la tension d'induit
18	no load connected to armature circuit	keine Last an den Ankerstromkreis	nessun carico collegato al circuito d'armatura	no hay ninguna carga conectada al circuito de inducido	aucune charge connectée au circuit d'induit
19	invalid nominal armature current setting; armature current M1MotNomCur (99.03) is set to zero	ungültige Einstellung des Nennankerstroms; Ankerstrom M1MotNomCur (99.03) ist auf Null eingestellt	impostazione non valida della corrente nominale d'armatura; corrente armatura M1MotNom (99,03) è impostata a zero	ajuste incorrecto de la intensidad de inducido nominal; la intensidad de inducido M1MotNomCur (99.03) se ajusta a cero	erreur réglage courant d'induit nominal ; courant d'induit M1MotNomCur (99.03) réglé sur zéro
20	field current does not decrease when the excitation is switched off	Feldstrom verringert sich nicht, wenn die Erregung ausgeschaltet ist	La corrente di campo non diminuisce quando l'eccitazione viene disattivata	la intensidad de campo no disminuye al desconectar la excitación	le courant d'excitation ne diminue pas à la mise hors tension de l'excitation
21	field current actual doesn't reach field current reference; no detection of field resistance; field circuit open (e.g. not connected) respectively interrupted	Feldstromsollwert; keine Erkennung des Feldwiderstands; Feldstromkreis offen (z.B. nicht angeschlossen) bzw. unterbrochen	valore di riferimento dato; nessun rilevamento della resistenza di campo; circuito di campo aperto (es. non collegato) oppure interrotto	la intensidad actual del campo no alcanza la referencia de intensidad de campo; no se detecta resistencia de campo; circuito de campo abierto (desconectado) o interrumpido	le courant réel d'excitation n'atteint pas la référence du courant d'excitation, aucune résistance d'excitation détectée; ouverture circuit d'excitation (ex., pas connecté) ou interrompu
22	no writing of control parameters of speed controller	die Parameter des Drehzahlreglers werden nicht geschrieben	nessuna scrittura dei parametri di controllo del regolatore di velocità	no se ha escrito ningún parámetro de control del regulador de velocidad	pas d'écriture de paramètres de commande du régulateur de vitesse

Signal	Diagnosis messages Definition	Diagnosemeldungen Beschreibung	Diagnosis messages Descrizione	Diagnosis messages Definición	Diagnosis messages Description
9.11	EN	DE	IT	SP	FR
23	tacho adjustment faulty or not OK or the tacho voltage is too high during autotuning	Tachoeinstellung falsch oder nicht in Ordnung	Adattamento tacho difettoso o non OK o la tensione della tacho è troppo alta durante l'autotattatura	ajuste del tacómetro incorrecto o fallido	erreur de réglage ou défaut dynamo tachymétrique
24	tuning of speed controller not possible due to speed limitation	die Abstimmung des Drehzahlreglers ist aufgrund der Drehzahlbegrenzung nicht möglich	non è possibile la taratura del regolatore di velocità a causa del limite di velocità	no es posible ajustar el regulador de velocidad debido a la limitación de velocidad	calibrage régulateur de vitesse impossible en raison des limites de vitesse
25	tuning of speed controller not possible due to voltage limitation	die Abstimmung des Drehzahlreglers ist aufgrund der Spannungsbegrenzung nicht möglich	non è possibile la taratura del regolatore di velocità a causa del limite di tensione	no es posible ajustar el regulador de tensión debido a la limitación de tensión	calibrage régulateur de vitesse impossible en raison des limites de tension
26	field weakening not allowed, see M1SpeedFbSel (50.03) and FidCtrlMode (44.01)	Feldschwächung nicht zulässig, siehe M1SpeedFbSel (50.03) und FidCtrlMode (44.01)	Indebolimento campo non permesso, vedi: M1SpeedFbSel (50.03) e FidCtrlMode (44.01)	no es posible el debilitamiento del campo; véase M1SpeedFbSel (50.03) y FidCtrlMode (44.01)	défluxage interdit, cf. <i>SéMesureVitesseM1 (50.03)</i> et <i>ModeReguleExcitat (44.01)</i>
27...30	reserved	reserviert	riservato	reservado	réservé
30	DCS800 Control Panel up- or download not started	DCS800-Steuertafel Hoch- oder Runterlesen nicht gestartet	DCS800 Control Panel up- o download non partito	no se ha iniciado la carga o descarga desde el panel de control del DCS800	chargement en lecture ou écriture micro-console DCS800 non démarré
32	DCS800 Control Panel data not up- or downloaded in time	DCS800-Steuertafel Daten werden nicht rechtzeitig Hoch- oder Runtergelesen	DCS800 Control Panel dati up- o downloadado non in tempo	DCS800 no se han cargado o descargado a tiempo	chargement en lecture ou écriture micro-console DCS800 non effectué à temps
33	reserved	reserviert	riservato	reservado	réservé
34	DCS800 Control Panel up- or download checksum faulty	Hoch- oder Runterlesen der DCS800-Steuertafel Prüfsummenfehler	DCS800 Control Panel up- o download controllo di parità difettoso	fallo de la suma de comprobación de la carga o descarga en el panel de control del DCS800	erreur du total de contrôle chargement en lecture ou écriture micro-console DCS800
35	DCS800 Control Panel up- or download software faulty	Hoch- oder Runterlesen der DCS800-Steuertafel Software fehlerhaft	DCS800 Control Panel up- o download software difettoso	fallo del software de carga o descarga en el panel de control del DCS800	erreur du logiciel chargement en lecture ou écriture micro-console DCS800
36	DCS800 Control Panel up- or download verification failed	Hoch- oder Runterlesen der DCS800-Steuertafel Verifizierung misslungen	DCS800 Control Panel up- or download verifica fallita	fallo de la verificación de la carga o descarga en el panel de control del DCS800	echec verification chargement en lecture ou écriture micro-console DCS800
37...49	reserved	reserviert	riservato	reservado	réservé
50	parameter flash faulty (erase)	Parameter Flash fehlerhaft (löschen)	flash parametri difettosa (cancellata)	Hardware	Materiel
51	parameter flash faulty (program)	Parameter Flash fehlerhaft (Programm)	flash parametri difettosa (programma)	Hardware	Materiel
52...69	reserved	reserviert	riservato	reservado	réservé
70	A132 ParConflict (alarm parameter setting conflict);	Konflikt:	A132 ParConflict (conflitto impostazione parametro allarme);	conflicto en el ajuste de los parámetros de alarma;	A132 ConflitParam (alarme de conflit de réglages de paramètres);
71	flux linearization parameters not consistent	Parameter für die Flusslinearisierung nicht konsistent	parametri di linearizzazione flusso non coerenti	parámetros de linealización de flujo contradictorios	incohérence paramètres de flux de linéarisation
72	reserved	reserviert	riservato	reservado	réservé
73	armature data not consistent [e.g. TypeCode (97.01) = None and S ConvScaleVolt (97.03) is not set properly or ConvNomVolt (4.04) = 0]	Parameterüberlauf	Dati armatura non coerenti [es. TypeCode (97.01) = Nessuno e S ConvScaleVolt (97.03) non è impostato correttamente o ConvNomVolt (4.04) = 0]	desbordamiento de parámetros	valeur paramètres hors limites
74...79	reserved	reserviert	riservato	reservado	réservé
80	Autotuning speed does not reach setpoint (EMF control)	Selfteststellung Drehzahl erreicht nicht den Sollwert (EMK-Regelung)	Autotattura: la velocità non raggiunge il setpoint (controllo EMF)	Autoajuste la velocidad no alcanza el punto de consigna (control EMF)	Autocalibrage la vitesse n'atteint pas la consigne (régulation FEM)
81	motor is not accelerating or wrong tacho polarity (tacho / encoder)	Motor beschleunigt nicht oder falsche Tachopolarität (Tacho / Impulsgeber)	Il motore non sta accelerando o la polarità tacho è sbagliata (tacho/encoder)	el motor no acelera o la polaridad del tacómetro es incorrecta (tacómetro/generador de pulsos)	polarité dynamo tachymétrique (dynamo tachymétrique/codeur)
82	not enough load (too low inertia) for the detection of speed controller parameters	unzureichende Last (Trägheitsmoment zu gering) für die Erkennung der Drehzahlreglerparameter	Carico non sufficiente (inerzia troppo bassa) per rilevare i parametri del regolatore di velocità	no hay suficiente carga (inercia demasiado baja) para la detección de los parámetros del regulador de velocidad	charge insuffisante (inertie trop faible) pour détecter les paramètres du régulateur de vitesse
83...89	reserved	reserviert	riservato	reservado	réservé
90	Thyristor diagnosis	Thyristordiagnose	Diagnosi Thyristor	Diagnostico del tristor	Diagnostic des thyristors
91	shortcut caused by V1	Kurzschluss verursacht durch V1	cortocircuito causato da V1	cortocircuito causado por V1	court-circuit provoqué par V1
92	shortcut caused by V2	Kurzschluss verursacht durch V2	cortocircuito causato da V2	cortocircuito causado por V2	court-circuit provoqué par V2
93	shortcut caused by V3	Kurzschluss verursacht durch V3	cortocircuito causato da V3	cortocircuito causado por V3	court-circuit provoqué par V3

Faults & Alarms / Diagnosis


Signal	Diagnosis messages Definition	Diagnosemeldungen Beschreibung	Diagnosis messages Descrizione	Diagnosis messages Definición	Diagnosis messages Description
93	shortcut caused by V4	Kurzschluss verursacht durch V4	cortocircuito causado da V4	cortocircuito causado por V4	court-circuit provoqué par V4
94	shortcut caused by V5	Kurzschluss verursacht durch V5	cortocircuito causado da V5	cortocircuito causado por V5	court-circuit provoqué par V5
95	shortcut caused by V6	Kurzschluss verursacht durch V6	cortocircuito causado da V6	cortocircuito causado por V6	court-circuit provoqué par V6
96	thyristor block test failed	Thyristorblockiertest misslungen	test blocco thyristor fallito	prueba del bloque de tiristores fallida	défaut test bloc thyristors
97	shortcut caused by V15 or V22	Kurzschluss verursacht durch V15 oder V22	cortocircuito causado da V15 o V22	cortocircuito causado por V15 o V22	court-circuit provoqué par V15 ou V22
98	shortcut caused by V16 or V23	Kurzschluss verursacht durch V16 oder V23	cortocircuito causado da V16 o V23	cortocircuito causado por V16 o V23	court-circuit provoqué par V16 ou V23
99	shortcut caused by V11 or V24	Kurzschluss verursacht durch V11 oder V24	cortocircuito causado da V11 o V24	cortocircuito causado por V11 o V24	court-circuit provoqué par V11 ou V24
100	shortcut caused by V12 or V25	Kurzschluss verursacht durch V12 oder V25	cortocircuito causado da V12 o V25	cortocircuito causado por V12 o V25	court-circuit provoqué par V12 ou V25
101	shortcut caused by V13 or V26	Kurzschluss verursacht durch V13 oder V26	cortocircuito causado da V13 o V26	cortocircuito causado por V13 o V26	court-circuit provoqué par V13 ou V26
102	shortcut caused by V14 or V21	Kurzschluss verursacht durch V14 oder V21	cortocircuito causado da V14 o V21	cortocircuito causado por V14 o V21	court-circuit provoqué par V14 ou V21
103	motor connected to ground	Motor an Masse kurzgeschlossen	motore collegato a terra	motor conectado a tierra	moteur raccordé à la terre
104	armature winding is not connected	Ankerwicklung ist nicht angeschlossen	avvolgimento d'armatura non collegato	el bobinado de inducido no está conectado	enroulement d'induit non raccordé
105...120	reserved	reserviert	riservato	reservado	réservé
121	AI monitoring	AI Überwachung	controllo AI	Monitorización de EA	Surveillance Entrée analogique (EA)
122	AI1 below 4 mA	AI1 unter 4 mA	AI1 inferiore a 4 mA	EA1 inferior a 4 mA	EA1 inférieure à 4 mA
123	AI2 below 4 mA	AI2 unter 4 mA	AI2 inferiore a 4 mA	EA2 inferior a 4 mA	EA2 inférieure à 4 mA
124	AI3 below 4 mA	AI3 unter 4 mA	AI3 inferiore a 4 mA	EA3 inferior a 4 mA	EA3 inférieure à 4 mA
125	AI4 below 4 mA	AI4 unter 4 mA	AI4 inferiore a 4 mA	EA4 inferior a 4 mA	EA4 inférieure à 4 mA
126	AI5 below 4 mA	AI5 unter 4 mA	AI5 inferiore a 4 mA	EA5 inferior a 4 mA	EA5 inférieure à 4 mA
127	AI6 below 4 mA	AI6 unter 4 mA	AI6 inferiore a 4 mA	EA6 inferior a 4 mA	EA6 inférieure à 4 mA
128...149	reserved	reserviert	riservato	AI7AC inferior a 4 mA	EA7AC inférieure à 4 mA
150	Option modules	Optionsmodule	Moduli opzionali:	Modulos opcionales	Modules optionnels
151	fieldbus module missing see <i>CommModule (98.02)</i>	Fieldbusmodul fehlt siehe <i>CommModule (98.02)</i>	modulo fieldbus mancante vedere <i>CommModule (98.02)</i>	modulo de bus de campo ausente; véase <i>CommModule (98.02)</i>	coupleur réseau absent cf. <i>ModuleCommunic (98.02)</i>
152	SDCS-COM-8 for DDCS- respectively fieldbus communication missing see <i>CommModule (98.02)</i>	SDCS-COM-8 für DDCS- bzw. Feldbuskommunikation fehlt, siehe <i>CommModule (98.02)</i>	SDCS-COM-8 per DDCS- persa comunicazione del rispettivo fieldbus vedi <i>CommModule (98.02)</i>	SDCS-COM-8 para la comunicación maestro-esclavo ausente; véase el grupo 70	SDCS-COM-8 pour communication Maître/esclave absente, cf. groupe 70
153	reserved	reserviert	riservato	reservado	réservé
154	RMBA-xx module missing see group 98	RMBA-xx Modul fehlt, siehe Gruppe 98	modulo RMBA-xx mancante vedi gruppo 98	modulo RMBA-xx ausente; véase el grupo 98	module RMBA-xx absent, cf. groupe 98
155	RAIO-xx in option slot on SDCS-CON-4 missing see group 98	RAIO-xx in Optionssteckplatz auf SDCS-CON-4 fehlt, siehe Gruppe 98	RAIO-xx mancante nello slot sulla SDCS-CON-4 vedi gruppo 98	RAIO-xx ausente en la ranura de módulos opcionales de SDCS-CON-4; véase el grupo 98	RAIO-xx absent dans support pour option de la SDCS-CON-4, cf. groupe 98
156	RAIO-xx in option slot on AIMA missing see group 98	RAIO-xx in Optionssteckplatz auf AIMA fehlt, siehe Gruppe 98	RAIO-xx mancante nello slot sulla AIMA vedi gruppo 98	RAIO-xx ausente en la ranura de módulos opcionales de AIMA; véase el grupo 98	RAIO-xx absent dans support pour option de la carte AIMA, cf. groupe 98
157	RDIO-xx in option slot on SDCS-CON-4 missing see group 98	RDIO-xx in Optionssteckplatz auf SDCS-CON-4 fehlt, siehe Gruppe 98	RDIO-xx mancante nello slot sulla SDCS-CON-4 vedi gruppo 98	RDIO-xx ausente en la ranura de módulos opcionales de SDCS-CON-4; véase el grupo 98	RDIO-xx absent dans support pour option de la SDCS-CON-4, cf. groupe 98
158	RDIO-xx in option slot on AIMA missing see group 98	RDIO-xx in Optionssteckplatz auf AIMA fehlt, siehe Gruppe 98	RDIO-xx mancante nello slot sulla AIMA vedi gruppo 98	RDIO-xx ausente en la ranura de módulos opcionales de AIMA; véase el grupo 98	RDIO-xx absent dans support pour option de la carte AIMA, cf. groupe 98
159	RTAC-xx in option slot on SDCS-CON-4 missing see group 98	RTAC-xx in Optionssteckplatz auf SDCS-CON-4 fehlt, siehe Gruppe 98	RTAC-xx mancante nello slot sulla SDCS-CON-4 vedi gruppo 98	RTAC-xx ausente en la ranura de módulos opcionales de SDCS-CON-4; véase el grupo 98	RTAC-xx absent dans support pour option de la SDCS-CON-4, cf. groupe 98
160	RTAC-xx in option slot on AIMA missing see group 98	RTAC-xx in Optionssteckplatz auf AIMA fehlt, siehe Gruppe 98	RTAC-xx mancante nello slot sulla AIMA vedi gruppo 98	RTAC-xx ausente en la ranura de módulos opcionales de AIMA; véase el grupo 98	RTAC-xx absent sur un support de la carte AIMA, cf. groupe 98
161	reserved	reserviert	riservato	reservado	réservé

Signal	Diagnosis messages Definition	Diagnosemeldungen Beschreibung	Diagnosis messages Descrizione	Diagnosis messages Definición	Diagnosis messages Description
9.11	EN	DE	IT	SP	FR
162	SDCS-IOB-2x respectively SDCS-IOB-3 connection does not match selection in IO BoardConfig (98.15)	SDCS-IOB2x bzw. SDCS-IOB-3 Anschluss entspricht nicht der Auswahl in IO BoardConfig (98.15)	SDCS-IOB-2x e rispettiva connessione SDCS-IOB-3 non si accordano alla selezione nel IO BoardConfig (98.15)	la conexión de SDCS-IOB2x o SDCS-IOB-3 no concuerda con la selección de IO BoardConfig (98.15)	le raccordement de la carte SDCS-IOB2x ou SDCS-IOB-3 ne correspond pas à la sélection faite au paramètre ConfigCarte F/S (98.15)
163	SDCS-DSL-4 missing see group 94 (needed for DCSLink)	SDCS-DSL-4 fehlt, siehe Gruppe 94 (für DCSLink benötigt)	SDCS-DSL-4 mancante vedi gruppo 94 (necessaria per DCSLink)	SDCS-DSL-4 ausente; véase el grupo 94 (necesario para DCSLink)	SDCS-DSL-4 absente, cf. groupe 94 (requisie pour DCSLink)
164	SDCS-DSL-4 missing see group 94 (needed for Modbus)	SDCS-DSL-4 fehlt, siehe Gruppe 94 (für Modbus benötigt)	SDCS-DSL-4 mancante vedi gruppo 94 (necessaria per Modbus)	SDCS-DSL-4 ausente; véase el grupo 94 (necesario para Modbus)	SDCS-DSL-4 absente, cf. groupe 94 (requisie pour Modbus)
	A134 ParComp (alarm parameter compatibility conflict):	A134 ParComp (Alarm Parameter-Kompatibilität):	A134 ParComp (allarme per conflitto di compatibilità parametro)	A134 ParComp (conflicto de compatibilidad de los parámetros de alarma):	A134 CompatiPara (alarme conflit compatibilité paramètres):
10000...	the parameter with the compatibility conflict can be identified by means of the last 4 digits	der Parameter mit dem Kompatibilitätskonflikt kann anhand der letzten vier Ziffern ermittelt werden	Il parametro con conflitto di compatibilità può essere identificato per mezzo degli ultimi 4 digits	el parámetro que presenta el conflicto de compatibilidad puede identificarse mediante sus últimas cuatro cifras	le paramètre à l'origine du conflit est identifié par les 4 derniers chiffres.
30000	Thyristor diagnosis	Thyristordiagnose	Diagnosti Thyristor	Diagnostico del tiristor	Diagnostic thyristors
31x0d	possibly trigger pulse channels are mixed up	eventuell sind die Zündimpulskanäle vertauscht	possibilità che siano scambiati i canali che danno l'impulso di trigger	es posible que los canales del pulso de activación no sean los correctos	commande d'impulsions éventuellement inversées
32x0d	V1 or V12 not conducting	V1 oder V12 leitet nicht	V1 o V12 non sta conducendo	V1 o V12 han cesado de conducir	V1 ou V12 non conducteur
33x0d	V2 or V13 not conducting	V2 oder V13 leitet nicht	V2 o V13 non sta conducendo	V2 o V13 han cesado de conducir	V2 ou V13 non conducteur
34x0d	V3 or V14 not conducting	V3 oder V14 leitet nicht	V3 o V14 non sta conducendo	V3 o V14 han cesado de conducir	V3 ou V14 non conducteur
35x0d	V4 or V15 not conducting	V4 oder V15 leitet nicht	V4 o V15 non sta conducendo	V4 o V15 han cesado de conducir	V4 ou V15 non conducteur
36x0d	V5 or V16 not conducting	V5 oder V16 leitet nicht	V5 o V16 non sta conducendo	V5 o V16 han cesado de conducir	V5 ou V16 non conducteur
	x = 0: only a single thyristor in bridge 1	x = 0: nur ein einzelner Thyristor in Brücke 1	x = 0: un solo thyristor nel ponte 1	x = 0: solamente un tiristor del puente	x = 0 : seul un thyristor du pont 1 n'est pas conducteur (par ex., 320dd = V2 ou V12 non conducteur)
	is not conducting (e.g. 320dd means V2 respectively V12 is not conducting)	in Brücke 1 leitet nicht (z.B. 320dd bedeutet, dass V2 bzw. V12 nicht leiten)	conduce (es. 320dd significa che V2 o rispettivamente V12 non conduce)	1 ha cesado de conducir (p. ej. 320dd significa que V2 o V12 han dejado de conducir)	pas conducteur (par ex., 320dd = V2 ou V12 non conducteur)
	x = 1 ... 6: additionally a second thyristor in bridge 1 is no conducting (e.g. 325dd means V2 and V5 respectively V12 and V15 are not conducting)	x = 1 ... 6: darüber hinaus leitet ein zweiter Thyristor in Brücke 1 nicht (z.B. 325dd bedeutet, dass V2 und V5 bzw. V12 und V15 nicht leiten)	x = 1 ... 6: in aggiunta un secondo thyristor nel ponte 1 non conduce (es. 325dd significa che V2 e V5 o rispettivamente V12 e V15 non conducono)	x = 1 ... 6: adicionalmente, un segundo tiristor del puente 1 ha cesado de conducir (p. ej. 325dd significa que V2 y V5 o bien V12 y V15 han dejado de conducir)	x = 1 ... 6 : un second thyristor du pont 1 n'est pas conducteur (par ex., 325dd = V2 et V5 ou V12 et V15 non conducteurs)
	dd = don't care, the numbers of this digits do not carry any information about the thyristors of the first bridge.	dd = don't care, diese Ziffern enthalten keine Informationen über die Thyristoren der ersten Brücke.	dd = non considerare, i numeri di questi digits non portano alcuna informazione circa i thyristors del primo ponte.	dd = carecen de importancia. Estos números no aportan ninguna información sobre los tiristores del primer puente.	dd = sans importance, ces chiffres ne contiennent aucune information sur les thyristors du premier pont.
	Example: 36030: means V16 in bridge 1 and V23 in bridge 2 are not conducting	Beispiel: 36030: bedeutet, dass V16 in Brücke 1 und V23 in Brücke 2 nicht leiten	esempio: 36030: significa V16 nel ponte 1 e V23 nel ponte 2 non conducono	Ejemplo: 36030: significa que V16, en el puente 1, y V23, en el puente 2, ya no conducen	Exemple : 36030= V16 (pont 1) et V23 (pont 2) non conducteurs
3dd1v	V21 not conducting	V21 leitet nicht	V21 non sta conducendo	V21 ha cesado de conducir	V21 non conducteur
3dd2v	V22 not conducting	V22 leitet nicht	V22 non sta conducendo	V22 ha cesado de conducir	V22 non conducteur
3dd3v	V23 not conducting	V23 leitet nicht	V23 non sta conducendo	V23 ha cesado de conducir	V23 non conducteur
3dd4v	V24 not conducting	V24 leitet nicht	V24 non sta conducendo	V24 ha cesado de conducir	V24 non conducteur
3dd5v	V25 not conducting	V25 leitet nicht	V25 non sta conducendo	V25 ha cesado de conducir	V25 non conducteur
3dd6v	V26 not conducting	V26 leitet nicht	V26 non sta conducendo	V26 ha cesado de conducir	V26 non conducteur


Signal	Diagnosis messages Definition	Diagnosemeldungen Beschreibung	Diagnosis messages Descrizione	Diagnosis messages Definición	Diagnosis messages Description
9.11	<b>EN</b> Y = 0: only a single thyristor in bridge 2 is not conducting (e.g. 3dd0020 means V22 is not conducting) Y = 1 ... 6: additionally a second thyristor in bridge 2 is no conducting (e.g. 3dd25 means V22 and V25 are not conducting) dd = don't care, the numbers of this digits do not carry any information about the thyristors of the second bridge. Example: 36030: means V16 in bridge 1 and V23 in bridge 2 are not conducting	<b>DE</b> Y = 0: nur ein einzelner Thyristor in Brücke 2 leitet nicht (z.B. 3dd0020 bedeutet, dass V22 nicht leitet) Y = 1 ... 6: darüber hinaus leitet ein zweiter Thyristor in Brücke 2 nicht (z.B. 3dd25 bedeutet, dass V22 und V25 nicht leiten) dd = don't care, diese Ziffern enthalten keine Informationen über die Thyristoren der ersten Brücke. Beispiel: 36030: bedeutet, dass V16 in Brücke 1 und V23 in Brücke 2 nicht leiten	<b>IT</b> Y = 0: un solo thyristor nel ponte 2 non conduce (es. 3dd0020 significa che V22 non conduce) Y = 1 ... 6: in aggiunta un secondo thyristor nel ponte 2 non conduce (es. 3dd25 significa che V22 e V25 non conducono) dd = non considerare, i numeri di questi digits non portano alcuna informazione circa i thyristors del secondo ponte. esempio: 36030: significa V16 nel ponte 1 e V23 nel ponte 2 non conducono	<b>SP</b> Y = 0: solamente un tiristor del puente 2 ha cesado de conducir (p. ej. 3dd0020 significa que V22 ha dejado de conducir) Y = 1 ... 6: adicionalmente, un segundo tiristor del puente 2 ha cesado de conducir (p. ej. 3dd25 significa que V22 y V25 han dejado de conducir) dd = carecen de importancia. Estos números no aportan ninguna información sobre los tiristores del segundo puente. Ejemplo: 36030: significa que V16, en el puente 1, y V23, en el puente 2, ya no conducen de velocidad).	<b>FR</b> Y = 0 : seul un thyristor du pont 2 n'est pas conducteur (par ex., 3dd0020 = V22 non conducteur) Y = 1 ... 6 : un second thyristor du pont 2 n'est pas conducteur (par ex., 3dd25 = V22 et V25 non conducteurs) dd = sans importance, ces chiffres ne contiennent aucune information sur les thyristors du second pont. Exemple : 36030= V16 (pont 1) et V23 (pont 2) non conducteurs
40000 ... 49999	<b>A124 SpeedScale</b> (alarm speed scaling): the parameter with the speed scaling conflict can be identified by means of the last 4 digits	<b>A124 SpeedScale</b> (Alarm Drehzahlnormierung): der Parameter mit dem Konflikt in der Drehzahlnormierung kann anhand der letzten vier Ziffern ermittelt werden	<b>A124 SpeedScale</b> (allarme scalatura velocità): il parametro con conflitto scalatura velocità può essere identificato per mezzo degli ultimi 4 digits	<b>A124 SpeedScale</b> (alarma del escalado de velocidad): el parámetro que presenta el conflicto de escalado de velocidad puede identificarse mediante sus últimas cuatro cifras	<b>A124 ErrFormatVlt</b> (alarma échelle de vitesse): le paramètre à l'origine du conflit est identifié par les 4 derniers chiffres.
50000 ... 59999	<b>F549 ParComp</b> (fault parameter compatibility conflict): the parameter with the compatibility conflict can be identified by means of the last 4 digits	<b>F549 ParComp</b> (Fehler Parameter Kompatibilität): Kompatibilitätskonflikt kann anhand der letzten vier Ziffern ermittelt werden	<b>F549 ParComp</b> (guasto per incompatibilità parametro): il parametro con conflitti di compatibilità può essere identificato per mezzo degli ultimi 4 digit	<b>F549 ParComp</b> (fallo de conflicto de compatibilidad de parámetros): el parámetro que presenta el conflicto de compatibilidad puede identificarse mediante sus últimas cuatro cifras	<b>F549 CompatibPara</b> (défaut conflit compatibilité paramètres): le paramètre à l'origine du conflit est identifié par les 4 derniers chiffres.
	<b>F545 ApplLoadFail</b> (ControlBuilder DCS800 application programming): task not configured attempt to run an illegal copy of a protected program retain data invalid caused by SDCS-CON-4 hardware problem	<b>F545 ApplLoadFail</b> (ControlBuilder DCS800 Applikationsprogrammierung): Zykluszeit nicht konfiguriert Versuch, eine illegale Kopie eines geschützten Programms auszuführen gesicherte Daten auf der SDCS-CON-4 sind durch ein Hardwareproblem ungültig	<b>F545 ApplLoadFail</b> (programma applicativo Control Builder DCS800): task non configurata tentativo di attivare una copia illegale di un programma protetto dati non validi trattenuti a causa di problema ardware della SDCS-CON-4	<b>F545 ApplLoadFail</b> (programación de aplicaciones para el DCS800 con ControlBuilder): tarea no configurada se ha intentado ejecutar una copia ilegal de un programa protegido se conservan los datos no válidos causados por el problema de hardware de SDCS-CON-4	<b>F545 DéfChargAppl</b> (programme d'application ControlBuilder DCS800): tâche non configurée tentative d'exécution d'une copie interdite d'un programme protégé copie de données erronée en raison d'un problème matériel de la carte SDCS-CON-4
64125	5 ms task halted (e.g. task contains an endless loop)	5 ms Zykluszeit angehalten (z.B. Zykluszeit enthält eine Endlosschleife)	task 5 ms bloccata (es. la task contiene un endless loop)	tarea de 5 ms detenida (p. ej. la tarea contiene un bucle infinito)	tâche arrêtée pendant 5 ms (ex., la tâche comporte une boucle infinie)
64126	20 ms task halted (e.g. task contains an endless loop)	20 ms Zykluszeit angehalten (z.B. Zykluszeit enthält eine Endlosschleife)	task 20 ms bloccata (es. la task contiene un endless loop)	tarea de 20 ms detenida (p. ej. la tarea contiene un bucle infinito)	tâche arrêtée pendant 20 ms (ex., la tâche comporte une boucle infinie)
64127	100 ms task halted (e.g. task contains an endless loop)	100 ms Zykluszeit angehalten (z.B. Zykluszeit enthält eine Endlosschleife)	task 100 ms bloccata (es. la task contiene un endless loop)	tarea de 100 ms detenida (p. ej. la tarea contiene un bucle infinito)	tâche arrêtée pendant 100 ms (ex., la tâche comporte une boucle infinie)
64128	500 ms task halted (e.g. task contains an endless loop)	500 ms Zykluszeit angehalten (z.B. Zykluszeit enthält eine Endlosschleife)	task 500 ms bloccata (es. la task contiene un endless loop)	tarea de 500 ms detenida (p. ej. la tarea contiene un bucle infinito)	tâche arrêtée pendant 500 ms (ex., la tâche comporte une boucle infinie)



# Macro & Firmware structure / Makro & Firmware Struktur / Struttura macro & firmware / Estructura del macro & firmware / Structure du logiciel macro & système



## Standard




**[DCS800Wizard] 2. Macro assistant**

Set general parameter  
 9908 Application macro **2WireDCcontUS**

Description of selected macro:  
 - STANDARD macro + DC contactor  
 - Drive is controlled by local I/O  
 - D17 for ON/OFF and D18 for START/STOP (2 wire)  
 - Speed reference is connected to SpeedRef AI-1  
 - DC contactor [US] via D0-8 (K39)  
 - JOG1=D1-1, JOG2=D1-2, ExtFault=D1-3  
 - D15 for E-stop not, RESET=D1-6

# 2-wireDCcontUS




**[DCS800Wizard] 2. Macro assistant**

Set general parameter:  
 9908 Application macro: **3WireDCcontUS**

Description of selected macro:  
 - STANDARD macro + DC contactor + (3 wire cont)  
 - Drive is controlled by local I/O  
 - ON/start pulse DI-7 and OFF/stop pulse (NC) DI-8  
 - Speed reference is connected to SpeedRef AI-1  
 - DC contactor (US) via DO-8 (X39)  
 - Jog1=DI-1, Jog2=DI-2, ExtFault=DI-3  
 - DI5 for E-stop not, RESET=DI-6

# 3-wireDCcont US




**[DCS800Wizard] 2. Macro assistant**

Set general parameter  
 9908 Application macro **3WireStandard**

Description of selected macro:  
 "" STANDARD macro + 3 wire control  
 - Drive is controlled by local I/O  
 - ON/start pulse DI-7 and OFF/ stop pulse (NC) DI-8  
 - DN/start pulse DI-7 and OFF/ stop pulse (NC) DI-8  
 - Speed reference is connected to SpeedRef AI-1  
 - Main contactor via DO-8 (x99)  
 - JDI1=DI-1, JDI2=DI-2, ExtFault=DI-3  
 - DI5 for E-stop not, RESET=DI-6

# 3-wire Standard




**[DCS800Wizard] 2. Macro assistant**

Set general parameter  
 9908 Application macro **TorqLimit**

Description of selected macro:  
 - S1 ANDAHD macro + torque limit = AI-2  
 - Drive is controlled by local I/O  
 - D17 for ON/OFF and D18 for START/STOP  
 - Speed reference is connected to SpeedRef AI-1  
 - Main contactor via DO-8 (X39)  
 - JOG1=D1-1, JOG2=D1-2, ExtFault=D1-3  
 - D1-5 for E-stop not, RESET=D1-6

# Torquelimit





**[DCS800Wizard] 2. Macro assistant**

Set general parameter  
 9908 Application macro **Man/Const**


Description of selected macro:  
 - Manual / constant speed [ motor pot ] macro  
 - Drive is controlled by local I/O  
 - DN/start pulse DI-7 and OFF/ stop pulse DI-8  
 - Speed reference AI-1 or motor pot (DI-1 = mux)  
 - Main contactor via DO-8 (x39)  
 - JOG1=DI-1, JOG2=DI-2, direction=DI-3  
 - DI-5 for E-stop not, RESET=DI-6

# Man/Const





# Hand/Auto




**[DCS800Wizard] 2. Macro assistant**

Set general parameter  
 9908 Application macro **Hand/MotPot**

Description of selected macro:  
 \*\*\*HAND /Motor potentiometer macro (stop=no rest)  
 -Drive is controlled by local I/O  
 -DN/start pulse DI-7 and OFF/ stop pulse (NC) DI-8  
 -Speed reference by motor pot or AI-1 (DI-4= max)  
 -Main contactor via DO-8 (X39)  
 -Speed up =DI-1, speed down=DI-2 direction=DI-3  
 -DI-5 for E-stop not, RESET=DI-6

# Hand/MotPot








**[DCS800Wizard] 2. Macro assistant**

Set general parameter  
 9908 Application macro: **TorqCtrl**

Description of selected macro:  
 - Torque control macro  
 - Drive is controlled by local I/O  
 - DI7 for ON/DOFF and DI8 for START/STOP  
 - Torque or speed reference AI-1 (DI-2=aux)  
 - Main contactor via DO-8 (DI-2=aux)  
 - ExtFault=DI-3, RESET=DI-6  
 - DI4 for DI2 not (start inhibition), DI5 for E-stop not"

# TorqueCtrl









# Declaration of Conformity

( Directive 73/23/EEC [Low Voltage], as amended by 93/68/EEC )  
( Directive 89/336/EEC [EMC], as amended by 93/68/EEC )

Document code : ABB/DEAPR/AD 06-02

We, ABB Automation Products GmbH  
Division Drives & Motors  
Wallstadter Str. 59 D68526 Ladenburg, Germany

herewith declare under our sole responsibility, that the product series

## **DCS 800 Converter Module up to supply voltage of 1000V~**

to which this declaration relates, is a BDM / CDM according EN 61800-1: 1998  
[ IEC 61 800-1 ]

It is in conformity with

- the **Low Voltage Directive (LVD) 73/23/EEC**, including amendment 93/68/EEC.  
Following standards have been applied:


- EN 61800-1: 1998 [ IEC 61 800-1 ]
- EN 60204-1: 1997 [ IEC 60 204-1 ] and

- the **Electromagnetic Compatibility (EMC) Directive 89/336/EEC**, including amendment 93/68/EEC. Following standards have been applied:

- EN 61800-3: 2004 [ IEC 61800-3 ]

This declaration is based on Technical Construction File, code 3ADT061024. It is provided, that instructions for installation, operation and maintenance are according the product documentation.

Ladenburg, 24.03.2006

  
\_\_\_\_\_  
APR Christian Wendler  
President

  
\_\_\_\_\_  
APR / AD Harald Jetses  
PRU Manager

This declaration does not express any assurance of characteristics.  
Installation and safety instructions mentioned in our installation manual must be obeyed.  
The conformity was tested in a typical configuration.





AWQ - 051201

## Herstellbescheinigung / Certificate of Manufacture

Datum / date: 01.12.2005

### Identifizierung des Produktes / Identification of product

Typ / type : ABB DC Converter Families DCS 400, DCS 500, DCS 600, DCS 800

### Prüfung / Test

Die Prüfung erfolgt nach interner, produktspezifischer Prüfanweisung.

*Routine test is performed in accordance with ABB product specific test instruction.*

### Erklärung / Declaration

Wir bestätigen die einwandfreie Herstellung und Prüfung der oben erwähnten Produkte in unserer Fabrik in Lampertheim, Deutschland nach unseren Normen und Sicherheitsvorschriften.

*We hereby confirm that the above mentioned products are manufactured and tested in our facility in Lampertheim, Germany in conformity with our standards and safety rules.*

**ABB Automation Products GmbH**  
**BUU Drives & Motors**  
**Factory Lampertheim**

Werksleiter  
General Manager



Harald Jetses

Produktionsleiter  
Operations Manager



Bernd Schmalenberger

**ABB Automation Products GmbH**

Für dieses Dokument und den darin dargestellten Gegenstand behalten wir uns alle Rechte vor. Vervielfältigungen, Bekanntgabe an Dritte oder Verwertung seines Inhalts sind ohne unsere ausdrückliche Zustimmung verboten. © ABB Automation Products GmbH 2005

2310

3ADW 000 208 R0101

# DCS800 family



## DCS800-S modules

The versatile drive for any application

20 ... 5,200 A<sub>DC</sub>  
0 ... 1,160 V<sub>DC</sub>  
230 ... 1,000 V<sub>AC</sub>  
IP00

- Compact
- Highest power ability
- Simple operation
- Comfortable assistants, e.g. for commissioning or fault tracing
- Scalable to all applications
- Free programmable by means of integrated IEC61131-PLC



## DCS800-A enclosed converters

Complete drive solutions

20 ... 20,000 A<sub>DC</sub>  
0 ... 1,500 V<sub>DC</sub>  
230 ... 1,200 V<sub>AC</sub>  
IP21 – IP54

- Individually adaptable to customer requirements
- User-defined accessories like external PLC or automation systems can be included
- High power solutions in 6- and 12-pulse up to 20,000 A, 1,500 V
- In accordance to usual standards
- Individually factory load tested
- Detailed documentation



## DCS800-E series

Pre-assembled drive-kits

20 ... 2,000 A<sub>DC</sub>  
0 ... 700 V<sub>DC</sub>  
230 ... 600 V<sub>AC</sub>  
IP00

- DCS800 module with all necessary accessories mounted and fully cabled on a panel
- Very fast installation and commissioning
- Squeezes shut-down-times in revamp projects to a minimum
- Fits into Rittal cabinets
- Compact version up to 450 A and Vario version up to 2,000 A



## DCS800-R Rebuild Kit

Digital control-kit for existing powerstacks

20 ... 20,000 A<sub>DC</sub>  
0 ... 1,160 V<sub>DC</sub>  
230 ... 1,200 V<sub>AC</sub>  
IP00

- Proven long life components are re-used, such as power stacks, (main) contactors, cabinets and cabling / busbars, cooling systems
- Use of up-to-date communication facilities
- Increase of production and quality
- Very cost-effective solution
- Open Rebuild Kits for nearly all existing DC drives
- tailor-made solutions for...
  - BBC PxD
  - BBC SZxD
  - ASEA TYRAK
  - other manufacturers



**ABB Automation Products**  
Wallstadter Straße 59  
68526 Ladenburg • GERMANY

Phone +49(0)6203-71-0  
Fax +49(0)6203-71-7609  
[www.abb.com/motors&drives](http://www.abb.com/motors&drives)  
[dc-drives@de.abb.com](mailto:dc-drives@de.abb.com)