

# Dell Latitude E6230/E6330


## Setup and Features Information

### About Warnings



**WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

### Latitude E6230 Front and Back View




**Figure 1. Front View**

- |                                   |                              |
|-----------------------------------|------------------------------|
| 1. microphone                     | 5. power button              |
| 2. camera (optional)              | 6. HDMI connector            |
| 3. camera status light (optional) | 7. USB 3.0 connector         |
| 4. display                        | 8. powered USB 3.0 connector |



Regulatory Model : P14T, P19S  
Regulatory Type : P14T001, P19S001  
2011 - 9

- |                          |                                   |
|--------------------------|-----------------------------------|
| 9. wireless switch       | 14. contactless smart-card reader |
| 10. ExpressCard slot     | 15. keyboard                      |
| 11. fingerprint reader   | 16. volume control buttons (3)    |
| 12. touchpad buttons (2) | 17. device status lights          |
| 13. touchpad             |                                   |




**Figure 2. Back View**

- |                            |   |
|----------------------------|---|
| 1. network connector       | 7. audio connector                        |
| 2. device status lights    | 8. cooling vents                          |
| 3. security cable slot     | 9. Secure Digital (SD) memory-card reader |
| 4. power connector         | 10. smart card reader                     |
| 5. VGA connector           |   |
| 6. eSATA/USB 2.0 connector |   |




**WARNING:** Do not block, push objects into, or allow dust to accumulate in the air vents. Do not store your Dell computer in a low-airflow environment, such as a closed briefcase, while it is running. Restricting the airflow can damage the computer or cause a fire. The computer turns on the fan when the computer gets hot. Fan noise is normal and does not indicate a problem with the fan or the computer.

# Latitude E6330 Front and Back View



**Figure 3. Front view**

- |                              |  |
|------------------------------|--|
| 1. microphone                | 12. fingerprint reader                     |
| 2. camera                    | 13. contactless smart card reader          |
| 3. camera status light       | 14. Secure Digital (SD) memory-card reader |
| 4. display                   | 15. touchpad buttons (2)                   |
| 5. power button              | 16. touchpad                               |
| 6. eSATA/USB 2.0 connector   | 17. trackstick buttons (3)                 |
| 7. powered USB 3.0 connector | 18. trackstick                             |
| 8. volume control buttons    | 19. keyboard                               |
| 9. wireless switch           | 20. device status lights                   |
| 10. optical drive            |  |
| 11. ExpressCard slot         |  |



**Figure 4. Back view**

- |                         |                     |
|-------------------------|---------------------|
| 1. security cable slot  | 6. power connector  |
| 2. network connector    | 7. VGA connector    |
| 3. mini HDMI connector  | 8. audio connector  |
| 4. device status lights | 9. cooling vents    |
| 5. USB 3.0 connector    | 10. smart card slot |





**WARNING:** Do not block, push objects into, or allow dust to accumulate in the air vents. Do not store your Dell computer in a low-airflow environment, such as a closed briefcase, while it is running. Restricting the airflow can damage the computer or cause a fire. The computer turns on the fan when the computer gets hot. Fan noise is normal and does not indicate a problem with the fan or the computer.


## Quick Setup




**WARNING:** Before you begin any of the procedures in this section, read the safety information that shipped with your computer. For additional best practices information, see [www.dell.com/regulatory\\_compliance](http://www.dell.com/regulatory_compliance).

 **WARNING:** The AC adapter works with electrical outlets worldwide. However, power connectors and power strips vary among countries. Using an incompatible cable or improperly connecting the cable to the power strip or electrical outlet may cause fire or equipment damage.

 **CAUTION:** When you disconnect the AC adapter cable from the computer, grasp the connector, not the cable itself, and pull firmly but gently to avoid damaging the cable. When you wrap the AC adapter cable, ensure that you follow the angle of the connector on the AC adapter to avoid damaging the cable.


 **NOTE:** Some devices may not be included if you did not order them.

1. Connect the AC adapter to the AC adapter connector on the computer and to the electrical outlet.




**Figure 5. AC Adapter**

2. Connect the network cable (optional).




**Figure 6. Network Connector**

3. Connect USB devices, such as a mouse or keyboard (optional).




**Figure 7. USB Connector**


4. Open the computer display and press the power button to turn on the computer.



**Figure 8. Power Button**

 **NOTE:** It is recommended that you turn on and shut down your computer at least once before you install any cards or connect the computer to a docking device or other external device, such as a printer.

## Specifications


 **NOTE:** Offerings may vary by region. The following specifications are only those required by law to ship with your computer. For more information regarding the configuration of your computer, click **Start** → **Help and Support** and select the option to view information about your computer.

---

### Power

---

AC Adapter 65 W and 90 W

 **NOTE:** 65 W AC adapter is available only for computers with integrated video card.

Input voltage 100 VAC to 240 VAC

Coin-cell battery 3 V CR2032 lithium coin cell

---

### Physical

---

#### Latitude E6230

Height 22.40 mm to 24.70 mm (0.88 inch to 0.97 inch)

Width 309.00 mm (12.16 inches)

Depth 226.00 mm (8.89 inches)

Weight 1.70 kg (3.75 lbs)

#### Latitude E6330

Height 25.40 mm to 30.10 mm (1.00 inch to 1.19 inches)

---

## Physical

---

Width	335.00 mm (13.19 inches)
Depth	223.00 mm (8.78 inches)
Weight	2.10 kg (4.63 lbs)

---

## Environmental

---

Operating Temperature:

Latitude E6230	10 °C to 35 °C (50 °F to 95 °F)
Latitude E6330	0 °C to 35 °C (32 °F to 95 °F)

## Information para NOM (únicamente para México)

Voltaje de alimentación	100 V CA – 240 V CA
Frecuencia	50 Hz – 60 Hz
Consumo eléctrico	1,50 A~2,50 A
Voltaje de salida	19,50 V de CC
Intensidad de salida	3,34 A/4,62 A

## Finding More Information and Resources

See the safety and regulatory documents that shipped with your computer and the regulatory compliance website at [www.dell.com/regulatory\\_compliance](http://www.dell.com/regulatory_compliance) for more information on:

- Safety best practices
- Regulatory certification
- Ergonomics

See [www.dell.com](http://www.dell.com) for additional information on:

- Warranty
- Terms and Conditions (U.S. only)
- End User License Agreement

Additional information on your product is available at [support.dell.com/manuals](http://support.dell.com/manuals).

**Information in this publication is subject to change without notice.**

**© 2011 Dell Inc. All rights reserved.**

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: Dell™, the DELL logo, Dell Precision™, Precision ON™, ExpressCharge™, Latitude™, Latitude ON™, OptiPlex™, Vostro™, and Wi-Fi Catcher™ are trademarks of Dell Inc. Intel®, Pentium®, Xeon®, Core™, Atom™, Centrino®, and Celeron® are registered trademarks or trademarks of Intel Corporation in the U.S. and other countries. AMD® is a registered trademark and AMD Opteron™, AMD Phenom™, AMD Sempron™, AMD Athlon™, ATI Radeon™, and ATI FirePro™ are trademarks of Advanced Micro Devices, Inc. Microsoft®, Windows®, MS-DOS®, Windows Vista®, the Windows Vista start button, and Office Outlook® are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. Blu-ray Disc™ is a trademark owned by the Blu-ray Disc Association (BDA) and licensed for use on discs and players. The Bluetooth® word mark is a registered trademark and owned by the Bluetooth® SIG, Inc. and any use of such mark by Dell Inc. is under license. Wi-Fi® is a registered trademark of Wireless Ethernet Compatibility Alliance, Inc.

Other trademarks and trade names may be used in this publication to refer to either the entities claiming the marks and names or their products, Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.