



Connect. Accelerate. Outperform.™

# **User Manual for Mellanox ConnectX<sup>®</sup>-3 10/40 Gigabit Ethernet Adapters for Dell PowerEdge Servers**

Rev 1.1

## NOTE:

THIS HARDWARE, SOFTWARE OR TEST SUITE PRODUCT (“PRODUCT(S)”) AND ITS RELATED DOCUMENTATION ARE PROVIDED BY MELLANOX TECHNOLOGIES “AS-IS” WITH ALL FAULTS OF ANY KIND AND SOLELY FOR THE PURPOSE OF AIDING THE CUSTOMER IN TESTING APPLICATIONS THAT USE THE PRODUCTS IN DESIGNATED SOLUTIONS. THE CUSTOMER’S MANUFACTURING TEST ENVIRONMENT HAS NOT MET THE STANDARDS SET BY MELLANOX TECHNOLOGIES TO FULLY QUALIFY THE PRODUCT(S) AND/OR THE SYSTEM USING IT. THEREFORE, MELLANOX TECHNOLOGIES CANNOT AND DOES NOT GUARANTEE OR WARRANT THAT THE PRODUCTS WILL OPERATE WITH THE HIGHEST QUALITY. ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT ARE DISCLAIMED. IN NO EVENT SHALL MELLANOX BE LIABLE TO CUSTOMER OR ANY THIRD PARTIES FOR ANY DIRECT, INDIRECT, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES OF ANY KIND (INCLUDING, BUT NOT LIMITED TO, PAYMENT FOR PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY FROM THE USE OF THE PRODUCT(S) AND RELATED DOCUMENTATION EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.



Mellanox Technologies  
 350 Oakmead Parkway Suite 100  
 Sunnyvale, CA 94085  
 U.S.A.  
[www.mellanox.com](http://www.mellanox.com)  
 Tel: (408) 970-3400  
 Fax: (408) 970-3403

Mellanox Technologies, Ltd.  
 Beit Mellanox  
 PO Box 586 Yokneam 20692  
 Israel  
[www.mellanox.com](http://www.mellanox.com)  
 Tel: +972 (0)74 723 7200  
 Fax: +972 (0)4 959 3245

© Copyright 2014. Mellanox Technologies. All Rights Reserved.

Mellanox®, Mellanox logo, BridgeX®, ConnectX®, Connect-IB®, CORE-Direct®, InfiniBridge®, InfiniHost®, InfiniScale®, MetroX®, MLNX-OS®, PhyX®, ScalableHPC®, SwitchX®, UFM®, Virtual Protocol Interconnect® and Voltaire® are registered trademarks of Mellanox Technologies, Ltd.

ExtendX™, FabricIT™, Mellanox Open Ethernet™, Mellanox Virtual Modular Switch™, MetroDX™, TestX™, Unbreakable-Link™ are trademarks of Mellanox Technologies, Ltd.

All other trademarks are property of their respective owners.

Dell and the DELL logo are trademarks of Dell Inc. Microsoft and Windows are trademarks of Microsoft Corporation. Linux is a trademark of Linus Torvalds. Intel is a trademark of Intel Corporation. Magic Packet is a trademark of Advanced Micro Devices, Inc. Red Hat is a trademark of Red Hat, Inc. PCI Express is a trademark of PCI-SIG. Any other trademarks or trade names mentioned are the property of their respective owners.

## Restrictions and Disclaimers

The information contained in this document, including all instructions, cautions, and regulatory approvals and certifications, is provided by the supplier and has not been independently verified or tested by Dell, except where specifically noted. Dell cannot be responsible for damage caused as a result of either following or failing to follow these instructions. All statements or claims regarding the properties, capabilities, speeds or qualifications of the part referenced in this document are made by the supplier and not by Dell. Dell specifically disclaims knowledge of the accuracy, completeness or substantiation for any such statements. All questions or comments relating to such statements or claims should be directed to the supplier.

## Export Regulations

Customer acknowledges that these Products, which may include technology and software, are subject to the customs and export control laws and regulations of the United States ("U.S.") and may also be subject to the customs and export laws and regulations of the country in which the Products are manufactured and/or received. Customer agrees to abide by those laws and regulations. Further, under U.S. law, the Products may not be sold, leased or otherwise transferred to restricted end-users or to restricted countries. In addition, the Products may not be sold, leased or otherwise transferred to, or utilized by an end-user engaged in activities related to weapons of mass destruction, including without limitation, activities related to the design, development, production or use of nuclear weapons, materials, or facilities, missiles or the support of missile projects, and chemical or biological weapons.

# Table of Contents

<b>Restrictions and Disclaimers</b>	<b>3</b>
<b>Export Regulations</b>	<b>3</b>
<b>Table of Contents</b>	<b>4</b>
<b>List of Tables</b>	<b>8</b>
<b>List of Figures</b>	<b>9</b>
<b>Revision History</b>	<b>10</b>
<b>About this Manual</b>	<b>11</b>
Intended Audience	11
Related Documentation	11
Document Conventions	11
Technical Support	11
<b>Chapter 1 Introduction</b>	<b>12</b>
1.1 Functional Description	12
1.2 Features	12
1.2.1 Single Root IO Virtualization (SR-IOV)	14
1.2.2 Remote Direct Memory Access (RDMA)	14
1.3 Supported Operating Systems/Distributions	14
<b>Chapter 2 Adapter Card Interfaces</b>	<b>15</b>
2.1 I/O Interfaces	15
2.1.1 Ethernet QSFP+/ SFP+ Interface	15
2.1.2 LED Assignment	15
<b>Chapter 3 Installing the Hardware</b>	<b>18</b>
3.1 System Requirements	18
3.1.1 Hardware	18
3.1.2 Operating Systems/Distributions	18
3.1.3 Software Stacks	18
3.1.4 Co-requisites	18
3.2 Safety Precautions	18
3.3 Pre-installation Checklist	19
3.4 Installation Instructions	19
3.4.1 For Adapters	19
3.4.2 For Mezzanine Cards	19
3.5 Connecting the Network Cables	20
3.5.1 Inserting a Cable into the Adapter Card	20
3.5.2 Removing a Cable from the Adapter Card	20
3.6 Identifying the Card in A System	20
3.6.1 On Linux	20
<b>Chapter 4 Driver Installation and Configuration</b>	<b>21</b>
4.1 Linux Driver	21

4.1.1	Installation Requirements . . . . .	21
4.1.2	Downloading Mellanox OFED . . . . .	21
4.1.3	Installing Mellanox OFED . . . . .	21
4.1.3.1	Pre-installation Notes . . . . .	22
4.1.4	Installation Script . . . . .	22
4.1.4.1	mlnxofedinstall Return Codes . . . . .	22
4.1.5	Installation Procedure . . . . .	23
4.1.6	Installation Results . . . . .	24
4.1.7	Post-installation Notes . . . . .	25
4.1.8	Uninstalling Mellanox OFED . . . . .	25
4.2	Linux Driver Features . . . . .	25
4.2.1	iSCSI Extensions for RDMA (iSER) . . . . .	25
4.2.2	iSER Initiator . . . . .	25
4.2.3	Quality of Service (QoS) Ethernet . . . . .	25
4.2.3.1	Mapping Traffic to Traffic Classes . . . . .	25
4.2.3.2	Plain Ethernet Quality of Service Mapping . . . . .	26
4.2.3.3	RoCE Quality of Service Mapping . . . . .	27
4.2.3.4	Raw Ethernet QP Quality of Service Mapping . . . . .	27
4.2.3.5	Map Priorities with tc_wrap.py/mlnx_qos . . . . .	27
4.2.3.6	Quality of Service Properties . . . . .	28
4.2.3.7	Quality of Service Tools . . . . .	29
4.2.4	Ethernet Time-Stamping . . . . .	32
4.2.4.1	Enabling Time Stamping . . . . .	32
4.2.4.2	Getting Time Stamping . . . . .	35
4.2.4.3	Querying Time Stamping Capabilities via ethtool . . . . .	36
4.2.5	RoCE Time Stamping . . . . .	36
4.2.5.1	Query Capabilities . . . . .	36
4.2.5.2	Creating Time Stamping Completion Queue . . . . .	37
4.2.5.3	Polling a Completion Queue . . . . .	37
4.2.5.4	Querying the Hardware Time . . . . .	38
4.2.6	Flow Steering . . . . .	38
4.2.6.1	Enable/Disable Flow Steering . . . . .	38
4.2.6.2	Flow Domains and Priorities . . . . .	39
4.2.7	Single Root IO Virtualization (SR-IOV) . . . . .	41
4.2.7.1	System Requirements . . . . .	41
4.2.7.2	Setting Up SR-IOV . . . . .	41
4.2.7.3	Enabling SR-IOV and Para Virtualization on the Same Setup . . . . .	44
4.2.7.4	Assigning a Virtual Function to a Virtual Machine . . . . .	44
4.2.7.5	Uninstalling SR-IOV Driver . . . . .	45
4.2.7.6	Configuring Pkeys and GUIDs under SR-IOV . . . . .	46
4.2.7.7	Ethernet Virtual Function Configuration when Running SR-IOV . . . . .	47
4.2.8	Ethtool . . . . .	48
4.2.9	Ethernet Performance Counters . . . . .	50
4.3	VMware Driver . . . . .	55
4.3.1	Installing and Running the Driver . . . . .	55
4.3.1.1	Installing and Running the VIB Driver on ESXi-5.x . . . . .	55
4.3.2	Installing and Running the offline_bundle Driver on ESXi-5.x . . . . .	57
4.3.3	Removing the VIB/offline_bundle Driver . . . . .	57

4.4	Windows	57
4.4.1	Installation Requirements	58
4.4.1.1	Required Disk Space for Installation	58
4.4.2	Software Requirements	58
4.4.2.1	Installer Privileges	58
4.4.3	Downloading Mellanox WinOF	58
4.4.4	Installing Mellanox WinOF	58
4.4.4.1	Attended Installation	58
4.4.4.2	Unattended Installation	59
4.4.5	Uninstalling Mellanox WinOF	59
4.4.6	Windows Performance Tuning	59
4.5	WinOF Features	59
4.5.1	Configuring Quality of Service (QoS)	59
4.5.2	RDMA over Converged Ethernet	61
4.5.2.1	RoCE Configuration	61
4.5.2.2	Configuring Router (PFC only)	63
4.5.3	Deploying Windows Server 2012 and 2012 R2 with SMB Direct	63
4.5.3.1	Hardware and Software Prerequisites	63
4.5.3.2	SMB Configuration Verification	63
4.5.3.3	Verifying SMB Connection	64
4.5.3.4	Verifying SMB Events that Confirm RDMA Connection	64
<b>Chapter 5</b>	<b>Remote Boot</b>	<b>65</b>
5.1	iSCSI Boot	65
5.1.1	RHEL6.4/RHEL6.5	65
5.1.1.1	Configuring the iSCSI Target Machine	65
5.1.1.2	Installing RHEL6.4/RHEL6.5 on a Remote Storage over iSCSI	66
5.1.1.3	SAN-Booting the Diskless Client with FlexBoot	70
5.1.2	Booting Windows from an iSCSI Target	70
5.1.2.1	Configuring the WDS, DHCP and iSCSI Servers	70
5.1.2.2	Configuring the Client Machine	71
5.1.2.3	Installing iSCSI	72
5.1.3	SLES11 SP3	73
5.1.3.1	Configuring the iSCSI Target Machine	73
5.1.3.2	Configuring the DHCP Server	75
5.1.3.3	Installing SLES11 SP3 on a Remote Storage over iSCSI	75
5.1.3.4	Using PXE Boot Services for Booting the SLES11 SP3 from the iSCSI Target	82
5.2	PXE Boot	82
5.2.1	SLES11 SP3	82
5.2.1.1	Configuring the PXE Server	82
<b>Chapter 6</b>	<b>Firmware</b>	<b>84</b>
<b>Chapter 7</b>	<b>Troubleshooting</b>	<b>85</b>
7.1	General	85
7.2	Linux	86
7.3	Windows	86
<b>Chapter 8</b>	<b>Specifications</b>	<b>88</b>
<b>Chapter 9</b>	<b>Regulatory</b>	<b>91</b>

9.1 Regulatory Statements . . . . .	91
9.1.1 FCC Statements (USA) . . . . .	91
9.1.2 EN Statements (Europe) . . . . .	92
9.1.3 ICES Statements (Canada) . . . . .	92
9.1.4 VCCI Statements (Japan) . . . . .	92
9.1.5 KCC Certification (Korea) . . . . .	93
<b>Appendix A Configuration for Mellanox Adapters through System Setup . . .</b>	<b>94</b>
<b>Appendix B Safety Warnings . . . . .</b>	<b>108</b>
<b>Appendix C Avertissements de sécurité d'installation (Warnings in French)</b>	<b>110</b>
<b>Appendix D Sicherheitshinweise (Warnings in German) . . . . .</b>	<b>112</b>
<b>Appendix E Advertencias de seguridad para la instalación (Warnings in Spanish)</b>	<b>114</b>

## List of Tables

Table 1:	Revision History Table	10
Table 2:	Documents List	11
Table 3:	LED Assignment for 10GbE SFP+ Network Adapters	15
Table 4:	LED Assignment for 40GbE QSFP+ Network Adapters	16
Table 5:	install.sh Return Codes	22
Table 6:	Flow Specific Parameters	40
Table 7:	ethtool Supported Options	49
Table 8:	Port IN Counters	51
Table 9:	Port OUT Counters	52
Table 10:	Port VLAN Priority Tagging (where <i> is in the range 0...7)	52
Table 11:	Port Pause (where <i> is in the range 0...7)	53
Table 12:	VPort Statistics (where <i>=<empty_string> is the PF, and ranges 1...NumOfVf per VF)	53
Table 13:	SW Statistics	54
Table 14:	Per Ring (SW) Statistics (where <i> is the ring I – per configuration)	55
Table 15:	Reserved IP Address Options	71
Table 16:	Mellanox ConnectX-3 Dual 40GbE QSFP+ Network Adapter Specifications	88
Table 17:	Mellanox ConnectX-3 Dual 10GbE SFP+ Network Adapter Specifications	89
Table 18:	Mellanox ConnectX-3 Dual 10GbE KR Blade Mezzanine Card Specifications	90
Table 19:	Ethernet Network Adapter Certifications	91



## List of Figures

Figure 1:	Mellanox ConnectX-3 Dual Port 40GbE QSFP+ Network Adapter Full Height Bracket	16
Figure 2:	Mellanox ConnectX-3 Dual Port 10GbE SFP+ Network Adapter Full Height Bracket	17
Figure 3:	Life Cycle Controller Main Configuration System Setup Menu	94
Figure 4:	Main Configuration Page Options	95
Figure 5:	Main Configuration Page - iSCSI Configuration - iSCSI General Parameters	101
Figure 6:	Main Configuration Page - iSCSI Configuration - iSCSI Initiator Parameters	102
Figure 7:	Main Configuration Page - iSCSI Configuration - iSCSI Target Parameters	103

# Revision History

This document was printed on August 12, 2014.

**Table 1 - Revision History Table**

Date	Rev	Comments/Changes
August 2014	1.1	<ul style="list-style-type: none"><li>• Added Section 4.2, "Linux Driver Features," on page 25</li><li>• Added Section 4.5, "WinOF Features," on page 59</li><li>• Added Section 5, "Remote Boot," on page 65</li><li>• Added Appendix A, "Configuration for Mellanox Adapters through System Setup," on page 94</li></ul>
November 2013	1.0	Initial Release

## About this Manual

This *User Manual* describes Mellanox Technologies ConnectX®-3 10/40 Gigabit Ethernet Adapter and Cards for Dell PowerEdge Servers. It provides details as to the interfaces of the board, specifications, required software and firmware for operating the board, and relevant documentation.

## Intended Audience

This manual is intended for the installer and user of these cards.

The manual assumes the user has basic familiarity with Ethernet networks and architecture specifications.

## Related Documentation

**Table 2 - Documents List**

<i>IEEE Std 802.3 Specification</i>	This is the IEEE Ethernet specification <a href="http://standards.ieee.org/getieee802">http://standards.ieee.org/getieee802</a>
PCI Express 3.0 Specifications	Industry Standard PCI Express 3.0 Base and PCI_Express_CEM_r3.0

## Document Conventions

This document uses the following conventions:

- MB and MBytes are used to mean size in mega Bytes. The use of Mb or Mbits (small b) indicates size in mega bits.
- PCIe is used to mean PCI Express

## Technical Support

Dell Support site: <http://www.dell.com/support>

# 1 Introduction

## 1.1 Functional Description

Mellanox Ethernet adapters utilizing IBTA RoCE technology provide efficient RDMA services, delivering high performance to bandwidth and latency sensitive applications. Applications utilizing TCP/UDP/IP transport can achieve industry-leading throughput over 10 or 40GbE. The hardware-based stateless offload and flow steering engines in Mellanox adapters reduce the CPU overhead of IP packet transport, freeing more processor cycles to work on the application. Sockets acceleration software further increases performance for latency sensitive applications. This User Manual relates to the following products:

- Mellanox ConnectX<sup>®</sup>-3 Dual Port 40GbE QSFP Network Adapter for Dell PowerEdge Servers with full height bracket
- Mellanox ConnectX<sup>®</sup>-3 Dual Port 40GbE QSFP Network Adapter for Dell PowerEdge Servers with low profile bracket
- Mellanox ConnectX<sup>®</sup>-3 Dual Port 10GbE DA/SFP+ Network Adapter for Dell PowerEdge Servers with full height bracket
- Mellanox ConnectX<sup>®</sup>-3 Dual Port 10GbE DA/SFP+ Network Adapter for Dell PowerEdge Servers with low profile bracket
- Mellanox ConnectX<sup>®</sup>-3 Dual Port 10GbE KR Blade Mezzanine Card for Dell PowerEdge Servers

## 1.2 Features

The adapters and cards described in this manual support the following features:

- Low latency RDMA over Ethernet
- Traffic steering across multiple cores
- Intelligent interrupt coalescence
- Advanced Quality of Service
- Dual Ethernet ports
- CPU off-load of transport operations
- Application Offload
- End-to-end QoS and congestion control
- Ethernet
  - IEEE 802.3ae 10 Gigabit Ethernet
  - IEEE 802.3ba 40 Gigabit Ethernet supported on Mellanox ConnectX-3 Dual Port 40GbE QSFP+ Network Adapter only
  - IEEE 802.3ad Link Aggregation and Failover
  - IEEE 802.1Q, 802.1p VLAN tags and priority
  - IEEE 802.1Qau Congestion Notification
  - IEEE P802.1Qbb D1.0 Priority-based Flow Control
  - Jumbo frame support (10KB)

- 128 MAC/VLAN addresses per port
- Wake on LAN (WoL) supported on Mellanox ConnectX-3 Dual Port 10GbE KR Blade Mezzanine Card only
- PCI Express Interface
  - PCIe Base 3.0 compliant, 1.1 and 2.0 compatible
  - 2.5, 5.0, or 8.0GT/s link rate x8
  - Auto-negotiates to x8, x4, or x1
  - Support for MSI/MSI-X mechanisms
- Hardware-based I/O Virtualization
  - Single Root IOV (SR-IOV) - see [Section 1.2.1, “Single Root IO Virtualization \(SR-IOV\),” on page 14](#)
  - Address translation and protection
  - Dedicated adapter resources
  - Multiple queues per virtual machine
  - Enhanced QoS for vNICs
  - VMware NetQueue support
- Additional CPU Offloads
  - RDMA over Converged Ethernet - see [Section 1.2.2, “Remote Direct Memory Access \(RDMA\),” on page 14](#)
  - TCP/UDP/IP stateless offload
  - Intelligent interrupt coalescence
- FlexBoot™ Technology
  - Remote boot over Ethernet
    - iSCSI boot
    - PXE boot
- Connectivity
  - Interoperable with 1/10/40GbE switches
  - QSFP+ connectors supported on Mellanox ConnectX-3 Dual Port 40GbE QSFP+ Network Adapter only
  - SFP+ connectors supported on Mellanox ConnectX-3 Dual Port 10GbE SFP+ Network Adapter only
  - Passive copper cable
  - Powered connectors for optical and active cable support
- Management and Tools
  - MIB, MIB-II, MIB-II Extensions, RMON, RMON 2
  - Configuration and diagnostic tools
- RoHS-R6 compliant

### 1.2.1 Single Root IO Virtualization (SR-IOV)

Single Root IO Virtualization (SR-IOV) is a technology that allows a physical PCIe device to present itself multiple times through the PCIe bus. This technology enables multiple virtual

instances of the device with separate resources. Mellanox adapters are capable of exposing up to 126 virtual instances called Virtual Functions (VFs). These virtual functions can then be provisioned separately. Each VF can be seen as an addition device connected to the Physical Function. It shares the same resources with the Physical Function, and its number of ports equals those of the Physical Function. SR-IOV is commonly used in conjunction with an SR-IOV enabled hypervisor to provide virtual machines direct hardware access to network resources hence increasing its performance.

### 1.2.2 Remote Direct Memory Access (RDMA)

Remote Direct Memory Access (RDMA) is the remote memory management capability that allows server to server data movement directly between application memory without any CPU involvement. RDMA over Converged Ethernet (RoCE) is a mechanism to provide this efficient data transfer with very low latencies on loss-less Ethernet networks. With advances in data center convergence over reliable Ethernet, ConnectX®-3 EN with RoCE uses the proven and efficient RDMA transport to provide the platform for deploying RDMA technology in mainstream data center application at 10GigE and 40GigE link-speed. ConnectX®-3 EN with its hardware offload support takes advantage of this efficient RDMA transport (InfiniBand) services over Ethernet to deliver ultra low latency for performance-critical and transaction intensive applications such as financial, database, storage, and content delivery networks. RoCE encapsulates IB transport and GRH headers in Ethernet packets bearing a dedicated ether type. While the use of GRH is optional within InfiniBand subnets, it is mandatory when using RoCE. Applications written over IB verbs should work seamlessly, but they require provisioning of GRH information when creating address vectors. The library and driver are modified to provide mapping from GID to MAC addresses required by the hardware.

## 1.3 Supported Operating Systems/Distributions

- RedHat Enterprise Linux (RHEL)
- SuSe Linux Enterprise Server (SLES)
- OpenFabrics Enterprise Distribution (OFED)
- Microsoft Windows Server Family of Operating Systems
- VMware ESX



For the list of the specific supported operating systems and distributions, please refer to the release notes for the applicable software downloads on the Dell support site: <http://www.dell.com/support>.

## 2 Adapter Card Interfaces

### 2.1 I/O Interfaces

Each adapter card includes the following interfaces:

- High speed port:
  - QSFP+ for the 40GbE Network Adapters
  - SFP+ for the 10GbE Network Adapters
  - Backplane connection to the M1000e chassis for the 10GbE KR Blade Mezzanine Card
- PCI Express (PCIe) x8 edge connector
- I/O panel LEDs (*does not apply with Mellanox ConnectX-3 Dual Port 10GbE KR Blade Mezzanine Card*)

#### 2.1.1 Ethernet QSFP+/ SFP+ Interface

Note: This section does not apply to *Mellanox ConnectX-3 Dual Port 10GbE KR Blade Mezzanine Card*.

The network ports of the ConnectX-3 adapter cards are compliant with the IEEE 802.3 Ethernet standards. The QSFP+ port has four Tx/Rx pairs of SerDes. The SFP+ port has one Tx/Rx pair of SerDes. Ethernet traffic is transmitted through the cards' QSFP+ or SFP+ connectors.

#### 2.1.2 LED Assignment

There is a one bicolor link LED, green and yellow, and a green color activity LED located on the I/O panel. Link LED color is determined by link speed. See [Table 3](#) and [Table 4](#) for different LED functions.

Note: This section does not apply to *Mellanox ConnectX-3 Dual Port 10GbE KR Blade Mezzanine Card*.

**Table 3 - LED Assignment for 10GbE SFP+ Network Adapters**

Link LED (Bicolor - Green and Yellow)	Activity LED (Green)	Function
Off	Off	No link present
Yellow	Off	1 Gb/s link is present <sup>a</sup>
Green	Off	10 Gb/s link is present
Yellow	Blinking Green	Speed lower than the maximum is active
Green	Blinking Green	Maximum supported speed is active


a. 1 Gb/s Link Speed is only supported with 1 Gb/s optics. No 1 Gb/s optics are currently supported.

**Table 4 - LED Assignment for 40GbE QSFP+ Network Adapters**

Link LED (Bicolor - Green and Yellow)	Activity LED (Green)	Function
Off	Off	No link present
Yellow	Off	10 Gb/s link is present <sup>a</sup>
Green	Off	40 Gb/s link is present
Yellow	Blinking Green	Speed lower than the maximum is active
Green	Blinking Green	Maximum supported speed is active


a. 10 Gb/s Link Speed is only supported with the Mellanox Quad to Serial Small Form Factor Pluggable Adapter (QSFP+ to SFP+ adapter or QSA). The QSA is not currently supported.

**Figure 1: Mellanox ConnectX-3 Dual Port 40GbE QSFP+ Network Adapter Full Height Bracket**





**Figure 2: Mellanox ConnectX-3 Dual Port 10GbE SFP+ Network Adapter Full Height Bracket**



## 3 Installing the Hardware

### 3.1 System Requirements

#### 3.1.1 Hardware

Dell PowerEdge Server with an available PCI Express x8 slot for installing the card is required.



For the list of supported Dell PowerEdge Servers please refer to the release notes for the applicable software and firmware downloads on the Dell support site: <http://www.dell.com/support>.

#### 3.1.2 Operating Systems/Distributions

Please refer to [Section 1.3, “Supported Operating Systems/Distributions,”](#) on page 14.



For the list of the specific supported operating systems and distributions, please refer to the release notes for the applicable software downloads on the Dell support site: <http://www.dell.com/support>.

#### 3.1.3 Software Stacks

Mellanox OpenFabric software package - MLNX\_OFED for Linux.

#### 3.1.4 Co-requisites

For full functionality including manageability support, minimum versions of Server BIOS, Integrated Dell Remote Access Controller (iDRAC), and Dell Lifecycle Controller are required.



For the list of co-requisites, please refer to the release notes for the applicable software and firmware downloads on the Dell support site: <http://www.dell.com/support>.

### 3.2 Safety Precautions



The adapter is being installed in a system that operates with voltages that can be lethal. Before opening the case of the system, observe the following precautions to avoid injury and prevent damage to system components.

1. Remove any metallic objects from your hands and wrists.
2. Make sure to use only insulated tools.
3. Verify that the system is powered off and is unplugged.
4. It is required to use an ESD strap or other antistatic devices.

### 3.3 Pre-installation Checklist

1. Verify that your system meets the hardware and software requirements stated above.
2. Shut down your system if active.
3. After shutting down the system, turn off power and unplug the cord.
4. Remove the card from its package. Please note that the card must be placed on an antistatic surface.
5. Check the card for visible signs of damage. Do not attempt to install the card if damaged.

### 3.4 Installation Instructions

#### 3.4.1 For Adapters

Refer to the manuals that were supplied with your system for instructions on installing add-in cards.

1. Before installing the card, make sure that the system is off and the power cord is not connected to the server. Please follow proper electrical grounding procedures.
2. Open the system case.
3. The adapter can be placed in an available slot.
4. A lesser width adapter can be seated into a greater width slot (x4 in a x8), but a greater width adapter cannot be seated into a lesser width slot (x8 in a x4). Align the adapter connector edge with the PCI Express connector slot.
5. Applying even pressure at both corners of the adapter, insert the adapter into the slot until it is firmly seated. When the adapter is properly seated, the adapter port connectors are aligned with the slot opening, and the adapter faceplate is visible against the system chassis.



Do not use excessive force when seating the adapter, as this may damage the system or the adapter.

6. Secure the adapter with the adapter clip or screw per the instructions provided with the server model.



Ensure that the adapters are seated correctly such that the QSFP+ or SFP+ ports of the adapter are unobstructed.

7. Close the system case.

#### 3.4.2 For Mezzanine Cards

Refer to the owner's manuals that were supplied with your Dell PowerEdge Blade Server for instructions on installing blade mezzanine cards.

1. Before installing the card, take the blade server out of the chassis
2. Open the system case.
3. The card can be placed in an available slot.

4. Expose the socket to be used for the new card. When replacing an existing card, remove the card from the socket. Grab the card on the edge on the side with UPC number and pull up while gently rocking the card back and forth. For a new installation remove the protective cover enclosing the socket for the card.
5. Line up the blade mezzanine card so that the pins of the card are over the sockets in the blade server. Plug the card into the socket by placing your thumb over the Dell part number label and pressing down until the card is fully seated.



Do not use excessive force when seating the card, as this may damage the system or the adapter.

6. Secure the blade mezzanine card with the mezzanine card latch.
7. Close the system case.

## 3.5 Connecting the Network Cables

### 3.5.1 Inserting a Cable into the Adapter Card

1. Support the weight of the cable before connecting it to the adapter card. Do this by using a cable holder or tying the cable to the rack.
2. Determine the correct orientation of the connector to the card before inserting the connector. Do not try and insert the connector upside down. This may damage the adapter card.
3. Insert the connector into the adapter card. Be careful to insert the connector straight into the cage. Do not apply any torque, up or down, to the connector cage in the adapter card.
4. Make sure that the connector locks in place.

### 3.5.2 Removing a Cable from the Adapter Card

1. Pull on the latch release mechanism thereby unlatching the connector and pull the connector out of the cage.
2. Do not apply torque to the connector when removing it from the adapter card.
3. Remove any cable supports that were used to support the cable's weight.

## 3.6 Identifying the Card in A System

### 3.6.1 On Linux

Get the device location on the PCI bus by running `lspci` and locating lines with the string “Mellanox Technologies”:

```
> lspci |grep -i Mellanox
27:00.0 Network controller: Mellanox Technologies MT27500 Family [ConnectX-3]
```

## 4 Driver Installation and Configuration

### 4.1 Linux Driver

For Linux, download and install the latest Linux Drivers for Mellanox ConnectX-3 Ethernet adapters software package available on the Dell support site <http://www.dell.com/support> For driver installation instructions, please refer to Dell documentation via <http://www.dell.com/support>.

#### 4.1.1 Installation Requirements

##### Required Disk Space for Installation

- 100 MB

##### Software Requirements

- Linux operating system



For the list of supported operating system distributions and kernels, release notes for the applicable software download on the Dell support site: <http://www.dell.com/support>.

##### Installer Privileges

- The installation requires administrator privileges on the target machine

#### 4.1.2 Downloading Mellanox OFED

**Step 1.** Verify that the system has a Mellanox network adapter (NIC) installed by ensuring that you can see ConnectX-3 in the display.

The following example shows a system with an installed Mellanox NIC:

```
host1# lspci -v | grep Mellanox
27:00.0 Network controller: Mellanox Technologies MT27500 Family [ConnectX-3]
```

**Step 2.** Download the software release to your host.

The software release name has the format `MLNX_OFED_LINUX-<ver>.tar.gz`

**Step 3.** Use the `md5sum` utility to confirm the file integrity of your software release. Run the following command and compare the result to the value provided on the download page.

```
host1$ md5sum MLNX_OFED_LINUX-<ver>.tar.gz
```

#### 4.1.3 Installing Mellanox OFED

The installation script, `install.sh`, performs the following:

- Discovers the currently installed kernel
- Uninstalls any software stacks that are part of the standard operating system distribution or another vendor's commercial stack
- Installs the `MLNX_OFED_LINUX` binary RPMs (if they are available for the current kernel)

### 4.1.3.1 Pre-installation Notes

- The installation script removes all previously installed Mellanox OFED packages and installs the software release.

### 4.1.4 Installation Script

Within each distribution specific subdirectory there is an installation script called `install.sh`. Its usage is described below. You will use it during the installation procedure described in Section 4.1.5, “Installation Procedure,” on page 23.

#### 4.1.4.1 mlnxofedinstall Return Codes

Table 5 lists the `install.sh` script return codes and their meanings.

**Table 5 - `install.sh` Return Codes**

Return Code	Meaning
0	The Installation ended successfully
1	The installation failed
2	No firmware was found for the adapter device
22	Invalid parameter
28	Not enough free space
171	Not applicable to this system configuration. This can occur when the required hardware is not present on the system.
172	Prerequisites are not met. For example, missing the required software installed or the hardware is not configured correctly.
173	Failed to start the <code>mst</code> driver

## 4.1.5 Installation Procedure

- Step 1.** Login to the installation machine as root.
- Step 2.** Copy the software release on your machine



For specific installation instructions, please refer to the applicable software download on the Dell support site <http://www.dell.com/support>.

- Step 3.** Un-tar the software release.

```
host1# tar -xvf MLNX_OFED_LINUX-<ver>.tar.gz
```

- Step 4.** Change directory to the distribution specific subdirectory.

```
host1# cd /MLNX_OFED_LINUX-<ver>/rhel6/rhel6.4
```

- Step 5.** Run the installation script (example).

```
./install.sh
This program will install the MLNX_OFED_LINUX package on your machine.
Note that all other Mellanox, OEM, OFED, or Distribution IB packages will be removed.
Do you want to continue?[y/N]:y

Installing mlnx-ofa_kernel RPM
Preparing... #####
mlnx-ofa_kernel #####
Installing kmod-mlnx-ofa_kernel RPM
Preparing... #####
kmod-mlnx-ofa_kernel #####
Installing mlnx-ofa_kernel-devel RPM
Preparing... #####
mlnx-ofa_kernel-devel #####
Installing user level RPMs:
Preparing... #####
ofed-scripts #####
Preparing... #####
libibverbs #####
Preparing... #####
libibverbs-devel #####
Preparing... #####
libibverbs-devel-static #####
Preparing... #####
libibverbs-utils #####
Preparing... #####
libmlx4 #####
Preparing... #####
libmlx4-devel #####
Preparing... #####
libibumad #####
Preparing... #####
libibumad-devel #####
Preparing... #####
```

```

libibmad-static #####
Preparing... #####
libibmad #####
Preparing... #####
libibmad-devel #####
Preparing... #####
libibmad-static #####
Preparing... #####
librdmacm #####
Preparing... #####
librdmacm-utils #####
Preparing... #####
librdmacm-devel #####
Preparing... #####
perftest #####
Device (02:00.0):
                02:00.0 Ethernet controller: Mellanox Technologies MT27500 Family [ConnectX-
                3]
                Link Width: 8x
                PCI Link Speed: Unknown

Installation finished successfully.

```

**Step 6.** The script adds the following lines to `/etc/security/limits.conf` for the userspace components such as MPI:

```

* soft memlock unlimited
* hard memlock unlimited

```

These settings unlimit the amount of memory that can be pinned by a user space application. If desired, tune the value unlimited to a specific amount of RAM.

## 4.1.6 Installation Results

### Software

- The OFED package is installed under the `/usr` directory.
- The kernel modules are installed under:
  - `mlx4` driver:

```
/lib/modules/<kernel_version>/extra/mlnx-ofa_kernel/drivers/net/ethernet/mellanox/mlx4/
```

- `RDS`:

```

/lib/modules/`uname -r`/updates/kernel/net/rds/rds.ko
/lib/modules/`uname -r`/updates/kernel/net/rds/rds_rdma.ko
/lib/modules/`uname -r`/updates/kernel/net/rds/rds_tcp.ko

```



Kernel's modules location may vary depending on the kernel's configuration. For example: `/lib/modules/`uname -r`/extra/kernel/drivers/net/ethernet/mellanox/mlx4/mlx4_core`

- The script `openibd` is installed under `/etc/init.d/`. This script can be used to load and unload the software stack.



- The installation process unlimits the amount of memory that can be pinned by a user space application. See [Step 6](#).
- Man pages will be installed under `/usr/share/man/`

### 4.1.7 Post-installation Notes

- Most of the Mellanox OFED components can be configured or reconfigured after the installation by modifying the relevant configuration files.

### 4.1.8 Uninstalling Mellanox OFED

Either use the distribution specific `uninstall.sh` script or use the script `/usr/sbin/ofed_uninstall.sh` to uninstall the Mellanox OFED package. The `ofed_uninstall.sh` is part of the `ofed-scripts` RPM.

## 4.2 Linux Driver Features

### 4.2.1 iSCSI Extensions for RDMA (iSER)

iSCSI Extensions for RDMA (iSER) extends the iSCSI protocol to RDMA. It permits data to be transferred directly into and out of SCSI buffers without intermediate data copies.

### 4.2.2 iSER Initiator

The iSER initiator is controlled through the iSCSI interface available from the `iscsi-initiator-utils` package.

Make sure iSCSI is enabled and properly configured on your system before proceeding with iSER.

Targets settings such as `timeouts` and `retries` are set the same as any other iSCSI targets.



If targets are set to auto connect on boot, and targets are unreachable, it may take a long time to continue the boot process if `timeouts` and `max_retries` are set too high.

Example for discovering and connecting targets over iSER:

```
iscsiadm -m discovery -o new -o old -t st -I iser -p <ip:port> -l
```

iSER also supports RoCE without any additional configuration required. To bond the RoCE interfaces, set the `fail_over_mac` option in the bonding driver.

### 4.2.3 Quality of Service (QoS) Ethernet

#### 4.2.3.1 Mapping Traffic to Traffic Classes

Mapping traffic to TCs consists of several actions which are user controllable, some controlled by the application itself and others by the system/network administrators.

The following is the general mapping traffic to Traffic Classes flow:

1. The application sets the required Type of Service (ToS).
2. The ToS is translated into a Socket Priority (`sk_prio`).
3. The `sk_prio` is mapped to a User Priority (UP) by the system administrator (some applications set `sk_prio` directly).
4. The UP is mapped to TC by the network/system administrator.
5. TCs hold the actual QoS parameters

QoS can be applied on the following types of traffic. However, the general QoS flow may vary among them:

- **Plain Ethernet** - Applications use regular inet sockets and the traffic passes via the kernel Ethernet driver
- **RoCE** - Applications use the RDMA API to transmit using QPs
- **Raw Ethernet QP** - Application use VERBs API to transmit using a Raw Ethernet QP

#### 4.2.3.2 Plain Ethernet Quality of Service Mapping

Applications use regular inet sockets and the traffic passes via the kernel Ethernet driver.

The following is the Plain Ethernet QoS mapping flow:

1. The application sets the ToS of the socket using `setsockopt (IP_TOS, value)`.
2. ToS is translated into the `sk_prio` using a fixed translation:

```
TOS 0 <=> sk_prio 0
TOS 8 <=> sk_prio 2
TOS 24 <=> sk_prio 4
TOS 16 <=> sk_prio 6
```

3. The Socket Priority is mapped to the UP:
  - If the underlying device is a VLAN device, `egress_map` is used controlled by the `vconfig` command. This is per VLAN mapping.
  - If the underlying device is not a VLAN device, the `tc` command is used. In this case, even though `tc manual` states that the mapping is from the `sk_prio` to the TC number, the `mlx4_en` driver interprets this as a `sk_prio` to UP mapping.  
Mapping the `sk_prio` to the UP is done by using `tc_wrap.py -i <dev name> -u 0,1,2,3,4,5,6,7`
4. The the UP is mapped to the TC as configured by the `mlx_qos` tool or by the `lldpad` daemon if DCBX is used.



Socket applications can use `setsockopt (SK_PRIO, value)` to directly set the `sk_prio` of the socket. In this case the ToS to `sk_prio` fixed mapping is not needed. This allows the application and the administrator to utilize more than the 4 values possible via ToS.



In case of VLAN interface, the UP obtained according to the above mapping is also used in the VLAN tag of the traffic

### 4.2.3.3 RoCE Quality of Service Mapping

Applications use RDMA-CM API to create and use QPs.

The following is the RoCE QoS mapping flow:

1. The application sets the ToS of the QP using the `rdma_set_option` option (`RDMA_OPTION_ID_TOS`, value).
2. ToS is translated into the Socket Priority (`sk_prio`) using a fixed translation:

```
TOS 0 <=> sk_prio 0
TOS 8 <=> sk_prio 2
TOS 24 <=> sk_prio 4
TOS 16 <=> sk_prio 6
```

3. The Socket Priority is mapped to the User Priority (UP) using the `tc` command.  
In case of a VLAN device, the parent real device is used for the purpose of this mapping.
4. The the UP is mapped to the TC as configured by the `mlnx_qos` tool or by the `lldpad` daemon if DCBX is used.



With RoCE, there can only be 4 predefined ToS values for the purpose of QoS mapping.

### 4.2.3.4 Raw Ethernet QP Quality of Service Mapping

Applications open a Raw Ethernet QP using VERBs directly.

The following is the RoCE QoS mapping flow:

1. The application sets the UP of the Raw Ethernet QP during the INIT to RTR state transition of the QP:
  - Sets `qp_attrs.ah_attrs.sl = up`
  - Calls `modify_qp` with `IB_QP_AV` set in the mask
2. The UP is mapped to the TC as configured by the `mlnx_qos` tool or by the `lldpad` daemon if DCBX is used



When using Raw Ethernet QP mapping, the TOS/sk\_prio to UP mapping is lost.



Performing the Raw Ethernet QP mapping forces the QP to transmit using the given UP. If packets with VLAN tag are transmitted, UP in the VLAN tag will be overwritten with the given UP.

### 4.2.3.5 Map Priorities with `tc_wrap.py/mlnx_qos`

Network flow that can be managed by QoS attributes is described by a User Priority (UP). A user's `sk_prio` is mapped to UP which in turn is mapped into TC.

- Indicating the UP

- When the user uses `sk_prio`, it is mapped into a UP by the `'tc'` tool. This is done by the `tc_wrap.py` tool which gets a list of  $\leq 16$  comma separated UP and maps the `sk_prio` to the specified UP.  
For example, `tc_wrap.py -ieth0 -u 1,5` maps `sk_prio 0` of `eth0` device to UP 1 and `sk_prio 1` to UP 5.
- Setting `set_egress_map` in VLAN, maps the `skb_priority` of the VLAN to a `vlan_qos`. The `vlan_qos` represents a UP for the VLAN device.
- In RoCE, `rdma_set_option` with `RDMA_OPTION_ID_TOS` could be used to set the UP
- When creating QPs, the `sl` field in `ibv_modify_qp` command represents the UP
- Indicating the TC
  - After mapping the `skb_priority` to UP, one should map the UP into a TC. This assigns the user priority to a specific hardware traffic class. In order to do that, `mlnx_qos` should be used. `mlnx_qos` gets a list of a mapping between UPs to TCs. For example, `mlnx_qos -ieth0 -p 0,0,0,0,1,1,1,1` maps UPs 0-3 to TC0, and Ups 4-7 to TC1.

#### 4.2.3.6 Quality of Service Properties

The different QoS properties that can be assigned to a TC are:

- Strict Priority (see “[Strict Priority](#)”)
- Minimal Bandwidth Guarantee (ETS) (see “[Minimal Bandwidth Guarantee \(ETS\)](#)”)
- Rate Limit (see “[Rate Limit](#)”)

##### Strict Priority

When setting a TC's transmission algorithm to be 'strict', then this TC has absolute (strict) priority over other TC strict priorities coming before it (as determined by the TC number: TC 7 is highest priority, TC 0 is lowest). It also has an absolute priority over non strict TCs (ETS).

This property needs to be used with care, as it may easily cause starvation of other TCs.

A higher strict priority TC is always given the first chance to transmit. Only if the highest strict priority TC has nothing more to transmit, will the next highest TC be considered.

Non strict priority TCs will be considered last to transmit.

This property is extremely useful for low latency low bandwidth traffic. Traffic that needs to get immediate service when it exists, but is not of high volume to starve other transmitters in the system.

##### Minimal Bandwidth Guarantee (ETS)

After servicing the strict priority TCs, the amount of bandwidth (BW) left on the wire may be split among other TCs according to a minimal guarantee policy.

If, for instance, TC0 is set to 80% guarantee and TC1 to 20% (the TCs sum must be 100), then the BW left after servicing all strict priority TCs will be split according to this ratio.

Since this is a minimal guarantee, there is no maximum enforcement. This means, in the same example, that if TC1 did not use its share of 20%, the remainder will be used by TC0.

##### Rate Limit

Rate limit defines a maximum bandwidth allowed for a TC. Please note that 10% deviation from the requested values is considered acceptable.

### 4.2.3.7 Quality of Service Tools

#### mlnx\_qos

`mlnx_qos` is a centralized tool used to configure QoS features of the local host. It communicates directly with the driver thus does not require setting up a DCBX daemon on the system.

The `mlnx_qos` tool enables the administrator of the system to:

- Inspect the current QoS mappings and configuration  
The tool will also display maps configured by TC and `vconfig set_egress_map` tools, in order to give a centralized view of all QoS mappings.
- Set UP to TC mapping
- Assign a transmission algorithm to each TC (strict or ETS)
- Set minimal BW guarantee to ETS TCs
- Set rate limit to TCs



For unlimited ratelimit set the ratelimit to 0.

#### Usage:

```
mlnx_qos -i <interface> [options]
```

#### Options:

```
--version      show program's version number and exit
-h, --help     show this help message and exit
-p LIST, --prio_tc=LIST
               maps UPs to TCs. LIST is 8 comma separated TC numbers.
               Example: 0,0,0,0,1,1,1,1 maps UPs 0-3 to TC0, and UPs
               4-7 to TC1
-s LIST, --tsa=LIST
               Transmission algorithm for each TC. LIST is comma
               separated algorithm names for each TC. Possible
               algorithms: strict, etc. Example: ets,strict,ets sets
               TC0,TC2 to ETS and TC1 to strict. The rest are
               unchanged.
-t LIST, --tcbw=LIST
               Set minimal guaranteed %BW for ETS TCs. LIST is comma
               separated percents for each TC. Values set to TCs that
               are not configured to ETS algorithm are ignored, but
               must be present. Example: if TC0,TC2 are set to ETS,
               then 10,0,90 will set TC0 to 10% and TC2 to 90%.
               Percents must sum to 100.
-r LIST, --ratelimit=LIST
               Rate limit for TCs (in Gbps). LIST is a comma
               separated Gbps limit for each TC. Example: 1,8,8 will
               limit TC0 to 1Gbps, and TC1,TC2 to 8 Gbps each.
-i INTF, --interface=INTF
               Interface name
-a
               Show all interface's TCs
```

**Get Current Configuration:**

```
tc: 0 ratelimit: unlimited, tsa: strict
  up: 0
    skprio: 0
    skprio: 1
    skprio: 2 (tos: 8)
    skprio: 3
    skprio: 4 (tos: 24)
    skprio: 5
    skprio: 6 (tos: 16)
    skprio: 7
    skprio: 8
    skprio: 9
    skprio: 10
    skprio: 11
    skprio: 12
    skprio: 13
    skprio: 14
    skprio: 15
  up: 1
  up: 2
  up: 3
  up: 4
  up: 5
  up: 6
  up: 7
```

**Set ratelimit. 3Gbps for tc0 4Gbps for tc1 and 2Gbps for tc2:**

```
tc: 0 ratelimit: 3 Gbps, tsa: strict
  up: 0
    skprio: 0
    skprio: 1
    skprio: 2 (tos: 8)
    skprio: 3
    skprio: 4 (tos: 24)
    skprio: 5
    skprio: 6 (tos: 16)
    skprio: 7
    skprio: 8
    skprio: 9
    skprio: 10
    skprio: 11
    skprio: 12
    skprio: 13
    skprio: 14
    skprio: 15
  up: 1
  up: 2
  up: 3
  up: 4
  up: 5
  up: 6
  up: 7
```

Configure QoS. map UP 0,7 to tc0, 1,2,3 to tc1 and 4,5,6 to tc 2. set tc0,tc1 as ets and tc2 as strict. divide ets 30% for tc0 and 70% for tc1:

```
mlnx_qos -i eth3 -s ets,ets,strict -p 0,1,1,1,2,2,2 -t 30,70
tc: 0 ratelimit: 3 Gbps, tsa: ets, bw: 30%
    up: 0
        skprio: 0
        skprio: 1
        skprio: 2 (tos: 8)
        skprio: 3
        skprio: 4 (tos: 24)
        skprio: 5
        skprio: 6 (tos: 16)
        skprio: 7
        skprio: 8
        skprio: 9
        skprio: 10
        skprio: 11
        skprio: 12
        skprio: 13
        skprio: 14
        skprio: 15
    up: 7
tc: 1 ratelimit: 4 Gbps, tsa: ets, bw: 70%
    up: 1
    up: 2
    up: 3
tc: 2 ratelimit: 2 Gbps, tsa: strict
    up: 4
    up: 5
    up: 6
```

### tc and tc\_wrap.py

The 'tc' tool is used to setup `sk_prio` to UP mapping, using the `mqprio` queue discipline.

In kernels that do not support `mqprio` (such as 2.6.34), an alternate mapping is created in `sysfs`. The 'tc\_wrap.py' tool will use either the `sysfs` or the 'tc' tool to configure the `sk_prio` to UP mapping.

Usage:

```
tc_wrap.py -i <interface> [options]
```

Options:

```
--version          show program's version number and exit
-h, --help         show this help message and exit
-u SKPRIO_UP, --skprio_up=SKPRIO_UP  maps sk_prio to UP. LIST is <=16 comma separated
                                         UP. index of element is sk_prio.
-i INTF, --interface=INTF  Interface name
```

Example: set `skprio 0-2` to `UP0`, and `skprio 3-7` to `UP1` on `eth4`

```
UP 0
    skprio: 0
    skprio: 1
    skprio: 2 (tos: 8)
    skprio: 7
    skprio: 8
    skprio: 9
    skprio: 10
    skprio: 11
    skprio: 12
    skprio: 13
    skprio: 14
    skprio: 15

UP 1
    skprio: 3
    skprio: 4 (tos: 24)
    skprio: 5
    skprio: 6 (tos: 16)

UP 2
UP 3
UP 4
UP 5
UP 6
UP 7
```

### Additional Tools

tc tool compiled with the `sch_mqprio` module is required to support kernel v2.6.32 or higher. This is a part of `iproute2` package v2.6.32-19 or higher. Otherwise, an alternative custom `sysfs` interface is available.

- `mlnx_qos` tool (package: `ofed-scripts`) requires `python >= 2.5`
- `tc_wrap.py` (package: `ofed-scripts`) requires `python >= 2.5`

## 4.2.4 Ethernet Time-Stamping

Time stamping is the process of keeping track of the creation of a packet. A time-stamping service supports assertions of proof that a datum existed before a particular time. Incoming packets are time-stamped before they are distributed on the PCI depending on the congestion in the PCI buffers. Outgoing packets are time-stamped very close to placing them on the wire.

### 4.2.4.1 Enabling Time Stamping

Time-stamping is off by default and should be enabled before use.

- *To enable time stamping for a socket:*



- Call `setsockopt()` with `SO_TIMESTAMPING` and with the following flags:

```
SOF_TIMESTAMPING_TX_HARDWARE: try to obtain send time stamp in hardware
SOF_TIMESTAMPING_TX_SOFTWARE: if SOF_TIMESTAMPING_TX_HARDWARE is off or
                               fails, then do it in software
SOF_TIMESTAMPING_RX_HARDWARE: return the original, unmodified time stamp
                               as generated by the hardware
SOF_TIMESTAMPING_RX_SOFTWARE: if SOF_TIMESTAMPING_RX_HARDWARE is off or
                               fails, then do it in software

SOF_TIMESTAMPING_RAW_HARDWARE: return original raw hardware time stamp
SOF_TIMESTAMPING_SYS_HARDWARE: return hardware time stamp transformed to
                               the system time base
SOF_TIMESTAMPING_SOFTWARE:    return system time stamp generated in
                               software

SOF_TIMESTAMPING_TX/RX determine how time stamps are generated.
SOF_TIMESTAMPING_RAW/SYS determine how they are reported
```

➤ **To enable time stamping for a net device:**

Admin privileged user can enable/disable time stamping through calling `ioctl(sock, SIOCSHWSTAMP, &ifreq)` with following values:

Send side time sampling:

- Enabled by `ifreq.hwstamp_config.tx_type` when

```

/* possible values for hwstamp_config->tx_type */
enum hwstamp_tx_types {
    /*
     * No outgoing packet will need hardware time stamping;
     * should a packet arrive which asks for it, no hardware
     * time stamping will be done.
     */
    HWTSTAMP_TX_OFF,

    /*
     * Enables hardware time stamping for outgoing packets;
     * the sender of the packet decides which are to be
     * time stamped by setting %SOF_TIMESTAMPING_TX_SOFTWARE
     * before sending the packet.
     */
    HWTSTAMP_TX_ON,

    /*
     * Enables time stamping for outgoing packets just as
     * HWTSTAMP_TX_ON does, but also enables time stamp insertion
     * directly into Sync packets. In this case, transmitted Sync
     * packets will not received a time stamp via the socket error
     * queue.
     */
    HWTSTAMP_TX_ONESTEP_SYNC,
};

```

Note: for send side time stamping currently only `HWTSTAMP_TX_OFF` and `HWTSTAMP_TX_ON` are supported.

**Receive side time sampling:**

- Enabled by `ifreq.hwtstamp_config.rx_filter` when

```

/* possible values for hwtstamp_config->rx_filter */
enum hwtstamp_rx_filters {
    /* time stamp no incoming packet at all */
    HWTSTAMP_FILTER_NONE,

    /* time stamp any incoming packet */
    HWTSTAMP_FILTER_ALL,

    /* return value: time stamp all packets requested plus some others */
    HWTSTAMP_FILTER_SOME,

    /* PTP v1, UDP, any kind of event packet */
    HWTSTAMP_FILTER_PTP_V1_L4_EVENT,
    /* PTP v1, UDP, Sync packet */
    HWTSTAMP_FILTER_PTP_V1_L4_SYNC,
    /* PTP v1, UDP, Delay_req packet */
    HWTSTAMP_FILTER_PTP_V1_L4_DELAY_REQ,
    /* PTP v2, UDP, any kind of event packet */
    HWTSTAMP_FILTER_PTP_V2_L4_EVENT,
    /* PTP v2, UDP, Sync packet */
    HWTSTAMP_FILTER_PTP_V2_L4_SYNC,
    /* PTP v2, UDP, Delay_req packet */
    HWTSTAMP_FILTER_PTP_V2_L4_DELAY_REQ,

    /* 802.AS1, Ethernet, any kind of event packet */
    HWTSTAMP_FILTER_PTP_V2_L2_EVENT,
    /* 802.AS1, Ethernet, Sync packet */
    HWTSTAMP_FILTER_PTP_V2_L2_SYNC,
    /* 802.AS1, Ethernet, Delay_req packet */
    HWTSTAMP_FILTER_PTP_V2_L2_DELAY_REQ,

    /* PTP v2/802.AS1, any layer, any kind of event packet */
    HWTSTAMP_FILTER_PTP_V2_EVENT,
    /* PTP v2/802.AS1, any layer, Sync packet */
    HWTSTAMP_FILTER_PTP_V2_SYNC,
    /* PTP v2/802.AS1, any layer, Delay_req packet */
    HWTSTAMP_FILTER_PTP_V2_DELAY_REQ,
};

```

Note: for receive side time stamping currently only `HWTSTAMP_FILTER_NONE` and `HWTSTAMP_FILTER_ALL` are supported.

**4.2.4.2 Getting Time Stamping**

Once time stamping is enabled time stamp is placed in the socket Ancillary data. `recvmsg()` can be used to get this control message for regular incoming packets. For send time stamps the outgoing packet is looped back to the socket's error queue with the send time stamp(s) attached. It can be received with `recvmsg(flags=MSG_ERRQUEUE)`. The call returns the original outgoing packet data including all headers prepended down to and including the link layer, the `scm_timestamping` control message and a `sock_extended_err` control message with `ee_errno==ENOMSG` and `ee_origin==SO_EE_ORIGIN_TIMESTAMPING`. A socket with such

a pending bounced packet is ready for reading as far as select() is concerned. If the outgoing packet has to be fragmented, then only the first fragment is time stamped and returned to the sending socket.



When time-stamping is enabled, VLAN stripping is disabled. For more info please refer to Documentation/networking/timestamping.txt in kernel.org

#### 4.2.4.3 Querying Time Stamping Capabilities via ethtool

➤ *To display Time Stamping capabilities via ethtool:*

- Show Time Stamping capabilities

```
ethtool -T eth<x>
```

Example:

```
ethtool -T eth0
Time stamping parameters for p2p1:
Capabilities:
    hardware-transmit      (SOF_TIMESTAMPING_TX_HARDWARE)
    software-transmit      (SOF_TIMESTAMPING_TX_SOFTWARE)
    hardware-receive       (SOF_TIMESTAMPING_RX_HARDWARE)
    software-receive       (SOF_TIMESTAMPING_RX_SOFTWARE)
    software-system-clock  (SOF_TIMESTAMPING_SOFTWARE)
    hardware-raw-clock     (SOF_TIMESTAMPING_RAW_HARDWARE)
PTP Hardware Clock: none
Hardware Transmit Timestamp Modes:
    off                    (HWTSTAMP_TX_OFF)
    on                    (HWTSTAMP_TX_ON)
Hardware Receive Filter Modes:
    none                   (HWTSTAMP_FILTER_NONE)
    all                    (HWTSTAMP_FILTER_ALL)
```

#### 4.2.5 RoCE Time Stamping



RoCE Time Stamping is currently at beta level.  
Please be aware that everything listed here is subject to change.

RoCE Time Stamping allows you to stamp packets when they are sent to the wire / received from the wire. The time stamp is given in a raw hardware cycles, but could be easily converted into hardware referenced nanoseconds based time. Additionally, it enables you to query the hardware for the hardware time, thus stamp other application's event and compare time.

##### 4.2.5.1 Query Capabilities

Time stamping is available if and only the hardware reports it is capable of reporting it. To verify whether RoCE Time Stamping is available, run `ibv_ex_query_device`.

For example:

```
struct ibv_exp_device_attr attr;
ibv_exp_query_device(context, &attr);
if (attr.comp_mask & IBV_EXP_DEVICE_ATTR_WITH_TIMESTAMP_MASK) {
    if (attr.timestamp_mask) {
        /* Time stamping is supported with mask attr.timestamp_mask */
    }
}
if (attr.comp_mask & IBV_EXP_DEVICE_ATTR_WITH_HCA_CORE_CLOCK) {
    if (attr.hca_core_clock) {
        /* reporting the device's clock is supported. */
        /* attr.hca_core_clock is the frequency in MHZ */
    }
}
```

#### 4.2.5.2 Creating Time Stamping Completion Queue

To get time stamps, a suitable extended Completion Queue (CQ) must be created via a special call to `ibv_create_cq_ex` verb.

```
cq_init_attr.flags = IBV_CQ_TIMESTAMP;
cq_init_attr.comp_mask = IBV_CQ_INIT_ATTR_FLAGS;
cq = ibv_create_cq_ex(context, cqe, node, NULL, 0, &cq_init_attr);
```



This CQ cannot report SL or SLID information. The value of `s1` and `s1_id` fields in `struct ibv_wc_ex` are invalid. Only the fields indicated by the `wc_flags` field in `struct ibv_wc_ex` contains a valid and usable value.



When using Time Stamping, several fields of `struct ibv_wc_ex` are not available resulting in RoCE UD / RoCE traffic with VLANs failure.

#### 4.2.5.3 Polling a Completion Queue

Polling a CQ for time stamp is done via the `ibv_poll_cq_ex` verb.

```
ret = ibv_poll_cq_ex(cq, 1, &wc_ex, sizeof(wc_ex));
if (ret > 0) {
    /* CQ returned a wc */
    if (wc_ex.wc_flags & IBV_WC_WITH_TIMESTAMP) {
        /* This wc contains a timestamp */
        timestamp = wc_ex.timestamp;
        /* Timestamp is given in raw hardware time */
    }
}
```



CQs that are opened with the `ibv_create_cq_ex` verb should be always be polled with the `ibv_poll_cq_ex` verb.

#### 4.2.5.4 Querying the Hardware Time

Querying the hardware for time is done via the `ibv_query_values_ex` verb.

For example:

```
ret = ibv_query_values_ex(context, IBV_VALUES_HW_CLOCK, &queried_values);
if (!ret && queried_values.comp_mask & IBV_VALUES_HW_CLOCK)
queried_time = queried_values.hwclock;
```

To change the queried time in nanoseconds resolution, use the `IBV_VALUES_HW_CLOCK_NS` flag along with the `hwclock_ns` field.

```
ret = ibv_query_values_ex(context, IBV_VALUES_HW_CLOCK_NS, &queried_values);
if (!ret && queried_values.comp_mask & IBV_VALUES_HW_CLOCK_NS)
queried_time_ns = queried_values.hwclock_ns;
```



Querying the Hardware Time is available only on physical functions / native machines.

#### 4.2.6 Flow Steering



Flow Steering is applicable to the `mlx4` driver only.

Flow steering is a new model which steers network flows based on flow specifications to specific QPs. Those flows can be either unicast or multicast network flows. In order to maintain flexibility, domains and priorities are used. Flow steering uses a methodology of flow attribute, which is a combination of L2-L4 flow specifications, a destination QP and a priority. Flow steering rules may be inserted either by using `ethtool` or by using InfiniBand verbs. The verbs abstraction uses a different terminology from the flow attribute (`ibv_flow_attr`), defined by a combination of specifications (`struct ibv_flow_spec_*`).

##### 4.2.6.1 Enable/Disable Flow Steering

Flow Steering is disabled by default and regular L2 steering is performed instead (B0 Steering). When using SR-IOV, flow steering is enabled if there is an adequate amount of space to store the flow steering table for the guest/master.

###### ➤ *To enable Flow Steering:*

- Step 1.** Open the `/etc/modprobe.d/mlnx.conf` file.
- Step 2.** Set the parameter `log_num_mgm_entry_size` to `-1` by writing the option `mlx4_core log_num_mgm_entry_size=-1`.
- Step 3.** Restart the driver

###### ➤ *To disable Flow Steering:*

- Step 1.** Open the `/etc/modprobe.d/mlnx.conf` file.
- Step 2.** Remove the options `mlx4_core log_num_mgm_entry_size= -1`.
- Step 3.** Restart the driver

### 4.2.6.2 Flow Domains and Priorities

Flow steering defines the concept of domain and priority. Each domain represents a user agent that can attach a flow. The domains are prioritized. A higher priority domain will always supersede a lower priority domain when their flow specifications overlap. Setting a lower priority value will result in higher priority.

In addition to the domain, there is priority within each of the domains. Each domain can have at most  $2^{12}$  priorities in accordance with its needs.

The following are the domains at a descending order of priority:

- **User Verbs** allows a user application QP to be attached into a specified flow when using `ibv_create_flow` and `ibv_destroy_flow` verbs
- `ibv_create_flow`

```
struct ibv_flow *ibv_create_flow(struct ibv_qp *qp, struct ibv_flow_attr *flow)
```

#### Input parameters:

- `struct ibv_qp` - the attached QP.
- `struct ibv_flow_attr` - attaches the QP to the flow specified. The flow contains mandatory control parameters and optional L2, L3 and L4 headers. The optional headers are detected by setting the size and `num_of_specs` fields:

`struct ibv_flow_attr` can be followed by the optional flow headers structs:

```
struct ibv_flow_spec_ib
struct ibv_flow_spec_eth
struct ibv_flow_spec_ipv4
struct ibv_flow_spec_tcp_udp
```

For further information, please refer to the `ibv_create_flow` man page.



Be advised that from MLNX\_OFED v2.0-3.0.0 and higher, the parameters (both the value and the mask) should be set in big-endian format.

Each header struct holds the relevant network layer parameters for matching. To enforce the match, the user sets a mask for each parameter. The supported masks are:

- All one mask - include the parameter value in the attached rule  
**Note:** Since the VLAN ID in the Ethernet header is 12bit long, the following parameter should be used: `flow_spec_eth.mask.vlan_tag = htons(0x0fff)`.
- All zero mask - ignore the parameter value in the attached rule

When setting the flow type to `NORMAL`, the incoming traffic will be steered according to the rule specifications. `ALL_DEFAULT` and `MC_DEFAULT` rules options are valid only for Ethernet link type since InfiniBand link type packets always include QP number.

For further information, please refer to the relevant man pages.

- `ibv_destroy_flow`

```
int ibv_destroy_flow(struct ibv_flow *flow_id)
```

#### Input parameters:

`ibv_destroy_flow` requires `struct ibv_flow` which is the return value of `ibv_create_flow` in case of success.

**Output parameters:**

Returns 0 on success, or the value of errno on failure.

For further information, please refer to the `ibv_destroy_flow` man page.

- **Ethtool**

Ethtool domain is used to attach an RX ring, specifically its QP to a specified flow.

Please refer to the most recent ethtool manpage for all the ways to specify a flow.

Examples:

- `ethtool -U eth5 flow-type ether dst 00:11:22:33:44:55 loc 5 action 2`  
All packets that contain the above destination MAC address are to be steered into rx-ring 2 (its underlying QP), with priority 5 (within the ethtool domain)
- `ethtool -U eth5 flow-type tcp4 src-ip 1.2.3.4 dst-port 8888 loc 5 action 2`  
All packets that contain the above destination IP address and source port are to be steered into rx-ring 2. When destination MAC is not given, the user's destination MAC is filled automatically.
- `ethtool -u eth5`  
Shows all of ethtool's steering rule

When configuring two rules with the same priority, the second rule will overwrite the first one, so this ethtool interface is effectively a table. Inserting Flow Steering rules in the kernel requires support from both the ethtool in the user space and in kernel (v2.6.28).

**MLX4 Driver Support**

The mlx4 driver supports only a subset of the flow specification the ethtool API defines. Asking for an unsupported flow specification will result with an “invalid value” failure.

The following are the flow specific parameters:

**Table 6 - Flow Specific Parameters**

	ether	tcp4/udp4	ip4
Mandatory	dst		src-ip/dst-ip
Optional	vlan	src-ip, dst-ip, src-port, dst-port, vlan	src-ip, dst-ip, vlan

- **RFS**

RFS is an in-kernel-logic responsible for load balancing between CPUs by attaching flows to CPUs that are used by flow's owner applications. This domain allows the RFS mechanism to use the flow steering infrastructure to support the RFS logic by implementing the `ndo_rx_flow_steer`, which, in turn, calls the underlying flow steering mechanism with the RFS domain.

Enabling the RFS requires enabling the 'ntuple' flag via the ethtool,

For example, to enable ntuple for eth0, run:

```
ethtool -K eth0 ntuple on
```



RFS requires the kernel to be compiled with the `CONFIG_RFS_ACCEL` option. This options is available in kernels 2.6.39 and above. Furthermore, RFS requires Device Managed Flow Steering support.



RFS cannot function if LRO is enabled. LRO can be disabled via ethtool.

- **All of the rest**

The lowest priority domain serves the following users:

- **The `mlx4 Ethernet driver`** attaches its unicast and multicast MACs addresses to its QP using L2 flow specifications
- **The `mlx4 ipoib driver`** when it attaches its QP to his configured GIDS



Fragmented UDP traffic cannot be steered. It is treated as 'other' protocol by hardware (from the first packet) and not considered as UDP traffic.



Use of `libibverbs v2.0-3.0.0` and `libmlx4 v2.0-3.0.0` and higher as of `MLNX_OFED v2.0-3.0.0` is recommended due to API changes.

## 4.2.7 Single Root IO Virtualization (SR-IOV)

### 4.2.7.1 System Requirements

To set up an SR-IOV environment, the following is required:

- `MLNX_OFED` Driver
- A server/blade with an SR-IOV-capable motherboard BIOS
- Hypervisor that supports SR-IOV such as: Red Hat Enterprise Linux Server Version 6.\*
- Mellanox ConnectX® Adapter Card family with SR-IOV capability

### 4.2.7.2 Setting Up SR-IOV

Depending on your system, perform the steps below to set up your BIOS. For further information, please refer to the appropriate BIOS User Manual:

- Step 4.** Enable “Virtualization Technology” in System BIOS => Processor setting. See Appendix A.5, “SR-IOV Configuration,” on page 104. Enable “SR-IOV Global Enable” in system BIOS - integrated Devices section
- Step 5.** Install a hypervisor that supports SR-IOV.
- Step 6.** Depending on your system, update the `/boot/grub/grub.conf` file to include a similar command line load parameter for the Linux kernel.

For example, to Intel systems, add:

```
default=0
timeout=5
splashimage=(hd0,0)/grub/splash.xpm.gz
hiddenmenu
title Red Hat Enterprise Linux Server (2.6.32-36.x86-645)
    root (hd0,0)
    kernel /vmlinuz-2.6.32-36.x86-64 ro root=/dev/VolGroup00/LogVol100 rhgb quiet
    intel_iommu=ona
    initrd /initrd-2.6.32-36.x86-64.img
```

- a. Please make sure the parameter "intel\_iommu=on" exists when updating the /boot/grub/grub.conf file, otherwise SR-IOV cannot be loaded.

- Step 7.** Enable SRIOV number of functions in PCI. Note: by default 8 virtual functions are enabled in PCI level.
- Step 8.** Create the text file /etc/modprobe.d/mlx4\_core.conf if it does not exist, otherwise delete its contents.
- Step 9.** Insert an "option" line in the /etc/modprobe.d/mlx4\_core.conf file to set the number of VFs, the protocol type per port, and the allowed number of virtual functions to be used by the physical function driver (probe\_vf).

For example:

```
options mlx4_core num_vfs=5 port_type_array=1,2 probe_vf=1
```

Parameter	Recommended Value
num_vfs	<ul style="list-style-type: none"> <li>• If absent, or zero: no VFs will be available</li> <li>• If its value is a single number in the range of 0-63: The driver will enable the num_vfs VFs on the HCA and this will be applied to all ConnectX® HCAs on the host.</li> <li>• If its format is a string: The string specifies the num_vfs parameter separately per installed HCA.</li> <li>• The string format is: "bb:dd.f-v,bb:dd.f-v,..." <ul style="list-style-type: none"> <li>• bb:dd.f = bus:device.function of the PF of the HCA</li> <li>• v = number of VFs to enable for that HCA</li> </ul> </li> </ul> <p>For example:</p> <ul style="list-style-type: none"> <li>• num_vfs=5 - The driver will enable 5 VFs on the HCA and this will be applied to all ConnectX® HCAs on the host</li> <li>• num_vfs=00:04.0-5,00:07.0-8 - The driver will enable 5 VFs on the HCA positioned in BDF 00:04.0 and 8 on the one in 00:07.0)</li> </ul> <p><b>Note:</b> PFs not included in the above list will not have SR-IOV enabled.</p>

Parameter	Recommended Value
port_type_array	<p>Specifies the protocol type of the ports. It is either one array of 2 port types 't1,t2' for all devices or list of BDF to port_type_array 'bb:dd.f-t1;t2,...'. (string)  Valid port types: 1-ib, 2-eth, 3-auto, 4-N/A  If only a single port is available, use the N/A port type for port2 (e.g '1,4').  Note: For dual port Ethernet only devices set port_type_array=2,2.</p>
probe_vf	<ul style="list-style-type: none"> <li>If absent or zero: no VF interfaces will be loaded in the Hypervisor/host</li> <li>If num0_vfs is a number in the range of 1-63, the driver running on the Hypervisor will itself activate that number of VFs. All these VFs will run on the Hypervisor. This number will apply to all ConnectX® HCAs on that host.</li> <li>If its format is a string: the string specifies the probe_vf parameter separately per installed HCA.</li> <li>The string format is: "bb:dd.f-v,bb:dd.f-v,... <ul style="list-style-type: none"> <li>bb:dd.f = bus:device.function of the PF of the HCA</li> <li>v = number of VFs to use in the PF driver for that HCA</li> </ul> </li> </ul> <p>For example:</p> <ul style="list-style-type: none"> <li>probe_vfs=5 - The PF driver will activate 5 VFs on the HCA and this will be applied to all ConnectX® HCAs on the host</li> <li>probe_vfs=00:04.0-5,00:07.0-8 - The PF driver will activate 5 VFs on the HCA positioned in BDF 00:04.0 and 8 for the one in 00:07.0)</li> </ul> <p><b>Note:</b> PFs not included in the above list will not activate any of their VFs in the PF driver.</p>

The example above loads the driver with 5 VFs (num\_vfs). The standard use of a VF is a single VF per a single VM. However, the number of VFs varies upon the working mode requirements.

The protocol types are:

**Step 10.** Reboot the server.



If the Mellanox card is not available after rebooting when SR-IOV is enabled (and many virtual functions were configured), the following steps can be taken:

1. Disable SR-IOV in the System BIOS
2. Reboot the server
3. Verify the adapter becomes available
4. Configure less SR-IOV virtual functions for the Mellanox adapters. Recommendation is less than 126 total functions (virtual and physical) for Mellanox devices.
5. Enable SR-IOV in the System BIOS

**Step 11.** Load the driver and verify the SR-IOV is supported. Run:

```
lspci | grep Mellanox
```

Where:

- "03:00" represents the Physical Function
- "03:00.X" represents the Virtual Function connected to the Physical Function

### 4.2.7.3 Enabling SR-IOV and Para Virtualization on the Same Setup

➤ *To enable SR-IOV and Para Virtualization on the same setup:*

**Step 1.** Create a bridge.

```
vim /etc/sysconfig/network-scripts/ifcfg-bridge0
DEVICE=bridge0
TYPE=Bridge
IPADDR=12.195.15.1
NETMASK=255.255.0.0
BOOTPROTO=static
ONBOOT=yes
NM_CONTROLLED=no
DELAY=0
```

**Step 2.** Change the related interface (in the example below bridge0 is created over eth5).

```
DEVICE=eth5
BOOTPROTO=none
STARTMODE=on
HWADDR=00:02:c9:2e:66:52
TYPE=Ethernet
NM_CONTROLLED=no
ONBOOT=yes
BRIDGE=bridge0
```

**Step 3.** Restart the service network.

**Step 4.** Attach a virtual NIC to VM.

```
ifconfig -a
...
eth6      Link encap:Ethernet  HWaddr 52:54:00:E7:77:99
          inet addr:13.195.15.5  Bcast:13.195.255.255  Mask:255.255.0.0
          inet6 addr: fe80::5054:ff:fee7:7799/64  Scope:Link
          UP BROADCAST RUNNING MULTICAST  MTU:1500  Metric:1
          RX packets:481 errors:0 dropped:0 overruns:0 frame:0
          TX packets:450 errors:0 dropped:0 overruns:0 carrier:0
          collisions:0 txqueuelen:1000
          RX bytes:22440 (21.9 KiB)  TX bytes:19232 (18.7 KiB)
          Interrupt:10 Base address:0xa000
...
```

### 4.2.7.4 Assigning a Virtual Function to a Virtual Machine


This section will describe a mechanism for adding a SR-IOV VF to a Virtual Machine.

#### Assigning the SR-IOV Virtual Function to the Red Hat KVM VM Server

**Step 1.** Run the virt-manager.

**Step 2.** Double click on the virtual machine and open its Properties.

**Step 3.** Go to Details->Add hardware ->PCI host device.



**Step 4.** Choose a Mellanox virtual function according to its PCI device (e.g., 00:03.1)

**Step 5.** If the Virtual Machine is up reboot it, otherwise start it.

**Step 6.** Log into the virtual machine and verify that it recognizes the Mellanox card. Run:

```
lspci | grep Mellanox
```

**Step 7.** Add the device to the `/etc/sysconfig/network-scripts/ifcfg-ethX` configuration file. The MAC address for every virtual function is configured randomly, therefore it is not necessary to add it.

#### 4.2.7.5 Uninstalling SR-IOV Driver

➤ *To uninstall SR-IOV driver, perform the following:*

**Step 1.** For Hypervisors, detach all the Virtual Functions (VF) from all the Virtual Machines (VM) or stop the Virtual Machines that use the Virtual Functions.

**Please be aware**, stopping the driver when there are VMs that use the VFs, will cause machine to hang.

**Step 2.** Run the script below. Please be aware, uninstalling the driver deletes the entire driver's file, but does not unload the driver.

```
[root@swl022 ~]# /usr/sbin/ofed_uninstall.sh
This program will uninstall all OFED packages on your machine.
Do you want to continue?[y/N]:y
Running /usr/sbin/vendor_pre_uninstall.sh
Removing OFED Software installations
Running /bin/rpm -e --allmatches kernel-ib kernel-ib-devel libibverbs libibverbs-devel
libibverbs-devel-static libibverbs-utils libmlx4 libmlx4-devel libibcm libibcm-devel
libibumad libibumad-devel libibumad-static libibmad libibmad-devel libibmad-static
librdmacm librdmacm-utils librdmacm-devel ibacm opensm-libs opensm-devel perftest comp
compat-dapl compat-dapl-devel dapl dapl-devel dapl-devel-static dapl-utils srptools infini
band-diags-guest ofed-scripts opensm-devel
warning: /etc/infiniband/openib.conf saved as /etc/infiniband/openib.conf.rpmsave
Running /tmp/2818-ofed_vendor_post_uninstall.sh
```

**Step 3.** Restart the server.

### 4.2.7.6 Configuring Pkeys and GUIDs under SR-IOV



Only the PFs are set via this mechanism. The VFs inherit their port types from their associated PF.

#### 4.2.7.6.1 SRIOV sysfs Administration Interfaces on the Hypervisor

Administration of GUIDs and PKeys is done via the sysfs interface in the Hypervisor (Dom0). This interface is under:

```
/sys/class/infiniband/<infiniband device>/iov
```

Under this directory, the following subdirectories can be found:

- `ports` - The actual (physical) port resource tables
  - Port GUID tables:
    - `ports/<n>/gids/<n>` where  $0 \leq n \leq 127$  (the physical port gids)
    - `ports/<n>/admin_guids/<n>` where  $0 \leq n \leq 127$  (allows examining or changing the administrative state of a given GUID)
    - `ports/<n>/pkeys/<n>` where  $0 \leq n \leq 126$  (displays the contents of the physical pkey table)
- `<pci id>` directories - one for Dom0 and one per guest. Here, you may see the mapping between virtual and physical pkey indices, and the virtual to physical gid 0.

Currently, the GUID mapping cannot be modified, but the pkey virtual to physical mapping can .

These directories have the structure:

- `<pci_id>/port/<m>/gid_idx/0` where  $m = 1..2$  (this is read-only)
- and
- `<pci_id>/port/<m>/pkey_idx/<n>`, where  $m = 1..2$  and  $n = 0..126$

For instructions on configuring `pkey_idx`, please see below.

#### 4.2.7.6.2 Configuring an Alias GUID (under `ports/<n>/admin_guids`)

- Step 1.** Determine the GUID index of the PCI Virtual Function that you want to pass through to a guest.

For example, if you want to pass through PCI function 02:00.3 to a certain guest, you initially need to see which GUID index is used for this function.

To do so:

```
cat /sys/class/infiniband/iov/0000:02:00.3/port/<port_num>/gid_idx/0
```

The value returned will present which guid index to modify on Dom0.

- Step 2.** Modify the physical GUID table via the `admin_guids` sysfs interface.

To configure the GUID at index `<n>` on port `<port_num>`:

```
cd /sys/class/infiniband/mlx4_0/iov/ports/<port_num>/admin_guids
echo <your desired guid> > n
```

**Example:**

```
cd /sys/class/infiniband/mlx4_0/iov/ports/1/admin_guids
echoa "0x002ffff8118" > 3
```

- a. echo "0x0" means let the SM assign a value to that GUID
- echo "0xffffffffffffff" means delete that GUID
- echo <any other value> means request the SM to assign this GUID to this index

**Step 3.** Read the administrative status of the GUID index.

To read the administrative status of GUID index *m* on port *n*:

```
cat /sys/class/infiniband/mlx4_0/iov/ports/<n>/admin_guids/<m>
```

**Step 4.** Check the operational state of a GUID.

```
/sys/class/infiniband/mlx4_0/iov/ports/<n>/gids (where n = 1 or 2)
```

The values indicate what gids are actually configured on the firmware/hardware, and all the entries are R/O.

**Step 5.** Compare the value you read under the "admin\_guids" directory at that index with the value under the "gids" directory, to verify the change requested in Step 3 has been accepted by the SM, and programmed into the hardware port GUID table.

If the value under `admin_guids/<m>` is different that the value under `gids/<m>`, the request is still in progress.

**4.2.7.7 Ethernet Virtual Function Configuration when Running SR-IOV****4.2.7.7.1 VLAN Guest Tagging (VGT) and VLAN Switch Tagging (VST)**

When running ETH ports on VGT, the ports may be configured to simply pass through packets as is from VFs (Vlan Guest Tagging), or the administrator may configure the Hypervisor to silently force packets to be associated with a VLAN/Qos (Vlan Switch Tagging).

In the latter case, untagged or priority-tagged outgoing packets from the guest will have the VLAN tag inserted, and incoming packets will have the VLAN tag removed. Any vlan-tagged packets sent by the VF are silently dropped. The default behavior is VGT.

The feature may be controlled on the Hypervisor from userspace via `iprout2 / netlink`:

```
ip link set { dev DEVICE | group DEVGROUP } [ { up | down } ]
...
[ vf NUM [ mac LLADDR ]
  [ vlan VLANID [ qos VLAN-QOS ] ]
  ...
  [ spoofchk { on | off } ] ]
...
```

use:

```
ip link set dev <PF device> vf <NUM> vlan <vlan_id> [qos <qos>]
```

- where NUM = 0..max-vf-num
- vlan\_id = 0..4095 (4095 means "set VGT")
- qos = 0..7

For example:

- `ip link set dev eth2 vf 2 qos 3` - sets VST mode for VF #2 belonging to PF eth2, with qos = 3
- `ip link set dev eth2 vf 2 4095` - sets mode for VF 2 back to VGT

#### 4.2.7.7.2 Additional Ethernet VF Configuration Options

- Guest MAC configuration

By default, guest MAC addresses are configured to be all zeroes. In the `mlx_ofed` guest driver, if a guest sees a zero MAC, it generates a random MAC address for itself. If the administrator wishes the guest to always start up with the same MAC, he/she should configure guest MACs before the guest driver comes up.

The guest MAC may be configured by using:

```
ip link set dev <PF device> vf <NUM> mac <LLADDR>
```

For legacy guests, which do not generate random MACs, the administrator should always configure their MAC addresses via `ip link`, as above.

- Spoof checking

Spoof checking is currently available only on upstream kernels newer than 3.1.

```
ip link set dev <PF device> vf <NUM> spoofchk [on | off]
```

#### 4.2.7.7.3 RoCE Support

RoCE is supported on Virtual Functions and VLANs may be used with it. For RoCE, the hypervisor GID table size is of 16 entries while the VFs share the remaining 112 entries. When the number of VFs is larger than 56 entries, some of them will have GID table with only a single entry which is inadequate if VF's Ethernet device is assigned with an IP address.

When setting `num_vfs` in `mlx4_core` module parameter it is important to check that the number of the assigned IP addresses per VF does not exceed the limit for GID table size.

## 4.2.8 Ethtool

`ethtool` is a standard Linux utility for controlling network drivers and hardware, particularly for wired Ethernet devices. It can be used to:

- Get identification and diagnostic information
- Get extended device statistics
- Control speed, duplex, autonegotiation and flow control for Ethernet devices
- Control checksum offload and other hardware offload features
- Control DMA ring sizes and interrupt moderation



The following are the ethtool supported options:

**Table 7 - ethtool Supported Options**

Options	Description
ethtool -i eth<x>	<p>Checks driver and device information.</p> <p>For example:</p> <pre>#&gt; ethtool -i eth2 driver: mlx4_en (MT_ODD0120009_CX3) version: 2.1.6 (Aug 2013) firmware-version: 2.30.3000 bus-info: 0000:1a:00.0</pre>
ethtool -k eth<x>	Queries the stateless offload status.
ethtool -K eth<x> [rx on off] [tx on off] [sg on off] [tso on off] [lro on off] [gro on off] [gso on off]	<p>Sets the stateless offload status.</p> <p>TCP Segmentation Offload (TSO), Generic Segmentation Offload (GSO): increase outbound throughput by reducing CPU overhead. It works by queuing up large buffers and letting the network interface card split them into separate packets.</p> <p>Large Receive Offload (LRO): increases inbound throughput of high-bandwidth network connections by reducing CPU overhead. It works by aggregating multiple incoming packets from a single stream into a larger buffer before they are passed higher up the networking stack, thus reducing the number of packets that have to be processed. LRO is available in kernel versions &lt; 3.1 for untagged traffic.</p> <p><b>Note:</b> LRO will be done whenever possible. Otherwise GRO will be done. Generic Receive Offload (GRO) is available throughout all kernels.</p>
ethtool -c eth<x>	Queries interrupt coalescing settings.
ethtool -C eth<x> adaptive-rx on off	<p>Enables/disables adaptive interrupt moderation.</p> <p>By default, the driver uses adaptive interrupt moderation for the receive path, which adjusts the moderation time to the traffic pattern.</p>
ethtool -C eth<x> [pkt-rate-low N] [pkt-rate-high N] [rx-usecs-low N] [rx-usecs-high N]	<p>Sets the values for packet rate limits and for moderation time high and low values.</p> <ul style="list-style-type: none"> <li>• Above an upper limit of packet rate, adaptive moderation will set the moderation time to its highest value.</li> <li>• Below a lower limit of packet rate, the moderation time will be set to its lowest value.</li> </ul>

**Table 7 - ethtool Supported Options**

Options	Description
ethtool -C eth<x> [rx-usecs N] [rx-frames N]	Sets the interrupt coalescing settings when the adaptive moderation is disabled. <b>Note:</b> usec settings correspond to the time to wait after the *last* packet is sent/received before triggering an interrupt.
ethtool -a eth<x>	Queries the pause frame settings.
ethtool -A eth<x> [rx on/off] [tx on/off]	Sets the pause frame settings.
ethtool -g eth<x>	Queries the ring size values.
ethtool -G eth<x> [rx <N>] [tx <N>]	Modifies the rings size.
ethtool -S eth<x>	Obtains additional device statistics.
ethtool -t eth<x>	Performs a self diagnostics test.
ethtool -s eth<x> msglvl [N]	Changes the current driver message level.
ethtool -T eth<x>	Shows time stamping capabilities
ethtool -l eth<x>	Shows the number of channels
ethtool -L eth<x> [rx <N>] [tx <N>]	Sets the number of channels

#### 4.2.9 Ethernet Performance Counters

Counters are used to provide information about how well an operating system, an application, a service, or a driver is performing. The counter data helps determine system bottlenecks and fine-tune the system and application performance. The operating system, network, and devices provide counter data that an application can consume to provide users with a graphical view of how well the system is performing.

The counter index is a QP attribute given in the QP context. Multiple QPs may be associated with the same counter set, If multiple QPs share the same counter its value represents the cumulative total.

- ConnectX®-3 support 127 different counters which allocated:
  - 4 counters reserved for PF - 2 counters for each port
  - 2 counters reserved for VF - 1 counter for each port
  - All other counters if exist are allocated by demand
- RoCE counters are available only through sysfs located under:
  - # /sys/class/infiniband/mlx4\_\*/ports/\*/counters/
  - # /sys/class/infiniband/mlx4\_\*/ports/\*/counters\_ext/

- Physical Function can also read Virtual Functions' port counters through sysfs located under:
  - # /sys/class/net/eth\*/vf\*\_statistics/

To display the network device Ethernet statistics, you can run:

```
Ethtool -S <devname>
```

**Table 8 - Port IN Counters**

Counter	Description
rx_packets	Total packets successfully received.
rx_bytes	Total bytes in successfully received packets.
rx_multicast_packets	Total multicast packets successfully received.
rx_broadcast_packets	Total broadcast packets successfully received.
rx_errors	Number of receive packets that contained errors preventing them from being deliverable to a higher-layer protocol.
rx_dropped	Number of receive packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol.
rx_length_errors	Number of received frames that were dropped due to an error in frame length
rx_over_errors	Number of received frames that were dropped due to overflow
rx_crc_errors	Number of received frames with a bad CRC that are not runts, jabbers, or alignment errors
rx_jabbers	Number of received frames with a length greater than MTU octets and a bad CRC
rx_in_range_length_error	Number of received frames with a length/type field value in the (decimal) range [1500:46] (42 is also counted for VLANtagged frames)
rx_out_range_length_error	Number of received frames with a length/type field value in the (decimal) range [1535:1501]
rx_lt_64_bytes_packets	Number of received 64-or-less-octet frames
rx_127_bytes_packets	Number of received 65-to-127-octet frames
rx_255_bytes_packets	Number of received 128-to-255-octet frames
rx_511_bytes_packets	Number of received 256-to-511-octet frames
rx_1023_bytes_packets	Number of received 512-to-1023-octet frames
rx_1518_bytes_packets	Number of received 1024-to-1518-octet frames

**Table 8 - Port IN Counters**

Counter	Description
rx_1522_bytes_packets	Number of received 1519-to-1522-octet frames
rx_1548_bytes_packets	Number of received 1523-to-1548-octet frames
rx_gt_1548_bytes_packets	Number of received 1549-or-greater-octet frames

**Table 9 - Port OUT Counters**

Counter	Description
tx_packets	Total packets successfully transmitted.
tx_bytes	Total bytes in successfully transmitted packets.
tx_multicast_packets	Total multicast packets successfully transmitted.
tx_broadcast_packets	Total broadcast packets successfully transmitted.
tx_errors	Number of frames that failed to transmit
tx_dropped	Number of transmitted frames that were dropped
tx_lt_64_bytes_packets	Number of transmitted 64-or-less-octet frames
tx_127_bytes_packets	Number of transmitted 65-to-127-octet frames
tx_255_bytes_packets	Number of transmitted 128-to-255-octet frames
tx_511_bytes_packets	Number of transmitted 256-to-511-octet frames
tx_1023_bytes_packets	Number of transmitted 512-to-1023-octet frames
tx_1518_bytes_packets	Number of transmitted 1024-to-1518-octet frames
tx_1522_bytes_packets	Number of transmitted 1519-to-1522-octet frames
tx_1548_bytes_packets	Number of transmitted 1523-to-1548-octet frames
tx_gt_1548_bytes_packets	Number of transmitted 1549-or-greater-octet frames

**Table 10 - Port VLAN Priority Tagging (where <i> is in the range 0...7)**

Counter	Description
rx_prio_<i>_packets	Total packets successfully received with priority i.
rx_prio_<i>_bytes	Total bytes in successfully received packets with priority i.
rx_novlan_packets	Total packets successfully received with no VLAN priority.

**Table 10 - Port VLAN Priority Tagging (where <i> is in the range 0...7)**

Counter	Description
rx_novlan_bytes	Total bytes in successfully received packets with no VLAN priority.
tx_prio_<i>_packets	Total packets successfully transmitted with priority i.
tx_prio_<i>_bytes	Total bytes in successfully transmitted packets with priority i.
tx_novlan_packets	Total packets successfully transmitted with no VLAN priority.
tx_novlan_bytes	Total bytes in successfully transmitted packets with no VLAN priority.

**Table 11 - Port Pause (where <i> is in the range 0...7)**

Counter	Description
rx_pause_prio_<i>	The total number of PAUSE frames received from the far-end port
rx_pause_duration_prio_<i>	The total time in microseconds that far-end port was requested to pause transmission of packets.
rx_pause_transition_prio_<i>	The number of receiver transitions from XON state (paused) to XOFF state (non-paused)
tx_pause_prio_<i>	The total number of PAUSE frames sent to the far-end port
tx_pause_duration_prio_<i>	The total time in microseconds that transmission of packets has been paused
tx_pause_transition_prio_<i>	The number of transmitter transitions from XON state (paused) to XOFF state (non-paused)

**Table 12 - VPort Statistics (where <i>=<empty\_string> is the PF, and ranges 1...NumOfVf per VF)**

Counter	Description
vport<i>_rx_unicast_packets	Unicast packets received successfully
vport<i>_rx_unicast_bytes	Unicast packet bytes received successfully
vport<i>_rx_multicast_packets	Multicast packets received successfully
vport<i>_rx_multicast_bytes	Multicast packet bytes received successfully

**Table 12 - VPort Statistics (where <i>=<empty\_string> is the PF, and ranges 1...NumOfVf per VF)**

Counter	Description
vport<i>_rx_broadcast_packets	Broadcast packets received successfully
vport<i>_rx_broadcast_bytes	Broadcast packet bytes received successfully
vport<i>_rx_dropped	Received packets discarded due to out-of-buffer condition
vport<i>_rx_errors	Received packets discarded due to receive error condition
vport<i>_tx_unicast_packets	Unicast packets sent successfully
vport<i>_tx_unicast_bytes	Unicast packet bytes sent successfully
vport<i>_tx_multicast_packets	Multicast packets sent successfully
vport<i>_tx_multicast_bytes	Multicast packet bytes sent successfully
vport<i>_tx_broadcast_packets	Broadcast packets sent successfully
vport<i>_tx_broadcast_bytes	Broadcast packet bytes sent successfully
vport<i>_tx_errors	Packets dropped due to transmit errors

**Table 13 - SW Statistics**

Counter	Description
rx_lro_aggregated	Number of packets aggregated
rx_lro_flushed	Number of LRO flush to the stack
rx_lro_no_desc	Number of times LRO description was not found
rx_alloc_failed	Number of times failed preparing receive descriptor
rx_csum_good	Number of packets received with good checksum
rx_csum_none	Number of packets received with no checksum indication
tx_chksum_offload	Number of packets transmitted with checksum offload
tx_queue_stopped	Number of times transmit queue suspended
tx_wake_queue	Number of times transmit queue resumed
tx_timeout	Number of times transmitter timeout

**Table 13 - SW Statistics**

Counter	Description
tx_tso_packets	Number of packet that were aggregated

**Table 14 - Per Ring (SW) Statistics (where <i> is the ring I – per configuration)**

Counter	Description
rx<i>_packets	Total packets successfully received on ring i
rx<i>_bytes	Total bytes in successfully received packets on ring i.
tx<i>_packets	Total packets successfully transmitted on ring i.
tx<i>_bytes	Total bytes in successfully transmitted packets on ring i.

## 4.3 VMware Driver

For VMware, download and install the latest Mellanox Ethernet Driver for VMware vSphere 5.X from the VMware support site: <http://www.vmware.com/support>.

### 4.3.1 Installing and Running the Driver

#### 4.3.1.1 Installing and Running the VIB Driver on ESXi-5.x

1. Log into the VMware ESXi server machine as root.
2. You can either:
  - a. Remove any earlier version of the driver from your VMware ESXi server machine prior to installing the new version. Run:

```
#> esxcli software vib list
#> esxcli software vib remove -n net-mlx4-en
```

- b. Install the mlx4\_en driver VIB package. Run:

```
#> esxcli software vib install -v <vib_url>
```

- c. Reboot ESXi server (The driver will be loaded automatically).

OR

- a. Update the driver. Run:

```
#> esxcli software vib update -v <vib_url>
```

- b. Reboot ESXi server (The driver will be loaded automatically).

» **To verify that the driver is loaded, run:**

```
#> vmkload_mod -l | grep mlx4_en
```

» ***To query network uplinks installed on your machine, run:***

```
#> esxcli network nic list
```

The number of uplinks claimed by MLX4\_EN driver should be displayed.



In Non Multifunction Mode, port 2 is identified as a pseudo device. Therefore devices are not seen by vSphere when added as uplink.



### 4.3.2 Installing and Running the offline\_bundle Driver on ESXi-5.x

1. Copy the offline\_bundle zip file to ESXi 5.0 machine and extract its contents.
2. You can install the driver in one of the following ways:
  - a. Remove any earlier version of the driver from your VMware ESXi server machine prior to installing the new version. Run:

```
#> esxcli software vib list
#> esxcli software vib remove -n net-mlx4-en
```

- b. Install the mlx4\_en driver offline\_bundle package. Run:

```
#> esxcli software vib install -d
<path>/mlx4_en-mlnx-1.6.1.2-offline_bundle-471530.zip
```

- c. Reboot ESXi server. (The driver will be loaded automatically).

OR

- a. Update the driver. Run:

```
#> esxcli software vib update -n net-mlx4-en -d
<path>/mlx4_en-mlnx-1.6.1.2-offline_bundle-471530.zip
```

- b. Reboot ESXi server. (The driver will be loaded automatically).

» **To verify that the driver is loaded, run:**

```
#> vmkload_mod -l | grep mlx4_en
```

» **To query network uplinks installed on your machine, run:**

```
#> esxcli network nic list
```

The number of uplinks claimed by MLX4\_EN driver should be displayed.



In Non Multifunction Mode, port 2 is identified as a pseudo device. Therefore devices are not seen by vSphere when added as uplink.

### 4.3.3 Removing the VIB/offline\_bundle Driver

» **To remove the VIB/offline\_bundle driver package from the ESXi server machine, run:**

```
#> esxcli software vib remove -n net-mlx4-en
```

## 4.4 Windows

For Windows, download and install the latest Mellanox OFED for Windows (WinOF) software package available at the Dell support site <http://www.dell.com/support>.

## 4.4.1 Installation Requirements

### 4.4.1.1 Required Disk Space for Installation

- 200 MB

### 4.4.2 Software Requirements

- Microsoft Windows Server operating system



For the list of supported operating systems, please refer to the release notes file accompanying the Windows Driver Dell Update Package on the Dell support site.

### 4.4.2.1 Installer Privileges

- The installation requires administrator privileges on the target machine

## 4.4.3 Downloading Mellanox WinOF

**Step 1.** Verify that the machine architecture.

Open a CMD console (Click Start ' Run and enter CMD). Enter the following command.

```
> echo %PROCESSOR_ARCHITECTURE%
```

- On an x64 (64-bit) machine, the output will be "AMD64".
- On an x86 (32-bit) machine, the output will be "x86"

**Step 2.** Download the Windows Driver Dell Update Package to your host.

The software release name has the format Network\_Driver\_NNNNN\_WN64\_XX.XX.XX.EXE.

**Step 3.** Use an md5 checksum utility such as Microsoft File Checksum Integrity Verifier to confirm the file integrity of the downloaded file. Checksum information is on the Dell support site <http://www.dell.com/support>.



For specific installation instructions, please refer to the applicable software download on the Dell support site: <http://www.dell.com/support>.

## 4.4.4 Installing Mellanox WinOF

This section provides instructions for two types of installation:

1. Attended Installation - An installation procedure that requires frequent user intervention.
2. Unattended Installation - An automated installation procedure that requires no user intervention.

### 4.4.4.1 Attended Installation

Double click the Dell Update Package and follow the GUI instructions to install Mellanox\_WinOF.

#### 4.4.4.2 Unattended Installation

From a CMD console, execute the Dell Update Package silently.

```
Network_Driver_NNNNN_WN_XX.XX.XX.EXE /s
```



For a list of Dell Update Package command line options, execute the Dell Update Package with the option "/?" or "/h"

```
Network_Driver_NNNNN_WN_XX.XX.XX.EXE /?
```

#### 4.4.5 Uninstalling Mellanox WinOF

To uninstall Mellanox\_WinOF on a single node, perform one of the following options:

Option 1. Click Start-> Control Panel-> Programs and Features. (NOTE: This requires elevated administrator privileges)

Option 2. Double click the Dell Update Package and follow the instructions of the install wizard.

Option 3. Click Start-> All Programs-> Mellanox Technologies-> MLNX\_WinOF-> Uninstall MLNX\_WinOF.

#### 4.4.6 Windows Performance Tuning

The user can configure the Ethernet adapter by setting some registry keys. The registry keys may affect Ethernet performance.

➤ *To improve performance, activate the performance tuning tool as follows:*

- Step 1. Start the "Device Manager" (open a command line window and enter: devmgmt.msc).
- Step 2. Open "Network Adapters".
- Step 3. Right click the relevant Ethernet adapter and select Properties.
- Step 4. Select the "Advanced" tab
- Step 5. Modify performance parameters (properties) as desired

### 4.5 WinOF Features

#### 4.5.1 Configuring Quality of Service (QoS)

Prior to configuring Quality of Service, you must install Data Center Bridging using one of the following methods:

➤ *To install the Data Center Bridging using the Server Manager:*

- Step 1. Open the 'Server Manager'.
- Step 2. Select 'Add Roles and Features'.
- Step 3. Click Next.
- Step 4. Select 'Features' on the left panel
- Step 5. Check the 'Data Center Bridging' checkbox.
- Step 6. Click 'Install'.

➤ *To install the Data Center Bridging using PowerShell:*

**Step 1.** Enable Data Center Bridging (DCB).

```
PS $ Install-WindowsFeature Data-Center-Bridging
```

**➤ To configure QoS on the host:**

The procedure below is not saved after the system is rebooted. Creating a script using the steps below and running it on the local machine is recommended. Please see the procedure below on how to add the script to the local machine startup scripts.

**Step 1.** Change the Windows PowerShell execution policy.

```
PS $ Set-ExecutionPolicy AllSigned
```

**Step 2.** Remove the entire previous QoS configuration.

```
PS $ Remove-NetQoSTrafficClass
PS $ Remove-NetQoSPolicy -Confirm:$False
```

**Step 3.** Set the DCBX Willing parameter to false as Mellanox drivers do not support this feature.

```
PS $ set-NetQoSDbxSetting -Willing 0
```

**Step 4.** Create a Quality of Service (QoS) policy and tag each type of traffic with the relevant priority.

In this example, TCP/UDP priority 1, ND/NDK priority 3 is used.

```
PS $ New-NetQoSPolicy "SMB" -store Activestore -NetDirectPortMatchCondition 445 -
PriorityValue8021Action 3
PS $ New-NetQoSPolicy "DEFAULT" -store Activestore -Default -PriorityValue8021Action 3
PS $ New-NetQoSPolicy "TCP" -store Activestore -IPProtocolMatchCondition TCP -
PriorityValue8021Action 1
PS $ New-NetQoSPolicy "UDP" -store Activestore -IPProtocolMatchCondition UDP -
PriorityValue8021Action 1
```

**Step 5.** [Optional] If VLANs are used, mark the egress traffic with the relevant VlanID. The NIC is referred as "Ethernet 4" in the examples below.

```
PS $ Set-NetAdapterAdvancedProperty -Name "Ethernet 4" -RegistryKeyword "VlanID" -RegistryValue "55"
```

**Step 6.** [Optional] Configure the IP address for the NIC.

If DHCP is used, the IP address will be assigned automatically.

```
PS $ Set-NetIPInterface -InterfaceAlias "Ethernet 4" -DHCP Disabled
PS $ Remove-NetIPAddress -InterfaceAlias "Ethernet 4" -AddressFamily IPv4 -Confirm:$false
PS $ New-NetIPAddress -InterfaceAlias "Ethernet 4" -IPAddress 192.168.1.10 -PrefixLength 24 -Type Unicast
```

**Step 7.** [Optional] Set the DNS server (assuming its IP address is 192.168.1.2).

```
PS $ Set-DnsClientServerAddress -InterfaceAlias "Ethernet 4" -ServerAddresses 192.168.1.2
```



After establishing the priorities of ND/NDK traffic, the priorities must have PFC enabled on them.

**Step 8.** Disable Priority Flow Control (PFC) for all other priorities except for 3.

```
PS $ Disable-NetQoSFlowControl 0,1,2,4,5,6,7
```

**Step 9.** Enable QoS on the relevant interface.

```
PS $ Enable-NetAdapterQos -InterfaceAlias "Ethernet 4"
```

**Step 10.** Enable PFC on priority 3.

```
PS $ Enable-NetQosFlowControl -Priority 3
```

➤ **To add the script to the local machine startup scripts:**

**Step 1.** From the PowerShell invoke.

```
gpedit.msc
```

**Step 2.** In the pop-up window, under the 'Computer Configuration' section, perform the following:

1. Select Windows Settings
2. Select Scripts (Startup/Shutdown)
3. Double click Startup to open the Startup Properties
4. Click Add
5. Browse for the script's location.
6. Click OK

## 4.5.2 RDMA over Converged Ethernet

### 4.5.2.1 RoCE Configuration

In order to function reliably, RoCE requires a form of flow control. While it is possible to use global flow control, this is normally undesirable, for performance reasons.

The normal and optimal way to use RoCE is to use Priority Flow Control (PFC). To use PFC, it must be enabled on all endpoints and switches in the flow path.

In the following section instructions are presented to configure PFC on Mellanox ConnectX™ cards. There are multiple configuration steps required, all of which may be performed via PowerShell. Therefore, although each step is presented individually, you may ultimately choose to write a PowerShell script to do them all in one step. Note that administrator privileges are required for these steps.

#### Prerequisites

The following are the driver's prerequisites in order to set or configure RoCE:

- All InfiniBand verbs applications which run over InfiniBand verbs should work on RoCE links if they use GRH headers.

#### Configuring Windows Host

➤ **To configure Priority flow control (PFC) on the host, perform the steps below:**

**Step 1.** Remove all the previous QoS configuration.

```
PS $ Remove-NetQosTrafficClass
PS $ Remove-NetQosPolicy -Confirm:$False
```

**Step 2.** Enable PowerShell to configure DCB.

```
PS $ Set-ExecutionPolicy Unrestricted
```

**Step 3.** Enable the Data Center Bridging (DCB) feature which is mandatory for PFC.

```
PS $ Install-WindowsFeature Data-Center-Bridging
```

- Step 4.** The DCBX Willing parameter should be set to false as Mellanox drivers do not support this feature.

```
PS $ set-NetQosDcbxSetting -Willing 0
```



Since PFC is all about controlling flow control at the granularity of traffic priority, it is necessary to assign different priorities to different kinds of network traffic.

The idea, as far as RoCE configuration goes, is to assign all ND/NDK traffic (since this is the only kind of traffic that can take advantage of RoCE) to one or more chosen priorities, and then enable PFC on those priorities.

In addition, one may wish to assign non-ND/NDK traffic to other priorities, so that only the RoCE traffic gets PFC.

- Step 5.** Create a Quality of Service (QoS) policy and tag each type of traffic with the relevant priority  
NOTE: In this example, TCP/UDP priority 1, ND/NDK priority 3 is used.

```
PS $ New-NetQosPolicy "SMB" -NetDirectPortMatchCondition 445 -
PriorityValue8021Action 3
PS $ New-NetQosPolicy "DEFAULT" -Default -PriorityValue8021Action 3
PS $ New-NetQosPolicy "TCP" -IPProtocolMatchCondition TCP -
PriorityValue8021Action 1
PS $ New-NetQosPolicy "UDP" -IPProtocolMatchCondition UDP -
PriorityValue8021Action 1
```

- Step 6.** If VLANs are used, Mark the egress traffic with the relevant VlanID.  
NOTE: The NIC is assumed as "Ethernet 4" as shown in the examples below.

```
PS $ Set-NetAdapterAdvancedProperty -Name "Ethernet 4" -RegistryKeyword "VlanID"
-RegistryValue "55"
```

- Step 7.** Configure the IP address for the NIC.

NOTE: If DHCP is used, the IP address will be assigned automatically.

```
PS $ Set-NetIPInterface -InterfaceAlias "Ethernet 4" -DHCP Disabled
PS $ Remove-NetIPAddress -InterfaceAlias "Ethernet 4" -AddressFamily IPv4 -Con-
firm:$false
PS $ New-NetIPAddress -InterfaceAlias "Ethernet 4" -IPAddress 192.168.1.10 -Pre-
fixLength 24 -Type Unicast
```

- Step 8.** Set the DNS server (assuming its IP address is 192.168.1.2).

```
PS $ Set-DnsClientServerAddress -InterfaceAlias "Ethernet 4"
-ServerAddresses 192.168.1.2
```



After establishing the priorities of ND/NDK traffic, the priorities must have PFC enabled on them.

- Step 9.** Enable Priority Flow Control (PFC) on priority 3, run.

```
PS $ Enable-NetQosFlowControl -Priority 3
```

- Step 10.** Disable PFC for all other priorities except for 3.

```
PS $ Disable-NetQosFlowControl 0,1,2,4,5,6,7
```

**Step 11.** Enable QoS on the relevant interface.

```
PS $ Enable-NetAdapterQos -InterfaceAlias "Ethernet 4"
```

#### Using Global Pause Flow Control (GFC)

➤ *To use Global Pause Flow Control (GFC) mode, disable QoS and Priority:*

```
PS $ Disable-NetQosFlowControl
PS $ Disable-NetAdapterQos
```

### 4.5.2.2 Configuring Router (PFC only)

The router uses L3's DSCP value to mark the egress traffic of L2 PCP. The required mapping, maps the three most significant bits of the DSCP into the PCP. This is the default behavior, and no additional configuration is required.

#### Copying Port Control Protocol (PCP) between Subnets

The captured PCP option from the Ethernet header of the incoming packet can be used to set the PCP bits on the outgoing Ethernet header.

### 4.5.3 Deploying Windows Server 2012 and 2012 R2 with SMB Direct

The Server Message Block (SMB) protocol is a network file sharing protocol implemented in Microsoft Windows. The set of message packets that defines a particular version of the protocol is called a dialect.

The Microsoft SMB protocol is a client-server implementation and consists of a set of data packets, each containing a request sent by the client or a response sent by the server.

SMB protocol is used on top of the TCP/IP protocol or other network protocols. Using the SMB protocol allows applications to access files or other resources on a remote server, to read, create, and update them. In addition, it enables communication with any server program that is set up to receive an SMB client request.

#### 4.5.3.1 Hardware and Software Prerequisites

The following are hardware and software prerequisites:

- Two or more machines running Windows Server 2012 and above
- One or more Mellanox ConnectX@-3 network adapter for each server

#### 4.5.3.2 SMB Configuration Verification

##### Verifying SMB Configuration

Use the following PowerShell cmdlets to verify SMB Multichannel is enabled, confirm the adapters are recognized by SMB and that their RDMA capability is properly identified.

- On the SMB client, run the following PowerShell cmdlets:

```
Get-SmbClientConfiguration | Select EnableMultichannel
Get-SmbClientNetworkInterface
```

- On the SMB server, run the following PowerShell cmdlets:

```
Get-SmbServerConfiguration | Select EnableMultichannel
```

```
Get-SmbServerNetworkInterface
netstat.exe -xan | ? {$_ -match "445"}
```

The NETSTAT command confirms if the File Server is listening on the RDMA interfaces.

### 4.5.3.3 Verifying SMB Connection

➤ *To verify the SMB connection on the SMB client:*

- Step 1.** Copy the large file to create a new session with the SMB Server.
- Step 2.** Open a PowerShell window while the copy is ongoing.
- Step 3.** Verify the SMB Direct is working properly and that the correct SMB dialect is used.

```
Get-SmbConnection
Get-SmbMultichannelConnection
netstat.exe -xan | ? {$_ -match "445"}
```



If there is no activity while running the commands above, you might get an empty list due to session expiration and no current connections.

### 4.5.3.4 Verifying SMB Events that Confirm RDMA Connection

➤ *To confirm RDMA connection, verify the SMB events:*

- Step 1.** Open a PowerShell window on the SMB client.
- Step 2.** Run the following cmdlets.  
NOTE: Any RDMA-related connection errors will be displayed as well.

```
Get-WinEvent -LogName Microsoft-Windows-SMBClient/Operational | ? Message -match "RDMA"
```



## 5 Remote Boot

### 5.1 iSCSI Boot

#### 5.1.1 RHEL6.4/RHEL6.5

##### 5.1.1.1 Configuring the iSCSI Target Machine

➤ *To configure the iSCSI target:*

**Step 1.** Download the IET target software from.

<http://sourceforge.net/projects/iscsitarget/files/iscsitarget/1.4.20.2/>

**Step 2.** Install iSCSI target and additional required software on target server.

```
[root@sqa030 ~]# yum install kernel-devel openssl-devel gcc rpm-build
[root@sqa030 tmp]# tar xzvf iscsitarget-1.4.20.2.tar.gz
[root@sqa030 tmp]# cd iscsitarget-1.4.20.2/
[root@sqa030 iscsitarget-1.4.20.2]# make && make install
```

**Step 3.** Create the IQN in the ietd configuration file.

```
Target iqn.2013-10.qalab.com:sqa030.prt9
Lun 0 Path=/dev/cciss/c0d0p9,Type=fileio,IOMode=wb
MaxConnections          1      # Number of connections/session. We only support 1
InitialR2T              Yes    # Wait first for R2T
ImmediateData          Yes    # Data can accompany command
MaxRecvDataSegmentLength 8192  # Max data per PDU to receive
MaxXmitDataSegmentLength 8192  # Max data per PDU to transmit
MaxBurstLength          262144 # Max data per sequence (R2T)
FirstBurstLength        65536  # Max unsolicited data sequence
DefaultTime2Wait        2      # Secs wait for ini to log out   Not used
DefaultTime2Retain      20     # Secs keep cmnds after log out Not used
MaxOutstandingR2T       1      # Max outstanding R2Ts per cmdnd
DataPDUInOrder          Yes    # Data in PDUs is ordered. We only support ordered
DataSequenceInOrder    Yes    # PDUs in sequence are ordered. We only support
                                ordered
ErrorRecoveryLevel      0      # We only support level 0
HeaderDigest            NONE   # PDU header checksum algo list. None or CRC32C
                                # If only one is set then the initiator must agree
                                # to it or the connection will fail
DataDigest              NONE   # PDU data checksum algo list   Same as above
MaxSessions             0      # Maximum number of sessions to this target 0 =
                                unlimited
NOPInterval             0      # Send a NOP-In ping each after that many seconds
                                if the
                                # conn is otherwise idle 0 = off
NOPTimeout              0      # Wait that many seconds for a response on a
                                NOP-In ping
                                # If 0 or > NOPInterval, NOPInterval is used!
                                # Various target parameters
Wthreads                8      # Number of IO threads
QueuedCommands          32     # Number of queued commands
```



The local Hard Disk partition assigned to the LUN (/dev/cciss/c0d0p9 in the example above) must not contain any valuable data, as this data will be destroyed by the installation process taking place later in this procedure

**Step 4.** Edit the /etc/sysconfig/iscsi-target file as follow.

```
OPTIONS="-c /etc/iet/ietd.conf --address=12.7.6.30"
```

**Step 5.** Start the iSCSI target service.

```
[root@sqa030 ~]# /etc/init.d/iscsi-target start
```

**Step 6.** Perform a sanity check by connecting to the iSCSI target from a remote PC on the 10GE network link.

### 5.1.1.2 Installing RHEL6.4/RHEL6.5 on a Remote Storage over iSCSI

**Step 1.** Reboot the diskless client and perform a PXE boot with FlexBoot.

This is not an iSCSI boot, rather a regular PXE initiated network deployment of RHEL6.4/RHEL6.5. In the DHCP server configuration, the PXELINUX (pxelinux.0) and a RHEL 6.4 distribution media will be provided for network installation.


The clients' HDD was removed beforehand; therefore the RHEL installer (also know as Anaconda) will ask to locate a HDD. The Anaconda's built-in iSCSI discovery will be used to connect to the iSCSI target LUN partition. For further information, please refer to: [https://access.redhat.com/site/documentation/en-US/Red\\_Hat\\_Enterprise\\_Linux/6/html-single/Installation\\_Guide/index.html#ISCSI\\_disks](https://access.redhat.com/site/documentation/en-US/Red_Hat_Enterprise_Linux/6/html-single/Installation_Guide/index.html#ISCSI_disks)

**Step 2.** Select the Network Interface (the same interface which was used by FlexBoot during PXE boot stage) for the installation process once prompted.


**Step 3.** Select the type of Installation Media access.

In this example, NFS is used, which also requires us to enter the NFS server name be entered, and the directory path to the installation media on the NFS.

**Step 4.** Select **Specialized Storage Devices**.




**Step 5.** Click on the + **Add Advanced Target** button.



**Step 6.** In the Advanced Storage Options window perform the following:

- Step a. Select the Add Iscsi Target option.
- Step b. Check the **Bind targets to network interfaces** checkbox.
- Step c. Click **+Add drive** button.



**Step 7.** Enter the IP address of iSCSI target.

Optionally, you may choose to enter a customized Initiator Name and select the necessary CHAP authentication of choice. Please refer to Section 5.1.1.3, “SAN-Booting the Diskless Client with FlexBoot,” on page 70 for further information.

In the example below, iSCSI Initiator Name is left with the default value given by the installer and iSCSI discovery authentication is left with No authentication.



**Step 8.** Check the relevant Node Name to log in.

If as a result of the discovery, multiple Node Names are found, select the one that is relevant.





**Step 9. Click Login.**


A successful login is mandatory to proceed. A failure at this stage is probably a result of a target or network configuration error and recovery/troubleshooting that is out of the scope of this document.

**Step 10. Make sure a new storage LUN appears in the Other AN Devices tab.**

A successful LUN discovery is mandatory to proceed. A failure at this stage is probably a result of a target or network configuration error and recovery/troubleshooting that is out of the scope of this document.

**Step 11. Click Next.****Step 12. Select Fresh Installation and proceed with the Installation**

**Step 13.** Select the **Use All Space** option.



**Step 14.** Click **Next** and proceed with the Installation.

**Step 15.** Select the **Basic Server** option.


This is only one of the options that can be chosen, not the mandatory one.



**Step 16.** Check the **Customize Now** checkbox.

**Step 17.** Click **Next**.

**Step 18.** Select **Infiniband Support** and **iSCSI Storage Client**.



**Step 19.** Click **Next**. Allow the installation to reach completion.

### 5.1.1.3 SAN-Booting the Diskless Client with FlexBoot

When the installation process is completed, the client will ask to reboot. At that point, the DHCP server configuration for that client needs to be changed so that when it PXE boots again, it will get the root-path IQN and LUN information from the DHCP server.

For further information, please refer to section DHCP Configuration for iSCSI Boot with Flex-Boot (PXE SAN Boot).



Restart your DHCP service after changing the dhcp configuration file.

- Reboot the system



The expected result is that for the diskless PXE client to boot the newly installed RHEL6.4/ RHEL6.5 from the iSCSI storage, and become an operational environment, accessible from any remote PC via ssh over 10GbE IP network

## 5.1.2 Booting Windows from an iSCSI Target

### 5.1.2.1 Configuring the WDS, DHCP and iSCSI Servers

#### Configuring the WDS Server

➤ *To configure the WDS server:*

1. Install the WDS server.
2. Extract the Mellanox drivers to a local directory using the '-a' parameter.

For boot over Ethernet, when using adapter cards with older firmware version than 2.30.8000, onewill need to extract the PXE package, otherwise use Mellanox WinOF VPI package.

Example:

```
Mellanox.msi.exe -a
```

3. Add the Mellanox driver to boot.wim<sup>1</sup>.

```
dism /Mount-Wim /WimFile:boot.wim /index:2 /MountDir:mnt
dism /Image:mnt /Add-Driver /Driver:drivers /recurse
dism /Unmount-Wim /MountDir:mnt /commit
```

#### 4. Add the Mellanox driver to install.wim<sup>1</sup>.

```
dism /Mount-Wim /WimFile:install.wim /index:4 /MountDir:mnt
dism /Image:mnt /Add-Driver /Driver:drivers /recurse
dism /Unmount-Wim /MountDir:mnt /commit
```

#### 5. Add the new boot and install images to WDS.

For additional details on WDS, please refer to:

<http://technet.microsoft.com/en-us/library/jj648426.aspx>

### Configuring iSCSI Target

#### ➤ To configure iSCSI Target:

1. Install iSCSI Target (e.g StartWind).
2. Add to the iSCSI target initiators the IP addresses of the iSCSI clients.

### Configuring the DHCP Server

#### ➤ To configure the DHCP server:

1. Install a DHCP server.
2. Add to IPv4 a new scope.
3. Add iSCSI boot client identifier (MAC/GUID) to the DHCP reservation.
4. Add to the reserved IP address the following options:

**Table 15 - Reserved IP Address Options**

Option	Name	Value
017	Root Path	<b>iscsi:11.4.12.65:::iqn:2011-01:iscsiboot</b> Assuming the iSCSI target IP is: <b>11.4.12.65</b> and the Target Name: <b>iqn:2011-01:iscsiboot</b>
060	PXEClient	PXEClient
066	Boot Server Host Name	WDS server IP address
067	Boot File Name	boot\x86\wdsnbp.com

### 5.1.2.2 Configuring the Client Machine

#### ➤ To configuring your client:

5. Verify the Mellanox adapter card is updated with a firmware version that supports iSCSI boot.



Please refer to the firmware release notes to see if a particular firmware supports iSCSI boot or PXE capability.

6. Set the “Mellanox Adapter Card” as the first boot device in the BIOS settings boot order.

1. Use 'index:2' for Windows setup and 'index:1' for WinPE.

1. When adding the Mellanox driver to install.wim, verify the appropriate index for the OS distribution is used. To check the OS run 'imagex /info install.wim'.

7. In Device Settings for the adapter, confirm that Legacy Boot Protocol is set to iSCSI and confirm that the Option ROM setting is set to Enabled.

### 5.1.2.3 Installing iSCSI

1. Reboot your iSCSI client.
2. Press F12 when asked to proceed to iSCSI boot.

```
VirtualMedia File View Macros Tools Power Chat Performance Help
[Link:down, TX:0 TXE:0 RX:0 RXE:0]
Waiting for link-up on net1... ok
DHCP (net1 00:c9:00:b5:92:22)... ok
net1: 11.0.0.21/255.255.0.0
net0: 11.0.0.20/255.255.0.0 (inaccessible)
Next server: 11.0.0.83
Filename: boot\x86\wdsnbp.com
Root path: iscsi:11.0.0.83:::iqn.1991-05.com.microsoft:l-winqa-083-l-winqa-083-
target
Registered SAN device 0x80
tftp://11.0.0.83/boot%5Cx86%5Cwdsnbp.com... ok

Downloaded WDSNBP from 11.0.0.83 11.0.0.83

WDSNBP started using DHCP Referral.
Contacting Server: 11.0.0.83 (Gateway: 0.0.0.0).
Architecture: x64
Contacting Server: 11.0.0.83.
TFTP Download: boot\x86\wdsnbp.com
Downloaded WDSNBP from 11.0.0.83 l-winqa-083

Press F12 for network service boot
Architecture: x64
Contacting Server: 11.0.0.83.
TFTP Download: boot\x64\pxeboot.n12
Current User(s): rcon: 10.0.72.43
```

3. Choose the relevant boot image from the list of all available boot images presented.

```
Windows Boot Manager (Server IP: 11.0.0.83)

Choose an operating system to start:
(Use the arrow keys to highlight your choice, then press ENTER.)


Microsoft Windows Setup 2012 (x64) 4.60RC10 (Eth) >
Microsoft Windows Setup 2012 (x64) 4.60RC10 (IB)
Microsoft Windows PE (x64) 2012 4.60RC10 VPI
Microsoft Windows PE (x64) 2012 4.60RC10 (Eth)
```



The above figure is an example only. Microsoft Windows 4.60 is the supported operating system.




4. Choose the Operating System to install.



5. Run the Windows Setup Wizard.

6. Choose iSCSI target drive to install Windows and follow the instructions presented by the installation Wizard.



Installation process will start once completing all the required steps in the Wizard, the Client will reboot and will boot from the iSCSI target.

## 5.1.3 SLES11 SP3

### 5.1.3.1 Configuring the iSCSI Target Machine

➤ *To configure the iSCSI target:*

**Step 1.** Download the IET target software from.

<http://sourceforge.net/projects/iscsitarget/files/iscsitarget/1.4.20.2/>

**Step 2.** Install iSCSI target and additional required software on target server.

```
[root@sqa030 ~]# yum install kernel-devel openssl-devel gcc rpm-build
[root@sqa030 tmp]# tar xzvf iscsitarget-1.4.20.2.tar.gz
[root@sqa030 tmp]# cd iscsitarget-1.4.20.2/
[root@sqa030 iscsitarget-1.4.20.2]# make && make install
```

**Step 3.** Create the IQN in the ietd configuration file.

```
Target iqn.2013-10.galab.com:sqa030.prt9
Lun 0 Path=/dev/cciss/c0d0p9,Type=fileio,IOMode=wb
MaxConnections          1      # Number of connections/session. We only support 1
InitialR2T              Yes    # Wait first for R2T
ImmediateData           Yes    # Data can accompany command
MaxRecvDataSegmentLength 8192  # Max data per PDU to receive
MaxXmitDataSegmentLength 8192  # Max data per PDU to transmit
MaxBurstLength          262144 # Max data per sequence (R2T)
FirstBurstLength        65536  # Max unsolicited data sequence
DefaultTime2Wait        2      # Secs wait for ini to log out   Not used
DefaultTime2Retain     20     # Secs keep cmnds after log out Not used
MaxOutstandingR2T      1      # Max outstanding R2Ts per cmnd
DataPDUInOrder         Yes    # Data in PDUs is ordered. We only support ordered
DataSequenceInOrder    Yes    # PDUs in sequence are ordered. We only support
                        ordered
ErrorRecoveryLevel      0      # We only support level 0
HeaderDigest            NONE    # PDU header checksum algo list. None or CRC32C
                        # If only one is set then the initiator must agree
                        # to it or the connection will fail
DataDigest              NONE    # PDU data checksum algo list   Same as above
MaxSessions             0      # Maximum number of sessions to this target 0 =
                        unlimited
NOPIInterval           0      # Send a NOP-In ping each after that many seconds
                        if the
                        # conn is otherwise idle 0 = off
NOPITimeout            0      # Wait that many seconds for a response on a
                        NOP-In ping
                        # If 0 or > NOPInterval, NOPInterval is used!
                        # Various target parameters
Wthreads               8      # Number of IO threads
QueuedCommands         32     # Number of queued commands
```



The local Hard Disk partition assigned to the LUN (/dev/cciss/c0d0p9 in the example above) must not contain any valuable data, as this data will be destroyed by the installation process taking place later in this procedure

**Step 4.** Edit the /etc/sysconfig/iscsi-target file as follow.

```
OPTIONS="-c /etc/iet/ietd.conf --address=12.7.6.30"
```

**Step 5.** Start the iSCSI target service.

```
[root@sqa030 ~]# /etc/init.d/iscsi-target start
```

**Step 6.** Perform a sanity check by connecting to the iSCSI target from a remote PC on the 10GE network link.

### 5.1.3.2 Configuring the DHCP Server

Edit a host-declaration for your PXE client in the DHCP configuration file, serving it with pxe-linux.0, and restart your DHCP.

Here is an example of such host declaration inside DHCP config file:


```
host qadell011 {
    filename "pxelinux.0" ;
    next-server 12.7.6.30;
    option host-name "qadell011";
    fixed-address 12.7.6.11 ;
    hardware ethernet 00:02:C9:E5:D8:E0 ;
}
```

### 5.1.3.3 Installing SLES11 SP3 on a Remote Storage over iSCSI


**Step 1.** In the DHCP server configuration, the PXELINUX (pxelinux.0) and a SLES11 SP3 distribution media will be provided for network installation.

The clients' HDD was removed beforehand; therefore the installer will ask to locate a HDD. The built-in iSCSI discovery will be used to connect to the iSCSI target LUN partition.

**Step 2.** Reboot the client and invoke PXE boot with the Mellanox boot agent.




**Step 3.** Select the "Install SLES11.3" boot option from the menu (see pxelinux.cfg example above). After about 30 seconds, the SLES installer will issue the notification below due to the PXELINUX boot label we used above.




**Step 4.** Click OK.


**Step 5.** Click on the **Configure iSCSI Disks** button.



**Step 6.** Choose **Connected Targets** tab.




**Step 7. Click Add.**





**Step 8. Enter the IP address of the iSCSI storage target.**


**Step 9. Click Next.**



**Step 10. Select the relevant target from the table (In our example, only one target exist so only one was discovered).**

**Step 11. Click Connect.****Step 12. Select onboot from drop-list.****Step 13. Click Next to exit the discovery screen.**


**Step 14.** Go to the **Connected Targets** tab again to confirm iSCSI connection with target.



**Step 15.** Click **OK**.

**Step 16.** Click **Next** back at the Disk Activation screen.



**Step 17.** Select **New Installation**.



**Step 18.** Click **Next**.

**Step 19.** Complete **Clock and Time Zone** configuration.



**Step 20. Select Physical Machine.****Step 21. Click Next.****Step 22. Click Install.**

Make sure "open-iscsi" RPM is selected for the installation under "Software".

After the installation is completed, the system will reboot.

Choose "SLES11.3x64\_iscsi\_boot" label from the boot menu (See Section 5.1.3.3, "Installing SLES11 SP3 on a Remote Storage over iSCSI," on page 75).

**Step 23.** Complete post installation configuration steps.



It is recommended to download and install the latest version of MLNX\_OFED\_LINUX available from [http://www.mellanox.com/page/products\\_dyn?product\\_family=26&mtag=linux\\_sw\\_drivers](http://www.mellanox.com/page/products_dyn?product_family=26&mtag=linux_sw_drivers)

#### 5.1.3.4 Using PXE Boot Services for Booting the SLES11 SP3 from the iSCSI Target

Once the installation is completed, the system will reboot. At this stage, it is expected from the client to perform another PXE network boot with FlexBoot®.

Choose the "SLES11.3x64 iSCSI boot" label from the boot menu (See Section 5.1.3.3, "Installing SLES11 SP3 on a Remote Storage over iSCSI," on page 75).

## 5.2 PXE Boot

### 5.2.1 SLES11 SP3

#### 5.2.1.1 Configuring the PXE Server

**Step 1.** Download SLES11SP3-kISO-VPI.tgz from [http://www.mellanox.com/page/products\\_dyn?product\\_family=34&mtag=flexboot](http://www.mellanox.com/page/products_dyn?product_family=34&mtag=flexboot)

**Step 2.** Extract the .tgz file on the PXE server, under the TFTP root directory.

For example:

```
[root@sqa030 ~]# cd /var/lib/tftpboot; tar xzvf SLES11SP3-kISO-VPI.tgz
```

The following are examples of PXE server configuration:

- PXE server configuration:

```
SLES11SP3-kISO-VPI/pxelinux.cfg/default
```

- Kernel and initrd for the installation:

```
SLES11SP3-kISO-VPI/pxeboot-install/initrd
SLES11SP3-kISO-VPI/pxeboot-install/linux
```

- Kernel and initrd for the boot after the installation:

```
SLES11SP3-kISO-VPI/pxeboot/initrd
SLES11SP3-kISO-VPI/pxeboot/linux
```

- kISO installation medium that can be used to boot from instead of booting the installer program over the network.

If choosing this method:

- Boot the client into the below SLES11 SP3 iso and proceed with the installation until the client fully boots up the installer program.
- Discover and connect to a remote iSCSI storage.  
During the installation process you will be asked to insert the original installation medium to continue with the installation.

```
SLES11SP3-kISO-VPI/sles11-sp3-x86_64-mlnx_ofed-2.1-1.0.6.iso
```

If the iso method above is not used, two different PXE server configurations are required (PXELINUX booting labels) for each phase discussed herein (booting the installer and post-installation boot)

- For booting the installer program off the TFTP server, please provide the client a path to the initrd and linux kernel as provided inside SLES11SP3-kISO-VPI/pxeboot-install/ in the tgz above.

The below is an example of such label.

```
LABEL SLES11.3x64_manual_install1
MENU LABEL ^1) Install SLES11.3
kernel SLES11SP3-kISO-VPI/pxeboot-install/linux
append initrd=SLES11SP3-kISO-VPI/pxeboot-install/initrd install=nfs://12.7.6.30/pxerepo/
SLES/11.3/x86_64/DVD1/?device=p4p2
IPAPPEND 2
```



To install SLES11 SP3 over iSCSI over IPoIB, the following parameters need to be added to the “append” statement above:

```
insmod=ib_ipoib insmod=libiscsi insmod=rdma_cm insmod=ib_iser
```

- For post-installation boot (booting the SLES 11 SP3 off the iSCSI storage using PXE services) please provide the booting client a path to the initrd and linux kernel as provided inside SLES11SP3-kISO-VPI/pxeboot/ in the tgz above.

The below is an example of such label.

```
LABEL SLES11.3x64_iscsi_boot
MENU LABEL ^2) SLES11.3 iSCSI boot
kernel SLES11SP3-kISO-VPI/pxeboot/linux
append initrd= SLES11SP3-kISO-VPI/pxeboot/initrd net-root=iscsi:12.7.6.30:::iqn.2013-
10.qalab.com:sqa030.prt9 TargetAd-dress=12.7.6.30 TargetName=iqn.2013-
10.qalab.com:sqa030.prt9 TargetPort=3260 net_delay=10 rootfstype=ext3 rootdev=/dev/sda2
```

The steps described in this document do not refer to an unattended installation with autoyast. For official information on SLES unattended installation with autoyast, please refer to:

[https://www.suse.com/documentation/sles11/book\\_autoyast/?page=/documentation/sles11/book\\_autoyast/data/book\\_autoyast.html](https://www.suse.com/documentation/sles11/book_autoyast/?page=/documentation/sles11/book_autoyast/data/book_autoyast.html)

The following is known to work with Mellanox NIC:

```
append initrd=SLES-11-SP3-DVD-x86_64-GM-DVD1/boot/x86_64/loader/initrd install=nfs://
<NFS IP Address>/<path the the repository directory>/ autoyast=nfs://<NFS IP Address>/
<path to autoyast xml directory>/autoyast-unattended.xml biosdevname=0
IPAPPEND 2
```

## 6 Firmware

Firmware and update instructions for these cards can be obtained from the Dell support web page: <http://www.dell.com/support>.

Note: The firmware version on the adapter can be checked using the following methods:

1. System Setup > Device Settings
2. Dell iDRAC

## 7 Dell Lifecycle Controller **Troubleshooting**

### 7.1 General

<b>Server unable to find the adapter</b>	<ul style="list-style-type: none"> <li>• Ensure that the adapter is placed correctly</li> <li>• Make sure the adapter slot and the adapter are compatible</li> <li>• Install the adapter in a different PCI Express slot</li> <li>• Use the drivers that came with the adapter or download the latest</li> <li>• Make sure your motherboard has the latest BIOS</li> <li>• Try to reboot the server</li> </ul>
<b>The adapter no longer works</b>	<ul style="list-style-type: none"> <li>• Reseat the adapter in its slot or a different slot, if necessary</li> <li>• Try using another cable</li> <li>• Reinstall the drivers for the network driver files may be damaged or deleted</li> <li>• Reboot the server</li> </ul>
<b>Adapters stopped working after installing another adapter</b>	<ul style="list-style-type: none"> <li>• Try removing and re-installing all adapters</li> <li>• Check that cables are connected properly</li> <li>• Make sure your motherboard has the latest BIOS</li> </ul>
<b>Link indicator light is off</b>	<ul style="list-style-type: none"> <li>• Ensure that adapter driver/s is loaded</li> <li>• Try another port on the switch</li> <li>• Make sure the cable is securely attached</li> <li>• Check your are using the proper cables that do not exceed the recommended lengths</li> <li>• Verify that your switch and adapter port are compatible</li> </ul>
<b>Link light is on, but with no communication established</b>	<ul style="list-style-type: none"> <li>• Check that the latest driver is loaded</li> <li>• Check that both the adapter and its link are set to the same speed and duplex settings</li> </ul>
<b>Low Performance with RDMA over Converged Ethernet (RoCE)</b>	<ul style="list-style-type: none"> <li>• Check to make sure flow-control is enabled on the switch ports.</li> </ul>

## 7.2 Linux

<b>Firmware Version Upgrade</b>	To download the latest firmware version refer to the Dell support site <a href="http://www.dell.com/support">http://www.dell.com/support</a>
<b>Environment Information</b>	<pre>cat/etc/issue uname -a cat/proc/cupinfo   grep 'model name'   uniq ofed_info   head -1 ifconfig -a ethtool &lt;interface&gt; ethtool -i &lt;interface_of_Mellanox_port_num&gt; ibdev2netdev</pre>
<b>Card Detection</b>	<code>lspci   grep -i Mellanox</code>
<b>Ports Information</b>	<pre>ibstat lbv_devinfo</pre>
<b>Collect Log File</b>	<pre>/var/log/messages dmesg &gt; system.logF</pre>

## 7.3 Windows

<b>Firmware Version Upgrade</b>	To download the latest firmware version refer to the Dell support site <a href="http://www.dell.com/support">http://www.dell.com/support</a>
<b>Performance is Low</b>	This can be due to non-optimal system configuration. See the section “Performance Tuning” to take advantage of Mellanox 10 GBit NIC performance
<b>Driver Does Not Start</b>	<p>This can happen due to an RSS configuration mismatch between the TCP stack and the Mellanox adapter. To confirm this scenario, open the event log and look under “System” for the “mlx4eth5” or “mlx4eth6” source. If found, enable RSS as follows: Run the following command: “netsh int tcp set global rss = enabled”.</p> <p>This is a less recommended suggestion, and will cause low performance. Disable RSS on the adapter. To do this set RSS mode to “No Dynamic Rebalancing”.</p>
<b>The Ethernet Driver Fails to Start</b>	<p>If in the Event log, under the mlx4_bus source, the following error message appears: RUN_FW command failed with error -22, this error message indicates that the wrong firmware image has been programmed on the adapter card.</p> <p>If a yellow sign appears near the Mellanox ConnectX Ethernet Adapter instance in the Device Manager display, this can happen due to a hardware error. Try to disable and re-enable “Mellanox ConnectX Adapter” from the Device Manager display.</p>

<b>No connectivity to a Fault Tolerance bundle while using network capture tools (e.g., Wireshark)</b>	This can happen if the network capture tool captures the network traffic of the non-active adapter in the bundle. This is not allowed since the tool sets the packet filter to “promiscuous”, thus causing traffic to be transferred on multiple interfaces. Close the network capture tool on the physical adapter card, and set it on the LBFO interface instead.
<b>No Ethernet connectivity on 1Gb/100Mb adapters after activating Performance Tuning (part of the installation)</b>	This can happen due to adding a TcpWindowSize registry value. To resolve this issue, remove the value key under HKEY_LOCAL_MACHINE\SYSTEM\CurrentControl-Set\Services\Tcpip\Parameters\TcpWindowSize or set its value to 0xFFFF
<b>System reboots on an I/OAT capable system on Windows Server 20</b>	This may occur if you have an Intel I/OAT capable system with Direct Cache Access enabled, and 9K jumbo frames enabled. To resolve this issue, disable 9K jumbo frames.
<b>Packets are being lost</b>	This may occur if the port MTU has been set to a value higher than the maximum MTU supported by the switch.
<b>Windows System Event Viewer Events</b>	Failed to reset the Mellanox ConnectX EN 10Gbit Ethernet NIC. Try disabling then re-enabling the “Mellanox Ethernet Bus Driver” device via the Windows device manager.
	Failed to initialize the Mellanox ConnectX EN 10Gbit Ethernet Adapter <X> because it uses old firmware version (<old firmware version>). You need to update the adapter to firmware version <new firmware version> or higher, and to restart your computer.
	Mellanox ConnectX EN 10Gbit Ethernet Adapter <X> device detected that the link connected to port <Y> is down. This can occur if the physical link is disconnected or damaged, or if the other end-port is down.
	Mismatch in the configurations between the two ports may affect the performance. When Using MSI-X, both ports should use the same RSS mode. To fix the problem, configure the RSS mode of both ports to be the same in the driver GUI.
	Mellanox ConnectX EN 10Gbit Ethernet Adapter <X> device failed to create enough MSI-X vectors. The Network interface will not use MSI-X interrupts. This may affects the performance. To fix the problem, configure the number of MSI-X vectors in the registry to be at least <Y>.

## 8 Specifications

**Table 16 - Mellanox ConnectX-3 Dual 40GbE QSFP+ Network Adapter Specifications**

<b>Physical</b>	<b>Board Size:</b> 2.71in. x 5.6in. (68.90 mm x 142.25 mm) <b>Full height Bracket Size:</b> 4.5 in. (116 mm) <b>Low profile Bracket Size:</b> 3.16 in. (80.3 mm)
	<b>Connector:</b> QSFP+ 40Gb/s
<b>Protocol Support</b>	<b>Ethernet:</b> 10GBASE-CR, 40GBASE-CR4 /-SR4
	<b>Data Rate:</b> 10/40Gb/s – Ethernet
	<b>PCI Express Gen3:</b> SERDES @ 8.0GT/s, 8lanes (2.0 and 1.1 compatible)
<b>Power and Environmental<sup>a</sup></b>	<b>Voltage:</b> 12V, 3.3V, 3.3V_AUX
	<b>Typ Power:</b> Passive Cables: 8.14W Optical Cables: 10.96W
	<b>Max Power:</b> Passive Cables: 9.98W Optical Cables: 13.51W
	<b>Temperature:</b> 0°C to 55°C Non-operational 0°C to 70°C Note: Thermal spec covers Power Level 1 QSFP modules
	<b>Humidity:</b> 90% relative humidity <sup>b</sup>
	<b>Air Flow:</b> 120LFM <sup>c</sup>
<b>Regulatory</b>	<b>EMC:</b> Refer to Chapter 9, “Regulatory,” on page 91
	<b>Safety:</b> IEC/EN 60950-1:2006 ETSI EN 300 019-2-2 IEC 60068-2- 64, 29, 32
	<b>RoHS:</b> RoHS-R6

- a. Thermal and power characteristics with optical modules only supported with Mellanox QSFP+ optical module, MC2210411-SR4 (Dell Part Number 2MJ5F)
- b. For both operational and non-operational states
- c. Air flow is measured ~1” from the heat sink between the heat sink and the cooling air inlet.



**Table 17 - Mellanox ConnectX-3 Dual 10GbE SFP+ Network Adapter Specifications**

<b>Physical</b>	<b>Size:</b> 2.71in. x 5.6in. (68.90 mm x 142.25 mm) <b>Full height Bracket Size:</b> 3.8in (96.52 mm) <b>Low profile Bracket Size:</b> 3.16in (80.3 mm)
	<b>Connector:</b> SFP+ 10Gb/s
<b>Protocol Support</b>	<b>Ethernet:</b> 10GBASE-CR, 10GBASE-R, and 1000BASE-R
	<b>Data Rate:</b> 10Gb/s – Ethernet
	<b>PCI Express Gen3:</b> SERDES @ 8.0GT/s, 8lanes (2.0 and 1.1 compatible)
<b>Power and Environmental<sup>a</sup></b>	<b>Voltage:</b> 12V, 3.3V, 3.3V_AUX
	<b>Typ Power:</b> Passive Cables: 4.84W Optical Cables: 6.24W
	<b>Max Power:</b> Passive Cables: 5.87W Optical Cables: 7.87W
	<b>Temperature:</b> Operational 0°C to 55°C Non-operational 0°C to 70°C Note: Thermal spec covers Power Level 1 SFP+ modules
	<b>Humidity:</b> 90% relative humidity <sup>b</sup>
	<b>Air Flow:</b> 100LFM <sup>c</sup>
<b>Regulatory</b>	<b>EMC:</b> Refer to <a href="#">Chapter 9, “Regulatory,”</a> on page 91
	<b>Safety:</b> IEC/EN 60950-1:2006 ETSI EN 300 019-2-2 IEC 60068-2- 64, 29, 32
	<b>RoHS:</b> RoHS-R6

- a. Thermal and power characteristics with optical modules only supported with Mellanox SFP+ optical module, MFM1T02A-SR (Dell Part Number T16JY).
- b. For both operational and non-operational states
- c. Air flow is measured ~1” from the heat sink between the heat sink and the cooling air inlet.

**Table 18 - Mellanox ConnectX-3 Dual 10GbE KR Blade Mezzanine Card Specifications**

<b>Physical</b>	<b>Size:</b> 3.4in. x 3.3in. (88 mm x 84mm)
<b>Protocol Support</b>	<b>Ethernet:</b> 10GBASE-KR, 10GBASE-KX4, 1000BASE-KX
	<b>Data Rate:</b> 1/10Gb/s – Ethernet
	<b>PCI Express Gen3:</b> SERDES @ 8.0GT/s, 8 lanes (2.0 and 1.1 compatible)
<b>Power and Environmental</b>	<b>Voltage:</b> 12V, 3.3Vaux
	<b>Typ Power:</b> 4.84
	<b>Max Power:</b> 5.87
	<b>Temperature:</b> Operational 0°C to 65°C Non-operational 0°C to 70°C
	<b>Humidity:</b> 90% relative humidity <sup>a</sup>
	<b>Air Flow:</b> 200LFM <sup>b</sup>
<b>Regulatory</b>	<b>Safety:</b> IEC/EN 60950-1:2006 ETSI EN 300 019-2-2 IEC 60068-2- 64, 29, 32
	<b>RoHS:</b> RoHS-R6

a. For both operational and non-operational states

b. Air flow is measured ~1” from the heat sink between the heat sink and the cooling air inlet.

## 9 Regulatory

**Table 19 - Ethernet Network Adapter Certifications**

OPN	FCC	VCCI	EN	ICES	CE	CB	cTUV <sub>us</sub>	KCC	C-TICK	CCC	GOST-R	S-MAR K
Mellanox ConnectX-3 Dual 40GbE QSFP+ Network Adapter	YES	YES	YES	YES	YES	YES	YES	YES	YES	Exemption letter	N/A	N/A
Mellanox ConnectX-3 Dual 10GbE SFP+ Network Adapter	YES	YES	YES	YES	YES	YES	YES	YES	YES	Exemption letter	N/A	N/A

### 9.1 Regulatory Statements

#### 9.1.1 FCC Statements (USA)

##### Class A Statements:

##### § 15.19(a)(4)

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

##### § 15.21

Statement

##### Warning!

Changes or modifications to this equipment not expressly approved by the party responsible for compliance (Mellanox Technologies) could void the user's authority to operate the equipment.

##### §15.105(a)

Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### 9.1.2 EN Statements (Europe)

#### EN55022 Class A Statement:

##### Warning

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

### 9.1.3 ICES Statements (Canada)

#### Class A Statement:

"This Class A digital apparatus complies with Canadian ICES-003.  
Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada."

### 9.1.4 VCCI Statements (Japan)

#### Class A Statement:

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

(Translation - "This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio interference may occur, in which case the user may be required to take corrective actions.")

## 9.1.5 KCC Certification (Korea)


### English Translation

Device	User's information
<p>A급 기기 (업무용 방송통신기기)</p>	<p>이 기기는 업무용(A급)으로 전자파적합등록을 한 기기이오니 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.</p>
<p><b>CLASS A device</b> (commercial broadcasting and communication equipment)</p>	<p>This device has been approved by EMC registration. Distributors or users pay attention to this point. This device is usually aimed to be used in other area except at home.</p>
<ul style="list-style-type: none"> <li>● Remark</li> </ul>	<p>Class A device: operated in a commercial area.</p>

## Appendix A: Configuration for Mellanox Adapters through System Setup

This section covers the main configuration options in Dell PowerEdge System Setup which can be accessed through BIOS or through Lifecycle Controller.

*Figure 3: System Setup Menu*




Setup menu options:

1. System BIOS
2. iDRAC Settings
3. Device Settings


To configure the Mellanox Adapter, choose 'Device settings' and the relevant Mellanox adapter:

**Figure 4: Main Configuration Page Options**



1. Shows general info regarding the adapter.
2. Allows configuration of SR-IOV on the adapter - see Appendix A.5, "SR-IOV Configuration," on page 104.
3. Allows setting the Blink LEDs to allow physical identification of the card


- a. To trigger Blink LEDs configure the number of seconds for it to blink (Max is 15 seconds).





## A.1 Main Configuration Page - Firmware Image Properties

The below provides Firmware the uEFI versions numbers.<sup>1</sup>




## A.2 Main Configuration Page - NIC Configuration

1. Allows configuration of Legacy Boot Protocol: None, PXE, iSCSI.
2. Allows configuration of Virtual LAN Mode and Virtual LAN ID.
3. Allows to Enable or Disable the Option ROM.


---

1. These version numbers are just an example.

4. Allows setting Boot Retry Count.




5. Allows setting Boot Retry Count.



## A.3 Main Configuration Page - iSCSI Configuration

This section allows to override the default configurations of iSCSI and replaces DHCP configuration of iSCSI.



**Figure 5: Main Configuration page - iSCSI Configuration - iSCSI General Parameters**



**Figure 6: Main Configuration Page - iSCSI Configuration - iSCSI Initiator Parameters**

The screenshot shows the Dell System Setup interface for iSCSI configuration. At the top, the Dell logo and 'System Set up' are visible, along with 'Help | About | Exit' links. Below this, a header identifies the network interface as 'NIC in Slot 4 Port 2: Mellanox ConnectX-3 40GbE QSFP+ Adapter - 00:02:C9:24:D9:90'. The main title of the page is 'Main Configuration Page - iSCSI Configuration - iSCSI Initiator Parameters'. The configuration fields are as follows:

Pv4 Address	<input type="text"/>
Subnet Mask	<input type="text"/>
Pv4 Default Gateway	<input type="text"/>
Pv4 Primary DNS	<input type="text"/>
iSCSI Name	<input type="text"/>
CHAP ID	<input type="text"/>
CHAP Secret	<input type="text"/>

An information box at the bottom left contains an 'i' icon and the text: 'Specifies the IPv4 address of the iSCSI initiator'. The footer of the interface includes 'PowerEdge R720', the instruction 'Use tab button to navigate page.', and a 'Back' button.

**Figure 7: Main Configuration Page - iSCSI Configuration - iSCSI Target Parameters**


The screenshot shows the 'System Setup' interface for a Dell PowerEdge R720 server. The title bar includes the Dell logo, 'System Setup', and navigation links 'Help | About | Exit'. The main header identifies the network interface as 'NIC in Slot 4 Port 2: Mellanox ConnectX-3 40GbE QSFP+ Adapter - 00:02:C9:24:D9:90'. Below this, the page title is 'Main Configuration Page • iSCSI Configuration • iSCSI First Target Parameters'. The configuration options are as follows:

Connect	<input type="radio"/> Disabled <input checked="" type="radio"/> Enabled
IP Address	<input type="text"/>
TCP Port	<input type="text" value="3260"/>
Boot LUN	<input type="text" value="0"/>
iSCSI Name	<input type="text"/>
CHAP ID	<input type="text"/>
CHAP Secret	<input type="text"/>
IP Version	Pv4

An information box at the bottom left contains the message: 'Enable connecting to the first iSCSI target.' The footer of the interface shows 'PowerEdge R720', 'Server Tray 0/0/00', 'Use tab button to navigate page.', 'Press ESC to exit page.', and a 'Back' button.

## A.4 Main Configuration Page - Device Level Configuration

Allows setting Global Flow control settings for the adapter's port.




## A.5 SR-IOV Configuration

Enabling SRIOV requires configuration both for the system and the specific Mellanox adapter.


To enable SR-IOV - follow the below steps 1-4.

To disable SR-IOV - set the configuration in steps 1-3 to disabled.



**Step 1.** Enable “Virtualization Technology” in System BIOS => Processor setting :**Step 2.** Enable “SR-IOV Global Enable”

Go to: System BIOS => integrated Devices section




**Step 3.** Enable SR-IOV on the relevant adapter and set the number of required virtual functions:

Go to: Device settings => Select the relevant Mellanox adapter.

By default, Mellanox adapter is set to SRI-OV enabled with 8 virtual functions.

Note the maximum number of virtual functions supported by the adapter PCIe.

Refer to the relevant driver user manual for support for SR-IOV and number of supported functions.



**Step 4.** Reboot the server for the SR-IOV configuration to take effect.

## Appendix B: Safety Warnings

Below is a list of safety warnings in English. For safety warnings in other languages, please refer to the appendices in this manual.

### 1. Installation Instructions



Read all installation instructions before connecting the equipment to the power source.

### 2. Over-temperature



This equipment should not be operated in an area with an ambient temperature exceeding the maximum recommended according to the Dell server.

### 3. During Lightning - Electrical Hazard



During periods of lightning activity, do not work on the equipment or connect or disconnect cables.

### 4. Copper Cable Connecting/Disconnecting



Some copper cables are heavy and not flexible, as such they should be carefully attached to or detached from the connectors. Refer to the cable manufacturer for special warnings and instructions.

### 5. Equipment Installation



This equipment should be installed, replaced, or serviced only by qualified personnel.

### 6. Equipment Disposal



Disposal of this equipment should be in accordance to all national laws and regulations.

### 7. Local and National Electrical Codes



This equipment should be installed in compliance with local and national electrical codes.

### 8. Hazardous Radiation Exposure



Caution – Use of controls or adjustment or performance of procedures other than those specified herein may result in hazardous radiation exposure.



**CLASS 1 LASER PRODUCT** and reference to the most recent laser standards:  
IEC 60 825-1:1993 + A1:1997 + A2:2001 and EN 60825-1:1994+A1:1996+  
A2:2001

## Appendix C: Avertissements de sécurité d'installation (Warnings in French)

### 1. Instructions d'installation



Lisez toutes les instructions d'installation avant de brancher le matériel à la source d'alimentation électrique.

### 2. Température excessive



Cet équipement ne doit pas être en service dans un local dont la température dépasse le maximum recommandé pour le serveur Dell.

### 3. Orages – dangers électriques



Pendant un orage, il ne faut pas utiliser le matériel et il ne faut pas brancher ou débrancher les câbles.

### 4. Branchement/débranchement des câbles en cuivre



Les câbles en cuivre sont lourds et ne sont pas flexibles, il faut donc faire très attention en les branchant et en les débranchant des connecteurs. Consultez le fabricant des câbles pour connaître les mises en garde et les instructions spéciales.

### 5. Installation du matériel



Ce matériel ne doit être installé, remplacé ou entretenu que par du personnel formé et qualifié.

### 6. Elimination du matériel



L'élimination de ce matériel doit s'effectuer dans le respect de toutes les législations et réglementations nationales en vigueur.

### 7. Codes électriques locaux et nationaux



Ce matériel doit être installé dans le respect des codes électriques locaux et nationaux.

### 8. Exposition au rayonnement grave



Mise en garde – l'utilisation de commandes ou de réglages ou l'exécution de procédures autres que ce qui est spécifié dans les présentes peut engendrer une exposition au rayonnement grave.



PRODUIT LASER DE CLASSE 1 » et références aux normes laser les plus récentes CEI 60 825-1:1993 + A1:1997 + A2:2001 et NE 60825-1:1994+A1:1996+ A2:2001

## Appendix D: Sicherheitshinweise (Warnings in German)

### 1. Installationsanleitungen



Lesen Sie alle Installationsanleitungen, bevor Sie das Gerät an die Stromversorgung anschließen.

### 2. Übertemperatur



Dieses Gerät sollte nicht in einer Umgebung mit einer Umgebungstemperatur von mehr als der maximal für den Dell-Server empfohlenen betrieben werden.

### 3. Bei Gewitter - Elektrische Gefahr



Arbeiten Sie während eines Gewitters und Blitzschlag nicht am Gerät, schließen Sie keine Kabel an oder ab.

### 4. Anschließen/Trennen von -Kupferkabel



Kupferkabel sind schwer und nicht flexible. Deshalb müssen sie vorsichtig an die Anschlüsse angebracht bzw. davon getrennt werden. Lesen Sie die speziellen Warnungen und Anleitungen des Kabelherstellers.

### 5. Geräteinstallation



Diese Gerät sollte nur von geschultem und qualifiziertem Personal installiert, ausgetauscht oder gewartet werden.

### 6. Geräteentsorgung



Die Entsorgung dieses Geräts sollte unter Beachtung aller nationalen Gesetze Bestimmungen erfolgen.

### 7. Regionale und nationale elektrische Bestimmungent



Dieses Gerät sollte unter Beachtung der regionalen und nationalen elektrischen Bestimmungen installiert werden.



This equipment should be installed in compliance with local and national electrical codes.



## 8. Strahlenkontakt



Achtung – Nutzung von Steuerungen oder Einstellungen oder Ausführung von Prozeduren, die hier nicht spezifiziert sind, kann zu gefährlichem Strahlenkontakt führen..



Klasse 1 Laserprodukt und Referenzen zu den aktuellsten Lasterstandards :  
ICE 60 825-1:1993 + A1:1997 + A2:2001 und EN 60825-1:1994+A1:1996+  
A2:2001

## Appendix E: Advertencias de seguridad para la instalación (Warnings in Spanish)

### 1. Instrucciones de instalación



Antes de conectar el equipo a la fuente de alimentación, leer todas las instrucciones de instalación.

### 2. Sobrecalentamiento



Este equipo no se debe utilizar en una zona con una temperatura ambiente superior a la máxima recomendada para el servidor Dell.

### 3. Cuando hay rayos: peligro de descarga eléctrica



No utilizar el equipo ni conectar o desconectar cables durante períodos de actividad de rayos.

### 4. Conexión y desconexión del cable Copper



Dado que los cables de cobre son pesados y no son flexibles, su conexión a los conectores y su desconexión se deben efectuar con mucho cuidado. Para ver advertencias o instrucciones especiales, consultar al fabricante del cable.

### 5. Instalación de equipos



La instalación, el reemplazo y el mantenimiento de este equipo estarán a cargo únicamente de personal capacitado y competente.

### 6. Eliminación de equipos



La eliminación definitiva de este equipo se debe efectuar conforme a todas las leyes y reglamentaciones nacionales.

### 7. Códigos eléctricos locales y nacionales



Este equipo se debe instalar conforme a los códigos eléctricos locales y nacionales.

### 8. Exposición a niveles de radiación peligrosos



Precaución: el uso de controles o ajustes o la realización de procedimientos distintos de los que aquí se especifican podrían causar exposición a niveles de radiación peligrosos.



PRODUCTO LÁSER DE CLASE 1 y referencia a las normas de láser más recientes:  
IEC 60825-1:2007/03 y EN 60825-1:2007