


DENSO

BHT-7500W

Bar Code Handy Terminal

Operator's Guide

This guide has been prepared expressly for the hands-on user. Always keep it nearby for speedy reference.



Related Publications

BHT-7500W User's Manual (Contained in the Manual Pack CD)

Instructions for using the handy terminal (BHT-7500W) and optical communication unit (CU-7000).

BHT-BASIC Programmer's Manual (Contained in the BHT-BASIC Compiler CD and Manual Pack CD)

Description for developing application programs of the handy terminal in BHT-BASIC.

Transfer Utility Guide (that comes with Transfer Utility)

Description about software that transmits data and programs between the handy terminal and computer.

Ir-Transfer Utility C Guide (that comes with Ir-Transfer Utility C)

Description about software that transmits data and programs between the handy terminal and computer via the optical communication unit (CU).

Ir-Transfer Utility E Guide (that comes with Ir-Transfer Utility E)

Description about software that transmits data and programs between the handy terminal and computer via the computer's integrated IR port or any of the specified external IR transceivers.

SAFETY PRECAUTIONS

Be sure to observe all these safety precautions.

Strict observance of these warning and caution indications are a **MUST** for preventing accidents which could result in bodily injury and substantial property damage. Make sure you fully understand all definitions of these terms and related symbols given below, before you proceed on to the text itself.



WARNING

Alerts you to those conditions which could cause serious bodily injury or death if the instructions are not followed correctly.



CAUTION

Alerts you to those conditions which could cause minor bodily injury or substantial property damage if the instructions are not followed correctly.

Meaning of Symbols



A triangle (\triangle) with a picture inside alerts you to a warning of danger. Here you see the warning for electrical shock.



A diagonal line through a circle (\circ) alerts you to something you should not do; it may or may not have a picture inside. Here you see a screwdriver inside the circle, meaning that you should not disassemble.



A black circle (\bullet) with a picture inside alerts you to something you **MUST** do. This example shows that you **MUST** unplug the power cord.



WARNING

Handling the rechargeable battery cartridge


- Never disassemble or heat the rechargeable battery cartridge, nor put it into fire or water; doing so could cause battery-rupture or leakage of battery fluid, resulting in a fire or bodily injury.



WARNING

- Do not carry or store the rechargeable battery cartridge together with metallic ball-point pens, necklaces, coins, hairpins, etc.

Doing so could short-circuit the terminal pins, causing the batteries to rupture or the battery fluid to leak, resulting in a fire or bodily injury.




- Avoid dropping the rechargeable battery cartridge or letting it undergo any shock or impact.

Doing so could cause the batteries to break, generate heat, rupture or burn.

- Only use the dedicated charger (CU-7001, C-700 or C-750) for charging the battery cartridge.

Using a different type of charger could cause battery-rupture or leakage of battery fluid and result in a fire, bodily injury, or serious damage to property.




- Never charge the rechargeable battery cartridge where any inflammable gases may be emitted; doing so could cause fire.

Handling the BHT

- The BHT-7500W uses a laser light for scanning bar codes. The intensity of the laser light might be too low to inflict bodily injury. However, do not look into the laser beam.

The BHT-7500W complies with Laser Safety Standard, Class II of 21 CFR Chapter 1, Subchapter J.

The BHT-7500W does not mount beam attenuator and laser radiation emission indicator required by this standard. Instead, the software-controlled Magic keys (see "Components and Functions") function as them because the laser light is not enabled without the Magic keys pressed.



- Do not look into the laser beam through the reading window or point the laser beam towards the eyes.

The laser beam emitted through the reading window is harmful to the eyes.

- Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION

Handling the rechargeable battery cartridge

- Never charge a wet or damp rechargeable battery cartridge.


Doing so could cause the batteries to break, generate heat, rupture or burn.



Handling the BHT



- Never put the BHT in places where there are excessively high temperatures, such as inside closed-up automobiles, or in places exposed to direct sunlight.

Doing so could affect the housing or parts, resulting in a fire.



- Avoid using the BHT in extremely humid or dusty areas, or where there are drastic temperature changes.

Moisture or dust will get into the BHT, resulting in malfunction, fire or electrical shock.



CAUTION

- Never disassemble or modify the BHT; doing so could result in an accident such as break or fire.



Never disassemble

- If smoke, abnormal odors or noises come from the BHT, immediately turn off the power, pull out the rechargeable battery cartridge, and contact your nearest dealer.




Failure to do so could cause smoke or fire.

- If foreign material or water gets into the BHT, immediately turn off the power, pull out the rechargeable battery cartridge, and contact your nearest dealer.



Failure to do so could cause smoke or fire.

- If you drop the BHT so as to damage its housing, immediately turn off the power, pull out the rechargeable battery cartridge, and contact your nearest dealer.



Failure to do so could cause smoke or fire.



- Do not use batteries or power sources other than the specified ones; doing so could generate heat or cause malfunction.



- In environments where static electricity can build into significant charges (e.g., if you wipe off the plastic plate with a dry cloth), do not operate the BHT. Doing so will result in malfunction or machine failure.



Components and Functions



* The trigger switch function is assigned to both of the M3 and M4 keys by default.

The functions of the keys may be set by user programs. Shown below is a set of sample functions.

C (Clear) key

Clears the last inputted data or returns to the original screen. If pressed together with [SF] key, this [C] key works as a backspace key.

PW (Power) key

Turns the BHT on or off.

Cursor keys


Used to move up to the preceding line, down to the next line, to the preceding character, and to the next character.

Numerical keys

Used for numerical input.

Function keys

Used for choosing functions.



ALP (Alphabet) key

Switches the keypad to alphabet entry.

SF (Shift) key

Used in combination with numerical keys for special input procedures.


M1/M2 (Magic) keys

Used as any of the trigger switch (default), [ENT] key, [SF] key, and backlight function on/off key depending upon definition in System Mode or in user programs. These keys can be also assigned string data.


ENT (Enter) key

Finalizes the inputted data or operations, and starts the corresponding processing.

About Status Indicators



Battery voltage level

 Shows the current battery voltage level.

If the voltage level is high, three bars appear; if low, a single bar appears.

NOTE

The displayed battery level shows the terminal voltage of the battery cartridge, not how much power is left.

The battery voltage level varies depending upon the operation of the BHT, so the displayed level also may vary .

Keypad shift state

SF Shows a bar when the keypad is shifted.

Alphabet input

ALP Shows a bar when the alphabet input function is activated.


Connection state in radio communication

Shows a bar when the BHT is synchronized with an access point.

Reading Bar Codes


Turn on the BHT power, bring the bar-code reading window to the bar code to be scanned, and press the trigger switch. The BHT emits a laser light to scan the bar code.

When the BHT has read the bar code successfully, the indicator LED will illuminate in green.



* The trigger switch function is assigned to both of the M3 and M4 keys by default.

- If the BHT fails to read due to specular effects or other factors, change the scanning angle of the reading window or the distance from codes as shown at right, and try it again. (Specular effects occur when the reflection of the light from the bar code becomes excessively strong. This can easily happen when the reflecting surface is polished or covered with vinyl.)



- Keep the BHT at a distance from a target bar code so that the bar code comes within approx. 90% of the laser scanning range (line length).
- The BHT can read bar codes at a maximum distance of 56 cm (22.0\")** from the bar-code reading window.

**Under the following conditions:

- Ambient illuminance: 500 lx (Xenon lamp)
- Code 39
- Reflection intensity: 85% min. for white and 5% max. for black
- Minimum narrow bar width: 1.4 mm min. (55.1 mils min.)

- The bar code reading procedure may differ depending upon the application used, so follow the application's manual.

NOTE

- Before reading bar codes, clean those labels if stained.
- Avoid using the BHT in direct sunlight. The BHT might fail to read correctly.
- To read bar codes on curved surfaces, apply the BHT to the target bar code so that the code comes to the center of the scanning range indicated by the laser beam.
- When you pull the bar-code reading window away from bar codes, the actual scanning range will become narrower than the range covered by the laser beam.

Using Radio Link

- If there are too many communications errors, first make sure that the BHT points directly at an access point because the 2.4-GHz band requires a more or less straight line path. Note also that the low-power radio waves have trouble passing through human bodies and other obstacles along that path.
- This link will not operate properly in the vicinity of microwave ovens, industrial heaters, high-frequency medical equipment, and other sources of radio waves in the 2.4-GHz band.
- Electromagnetic noise from personal computers, refrigerators, and other home appliances can also interfere with link operation.
- Environmental factors that can also interfere with link operation include large metallic objects, metallic dust, or metallic walls in the vicinity of the path and vibration at either end.

NOTE


To System Designers:

- Before developing the application, make sure that the intended environment is free of the interference factors above and thus actually capable of supporting link operation.
- Assume that there will be communications failures requiring robust retry capabilities in the software.

Using Infrared Link

■ CU-7000

Make sure that the BHT is securely in the CU-7000.




NOTE


Shield the IrDA interface from direct sunlight, intense overhead lighting (inverter-driven fluorescent lighting, in particular), and other potential sources of infrared radiation. Sources to watch out for include remote control units for television sets and the like.

Adjusting the LCD Contrast & Beeper Volume and Switching the Beeper & Vibrator


While holding down the **[M1]** or **[M4]** key, press the **[PW]** key, and any of the following screens will appear on the LCD. This screen will disappear if no keys are pressed for five seconds.



When the beeper is selected (default)



When the vibrator is selected



When both the beeper and vibrator are selected

(The current selection is highlighted.)

Adjusting the LCD contrast

You can adjust the LCD brightness to eight contrast levels.

- 1) Use the **[▲]** and **[▼]** keys to select the LCD CONTRAST line.
- 2) To decrease the contrast, press the **[◀]** key; to increase it, press the **[▶]** key.

Switching the beeper & vibrator

You may choose any of three ways—beeping only, vibrating only, or beeping & vibrating as a confirmation of completion of bar-code reading.





- (1) Use the **[▲]** and **[▼]** keys to select the BEEPER VIBRATION line that will be highlighted in any one of the following three states:




- (2) Use the **[◀]** and **[▶]** keys to highlight the desired way(s).

Adjusting the beeper volume


You can adjust the beeper volume to four levels from OFF to MAX.

- 1) Use the  and  keys to select the BEEPER VOLUME line.
- 2) To turn down the volume, press the  key; to turn it up, press the  key.

After making the above setting, press the  key or press no keys for 5 seconds, and the new setting will be fixed and the above screen will disappear.

Setting the Backlight

Pressing the **M4** key while holding down **SF** (Shift) key activates or deactivates the backlight function.




NOTE

In user programs, you can select the key to be used for activating or deactivating the backlight function (instead of the initial setting: combination of **SF** and **M4**), as well as modifying the ON-duration of the backlight before the automatic turning-off.

Loading the Rechargeable Battery Cartridge

Before the first use of the BHT, be sure to load the rechargeable battery cartridge as shown below. The battery cartridge is not loaded in the BHT when shipped from the factory.

- (1) Charge the rechargeable battery cartridge.
- (2) Turn the BHT upside down.
- (3) As shown below, slide the battery cartridge into the BHT until it clicks into place. (To remove it, press the release button.)



NOTE


The BHT integrates a rechargeable backup power source which backs up the memory and calendar clock in the BHT when no battery cartridge is loaded or the voltage level of the battery cartridge drops below the specified level. The backup power source is automatically charged by the battery cartridge.

When you first load the battery cartridge after purchase or you load it after leaving the BHT unused for a long time, do not remove the battery cartridge for at least 10 minutes after that loading. This is for charging the memory backup source integrated in the BHT.

Display message in turning off the BHT

The following alarm message will be displayed when you turn the BHT off.

While this message is displayed, do not remove the rechargeable battery cartridge or dry battery cartridge.



Shutdown
in progress.

Do not remove the
battery.

NOTE

If you remove the battery cartridge when the above message displays and leave the BHT for more than one hour, then the message “Contact your administrator. Note the error number. (2XXX)” may appear on the LCD when you reload the battery cartridge and turn the BHT on.

Battery Replacement Notes

■ When is battery replacement needed?

If the "Charge the battery!" appears on the LCD, replace the rechargeable battery cartridge with a fully charged one.

If you leave the BHT without replacing the battery cartridge, the integrated calendar clock or data will no longer be backed up so that the calendar clock will stop or the "Contact your administrator. Note the error number. (XXXX)" will appear on the LCD.

NOTE

Be sure to power off the BHT before battery replacement.

Replace the rechargeable battery cartridge quickly. Load a charged battery cartridge within 3 minutes after the removal in order to avoid data loss.

After battery replacement, power on the BHT and check the BHT operation.

■ If you will use the BHT more than one time per month:

Keep the rechargeable battery cartridge loaded in the BHT.

■ If you will not be using the BHT for more than one month:


Remove the rechargeable battery cartridge from the BHT and then store the BHT. To do so, be sure to follow the procedure given below.

(1) When removing the battery cartridge:

Press the **PW** key for more than 3 seconds to power off the BHT.

The following message will appear on the LCD and the BHT will start backing up data. After completion of the backup operation so that the message disappears, remove the battery cartridge.

(The backup operation may take several tens of seconds depending upon the volume of data to be backed up.)




- (2) When powering on the BHT after storage with no battery cartridge loaded:

Even after removal of the rechargeable battery cartridge, the calendar clock will work with the backup power source for a while.

If the calendar clock backup has stopped, loading the battery cartridge and powering on the BHT will display the following message, prompting you to set the current date and time.

For details about the setting procedure, contact your system administrator.

(The indication "00/01/01 00:00" will vary depending upon the calendar clock state.)



```
Set the current  
date and time.
```

```
00/01/01 00:00  
_ / /      :
```

Error Messages

If some error occurs when the power is turned on or during program execution, one of the following error messages will appear on the LCD.

System Program error

```
*****  
**   No System!  **  
*****
```

■ Problem

A System Program error has occurred.

NOTE

If this error occurs, the BHT beeps five times (for 0.1 second per beep) and then turns itself off.

■ Solution

Contact your system administrator.

Low battery indication—Level 1

```
Battery voltage  
has lowered.
```

■ Problem

When the power is turned on or off or during execution of program (System Mode or application), the battery output level has dropped below a specified lower level limit.

NOTE

If low battery is detected, the BHT displays this message for approx. 2 seconds and beeps three times (for 0.1 second per beep). After that, it will resume previous regular operation.

■ Solution

The service life of the rechargeable battery cartridge will expire soon, requiring replacement or recharge.

Replace it with a fully charged battery cartridge or charge it.

Low battery indication—Level 2

■ Problem

When the power is turned on or during execution of program (System Mode or application), the battery output level has lowered.

NOTE

If lower battery is detected, the BHT beeps five times (for 0.1 second per beep) and then turns itself off. Depending upon the battery level, the beeper may not sound five times.

■ Solution

Replace it with a fully charged battery cartridge or charge it.

```
Charge the
battery!
```

Abnormally powered off last

■ Problem

After powered off abnormally*, the BHT had been left with no battery cartridge loaded or with a discharged battery cartridge loaded, so unsaved data was lost.

(*“Normally powered off” refers to powered off with the PW key or by the auto power-off feature.)

■ Solution

Contact your system administrator.

```
Your terminal was
not shut down
properly the last
time it was used.
```

```
Unsaved data
was lost.
```

```
[SF+2]
```

Execution program not selected

■ Problem

No user program has been selected as an execution program to be run when the power is turned on.

NOTE

If this error occurs, the BHT beeps five times (for 0.1 second per beep) and then turns itself off.

■ Solution

Contact your system administrator.

```
No execution
program selected.
Contact your
administrator.
```

System Program malfunction

■ Problem

During execution of System Program, the System Program has attempted to write onto the write-protected area of the memory.

(xxxxxxx: Error address)

NOTE If this error occurs, the BHT beeps five times (for 0.1 second per beep).

```
Reload the battery
to restart!

XXXXXXXXX 01
```

■ Solution

Unload and reload the rechargeable battery cartridge, then turn on the power. If this error occurs frequently, contact your system administrator.

■ Problem

During execution of System Program, the System Program has received an invalid command code.

(xxxxxxx: Error address)

NOTE If this error occurs, the BHT beeps five times (for 0.1 second per beep).

```
Reload the battery
to restart!

tskid:XXXXXXXX
ercd :XXXXXXXX
addr :XXXXXXXX 02
```

■ Solution

Unload and reload the rechargeable battery cartridge, then turn on the power. If this error occurs frequently, contact your system administrator.

Resume data lost

■ Problem

No resume data has been retained since the BHT was not normally powered off and then left with no battery cartridge loaded or with a discharged battery cartridge loaded even if the resume function had been set to ON.

NOTE The BHT displays this error message for 3 seconds and automatically runs the execution program from the point of start-up.

```
No resume info.
has been retained.
Program restarts
automatically.
```

Your settings in
System Mode
have been lost.

Will reset
to defaults.

Error in System Mode settings

■ Problem

Your settings made in System Mode contain an error.

NOTE

If this error occurs, the System Mode settings revert to the factory defaults.

TIP

The BHT displays this error for 3 seconds and then displays the “No execution program selected...” message.

■ Solution

Contact your system administrator.

System down error

■ Problem

An error has occurred during execution of System Program.

NOTE

If this error occurs, the BHT beeps five times (for 0.1 second per beep).

■ Solution

Unload and reload the rechargeable battery cartridge, then turn on the power.

If this error occurs frequently, contact your system administrator.

System down error!

```
type:XXXXXXXX R0 :XXXXXXXXX
ercd:XXXXXXXX R1 :XXXXXXXXX
inf1:XXXXXXXX R2 :XXXXXXXXX
inf2:XXXXXXXX R3 :XXXXXXXXX
R4 :XXXXXXXXX
SR :XXXXXXXX R5 :XXXXXXXXX
PC :XXXXXXXX R6 :XXXXXXXXX
PR :XXXXXXXX R7 :XXXXXXXXX
R8 :XXXXXXXXX
R9 :XXXXXXXXX
R10:XXXXXXXXX
R11:XXXXXXXXX
R12:XXXXXXXXX
R13:XXXXXXXXX
R14:XXXXXXXXX
R15:XXXXXXXXX
```


System administrator to be called

Contact your
administrator.
Note the error
number.
(XXXX)

■ Problem

Any of the following errors has occurred:

- | | |
|---|--------|
| (1) Hardware error or calendar clock error: | (1010) |
| Flash memory error: | (1020) |
| (2) Memory storage error | (2XXX) |
| (3) Execution program error | (3010) |
| (XXXX: Error code) | |

NOTE

If any of the above errors occurs, the BHT beeps five times (for 0.1 second per beep) and then turns itself off.

■ Solution

Turn on the power again. If this error occurs frequently, contact your system administrator.

Proper Care of the BHT

Clean the housing and the rechargeable battery cartridge terminals with a dry, soft cloth. Before cleaning, be sure to power off the BHT.

- Never use benzene, alcohol, or other organic solvents. The housing may be marred or the paint may come off.
- Never rub or strike the liquid crystal display (LCD) with anything hard. The LCD surface will be easily scratched or broken.
- When cleaning the keypad, do not scrub the surface too hard, and do not pull on the keys. Doing so may break the keys or cause the keypad to dislocate.
- If the BHT becomes smudged, moisten a soft cloth with neutral detergent and wring it out thoroughly. Wipe the BHT with the cloth and then go over it again with a dry cloth.



Dust or dirt accumulating on the clear plate of the bar-code reading window will affect reading performance. If you use the BHT in dusty areas, therefore, periodically check the clear plate of the bar-code reading window and clean it if dusty.

- To clean the plate, first blow the dust away with an air brush. Then wipe the plate with a cotton swab or the similar soft one gently.
- If sand or hard particles have accumulated, never rub the plate; doing so will scratch or damage it. Blow the particles away with an air brush or a soft brush.

Handling Notes

- An early upload of gathered data is recommended, since the data stored in the RAM might be affected by the so-called “soft error” or other environmental phenomena. In some cases, the “Contact your administrator.” will appear on the LCD.
- Do not use the BHT near a personal or amateur radio device. Doing so may cause the BHT to malfunction.
- Avoid storing the rechargeable battery cartridge in a hot place. The battery capacity may be decreased.
- Do not touch the charge terminals of the battery cartridge by hand or stain those terminals. Doing so could result in a charging failure.
- Use a dedicated rechargeable battery cartridge for the BHT. Do not use a dry battery cartridge.
- When connecting or disconnecting the direct-connect interface cable to/from the BHT, do not plug or unplug at an angle and do not pull the cable strongly. Doing so will result in a machine failure.
- Do not use the BHT near a magnet or device that generates strong magnetic field. Doing so will deflect the optical axis of the laser beam, resulting in a reading failure or machine trouble.
- If the BHT has been stored in a hot (50°C to 60°C, 122°F to 140°F) and humid place, allow it to sit at room temperature and humidity for at least one day before use. Using the BHT with its inside being hot will fail to scan or result in a machine failure.

Declaration of Conformity (For European Union)

The radio frequency module that complies with the Directive 99/5/EC(R&TTE) is mounted on this device (BHT-7500W).

DECLARATION OF CONFORMITY Directive 99/5/EC (R&TTE)

Manufacturer or

Authorized representative : **DENSO WAVE INCORPORATED**

Address : **1-1 Showa-cho, Kariya-shi, Aichi-ken, 448-8661, Japan**

We declare on our sole responsibility, that the following product :

- Kind of equipment : ***Radio frequency module***

- Type-designation : ***MI802B3***

is compliance with the essential requirement of §3 of the R&TTE.

- Health and safety requirements pursuant to §3(1)a :

Applied Standard(s) or other means of providing conformity :
EN60950 : 2000

- Protection requirements concerning EMC §3(1)b :

Applied Standard(s) or other means of providing conformity :
EN301 489-17 : 2000

- Measures for the effective use of the Radio frequency spectrum §3(2) :

Applied Standard(s) or other means of providing conformity :
ETS300 328/A2 : 2001

CE marking



- DENSO WAVE INCORPORATED does not assume any product liability arising out of, or in connection with, the application or use of any product, circuit, or application described herein.

- Intellectual Property Precaution

DENSO WAVE INCORPORATED ("DENSO WAVE") takes reasonable precautions to ensure its products do not infringe upon any patent or other intellectual property rights of other(s), but DENSO WAVE cannot be responsible for any patent or other intellectual property right infringement(s) or violation(s) which arise from (i) the use of DENSO WAVE's product(s) in connection or in combination with other component(s), product(s), data processing system(s) or equipment or software not supplied from DENSO WAVE; (ii) the use of DENSO WAVE's products in a manner for which the same were not intended nor designed; or (iii) any modification of DENSO WAVE's products by other(s) than DENSO WAVE.

DENSO WAVE INCORPORATED
4-2-12, Toranomom, Minato-ku, Tokyo, Japan 105-0001
<http://www.denso-wave.com/>

496487-4211