

INSTRUCTION MANUAL



KONGSBERG

cNODE Mini MF 4000 m





KONGSBERG

cNODE Mini
Medium Frequency, 4000 m
Instruction manual

331869/E

April 2016 © Kongsberg Maritime AS

331869/E

April 2016 © Kongsberg Maritime AS

Table of contents

ABOUT THIS MANUAL.....	5
CNODE MINI.....	6
System description.....	7
Naming description.....	7
System diagram.....	8
System units.....	9
Scope of supply.....	11
General supply conditions.....	12
Receipt, unpacking and storage.....	12
Equipment responsibility.....	12
Support information.....	13
CABLE LAYOUT AND INTERCONNECTIONS.....	14
End cap connectors.....	15
Power converter connectors.....	16
OPERATIONAL PROCEDURES.....	18
Charging the transponder.....	19
Powering up the transponder.....	20
Powering down the transponder.....	21
Responder function.....	21
Setting up the internal tilt sensor.....	22
Configuring the transponder.....	22
MAINTENANCE.....	23
Charging the transponder.....	24
Cleaning the transponder.....	25
Inserting an O-ring.....	25
Opening the transponder.....	26
Changing the transducer.....	26
Lubricating the subsea connector.....	27
SPARE PARTS.....	28
cNODE Mini maintenance kit spare part.....	29
TD40V spare part.....	29
TD180 spare part.....	29
TD80V spare part.....	30
Split transponder (S) for remote transducer spare part.....	30
Remote transducer TDR180 spare part.....	30
Remote transducer TDR40V spare part.....	30

Remote transducer TDR30H spare part.....	31
Remote transducer TDR30V spare part.....	31
Transducer cable 6 m spare part	31
Depth sensor spare part.....	31
Battery spare part	32
Tube spare part.....	32
End cap spare part.....	32
Battery charger spare part	32
Power supply spare part.....	33
EMI Shield gasket - spare part.....	33
Retainer cord - Spare part	33
Transponder Test and Configuration unit (TTC30) spare part.....	33
TECHNICAL SPECIFICATIONS.....	34
Performance specification.....	35
Weight and outline dimensions	37
Power specifications.....	39
Environmental specifications	40
DRAWING FILE.....	41
cNODE Mini 31-40V-St outline dimensions.....	42
cNODE Mini 34-180 outline dimensions	43
cNODE Mini 34-40V outline dimensions	44
cNODE Mini 3x-180-D outline dimensions	45
cNODE Mini 3x-80V-D-St outline dimensions	46
cNODE Mini 31-80V-St outline dimensions.....	47

About this manual

Observe this general information about the cNODE Mini Instruction manual; its purpose and target audience.

Purpose of manual

The purpose of this instruction manual is to provide the descriptions and procedures required to install, operate and maintain the cNODE Mini.

Target audience

The manual is intended for all users of cNODE Mini.

Registered trademarks

Observe the registered trademarks that apply.

Windows®, Windows XP®, and Windows® 7 are either registered trademarks, or trademarks of Microsoft Corporation in the United States and/or other countries.

HiPAP® is a registered trademark of Kongsberg Maritime AS in Norway and other countries.

cNODE® is a registered trademark of Kongsberg Maritime AS in Norway and other countries.

cNODE Mini

Topics

[System description, page 7](#)

[Naming description, page 7](#)

[System diagram, page 8](#)

[System units, page 9](#)

[Scope of supply, page 11](#)

[General supply conditions, page 12](#)

[Support information, page 13](#)

System description

cNODE Mini is a family of transponders for underwater positioning and data links. cNODE Mini is designed to be a very versatile system with many interchangeable parts.

The transponders are operated from Acoustic Position Operator Station (APOS) with an acoustic telemetry link for command and data transfer. The transponders are compatible with both HiPAP Cymbal acoustic protocol for positioning and data link, and HPR 400 channels and telemetry. Perform SSBL positioning with a total of 560 HiPAP Cymbal channels and 56 HPR 400 channels, LBL positioning and acoustic link for command and data transfer. The transponders have both transponder and responder functions.

The transponders are rated to up to 4000 m with a housing made of aluminium or stainless steel. The transponders are designed with a modular construction which means that the transponder electronics, battery pack and optional add-on's can be replaced individually to suit the operation.

A transponder is normally a self-contained unit, receiving power from an internal rechargeable battery pack. The transponder can also be powered from an external power supply.

The transponder unit is designed with a modular construction such that the transponder electronics, battery pack and options (where applicable) can be replaced individually.

The transponder may be secured to a subsea structure using mounting brackets.

Note

Always make sure the vent screw is closed before deployment.

Naming description

The transponder name consists of the model name, the model number, the transducer beam width and any options included.

Model name

Mini

Model number

The two digit number in the transponder name describes the frequency band and the depth rating.

Example:

First number =Frequency band	Second number = Depth rating
3 = 30 kHz	4 = 4000 meters

Transducer beam width

180 = 180° beam width

40V = 40° vertical beam width

80V = 80° vertical beam width

Optional transponder modules

D: Depth sensor

Example of transponder name

The transponder name cNODE Mini 34-40V indicates that this transponder unit is operating in the 30 kHz, rated to 4000 metres depth, with a 40° transducer beam width vertical. The standard transponder tube material is aluminium.

Transponder identification


The transponders have labels that identifies:

- the transponder name
- serial number
- default channels

System diagram

The system diagram identifies the main components of the cNODE Mini.

cNODE Mini



- A** Transducer
- B** Top section module
- C** Tube
- D** End cap module

System units

cNODE is a family of transponders for underwater positioning and data links. The cNODE Mini is designed to be a very versatile system with many interchangeable units.

TD180

The transducer has a 180° omnidirectional beam width, and is available in aluminium and stainless steel.




TD40V

The transducer has a 40° vertical beam width, and is available in aluminium and stainless steel.



TD80V

The transducer has a 80° vertical beam width, and is only available in stainless steel.



Split transponder for remote transducer (S)

This top end cap has a standard external connector for remote transducers.



TDR180

The transducer has a 180° omnidirectional beam width. Available in aluminium and Super Duplex stainless steel.



TDR40V

The transducer has a 40° vertical beam width. Available in aluminium and Super Duplex stainless steel.



TDR30H

The transducer has a 30° horizontal beam width. Available in aluminium and Super Duplex stainless steel.



TDR30V

The transducer has a 30° vertical beam width. Available in aluminium and Super Duplex stainless steel.



Transducer cable 6 m

The transducer cable has two Subconn connectors; MCIL4F and MCIL4M. The cable connects all the remote transducers to the transponder.



Depth sensor

The depth sensor is a top section module. Available in aluminium and stainless steel.



Tube

The tube contains the battery and the electronics for the Mini transponder. Available in aluminium and stainless steel.



End cap

The end cap has a vent screw, safety valve with on/off switch and two external connectors and is available in aluminium and stainless steel.



Battery

The battery is a rechargeable nickel-metal hybrid battery.



Battery charger

Charging the battery has some risks, read the procedure first.



Power supply

Use the AC to DC converter for continuous charging of the cNODE Mini from an AC source.

Available in aluminium and stainless steel.



TTC (Transponder Test and Configuration unit)

The TTC 30 unit is for on deck testing and configuration of medium frequency transponders. It can test all KONGSBERG transponder channels, Cymbal and HPR 400. It can also test telemetry transponders with internal and external sensors.



Scope of supply

The following items are provided when you order a transponder.

- Transponder
- Instruction manual

General supply conditions

The following general supply conditions apply to this Kongsberg cNODE Mini delivery.

Receipt, unpacking and storage

Upon accepting shipment of the equipment, the shipyard and/or the dealer must ensure that the delivery is complete and inspect each shipping container for evidence of physical damage.

If the inspection reveals any indication of crushing, dropping, immersion in water or any other form of damage, the recipient should request that a representative from the company used to transport the equipment be present during unpacking.

All equipment must be inspected for physical damage, i.e. broken controls and indicators, dents, scratches etc. during unpacking. If any damage to the equipment is discovered, the recipient must notify both the transportation company and Kongsberg Maritime so that Kongsberg Maritime can arrange for replacement or repair of the damaged equipment.

Once unpacked, the equipment must be stored in a controlled environment with an atmosphere free of corrosive agents, excessive humidity or temperature extremes.

The equipment must be covered to protect it from dust and other forms of contamination when stored.

Equipment responsibility

Unless otherwise stated in the contract, the shipyard doing the installation and/or equipment dealer becomes fully responsible for the equipment upon receipt.

The duration of responsibility cover:

- The period of time the equipment is stored locally before installation
- The entire installation process
- Commissioning
- The period of time between commissioning and the final acceptance of the equipment by the end user or owner

Unless other arrangements have been made in the contract, the Kongsberg cNODE Mini guarantee period (as specified in the contract) begins when the acceptance documents have been signed.

Support information

If you need support for your Kongsberg cNODE Mini you must contact Kongsberg Maritime AS.

- **Company name:** Kongsberg Maritime AS
- **Address:** Strandpromenaden 50, 3190 Horten, Norway
- **Telephone, 24h support:** +47 33 03 24 07
- **Telefax:** +47 33 04 76 19
- **Website:** <http://www.km.kongsberg.com>
- **Support website:** http://www.km.kongsberg.com/support_hpr
- **E-mail address:** km.support.hpr@kongsberg.com


Cable layout and interconnections

Topics

[End cap connectors, page 15](#)

[Power converter connectors, page 16](#)

End cap connectors



The end cap has two connectors:

- External signal connector; 8 pin male subconn MCBH8M for serial line, external power supply and responder signal
- External charge connector; 8 pin female subconn MCBH8F for charging the battery


Signal connector pin out

Pin no.	Signal
1	TP TX
2	GND
3	TP RX
4	Responder +
5	Responder —
6	GND
7	Ext. power +15 VDC (use in parallel with 8)
8	Ext. power +15 VDC (use in parallel with 7)

Battery charger connector pin out

Pin no.	Signal
1	Charger A
2	Charger B
3	Charger C
4	NTC A
5	NTC B
6	NTC C
7	GND
8	GND

Power converter connectors



The end cap has two connectors:

- Power in connector; 6 pin male subconn MCBH6MAS
- Power out connector; 6 pin female subconn MCBH6FAS

Power in connector pin out

Pin no.	Signal
1	Responder +
2	115/230 VAC (L)
3	115/230 VAC (L)
4	Responder –
5	115/230 VAC (N)
6	115/230 VAC (N)

Power out connector pin out

Pin no.	Signal
1	Responder +
2	15 VDC
3	15 VDC
4	Responder –
5	GND
6	GND

Operational procedures

Topics

[Charging the transponder, page 19](#)

[Powering up the transponder, page 20](#)

[Powering down the transponder, page 21](#)

[Responder function, page 21](#)

[Setting up the internal tilt sensor, page 22](#)

[Configuring the transponder, page 22](#)

Charging the transponder

The battery is charged inside the cNODE Mini. This is connected with some risk, please read the information below and follow the charge procedure carefully.

Prerequisites

Caution

When you are charging the battery ensure good ventilation and stable temperature. Do not cover the transponder. No open fire, sparks or smoking in the area.

NiMH batteries can generate some hydrogen and oxygen gas, the amount depending on certain conditions. Most often this generation occurs during charging.

Procedure

1 Switch off the transponder.

2 Climatize the transponder.

The battery must have a temperature between 5 °C and 40 °C. Recommended charging temperature is 25 °C.

3 Unscrew the vent screw until you feel some resistance (a nylon washer is forced against a metal surface). The O-ring is now visible.

Hold the transponder in an upright position while you do this, so that any water droplets caught around the vent screw comes out, rather than going inside the cNODE Mini.

4 Connect the charger plug to the connector on the transponder marked CHARGE.

5 Connect Power supply to mains (110 or 220 VAC).

6 Switch on the charger.

The charger measures the battery status; all LEDs emit constant yellow light. If the temperature is out of range, the LEDs will flash orange/green.

Fast charge starts and the LEDs emit constant orange light.

When the battery is fully charged the LEDs will be green with a yellow flash every minute.

7 Switch off the charger.

8 Disconnect the charger plug from the transponder.

9 Close the vent screw.

Tighten the vent screw by hand only, until you feel a rather sudden resistance. (an internal axial O-ring hits a metal surface, compresses 0.3 mm, before 2 metal surfaces meet). The main flat circular surface of the end cap should now align with the edge of a semicircular groove that runs all around the vent screw. This is to visually confirm that the vent screw has been properly tightened.

Result

When the battery is fully charged the charger will start trickle charging the battery. It is not recommended to trickle charge the battery for a long time. It is better to fast charge, and then top up the battery just before operation.

Further requirements

Caution


When the charging is done, always make sure the vent screw is closed.

Deploying the transponder with the vent screw open will ruin the transponder.

Powering up the transponder

Before deploying the transponder you must connect the battery to the internal circuitry.

Procedure



- 1 See the alignment markers on the ON/OFF switch.
- 2 Align the markers using a suitable screwdriver.

Result

The unit transmits bursts when switched on.


Each time the transponder is switched on, it resets to the two default channels.

Note

Always make sure the vent screw is closed before deployment.

Powering down the transponder

Procedure



- Use a suitable screwdriver to move the two marker dots away from each other.

Result

The transponder is off in all three other positions.

Note

Always keep the transponder switched off when not in use.

Always make sure the vent screw is closed before deployment.

Responder function

Procedure

- cNODE will automatically change to responder mode if a responder trigger signal is present. cNODE will change back to transponder mode if no new trigger signal is received within the next 30 seconds.


Result

See APOS online help for setting up a responder.

Setting up the internal tilt sensor

The transponder needs to face the right way to show the correct values.

Procedure



- Top view of the transponder to the left in this figure - showing the FWD direction. FWD is marked with the two holes in the bottom end cap module.

Configuring the transponder

The transponder channel and mode can be changed.

Prerequisites

The transponder is configured by Kongsberg Maritime. The channel and mode (FSK or cymbal) may be changed if required. The procedure to change configurations depends on the HiPAP/HPR system in use.

Procedure

- Change the channel and mode either by acoustic telemetry from a HiPAP system or via serial line from a Transponder Test and Configuration unit.
See APOS online help or the instruction manual for the TTC.

Maintenance

Topics

[Charging the transponder, page 24](#)

[Cleaning the transponder, page 25](#)

[Inserting an O-ring, page 25](#)

[Opening the transponder, page 26](#)

[Changing the transducer, page 26](#)

[Lubricating the subsea connector, page 27](#)

Charging the transponder

The battery is charged inside the cNODE Mini. This is connected with some risk, please read the information below and follow the charge procedure carefully.

Prerequisites

Caution

When you are charging the battery ensure good ventilation and stable temperature. Do not cover the transponder. No open fire, sparks or smoking in the area.

NiMH batteries can generate some hydrogen and oxygen gas, the amount depending on certain conditions. Most often this generation occurs during charging.

Procedure

1 Switch off the transponder.

2 Climatize the transponder.

The battery must have a temperature between 5 °C and 40 °C. Recommended charging temperature is 25 °C.

3 Unscrew the vent screw until you feel some resistance (a nylon washer is forced against a metal surface). The O-ring is now visible.

Hold the transponder in an upright position while you do this, so that any water droplets caught around the vent screw comes out, rather than going inside the cNODE Mini.

4 Connect the charger plug to the connector on the transponder marked CHARGE.

5 Connect Power supply to mains (110 or 220 VAC).

6 Switch on the charger.

The charger measures the battery status; all LEDs emit constant yellow light. If the temperature is out of range, the LEDs will flash orange/green.

Fast charge starts and the LEDs emit constant orange light.

When the battery is fully charged the LEDs will be green with a yellow flash every minute.

7 Switch off the charger.

8 Disconnect the charger plug from the transponder.

9 Close the vent screw.

Tighten the vent screw by hand only, until you feel a rather sudden resistance. (an internal axial O-ring hits a metal surface, compresses 0.3 mm, before 2 metal surfaces meet). The main flat circular surface of the end cap should now align with the edge of a semicircular groove that runs all around the vent screw. This is to visually confirm that the vent screw has been properly tightened.

Result

When the battery is fully charged the charger will start trickle charging the battery. It is not recommended to trickle charge the battery for a long time. It is better to fast charge, and then top up the battery just before operation.

Further requirements**Caution**

When the charging is done, always make sure the vent screw is closed.

Deploying the transponder with the vent screw open will ruin the transponder.

Cleaning the transponder

The transponder must be cleaned after use.

Procedure

- 1 Remove any growth and dirt with a stiff brush or a wooden or plastic scraper. Be careful not to damage the transducer.
- 2 Clean the unit thoroughly with lots of fresh water.
- 3 Dry off, so no water can come inside when opening.

Inserting an O-ring

The O-rings must be inspected for damage as often as possible.

Procedure**Note**

Make sure to keep the O-rings and mating surfaces free of dust and debris.

Do not use a screwdriver or similar when removing the O-ring, use an O-ring tool.

- 1 Open the transponder.
- 2 Remove the existing O-ring.
- 3 Clean the surface and cover it with a thin film of silicone grease.
Use lint-free objects when cleaning the surfaces.
- 4 Insert the new O-ring.

- 5 Close the transponder.

Opening the transponder

In order to replace the transponder battery - and to access the electronic module for maintenance - the unit must be opened.

Prerequisites

The transponder must be cleaned and dried before opening, so that no dirt or water seeps into the unit when it is opened.

Procedure

- 1 Pull out the lock cord between the tube and the end cap.
If the lock cord is hard to remove, try carefully opening the vent screw. Pressure may have built up inside the transponder.
- 2 Remove the end cap.
There is a 5 mm orientation peg at either end of the tube. When pulling apart, make sure to keep this orientation until all parts are completely free from each other. Forceful twisting of the parts relative to each other while the internal parts are still mated, will damage the unit.
- 3 Pull out the lock cord between the transducer and the tube.
- 4 Remove the transducer carefully, the chassis and the battery is fastened to the transducer.
- 5 Replace the O-rings that are damaged or used for more than a year.
- 6 Make sure the mating surfaces and the O-rings are completely clean and wipe a thin film of silicone grease over the rings and mating surfaces.

Result

Follow the procedure for opening the transponder in reverse order to close it.

Changing the transducer

The transducer is a sealed unit and does not open. If the transducer is damaged, replace the whole unit.

Prerequisites

The transponder needs to be clean and open to change the transducer.

Procedure

- 1 Remove the battery carefully.
- 2 Unscrew the chassis from the transducer.
- 3 Make sure the new transducer is of the same type as the old.
- 4 Fasten the transducer to the chassis and fit the battery.

Further requirements

Assemble the transponder.

Lubricating the subsea connector

The subsea connector must be kept clean from grit and dirt.

Prerequisites

Caution

Do not use silicone based sprays like 5–55, WD-40 or similar. These products will degrade the rubber fused around the metal pins.

Procedure

- 1 Remove the dummy plug or the external cable from the connector.
- 2 Apply Molykote 44M silicone based grease.
Half a match head dose per contact is enough.

Spare parts

Topics

[cNODE Mini maintenance kit spare part, page 29](#)

[TD40V spare part, page 29](#)

[TD180 spare part, page 29](#)

[TD80V spare part, page 30](#)

[Split transponder \(S\) for remote transducer spare part, page 30](#)

[Remote transducer TDR180 spare part, page 30](#)

[Remote transducer TDR40V spare part, page 30](#)

[Remote transducer TDR30H spare part, page 31](#)

[Remote transducer TDR30V spare part, page 31](#)

[Transducer cable 6 m spare part, page 31](#)

[Depth sensor spare part, page 31](#)

[Battery spare part, page 32](#)

[Tube spare part, page 32](#)

[End cap spare part, page 32](#)

[Battery charger spare part, page 32](#)

[Power supply spare part, page 33](#)

[EMI Shield gasket - spare part, page 33](#)

[Retainer cord - Spare part, page 33](#)

[Transponder Test and Configuration unit \(TTC30\) spare part, page 33](#)

cNODE Mini maintenance kit spare part

- **Part name:** cNODE Mini maintenance kit
- **Part number:** 351794

The kit consists of:

- 2 locking cords
- 4 O-rings 58 mm
- 2 locking sleeves MCDLSF
- 1 female dummy plug
- 1 male dummy plug
- 1 O-ring 12 mm
- 1 O-ring 10 mm

TD40V spare part

Aluminium

- **Part name:** TD40V Mini Aluminium
- **Part number:** 332186



Stainless steel

- **Part name:** TD40V St Mini Steel
- **Part number:** 365401

TD180 spare part

Aluminium

- **Part name:** TD180 Mini Aluminium
- **Part number:** 333059




Stainless steel

- **Part name:** TD180 St Mini Steel
- **Part number:** 320885

TD80V spare part

- **Part name:** TD80V St Mini Steel
- **Part number:** 352910



Split transponder (S) for remote transducer spare part

Aluminium

- **Part name:** Split transponder (S) for remote transducer Aluminium
- **Part number:** 349750



Stainless steel

- **Part name:** Split transponder (S) for remote transducer Stainless steel
- **Part number:** 330071

Remote transducer TDR180 spare part

Aluminium

- **Part name:** Remote transducer TDR180
- **Part number:** 349742



Stainless steel

- **Part name:** Remote transducer TDR180
- **Part number:** 375361

Remote transducer TDR40V spare part

Aluminium

- **Part name:** Remote transducer TDR40V
- **Part number:** 349743



Stainless steel

- **Part name:** Remote transducer TDR40V
- **Part number:** 375360

Remote transducer TDR30H spare part

Aluminium

- **Part name:** Remote transducer TDR30H
- **Part number:** 345773



Stainless steel

- **Part name:** Remote transducer TDR30H
- **Part number:** 375359

Remote transducer TDR30V spare part

Aluminium

- **Part name:** Remote transducer TDR30V
- **Part number:** 333445



Stainless steel

- **Part name:** Remote transducer TDR30V
- **Part number:** 370447

Transducer cable 6 m spare part

- **Part name:** Transducer cable, 6 m
- **Part number:** 345772



Depth sensor spare part

Aluminium

- **Part name:** cNODE Mini Depth sensor
- **Part number:** 402525

Stainless steel

- **Part name:** cNODE Mini Depth sensor, steel
- **Part number:** 405689



Battery spare part

- **Part name:** Battery
- **Part number:** 290–220687



Tube spare part

Aluminium

- **Part name:** cNODE Tube aluminium
- **Part number:** 381346



Stainless steel

- **Part name:** cNODE Tube stainless steel
- **Part number:** 381343

End cap spare part

Aluminium

- **Part name:** cNODE Mini end cap aluminium
- **Part number:** 351794



Stainless steel

- **Part name:** cNODE Mini end cap steel
- **Part number:** 349131

Battery charger spare part

- **Part name:** Battery charger cNODE Mini
- **Part number:** 290-220687



Power supply spare part

Aluminium

- **Part name:** cNODE Power supply Aluminium
- **Part number:** 346471



Stainless steel

- **Part name:** cNODE Power supply Steel
- **Part number:** 367386

EMI Shield gasket - spare part

The Electromagnetic interference (EMI) shield gasket is used to establish a firm electrical connection between the outer body of the transponder and the end cap. This electrical connection is vital, because the end cap holds the sacrificial zinc anodes.

- **Part name:** Electromagnetic interference (EMI) shield gasket
- **Part number:** 314433

Retainer cord - Spare part

The plastic retainer cord is used to secure and hold the end caps in place when the transponder housing is closed.

- **Part name:** Retainer cord
- **Part number:** 314415

Transponder Test and Configuration unit (TTC30) spare part

- **Part name:** TTC 30
- **Part number:** 345775



Technical specifications

Topics

[Performance specification, page 35](#)

[Weight and outline dimensions, page 37](#)

[Power specifications, page 39](#)

[Environmental specifications, page 40](#)

Performance specification

These performance specifications summarize the main functional and operational characteristics of the cNODE Mini.

cNODE Mini 3x series

- **Frequency band:** Medium frequency (MF)
- **Maximum depth rating:** 4000 m

Internal tilt

- **Max. detectable angles:** $\pm 90^\circ$
- **Accuracy:** $\pm 2^\circ$


Responder trigger signal

Responder trigger connection via the external signal connector.

- **Logic pulse:** Positive
- **Amplitude:** 5 to 25 V
- **Duration:** 2 to 6 ms


TD180

- **Beam pattern:**
- **Transducer beam:** 180° vertical
- **Frequency band:** Medium frequency
- **Receiver sensitivity:** 100 dB
- **Maximum source levels:**
 - Max 190 dB
 - High 184 dB
 - Low 178 dB
 - Min 173 dB




TD40V

- **Beam pattern:**
- **Transducer beam:** 40° vertical
- **Frequency band:** Medium frequency
- **Receiver sensitivity:** 90 dB
- **Maximum source levels:**
 - Max 203 dB
 - High 197 dB
 - Low 191 dB
 - Min 183 dB



TD80V

- **Beam pattern:**
- **Transducer beam:** 80° vertical
- **Frequency band:** Medium frequency
- **Receiver sensitivity:** 85 dB
- **Maximum source levels:**
 - Max 188 dB
 - High 182 dB
 - Low 176 dB
 - Min 171 dB



Battery charger

- **Charge method:** Constant current, charging the three battery strings individually
- **Detection method for fully charged battery:** Temperature rise, maximum temperature and maximum time (165 min.)
- **Charging time:** 2 hours 45 minutes for an empty battery

Weight and outline dimensions

These weights and outline dimension characteristics summarize the physical properties of the cNODE Mini.

cNODE Mini

Transponder	Weight in air	Weight in water	Height	Diameter
cNODE Mini 34-40V	6.7 kg	3.4 kg	600 mm	85 mm
cNODE Mini 34-180	6.7 kg	3.4 kg	598 mm	85 mm
cNODE Mini 31-80V-D-St	15.4 kg	11.4 kg	718 mm	85 mm

TD180

- **Height:** 70.5 mm
- **Diameter:** Ø88 mm

TD40V

- **Height:** 71 mm
- **Diameter:** Ø100 mm

TD30H

- **Height:** 123 mm
- **Diameter:** Ø77 mm

TD80V

- **Height:** 36.5 mm
- **Diameter:** Ø80 mm

Remote transducer TDR180

- **Height:** 209.8 mm
- **Diameter:** Ø 88 mm

Remote transducer TDR40V

- **Height:** 218.6 mm
- **Diameter:** Ø 100 mm

Remote transducer TDR30H

- **Height:** 262.4 mm

- **Diameter:** Ø 77 mm

Remote transducer TDR30V

- **Height:** 279.5 mm
- **Diameter:** Ø 166mm

Transducer cable for remote transducers

- **Length:** 6 m

Split transponder (S) for remote transducer

- **Height:** 31.5 mm
- **Diameter:** Ø85 mm

Depth sensor (D)

- **Height:** 154 mm
- **Diameter:** Ø85 mm

Tube

- **Height:** 495 mm
- **Diameter:** Ø85 mm

Basic end cap

- **Height:** 31.5 mm
- **Diameter:** Ø85 mm

Floating collar

- **Height:** 845 mm
- **Width:** 290 mm

Power supply

- **Height:** 309.2 mm
- **Diameter:** Ø85 mm

Battery charger

Weight	Height	Width	Depth
2.9 kg	83 mm	256 mm	355 mm

Power specifications

These power characteristics summarize the power specifications for the cNODE Mini.

cNODE Mini battery lifetime

- Quiescent: 60 days

Mini 34–180 series – Cymbal and Mini 31–180 series – Cymbal

Update rate	1 seconds [days]	2 seconds [days]	3 seconds [days]	4 seconds [days]	5 seconds [days]	10 seconds [days]
TX power level						
Minimum	5.7	6.0	6.1	6.2	6.2	6.3
Low	4.2	5.1	5.4	5.6	5.8	6.1
High	2.1	3.2	3.8	4.2	4.5	5.3
Maximum	0.5	1.1	1.5	1.9	2.2	3.3

Mini 34–180 series – FSK and Mini 31–180 series – FSK

Update rate	1 seconds [days]	2 seconds [days]	3 seconds [days]	4 seconds [days]	5 seconds [days]	10 seconds [days]
TX power level						
Minimum	10.1	10.4	10.5	10.6	10.6	10.7
Low	8.5	9.5	9.9	10.1	10.2	10.5
High	5.3	7.1	8.0	8.5	8.9	9.7
Maximum	1.8	3.1	4.1	4.8	5.4	7.3

Mini 34–40V series – Cymbal and Mini 31–40V series – Cymbal

Update rate	1 seconds [days]	2 seconds [days]	3 seconds [days]	4 seconds [days]	5 seconds [days]	10 seconds [days]
TX power level						
Minimum	5.7	6.0	6.1	6.2	6.2	6.3
Low	3.5	4.5	5.0	5.3	5.5	5.9
High	1.2	2.1	2.8	3.3	3.6	4.6
Maximum	0.3	0.6	0.9	1.2	1.5	2.4

Mini 34–40V series – FSK and Mini 31–40V series – FSK

Update rate	1 seconds [days]	2 seconds [days]	3 seconds [days]	4 seconds [days]	5 seconds [days]	10 seconds [days]
TX power level						
Minimum	10.1	10.4	10.5	10.6	10.6	10.7
Low	7.5	8.8	9.4	9.7	9.9	10.3
High	3.6	5.4	6.5	7.2	7.8	9.0
Maximum	1.1	2.0	2.8	3.4	3.9	5.8

Battery charger

- **Voltage requirement:** 110 or 220 V

Environmental specifications

These environmental specifications summarize the temperature and humidity requirements for the cNODE Mini.

All cNODE Mini transponders

- **Operational temperature:** -5 to +55°C
- **Storage temperature:** -40 to +70°C

Battery

- **Operational temperature:** -5 to +55°C
- **Storage temperature:** -20 to +30°C
- **Storage humidity:** <50% relative

Battery charger

- **Operational temperature:** 5 to 40°C for fast charging
- **Storage temperature:** -40 to +70°C
- **Relative humidity:** 10 to 90% relative non-condensing
- **Ingress protection:** IP30

Drawing file

Topics

[cNODE Mini 31-40V-St outline dimensions, page 42](#)

[cNODE Mini 34-180 outline dimensions, page 43](#)

[cNODE Mini 34-40V outline dimensions, page 44](#)


[cNODE Mini 3x-180-D outline dimensions, page 45](#)

[cNODE Mini 3x-80V-D-St outline dimensions, page 46](#)

[cNODE Mini 31-80V-St outline dimensions, page 47](#)


cNODE Mini 31-40V-St outline dimensions

Drawing 400753




cNODE Mini 34-180 outline dimensions

Drawing 351790




cNODE Mini 34-40V outline dimensions

Drawing 329305




cNODE Mini 3x-180-D outline dimensions

Drawing 402539




cNODE Mini 3x-80V-D-St outline dimensions

Drawing 356189



cNODE Mini 31-80V-St outline dimensions

Drawing 381473



Index

290-220687	battery charger (spare part)	32	battery charger	
290-220687	battery (spare part)	32	description	11
314415	retainer cord (spare part)	33	spare part	32
314433	electromagnetic interference (EMI) shield		block	
	gasket (spare part)	33	diagram	8
320885	TD180 St (spare part)	29	book	
332186	TD40V (spare part)	29	purpose	5
	TD80V (spare part)	30	target audience	5
333059	TD180 (spare part)	29		
345775	TTC 30 (spare part)	33	C	
346471	power supply (spare part)	33	cables	
349750	split transponder (S) for remote transducer		interconnection	14
	(spare part)	30	interface	14
351794	maintenance kit (spare part)	29	layout	14
365401	TD40V St (spare part)	29	characteristics	
367386	power supply (spare part)	33	performance	35
381343	tube (spare part)	32	charging	
381346	tube (spare part)	32	transponder	19, 24
402525	depth sensor (spare part)	31	cleaning	
405689	depth sensor (spare part)	31	transponder	25
			configuration	
			transponder	22
			configuring	
			transponder	22
			D	
A			depth sensor	
about			description	10
battery	11		spare part	31
battery charger	11		description	
depth sensor	10		battery	11
description	7		battery charger	11
naming description	7		depth sensor	10
power supply	11		naming	7
transducer	9		power supply	11
TTC	11		system	7
tube	10		transducer	9
activate			TTC	11
responder function	21		tube	10
audience			dimensions	
this manual	5		specifications	37
			drawing	
			system diagram	8
B			E	
battery			electromagnetic interference (EMI) shield gasket	
description	11		spare part	33
spare part	32		EMI shield gasket	
			spare part	33
			end cap	
			top	26
			environmental	
			requirements	40
			equipment	
			handling	12
			receipt	12

responsibility	12	power supply	33
storage	12	TTC 30	33
F		outline dimensions	
functional		specifications	37
diagram	8	P	
G		performance	
general supply conditions	12	specifications	35
equipment responsibility	12	pin out	
receipt	12	end cap connectors	15
storage	12	power converter connectors	16
unpacking	12	power	
H		requirements	39
how to		power converter	
open the transponder	26	description	11
humidity		pin out	16
requirements	40	power down	
I		transponder	21
information		power supply	
support	13	description	11
inserting		spare part	33
o-ring	25	power up	
interconnection		transponder	20
cables	14	pressure sensor	
interface		description	10
cables	14	spare part	31
K		procedure	
Kongsberg Maritime		opening the transponder	26
support	13	publication	
L		purpose	5
lubricating		target audience	5
subsea connector	27	purpose	
M		this manual	5
maintenance kit		R	
spare part	29	reader	
manual		this manual	5
purpose	5	receipt	
target audience	5	general supply conditions	12
N		registered trademarks	5
naming		remote transducer	
description	7	TDR180	30
O		remote transducer cable	
o-ring		spare parts	31
inserting	25	remote transducer TDR30H	
open		spare parts	31
transponder	26	remote transducer TDR30V	
order number		spare parts	31
		remote transducer TDR40V	
		spare parts	30
		replacement	
		transducer	26
		requirements	
		environmental	40
		humidity	40
		power	39
		temperature	40
		responder	
		activate	21
		responsibility	
		equipment	12
		retainer cord	
		spare part	33

S

scope of supply 11

spare part 28

 battery 32

 battery charger 32

 depth sensor 31

 electromagnetic interference (EMI) shield

 gasket 33

 maintenance kit 29

 power supply 33

 retainer cord 33

 split transponder (S) for remote transducer 30

 TD180 29

 TD180 St 29

 TD40V 29

 TD40V St 29

 TD80V 30

 TTC 30 33

 tube 32

spare parts

 remote transducer cable 31

 remote transducer TDR30H 31

 remote transducer TDR30V 31

 remote transducer TDR40V 30

 TDR180 30

 TDR30H 31

 TDR30V 31

 TDR40V 30

specifications

 dimensions 37

 outline dimensions 37

 performance 35

 weight 37

split transponder (S) for remote transducer

 spare part 30

standard items

 provided with the delivery 11

start

 transponder 20

stop

 transponder 21

storage

 general supply conditions 12

subsea connector

 lubricating 27

supply conditions 12

 equipment responsibility 12

 receipt 12

 storage 12

 unpacking 12

support information 13

system

 diagram 8

system description 7

system units

 transducer 9

T

target audience

 this manual 5

TD180

 spare part 29

 weight and outline dimensions 37

TD180 St

 spare part 29

TD30H

 weight and outline dimensions 37

TD40V

 spare part 29

 weight and outline dimensions 37

TD40V St

 spare part 29

TD80V

 spare part 30

 weight and outline dimensions 37

TD180

 remote transducer 30

 spare parts 30

TDR30H

 spare parts 31

TDR30V

 spare parts 31

TDR40V

 spare parts 30

temperature

 requirements 40

this manual

 purpose 5

 target audience 5

tilt sensor

 internal 22

top end cap

 open 26

trademarks

 registered 5

transducer

 description 9

 replacement 26

transponder

 charging 19, 24

 cleaning 25

 configuration 22

 open 26

 power down 21

 power up 20

 start 20

 stop 21

 tilt sensor 22

transponder test and configuration unit

 description 11

TTC

 description 11

TTC 30

 spare part 33

tube

 description 10

 spare part 32

U

unpacking

 general supply conditions 12

W

weight

 specifications 37

weight and outline dimensions	
TD180	37
TD30H	37
TD40V	37
TD80V	37
wiring	
end cap connectors.....	15
information	14
power converter connectors	16

©2016 Kongsberg Maritime