

# **ARC EM Starter Kit User Guide**

Version 6280-009 March 2015

#### **Copyright Notice and Proprietary Information Notice**

Copyright © 2015 Synopsys, Inc. All rights reserved. This software and documentation contain confidential and proprietary information that is the property of Synopsys, Inc. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Synopsys, Inc., or as expressly provided by the license agreement.

#### **Destination Control Statement**

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

#### **Disclaimer**

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

#### **Trademarks**

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at <a href="http://www.synopsys.com/Company/Pages/Trademarks.aspx">http://www.synopsys.com/Company/Pages/Trademarks.aspx</a>.

All other product or company names may be trademarks of their respective owners.

Synopsys, Inc. 690 E. Middlefield Road Mountain View, CA 94043 www.synopsys.com

### **Contents**

1 Preface	9
Document Structure	9
2 Introduction	10
About the ARC EM Starter Kit	10
Target Applications	10
Tool Requirements	11
Platform Requirements	11
Development Process	11
3 Getting Started	13
Package Contents	13
Set up the ARC EM Starter Kit	14
Default Board Settings	14
Board Jumper Settings	14
Select the Default ARC EM Configuration	14
Connect the USB Cable	16
USB Driver Installation	16
Connect the Power Supply	16
Run the Self-Test	17
Self-Test and Bootloader	17
View Self-Test Output on PuTTY Console	18
4 Working with ARC EM Starter Kit	22
Selecting ARC EM Configurations	22
Connecting External Interfaces to the ARC EM Starter Kit	
Connecting the PMODAD2 Extension Module	25
5 About the Demo Packages	
About the Bare-Metal Demo Package	26
Supported ARC EM Starter Kit Hardware	
Directory Structure	
Compatibility	
About the MQX Demo Package	
Overview	

Directory Structure	31
6 Building and Running Applications	33
Building, Running, and Debugging Projects Using the MetaWare IDE	33
Download and Install MetaWare	33
Licenses	34
Download MetaWare Lite	34
Install MetaWare Lite	34
Hardware Connections between MetaWare and ARC EM Starter Kit	34
Run Applications using the MetaWare IDE	35
Building and Running Applications Using make	44
Building and Running Projects Using the ARC GNU IDE	48
7 Creating Applications Using the MetaWare Tools	58
Creating an Application Using the Command Line Tools	58
Debugging Applications Using the MetaWare Debugger	59
Creating Application Using the MetaWare IDE	60
Create a New Project in the MetaWare IDE	60
Invoking the Debugger and Running the Executable	65
8 Running Applications in Self-Boot Mode	69
Self-Boot Application Concept	69
Building a Self-Boot Application	69
Write the Self-Boot Application Image to SPI Flash	70
Writing	70
Reading	72
Running the Self-Boot Application	72
SPI Flash Memory Structure	73
Appendix: A Hardware Functional Description	75
Board Overview	75
FPGA Design Overview	77
External Hardware Interfaces	78
Connecting Peripheral Controllers	79
Pmod Pin Configuration	80
PMOD_MUX_CTRL Register	80
Pmod1 Configuration	81

UART_MAP_CTRL Register	81
Pmod2 Configuration	83
Pmod3 Configuration	83
Pmod4 Configuration	85
Pmod5 Configuration	85
Pmod6 Configuration	86
Pmod7 Configuration	88
Pmods Configuration summary	89
Headers J10, J11, J12	91
Peripheral Controllers	93
GPIO	93
I2C	94
SPI Master	95
SPI Slave	97
UART	98
Pin Mux Controller	100
Peripheral Memory Mapping	101
Interrupts Connections	101
On-Board Devices	102
JTAG Connector	102
USB	102
SD Card	102
Man-Machine Interface	102
Power Supply	104
Appendix: B ARC EM Configurations	
Programmer's Model	105
Core Configurations and Memory Mapping	105
ARC_EM5D and ARC_EM4 Configurations	105
ARC_EM7DARC_EM7DFPU, ARC_EM6 and ARC_EM6FPU Configurations	107
Detailed Core Configurations	109
Troubleshooting	
Appendix: C FPGA Image Recovery	
Board Jumper Settings	

Xilinx Lab Tools Installation		
Connecting the FPGA Programming Cable		
FPGA Programming Sequence	116	
SPI Flash-Programming Sequence	120	
Appendix: D Using a JTAG Debugger	125	
Ashling Opella-XD Debugger	125	
Lauterbach TRACE32 Debugger	127	
Lauterbach TRACE32 Tool Installation	128	
Glossary and References	129	
Glossary	129	
References	130	

### **List of Figures**

Figure 1 Board Jumper and Switch Locations	14
Figure 2 SW1 Switch	15
Figure 3 Power Supply and USB Cable Connection to the Board	17
Figure 4 COM6 Port	
Figure 5 PuTTY Configuration Window	20
Figure 6 Self-test Results in a Terminal Window, ARC_EM5D	21
Figure 7 SW1 DIP Switch	23
Figure 8 Peripheral device connected using Pmod	24
Figure 9 PmodAD2 Connection to Pmod2	
Figure 10 MIDE Directory	35
Figure 11 Selecting a Workspace	35
Figure 12 MetaWare IDE — Select Workspace Directory	36
Figure 13 MetaWare IDE — Select an Import Source	37
Figure 14 MetaWare IDE — Select Projects for Import	38
Figure 15 MetaWare IDE - Demo Projects in the Workspace	39
Figure 16 MetaWare IDE - Set Active Build Configurations	39
Figure 17 MetaWare IDE – Build Results in Console Window	40
Figure 18 MetaWare IDE – Selecting the Debug Configuration from the Run Menu	40
Figure 19 MetaWare IDE – Creating the new Debug Configuration	41
Figure 20 MetaWare IDE – Selecting a Name for the New Debug Configuration	42
Figure 21 MetaWare IDE – Selecting the Debugger Target	
Figure 22 MetaWare IDE – Debug Window	43
Figure 23 ARC GNU IDE - Select Workspace Directory	48
Figure 24 ARC GNU IDE - Import Existing Projects into Workspace (First Step)	49
Figure 25 ARC GNU IDE - Import Existing Projects into Workspace (Second step)	
Figure 26 ARC GNU IDE - List of Demo Projects in the Workspace	50
Figure 27 ARC GNU IDE - Set Active Build Configurations	51
Figure 28 ARC GNU IDE - Build Results in Console Window	52
Figure 29 ARC GNU IDE - Creating a Debug Configuration	53
Figure 30 ARC GNU IDE – Program Selection	54
Figure 31 ARC GNU IDE - Commands Initialization from the Debugger	55
Figure 32 ARC GNU IDE – Debug Window	56
Figure 33 ARC GNU IDE – Stepping Toolbar	56
Figure 34 ARC GNU IDE – Stepping Toolbar	57
Figure 35 ARC GNU IDE – Stepping Toolbar	57
Figure 36 MetaWare Settings Required to Use ARC JTAG through USB	60
Figure 37 MetaWare IDE - Creating a New Project	61
Figure 38 MetaWare IDE - Select Project Configurations	62
Figure 39 MetaWare IDE - Select TCF File	
Figure 40 MetaWare IDE - Create New Source File	
Figure 41 MetaWare IDE - Console Output for Test Project	
Figure 42 MetaWare IDE - Creating New Debug Configuration	
Figure 43 MetaWare IDE - Configure Debugger	
Figure 44 MetaWare IDE - Debug Perspective	

Figure 45 MetaWare IDE - Console window	68
Figure 46 Output of spi_rw	
Figure 47 Typical Flash Memory Structure	74
Figure 48 FGPA Design Block Diagram	77
Figure 49 Pmod Pin Numbering	80
Figure 50 Pin Positions at Headers J10, J11, and J12	
Figure 51 DW I2C Connection	94
Figure 52 DW SPI Master Connection	
Figure 53 DW UART Components Connection	98
Figure 54 Memory Map of ARC_EM5D Configuration	106
Figure 55 Memory Map of ARC_EM7D and ARC_EM7DFPU Configurations	108
Figure 56 Welcome Dialog	114
Figure 57 Product Registration Dialog	
Figure 58 USB FPGA Programming Cable Connection to the Board	116
Figure 59 iMPACT Tool – Main Window View	
Figure 60 iMPACT Tool – Initialize Chain Menu Option	118
Figure 61 iMPACT Tool – Assign New Configuration File Dialog Box	
Figure 62 iMPACT View of the Successful FPGA Programming	
Figure 63 iMPACT Tool – select SPI device	
Figure 64 iMPACT Tool – Add PROM File Dialog Box	122
Figure 65 iMPACT Tool – Select Attached SPI/BPI Dialog Box	
Figure 66 iMPACT View of the Successful SPI ROM Programming	124
Figure 67 Ashling XD Pod with Debug Cable	125
Figure 68 Jumper J8 Set	126
Figure 69 ARC JTAG Connection to the Board	127
Figure 70 Lauterbach TRACE32 with Debug Cable	127

### **List of Tables**

Table 1 Predefined ARC Configurations	15
Table 2 Predefined ARC Configurations	22
Table 3 Selecting the Configuration	23
Table 4 Directory Structure of the Bare-Metal Demo Package	28
Table 5 Availability of Bare-Metal demo Applications for Different Tools	29
Table 6 Core Configuration Supported for MetaWare and ARC GNU	29
Table 7 MQX Environment Variables	
Table 8 Folder Structure of the MQX Demo Package	
Table 9 Peripheral Devices Connection to Pmods	78
Table 10 Board Connections Overview of Peripheral Controllers	79
Table 11 Pin Assignment of Pmod1 (J1) Upper Row Depending on PM1[0]	
Table 12 Pin Assignment of Pmod1 (J1) Lower Row depending on PM1[2]	
Table 13 Pin Assignment of Pmod2 (J2) Depending on PM2[0]	
Table 14 Pin Assignment of Pmod3 (J3) Depending on PM3[0]	
Table 15 Pin Assignment of Pmod4 (J4) Depending on PM4[0]	
Table 16 Pin Assignment of Pmod5 (J5) Upper Row Depending on PM5[0]	
Table 17 Pin Assignment of Pmod5 (J5) Lower Row Depending on PM5[2]	
Table 18 Pin Assignment of Pmod6 (J6) Upper Row Depending on PM6[0]	
Table 19 Pin Assignment of Pmod6 (J6) Lower Row Depending on PM6[2]	
Table 20 Pin Assignment of Pmod7 (J7) Depending on PM7[0]	
Table 21 Pmods configuration summary	
Table 22 Pin Assignment of the Header J10 Depending on PM2[0]	
Table 23 Pin Assignment of the Header J11 Depending on PM3[0]	
Table 24 Pin Assignment of the Header J12 Depending on PM4[0]	
Table 25 SPI Master Signals Usage	
Table 26 Register File Mapping	
Table 27 Peripheral Memory Mapping	
Table 28 Interrupts Connections	
Table 29 Configuration Details	
Table 30 Board Jumper Settings	
Table 31 ARC EM Starter Kit JTAG Connector Pin-out	126

This chapter outlines the document structure and provides a brief chapter overview. Additionally, it contains a list of available resources and other supporting documents.

#### **Document Structure**

This document consists of the following chapters:

- Preface Overview of the available documentation and its organization.
- Introduction Overview of the ARC EM Starter Kit, target applications, and the tool requirements.
- Getting Started Software required for the ARC EM Starter Kit and step-by-step guide on how to connect it to a power supply and to a debugger.
- Working with ARC EM Starter Kit Procedures about how to configure the ARC EM Starter Kit.
- About the Demo Packages This section describes the demo packages used for ARC EM Starter Kit.
- Building and Running Applications Procedures about how to build, run, and debug applications using the MetaWare Development Toolkit and ARC GNU.
- Creating Applications Using the MetaWare Tools Procedures to create and debug software applications using the MetaWare Tools.
- Running Applications in Self-Boot Mode Procedures to run applications in self-boot mode.
- Hardware Functional Description Information about the hardware used in the ARC EM Starter Kit.
- ARC EM Configurations Information about the ARC EM configurations packaged with the ARC EM Starter Kit.
- FPGA Image Recovery Information about how to program the FPGA.
- Using a JTAG Debugger Information about using a JTAG debugger.
- Glossary and References List of abbreviations, terms, and external references.

This document describes the ARC EM Starter Kit and procedures to build and run applications on the ARC EM Starter Kit.

### About the ARC EM Starter Kit

The DesignWare® ARC® EM Starter Kit enables rapid software development, code porting, software debugging, and profiling for ARC EM5D and ARC EM7D processors.

The ARC EM Starter Kit consists of a hardware platform, including pre-installed FPGA images of ARC EM5D, ARC EM7D, and ARC EM7DFPU configurations with peripherals, and a software package. The ARC EM4 processor is a subset of ARC EM5D processor, and ARC EM6 processor is a subset of ARC EM7D processor. So software may be built for ARC EM4 or ARC EM6 processors but then run on the ARC EM5D or ARC EM7D processor configurations on the starter kit.

The development board is based on a Xilinx Spartan®-6 LX150 FPGA and supports hardware extensions using six 2x6 connectors supporting a total of 48 user I/O pins (plus power and ground pins) that can be used to connect components such as sensors, actuators, memories, displays, buttons, switches, and communication devices. A Digilent Pmod™ compatible extension board containing a four-channel 12-bit A/D converter with an I2C interface and an AC power adapter is included in the package.

### **Target Applications**

The ARC EM Starter Kit is targeted at the following applications:

- Evaluation of ARC EM processors
- Performance analysis of ARC EM processors

Tool Requirements ARC EM Starter Kit

You can connect the following end-devices to the ARC EM Starter Kit:

- Sensors
- Actuators
- Displays
- Buttons
- Switches
- Communication devices

### **Tool Requirements**

The ARC EM Starter Kit requires the following tools to be installed on your host:

Digilent Adept software — Software driver for the Digilent JTAG-USB cable.



#### Note

Make sure that you are using latest version of Adept driver. For minimal version of Adept software, see *DesignWare ARC EM Starter Kit 2.1 Release Notes*.

- MetaWare Development Toolkit DesignWare ARC tools to run and debug applications on the DesignWare ARC processors.
- ARC GNU an open-source development environment to run and debug applications for the DesignWare ARC processors. For more details, see ARC GNU documentation.

### **Platform Requirements**

For a list of platforms supported by ARC EM Starter Kit, see *DesignWare ARC EM Starter Kit 2.1 Release Notes*.

### **Development Process**

The ARC EM Starter Kit allows you to develop software applications using the following software tools:

- MetaWare Lite A free downloadable version of the MetaWare Development Toolkit.
   MetaWare Lite has the following restrictions:
  - Supports only the Windows platform.
  - The code size is restricted to 32K or less.

Development Process ARC EM Starter Kit

For more information about downloading and installing MetaWare Lite, see Download MetaWare Lite.

 MetaWare Development Toolkit — A software development toolchain that supports the development, debugging, and tuning of embedded applications for the DesignWare ARC processors.

The toolchain includes a compiler and debugger. MetaWare Development Toolkit is a licensed product from Synopsys. This MetaWare Development Toolkit must be separately licensed from the ARC EM Starter Kit.

For more information see Building, Running, and Debugging projects using the Meta-Ware IDE.ARC GNU — ARC GNU is an open source development environment for ARC processors. The tools include the GCC compiler and GDB debugger as well a number of utilities and libraries that make up a complete software tool chain. For more information see, Building and running projects using the ARC GNU IDE.

This chapter describes the software required for the ARC EM Starter Kit. It also contains a step-by-step guide on how to connect the ARC EM Starter Kit to a power supply and to a debugger.

Use the following procedure to set up the ARC EM Starter Kit and perform the self-test

- Unpack the Package Contents
- Setting up the ARC EM Starter Kit
- 3. Connecting the USB
- 4. Connecting the Power Supply
- 5. Running Self-Test

### **Package Contents**

The ARC EM Starter Kit package contains the following items:

- FPGA module with Xilinx Spartan-6 FPGA device mounted on base board with extension connectors and peripherals
- 4-channel 12-bit A/D converter extension module
- 100-240V AC power adapter
- USB cable



Software examples and ARC GNU software tools are available from the ARC EM Starter Kit Downloads Web page: http://www.synopsys.com/cgi-bin/dwarcsw/arcemsk/menu.cgi.

Typically a password is provided by email when you register to order the kit. If you do not have a password, submit this form:

http://www.synopsys.com/cgi-bin/dwarcsw/req1.cgi?id=arcemsk.

#### **Next Steps:**

Setting up the ARC EM Starter Kit.


### Set up the ARC EM Starter Kit

The following sections explain the procedures to connect the ARC EM Starter Kit to your host.

#### **Default Board Settings**

This section describes default settings for links and switches on the board.

Figure 1 Board Jumper and Switch Locations



### **Board Jumper Settings**


The ARC EM Starter Kit hardware contains pre-installed FPGA configurations that are ready for use.

### **Select the Default ARC EM Configuration**

The FPGA board includes an SPI flash storage device pre-programmed with four FPGA images containing different configurations of DesignWare® ARC EM cores. ARC\_EM5D is the default processor configuration.

The FPGA image can be selected using the pins 1 and 2 of the SW1 switch on the board:

Figure 2 SW1 Switch



The default configuration parameters of bit 1 and bit 2 are provided in Table 1.

Table 1 Predefined ARC Configurations

Bit 1	Bit 2	Configuration
OFF	OFF	ARC_EM5D

The selected configuration is downloaded from the on-board SPI flash device automatically after the board is powered up or after you press the *FPGA configure* button located above the letter "C" of the ARC logo.

Bits 3 and 4 the SW1 switch must be in the OFF position to perform a self-test.

The configuration loading process might take up to twenty seconds after the board is powered on. The green LED on the FPGA module is on during this period. After the configuration is loaded, the ARC EM processor performs a self-test as described in the Running Self-Test section.



After FPGA configuration, the SW1 switch is available for user applications.

#### **Next Steps:**

Connect the USB Cable.

ARC EM Starter Kit Connect the USB Cable

#### Connect the USB Cable

A single USB cable provides a communication channel between the debugger and the ARC EM Starter Kit board:

- A USB-JTAG interface
- A USB-UART debug console

If you have not installed the MetaWare Development Toolkit, you can alternatively use the USB-UART channel to establish communication between the ARC EM core and another serial console such as PuTTY.

#### **USB Driver Installation**

In order to use JTAG-USB and JTAG-UART interfaces, a driver is required on the host on which you run the MetaWare debugger or another serial debug console such as PuTTY.

The driver is a part of the Digilent Adept System tool and can be downloaded from the Digilent web site at www.digilentinc.com.

Follow the installation instructions provided by Digilent.

#### **USB Connections**

Use the USB cable delivered as part of the ARC EM Starter kit.

- 1. Connect the mini-USB plug to the connector **J7** on the board as shown on Figure 3.
- Connect the other end of the cable to the host running the debugger.



The J8 header needs to be open (jumper removed) to enable communication with the debugger via the USB-JTAG channel. This is the factory default setting. The USB-UART channel for a serial console is always enabled.

### **Connect the Power Supply**

Use the universal switching power adapter (110-240 Volts AC to 5 Volts DC) provided in the package. Connect the appropriate AC plug for your AC power outlet. Connect the DC plug to the connector **J13** "5V DC" on the board as shown on Figure 3. Finally, connect the AC plug to your AC power outlet.



The ARC EM Starter Kit board operates on 5V DC. It does not have any user-accessible means to change power-supply settings.

Run the Self-Test ARC EM Starter Kit




Figure 3 Power Supply and USB Cable Connection to the Board

#### **Next Steps:**

• Running Self-Test.

### **Run the Self-Test**

#### Self-Test and Bootloader

After the FPGA image is loaded from the SPI-flash memory, the ICCM of the ARC processor contains a pre-programmed image of the self-test application that is executed after a CPU reset.

The self-test application behavior depends on bit 3 of the on-board DIP switch SW1.

**Bit 3 – skip self-test app**. When this bit is on, the self-test application does not perform any tests and does not send any messages to the console. However, in any position of Bit 3, the startup code enables LED7 to indicate the CPU start.

To run self-test application the Bit 3 switch should be off.

The Self-test application indicates the core configuration loaded into FPGA as follows:

- LED0 ARC EM5D
- LED1 ARC EM7D
- LED2 ARC EM7DFPU

The Self-test application performs the following actions:

ARC EM Starter Kit Run the Self-Test

1. Runs the startup code, which initializes program counter and stack pointer.

- 2. Checks the ARC EM IDENTITY register.
- 3. Initializes and test peripheral controllers.
- 4. Flashes LEDs.
- 5. Tests SPI flash.
- 6. Prints the following information to the console:
  - Version of self-test application
  - ARC EM configuration number
  - ARC processor ID
  - Type of SPI flash

#### **View Self-Test Output on PuTTY Console**

PuTTY is a simple debug console that you can use when the MetaWare Development Toolkit is not installed.

#### **Prerequisites**

- USB cable is connected to your host and the USB drivers are installed.
- Board is powered up.


#### **Procedure**

- 1. Click Start > Control Panel > Device Manager.
- 2. In the **Device Manager** window, double-click **Ports (COM & LPT)**.
- Select USB Serial Port and take note of the COM port assigned to the USB Serial Port

Example: Figure 4 shows the port COM6 being used.

Run the Self-Test ARC EM Starter Kit

Figure 4 COM6 Port




- 4. Download putty.exe from http://www.putty.org.
- 5. Double-click the downloaded putty.exe file.

The **PuTTY Configuration** window appears.

- Select Serial connection type.
- 7. Enter the COM port name from Step 2 in the **Serial line** field and set the **Speed** field to 115200 as shown in Figure 5.

ARC EM Starter Kit Run the Self-Test

Figure 5 PuTTY Configuration Window




- 8. Click the **Open** button to launch the PuTTY terminal.
- 9. Press the ARC EM Reset button after launching PuTTY.
- 10. The self-test is performed.

Figure 6 on page 21 shows the console output after completion of self-test application. This example uses the ARC\_EM5D configuration (SW1 bits 1 and 2 both off).

Run the Self-Test ARC EM Starter Kit

Figure 6 Self-test Results in a Terminal Window, ARC\_EM5D



#### **Next Steps:**

After you have successfully completed the self-test of the ARC EM Starter Kit, you can start working with the ARC EM Starter Kit.

The following chapters explain some of the tasks you can do with the ARC EM Starter Kit:

- Building, Running, and Debugging Projects Using the MetaWare IDE
- Building and Running Projects Using the ARC GNU IDE
- Selecting ARC EM Configurations
- Connecting External Interfaces to the ARC EM Starter Kit
- Connecting the PMODAD2 Extension Module
- Creating Applications Using the MetaWare Tools

### Working with ARC EM Starter Kit

### **Selecting ARC EM Configurations**

This section describes the usage of the preloaded FPGA images that are stored in the onboard SPI Flash device.

Spartan-6 FPGAs include a capability called MultiBoot that allows the FPGA to selectively reprogram and reload its bitstream from an attached external memory. The MultiBoot feature allows the FPGA application to load different FPGA bitstreams under the control of the FPGA application.

The FPGA board includes an SPI flash storage device that is pre-programmed with FPGA images with different configurations of DesignWare® ARC EM cores: ARC\_EM5D, ARC\_EM7D, and ARC\_EM7DFPU.

Table 2 describes the main parameters of each configuration.

Table 2 Predefined ARC Configurations

Devemeters		Configurati	ons
Parameters	ARC_EM5D	ARC_EM7D	ARC_EM7DFPU
ICCM	128 KB	32 KB	32 KB
DCCM	256 KB	32 KB	32 KB
Instruction Cache	-	16KB	16KB
Data cache	-	16KB	16KB
Timers	2	2	2
Core Registers	32	32	32
Address Width	32	32	32


#### Note:

The EM4 processor is a subset of EM5D, and EM6 is a subset of EM7D. So software may be built for EM4 or EM6 but then run on EM5D or EM7D respectively.

For a detailed description of the predefined configurations, see Appendix A, Detailed Core Configurations.

The FPGA image can be selected with pins 1 and 2 of the SW1 DIP switch on the base-board as shown in Figure 7.

Figure 7 SW1 DIP Switch



The definitions of bits 1 and 2 are described in the Table 3.

Table 3 Selecting the Configuration

Bit 1	Bit 2	Configuration
OFF	OFF	ARC_EM5D (and ARC_EM4)
ON	OFF	ARC_EM7D (and ARC_EM6)
OFF	ON	ARC_EM7DFPU (and ARC_EM6PFU) This is ARC_EM7D with Floating Point Unit
ON	ON	Reserved

The selected configuration is downloaded from the on-board SPI flash device automatically after power on or after you press the FPGA configure button located above the letter 'C' of the ARC logo on the baseboard. The loading process takes up to 20 seconds, and a green LED on the FPGA module is on during this period. After that, the ARC EM processor optionally performs a self-test and/or starts a user application. This action depends on the position of bits 3 and 4 of SW1 as described in the section below.



After the FPGA is programmed, the DIP switches are available for user applications. They must be switched back to the position for the desired predefined FPGA image, before you press the FPGA Configure button and power the board up.

### Connecting External Interfaces to the ARC EM Starter Kit

This section describes the connection of peripheral devices using Pmod connectors on the baseboard.

The baseboard has several unified connectors that can be used to connect peripheral devices. These connectors comply with the Pmod™ Interface Specification by Digilent Inc.

Refer to the *Digilent Pmod Interface Specification* for more details.






### **Connecting the PMODAD2 Extension Module**

A PmodAD2 module is included in the ARC EM Starter Kit. This is a four-channel 12-bit A/D converter with a Pmod I2C interface.

The module has a 2x4-pin Pmod connector. Insert the module on the left side of connector J2, J3, or J4 using pins 3, 4, 5, 6, 9, 10, 11, 12.

As an example, Figure 9 shows how the PmodAD2 can be connected to Pmod2.

Figure 9 PmodAD2 Connection to Pmod2



For information on how to configure and use Pmod connectors, see section Pmod Pin Configuration in page 80.

This section describes the demo packages used for ARC EM Starter Kit.

### **About the Bare-Metal Demo Package**

The bare-metal demo applications contain sample code to illustrate how to build a simple applications and communicate with peripheral devices available on the board. The following applications are included in the bare-metal demo package, which can be downloaded from the ARC EM Starter Kit download page.

• hello

This application prints "Hello world" in the debug console over the JTAG connection. Note: This application is available for the MetaWare Development toolkit only.

• hello uart

This application prints "Hello world" in the UART console.

• leds

This application demonstrates how to configure and use LED indicators connected to the GPIO controller.

• leds spi

This application demonstrates how to build an application running in self-boot mode. It includes the necessary startup and make files .The functionality of this application is the same as in leds demo. See details in readme.txt.

fibonacci

This application is a simple math example. It calculates the Fibonacci sequence and returns 0 if the result of the calculation is correct, or 1 otherwise.

spi rw

This application lets you write and read a binary image to/from the on-board SPI Flash memory.

adc

This application demonstrates reading data from an external ADC module PmodAD2 connected to the extension port Pmod2.

• temp sensor

This application demonstrates reading data from an external temperature sensor module PmodTMP2 connected to the extension port Pmod2 and prints the current temperature on an external LCD display PmodCLS connected to Pmod6 and Pmod7.



#### Note

This application requires additional Pmod extension boards not included in the ARC EM Starter Kit package.

All demo applications use peripheral controllers to indicate status by LEDs, send information to a UART, or read data from a device connected to a PMOD connector. To support peripheral devices, the bare-metal package includes an IO library. The IO library provides a simple low-level IP for peripheral controllers: I2C, SPI, UART and GPIO.

The following IO modules are included:

- GPIO GPIO driver includes simple functions for reading the status of onboard buttons, switches, LEDs, and programming the LEDs.
- I2C polling-mode driver includes functions for initializing the I2C controller, reading, and writing data from I2C slave device. The I2C driver supports only I2C slave mode.
- mux multiplexer driver defines and functions to configure PMOD multiplexer and select routing modes for communication interfaces: SPI, UART.
- SPI low-level functions to work with the SPI interface.
- UART a few simple functions for printing to the UART.
- Flash SPI flash driver. The driver provides functions for reading, writing, and erasing of onboard SPI flash memory.
- LCD PmodCLS LCD display driver supports two-string text LCD display connected using SPI.

### **Supported ARC EM Starter Kit Hardware**

The bare-metal demo applications are configured by default to support the latest version of the ARC EM Starter kit hardware (FPGA image). The version of the FPGA image used in the board is part of the service information printed on the console during the self-test execution as follows:

To support older versions of ARC EM Starter Kit, open file options.mk from the /options folder and set PRODUCT variable to your version of the hardware as shown below:

```
# emsk_1.1
# emsk_2.0
# emsk_2.1
#
PRODUCT = emsk 2.1
```

### **Directory Structure**

Table 4 represents the directory structure of the bare-metal demo package:

Table 4 Directory Structure of the Bare-Metal Demo Package

Directory	Description	
apps/	Example applications in subfolders. It contains sources, configurations, and makefiles.	
/adc	Example application for reading the data from the AD converter PmodAD2: application sources and makefile	
/fibonacci	A simple math application	
/hello	"Hello world" application sources and makefile	
/hello_uart	UART version of "Hello world" application sources and makefile	
/leds	Flashing LEDs application sources and makefile	
/leds_spi	Self-boot version of flashing LEDs application	
/spi_flash	Example application for reading and writing SPI flash: application sources and makefile	
board/	Configuration files and header files for specific boards	
boot/	Bootloader source code and makefile	
common/	Common C, assembly, and header files for all applications	
io/	Source files and makefiles for the peripheral controllers library	
/flash	Source files of SPI FLASH module (required SPI controller module)	
/gpio	Source files of GPIO controller module (access to onboard LED, DIP-switch, and buttons)	
/i2c	Source files of I2C controller module	
/lcd	Source files of character-based LCD controller	
/mux	Source files of PMOD multiplexer	
/spi	Source files of SPI controller module	
/timers	Source files of the timer module	
/uart	Source files of UART controller module	
/wdt	Source files of Watchdog timer module	

Directory	Description
options/	Configuration files for building demo applications
project_arcgnu/	IDE projects for ARC GNU toolchain
project_arcmw/	IDE projects for MetaWare

### Compatibility

The bare-metal applications are provided with a rich build environment for the MetaWare Development Toolkit and the ARC GNU toolchain supporting command-line and IDE projects. Table 5 lists the availability of the demo applications for the different tools.

Table 5 Availability of Bare-Metal demo Applications for Different Tools

Application	Command Line		IDE	
	MetaWare	ARC GNU	MetaWare	ARC GNU
adc	Yes	Yes	Yes	Yes
fibonacci	Yes	Yes	Yes	Yes
hello	Yes	No	Yes	No
hello_uart	Yes	Yes	Yes	Yes
leds	Yes	Yes	Yes	Yes
spi_rw	Yes	No	Yes	No
temp_sensor	Yes	No	Yes	No

Table 6 lists the core configurations that are supported by the software development tools.

Table 6 Core Configuration Supported for MetaWare and ARC GNU

CPU Configuration	Target Name for Bare-Metal Software	MetaWare	ARC GNU
ARC_EM5D	em5d	Yes	Yes
ARC_EM7D	em7d	Yes	Yes
ARC_EM7DFPU	em7dfpu	Yes	Yes
ARC_EM4	em4	Yes	Yes
ARC_EM6	em6	Yes	Yes
ARC_EM6FPU	em6fpu	Yes	Yes

### **About the MQX Demo Package**

#### Overview

The MQX demo package contains the following:

- Binary version of the MQX operating system (source files are not included) prebuilt for use with the EM Starter Kit board.
- Example MQX applications with source code that demonstrate how to build a simple MQX application and work with the peripheral device drivers.

You can download the software package including MQX demo from the ARC EM Starter Kit download page. You receive the corresponding URL after ordering the product.

Unzip the software package on a Windows machine, open the MQX folder, and follow the instructions inside the README.txt file to install and configure MQX.

You can copy the MQX RTOS Evaluation Kit to any directory location on your machine. If you want to use MQX RTOS with the MetaWare IDE, the MetaWare IDE assumes that the MQX RTOS is installed at the default location:

C:\ARC\software\mqx2.61c

If you install the MQX RTOS in a different location, you must change the environment variables in the MetaWare IDE. Click **Window** > **Preferences** > **C/C++** > **Build** > **Environment**, and edit the environment variables. Table 7 lists the MQX environment variables.

Table 7 MQX Environment Variables

Environment Variable	Default Value	
MQX_COMPILER_ROOT	C:\ARC\MetaWare\arc	
MQX_ROOT	C:\ARC\software\mqx2.61c	
MQX_CONFIG	%MQX_ROOT%\build\config.mk	
MQX_PSP_LIB_DIR	<ul> <li>%MQX_ROOT%\build\mqx.a config_dir</li> <li>where mqx.a config_dir&gt; can be one of the following choices:</li> <li>arcv2em_0.met - corresponds to config0</li> <li>arcv2em_1.met - corresponds to config1</li> <li>arcv2em_2.met - corresponds to config2</li> </ul>	

The MQX demo package for ARC EM Starter kit includes the following applications:

dw\_apb\_led
 This application demonstrates how to configure and use LED indicators connected to the GPIO controller.

- dw apb button led
  - This application demonstrates how to control LED indicators using push buttons connected to GPIO pins.
- dw apb switch led

This application demonstrates how to control LED indicators using switches connected to GPIO pins.

dw apb uart

This application demonstrates how to configure the DW APB UART for different parameters, such as baud rate, start bit, and stop bits.

• dw spi sd card

This application demonstrates the following features

- Setting the SD card in the SPI mode
- Checking the supported voltage ranges of an SD card
- Starting and finishing the initialization process
- Determining the capacity of the SD card (SDSD, SDHC)
- Getting the CID and CSD of the SD card
- Performing a sector write of 512 bytes
- Performing a sector read of 512 bytes
- i2c adc

This application demonstrates reading ADC data from the PmodAD2 extension board, included in the ARC EM Starter Kit, using an I2C interface. The internal dw\_apb\_i2c is programmed to operate in I2C master mode. The PmodAD2 device is an I2C slave.

### **Directory Structure**

31

Table 8 describes the folder structure of the MQX demo package.

Table 8 Folder Structure of the MQX Demo Package

Directory	Description
examples/starterkit/	Demo applications subfolders
examples/starterkit/ dw_apb_led	Application sources and makefile for the GPIO demo using LEDs
examples/starterkit/ dw_apb_button_led	Application sources and makefile for the GPIO demo controlling LEDs by push buttons

Directory	Description
examples/starterkit/ dw_apb_switch_led	Application sources and makefile for the GPIO demo controlling LEDs by DIP switches
examples/starterkit/ dw_apb_uart	Application sources and makefile for the UART demo
examples/starterkit/ dw_spi_sd_card	Application sources and makefile for the SD card demo
examples/starterkit/i2c_adc	Application sources and makefile for the I2C ADC demo
build/starterkit	Configuration files for building applications for the different core configurations that are included in the ARC EM Starter Kit
library/	MQX libraries
doc/	MQX documentation including the MQX user guide for DW peripheral device drivers

### **Building and Running Applications**

The ARC EM Starter Kit allows you to develop software applications using the following software tools:

- MetaWare Lite A free downloadable version of the MetaWare Development Toolkit.
   MetaWare Lite has the following restrictions:
  - Supports only the Windows platform.
  - The code size is restricted to 32K or less.
  - Supports the ARC EM family of processors only.

For more information about downloading and installing MetaWare Lite, Building, Running, and Debugging projects using the MetaWare IDE.

- MetaWare Development Toolkit A software development toolchain that supports the
  development, debugging, and tuning of embedded applications for the DesignWare ARC
  processors. The toolchain includes a compiler and debugger. The MetaWare
  Development Toolkit must be separately licensed. For more information, see Building,
  Running, and Debugging projects using the MetaWare IDE.
- ARC GNU ARC GNU is an open source development environment for ARC processors. The tools include the GCC compiler and GDB debugger as well a number of utilities and libraries that make up a complete software tool chain. For more information, see Building and running projects using the ARC GNU IDE.
- All software tools support both GUI and command line build approaches. The command line approach similar for MetaWare and ARC GNU. For more information on how build applications and run applications in this mode, see <u>Building and Running Applications</u> <u>Using gmake</u>.

## **Building, Running, and Debugging Projects Using the MetaWare IDE**

You can use the MetaWare Development Toolkit or MetaWare Lite.

#### **Download and Install MetaWare**

The MetaWare toolkit is required for embedded software development on ARC processors. This software toolkit is not included in the ARC EM Starter Kit download. Follow the instructions listed below to download and install MetaWare Development Toolkit.

#### **Downloading MetaWare**

- 1. Go to https://www.synopsys.com/dw/dwdl.php?id=arc\_MWDT\_ARC
- 2. Select and download the appropriate platform specific download image:
  - mw devkit arc <revision> win install.exe for Windows

#### Installation on Windows

1. Double click the mw\_devkit\_arc\_<revision>\_win\_install.exe file from a Windows Explorer window to run the installer, and follow the on-screen instructions.

#### Licenses

The DesignWare® MetaWare® Development Toolkit for ARC requires a license from Synopsys.

Follow instructions provided with DesignWare® MetaWare® Development Toolkit to set up a license.

#### **Download MetaWare Lite**

1. You must register at the following website to download MetaWare Lite:

http://www.synopsys.com/cgi-bin/arcmwtk\_lite/reg1.cgi

- 2. Complete the registration form to receive the download link.
- Click Continue.

A download link with the activation key is sent to the registered email address.

4. Click the download link in the welcome mail to download the software.

#### **Install MetaWare Lite**



#### Note

Ensure you have the following information before proceeding with the installation:

- Email address registered with Synopsys Inc. to download MetaWare Lite.
- Activation key you can find this information in the confirmation email from Synopsys Inc.
- 1. Double-click the DW ARC MetaWare Lite J 2014 12 win.exe file.
- Follow the on-screen instructions to complete the installation process.

#### Hardware Connections between MetaWare and ARC EM Starter Kit

Connect the board to the computer using the Digilent USB cable.


### **Run Applications using the MetaWare IDE**

This section describes how to set up a project in the Eclipse-based MetaWare IDE.

#### Setting up a Workspace


1. Start the MetaWare IDE by double-clicking mide.exe in the directory /MetaWare/ide of the directory in which the MetaWare toolkit is installed. (Other startup options are possible depending on the options selected during installation of the MetaWare toolkit.)

Figure 10 MIDE Directory




2. In the pop-up screen, select baremetal/project\_arcmw as the current workspace and click **OK**.


Figure 11 Selecting a Workspace



The files belonging to the demo projects have to be installed in the Eclipse IDE workspace.

Figure 12 on page 36 illustrates this process step-by-step.






3. Close the **Welcome** view to get access to the workspace.


4. Click **File > Import** from the top menu of the MetaWare IDE. Then select **Existing Projects into Workspace** and click the **Next** button.

Figure 13 MetaWare IDE — Select an Import Source




6. Select your baremetal/project\_arcmw folder as the root directory and select all projects available there for import. Then click the **Finish** button to import the demo projects into your workspace.

Figure 14 MetaWare IDE — Select Projects for Import



7. The MetaWare IDE loads and displays the demo projects in your workspace as shown in Figure 15.


Figure 15 MetaWare IDE - Demo Projects in the Workspace



### **Building a Project Using the MetaWare IDE**

- Build the I/O library before the demo applications. To build the I/O library, right click on an I/O project and select **Build Project** from the context menu.
- 2. Right-click one of the application projects.
- Select Build Configurations > Set Active and select your build target, for example em5d.

Figure 16 MetaWare IDE - Set Active Build Configurations



This step selects the em5d configuration of the project for building. You can choose another option to match your debug target.

- 4. Rebuild the project using either of the following methods:
- Right-click the project and select Build Project from the context menu.
- Press CTRL-B.

You can see the build results in the **Console** window. An example is shown in Figure 17.

Figure 17 MetaWare IDE - Build Results in Console Window

```
Problems @ Tasks © Console X Properties

CDT Build Console [leds]

19:46:20 **** Build of configuration em5d for project leds ****
gmake all :

Building file: (:', proj/emsk2_1/baremetal/apps/leds/src/flashing_leds.c'

'Invoking: NetWainer aRe Em (/-t+ Common/inc - I../.../.)obard/emsk2_1/jinc - Hnocopyr - arcv2em - core1 - Xbs - Xsa - Xmpy_option=mpyd - Xdiv_rem=radix2 - Xswap - Xcd - Xtimer0 - Xtimer0
```

#### **Debugging a Project Using the MetaWare IDE**

After the C Project is successfully compiled, you can debug the resulting executable on the ARC EM Starter Kit board. This section provides short instructions how to configure and run a debug session in the MetaWare IDE.

To debug the project, create a new debug configuration:


 Select **Debug Configurations** from the **Run** menu or click the down arrow next to the bug icon:

Figure 18 MetaWare IDE - Selecting the Debug Configuration from the Run Menu



2. Double click **C/C++ Application** or click the top left icon to create a new debug configuration for the project.

Figure 19 MetaWare IDE - Creating the new Debug Configuration



3. Optionally select a name for the new debug configuration (by default, it equals the project name followed by the selected build target).




Figure 20 MetaWare IDE - Selecting a Name for the New Debug Configuration

- 4. Click the **Debugger** tab, **Target Selection** and configure the target to use **Hardware**.
- 5. Select **Digilent JTAG cable** as the hardware connection type.





Figure 21 MetaWare IDE - Selecting the Debugger Target

6. Click the **Debug** button in the **Debug configurations** dialog to initiate a debug session and switch the IDE to the **Debug** perspective:

Figure 22 MetaWare IDE - Debug Window



7. Click the run button in the toolbar at the top of MetaWare IDE window to run the application.

- 8. When done, click the **Terminate** button on the toolbar to close the debug session.
- 9. Click the **C/C++** button to display the **Project Explorer**.

# **Building and Running Applications Using make**

Bare-metal demo applications use the GNU gmake utility to build. The build environment provided with the bare-metal applications supports the MetaWare Development Toolkit and the ARC GNU toolchain.

#### **Build Environment**

Each demo project has an individual makefile, but uses common configuration options that are located in the options folder:

- options.mk
  - Common options file with default settings for all applications. It sets the default core configuration, default board settings, and the toolchain version and includes other configuration files depending on the parameter settings.
- rules.mk
  - This file defines rules for building source and object files and common targets for the build.
- Tool specific settings are located in /options/tools subfolder
- toolchain gnu.mk, toolchain mw.mk
  - These files define toolchain-specific parameters (compiler, linker, and so on).
- Board and core specific configuration files are located in the /board/emsk\_2.1/cfg folder
- core xx.mk
  - defines configuration-specific command line parameters (such core options, CPU CLOCK, and so on).
- board.mk
  - defines board specific settings like supported cores, JTAG settings, common defines, and so on...
- emxx.tcf
  - provides configuration options for ARC tools
- link emxx.ln
  - is a memory map file for ARC GNU linker
- map\_emxx.metis a memory map file for MetaWare linker

To build a demo application, perform the following actions, illustrated here for the leds demo application:

1. Open options/options.mk and set up the core configuration and toolchain by setting the CURRENT\_CORE and TOOLCHAIN variables. Set CURRENT\_CORE = em5d and TOOLCHAIN = mw.

- 2. Open a command window.
- 3. Navigate to the leds application folder:

cd C:/EMSK/baremetal/apps/leds/

4. Type the following command:

```
gmake all
```

The command above builds the demo application.

By default, the makefiles of the bare-metal demo applications support the following targets:

- clean
  - Clean all object and temporary files in the application folder and in the I/O folders of the I/O components linked to the project.
- all
  - Compile and link the application. Object and ELF files are placed in the project folder.
- build
  - Clean and build application using the targets described above.

For a detailed description of configuration options and information on using particular applications, refer to the readme.txt file in the corresponding application folder.

#### **Running an Application Using MetaWare**

All demo applications are compatible with the MetaWare development tools. The demo applications can be configured for all processor configurations available in the ARC EM Starter Kit board.

The MetaWare build environment provides additional makefile targets for running applications using the MetaWare debugger or in batch mode:

- run
  - Load and execute the application using the MetaWare debugger in command-line mode.
- gui

Load the application on the ARC EM core and execute the MetaWare debugger in GUI mode. You can set breakpoints, run the program step by step, watch variables, and perform other actions.

#### **Running an Application Using ARC GNU Tools**

The following list of demo applications can be built using the ARC GNU toolchain:

- adc
- hello\_uart
- fibonacci
- leds

The other demo applications use the MetaWare hostlink interface, which is not supported by the ARC GNU toolchain. Before running application on ARC EM Starter kit board open a windows console and type the following command for running OpenOCD:

```
openocd -f ../share/openocd/scripts/target/snps_starter_kit_arc-em.cfg
-c init -c halt -c "reset halt"
```



ARC GNU IDE 2014.08 includes a version of the OpenOCD configuration file incompatible with EMSK 2.x. Use the  $snps\_em\_sk-2.0.cfg$ " file from the baremetal/project arcgnu folder instead.

Then open one more Windows console, load and run your application by using GDB in command-line mode:

```
arc-elf32-gdb --quiet leds.elf
(gdb) target remote 127.0.0.1 :3333
(gdb) set remotetimeout 15
(gdb) load
(gdb) break main
(gdb) continue
(gdb) step
(gdb) next
(gdb) break exit
(gdb) continue
```

```
Note
```

You might see the following message after the (gdb) target remote 127.0.0.1 :3333 command:

```
Remote debugging using 127.0.0.1 :3333

exit (code=0) at /bld/arc/unisrc-
4.8win/newlib/libc/stdlib/exit.c:61
61 /bld/arc/unisrc-4.8win/newlib/libc/stdlib/exit.c: No such file or directory.

It is not an error. It might occur because ARC GNU sources are not supplied by this tool.
```

Detailed information on how to load and debug applications for ARC processors using the ARC GNU debugger is provided in the ARC GDB Getting Started document.

### **Building MQX Applications Using gmake**

In order to build an MQX demo application perform the following actions:

- 1. Open a command window.
- 2. Navigate to the application folder, <code>dw\_apb\_led</code> demo is used below as an example:

```
C:\ARC\software\mqx2.61c\examples\starterkit\dw apb led\
```

- 3. Type one of the following commands, depending on the core configuration you are using:
  - ARC EM5D

```
gmake MQX_CONFIG= C:\ARC\software\mqx2.61c
\build\starterkit\config0.mk
```

ARC EM7D

```
gmake MQX_CONFIG= C:\ARC\software\mqx2.61c
\build\starterkit\config1.mk
```

ARC EM7DFPU

```
gmake MQX_CONFIG= C:\ARC\software\mqx2.61c
\build\starterkit\config2.mk
```

These commands build the demo application for a respective target processor.

Use the following command to run a demo application:

```
mdb -OS=MQX-run -digilent <application
dir>/arcv2em_<core_config_#>.met/<elf-filename>.elf
```

For example, to run the  $dw_apb_led$  demo on an ARC\_EM5D configuration, use the following command:

```
mdb -OS=MQX-run -digilent
C:\ARC\software\mqx2.61c\examples\starterkit\dw_apb_led\arcv2em_0.me
t\dw apb led.elf
```

For a detailed description of configuration options and information on using particular applications, refer to the readme.txt file in the corresponding application folder and consult the driver documentation in the doc/folder.

## **Building and Running Projects Using the ARC GNU IDE**

### **Obtaining the ARC GNU Toolchain**

Prebuilt versions of the ARC GNU tools are available from the GitHub website:

https://github.com/foss-for-synopsys-dwc-arc-processors/arc\_gnu\_eclipse/releases

The ARC GNU Toolchain is also made available as source code, allowing it to be built and installed on any supported platform. The main git repository for the ARC GNU tool chain is

https://github.com/foss-for-synopsys-dwc-arc-processors/toolchain

### **Using the IDE Workspace**

The files belonging to the demo projects have to be installed in the Eclipse IDE workspace. The instructions below illustrate this process step-by-step:

 Run the ARC GNU IDE and select baremetal/project\_arcgnu as the current workspace.





Figure 23 ARC GNU IDE - Select Workspace Directory

2. Close the **Welcome** view to see your workspace.

3. Select File > import in the top menu, then select General > Existing Projects into Workspace and click the Next button.

Figure 24 ARC GNU IDE - Import Existing Projects into Workspace (First Step)



4. Select your baremetal/project\_gnu folder as the root directory and select all projects available there for import. Then click the **Finish** button to import the demo projects into your workspace. See Figure 25 for more details.






Figure 25 ARC GNU IDE - Import Existing Projects into Workspace (Second step)

The IDE loads and displays the demo projects in your workspace as shown in Figure 26.






### **Building a Project Using the ARC GNU IDE**

- The I/O library must be built before any demo applications can be built. To build the I/O library, right-click on the I/O project and select **Build Project** in the context menu.
- 2. Right-click one of the application projects and select **Build Configurations > Set Active** and select your build target, for example **em5d** as shown in Figure 27.

Figure 27 ARC GNU IDE - Set Active Build Configurations



This step selects an ARC\_EM5D configuration of the project for building. You can choose another option to match your debug target. A full list of available targets and corresponding core configurations are described in Compatibility section of this document.

- 3. Rebuild the project using any of the following methods:
  - o Right-click the project again and select Build Project.
  - o Press CTRL-B.

You can see the build results in the console window.

Figure 28 ARC GNU IDE - Build Results in Console Window

```
🦹 Problems 🔎 Tasks 📮 Console 🛭 🗏 Properties 🛮 Terminal 1
CDT Build Console [leds]
21:47:40 **** Build of configuration em5d for project leds ****
'Building file: C:/_proj/emsk/emsk_2.0/src/emsk2.0/baremetal/apps/leds/src/flashing leds.c'
'Invoking: ARC Windows ELF32 GCC C Compiler'
arc-elf32-gcc -I../../../board/emsk_2.0/inc -I../../.common/inc -I../../io -00 -Wall -Wa,-adhlns="SRC/fl
'Finished building: C:/_proj/emsk/emsk_2.0/src/emsk2.0/baremetal/apps/leds/src/flashing_leds.c'
'Building target: leds.elf'
'Invoking: ARC Windows ELF32 GCC C Linker'
arc-elf32-gcc -T"../../board/emsk_2.0/cfg/link_em5d.ln" -nostartfiles -Wl,-Map,leds.map -mcpu=arcem -mlitt
'Finished building target: leds.elf'
'Invoking: ARC Windows ELF32 GNU Print Size'
arc-elf32-size --format=berkeley leds.elf
                 bss
                                   hex filename
          data
                           dec
          4 18436
                                  4f90 leds.elf
  1928
                         20368
'Finished building: leds.siz'
21:47:41 Build Finished (took 1s.201ms)
```

### Debugging a Project Using the ARC GNU IDE


After the project is successfully compiled by ARC GCC, you can debug the resulting executable on the ARC EM Starter Kit board.

This section provides short instructions on how to configure and run a debug session in the ARC GNU toolchain IDE. The full documentation of the debugger features is available in the ARC\_GNU\_IDE\_GettingStarted.pdf provided with the ARC GNU Toolchain.

To debug the project, create a new debug configuration using arc-elf32-gdb.


- Select **Debug Configurations** from the **Run** menu.
- 2. Double click ARC C/C++ or click the top left icon to create a new debug configuration for the project:
- Select a name for the new debug configuration (by default, it equals the project name followed by the selected build target).

Figure 29 ARC GNU IDE - Creating a Debug Configuration



4. Click the **Search Project** and select the required program.





Note that if you are building an application only for one configuration, the ARC GNU IDE automatically selects it.

?

5. Navigate to the **Debugger** tab and select "ARC remote gdb/mi" from the **Debugger** drop down menu.

In the **Debugger Options** select *Gdbserver Settings* sub-tab. The ARC GDB Server **JTAG via OpenOCD** and the COM port can be selected from here.

In JTAG via OpenOCD section map OpenOCD PATH to the board configuration file baremetal/project\_arcgnu/snps\_em\_sk-2.0.cfg





Figure 31 ARC GNU IDE - Commands Initialization from the Debugger

Note that there might be a problem with OpenOCD not binding to the localhost. If it happens, the **Host Address** at **Gdbserver Setting**s sub-tab should be changed to real IP. Otherwise, the debug session would not start.

6. Click the **Debug** button in the **Debug configurations** dialog to initiate the debug session. This action automatically launches the PuTTY and OpenOCD applications in the background and connects to the UART on the ARC EM Starter Kit board. OpenOCD startup log messages appear on the console.

Figure 32 ARC GNU IDE - Debug Window



**Note** 

If a serial terminal is already open before debugging, close it to avoid contention between the GNU tool and the standalone serial console


7. Step through each line by using F5 (step into), or F6 (step over).

Figure 33 ARC GNU IDE - Stepping Toolbar




Toggle a breakpoint at the last line of main(), which is "}", and then click **Resume** or press F8.

Figure 34 ARC GNU IDE - Stepping Toolbar



Terminate all external tools like a PuTTY before you quit current debugging process.

Figure 35 ARC GNU IDE - Stepping Toolbar



# **Creating Applications Using the MetaWare Tools**

This chapter describes how to create and run a simple application using the MetaWare tools in IDE and command-line modes.

### **Creating an Application Using the Command Line Tools**

The following procedure describes the process of building a simple "Hello world" application for the ARC EM Starter Kit. This application can be used as a starting point for creating your own applications to run on the Starter Kit.

#### Prerequisites:

- Ensure that you have downloaded and installed the MetaWare Development Toolkit.
   See Download and Install MetaWare.
- Ensure that you have connected the ARC EM Starter Kit to the host. See Quick Connection Guide.

Perform the following steps in order to create an application:

1. Create a simple C program that prints "Hello world" string to the default stdout device. For example:

```
#include "stdio.h"

int main(void) {
  printf("Hello world");
  return 0;
}
```

2. Save the code above as myhello.c

3. Build your application running the MetaWare compiler in command line mode:

```
ccac myhello.c -av2em -core1 -Os -Hpfnoflt -Hldopt=
-Bbase=0x100 -o myhello.elf
```

This command compiles and links <code>myhello.elf</code> for ARC EM core version 1. The <code>myhello.elf</code> file is created in the same folder as the source file. Ensure that the base address points to the right memory region for ARC\_EM5 and ARC\_EM7D configurations. You also can use a linker script to manage memory allocation for your application; example memory linker scripts are available in

/baremetal/board/emsk 2.1/cfg folder:

```
map_em5d.met - for ARC_EM5D configuration
map_em7d.met - for ARC_EM7D and ARC_EM7DFPUconfiguration
map_em7dfpu.met - for ARC_EM7DFPUconfiguration
```

There are also available met-files for the em4, em6 and em6fpu configurations.

The command line below illustrates how to build the application using a linker script for ARC\_EM5D configuration:

```
ccac myhello.c -av2em -core1 -Os -Hpfnoflt -Hldopt=
-Bbase=0x100 -o myhello.elf map_em5d.met
```


## **Debugging Applications Using the MetaWare Debugger**

1. Use the following command to launch your application in the MetaWare GUI debugger in an interactive mode:

```
mdb -digilent myhello.elf
```

2. In the Debug a process or processes dialog, click **Debugger Options** and set the debugger options as shown in Figure 36.

Figure 36 MetaWare Settings Required to Use ARC JTAG through USB



3. Click OK.

"Hello world" output appears on the command line.

## **Creating Application Using the MetaWare IDE**

### Create a New Project in the MetaWare IDE

- 1. Launch the MetaWare IDE.
- Select Create a New Project.
- From the Select a wizard dialog box that results, select C/C++-> C Project and click Next.
- 4. Add a **Project Name** (for example: Lab1).
- 5. To create an **Empty Project** with an **ARC EM Generic** executable, select the appropriate options as shown in Figure 37, and then click **Next**.




Figure 37 MetaWare IDE - Creating a New Project

6. Click **Next** again to create both Debug and Release configurations.




Figure 38 MetaWare IDE - Select Project Configurations


- 7. Click the **Next** button to proceed selecting a Tool Configuration File (TCF); this step presets the IDE with the right compile options and memory mapping.
  - a. In the board/emsk\_2.1/cfg folder, select Browse to a TCF file and select the TCF file corresponds to your ARC EM configuration. (The EM4 processor is a subset of EM5D, and EM6 is a subset of EM7D. So software may be built for EM4 but then run on EM5D or built for EM6 but then run on EM7D)

M C++ Project **ARChitect-generated Tool Configuration File** Associates a Tool Configuration file to this project from which defaults are derived No associated TCF file Choose predefined TCF file em4\_ecc.tcf em4\_parity.tcf em4\_rtos.tcf em4\_sensor.tcf em6\_gp.tcf Browse to a TCF file  $C:\EMSK\baremetal\options\arcv2em4.tcf$ Browse... ? < Back Next > <u>F</u>inish Cancel

Figure 39 MetaWare IDE - Select TCF File

- 8. Click **Finish** to create the project.
- Select File > New > Source File and, create a new source file for your project. For example myhello.c

Figure 40 MetaWare IDE - Create New Source File



Create a simple C program that prints "Hello world" to the default stdout device. For example:

```
#include "stdio.h"

int main(void) {
  printf("Hello world");
  return 0;
}
```

- 10. Save your file.
- 11. To create the executable, select **Build Project** under the **Project** main menu, or mouse over the **myhello** project, right-click, and select **Build Project**.
- 12. Review the messages in the **Problems** and **Console** panes at the bottom of the window to verify a successful build.

Figure 41 MetaWare IDE - Console Output for Test Project

```
Problems  Tasks Console  Properties

CDT Build Console [myhello]

12:05:09 **** Build of configuration Debug for project myhello ****
gmake all

'Building file: ../myhello.c'

'Invoking: MetaWare ARC EM C/C++ Compiler'

ccac - c - g - Honcopyr - arcv2em - corel - Xbs - Xsa - Xmpy - Xdiv_rem=radix2 - Xswap - Xcd - Xtimer0 - Xtimer1 - Humake - Hdepend="depend" - o "myhello.c"

'Finished building: ../myhello.c'

'Invoking: MetaWare Linker for ARCompact'

ccac - Holopt-q - e_start - Xbs - Xsa - Xmpy - Xdiv_rem=radix2 - Xswap - Xcd - arcv2em - o "myhello.elf"

'Invoking: MetaWare Linker for ARCompact'

ccac - Hdopt-q - e_start - Xbs - Xsa - Xmpy - Xdiv_rem=radix2 - Xswap - Xcd - arcv2em - o "myhello.elf"

'Finished building target: myhello.elf'

'...

12:05:13 Build Finished (took 4s.109ms)
```

65


### Invoking the Debugger and Running the Executable

Make sure that the ARC EM Starter kit board is connected to your computer by USB cable.

- Select Run > Debug Configurations or right-click myhello and select Debug As > Debug Configurations.
- Double click the C/C++ Application, or click New icon (☐) with C/C++ Application selected

The IDE displays a window similar to Figure 42. The **Main** tab is selected by default.


Figure 42 MetaWare IDE - Creating New Debug Configuration



- Click the **Debugger** tab and set up the debugger to run the application on an ARC EM Starter Kit board.
- 4. Click the **Target Selection** menu in the **Debugger Options** field.
  - a. On the right side of **Debugger Options** field, in the **Select the target** field, select **Hardware**.


b. In the Hardware connection field, choose the Digilent JTAG cable from the Choose hardware connection type drop-down menu. Keep the defaults for all other settings.

Figure 43 MetaWare IDE - Configure Debugger



Click **Debug** and confirm the perspective switch by selecting **yes** in the pop-up window. The **Debug** perspective opens as shown in Figure 44.

Figure 44 MetaWare IDE - Debug Perspective




Click the Resume/Run button:



7. The application prints "Hello world" in the **Console** window.

Figure 45 MetaWare IDE - Console window



## **Running Applications in Self-Boot Mode**

This chapter describes how to build a self-booting application, write it into SPI memory, and run it after the board power up or reset.

### **Self-Boot Application Concept**

ARC EM Starter kit provides an ability to store a customer application in SPI flash memory and run it after power up. That application is called a *self-boot application* in this chapter.

The following are the basic stages in preparing and using self-boot applications:

- 1. Build the self-boot application
- 2. Write the self-boot application to SPI memory
- 3. Run the self-boot application

Running the application is a process executed by ARC EM Starterkit board. Preparing application for running in self-boot mode requires connecting the ARC EM Starter Kit to a host with Windows OS and installed MetaWare or MetaWare Lite tools.

## **Building a Self-Boot Application**

The following requirements exist for an application built for running in self-boot mode:

- The application can be built for a target CPU configuration. There are some differences between four configurations of cores supported by ARC EM Starter Kit, and an application built for ARC EM5D might not work properly on an ARC EM7D. Make sure that you build your application using the correct core configuration.
- The application must be linked to use a valid memory segment and cannot use the memory space from 0x0000\_0000 to 0x0000\_4000, which is reserved for the bootloader. A valid memory segment means that the memory used by your application must be available for a target core configuration. An application mapped in non-existent memory region does not work.

The led\_spi application from baremetal/apps is an example of a self-boot application.

### Write the Self-Boot Application Image to SPI Flash

The SPI interface on the ARC EM Starter Kit board does not connect directly to JTAG and not available through any PMOD. An application image can be written to the flash memory by using the spi rw application from the demo package.

The spi\_rw is an application for the ARC EM cores. It communicates with the file system of a host computer using the JTAG interface to read/write file from the host computer and store/load data on the on-board SPI flash memory chip.

The spi rw application supports write and read commands:

### Writing

The w command writes a binary image to the on-board SPI flash memory.

The spi\_rw application expects a few parameters to write and configure self-boot application, such as:

```
gmake run CMD LINE="-w <file> <ram address> <start address>"
```

- -w switches spi rw to write mode.
- <file> is path to self-boot application image, for example:
   C:\EMSK\baremetal\apps\leds spi\leds spi.img.
- <ram address> defines the RAM start address for loading an application image.
- <start\_address> defines the address from which the bootloader starts the execution of the loaded image.

The spi\_rw is an ARC processor application; run it on the ARC processor. To run the application in command line mode do the following steps:

- 1. Open a command-line console on your host.
- 2. Navigate to the spi\_rw application folder.
- 3. Type the following command in the command-line console:

```
gmake run CMD LINE="<cmd line parameters>"
```

With < cmd line parameters > as described above.

The following instructions illustrate how to write the <code>leds\_spi.img</code> application to be loaded in ICCM memory with the start address 0x4000.

- 1. Open a command -line console on your host.
- 2. Navigate to baremetal/apps/leds\_spi.
- 3. Build leds\_spi.img using the command gmake build.
- 4. Navigate to baremetal/apps/spi rw.

5. Build spi rw by running the following command:

```
gmake
```

6. Write leds spi to SPI flash by running the following command:

```
gmake run CMD_LINE="-w ../leds_spi/leds_spi.img 0x4000
0x4000"
```

#### This command does the following:

- 1. It runs mdb debugger in command-line mode and loads the spi\_rw application in the ARC EM Starter Kit.
- Starts debugger execution of spi\_rw on the ARC processor with the specified command line parameters. The spi\_rw application reads the self-boot image form the host though the JTAG port and writes it into SPI memory.
- 3. After the self-boot image is written into the SPI memory, the spi\_rw application creates a header with the parameters needed for running the self-boot image and writes this header into SPI memory.
- 4. After completion all SPI programming operations the spi\_rw application prints status information in the console as shown in Figure 46.

Figure 46 Output of spi\_rw

### Reading

The spi\_rw application also provides an ability to read binary image from SPI flash in a file on a host computer by using the follow command:

```
gmake run CMD LINE="-r <file>"
```

- -r switches spi rw to read mode.
- <file> is name of the file to read binary data from SPI.

To use the read command to do the following steps:

- Open command-prompt console.
- 2. Navigate to baremetal/apps/spi rw
- Build spi\_rw by running the following command gmake
- 4. Write leds spi to SPI flash by running the following command:

```
gmake run CMD LINE="-r read.img"
```

5. The spi\_rw application creates the read.img file in the current folder. This file contains the self-boot image read from SPI flash.

```
Note The spi_rw applications are only compatible with the MetaWare toolkit.
```

# **Running the Self-Boot Application**

After the board is powered up, the ICCM memory has a predefined application that includes self-tests and bootloader parts. After completion of self-tests, this application checks state of on-board DIP switch SW1. If bit 4 of SW1 is ON, the bootloader is starting. The bootloader checks SPI flash memory for a data structure with the self-boot image parameters. This structure includes the following information:

The bootloader looks for a head signature in SPI flash memory at address 0xD80000. After the signature is found, the bootloader reads the image parameters from the header and starts loading procedure:

- 1. The bootloader starts copying the application image from address start in SPI-flash to address ramaddr in the processor memory. The number of bytes for copying is declared in the size parameter of self-boot header. The ramaddr can point to a DDR, ICC or DCCM memory space, except the space 0x00000000 0x00004000, which is reserved for the bootloader.
- After copying the data, the bootloader compares the checksum of the application image with the checksum from self-boot header, and if they are equal the bootloader start executing the application from the address specified by the ramaddr parameter of self-boot header.

Position Bit3 of on-board DIP switch SW1 affects the console output of the bootloader. Setting Bit 3 to the 'On' position suppresses console output. When Bit 3 is on the 'Off' position the bootloader prints the parameters of the self-boot image and indicates the status of the loading process.



The bootloader does not check the compatibility of application stored in SPI flash memory with selected core configuration. Make sure that you run your application on the right core configuration.

# **SPI Flash Memory Structure**


The flash memory is divided in two sections: *FPGA image* and *Application*. The *Application* section contains the main code for the application and header, and the FPGA section contains the default core configurations for FPGA.

The header contains the following information:

- Application image size
- RAM destination address
- Checksum
- Start address from which the CPU starts code execution after loading

### A typical memory structure is shown in Figure 47.

Figure 47 Typical Flash Memory Structure



# Appendix: A Hardware Functional Description

This appendix provides information about the hardware used in the ARC EM Starter Kit.

## **Board Overview**

The ARC EM Starter Kit consists of two boards:

- FPGA module with a Xilinx Spartan-6 XC6SLX150-3FGG484C FPGA device.
- Base board with extension connectors and peripherals.

The kit has the following on-board peripheral devices:

- 2×16-bit wide 1 Gbit (128 MB) DDR3 SDRAM
- 128 Mbit (16 MB) SPI Flash memory (Winbond W25Q128BV [19])
- SD card reader
- LFDs
- Push-buttons
- DIP switches
- Seven Pmod connectors
- On-board clock oscillator

The SPI flash contains three pre-programmed FPGA images. One image is loaded after board power up, depending on DIP switch position. Refer to Selecting ARC EM Configurations section for more information.

Every FPGA image includes an ARC EM core and a set of DesignWare peripheral controllers connected to the on-board devices and external interfaces via pin-sharing logic. This allows sharing of 52 I/O pins between GPIO, SPI, I2C and UART devices. The customer application can configure the external connectors as needed (refer to *External Hardware Interfaces* section for more information).

The ARC\_EM5D core runs at 35 MHz clock, ARC\_EM7D runs at 30 MHz clock and ARC\_EM7DFPU runs at 20 MHz clock.

ARC EM Starter Kit Board Overview

Depending on the selected configuration, the ARC core supports the following features:

- Different internal memory (SRAM) or external DDR3 memory with different cache parameters
- Floating Point Unit

The basic peripheral set includes the following items:

• GPTO

Four ports connected to LEDs, buttons, on-board switch, and external connectors

• DW UART

Three separate ports.

UART0 is connected to the external interfaces using pin-sharing logic. It can optionally be accessed at the Pmod1 connector.

UART1 is internally connected to an on-board UART-to-USB converter and used as default console for demo applications.

UART2 is connected to the external interfaces using the pin-sharing logic. It can optionally be accessed at the Pmod5 connector.

• DW SPI master

SPI master controller. It is connected to on-board devices (SPI flash and SD card) and to external interfaces via pin-sharing logic and can optionally be accessed at the connectors Pmod5 or Pmod6. It can also address the SPI slave interface for loop-back testing.

DW SPI slave

SPI slave controller. It is connected to the external interface using pin-sharing logic and can optionally be accessed at the Pmod1 connector.

• DW I2C

Two separate ports.

I2C\_0 controller is connected to the external interfaces using pin-sharing logic and can optionally be accessed at the connectors Pmod2 or Pmod3.

I2C\_1 controller is connected to the external interfaces using the pin-sharing logic and can optionally be accessed at the connector Pmod4.

The PmodAD2 extension board, provided with the ARC EM Starter kit, connects to the main board using the I2C interface.

• DW Timers

Two separate timers.

• DW WDT


WDT Controller.

ARC EM Starter Kit FPGA Design Overview

# **FPGA Design Overview**

Figure 48 shows the hardware architecture of the FPGA design implemented in the ARC EM Starter kit.

Figure 48 FGPA Design Block Diagram



External Hardware Interfaces ARC EM Starter Kit

### **External Hardware Interfaces**

This section describes the external hardware interface devices that can be used with ARC EM Starter Kit.

External hardware interface devices can be connected to the ARC EM Starter Kit using Pmod connectors. Table 9 provides an overview of possible peripheral combinations for each Pmod connector.

Table 9 Peripheral Devices Connection to Pmods

Pmod	Pmod	Peripherals						
Pillod	connector	MUX option 0	MUX option 1					
Pmod1	J1	GPIOs	External SPI master + UART0					
Pmod2	J2	GPIOs	ARC EM control/status signals + I2C_0					
Pmod3	Ј3	GPIOs	GPIO + I2C_0					
Pmod4	J4	GPIOs	GPIO + I2C_1					
Pmod5	J5	GPIOs	External SPI slave 1 + UART2					
Pmod6	Ј6	GPIOs	External SPI slave 0 and CS outputs for all other SPI slaves + ARC EM control/status signals					
Pmod7	J20	GPIOs	ARC EM control/status signals					

The functionality of the Pmod connectors is programmable. Each connector can operate either as a GPIO or as a dedicated peripheral device. Several connectors provide access to ARC EM status and control pins.

The GPIO ports are configured as inputs or outputs using the GPIO driver.

A PmodAD2 module is included in the ARC EM Starter kit. This is a 4-channel 12-bit A/D converter with a Pmod I2C interface. It can be connected to any of the connectors J2, J3 or J4. Refer to Connecting the PMODAD2 Extension Module section for more details.

The sections below provide information about register programming, possible connections, and other details.

# **Connecting Peripheral Controllers**


Table 10 Board Connections Overview of Peripheral Controllers

Peripherals	Board connection
GPIO Port A[2:0]	Buttons: (Above letter 'A' in ARC logo, L, R)
GPIO Port A[31:8]	Pmods (J1, J2, J3, J4, J5, J6) pins [10:7]
GPIO Port B[8:0]	LEDs [8:0] Port B[0] controls LED0 Port B[1] controls LED1 Port B[8] controls LED8 The LED is on if its corresponding control bit is programmed to 0.
GPIO Port C[3:0]	DIP Switch SW1 SW1 switch 1 connected to Port C[0] SW1 switch 2 connected to Port C[1] SW1 switch 3 connected to Port C[2] SW1 switch 4 connected to Port C[3]
GPIO Port C[31:8]	Pmods (J1, J2, J3, J4, J5, J6) pins [4:1]
GPIO Port D[11:0]	Pmods (J3, J4, J20)
I2C_0	Pmods (J2, J3)
I2C_1	Pmod J4
SPI Master CS0	Pmod J6 pins [4:1]
SPI Master CS1	Pmod J5 pins [4:1]
SPI Master CS3	SD Card
SPI Master CS4	Internal loopback to SPI Slave when register SPI_MAP_CTRL[0]=1 (for test purposes).
SPI Slave	Pmod J1 [10:7] pins when SPI_MAP_CTRL[0]=0 Internal loopback to SPI Master when SPI_MAP_CTRL[0]=1 (for test purposes). Refer to the SPI Slave section for more details.
UART 0	Pmod J1 pins [4:1]
UART 1	USB UART (debug console)
UART 2	Pmod J5 pins [10:7]

Pmod Pin Configuration ARC EM Starter Kit

Figure 49 shows the location of the Pmod pins on the board connectors.

Figure 49 Pmod Pin Numbering



Pmod bits 5 and 11 are connected to GND for all PMOD connectors.

Pmod bits 6 and 12 are connected to 3.3 V for all PMOD connectors.

# **Pmod Pin Configuration**

Pmod pins are configured by the Pin Mux Controller using the PMOD\_MUX\_CTRL register. This register is mapped to the peripheral register file (refer to *Table 26*).

# PMOD\_MUX\_CTRL Register

Default	0x0
Peripheral memory offset	0x0
Access	Read/Write

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	F	Rese	erve	d		PM7	<b>'</b> [1:0]	I	PM6	[3:0	]	I	PM5	[3:0	]	F	PM4	[3:0	]	Р	PM3[	3:0	]	Р	M2	[3:0	0]	Р	M1	[3:0	·]

Pmod Pin Configuration ARC EM Starter Kit

### **Pmod1 Configuration**

PM1[3:0] – select signals connected to Pmod1 at the J1 connector

Pins 1, 2, 3, 4, and 7 of Pmod1 (J1) are pulled up irrespective of the setting of PM1.

Note: PM1[1] and PM1[3] are reserved.

### Using Pmod1 (J1) As a GPIO Port

This is the default setting after a reset.

Set PM1[0] = 0 - Pmod1[4:1] are connected to DW GPIO Port C[11:8].

Set PM1[2] = 0 - Pmod1[10:7] are connected to DW GPIO Port A[11:8].

See Table 11 and Table 12 for the detailed pin assignment.

### Using Pmod1 (J1) Upper Row As a UART

Set PM1[0] = 1 - Pmod1[4:1] are connected to the DW UART0 signals.

The UART signal mapping to the Pmod1[4:1] port is controlled by the <code>UART\_MAP\_CTRL</code> register.

This register is mapped to the peripheral register file (refer to Table 26).

### **UART\_MAP\_CTRL** Register

Default	0xE4
Peripheral memory offset	0xC
Access	UART_MAP_CTRL[7:0] bits have R/W access

31		8	7	6	5	4	3	2	1	0
	Reserved		UM4	[1:0]	UM3	B[1:0]	UM2	2[1:0]	UM1	[1:0]

Table 11 Pin Assignment of Pmod1 (J1) Upper Row Depending on PM1[0]

Pmod1 Pins (J1)	PM1[0]=0	PM1[0]=1					
Fillout Fills (31)	GPIO Signal	UART Signal					
4	Port C[11]	RTS_N if UM4="11" (default) RXD if UM4="10"  TXD if UM4="01"  CTS_N if UM4="00"					
3	Port C[10]	RTS_N if UM3="11"  RXD if UM3="10" (default)  TXD if UM3="01"  CTS_N if UM3="00"					

2	Port C[9]	RTS_N if UM2="11" RXD if UM2="10" TXD if UM2="01" (default) CTS_N if UM2="00"
1	Port C[8]	RTS_N if UM1="11"  RXD if UM1="10"  TXD if UM1="01"  CTS_N if UM1="00" (default)

### **UART** mapping examples:

Pmod Interface Type 4 UART

Set UART\_MAP\_CTRL=0xE4 (Binary: 11 10 01 00)

UM1 = "00": Pmod1[1] connected to CTS\_N

UM2 = "01": Pmod1[2] connected to TXD

UM3 = "01": Pmod1[3] connected to RXD

UM4 = "11": Pmod1[4] connected to RTS\_N

Pmod Interface Type 3 UART

Set UART\_MAP\_CTRL=0x6C (Binary: 01 10 11 00)

UM1 = "00": Pmod1[1] connected to CTS\_N

UM2 = "11": Pmod1[2] connected to RTS\_N

UM3 = "10": Pmod1[3] connected to RXD

UM4 = "01": Pmod1[4] connected to TXD

### Using Pmod1 (J1) Lower Row As an SPI Slave

Set PM1[2] = 1 - Pmod1[10:7] are connected to DW SPI Slave signals.

Table 12 Pin Assignment of Pmod1 (J1) Lower Row depending on PM1[2]

Dmod1 Dine ( I1)	PM1[2]=0	PM1[2]=1
Pmod1 Pins (J1)	<b>GPIO Signals</b>	SPI signals
10	Port A[11]	SPI SLV SCLK
9	Port A[10]	SPI SLV MISO
8	Port A[9]	SPI SLV MOSI
7	Port A[8]	SPI SLV CS_N

Pmod Pin Configuration ARC EM Starter Kit

### **Pmod2 Configuration**

PM2[3:0] – select signals connected to Pmod2 at the J2 connector.

Pins 3 and 4 are pulled up, while pins 1 and 7 are pulled down irrespective of the setting of PM2.

Note: PM2[3:1] are reserved.

### Using Pmod2 (J2) as a GPIO Port

This is the default setting after a reset.

Set PM2[0] = 0 - Pmod2[4:1] are connected to DW GPIO Port C[15:12].

Pmod2[10:7] are connected to DW GPIO Port A[15:12].

### Using Pmod2 (J2) as an I2C port and to access the ARC EM halt/run interface

Set PM2[0] = 1 - Pmod2[4:3] are connected to DW I2C\_0 signals,

Pmod2[2:1] and Pmod2[8:7] are connected to the ARC EM halt/run interface.

In this mode the ARC EM halt/run interface is mapped to Pmod2 next to the I2C signals. The halt/run interface signals can be conveniently accessed at the header J10 (see the section *Headers J10, J11, J12*).

Table 13 Pin Assignment of Pmod2 (J2) Depending on PM2[0]

Dmod2 Dino (12)	PM2[0]=0	PM2[0]=1
Pmod2 Pins (J2)	GPIO Signals	Signals
10	Port A[15]	N/C
9	Port A[14]	N/C
8	Port A[13]	halt_ack
7	Port A[12]	halt_req
4	Port C[15]	I2C_0 SDA
3	Port C[14]	I2C_0 SCL
2	Port C[13]	run_ack
1	Port C[12]	run_req

# **Pmod3 Configuration**

PM3[3:0] – select signals connected to Pmod3 at the J3 connector.

Pins 1, 2, 3, 4, 5, and 6 are pulled up irrespective of the PM3[0] setting.

PM3[3:1] are reserved.

### Using Pmod3 (J3) As a GPIO Port

This is the default setting after reset.

Set PM3[0] = 0 - Pmod3[4:1] are connected to DW GPIO Port C[19:16].

Pmod3[10:7] are connected to DW GPIO Port A[19:16].

### Using Pmod3 (J3) As an I2C Interface

Set PM3[0] = 1 - Pmod3[4:3] are connected to DW I2C 0 signals

Pmod3[2:1] are connected to DW GPIO Port D[1:0].

Pmod3[8:7] are connected to DW GPIO Port D[3:2].

In this mode a few GPIO signals are mapped to Pmod3 next to the I2C signals. These GPIO signals can be conveniently accessed at the header J11 (see the section *Headers J10, J11, J12*).

Table 14 Pin Assignment of Pmod3 (J3) Depending on PM3[0]

Dmod2 Dinc (12)	PM3[0]=0	PM3[0]=1
Pmod3 Pins (J3)	GPIO Signals	Signals
10	Port A[19]	N/C
9	Port A[18]	N/C
8	Port A[17]	Port D[3]
7	Port A[16]	Port D[2]
4	Port C[19]	I2C_0 SDA
3	Port C[18]	I2C_0 SCL
2	Port C[17]	Port D[1]
1	Port C[16]	Port D[0]

### **Pmod4 Configuration**

PM4[3:0] – select signals connected to Pmod4 at the J4 connector.

Pins 1, 2, 3, 4, 5, and 6 are pulled up irrespective of the setting of PM4[0].

Note: PM4[3:1] are reserved.

### Using Pmod4 (J4) as a GPIO Port

This is the default setting after a reset.

Set PM4[0] = 0 - Pmod4[4:1] are connected to DW GPIO Port C[23:20].

Pmod4[10:7] are connected to DW GPIO Port A[23:20].

### Using Pmod4 (J4) as an I2C Interface

Set PM4[0] = 1 - Pmod4[4:3] are connected to DW I2C\_1 signals,

Pmod4[2:1] are connected to DW GPIO Port D[5:4].

Pmod4[8:7] are connected to DW GPIO Port D[7:6].

In this mode, a few GPIO signals are mapped to Pmod4 next to the I2C signals. These GPIO signals can be conveniently accessed at the header J12 (see the section *Headers J10, J11, J12*).

Table 15 Pin Assignment of Pmod4 (J4) Depending on PM4[0]

Dmod4 nino (14)	PM4[0]=0	PM4[0]=1
Pmod4 pins (J4)	<b>GPIO Signals</b>	Signals
10	Port A[23]	N/C
9	Port A[22]	N/C
8	Port A[21]	Port D[7]
7	Port A[20]	Port D[6]
4	Port C[23]	I2C_1 SDA
3	Port C[22]	I2C_1 SCL
2	Port C[21]	Port D[5]
1	Port C[20]	Port D[4]

### **Pmod5 Configuration**

PM5[3:0] – select signals connected to Pmod5 at the J5 connector.

Pins 3, 7 and 9 are pulled up irrespective of the setting of PM5.

Note: PM5[1] and PM5[3] are reserved.

### Using Pmod5 (J5) As a GPIO Port

This is the default setting after a reset.

Set PM5[0] = 0 - Pmod5[4:1] are connected to DW GPIO Port C[27:24].

Set PM5[2] = 0 - Pmod5[10:7] are connected to DW GPIO Port A[27:24].

### Using Pmod5 (J5) As an SPI Master (Four-Pin Interfaces Using CS1\_N)

Set PM5[0] = 1 - Pmod5[4:1] are connected to DW SPI Master signals using CS1\_N.

This allows you to connect an SPI slave to the DW SPI Master. Additional SPI slaves can be connected to the same DW SPI Master at Pmod6.

### Using Pmod5 (J5) As a UART

Set PM5[2] = 1 - Pmod5[10:7] are connected to the DW UART2 signals.

Table 16 Pin Assignment of Pmod5 (J5) Upper Row Depending on PM5[0]

DmodE Dino (15)	PM5[0]=0	PM5[0]=1
Pmod5 Pins (J5)	<b>GPIO Signals</b>	SPI Signals
4	Port C[27]	SPI MST SCLK
3	Port C[26]	SPI MST MISO
2	Port C[25]	SPI MST MOSI
1	Port C[24]	SPI MST CS1_N

Table 17 Pin Assignment of Pmod5 (J5) Lower Row Depending on PM5[2]

Decode Dino (15)	PM5[2]=0	PM5[2]=1
Pmod5 Pins (J5)	<b>GPIO Signals</b>	UART Signals
10	Port A[27]	UART2 RTS_N
9	Port A[26]	UART2 RXD
8	Port A[25]	UART2 TXD
7	Port A[24]	UART2 CTS_N

# **Pmod6 Configuration**

PM6[3:0] – select signals connected to Pmod6 at J6 connector.

Pin 3 is pulled up irrespective of the setting of PM6.

Note: PM6[1] and PM6[3] are reserved.

Pmod Pin Configuration ARC EM Starter Kit

### Using Pmod6 (J6) As a GPIO Port

Set PM6[0] = 0 - Pmod6[4:1] are connected to DW GPIO Port C[31:28].

Set PM6[2] = 0 - Pmod6[10:7] are connected to DW GPIO Port A[31:28].

### Using Pmod6 (J6) As an SPI Master (Four-Pin Interface with One Chip Select CS0\_N)

Set PM6[0] = 1 - Pmod6[4:1] are connected to DW SPI Master signals using CS0\_N.

This allows you to connect an SPI slave to the DW SPI Master. Additional SPI slave can be connected to the same DW SPI Master at Pmod5. Alternatively, two additional chip select signals can be made available at the lower row of Pmod6.

### Using Pmod6 (J6) As an SPI Master (Seven-Pin Interface with Three Chip Selects)

Set PM6[0] = 1 - Pmod6[4:1] are connected to DW SPI Master signals using CS0\_N.

Set PM6[2] = 1 – Pmod6[8:7] are connected to the DW SPI Master chip select signals CS1\_N and CS2\_N

Pmod6[6:5] are connected to the ARC EM halt and sleep status signals

This allows connecting three SPI slaves to the DW SPI Master. In this case do not use Pmod5 as an SPI Master, because it uses the same chip-select signals.

### Using Pmod6 (J6) to Monitor the ARC EM Halt and Sleep Status Signals

Set PM6[2] = 1 - Pmod6[8:7] are connected to the DW SPI Master chip select signals CS1\_N and CS2\_N

Pmod6[6:5] are connected to the ARC EM halt and sleep status signals

Table 18 Pin Assignment o	of Pmod6 (Je	6) Upper Row L	Depending on Pl	M6[0]

Dmode Dino (16)	PM6[0]=0	PM6[0]=1
Pmod6 Pins (J6)	<b>GPIO Signals</b>	SPI signals
4	Port C[31]	SPI MST SCLK
3	Port C[30]	SPI MST MISO
2	Port C[29]	SPI MST MOSI
1	Port C[28]	SPI MST CSO_N

Table 19 Pin Assignment of Pmod6 (J6) Lower Row Depending on PM6[2]

Prode Ding (16)	PM6[2]=0	PM6[2]=1
Pmod6 Pins (J6)	<b>GPIO Signals</b>	Signals
10	Port A[31]	sleep
9	Port A[30]	halt

Pmode Dine (16)	PM6[2]=0	PM6[2]=1
Pmod6 Pins (J6)	<b>GPIO Signals</b>	Signals
8	Port A[29]	SPI MST CS2_N
7	Port A[28]	SPI MST CS1_N

### **Pmod7 Configuration**

PM7[1:0] – select signals connected to Pmod7 at J20 connector.

Note: PM7[1] is reserved.

### Using Pmod7 (J20) As a GPIO Port

Set PM7[0] = 0 - Pmod7[4:1] are connected to DW GPIO Port D[11:8].

### Using Pmod7 (J20) to Monitor the ARC EM Sleep Status Signals

Set PM7[0] = 1 - Pmod7[4:1] are connected to the ARC EM sleep status signals.

Table 20 Pin Assignment of Pmod7 (J7) Depending on PM7[0]

Dmod7 Dine (120)	PM7[0]=0	PM7[0]=1
Pmod7 Pins (J20)	GPIO Signals	Signals
4	Port D[11]	sleep
3	Port D[10]	sleep_mode[2]
2	Port D[9]	sleep_mode[1]
1	Port D[8]	sleep_mode[0]



Pmod7 is implemented using staggered drill-holes. You can plug a standard six-pin Pmod cable into the drill-holes using the six-pin header and gender changer that is typically provided with the Pmod cable. The staggering of the drill-holes ensures a tight and reliable connection. If desired you can also solder a 1x6 header or a 1x6 female connector.

An example for programming the Pmod pin configuration can be found in the bare-metal demo application.

Pmod Pin Configuration ARC EM Starter Kit

# **Pmods Configuration summary**

Table 21 Pmods configuration summary

Pmod1 Pins (J1)	PM1[2]=0	PM1[2]=1
10	Port A[11]	SPI SLV SCLK
9	Port A[10]	SPI SLV MISO
8	Port A[9]	SPI SLV MOSI
7	Port A[8]	SPI SLV CS_N
Pmod1 Pins (J1)	PM1[0]=0	PM1[0]=1
4	Port C[11]	UARTO (Table 11)
3	Port C[10]	UARTO (Table 11)
2	Port C[9]	UARTO (Table 11)
1	Port C[8]	UARTO (Table 11)
Pmod2 Pins (J2)	PM2[0]=0	PM2[0]=1
10	Port A[15]	N/C
9	Port A[14]	N/C
8	Port A[13]	halt_ack
7	Port A[12]	halt_req
4	Port C[15]	I2C_0 SDA
3	Port C[14]	I2C_0 SCL
2	Port C[13]	run_ack
1	Port C[12]	run_req
Pmod3 Pins (J3)	PM3[0]=0	PM3[0]=1
10	Port A[19]	N/C
9	Port A[18]	N/C
8	Port A[17]	Port D[3]
7	Port A[16]	Port D[2]
4	Port C[19]	I2C_0 SDA
3	Port C[18]	I2C_0 SCL
2	Port C[17]	Port D[1]
1	Port C[16]	Port D[0]
Pmod4 pins (J4)	PM4[0]=0	PM4[0]=1

	/ 6
	N/C
Port A[22]	N/C
Port A[21]	Port D[7]
Port A[20]	Port D[6]
Port C[23]	I2C_1 SDA
Port C[22]	I2C_1 SCL
Port C[21]	Port D[5]
Port C[20]	Port D[4]
PM5[2]=0	PM5[2]=1
Port A[27]	UART2 RTS_N
Port A[26]	UART2 RXD
Port A[25]	UART2 TXD
Port A[24]	UART2 CTS_N
PM5[0]=0	PM5[0]=1
Port C[27]	SPI MST SCLK
Port C[26]	SPI MST MISO
Port C[25]	SPI MST MOSI
Port C[24]	SPI MST CS1_N
PM6[2]=0	PM6[2]=1
Port A[31]	sleep
Port A[30]	halt
Port A[30] Port A[29]	halt SPI MST CS2_N
Port A[29]	SPI MST CS2_N
Port A[29] Port A[28]	SPI MST CS2_N SPI MST CS1_N
Port A[29] Port A[28] PM6[0]=0	SPI MST CS2_N SPI MST CS1_N PM6[0]=1
Port A[29] Port A[28]  PM6[0]=0 Port C[31]	SPI MST CS2_N SPI MST CS1_N PM6[0]=1 SPI MST SCLK
	Port A[21]  Port A[20]  Port C[23]  Port C[22]  Port C[21]  Port C[20]  PM5[2]=0  Port A[27]  Port A[26]  Port A[25]  Port A[24]  PM5[0]=0  Port C[27]  Port C[26]  Port C[25]  Port C[24]  PM6[2]=0

Headers J10, J11, J12 ARC EM Starter Kit

Pmod7 Pins (J20)	PM7[0]=0	PM7[0]=1
4	Port D[11]	sleep
3	Port D[10]	sleep_mode[2]
2	Port D[9]	sleep_mode[1]
1	Port D[8]	sleep_mode[0]

# **Headers J10, J11, J12**

The Pmod connectors J2, J3 and J4 can be used to plug in peripheral modules with a Pmod I2C interface, which uses only eight out of 12 available Pmod pins.

According to the Pmod signal mapping described in the *Pmod Pin Configuration* section, four pins that are not used for the I2C interface are available for other purposes, such as GPIO or ARC EM control signals. However, when an I2C Pmod module is inserted into the Pmod connector on the board, physical access to the other four Pmod pins might be difficult, depending on the design of the I2C module. To facilitate access to these signals, they are also connected to separate headers J10, J11, and J12.

The pins 5, 6, 7, 8 of J10, J11, and J12 are connected to the ground. Therefore, you can put jumpers in place to tie any signals on pins 1, 2, 3, or 4 to the ground.

Figure 50 Pin Positions at Headers J10, J11, and J12




Table 22 lists the pin assignment at the header J10 depending on bit PM2[0] of the PMOD MUX CTRL register.

Table 22 Pin Assignment of the Header J10 Depending on PM2[0]

140	PM2[0]=0	PM2[0]=1
J10	GPIO Signals	ARC EM Signals
1	Port C[12]	run_req
2	Port A[12]	halt_req
3	Port A[13]	halt_ack

ARC EM Starter Kit Headers J10, J11, J12

4	Port C[13]	run_ack
5		
6		
7	G	IND
8		
9		

The following pin assignment is used at the header J11 depending on bit PM3 of the PMOD\_MUX\_CTRL Register:

Table 23 Pin Assignment of the Header J11 Depending on PM3[0]

J11	PM3[0]=0	PM3[0]=1	
311	GPIO Signals	GPIO Signals	
1	Port C[16]	Port D[0]	
2	Port A[16]	Port D[2]	
3	Port A[17]	Port D[3]	
4	Port C[17]	Port D[1]	
5			
6	GND		
7			
8			

The following pin assignment is used at the header J12 depending on bit PM4 of the PMOD\_MUX\_CTRL Register.

Table 24 Pin Assignment of the Header J12 Depending on PM4[0]

J12	PM4[0]=0	PM4[0]=1	
	GPIO Signals	GPIO Signals	
1	Port C[20]	Port D[4]	
2	Port A[20]	Port D[6]	
3	Port A[21]	Port D[7]	
4	Port C[21]	Port D[5]	
5	GND		
6			

Peripheral Controllers ARC EM Starter Kit

7
8

# **Peripheral Controllers**

This section describes peripheral devices included in the FPGA project of the ARC EM Starter Kit.

The following peripheral devices are available:

- SPI master
- SPI slave
- I2C
- UART
- GPIO
- WDT
- Timers

The following DesignWare IP components were used to implement the peripherals:

- DW apb uart Universal Asynchronous Receiver/Transmitter
- DW apb gpio General Purpose Programmable I/O
- DW apb ssi Synchronous Serial Interface (SPI)
- DW apb i2c I2C interface
- DW apb wdt WDT
- DW apb timers Timers

General information about DesignWare components can be found at http://www.synopsys.com/IP/Pages/default.aspx

### **GPIO**

Basic GPIO functionality is provided with the Synopsys DesignWare GPIO IP (DW\_apb\_gpio) [4].

This IP controls push buttons, LEDs, and DIP switches and provides the GPIO functionality of Pmod connectors.

The Pmod connectivity is defined by control register settings described in the *Connecting Peripheral Controllers* section.

The DW apb gpio is configured to have the following 4 ports:

Port A width is 32 bits

ARC EM Starter Kit Peripheral Controllers

- Port B width is 9 bits
- Port C width is 32 bits
- Port D width is 12 bits

Port A includes debounce logic and supports interrupt processing. It generates a single, combined interrupt connected to the ARC EM interrupt controller port irq 18.

A detailed description of the peripheral can be found in the *DesignWare DW\_apb\_gpio Databook* [4].


GPIO Controller registers are mapped to the peripheral memory (see *Table 27*).

### I<sub>2</sub>C

Two instances of an I2C peripheral is available. It can be programmed at run time either as a master or slave device. It supports I2C standard and fast mode (up to 400 kHz).

Master mode allows multiple I2C slaves to be connected. Three PMOD connectors (Pmod 2, Pmod3, or Pmod4) are available for direct connection of up to three I2C slaves to the I2C masters; the Pmod connectivity is defined with the control register settings as described in the *Connecting Peripheral Controllers* section. If needed, additional slaves can be connected using external breadboards that support the necessary wiring to hook up multiple slaves to a single Pmod interface. Figure 51 shows the interconnection between dw apb i2c and the Pmod connectors.

Figure 51 DW I2C Connection



Signals of I2C 0 controller may be mapped to Pmod2 and Pmod3, signals of I2C 1 controller may be mapped to Pmod4. Signals of I2C 0 device are connected as wired AND. When some Pmod connector is not selected by the pin mux controller, the corresponding signals are connected to high level.

In slave mode, I2C slave address is programmable at run-time. The default I2C slave address is 0x55.

Peripheral Controllers ARC EM Starter Kit

The ARC EM Starter Kit includes a driver for the I2C peripheral. The I2C functionality is based on the Synopsys DesignWare I2C IP (DW\_apb\_i2c). A detailed description can be found in the DesignWare DW\_apb\_i2c Databook [5].

I2C Controller registers are mapped to the peripheral memory (refer to Table 27)

#### **SPI Master**

The SPI Master has six chip-select outputs. Therefore, it can control up to six SPI devices:

- On-board SPI flash memory
- On-board SD Card
- Internal SPI Slave
- Up to three SPI peripherals connected to Pmod connectors

The SPI Master is implemented using the Synopsys DesignWare <code>DW\_apb\_ssi</code> IP component. Its detailed description can be found in the <code>DW\_apb\_ssi</code> Databook [6].

The SPI Master uses a system clock (pclk) and an additional peripheral clock (ssi\_clk) for the SPI interface. The system clock is 35 MHz in ARC\_EM5D, 30 MHz in ARC\_EM7D and 20 MHz in ARC EM7DFPU. The peripheral clock is always 50 MHz.

The SPI Master control registers are mapped to the peripheral memory (refer to *Table 27*)



The DW\_apb\_ssi IP supports other serial protocols too. However, the IP configuration selected for the ARC EM Starter Kit supports SPI mode only.

The IP contains separate receive and transmit FIFOs, which have a depth of 32 words each. The width of both transmit and receive FIFO buffers is fixed at 16 bits due to the serial specifications, which state that a serial transfer (data frame) can be from four to 16 bits in length.

Data frames that are less than 16 bits in length must be right-justified when written into the transmit FIFO buffer. The shift control logic automatically right-justifies received data in the receive FIFO buffer. The device supports all four SPI modes (clock polarity and clock phase), which can be programmed at run-time.

The maximum achievable SPI clock frequency is 25 MHz.


The ARC EM Starter Kit includes a driver for the SPI master peripheral. Refer to the *DW APB SPI Master Controller User Manual* for information on how to control the peripheral. The chip-select assignment of the SPI Master is described in Table 25.

ARC EM Starter Kit Peripheral Controllers

Table 25 SPI Master Signals Usage

Chip Select Name	Devices
CS0	Pmod 6 pin 1 (connector J6)
CS1	Pmod 5 pin 1 (connector J5), or Pmod 6 pin 7(connector J6)
CS2	Pmod 6 pin 8 (connector J6)
CS3	On-board SD card
CS4	Internal SPI Slave (when register SPI_MAP_CTRL[0]=1)
CS5	On-board SPI Flash memory

Figure 52 DW SPI Master Connection



The Pmod multiplexer allows using the SPI master in two different ways: multiple Pmod SPI mode and pin-count optimized mode.

### **Multiple Pmod SPI Mode**

Each SPI slave has its own Pmod SPI compliant interface with individual clock, data, and chip-select signals. The SPI master generates a single clock and a single data output. These signals are branched to multiple Pmod connectors. The data inputs from the slaves

Peripheral Controllers ARC EM Starter Kit

are multiplexed into one signal. This mode is controlled by the chip-select outputs of the master.

Use this mode if you want to connect one or several Pmod-compliant SPI modules in a convenient way. You can directly connect the Pmod SPI modules to the Pmod connectors on the board.

To select this mode, go to the register PMOD\_MUX\_CTRL and set PM6[0]=1, PM5[0]=1 and/or PM5[2]=1 depending on the desired number and location of SPI interfaces.

### **Pin-Count Optimized Mode**

All SPI slaves share the clock and data signals. However, they have individual chip-select signals. All SPI signals are located in a single Pmod connector, namely Pmod6 at connector J6.

Use this mode if you want to connect extension boards with multiple SPI slaves. This is typically done using wires as this is not a standard Pmod SPI interface.

To select this mode, go to register PMOD MUX CTRL and set PM6[0]=1 and PM6[2]=1.



For more information on the location of individual SPI signals on the Pmod connectors, refer to the Pmod Pin Configuration section.

### **SPI Slave**

The SPI Slave is implemented using the Synopsys DesignWare DW\_apb\_ssi IP component. Refer to the *DW\_apb\_ssi Databook* [6] for a detailed description.

The SPI slave uses a system clock (pclk) and a peripheral clock (ssi\_clk) for the SPI interface. The system clock is 35 MHz in ARC\_EM5D, 30 MHz in ARC\_EM7D and 20 MHz in ARC EM7DFPU and the peripheral clock is 50 MHz.

The SPI Slave control registers are mapped to the peripheral memory (refer to Table 27).



The  $DW_apb_ssi$  IP supports other serial protocols. However, the configuration selected for the ARC EM Starter Kit supports SPI mode only.

The IP contains separate receive and transmit FIFOs, which have a depth of 32 words each. The width of both transmits and receives FIFO buffers is fixed at 16 bits due to the serial specifications, which state that a serial transfer (data frame) can be four to 16 bits in length.

Data frames that are less than 16 bits in length must be right-justified when written into the transmit FIFO buffer. The shift-control logic automatically right-justifies receive data in the receive FIFO buffer. The device supports all four SPI modes (clock polarity and clock phase), which can be programmed at run-time.

If the SPI slave is in transmit only mode, the maximum achievable SPI clock frequency is 6.25 MHz.

ARC EM Starter Kit Peripheral Controllers

If the SPI slave is in transmit and receive mode, the maximum achievable SPI clock frequency is 5 MHz.

The ARC EM Starter Kit includes the driver for the SPI slave peripheral. Refer to the *DW APB SPI Master Controller User Manual* for information on how to control the peripheral.

### **UART**

The UART is implemented using the Synopsys DesignWare UART IP (DW\_apb\_uart). Refer to *Synopsys DesignWare DW\_apb\_uart Databook* [8] for more information (including a register description).

The UART Controller uses a system clock (pclk) and a peripheral clock (sclk) for the UART interface. The system clock is 35 MHz in ARC\_EM5D, 30 MHz in ARC\_EM7D and 20 MHz in ARC\_EM7DFPU. The peripheral clock is always 50 MHz.


UART Controller registers are mapped to the peripheral memory (refer to Table 27).

The IP contains FIFOs, which have a depth of 32 words. The device supports auto flow control.

The FPGA design includes three UART instances; one of them is connected to the USB Debug Console as shown in the Figure 48 FGPA Design Block Diagram. The corresponding USB / UART Interfaces are located on the board.

Figure 53 DW UART Components Connection

Peripheral Controllers ARC EM Starter Kit



The ARC EM Starter Kit includes a driver for the UART peripheral. Refer to the *DW APB ARC EM Starter Kit UART User Manual* for information on how to control the peripheral.

#### **Timers**

The Timers are implemented using the Synopsys DesignWare Timers IP (DW\_apb\_timers). Refer to *Synopsys DesignWare DW\_apb\_timers Databook* [7] for more information (including a register description).

The Timers Controller uses a system clock (pclk). The system clock is 35 MHz in ARC\_EM5D, 30 MHz in ARC\_EM7D and 20 MHz in ARC\_EM7DFPU.

Timers controller registers are mapped to the peripheral memory (refer to Table 27).

#### **WDT**

The WDT is implemented using the Synopsys DesignWare WDT IP (DW\_apb\_wdt). Refer to Synopsys DesignWare DW\_apb\_wdt Databook [9] for more information (including a register description).

The WDT controller uses a system clock (pclk) and a peripheral clock (tclk) as watchdog timer clock. The system clock is 35 MHz in ARC\_EM5D, 30 MHz in ARC\_EM7D and 20 MHz in ARC\_EM7DFPU. The peripheral clock is always 50 MHz.

The WDT controller registers are mapped to the peripheral memory (refer to Table 27).

Peripheral Controllers ARC EM Starter Kit

### **Pin Mux Controller**

The pin mux controller connects the peripheral controllers to external hardware interfaces and to each other. The Pin Mux Controller registers are mapped to the peripheral memory starting from the pin mux controller base address (refer to Table 27). Registers are listed in Table 26.

Table 26 Register File Mapping

Offset	Register Name	Default Value	Description
0x0	PMOD_MUX_CTRL	0x0	This register controls mapping of the peripheral device signals on Pmod connectors. Refer to the <i>Pmod Pin Configuration</i> section for more details.
0x4	I2C_MAP_CTRL	0x0	Reserved for future extensions
0x8	SPI_MAP_CTRL	0x0	SPI_MAP_CTRL[0] selects the mode of operation of the SPI Slave:  Normal operation, SPI_MAP_CTRL[0]=0: SPI Slave is connected to Pmod1 at connector J1.  Loop-back mode, SPI_MAP_CTRL[0]=1: SPI Slave is connected to the SPI Master inside the FPGA using CS4. This mode is for test purposes only.
0xC	UART_MAP_CTRL	0xE4	This register controls mapping of the UART signals on the Pmod1 connector. Refer to the <i>Pmod Pin Configuration</i> section for more details.

ARC EM Starter Kit Peripheral Controllers

# **Peripheral Memory Mapping**

The peripheral memory mapping depends on the AHB address width. The configurations use an address width of 32 bits.

Table 27 Peripheral Memory Mapping

Nama	Address width: 32 bits		Size
Name	Start	End	
Pin Mux Controller	0xF0000000	0xF0000FFF	4KB
GPIO	0xF0002000	0xF0002FFF	4KB
Timers	0xF0003000	0xF0003FFF	4KB
I2C_0	0xF0004000	0xF0004FFF	4KB
I2C_1	0xF0005000	0xF0005FFF	4KB
SPI Master	0xF0006000	0xF0006FFF	4KB
SPI Slave	0xF0007000	0xF0007FFF	4KB
UART0	0xF0008000	0xF0008FFF	4KB
UART1	0xF0009000	0xF0009FFF	4KB
UART2	0xF000A000	0xF000AFFF	4KB
WDT	0xF000B000	0xF000BFFF	4KB

# **Interrupts Connections**

Table 28 Interrupts Connections

Interrupt	Component
irq_18	GPIO controller
irq_19	I2C_0 controller
irq_20	I2C_1 controller
irq_21	SPI Master controller
irq_22	SPI Slave controller
irq_23	UART0
irq_24	UART1
irq_25	UART2
irq_26	WDT

ARC EM Starter Kit On-Board Devices

irq_27	DW Timer 0
irq_28	DW Timer 1

### **On-Board Devices**

### JTAG Connector

It is recommended to use the USB interface for JTAG debugging. Alternatively, it is possible to use industry-standard debug probes connected to the 20-pin JTAG connector J15.

The ARC EM Starter Kit supports a standard four-wire JTAG interface. The two-wire IEEE 1149.7 C JTAG is not supported.

Refer to the Appendix C for examples of using JTAG debuggers.

#### **USB**

The mini-USB port can be used for several purposes:

- ARC JTAG debugging port
- UART debug console
- FPGA bitfile programming

Put jumper J8 in place for FPGA programming and remove it when the USB port is used for ARC JTAG or as a UART debug console.

Refer to FPGA Programming for details on how to install and use the Digilent Adept and Xilinx iMPACT software.

### **SD Card**

The SD card interface works in SPI mode. It is connected to channel 3 of the SPI Master. The ARC EM Starter Kit includes an MQX application that supports SD cards in raw mode. Refer to the *About the MQX* Demo Package section for more details.

### **Man-Machine Interface**

The following components are available on the ARC EM Starter Kit board:

- Push buttons
- DIP-switches
- Jumpers
- LEDs

ARC EM Starter Kit On-Board Devices

#### **Push Buttons**

Name	Location	Description
A	Above letter "A" of the ARC logo	ARC start button when processor is halted. Additionally, this button is connected to DW GPIO Port A[2]. Debouncing is implemented inside the DW GPIO IP.
		Note that when the processor is halted (for example, for debugging), pressing this button continues execution; pay special attention to this button in debug mode; in general mode it may be used by the user application same way as the 'L' and 'R' buttons.
Reset	Above letter "R" of the ARC logo	ARC reset
С	Above letter "C" of the ARC logo	Configure button. Pushing this button has the same effect as a power-on reset and triggers the FPGA to re-load the bitfile from the serial flash memory.
L	Marked 'L'	User button. This button is connected to DW GPIO Port A[0]. Debouncing is implemented inside the GPIO IP.
R	Marked 'R'	User button. This button is connected to DW GPIO Port A[1]. Debouncing is implemented inside the GPIO IP.

Note: three push buttons (A, L, R) are available for user purposes.

#### **DIP-Switches**

The four-bit DIP-switch SW1 is used for the following purposes:

- 1. Controlling input ports for user GPIOs
  - Switch 1 is connected to GPIO Port C[0].
  - Switch 2 is connected to GPIO Port C[1].
  - Switch 3 is connected to GPIO Port C[2].
  - Switch 4 is connected to GPIO Port C[3].
- 2. Selection of the predefined FPGA image to be loaded at power-on or after pressing the configuration button 'C' (Switch 1 and Switch 2) as described in the section Select ARC EM Configurations.
- Enabling a Self-test application (Switch 3) as described in the section Self-Test and Bootloader
- 4. Running user applications from SPI flash (Switch 4) as described in the section Running Applications in Self-Boot Mode.



If switches 1 or 2 are used for user applications, ensure that they are switched to a proper position for the predefined FPGA image, before board power on or before the configuration button 'C' is pressed.

ARC EM Starter Kit On-Board Devices

### **Jumpers**

Refer to ARC EM Starter Kit Getting Started for more information.

#### **LEDs**

Nine LEDs can be used as output ports for user GPIOs. The LEDs LED0 to LED8 are located below the ARC Synopsys logo on the board. LED8 is located next to the DIP switch SW1.

LED GPIO mapping:

- GPIO Port B[0] controls LED0
- GPIO Port B[1] controls LED1
- GPIO Port B[8] controls LED8

If the LED is on, its corresponding control bit is programmed to 0.

After a reset, the LEDs indicate the selected ARC EM configuration and display the result of a self-test.

# **Power Supply**

Use a universal power adapter (110-240 Volts AC to 5 Volts DC) from the package. Connect the appropriate AC plug for your AC power outlet. Connect the DC plug to the connector J13 "5V DC" on the board as shown on Figure 4. Finally, connect the AC plug to your AC power outlet.

# Appendix: B ARC EM Configurations

This chapter is intended for programmers of the ARC EM Starter Kit. It includes an overview of the demo applications provided with the ARC EM Starter Kit and explains how to use the ARC EM Starter Kit software development

# **Programmer's Model**

The ARC EM Starter Kit provides three different ARC EM core configurations that can be used for running applications on a 35 MHz CPU clock for ARC\_EM5D configuration, 30 MHz clock for ARC\_EM7D and 20 MHz for ARC\_EM7DFPU.

The detailed configurations of the four cores are described in Detailed Core Configurations.

For information about the ARC EM architecture, refer to the *ARCv2 ISA Programmer's Reference* [12].

For information about building and running applications on the target platform, refer to the *C/C++ Programmer's Guide for the MetaWare Compiler* [13].

# **Core Configurations and Memory Mapping**

From a programmer's point of view, the ARC EM Starter kit provides two different memory maps:

- ARC\_EM5D and ARC\_EM4 configurations
- ARC\_EM7D, ARC\_EM7DFPU, ARC\_EM6 and ARC\_EM6FPU configurations

## ARC\_EM5D and ARC\_EM4 Configurations

This is an ARC EM core with 32 bits of address space, 128 KB of code memory (ICCM) and 256 KB of data memory (DCCM).

Corresponding MetaWare compiler options for this configuration are:

```
-arcv2em -core1 -HL -Xcode_density -Xswap -Xnorm -Xmpy16 -Xmpy -Xmpyd -Xshift_assist -Xbarrel_shifter -Xdsp_complex -Xtimer0 -Xtimer1
```

# The memory map is shown in Figure 54.

Figure 54 Memory Map of ARC\_EM5D Configuration

0xFFFFFFF	
0=000,000	WDT
0xF000B000	UART 2
0xF000A000	UART 1
0xF0009000	UART 0
	SPI Slave
0xF0007000	SPI Master
0xF0006000	I2C 1
0xF0005000	I2C 0
0xF0004000	Timers
0xF0003000	GPIO
0xF0002000	Pin MUX
0xF0000000	
0x80040000	
	DCCM 256K
0x80000000	
0x10000000	
0x00020000	
0,00020000	ICCM 128K
0~0000000	ICCIVI IZON
0x00000200	Interrupts Vectors
0x00000000	

# ARC\_EM7DARC\_EM7DFPU, ARC\_EM6 and ARC\_EM6FPU Configurations

This is an ARC EM core with 32 bits of address space, 32 KB of code memory (ICCM) and 32 KB of data memory (DCCM). The corresponding MetaWare compiler options for this configuration are:

### ARC\_EM7D:

```
-arcv2em -core1 -HL -Xcode_density -Xswap -Xnorm -Xmpy16 -Xmpy
-Xmpyd -Xshift_assist -Xbarrel_shifter -Xdsp_complex
-Xtimer0 -Xtimer1
```

### ARC\_EM7DFPU:

```
-arcv2em -corel -HL -Xcode_density -Xswap -Xnorm -Xmpy16 -Xmpy
-Xmpyd -Xshift_assist -Xbarrel_shifter -Xdsp_complex -Xfpus_div
-Xfpu mac -Xfpuda -Xtimer0 -Xtimer1
```

The memory map is shown in Figure 55.

Figure 55 Memory Map of ARC\_EM7D and ARC\_EM7DFPU Configurations

0xFFFFFFF	
0. 50000000	WDT
0xF000B000 -	UART 2
	UART 1
0xF0009000 -	UART 0
0xF0008000	SPI Slave
0xF0007000	SPI Master
0xF0006000	I2C 1
0xF0005000 -	I2C 0
0xF0004000	Timers
0xF0003000	GPIO
0xF0002000 - 0xF0000000 -	Pin MUX
0×80008000	
0x80000000	DCCM 32K
0x18000000	
	DDR3
0x10000000 -	
	ICCM 32K
0x00000200	Interrupts Vectors
0x00000000 -	

# **Detailed Core Configurations**

Table 29 describes the ARC\_EM5D, ARC\_EM7D and ARC\_EM7DFPU configurations.

Table 29 Configuration Details

Configuration Option	Description	ARC_EM5D	ARC_EM7D	ARC_EM7D FPU
instances	The number of instantiations of this core	1	1	1
dsp_impl	Infer DSP data path elements from Veri- log operators or use optimized versions	Inferred	inferred	inferred
dsp_complex	Enable support for 16b+16b complex datatype operations: CMAC, CMACC, CBFLY	True	true	true
fpu_dp_assist	Enables double- precision accelera- tion instructions	-	-	True
fpu_fma_option	Enables the fused multiply-add & multiply-subtract instructions	-	-	True
fpu_mas_cycles	The number of mul/add/sub cycles	-	-	2
fpu_div_option	Enables divide & square-root acceleration	-	-	True
fpu_div_cycles	Controls div/sqrt implementation	-	-	17
code_density_opt ion	Code Density ISA extension.	True	True	True
bitscan_option	Bit-Scan ISA extension.	True	True	True
number_of_interr upts	The total number of interrupts	13	13	13

Configuration Option	Description	ARC_EM5D	ARC_EM7D	ARC_EM7D FPU
external_interru pts	Number of external interrupt pins.	11	11	11
intvbase_preset	Interrupt vector base.	0	0	0
rgf_num_regs	Number of core registers.	32	32	32
rgf_wr_ports	Register file: number of write ports.	1	1	1
byte_order	Endianness.	Little	Little	Little
shift_option	Shift option.	3	3	3
swap_option	SWAP instruction.	True	True	True
div_rem_option	DIV/REM option.	radix2	radix2	radix2
mpy_option	Multiplier ISA option.	None	None	None
stack_checking	Include logic for validating stack accesses. Stack access violations are subject to privilege violation exceptions.	False	False	False
code_protection	Disables any load or store to the corresponding region	False	False	False
timer_0_int_leve l	Timer 0 interrupt level.	1	1	1
timer_1_int_leve	Timer 1 interrupt level.	0	0	0
dccm_size	Size of the Data Closely Coupled Memory (DCCM) in bytes.	262144	32768	32768
dccm_dmi	DCCM has DMI port.	False	false	false
iccm0_size	Defines the size of ICCM0 in bytes. This ICCM has 0	131072	32768	32768

Configuration Option	Description	ARC_EM5D	ARC_EM7D	ARC_EM7D FPU
	wait states.			
iccm0_base	Sets the initial memory region assignment for ICCM0.	0	0	0
iccm0_dmi	ICCM0 has DMI port.	False	False	False
rgf_num_banks	Two register banks are needed for fast IRQ, but may be selected even without.	1	1	1
rgf_banked_regs	Number of banked registers.	32	32	32
number_of_levels	Number of interrupt levels.	2	2	2
firq_option	Fast IRQ enabled.	false	false	false
num_actionpoints	Number of trigger events available.	2	2	2
aps_feature	Selects Actionpoint feature set.	min	min	min
smart_stack_entr	Specifies the number of entries in the trace buffer.	8	8	8
pct_counters	The number of Performance Monitor counters	8	8	8
dc_size	D-cache size.	-	16384	16384
dc_ways	D-cache ways.	-	2	2
dc_bsize	D-cache line length.	-	32	32
dc_feature_level	D-cache feature level.	-	2	2
dc_uncached_region	D-cache uncached region.	-	false	false
ic_size	I-cache size.	-	16384	16384

Configuration Option	Description	ARC_EM5D	ARC_EM7D	ARC_EM7D FPU
ic_ways	I-cache ways.	-	2	2
ic_bsize	I-cache line length.	-	32	32
ic_pwr_opt_level	I-cache dynamic power optimization.	-	1	1
ic_feature_level	I-cache feature level.	-	2	2
ic_disable_on_re set	Disable I-cache on reset.		False	False

## **Troubleshooting**

The following message may appear when you try to connect using the MetaWare debugger:

```
[DIGILENT] Device enumeration: #0 is `TE0604-02'=JTAG-ONB4.
[DIGILENT] We choose device : #0 `TE0604-02' from 1 possible devices.

[DIGILENT] Product=508 variant=1 fwid=57 firmware-version=108.
[DIGILENT] It is possible to set the JTAG speed.

[DIGILENT] Current speed is 100000000 Hz.

[JTAG] ARC 1 does not exist; the chain has 0 ARCs.

Download failed (2).

No process.

Exiting due to error and because exit_on_error=1.

C:\ARC\MetaWare\arc/bin/cld: Permission denied
```

This means that the J8 jumper was left after programming the FPGA. Remove it to eliminate this message.

1. Make sure that you are using the correct console settings for the dw\_apb\_uart application:

```
Baudrate=115200 Kb/s
Bits=8
Parity=None
Stop=1
```

# Appendix: C FPGA Image Recovery

ARC EM Starter Kit has pre-programmed configurations stored in SPI flash. However, it is possible to do firmware updates using Xilinx tools.

This section describes software and hardware tools required for FPGA image programming and the actions required to perform it.

#### **Board Jumper Settings**

The ARC EM Starter Kit hardware contains pre-installed FPGA configurations. Therefore, it is ready to use with no extra actions needed.


Table 30 describes the board jumper settings. Changing jumper positions is only needed for reprogramming the FPGA or the serial flash memory.

Jumper J8 has two pins. J16 has three pins; pin 1 is at the bottom and it is the closest one to J8.

Table 30 Board Jumper Settings

Reference	Description	Default Jumper Setting	
Ј8	This jumper selects the JTAG target.		
	Select the ARC EM processor Leave the pins open when using the Meta- Ware Debugger		
	Select the FPGA Put a jumper in place during FPGA configuration, for example for programming the bitfile.		
J16	This jumper selects the SDIO mode.	Warning: Do not alter this setting.	
	normal SDIO mode		

ARC EM Starter Kit Xilinx Lab Tools Installation



### **Xilinx Lab Tools Installation**


The Xilinx Lab Tools utility is optional. This toolset includes the **iMPACT** tool, which can be used to configure the FPGA with bitfiles that may become available on the ARC EM Starter Kit download site. The Xilinx Lab Tools can be downloaded from the following address: <a href="http://www.xilinx.com/support/download/index.htm">http://www.xilinx.com/support/download/index.htm</a>.

To install Xilinx Lab tools, perform the following steps:

1. Unzip the Lab Tool package and execute the xsetup.exe.


This starts the installation:

Figure 56 Welcome Dialog



2. In the next dialog, choose the following tick-boxes and click **Next**:

Figure 57 Product Registration Dialog



3. Proceed with the installation and wait until it is finished.

The program is now installed.

## **Connecting the FPGA Programming Cable**

Programming of an FPGA bitfile is normally not required, because pre-programmed images are available in the SPI Flash memory. Refer to the Select ARC EM Configurations section for more details.


Cabling is required if you wish to program other bitfiles that may become available on the ARC EM Starter Kit web site.

The following cabling is required for programming the board with an FPGA bitfile:

USB cable with mini-USB connector

Connect this cable to the connector J7 on the board and to your computer.

Figure 58 USB FPGA Programming Cable Connection to the Board



## **FPGA Programming Sequence**


This section describes the process of programming the Xilinx FPGA in the ARC EM Starter Kit with bitfiles using the iMPACT tool.

It is assumed that the USB programming cable is attached to the appropriate connector on the board according to the *Connecting the FPGA Programming Cable* section.

To perform FPGA programming, perform the following steps:

- 1. Put a jumper in place at header **J8**.
- 2. Run the Xilinx iMPACT tool:


Figure 59 iMPACT Tool - Main Window View



- 3. Cancel the iMPACT Project selection dialog.
- 4. Select the **Boundary Scan** option from the **Flows** toolbar, situated in the upper left corner of the application.


# 5. When the **Boundary Scan** window appears, right click on it and select **Initialize Chain** option.

Figure 60 iMPACT Tool - Initialize Chain Menu Option



Select the FPGA **XC6SLX150** in the sequence of detected devices. Double-click on it and point to the location of an FPGA image \*.bit file.

Figure 61 iMPACT Tool – Assign New Configuration File Dialog Box



- 6. If no SPI flash programming is required, select "No" in the window appeared.
- 7. Right-click on the **FPGA** device and select "**Program**".
- 8. A screenshot of the iMPACT tool after successful programming is shown in Figure 62.




Figure 62 iMPACT View of the Successful FPGA Programming

9. Remove the jumper from header J8.

## **SPI Flash-Programming Sequence**

This section describes the process of programming the SPI Flash in the ARC EM Starter Kit with MCS files using the iMPACT tool.

It is assumed that the USB programming cable is attached to the appropriate connector on the board according to the *Connecting the FPGA Programming Cable* section.

In order to perform SPI flash programming, perform the following steps:

- 1. Put a jumper in place at header **J8**.
- 2. Run the Xilinx iMPACT tool.
- 3. Cancel the project selection dialog box.
- 4. Select the **Boundary Scan** option from the **Flows** toolbar, situated in the upper left corner of the application.

- 5. When the **Boundary Scan** window appears, right click on it and select **Initialize Chain** option.
- 6. Select the SPI/BPI dashed frame above FPGA icon in the sequence of detected devices. Double-click it and point to the location of a flash image \*.mcs file.

Figure 63 iMPACT Tool - select SPI device






Figure 64 iMPACT Tool - Add PROM File Dialog Box




7. Select SPI PROM W25Q128BV flash type, data with data width 1.

Figure 65 iMPACT Tool - Select Attached SPI/BPI Dialog Box



- 8. Right-click on the Flash device and select Program.
- 9. Accept the default programming options.
- 10. Flash programming takes approximately four minutes.
- 11. A screen shot of the iMPACT tool after successful programming is shown in Figure 66.

Figure 66 iMPACT View of the Successful SPI ROM Programming




# Appendix: D Using a JTAG Debugger

It is best to use the on-board USB port to connect your debugger. If you wish to use a JTAG debug cable instead, you can connect it to the JTAG debugging port at the J15 connector. This section describes software and hardware tools for using example JTAG debuggers.

## **Ashling Opella-XD Debugger**

The Ashling Opella-XD debugger has two components: The Opella-XD for ARC Debug Probe and the 20-way JTAG Debug cable TPAOP-ARC20. They are shown in Figure 67.





For more details, refer to http://www.ashling.com/.

Connect the JTAG debug cable connect to the J15 connector on the baseboard. Match the signal names on the cable and the connector according to Table 31.

Table 31 ARC EM Starter Kit JTAG Connector Pin-out

J15 pin number	JTAG signal
1	V_REF
4	GND
5	TDI
7	TMS
9	TCK
13	TDO

To use the JTAG connected to J15 make sure that the J8 jumper has been set.

Figure 68 Jumper J8 Set




Figure 69 ARC JTAG Connection to the Board



# **Lauterbach TRACE32 Debugger**

The Lauterbach TRACE32 debugger for ARC cores has two components:

- Power debug module
- JTAG debugger for ARC

These components are shown in Figure 70.

Figure 70 Lauterbach TRACE32 with Debug Cable



For more information, refer to http://www.lauterbach.com/frames.html?bdmarc.html.

Connect the debugger to the J15 connector on the baseboard. The JTAG pin assignment is the same as for the Ashling debugger. Refer to *Table 31* for more information.

## **Lauterbach TRACE32 Tool Installation**

This tool is required if the Lauterbach TRACE32 debugger is used for JTAG communication with an ARC EM core.

The software can be downloaded from the Lauterbach Download Center web page at <a href="http://www.lauterbach.com/frames.html">http://www.lauterbach.com/frames.html</a>?downloadcenter.html.

# **Glossary and References**

This chapter contains a list of specific terms used in this document and references for further reading.

## **Glossary**

#### **APB**

AMBA Advanced Peripheral Bus

#### **AHB**

AMBA Advanced High Performance Bus

#### **DCCM**

**Data Closely Coupled Memory** 

#### **DMP**

Data Memory Pipeline (ARC proprietary bus)

#### DW

Synopsys DesignWare IP solutions

#### **GPIO**

General Purpose Input/Output pins

#### ICCN

Instruction Closely Coupled Memory

#### **Pmod**

Digilent Pmod™ socket connector

ARC EM Starter Kit References

### References

[1] ARC EM Starter Kit Getting Started http://www.synopsys.com/dw/ipdir.php?ds=arc\_em\_starter\_kit

- [2] AMBA Specification (http://www.arm.com)
- [3] AMBA APB3 Specification (http://www.arm.com)
- [4] Synopsys DesignWare DW\_apb\_gpio Databook, version 2.10a, June 2014
- [5] Synopsys DesignWare DW\_apb\_i2c Databook, version 1.22a, June 2014
- [6] Synopsys DesignWare DW\_apb\_ssi Databook, version 3.23a, June 2014
- [7] Synopsys DesignWare DW\_apb\_timers Databook, version 2.09a, June 2014
- [8] Synopsys DesignWare DW\_apb\_uart Databook, version 3.15a, June 2014
- [9] Synopsys DesignWare DW\_apb\_wdt Databook, version 1.08a, June 2014
- [10] Synopsys DesignWare DW\_apb Databook, version 2.03a, June 2014
- [11] Xilinx UG380: Spartan-6 FPGA Configuration User Guide (http://www.xilinx.com/support/documentation/user\_guides/ug380.pdf)
- [12] ARCv2 ISA Programmer's Reference
- [13] C/C++ Programmer's Guide for the MetaWare Compiler
- [14] Xilinx XAPP496 (http://www.xilinx.com/support/documentation/application\_notes/xapp496.pdf)
- [15] Maxim DS2502-E48 product overview (http://www.maxim-ic.com/datasheet/index.mvp/id/3748)
- [16] Maxim DS2432 product page (http://www.maximintegrated.com/datasheet/index.mvp/id/2914)
- [17] Xilinx DS160: Spartan-6 Family Overview (http://www.xilinx.com/support/documentation/data\_sheets/ds160.pdf)
- [18] Xilinx DS162: Spartan-6 FPGA Data Sheet: DC and Switching (http://www.xilinx.com/support/documentation/data\_sheets/ds162.pdf)
- [19] Winbond W25Q128BV product overview (http://www.winbond.com/hq/enu/ProductAndSales/ProductLines/FlashMemory/SerialF lash/W25Q128BV.htm)
- [20] DesignWare ARB SPI Master Controller User Manual