



SERVICE MANUAL

**1977
thru
1984**

MODEL 210 & T210 SERIES



**FAA APPROVAL HAS BEEN OBTAINED ON TECHNICAL DATA IN
THIS PUBLICATION THAT AFFECTS AIRPLANE DESIGN.**

**REVISION 3 INCORPORATES TEMPORARY REVISIONS 1, 2, AND 3,
DATED 1 DECEMBER 1992, 1 APRIL 1993, AND 3 OCTOBER 1994.**

**COPYRIGHT ©1996
CESSNA AIRCRAFT COMPANY
WICHITA, KANSAS, USA**

**D2057-3-13
(RGI-50-7/02)**

REVISION 3

10 SEPTEMBER 1982

1 MARCH 1996



TEMPORARY REVISION NUMBER 8

DATE 5 April 2004

MANUAL TITLE Model 210 & T210 Series 1977 Thru 1984 Service Manual
MANUAL NUMBER - PAPER COPY D2057-3-13
MANUAL NUMBER - AEROFICHE D2057-3-13AF
TEMPORARY REVISION NUMBER D2057-3TR8
MANUAL DATE 10 September 1982 **REVISION NUMBER** 3 **DATE** 1 March 1996

This Temporary Revision consists of the following pages, which affect and replace existing pages in the paper copy manual and supersede aerofiche information.

SECTION	PAGE	AEROFICHE FICHE/FRAME	SECTION	PAGE	AEROFICHE FICHE/FRAME
2	27	1/B22			
2	32	1/C03			

REASON FOR TEMPORARY REVISION

1. To add the cleaning interval of the engine fuel injection nozzles.

FILING INSTRUCTIONS FOR THIS TEMPORARY REVISION

1. For Paper Publications, file this cover sheet behind the publication's title page to identify the inclusion of the Temporary Revision into the manual. Insert the new pages into the publication at the appropriate locations and remove and discard the superseded pages.
2. For Aerofiche Publications, draw a line with permanent red ink marker, through any aerofiche frame (page) affected by the Temporary Revision. This will be a visual identifier that the information on the frame (page) is no longer valid and the Temporary Revision should be referenced. For "added" pages in a Temporary Revision, draw a vertical line between the applicable frames. Line should be wide enough to show on the edges of the pages. Temporary Revisions should be collected and maintained in a notebook or binder near the aerofiche library for quick reference.



TEMPORARY REVISION NUMBER 7

DATE 7 October 2002

MANUAL TITLE Model 210 & T210 Series 1977 Thru 1984 Service Manual
MANUAL NUMBER - PAPER COPY D2057-3-13
MANUAL NUMBER - AEROFICHE D2057-3-13AF
TEMPORARY REVISION NUMBER D2057-3TR7
MANUAL DATE 10 September 1982 **REVISION NUMBER** 3 **DATE** 1 March 1996

This Temporary Revision consists of the following pages, which affect and replace existing pages in the paper copy manual and supersede aerofiche information.

SECTION	PAGE	AEROFICHE FICHE/FRAME	SECTION	PAGE	AEROFICHE FICHE/FRAME
2	28	1/B23			
2	28A/Deleted	NA			
2	29	1/B24			
2	30	1/C01			
2	31	1/C02			
2	32	1/C03			
2	32A/Deleted	NA			
2	33	Added			
2	34	Added			
2	35	Added			
2	36	Added			
16	22C	Added			
16	22D	Added			

REASON FOR TEMPORARY REVISION

1. To include the requirement to inspect all fluid carrying lines and hoses in the cabin and wing areas. Revise the Special Inspection Items section and add a Component Time Limits section and a fuel quantity indicating system operational test.

FILING INSTRUCTIONS FOR THIS TEMPORARY REVISION

1. For Paper Publications, file this cover sheet behind the publication's title page to identify the inclusion of the Temporary Revision into the manual. Insert the new pages into the publication at the appropriate locations and remove and discard the superseded pages.
2. For Aerofiche Publications, draw a line with permanent red ink marker, through any aerofiche frame (page) affected by the Temporary Revision. This will be a visual identifier that the information on the frame (page) is no longer valid and the Temporary Revision should be referenced. For "added" pages in a Temporary Revision, draw a vertical line between the applicable frames. Line should be wide enough to show on the edges of the pages. Temporary Revisions should be collected and maintained in a notebook or binder near the aerofiche library for quick reference.

TEMPORARY REVISION NUMBER 6

DATED 7 January 2000

MANUAL TITLE MODEL 210 & T210 SERIES 1977 THRU 1984 SERVICE MANUAL

MANUAL NUMBER - PAPER COPY D2057-3-13 AEROFICHE D2057-3-13AF

TEMPORARY REVISION NUMBER PAPER COPY D2057-3TR6 AEROFICHE N/A

MANUAL DATE 10 SEPTEMBER 1982 REVISION NUMBER 3 DATE 1 MARCH 1996

This Temporary Revision consists of the following pages, which affect existing pages in the paper copy manual and supersede aerofiche information.

SECTION	PAGE	AEROFICHE FICHE/FRAME	SECTION	PAGE	AEROFICHE FICHE/FRAME
2	28A	Added			
2	32A	Added			

REASON FOR TEMPORARY REVISION

To include the inspection requirements of Cessna Service Bulletin SEB99-18.

FILING INSTRUCTIONS FOR THIS TEMPORARY REVISION

For Paper Publications:

File this cover sheet behind the publication's title page to identify the inclusion of the Temporary Revision into the manual. Insert the new pages into the publication at the appropriate locations. Draw a line, with a permanent red ink marker, through any superceded information.

For Aerofiche Publications:

Draw a line through any aerofiche frame (page) affected by the Temporary Revision with a permanent red ink marker. This will be a visual identifier that the information on the frame (page) is no longer valid and the Temporary Revision should be referenced. For "added" pages in a Temporary Revision, draw a vertical line between the applicable frames which is wide enough to show on the edges of the pages. Temporary Revisions should be collected and maintained in a notebook or binder near the aerofiche library for quick reference.

TEMPORARY REVISION NUMBER 5

DATED 2 March, 1998

MANUAL TITLE MODEL 210 SERIES 1977 THRU 1984 SERVICE MANUAL

MANUAL NUMBER - PAPER COPY D2057-3-13 AEROFICHE D2057-3-13AF

TEMPORARY REVISION NUMBER - PAPER COPY D2057-3TR5-13 AEROFICHE N/A

MANUAL DATE 10 September, 1982 REVISION NUMBER 3 DATE 1 March, 1996

This Temporary Revision consists of the following pages, which affect and replace existing pages in the paper copy manual and supersede aerofiche information.

CHAPTER/ SECTION/ SUBJECT	PAGE	AEROFICHE FICHE/FRAME	CHAPTER/ SECTION/ SUBJECT	PAGE	AEROFICHE FICHE/FRAME
2	30	1 C-01			
2	31	1 C-02			
2	32	1 C-03			

REASON FOR TEMPORARY REVISION

To add Parker Hannifin Vacuum Manifold Check Valve inspection/replacement times to inspection section.

FILING INSTRUCTIONS FOR THIS TEMPORARY REVISION

For Paper Publications:

File this cover sheet behind the publication's title page to identify inclusion of the temporary revision in the manual. Insert the new pages in the publication at the appropriate locations and remove and discard the superseded pages.

For Aerofiche Publications:

Draw a line, with a permanent red ink marker, through any aerofiche frame (page) affected by the temporary revision. This will be a visual identifier that the information on the frame (page) is no longer valid and the temporary revision should be referenced. For "added" pages in a temporary revision, draw a vertical line between the applicable frames. Line should be wide enough to show on the edges of the pages. Temporary revisions should be collected and maintained in a notebook or binder near the aerofiche library for quick reference.

TEMPORARY REVISION NUMBER 4

DATED October 1, 1997

MANUAL TITLE Model 210, And T210 Series
1977 Thru 1984 Service Manual

MANUAL NUMBER - PAPER COPY D2057-3-13 AEROFICHE D2057-3-13AF

TEMPORARY REVISION NUMBER - PAPER COPY D2057-3TR4-13 AEROFICHE N/A

MANUAL DATE 10 September 1982 REVISION NUMBER 3 DATE 1 March 1996

This Temporary Revision consists of the following pages, which affect and replace existing pages in the paper copy manual and supersede aerofiche information.

CHAPTER/ SECTION/ SUBJECT	PAGE	AEROFICHE FICHE/FRAME	CHAPTER/ SECTION/ SUBJECT	PAGE	AEROFICHE FICHE/FRAME
1	5	1A14			
1	6	1A15			
1	7	Added			
1	8	Added			
1	9	Added			
1	10	Added			
1	11	Added			
1	12	Added			
1	13	Added			
1	14	Added			
1	15	Added			
1	16	Added			
1	17	Added			
1	18	Added			
1	19	Added			
1	20	Added			
1	21	Added			
1	22	Added			
14	3	2H10			

REASON FOR TEMPORARY REVISION

1. To add wet torque values for McCauley propeller hub bolts and add standard torque value tables.

FILING INSTRUCTIONS FOR THIS TEMPORARY REVISION

For Paper Publications:

File this cover sheet behind the publication's title page to identify inclusion of the temporary revision in the manual. Insert the new pages in the publication at the appropriate locations and remove and discard the superseded pages.

For Aerofiche Publications:

Draw a line, with a permanent red ink marker, through any aerofiche frame (page) affected by the temporary revision. This will be a visual identifier that the information on the frame (page) is no longer valid and the temporary revision should be referenced. For "added" pages in a temporary revision, draw a vertical line between the applicable frames. Line should be wide enough to show on the edges of the pages. Temporary revisions should be collected and maintained in a notebook or binder near the aerofiche library for quick reference.

LIST OF EFFECTIVE PAGES

INSERT LATEST REVISED PAGES, DESTROY SUPERSEDED PAGES.

NOTE: The portion of the text affected by the changes is indicated by a vertical line in the outer margins of the page.
Changes to illustrations are indicated by miniature pointing hands.

Dates of issue for original and revised pages are:

Original..... 0..... 10 September 1982
Revision 1..... 3 October 1983
Revision 2..... 29 November 1983
Revision 3..... 1 March 1996

TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 802, CONSISTING OF THE FOLLOWING:

Page No.	Revision No.	Page No.	Revision No.	Page No.	Revision No.
*Title	3	5-11	2	*5A-11A thru 5A-11D	3
*A thru B	3	5-12	0	*5A-12 Blank	3
*C Blank	2	*5-13 thru 5-14	3	*5A-13 thru 5A-16	3
* i thru iv	3	5-15 thru 5-20	0	5A-17 thru 5A-18	0
1-1 thru 1-6	2	*5-20A	3	5A-18A	0
*2-1	3	5-20B Blank	0	*5A-18B	3
2-2	0	5-21 thru 5-22	0	5A-19 thru 5A-21	0
2-3 thru 2-4	2	*5-22A	3	*5A-22 thru 5A-27	3
2-5 thru 2-7	0	5-22B	0	5A-28 thru 5A-29	2
*2-8	3	5-23 thru 5-25	0	*5A-30	3
2-9	0	*5-26	3	5A-31 thru 5A-34	0
2-10	2	5-26A thru 5-26B	0	5A-35	2
2-11 thru 2-12	0	*5-27	3	*5A-36	3
2-13	2	5-28	0	5A-37 thru 5A-38	0
2-14	0	*5-29	3	*6-1 thru 6-2	3
2-15	1	5-30 thru 5-31	2	6-3	0
2-16	2	5-32	0	*6-4	3
2-17	0	*5-33 thru 5-34	3	6-5	0
2-18	2	*5-34A	3	*6-6	3
2-19	0	5-34B Blank	2	6-7 thru 6-8	0
2-20	2	5-35 thru 5-37	0	*6-9 thru 6-11	3
2-21 thru 2-23	0	*5-38	3	6-12 Blank	2
*2-24	3	5-39 thru 5-43	0	*7-1 thru 7-2	3
2-25	0	5-44	2	7-3 thru 7-5	0
2-26	1	*5-45	3	*7-6 thru 7-7	3
*2-27	3	5-46	2	7-8	0
2-28	0	5-47 thru 5-49	0	*7-9	3
*2-29	3	*5-50 thru 5-52	3	7-10 Blank	2
2-30	1	*5-52A	3	*8-1 thru 8-3	3
*2-31 thru 2-32	3	*5-52B Blank	3	8-4 thru 8-6	0
*3-1	3	5-53	0	*8-7	3
3-2 thru 3-7	0	5-54	2	8-8 Blank	2
3-8	2	*5-55 thru 5-60	3	*9-1 thru 9-2	3
*3-9 thru 3-10	3	*5-60A	3	9-3	0
3-11 thru 3-15	0	*5-60B Blank	3	*9-4	3
3-16	2	5-61 thru 5-65	2	9-5 thru 9-9	0
3-17 thru 3-31	0	*5-66 thru 5-68	3	*9-10	3
3-32 Blank	0	5-69 thru 5-72	2	9-11 thru 9-16	0
4-1 thru 4-2	0	*5-73	3	*10-1	3
*4-3	3	5-74 thru 5-94	2	10-2 thru 10-8	0
4-4 thru 4-6	0	*5A-1 thru 5A-2	3	*11-1	3
*5-1 thru 5-3	3	5A-3 thru 5A-7	0	11-2 thru 11-3	0
5-4 thru 5-10	0	*5A-8 thru 5A-11	3	11-4	2

Upon receipt of the second and subsequent revisions to this book, personnel responsible for maintaining this publication in current status should ascertain that all previous revisions have been received and incorporated.

* The asterisk indicates pages revised, added, or deleted by the current revision.

LIST OF EFFECTIVE PAGES, Cont.

Page No.	Revision No.	Page No.	Revision No.	Page No.	Revision No.
*12-1	3	14-2A Blank	0	*17-66 thru 17-68	3
12-2	0	14-2B	0	*17-68A	3
12-2A	2	14-3 thru 14-5	2	*17-68B Blank	3
12-2B Blank	2	14-6 thru 14-7	0	*17-69 thru 17-71	3
12-3 thru 12-8	0	*14-8	3	17-72 thru 17-73	0
*12-9	3	*15-1 thru 15-2	3	*17-74 thru 17-75	3
12-10	0	15-2A	0	17-76 thru 17-77	0
12-11	2	15-2B Blank	0	17-78 thru 17-80	2
12-12 thru 12-13	0	15-3 thru 15-10	0	*18-1	3
12-14 Blank	0	15-11 thru 15-15	1	18-2	0
12-15	2	*15-16	3	18-3 thru 18-4	2
*12-16	3	15-17	1	18-5	0
12-17 thru 12-18	2	15-18	0	18-6 Blank	0
*12-18A	3	15-19 thru 15-21	1	18-6A thru 18-6C	2
12-18B Blank	2	15-22	2	*18-6D	3
12-19	0	15-23 thru 15-30	1	18-7 thru 18-12	2
12-20	2	*15-31 thru 15-32	3	18-12A	2
12-21 thru 12-27	0	15-33 thru 15-34	2	18-12B Blank	2
12-28 Blank	0	15-34A	2	18-13 thru 18-17	0
12-29 thru 12-30	2	15-34B Blank	2	18-18	2
12-31 thru 12-38	0	15-35 thru 15-40	1	18-19 thru 18-26	0
*12A-1 thru 12A-2	3	15-40A thru 15-40E	1	*18-27	3
12A-3	2	15-40F	2	18-28 thru 18-29	0
12A-4	0	*15-41	3	18-30 Blank	0
12A-4A	0	15-42 thru 15-46	0	*19-1	3
12A-4B Blank	0	*15-47 thru 15-49	3	19-2 thru 19-4	0
12A-5 thru 12A-9	0	15-50 Blank	0	*19-5 thru 19-6	3
*12A-10	3	*16-1	3	*20-1 thru 20-2	3
12A-11 thru 12A-13	0	16-2	0	20-2A	2
12A-14 Blank	0	*16-3	3	20-2B Blank	2
12A-15 thru 12A-16	0	16-4 thru 16-9	0	20-3	0
12A-16A thru 12A-16B	2	16-10	1	20-4	2
12A-17 thru 12A-18	2	16-11	0	20-5 thru 20-29	0
12A-18A	2	16-12 thru 16-13	2	20-30 thru 20-32	2
12A-18B Blank	2	16-14	0	20-32A	2
12A-19 thru 12A-30	0	16-15 thru 16-16	2	20-32B Blank	2
12A-31	2	16-17	0	20-33 thru 20-34	0
12A-32 thru 12A-33	0	*16-18	3	20-35 thru 20-38	2
12A-34 Blank	0	16-19	0	20-38A thru 20-38B	2
13-1 thru 13-4	0	*16-20 thru 16-22	3	20-39	2
*13-5 thru 13-6	3	*16-22A	3	20-40 thru 20-102	0
13-7 thru 13-8	0	*16-22B Blank	3	20-103	2
13-9	2	16-23 thru 16-29	0	20-104	0
13-10 thru 13-14	0	16-30 thru 16-32	2	20-105 thru 20-106	2
13-15 thru 13-16	2	*17-1 thru 17-2	3	20-107 thru 20-129	0
13-17 thru 13-23	0	17-3 thru 17-8	0	20-130 thru 20-132	2
13-24	2	*17-9 thru 17-10	3	20-132A	2
13-25 thru 13-30	0	17-11 thru 17-28	0	20-132B Blank	2
13-31	2	*17-29 thru 17-30	3	20-133 thru 20-147	0
13-32 thru 13-33	0	17-31 thru 17-49	0	20-148	2
13-34 Blank	0	17-50	2	20-149 thru 20-157	0
*14-1	3	17-51 thru 17-65	0	20-158 Blank	0
14-2	0				

* The asterisk indicates pages revised, added, or deleted by the current revision.

MODEL 210 & T210 SERIES SERVICE MANUAL

TABLE OF CONTENTS

SECTION	PAGE NO. AEROFICHE/MANUAL
1. GENERAL DESCRIPTION	1A10/1-1
2. GROUND HANDLING, SERVICING, CLEANING, LUBRICATION AND INSPECTION	1A20/2-1
3. FUSELAGE	1C9/3-1
4. WINGS AND EMPENNAGE	1D20/4-1
5. LANDING GEAR, BRAKES AND HYDRAULIC SYSTEM (THRU 1978 MODELS)	1E5/5-1
5A. LANDING GEAR, BRAKES AND HYDRAULIC SYSTEM (BEGINNING WITH 1979 MODELS)	1I15/5A-1
6. AILERON CONTROL SYSTEM	1K16/6-1
7. WING FLAP CONTROL SYSTEM	1L3/7-1
8. ELEVATOR CONTROL SYSTEM	2A2/8-1
9. ELEVATOR TRIM TAB CONTROL SYSTEM	2A17/9-1
10. RUDDER CONTROL SYSTEM	2B13/10-1
11. RUDDER TRIM CONTROL SYSTEM	2C1/11-1
12. ENGINE (NORMALLY ASPIRATED)	2C13/12-1
12A. ENGINE (TURBOCHARGED)	2E6/12A-1
13. FUEL SYSTEM	2F19/13-1
14. PROPELLERS AND PROPELLER GOVERNORS	2H6/14-1
15. UTILITY SYSTEMS	2H16/15-1
16. INSTRUMENTS AND INSTRUMENT SYSTEMS	2K1/16-1
17. ELECTRICAL SYSTEMS	3A2/17-1
18. STRUCTURAL REPAIR	3D11/18-1
19. EXTERIOR PAINTING	3E21/19-1
20. WIRING DIAGRAMS	3F5/20-1

WARNING

When performing any inspection or maintenance that requires turning on the master switch, installing a battery, or pulling the propeller through by hand, treat the propeller as if the ignition switch were ON. Do not stand nor allow anyone else to stand, within the arc of the propeller, since a loose or broken wire or a component malfunction could cause the propeller to rotate.

MODEL 210 & T210 SERIES SERVICE MANUAL

CROSS REFERENCE LISTING OF POPULAR NAME VS. MODEL NUMBERS AND SERIALS

All aircraft, regardless of manufacturer, are certified under model number designations. However, popular names are often used for marketing purposes. To provide a consistent method of referring to these aircraft, the model number will be used in this publication unless the popular name is necessary to differentiate between versions of the same basic model. The following table provides a listing of popular name, model number and serial number.

POPULAR NAME	MODEL YEAR	MODEL	BEGINNING	SERIAL ENDING
CENTURION	1977	210M	21061574	21062273
TURBO CENTURION	1977	T210M	21061574	21062273
CENTURION II	1977	210M	21061574	21062273
TURBO CENTURION II	1977	T210M	21061574	21062273
CENTURION	1978	210M	21062274	21062954
TURBO CENTURION	1978	T210M	21062274	21062954
CENTURION II	1978	210M	21062274	21062954
TURBO CENTURION II	1978	T210M	21062274	21062954
CENTURION	1979	210M	21062955	21063640
TURBO CENTURION	1979	T210M	21062955	21063640
CENTURION II	1979	210M	21062955	21063640
TURBO CENTURION II	1979	T210M	21062955	21063640
CENTURION	1980	210M	21063641	21064135
TURBO CENTURION	1980	T210M	21063641	21064135
CENTURION II	1980	210M	21063641	21064135
TURBO CENTURION II	1980	T210M	21063641	21064135
CENTURION	1981	210N	21064136	21064535
TURBO CENTURION	1981	T210N	21064136	21064535
CENTURION II	1981	210N	21064136	21064535
TURBO CENTURION II	1981	T210N	21064136	21064535
CENTURION	1982	210N	21064536	21064772
TURBO CENTURION	1982	T210N	21064536	21064772
CENTURION II	1982	210N	21064536	21064772
TURBO CENTURION II	1982	T210N	21064536	21064772
CENTURION	1983	210N	21064773	21064822
TURBO CENTURION	1983	T210N	21064773	21064822
CENTURION II	1983	210N	21064773	21064822
TURBO CENTURION II	1983	T210N	21064773	21064822
CENTURION	1984	210N	21064823	21064897
TURBO CENTURION	1984	T210N	21064823	21064897
CENTURION II	1984	210N	21064823	21064897
TURBO CENTURION II	1984	T210N	21064823	21064897

MODEL 210 & T210 SERIES SERVICE MANUAL

INTRODUCTION

This manual contains factory-recommended procedures and instructions for ground handling, servicing, and maintaining Cessna 210 Series Models. The 210 and T210 Series Models covered in this manual are identical, except the Model T210 is turbocharged. Besides serving as a reference for the experienced mechanic, this book also covers step-by-step procedures for the less experienced.

This service manual is designed for aerofiche presentation. To facilitate the use of the aerofiche, refer to the aerofiche header for basic information.

IMPORTANT INFORMATION CONCERNING KEEPING CESSNA PUBLICATIONS CURRENT

The information in this publication is based on data available at the time of publication and is updated, supplemented, and automatically amended by all information issued in Service News Letters, Service Bulletins, Supplier Service Notices, Publication Changes, Revisions, Reissues and Temporary Revisions. All such amendments become part of and are specifically incorporated within this publication. Users are urged to keep abreast of the latest amendments to this publication through the Cessna Product Support subscription services. Cessna Service Stations have also been supplied with a group of supplier publications which provide disassembly, overhaul, and parts breakdowns for some of the various supplier equipment items. Suppliers publications are updated, supplemented, and specifically amended by supplier issued revisions and service information which may be reissued by Cessna; thereby automatically amending this publication and is communicated to the field through Cessna's Authorized Service Stations and/or through Cessna's subscription services.

WARNING

ALL INSPECTION INTERVALS, REPLACEMENT TIME LIMITS, OVERHAUL TIME LIMITS, THE METHOD OF INSPECTION, LIFE LIMITS, CYCLE LIMITS, ETC., RECOMMENDED BY CESSNA ARE SOLELY BASED ON THE USE OF NEW, REMANUFACTURED, OR OVERHAULED CESSNA APPROVED PARTS. IF PARTS ARE DESIGNED, MANUFACTURED, REMANUFACTURED, OVERHAULED, PURCHASED, AND/OR APPROVED BY ENTITIES OTHER THAN CESSNA, THEN THE DATA IN CESSNA'S MAINTENANCE/SERVICE MANUALS AND PARTS CATALOGS ARE NO LONGER APPLICABLE AND THE PURCHASER IS WARNED NOT TO RELY ON SUCH DATA FOR NON-CESSNA PARTS. ALL INSPECTION INTERVALS, REPLACEMENT TIME LIMITS, OVERHAUL TIME LIMITS, THE METHOD OF INSPECTION, LIFE LIMITS, CYCLE LIMITS, ETC., FOR SUCH NON-CESSNA PARTS MUST BE OBTAINED FROM THE MANUFACTURER AND/OR SELLER OF SUCH NON-CESSNA PARTS.

1. **REVISIONS/CHANGES.** Revisions/changes are issued for this publication as required and include only pages that require updating.
2. **REISSUE.** A reissue is issued as required, and is a complete manual incorporating all the latest information and outstanding revisions/changes. It supersedes and replaces previous issue(s).

REVISIONS/CHANGES and REISSUES can be purchased from a Cessna Service Station or directly from Cessna Parts Distribution (CPD 2), Dept. 701, Cessna Aircraft Company, P. O. Box 949, Wichita, Kansas 67201 (walk-in address: 5800 East Pawnee, Wichita, Kansas 67218).

All supplemental service information concerning this manual is supplied to all appropriate Cessna Service Stations so that they have the latest authoritative recommendations for servicing these Cessna airplanes. Therefore, it is recommended that Cessna owners utilize the knowledge and experience of the factory-trained Service Station Organization.

MODEL 210 & T210 SERIES SERVICE MANUAL

CUSTOMER CARE SUPPLIES AND PUBLICATIONS CATALOG

A Customer Care Supplies and Publications Catalog is available from a Cessna Service Station or directly from Cessna Parts Distribution (CPD 2), Dept. 701, Cessna Aircraft Company, P. O. Box 949, Wichita, Kansas 67201 (walk-in address: 5800 East Pawnee, Wichita, Kansas 67218). This catalog lists all publications and Customer Care Supplies available from Cessna for prior year models as well as new products. To maintain this catalog in a current status, it is revised quarterly and issued on Aerofiche with the quarterly Service Information Summaries. A listing of all available publications is issued periodically by the Cessna Propeller Product Support Department.

SUPPLEMENTAL TYPE CERTIFICATE INSTALLATIONS

Inspection, maintenance, and parts requirements for supplemental type certificate (STC) installations are not included in this manual. When an STC installation is incorporated on the airplane, those portions of the airplane affected by the installation must be inspected in accordance with the inspection program published by the owner of the STC. Since STC installations may change systems interface, operating characteristics, and component loads or stresses on adjacent structures, Cessna provided inspection criteria may not be valid for airplanes with STC installations.

CUSTOMER COMMENTS ON MANUAL

Cessna Aircraft Company has endeavored to furnish you with an accurate, useful, up-to-date manual. This manual can be improved with your help. Please use the return card, provided with your manual, to report any errors, discrepancies, and omissions in this manual as well as any general comments you wish to make.

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 1

GENERAL DESCRIPTION

	Page No. Aerofiche/Manual		
GENERAL DESCRIPTION	1A10/1-1	Aircraft Specifications	1A10/1-1
Model 210 Series	1A10/1-1	Stations	1A10/1-1
Description	1A10/1-1	Bolt Torques	1A14/1-5

1-1. GENERAL DESCRIPTION.

1-2. MODEL 210-SERIES.

1-3. DESCRIPTION. The Cessna Centurion, Centurion II, Turbo Centurion, and Turbo Centurion II (Model 210 Series) aircraft, described in this manual, are single-engine, high-wing monoplanes of all metal, semimonocoque construction. Wings are full cantilever, with sealed sections forming fuel bays. The fully-retractable tricycle landing gear consists of tubular spring-steel main gear struts and a steerable nose gear with an air-hydraulic fluid shock strut. The six place seating arrangement is of conventional, forward facing type. Powering the Model 210 Series is a Continental, horizontally-opposed, air-cooled, six-cylinder, fuel-injected engine driving an all-metal, constant-speed propeller. A more desirable higher performance aircraft, is offered in the turbocharged version of the Model 210 Series.

1-4. AIRCRAFT SPECIFICATIONS. Leading particulars of these aircraft, with dimensions based on gross weight, are given in figure 1-1. If these dimensions are used for constructing a hangar on computing clearances, remember that such factors as nose gear strut inflation, tire pressures, tire sizes, and load distribution may result in some dimensions that are considerably different from those listed.

1-5. STATIONS. A station diagram is shown in figure 1-2 to assist in locating equipment when a written description is inadequate or impractical.

MODEL 210 & T210 SERIES SERVICE MANUAL

MODEL 210 AND T210 SERIES

MAXIMUM WEIGHT - 210	
Ramp	3812 lbs.
Takeoff or Landing	3800 lbs.
STANDARD EMPTY WEIGHT - 210	
Centurion	2173 lbs.
Centurion II	2223 lbs.
MAXIMUM USEFUL LOAD - 210	
Centurion	1639 lbs.
Centurion II	1589 lbs.
MAXIMUM WEIGHT - T210	
Ramp	4016 lbs.
Takeoff	4000 lbs.
Landing	3800 lbs.
STANDARD EMPTY WEIGHT - T210	
Turbo Centurion	2263 lbs.
Turbo Centurion II	2311 lbs.
MAXIMUM USEFUL LOAD - T210	
Turbo Centurion	1753 lbs.
Turbo Centurion II	1705 lbs.
FUEL CAPACITY	
Total	90 gal.
Usable - Thru Serial 21064535	89 gal.
Usable - Beginning with Serial 21064536	87 gal.
OIL CAPACITY	
With External Oil Filter and All Turbocharged Engines	10 qt. 11 qt.
ENGINE MODEL	
210 (Refer to Section 12 for Engine Data)	CONTINENTAL IO-520
T210 (Refer to Section 12A for Engine Data)	CONTINENTAL TSIO-520
PROPELLER (Constant-Speed)	
(Three Blades)	80" McCAULEY
LANDING GEAR (Retractable, Hydraulically-Actuated)	
	Tricycle
MAIN WHEEL TIRES	
Pressure	6.00 x 6 55 psi
NOSE WHEEL TIRE	
210	5.00 x 5, 6 ply
Pressure	50 psi
T210 (THRU T21062954)	5.00 x 5, 6 ply
Pressure	50 psi
T210 (BEGINNING WITH T21062955)	5.00 x 5, 10 ply
Pressure	88 psi

Figure 1-1. Aircraft Specifications (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL



MODEL 210 AND T210 SERIES

NOSE GEAR STRUT PRESSURE (Strut Extended)	90 psi
WHEEL ALIGNMENT	
Camber	4° ± 1° 30'
Toe-in	0" to .06"
AILERON TRAVEL	
Up	20° ± 2°
Down	15° ± 2°
WING FLAP TRAVEL (Electrically-Actuated)	0° ± 0° to 30°, +1° -2°
RUDDER TRAVEL (Measured parallel to water line)	
Right	24° ± 1°
Left	24° ± 1°
RUDDER TRAVEL (Measured perpendicular to hinge line)	
Right	27° 13' ± 1°
Left	27° 13' ± 1°
ELEVATOR TRAVEL	
Up	23° ± 1°
Down	17° ± 1°
ELEVATOR TRIM TAB TRAVEL	
Up	25° ± 1°
Down	10° ± 1°
PRINCIPAL DIMENSIONS	
Wing Span	441.75"
Tail Span	156.32"
Length	337.96"
Fin Height (Maximum with Nose Gear Depressed and Flashing Beacon Installed on Fin)	112.92"
Track Width	104.20"
BATTERY LOCATION	Left Side of Firewall

Figure 1-1. Aircraft Specifications (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

MODEL 210 SERIES



*** INDICATES CANTED BULKHEAD**

Figure 1-2. Reference Stations

MODEL 210 & T210 SERIES SERVICE MANUAL

1-6. MATERIAL AND TOOL CAUTIONS - GENERAL

A. Mercury

CAUTION

THERMOMETERS AND OTHER TEST EQUIPMENT CONTAINING MERCURY, MUST NOT BE USED ON THE AIRPLANE.

Mercury, by the amalgamation process, can penetrate any break in the finish, paint or sealing coating of a metal structural element. An oxide coating on a dry metallic surface will tend to inhibit an immediate action while a bright, polished, shining or scratched surface will hasten the process. Moisture will also promote the amalgamation process. Soils, greases or other inert contaminants, present on the metal surfaces, will prevent the start of the action. The corrosion and embrittlement which results from an initial penetration, can be extremely rapid in structural members under load. Once it has begun, there is no known method of stopping it. Complete destruction of the load carrying capacity of the metal will result.

b. Maintenance Precautions

WARNING

DURING MAINTENANCE, REPAIR AND SERVICING OF THE AIRPLANE, MANY SUBSTANCES AND ENVIRONMENTS ENCOUNTERED MAY CAUSE INJURY IF PROPER PRECAUTIONS ARE NOT OBSERVED.

Carefully read and follow all instructions, and especially adhere to all cautions and warnings provided by the manufacturer of the product being used. Use appropriate safety equipment as required including goggles, face shields, breathing apparatus, protective clothing and gloves. Fuel, engine oil, solvents, volatile chemicals, adhesives, paints and strong cleaning agents may cause injury when contacting the skin or eyes, or when vapors are breathed. When sanding composites or metals or otherwise working in an area where dust particles may be produced, the area should be ventilated and the appropriate respirator must be used.

c. General Usage Solvents

General usage solvents include the following:

- Methyl Propyl Ketone
- Toluene
- Isopropyl Alcohol
- Acetone
- Methylene Chloride
- 1,1,1-Trichloroethane
- Naptha
- Trichloroethylene

These chemicals/solvents are generally colorless, evaporate quicker than water, and tend to give off vapors in higher quantities as their temperature increases. The vapors are generally heavier than air, which causes them to collect in low lying areas or push normal oxygen and air out of a confined area. This situation can lead to

Solvents are hazardous to work with because of their flammability, rate of evaporation and reaction to oxidizers. Solvents can also be an irritant to the skin and eyes.

A single spark, a smoldering cigarette, or even atmospheric conditions can ignite solvent vapors. The lower the flash point of the chemical, the more likely it is to become flammable. Generally, flash points of less than 100°F (37.8°C) are considered flammables. Examples of solvent flash points are shown below:

SOLVENT	FLASH-POINT
Methyl Propyl Ketone	45°F (7.2° C)
Toluene	39°F (3.9° C)
Isopropyl Alcohol	53.6°F (12° C)
Acetone	1.4° (-17°C)

The rate of evaporation is closely tied to flammability, because normally the vapors must be present to ignite the liquid. Vaporization also allows solvents, even those that are not flammable, to get into the air and into the body's blood stream through the lungs.

Solvents can also react explosively with oxidizers (chemicals which release oxygen). A very violent and uncontrollable reaction takes place which generates heat rapidly. For this reason, it is very important for each person to be aware of specific chemicals in use in the work area, and to adhere to the labeling of containers. Chemical manufacturers are required to label each container with a diamond shaped symbol: red for flammable and yellow for oxidizers.

Solvents can also damage the hands and skin. Solvents dry out skin and dissolve the natural oils. The condition can develop into an irritation, or if left untreated with continuous exposure, it may progress to a dermatitis. Damaged skin allows other contaminants to worsen the condition, because the contaminants have easier access to the deeper levels of the skin. In serious cases, blood poisoning is also possible.

The best defense against skin irritation is not to be exposed. If exposure is unavoidable, steps should be taken to limit exposure times. Prolonged exposure to these irritants can lead to long term liver damage.

MODEL 210 & T210 SERIES SERVICE MANUAL

1-7. TORQUE DATA - MAINTENANCE PRACTICES

To ensure security of installation and prevent over stressing of components during installation, the torque values outlined in this section and other applicable chapters of this manual should be used during installation and repair of components.

The torque value tables, listed in this section, are standard torque values for the nut and bolt combinations shown. If a component requires special torque values, those values will be listed in the applicable maintenance practices section

Torque is typically applied and measured using a torque wrench. Different adapters, used in conjunction with the torque wrench, may produce an actual torque to the nut or bolt which is different from the torque reading. Figure 1-4 is provided to help calculate actual torque in relation to specific adapters used with the torque wrench

Free Running Torque Value

Free running torque value is the torque value required to rotate a nut on a threaded shaft, without tightening. Free running torque value does not represent the torque values listed in the tables of this section. Torque values listed in the tables represent the torque values above free running torque.

EXAMPLE

If final torque required is to be 150 inch-pounds and the free running torque is 25 inch-pounds, then the free running torque must be added to the required torque to achieve final torque of $150 + 25 = 175$ inch-pounds.

Breakaway torque value is the value of torque required to start a nut rotating on a thread shaft, and does not represent free running torque value. It should be noted that on some installations the breakaway torque value cannot be measured.

General Torquing Notes:

- a. These requirements do not apply to threaded parts used for adjustment, such as turnbuckles and rod ends.
- b. Torque values shown are for clean, nonlubricated parts. Threads should be free of dust, metal filings, etc. Lubricants, other than that on the nut as purchased, should not be used on any bolt installation unless specified.
- c. Assembly of threaded fasteners, such as bolts, screws and nuts, should conform to torque values shown in Table 1-1.
- d. When necessary to tighten from the bolt head, increase maximum torque value by an amount equal to shank friction. Measure shank friction with a torque wrench.
- e. Sheet metal screws should be tightened firmly, but not to a specific torque value.

f. Countersunk washers used with close tolerance bolts must be installed correctly to ensure proper torquing (refer to Figure 1-5).

g. Tighten accessible nuts to torque values per Table 1-1. Screws attached to nutplates, or screws with threads not listed in Table 201 should be tightened firmly, but not to a specific torque value. Screws used with dimpled washers should not be drawn tight enough to eliminate the washer crown.

h. Table 1-1 is not applicable to bolts, nuts and screws used in control systems or installations where the required torque would cause binding or would interfere with proper operation of parts. On these installations, the assembly should be firm but not binding.

i. Castellated Nuts.




Self-locking and non self-locking castellated nuts, except MS17826, require cotter pins and should be tightened to the minimum torque value shown in Table 1-1. The torque may be increased to install the cotter pin, but this increase must not exceed the alternate torque values.

MS17826 self-locking, castellated nuts shall be torqued per Table 1-1.

The end of the bolt or screw should extend through the nut at least two full threads including the chamfer.

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE: WHEN USING A TORQUE WRENCH ADAPTER WHICH CHANGES THE DISTANCE FROM THE TORQUE WRENCH DRIVE TO THE ADAPTER DRIVE, APPLY THE FOLLOWING FORMULAS TO OBTAIN THE CORRECTED TORQUE READING.




$$\text{FORMULA } \frac{T \times L}{L + E} = Y$$

EXAMPLE (WITH "E" AS PLUS DIMENSION)

T = 135 IN-LB	Y = $\frac{135 \times 10}{10 + 1.5} = 117.39$
Y = UNKNOWN	
E = 1.5 IN	Y = 117 IN-LB
L = 10.0 IN	

LEGEND

- T = ACTUAL (DESIRED) TORQUE
- Y = APPARENT (INDICATED) TORQUE
- L = EFFECTIVE LENGTH LEVER
- E = EFFECTIVE LENGTH OF EXTENSION



$$\text{FORMULA } \frac{T \times L}{L - E} = Y$$

EXAMPLE (WITH "E" AS MINUS DIMENSION)


T = 135 IN-LB	Y = $\frac{135 \times 10}{10 - 1.5} = \frac{1350}{8.5} = 158.82$
Y = UNKNOWN	
L = 10.0 IN	Y = 159 IN-LB
E = 1.5 IN	

5598C2005

Torque Wrench and Adapter Formulas
Figure 1-4 Sheet 1

MODEL 210 & T210 SERIES SERVICE MANUAL


EXTERNAL WRENCHING HEAD



CORRECT INSTALLATION

INSTALL WASHER WITH COUNTERSUNK
FACE NEXT TO BOLT HEAD RADIUS

INTERNAL WRENCHING HEAD



INCORRECT INSTALLATION

**CAUTION: NEVER INSTALL STANDARD
WASHER OR COUNTERSUNK
WASHER IN REVERSE WHEN
USING BOLTS WITH RADIUS
UNDER THE HEAD**

5598C1004
5598C1004A

Washer Installation Close Tolerance Bolts
Figure 1-5 Sheet 1

MODEL 210 & T210 SERIES SERVICE MANUAL

Table 1-1: Torque Requirements For Steel Bolts, Screws and Nuts (Inch-Pounds)

SIZE	FINE THREADED SERIES (TENSION TYPE NUTS)		FINE THREADED SERIES (SHEAR TYPE NUTS EXCEPT MS17826)		MS17826 NUTS	
	Standard Torque	Alternate Torque	Standard Torque	Alternate Torque	Standard Torque	Alternate Torque
8-36	12 to 15	--	7 to 9	--	--	--
10-32	20 to 25	20 to 28	12 to 15	12 to 19	12 to 15	12 to 20
1/4-28	50 to 70	50 to 75	30 to 40	30 to 48	30 to 40	30 to 45
5/16-24	100 to 140	100 to 150	60 to 85	60 to 100	60 to 80	60 to 90
3/8-24	160 to 190	160 to 260	95 to 110	95 to 170	95 to 110	95 to 125
7/16-20	450 to 500	450 to 560	270 to 300	270 to 390	180 to 210	180 to 225
1/2-20	480 to 690	480 to 730	290 to 410	290 to 500	240 to 280	240 to 300
9/16-18	800 to 1000	800 to 1070	480 to 600	480 to 750	320 to 370	320 to 400
5/8-18	1100 to 1300	1100 to 1600	660 to 780	660 to 1060	480 to 550	480 to 600
3/4-16	2300 to 2500	2300 to 3350	1300 to 1500	1300 to 2200	880 to 1010	880 to 1100
7/8-14	2500 to 3000	2500 to 4650	1500 to 1800	1500 to 2900	1500 to 1750	1500 to 1900
1-14	3700 to 4500	3700 to 6650	2200 to 3300	2200 to 4400	2200 to 2700	2200 to 3000
1-1/8-12	5000 to 7000	5000 to 10000	3000 to 4200	3000 to 6300	3200 to 4200	3200 to 5000
1-1/4-12	9000 to 11000	9000 to 16700	5400 to 6600	5400 to 10000	5900 to 6400	5900 to 7000

Fine Thread Tension application nuts include: AN310, AN315, AN345, MS17825, MS20365, MS21044 through MS21048, MS21078, NAS679, NAS1291.

Fine Thread Shear application nuts include: AN316, AN320, MS21025, MS21042, MS21043, MS21083, MS21245, NAS1022, S1117.

Coarse Thread application nuts include: AN340, MS20341, MS20365, MS35649

Table 1-1: Torque Values (Newton Meters) Nuts, Bolts and Screws (Steel)

SIZE OF BOLT, NUT OR SCREW	FINE THREADED SERIES (TENSION TYPE NUTS)		FINE THREADED SERIES (SHEAR TYPE NUTS EXCEPT MS17826)		MS17826 NUTS	
	Standard Torque	Alternate Torque	Standard Torque	Alternate Torque	Standard Torque	Alternate Torque
8-36	1.4 to 1.7	--	0.8 to 1.0	--	--	--
10-32	2.3 to 2.8	2.3 to 3.2	1.4 to 1.7	1.4 to 2.1	1.4 to 1.7	1.4 to 2.3
1/4-28	5.6 to 7.9	5.6 to 8.5	3.4 to 4.5	3.4 to 5.4	3.4 to 4.5	3.4 to 5.1
5/16-24	11.3 to 15.8	11.3 to 16.9	6.8 to 9.6	6.8 to 11.3	6.8 to 9.0	6.8 to 10.2
3/8-24	18.1 to 21.5	18.1 to 29.4	10.7 to 12.4	10.7 to 19.2	10.7 to 12.4	10.7 to 14.1
7/16-20	50.8 to 56.5	50.8 to 63.3	30.5 to 33.9	30.5 to 44.1	20.3 to 23.7	20.3 to 25.4
1/2-20	54.2 to 78.0	54.2 to 82.5	32.8 to 46.3	32.8 to 56.5	27.1 to 31.6	27.1 to 33.9
9/16-18	90.4 to 113.0	90.4 to 120.9	54.2 to 67.8	54.2 to 84.7	36.2 to 41.8	36.2 to 45.2
5/8-18	124.3 to 146.9	124.3 to 180.8	74.6 to 88.1	74.6 to 119.8	54.2 to 62.1	54.2 to 67.8
3/4-16	259.9 to 282.5	259.9 to 378.5	146.9 to 169.5	146.9 to 248.6	99.4 to 114.1	99.4 to 124.3
7/8-14	282.5 to 339.0	282.5 to 525.4	169.5 to 203.4	169.5 to 327.7	169.5 to 197.7	169.5 to 214.7
1-14	418.0 to 508.4	418.0 to 751.3	248.6 to 372.9	248.6 to 497.1	248.6 to 305.1	248.6 to 339.0
1-1/8-12	564.9 to 790.9	564.9 to 1129.9	339.0 to 474.5	339.0 to 711.8	361.6 to 474.5	361.6 to 564.9
1-1/4-12	1016.9 to 1242.8	1016.9 to 1886.9	610.1 to 745.7	610.1 to 1129.9	666.6 to 723.1	666.6 to 790.9

MODEL 210 & T210 SERIES SERVICE MANUAL

Torque Requirements for Hi-Lok Fasteners

Use Table 1-2 to determine torque requirements for Hi-Lok fasteners.

NOTE: This table is used in conjunction with MS21042 self-locking nuts.

Table 1-2. Torque Values Hi-Lok Fasteners (Used with MS21042 Self-Locking Nuts)

NOMINAL FASTENER DIAMETER	ALLOY STEEL 180 - 200 KSI (INCH POUNDS)	ALLOY STEEL 180 - 200 KSI (NEWTON METERS)
6-32	8 to 10	0.9 to 1.1
8-32	12 to 15	1.4 to 1.7
10-32	20 to 25	2.3 to 2.8
1/4-28	50 to 70	5.6 to 7.9
5/16-24	100 to 140	11.3 to 15.8
3/8-24	160 to 190	18.1 to 21.5
7/16-20	450 to 500	50.8 to 56.5
1/2-20	480 to 690	54.2 to 78.0

Torque Requirements for Electrical Current Carrying And Airframe Ground Fasteners

Use Table 1-3 to determine torque requirements for threaded electrical current carrying fasteners.

Torque values shown are clean, nonlubricated parts. Threads shall be free of dust and metal filings. Lubricants, other than on the nut as purchased, shall not be used on any bolt installations unless specified in the applicable chapters of this manual.

All threaded electrical current carrying fasteners for relay terminals, shunt terminals, fuse limiter mount block terminals and bus bar attaching hardware shall be torqued per Table 1-3.

NOTE: There is no satisfactory method of determining the torque previously applied to a threaded fastener. When retorquing, always back off approximately 1/4 turn or more before reapplying torque.

Use Table 1-4 to determine torque requirements for threaded fasteners used as airframe electrical ground terminals.

Table 1-3. Torque Values Electrical Current Carrying Fasteners

FASTENER DIAMETER	TORQUE VALUE (INCH POUNDS)	TORQUE VALUE (NEWTON METERS)
6-32	8 to 12	0.9 to 1.4
8-32	13 to 17	1.5 to 1.9
10-32	20 to 30	2.3 to 3.4
3/16	20 to 30	2.3 to 3.4
1/4	40 to 60	4.5 to 6.8
5/16	80 to 100	9.0 to 11.3
3/8	105 to 125	11.9 to 14.1
1/2	130 to 150	14.7 to 16.9

MODEL 210 & T210 SERIES SERVICE MANUAL

Table 1-4. Torque Values Airframe Electrical Ground Terminals

FASTENER DIAMETER	TORQUE VALUE (INCH POUNDS)	TORQUE VALUE (NEWTON METERS)
5/16	130 to 150	14.7 to 16.9
3/8	160 to 190	18.1 to 21.5

Torque Requirements for Rigid Tubing and Hoses

Use Table 1-5 to determine torque requirements for tubes and hoses.

Table 1-5. Tubing/Hose Torque Limits (Inch-Pounds)

Hose Size	Tubing O.D.	Flared or Flareless Fitting with Aluminum or Annealed Stainless Steel Tubing, and Hose with Aluminum Inserts		Flared or Flareless Fitting with Steel Tubing, and Hose with Steel Inserts	
		Min	Max	Min	Max
-2	1/8	45	55	65	75
-3	3/16	75	85	95	105
-4	1/4	105	115	135	150
-5	5/16	135	145	180	200
-6	3/8	160	175	260	285
-8	1/2	265	290	475	525
-10	5/8	340	375	665	735
-12	3/4	425	470	855	945
-16	1	710	785	1140	1260

Table 1-5. Tubing/Hose Torque Limits (Newton Meters)

Hose Size	Tubing O.D.	Flared or Flareless Fitting with Aluminum or Annealed Stainless Steel Tubing, and Hose with Aluminum Inserts		Flared or Flareless Fitting with Steel Tubing, and Hose with Steel Inserts	
		Min	Max	Min	Max
-2	1/8	5.1	6.2	7.3	8.5
-3	3/16	8.5	9.6	10.7	11.9
-4	1/4	11.5	13.0	15.3	16.9
-5	5/16	15.3	16.4	20.3	22.6
-6	3/8	18.1	19.8	29.4	32.2
-8	1/2	29.9	32.8	53.7	59.3
-10	5/8	38.4	42.4	75.1	83.0
-12	3/4	48.0	53.1	96.6	106.8
-16	1	80.2	88.7	128.8	142.4

MODEL 210 & T210 SERIES SERVICE MANUAL

1-8. SAFETYING - MAINTENANCE PRACTICES

Safety Wire Inconel (Uncoated), Monel (Uncoated).

Used for general safety wiring purposes. Safety wiring is the application of wire to prevent relative movement of structural or other critical components subjected to vibration, tension, torque, etc. Monel to be used at temperatures up to 700°F (370°C) and inconel to be used at temperatures up to 1500°F (815°C). Identified by the color of the finish, monel and inconel color is natural wire color.

Copper, is cadmium plated and dyed yellow in accordance with FED-STD 595.

This wire will be used for shear and seal wiring applications. Shear applications are those where it is necessary to purposely break or shear the wire to permit operation or actuation of emergency devices. Seal applications are those where the wire is used with a lead seal to prevent tampering or use of a device without indication. Identified by the color of the finish, copper wire is dyed yellow.

Aluminum Alloy (Alclad 5056), is anodized and dyed blue in accordance with FED-STD 595.

This wire will be used exclusively for safety wiring magnesium parts.

NOTE

Surface treatments which obscure visual identification of safety wire is prohibited.

Inconel or monel, wire can be substituted for same diameter and length of carbon steel or corrosion resistant wire.

Wires are visually identifiable by their colors: natural for inconel and monel, yellow for copper, and blue for aluminum.

Cotter Pin.

The selection of material shall be in accordance with temperature, atmosphere and service limitations.

Safety Wire

The size of the safety wire shall be in accordance with the requirements of Table 1-6.

0.032 inch diameter safety wire is for general purpose use; however, 0.020 inch diameter safety wire may be used on parts having a nominal hole diameter of less than 0.045 inch, on parts having a nominal hole diameter between 0.045 and 0.062 inch with spacing between parts of less than two inches, or on closely spaced screws and bolts of 0.25 inch diameter and smaller.

0.020 inch diameter copper wire shall be used for shear and seal wire applications.

When employing the single wire method of locking, the largest nominal size wire for the applicable material or part in which the hole will accommodate shall be used.

Safety Wire Installation (Refer to Figure 1-6).

CAUTION

SCREWS IN CLOSELY SPACED GEOMETRIC PATTERNS WHICH SECURE HYDRAULIC OR AIR SEALS, HOLD HYDRAULIC PRESSURE, OR USED IN CRITICAL AREAS SHOULD USE THE DOUBLE TWIST METHOD OF SAFETY WIRING.

Single wire method of safety wiring shall use the largest nominal size wire listed in Table 1-6, which will fit the hole.

The double twist method of safety wiring shall be used as the common method of safety wiring. It is really one wire twisted on itself several times. The single wire method of safety wiring may be used in a closely spaced, closed geometrical pattern (triangle, square, circle, etc.), on parts in electrical systems, and in places that would make the single wire method more advisable. Closely spaced shall be considered a maximum of two inches between centers.


Use single wire method for shear and seal wiring application. Make sure the wire is installed so that it can be easily broken when required in an emergency situation. For securing emergency devices where it is necessary to break the wire quickly, use copper only.

Safety wiring by the double twist method shall be done as follows:

One end of the safety wire shall be inserted through one set of safety wire holes in the bolt head. The other end of the safety wire shall preferably be looped firmly around the head to the next set of safety wire holes in the same unit and inserted through this set of safety wire holes. The "other end" may go over the head when the clearances around the head are obstructed by adjacent parts.

The strands, while taut, shall be twisted until the twisted part is just short of the nearest safety wire hole in the next unit. The twisted portion shall be within 1/8 inch of the holes in each unit. The actual number of twists will depend upon the wire diameter, with smaller diameters being able to have more twists than larger diameters. The twisting shall keep the wire taut without over stressing or allowing it to become nicked, kinked or mutilated. Abrasions from commercially available twist pliers shall be acceptable.


MODEL 210 & T210 SERIES SERVICE MANUAL




STEP 1. INSERT WIRE THROUGH BOLT A AND BEND AROUND BOLT (IF NECESSARY, BEND WIRE ACROSS BOLT HEAD). TWIST WIRES CLOCKWISE UNTIL THEY REACH BOLT B.

STEP 2. INSERT ONE END OF WIRE THROUGH BOLT B. BEND OTHER END AROUND BOLT (IF NECESSARY, BEND WIRE ACROSS HEAD OF BOLT). TWIST WIRES COUNTERCLOCKWISE 1/2 INCH OR SIX TWISTS. CLIP ENDS. BEND PIGTAIL BACK AGAINST PART.

NOTE: RIGHT THREADED PARTS SHOWN: REVERSE DIRECTIONS FOR LEFT PARTS.



MULTIPLE FASTENER APPLICATION DOUBLE TWIST - MULTIPLE HOLE METHOD.




DOUBLE-TWIST SAFETYING SINGLE HOLE METHOD


5598C2001
5599C2001
6598C1029

Lockwire Safetying
Figure 1-6, Sheet 1


MODEL 210 & T210 SERIES SERVICE MANUAL




BOLTS IN CLOSELY SPACED, CLOSED GEOMETRICAL PATTERN, SINGLE WIRE METHOD



EXTERNAL SNAP RING SINGLE-WIRE METHOD



SINGLE FASTENER APPLICATION DOUBLE-TWIST METHOD



SMALL SCREWS IN CLOSELY SPACED, CLOSED GEOMETRICAL PATTERN, SINGLE WIRE METHOD



NOTE: RIGHT THREADED PARTS SHOWN. REVERSE DIRECTION FOR LEFT THREADS



Lockwire Safetying
Figure 1-6, Sheet 2

5598C1003
5598C1024
5598C1024
5598C1024

MODEL 210 & T210 SERIES SERVICE MANUAL



**Lockwire Safetying
Figure 1-6, Sheet 3**

5598C1001
5598C1001

MODEL 210 & T210 SERIES SERVICE MANUAL

Table 1-6. Safety Wire

MATERIAL	SIZE AND NUMBER (MS20995-XXX)								
	0.015	0.020	0.032	0.040	0.041	0.047	0.051	0.091	
Ni-Cu Alloy (Monel)	—	—	NC20	NC32	NC40	—	—	NC51	NC91
Ni-Cr-Fe Alloy (Inconel)	—	—	N20	N32	N40	—	—	N51	N91
Carbon Steel	—	—	F20	F32	—	F41	F47	—	F91
Corrosion Resistant Steel	—	C15	C20	C32	—	C41	C47	—	C91
Aluminum Alloy (Blue)	—	—	AB20	AB32	—	AB41	AB47	—	AB91
Copper (Yellow)	—	CY15	CY20	—	—	—	—	—	—

The wire shall be twisted to form a pigtail of 3 to 5 twists after wiring the last unit. The excess wire shall be cut off. The pigtail shall be bent toward the part to prevent it from becoming a snag. Safety wiring multiple groups by the double twist double hole method shall be the same as the previous double twist single hole method except the twist direction between subsequent fasteners may be clockwise or counterclockwise.

Spacing

When safety wiring widely spaced multiple groups by the double twist method, three units shall be the maximum number in a series.

When safety wiring closely spaced multiple groups, the number of units that can be safety wired by a twenty four inch length of wire shall be the maximum number in a series.

Widely spaced multiple groups shall mean those in which the fastenings are from four to six inches apart. Safety wiring shall not be used to secure fasteners or fittings which are spaced more than six inches apart, unless tie points are provided on adjacent parts to shorten the span of the safety wire to less than six inches.

Tension

Parts shall be safety wired in such a manner that the safety wire shall be put in tension when the part tends to loosen. The safety wire should always be installed and twisted so that the loop around the head stays down and does not tend to come up over the bolt head and leave a slack loop.

NOTE

This does not necessarily apply to castellated nuts when the slot is close to the top of the nut, the wire will be more secure if it is made to pass along the side of the stud.

Care shall be exercised when installing safety wire to ensure that it is tight but not over stressed.

Usage

A pigtail of 0.25 to 0.50 inch (3 to 5 twists) shall be made at the end of the wiring. This pigtail shall be bent back or under to prevent it from becoming a snag.

Safety wire shall be new upon each application.

When castellated nuts are to be secured with safety wire, tighten the nut to the low side of the selected torque range, unless otherwise specified, and if necessary, continue tightening until a slot aligns with the hole.

In blind tapped hole applications of bolts or castellated nuts on studs, the safety wiring shall be as described in these instructions.

Hollow head bolts are safetied in the manner prescribed for regular bolts.

Drain plugs and pet cocks may be safetied to a bolt, nut or other part having a free lock hole in accordance with the instructions described in this text.

External snap rings may be locked, if necessary, in accordance with the general locking principles as described and illustrated. Internal snap rings shall not be safety wired.

When safety wiring is required on electrical connectors which use threaded coupling rings, or on plugs which employ screws or rings to fasten the individual parts of the plug together, they shall be safety wired with 0.020 inch diameter wire in accordance with the safety wiring principles as described and illustrated. It is preferable to safety wire all electrical connectors individually. Do not safety wire one connector to another unless it is necessary to do so.

Drilled head bolts and screws need not be safety wired if installed into self-locking nuts or installed with lock washers. Castellated nuts with cotter pins or safety wire are preferred on bolts or studs with drilled shanks but self-locking nuts are permissible within the limitations of MS33588.

MODEL 210 & T210 SERIES SERVICE MANUAL

Larger assemblies, such as hydraulic cylinder heads for which safety wiring is required but not specified, shall be safety wired as described in these instructions.

Safety wire shall not be used to secure nor shall safety wire be dependent upon fracture as the basis for operation of emergency devices such as handles, switches, guards covering handles, etc., that operate emergency mechanism such as emergency exits, fire extinguishers, emergency cabin pressure release, emergency landing gear release and the like. However, where existing structural equipment or safety of flight emergency devices require shear wire to secure equipment while not in use, but which are dependent upon shearing or breaking of the safety wire for successful emergency operation of equipment, particular care shall be exercised so that wiring under these circumstances shall not prevent emergency operations of these devices.

Cotter Pin Installation

General instruction for the selection and application of cotter pins (Refer to Figure 1-7).

Select cotter pin material in accordance with temperature, atmosphere and service limitations.

Cotter pins shall be new upon each application.

When nuts are to be secured to the fastener with cotter pins, tighten the nut to the low side (minimum) of the applicable specified or selected torque range, unless otherwise specified, and if necessary, continue tightening until the slot aligns with the hole. In no case shall the high side (maximum) torque range be exceeded.

Castellated nuts mounted on bolts may be safetied with cotter pins or safety wire. The preferred method is with the cotter pin. An alternate method where the cotter pin is mounted normal to the axis of the bolt may be used where the cotter pin in the preferred method is apt to become a snag.

In the event of more than 50 percent of the cotter pin diameter is above the nut castellation, a washer should be used under the nut or a shorter fastener should be used. A maximum of two washers may be permitted under a nut.

The largest nominal diameter cotter pin listed in MS24665, which the hole and slots will accommodate, shall be used; but in no application to a nut, bolt or screw shall the pin size be less than the sizes described in Figure 1-7.

Install the cotter pin with the head firmly in the slot of the nut with the axis of the eye at right angles to the bolt shank, and bend prongs so that the head and upper prong are firmly seated against the bolt.

In the pin applications, install the cotter pin with the axis of the eye parallel to the shank of the clevis pin or rod end. Bend the prongs around the shank of the pin or rod end.

Cadmium plated cotter pins shall not be used in applications bringing them in contact with fuel, hydraulic fluid or synthetic lubricants.

Safetying Turnbuckles

Use of Safety Wire.

Some turnbuckles are secured using safety wire. These safetying procedures are detailed and illustrated in Federal Publication AC 43-13.1A, Safety Methods For Turnbuckles.

Use of Locking Clips

General instruction for the selection and application of locking clips (Refer to Figures 1-8 and 1-9).

Prior to safetying, both threaded terminals should be screwed an equal distance into the turnbuckle barrel, and should be screwed in, at a minimum, so no more than three threads of any terminal are exposed outside the body.

After the turnbuckle has been adjusted to its locking position, with the groove on terminals and slot indicator notch on barrel aligned, insert the end of the locking clip into the terminal and barrel until the "U" curved end of the locking clip is over the hole in the center of the barrel.

- Press the locking clip into the hole to its full extent.
- The curved end of the locking clip will latch in the hole in the barrel.
- To check proper seating of locking clip, attempt to remove pressed "U" end from barrel hole with fingers only.

NOTE


Do not use a tool as the locking clip could be distorted.

Locking clips are for one time use only and should not be reused.


Both locking clips may be inserted in the same hole of the turnbuckle barrel or in opposite holes of the turnbuckle barrel.

MODEL 210 & T210 SERIES SERVICE MANUAL


TO PROVIDE CLEARANCE
PRONG MAY BE CUT HERE




CASTELLATED NUT ON BOLT
PREFERRED METHOD



CASTELLATED NUT ON BOLT
ALTERNATE METHOD



THREAD SIZE	MINIMUM PIN SIZE (INCH)
6	0.028
8	0.044
10	0.044
1/4	0.044
5/16	0.044
3/8	0.072
7/16	0.072
1/2	0.072
9/16	0.086
5/8	0.086
3/4	0.086
7/8	0.086
1	0.086
1 1/8	0.116
1 1/4	0.116
1 3/8	0.116
1 1/2	0.116




PIN APPLICATION



Cotter Pin Safetying
Figure 1-7, Sheet 1

5598C1025
5598C1025
5598C1025
5598C1025


MODEL 210 & T210 SERIES SERVICE MANUAL




55982002
6280C1004

Safetying Turnbuckle Assemblies
Figure 1-8, Sheet 1

MODEL 210 & T210 SERIES SERVICE MANUAL



TYPICAL TURNBUCKLE ASSEMBLY



METHOD OF ASSEMBLING LOCKING CLIPS, TURNBUCKLE BARREL AND TERMINALS

NOMINAL CABLE DIA.	THREAD UNF-3	LOCKING CLIP MS21256 (NOTE 1)	TURNBUCKLE BODY MS21251
1/16	No. 6-40	-1	-2S
3/32	No. 10-32	-1	-3S
		-2	-3L
		-1	-4S
1/8		-2	-4L
5/32	1/4-28	-1	-5S
		-2	-5L
		-1	-6S
3/16	5/16-24	-2	-6L
7/32		-2	-7L
1/4	3/8-24	-2	-8L
9/32	7/16-20	-3	-9L
5/16	1/2-20	-3	-10L

NOTE 1: TWO LOCKING CLIPS REQUIRED FOR EACH TURNBUCKLE.



Safelying Turnbuckle Assemblies

Figure 1-9, Sheet 1

5598C1023
5598C1023

MODEL 210 & T210 SERIES SERVICE MANUAL

1-9. CONTROL CABLE WIRE BREAKAGE AND CORROSION LIMITATIONS

Examination of Control Cables.

Control cable assemblies are subject to a variety of environmental conditions and forms of deterioration. Some deterioration, such as wire or strand breakage, is easy to recognize. Other deterioration, such as internal corrosion or cable distortion, is harder to identify. The following information will aid in detecting these cable conditions.

Broken Wire Examination (Refer to Figure 1-9).

Examine cables for broken wires by passing a cloth along length of cable. This will detect broken wires, if cloth snags on cable. Critical areas for wire breakage are those sections of cable which pass through fairleads, across rub blocks, and around pulleys. If no snags are found, then no further inspection is required. If snags are found or broken wires are suspected, then a more detailed inspection is necessary, which requires that the cable be bent in a loop to confirm broken wires. Loosen or remove cable to allow it to be bent in a loop as shown. While rotating cable, inspect bent area for broken wires.

Wire breakage criteria for cables in flap, aileron, rudder, and elevator systems are as follows:


Individual broken wires at random locations are acceptable in primary and secondary control cables when there are no more than six broken wires in any given ten-inch cable length.

Corrosion.


Carefully examine any cable for corrosion that has a broken wire in a section not in contact with wear-producing airframe components, such as pulleys, fairleads, rub blocks, etc. It may be necessary to remove and bend cable to properly inspect it for internal strand corrosion, as this condition is usually not evident on outer surface of cable. Replace cable if internal corrosion is found. If a cable has been wiped clean of its corrosion-preventive lubricant and metal-brightened, the cable shall be examined closely for corrosion.

MODEL 210 & T210 SERIES SERVICE MANUAL

BROKEN WIRE UNDETECTED BY
WIPING CLOTH ALONG CABLE



BROKEN WIRE DETECTED VISUALLY
WHEN CABLE WAS REMOVED
AND BENT



DO NOT BEND INTO LOOP SMALLER
THAN 50 CABLE DIAMETERS

NORMAL TECHNIQUE FOR
BENDING CABLE AND
CHECKING FOR BROKEN WIRES

Cable Broken Wire Examination
Figure 1-9 Sheet 1

5561C1119

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 2

GROUND HANDLING, SERVICING, CLEANING, LUBRICATION AND INSPECTION

WARNING

When performing any inspection or maintenance that requires turning on the master switch, installing a battery, or pulling the propeller through by hand, treat the propeller as if the ignition switch were ON. Do not stand nor allow anyone else to stand, within the arc of the propeller, since a loose or broken wire or a component malfunction could cause the propeller to rotate.

TABLE OF CONTENTS	Page No. Aerofiche/Manual	
GROUND HANDLING	1A21/2-2	
Towing	1A21/2-2	Nose Gear Shimmy Dampener 1B6/2-11
Hoisting	1A21/2-2	Hydraulic Brake Systems 1B6/2-11
Jacking	1A21/2-2	Landing Gear Hydraulic Retraction System 1B6/2-11
Leveling	1A21/2-2	Hydraulic Fluid Sampling and Contamination Check 1B7/2-12
Weighing	1A21/2-2	Oxygen System 1B7/2-12
Parking	1A22/2-3	Face Masks 1B7/2-12
Tie-Down	1A22/2-3	CLEANING 1B7/2-12
Flyable Storage	1A22/2-3	General Description 1B7/2-12
Returning Aircraft to Service	1A22/2-3	Upholstery and Interior 1B7/2-12
Temporary Storage	1A22/2-3	Plastic Trim 1B7/2-12
Inspection During Storage	1B1/2-6	Windshield and Windows 1B7/2-12
Returning Aircraft to Service	1B1/2-6	Aluminum Surfaces 1B7/2-12
Indefinite Storage	1B1/2-6	Painted Surfaces 1B7/2-12
Inspection During Storage	1B2/2-7	Engine and Engine Compartment 1B8/2-13
Returning Aircraft to Service	1B2/2-7	Propeller 1B9/2-14
SERVICING	1B3/2-8	Wheels 1B9/2-14
Description	1B3/2-8	LUBRICATION 1B9/2-14
Fuel Bays	1B3/2-8	General Description 1B9/2-14
Fuel Additives for Cold Weather Operation	1B3/2-8	Nose Gear Torque Links 1B9/2-14
Fuel Drains	1B4/2-9	Tachometer Drive Shaft 1B9/2-14
Engine Oil	1B4/2-9	Wheel Bearing Lubrication 1B9/2-14
Engine Induction Air Filter	1B4/2-9	Wing Flap Actuator 1B9/2-14
Vacuum System Air Filter	1B5/2-10	Rod End Bearings 1B9/2-14
Battery	1B5/2-10	INSPECTION 1B18/2-23
Tires	1B6/2-11	
Nose Gear Strut	1B6/2-11	

MODEL 210 & T210 SERIES SERVICE MANUAL

2-1. GROUND HANDLING.

2-2. TOWING. Moving the aircraft by hand is accomplished by using the landing gear struts as push points. A tow bar attached to the nose gear should be used for steering and maneuvering the aircraft. When no tow bar is available, press down at the horizontal stabilizer front spar, adjacent to the fuselage, to raise the nose wheel off the ground. With the nose wheel clear of the ground, the aircraft can be turned by pivoting it about the main wheels.

CAUTION

When towing the aircraft, never turn the nose wheel more than 35 degrees either side of center or the nose gear will be damaged. Do not push on control surfaces or outboard empennage surfaces. When pushing on the tailcone, always apply pressure at a bulkhead to avoid buckling the skin.

2-3. HOISTING. The aircraft may be hoisted with a hoist of two-ton capacity, either by using hoisting rings (optional equipment) or by using suitable slings. The front sling should be hooked to the engine lifting eye, and the aft sling should be positioned around the

fuselage at the first bulkhead forward of the leading edge of the stabilizer. If the optional hoisting rings are used, a minimum cable length of 60 inches for each cable is required to prevent bending of the eye-bolt type hoisting rings. If desired, a spreader jig may be fabricated to apply vertical force to the eye-bolts.

2-4. JACKING. Refer to figure 2-2 for jacking procedures.

CAUTION

When using the landing gear strut jack pad, flexibility of the gear strut will cause the main wheel to slide inboard as the wheel is raised, tilting the jack. The jack must then be lowered for a second jacking operation. Jacking both wheels simultaneously with landing gear strut jack pad is not recommended.

2-4A. LEVELING. Longitudinally leveling of the aircraft is accomplished by backing out the two screws on the left side of the fuselage and then placing a level across the screws. Corresponding points on either the upper or lower main door sills may be used to level the aircraft laterally.

2-4B. WEIGHING AIRCRAFT. Refer to Pilot's Operating Handbook.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

TOW BAR: PART NUMBER 0501019-1, IS AVAILABLE FROM THE CESSNA SUPPLY DIVISION.




Figure 2-1. Typical Tow Bar

2-5. **PARKING.** Parking precautions depend principally on local conditions. As a general precaution, it is wise to set the parking brake or chock the wheels, and install the control lock. In severe weather, and high wind conditions, tie down the aircraft as outlined in paragraph 2-6 if a hangar is not available.

2-6. **TIE-DOWN.** When mooring the aircraft in the open, head into the wind if possible. Secure control surfaces with the internal control lock and set brakes.

CAUTION

Do not set parking brakes when they are overheated or during cold weather when accumulated moisture may freeze them.

a. Tie ropes, cables or chains to the wing tie-down fittings located mid-wing in line with the outboard edge of the flaps. Secure the opposite ends of ropes cables or chains to ground anchors.

b. Secure a tie-down rope (no chains or cables) to upper trunnion of the nose gear, and secure opposite end of rope to ground anchor.

c. Secure the middle of a rope to the tail tie-down ring. Pull each end of rope away at a 45-degree angle and secure to ground anchors at each side of tail.

d. Secure control lock on pilot control column. If control lock is not available, tie pilot control wheel back with front seat belt.

e. These aircraft are equipped with a spring-loaded steering bungee which affords protection against normal wind gusts. However, if extremely high wind gusts are anticipated, additional locks may be installed.

2-7. **FLYABLE STORAGE.** Flyable storage is defined as a maximum of 30 days non-operational storage and/or the first 25 hours of intermittent engine operation.

NOTE

The aircraft is delivered from Cessna with a Corrosion Preventive Aircraft Engine

Oil (Military Specification MIL-C-6529, Type II). This engine oil is a blend of aviation grade straight mineral oil and a corrosion preventive compound. This engine oil should be used for the first 25 hours of engine operation. In the event it is necessary to add oil during the first 25 hours of operation use only aviation grade straight mineral oil of the correct viscosity.

During the 30 day non-operational storage or the first 25 hours of intermittent engine operation, every seventh day the propeller shall be rotated by hand without running the engine. After rotating the engine five revolutions, stop the propeller 45° to 90° from the position it was in. If the aircraft is stored outside, tie-down in accordance with paragraph 2-8. In addition, the pitot tube, static air vents, air vents, openings in the engine cowling, and other similar openings shall have protective covers installed to prevent entry of foreign material. If at the end of thirty (30) days aircraft will not be removed from storage, the engine shall be started and run. The preferred method would be to fly the aircraft for thirty (30) minutes, and up to, but not exceeding normal oil and cylinder temperatures.


CAUTION

Excessive ground operation shall be avoided.

2-8. **RETURNING AIRCRAFT TO SERVICE.** After flyable storage, returning the aircraft to service is accomplished by performing a thorough pre-flight inspection. At the end of the first 25 hours of engine operation, drain engine oil and clean oil pressure screen (or change external oil filter element). Service engine with correct grade and quantity of oil. Refer to figure 2-4 and paragraph 2-20 for correct grade of engine oil.

2-9. **TEMPORARY STORAGE.** Temporary storage is defined as aircraft in a non-operational status for a maximum of 90 days. The aircraft is constructed

MODEL 210 & T210 SERIES SERVICE MANUAL



ITEM NUMBER	TYPE AND PART NUMBER	REMARKS
①	#2-170 Basic jack #2-109 Leg Extension #2-70 Slide tube extension	Closed height: 69-1/2 inches; extended height: 92" (Insert slide tube extension into basic jack)
②	Cessna #2-168	Universal tail stand (SEE NOTE 2)
③	Block Cessna #120028-1	1 x 4 x 4 padded with 1/4" rubber Jack point (SEE NOTE 1)

- Provisions are furnished on the bottom of each wing for installation of optional 120028-1 jack points.
- Weighted adjustable stand attaches to tie-down ring.

Wing jack points are aft of the aircraft center-of-gravity. This causes the aircraft to be nose heavy when on jacks. Place additional weights (shot bags or sand bags) on the weighted tail stand to hold the tail down. In addition, the base of adjustable tail stand (2-168) is to be filled with concrete for additional weight as a safety factor.

- Items (1), (2) and (3) are available from the Cessna Supply Division.

Figure 2-2. Jacking Details (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

JACKING AIRCRAFT

1. Lower the aircraft tail so that wing jack and stands can be placed at wing jack points.
2. Raise aircraft tail and attach tail stand to tail tie-down ring. BE SURE the tail stand weighs enough to keep the tail down under all conditions and that it is strong enough to support any weight that may be placed upon it.
3. Raise jacks evenly until desired height is reached. When jacking the aircraft, the main landing gear wheels must be a minimum of 16" above shop floor for landing gear retraction.
4. The jack point on the bottom of the step may be used to raise only one main wheel. Do not use brake casting as a jack point.
5. The nose may be raised by weighting down the tail. Place weight on each side of stabilizer, next to fuselage.
6. Whenever the landing gear is to be operated in the shop, use the wing jack and tail jack points to raise the aircraft.
7. The aircraft may be hoisted as outlined in paragraph 2-3.

REMOVING AIRCRAFT FROM JACKS

1. Place landing gear control handle in gear down position.
2. Operate ground hydraulic power source or aircraft emergency hydraulic hand pump until landing gear is down and locked and the green indicator light is observed.
3. Disconnect ground hydraulic power source and/or stow emergency hydraulic hand pump handle.
4. Ascertain that green (DOWN) light is illuminated; then place master switch in OFF position.
5. Lower jacks evenly until aircraft rests on the landing gear and remove wing jacks and tail stand.
6. Compress nose landing gear shock strut to static position.

SHOP NOTES:

Figure 2-2. Jacking Details (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

of corrosion-resistant alclad aluminum, which will last indefinitely under normal conditions if kept clean. However, these alloys are subject to oxidation. The first indication of corrosion on unpainted surfaces is in the form of white deposits or spots. On painted surfaces, the paint is discolored or blistered. Storage in a dry hangar is essential to good preservation and should be procured, if possible. Varying conditions will alter the measures of preservation, but under normal conditions in a dry hangar, and for storage periods not to exceed 90 days, the following methods of treatment are suggested.

- a. Fill fuel bays with correct grade of gasoline.
- b. Clean and wax aircraft thoroughly.
- c. Clean any oil or grease from tires, and coat tires with a tire preservative. Cover tires to protect against grease or oil.
- d. Either block up fuselage to relieve pressure on tires or rotate wheels every 30 days to prevent flat spotting the tires.
- e. Lubricate all airframe items and seal or cover all openings which could allow moisture and/or dust to enter.

NOTE

The aircraft battery serial number is recorded in the aircraft equipment list. To assure accurate warranty records, the battery should be reinstalled in the same aircraft from which it was removed. If the battery is returned to service in a different aircraft, appropriate record changes must be made and notification sent to the Cessna Claims Department.

- f. Remove battery and store in a cool, dry place; service battery periodically and charge as required.

NOTE

An engine treated in accordance with the following may be considered being protected against normal atmospheric corrosion for a period not to exceed 90 days.

- g. Disconnect spark plug leads and remove upper and lower spark plugs from each cylinder.

NOTE

The preservative oil must be Lubricating Oil-Contact and Volatile, Corrosion Inhibited, MIL-L-46002, Grade 1, or equivalent.

- h. Using a portable pressure sprayer, spray preservative oil through the upper spark plug hole of each cylinder with the piston in a down position. Rotate crankshaft as each pair of cylinders is sprayed.
 - i. After completing step "h," rotate crankshaft so that no piston is at a top position.
 - j. Again, spray each cylinder without moving the crankshaft, to thoroughly cover all interior surfaces of the cylinder above the piston.
 - k. Install spark plugs and connect spark plug leads.

- l. Apply preservative oil to the engine interior by spraying approximately two ounces of the preservative oil through the oil filler tube.

m. Seal all engine openings exposed to the atmosphere, using suitable plugs or non-hygroscopic tape. Attach a red streamer at each point that a plug or tape is installed.

n. If the aircraft is to be stored outside, perform the procedures outlined in paragraph 2-6. In addition, the pitot tube, static source vents, air vents, openings in the engine cowling, and other similar openings should have protective covers installed to prevent entry of foreign material.

o. Attach a warning placard to the propeller to the effect that the propeller shall not be moved while the engine is in storage.

2-10. INSPECTION DURING STORAGE.

- a. Inspect airframe for corrosion at least once a month. Remove dust collections as frequently as possible. Clean and wax aircraft as required.
- b. Inspect the interior of at least one cylinder through the spark plug hole for corrosion at least once each month.

NOTE

Do not move crankshaft when inspecting interior of cylinder for corrosion.

- c. If at the end of the 90 day period, the aircraft is to be continued in non-operational storage, repeat the procedural steps "g" thru "o" of paragraph 2-9.

2-11. RETURNING AIRCRAFT TO SERVICE. After temporary storage, use the following procedure to return the aircraft to service.

- a. Remove aircraft from blocks. Check tires for proper inflation.
- b. Check and install battery.
- c. Check that oil sump has proper grade and quantity of engine oil.
- d. Service induction air filter and remove warning placard from propeller.
- e. Remove materials used to cover openings.
- f. Remove, clean and gap spark plugs.
- g. While spark plugs are removed, rotate propeller several revolutions to clear excess rust preventive oil from cylinders.
- h. Install spark plugs and torque to values listed in Section 12 or 12A of this manual.
 - i. Check fuel strainer. Remove and clean filter screen, if necessary. Check fuel bays and fuel lines for moisture and sediment. Drain enough fuel to eliminate moisture and sediment.
 - j. Perform a thorough pre-flight inspection, then start and warm-up engine.

2-12. INDEFINITE STORAGE. Indefinite storage is defined as aircraft in a non-operational status for an indefinite period of time. Engines treated in accordance with the following may be considered protected against normal atmospheric corrosion, provided the procedures outlined in paragraph 2-13 are performed at the intervals specified.

MODEL 210 & T210 SERIES SERVICE MANUAL

- a. Operate engine until oil temperature reaches normal operating range. Drain engine oil sump and reinstall & safety drain plug.
- b. Fill oil sump to normal operating capacity with corrosion preventive mixture which has been thoroughly mixed.

NOTE

Corrosion preventive mixture consists of one part compound MIL-C-6529, Type I, mixed with three parts new lubricating oil of the grade recommended for service.

- c. Immediately after filling the oil sump with corrosion preventive mixture, fly the aircraft for a period of time not to exceed a maximum of 30 minutes.

d. With engine operating at 1200 to 1500 rpm and induction air filter removed, spray corrosion preventive mixture into induction airbox, at the rate of one-half gallon per minute, until heavy smoke comes from exhaust stack, then increase the spray until the engine is stopped.

CAUTION

Injecting corrosion-preventive mixture too fast can cause a hydrostatic lock.

- e. Do not rotate propeller after completing step "d."
- f. Remove all spark plugs and spray corrosion-preventive mixture, which has been pre-heated (221° to 250° F.) into all spark plug holes to thoroughly cover interior surfaces of cylinders.

NOTE

To thoroughly cover all surfaces of the cylinder interior, move the nozzle of the spray gun from the top to the bottom of the cylinder. If by accident the propeller is rotated following this spraying, respray the cylinders to insure an unbroken coverage on all surfaces.

- g. Install lower spark plugs or install solid plugs, and install dehydrator plugs in upper spark plug holes. Be sure that dehydrator plugs are blue in color when installed.
- h. Cover spark plug lead terminals with shipping plugs (AN4060-1) or other suitable covers.
- i. With throttle in full open position, place a bag of desiccant in the induction air intake and seal opening with moisture resistant paper and tape.
- j. Place a bag of desiccant in the exhaust tail-pipe(s) and seal openings with moisture resistant tape.
- k. Seal cold air inlet to the heater muff with moisture resistant tape.
- l. Seal engine breather by inserting a protex plug in the breather hose and clamping in place.
- m. Seal all other engine openings exposed to atmosphere using suitable plugs or non-hygroscopic tape.

NOTE

Attach a red streamer to each place plugs or tape is installed. Either attach red streamers outside of the sealed area with tape or to the inside of the sealed area with safety wire to prevent wicking of moisture into the sealed area.

- n. Drain corrosion-preventive mixture from engine sump and reinstall drain plug.

NOTE

The corrosion-preventive mixture is harmful to paint and should be wiped from painted surfaces immediately.

- o. Attach a warning placard on the throttle control knob, to the effect that the engine contains no lubricating oil. Placard the propeller to the effect that it should not be moved while the engine is in storage.
- p. Prepare airframe for storage as outlined in paragraph 2-9 thru step "f."

NOTE

As an alternate method of indefinite storage, the aircraft may be serviced in accordance with paragraph 2-9 providing the aircraft is run up at maximum intervals of 90 days and then reserviced per paragraph 2-9.

2-13. INSPECTION DURING STORAGE. Aircraft in an indefinite storage shall be inspected as follows:

- a. Inspect cylinder protex plugs each 7 days.
- b. Change protex plugs if their color indicates an unsafe condition.
- c. If the dehydrator plugs have changed color in one half of the cylinders, all desiccant material in the engine shall be replaced with new material.
- d. Every 6 months respray the cylinder interiors with corrosion-preventive mixture and replace all desiccant and protex plugs.

NOTE

Before spraying, inspect the interior of one cylinder for corrosion through the spark plug hole and remove at least one rocker box cover and inspect the valve mechanism.

2-14. RETURNING AIRCRAFT TO SERVICE.

- After indefinite storage, use the following procedure to return the aircraft to service.
- a. Remove aircraft from blocks and check tires for correct inflation. Check for correct nose gear strut inflation.
 - b. Check battery and install.
 - c. Remove all materials used to seal and cover openings.
 - d. Remove warning placards posted at throttle and propeller.
 - e. Remove and clean engine oil screen, then re-install and safety. On aircraft that are equipped with an external oil filter, install new filter element.

MODEL 210 & T210 SERIES SERVICE MANUAL

- f. Remove oil sump drain plug and drain sump. Install and safety drain plug and fill engine with oil.

NOTE

The corrosion-preventive mixture will mix with the engine lubrication oil, so flushing the oil system is not necessary. Draining the oil sump will remove enough of the corrosion-preventive mixture.

- g. Service and install the induction air filter.
h. Remove dehydrator plugs and spark plugs or plugs installed in spark plug holes and rotate propeller by hand several revolutions to clear corrosion-preventive mixture from cylinders.
i. Clean, gap and install spark plugs. Torque plugs to value listed in Section 12 or 12A.
j. Check fuel strainer. Remove and clean filter screen. Check fuel tanks and fuel lines for moisture and sediment, and drain enough fuel to eliminate.
k. Perform a thorough pre-flight inspection, then start and warm-up engine.
l. Thoroughly clean aircraft and flight test aircraft.

2-15. DELETED.

2-16. SERVICING.

2-17. DESCRIPTION. Servicing requirements are shown in figure 2-4. The following paragraphs supplement this figure by adding details not included in the figure.

2-18. FUEL BAYS. An area of each wing is sealed to form an integral fuel bay. Recommended fuel grades are listed in figure 2-4. Fuel bays should be filled immediately after flight to lessen condensation in bays and lines.

NOTE

Beginning with Serial 21064536, before refueling or when the aircraft is parked on a slope, place the fuel selector handle in the LEFT ON or RIGHT ON position, whichever corresponds to the low wing. This will minimize crossfeeding from the fuller bay and reduce fuel seepage from the wing vents.

2-18A. USE OF FUEL ADDITIVES FOR COLD WEATHER OPERATION. Strict adherence to recommended preflight draining instructions will eliminate any free water accumulations from the tank sumps. While small amounts of water may still remain in solution in the gasoline, it will normally be consumed and go unnoticed in the operation of the engine.

One exception to this can be encountered when operating under the combined effect of: 1) use of certain fuels, with 2) high humidity conditions on the ground 3) followed by flight at high altitude and low temperature. Under these unusual conditions small amounts of water in solution can precipitate from the fuel stream and freeze in sufficient quantities to induce partial icing of the engine fuel system.

While these conditions are quite rare and will not normally pose a problem to owners and operators, they do exist in certain areas of the world and consequently must be dealt with when encountered.

Therefore, to alleviate the possibility of fuel icing occurring under these unusual conditions it is permissible to add isopropyl alcohol or ethylene glycol monomethyl ether (EGME) compound to the fuel supply. See Figure 2-3 for fuel additive mixing ratio.

CAUTION

Diethylene glycol monomethyl ether (DiEGME) has NOT been approved by engine manufacturer for use with propeller single engine aircraft.

The introduction of alcohol or EGME compound into the fuel provides two distinct effects: 1) it absorbs the dissolved water from the gasoline and 2) alcohol has a freezing temperature depressant effect.

Alcohol, if used, is to be blended with the fuel in a concentration of 1% by volume. Concentrations greater than 1% are not recommended since they can be detrimental to fuel tank materials.

The manner in which the alcohol is added to the fuel is significant because alcohol is most effective when it is completely dissolved in the fuel. To insure proper mixing the following is recommended.

1. For best results the alcohol should be added during the fueling operation by pouring the alcohol directly on the fuel stream issuing from the fuel nozzle.
2. An alternate method that may be used is to premix the complete alcohol dosage with some fuel in a separate clean container (approximately 2-3 gallon capacity) and then transfer this mixture to the tank prior to the fuel operation.

Any high quality isopropyl alcohol may be used, such as: Anti-icing fluid (MIL-F-5566) or Isopropyl alcohol (Federal Specification TT-I-735a).

Ethylene glycol monomethyl ether (EGME) compound in compliance with MIL-I-27686 or Phillips PFA-55MB, if used, must be carefully mixed with the fuel in concentrations not to exceed 0.15% by volume.

CAUTION

Mixing of the EGME compound with the fuel is extremely important because concentration in excess of that recommended (0.15 percent by volume maximum) will result in detrimental affects to the fuel tanks, such as deterioration of protective primer and sealants and damage to O-rings and seals in the fuel system and engine components. Use only blending equipment that is recommended by the manufacturer to obtain proper proportioning.

Do not allow the concentrated EGME compound to come in contact with the airplane finish or fuel cell as damage can result.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 2-3. Fuel Additive Mixing Ratio Chart

Prolonged storage of the airplane will result in a water buildup in the fuel which "leeches out" the additive. An indication of this is when an excessive amount of water accumulates in the fuel tank sumps. The concentration can be checked using a differential refractometer. It is imperative that the technical manual for the differential refractometer be followed explicitly when checking the additive concentration.

2-19. FUEL DRAINS. Drains are located at various places throughout the fuel system. Refer to Section 13 for locations of the various drains in the system. Remove drain plugs and open drain valves at the intervals specified in figure 2-4. To use drain cup for sampling, place cup to valve and depress valve with rod protruding from cup. If water is found during daily inspection, open all drain valves and remove all fuel drain plugs to drain all water from the fuel system.

2-20. ENGINE OIL. Check engine lubricating oil with the dipstick five to ten minutes after the engine has been stopped. The aircraft should be in as near a level position as possible when checking the engine oil so that a true reading is obtained. Engine oil should be drained while the engine is still hot, and the nose of the aircraft should be raised slightly for more positive draining of any sludge which may have collected in the engine oil sump. Engine oil should be changed every six months, even though less than the specified hours have accumulated. Reduce these intervals for prolonged operations in dusty areas and in cold climates where sludging conditions exist, or where short flights and long idle periods are encountered, which cause sludging conditions. Always change oil and clean oil pressure screen (or change

external filter element) whenever oil on the dipstick appears dirty. Aviation grade ashless dispersant oil conforming to Continental Motors Specification MHS-24, and all revisions or supplements thereto, and conforming with current Continental Aircraft Engine Service Bulletins shall be used.

NOTE

The aircraft is delivered from Cessna with a corrosion preventive aircraft engine oil (MIL-C-6250, Type I). If oil must be added during the first 25 hours of operation, use only aviation grade straight mineral oil conforming to Specification MIL-L-6082. After the first 25 hours of operation, drain engine oil sump and clean the oil pressure screen. If an optional oil filter is installed, change filter element at this time. Refill sump with correct quantity and grade of dispersant oil conforming to Continental Motors Specification MHS-24 and with current Continental Aircraft Engine Service Bulletins. Newly overhauled engines should also be operated on aviation grade straight mineral oil conforming to Specification MIL-L-6082 until a total of 25 hours have accumulated.

MODEL 210 & T210 SERIES SERVICE MANUAL

When changing engine oil, remove and clean oil pressure screen or install a new filter element on aircraft equipped with an external oil filter. To drain oil, proceed as follows:

- a. Operate engine until oil temperature is at normal operating temperature.
- b. Remove oil drain plug from engine sump and allow oil to drain into a container.
- c. After engine oil has drained, install and safety drain plug.
- d. Remove and clean oil pressure screen or change external oil filter element.
- e. Service engine with correct quantity and viscosity of aviation grade engine oil.

NOTE

Refer to inspection charts for intervals for changing engine oil and external filter elements. Refer to figure 2-4 for correct viscosities and capacities of aviation grade engine oil.

2-21. ENGINE INDUCTION AIR FILTER. The induction air filter keeps dust and dirt from entering the induction system. The value of maintaining the air filter in a good clean condition can never be over-stressed. More engine wear is caused through the use of a dirty or damaged air filter than is generally believed. The frequency with which the filter should be removed, inspected and cleaned will be determined primarily by aircraft operating conditions. A good general rule, however, is to remove, inspect and clean the filter at least every 50 hours of engine operating time, and more frequently if warranted by operating conditions. Under extremely dusty conditions, daily servicing of the filter is recommended. To service the induction filter, proceed as follows:

- a. Remove filter from aircraft.

NOTE

Use care to prevent damage to filter element when cleaning filter with compressed air.

- b. Clean filter by blowing with compressed air (not over 100 psi) from direction opposite of normal air flow. Arrows on filter case indicate direction of normal air flow.

CAUTION

Do not use solvent or cleaning fluids to wash filter. Use only a water and household detergent solution when washing the filter.

- c. After cleaning as outlined in step "b", the filter may be washed, if necessary, in a solution of warm water and a mild household detergent. A cold water solution may be used.

NOTE

The filter assembly may be cleaned with compressed air a maximum of 30 times or it may be washed a maximum of 20

times. A new filter should be installed after using 500 hours of engine operating time or one year, whichever should occur first. However, a new filter should be installed anytime the existing filter is damaged. A damaged filter may have sharp or broken edges in the filtering panels which would allow unfiltered air to enter the induction system. Any filter that appears doubtful, shall have a new filter installed in its place.

- d. After washing, rinse filter with clear water until rinse water draining from filter is clear. Allow water to drain from filter and dry with compressed air (not over 100 psi).

NOTE

The filtering panels of the filter may become distorted when wet, but they will return to their original shape when dry.

- e. Be sure airbox is clean, and inspect filter. If filter is damaged, a new filter should be installed.
- f. Install filter at entrance to airbox with gasket on aft face of filter frame and with flow arrows on filter frame pointed in the correct direction.

2-22. VACUUM SYSTEM AIR FILTER. The vacuum system central air filter keeps dust and dirt from entering the vacuum operated instruments. Inspect filter every 200 hours for damage. Replace filter when damaged, every 500 hours of operation or whenever it becomes sufficiently clogged to cause suction gage readings to drop below 4.6 in Hg. Do not operate the vacuum system with the filter removed, or a vacuum line disconnected as particles of dust or other foreign matter may enter the system and damage the vacuum-operated instruments.

CAUTION

Excessive smoking will cause premature filter clogging.

2-23. BATTERY. Battery servicing involves adding distilled water to maintain the electrolyte even with the horizontal baffle plate or split ring at the bottom of the filler holes, checking cable connections, and neutralizing and cleaning off any spilled electrolyte or corrosion. Use bicarbonate of soda (baking soda) and clean water to neutralize electrolyte or corrosion. Follow with a thorough flushing with clean water. Do not allow bicarbonate of soda to enter battery. Brighten cable and terminal connection with a wire brush, then coat with petroleum jelly before connecting. Check the battery every 50 hours (or at least every 30 days), oftener in hot weather. Add only distilled water, not acid or "rejuvenators," to maintain electrolyte level in the battery. Inspect the battery box and clean and remove any evidence of corrosion.

MODEL 210 & T210 SERIES SERVICE MANUAL

2-24. TIRES. Maintain tire pressure at the value specified in Section 1. When checking pressure, examine tire for wear, cuts, bruises and slippage.

NOTE

Recommended tire pressure should be maintained. Especially in cold weather, remember that any drop in temperature of the air inside a tire causes a corresponding drop in pressure.

2-25. NOSE GEAR STRUT. The nose gear strut requires periodic checking to ascertain that the strut is filled with hydraulic fluid and is inflated to the correct air pressure. To fill the nose gear strut with hydraulic fluid and air, proceed as follows:

- a. Remove valve cap and release all air.
- b. Remove valve housing assembly.
- c. Compress strut completely (stops in contact with outer barrel hub).
- d. Oil level.
 1. Fluid used should comply with Specification MIL-H-5606.
 2. Fill strut to bottom of valve installation hole.
 3. Maintain oil level at bottom of valve installation hole.
- e. Fully extend strut.
- f. Replace valve housing assembly.
- g. With strut fully extended and nose wheel clear of ground, inflate strut to 90 PSI.

NOTE

The nose landing gear shock strut will normally require only a minimum amount of service. Maintain the strut extension pressure as shown in figure 1-1. Lubricate landing gear as shown in figure 2-5. Check the landing gear daily for general cleanliness, security of mounting, and for hydraulic fluid leakage. Keep machined surfaces wiped free of dirt and dust, using a clean lint-free cloth saturated with hydraulic fluid (MIL-H-5606) or kerosene. All surfaces should be wiped free of excessive hydraulic fluid.

2-26. NOSE GEAR SHIMMY DAMPENER. The shimmy dampener should be serviced at least every 100 hours. The dampener must be filled completely with hydraulic fluid, free of entrapped air with the compensating piston bottomed in the rod. Check that piston is completely bottomed as follows:

- a. Remove shimmy dampener from the aircraft.
- b. While holding the shimmy dampener in a vertical position with the filler plug pointed upward, loosen the filler plug.
- c. Allow the spring to bottom out the floating piston inside the shimmy dampener rod.
- d. When the fluid stops flowing, insert a length of stiff wire through the air bleed hole in the setscrew at the end of the piston rod until it touches the floating piston. The depth should be 3-13/16 inches.

NOTE

If the wire insertion is less than 3-13/16 inches, the floating piston is lodged in the shaft. If the wire cannot be used to free the piston, the rod assembly and piston should be replaced.

Service the shimmy dampener as follows:

- a. Remove filler plug from dampener.
- b. Move piston completely to opposite end from filler plug.
- c. Fill dampener with clean hydraulic fluid.
- d. Reinstall filler plug and safety.
- e. Wash dampener in solvent and wipe dry with a cloth.
- f. Reinstall shimmy dampener in aircraft.

NOTE

Keep shimmy dampener, especially the exposed portions of the dampener piston shaft, clean to prevent collection of dust and grit which could cut the seals in the dampener barrel. Keep machined surfaces wiped free of dirt and dust, using a clean lint-free cloth saturated with hydraulic fluid (MIL-H-5606) or kerosene. All surfaces should be wiped free of excessive hydraulic fluid.

2-27. HYDRAULIC BRAKE SYSTEMS. Check brake master cylinders and refill with hydraulic fluid as specified in the inspection charts. Bleed the brake system of entrapped air whenever there is a spongy response to the brake pedals. Refer to Section 5 for filling and bleeding the brake system.

2-28. LANDING GEAR HYDRAULIC RETRACTION SYSTEM. Draining, filling and bleeding of the landing gear hydraulic system can be accomplished by the following method.

- a. Place aircraft master switch in OFF position and place aircraft on jacks as shown in figure 2-2. Bleed pressure from system by moving landing gear selector valve to gear UP position.

CAUTION

Do not turn master switch ON while hydraulic system is open to atmosphere. The pump will automatically start, causing hydraulic fluid to spray from any open line.

- b. Drain system by removing cap from elbow on right side of power pack (behind access cover) and attaching a drain hose to the elbow. Place end of hose in a container of at least one gallon capacity and using emergency hand pump, pump fluid into container. When power pack reservoir is empty, replace cap.
- c. Fill power pack reservoir with MIL-H-5606 hydraulic fluid by inserting a funnel or filler hose in dipstick opening on top of power pack body.

MODEL 210 & T210 SERIES SERVICE MANUAL

d. Bleed system by cycling landing gear through several cycles. Refill power pack reservoir with MIL-H-5606 hydraulic fluid and remove aircraft from jacks.

2-29. HYDRAULIC FLUID SAMPLING AND CONTAMINATION CHECK. At the first 50 and first 100 hour inspection and thereafter at each 500 hour inspection or one year, whichever should occur first, a sample of fluid should be taken and examined for sediment and discoloration. This may be done as follows:

a. Place aircraft master switch in OFF position and replace aircraft on jacks as shown in figure 2-2. Bleed pressure from system by moving landing gear selector valve to gear UP position.

CAUTION

Do not turn master switch ON while hydraulic system is open to atmosphere. The pump will automatically start, causing hydraulic fluid to spray from any open line.

b. Remove cap from elbow on right side of power pack (behind access cover) and place a nonmetal container below opening.

c. Place landing gear selector valve in DOWN position and operate emergency hand pump to pump fluid into container.

d. If the drain fluid is clear and not appreciably darker in color than new fluid, continue to use the present fluid.

e. If the fluid color is doubtful, place a fluid sample in a nonmetallic container and insert a strip of polished copper in the fluid.

f. Keep copper in the fluid for six hours at a temperature of 70°F or more. A slight darkening of the copper is permissible, but there should be no pitting or etching visible up to 20X magnification. If pitting or etching is evident, drain fluid from power pack reservoir. Fill power pack with MIL-H-5606 hydraulic fluid and bleed air from system.

2-30. OXYGEN SYSTEM. Refer to Section 15.

2-31. FACE MASKS. Refer to Section 15.

2-32. CLEANING.

2-33. GENERAL DESCRIPTION. Keeping the aircraft clean is important. Besides maintaining the trim appearance of the aircraft, cleaning lessens the possibility of corrosion and makes inspection and maintenance easier.

2-34. UPHOLSTERY AND INTERIOR. Cleaning prolongs the life of upholstery fabrics and interior trim. To clean the interior, proceed as follows:

a. Empty all the ashtrays.

b. Brush out or vacuum clean the upholstery and carpeting to remove dirt.

c. Wipe leather and plastic surfaces with a damp cloth.

d. Soiled upholstery fabrics and carpet may be cleaned with a foam-type detergent, used according to the manufacturer's instructions.

e. Oily spots and stains may be cleaned with household spot removers, used sparingly. Before using any solvent, read the instructions on the container and test it on an obscure place in the fabric to be cleaned. Never saturate the fabric with a volatile solvent; it may damage the packing and backing material.

f. Scrape off sticky materials with a dull knife, then spot clean the area.

2-35. PLASTIC TRIM. The instrument panel, plastic trim and control knobs need only be wiped off with a damp cloth. Oil and grease on the control wheel and control knobs can be removed with a cloth moistened with Stoddard solvent.

2-36. WINDSHIELD AND WINDOWS. These surfaces should be cleaned carefully with plenty of fresh water and a mild detergent, using the palm of the hand to feel and dislodge any caked dirt or mud. A sponge, soft cloth, or chamois may be used, but only as a means of carrying water to the plastic. Rinse thoroughly, then dry with a clean moist chamois. Do not rub the plastic with a dry cloth as this builds up an electrostatic charge which attracts dust. Oil and grease may be removed by rubbing lightly with a soft cloth moistened with Stoddard solvent.

CAUTION

Do not use gasoline, alcohol, benzene, acetone, carbon tetrachloride, fire extinguisher fluid, de-icer fluid, lacquer thinner or glass window cleaning spray. These solvents will soften and craze the plastic.

After washing, the plastic windshield and windows should be cleaned with an aircraft windshield cleaner. Apply the cleaner with soft cloths and rub with moderate pressure. Allow the cleaner to dry, then wipe it off with soft flannel cloths. A thin, even coat of wax, polished out by hand with soft flannel cloths, will fill in minor scratches and help prevent further scratching. Do not use a canvas cover on the windshield or windows unless freezing rain or sleet is anticipated since the cover may scratch the plastic surface.

2-37. ALUMINUM SURFACES. The aluminum surfaces require a minimum of care, but should never be neglected. The aircraft may be washed with non-alkaline grease solvents to remove oil and/or grease. Household-type detergent soap powders are effective cleaners, but should be used cautiously since some of them are strongly alkaline. Many good aluminum cleaners, polishes and waxes are available from commercial suppliers of aircraft products.

2-38. PAINTED SURFACES. The painted exterior surfaces of your new Cessna have a durable, long lasting finish. Approximately 10 days are required for the paint to cure completely; in most cases, the curing period will have been completed prior to delivery of the airplane. In the event that polishing or buffing is required within the curing period, it is recommended that the work be done by someone ex-

MODEL 210 & T210 SERIES SERVICE MANUAL

perienced in handling uncured paint. Any Cessna Dealer can accomplish this work.

Generally, the painted surfaces can be kept bright by washing with water and mild soap, followed by a rinse with water and drying with cloths or a chamois. Harsh or abrasive soaps or detergents which cause corrosion or scratches should never be used. Remove stubborn oil and grease with a cloth moistened with Stoddard solvent.

To seal any minor surface chips or scratches and protect against corrosion, the airplane should be waxed regularly with a good automotive wax applied in accordance with the manufacturer's instructions. If the airplane is operated in a seacoast or other salt water environment, it must be washed and waxed more frequently to assure adequate protection. Special care should be taken to seal around rivet heads and skin laps, which are the areas most susceptible to corrosion. A heavier coating of wax on the leading edges of the wings, and tail and on the cowl nose cap and propeller spinner will help reduce the abrasion encountered in these areas. Reapplication of wax will generally be necessary after cleaning with soap solutions or after chemical de-icing operations.

2-39. ENGINE AND ENGINE COMPARTMENT. An engine and accessories wash down should be accomplished during each 100-hour inspection to remove oil, grease, salt corrosion or other residue that might conceal component defects during inspection. Also, periodic cleaning can be very effective in preventive maintenance.

Precautions should be taken when working with cleaning agents such as wearing of rubber gloves, an apron or coveralls and a face shield or goggles. Use the least toxic of available cleaning agents that will satisfactorily accomplish the work. These cleaning agents include: (1) Stoddard Solvent (Specification P-D-680 type II), (2) A water alkaline detergent cleaner (MIL-C-25769J) mixed, 1 part cleaner, 2 to 3 parts water and 8 to 12 parts Stoddard solvent or (3) A solvent base emulsion cleaner (MIL-C-4361B) mixed 1 part cleaner and 3 parts Stoddard solvent.

CAUTION

Do not use gasoline or other highly flammable substances for washdown.

Perform all cleaning operations in well ventilated work areas and ensure that adequate firefighting and safety equipment is available. Do not smoke or expose a flame, within 100 feet of the cleaning area. Compressed air, used for cleaning agent, application or drying, should be regulated to the lowest practical pressure. Use of a stiff bristle brush rather than a steel brush is recommended if cleaning agents do not remove excess grease and grime during spraying.

A recommended procedure for cleaning an engine and accessories is as follows:

CAUTION

Do not attempt to wash an engine which is still hot or running. Allow the engine to cool before cleaning.

- a. Remove engine cowling in accordance with Paragraph 12-3.
- b. Carefully cover the coupling area between the vacuum pump and the engine drive shaft so that no cleaning solvent can reach the coupling or seal.
- c. Cover the open end of the vacuum discharge tube.
- d. Cover the vacuum relief valve filter, if installed in the engine compartment.
- e. Use fresh water for wash down when the engine is contaminated with salt or corrosive chemicals. A cleaning agent such as described previously may then be used to remove oil and grime.

CAUTION

Care should be exercised to not direct cleaning agents or water streams at openings on the starter, magnetos, alternator, vacuum pump or turbocharger relief valve.

- f. Thoroughly rinse with clean warm water to remove all traces of cleaning agents.

CAUTION

Cleaning agents should never be left on engine components for an extended period of time. Failure to remove them may cause damage to components, such as neoprene seals and silicone fire sleeves, and could cause additional corrosion.

- g. Completely dry engine and accessories using clean, dry compressed air.
- h. Remove the cover over the coupling area.
- i. Remove the cover from the vacuum discharge tube.
- j. Remove the cover from the vacuum relief valve filter, if installed.
- k. If desired, engine cowling may be washed with the same cleaning agents, then rinsed thoroughly and wiped dry. After cleaning engine, relubricate all control arms and moving parts as required.
- l. Reinstall engine cowling.

WARNING

For maximum safety, check that the magneto switches are OFF, the throttle is closed, the mixture control is in the idle cut-off position, and the airplane is secured before rotating the propeller by hand. Do not stand within the arc of the propeller blades while turning the propeller.

- m. Before starting engine rotate the propeller by hand no less than four complete revolutions.

MODEL 210 & T210 SERIES SERVICE MANUAL

2-40. **PROPELLER.** The propeller should be wiped occasionally with an oily cloth to remove grass and bug stains. In salt water areas, this will assist in corrosion-proofing the propeller.

2-41. **WHEELS.** The wheels should be washed periodically and examined for corrosion, chipped paint, and cracks or dents in the wheel halves or in the flanges or hubs. If defects are found remove and repair in accordance with Section 5. Discard cracked wheel halves, flanges or hubs and install new parts.

2-42. **LUBRICATION.**

2-43. **GENERAL DESCRIPTION.** Lubrication requirements are outlined in figure 2-5. Before adding lubricant to a fitting, wipe the fitting free of dirt. Lubricate until grease appears around part being lubricated and wipe excess grease from parts. The following paragraphs supplement figure 2-5 by adding details not shown in the figure.

2-44. **NOSE GEAR TORQUE LINKS.** Lubricate torque links every 50 hours. When operating in dusty conditions, more frequent lubrication is recommended.

2-45. **TACHOMETER DRIVE SHAFT.** Refer to Section 16

2-46. **WHEEL BEARING LUBRICATION.** Clean and repack wheel bearings at the first 100-hour inspection and at each 500-hour inspection thereafter. If more than the usual number of take-off and landings are made, extensive taxiing is required or the aircraft is operated in dusty areas

or under seacoast conditions, clean and lubricate wheel bearings at each 100-hour inspection.

2-47. **WING FLAP ACTUATOR.** Clean and lubricate wing flap actuator jack screw each 100 hours as follows:

- a. Expose jack screw by operating flaps to full-down position.
- b. Clean jack screw threads with solvent rag and dry with compressed air.


NOTE

It is not necessary to remove actuator from aircraft to clean or lubricate threads.

- c. With oil can, apply light coat of No. 10 weight, non-detergent oil to threads of jack screw.

2-48. **ROD END BEARINGS.** Periodic inspection and lubrication is required to prevent corrosion of the bearing in the rod end. At each 100-hour inspection, disconnect the control rods at the aileron and inspect each rod end for corrosion. If no corrosion is found, wipe the surface of the rod end balls with general purpose oil and rotate ball freely to distribute the oil over its entire surface and connect the control rods to the aileron. If corrosion is detected during inspection, install new rod ends.

MODEL 210 & T210 SERIES SERVICE MANUAL



(REFER TO SHEET 2 FOR NOTES)

Figure 2-4. Servicing (Sheet 1 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL

HYDRAULIC FLUID:
SPEC. NO. MIL-H-5606

OXYGEN:
SPEC. NO. MIL-O-27210

SPECIFIED AVIATION GRADE FUELS:

WARNING


ONLY AVIATION GRADE FUELS ARE APPROVED FOR USE.

ENGINE MODEL	APPROVED FUEL GRADES	NOTE
Continental IO-520-L & TSIO-520-R	100LL (blue)	1
	100 (green) (formerly 100/130)	1

NOTE

- Compliance with Continental Aircraft Engine Service Bulletin M82-8 and all supplements or revisions thereto, must be accomplished.

SPECIFIED AVIATION GRADE OIL:



Aviation grade ashless dispersant oil, conforming to Continental Motors Specification MHS-24, and all revisions or supplements thereto, must be used except as noted in paragraph 2-20, herein. Refer to Continental Aircraft Engine Service Bulletin M82-8, and any superseding bulletins, revisions or supplements thereto, for further recommendations.

Oil capacities for the aircraft are given in the following chart. To minimize loss of oil through the breather, fill to specified oil level on dipstick for normal operation (flight of less than three hours duration). For extended flight, fill to FULL mark on dipstick. Do not operate with less than MINIMUM FOR FLIGHT quantities listed. If an external oil filter is installed, one additional quart of oil is required when filter is changed.

CAPACITY (TOTAL)	CAPACITY (TOTAL WITH FILTER)	NORMAL OPERATION	MINIMUM FOR FLIGHT
10	11	8	7

Figure 2-4. Servicing (Sheet 2 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL



DAILY

- 1 **FUEL BAYS:**
Service after each flight. Keep full to retard condensation. Refer to paragraph 2-18 for details.
- 6 **FUEL BAY SUMP DRAINS:**
Drain off any water and sediment before first flight of the day.
- 19 **FUEL STRAINER:**
Drain off any water and sediment before first flight of the day.
- 15 **OIL DIPSTICK:**
Check on preflight. Add oil as necessary. Refer to paragraph 2-20 for details. Check that filler cap is tight and oil filler is secure.
- 8 **PITOT AND STATIC PORTS:**
Check for obstructions before first flight of the day.
- 7 **OXYGEN CYLINDERS:**
Check for anticipated requirements before each flight. Refer to Section 15 for details.
- 17 **NOSE GEAR SHOCK STRUT:**
Check on preflight. Check inner barrel showing below outer barrel to be 1.00-2.00 (approximately 1.20) inches after bouncing. Deviation from these dimensions is cause to check and service strut per paragraph 2-25.



25 HOURS

- 16 **ENGINE OIL SYSTEM: FIRST 25 HOURS**
Drain engine oil and change external oil filter (if equipped). Refill engine with ashless dispersant oil.
- 21 **HYDRAULIC POWER PACK**
Check every 25 hours and after a gear extension which uses the hydraulic hand pump.




50 HOURS


- 4 **INDUCTION AIR FILTER:**
Clean filter per paragraph 2-21. Replace as required.
- 13 **BATTERY:**
Check electrolyte level and clean battery compartment each 50 hours or each 30 days.
- 16 **ENGINE OIL SYSTEM:**
Change oil each 50 hours if engine is NOT equipped with external filter; if equipped with external oil filter, change oil and filter each 100 hours or every 6 months, whichever occurs first.
- 18 **SHIMMY DAMPENER:**
Check fluid level and refill as required in accordance with paragraph 2-26.
- 10 **TIRES:**
Maintain correct tire inflation as listed in Section 1. Refer to paragraph 2-24 for details.
- 17 **NOSE GEAR SHOCK STRUT:**
Keep strut filled and inflated to correct pressure. Refer to paragraph 2-25 for details.
- 2 **HYDRAULIC FLUID RESERVOIR:**
At first 50 and first 100 hours, thereafter at each 500 hours or one year, whichever comes first, a sample of hydraulic fluid should be examined for sediment and discoloration as outlined in paragraph 2-29.

Figure 2-4. Servicing (Sheet 3 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL



- 2 **HYDRAULIC FLUID RESERVOIR:**
At first 50 and first 100 hours, thereafter at each 500 hours or one year, whichever comes first, a sample of hydraulic fluid should be examined for sediment and discoloration as outlined in paragraph 2-29.
- 3 **FUEL/AIR CONTROL UNIT SCREEN:**
Remove and clean screen.
- 5 **VACUUM RELIEF VALVE FILTER:**
Replace each 100 hours.
- 16 **ENGINE OIL SYSTEM:**
Change oil and filter each 100 hours or every 6 months, whichever occurs first.
- 19 **FUEL STRAINER:**
Disassemble and clean strainer bowl and screen.



- 11 **VACUUM SYSTEM CENTRAL AIR FILTER:**
Inspect filter element for damage. Refer to paragraph 2-22.
- 6 **FUEL BAY SUMP DRAINS:**
Drain off any water or sediment.
- 9 **FUEL RESERVOIR DRAIN:**
Open drain valve(s) and drain off water and sediment.
- 12 **BRAKE MASTER CYLINDERS:**
Check fluid level and fill as required with hydraulic fluid.



- 11 **VACUUM SYSTEM CENTRAL AIR FILTER:**
Replace every 500 hours. Refer to paragraph 2-22.
- 2 **HYDRAULIC FLUID RESERVOIR:**
At first 50 and first 100 hours, thereafter at each 500 hours or one year, whichever comes first, a sample of hydraulic fluid should be examined for sediment and discoloration as outlined in paragraph 2-29.
- 4 **INDUCTION AIR FILTER:**
Replace every 500 hours or annually. Refer to paragraph 2-21.




- 14 **GROUND SERVICE RECEPTACLE**
Connect to 24-volt, D.C. negative-ground power unit for cold weather starting and lengthy ground maintenance of the aircraft's electrical equipment with the exception of electronic equipment. Master switch should be turned on before connecting a generator-type or battery-type external power source. Refer to Section 17.

Figure 2-4. Servicing (Sheet 4 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL

FREQUENCY (HOURS)



METHOD OF APPLICATION



WHERE NO INTERVAL IS SPECIFIED, LUBRICATE AS REQUIRED AND WHEN ASSEMBLED OR INSTALLED.

NOTE

The military specifications listed below are not mandatory, but are intended as guides in choosing satisfactory materials. Products of most reputable manufacturers meet or exceed these specifications.

LUBRICANTS

PG	SS-G-659	POWDERED GRAPHITE
GR	MIL-G-81322A	GENERAL PURPOSE GREASE
GH	MIL-G-23827A	AIRCRAFT AND INSTRUMENT GREASE
GL	MIL-G-21164C	HIGH AND LOW TEMPERATURE GREASE
OG	MIL-L-7870A	GENERAL PURPOSE OIL
PL	VV-P-236	PETROLATUM
GT		NO. 10WT NON-DETERGENT OIL
OL	VV-L-800A	LIGHT OIL





Figure 2-5. Lubrication (Sheet 1 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL

● DO NOT OIL IF OPERATING IN EXTREMELY DUSTY CONDITIONS.

ELECTRIC FLAP DRIVE MECHANISM




ALSO REFER TO PARAGRAPH 2-48



SCREW JACK THREADS


AILERON BELLCRANKS



ROD ENDS

NEEDLE BEARINGS

NEEDLE BEARING ROLLERS



CONTROL COLUMN

THRUST BEARINGS




NEEDLE BEARINGS



NEEDLE BEARING



FLAP BELLCRANKS AND DRIVE PULLEYS




ROD ENDS

NEEDLE BEARINGS



RUDDER BARS AND PEDALS




OILITE BEARINGS (RUDDER BAR ENDS)

ALL LINKAGE POINT PIVOTS




BEARING BLOCK HALVES

PARKING BRAKE HANDLE SHAFT



GEAR WARNING AND FUEL PUMP SWITCH CONTROL



ENGINE CONTROLS

Figure 2-5. Lubrication (Sheet 2 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 2-5. Lubrication (Sheet 3 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL

SPRAY BOTH SIDES OF SHADED AREAS WITH ELECTROFILM LUBRI-BOND "A" WHICH IS AVAILABLE IN AEROSOL SPRAY CANS, OR AN EQUIVALENT LUBRICANT. TORQUE ATTACHING BOLT TO 10-20 LB-IN.



NOTES

Sealed bearings require no lubrication.

McCauley propellers are lubricated at overhaul and require no other lubrication.

Do not lubricate roller chains or cables except under seacoast conditions. Wipe with a clean, dry cloth.

Lubricate unsealed pulley bearings, Oilite bearings, pivot and hinge points, and any other friction point obviously needing lubrication, with general purpose oil every 1000 hours or oftener, if required.

Paraffin wax rubbed on seat rails will ease sliding the seats fore and aft.

Lubricate door latching mechanism with MIL-S-8660 silicone compound or equivalent lubricant, applied sparingly to friction points, every 1000 hours or oftener if binding occurs. No lubrication is recommended for the rotary clutch.

Apply DOOR-EZE lubricant to latch bolt.

Figure 2-5. Lubrication (Sheet 4 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL

I INSPECTION REQUIREMENTS.

As required by Federal Aviation Regulations, all civil aircraft of U.S. registry must undergo a COMPLETE INSPECTION (ANNUAL) each twelve calendar months. In addition to the required ANNUAL inspection, aircraft operated commercially (for hire) must also have a COMPLETE AIRCRAFT INSPECTION every 100 hours of operation.

In lieu of the above requirements, an aircraft may be inspected in accordance with a progressive inspection schedule, which allows the work load to be divided into smaller operations that can be accomplished in shorter time periods.

Therefore, the Cessna Aircraft Company recommends PROGRESSIVE CARE for aircraft that are being flown 200 hours or more per year, and the 100 HOUR inspection for all other aircraft.

II INSPECTION CHARTS.

The following charts show the recommended intervals at which items are to be inspected.

As shown in the charts, there are items to be checked each 50 hours, each 100 hours, each 200 hours, and also Special Inspection items which require servicing or inspection at intervals other than 50, 100 or 200 hours.

- a. When conducting an inspection at 50 hours, all items marked under EACH 50 HOURS would be inspected, serviced or otherwise accomplished as necessary to insure continuous airworthiness.
- b. At each 100 hours, the 50 hour items would be accomplished in addition to the items marked under EACH 100 HOURS as necessary to insure continuous airworthiness.
- c. An inspection conducted at 200 hour intervals would likewise include the 50 hour items and 100 hour items in addition to those at EACH 200 HOURS.
- d. The numbers appearing in the SPECIAL INSPECTION ITEMS column refer to data listed at the end of the inspection charts. These items should be checked at each inspection interval to insure that applicable servicing and inspection requirements are accomplished at the specified intervals.
- e. A COMPLETE AIRCRAFT INSPECTION includes all 50, 100 and 200 hour items plus those Special Inspection Items which are due at the time of the inspection.

III INSPECTION PROGRAM SELECTION.

AS A GUIDE FOR SELECTING THE INSPECTION PROGRAM THAT BEST SUITS THE OPERATION OF THE AIRCRAFT, THE FOLLOWING IS PROVIDED.

1. IF THE AIRCRAFT IS FLOWN LESS THAN 200 HOURS ANNUALLY.
 - a. IF FLOWN FOR HIRE

An aircraft operating in this category must have a COMPLETE AIRCRAFT INSPECTION each 100 hours and each 12 calendar months of operation. A COMPLETE AIRCRAFT INSPECTION consists of all 50, 100, 200 and Special Inspection Items shown in the inspection charts as defined in paragraph II above.

- b. IF NOT FLOWN FOR HIRE

An aircraft operating in this category must have a COMPLETE AIRCRAFT INSPECTION each 12 calendar months (ANNUAL). A COMPLETE AIRCRAFT INSPECTION consists of all 50, 100, 200 and Special Inspection Items shown in the inspection charts as defined in paragraph II above. In addition, it is recommended that between annual inspections, all items be inspected at the intervals specified in the inspection charts.

MODEL 210 & T210 SERIES SERVICE MANUAL

2. IF THE AIRCRAFT IS FLOWN MORE THAN 200 HOURS ANNUALLY.

Whether flown for hire or not, it is recommended that aircraft operating in this category be placed on the CESSNA PROGRESSIVE CARE PROGRAM. However, if not placed on Progressive Care, the inspection requirements for aircraft in this category are the same as those defined under paragraph III 1. (a) and (b).

Cessna Progressive Care may be utilized as a total concept program which insures that the inspection intervals in the inspection charts are not exceeded. Manuals and forms which are required for conducting Progressive Care inspections are available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations.

IV INSPECTION GUIDE LINES.

- (a) **MOVABLE PARTS** for: lubrication, servicing, security of attachment, binding, excessive wear, safetying, proper operation, proper adjustment, correct travel, cracked fittings, security of hinges, defective bearings, cleanliness, corrosion, deformation, sealing and tension.
- (b) **FLUID LINES AND HOSES** for: leaks, cracks, dents, kinks, chafing, proper radius, security, corrosion, deterioration, obstruction and foreign matter.
- (c) **METAL PARTS** for: security of attachment, cracks, metal distortion, broken spotwelds, corrosion, condition of paint and any other apparent damage.
- (d) **WIRING** for: security, chafing, burning, defective insulation, loose or broken terminals, heat deterioration and corroded terminals.
- (e) **BOLTS IN CRITICAL AREAS** for: correct torque in accordance with torque values given in the chart in Section 1, when installed or when visual inspection indicates the need for a torque check.

NOTE

Torque values listed in Section 1 are derived from oil-free cadmium-plated threads, and are recommended for all installation procedures contained in this book except where other values are stipulated. They are not to be used for checking tightness of installed parts during service.

- (f) **FILTERS, SCREENS & FLUIDS** for: cleanliness, contamination and/or replacement at specified intervals.
- (g) **AIRCRAFT FILE.**

Miscellaneous data, information and licenses are a part of the aircraft file. Check that the following documents are up-to-date and in accordance with current Federal Aviation Regulations. Most of the items listed are required by the United States Federal Aviation Regulations. Since the regulations of other nations may require other documents and data, owners of exported aircraft should check with their own aviation officials to determine their individual requirements.

To be displayed in the aircraft at all times:

1. Aircraft Airworthiness Certificate (FAA Form 8100-2).
2. Aircraft Registration Certificate (FAA Form 8050-3).
3. Aircraft Radio Station License, if transmitter is installed (FCC Form 556).

To be carried in the aircraft at all times:

1. Weight and Balance, and associated papers (Latest copy of the Repair and Alteration Form, FAA Form 337, if applicable).
2. Aircraft Equipment List.
3. Pilot's Operating Handbook.

To be made available upon request:

1. Aircraft Log Book and Engine Log Book.

MODEL 210 & T210 SERIES SERVICE MANUAL

(b) ENGINE RUN-UP.

Before beginning the step-by-step inspection, start, run up and shut down the engine in accordance with instructions in the Pilot's Operating Handbook. During the run-up observe the following, making note of any discrepancies or abnormalities:

1. Engine temperatures and pressures.
2. Static rpm. (Also refer to Section 12 or 12A of this Manual.)
3. Magneto drop. (Also refer to Section 12 or 12A of this Manual).
4. Engine response to changes in power.
5. Any unusual engine noises.
6. Fuel selector and/or shut-off valve; operate engine(s) on each tank (or cell) position and OFF position long enough to ensure shut-off and/or selector valve functions properly.
7. Idling speed and mixture; proper idle cut-off.
8. Alternator and ammeter.
9. Suction gage.
10. Fuel flow indicator.

After the inspection has been completed, an engine run-up should again be performed to determine that any discrepancies or abnormalities have been corrected.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

IMPORTANT

READ ALL INSPECTION REQUIREMENTS PARAGRAPHS PRIOR TO USING THESE CHARTS.

SPECIAL INSPECTION ITEM

EACH 200 HOURS

EACH 100 HOURS

EACH 50 HOURS

PROPELLER

- | | | |
|--|---|----|
| 1. Spinner | ● | |
| 2. Spinner bulkhead | ● | |
| 3. Blades | ● | |
| 4. Bolts and nuts | ● | |
| 5. Hub | ● | |
| 6. Governor and control | ● | 11 |
| 7. Anti-Ice electrical wiring | ● | |
| 8. Anti-Ice brushes, slip ring and boots | ● | |

ENGINE COMPARTMENT

Check for evidence of oil and fuel leaks, then clean entire engine and compartment, if needed, prior to inspection.

- | | | |
|---|---|---|
| 1. Engine oil screen filler cap, dipstick, drain plug and external filter element | ● | 1 |
| 2. Oil cooler | ● | |
| 3. Induction air filter | ● | 2 |
| 4. Induction airbox, air valves, doors and controls | ● | |
| 5. Cold and hot air hoses | ● | |
| 6. Engine baffles | ● | |
| 7. Cylinders, rocker box covers and push rod housings | ● | |
| 8. Crankcase, oil sump, accessory section and front crank shaft seal.. . . . | ● | |
| 9. Hoses, metal lines and fittings | ● | 3 |
| 10. Intake and exhaust systems | ● | 4 |
| 11. Ignition harness | ● | |
| 12. Spark plugs | ● | |
| 13. Compression check | ● | |
| 14. Crankcase and vacuum system breather lines | ● | |
| 15. Electrical wiring | ● | |
| 16. Vacuum pump | ● | |

MODEL 210 & T210 SERIES SERVICE MANUAL

	<u>SPECIAL INSPECTION ITEM</u>		
	<u>EACH 200 HOURS</u>	<u>EACH 100 HOURS</u>	<u>EACH 50 HOURS</u>
18. Engine controls and linkage	•		6
19. Engine shock mounts, mount structure and ground straps	•		
20. Cabin heat valves, doors and controls	•		
21. Starter, solenoid and electrical connections	•		
22. Starter brushes, brush leads and commutator	•		
23. Alternator and electrical connections	•		21
24. Alternator brushes, brush leads, commutator or slip ring	•		7
25. Voltage regulator mounting and electrical leads	•		
26. Magnetos (external) and electrical connections	•		
27. Magneto timing	•		8
28. Fuel-air (metering) control unit	•		
29. Firewall	•		
30. Fuel injection system	•		
31. Engine cowl flaps and controls	•		
32. Engine cowling	•		
33. Turbocharger	•		9
34. All oil lines to turbocharger waste gate and controller	•		22
35. Waste gate, actuator and controller	•		
36. Turbocharger pressurized vent lines to fuel pump, discharge nozzles and fuel flow gage ..	•		
37. Turbocharger mounting brackets and linkage	•		
38. Alternator support bracket for security	•		
39. Fuel manifold valves, valve covers, and fuel system	•		31
40. Fuel injection nozzles	•		34
 FUEL SYSTEM			
1. Fuel strainer, drain valve and control, fuel bay vents, caps and placards	•		23
2. Fuel strainer screen and bowl	•		27
3. Fuel injector screen	•		
4. Fuel reservoir(s)	•		
5. Drain fuel and check bay interior, attachment and outlet screens	•		29
6. Fuel bays and sump drains	•		

MODEL 210 & T210 SERIES SERVICE MANUAL

SPECIAL INSPECTION ITEM
EACH 200 HOURS
EACH 100 HOURS
EACH 50 HOURS

7. Fuel selector valve and placards	•	
8. Auxiliary fuel pump and throttle switches		•
9. Engine-driven fuel pump		•
10. Fuel quantity indicators and sensing units	•	
11. Fuel lines, check valve and vapor return line		• 24
12. Turbocharger vent system		•
13. Engine primer		•
14. Perform a fuel quantity indicating system operational test. Refer to Section 16 for detailed accomplishment instructions.		• 32

LANDING GEAR

1. Brake fluid, lines and hose, linings, discs, brake assemblies and master cylinders		• 19
2. Main gear wheels	•	
3. Wheel bearings		• 10
4. Main gear springs		•
5. Tires	•	
6. Torque link lubrication	•	
7. Parking brake system		•
8. Nose gear strut and shimmy dampener (service as required)	•	
9. Nose gear wheel	•	
10. Nose gear fork		•
11. Nose gear steering system		•
12. Parking brake and toe brakes operational test	•	

LANDING GEAR RETRACTION SYSTEM

NOTE

When performing an inspection of the landing gear retraction system, the aircraft must be placed on jacks and an external power source of at least 60 Amps should be used to prevent drain on the aircraft battery when operating the system.

1. Operate the landing gear through five fault-free cycles.		•
2. Check landing gear doors for positive clearance with any part of the landing gear during operation, and for proper fit when closed.	•	
3. Check all hydraulic system components for security, hydraulic leaks and any apparent damage to components or mounting structure.		• 19

MODEL 210 & T210 SERIES SERVICE MANUAL

SPECIAL INSPECTION ITEM
EACH 200 HOURS
EACH 100 HOURS
EACH 50 HOURS

4. Check doors, hinges, hinge pins and linkage for evidence of wear, other damage and security of attachment.	•		
5. Inspect internal wheel well structure for cracks, dents, loose rivets, bolts and nuts corrosion or other damage.	•		
6. Check electrical wiring and switches for security of connections, and switch operation. Check position indicator lights for proper operation. Check wiring for proper routing and support.	•		
7. Perform operational check and ensure proper rigging of all systems and components including downlocks, uplocks, doors, switches, actuators and power pack (observing cycle time).	•		
8. Check main gear strut to pivot attachment.	•		
9. Check condition of all springs.	•		
10. Hydraulic fluid contamination check.	•		12
11. Clean power pack self-relieving check valve filter.	•		
12. Landing gear and door manifold solenoids (mounted on top of gear and door manifolds).	•		28
13. Hydraulic Pressure check primary and thermal relief valves and pressure switch.	•		30

AIRFRAME

1. Aircraft exterior	•		
2. Aircraft structure	•		
3. Windows, windshield, doors and seals	•		
4. Seat stops, seat rails, upholstery, structure and mounting	•		26
5. Seat belts and shoulder harnesses	•		
6. Control column bearings, sprockets, pulleys, cables, chains and turnbuckles	•		
7. Control lock, control wheel and control column mechanism	•		
8. Instruments and markings	•		
9. Vacuum system air filter	•		13
10. Magnetic compass compensation	•		29
11. Instrument wiring and plumbing	•		
12. Instrument panel, shock mounts, ground straps, cover, decals and labeling	•		
13. Defrosting, heating and ventilating systems and controls	•		
14. Cabin upholstery, trim, sun visors and ashtrays	•		
15. Area beneath floor, lines, hose, wires and control cables	•		
16. Lights, switches, circuit breakers, fuses, and spare fuses	•		

MODEL 210 & T210 SERIES SERVICE MANUAL

SPECIAL INSPECTION ITEM
EACH 200 HOURS
EACH 100 HOURS
EACH 50 HOURS

17. Exterior lights	•	
18. Pitot and static systems		•
19. Stall warning unit and pitot heater		•
20. Radios, radio controls, avionics and flight instruments	•	
21. Antennas and cables		•
22. Battery, battery box and battery cables	•	
23. Battery electrolyte		• 14
24. Emergency locator transmitter	•	15
25. Oxygen system		•
26. Oxygen supply, masks and hose	•	16
27. De-ice system plumbing		•
28. De-ice system components		•
29. De-ice system boots		•
30. Vacuum Relief valve filter		5
31. Vacuum manifold check valve (If so equipped)		33
32. Inspect all fluid-carrying lines and hoses in the cabin and wing areas for leaks, damage, abrasion, and corrosion.	•	

CONTROL SYSTEMS

In addition to the items listed below, always check for correct direction of movement, correct travel and correct cable tension.

1. Cables, terminals, pulleys, pulley brackets, cable guards, turnbuckles and fairleads		•
2. Chains, terminals, sprockets and chain guards		•
3. Trim control wheels, indicators, actuator and bungee	•	25
4. Travel stops		•
5. Decals and labeling		•
6. Flap control switch, rollers, tracks, and position indicator	•	
7. Flap motor, transmission, limit switches, structure, linkage, bellcranks etc		•
8. Flap actuator jackscrew threads.		17
9. Elevator and trim tab hinges and push-pull tubes	•	
10. Elevator trim tab actuator free play inspection		• 18
11. Elevator trim tab actuator lubrication inspection		• 18
12. Rudder pedal assemblies and linkage		•
13. External skins of control surfaces and tabs	•	20
14. Ailerons, hinges, and control rods		•
15. Internal structure of control surfaces		•
16. Balance weight attachment		•

MODEL 210 & T210 SERIES SERVICE MANUAL

SPECIAL INSPECTION ITEMS

1. First 25 hours: Use mineral oil conforming with MIL-C-6529 Type II for the first 25 hours of operation or until oil consumption has stabilized, or six months, whichever occurs first. If oil consumption has not stabilized in this time, drain and replenish the oil and replace the oil filter. After the oil consumption has stabilized, change to an ashless dispersant oil. Refer to Teledyne Continental Service Information Letter SIL99-2 or latest revision for a current listing of lubricants authorized by TCM. Change oil each 25 hours if engine is NOT equipped with external oil filter. If it is equipped with an external oil filter, change oil filter element and oil at each 50 hours of operation or every six months, whichever occurs first. Refer to the latest edition of the TCM engine operator/maintenance manual for the latest oil change intervals and inspection procedures.
2. Clean filter per paragraph 2-21. Replace as required.
3. Replace engine compartment hoses per the following schedule:
 - A. Cessna-Installed Flexible Fluid-Carrying Rubber Hoses, replace every 5 years or at engine overhaul, whichever occurs first.
 - B. Cessna-Installed Flexible Fluid-Carrying Teflon Hoses, replace every 10 years or at engine overhaul, whichever occurs first.
 - C. TCM-Installed Engine Compartment Flexible Fluid-Carrying Hoses, refer to Teledyne Continental Service Bulletin SB97-6 or latest revision for hose replacement intervals.
4. General inspection every 50 hours. Refer to Section 12 for Special 100-hour inspection for IO-520 exhaust system. Refer to Section 12A for 50-hour inspection for turbocharged airplanes.
5. Change each 100 hours.
6. Each 50 hours for general condition and freedom of movement. These controls are not repairable. Replace at each engine overhaul or sooner, if required.
7. Inspect each 50 hours.
8. Internal timing and magneto-to-engine timing limits are described in detail in Section 12.
9. Remove insulation blanket or heat shield and inspect for burned area, bulges or cracks. Remove tailpipe and ducting; inspect turbine for coking, carbonization, oil deposits and impeller damage.
10. First 100 hours and each 500 hours thereafter. More often if operated under prevailing wet or dusty conditions. Refer to Section 5 of this manual for inspection procedures.
11. If leakage is evident, refer to McCauley Governor Service Manual.
12. At first 50 hours, first 100 hours, and thereafter each 500 hours or one year, whichever occurs first.
13. Inspect for damage every 200 hours. Replace every 500 hours. Refer to paragraph 2-22.
14. Check electrolyte level and clean battery compartment each 50 hours or each 30 days, whichever occurs first.
15. Refer to Section 17 of this manual.
16. Inspect masks, hose and fittings for condition, routing and support. Test, operate and check for leaks.
17. Refer to paragraph 2-47 for detailed instruction.

MODEL 210 & T210 SERIES SERVICE MANUAL

18. Replacement or overhaul of the actuator is required each 1,000 hours and/or 3 years, whichever comes first. Refer to figure 2-5 for grease specifications.
NOTE: Refer to Section 9 of this service manual and Cessna Single Engine Service Letter SE73-25, or latest revision, for free-play limits, inspection, replacement and/or repair information.
19. Each 5 years, overhaul all retraction and brake system components. Check for wear, and replace all rubber packings and backups and hydraulic hoses.
20. Refer to paragraph 2-48 for ball rod end inspection.
21. Refer to Section 17 of this manual for belt tension check procedures.
22. Replace check valve in the turbocharger oil line every 1,000 hours.
23. Beginning with T210, 21063661 and earlier airplanes modified by SK210-93. Check fuel strainer insulation for security.
24. Beginning with T210, 21063661 and earlier airplanes modified by SK210-93. Check that the fuel line insulation in the nose gear tunnel is in good condition. All fuel lines and vapor return lines are as far from the exhaust system components as the installation will permit.
25. Compliance with Cessna Service Letter SE80-65 is required.
26. Inspect seat rails for cracks every 50 hours. Refer to Section 3.
27. Compliance with Cessna Single Engine Customer Care, Service Information Letter SE82-36 and Owner Advisory SE82-36A is required.
28. Disassemble, clean and reassemble every 100 hours or 5 years, and whenever the solenoid is accessible.
29. Each 1,000 hours, or to coincide with engine overhaul.
30. Can be operationally pressure checked in the airplane without power pack removal from the airplane (refer to paragraph 5A-5A). To determine if the relief valve disassembly or adjustment is necessary, relief valves can be bench checked after removal from power pack (refer to paragraph 5A-11A).
31. Each 100 hours or whenever fuel flow fluctuation is encountered, inspect fuel manifold valves, valve covers, and fuel system components and lines for signs of leaks. Refer to Teledyne Continental Motors Service Bulletin SB95-7.
32. Fuel quantity indicating system operational test is required every 12 months. Refer to Section 15 for detailed accomplishment instructions.
33. Check condition and operation of check valve manifold, beginning five years from date of manufacture, and every twelve months thereafter. Replace check valve manifold ten years from date of manufacture. Refer to Airborne Products Reference Memo #39 for manufacture date information.
34. At the first 100-hour inspection on new, rebuilt or overhauled engines, remove and clean the fuel injection nozzles. Thereafter, the fuel injection nozzles must be cleaned at 300-hour intervals or more frequently if fuel stains are found.

MODEL 210 & T210 SERIES SERVICE MANUAL

2-45. COMPONENT TIME LIMITS

1. General

- A. Most components listed throughout Section 2 should be inspected as detailed elsewhere in this section and repaired, overhauled or replaced as required. Some components, however, have a time or life limit, and must be overhauled or replaced on or before the specified time limit.

NOTE: The terms overhaul and replacement as used within this section are defined as follows:

Overhaul - Item may be overhauled as defined in FAR 43.2 or it can be replaced.

Replacement - Item must be replaced with a new item or a serviceable item that is within its service life and time limits or has been rebuilt as defined in FAR 43.2.

- B. This section provides a list of items which must be overhauled or replaced at specific time limits. Table 1 lists those items which Cessna has mandated must be overhauled or replaced at specific time limits. Table 2 lists component time limits which have been established by a supplier to Cessna for the supplier's product.
- C. In addition to these time limits, the components listed herein are also inspected at regular time intervals set forth in the Inspection Charts, and may require overhaul/replacement before the time limit is reached based on service usage and inspection results.

2. Cessna-Established Replacement Time Limits

- A. The following component time limits have been established by Cessna Aircraft Company.

Table 1: Cessna-Established Replacement Time Limits

COMPONENT	REPLACEMENT TIME	OVERHAUL
Restraint Assembly Pilot, Copilot, and Passenger Seats	10 years	NO
Trim Tab Actuator	1,000 hours or 3 years, whichever occurs first	YES
Vacuum System Filter	500 hours	NO
Vacuum System Hoses	10 years	NO
Pitot and Static System Hoses	10 years	NO
Vacuum Relief/Regulator Valve Filter (If Installed)	500 hours	NO
Engine Compartment Flexible Fluid Carrying Teflon Hoses (Cessna-Installed) Except Drain Hoses (Drain hoses are replaced on condition)	10 years or engine overhaul, whichever occurs first (Note 1)	NO

MODEL 210 & T210 SERIES SERVICE MANUAL

COMPONENT	REPLACEMENT TIME	OVERHAUL
Engine Compartment Flexible Fluid-Carrying Rubber Hoses (Cessna-Installed) Except Drain Hoses (Drain hoses are replaced on condition)	5 years or engine overhaul, whichever occurs first (Note 1)	NO
Engine Air Filter	500 hours or 36 months, whichever occurs first (Note 9)	NO
Engine Mixture, and Throttle, Controls	At engine TBO	NO
Oxygen Bottle - Light Weight Steel (ICC-3HT, DOT-3HT)	Every 24 years or 4,380 cycles, whichever occurs first	NO
Oxygen Bottle - Composite (DOT-E8162)	Every 15 years	NO
Engine-Driven Dry Vacuum Pump Drive Coupling (Not lubricated with engine oil)	6 years or at vacuum pump replacement, whichever occurs first	NO
Engine-Driven Dry Vacuum Pump (Not lubricated with engine oil)	500 hours (Note 10)	NO
Standby Dry Vacuum Pump	500 hours or 10 years, whichever occurs first (Note 10)	NO
Check Valve (Turbocharger Oil Line Check Valve)	Every 1,000 hours of operation (Note 11)	NO

3. Supplier-Established Replacement Time Limits

- A. The following component time limits have been established by specific suppliers and are reproduced as follows:

Table 2: Supplier-Established Replacement Time Limits

COMPONENT	REPLACEMENT TIME	OVERHAUL
ELT Battery	(Note 3)	NO
Vacuum Manifold	(Note 4)	NO
Magnetos	(Note 5)	YES
Engine	(Note 6)	YES
Engine Flexible Hoses (TCM-Installed)	(Note 2)	NO
Auxiliary Electric Fuel Pump	(Note 7)	YES
Propeller	(Note 8)	YES

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

Note 1: This life limit is not intended to allow flexible fluid-carrying Teflon or rubber hoses in a deteriorated or damaged condition to remain in service. Replace engine compartment flexible Teflon (AE3663819BXXXX series hose) fluid-carrying hoses (Cessna-installed only) every ten years or at engine overhaul, whichever occurs first. Replace engine compartment flexible rubber fluid-carrying hoses (Cessna-installed only) every five years or at engine overhaul, whichever occurs first (this does not include drain hoses). Hoses which are beyond these limits and are in a serviceable condition, must be placed on order immediately and then be replaced within 120 days after receiving the new hose from Cessna.

Note 2: Refer to Teledyne Continental Service Bulletin SB97-6, or latest revision.

Note 3: Refer to FAR 91.207 for battery replacement time limits.

Note 4: Refer to Airborne Air & Fuel Product Reference Memo No. 39, or latest revision, for replacement time limits.

Note 5: For airplanes equipped with Slick magnetos, refer to Slick Service Bulletin SB2-80C, or latest revision, for time limits.

For airplanes equipped with TCM/Bendix magnetos, refer to Teledyne Continental Motors Service Bulletin No. 643, or latest revision, for time limits.

Note 6: Refer to Teledyne Continental Service Information Letter SIL98-9, or latest revision, for time limits.

Note 7: Refer to Cessna Service Bulletin SEB94-7 Revision 1/Dukes Inc. Service Bulletin NO. 0003, or latest revision.

Note 8: Refer to the applicable McCauley Service Bulletins and Overhaul Manual for replacement and overhaul information.

Note 9: The air filter may be cleaned, refer to Section 2 of this service manual and for airplanes equipped with an air filter manufactured by Donaldson, Refer to Donaldson Aircraft Filters Service Instructions P46-9075 for detailed servicing instructions.

The address for Donaldson Aircraft Filters is:

Customer Service
115 E. Steels Corners RD
Stow OH. 44224

Do not overservice the air filter; overservicing increases the risk of damage to the air filter from excessive handling. A damaged/worn air filter may expose the engine to unfiltered air and result in damage/excessive wear to the engine.

Note 10: Replace engine-driven dry vacuum pump not equipped with a wear indicator every 500 hours of operation, or replace according to the vacuum pump manufacturer's recommended inspection and replacement interval, whichever occurs first.

Replace standby vacuum pump not equipped with a wear indicator every 500 hours of operation or 10 years, whichever occurs first, or replace according to the vacuum pump manufacturer's recommended inspection and replacement interval, whichever occurs first.

For a vacuum pump equipped with a wear indicator, replace pump according to the vacuum pump manufacturer's recommended inspection and replacement intervals.

Note 11: Replace the turbocharger oil line check valve every 1,000 hours of operation (Refer to Cessna Service Bulletin SEB91-7 Revision 1, or latest revision).

MODEL 210 & T210 SERIES SERVICE MANUAL

THIS PAGE INTENTIONALLY LEFT BLANK

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 3

FUSELAGE

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
FUSELAGE	1C9/3-1	Removal and Installation	1C23/3-15
Windshield and Windows	1C9/3-1	Sealing	1C23/3-15
Description	1C9/3-1	Scupper Drain Installation	1C23/3-15
Cleaning	1C9/3-1	Seats	1C23/3-15
Waxing	1C9/3-1	Pilot	1C23/3-15
Repair	1C11/3-3	Copilot	1C23/3-15
Scratches	1C11/3-3	3rd and 4th	1C23/3-15
Cracks	1C11/3-3	Description	1C23/3-15
Sealing	1C14/3-6	Removal and Installation	1C23/3-15
Windshield	1C14/3-6	Bench (5th and 6th)	1C24/3-16
Removal	1C14/3-6	Description	1C24/3-16
Installation	1C14/3-6	Removal and Installation	1C24/3-16
Windows	1C14/3-6	Repair	1C24/3-16
Movable	1C14/3-6	Cabin Upholstery	1C24/3-16
Removal and Installation	1C14/3-6	Materials and Tools	1D9/3-25
Wrap-Around Rear	1C14/3-6	Soundproofing	1D9/3-25
Removal and Installation	1C14/3-6	Cabin Headliner	1D9/3-25
Fixed	1C14/3-6	Removal	1D9/3-25
Cabin Structure	1C14/3-6	Installation	1D9/3-25
Sealing	1C14/3-6	Upholstery Panels	1D10/3-26
Cabin Doors	1C14/3-6	Removal and Installation	1D10/3-26
Removal and Installation	1C14/3-6	Carpeting	1D10/3-26
Wedge Adjustment	1C14/3-6	Removal and Installation	1D10/3-26
Weatherstrip	1C14/3-6	Safety Provisions	1D10/3-26
Sealing	1C14/3-6	Baggage Retaining Net	1D10/3-26
Latches	1C14/3-6	Description	1D10/3-26
Description	1C14/3-6	Safety Belts	1D10/3-26
Adjustment (Thru 21063640)	1C17/3-9	Description	1D10/3-26
Lock	1C17/3-9	Shoulder Harness	1D11/3-27
Indexing Inside Handle (Thru 21063640)	1C17/3-9	Description	1D11/3-27
Installation of Lock Assembly (Beginning with 21063641)	1C17/3-9	Inertia Reel Harness	1D11/3-27
Installation of Latch Assembly (Beginning with 21063641)	1C17/3-9	Description	1D11/3-27
Installation of Cable Assembly (Beginning with 21063641)	1C17/3-9	Removal and Installation	1D11/3-27
Rigging Cable Assembly (Beginning with 21063641)	1C17/3-9	Glider Tow-Hook	1D11/3-27
Rigging Inside Door Handle (Beginning with 21063641)	1C21/3-13	Description	1D11/3-27
Door Pull Handle	1C23/3-15	Rear View Mirror	1D11/3-27
Removal and Installation	1C23/3-15	Description	1D11/3-27
Baggage Door	1C23/3-15	Stretcher	1D11/3-27
		Description	1D11/3-27
		Removal and Installation	1D11/3-27
		Cabin Step Installation	1D13/3-29
		Description	1D13/3-29
		Removal and Installation	1D13/3-29
		Seat Rail Inspection	1D14/3-30

3-1. FUSELAGE.

3-2. WINDSHIELD AND WINDOWS. (See figure 3-2.)

3-3. DESCRIPTION. The windshield and windows are single-piece acrylic plastic panels set in sealing strips and held in place by formed retaining strips secured to the fuselage with screws and rivets. Inmont Corp. 579.6 sealing compound used in con-

junction with a felt seal, is applied to all edges of the windshield and windows with exception of the wing root area. The wing root fairing has a heavy felt strip which completes the windshield sealing.

3-4. CLEANING. (Refer to Section 2.)

3-5. WAXING. Waxing will fill in minor scratches in clear plastic and help protect the surface from

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 3-1. Repair of Windshields and Windows

MODEL 210 & T210 SERIES SERVICE MANUAL

further abrasion. Use a good grade of commercial wax applied in a thin, even coat. Bring the wax to a high polish by rubbing lightly with a clean, dry flannel cloth.

3-6. REPAIR. Replace extensively damaged transparent plastic rather than repair whenever possible, since even a carefully patched part is not the equal of a new section, either optically or structurally. At the first sign of crack development, drill a small hole at the extreme end of the crack as shown in figure 3-1. This serves to localize the cracks and to prevent further splitting by distributing the strain over a large area. If the cracks are small, stopping them with drilled holes will usually suffice until replacement or more permanent repair can be made. The following repairs are permissible; however, they are not to be located in the pilot's line of vision during landing or normal flight.

a. **SURFACE PATCH.** If a surface patch is to be installed, trim away the damaged area and round all corners. Cut a piece of plastic of sufficient size to cover the damaged area and extend at least 3/4-inch on each side of the crack or hole. Bevel the edges as shown in figure 3-1. If the section to be repaired is curved, shape the patch to the same contour by heating it in an oil bath at a temperature of 248° to 302°F., or it may be heated on a hot plate until soft. Boiling water should not be used for heating. Coat the patch evenly with plastic solvent adhesive and place immediately over the hole. Maintain a uniform pressure of from 5 to 10 psi on the patch for a minimum of three hours. Allow the patch to dry 24 to 36 hours before sanding or polishing is attempted.

b. **PLUG PATCH.** In using inserted patches to repair holes in plastic structures, trim the holes to a perfect circle or oval and bevel the edges slightly. Make the patch slightly thicker than the material being repaired, and similarly bevel the edges. Install patches in accordance with procedure illustrated in figure 3-1. Heat the plug until soft and press into the hole without cement and allow to cool to make a perfect fit. Remove the plug, coat the edges with adhesive, and then reinsert in the hole. Maintain a firm light pressure until the cement has set, then sand or file the edges level with the surface; buff and polish.

3-7. SCRATCHES. Scratches on clear plastic surfaces can be removed by hand-sanding operations followed by buffing and polishing, if steps below are followed carefully.

a. Wrap a piece of No. 320 (or finer) sandpaper or abrasive cloth around a rubber pad or wood block. Rub surface around the scratch with a circular motion, keeping abrasive constantly wet with clean water to prevent scratching the surface further. Use minimum pressure and cover an area large enough to prevent the formation of "bull's-eyes" or other optical distortions.

CAUTION

Do not use a coarse grade of abrasive. No. 320 is of maximum coarseness.

b. Continue sanding operation, using progressively

finer grade abrasives until the scratches disappear.

c. When the scratches have been removed, wash area thoroughly with clean water to remove all the gritty particles. The entire sanded area will be clouded with minute scratches which must be removed to restore the transparency.

d. Apply fresh tallow or buffing compound to a motor-driven buffing wheel. Hold wheel against plastic surface, moving it constantly over the damaged area until cloudy appearance disappears. A 2000-foot-per-minute surface speed is recommended to prevent overheating and distortion. (Example: 750 rpm polishing machine with a 10 inch buffing bonnet.)

NOTE

Polishing can be accomplished by hand but will require a considerably longer period of time to attain the same result as produced by a buffing wheel.

e. When buffing is finished, wash the area thoroughly and dry with a soft flannel cloth. Allow surface to cool and inspect the area to determine if full transparency has been restored. Apply a thin coat of hard wax and polish the surface lightly with a clean flannel cloth.

NOTE

Rubbing the plastic surface with a dry cloth will build up an electrostatic charge which attracts dirt particles and may eventually cause scratching of surface. After wax has hardened, dissipate this charge by rubbing the surface with a slightly damp chamois. This will also remove dust particles which have collected while the wax is hardening.

f. Minute hairline scratches can often be removed by rubbing with commercial automobile body cleaner or fine-grade rubbing compound. Apply with a soft, clean, dry cloth or imitation chamois.

3-8. CRACKS. (See figure 3-1.)

a. When a crack appears in a panel, drill a hole at the end of crack to prevent further spreading. The hole should be approximately 1/8 inch in diameter, depending on length of the crack and thickness of the material.

b. Temporary repairs to flat surfaces can be accomplished by placing a thin strip of wood over each side of the surface and inserting small bolts through the wood and plastic. A cushion of sheet rubber or aircraft fabric should be placed between the wood and plastic on both sides.

c. A temporary repair can be made on a curved surface by placing fabric patches over the affected areas. Secure the patches with aircraft dope, Specification No. MIL-D-5549; or lacquer, Specification No. MIL-L-7178. Lacquer thinner, Specification No. Mil-T-6094 can also be used to secure the patch.

MODEL 210 & T210 SERIES SERVICE MAI





Figure 3-2. Windshield and Fixed Window Installation and Cabin Sealing (Sheet 1 of 2)


MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

- When cabin top skin has been removed, seal between skin (15) and radius formed by two flanges of root rib (17) with Inmont Corp. No. 576.1 sealant
- Krylon Ignition sealer No. 1304 may be used on inside of cabin top skin around rivets that are found to be leaking.
- Seal openings and joints at all intersections of carry-thru spars (16) and (21), root rib (17), doublers (18) and door post (22) with RTV 102 (General Electric Co.) sealant.
- On each side of forward fuselage, seal radio cooling scoop (23) at intersection of outer skin with General Electric Co. RTV 102 sealant.



Detail H



Detail J

NOTE

Seal any openings at intersection of floorboard and vertical parts of cabin structure and reservoir fuel lines with RTV 102 (General Electric Co.) sealant.

NOTE


Seal all hoses, lines and wiring protruding through openings (20) in root rib with Inmont Corp. No. 579.6 sealant.

NOTE


Seal radius formed by cabin top skin (15) and carry-thru spar (16) with Acryl-R 5504 (Schnee-Morehead Chemical Inc.) sealant per Detail I.

NOTE

Seal all openings in structure with cloth backed pressure sensitive tape; 230 or 231 Polyken, Polyken Kendall Division, Chicago, Ill; Tuck 92T, Technical Tape Corp., Shawnee Mission, Ks; or P69, P670, or P672 Permacel, New Brunswick, N.J.; or any equivalent.



Detail I



- | | |
|--------------------------------|---------------------------|
| 15. Cabin Top Skin | 21. Front Carry-Thru Spar |
| 16. Carry-Thru Spar | 22. Door Post |
| 17. Root Rib | 23. Radio Cooling Scoop |
| 18. Doubler | |
| 19. Sealant | |
| 20. Root Rib Opening (Typical) | |

Figure 3-2. Windshield and Fixed Window Installation and Cabin sealing (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

3-9. SEALING. (See figure 3-2.)

3-10. WINDSHIELD. (See figure 3-2.)

3-11. REMOVAL.

- Drill out rivets securing top retainer strip.
- Remove screws securing front retainer strip.
- Remove wing fairings over windshield edges.

NOTE

Remove and tape compass and outside air temperature gage clear of work area. Do not disconnect electrical wiring.

d. Pull windshield straight forward, out of side and top retainers.

3-12. INSTALLATION.

- Apply felt strip and sealing compound or sealing tape to all edges of windshield to prevent leaks.
- Reverse steps in preceding paragraph for re-installation.
- When installing a new windshield, check fit and carefully file or grind away excess plastic.
- Use care not to crack windshield when installing. Starting at upper corner and gradually working windshield into position is recommended.

3-13. WINDOWS.

3-14. MOVABLE. (See figure 3-3.) A movable window, hinged at the top, is installed in the left cabin door on all aircraft and may also be installed in the right door as a customer option.

3-15. REMOVAL AND INSTALLATION.

- Disconnect window stop (5).
- Remove pins from window hinges (6).
- Reverse preceding steps for reinstallation. To remove frame from plastic panel, drill out blind rivets at frame splice. When replacing plastic panel in frame, ensure sealing strip and an adequate coating of Presstite No. 579.6 sealing compound is used around all edges of panel.

3-16. WRAP-AROUND REAR. (See figure 3-2.)

The rear window is a one-piece acrylic plastic panel set in sealing strips and held in place by retaining strips.

3-17. REMOVAL AND INSTALLATION.

- Remove upholstery as necessary to expose retainer strips inside cabin.
- Drill out rivets as necessary to remove the retainers on both sides and the lower edge of window.
- Remove window by starting at aft edge and pulling window into the cabin area.
- Reverse preceding steps for reinstallation. Apply sealing strips and an adequate coating of sealing compound to prevent leaks. When installing a new window, check fit and carefully file or grind away excess plastic.
- Use care not to crack the window when installing.

3-18. FIXED. (See Figure 3-2.) Fixed windows, mounted in sealing strips and sealing compound, are held in place by various retainer strips. To replace the side windows, remove upholstery and trim panels as necessary and drill out the rivets securing retainers. Except for the left door, rear window and windshield, the aircraft is equipped with double windows. Apply felt strip and sealing compound to all edges of the window to prevent leaks. Check fit and carefully file or grind away excess plastic. Use care not to crack the window when installing.

3-19. CABIN STRUCTURE. (See figure 3-2.)

3-20. SEALING. (See figure 3-2.)

3-21. CABIN DOORS. (See figures 3-3 thru 3-4A.)

3-22. REMOVAL AND INSTALLATION. Removal of cabin doors is accomplished by removing the screws attaching the hinges and door stop, or by removing the hinge pins attaching the door and door stop. If permanent hinge pins are removed from the door hinges, they may be replaced by clevis pins secured with cotter pins, or new hinge pins may be installed by inserting pin through both hinge halves and chucking a rivet set in a hand drill, hold one end of pin and form head on opposite end. Reverse pin and repeat process.

3-23. WEDGE ADJUSTMENT. Wedges, at upper forward edge of the door aid in preventing air leaks at this point. They engage as the door is closed. Several attaching holes are located in the wedges and the set of holes giving best results should be selected.

3-24. WEATHERSTRIP. Weatherstrip is bonded around the edges of the cabin door and the movable window opening. A hollow center, fluted type seal is used. When replacing door seals, ensure mating surfaces are clean, dry and free of oil and grease. Position butt ends of seal at door low point and cut a small notch in seal at this point for drainage. Apply a thin, even coat of EC-880 adhesive (3-M Co.) or equivalent to each surface and allow to dry until tacky before pressing into place.

3-25. SEALING. (See figure 3-3.)

3-26. LATCHES. (See figure 3-4.)

3-27. DESCRIPTION. (See figures 3-4, 3-4A and 3-5.) Through 21063640, The cabin door latch is a push-pull bolt type, utilizing a rotary clutch for positive bolt engagement. As the door is closed, teeth on underside of bolt engages gear teeth on clutch. The clutch gear rotates in one direction only, and holds door until handle is moved to LOCK position, driving bolt into slot. Beginning with 21063641, the rotary clutch is replaced with a spring-loaded latch pin. As the door is closed, (see figure 3-4A), push rod (14) rides up on actuator (45), causing bolt (13) to disengage from catch (20), driving bolt into slot. As the Door is opened, by pulling outboard on the handle (21), bolt (13) is pulled out of slot, engaging spring-loaded catch (20).


MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

Spray cabin window seals with MS-122 (Miller-Stephenson Chem. Corp., Danbury, Conn.) or equivalent. Caution, do not overspray; confine to seals.

NOTE

Forming the flange of a bonded door is not permissible as it could cause material separation.



1. Upholstery Clip
2. Upholstery Panel
3. Wedge
4. Spring
5. Window Stop
6. Window Hinge
7. Latch Plate
8. Cabin Door
9. Window Frame
10. Window
11. Washer
12. Nut
13. Lock Assembly
14. Latch Handle
15. Lower Hinge
16. Upper Hinge
24. Window Seal
30. Cam
31. Screw
32. Washer
33. Window Seal
34. Door Seal
35. Rubber Shim
36. Tape
42. Splice Gap

(LH ONLY)

Detail A

Latch, See figure 3-4.

Detail B

Detail C

NOTE

Seal operable window frame splice gap (42) with Inmont Corp. 576.1 sealant.

NOTE

After installing cam (30) on lock assembly (13), seal over head of screw (31) and washer (32) with RTV 103 (General Electric Co.) sealant.

NOTE

Cover edge of window (10) around perimeter with No. 33 electrical tape (36) 1.00 inch wide.

NOTE

Use rubber shim (35) as required to obtain proper fit of seal (34).

Figure 3-3. Cabin Door Installation (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 3-3. Cabin Door Installation (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

3-28. ADJUSTMENT. (Thru 21063640.) (Refer to figure 3-4.) Vertical adjustment of rotary clutch is afforded by slotted holes which ensure sufficient gear-to-bolt engagement and proper alignment. Adjustment for bolt (2) extension is accomplished by loosening the four bolt adjustment screws (26) sufficiently to move side bolt guide (3) forward in the slotted holes to retract the bolt, and aft to extend the bolt. Carefully close door after adjustment to check bolt extension and clearance with door jamb and alignment with clutch assembly.

NOTE

Lubricate the door latch per Section 2. No lubrication is recommended for the rotary clutch.

3-29. LOCK. In addition to interior locks, a cylinder and key type lock is installed on the left door. If the lock is to be replaced, the new one may be modified to accept the original key. This is desirable, as the same key is used for the ignition switch and the cabin door lock. After removing the old lock from door, proceed as follows:

- Remove the lock cylinder from new housing.
- Insert the original key into the new cylinder and file off any protruding tumblers flush with cylinder. Without removing key, check that cylinder rotates freely in the housing.
- Install the lock assembly in door, and check lock operation with the door open.
- Destroy the new key and disregard the code number on cylinder.

3-30. INDEXING INSIDE HANDLE. (Thru 21063640.) (Refer to Figure 3-4.) When the inside handle (12) is removed, reinstall in relation to position of bolt (2), which should be in LOCK position, when following these procedures.

- Temporarily install inside handle (12) on shaft assembly (16), aligning horizontally with arm rest.
- Move inside handle (12) back and forth slightly to ensure mechanism is centered in LOCK position.
- Set inside handle adjustment screw (27) as required to align handle parallel to centerline of handle axis.
- Without rotating shaft assembly (16), remove handle, and install placard (10) with LOCK index forward and aligned horizontally with arm rest.
- Install inside handle (12) to align with LOCK index on placard (10), and install handle-retaining screw (13).
- Ensure bolt (2) clears door post and teeth engage clutch gear when handle is in CLOSE position.

3-31. INSTALLATION OF LOCK ASSEMBLY ON LATCH ASSEMBLY. (Beginning with 21063641.) (Refer to figure 3-4A.)

- Assembly locking arm (3) with pin (5).
- Place pin (5) in 1/8-inch hole of latch base assembly (23).
- Align .099-inch hole of locking arm (3) with .094-inch hole in latch base assembly (23), and install pin (4).
- Assemble cam assembly (1) to locking arm (3). Cam should be on latch side of locking arm (3).
- Use washers between cam assembly (1) and cotter pin (2), and install cotter pin on clevis bolt.

3-32. INSTALLATION OF LATCH ASSEMBLY. (Beginning with 21063641.) (Refer to figure 3-4A.)

NOTE

Install with latch in CLOSED position.

- Install latch assembly between door pan and door skin.
- Cable assembly should be forward of latch base attach plate, and inboard of latch base cup.
- Extend latch handle through cutout in door skin. This will pull latch bolt back far enough to allow latch to fall into place.
- Push latch assembly aft so that bolt (13) and push rod (14) extend through their respective holes.
- Trip push rod (14) so that bolt (13) is fully extended and outside handle (21) is flush.
- Secure latch to door pan with four NAS220-5 screws through base assembly (23) and two AN525-10R6 screws through aft flange of door pan.
- Drill eleven .128-inch holes to align with latch base assembly (23).

NOTE

Do not oversize holes in the latch base, and do not rivet base to skin at this time.

3-33. INSTALLING CABLE ASSEMBLY. (Beginning with 21063641.) (Refer to figure 3-4A.)

NOTE

Remove cover assembly (41).

- On pin end of cable assembly (25), attach clamp (26) and self-locking clip-on nut (34), one-inch from end of casing, as shown in Detail A.
- Insert pin end of cable between door pan and door skin at aft end of door. Push pin end of cable to top of door.
- Remove plug button (29) and align pin on cable with pin guide (31), and insert pin through guide. Access is gained through .875-inch hole (33).
- Align clamp on cable casing with hole located one-inch below .875-inch hole (33), and install screw.
- Check operation of cable. If sluggish operation of cable is encountered, add S-1450-24A-0762 washers (27) to self-locking clip-on nut (34) to facilitate smoother cable operation.


NOTE

Washers are to be bonded to clip-on nut with 579.6 sealer (Inmont Corp., St. Louis, Missouri), or equivalent.

3-34. RIGGING CABLE ASSEMBLY. (Beginning with 21063641.) (Refer to figure 3-4A.)

MODEL 210 & T210 SERIES SERVICE MANUAL

- 10. Placard
- 11. Deleted
- 12. Inside Handle
- 13. Handle-Retaining Screw
- 14. Plate Assembly
- 15. Spacer
- 16. Shaft Assembly
- 17. Bolt Push Rod
- 20. Doubler
- 21. Shim
- 22. Rotary Clutch Assembly
- 23. Guide
- 24. Door Post
- 25. Cover
- 27. Inside Handle Adjust Screw




CABIN DOOR
ROTARY CLUTCH

NOTE

Rotary clutch components are matched upon assembly. The clutch mechanism, if defective, should be replaced as a unit.

NOTE

On aircraft serials 21061574 thru 21061619, a special made-to-order Service Kit (SK206-17) is available from Cessna Parts Distribution (CPD 2), through Cessna Service Stations, for installing the rotary clutch further outboard. This modification enables the door to be initially closed easier and the cabin doors to remain closed on the ground during gusty wind conditions.



ROTATED 90° TO
EXPOSE FACE

NOTE

Set adjustment screw (item 27) in slot to maintain the handle parallel to C/L of handle axis in the locked position.

Figure 3-4. Door Latch (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

Refer to paragraph 3-28
for bolt (2) adjustment.





Figure 3-4. Door Latch (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL



NOTE
Apply DOOR-EZE lubricant to bolt (13).

- | | |
|-----------------|-------------------------|
| 1. Cam Assembly | 13. Bolt |
| 2. Cotter Pin | 14. Push Rod |
| 3. Locking Arm | 15. Rivet |
| 4. Pin | 16. Pin |
| 5. Pin | 17. Pin |
| 6. Cotter Pin | 18. Spring |
| 7. Pull Bar | 19. Spring |
| 8. Deleted | 20. Catch |
| 9. Pin | 21. Outside Handle |
| 10. Cotter Pin | 22. Lock Washer |
| 11. Lock Washer | 23. Latch Base Assembly |
| 12. Pin | 24. Pin |

Figure 3-4A. Cabin Door and Latch Assembly (Sheet 1 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 3-4A. Cabin Door and Latch Assembly (Sheet 2 of 3)

NOTE

Make sure door latch is in OPEN position before proceeding.

- a. Cut casing of cable assembly approximately two inches from clamp (42) on push rod assembly (43).
- b. Insert core of cable through clamp (42).
- c. Pull core through clamp so that pin (32) extends approximately 1/8-inch from door pan contour.
- d. Cut core approximately one-inch forward of push rod clamp (42).
- e. Secure two nuts to push rod clamp.
- f. Operate latch several times to ensure latch works freely. If latch binds up and will not work freely, remove cable core from clamp (42) and operate latch. If latch operates easily without cable attachment, check cable for possible adjustments to facilitate ease of operation.
- g. After cable operates freely, install cover assembly (41) and recheck cable for operation.

3-35. RIGGING INSIDE DOOR HANDLE. (Begin-

ning with 21063641.) See figure 3-4A.)

- a. With latch secured to door pan, attach push rod assembly (43) to pull bar (7), and secure with pin (9).

NOTE

Do not install cotter pin (10).

- b. Ensure that latch is in CLOSED position.
- c. By removing pin (9) that connects push rod to latch base assembly, rotate rod in or out (180°) for adjustment. Adjust rod so that it takes a load of 6 pounds to 12 pounds at the end of the inner handle to move it from closed position to overcenter position.

NOTE

Rod must be attached to latch assembly before rigging can be accomplished.

- d. For fine adjustment for overcentering latch assembly, proceed as follows:

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 3-4A. Cabin Door and Latch Assembly (Sheet 3 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

Cabin door latch must be in OPEN position. Latch must operate smoothly and freely.

1. Adjust striker plate (49) forward by installing 1212147-1 shims (50) as required, so that there is a minimal clearance between bolt (13) and striker (49).

NOTE

This adjustment will ensure that when the door is opened from the outside, the bolt will engage the latch catch, and the exterior handle will stay open until the door is closed again.

NOTE

If cabin door is located too far forward such that the door latch will not operate, this will not allow latch assembly push rod (14) to ride up on actuator (45) and trigger the latch bolt (13), install 1212150-1 shims (46) as required beneath actuator (45), located on cover assembly (48).

2. Close the cabin door from inside the aircraft. When latch is overcentered, the exterior handle should pull flush. If it does not pull flush, the connecting push rod from the door latch to the inside handle assembly should be lengthened, adjusted "out".

3. On aircraft which have not been modified per Mod Kit 1209062, when adjusting push rod (43), it need only be adjusted 1/2 turn. To accomplish this, base plate assembly (44) should be removed.

NOTE

When making this adjustment on the overcentering of the latch, it may be noticed that there is a sharp, loud canning noise when the inside handle is pushed down. It is preferred that the outside door handle be flush, even if the canning noise is noticeable.

4. To make 1/2 turn adjustment, remove smaller end of push rod (43) and turn it over (180°). Then re-install base plate assembly.
5. When closing cabin door from the outside, by using a large, sharp force on the outside handle, it is possible to overcenter the inside handle, thus locking one's self out. To prevent this from occurring on aircraft modified per Mod Kit 1209062, when adjusting the push rod in step "2", adjust the push rod so there is a sufficient force (6 to 12 pounds) against the inside handle to prevent it from overcentering when closing the door from the outside. (Refer to paragraph 3-35.)
6. Do not file, grind or sand any portion of the bolt.
7. Recheck clamps that secure cable. There must not be any slippage between cable casing and clamp.
8. After overcenter adjustment has been made, install cotter pin (10) in clevis pin (9).

- e. Rivet latch base (23) to door skin with MS20426A4-3 rivets.

- f. Attach lock assembly casing (36) to door skin (37) with nut (38) provided.

- g. Install tumblers (35) and attach cam (1) to tumblers with screw and lock washer provided (40) and (39).

- h. Operate lock several times to assure that all parts function properly.

NOTE

Steps "f", "g" and "h" apply to left-hand doors only.

- 3-36. DOOR PULL HANDLE. (See figure 3-3.)

- 3-37. REMOVAL AND INSTALLATION. (See figure 3-3, sheet 2.) The figure may be used as a guide for removal and installation of the door pull handle.

- 3-38. BAGGAGE DOOR. (See figure 3-5.)

- 3-39. REMOVAL AND INSTALLATION.

- a. Disconnect door stop.
- b. Remove hinge pin.
- c. Reverse preceding steps for reinstallation.

- 3-40. SEALING. (See figure 3-5.)

- 3-41. SCUPPER DRAIN INSTALLATION. (See figure 3-5.)

- a. Parts and materials required may be obtained from the Cessna Supply Division.
- b. Installation is accomplished with trim panel under baggage door removed and carpet loosened along left side of floor.
- c. Remove sealant from intersection of bulkhead (44), floor (45), and at lower left forward corner of compartment for drain to lower fuselage.
- d. Drill .250" drain hole (46) in lower left forward corner of baggage compartment per detail F.
- e. Install scupper (47) in lower left side of baggage compartment by bonding scupper to floor and at both ends with General Electric RTV-102 sealant.
- f. Drill four number 40 holes through scupper (47) and floor (45), equally spaced, starting 2.5" from forward end. Install four sheetmetal screws (48).
- g. Reinstall trim panel and carpet.

- 3-42. SEATS. (See figure 3-6.)

- 3-43. PILOT. (See figure 3-6, sheet 1 of 3.)

- a. Articulating recline/vertical adjust.

- 3-44. COPILOT. (See figure 3-6, sheet 1 of 3.)

- a. Articulating recline.
- b. Articulating recline/vertical adjust.

- 3-45. 3RD AND 4TH.

- a. Articulating recline.

- 3-46. DESCRIPTION. These seats are manually-operated throughout their full range of operation. Seat stops are provided to limit fore-and-aft travel.

- 3-47. REMOVAL AND INSTALLATION.

MODEL 210 & T210 SERIES SERVICE MANUAL

- a. Remove seat stops.
- b. Disengage the seat adjustment pin.
- c. Slide seat fore-and-aft to disengage seat rollers from rails.
- d. Lift seat out.
- e. Reverse preceding steps for reinstallation. Ensure all seat stops are reinstalled.

WARNING

It is extremely important that the pilot's seat stops are installed. Acceleration and deceleration could possibly permit seat to become disengaged from the seat rails and create a hazardous situation, especially during take-off and landing.

3-48. BENCH. (See figure 3-6, sheet 3 of 3 and figure 3-6B.)

3-49. DESCRIPTION. These seats incorporate no adjustment provisions and are bolted to the cabin structure. The seat back folds down to provide additional storage space on top of the main gear wheel well and on top of the seat back. Beginning with serial 21064773, the seat bottom may be removed from the frame by removing two bolts.

3-50. REMOVAL AND INSTALLATION.

- a. Pull up on knob (1) to unlatch seat back.
- b. Remove pin (10) from guide (8) on each side of seat back.
- c. Remove bolts (14) from the three seat legs.
- d. Remove bolts (9) from both sides of seat bottom.

NOTE

Bolts (9) are located inside the main gear wheel well.

- e. With the seat back folded down, use care and slide the two inside seat belts out from between the seat back and bottom. Remove seat from aircraft.
- f. Reverse preceding steps for reinstallation.


3-51. REPAIR. Replacement of defective parts is recommended in repair of seats.

3-52. CABIN UPHOLSTERY. Due to the wide selection of fabrics, styles and colors, it is impossible to depict each particular type of upholstery. The following paragraphs describe general procedures which will serve as a guide in removal and replacement of upholstery. Major work, if possible, should be done

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

- | | |
|------------------------|------------------------|
| 1. Shim | 22. Baggage Door |
| 2. Striker | 23. Latch Bolt |
| 3. Hinge Half | 24. Bearing Assembly |
| 4. Rod Support Bracket | 25. Latch Pan Assembly |
| 5. Bracket | 26. Link Bolt |
| 6. Hinge Pin | 27. Handle Shaft |
| 7. Ball Joint | 28. Lock Cover |
| 8. Balance Spring | 29. Washer |
| 9. Bulkhead | 30. Lock Screw |
| 10. Escutcheon | 31. Drain Hole |
| 11. Washer | 33. Sealant |
| 12. Door Stop | 34. Bulkhead |
| 13. Nut | 35. Skin |
| 14. Latch Assembly | 36. Floor |
| 15. Spacer | 37. Stringer |
| 16. Outer Skin | 39. Circular Seal |
| 17. Seal | 40. Inner seal Pan |
| 19. Handle | 41. Dorsal Fin |
| 20. Lock Assembly | 42. Fin Fairing |
| 21. Cam | 43. Door Jam |




NOTES


- Check that all attaching screws in dorsal fin (41) are tight. Seal fin fairing (42) and three attaching screws with Inmont 576.1.
- Install hinge pin (6) from aft end of door assembly (22) with end bend inboard of hinge.
- Check that loop on aft end of baggage door hinge pin (6) does not interfere with seal (17) when door is closed. Reform loop as necessary to prevent hinge pin (6) from rotating and compressing seal (17).
- Ensure baggage door inner seal pan (40), provides a smooth mating surface for door seal (17). Fill any low areas with White Streak filler, sand until smooth and repaint.
- Install shims (1) as required to obtain engagement shown in Detail D between striker plate (2) and baggage door latch bolt (23).
- Install washers (29) as required to align link (26) perpendicular to handle shaft (27). At least one washer must be installed between link and cotter pin.
- Bond seal (17) around baggage door with EC-880 (3M Co.) or equivalent. Locate butt ends of seal at door low point, no closer than 2.00 inches to latch assembly.
- Cut small notch in one end of hollow seal (17) to allow for drainage. Do not cement butt ends together.
- Seal lock screw (30) to cap (28) and area where cam (21) passes thru cap with RTV-102 (General Electric Co.) or equivalent.
- Ensure drain holes (31) are clear.
- The baggage door is of bonded construction. Reforming of this door is not permissible as material separation may occur in the flange area.
- Apply Inmont Corp. 576.1 sealant (33) to open areas between striker and jamb per detail D.
- Seal baggage compartment structure for water tight seal by applying RTV 102 (General Electric Co.) sealant at openings and intersections of bulkhead, skin, floor and stringers per detail F.
- Seal intersection of door jam (43) and outer skin (16) with Inmont Corp. 576.1 sealant.
- If baggage door continues to leak around seal in hinge area after all sealing procedures have been used, a length of S-1453-1 circular cross section seal may be used as a back-up to reinforce the door seal (17). Cement S-1453-1 seal (39) with 3-M Co. EC-880 adhesive to door inner skin pan (40) per detail B along the full length of hinge area and down the forward and aft sides approximately three inches. Readjust baggage door as necessary.
- On some late 1978 models a scupper drain was installed in the baggage compartment. This installation may be installed on earlier aircraft per sheet 3.

Figure 3-5. Baggage Door Installation and Compartment Sealing (Sheet 1 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Detail **A**




Detail **B**

NOTE


Locate edge of seal (17) 1/8 inch or less from edge of outer periphery of baggage door.




Detail **F**



Detail **C**



Detail **E**



Detail **D**

Figure 3-5. Baggage Door Installation and Compartment Sealing (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 3-5. Baggage Door Installation and Compartment Sealing (Sheet 3 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL


1. Vertical Adjustment Handle
2. Fore/Aft adjustment Handle
3. Adjustment Pin
4. Spring
5. Seat Bottom
6. Articulating Adjustment Handle
7. Adjustment Screw
8. Bellcrank
9. Seat Back
10. Spacer
11. Channel
12. Torque Tube
13. Seat Structure
14. Roller
15. Stiffener
16. Trim
17. Seat Belt Retainer
18. Guide
19. Collar

● 21061574 THRU 21063178

□ 21061574 THRU 21064135

* BEGINNING WITH 21064136

* 21061574 THRU 21062874



**INFINITELY-ADJUSTABLE
PILOT AND COPILOT SEAT**


Figure 3-6. Seat Installation (Sheet 1 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

3rd and 4th seat assemblies are left and right hand and must be installed on their respective side. When not installed properly the aisle to the rear seat is eliminated.

● 21061574 THRU 21062273
 □ BEGINNING WITH 21062274



ARTICULATING RECLINE
 3RD AND 4TH

Figure 3-6. Seat Installation (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 3-6. Seat Installation (Sheet 3 of 3)


MODEL 210 & T210 SERIES SERVICE MANUAL

SEAT PEDESTAL ASSEMBLY

● BEGINNING WITH 21064773

□ THRU 21063178

* BEGINNING WITH 21063179



1. Vertical Adjust Handle
2. Bearing Block
3. Vertical Adjust Screw
4. Vertical Adjust Nut
5. Seat Adjust Handle
6. Seat Adjust Pin
7. Spring
8. Seat Back Adjust Handle
9. Bearing
10. Jack Screw
11. RH Crank

12. Splice
13. LH Crank
14. Torque Tube Bellcrank
15. Rear Torque Tube
16. Seat Pivot Bracket
17. Seat Back Adjust Bellcrank
18. Forward Torque Tube Bellcrank
19. Collar
20. LH Pedestal
21. RH Pedestal
22. Link-Seat Lock

Figure 3-6A. Seat Pedestal Assembly

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 3-6B. Rear Bench Seat

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 3-7. Cabin Headliner Installation

by an experienced mechanic. If the work must be done by a mechanic unfamiliar with upholstery practices, the mechanic should make careful notes during removal of each item to facilitate replacement later.

3-53. MATERIALS AND TOOLS. Materials and tools will vary with the job. Scissors for trimming upholstery to size and a dull-bladed putty knife for wedging material beneath retainer strips are the only tools required for most trim work. Use industrial rubber cement to hold soundproofing mats and fabric edges in place. Refer to Section 18 for thermoplastic repairs.

3-54. SOUNDPROOFING. The aircraft is insulated with spun glass mat-type insulation and a sound deadener compound applied to inner surfaces of the skin in most areas of the cabin and baggage compartment. All soundproofing material should be replaced in its original position any time it is removed. A soundproofing panel is placed in the gap between wing and fuselage and held in place by the wing root fairings.

3-55. CABIN HEADLINER. (See figure 3-7.)

3-56. REMOVAL.

a. Remove all overhead oxygen, ventilating and light consoles, sun visors, dome lights, all inside finish strips and plates and any other visible retainers securing headliner.

b. Work edges of headliner free from metal teeth which hold fabric.

c. Starting at the front of headliner and working toward the rear, work headliner down, removing screws through the metal tabs which hold the wire

bows to cabin top. Pry loose outer ends of the bows from retainers above doors. Detach each wire bow in succession.

d. Remove headliner assembly and bows from the aircraft.

NOTE

Due to the difference in length and contour of wire bows, each bow should be tagged to assure proper location in the headliner.

e. Remove the spun glass soundproofing panels.

NOTE


The lightweight soundproofing panels are held in place with industrial rubber cement.

3-57. INSTALLATION.

a. Before installation, check all items concealed by headliner for security. Use wide cloth tape to secure loose wires to the fuselage and to seal any openings in the wing roots. Straighten tabs bent during removal of headliner.

b. Apply cement to inside of skin in the areas where soundproofing panels are not supported by wire bows and press soundproofing in place.

c. Insert wire bows into headliner seams and secure the two bows at rear of headliner. Stretch the material along edges to properly center, but do not stretch it tight enough to destroy ceiling contours or distort wire bows. Secure edges of headliner with the metal teeth.



1. Mirror Assembly
2. Bracket Assembly
3. Washer
4. Knurled Nut
5. Cowl Deck
6. Spacer
7. Eyebrow

Thru Serial 21062954

Figure 3-8. Rear View Mirror Installation

d. Work headliner forward, installing each wire bow in place with the metal tabs. Wedge ends of wire bows into the retainer strips. Stretch headliner just taut enough to avoid wrinkles and maintain a smooth contour.

e. When all bows are in place and fabric edges are secured, trim off excess fabric and reinstall all items removed.

3-58. UPHOLSTERY PANELS.

3-59. REMOVAL AND INSTALLATION. Removal of the upholstery side panels is accomplished by removing the seats for access and removing screws, retaining strips and ash trays as required to free the panels. When reinstalling side panels, do not overtighten screws. Larger screws may be used in enlarged holes as long as the area behind the hole is checked for wiring, fuel lines and other components which might be damaged by using a longer screw. Automotive type spring clips attach the door panels and a dull putty knife makes an excellent tool for prying the clips loose. The rear baggage panel is secured to the aft cabin wall with cloth retaining strips for easy removal.

3-60. CARPETING.

3-61. REMOVAL AND INSTALLATION. Cabin area and baggage compartment carpeting is held in place by rubber cement, small sheet metal screws and retaining strips. Cloth retaining strips are also installed on some aircraft near access plate locations

for quick-removal of the carpeting and inspection in these areas. When fitting a new carpet, use the old one as a pattern for trimming and marking screw holes.

3-62. SAFETY PROVISIONS.

3-63. BAGGAGE RETAINING NET.

3-64. DESCRIPTION. A nylon baggage net having six tie-down straps is provided to secure baggage in the area aft of the wheel well and on the backs of the fifth and sixth seats when they are used for stowing baggage. When using the baggage net to secure baggage stowed aft of the wheel well, only four of the net tie-down straps are usually used. They are fastened to the two tie-down rings located on the forward edge of the wheel well and two rings at the bottom edge of the rear cabin window. If the fifth and sixth seats are not occupied, the seat backs may be folded forward to create more baggage area. If this area is used, all six tie-down straps must be used. Tie the front straps of the net to the front legs of the fifth and sixth seats and the remaining four straps to the tie-down rings provided.

3-65. SAFETY BELTS. (See figures 3-6 and 3-10.)

3-66. DESCRIPTION. Safety belts should be replaced if frayed or cut, latches are defective or stitching is broken. Attaching parts should be replaced if excessively worn or defective. The pilot and copilot seat safety belts are attached to brackets

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 3-9. Stretcher Installation

bolted to the cabin floor. The 3rd and 4th seat belts are attached to brackets bolted to the cabin floor and fuselage structure. The bench seat belts are attached to a bracket bolted to the cabin floor and to the seats themselves.

NOTE

The belt half with the buckle should be installed on the outboard side of the seat to ensure proper operation of the shoulder harness.

3-67. **SHOULDER HARNESS.** (See figure 3-10.)

3-68. **DESCRIPTION.** Individual shoulder harnesses may be installed for each seat. The pilot and copilot harnesses are bolted to the upper rear doorposts and the 3rd, 4th and bench seat harnesses are bolted to the aft cabin structure.

3-69. **INERTIA REEL HARNESS.** (See figure 3-10.)

3-70. **DESCRIPTION.** An inertia reel harness assembly may be installed for the pilot and copilot positions. The inertia reels are installed in a mounting base located in the aft center overhead console. The shoulder and lap belt are one assembly with an adjuster to position the shoulder harness. The reel is designed to lock and hold when a 2 to 3 "g" force is applied and 12 inches of webbing remain on the reel. The reel can be checked for proper operation by giving webbing a quick tug, the reel should lock and hold.

3-71. **REMOVAL AND INSTALLATION.**

- Remove the screws retaining the escutcheon on aft center console and remove the oxygen outlet covers by rotating counter-clockwise if installed.
- Remove screws in mounting bracket and remove (2) screws in each reel assembly and pull belt through bracket.
- Re-install by reversing the procedure.

3-72. **GLIDER TOW-HOOK.**

3-73. **DESCRIPTION.** A glider tow-hook, which is mounted in place of the tail tie-down ring, is available thru 21062954.

3-74. **REAR VIEW MIRROR.** (See figure 3-8.)

3-75. **DESCRIPTION.** A rear view mirror may be installed on the cowl deck above the instrument panel, on aircraft thru 21062954. Figure 3-8 shows details of the installation.


3-76. **STRETCHER INSTALLATION.** (See figure 3-9)

3-77. **DESCRIPTION.** A portable stretcher may be installed in the aircraft. The stretcher is installed by removing the copilot seat and utilizing the copilot's seat belt and the right hand center seat and seat belt.


3-78. **REMOVAL AND INSTALLATION.**

- Remove copilot's seat and store in baggage com-


MODEL 210 & T210 SERIES SERVICE MANUAL



Detail **A** and **B**




Detail **C** and **D**




NOTE

For rear seat belt attach, see figure 3-6.

1. Shoulder Harness Tray
2. Shoulder Harness
3. Washer
4. Spacer
5. Cover
6. Bolt
7. Seat Belt
8. Bracket



Detail **E**



Detail **F**

Figure 3-10. Seat Belt and Shoulder Harness Installation (Sheet 1 of 2).

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 3-10. Seat Belt and Shoulder Harness Installation (Sheet 2 of 2).

partment.

- b. Replace right hand cabin door hinge pins with removable hinge pins.
- c. Replace right hand cabin door stop hinge rivet with a pin, washer and cotter pin.
- d. Pass stretcher through cabin door, head-end first. Rotate stretcher until head end rests on right hand center seat. Engage legs at the foot of the stretcher with copilot seat rails and secure locking pin on in-board leg.
- e. Secure head end of stretcher with right hand center seat belt.
- f. For removal, reverse the preceding steps.

3-79. CABIN STEP INSTALLATION. (See figure 3-11.)


3-80. DESCRIPTION. To facilitate entry and exit from the aircraft, a retractable step is installed. The step is operated by a cable assembly attached to

the nose gear actuator and is extended and retracted with the nose gear.

3-81. REMOVAL AND INSTALLATION. (See figure 3-11.)

- a. Remove the co-pilot seat, carpeting, inspection covers and step cover as required to gain access to the step assembly.
- b. Disconnect cable (27) by removing the cotter pin and the attaching pin located at the end of the cable.
- c. Disconnect cable (4) by removing pulley (3) from the step assembly. Retain the pulley for reinstallation.
- d. Remove the attaching pin from the cable cover (5) and bracket (6).
- e. Remove bolt (25) and remove the step assembly from the aircraft.
- f. To install cabin step, reverse the preceding steps.

MODEL 210 & T210 SERIES SERVICE MANUAL



NOTE

Step tread is bonded to step assembly (2) with EC-1300L (3M Company, St. Paul, Minnesota 55101) or equivalent.

Cover seal (7) is bonded to pulley bracket (8) with EC-1300L or EC-880 (3M Company, St. Paul, Minn. 55101) or equivalent adhesive and sealed with RTV102 white adhesive sealant (General Electric, Waterford, New York) or equivalent sealant.

NOTE

Lubricate bushing (24) and bearing (23) with MIL-G-21164 grease. Cable assemblies (4) and (27) may be lubricated with Petrolatum VV-P-236.

Washers may be added or deleted from stop bolt (19) to adjust travel of step attach assembly (1). No specific measurement is required; only to facilitate entry and exit from aircraft.

- | | | |
|--------------------------|----------------------------|-----------------------------|
| 1. Step Attach Assembly | 10. Boss | 20. Spring |
| 2. Step Assembly | 11. Grommet | 21. Bracket |
| 3. Pulley | 12. Fitting Assembly | 22. Race |
| 4. Cable Assembly | 13. Nose Gear Drag Fitting | 23. Bearing |
| 5. Cable Cover | 14. Pulley Bracket | 24. Bushing |
| 6. Bracket | 15. Turnbuckle | 25. Internal Wrenching Bolt |
| 7. Cover Seal | 16. Spring Clip | 26. Support |
| 8. Pulley Bracket | 17. Nose Gear Attach Hook | 27. Cable Assembly |
| 9. Bulkhead Sealant 44.0 | 18. Pulley | 28. Spacer |
| | 19. Stop Bolt | 29. Step Support Cover |

Figure 3-11. Cabin Step Installation


NOTE

For cable rigging instructions refer to Section 5. When rigging procedure is complete, safety wire turnbuckle (15).

g. Refer to Section 5 for removal and installation of components not specifically called out in the preceding steps.

3-67. SEAT RAIL INSPECTION. A special inspection of the seat rails should be conducted each 50 hours. See figure 3-12 for inspection procedures.

MODEL 210 & T210 SERIES SERVICE MANUAL



REPLACE SEAT RAIL WHEN:

- Any portion of web or lower flange is cracked (index 2).
- Any crack in crown of rail in any direction other than right angle to length of crack.
- Number of cracks on any one rail exceeds four, or any two cracks (index 1) are closer than one-inch.

NOTE

Use of seat rail cargo tie-downs is not permissible on seat rails with cracks.

Figure 3-12. Seat Rail Inspection

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 4

WINGS AND EMPENNAGE

TABLE OF CONTENTS	Page No. Aerofiche/Manual
WINGS AND EMPENNAGE	1D20/4-1
Wings	1D20/4-1
Description	1D20/4-1
Removal	1D20/4-1
Repair	1D21/4-2
Installation	1D21/4-2
Adjustment	1D21/4-2
Vertical Fin	1D21/4-2
Description	1D21/4-2
Removal	1D21/4-2
Repair	1D21/4-2

Installation	1D21/4-2
Horizontal Stabilizer	1D21/4-2
Description	1D21/4-2
Removal	1D22/4-3
Repair	1D22/4-3
Installation	1D22/4-3
Stabilizer Abrasion Boots	1D22/4-3
Description	1D22/4-3
Removal	1D22/4-3
Installation	1D22/4-3

4-1. WINGS AND EMPENNAGE.

4-2. WINGS. (See figure 4-1.)

4-3. DESCRIPTION. Each all-metal wing panel is a full cantilever type, with a single main spar, two fuel spars, formed ribs and stringers. The front fuel spar also serves as an auxiliary spar and provides the forward attachment point for the wing. An inboard section of the wing, forward of the main spar, is sealed to form an integral fuel bay area. Stressed skin is riveted to the spars, ribs and stringers to complete the structure. An all-metal, balanced aileron, flap, and a detachable wing tip are part of each wing assembly. A navigation light is mounted in each wing tip.

4-4. REMOVAL. Wing panel removal is most easily accomplished if four men are available to handle the wing. Otherwise, the wing should be supported with a sling or maintenance stand when the fastenings are loosened.

- a. Remove wing gap fairings and fillets.
- b. Drain fuel from wing being removed. (Observe precautions outlined in Section 13.)
- c. Remove cabin headliner in accordance with procedures outlined in Section 3.

WARNING

Oil, grease or other lubricants in contact with high-pressure oxygen, create a serious fire hazard and such contact should be avoided. Do not permit smoking or open flame in or near aircraft while work is performed on oxygen systems.

d. (Refer to Section 15.) Rotate valves on three cylinders clockwise to shut off filler line pressure; the quick-release adapter on the cylinder-regulator assembly will retain pressure within the cylinder. Disconnect oxygen filler line at first tee upstream from filler valve.

e. Disconnect:

1. Electrical wires at wing root disconnects.
2. Fuel lines at wing root.
3. Pitot line (left wing only) at wing root.
4. Cabin ventilator hose at wing root.
5. Aileron carry-thru cable and aileron direct cables of wing being removed, at turnbuckles behind headliner front shield and doorpost shield.

NOTE

To ease rerouting the cables, a guide wire may be attached to each cable before it is pulled free from the wing. Then disconnect cable from wire and leave the guide wire routed through the wing; it may be attached again to the cable during reinstallation and used to pull the cable into place.

f. If right wing is being removed, disconnect flap cables from right flap drive pulley, and remove cable guards and/or pulleys as required to pull flap cables into right wing root area.

g. If left wing is being removed, relieve tension on right flap cables at right flap drive pulley. Disconnect right flap cables at flap actuator in left wing and remove pulleys to pull flap cables into left wing root area.

NOTE

Rigging of flap actuator and components in left wing need not be disturbed to remove either wing. It is recommended that flap be secured in streamlined position with tape during wing removal to prevent damage, since flap will swing freely.

- h. Remove nut, washer and bolt attaching front fuel spar to fuselage.
- i. Remove bolts, washers and retainers holding main spar dowel pins in position.
- j. Support wing at inboard and outboard ends, and

MODEL 210 & T210 SERIES SERVICE MANUAL

remove dowel pins that attach main wing spar to fuselage. It is recommended to remove the top dowel pin first, then lower outboard end of wing before removing bottom dowel pin.

NOTE

It may be necessary to use a long punch to drive out main wing spar attaching dowel pins, or to rock wing slightly while removing pins. Care must be taken not to damage dowel pins, spar fittings or spar carry-thru fittings as these are reamed holes and close tolerance dowel pins.

k. Remove wing and lay on padded stand.

4-5. REPAIR. A damaged wing panel may be repaired in accordance with instructions outlined in Section 18. Extensive repairs of wing skin or structure are best accomplished by using the wing repair jig, which may be obtained from Cessna. The jig serves not only as a holding fixture, making work on the wing easier, but also assures absolute alignment of the repaired wing.

4-6. INSTALLATION.

NOTE

Refer to figure 4-1 for lubrication of dowel pins prior to installation.

- a. Hold wing in position with wing tip low.
- b. Install:
 1. Dowel pins attaching main spar to fuselage. (Install bottom pin first, then rotate wing tip up, and install top pin.)
 2. Bolts, washers and nuts that hold main spar attach dowel pins in position.
 3. Front fuel spar attach bolt, washer and nut.
- c. Route flap and aileron cables and make proper connections.
- d. Connect:
 1. Electric wires at wing root disconnects.
 2. Fuel lines at wing root.
 3. Pitot line (if left wing is being installed.)
 4. Cabin ventilator hose at wing root.
 5. Oxygen filler line at tee in cabin top area.

CAUTION

Be sure to turn valves counterclockwise on three oxygen cylinders to turn on filler line pressure. Refer to Section 15 for a complete oxygen system leak test prior to installing headliner.

- e. Rig aileron system (Section 6).
- f. Rig flap system (Section 7).
- g. Refill fuel bays and check all connections for leaks.

NOTE

If a new wing is being installed, it will be necessary to calibrate the fuel control monitor in the cabin ceiling area. Refer to Section 16 for calibration procedure.

- h. Check operation of navigation, courtesy and landing lights.
- i. Check operation of fuel quantity indicator.
- j. Install wing gap fairings and fillets.

NOTE

Be sure to install soundproofing panel in wing gap before replacing fairing.

k. Install headliner, interior panels, upholstery and inspection plates.

- l. Test operation of flap and aileron systems.

4-7. ADJUSTMENT (CORRECTING "WING-HEAVY" CONDITION). If considerable control wheel pressure is required to keep the wings level in normal flight, a wing-heavy condition exists. Refer to Section 6 for adjustment of aileron tabs.

4-8. VERTICAL FIN. (See figure 4-2.)

4-9. DESCRIPTION. The fin is primarily of metal construction, consisting of ribs and spars covered with skin. Fin tips are glass fiber/ABS construction. Hinge brackets at the rear spar attach the rudder.

4-10. REMOVAL. The fin may be removed without first removing the rudder. However, for access and ease of handling, the rudder may be removed if desired, following the procedures outlined in Section 10.

- a. Remove fairings on both sides of fin.
- b. Disconnect flashing beacon lead, tail navigation light lead, antennas and antenna leads and rudder cables if rudder has not been removed.
- c. Remove screws attaching dorsal fin to fuselage.
- d. Remove bolts attaching fin front and rear spars to fuselage.
- e. Remove fin.

4-11. REPAIR. A damaged fin may be repaired in accordance with applicable instructions outlined in Section 18.

4-12. INSTALLATION. Reverse procedures outlined in paragraph 4-10 to install the fin. Be sure to check and reset rudder and elevator travel if any stop bolts were removed or settings disturbed. Refer to Sections 8 and 10 respectively for setting elevator and rudder travel. Refer to figure 1-1 for control surface travels.

4-13. HORIZONTAL STABILIZER. (See figure 4-3.)

4-14. DESCRIPTION. The horizontal stabilizer is

MODEL 210 & T210 SERIES SERVICE MANUAL

primarily of metal construction, consisting of ribs and a front and rear spar which extends throughout the full span of the stabilizer. The skin is riveted to both spars and ribs. Stabilizer tips are constructed of ABS. The elevator tab actuator screw is contained within the horizontal stabilizer assembly, and is supported by a bracket riveted to the rear spar. The underside of the stabilizer contains an opening which provides access to the elevator tab actuator screw. Hinges on the rear spar support the elevator.

4-15. REMOVAL.

- a. Remove elevators and rudder in accordance with procedures outlined in Sections 8 and 10.
- b. Remove vertical fin in accordance with procedures outlined in paragraph 4-10.
- c. Disconnect elevator trim control cables at clevis, turnbuckle and clamps inside tailcone, remove pulleys which route the aft cables into horizontal stabilizer, and pull cables out of tailcone.
- d. Remove bolts securing horizontal stabilizer to fuselage.
- e. Remove horizontal stabilizer.

4-16. REPAIR. A damaged horizontal stabilizer may be repaired in accordance with applicable instructions outlined in Section 18.

4-17. INSTALLATION. Reverse the procedures outlined in paragraph 4-15 to install the horizontal stabilizer. Rig the control systems as necessary, following instructions outlined in applicable sections. Set control surface travels to values listed in figure 1-1.

4-18. STABILIZER ABRASION BOOTS.

NOTE

Accessory Kit AK182-217 is no longer available from Cessna for installation of abrasion boots. Order two abrasion boots (P/N 1232040-5) and one cement (P/N EC1300LP), available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations, for installation of abrasion boots on aircraft not so equipped.

4-19. DESCRIPTION. The aircraft may be equipped with two extruded rubber abrasion boots, one on the leading edge of each horizontal stabilizer. These boots are installed to protect the stabilizer leading edge from damage caused by rocks thrown back by the propeller.

4-20. REMOVAL. The abrasion boots can be removed by loosening one end of the boot and pulling it off the stabilizer with an even pressure. Excess adhesive or rubber can be removed with Methyl-Ethyl-Ketone.

4-21. INSTALLATION. Install abrasion boots as outlined in the following procedures.

- a. Trim boots to desired length.
- b. Mask off boot area on leading edge of stabilizer with one-inch masking tape, allowing 1/4-inch margin.
- c. Clean metal surfaces of stabilizer, where boot is to be installed, with Methyl-Ethyl-Ketone.
- d. Clean inside of abrasion boot with Methyl-Ethyl-Ketone and a Scotch Brite pad to ensure complete removal of paraffin/talc. Then a normal wipe down with MEK on a cloth will leave surface suitable for bonding to the aluminum.

NOTE

Boots may be applied over epoxy primer, but if the surface has been painted, the paint shall be removed from the bond area. This shall be done by wiping the surfaces with a clean, lint-free rag, soaked with solvent, and then wiping the surfaces dry, before the solvent has time to evaporate, with a clean, dry lint-free rag.

- e. Stir cement (EC-1300, Minnesota Mining and Manufacturing Co.) thoroughly.
- f. Apply one even brush coat to the metal and the inner surface of the boot. Allow cement to air-dry for a minimum of 30 minutes, and then apply a second coat to each surface. Allow at least 30 minutes (preferably one hour) for drying.
- g. After the cement has thoroughly dried, reactivate the surface of the cement on the stabilizer, and boot, using a clean, lint-free cloth, heavily moistened with Toluol. Avoid excess rubbing, which would remove the cement from the surfaces.
- h. Position the boot against leading edge, exercising care not to trap air between boot and stabilizer.

NOTE

Should boot be attached "off-course", pull it up immediately, with a quick motion, and reposition it properly.

- i. Press roll entire surface of boot to assure positive contact between the two surfaces.
- j. Apply a coat of GACO N700A sealer, or equivalent, conforming to MIL-C-21067, along the trailing edges of the boot to the surface of the skin to form a neat, straight fillet.
- k. Remove masking tape and clean stabilizer of excess material.
- l. Mask to the edge of the boot for painting stabilizer.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 4-1. Wing Installation

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 4-2. Vertical Fin Installation

MODEL 210 & T210 SERIES SERVICE MANUAL



- 1. Nut
- 2. Washer
- 3. Bolt
- 4. Bracket
- 5. Nut
- 6. Washer
- 7. Bushing

- 8. Bracket
- 9. Bolt
- 10. Elevator Pylon Bracket
- 11. Elevator Inboard Hinge
- 12. Elevator Outboard Hinge
- 13. Stabilizer Assembly
- 14. Lower Left Fairing

- 15. Lower Right Fairing
- 16. Forward Left Fairing
- 17. Forward Right Fairing
- 18. Upper Right Fairing
- 19. Upper Left Fairing
- 20. Bulkhead
- 21. Nutplate

Figure 4-3. Horizontal Stabilizer Installation

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 5

LANDING GEAR, BRAKES AND HYDRAULIC SYSTEM (THRU 1978 MODELS)

WARNING

When performing any inspection or maintenance that requires turning on the master switch, installing a battery, or pulling the propeller through by hand, treat the propeller as if the ignition switch were ON. Do not stand nor allow anyone else to stand, within the arc of the propeller, since a loose or broken wire or a component malfunction could cause the propeller to rotate.

NOTE

Beginning with 1979 models, major changes were made in the aircraft hydraulic system. To avoid the confusion of serialization, Section 5A has been added following this section. Section 5A covers 1979 and ON changes. However Section 5 contains information which is still applicable to the aircraft described in Section 5A. To avoid repetition of information in Section 5A, the reader is referred back to this section.

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
LANDING GEAR SYSTEM	1E7/5-3	Main Landing Gear Door System	1F2/5-21
Description	1E7/5-3	Description	1F2/5-21
System Operation (Thru		Removal/Installation of	
21062273)	1E8/5-4	Strut and Wheel Doors	1F2/5-21
System Operation (Beginning		Strut Door Actuator	
with 21062274)	1E8/5-4	Removal/Installation	1F2/5-21
Trouble Shooting	1E9/5-4	Strut Door Actuator	
Main Landing Gear	1E16/5-12	Disassembly	1F2/5-21
Description	1E16/5-12	Inspection	1F2/5-21
Main Gear Strut Removal	1E17/5-13	Reassembly	1F2/5-21
Main Gear Strut Installation	1E17/5-13	Wheel Door Actuator	
Main Landing Gear Actuator		Removal	1F2/5-21
Removal	1E17/5-13	Disassembly (Thru	
Disassembly	1E17/5-13	21062273)	1F2/5-21
Inspection of Parts	1E17/5-13	Inspection (Thru	
Parts Repair/Replacement	1E19/5-15	21062273)	1F2/5-21
Reassembly	1E19/5-15	Reassembly (Thru	
Installation	1E20/5-16	21062273)	1F4/5-22A
Strut-to-Actuator Linkage	1E21/5-17	Disassembly (Beginning	
Description	1E21/5-17	with 21062274)	1F4/5-22A
Pivot Assembly Removal	1E21/5-17	Inspection (Beginning	
Pivot Assembly Installation	1E21/5-17	with 21062274)	1F4/5-22A
Main Gear Uplock Mechanism		Reassembly (Beginning	
Description	1E21/5-17	with 21062274)	1F4/5-22A
Removal/Installation	1E21/5-17	Main Wheel and Tire Assembly	
Uplock Actuator	1E21/5-17	Description	1F4/5-22A
Disassembly	1E21/5-17	Removal	1F4/5-22A
Inspection of Parts	1E22/5-18	Cleveland Main Wheel	
Reassembly	1E22/5-18	and Tire Disassembly	1F7/5-24
Main Gear Downlock		Inspection/Repair	1F7/5-24
Mechanism	1E23/5-19	Reassembly	1F9/5-26
Description	1E23/5-19	McCauley Two-Piece	
Removal/Installation		Main Wheel and Tire	
of Components	1E23/5-19	Disassembly	1F9/5-26
Downlock Actuator	1F1/5-20A	Inspection/Repair	1F9/5-26
Disassembly	1F1/5-20A	Reassembly	1F9/5-26
Inspection/Repair	1F1/5-20A	McCauley Three-Piece	
Reassembly	1F1/5-20A	Main Wheel and Tire	
		Disassembly	1F11/5-26B

MODEL 210 & T210 SERIES SERVICE MANUAL

TABLE OF CONTENTS	Page No. Aerofiche/Manual		Page No.
Inspection/Repair	1F11/5-26B	Torque Links	1G3/5-41
Reassembly	1F11/5-26B	Description	1G3/5-41
Installation	1F11/5-26B	Removal	1G4/5-42
Main Wheel Door Close System		Disassembly/Reassembly	1G4/5-42
Accumulator	1F12/5-27	Installation	1G4/5-42
Description	1F12/5-27	Nose Gear Uplock Mechanism	1G5/5-43
Removal	1F12/5-27	Description	1G5/5-43
Disassembly/Reassembly	1F12/5-27	Removal	1G5/5-43
Installation	1F12/5-27	Installation	1G5/5-43
Main Wheel Door Close System		Nose Gear Downlock Mechanism	1G5/5-43
Accumulator	1F12/5-27	Description	1G5/5-43
Description	1F12/5-27	Removal/Installation	1G5/5-43
Removal	1F12/5-27	Nose Gear Actuator	1G5/5-43
Disassembly/Reassembly	1F12/5-27	Description	1G5/5-43
Installation	1F12/5-27	Removal	1G7/5-45
Main Wheel and Axle Removal	1F12/5-27	Disassembly	1G7/5-45
Installation	1F12/5-27	Inspection/Repair of Parts	1G7/5-45
Main Wheel Alignment	1F14/5-29	Assembly	1G8/5-46
Wheel Balancing	1F14/5-29	Installation	1G8/5-46
Brake System	1F14/5-29	Uplock and Release Actuator	
Description	1F14/5-29	Removal/Installation	1G8/5-46
Trouble Shooting	1F14/5-29	Disassembly/Inspection/ Repair/Reassembly	1G8/5-46
Brake Master Cylinder	1F16/5-31	Nose Gear Door System	1G8/5-46
Description	1F16/5-31	Description	1G8/5-46
Removal	1F16/5-31	Operation	1G8/5-46
Disassembly	1F17/5-32	Removal/Installation	1G8/5-46
Inspection/Repair	1F17/5-32	Door Mechanism Removal/ Installation	1G8/5-46
Reassembly	1F17/5-32	Nose Gear Strut Door	
Installation	1F17/5-32	Removal/Installation	1G10/5-48
Hydraulic Brake Lines	1F17/5-32	Nose Wheel Steering System	1G10/5-48
Description	1F17/5-32	Description	1G10/5-48
Wheel Brake Assemblies	1F17/5-32	Removal/Installation of Components	1G10/5-48
Description	1F17/5-32	Rigging	1G10/5-48
Removal	1F17/5-32	Trouble Shooting	1G10/5-48
Disassembly	1F17/5-32	Nose Wheel and Tire Assembly	1G10/5-48
Inspection/Repair	1F17/5-32	Description	1G10/5-48
Reassembly	1F19/5-34	Operation	1G11/5-49
Installation	1F19/5-34	Removal	1G11/5-49
Brake Linings	1F19/5-34	Cleveland	
Non-Asbestos Organic or Metallic Brake Linings	1F19/5-34	Disassembly	1G12/5-50
Checking Lining Wear	1F20/5-34A	Inspection/Repair	1G12/5-50
Brake Lining Installation	1F20/5-34A	Reassembly	1G12/5-50
Brake System Bleeding	1F20/5-34A	McCauley	
Parking Brake System	1F20/5-34A	Disassembly	1G12/5-50
Description	1F20/5-34A	Inspection/Repair	1G12/5-50
Removal/Installation of Components	1F20/5-34A	Reassembly	1G12/5-50
Inspection/Repair of Components	1F22/5-36	Installation	1G13/5-51
Nose Gear System	1F22/5-36	Hydraulic Power System	1G13/5-51
Description	1F22/5-36	General Description	1G13/5-51
Operation	1F22/5-36	Components Repair	1G13/5-51
Trouble Shooting	1F22/5-36	Repair Versus Replacement	1G13/5-51
Nose Gear Assembly Removal	1F22/5-36	Repair Parts and Equipment	1G13/5-51
Disassembly of Nose Gear Strut	1F24/5-38	Equipment and Tools	1G13/5-51
Inspection/Repair of Shock Strut	1F24/5-38	Hand Tools	1G13/5-51
Reassembly	1F24/5-38	Compressed Air	1G13/5-51
Installation	1G2/5-40	Hydraulic System Leak Check	1G13/5-51
Shimmy Dampener	1G2/5-40	Power Pack	1G14/5-52
Description	1G2/5-40	Description	1G14/5-52
Removal	1G2/5-40	On-Aircraft Hydraulic Power Pack Operational Checks	1G14/5-52
Disassembly	1G2/5-40	Removal	1G14/5-52
Inspection/Repair	1G3/5-41	Disassembly	1G20/5-56
Reassembly	1G3/5-41	Inspection/Repair of Components	1G20/5-56
		Reassembly	1G20/5-56

MODEL 210 & T210 SERIES SERVICE MANUAL

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
Installation of Power Pack	1G22/5-58	Inspection/Repair	1H3/5-61
Pressure Switch	1G22/5-58	Reassembly	1H3/5-61
Description	1G22/5-58	Adjustment	1H6/5-64
Disassembly	1G22/5-58	Door Manifold Assembly	1H6/5-64
Cleaning/Inspection/ Repair	1G22/5-58	Disassembly	1H6/5-64
Assembly	1G22/5-58	Cleaning/Inspection of Components	1H6/5-64
Adjustment	1G23/5-59	Reassembly	1H6/5-64
Relief Valve and Thermal Relief Valve Assemblies	1G23/5-59	Landing Gear Hand Pump	1H6/5-64
Bench Check of Relief Valve and Thermal Relief Valve	1G23/5-59	Description	1H6/5-64
Disassembly	1G24/5-60	Removal	1H6/5-64
Inspection	1G24/5-60	Disassembly	1H6/5-64
Assembly and Adjustment	1G24/5-60	Inspection of Components	1H7/5-65
Door System Thermal Relief Valve	1G24/5-60	Reassembly	1H7/5-65
Landing Gear and Door Manifold Assemblies	1G24/5-60	Installation	1H7/5-65
Description	1G24/5-60	Landing Gear Position Selector Valve	1H8/5-66
Solenoids	1G24/5-60	Removal/Installation	1H8/5-66
Disassembly	1G24/5-60	Disassembly/Reassembly	1H8/5-66
Inspection/Cleaning of Components	1G24/5-60	Inspection of Parts	1H8/5-66
Assembly	1G24/5-60	Strut Step Installation	1H8/5-66
Landing Gear Manifold (Thru 21062273)	1G24/5-60	Rigging Throttle-Operated Microswitches	1H10/5-68
Disassembly	1G24/5-60	Rigging of Main Landing Gear	1H10/5-68
Inspection/Repair	1H1/5-60A	Rigging of Nose Landing Gear	1H20/5-78
Reassembly	1H3/5-61	Rigging of Nose Gear Doors	1H20/5-78
Landing Gear Manifold (Beginning with 21062274)	1H3/5-61	Rigging of Nose Gear Limit Switches	1H20/5-78
Disassembly	1H3/5-61	Rigging of Nose Gear Squat Switch	1H20/5-78
		Rigging Retractable Step Cable Assembly	1H20/5-78
		Hydraulic and Electric System Schematics	1H23/5-81

It is sometimes necessary to open the landing gear doors while the aircraft is on the ground with the engine stopped. Operate the doors with the landing gear handle in the "DOWN" position. Except on aircraft 21062274 thru 21062954, to open the doors, turn off the master switch and operate the hand pump until the doors are open. To close the doors, turn the master switch on. On aircraft 21062274 thru 21062954, the hand pump is required to open and close the doors.

Position of the master switch for gear door operation is easily remembered by the following rule: OPEN CIRCUIT = OPEN DOORS; CLOSED CIRCUIT = CLOSED DOORS.

WARNING

Before working in landing gear wheel wells, PULL-OFF hydraulic pump circuit breakers. Thru Serial 21062273, the pump circuit breaker is located in the circuit breaker panel, located immediately forward of the pilot's control wheel. Beginning with Serial 21062274, the pump circuit breaker is located in the circuit breaker panel, located immediately forward of the left forward doorpost. The hydro-electric power pack system is designed to pressurize the landing gear DOOR CLOSE system to 1500 PSI at any time the master switch is turned on. Injury might occur to someone working in wheel well area if master switch is turned on for any reason.

5-1. LANDING GEAR SYSTEM.

5-2. DESCRIPTION. (Refer to Hydraulic and Electric System Schematic, figure 5-37.) A hydraulically-

operated, retractable landing gear is employed on the aircraft. The hydraulic power system includes equipment required to provide a flow of pressurized hydraulic fluid to the landing gear system. The Cessna-manufactured, self-contained, hydro-electric pack is located in the pedestal, with the hand pump remotely located between the two front seats on the floorboard. The gear selector handle is located on the lower lefthand switch panel. A circuit breaker, protecting the pump, is located in the circuit breaker panel, located immediately forward of the pilot's control wheel thru Serial 21062273. Beginning with Serial 21062274, the pump circuit breaker is in the circuit breaker panel, located immediately forward of the left-hand forward doorpost. It is necessary to pull out on the gear selector handle prior to moving the handle up or down. The handle is fitted with a small wheel for easy identification and assisting in holding the handle in rough air. The right side of the pedestal cover is fitted with a quick-removable access door for checking and servicing the hydraulic fluid level. The selector handle controls the gear position through an electrical switch thru Serial 21062273 and by means of a hydraulic shuttle valve on aircraft beginning with Serial 21062274.

MODEL 210 & T210 SERIES SERVICE MANUAL

5-3. SYSTEM OPERATION. (Thru Serial 21062273)

NOTE

Refer to the hydraulic schematic diagrams at the end of this section to trace the flow of hydraulic fluid as outlined in the following paragraph.

When the aircraft master switch is closed, the hydraulic power pack is ready to operate. When the gear-up position is selected with the selector switch, the gear valve solenoid connects the gear-up line to the system pressure, and the gear-down line to return. At the same time, the electric motor that powers the hydraulic pump is turned on. The hydraulic pressure is passed through a filter, and is then divided between the gear valve and door valve. Before hydraulic pressure can reach the gear valve, a priority valve must open. The priority valve can open only under two conditions:

1. There can be no pressure in the door close line, because door close pressure is applied to a piston to hold priority valve closed.

2. System pressure must build up to 750 psig before the valve can open.

Pressure therefore, must go to the door-open line. Pressure in the door-close line is prevented from returning by the door-close lock check valve, and the valve is opened by a piston that senses door-open pressure. When the pressure reaches 400 psig, the door-close lock check valve opens and the doors on the aircraft open. At 750 psig, the priority valve opens and the landing gear begins to retract. As soon as the landing gear is locked in the UP position, the landing gear up limit switches sequence the door solenoid valve to the door close position. When pressure in the door-close line reaches 1500 psig, the pressure switch shuts off the motor and the GEAR-DOWN cycle is similar to the GEAR-UP cycle, except the gear solenoid is not energized during the gear-down cycle. The system has been designed so that at any time during system operation, the direction of system of operation may be reversed. Under these conditions, the first operation of the system after the selector switch is moved is to completely open the doors, and then move the gear into the newly-selected position, after which, the doors will close again. There is no danger of interference between the gear and doors of the aircraft, since the gear does not receive hydraulic pressure unless the doors are in the fully-opened position.

5-3A. SYSTEM OPERATION. (Beginning with Serial 21062274)

NOTE

Refer to the hydraulic schematic diagrams at the end of this section to trace the flow of hydraulic fluid as outlined in the following paragraph.

When the aircraft master switch is closed, the hydraulic power pack is ready to operate. When the gear-up position is selected with the selector handle the selector valve connects the gear-up line to the system pressure, and the gear-down line to return. At the same time, the electric motor that powers the hydraulic pump is turned on. The hydraulic pressure is passed through a filter, and is then divided between the selector valve and door valve. Before hydraulic pressure can reach the selector valve, a priority valve must open. The priority valve can open only under two conditions:

1. There can be no pressure in the door close line, because door close pressure is applied to a piston to hold priority valve closed.

2. System pressure must build up to 750 psig before the valve can open. Pressure therefore, must go to the door-open line. Pressure in the door-close line is prevented from returning by the door-close lock check valve, and the valve is opened by a piston that senses door-open pressure. When the pressure reaches 400 psig, the door-close lock check valve opens and the doors on the aircraft open. At 750 psig, the priority valve opens and the landing gear begins to retract. As soon as the landing gear is locked in the UP position, the landing gear up limit switches sequence the door solenoid valve to the door close position. When pressure in the door-close line reaches 1500 psig, the pressure switch shuts off the motor and the GEAR-DOWN cycle is similar to the GEAR-UP cycle. The system has been designed so that at any time during system operation, the direction of system of operation may be reversed. Under these conditions, the first operation of the system after the selector handle is moved is to completely open the doors, and then move the gear into the newly-selected position, after which, the doors will close again. There is no danger of interference between the gear and doors of the aircraft, since the gear does not receive hydraulic pressure unless the doors are in the fully-opened position.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

5-4. TROUBLE SHOOTING.

Just because this chart lists a probable cause, proper checkout procedures cannot be deleted and the replacement of a part is not necessarily the proper solution to the problem. The mechanic should always look for obvious problems such as loose or broken parts, external leaks, broken wiring, etc. To find the exact cause of a problem, a mechanic should use a hand pump, pressure gage and a voltmeter to isolate each item in the system. Hydraulic fluid will foam if air is pumped into system, causing fluid to be blown overboard thru pack vent line.

The problems listed are all with the systems controls in their normal operating position: Master switch ON, hydraulic pump breaker IN and landing gear breaker IN. During landing gear system servicing, a power supply capable of maintaining 27.5 volts throughout the gear cycle must be used to augment the ship's battery.

CAUTION

Prior to using Hydro-Test unit with power pack, remove and dry off filler plug and dipstick. Adjust cap tension so that no movement of cap is apparent. Failure to accomplish these procedures could result in filler cap coming loose from power pack.

TROUBLE	PROBABLE CAUSE	REMEDY
MOTOR PUMP WILL NOT OPERATE GEAR BUT EMERGENCY HAND PUMP WILL OPERATE GEAR.	Low voltage (in flight).	Check alternator and wiring.
	Fluid level low in reservoir.	Refill reservoir.
	Motor pump failure.	Replace pump.
	Faulty check valve	Replace valve
	Loose or clogged suction screen assembly in power pack	Remove power pack, disassemble and clean suction screen. Check screen for contamination, determine cause of contamination and remedy. Replace screen assembly or seal existing assembly. Prime parts to be assembled with Grade T Primer, using care to avoid getting primer on screen. Seal with hydraulic sealant (Catalog #69; Loctite Corp.) upon installation. Allow 15-30 minutes cure time if primed; 2-4 hours if unprimed.
	NOTE	
	Motor and pump are not repairable and must be replaced.	
	Pump frozen.	Remove motor and coupling from top of power pack and replace pump.
Broken pump or motor drive shaft or coupling.	Remove motor and pump from top of power pack and replace motor, pump and coupling.	

MODEL 210 & T210 SERIES SERVICE MANUAL

TROUBLE SHOOTING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
MOTOR PUMP WILL NOT OPERATE GEAR BUT EMERGENCY HAND PUMP WILL OPERATE GEAR (Cont).	If motor was not turning, check wiring and motor.	Check motor for loose or broken connections; check for frozen pump or coupling. Check circuit breaker in pedestal.
	Bad pump shaft seal.	Replace pump.
	External leakage around top of pump assembly	Remove motor and pump assemblies from top of power pack and replace upper packing and/or back-up rings
	Air lock in pump (new pack installation or pump replacement).	Remove filter and intermittently bump start switch until fluid flows. Replace filter.
	Bad pump body O-rings	Remove motor and pump assemblies from top of power pack and replace lower packing and/or back-up rings
PUMP OR EMERGENCY PUMP WILL NOT BUILD PRESSURE IN SYSTEM.	No fluid in reservoir.	Refill reservoir.
	Broken hydraulic line.	Check for evidence of leakage and repair or replace line. Flush out system and refill reservoir.
	Filter in outlet check valve improperly positioned in filter body, or seal between filter and check valve improperly positioned.	Replace seal and position filter in retainer with Petrolatum.
	Bad O-ring actuator piston; O-ring left out after repair.	Disconnect line upstream from actuator and check for pressure. Perform this check for all actuators in system.
	Bad O-ring on priority valve in gear manifold assembly. O-ring left out or damaged during repair of valve.	Disassemble manifold and replace O-ring.
	Bad O-ring on gear or door control valve.	Replace O-ring.
	Thermal relief valve stuck open.	Replace valve.
DOORS WILL NOT CLOSE GEAR INDICATOR LIGHT NOT ILLUMINATED.	Master switch not on.	Turn master switch on.
	Broken or loose door close hydraulic line.	Locate and repair or replace defective line.

MODEL 210 & T210 SERIES SERVICE MANUAL

TROUBLE SHOOTING (Cont)

TROUBLE	PROBABLE CAUSE	REMEDY
DOORS WILL NOT CLOSE GEAR INDICATOR LIGHT NOT ILLUMINATED. (Cont)	Defective limit switch circuit.	Check limit switch settings; locate and repair or replace limit switch circuit.
	Landing gear did not lock into position.	Check landing gear uplock and/or downlock mechanism for proper operation.
	Broken ground wire at socket or lamp not making contact in socket.	Repair or replace wire; check lamp contact.
GEAR AND DOORS OPERATE PROPERLY BUT INDICATOR LIGHT IS NOT ILLUMINATED.	Lamp burned out.	Replace lamp.
	Defective wiring.	Check circuit and repair wiring.
	NOTE If press-to-test operates, pull wire bundle toward lamp socket.	
DOORS WILL NOT CLOSE GEAR INDICATOR LIGHT IS ILLUMINATED.	Improper wiring at gear control switch.	Check circuitry and repair or rewire.
	Door control valve stuck.	Repair or replace control valve unit.
	Broken or loose door lines.	Tighten or replace lines.
PUMP OPERATES BUT DOORS WILL NOT OPEN	Refer to second listed trouble in this chart.	Use same remedies.
	Improper wiring installation.	Check door control valve wiring circuitry.
	Door solenoid valve jammed or stuck in door - close position.	Disassemble valve and replace defective parts.
	Crossed hydraulic lines in aircraft belly.	Most common place is aft and left of hand pump.
GEAR UNLOCKS BEFORE DOORS ARE FULLY OPEN.	Priority valve setting too low.	Check for weak spring, dull seat or replace entire valve.
	Binding in door system.	Disconnect door actuators and manually move doors and check for binding in linkage.
	Stiff operation of door actuators.	Check operation of actuator piston and rod.

MODEL 210 & T210 SERIES SERVICE MANUAL

TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
GEAR UNLOCKS BEFORE DOORS ARE FULLY OPEN.	Restriction in door open or door close line.	Using pressure gage, check pressure in door open or door close line, when gear unlocks. If pressure is greater than 700 psi, check for restrictions. Locate restrictions and remove. If contaminants are in line, investigate cause and remedy; flush system.
DOORS OPEN BUT GEAR DOES NOT OPERATE.	Improper wiring.	Check circuitry, using wiring diagrams in this Section or Section 20.
	Gear solenoid jammed or stuck (Thru Serial 21062273)	Disassemble valve and replace defective parts.
	Shorted gear control switch. (Thru Serial 21062273)	Check switch circuitry.
	Priority valve setting too high or stuck closed.	Check valve componets for defects. Replace as necessary.
	Faulty O-rings downstream of priority valve (anywhere in system).	Locate faulty unit and replace O-rings.
DOORS OPEN BUT GEAR DOES NOT OPERATE (DOWN AND LOCKED ONLY).	Faulty or stuck squat switch.	Check switch wiring or setting.
HAND PUMP DOES NOT BUILD PRESSURE, BUT ELECTRIC PUMP OPERATES PROPERLY.	Check valve in hand pump sticking.	Inspect check valve.
	Defective hand pump outlet check valve.	Replace valve.
	Main gear or downlock actuator O-ring leaking.	Disassemble actuator and replace O-rings.
LANDING GEAR OPERATION EXTREMELY SLOW.	Fluid level low in reservoir.	Refill reservoir.
	Downlock rod adjustment incorrect (mainly LH rod).	Adjust rod end to lengthen actuator one turn.
	Pump failure.	Replace pump.
	Low voltage in electrical system.	Check alternator and wiring.
	Pump motor brushes worn.	Replace pump motor.
	Downlocks not in full unlock position.	Adjust downlocks.
	Fluid leak in door or gear line.	Locate and repair or replace broken line or fitting.

MODEL 210 & T210 SERIES SERVICE MANUAL

TROUBLE SHOOTING (Cont)

TROUBLE	PROBABLE CAUSE	REMEDY
LANDING GEAR OPERATION EXTREMELY SLOW (Cont)	Air leakage around pump suction screen assembly.	Either replace suction screen assembly or seal and install existing assembly as follows: Prime parts to be assembled with Grade T Primer, using care to avoid getting primer on screen. Seal with hydraulic sealant (Catalog #69; Loctite Corp.) upon installation. Allow 15-30 minutes cure time if primed; 2-4 hours if unprimed.
	Defective piston seal in gear or door cylinder.	Replace with new seal.
	Excessive internal power pack leakage.	Remove and repair or replace power pack.
PUMP OPERATES, DOORS OPEN AND GEAR STARTS TO EXTEND. DOORS CLOSE BEFORE GEAR IS COMPLETELY EXTENDED; HAND PUMP WILL NOT PUMP GEAR DOWN.	Downlock switch makes contact before gear is down and locked.	Reset downlock actuator switches; replace if damaged.
	Interference between downlock and gear saddle clamp bolt head.	Remove interference.
POWER PACK EXTERNAL LEAKAGE.	Static seals (all fittings).	Remove and replace O-rings and/or back-up rings as required. Check tubing flares for leaks.
	Gear or door solenoid.	Replace O-rings.
	Transfer tubes between manifold and power pack body.	Disassemble power pack and replace O-rings.
	Reservoir cover.	Remove power pack and remove cover; replace seals.
GEAR DOWN-LOCK WILL NOT RETURN TO FULL-LOCK POSITION.	Binding in spring and tube assemblies.	Check operation to locate binding and eliminate.
DOORS CLOSE BEFORE ALL GEARS ARE FULLY LOCKED.	Faulty limit switch.	Replace switch.
	Short in wiring.	Check wiring continuity.
	Cracked terminal block.	Replace terminal block.
DOORS WILL OPEN BUT GEAR WILL NOT RETRACT.	Lines between downlock actuators crossed.	Properly route lines.
	Lines crossed at gear uplock valve.	Properly route lines.
	Gear uplock valve installed backward.	Install properly.

MODEL 210 & T210 SERIES SERVICE MANUAL

TROUBLE SHOOTING (Cont)

TROUBLE	PROBABLE CAUSE	REMEDY
DOORS WILL OPEN BUT GEAR WILL NOT RETRACT (Cont).	Improper setting of right and left downlock actuators.	Reset in accordance with applicable paragraph in this Section.
NOSE GEAR WILL NOT UPLOCK IN FLIGHT.	Restricted line.	Blow out line.
	Faulty nose gear actuator.	Replace actuator.
	Improper setting of downlock.	Reset in accordance with applicable paragraph in this Section.
	NOTE On ground test, nose gear should have constant movement from downlock to uplock position.	
NOSE WHEEL DOOR AND MAIN WHEEL DOORS OPERATE IN REVERSE.	Crossed lines.	Check main gear door lines in wheel well at forward bulkhead; lines are very easy to cross at this location.
NOSE GEAR HITS HARD IN UPLOCK POSITION.	RH downlock actuator improperly rigged.	Reset RH downlock actuator.
RH GEAR UNLOCKS BUT LH GEAR WILL NOT UNLOCK.	Improper setting of RH downlock actuator rod.	Check rigging procedures outlined in this Section.
BOTH RH AND LH MAIN GEAR UNLOCK BUT ONLY NOSE GEAR WILL RETRACT.	Improper setting of LH downlock actuator rod.	Check rigging procedures outlined in this Section.
MOTOR PUMP TURNS OFF AFTER GEARS UNLOCK; WILL NOT TURN ON BY WORKING SELECTOR SWITCH. HAND PUMP WILL PUT GEAR DOWN.	Defective pressure switch circuit.	Check circuit continuity.
		Check switch adjustment
POWER PACK WILL OPERATE SYSTEM AFTER BEING STARTED BY HAND PUMP.	Broken wire or defective diode in wire from "DOWN" side of selector switch to contactor. (Refer to wiring diagrams in this Section or Section 20.)	Replace diode. Repair or replace wiring.
SET SCREW ON CAM NOT EXTENDED ENOUGH FOR GEAR TO MOVE CAM OVER CENTER.	Check washers under bolt on downlock arm assembly.	Add AN960-10 washer under bolt downlock arm assembly
MAIN GEAR WILL NOT LOCK OVER CENTER.	Main gear not centered in support.	Rerig saddle per rigging instructions.
MAIN GEARS HIT UPLOCK HOOK VERY HARD.	Insufficient main gear actuator snubbing action.	Adjust flow control valve in gear manifold.

MODEL 210 & T210 SERIES SERVICE MANUAL

TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
MALFUNCTION OF GEAR INDICATOR LIGHTS.	<ol style="list-style-type: none"> 1. Both lights on at same time. 2. Light will change from green to amber or in reverse when gear control switch is moved. 	Check ground wire for proper connection.
<p>SYSTEM WORKS NORMALLY EXCEPT MOTOR TURNS ON AND OFF AT REGULAR INTERVALS. (GEAR IN EITHER UP OR DOWN POSITION). GEAR DOORS SAG WHILE AIRCRAFT IS ON GROUND. ENGINE AND ELECTRICITY OFF.</p> <p style="text-align: right;">Leak in door close system. Refer to the following procedure and to figures 5-27 and 5-33A.</p> <ol style="list-style-type: none"> 1. Support aircraft on jacks or secure tail in the event something might unlock nose wheel and allow it to collapse. 2. Remove console cover and sheet metal cover from power pack support. 3. Master switch OFF. 4. Remove cap from pressure port on pedestal structure and install pressure gage to port. 5. Open doors as required to bleed any pressure in system. 6. Remove hand pump line from power pack port fitting (left-hand aft fitting). 7. Attach flex line to disconnected line. (have port open) 8. Remove door close line from its fitting on power pack (left hand forward fitting). 9. Connect flex line to door close port (fitting) on power pack and pressurize to 1500 psi with hand pump. 10. Observe pressure gage for leak-down; pressure should hold for better than 10 minutes. <ol style="list-style-type: none"> (a) Master switch OFF - if leakage comes from hand pump fitting (open) 3 or 4 drops - thermal relief valve leaking; replace. (b) No leaks above - pull hydraulic circuit breaker out, master switch ON - repressurize system with hand pump to 1500 PSI. <ol style="list-style-type: none"> 1. If hand pump port leaks in this configuration, lock out valve is leaking. 11. With the preceding checks completed, and whether leaks were found or not, make this final check while working in this area: <p style="margin-left: 20px;">Remove flex line from door fitting and attach to door line and apply pressure to system. There might be a slight bleed-down on first application of pressure pump to 1500 PSI a second time. Pressure should hold.</p> 12. The preceding procedure checks the door cylinders for leakage. If the system does not bleed down, disconnect added equipment and reconnect lines and pressure cap to pressure port and reinstall console covers. If on this last test, pressure does not hold, one or more of the door cylinders are leaking. They will have to be checked individually. TEST SYSTEM BEFORE FLIGHT. 		

MODEL 210 & T210 SERIES SERVICE MANUAL

TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
UNEVEN FALL OF MAIN GEAR.	Air in system.	Bleed system of air.
	Cold operating temperatures.	Operate power pack until fluid has reached operating temperature.
	Improper snubber adjustment.	Adjust flow control valve in gear manifold.

5-5. MAIN LANDING GEAR.

5-6. DESCRIPTION. The tubular main landing gear struts rotate aft and inboard to stow the main

wheels below the baggage compartment. Struts are down locked by an overcenter lock, actuated by a hydraulic cylinder for each strut. Uplocks are located on the main wheel stowage bay forward

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

bulkhead. Uplocking the gear pawls here, hold the struts in the stowed position. Rotation of the landing gear to extend or retract the struts is achieved through pivot assemblies, which are in turn bolted through a splined shaft, to the hydraulic rotary actuators.

5-7. MAIN GEAR STRUT REMOVAL. (See figure 5-1.)

- a. Jack aircraft in accordance with procedures outlined in Section 2.
- b. Disconnect brake line (17) at wheel cylinder and drain brake system of strut being removed.
- c. Place landing gear handle up, with master switch off, and operate emergency hand pump until main gear downlocks release.
- d. Remove bolt (31) and nut securing strut to pivot assembly (3).
- e. Work strut and wheel from pivot assembly (3).

5-8. MAIN GEAR STRUT INSTALLATION. (Refer to figure 5-1.)

NOTE

The following procedure installs the landing gear as a complete assembly. Refer to applicable paragraphs for installation of individual components.

- a. Lubricate new O-rings (19) and end of strut (5) with Petrolatum VV-P-236, hydraulic fluid MIL-L-5606, or Corning DC-7 (keep DC-7 away from areas to be painted) before installation. Install O-rings (19) on plug (20).
- b. Remove caps from brake line fitting (18) and brake line (17), attach brake line (17) to brake line fitting (18), and work plug (20) and strut (5) into pivot assembly (3).

NOTE

When installing a new pivot assembly (3), burnishing the 2-100" I.D. bore may be required to facilitate assembly of landing gear strut (5).

- c. Align hole in plug (20) with holes in pivot assembly (3) using special tool No. SE934.

NOTE

Special tool No. SE934 is available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations. This tool is designed to install strut attaching bolt without damaging the O-rings in the plug.

- d. Install the strut attaching bolt (31) by pushing the SE934 tool through the aligned holes of the pivot assembly (3), strut (5), and plug (20), with the threaded end of the bolt (31). Install and tighten nut and washer on the bolt (31).

- e. Fill and bleed brake system in accordance with paragraph 5-77 in this manual.

5-9. MAIN LANDING GEAR ACTUATOR.

5-10. REMOVAL OF MAIN GEAR ACTUATOR.

- a. Remove seats and peel back carpet as necessary to gain access to plate above actuator; remove access plate.
- b. Remove access plate from bulkhead forward of actuator.
- c. Disconnect and drain hydraulic brake line at wheel brake cylinder.
- d. Place landing gear control handle UP, with master switch off, and operate emergency hand pump until main gear downlocks release.
- e. Disconnect and cap or plug all the hydraulic lines at the actuator.
- f. Remove bolts attaching actuator mounting flange to bulkhead forging.
- g. Work actuator free of forging and pivot assembly; remove actuator.

5-11. DISASSEMBLY OF ACTUATOR. (Refer to figure 5-2.)

NOTE

Leading particulars of the actuator are as follows:

Cylinder Bore Diameter	2.250 in.
Piston Rod Diameter998 in.
Piston Stroke	2.970 in.

- a. Remove screw (23). Remove end gland (22) by unscrewing end gland from cylinder body (15).
- b. Remove end cap (6). Remove AN316-4R nuts (9), if installed, and remove cap (5) by pulling from cylinder body (15). Using a small rod, push piston (18) from cylinder body (15).
- c. Remove cap (5) from shaft (14) by removing retainer (2) and washer (3).
- d. Remove shaft (14), sector (12) and washer (11) from cylinder body (15).
- e. Remove setscrew (13) from sector (12). Remove section from shaft (14).

NOTE

Unless defective, do not remove name plate, bearing (7) and (10) or roller (8).

- f. Remove O-ring (17) and back-up ring (16) from cylinder body (15). Discard O-ring (17).
- g. Remove O-ring (20) and back-ring (21) from end gland (22). Discard O-ring (20).
- h. Remove and discard O-ring (19) from piston (18).

5-12. INSPECTION OF PARTS.

- a. Thoroughly clean all parts in cleaning solvent (Federal Specification PS-661, or equivalent.)
- b. Inspect all threaded surfaces for cleanliness, cracks and wear.
- c. Inspect cap (5), washers (3) and (11), sector (12), shaft (14), piston (18), roller (8), if removed, and cylinder body (15) for cracks, chips, scratches, scoring, wear or surface irregularities which may affect their function or the overall operation of the actuator.
- d. Inspect bearings (7) and (10), if removed, for

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-1. Main Landing Gear Installation


MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

Lubricate sector, piston, rack gears and all bearings with MIL-G-21164 lubricant during assembly of the main gear actuator.

NOTE

Install new packings, lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.



1. Bolt
2. Retainer
3. Washer
4. Washer
5. Cap
6. End Cap
7. Bearing
8. Roller
9. AN316-4R Nut
10. Bearing
11. Washer
12. Sector
13. Setscrew
14. Shaft
15. Cylinder Body
16. Back-Up Ring
17. O-Ring
18. Piston
19. O-Ring
20. O-Ring
21. Back-Up Ring
22. End Gland
23. Screw

Figure 5-2. Main Landing Gear Actuator Assembly

freedom of motion, scores, scratches or Brinnel marks.

5-13. PARTS REPAIR/REPLACEMENT. Repair of small parts of the main landing gear actuator is impractical. Replace all defective parts. Minor scratches or score marks may be removed by polishing with abrasive crocus cloth (Federal Specification P-C-458), providing their removal does not affect operation of the unit. During assembly, install all new packings.

5-14. MAIN GEAR ACTUATOR REASSEMBLY. (Refer to figure 5-2.)

NOTE

Use MIL-G-2116C lubricant on roller (8), bearings (7) and (10), if removed, and sector (12) when installing in cylinder body (15).

a. If bearings (7) and roller (8) were removed, press one bearing (7) into cylinder body (15) until it is flush. Install roller (8) and press second bearing (7) in place to hold roller. Use care to prevent

damage to bearings and roller.

b. If bearing (10) was removed, press bearing into cap (5) until flush.

c. Assemble sector (12) on shaft (14), aligning index marks on shaft and sector. Install setscrew (13), making sure that setscrew enters shaft.

d. Position washer (11) and cap (5) on shaft (14). Install washer (3) and retainer (2) on shaft.

e. If actuator is to be installed in aircraft, install cap and shaft assembly on cylinder body with bolts (1) and washers (4). If actuator is not to be installed in aircraft, install cap and shaft assembly on cylinder body with bolts (1), washers (4) and AN316-4R nuts (9).

f. Install back-up ring (16) and O-ring (17) in cylinder body bore. Install new O-ring (19) on piston (18).

NOTE

Install new packings, lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

g. Rotate shaft (14) so that teeth on sector (12) are toward cylinder body.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-3. Fabrication of Main Landing Gear Actuator End Gland Removal Tool

h. Slide piston (18) into cylinder body, rotating shaft (14) as necessary to engage first tooth on sector (12) with first tooth on piston rack. Use care to prevent damage to packings in cylinder bore and on piston.

NOTE

Lubricate sector and piston rack gears with MIL-G-21164C lubricant. Apply lubricant sparingly. Over-greasing might cause contamination of hydraulic cylinder assembly with grease which might work past packing (7).

- Install back-up ring (21) and new O-ring (20) on end gland (22).
- Install end gland in cylinder and tighten until end of gland is flush with end of cylinder body. Install and tighten screw (23).
- Install end cap (6) at end of actuator assembly.

5-15. MAIN GEAR ACTUATOR INSTALLATION. (Refer to figure 5-1).

- With main gear pivot assembly rotating freely, match pivot and actuator sector gear markings together and slide actuator in place. Make sure that index marks are aligned.
- Install bolts attaching mounting flange to bulkhead forging. Torque bolts to 50-70 lb-in.

MODEL 210 & T210 SERIES SERVICE MANUAL

- c. Connect hydraulic lines to actuator.
- d. Install access plates on bulkhead forward of actuator.
- e. Connect brake line at wheel cylinder. Fill and bleed brake system in accordance with instructions in applicable paragraph in this Section.
- f. Rig landing gear in accordance with procedures outlined in applicable paragraph in this Section.
- g. Remove aircraft from jacks and install access covers, carpeting and seats removed for access.

5-16. MAIN LANDING GEAR STRUT-TO-ACTUATOR LINKAGE. (Refer to figure 5-1.)

5-17. DESCRIPTION. Each main landing gear actuator attaches directly to a pivot assembly, which in turn is attached to, and rotates its own main landing gear strut.

5-18. PIVOT ASSEMBLY REMOVAL. (Refer to figure 5-1.)

- a. Remove main landing gear strut as outlined in paragraph 5-7.
- b. Loosen nut (12) and telescope pivot shaft (13) inboard to free pivot assembly (3) from bearing (6) in inboard support (2).
- c. Remove pivot assembly (3), bearing (8) and bearing race (7).

5-19. PIVOT ASSEMBLY INSTALLATION. (Refer to figure 5-1.)

- a. Install bearing (8) and race (7) on shaft of pivot assembly (3); install tab washer (11) and nut (12) on pivot shaft (13).
- b. Position shaft of pivot assembly (3) into bearing (6) in inboard support (2). Lubricate bearing (6) with MIL-G-21164 grease. Be sure thrust bearing and race are correctly positioned.
- c. Telescope pivot shaft (13) and fit shaft (13) into bushing (16) in outboard support (4).
- d. Tighten nut (12) firmly and safety in place, bending corresponding tangs of washer (11). Pivot assembly shall rotate freely.

5-20. MAIN GEAR UPLOCK MECHANISM. (Refer to figure 5-4.)

5-21. DESCRIPTION. The uplock actuator cylinder and latches for the main landing gear are located on the aft side of canted bulkhead station 106.00 (refer to Section 1 of this manual.) The latches are controlled by a single actuator, located on the aircraft centerline, by means of bellcrank and linkage assemblies.

5-22. REMOVAL AND INSTALLATION OF MAIN GEAR UPLOCK MECHANISM. (Refer to figure 5-4.)

WARNING

Before working in landing gear wheel wells, PULL-OFF hydraulic pump circuit breakers. Thru Serial 21062273, the pump circuit breaker is located in the circuit breaker panel, located immediately forward of the pilot's control wheel. Beginning with Serial 21062274, the pump circuit breaker is located in the circuit breaker panel, located immediately forward of the left forward doorpost. The hydro-electric power pack system is designed to pressurize the landing gear DOOR CLOSE system to 1500 psi at any time the master switch is turned on. Injury might occur to someone working in wheel well area if master switch is turned on for any reason.

- a. Turn master switch OFF and, using hand pump, open landing gear doors.
- b. Components of the main landing gear uplock system are readily accessible on the aft side of canted bulkhead station 106.00 (refer to Section 1 of this manual.)
- c. Components may be removed or installed using figure 5-4 as a guide.
- d. Upon installation, rig uplocks in accordance with applicable paragraph in this Section.

5-22A. UPLOCK ACTUATOR.

5-23. UPLOCK ACTUATOR DISASSEMBLY. (Refer to figure 5-5.)

NOTE

Leading particulars of the actuators

Cylinder Bore Diameter	0.749 +.002,-.000 in.
Piston Diameter	0.747+.000,-.001 in.
Stroke (to unseat valve)	0.719 ± .031 in.

- a. Remove fitting (5), spring (7) and balls (8) and (9).
- b. Cut safety wire and unscrew end plug (19) from barrel and valve body (12).
- c. If end fitting (1) is installed, loosen nut (2) and remove end fitting from barrel and valve body.
- d. Remove springs (18) and (17) and push piston and rod (13) from barrel and valve body.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-4. Main Landing Gear Uplock Installation

e. Remove and discard all O-rings and back-up rings.

5-24. INSPECTION OF PARTS. (Refer to figure 5-5.)

- a. Inspect all threaded surfaces for cleanliness and for freedom of cracks and excessive wear.
- b. Inspect ball spring (7) for evidence of breaks and distortion.
- c. Inspect inner and outer piston springs (18) and (17) for evidence of breaks and distortion.
- d. Inspect end fitting, piston and rod, barrel, valve body, balls and ball seats for cracks, scratches, scoring, wear or surface irregularities which might affect their function or the overall function of the unit.
- e. Repair of most parts of the uplock actuator is impractical. Replace defective parts. Minor

scratches and scores may be removed by polishing with fine abrasive crocus cloth (Federal Specification PC-458), providing their removal does not affect operation of the unit.

5-25. UPLOCK ACTUATOR REASSEMBLY. (Refer to figure 5-5.)

NOTE

Install all new O-rings and back-up rings during reassembly of the actuator.

- a. Install new O-rings and back-up rings in grooves of piston and rod (13).
- b. Install new O-ring and back-up rings in grooves of barrel and valve body (12).
- c. Slide piston and rod into barrel and valve

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-5. Lock and Unlock Actuators

body. Use care to prevent damage to O-rings and back-up rings.

d. Insert piston springs (18) and (17), then install end fitting (1) or end plug (19) to barrel and valve body.

e. Insert balls (8) and (9) and spring (7) in barrel and valve body.

f. Install new O-ring (6) on fitting (5). Install and tighten fitting.


5-26. DOWNLOCK MECHANISM. (Refer to figure 5-6.)

5-27. DESCRIPTION. The downlock mechanism is comprised of hydraulic actuators connected to arm assemblies, which trip downlock hooks, releasing the main landing gear struts. Figure 5-6 illustrates the downlock mechanism and may be

used as a guide for determining relationship of parts. A locator illustration is also provided, which shows station numbers, bulkheads, ribs and parts of the downlock mechanism. To locate a specific fuselage station, refer to the station diagram in Section 1 of this manual.

5-28. REMOVAL AND INSTALLATION OF COMPONENTS. (Refer to figure 5-6.) The downlock mechanisms are located just forward and aft of the rear doorpost under the floorboard. Access to the mechanisms is gained by removing the seats, peeling back the carpet and removing the access plates immediately forward and aft of the rear doorpost on either side of the aircraft. Figure 5-6 may be used as a guide for removal and installation of the components of the downlock mechanisms. Upon complete reassembly of the downlock mechanisms,

MODEL 210 & T210 SERIES SERVICE MANUAL



* Install internal tooth washer under bolt heads.

* Prime bolts with LOCTITE GRADE "T" PRIMER and seal with LOCTITE CV or CATALOG #85 or #83.

1. Tie
2. Boot
3. Pin
4. Spacer
5. Arm Assembly
6. Downlock Adjustment Screw
7. Hook
8. Setscrew
9. Downlock Switch
10. Spring Assembly
11. Eyebolt
12. Shim
13. Support Assembly
14. Landing Gear Strut
15. Shell Assembly
16. Stud
17. Bolt
18. Rod End
19. Actuator




Figure 5-6. Main Landing Gear Downlock Installation

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-6A. Main Landing Gear Downlock Actuator.

rig the main landing gear in accordance with procedures outlined in the applicable paragraph in this Section.

5-28A. DOWNLOCK ACTUATOR.

5-29. DISASSEMBLY. (Refer to figure 5-6A.)

- a. Loosen nut (1) and unscrew end fitting (2) from body (3). Spring (4) can also be removed.
- b. Remove fitting (5), spring (6), ball (7), and ball (8) from body (3).
- c. Remove piston/rod (9) from body (3).
- d. Remove and discard all packings and back-up rings from end fitting (2), body (3), and piston/rod (9).

5-29A. INSPECTION AND REPAIR.

- a. Inspect all threaded surfaces for cleanliness and for freedom from cracks and excessive wear.
- b. Inspect spring (6) for evidence of breaks and distortion.
- c. Inspect piston spring (4) for evidence of breaks and distortion.

d. Inspect end fitting, piston/rod, barrel, valve body, balls and ball seats for cracks, scratches, scoring, wear or surface irregularities which might affect their function or the overall function of the unit.

e. Repair of most parts of the uplock actuator is impractical. Replace defective parts. Minor scratches and scores may be removed by polishing with fine abrasive crocus cloth (Federal Specification PC-458), providing their removal does not affect operation of the unit.

5-29B. REASSEMBLY.

NOTE

Install new O-rings and back-up rings lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

- a. Assemble by reversing procedures outlined in paragraph 5-29.

MODEL 210 & T210 SERIES SERVICE MANUAL

5-30. MAIN LANDING GEAR DOOR SYSTEM.

5-31. DESCRIPTION. Main gear doors open for main gear retraction or extension and return to closed positions at the close of either cycle. The strut doors are opened and closed by a double-acting hydraulic actuator. The wheel doors are actuated by a double-actuating hydraulic actuator for each door. The actuators are held closed by the door close system accumulator.

5-32. REMOVAL AND INSTALLATION OF MAIN GEAR STRUT AND WHEEL DOORS. (Refer to figure 5-7.)

- a. Open landing gear doors.
- b. Disconnect door from actuator linkage by removing pin or bolt.
- c. Remove door hinge pins or bolts.
- d. Install door by reversing the preceding steps.
- e. Rig doors in accordance with applicable paragraph.

5-33. MAIN GEAR STRUT DOOR ACTUATOR REMOVAL AND INSTALLATION.

WARNING

Turn master switch "off" and pull pump motor circuit breaker before disconnecting any hydraulic lines in the landing gear system.

- a. Peel back carpet as required and remove access cover in center of floorboard just forward of rear seat.
- b. Open doors using hand pump then disconnect hydraulic lines at actuator. Cap or plug lines and fittings.
- c. Remove bolts at each end of actuator attaching rod end to bellcrank and actuator body to mounting bracket. Remove actuator from aircraft.
- d. Reverse procedure to install actuator.

5-33A. DISASSEMBLY. (Refer to figure 5-8.)

- b. Remove retaining ring (1) from end of cylinder (6).
- c. Pull piston rod (5), end gland (4) from cylinder (6). A sharp blast of air applied to the hydraulic port at bearing end of cylinder may be used to remove piston rod.
- d. Remove end gland (4) from piston rod (5).
- e. Remove and discard back-up rings and O-rings from gland and piston rod.

5-33B. INSPECTION. (Refer to figure 5-8.)

- a. Inspect all threaded surfaces for cleanliness and for freedom of cracks and excessive wear or damage.
- b. Inspect end gland (4), piston rod (5) and cylinder (6) for cracks, chips, scratches, scoring, wear or surface irregularities which might affect their function or the overall function of the door actuator.

c. Repair of most parts of the landing gear door actuator assembly is impractical. Replace defective parts with new parts.

d. Minor scratches may be removed by polishing with fine abrasive crocus cloth (Federal Specification PC-458), providing their removal does not affect the operation of the unit.

5-33C. REASSEMBLY. (Refer to figure 5-8.)

NOTE

Lubricate all O-rings and back-up rings with Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow Corning DC-7 during assembly.

- a. Install new O-ring and back-up ring in gland and install gland on piston rod. Use care to prevent damage to O-rings and back-up rings.
- b. Install new O-rings and back-up rings on piston and on gland.
- c. Install piston rod and gland into cylinder and install retaining ring. Use care to prevent damage to O-rings and back-up rings.

5-34. MAIN WHEEL DOOR ACTUATOR REMOVAL.

- a. Open landing gear doors.
- b. Disconnect and cap or plug hydraulic hoses at the actuator.
- c. Disconnect actuator rod by removing attaching nut and bolt at door.
- d. Remove nut and bolt attaching actuator to fuselage bracket and remove actuator.

5-35. MAIN WHEEL DOOR ACTUATOR DISASSEMBLY. (Thru Serial 21062273, refer to figure 5-8A.)

- a. Loosen check nut (2) and remove rod end (1).
- b. Remove retaining ring (3) from end of cylinder (10).
- c. Pull piston rod (8), gland (6) or (7) from cylinder (10). A sharp blast of air applied to the hydraulic port at bearing end of cylinder may be used to remove piston rod.
- d. Remove gland (6) or (7) from piston rod (8).
- e. Remove and discard back-up rings and O-rings from gland and piston rod.
- f. Do not remove bearing (9) unless it is defective.

5-35A. INSPECTION. (Thru Serial 21062273.)

- a. Inspect all threaded surfaces for cleanliness and for freedom of cracks and excessive wear or damage.
- b. Inspect gland (6) or (7), piston rod (8) and cylinder (10) for cracks, chips, scratches, scoring, wear or surface irregularities which might affect their function or the overall function of the door actuator.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-7. Main Landing Gear Doors Installation

MODEL 210 & T210 SERIES SERVICE MANUAL

- c. Repair of most parts of the landing gear door actuator assembly is impractical. Replace defective parts with new parts.
- d. Minor scratches may be removed by polishing with fine abrasive crocus cloth (Federal Specification PC-458), providing their removal does not affect the operation of the unit.

5-35B. REASSEMBLY. (Thru Serial 21062273.) (Refer to figure 5-8A.)

NOTE

Lubricate all O-rings and back-up rings with a film of Petrolatum VV-P-236, Hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

- a. Install new O-ring and back-up ring in gland and install gland on piston rod. Use care to prevent damage to O-rings and back-up rings.
- b. Install new O-rings and back-up rings on piston and on gland.
- c. Install piston rod and gland into cylinder and install retaining ring. Use care to prevent damage to O-rings and back-up rings.
- d. Install lock nut and rod end.

NOTE

If bearing (9) was removed, install and stake six places, three on each side.

5-36. MAIN WHEEL DOOR ACTUATOR DISASSEMBLY. (Beginning with Serial 21062274, refer to figure 5-8A.)

- a. Loosen check nut (2) and remove rod end (1).
- b. Remove safety wire from end fitting (11) unscrew end fitting from actuator cylinder (10).
- c. Pull piston rod (8) from cylinder.
- d. Remove and discard back-up rings and O-rings from end fitting and piston rod.
- e. Do not remove bearing (9) unless it is defective.

5-36A. INSPECTION. (Beginning with Serial 21062274.)

- a. Inspect all threaded surfaces for cleanliness and for freedom of cracks and excessive wear or damage.
- b. Inspect end fitting, piston rod and cylinder for cracks, chips, scratches, scoring, wear or surface irregularities which might affect their function or the overall function of the door actuator.
- c. Repair of most parts of the gear door actuator is impractical. Replace defective parts with new parts.
- d. Minor scratches may be removed by polishing

with fine abrasive crocus cloth (Federal Specification PC-458, providing their removal does not affect the operation of the unit.

5-36B. REASSEMBLY. (Beginning with Serial 21062274.)

- a. Install new O-ring and back-up ring inside end fitting. Install new O-ring on outside of end fitting.
- b. Install new O-rings and back-up rings on piston.
- c. Install piston in cylinder using care to avoid damaging O-rings and back-up rings.
- d. Install end fitting on piston rod and screw into cylinder. Use care to prevent damage to O-ring and back-up ring inside end fitting.
- e. Tighten end fitting and install new safety wire.

NOTE

If bearing (9) was removed, install and stake six places, three on each side.

5-37. MAIN WHEEL AND TIRE ASSEMBLY.

5-38. DESCRIPTION. The aircraft may be equipped with either Cleveland or McCauley wheel and tire assemblies. Separate disassembly, inspection and reassembly instructions are provided for each type.

CAUTION

Use of recapped tires or new tires not listed on the aircraft equipment list are not recommended due to possible interference between the tire and structure when landing gear is in the retracted position.


5-39. REMOVAL OF MAIN WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-1.)

NOTE

It is not necessary to remove the main wheel to reline brakes or remove brake parts, other than the brake disc or torque plate.

- a. Using the jack point under step on main gear strut, jack up wheel being removed in accordance with procedures outlined in Section 2.
- b. Remove hub caps (25).
- c. Remove cotter pin (32) and nut (24).
- d. Remove bolts and washers attaching back plate, and remove back plate (Index 22, figure 5-9, Sheet 1).
- e. Pull wheel and tire assembly (23) from axle (21).

MODEL 210 & T210 SERIES SERVICE MANUAL




- 1. Retaining Ring
- 2. O-Ring
- 3. Back-Up Ring

- 4. Gland
- 5. Piston Rod
- 6. Cylinder

Figure 5-8 Main Strut Door Actuator

MODEL 210 & T210 SERIES SERVICE MANUAL

MAIN GEAR DOOR
AND NOSE GEAR
DOOR ACTUATOR



BEGINNING WITH
SERIAL 21062274

THRU SERIAL
21062273

- | | |
|-------------------|-----------------|
| 1. Rod End | 8. Piston Rod |
| 2. Check Nut | 9. Bearing |
| 3. Retaining Ring | 10. Cylinder |
| 4. O-Ring | 11. End Fitting |
| 5. Back-Up Ring | 12. Spacer |
| 6. Gland | *13. Spacer |
| *7. Gland | |

*USED IN NOSE GEAR DOOR ACTUATOR

Figure 5-8A Main Wheel Door Actuator

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-9. Main Landing Gear Wheel, Tire and Brake Assembly (Sheet 1 of 3)

5-40. DISASSEMBLY OF CLEVELAND MAIN WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-9.)

- a. Deflate tire and break tire beads loose.

CAUTION

Avoid damaging wheel flanges when breaking tire beads loose. A scratch, gouge or nick may cause wheel failure.

- b. Remove thru-bolts and separate wheel halves, removing tire, tube and brake disc.
- c. Remove grease seal rings, felts and bearing cones from wheel halves.

NOTE

The bearing cups are a press fit in the wheel halves and should not be removed unless replacement is necessary. To remove the bearing cups, heat the wheel half in boiling water for 15 minutes. Using an arbor press, if available, press out the bearing cup and press in the new cup while the wheel is still hot.

5-41. INSPECTION AND REPAIR OF CLEVELAND MAIN WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-9.)

- a. Clean all metal parts and the grease seal felts in solvent and dry thoroughly.
- b. Inspect wheel halves for cracks. Cracked wheel halves should be replaced. Sand out nicks, gouges and corroded areas. When the protective

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-9 Main Wheel and Tire Assembly (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL

coating has been removed, the area should be cleaned thoroughly, primed with nonzinc chromate, and repainted with aluminum lacquer.

c. Brake disc should be replaced if excessively scored or warped. Small nicks and scratches should be sanded smooth. See paragraph 5-72.

d. Bearing cups and cones should be inspected carefully for damage and discoloration. After cleaning, repack cones with clean aircraft wheel bearing grease (Section 2) before installation in the wheel.

5-42. REASSEMBLY OF CLEVELAND MAIN WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-9.)

a. Insert thru-bolts through brake disc and position in the inner wheel half, using the bolts to guide the disc. Assure the disc is bottomed in wheel half.

b. Position tire and tube with the inflation valve through hole in outboard wheel half. Place inner wheel half in position. Apply a light force to bring wheel halves together. Maintaining the light force, assemble a washer and nut on one thru-bolt and tighten snugly. Assemble remaining washers and nuts on thru-bolts and torque to 150 lb-in.

CAUTION

Uneven or improper torque of thru-bolt nuts may cause failure of bolts, with resultant wheel failure.

c. Clean and repack bearing cones with clean aircraft wheel bearing grease (refer to Section 2 of this manual).

d. Assemble bearing cones, grease seal felts and rings into wheel halves.

e. Inflate tire to seat tire beads, then adjust to correct pressure specified in figure 1-1.

5-43. DISASSEMBLY OF McCAULEY TWO-PIECE MAIN WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-9, Sheet 2.)

a. Deflate tire and break tire beads loose.

CAUTION

Avoid damaging wheel flange when breaking tire beads loose. A scratch, gouge, or nick may cause wheel failure.

b. Remove thru-bolts (24) and separate wheel halves (6) and (10), removing tire (8), tube (9), and brake disc (13).

c. Remove grease seal retainers (2) and (4), grease seal felts (3), and bearing cones (5) from wheel halves (6) and (10).

NOTE

The bearing cups are a press fit in the wheel halves and should not be removed unless replacement is necessary. To remove the bearing cups, heat the wheel half in boiling water for 15 minutes. Using an arbor press, if available, press out the bearing cup and press in the new cup while the wheel is still hot.

5-44. INSPECTION AND REPAIR OF McCAULEY TWO-PIECE MAIN WHEEL AND TIRE ASSEMBLY (Refer to figure 5-9.)

a. Clean all metal parts and the grease seal felts in solvent and dry thoroughly.

b. Inspect wheel halves for cracks. Cracked wheel halves should be replaced. Sand out nicks, gouges and corroded areas. When the protective coating has been removed, the area should be cleaned thoroughly, primed with nonzinc chromate, and repainted with aluminum lacquer.

c. Brake disc should be replaced if excessively scored or warped. Small nicks and scratches should be sanded smooth. See paragraph 5-72.

d. Bearing cups and cones should be inspected carefully for damage and discoloration. After cleaning, repack cones with clean aircraft wheel bearing grease (Section 2) before installation in the wheel.

5-44A. REASSEMBLY OF McCAULEY TWO-PIECE MAIN WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-9.)

a. Insert thru-bolts through brake disc and position in the inner wheel half, using the bolts to guide the disc. Assure the disc is bottomed in wheel half.

b. Position tire and tube with the inflation valve through hole in outboard wheel half. Place inner wheel half in position. Apply a light force to bring wheel halves together. Maintaining the light force, assemble a washer and nut on one thru-bolt and tighten snugly. Assemble remaining washers and nuts on thru-bolts and torque to 150 lb-in.

CAUTION

Uneven or improper torque of thru-bolt nuts may cause failure of bolts, with resultant wheel failure.

c. Clean and repack bearing cones with clean aircraft wheel bearing grease (refer to Section 2 of this manual).

d. Assemble bearing cones (5), grease seal felts (3), and grease seal retainers (2) and (4) into wheel halves (6) and (10).

e. Inflate tire to seat tire beads, then adjust to correct pressure.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-9. Main Landing Gear Wheel, Tire and Brake Assembly (Sheet 3 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL

5-45. DISASSEMBLY OF McCAULEY THREE PIECE MAIN WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-9.)

- a. Remove screws attaching hub cap; remove hub cap.

WARNING

Injury can result from attempting to remove wheel flanges with the tire and tube inflated. Avoid damaging wheel flanges when breaking tire beads loose. A scratch, gouge or nick in wheel flanges could cause wheel failure.

- b. Remove valve core and deflate tire and tube. Break tire beads loose from wheel flanges.
- c. Remove cap screws.
- d. Remove brake disc.
- e. Separate wheel flanges from wheel hub. Retain spacers on each side of wheel hub.
- f. Remove wheel hub from tire.
- g. Remove retainer rings and remove grease seal retainers, grease seal felts and bearing cones.

NOTE

The bearing cups (races) are a press fit in the wheel hub and should not be removed unless a new part is to be installed. To remove the bearing cup, heat wheel hub in boiling water for 30 minutes, or in an oven not to exceed 121°C (250°F). Using an arbor press, if available, press out the bearing cup and press in the new bearing cup while the wheel is still hot.

5-45A. INSPECTION AND REPAIR OF McCAULEY THREE PIECE MAIN WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-9.)

- a. Clean all metal parts, grease seal felts and phenolic spacers in cleaning solvent and dry thoroughly.
- b. Inspect wheel flanges and wheel hub for cracks. Cracked wheel flanges or hub shall be discarded and new parts installed.

- c. Sand out smooth nicks, gouges and corroded areas. When the protective coating has been removed, the area should be cleaned thoroughly, primed with zinc chromate and painted with aluminum lacquer.

- d. Brake disc should be replaced if excessively scored or warped. Small nicks and scratches should be sanded smooth. See paragraph 5-72.

- e. Carefully inspect bearing cones and cups for damage and discoloration. After cleaning, pack bearing grease (refer to Section 2 of this manual) before installing in the wheel hub.

5-45B. REASSEMBLY OF McCAULEY THREE PIECE MAIN WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-9.)

- a. Place wheel hub in tire and tube with tube inflation stem in cutout of wheel hub.
- b. Place spacer and wheel flange on inboard side of wheel hub (opposite of tube inflation stem), then place washer under head of each capscrew and start capscrew into hub threads.
- c. Place spacer and wheel flange on other side and align valve stem in cutout in wheel flange..
- d. Place washer under head of each capscrew and start capscrews into hub threads.

CAUTION

Be sure that spacers and wheel flanges are seated on flanges of wheel hub. Uneven or improper torque of capscrews can cause failure of the capscrews or hub threads with resultant wheel failure.

- e. Tighten capscrews evenly and torque to 190-200 lb in.
- f. Clean and pack bearing cones with clean aircraft wheel bearing grease. Refer to Section 2 of this manual for grease type.
- g. Assemble bearing cones, grease seal felts and retainer into wheel hub.
- h. Inflate tire to seat tire beads, then adjust to correct pressure specified in figure 1-1.

5-46 INSTALLATION OF MAIN WHEEL AND TIRE ASSEMBLY.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

- a. Place wheel on axle.
- b. Install axle nut and tighten until a slight bearing drag is obvious when the wheel is rotated. Back off nut to nearest castellation and install cotter pin.
- c. Place brake back plate in position and secure with bolts and washers. Safety wire the bolts.
- d. Install hub caps.

5-47. MAIN WHEEL DOOR CLOSE SYSTEM ACCUMULATOR. (Refer to figure 5-10.)

5-48. DESCRIPTION. The accumulator serves two purposes. This unit maintains pressure in the door-close system, keeping the main wheel doors up and closed. The accumulator also dampens pressure surge and serves as a reservoir to offset normal leak-down in the system.

WARNING

BEFORE WORKING IN WHEEL WELL AREA. PULL HYDRAULIC PUMP CIRCUIT BREAKER OFF.

5-49. REMOVAL OF ACCUMULATOR. (Refer to figure 5-10.)

WARNING

Filler and safety valve (8) does not contain a core. To release accumulator pressure, loosen nut on end of valve. If the valve installed contains a core, the valve should be replaced with a valve which does not contain a core. Injury can occur if pressure is not released properly.

- a. Open main gear doors. This will drop hydraulic pressure to zero.
- b. Relieve accumulator pressure by turning nut on end of valve approximately 1/4 turn.
- c. Disconnect and plug or cap hydraulic line at accumulator.
- d. Remove bolt, washer, spacer and nut at outboard end and remove clamp, screw and nut at inboard end; remove accumulator.

5-50. DISASSEMBLY AND REASSEMBLY OF ACCUMULATOR. (Refer to figure 5-10.)

- a. Remove retainer (18) only after ensuring that pressure has been relieved. Remove gland (19), piston (20), and filler and safety valve (8) if required.
- b. Remove and discard packings (22) and back-up rings (23).
- c. Reverse the preceding steps, using new packings and back-up rings, for reassembly of the accumulator.

NOTE

Install new packings and back-up rings lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

5-51. INSTALLATION OF ACCUMULATOR. (Refer to figure 5-10.)

WARNING

BEFORE WORKING IN WHEEL WELL AREA. PULL HYDRAULIC PUMP CIRCUIT BREAKER OFF.

- a. Install bolt, washer, spacer and nut at outboard end and clamp screw and nut at inboard end.
- b. Connect hydraulic line at accumulator.
- c. Pressurize accumulator with nitrogen or dry air to 500 ± 50 psig. Hydraulic pressure should be zero.

NOTE

Adapter hose and fitting kit (nitrogen bottle to accumulator) number ZN216, available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations, can be used to charge the accumulator.

5-52. MAIN WHEEL AND AXLE REMOVAL. (Refer to figure 5-1.)

- a. Remove hub caps.
- b. Remove wheel from axle in accordance with procedures outlined in paragraph 5-39.
- c. Disconnect, drain and plug hydraulic brake line at the brake cylinder.
- d. Remove bolts, washers, nuts and stud securing axle and brake components to fitting at lower end of strut.

NOTE

When removing axle from strut fitting, note number and position of wheel alignment shim. Mark these shims or tape together carefully so they can be reinstalled in exactly the same position to ensure that wheel alignment is not disturbed. Also, note position of stud attaching axle to fitting so that the stud may be installed in the same position. Stud is the uplock for the main gear.

5-53. MAIN WHEEL AND AXLE INSTALLATION. (Refer to figure 5-1.)


- a. Secure axle and brake components to strut fitting, making sure that wheel alignment shims and stud are reinstalled in their original position.

NOTE

Shim: P/N 1241061-3, available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations, can be installed between axle and fitting, if necessary, to maintain .050 inch minimum clearance between axle fitting and brake disc.

- b. Install wheel assembly on axle in accordance with paragraph 5-46.
- c. Connect hydraulic brake line to brake cylinder.
- d. Fill and bleed affected brake system.
- e. Install hub caps.
- f. Check wheel alignment.

MODEL 210 & T210 SERIES SERVICE MANUAL



- 1. Adjustable Rod End
- 2. Wheel Door Actuator
- 3. Canted Bulkhead Station 124. 60
- 4. Clamp
- 5. Warning Placard *
- 6. Safety Wire
- 7. Accumulator
- 8. Filler and Safety Valve
- 9. Door Hinge
- 10. Safety Clamp
- 11. Hose
- 12. Tee
- 13. Tubing
- 14. Warning Placard *
- 15. Bracket
- 16. Tunnel
- 17. Hose
- 18. Retainer
- 19. Gland
- 20. Piston
- 21. Cylinder
- 22. Packing
- 23. Back-Up Ring

WARNING

* BEFORE WORKING IN WHEEL WELL AREA, PULL HYDRAULIC PUMP CIRCUIT BREAKER OFF

WARNING

* RELEASE AIR AND FLUID PRESSURE BEFORE REMOVING ANY PART OF THIS ASSEMBLY

WARNING

Valve (8) does not contain a core. To release accumulator pressure, loosen nut on end of valve. If the valve installed contains a core the valve should be replaced with a valve which does not contain a core. Injury can occur if pressure is not released properly.

Detail A

Figure 5-10. Main Landing Gear Wheel Door Close System Accumulator

MODEL 210 & T210 SERIES SERVICE MANUAL

5-54. **MAIN WHEEL ALIGNMENT.** Correct main wheel alignment is obtained through the use of tapered shims between the landing gear strut and the flange of the axle. Refer to figure 5-11 for procedures to use in checking alignment. Wheel shims, and the correction imposed on the wheel by the various shims, are listed in the illustration.

NOTE

Failure to obtain acceptable wheel alignment through the use of the shims indicates a deformed main gear strut or a bent axle.

5-55. **WHEEL BALANCING.** Since uneven tire wear is usually the cause of wheel unbalance, replacing the tire probably will correct this condition. Tire and

5-58. **TROUBLE SHOOTING.**


tube manufacturing tolerances permit a specified amount of static unbalance. The lightweight point of the tire is marked with a red dot on the tire sidewall, and the heavyweight point of the tube is marked with a contrasting color line (usually near the valve stem). When installing a new tire, place these marks adjacent to each other. If a wheel becomes unbalanced during service, it may be statically balanced. Wheel balancing equipment is available from Cesana Parts Distribution (CPD 2) through Cesana Service Stations.

5-56. **BRAKE SYSTEM.**

5-57. **DESCRIPTION.** The hydraulic brake system consists of two master cylinders, brake lines, connecting each master cylinder to its corresponding wheel brake cylinder, and the single, disc-type brake assembly, located at each main landing gear wheel.


TROUBLE	PROBABLE CAUSE	REMEDY
DRAGGING BRAKES.	Brake pedal binding.	Check and adjust properly.
	Parking brake linkage holding brake pedal down.	Check and adjust properly.
	Worn or broken piston return spring. (In master cylinder.)	Repair or replace master cylinder.
	Insufficient clearance at Lock-O-Seal in master cylinder.	Adjust as shown in figure 5-12.
	Restriction in hydraulic lines or restriction in compensating port in master brake cylinder.	Drain brake lines and clear the inside of the brake line with filtered compressed air. Fill and bleed brakes. If cleaning the lines fail to give satisfactory results, the master cylinder may be faulty and should be repaired.
	Worn, scored, or warped brake discs.	Replace brake disc and linings.
	Damage or accumulated dirt restricting free movement of wheel brake parts.	Clean and repair or replace parts as necessary.
BRAKES FAIL TO OPERATE.	Leak in system.	Check entire system for leaks. If brake master cylinders or wheel assemblies are leaking, they should be repaired or replaced.
	Air in system.	Bleed system.
	Lack of fluid in master cylinders.	Fill and bleed systems.

MODEL 210 & T210 SERIES SERVICE MANUAL




TOP VIEW OF TOE-IN CHECK

Measure toe-in at edges of wheel flange. Difference in measurements is toe-in for one wheel. (half of toe-in.)



FRONT VIEW OF CAMBER CHECK

Measure camber by reading protractor level held vertically against outboard flanges of wheel.




NOTE

See Section 1, figure 1-1 for toe-in and camber tolerances. Setting toe-in and camber within these tolerances while the cabin and fuel tanks are empty will give approximately zero toe-in and zero camber at gross weight. Therefore, if normal operation is at less than gross weight and abnormal tire wear occurs, realign the wheels to attain the ideal setting for the load conditions. Refer to sheet 2 of this figure for shims availability. Always use the least number of shims possible to obtain the desired result.

Figure 5-11. Wheel Alignment (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL



NOTE

To assure adequate thread engagement of the mounting bolts, use 0541111-2 or 0441139-6 shim alone and/or 0541157-1, -2, -3 or 0441139-5 shims in and combination as required to get zero toe-in and zero camber at normal operating weight. Total thickness of shims at upper bolts must not exceed .195. If any tapered shims are used, all AN960 washers must be removed from the upper bolts.

Figure 5-11. Wheel Alignment (Sheet 2 of 2)

5-59. BRAKE MASTER CYLINDER.

5-60. DESCRIPTION. The brake master cylinders, located immediately forward of the pilot's rudder pedals, are actuated by applying pressure at the top of the rudder pedals. A small reservoir is incorporated into each master cylinder for the fluid

supply. When dual brakes are installed, mechanical linkage permits the copilot pedals to operate the master cylinders.

5-61. BRAKE MASTER CYLINDER REMOVAL.

a. Remove bleeder screw at wheel brake assembly and drain hydraulic fluid from

MODEL 210 & T210 SERIES SERVICE MANUAL

brake cylinders.

- b. Remove front seats and rudder bar shield for access to brake master cylinders.
- c. Disconnect parking brake linkage and disconnect brake master cylinders from rudder pedals.
- d. Disconnect hydraulic hose from brake master cylinders and remove cylinders.
- e. Plug or cap hydraulic fittings, hose and lines to prevent entry of foreign material.

5-62. BRAKE MASTER CYLINDER DISASSEMBLY. (Refer to figure 5-12.)

- a. Unscrew clevis (1) and jamb nut (2).
- b. Remove screw (18).
- c. Remove filler plug (17) and setscrew (5).
- d. Unscrew cover (4) and remove up over piston rod (3).
- e. Remove piston rod (3) and compensating sleeve (16).
- f. Slide sleeve (16) up over rod (3).
- g. Unscrew nut (12) from threads of piston rod (3).
- h. Remove piston spring (13) and O-ring (9) from piston (14).

5-63. BRAKE MASTER CYLINDER INSPECTION AND REPAIR. (Refer to figure 5-12.) Repair is limited to installation of new parts, cleaning and adjusting. (Refer to reassembly paragraph for adjustment.) Use clean hydraulic fluid (MIL-H-5606) as a lubricant during reassembly of the cylinders. Inspect Lock-O-Seal (Parker Seal Co. P/N 800-001-6) and replace if damaged. Replace all O-rings. Filler plug must be vented so pressure cannot build up in the reservoir during brake operation. Remove plug and drill 1/16-inch hole, 30° from vertical, if plug is not vented.

5-64. BRAKE MASTER CYLINDER REASSEMBLY. (Refer to figure 5-12.)

- a. Install Lock-O-Seal (15) at bottom of piston rod (3).
- b. Install O-ring (9) in groove in piston (14); insert piston spring (13) into piston, and slide assembly up on bottom threaded portion of piston rod (3).
- c. Run nut (12) up threads to spring (13). Tighten nut enough to obtain 0.040 ± 0.005-inch clearance between top of piston and bottom of Lock-O-Seal, as shown in the figure.
- d. Install piston return spring (11) into cylinder (10) portion of body (7).
- e. Install piston rod (3) through spring (11).
- f. Slide compensating sleeve (16) over rod (3).
- g. Install cover (4) and screw (18).
- h. Install jamb nut (2) and clevis (1).
- i. Install filler plug (17), making sure vent

hole is open.

- j. Install setscrew (5).

5-65. BRAKE MASTER CYLINDER INSTALLATION.

- a. Connect hydraulic hoses to brake master cylinders and install cylinders.
- b. Connect brake master cylinders to rudder pedals and connect parking brake linkage.
- c. Install rudder bar shield and install front seats.
- d. Install bleeder screw at wheel brake assembly and fill and bleed brake system in accordance with applicable paragraph in this Section.

5-66. HYDRAULIC BRAKE LINES.

5-67. DESCRIPTION. The brake lines are of rigid tubing, except for flexible hose used at the brake master cylinders. A separate line is used to connect each brake master cylinder to its corresponding wheel brake cylinder.

WARNING

After connecting brake hose, ensure that hose does not contact or rub against brake disc, causing brake hose failure.

5-68. WHEEL BRAKE ASSEMBLIES. (Refer to figure 5-9.)

5-69. DESCRIPTION. The wheel brake assemblies employ a floating brake assembly and a disc which is attached to the main wheel.

5-70. WHEEL BRAKE REMOVAL. (Refer to figure 5-9.) Wheel brake assemblies can be removed by disconnecting the brake line (drain fluid when disconnecting line) and removing the brake back plate. The brake disc is removed after the wheel is removed and disassembled. -To remove the torque plate, remove wheel and axle.

5-71. WHEEL BRAKE DISASSEMBLY. Refer to figure 5-9 for a breakdown of wheel brake parts. This figure may be used as a guide for disassembling the wheel brakes.

5-72. WHEEL BRAKE INSPECTION AND REPAIR.

- a. Clean all parts except brake linings and O-rings in dry cleaning solvent and dry thoroughly.
- b. Install all new O-rings. If O-ring reuse is necessary, wipe with a clean cloth saturated in hydraulic fluid and inspect for damage.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-12. Brake Master Cylinder

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

Thorough cleaning is important. Dirt and chips are the greatest single cause of malfunctions in the hydraulic brake system.

c. Check brake lining for deterioration and maximum permissible wear. (Refer to applicable paragraph for maximum wear limit.)

d. Inspect brake cylinder bore for scoring. A scored cylinder will leak or cause rapid O-ring wear. Install a new-brake cylinder if the bore is scored.

e. If the anchor bolts of the brake assembly are nicked or gouged, they shall be sanded smooth to prevent binding with the pressure plate or torque plate. When new anchor bolts are to be installed, press out old bolts and install new bolts with a soft mallet.

f. Inspect wheel brake disc for minimum thickness. If disc is below minimum thickness, install a new part.

Minimum thicknesses are as follows:

Cleveland disc no. 164-15A: .340-inch

McCauley discs No. C30398 and C30615-3: .325-inch.

5-73. WHEEL BRAKE REASSEMBLY. (Refer to figure 5-9.)

NOTE

Lubricate parts with a clean hydraulic fluid during brake reassembly.

a. Refer to figure 5-9 as a guide while reassembling wheel brakes.

5-74. WHEEL BRAKE INSTALLATION.

a. Place brake assembly in position with pressure plate in place.

NOTE

If torque plate was removed, install as the axle is installed, or install on axle. If the brake disc was removed, install as wheel is assembled.

5-74A. BRAKE LININGS. (1977 THRU 1983 MODELS.) The pads are equipped with asbestos based linings. When replacement is required, the new pads must be properly conditioned (broken in) in order to provide optimum service life. Conditioning will generate sufficient heat to cure the resins in the material, but will not cause the material to carburize due to excessive heat. Condition the brakes by performing a series of at least six light braking applications from 25 to 40 MPH to a complete stop. Allow the brake discs to partially cool after each stop.

5-74B. NON-ASBESTOS ORGANIC OR METALLIC BRAKE LININGS. Beginning with 1984 models, the brake lining pads used in this assembly are either non-asbestos organic composition or iron based metallic

composition. Brake pads must be properly conditioned (glazed) before use in order to provide optimum service life. This is accomplished by a brake burn-in. Burn-in also wears off brake high spots prior to operational use. If brake use is required before burn-in, use brakes intermittently at LOW taxi speeds.

5-74C. BRAKE BURN-IN.

CAUTION

Brake burn-in must be performed by a qualified person familiar with acceleration and stop distances of the airplane.

a. Non-asbestos Organic Composition Burn-in.

1. Taxi the airplane for 1500 feet, with engine at 1700 RPM, applying brake pedal force as need to maintain 5 to 10 M.P.H. (5 to 9 Knots).

2. Allow brakes to cool for 10 to 15 minutes.

3. Apply brakes and check to see if a high throttle static engine run-up can be held with normal pedal force. If so, conditioning burn-in is complete.

4. If static run-up cannot be held, repeat Steps 1. thru 3. as needed.

b. Metallic Composition Burn-in.

1. Taxi the airplane at 34 to 40 M.P.H. (30 to 35 Knots) and perform full stop braking application.

CAUTION

Brake conditioning using successive stops at higher speeds could cause brakes to overheat resulting in warped discs and/or pressure plates.

2. Without allowing brake discs to cool substantially, repeat Step 1. for second full stop braking application.

3. Apply brakes and check to see if a high throttle static engine run-up can be held with normal pedal force. If so, conditioning burn-in is complete.

4. If static run-up cannot be held, repeat Steps 1. thru 3. as needed.

NOTE

Normal brake usage should generate enough heat to maintain the glaze throughout the life of the lining. Light brake usage can cause the glaze to wear off, resulting in reduced brake performance. Visual inspection of brake disc will indicate brake lining condition. A smooth, non-grooved surface indicates linings are properly glazed. Rough, grooved linings must be reglazed. In such cases, the lining may be conditioned again following the instructions set forth above.

NOTE

Do not set parking brakes while brake discs are hot.

MODEL 210 & T210 SERIES SERVICE MANUAL

5-75. CHECKING BRAKE LINING WEAR. New brake lining should be installed when the existing lining has worn to a thickness of 3/32-inch. A 3/32-inch strip of material held adjacent to each lining can be used to determine amount of wear. The shank end of a drill bit of the correct size can also be used to determine wear of brake linings.

5-76. BRAKE LINING INSTALLATION. (Refer to figure 5-9.)

- a. Remove bolts securing back plate, and remove back plate.
- b. Pull brake cylinder out of torque plate and slide pressure plate off anchor bolts.
- c. Place back plate on a table with lining side down flat. Center a 9/64-inch (or slightly smaller punch in the rolled rivet, and hit the punch sharply with a hammer. Punch out all rivets securing the linings to the back plate in the same manner.

NOTE

A rivet setting kit, Part No. 199-1, is available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations.

- d. Clamp the flat side of the anvil in a vise.
- e. Align new lining on back plate and place brake rivet in hole with rivet head in the lining. Place the head against the anvil.
- f. Center rivet setting punch on lips of rivet. While holding back plate down firmly against lining, hit punch with a hammer to set rivet. Repeat blows on punch until lining is firmly against back plate.
- g. Realign the lining on the back plate and install and set rivets in the remaining holes.
- h. Install a new lining on pressure plate in the same manner.
- i. Position pressure plate on anchor bolts and place cylinder in position so that anchor bolts slide into the torque plate.
- j. Install back plate with bolts and washers.

WARNING

After reinstallation of the brake assembly, check brake line clearance to the disc in the area above the axle.

5-77. BRAKE SYSTEM BLEEDING.

NOTE

Bleeding with a clean hydraulic pressure source connected to the wheel cylinder bleeder is recommended.

- a. Remove brake master cylinder filler plug and screw flexible hose with appropriate fitting into the filler hole at top of the brake master cylinder.
- b. Immerse opposite end of flexible hose into a container with enough hydraulic fluid to cover end of the hose.
- c. Connect a clean hydraulic pressure source, such as a hydraulic hand pump or Hydro-Fill unit to the bleeder valve in the wheel cylinder.
- d. As fluid is pumped into the system, observe the immersed end of the hose at the master cylinder for evidence of air bubbles being forced from the brake system. When bubbling has ceased, remove bleeder source from wheel cylinder and tighten the bleeder valve.

5-78. PARKING BRAKE SYSTEM. (Refer to figure 5-13.)

5-79. DESCRIPTION. The parking brake system consists of a handle and ratchet mechanism, connected by a cable to linkage at the brake master cylinders. Pulling out on the handle depresses both brake master cylinder piston rods and the handle ratchet locks the handle in this position until the handle is turned and released.

5-80. REMOVAL AND INSTALLATION OF COMPONENTS. Refer to figure 5-13 for relative location of system components. The illustration may be used as a guide during removal and installation of components.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-13. Parking Brake System

5-79. DESCRIPTION. The parking brake system consists of a handle and ratchet mechanism, connected by a cable to linkage at the brake master cylinders. Pulling out on the handle depresses both brake master cylinder piston rods and the handle ratchet locks the handle in this position until the handle is turned and released.

5-80. REMOVAL AND INSTALLATION OF COMPONENTS. Refer to figure 5-13 for relative location of system components. The illustration may be used as a guide during removal and installation of components.

MODEL 210 & T210 SERIES SERVICE MANUAL

5-81. INSPECTION AND REPAIR OF SYSTEM COMPONENTS. Inspect lines for leaks, cracks, dents, chafing, improper radius, security, corrosion, deterioration, obstructions and foreign matter. Check brake master cylinders and repair or replace as outlined in applicable paragraph in this Section. Check parking brake handle and ratchet for proper operation and release. Replace worn or damaged parts.

5-82. NOSE GEAR SYSTEM.

5-83. DESCRIPTION. The nose gear consists of a pneumatic shock strut assembly, mounted in a trunnion assembly, a steering arm and bungee.

5-85. TROUBLE SHOOTING.

shimmy dampener, uplock mechanism, nose wheel, tire and tube, hub cap, bearings, seals and a double-acting hydraulic actuator for extension and retraction. A claw-like hook on the actuator serves as a downlock for the nose gear.

5-84. OPERATION. The nose gear shock strut is pivoted just forward of the firewall. Retraction and extension of the nose gear is accomplished by a double-acting hydraulic cylinder, the forward end of which contains the nose gear downlock. Initial action of the cylinder disengages the downlock before retraction begins. A separate single-acting hydraulic cylinder unlocks the nose gear uplock hook.

TROUBLE	PROBABLE CAUSE	REMEDY
HYDRAULIC FLUID LEAKAGE FROM NOSE STRUT.	Defective strut seals and/or defects in lower strut.	Replace defective seals; stone out small defects in lower strut. Replace lower strut if badly scored or damaged.
NOSE STRUT WILL NOT HOLD AIR PRESSURE.	Defective filler valve or valve not tight.	Check gasket and tighten loose valve. Replace defective valve.
	Defective O-ring at top of strut.	Replace O-ring.
	Result of fluid leakage at bottom of strut.	Replace defective seals; stone out small defects in lower strut. Replace lower strut if badly scored or damaged.
NOSE WHEEL SHIMMY.	Nose strut attachment loose.	Secure attaching parts.
	Shimmy dampener lacks fluid.	Service shimmy dampener.
	Defective shimmy dampener.	Repair or replace dampener.
	Loose or worn steering components.	Tighten loose parts; replace if defective.
	Loose torque links.	Add shim washers and replace parts as necessary.
	Loose wheel bearings.	Replace bearings if defective; tighten axle nut properly.
	Nose wheel out of balance.	Refer to applicable paragraph.

5-86. REMOVAL OF NOSE GEAR ASSEMBLY.

a. Jack aircraft or weight the tail of aircraft to raise nose wheel off the ground.

WARNING

Before working in landing gear wheel wells, PULL-OFF hydraulic pump circuit breakers. Thru Serial 21062273, the pump circuit breaker is located in

the circuit breaker panel, located immediately forward of the pilot's control wheel. Beginning with Serial 21062274, the pump circuit breaker is located in the circuit breaker panel, located immediately forward of the left forward doorpost. The hydro-electric power pack system is designed to pressurize the landing gear DOOR CLOSE system to 1500 psi at any time the master switch

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-14. Nose Gear Installation

is turned on. Injury might occur to someone working in wheel well area if master switch is turned on for any reason.

- b. Open landing gear doors and disconnect nose wheel door push-pull rods (items 13, figure 5-21.)
- c. Tag for identification and disconnect electrical wires at gear-down microswitch, located on forward end of nose gear actuator (item 6, figure 5-19.)
- d. Tag for identification and disconnect electrical wires at nose gear safety switch on torque links and remove clamps attaching wires to nose gear strut.
- e. Disconnect steering bungee from steering bell-crank.
- f. Disconnect nose gear actuator from strut by removing cotter pin, castellated nut and spring clip, after removing safety wire from turnbuckle and loosening turnbuckle barrel. Remove washers and bolt.

NOTE

Retain spacer washers between downlock hooks on end of actuator.

- g. Disconnect nose gear strut door tie rods (items 2, figure 5-21) from nose gear.
- h. Remove trunnion bolts (items 4 and 13, figure 5-14.)

NOTE

Trunnion bolts are accessible from inside the cabin at the very forward end of the tunnel cover at the firewall. Two men will be required to remove these bolts, one working inside the cabin, and the other working in the nose wheel well. Observe the WARNINGS in this paragraph and at the beginning of this Section.

MODEL 210 & T210 SERIES SERVICE MANUAL

1. Work entire nose gear assembly free of aircraft.

5-87. DISASSEMBLY OF NOSE GEAR STRUT. (Refer to figure 5-15.)

NOTE

The following procedure applies to the nose gear shock strut after it has been removed from the aircraft, and the nose wheel has been removed. In many cases, separating the upper and lower struts will permit inspection and parts replacement without removal or complete strut disassembly.

WARNING

Deflate strut completely before removing bolt (33), lock ring (31) or bolt (2). Also deflate strut before disconnecting torque links.

- a. (Refer to figure 5-14.) Remove torque links (17). Note positions of washers, shims, spacers, and bushings.
- b. (Refer to figure 5-14.) Remove shimmy dampener (10) and steering bungee (12).
- c. Remove link from steering shaft and collar.
- d. Remove lock ring from groove inside lower end of upper strut. A small access hole is provided at the lock ring groove to facilitate removal of lock ring.

NOTE

Hydraulic fluid will drain from strut as lower strut is pulled from upper strut.

- e. Using a straight, sharp pull, remove lower strut from upper strut. Invert lower strut and drain hydraulic fluid from strut.
- f. Remove lock ring and bearing from lower strut.
- g. Slide shims, if used, packing support ring, scraper ring, retaining ring and lock ring from lower strut.

NOTE

Note number of shims, relative position and top side of each ring and bearing to aid in reassembly.

- h. Remove and discard O-rings and back-up rings from packing support ring.
- i. Remove metering pin and base plug by removing bolt from lower strut and fork assembly.

NOTE

Lower strut and fork are a press fit, drilled on assembly. Separation of these parts is not recommended, except for replacement of parts.

- j. Remove and discard O-rings from metering pin and base plug.

k. Remove orifice support by removing bolt at top of strut. Remove and discard O-ring from orifice support.

- 1. Remove collar from upper strut. To remove collar, remove bolt and tab washer. Remove washers, shims, if installed, and steering collar.

NOTE

Upper and lower trunnions are press fitted to the upper strut with braces installed during assembly. Pin is also press fitted to the lower trunnion.

5-88. INSPECTION AND REPAIR OF SHOCK STRUT COMPONENTS. (Refer to figure 5-15.)

- a. Bushings and bearings in upper trunnion and lower trunnion may be replaced as required. Needle bearing in collar should not be replaced. Replace entire steering collar if needle bearing is defective.
- b. Thoroughly clean all parts in solvent and inspect them carefully. Replace all worn or defective parts and all O-rings, seals and back-up rings with new parts.
- c. Sharp metal edges should be smoothed with No. 400 emery paper, then cleaned with solvent.

5-89. REASSEMBLY OF NOSE GEAR STRUT. (Refer to figure 5-15.)

NOTE

Assemble these parts lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606 or Dow Corning DC-7.

- a. Install top washer (21), steering collar (21), shims (22) (as many as were removed), and collar (23). Screw collar (23) up threads on lower end of upper strut (10) until it is flush with the lower end of the strut, to the nearest one-third turn. Use shims as required above lower washer, to fill gap between collars. Shims are available from Cessna Parts Distribution (CPD 2), through Cessna Service Stations, as follows:

1243030-5	0.006"
1243030-6	0.012"
1243030-7	0.020"

NOTE

When correct number of shims are installed, secure collar (23) with bolt (43) and secure bolt with tab washer (44) by bending tabs of washer.

- b. Install O-ring (37) on base plug (36).
- c. Install O-ring (35) on metering pin (38), and install in base plug (36).
- d. Install bolt (33) through holes in fork (34) and base plug (36). Install nut on bolt.
- e. Install lock ring (31), retaining ring (30) and scraper ring (29) down over lower strut (27). Ensure they are installed in same positions as they were when removed.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-15. Nose Gear Shock Strut Assembly

f. Install O-rings (40) and (41) and back-up rings (39) in packing support ring (28).

on each side of O-ring (40) with concave surface of back-up rings next to O-ring.

NOTE

Install contoured back-up rings (39), one

g. Install bearing (25) and lock ring (24) at upper end of lower strut assembly.

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

Ensure that beveled edge of bearing is installed up next to lock ring.

- h. Install upper strut assembly over lower strut assembly.
- i. Install lock ring (31) in groove in lower end of upper strut (10). Position lock ring so that one of its ends covers the small access hole in the lock ring groove.
- j. Install steering shaft (17) up through hole in lower trunnion (8) and hole in upper trunnion (3).
- k. Install steering arm (14) over steering shaft (17) and secure with roll pins.
- l. Install link (18) to bottom of steering shaft (17) and attach opposite end to steering collar (21).
- m. If braces (1) were removed, they should be installed, connecting at upper trunnion (3) and lower trunnion (8).
- n. Attach lower torque link to torque link fitting (32) and upper torque link to steering collar (21).
- o. Install O-ring (6) and filler valve (5) on orifice support (7).
- p. Install orifice support in upper strut (10), install bolt (2).
- q. Service shock strut as outlined in Section 2 of this manual.

5-90. INSTALLATION OF NOSE GEAR STRUT.

WARNING

Before working in landing gear wheel wells, PULL-OFF hydraulic pump circuit breakers. Thru Serial 21062273, the pump circuit breaker is located in the circuit breaker panel, located immediately forward of the pilot's control wheel. Beginning with Serial 21062274, the pump circuit breaker is located in the circuit breaker panel, located immediately forward of the left forward doorpost. The hydro-electric power pack system is designed to pressurize the landing gear DOOR CLOSE system to 1500 psi at any time the master switch is turned on. Injury might occur to someone working in wheel well area if master switch is turned on for any reason.

- a. Work entire nose gear assembly into nose gear wheel well.

NOTE

Trunnion bolts are accessible from inside the cabin, at the very forward end of the tunnel cover at the firewall. Two men will be required to install these bolts, one working inside the cabin, the other working in the nose wheel well.

- b. Install trunnion bolts (items 4 and 13, figure 5-14.)
- c. Install nose gear strut door tie rods (items 2, figure 5-21.) Install right-hand tie rod on outboard side of eyebolt only (as shown in figure 5-21), when connecting nose gear strut doors. Left-hand tie rod clevis should be installed as shown in figure 5-21.
- d. Install nose gear actuator, washers, spring clip and castellated nut.

NOTE

When connecting nose gear actuator to strut, lubricate and torque bolt as outlined in the lubrication charts in Section 2 of this manual.

- e. Install steering bungee to steering bellcrank.
- f. Connect wires marked for identification at safety switch on torque links, and install clamps attaching wires to nose gear strut.
- g. Connect electrical wires marked for identification at gear-down microswitch, located on forward end of nose gear actuator (item 5, figure 5-19.)
- h. Connect nose wheel door push-pull rods (items 13, figure 5-21.)
- i. Rig nose gear and nose gear doors in accordance with procedures outlined in applicable paragraphs in this Section.
- j. Rig retractable step cable in accordance with procedures outlined in applicable paragraph in this Section.

5-91. SHIMMY DAMPENER. (Refer to figure 5-16.)

5-92. DESCRIPTION. The shimmy dampener is a self-contained hydraulic cylinder which acts as a restrictor. When the steering system reacts too rapidly, the shimmy dampener maintains pressure against the steering arm by means of a piston which permits a restricted flow of hydraulic fluid from either end of the cylinder to the other through an orifice in the piston.

5-93. SHIMMY DAMPENER REMOVAL. (Refer to figure 5-14.)

- a. Remove bolt securing shimmy dampener to steering shaft.
- b. Remove bolt attaching dampener to bracket, attached to lower trunnion.
- c. Remove shimmy dampener from aircraft.

5-94. DISASSEMBLY OF SHIMMY DAMPENER. (Refer to figure 5-16.)

- a. Remove outer retaining ring (7).
- b. Remove bearing head (6).
- c. Remove O-rings (3) from bearing head.
- d. Remove internal retaining ring (5).
- e. Remove rod assembly (8).

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-16. Shimmy Dampener

- f. Remove O-ring (3), and back-up ring (9).
- g. Remove setscrew (14), spring (13), floating piston (12) and O-ring (3).
- h. Remove bolt (1) and Stat-O-Seal (2).
- i. Remove O-ring (3).

5-95. INSPECTION AND REPAIR OF SHIMMY DAMPENER. (Refer to figure 5-16.)

- a. Thoroughly clean all parts in solvent and inspect carefully.
- b. Sharp metal edges should be smoothed with No. 400 emery paper, then thoroughly cleaned with solvent.
- c. Replace all worn or defective parts.

5-96. REASSEMBLY OF SHIMMY DAMPENER. (Refer to figure 5-16.)

NOTE

Lubricate new seals, packing and internal parts with Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7. Do not use DC-7 on surfaces to be painted.

- a. If piston (10) was removed, install piston and install roll pin (11).

NOTE


Orifice in piston (10) connects to passage in rod assembly (8).

- b. Install O-ring (3), floating piston (12), spring (13) and setscrew (14) in rod assembly (8).
- c. Install O-ring (3) in barrel (4).
- d. Install rod assembly (8) in barrel (4).
- e. Install back-up ring (9) and O-ring (3).
- f. Install internal retaining ring (5).
- g. Install O-rings (3) on bearing head (6).
- h. Install bearing head (6) over shaft assembly (8) in barrel (4).
- i. Install outer retaining ring (7).
- j. Install Stat-O-Seal (2) on bolt (1).
- k. Install bolt (1) in barrel (4).
- l. Service shimmy dampener in accordance with procedures outlined in Section 2 of this manual.

5-97. TORQUE LINKS. (Refer to figure 5-17.)

5-98. DESCRIPTION. The torque links align the lower strut with the nose gear steering system, but

MODEL 210 & T210 SERIES SERVICE MANUAL



NOTE

Shims (4) are available to use as required between torque link and nose gear fork to remove any looseness. Also, shim (15) is used as required (maximum of three shims) to prevent over-extension of the nose gear strut. See figure 5-15. Lubricate torque links with MIL-G-81522A general purpose grease.

1. Nut
2. Cotter Pin
3. Washer
4. Shim
5. Bushing
6. Upper Torque Link
7. Grease Fitting
8. Safety Switch
9. Bracket
10. Spacer
11. Bolt
12. Switch Actuator
13. Lower Torque Link
14. Centering Lug
15. Shim
16. Bolt

Figure 5-17. Nose Gear Torque Links

permit shock strut action.

5-99. REMOVAL OF TORQUE LINKS. (Refer to figure 5-17.)

WARNING

DEFLATE NOSE GEAR SHOCK STRUT COMPLETELY BEFORE REMOVING TORQUE LINKS.

- a. Remove nuts and washers attaching safety switch (8) to bracket (9); remove switch from bracket
- b. Remove washers, shims, spacers, bolts and nuts. Nose position of attaching hardware for reinstallation.

5-100. DISASSEMBLY AND REASSEMBLY. (Refer to figure 5-17.) The figure may be used as a guide for disassembly and reassembling the torque links. Bushings should not be removed except for replacement of parts. Replace any parts

if excessively worn.

5-101. INSTALLATION OF TORQUE LINKS.

- a. With shock strut completely deflated, install upper torque link to collar on nose gear strut.
- b. Install lower torque link to torque link attach point on nose gear fork.
- c. Install upper key washer and nut on safety switch, install switch in bracket, and install star washer and nut on threads of switch.
- d. Tighten attaching bolt nuts snugly, then tighten to align next castellation with cotter pin hole in bolt.
- e. Check upper and lower torque links for looseness. If looseness is apparent, remove attaching nuts and install shims (item 4, figure 5-17) as necessary to take up any looseness. This will assist in preventing nose wheel shimmy.
- f. Retighten attaching nuts snugly, then tighten to align next castellation with cotter pin hole in bolt; install cotter pin.
- g. Fill and inflate shock strut in accordance with procedures outlined in Section 2 of this manual.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-18. Nose Gear Uplock Mechanism

5-102. NOSE GEAR UPLOCK MECHANISM. (Refer to figure 5-18.)

5-103. DESCRIPTION. The nose gear uplock mechanism, located in the top of the nose wheel well, is a hydraulically-unlocked hook that is spring-loaded to the locked position. The nose gear indicator switch is attached to a bracket welded to the uplock hook.

5-104. REMOVAL OF NOSE GEAR UPLOCK MECHANISM. (Refer to figure 5-18.)

a. With master switch OFF, pump landing gear doors open.

NOTE

With doors open, all components are readily accessible at top forward end of the nose wheel well.

- b. Disconnect links (11) from actuator (10).
- c. Disconnect spring (9) from aircraft structure or from hook on bellcrank assembly (3).
- d. Unscrew nut attaching uplock switch (5).
- e. Remove bolt (1) through right-hand tunnel wall.

5-105. INSTALLATION OF NOSE GEAR UPLOCK MECHANISM. (Refer to figure 5-18.)

a. Place bellcrank and hook (3) assembly in

position and install washer between bellcrank and right-hand tunnel wall, then install bellcrank and hook assembly; install bolt (1), bearing (8), washer and nut.

- b. Install uplock switch (5).
- c. Attach spring (9) to aircraft structure or to hook on bellcrank assembly (3).
- d. Connect links (11) to actuator (10).
- e. Rig system in accordance with applicable paragraph.

5-106. NOSE GEAR DOWNLOCK MECHANISM. (Refer to figure 5-19.)

5-107. DESCRIPTION. The nose gear downlock mechanism is a hook at the piston rod end of the nose gear actuator.

5-108. REMOVAL AND INSTALLATION OF NOSE GEAR DOWNLOCK MECHANISM. (Refer to figure 5-19.) Refer to figure 5-20 and paragraph 5-111, which outlines procedures for removing the nose gear actuator. Components of the downlock mechanism will be freed as the actuator is removed.

5-109. NOSE GEAR ACTUATOR. (Refer to figure 5-20.)

5-110. DESCRIPTION. The nose gear actuator extends and retracts the nose gear and serves as a

MODEL 210 & T210 SERIES SERVICE MANUAL

● May be purchased from:
Electro-Film Inc.
7116 Laurel Canyon Blvd.
Hollywood, CA 91605

★ May be purchased from:
Everlube Corp.
P. O. Box 2200
Hi-Way 52 N. W.
West LaFayette, Ind. 47906

NOTE

The downlock hooks (2) and (7) have been dry film lubricated at the factory and should last the life of the parts. However, they may be field lubricated with the following products:

- 1. Lubri-Bond A.
- 2. Lubri-Bond 220.
- ★ 3. Permasilk.

After application allow parts to air dry for six hours, or dry for one hour at 120°F.




Figure 5-19. Nose Gear Downlock Mechanism

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-20. Nose Gear Actuator

rigid drag strut in the gear-down position. A spring clip attaches the retractable step cable turnbuckle to the nose gear actuator.

5-111. REMOVAL OF NOSE GEAR ACTUATOR.

(Refer to figure 5-19.)

- a. Open doors and jack aircraft or weight down tail to raise nose wheel off the ground.
- b. Tag for identification and disconnect electrical wires at the downlink switch (5), located at the forward end of the actuator (6).
- c. Disconnect hydraulic hoses from actuator (6). Cap or plug hose and fitting openings to prevent entry of foreign material.
- d. Disconnect actuator (6) from lower trunnion (1) by removing cotter pin, castellated nut, washers, and bolt.
- e. Retain components of downlock mechanism which will be freed by removing bolt (8).

5-112. DISASSEMBLY OF NOSE GEAR ACTUATOR.

(Refer to figure 5-20.)

- a. Loosen nut (13) at end of piston (19) and remove rod

end assembly as a unit; remove nut from piston (19).

- b. Remove safety wire from knurled nut (17), and loosen knurled nut (17).
- c. Remove bearing end (16) from cylinder (22), and remove knurled nut (17) from cylinder (22).
- d. Pull piston from cylinder (22).
- e. Remove O-rings (18) and back-up rings (20) from bearing end (16) and piston (19).
- f. Disassemble hook assembly.

NOTE

Remember that spring clip is installed under castellated nut and washer.

5-113. INSPECTION AND REPAIR OF PARTS OF NOSE GEAR ACTUATOR. (Refer to figure 5-20.)

- a. Inspect all threaded surfaces for cleanliness and for cracks or excessive wear.
- b. Inspect downlock hook spring for evidence of breaks and distortion. Free length of spring must be 2.406 ± 0.080 -inches, and compressed to 2.00-

MODEL 210 & T210 SERIES SERVICE MANUAL

inches under a 19.80 ± 2.0 pound load.

c. Inspect hooks, spring guide, bearing end, piston, cylinder and bushing for cracks, chips, scratches, scoring, wear or surface irregularities which may affect their function or the overall function of the nose gear actuator.

d. Repair of most parts of the actuator assembly is impractical. Replace defective parts with serviceable parts.

e. Minor scratches and scores may be removed by polishing with fine abrasive crocus cloth (Federal Specification PC-458), providing their removal does not affect operation of the unit.

5-114. ASSEMBLY OF NOSE GEAR ACTUATOR. (Refer to figure 5-20.)

NOTE

When reassembling actuator, install new O-rings and back-up rings lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

- a. Install O-rings and back-up rings in bearing end.
- b. Install O-rings and back-up rings on piston.
- c. Insert piston into cylinder. Do not damage back-up rings and O-rings when inserting piston.
- d. With knurled nut on cylinder, install bearing end on cylinder. Use care to avoid damage to O-rings and back-up rings when installing bearing end on cylinder.

NOTE

Centerlines of hook pin holes and bushing hole must be parallel within .005 with actuator assembled to a length of 11.58" ± .03 (thru 1978 models.) 11.98" ± .03 (Beginning with 1979 models).

- e. Tighten and safety wire knurled nut.
- f. Install lock nut on end of piston.
- g. Assemble and install hook assembly on piston.

5-115. INSTALLATION OF NOSE GEAR ACTUATOR.

NOTE

Before installing nose gear actuator, check condition of fit and attaching bolts and bushings. Replace any defective parts. Fill actuator with hydraulic fluid.

- a. Attach aft end of actuator to fuselage structure with bolt, washer and nut. Safety nut with cotter pin.
- b. Assemble and attach nose gear downlock mechanism to lower trunnion as shown in figure 5-18.

5-116. REMOVAL AND INSTALLATION OF NOSE GEAR UPLOCK AND RELEASE ACTUATOR.

- a. Disconnect uplock spring.

b. Disconnect and cap or plug hydraulic lines at actuator.

c. Disconnect and tag up-limit switch electrical wires.

d. Remove cotter pin and clevis pin attaching actuator link to bellcrank arm. Note position of spacer washers and direction of clevis pin.

e. Remove nuts, washers and bolts attaching actuator to wheel well tunnel wall. Note and retain shims between actuator and tunnel wall.

f. Remove bolt, washer and nut attaching bellcrank at top of nose wheel.

NOTE

Use care to avoid dropping bearings in bellcrank assembly. Retain washers used as shims at each end of bellcrank.

g. Install uplock mechanism and actuator by reversing the preceding steps. Install shims and washers as noted during removal.

5-117. DISASSEMBLY, INSPECTION AND REPAIR OF PARTS AND REASSEMBLY OF NOSE GEAR UPLOCK AND RELEASE ACTUATOR. (Refer to figure 5-5 and paragraphs 5-23 thru 5-25.)

5-118. NOSE GEAR DOOR SYSTEM. (Refer to figure 5-21.)

5-119. DESCRIPTION. The nose gear door system consists of a right and left forward door, actuated by push-pull rods and a torque tube assembly and a right and left aft door, mechanically linked to the nose gear trunnion.

5-120. OPERATION. The nose gear forward doors open for nose gear retraction or extension and close again when the cycle is completed. These doors are held in the closed position by the door lock valve, located in the door manifold assembly, mounted on the power pack, by trapping fluid in the door lines. Actuation of the nose gear forward doors is accomplished by a double-acting hydraulic cylinder. The nose gear aft doors are mechanically linked to the nose gear trunnion. These doors open as the nose gear extends and close as it is retracted.

5-121. REMOVAL AND INSTALLATION OF NOSE WHEEL DOORS. (Refer to figure 5-21.)

- a. Open landing gear doors.
- b. Remove engine cowl.
- c. Disconnect push-pull rod from bracket on door by removing nut, bolt and washers.
- d. Remove nuts and bolts attaching each hinge pivot. Work from upper side of cowl opening to remove bolts. Retain bushings in hinge pivot.
- e. To replace nose wheel doors, reverse the preceding steps.

5-122. REMOVAL AND INSTALLATION OF NOSE WHEEL DOOR MECHANISM. (Refer to figure 5-21.)

- a. Open landing gear doors.
- b. Disconnect actuator at torque tube by

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-21. Nose Gear Door System

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-22. Nose Wheel Steering System

removing nut, washer and bolt.

c. Disconnect and cap or plug hydraulic hose at actuator.

d. Remove nut, washer and bolt attaching actuator to its mounting bracket in nose wheel well. (See "notes" in figure 5-21.)

e. Disconnect door push-pull rods at door bracket.

f. Remove torque tube by removing nuts, washers and bolts securing it to mounting brackets.

g. Reverse preceding steps for installation.

5-123. REMOVAL AND INSTALLATION OF NOSE GEAR STRUT DOORS. (Refer to figure 5-21.)

a. Disconnect tie rod assemblies from door.

b. Remove screw, washer and nut securing door hinge pin and pull hinge pin from door hinge, allowing door to be removed.

c. To remove tie rod assemblies, remove ball end stud securing tie rod to nose gear trunion. Do not change length of rod assembly unless necessary. Changing rod assembly length will make readjustment necessary on installation.

d. Install strut doors and linkage by reversing preceding steps.

e. Observe note in figure 5-21.

NOTE

Install right-hand tie rod on outboard side of eyebolt only, when connecting nose gear strut doors. Left-hand tie rod should be installed as shown in figure 5-21.

5-124. NOSE WHEEL STEERING SYSTEM. (Refer to figure 5-22.)

5-125. DESCRIPTION. The nose wheel steering system links the rudder pedals to the nose wheel fork, affording steering control through use of the rudder pedals. The nose gear torque links straighten the nose wheel as the landing gear is retracted.

5-126. REMOVAL AND INSTALLATION OF NOSE WHEEL STEERING SYSTEM COMPONENTS. (Refer to figure 5-22.) Refer to the figure as a guide in determining relationship of steering system components. Also, the illustration may be used as a guide during removal and installation of system components.

5-127. RIGGING OF NOSE WHEEL STEERING SYSTEM. Since the nose wheel steering system is connected with the rudder control system, adjustment to one system would directly affect the other. Refer to Section 10 of this manual for rigging procedures for the rudder system and the nose wheel steering system.

5-128. TROUBLE SHOOTING. (Refer to paragraph 5-85.)

5-129. NOSE WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-23.)

5-130. DESCRIPTION. The aircraft may be equipped with either Cleveland or McCauley wheel assemblies. Separate disassembly, inspection and reassembly procedures are provided for each type.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-23. Nose gear Wheel and Tire Assembly

NOTE

Use of recapped tires or new tires not listed on the aircraft equipment list are not recommended due to possible interference between the tire and structure when landing gear is in the retracted position.

5-131. OPERATION. The nose gear wheel is free-rolling on an independent axle and is used to steer the aircraft while taxiing by means of the nose wheel steering system.

5-132. REMOVAL OF NOSE WHEEL AND TIRE ASSEMBLY.

MODEL 210 & T210 SERIES SERVICE MANUAL

- a. Weight tail of aircraft to raise nose wheel off the ground.
- b. Remove nose wheel axle bolt.
- c. Use a rod or long punch inserted in ferrule to tap opposite ferrule out of nose wheel fork.
- d. Remove spacers, axle tube and hub caps before disassembling nose wheel.
- e. Reverse preceding steps to install nose wheel. Tighten axle bolt until a slight bearing drag is obvious when the wheel is turned. Back off nut to nearest castellation and install cotter pin.

5-133. DISASSEMBLY OF CLEVELAND NOSE WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-23.)

WARNING

Injury can result from attempting to separate wheel halves with the tire inflated. Avoid damaging wheel flanges when breaking tire beads loose.

- a. Remove valve core, completely deflate tire, and break tire beads loose.
- b. Remove thru-bolts and separate wheel halves.
- c. Remove tire and tube.
- d. Remove snap rings (1), grease seal felts (6), grease seal rings (2), and bearings (3).

NOTE

The bearing cups are a press fit in the wheel halves and should not be removed unless replacement is necessary. To remove, heat wheel half in boiling water for 15 minutes. Using an arbor press, if available, press out bearing cup and press in the new one while the wheel is still hot.

5-134. INSPECTION AND REPAIR OF CLEVELAND NOSE WHEEL AND TIRE ASSEMBLY. Procedures outlined in paragraph 5-41 for the main wheel and tire assemblies may be used as a guide for inspection and repair of the nose wheel and tire assembly.

5-135. REASSEMBLY OF CLEVELAND NOSE WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-23.)

- a. Place tube inside tire and align balance marks on tire and tube.
- b. Place tire and tube on wheel half with tube valve stem through hole in wheel half.

CAUTION

Uneven or improper torque of the thru-bolt nuts may cause bolt failure with resultant wheel failure.

- c. Insert thru-bolts, position other wheel half and secure with nuts and washers. Torque bolts to value stipulated in figure 5-23.
- d. Clean and repack bearing cones with clean wheel bearing grease.
- e. Assemble bearings (3), grease seal rings (2), and grease seal felts (6) into wheel halves and install snap rings (1).

- f. Inflate tire to seat tire beads, then adjust to correct pressure.

5-136. DISASSEMBLY OF McCAULEY NOSE WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-23.)

- a. Remove hub caps, completely deflate tire, and break tire beads loose at wheel flanges.

WARNING

Injury can result from attempting to remove wheel flanges with tire and tube inflated. Avoid damaging wheel flanges when breaking tire beads loose. A scratch, gouge or nick in wheel flange could cause wheel failure.

- b. Remove nuts and washers.
- c. Remove thru-bolts and washers.
- d. Separate and remove wheel halves from tire and tube.
- e. Remove retainer ring (13), grease seal retainer (14), felt grease seal (15), and bearing cone (21) from each wheel half (18).

NOTE

The bearing cups (races) are a press fit in the wheel hub and should not be removed unless a new part is to be installed. To remove the bearing cup, heat wheel hub in boiling water for 30 minutes, or in an oven not to exceed 121°C (250°F). Using an arbor press, if available, press out the bearing cup and press in the new bearing cup while the wheel hub is still hot.

5-137. INSPECTION AND REPAIR OF McCAULEY NOSE WHEEL AND TIRE ASSEMBLY.

- a. Clean all metal parts and felt grease seals in Stoddard solvent, or equivalent, and dry thoroughly.

NOTE

A soft bristle brush may be used to remove hardened grease, dust or dirt.

- b. Inspect wheel halves (18) for cracks or damage.
- c. Inspect bearing cones (21), bearing cups (19), retainer rings (13), and felt grease seals (15) for wear or damage.
- d. Inspect thru-bolts (20) and nuts (16) for cracks in threads or cracks in radius under bolt head.
- e. Replace cracked or damaged wheel halves (18).
- f. Replace damaged retainer rings (13) and seals.
- g. Replace any worn or cracked thru-bolts (20) or nuts (16).
- h. Replace any worn or damaged bearing cups (19) or bearing cones (21).
- i. Remove any corrosion or small nicks.
- j. Repair reworked areas of wheel by cleaning thoroughly, then applying one coat of clear lacquer paint.
- k. Pack bearing cones (21) with grease specified in Section 2 of this manual.

5-138. REASSEMBLY OF McCAULEY NOSE WHEEL AND TIRE ASSEMBLY. (Refer to figure 5-23.)

- a. Assemble bearing cone, grease seal retainer, felt grease seal, grease seal retainer and retaining ring into both wheel halves.
- b. Insert tube in tire, aligning index marks on tire and tube.

MODEL 210 & T210 SERIES SERVICE MANUAL

- c. Place wheel half into tire and tube (side opposite valve stem), aligning base of valve stem in valve slot. With washer under head of thru-bolt, insert bolt through wheel half.
- d. Place wheel half into other side of tire and tube, aligning valve stem in valve slot.
- e. Install washers and nuts on thru-bolts and pre-torque to 10-50 lb. in.

CAUTION

Uneven or improper torque of nuts can cause failure of bolts with resultant wheel failure. Do not use impact wrench on thru-bolts or nuts.

- f. Prior to torquing nuts, inflate tire to 10-15 psi air pressure to seat tire.
- g. Dry torque nuts evenly to 140-150 in lb.
- h. Inflate tire to pressure specified in Section 1.

5-139. INSTALLATION OF NOSE WHEEL AND TIRE ASSEMBLY.

- a. Install nose wheel in fork and install ferrules.
- b. Install axle stud.
- c. Tighten axle stud until a slight bearing drag is obvious when the wheel is turned. Back off nut to nearest castellation and install cotter pins.

5-140. THRU 5-151. DELETED.

5-152. HYDRAULIC POWER SYSTEM COMPONENTS. (Refer to figure 5-24.)

5-153. GENERAL DESCRIPTION. The hydraulic power system includes equipment required to provide a flow of pressurized hydraulic fluid to the retractable landing gear system. Main components of the hydraulic power system include the power pack and the emergency hand pump.

5-154. HYDRAULIC COMPONENTS REPAIR. Since emphasis here is on repair and not overhaul of the basic components of the hydraulic system, it is unlikely that the mechanic will go through all of the procedures outlined. Instead, he will repair the particular item which is causing the difficulty.

5-155. REPAIR VERSUS REPLACEMENT. Often, the moderate trade-in price for a factory-rebuilt component is less than the accumulated cost of labor, parts and (often time consuming) trial and error adjustment. Repair or replacement of a component will depend on the time, equipment and skilled labor that is locally available.

5-156. REPAIR PARTS AND EQUIPMENT. Repair parts may be ordered from the applicable Parts Catalog. Test equipment may be ordered from the Special Tools and Support Equipment Catalog. Both publications are available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations.

5-157. EQUIPMENT AND TOOLS.

5-158. HAND TOOLS. The following hand tools are necessary for repair work on the power pack and other hydraulic components.

- Snap Ring Pliers
- Strap Wrench (for removing door solenoids and various cylinder barrels of the hydraulic actuators.)
- Needle-Nose Pliers
- Pin Punches
- Duck-bill Pliers
- Box end and Open end Wrenches

Locally-fabricated items, handy for power pack repair, are various 1/4-inch aluminum rods, ground to a gradual taper, and hooks formed from brass welding rod to extricate small plungers from hydraulic ports. Hooks formed from brass welding rod must not be over 1/16-inch in length, so as not to scratch or score the bore. Various sizes of Allen wrenches may be welded to "T" handles for use when removing, installing or adjusting the various internal wrenches, plugs or valves.

5-159. COMPRESSED AIR. The simplest method of removing some hydraulic parts in inaccessible galleries of the power pack is a quick blast of compressed air from behind. Parts can be blown out in seconds, which would otherwise take endless "fishing" operation to extricate. An air hose and nozzle are common-sense tools.

5-159A. HYDRAULIC SYSTEM LEAK CHECK. (Refer to figure 5-24.)

- a. Jack aircraft in accordance with procedures in Section 2 of this manual.
- b. To relieve system pressure, pull the GEAR PUMP circuit breaker to OFF, move the gear selector handle to UP, and move back to the DOWN position.
- c. Install a 0-2000 PSI gage at the tee (Index 47, figure 5-26) on the left side of the power pack.
- d. Push the GEAR PUMP circuit breaker to the ON position, turn ON the master switch, and move gear selector handle to the UP position.
- e. Monitor pressure gage, after retraction cycle is complete, for pressure bleed down.
- f. If bleed down occurs, it can be an internal or external leak anywhere in the system.

NOTE

When any line is disconnected, be prepared for fluid leakage.

- g. Disconnect the return line from the gear selector. If fluid comes from the selector, the internal leak is in the system.
- h. If no leak-by is found, it can be assumed there is an internal leak in the power pack. If leak is found, proceed to step "j." Reconnect the return line.
- i. Power pack internal leakage can only be attributed to a bad thermal relief valve, self-relieving check valve, or self-relieving check valve O-ring. The only way to isolate part that is leaking is to systematically replace

MODEL 210 & T210 SERIES SERVICE MANUAL

the self-relieving check valve O-ring, self-relieving check valve, and then thermal relief valve. Repeat leak test after replacement of each part to ensure leak correction.

j. Remove gear DOWN line from selector. If fluid comes from the line, one or more of the gear actuators is leaking. To locate the leaking actuator, disconnect the return line from each actuator; the leaking actuator will have fluid draining from the actuator port. Following the appropriate paragraphs in this section, remove, overhaul, and reinstall the actuator.

k. Reconnect gear DOWN line to the selector.

l. Recheck all lines that were disconnected for security.

m. Lower the landing gear. Following the procedures in step "b.", relieve the system pressure.

n. Remove the pressure gage from service tee.

o. In accordance with the procedures in Section 2 of this manual replenish the power pack reservoir with MIL-H-5606 hydraulic fluid and bleed the system.

p. Remove aircraft from jacks.

5-160. POWER PACK.

5-161. DESCRIPTION. The hydraulic power pack, located in the pedestal, is a multi-purpose control unit. It contains a hydraulic reservoir, valves, an electrically-driven motor, and the pump. An emergency hand pump, located between the pilot's and copilot's seats, uses reservoir fluid to permit manual extension of the landing gear.

NOTE

The hydraulic power pack relief valve, thermal relief valve, and pressure switch can be operationally checked on the aircraft without power pack removal from the aircraft or disassembly. Refer to paragraph 5-161A for specific instructions. Refer to paragraph 5-172A for relief valve and thermal relief valve bench check instructions if the power pack is removed from aircraft.

5-161A. ON-AIRCRAFT HYDRAULIC POWER PACK OPERATIONAL CHECKS. (Refer to figure 5-26.)

The relief valve, thermal relief valve, and pressure switch should be pressure checked each 100 hours. They can be operationally checked without removal from aircraft. For bench check instructions after removal from power pack, refer to paragraph 5-172A.

NOTE

Checks are to be performed with external power set at 28.5 volts.

a. Relief Valve.

- (1) Jack aircraft in accordance with procedures outlined in Section 2.
- (2) Remove cap and install pressure gage at tee (47) fitting on left side of power pack.
- (3) Pull landing gear circuit breaker.
- (4) Select landing gear handle to DOWN position.
- (5) Install 18 gage (minimum) jumper wire between buss side of contactor and small terminal on pump motor contactor (to energize coil).

(6) Push landing gear circuit breaker in; power pack should run; monitor pressure.

(7) Relief valve should open at 1800 PSI, +0 or -50 PSI.

(8) After check is complete, remove pressure from system, remove pressure gage, install cap on tee (47), pull landing gear circuit breaker, remove jumper wire, push landing gear circuit breaker back in, and return system to original configuration.

b. Thermal Relief Valve.

(1) With aircraft on jacks and pressure gage installed at tee (47) fitting on left side of power pack, pull landing gear circuit breaker.

(2) Select landing gear to DOWN position.

(3) Extend emergency gear pump handle.

(4) Pump emergency gear pump handle and monitor pressure. Thermal relief valve should open at 2050 PSI \pm 100 PSI.

(5) After check is complete, remove pressure from system, remove pressure gage, and install cap on tee (47).

(6) Push in landing gear circuit breaker, and return system to original configuration.

c. Pressure Switch.

(1) With aircraft on jacks and pressure gage installed at tee (47) fitting on left side of power pack, pull landing gear circuit breaker.

(2) Select landing gear UP and DOWN several times to relieve pressure in landing gear system.

(3) Select landing gear UP, and push in landing gear circuit breaker.

(4) After gear raising cycle is complete, check pressure. Pressure should be 1500 PSI.

(5) Select gear DOWN. After gear lowering cycle is complete, pressure should be 1500 PSI.

(6) After check is complete, remove pressure from system, remove pressure gage, install cap on tee, and return system to original configuration.


5-162. REMOVAL OF POWER PACK. (Refer to figure 5-25.)

NOTE

As hydraulic lines are connected or removed, plug or cap all openings to prevent entry of foreign material in the lines or fittings.

- a. Remove front seats and spread drip cloth over carpet.
- b. Remove decorative cover from pedestal as outlined in Section 9 of this manual.
- c. Remove upper panel from aft face of pedestal panel.
- d. Remove screws attaching indicator assembly at top of pedestal; remove indicator assembly.
- e. Remove four bolts attaching wheel and gear box assembly; remove wheel and gear box assembly.
- f. Loosen idler sprocket by loosening bolt and sliding sprocket inboard in slot.
- g. Disconnect chain at its connecting link.
- h. Remove left-hand and right-hand chain guards.
- i. Allow chain to remain on gimbal assembly in lower pedestal area.
- j. Position gallon container under drain elbow at right-hand forward side of pedestal.
- k. Remove cap from elbow and attach drain hose.


MODEL 210 & T210 SERIES SERVICE MANUAL



Thru 21062273

Figure 5-24. Hydraulic System Components (Sheet 1 of 3)


MODEL 210 & T210 SERIES SERVICE MANUAL



21062274 thru 21062954

Figure 5-24. Hydraulic System Components (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL



BEGINNING WITH 21062955

Figure 5-24. Hydraulic System Components (Sheet 3 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-25. Power Pack Removal and Installation

- l. Using hand pump, drain reservoir fluid into container.
- m. Disconnect and cap or plug all hydraulic lines at power pack.
- n. Disconnect wiring from pressure switch.
- o. Remove three mounting bolts, one on each side of pedestal, and one through mounting bracket on forward side of pedestal.

NOTE

It is not necessary to disturb the studs on the left and right side of pedestal to remove the power pack.

- p. Remove power pack and power pack attach bracket (14) from pedestal as a unit..

MODEL 210 & T210 SERIES SERVICE MANUAL

5-163. **DISASSEMBLY OF POWER PACK.** (Refer to figure 5-26.)

- a. Remove fittings from body assembly and place body assembly in vise.
- b. Remove nut (23), reservoir washer (22), and packing (3) at stud (31) at bottom of reservoir (25); remove reservoir.

NOTE

If reservoir will not disengage from body assembly, replace fittings and cap or plug all fittings except vent fitting. Attach air hose at vent fitting and apply pressure (not to exceed 15 PSI: reservoir proof pressure); remove reservoir. A strap clamp is not recommended as clamp may damage reservoir.

- c. Remove door manifold assembly (Index 35, figure 5-27) and gear solenoid assembly from body assembly of power pack.

NOTE

Disassembly of pressure switch assembly and relieve valve assembly is normally not required. Refer to applicable paragraphs for specific instructions.

- d. Remove pressure switch and dipstick from body assembly.
- e. Remove large packing (3) from bottom of body assembly.
- f. Remove baffle (29), spacers (27), and washer (26).
- g. Remove union (14), packing (3), retainer ring (7), and screw (24) at bottom of reservoir (25).
- h. Remove motor and pump assembly (10) from body assembly.
- i. Remove packings and back-up rings from pump assembly (10); remove coupling (11).
- j. Remove return tubes (30) and packings from body assembly.
- k. Remove relief valve assembly from body assembly.

NOTE

Suction screen assembly (32) need not be removed from body assembly to be cleaned. However, if suction screen assembly is damaged, it should be removed as outlined in step "l." of this paragraph observing the following caution:

CAUTION

Use extreme caution in removing suction screen assembly. Damage to suction screen assembly or clearance between suction screen assembly and body assembly will cause slow landing gear retraction.

- l. Working through center hole in top of body assembly, and using a drift or punch made of soft material, tap out suction screen assembly (32).

- m. Remove fittings from body assembly, if still installed, union (14), packing (3), retainer ring (7), and fluid filter screen (8) from body assembly.
- n. Remove thermal relief valve and check self-relieving check valve from body assembly.

NOTE

To remove thermal relief valve when power pack is installed in aircraft, remove retainer (6). While holding your hand to catch valve, gently pump hand pump. Valve will be ejected out into your hand. Be careful not to pump hand pump too hard.

5-164. INSPECTION AND REPAIR OF POWER PACK COMPONENTS.

- a. Wash all parts in cleaning solvent (Federal Specification P-S-661, or equivalent) and dry with filtered air.
- b. Inspect seating surfaces. They should have very sharp edges. Seats may be lapped, if necessary, to obtain sharp edges.
- c. Inspect all threaded surfaces for serviceable condition and cleanliness.
- d. Inspect all parts for scratches, scores, chips, cracks and indications of excessive wear.

5-165. **REASSEMBLY OF POWER PACK.** (Refer to figure 5-26.)

NOTE

Lubricate threads, new packings and retaining rings with a film of Petroleum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7 during reassembly of power pack.

- a. Assemble and install thermal relief valve and self relieving check valve in body assembly.
- c. Install fluid filter screen (8), retainer ring (7), packing (3) and union (14) in top of body assembly (34).
- c. Install suction screen assembly (32), if removed.

CAUTION

Use extreme caution when installing suction screen assembly. Damage to screen assembly or clearance between screen assembly and body will cause slow landing gear retraction.


- d. Install relief valve assembly in body assembly.
- e. Install packings and return tubes (30) in body assembly.
- f. Install packings and back-up rings on pump assembly (10); install coupling (11).
- g. Install pump assembly (10) and motor on body assembly.
- h. Install screen (24), retainer ring (7), packing (3), and union (14) on bottom of reservoir (25).
- i. Install washer (26), spacers (27), and baffle (29).
- j. Install large packing (3) on bottom of body assembly.

MODEL 210 & T210 SERIES SERVICE MANUAL

SHIM (39) APPLICABILITY

SHIM PART NO.	THICKNESS	MATERIAL	EFFECT IN PRESSURE (PSI)
9880705-1	.005	BRASS	60
9880705-2	.010	BRASS	120
9880705-3	.016	BRASS	200

1. Self-Relieving Check Valve
2. Thermal Relief Valve
3. Packing
4. Filter Assembly - Self Relieving Check Valve
5. Back-Up Ring
6. Retainer
7. Retainer Ring
8. Fluid Filter Screen
9. Dipstick
10. Pump Assembly
11. Coupling
12. Spring
13. Piston
14. Union
15. Adapter
16. Orifice
17. Poppet
18. Ball
19. Spring Guide
20. Housing
21. Nut
22. Reservoir Washer
23. Nut
24. Screen
25. Reservoir
26. Washer
27. Spacer
28. Nameplate
29. Baffle
30. Return Tube
31. Stud
32. Suction Screen Assembly
33. Plug
34. Body Assembly
35. Adjustment Screw
36. Cap and Housing Assembly
37. Pin
38. Spring
39. Shim
40. Stop
41. Guide
42. Packing
43. Piston (Needle Roller)
44. Packing
45. Fitting
46. Snubber
47. Tee



NOTE

Before assembly, lubricate all packing with Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

Figure 5-26. Power Pack Disassembly and Reassembly

MODEL 210 & T210 SERIES SERVICE MANUAL

k. Install dipstick (9), pressure switch, door manifold assembly (Index 35, figure 5-27), and gear manifold assembly on body assembly.

l. Attach reservoir (25) to body assembly with packing (3), reservoir washer (22), and nut (23).

5-166. INSTALLATION OF POWER PACK. (Refer to figure 5-25.)

a. Work power pack into position and install three bolts that secure power pack to pedestal.

b. Connect all hydraulic lines to power pack fittings. Ensure that all fittings are properly installed, with jamnuts tight, after lines are tightened.

c. Install wheel and gear box assembly and indicator assembly in top of pedestal.

d. Install left-hand and right-hand chain guards for rudder trim chain.

e. Connect chain at connecting link after stringing chain over idler sprocket.

f. Tighten idler sprocket by sliding sprocket outboard in slot and tightening bolt.

g. Connect ground wire to pressure switch and wire to motor.

h. Connected power pack wiring to plug.

i. Install upper panel on pedestal.

j. Fill reservoir on right-hand side of power pack with clean hydraulic fluid in accordance with procedures outlined in Section 2 of this manual.

k. Jack aircraft as outlined in Section 2 of this manual.

l. Operate gear thru several cycles to bleed system. Check for correct operation and signs of fluid leakage. A 28V power supply should be used to augment the ship's battery.

5-167. PRESSURE SWITCH. (Refer to figure 5-26.)

5-168. DESCRIPTION. When installed in the aircraft, the pressure switch is mounted on the right-hand (aft) side of the power pack in the console. This switch senses pressure in the DOOR-CLOSE line. After gear extension or retraction (after the doors close), pressure builds in the DOOR-CLOSE line. At approximately 1500 PSI, the pressure switch opens, turning off the power pack. The pressure switch will continue to hold the electrical circuit open until pressure in the system drops to a preset value, at which time, the pump will again operate to build up pressure to approximately 1500 PSI.

NOTE

The hydraulic power pack relief valve, thermal relief valve, and pressure switch can each be operationally checked on the aircraft without disassembly. Refer to paragraph 5-161A for specific instructions.

5-169. DISASSEMBLY OF PRESSURE SWITCH. (Refer to figure 5-26.)

a. Remove pin (37).

b. Unscrew cap and housing assembly (36) from fitting (45).

c. Remove spring (38).

d. Remove shims (39) from flange of guide (41).

NOTE

The chart in figure 5-26 lists shims (39) by part number, thickness and effect on operating pressure (psi).

e. Unscrew guide (41) from fitting (45).

CAUTION

Do not damage lip of guide (41). Guide threads and threads of fitting (45) are primed with Loctite Grade T primer and sealed with Loctite Grade AV sealer.

f. Remove piston (43).

g. Remove packings (42) and (44).

h. Remove snubber (46) from fitting (45).

CAUTION

Threads of snubber (46) and fitting (45) are primed with Loctite Grade T primer and sealed with Loctite Grade AV sealer.

5-170. CLEANING, INSPECTION AND REPAIR OF PRESSURE SWITCH. (Refer to figure 5-26.)

a. Clean sealant from threads of snubber (46), fitting (45) and guide (41) with wire brush.

b. Clean all parts with cleaning solvent (Federal Specification P-S-661, or equivalent) and dry thoroughly.

c. Discard all removed packings (42) and (44) and replace with new packings.

d. Inspect all pressure switch parts for scratches, scores, chips, cracks and indications of wear.

e. All damaged parts shall be replaced with new parts.

NOTE

Thorough cleaning is important. Dirt and chips are the greatest single cause of malfunctions in hydraulic systems. Carefulness and proper handling of parts to prevent damage must be observed at all times.

f. Snubber (46) can be cleaned with solvent, then blown out with high pressure compressed air.

g. Assure that .062-inch vent hole is open in stop (40).

5-171. ASSEMBLY OF PRESSURE SWITCH. (Refer to figure 5-26.)

a. Prime threads of snubber (46) and internal threads of fitting (45) with Loctite Grade T primer and apply Loctite Grade AV sealer to threads of snubber (46). Install snubber into fitting with a slotted screwdriver.

NOTE

When reassembling pressure switch, install new packing and internal parts, except as noted, lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

b. Install packing (42) in fitting (45).

MODEL 210 & T210 SERIES SERVICE MANUAL

- c. Lubricate packing (44) and guide (41) and install packing on guide.
- d. Prime threads of guide (41) and internal threads of fitting (45) with Loctite Grade T primer and apply Loctite Grade AV sealer to threads of guide (41). Install guide into fitting and finger tighten.
- e. Install test gage in power pack body fitting.
- f. Assure that sealant in fitting (45) is dry; screw fitting assembly in console.
- g. Pump emergency hand pump just enough for fluid to seep from top of guide (41).
- h. Lubricate piston (43) and insert piston into hole in guide (41).
- i. Lubricate stop (40) and install over guide (41).
- j. Install exact number and thickness of shims (39) as were removed.

NOTE

If same number of shims (39) are installed as were removed, pressure should not require adjustment. If readjustment is necessary, a chart of shim part numbers, thickness and effect in pressure adjustment is illustrated in figure 5-26.

- k. Lubricate spring (38) and install over shims (39)
- l. Screw cap and housing assembly (36) on fitting (45).

NOTE

Do not install pin (37) until pressure adjustment has been checked.

5-172. ADJUSTMENT OF PRESSURE SWITCH. (Refer to figure 5-26.)

- a. Jack aircraft in accordance with procedures outlined in Section 2 of this manual.
- b. Screw cap and housing assembly (36) on fitting (45) enough to bottom piston (43) out in stop (40).
- c. Turn cap and housing assembly (36) back from full thread engagement one turn, plus 0, minus one-fourth turn, to locate hole in fitting (45) in slot in skirt of cap and housing assembly.
- d. Attach electrical connections to pressure switch, and attach external power source.
- e. Turn on master switch.
- f. Pump hand pump to obtain 1500 PSI on test gage.
- g. The switch should open the electrical circuit to the pump solenoid when pressure in the system increases to approximately 1500 PSI.
- h. If switch opens electrical circuit to solenoid prematurely, disassemble pressure switch down to shims (39) and add shims as necessary to obtain desired pressure; repeat steps "b" and "c".

NOTE

The chart in figure 5-26 lists shims by part number, thickness and the effect in psi each shim will have on switch operation.

- i. If switch opens electrical circuit to solenoid at higher than 1500 ± 50 PSI, disassemble pressure switch down to shims (39), and remove shims as necessary to obtain desired pressure; repeat steps "b." and "c."
- j. Turn off master switch.
- k. Drive new pin (37) through slot in housing skirt and hole in fitting (45).
- l. Remove aircraft from jacks.

5-172. RELIEF VALVE AND THERMAL RELIEF VALVE ASSEMBLIES. (Refer to figure 5-26.) The relief valve assembly (5) serves to limit that amount of pressure which can be generated by the pump assembly (10). The thermal relief valve (2), located on the system side of the self-relieving check valve (1), serves to limit the system pressure. System pressure can increase due to thermal expansion.

5A-172A. BENCH CHECK OF RELIEF VALVE AND THERMAL RELIEF VALVE. (Refer to figure 5-26.)

NOTE

The hydraulic power pack relief valve, thermal relief valve, and pressure switch can be operationally checked on the aircraft without power pack removal from the aircraft or disassembly. Refer to paragraph 5-161A for specific instructions.

If on-aircraft pressure checking of the power pack reveals out-of-tolerance relief valve opening, it may be necessary to determine if relief valve disassembly or adjustment is necessary. Once removed from power pack, individual relief valves can be bench checked.

NOTE

Adequate precautions should be taken to recover hydraulic fluid which will be expelled from the primary relief valve while under pressure.

a. Relief Valve.

- (1) Using a hydraulic pump with a flow rate of 0.5 to 0.7 gallons per minute connected to a hydraulic reservoir, a pressure gage with 2500 PSI capacity, and a hose with appropriate fittings, connect hydraulic pump to adapter (15) of the relief valve.
- (2) Apply pressure slowly to ensure that relief valve assembly opens at correct pressure reading. Relief valve should open at 1800 PSI, + 0 or -50 PSI. Refer to paragraph 5-172D for adjustment instructions.

b. Thermal Relief Valve.

- (1) Using a hand pump connected to a hydraulic reservoir, a pressure gage with 2500 PSI capacity, and a hose with appropriate fittings, connect hand pump to adapter (2) of the thermal relief valve.
- (2) Manually pump pressure up slowly to ensure that relief valve assembly opens at correct pressure reading. Thermal relief valve is preset at factory to open at 2050, ± 100 PSI. No further adjustment should be necessary.

MODEL 210 & T210 SERIES SERVICE MANUAL

5-172B. DISASSEMBLY. (Refer to figure 5-26.)

NOTE

The relief valve assembly is preset by the factory and normally will not require disassembly. Refer to steps "h" and "i" of paragraph 5-172D to determine if disassembly or adjustment is necessary.

- a. Remove nut (21) and adjustment screw (35) from housing (20).
- b. Remove spring (12), spring guide (19), balls (18), and piston (13) from housing (20).
- c. Loosen nut (21) and remove adapter (15) from housing (20).
- d. Remove poppet (17) and orifice (16) from adapter (15).

5-172C. INSPECTION.

- a. Wash all parts in cleaning solvent (Federal Specification P-S-661 or equivalent) and dry with filtered air.
- b. Inspect all threaded surfaces for serviceable condition and cleanliness.
- c. Inspect all parts for scratches, scores, chips, cracks, and indications of excessive wear.

5-172D. ASSEMBLY AND ADJUSTMENT. (Refer to figure 5-26.)

NOTE

When reassembling relief valve, install new packing and internal parts lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

- a. Install orifice (16) and poppet (17) into adapter (15). (New packing must be installed on poppet.)
- b. Install nut (21) and housing (20) on adapter (15).
- c. Tighten adapter (15) into housing (20) and torque to 100-150 lb-in (nut [21] must not contact housing [20] during torquing).
- d. Tighten nut (21) against housing (20), and torque to 100-150 lb-in.
- e. Install one ball (18) into housing (20) so that it rests on poppet (17). Install piston (13) into housing (20); then install remaining ball (18) into end of piston (13).
- f. Insert spring guide (19) and spring (12) into housing (20) making sure that balls (18) and piston (13) remain in correct position.
- g. Turn adjustment screw (35) into housing (20) until it just contacts spring (12); then turn in one additional turn. Start nut (21) onto adjustment screw (35) and snug against housing (20).
- h. Connect a hydraulic pump with a flow rate of 0.5 to 0.7 gallons-per-minute, and a pressure gage with 2500 PSI capacity to relief valve. Apply pressure slowly to insure that relief valve assembly opens and resets at the following pressure readings:
OPEN 1800 + 00 - 50 PSI
RESET 1300 PSI
(Leakage not to exceed 10 drops-per-minute.)

- i. If adjustment of relief valve is necessary, turn adjustment screw (35) in to increase pressure; back adjustment screw out to decrease pressure. Tighten nut (21) against housing (20) and torque to 100-150 lb-in. Recheck pressure adjustment.

5-173. DOOR SYSTEM THERMAL RELIEF VALVE. (Refer to figure 5-26.) The relief valve is located in the power pack assembly. The valve is preset at the factory to open at 2050, ± 100 PSI. No further adjustment should be necessary.

5-174. LANDING GEAR AND DOOR MANIFOLD ASSEMBLIES. (Refer to figure 5-27.)

5-175. DESCRIPTION. The manifolds are mounted on the power pack in the console. Refer to the schematic diagrams at the end of this Section for system operation.

5-176. SOLENOIDS. The solenoids are mounted on the top of the gear and door manifolds, and should be disassembled, cleaned and reassembled every 1000 hours or 5 years, and whenever the solenoid is accessible.

5-177. DISASSEMBLY OF SOLENOID. (Refer to figure 5-27.)

- a. Cut safety wire and remove solenoid from manifold.
- b. Remove screws.
- c. Remove top.
- d. Remove plunger.
- e. Remove gland.
- f. Remove and discard packing.

5-178. INSPECTION AND CLEANING OF SOLENOID COMPONENTS. Wash all parts in solvent (Federal Specification P-S-661, or equivalent) and dry with filtered air. If any parts are found defective or worn, replace the entire solenoid assembly. (Replace packing.)

5-179. ASSEMBLY OF SOLENOID. (Refer to figure 5-27.)

- a. Install new packing
- b. Install plunger.
- c. Install top
- d. Install screws.
- e. Install gland.

5-180. LANDING GEAR MANIFOLD. (Thru Serial 21062273.)

5-181. DISASSEMBLY. (Refer to figure 5-27.)

NOTE

As gear manifold assembly is removed from body of power pack, transfer tube (13) will fall free. Also, be careful of spool (3), which is installed in top of selector valve (4).

MODEL 210 & T210 SERIES SERVICE MANUAL

- a. Remove packing (12) from bottom of manifold.
- b. Remove packings (11) and (14) from transfer tube (13).
- c. Remove retainer (18) from gear manifold assembly. Remove packings (19) from retainer.

NOTE

Retainer (18) is sealed in manifold assembly with Loctite Hydraulic Sealant or STA-LOK No. 550, or equivalent sealant.

- d. Remove AN316-4R nut (8) and screw (6).
- e. Using a blunt tool or welding rod, push flow valve spool (17) flow valve sleeve (24), spring (15) and spring guide (26) through bottom of manifold assembly.

NOTE

Use care to prevent damage to spring guide (26), flow valve spool (17) or flow valve sleeve (24).

- f. Remove flow valve spool (17) from flow valve sleeve (24).
- g. Remove packings (19) and (2) and back-up rings (20) and (22) from flow valve sleeve (24).
- h. Remove packing (16) from flow valve spool (17).

- i. Remove spring guide (26) from spring (15), and remove packing (25) and back-up ring (23) from spring guide (26).

j. Cut safety wire and remove gear up-down solenoid (1) from manifold. Remove packing (2) from gear up-down solenoid (1).

k. Using a hook formed from brass welding rod, and inserted into oil hole in selector valve (4), withdraw selector valve from manifold.

CAUTION

Be sure that end of hook is not over 1/16-inch long. Use care to prevent scratching bore in manifold. Removal of selector valve will be difficult due to friction caused by packings.

- l. Remove packings (5) from selector valve.
- m. Remove spring (7).

5-181A. INSPECTION AND REPAIR.

a. Wash all parts in cleaning solvent (Federal Specification P-S-661, or equivalent) and dry with filtered air.

b. Inspect seating surfaces. They should have very sharp edges. Seats may be lapped, if necessary, with No. 1200 lapping compound.

c. Inspect all threaded surfaces for serviceable condition and cleanliness. Clean sealant from retainer threads.

MODEL 210 & T210 SERIES SERVICE MANUAL

- d. Inspect all parts for scratches, scores, chips, cracks and indications of excessive wear.

5-181B. REASSEMBLY.

NOTE

When reassembling door manifold, install new packings, back-up rings, and existing threaded parts lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

- a. Lubricate packings on selector valve (4).
- b. Install packing in bottom of manifold.
- c. Install spring (7) and selector valve (4) in manifold.

NOTE

Be sure spool (3) is installed in selector valve (4) in position shown in Figure 5-27.

- d. Install packing (2) on solenoid (1). Install solenoid on manifold and safety wire as shown in view A A.
- e. Install screw (6) and AN316-4R nut (8) in top of manifold.
- f. Install packing (25) and back-up ring (23) on spring guide (26).
- g. Install spring guide (26).
- h. Install spring (15).
- i. Install packings (19 and 21) and back-up rings (20 and 22) on flow valve sleeve (24).
- j. Install spool (17) in sleeve (24); install assembly in bottom of manifold.
- k. Install packing (19) on retainer (18).
- l. Prime threads of retainer (18) with Grade T Primer and seal with Loctite Hydraulic Sealant or STA-LOK No. 550, or equivalent sealer.
- m. Install retainer (18).
- n. Install packings on transfer tube (13).
- o. Prior to installing manifold on body of power pack, install transfer tube (13) in body of pack.
- p. Refer to paragraph 5-184 for adjustment procedures.

5-182. LANDING GEAR MANIFOLD. (Beginning with Serial 21062274.)

5-183. DISASSEMBLY. (Refer to figure 5-28.)

NOTE

As gear manifold assembly is removed from body of power pack, transfer tube (18) will fall free.

- a. Remove packing from bottom of manifold.
- b. Remove packings from transfer tube.
- c. Remove retainer (10) from gear manifold assembly.

NOTE

Retainer (10) is sealed in manifold assembly with Loctite Hydraulic Sealant or STA-LOK No. 550, or equivalent sealant.

- d. Remove AN316-4R nut (8) and screw (6).
- e. Using a blunt tool or welding rod, push flow valve sleeve (4) and flow valve spool (11), spring (13) and spring guide (16) through bottom of manifold body (3).

NOTE

Use care to prevent damage to spring guide (16), flow valve spool (11) or flow valve sleeve (4).

- f. Remove flow valve spool (11) from sleeve (4).
- g. Remove packings and back-up rings from sleeve (4).
- h. Remove packing from spool (11).
- i. Remove packing and back-up ring from spring guide (16).

5-183A. INSPECTION AND REPAIR.

- a. Wash all parts in cleaning solvent (Federal Specification P-S-661, or equivalent) and dry with filtered air.
- b. Inspect seating surfaces. They should have very sharp edges. Seats may be lapped, if necessary, with No. 1200 lapping compound.
- c. Inspect all threaded surfaces for serviceable condition and cleanliness. Clean sealant from retainer threads.
- d. Inspect all parts for scratches, scores, chips, cracks and indications of excessive wear.

5-183B. REASSEMBLY.

- a. Install screw (6) and AN316-4R nut (8) in top of manifold.
- b. Install packing (15) and back-up ring (14) on spring guide (16).
- c. Install spring guide (16).
- d. Install spring (13).
- e. Install packings (1) and (2), and back-up rings (5 and 7) on flow valve sleeve (4).
- f. Install packing (12) on spool (11).
- g. Install spool (11) in sleeve (4): install assembly in bottom of manifold.
- h. Install packing (9) on retainer (10).
- i. Prime threads of retainer (10) with Grade T Primer and seal with Loctite Hydraulic Sealant or STA-LOK No. 550, or equivalent sealer.
- j. Install retainer (10).
- k. Install packings (19) on transfer tube (18).
- l. Prior to installing manifold on body of power pack, install transfer tube (18) in body of pack.
- m. Refer to paragraph 5-184 for adjustment procedures.

MODEL 210 & T210 SERIES SERVICE MANUAL

Safety wire solenoids (1) and (27) after installing on gear and door manifold assemblies.

Prime threads of retainer (18) with Grade T Primer and seal with Loctite Hydraulic Sealant or STA-LOK No. 550, or equivalent sealant.

1. Gear Up-Down Solenoid
2. Packing
3. Spool
4. Selector Valve
5. Packing
6. Screw
7. Spring
8. AN 316-4R Nut
9. Gear Solenoid Assembly
10. Plug
11. Packing
12. Packing
13. Transfer Tube
14. Packing
15. Spring
16. Packing
17. Flow Valve Spool
18. Retainer
19. Packing
20. Back-Up Ring
21. Packing
22. Back-Up Ring
23. Back-Up Ring
24. Flow Valve Sleeve
25. Packing
26. Spring Guide
27. Door Open-Close Solenoid
28. Retainer Ring
29. End Gland
30. Packing
31. Back-Up Ring
32. Packing
33. Back-Up Ring
34. Piston
35. Door Manifold Assembly
36. Plug
37. Packing
38. Door Lock Valve
39. Packing
40. Packing
41. Packing
42. Transfer Tube
43. Plug
44. Spring
45. Packing
46. Selector Valve
47. Spool
48. Packing
49. Screw
50. Top
51. Plunger
52. Housing
53. Packing
54. Gland





Figure 5-27. Gear Assembly Manifold and Door Manifold Assemblies

MODEL 210 & T210 SERIES SERVICE MANUAL



1. Packing
2. Packing
3. Body
4. Flow Valve Sleeve
5. Back-Up Ring
6. Adjustment Screw
7. Back-Up Ring
8. AN 316 -4R Nut
9. Packing
10. Retainer
11. Flow Valve Spool
12. Packing
13. Spring
14. Back-Up Ring
15. Packing
16. Spring Guide
17. Packing
18. Transfer Tube
19. Packing
20. Packing

GEAR MANIFOLD ASSEMBLY
(Beginning with serial 21062274)

Figure 5-28. Gear Manifold Assembly

MODEL 210 & T210 SERIES SERVICE MANUAL

5-184. ADJUSTMENT OF GEAR MANIFOLD ASSEMBLY (Refer to figure 5-27 or 5-28.)

NOTE

With manifolds installed on power pack and power pack installed on aircraft, if main landing gear moves into the up or down locks with sufficient force to jar the aircraft, the flow control valve in the landing gear manifold should be adjusted in accordance with the following procedures.

- a. Jack aircraft in accordance with procedures outlined in Section 2 of this manual, and attach external power source.
- b. Loosen AN 316-4R nut (8).
- c. Back off screw (6) counterclockwise to maximum snub position.
- d. Rotate screw (6) clockwise to increase speed of gear rotation and counterclockwise to slow speed of gear rotation.
- e. When desired setting has been achieved, tighten AN 316-4R nut (8).

5-185. DOOR MANIFOLD ASSEMBLY. (Refer to figure 5-27.)

5-186. DISASSEMBLY OF DOOR MANIFOLD. (Refer to figure 5-27.)

NOTE

As door manifold assembly is removed from body of power pack, transfer tube (42) will fall free.

- a. Remove packings (41) from transfer tube (42).
- b. Remove packings from bottom of manifold, and remove door lock valve (38).
- c. Remove spring (44).
- d. Cut safety wire and remove solenoid (27); remove packing (48) from solenoid.
- e. Using a hook, formed from brass welding rod, and inserted into oil hole in selector valve (46), withdraw selector valve from manifold.

CAUTION

Be sure that end of hook is not over 1/16-inch long. Use with care to prevent scratching bore in manifold. Removal of selector valve will be difficult due to friction caused by packings.

- f. Remove packings (45) from selector valve (46).
- g. Remove spool (47) from selector valve.
- h. Remove retainer ring (28).
- i. Remove end gland (29).
- j. Remove piston (34).
- k. Remove packings and back-up rings from end

gland and piston.

5-187. CLEANING AND INSPECTION OF DOOR MANIFOLD COMPONENTS.

- a. Wash all parts in cleaning solvent (Federal Specification P-S-661, or equivalent) and dry with filtered air.
- b. Inspect seating surfaces. They should have very sharp edges. Seats may be lapped, if necessary, to obtain sharp edges.
- c. Inspect all threaded surfaces for serviceable condition and cleanliness.
- d. Inspect all parts for scratches, scores, chips, cracks and indication of excessive wear.

5-188. REASSEMBLY OF DOOR MANIFOLD. (Refer to figure 5-27)

NOTE

When reassembling door manifold, install new packings, back-up rings, and existing threaded parts lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

- a. Install new packings on end gland (29), piston (34), selector valve (46) and transfer tube (42).
- b. Install packings and door lock valve in bottom of manifold.
- c. Install spring (44) and selector valve (46) in manifold.

NOTE

Be sure spool (47) is installed in selector valve (46) in position shown in figure 5-28.)

- d. Install packing (48) on solenoid (27).
- e. Install solenoid on manifold and safety wire as shown in view A-A.
- f. Install piston (34) and end gland (29) in manifold.
- g. Install retainer ring (28).
- h. Prior to installing manifold on body of power pack, install transfer tube (42) in body of power pack.

5-189. LANDING GEAR HAND PUMP. (Refer to figure 5-29.)

5-190. DESCRIPTION. The hand pump is located in the cabin floor area between the pilot and copilot seats. The pump supplies a flow of pressurized hydraulic fluid to open the doors and extend the landing gear if hydraulic pressure should fail.

5-191. REMOVAL OF LANDING GEAR HAND PUMP. (Refer to figure 5-29.)

5-192. DISASSEMBLY OF LANDING GEAR HAND PUMP. (Refer to figure 5-29.)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-29. Landing Gear Hand Pump

5-193. INSPECTION OF LANDING GEAR HAND PUMP COMPONENTS. (Refer to figure 5-29.)

5-194. REASSEMBLY OF LANDING GEAR

HAND PUMP. (Refer to figure 5-29.)

5-194A. INSTALLATION OF LANDING GEAR HAND PUMP. (Refer to figure 5-29.)

MODEL 210 & T210 SERIES SERVICE MANUAL

5-195. LANDING GEAR POSITION SELECTOR VALVE. (Refer to figure 5-30.) A mechanical gear position selector valve is located in the switch panel. The pilot shuttles the valve mechanically when he changes gear handle position. The handle must be pulled out prior to selecting gear position. Moving the selector handle opens and closes ports in the valve, enabling fluid under pressure to flow to the various system components to retract or extend the landing gear. A microswitch, mounted on the selector valve, is also actuated by movement of the selector handle and directs electrical current to the door close solenoid and pump motor. Refer to the hydraulic system schematics at the end of this section for switch circuitry.

5-195A. REMOVAL AND INSTALLATION. (Refer to figure 5-30.)

- a. Loosen jamnut (18) and remove knob (19).

CAUTION

As hydraulic lines are disconnected, fluid will leak. Precautions must be taken to prevent excessive leakage, such as spreading drip cloths under fittings and capping lines and fittings. Tag all electrical leads to insure correct re-installation.

- b. Disconnect four hydraulic lines routed to valve and all electrical leads to micro-switch.
- c. Remove screws attaching valve to instrument panel.

- d. Remove selector valve.
- e. Reverse preceding steps to install gear selector valve.

5-195B. DISASSEMBLY AND REASSEMBLY. (Refer to figure 5-30.)

- a. Remove cover (1), lock ring (3) and cap (4). Thru 21063811, remove race (5) and bearing (6). Beginning with 21063812, remove washer (20).
- b. Remove cotter pin (7), washer (8) and spring (9).
- c. Pull rod (17) from disc (15); remove disc.
- d. Remove pucks (11) and springs (12).
- e. Reverse preceding steps for reassembly.

5-195C. INSPECTION OF PARTS. Replace packings (10) and (16). Check valve for wear, foreign or abrasive materials. Disc (15) may be refaced (lapped) if worn or abraded. Check rollers in bearings (6).

5-196. INSTALLATION OF LANDING GEAR STRUT STEP. (Refer to figure 5-31.)


NOTE

Step is bonded to gear spring with Uralite 3121 or 3M EC-2216 adhesive.

- a. Remove wheel, axle and fitting in accordance with paragraph 5-52.
- b. Mark position on inboard side of step that was removed so that new step assembly will be installed in as nearly the same position on the strut.
- c. Remove all traces of the original bracket and adhesive as well as any rust, paint or scale, with a

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL



1. Cover
2. Motor/Door Solenoid Switch
3. Lock Ring
4. Cap
5. Race
6. Bearing
7. Cotter Pin
8. Washer
9. Spring
10. Packing
11. Puck
12. Spring
13. Packing
14. Body
15. Disc
16. Packing
17. Rod
18. Jamnut
19. Knob
20. Washer

NOTE

Beginning with 21063812, steel disc (15) is replaced by aluminum disc (15). Bearing (6) and race (5) are replaced by teflon washer (20) at the same aircraft serial.

Figure 5-30. Landing Gear Selector Valve

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-31. Landing Gear Strut Step Installation

wire brush and coarse sandpaper.

d. Leave surfaces of strut slightly roughened or abraded, but deep scratches or nicks should be avoided. Also, roughen bonding surface of the new step.

e. Clean surfaces to be bonded together thoroughly. If a solvent is used, remove all traces of the solvent with a clean, dry cloth. It is important that the bonding surfaces be clean and thoroughly dry.

f. Apply non-zinc chromate primer to cleaned area on strut. Dry film thickness is to be .0003 to .0005-inch.

g. Mix adhesive (Uralite 3121 or 3M EC-2216 per manufacturer's instructions. Note pot life.

h. Spread a coat of mixed adhesive on bonding surfaces of strut and step assembly.

i. Slide new step up strut as far as it will go, then use soft mallet to drive step to mark on strut. Be sure step is level.

CAUTION

It is important to install step in as nearly the same location as old step. If step is not installed high enough on strut, during landing gear retraction, step will contact top of strut well wall.

j. Remove excess adhesive with lacquer thinner.

k. Allow adhesive to thoroughly cure according to the manufacturer's recommendations before flexing gear spring strut or apply loads to the step.

l. Paint gear spring and step after curing is completed.

m. Install wheel, axle and fitting.

5-197. RIGGING THROTTLE-OPERATED MICROSWITCHES. (Refer to figure 5-32.)

Rigging procedures for sea level or turbocharged aircraft are outlined in the figure.

5-198. RIGGING OF MAIN LANDING GEAR. (Refer to figure 5-34.)

NOTE

All of the following rigging adjustments shall be accomplished with the aircraft on jacks and in a level condition, using the ship's power-pack to supply pressure. A ground power source should augment the ship's battery.

a. With main gear unlocked and main landing gear support forging assembled loose to the outboard support assembly, bring main landing gear strut into "DOWN" position and adjust as follows:

1. Center and shim simultaneously main landing gear support, using shims (P/N 1241629) between outboard forging and landing gear support assembly. The following shims are available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations.

1241629-1	0.016 inch
1241629-2	0.025 inch
1241629-3	0.050 inch
1241629-4	0.071 inch

2. Use shims between downlock support assembly and outboard support assembly, to level wings and assure that end points of main landing gear wheel axle points are within ± 0.25 inch.

NOTE

This measurement may be made from a point beneath the wing main spar on the upper door sill to the top bolt attaching ankle bone to the spring strut. Make measurements from corresponding points on the upper door sills. Shim thickness between downlock support and outboard support assembly shall not exceed 0.075 inch with a minimum thickness of 0.025 inch for either main gear.

3. Before installing downlock hook (4), adjustment screw (5), and arm assembly (7), adjust hook

MODEL 210 & T210 SERIES SERVICE MANUAL

SETTING THROTTLE SWITCHES

1. During flight at 120 MPH (IAS), 2500', prop control full forward for maximum RPM, and with the gear and flaps up, mark the throttle control position corresponding to the following manifold pressures:


Model 210M _____ 12.0" \pm .5"

Model T210M _____ 15.0" \pm 1.0"

2. Then adjust the gear warning horn throttle switch on the ground to activate at the throttle control position as marked in flight.

"For each 1000 feet above 2500' MSL, decrease the manifold pressure at which the throttle control position is marked by 0.5 inches."

REFER TO
SECTION 2
FOR CONTROL
LUBRICATION



VIEW LOOKING AFT AND
OUTBOARD AT RIGHT-
HAND SIDE OF FIREWALL

- | | |
|------------------|----------------------------|
| 1. Switch Cover | 6. Switch Mounting Bracket |
| 2. Switch Cover | 7. Arm Assembly |
| 3. Spacer | 8. Gear Warning Cam |
| 4. Switch | 9. Fuel Pump Cam |
| 5. Switch Spacer | 10. Bushing |

Figure 5-32. Rigging Throttle-Operated Microswitch

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

If it is planned to use the aircraft power system during rigging procedures, outlined in the following paragraphs, the following steps should be considered.

IMPORTANT POINTS CONCERNING ELECTRO-HYDRAULIC SYSTEM INTERRELATIONSHIP

1. The electrical system is a 24-28 volt system (24 volt battery and 28 volt alternator). The alternator is regulated to 27.7 volts, so bus voltage during engine operation will be 27.5 ± 0.5 volts.
2. The electro-hydraulic power pack motor requires a nominal 20 amps at 27.5 volts during gear operation with starting current peaking out at 30 amps.

If the motor is operated in the shop on the ship's battery (engine not running), then system voltage is only 22 to 24 volts during first and second gear cycles. It may be even less if the ship's battery is old or partially discharged.


During landing gear system servicing, a power supply capable of maintaining 27.5 volts throughout the gear cycle must be used to augment the ship's battery.

3. The power pack includes an electrically-driven pump and two electric solenoid shuttle valves. These valves are normally energized during flight (gear retracted, doors closed). The door valve is de-energized during the doors open and gear cycling action. The door valve is re-energized at the end of the gear-extension or retraction cycle, causing the doors to close.

The pump motor is putting forth its maximum effort at about the same time the door valve is energized. If the battery-alternator combination is not maintaining 27.5 volts, the gear valve may not shuttle. The doors remain open and the pump continues to run.

The typical door solenoid will operate at 21.0 to 21.5 volts when hot. In a service shop, when cycling the gear using a limited capability power source, the voltage required to energize the door solenoid may not be developed.

MODEL 210 & T210 SERIES SERVICE MANUAL



Thru 21062273









LINE CODE	
	DOOR OPEN LINE
	VENT TUBE
	GEAR UP LINE
	HAND PUMP SUCTION LINE
	GEAR DOWN LINE
	HAND PUMP PRESSURE
	DOOR CLOSE LINE
	FLOW DIRECTION

Figure 5-33. Hydraulic Power Pack Line Routing

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-33A Hydraulic Power Pack Line Routing

MODEL 210 & T210 SERIES SERVICE MANUAL

setscrew (15) to stop hook 0.06, +0.03, -0.20-inch overcenter, as shown in figure 5-34.

4. Adjust downlock hook to clear inboard side of gear pivot ear to a minimum of 0.06 inch.

NOTE

A spacer (P/N 1241614-1) is installed on each side of the downlock arm assembly. Spacer may be relocated to the inboard or outboard side of the downlock arm assembly to obtain the 0.06 inch clearance between hook assembly and the inboard of gear pivot ear. After adjustment, both spacers MIGHT end up on either the inboard or outside of downlock arm assembly.

b. A new downlock actuator assembly is received with a preassembled length of 12.45 inches, and the three hydraulic ports in the same plane. Install actuator assembly, attaching it to fuselage structure and downlock hook arm assembly.

c. With landing gear free, hydraulic pressure off, and downlock system in position shown in figure 5-34, swing gear into DOWN position and adjust adjustment screw (5) as follows:

NOTE

To relieve hydraulic pressure, pull hydraulic pump circuit breaker off, and move gear selector switch up and down two or three times.

1. If downlock locks, turn adjustment screw (5) one-quarter turn OUT at a time until lock will not lock; then turn in one-quarter turn and secure pin.

2. If downlock does not lock, turn adjustment screw (5) one-quarter turn IN at a time until lock will lock, and secure pin.

d. Readjust hook setscrew (15) to stop hook (4) 0.06, +0.03, -0.02-inch overcenter as shown in figure 5-34.

e. When checking overcenter measurement of downlock arm assembly, landing gear should be as shown in figure 5-34, with nut, washer and spacer removed, which retain downlock arm assembly. Use downlock overcenter gages (P/N SE960) to determine if downlock hook assembly is still within tolerance as shown on sheet 2 of figure 5-34. Use gages as follows:

NOTE

Gages (P/N SE960) are available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations.

1. Remove nut, washer, and spacer which retain arm assembly (7) to support assembly (3).

2. Install 0.090 downlock gage (SE960) on inboard side of hook (4) as shown in figure 5-34. Upper portion of gage should rest against head of pin attaching

adjustment screw. If hook (4) is under maximum overcenter tolerance, green area of gage will contact spacer on gear pivot, while red area will not make contact with 0.050-inch diameter shoulder, as shown in figure 5-34. When hook (4) is on maximum overcenter tolerance, both green and red areas will make contact. If red area makes contact and green area does not, the hook setscrew (15) should be adjusted INWARD to bring overcenter dimension to within tolerance.

3. Install 0.040-inch downlock gage (SE960) on inboard side of hook (4) as shown in figure 5-34. If hook (4) is over minimum overcenter tolerance, green area of gage will contact shoulder, while red area will not make contact with spacer.

4. When hook (4) is on minimum overcenter tolerance, both green and red areas will make contact.

5. If overcenter tolerance is less than 0.040-inch, the red area will make contact, while the green area will not. If this condition exists, the next step is to determine if the hook adjustment screw (5) is making contact with the setscrew (15). This is accomplished by lifting the landing gear spring upward off the hook (4) and checking for possible rotation of the hook (4), by hand, with hydraulic pressure off.

6. If a slight rotation is possible, hook setscrew (15) is not contacting adjustment screw (5). If contact is not being made, downlock actuator (25) will have to be readjusted by backing off actuator's rod end one-half turn at a time (one-and-one-half turn maximum adjustment) until hook (4) is 0.040-inch or more overcenter and contact is being made between setscrew (15) and adjustment screw (4). If contact is being made, the hook setscrew (15) should be adjusted outward to increase overcenterness within tolerance.

NOTE

For correct rigging, hook setscrew (15) must make contact with adjustment screw (5) and green areas of both gages must contact as shown in figure 5-34 for overcenterness to be within tolerance.

f. Now that hook adjustment screw (5) has been adjusted, and hook setscrew (15) has been set to stop hook at 0.06, + 0.03, -0.02-inch overcenter, check downlock actuator rod end adjustment as follows:

1. Connect all hydraulic lines, fill system with MIL-H-5606 hydraulic fluid and purge system of air by cycling gear through several cycles.

NOTE


Check fluid level in power-pack reservoir frequently during purging and rigging procedures.

2. Pull hydraulic pump circuit breaker off.

3. With gear in the down and locked position, move the gear selector handle to the GEAR UP position.

MODEL 210 & T210 SERIES SERVICE MANUAL

RIGGING DOWNLOCK ASSEMBLIES LOOKING INBOARD AND AFT AT RIGHT-HAND DOWNLOCK ASSEMBLY FROM RH DOOR OPENING



1. Outboard Support
2. Spring Assembly
3. Support Assembly
4. Hook
5. Adjustment Screw
6. Downlock Actuator Rod
7. Arm Assembly
8. Pivot Assembly
9. Spacer
10. Shim
11. Landing Gear Strut
12. Spacer (NAS-43HT8-3)
13. Spacer (P/N 1241614)
14. Downlock Hook Over-center Gage (SE960)
15. Hook Setscrew
16. Shoulder
17. Spacer
18. Down Limit Switch
19. Uplock Support
20. Support
21. Push-Pull Rod
22. Lock Assembly
23. Up Limit Switch
24. Uplock Stud
25. Actuator

Figure 5-34. Rigging Main Landing Gear (Sheet 1 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 5-34. Rigging Main Landing Gear (Sheet 2 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL



WARNING

Before working in landing gear wheel wells, PULL-OFF hydraulic pump circuit breakers. Thru Serial 21062273, the pump circuit breaker is located in the circuit breaker panel, located immediately forward of the pilot's control wheel. Beginning with Serial 21062274, the pump circuit breaker is located in the circuit breaker panel, located immediately forward of the left forward doorpost. The hydro-electric power pack system is designed to pressurize the landing gear DOOR CLOSE system to 1500 psi at any time the master switch is turned on. Injury might occur to someone working in wheel well area if master switch is turned on for any reason.

Figure 5-34. Rigging Main Landing Gear (Sheet 3 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-34. Rigging Main Landing Gear (Sheet 4 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL

position and note the actuation of main gear downlock hooks.

4. As soon as left downlock hook is actuated to unlock left gear, move gear selector handle back to "GEAR DOWN" position to simulate what would occur if the pilot were to select gear down before the gear was fully retracted.

5. If downlock hooks do not lock the gear in the down position, check downlock system for misalignment.

g. With main gear in up-locked position, and system pressure released, adjust uplock supports such that ends of lock hooks are 0.92 inch inboard of lock hook attach bolt. (Refer to figure 5-34.)

h. Adjust uplock system push-pull rods such that when uplock latches are disengaged, both main gear struts are released simultaneously and uplock studs clear latches 0.15 inch minimum.

5-200. RIGGING OF NOSE LANDING GEAR.
(Refer to figure 5-35.)

NOTE

The nose gear downlock mechanism is basically a claw hook at the end of the piston rod end of the nose gear actuator.

a. Jack aircraft in accordance with procedures outlined in Section 2 of this manual.

NOTE

The nose gear shock strut must be correctly inflated prior to rigging the nose gear. Refer to Section 1 of this manual for correct nose shock strut inflation.

b. The external claw locks on the nose gear actuator shall completely engage lock pins without drag, and crossbar shall rotate freely to indicate it is not bearing on either side of slot in rod end. Adjust rod end of actuator as required.

CAUTION

The piston rod is flattened near the threads to provide a wrench pad. Do not grip the piston rod with pliers, as tool marks will cut the O-ring seal in the actuator.

5-201. RIGGING OF NOSE GEAR DOORS. Nose gear door adjustments are accomplished with push-pull rods as required to cause the doors to close snugly. Doors must fair when the nose gear is fully retracted. Link rods are to be adjusted so that the doors, when in the open position, clear any part of the nose gear assembly by a minimum of 0.25-inch during retraction. Trim outboard edge of nose gear doors so that door-to-skin clearance is 0.18-inch minimum to 0.21-inch maximum. Nose gear strut doors shall fair when nose gear lock bushing is fully engaged with uplock hook.

5-202. RIGGING OF NOSE GEAR LIMIT SWITCHES. (Refer to figure 5-35.) The nose gear down indicator switch is operated by an arm on the downlock mechanism. The nose gear up indicator switch is attached to the uplock hook in the top of the nose wheel well. After jacking the aircraft, adjust the switches as shown in figure 5-35.

5-203. RIGGING OF NOSE GEAR SQUAT SWITCH. The nose gear squat switch, electrically-connected to the landing gear lockout solenoid, is operated by an actuator, attached to the nose gear lower torque link. Adjust the squat switch contacts to close when the strut is between 0.12 and 0.25-inch from fully extended.

5-204. RIGGING RETRACTABLE STEP CABLE ASSEMBLY. (Refer to figure 5-36.)

WARNING

Before working in landing gear wheel wells, PULL-OFF hydraulic pump circuit breakers. Thru Serial 21062273, the pump circuit breaker is located in the circuit breaker panel, located immediately forward of the pilot's control wheel. Beginning with Serial 21062274, the pump circuit breaker is located in the circuit breaker panel, located immediately forward of the left forward doorpost. The hydro-electric power pack system is designed to pressurize the landing gear DOOR CLOSE system to 1500 psi at any time the master switch is turned on. Injury might occur to someone working in wheel well area if master switch is turned on for any reason.

- a. Rig nose gear in accordance with procedures outlined in paragraph 5-200.
- b. Rig nose gear doors in accordance with procedures outlined in paragraph 5-201.
- c. Rig nose gear limit switches and nose gear squat switch as outlined in paragraphs 5-202 and 5-203 respectively.
- d. While aircraft is still on jacks, extend landing gear and disconnect strut door tie rods. DO NOT DISTURB ROD ADJUSTMENT.
- e. Attach retractable step assembly cable turnbuckle to spring clip at hook assembly on forward end of nose gear actuator, if not previously attached.
- f. Retract landing gear to up and locked position.
- g. Adjust retractable step assembly cable turnbuckle to hold cabin step in its best faired condition; safety wire turnbuckle.
- h. Extend landing gear and attach tie rods to strut doors.

NOTE

Install right-hand tie rod on outboard side of eyebolt only, when connecting nose gear strut doors. Left-hand tie rod should be installed in normal manner.

- i. Remove aircraft from jacks.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-35. Rigging Nose Landing Gear

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-36. Rigging Retractable Step Cable Assembly

j. Washers may be added or deleted from stop bolt (5) to adjust travel of step attach assembly (1).

No specific measurement is required; only to facilitate entry and exit from aircraft.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

Thru Serial 21062273




Figure 5-37. Hydraulic and Electric System Schematic (Sheet 1 of 7)

MODEL 210 & T210 SERIES SERVICE MANUAL

Thru Serial 21062273




Figure 5-37. Hydraulic and Electric System Schematic (Sheet 2 of 7)

MODEL 210 & T210 SERIES SERVICE MANUAL

Thru Serial 21062273




Figure 5-37. Hydraulic and Electric System Schematic Sheet 3 of 7)

MODEL 210 & T210 SERIES SERVICE MANUAL

Thru Serial 21062273




Figure 5-37. Hydraulic and Electric System Schematic (Sheet 4 of 7)

MODEL 210 & T210 SERIES SERVICE MANUAL

Thru Serial 21062273




Figure 5-37. Hydraulic and Electric System Schematic (Sheet 5 of 7)

MODEL 210 & T210 SERIES SERVICE MANUAL

Thru Serial 21062273




Figure 5-37. Hydraulic and Electric System Schematic (Sheet 6 of 7)

MODEL 210 & T210 SERIES SERVICE MANUAL

Thru Serial 21062273




Figure 5-37. Hydraulic and Electric System Schematic (Sheet 7 of 7)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-38. Hydraulic and Electric System Schematic (Serial 21062274 thru 21062954) (Sheet 1 of 7)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-58. Hydraulic and Electric System Schematic (Serial 21062274 thru 21062954) (Sheet 2 of 7)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-38. Hydraulic and Electric System Schematic (Serial 21062274 thru 21062954) (Sheet 3 of 7)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-38. Hydraulic and Electric System Schematic (Serial 21062274 thru 21062954) (Sheet 4 of 7)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-38. Hydraulic and Electric System Schematic (Serial 21062274 thru 21062954) (Sheet 5 of 7)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-38. Hydraulic and Electric System Schematic (Serial 21062274 thru 21062954) (Sheet 6 of 7)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5-38. Hydraulic and Electric System Schematic (Serial 21062274 thru 21062954) (Sheet 7 of 7)

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 5A

LANDING GEAR, BRAKES AND HYDRAULIC SYSTEM (BEGINNING WITH 1979 MODELS)

WARNING

When performing any inspection or maintenance that requires turning on the master switch, installing a battery, or pulling the propeller through by hand, treat the propeller as if the ignition switch were ON. Do not stand nor allow anyone else to stand, within the arc of the propeller, since a loose or broken wire or a component malfunction could cause the propeller to rotate.

NOTE

This section covers 1979 and ON models, and was added to avoid the confusion of serialization caused by major changes in the aircraft hydraulic system. However, Section 5 contains information which is also applicable to these models. To avoid repetition, the reader is referred back to Section 5 for this information.

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
LANDING GEAR SYSTEM	1I17/5A-3	Reassembly	1J15/5A-18
Description	1I17/5A-3	Adjustment	1J16/5A-18A
Trouble Shooting	1I18/5A-4	Emergency Hand Pump	1J16/5A-18A
Hydraulic System Leak Check	1I22/5A-8	Description	1J16/5A-18A
Power Pack	1I23/5A-9	Removal and Installation	1J17/5A-18B
Description	1I23/5A-9	Disassembly	1J17/5A-18B
On-Aircraft Hydraulic Power		Inspection and Repair	1J17/5A-18B
Pack Operational Checks	1I23/5A-9	Reassembly	1J17/5A-18B
Removal	1I23/5A-9	Landing Gear Selector Valve	1J17/5A-18B
Disassembly	1I24/5A-10	Description	1J17/5A-18B
Inspection	1I24/5A-10	Removal and Installation	1J18/5A-19
Reassembly	1I24/5A-10	Disassembly and Reassembly	1J18/5A-19
Installation	1J11/5A-14	Inspection and Repair	1J19/5A-20
Primary and Thermal Relief		Rigging Throttle-Operated	
Valve Assemblies	1J12/5A-15	Warning Horn Microswitch	1J19/5A-20
Bench Check of Primary and		Main Landing Gear	1J19/5A-20
Thermal Relief Valves	1J12/5A-15	Description	1J19/5A-20
Removal	1J12/5A-15	Trouble Shooting	1J21/5A-22
Disassembly	1J12/5A-15	Removal	1J21/5A-22
Inspection	1J12/5A-15	Installation	1J21/5A-22
Assembly and Adjustment	1J12/5A-15	Rigging	1K1/5A-26
Installation	1J13/5A-16	Rigging Main Gear Down	
Pressure Switch	1J13/5A-16	Limit Switches	1K2/5A-27
Description	1J13/5A-16	Rigging Main Gear Up	
Removal (Thru 21063964		Limit Switches	1K2/5A-27
plus 21063973)	1J13/5A-16	Main Wheel and Tire	1K5/5A-30
Disassembly	1J13/5A-16	Description	1K5/5A-30
Inspection and Repair	1J14/5A-17	Balancing and Alignment	1K5/5A-30
Reassembly	1J14/5A-17	Main Wheel and Axle	1K5/5A-30
Adjustment	1J15/5A-18	Main Gear Actuator	1K5/5A-30
Installation	1J15/5A-18	Removal	1K5/5A-30
Removal (21063965 thru		Disassembly	1K5/5A-30
21063972 and 21063974		Inspection	1K6/5A-31
& on)	1J15/5A-18	Parts Repair/Replacement	1K6/5A-31
Disassembly	1J15/5A-18	Reassembly	1K6/5A-31
Inspection and Repair	1J15/5A-18	Installation	1K6/5A-31

MODEL 210 & T210 SERIES SERVICE MANUAL

TABLE OF CONTENTS Page No.
Aerofiche/Manual

Main Gear Pivot Assembly . . .	1K6/5A-31	Nose Gear Door System . . .	1K8/5A-33
Removal	1K6/5A-31	Description	1K8/5A-33
Inspection and Repair . . .	1K6/5A-31	Removal and Installation . . .	1K8/5A-33
Installation	1K6/5A-31	Nose Wheel Steering System . . .	1K8/5A-33
Gear Position Indicator	1K7/5A-32	Description	1K8/5A-33
Switches	1K7/5A-32	Rigging Nose Landing Gear . . .	1K8/5A-33
Description	1K7/5A-32	Rigging Nose Gear Down	
Main Gear Downlock Actuator . .	1K7/5A-32	Limit Switch	1K8/5A-33
Description	1K7/5A-32	Rigging Nose Gear Up	
Main Gear Strut Step	1K7/5A-32	Limit Switch	1K8/5A-33
Description	1K7/5A-32	Rigging of Nose Gear Squat . . .	
Removal	1K7/5A-32	Switch	1K8/5A-33
Installation	1K7/5A-32	Rigging of Nose Gear Doors . . .	1K8/5A-33
Nose Gear System	1K7/5A-32	Final Landing Gear Systems . . .	
Description	1K7/5A-32	Check	1K8/5A-33
Operation	1K7/5A-32	Nose Wheel and Tire	1K12/5A-37
Trouble Shooting	1K7/5A-32	Brake System	1K12/5A-37
Removal of Nose Gear		Brake Master Cylinder	1K12/5A-37
Assembly	1K7/5A-32	Description	1K12/5A-37
Shimmy Dampener	1K7/5A-32	Removal	1K12/5A-37
Torque Links	1K7/5A-32	Disassembly	1K12/5A-37
Squat Switch	1K7/5A-32	Inspection and Repair	1K12/5A-37
Nose Gear Downlock		Reassembly	1K12/5A-37
Mechanism	1K8/5A-33	Installation	1K12/5A-37
Nose Gear Actuator	1K8/5A-33	Parking Brake System	1K12/5A-37

MODEL 210 & T210 SERIES SERVICE MANUAL

WARNING

When performing any inspection or maintenance that requires turning on the master switch, installing a battery, or pulling the propeller through by hand, treat the propeller as if the ignition switch were ON. Do not stand, nor allow anyone else to stand, within the arc of the propeller, since a loose or broken wire, or a component malfunction, could cause the propeller to rotate.

5A-1. LANDING GEAR SYSTEM.

5A-2. DESCRIPTION. Retraction and extension of the landing gear is accomplished by a hydraulically-powered system, integrated with electrical circuits which help control and indicate gear position. Retraction and extension of the landing gear incorporates a nose gear actuator and two main gear actuators. The main gear actuators control the main gear struts through a sector gear arrangement. The nose gear doors are mechanically-operated. The doors are closed with the gear retracted and are open with the landing gear extended. The main gears have no doors. Hydraulic fluid is supplied to the landing gear actuating cylinders by an electrically-powered power pack assembly, located inside the center console. The hydraulic reservoir is an integral part of the power pack assembly. Gear selection is accomplished manually by moving a gear selector handle, located immediately left of center, in the switch panel. It is necessary to pull out on the gear selector to move the handle up or down. For emergency ex-

tension of the gear, the selector handle must be in the DOWN position before the hand pump will energize the system. A pressure switch is mounted on the pump body. This switch opens the electrical circuit to the pump solenoid when pressure in the system increases to approximately 1500 psi. The pressure switch will continue to hold the electrical circuit open until pressure in the system drops to approximately 1000 psi. This will occur whether the gear selector handle is in either the UP or DOWN position. During a normal cycle, landing gear extended and locked can be detected by illumination of the gear DOWN indicator (green) light. Indication of gear retracted is provided by illumination of the UP indicator (amber) light. The nose gear squat switch, activated by the nose gear, electrically averts inadvertent retraction whenever the nose gear strut is compressed by the weight of the aircraft. Beginning with 1983 models, the up indicator (amber) light is replaced with a GEAR UNSAFE indicator (red) light. The GEAR UNSAFE (red) light is on anytime the gear is in transit (retract or extend), or whenever system pressure drops below 1000 PSI with the safety (squat) switch closed.

NOTE

It is possible to have the red and green lights on momentarily at the same time after the completion of the extend cycle, or when rotating during takeoff. However, if both stay on after the completion of the extend cycle, or if the red light stays on longer than 5 to 7 seconds during the retract cycle, a malfunction has occurred.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

5A-3. TROUBLE SHOOTING.

Just because this chart lists a probable cause, proper checkout procedures cannot be deleted and the replacement of a part is not necessarily the proper solution to the problem. The mechanic should always look for obvious problems such as loose or broken parts, external leaks, broken wiring, etc. To find the exact cause of a problem, a mechanic should use a hand pump, pressure gage and a voltmeter to isolate each item in the system. hydraulic fluid will foam if air is pumped into system, causing fluid to be blown overboard thru pack vent line.

The problems listed are all with the systems controls in their normal operating position: Master switch ON, hydraulic pump breaker IN and landing gear breaker IN. During landing gear system servicing, a power supply capable of maintaining 27.5 volts throughout the gear cycle must be used to augment the ship's battery.

CAUTION

Prior to using Hydro-Test unit with power pack, remove and dry off filler plug and dipstick. Adjust cap tension so that no movement of cap is apparent. Failure to accomplish these procedures could result in filler cap coming loose from power pack.

TROUBLE	PROBABLE CAUSE	REMEDY
MOTOR PUMP WILL NOT OPERATE GEAR BUT EMERGENCY HAND PUMP WILL OPERATE GEAR.	Low voltage (in flight).	Check alternator and wiring.
	Fluid level low in reservoir.	Refill reservoir.
	Motor pump failure.	Replace pump.
	Faulty check valve	Replace valve
	NOTE	
	Motor and pump are not repairable and must be replaced.	
	Pump frozen.	Remove motor and coupling from top of power pack and replace pump.
	Broken pump or motor drive shaft or coupling.	Remove motor and pump from top of power pack and replace motor, pump and coupling.
	If motor was not turning, check wiring and motor.	Check motor for loose or broken connections; check for frozen pump or coupling. Check circuit breaker in pedestal.
	Bad pump shaft seal.	Replace pump.
External leakage around top of pump assembly	Remove motor and pump assemblies from top of power pack and replace upper packing and/or back-up rings	
Air lock in pump (new pack installation or pump replacement.	Remove filter and intermittently bump start switch until fluid flows. Replace filter.	
PUMP OR EMERGENCY PUMP WILL NOT BUILD PRESSURE IN SYSTEM.	No fluid in reservoir.	Refill reservoir.

MODEL 210 & T210 SERIES SERVICE MANUAL

TROUBLE SHOOTING (Cont)

TROUBLE	PROBABLE CAUSE	REMEDY
PUMP OR EMERGENCY PUMP WILL NOT BUILD PRESSURE IN SYSTEM. (Cont).	Broken hydraulic line.	Check for evidence of leakage and repair or replace line. Flush out system and refill reservoir.
	Bad O-ring actuator piston; O-ring left out after repair.	Disconnect line upstream from actuator and check for pressure. Perform this check for all actuators in system.
	Bad O-ring on gear control valve.	Replace O-ring.
	Thermal relief valve stuck open.	Replace valve.
HAND PUMP DOES NOT BUILD PRESSURE, BUT ELECTRIC PUMP OPERATES PROPERLY.	Check valve in hand pump sticking.	Inspect check valve.
	Defective hand pump outlet check valve.	Replace valve.
	Main gear or downlock actuator O-ring leaking.	Disassemble actuator and replace O-rings.
	Filter in outlet check valve improperly positioned in filter body, or seal between filter and check valve improperly positioned.	Replace seal and position filter in retainer with Petrolatum.
LANDING GEAR OPERATION EXTREMELY SLOW.	Downlock rod adjustment incorrect (mainly LH rod).	Adjust rod end to lengthen actuator one turn.
	Pump failure.	Replace pump.
	Low voltage in electrical system.	Check alternator and wiring.
	Replace pump motor.	Pump motor brushes worn.
	Fluid leak in gear line.	Locate and repair or replace broken line or fitting.
	Excessive internal power pack leakage.	Remove and repair or replace power pack.
POWER PACK EXTERNAL LEAKAGE.	Static seals (all fittings).	Remove and replace O-rings and/or back-up rings as required. Check tubing flares for leaks.
	Reservoir cover.	Remove power pack and remove cover; replace seals.
GEAR DOWN-LOCK WILL NOT RETURN TO FULL-LOCK POSITION.	Binding in spring and tube assemblies.	Check operation to locate binding and eliminate.

MODEL 210 & T210 SERIES SERVICE MANUAL

5A-3. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
LANDING GEAR FAILS TO RETRACT.	Hydraulic pump motor circuit breaker open.	Reset, determine cause for opening. Repair or replace components as necessary.
	Instrument panel gear indicator circuit breaker open.	Reset breaker. Determine cause for tripped breaker.
	Hydraulic pump motor circuit wires disconnected or broken.	Repair or replace wiring.
	Instrument panel gear indicator circuit wires disconnected or open.	Repair or replace wiring.
	Nose gear squat switch inoperative.	Install new switch.
	Pressure switch defective.	Install new switch.
	Hydraulic pump motor solenoid defective.	Install new solenoid.
	Hydraulic pump motor ground.	Check for ground.
	Hydraulic pump motor defective.	Replace motor.
	Reservoir fluid level below operating level.	Fill reservoir with hydraulic fluid.
	Battery low or dead.	Check battery condition. Install new battery.
GEAR RETRACTION OR EXTENSION EXTREMELY SLOW.	Reservoir fluid level below operating level.	Fill reservoir with hydraulic fluid (Refer to Section 2).
	Restriction in hydraulic system.	Isolate and remove restrictions.
PUMP MOTOR STOPS BEFORE GEAR IS RETRACTED.	Hydraulic pump motor circuit breaker open.	Reset, determine cause for opening. Repair or replace components as necessary.
	Instrument panel gear indicator circuit breaker open.	Reset circuit breaker. Determine cause of tripped circuit breaker.
	Pressure switch out of adjustment.	Remove, adjust or install new switch.
	Restriction in hydraulic system, allowing pressure to build up and shut off pump motor before gear is retracted.	Isolate and determine cause. Remove restriction.
PUMP MOTOR STOPS BEFORE GEAR IS EXTENDED.	Hydraulic pump motor circuit breaker open.	Reset, determine cause for opening. Repair or replace components as necessary.
	Instrument panel gear indicator circuit breaker open.	Reset circuit breaker. Determine cause of tripped circuit breaker.

MODEL 210 & T210 SERIES SERVICE MANUAL

TROUBLE SHOOTING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
PUMP MOTOR CONTINUES TO RUN AFTER GEAR IS FULLY RETRACTED OR EXTENDED.	Pressure switch defective.	Install new switch.
	Pressure switch out of adjust.	Remove, adjust or install new switch.
	Hydraulic pump motor solenoid defective.	Install new solenoid.
	Internal leakage in system.	Check actuators for internal leakage. Repair or install new actuators.
	External system leakage.	Check all lines and hose for leakage. Repair or install new parts.
	Power pack relief valve out of adjustment.	Disassemble and repair or replace valve assembly.
	Hydraulic motor solenoid defective.	Install new solenoid.
PUMP MOTOR CYCLES EXCESSIVELY AFTER GEAR IS RETRACTED.	Pressure switch out of adjustment.	Remove, adjust or install new switch.
	Internal leakage in system.	Check actuators for internal leakage. Repair or install new actuators.
	External system leakage.	Check all lines and hose for leakage. Repair or install new parts.
GEAR DOES NOT FULLY RETRACT, BUT PUMP MOTOR CONTINUES TO RUN.	Internal leakage in system.	Check actuators for internal leakage. Repair or install new actuators.
	Reservoir fluid level below operating level.	Fill reservoir with hydraulic fluid (Refer to Section 2).
LANDING GEAR FAILS TO EXTEND.	Battery low or dead.	Check battery condition. Install new battery.
	Hydraulic pump motor circuit breaker open.	Reset, determine cause for opening. Repair or replace components as necessary.
	Instrument panel gear indicator circuit breaker open.	Reset circuit breaker. Determine cause of tripped circuit breaker.
	Hydraulic pump motor circuit wires disconnected or broken.	Repair or replace wiring.
	Hydraulic pump motor solenoid defective.	Install new solenoid.

MODEL 210 & T210 SERIES SERVICE MANUAL

TROUBLE SHOOTING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
LANDING GEAR FAILS TO EXTEND (cont).	Hydraulic pump motor ground.	Check ground.
	Hydraulic pump motor defective.	Replace motor.
	Reservoir fluid level below operating level.	Fill reservoir with hydraulic fluid (Refer to Section 2.)
	Nose gear contacts stop bolts.	Adjust stop bolts to obtain proper clearance. (Refer to paragraph 5A-87).
RH GEAR UNLOCKS BUT LH GEAR WILL NOT UNLOCK.	Improper setting of RH downlock actuator rod.	Check rigging procedures outlined in this Section.
BOTH RH AND LH MAIN GEAR UNLOCK BUT ONLY NOSE GEAR WILL RETRACT.	Improper setting of LH downlock actuator rod.	Check rigging procedures outlined in this Section.
MOTOR PUMP WILL NOT TURN ON BY WORKING SELECTOR SWITCH. HAND PUMP WILL PUT GEAR DOWN.	Defective pressure switch circuit.	Check circuit continuity.
		Check switch adjustment
SET SCREW ON CAM NOT EXTENDED ENOUGH FOR GEAR TO MOVE CAM OVER CENTER.	Check washers under bolt on downlock arm assembly.	Add AN960-10 washer under bolt downlock arm assembly
MAIN GEAR WILL NOT LOCK OVER CENTER.	Main gear not centered in support.	Rerig saddle per rigging instructions.
MALFUNCTION OF GEAR INDICATOR LIGHTS.	<ol style="list-style-type: none"> 1. Both lights on at same time. 2. Light will change from green to amber or in reverse when gear control switch is moved. 	Check ground wire for proper connection.

5A-3A. HYDRAULIC SYSTEM LEAK CHECK. (Refer to figure 5A-2.)

- a. Jack aircraft in accordance with procedures in Section 2 of this manual.
- b. To relieve system pressure, pull the GEAR PUMP circuit breaker to OFF, move the gear selector handle to UP, and move back to the DOWN position.
- c. Install a 0-2000 PSI gage at the tee (Index 28, figure 5A-3) on the left side of the power pack.
- d. Push the GEAR PUMP circuit breaker to the ON position, turn ON the master switch, and move gear selector handle to the UP position.
- e. Monitor pressure gage, after retraction cycle is complete, for pressure bleed down.
- f. If bleed down occurs, it can be an internal or external leak anywhere in the system.

NOTE

When any line is disconnected, be prepared for fluid leakage.

- g. Disconnect the return line from the gear selector. If fluid comes from the selector, the internal leak is in the system.
- h. If no leak-by is found, it can be assumed there is an internal leak in the power pack. If leak is found, proceed to step "j." Reconnect the return line.
- i. Power pack internal leakage can only be attributed to a bad thermal relief valve, check valve, or check valve O-ring. The only way to isolate part that is leaking is to systematically replace the check valve O-ring, check valve, and then thermal relief valve. Repeat leak test after replacement of each part to ensure leak correction.

MODEL 210 & T210 SERIES SERVICE MANUAL

- j. Remove gear DOWN line from the selector. If fluid comes from the line, one or more of the gear actuators is leaking. To locate the leaking actuator, disconnect the return line from each actuator. The leaking actuator will have fluid draining from the actuator port. Following the appropriate paragraphs in this section remove, overhaul and reinstall the actuator.
- k. Reconnect gear down line to the selector.
- l. Recheck all lines that were disconnected for security.
- m. Lower the landing gear. Following the procedures in step "b" relieve the system pressure.
- n. Remove the pressure gage from the service tee.
- o. In accordance with the procedures in Section 2 of this manual replenish the power pack reservoir with MIL-H-5606 hydraulic fluid and bleed the system.
- p. Remove aircraft from jacks.

5A-4. POWER PACK. (Refer to figure 5A-3.)

5A-5. DESCRIPTION. The hydraulic power pack, located in the pedestal, is a multi-purpose control unit. It contains a hydraulic reservoir, valves, an electrically-driven motor, and the pump. An emergency hand pump, located between the pilot's and copilot's seats, uses reservoir fluid to permit manual extension of the landing gear.

NOTE

The hydraulic power pack primary relief valve, thermal relief valve, and pressure switch can be operationally checked on the aircraft without power pack removal from the aircraft or disassembly. Refer to paragraph 5A-5A for specific instructions. Refer to paragraph 5A-11A for primary and thermal relief valve bench check instructions if the power pack is removed from aircraft.

5A-5A. ON-AIRCRAFT HYDRAULIC POWER PACK OPERATIONAL CHECKS. (Refer to figure 5A-3.) The primary and thermal relief valves and pressure switch should be pressure checked each 100 hours. They can be operationally checked without removal from aircraft. For bench check instructions after removal from power pack, refer to paragraph 5A-11A.

NOTE

Checks are to be performed with external power set at 28.5 volts.

- a. Primary Relief Valve.
 - (1) Jack aircraft in accordance with procedures outlined in Section 2.
 - (2) Remove cap and install pressure gage at tee (28) fitting on left side of power pack.
 - (3) Pull landing gear circuit breaker.
 - (4) Select landing gear handle to DOWN position.
 - (5) Install 18 gage (minimum) jumper wire between buss side of contactor and small terminal on pump motor contactor (to energize coil).

- (6) Push landing gear circuit breaker in; power pack should run; monitor pressure.
- (7) Primary Relief valve should open at 1800 PSI, +0 or -50 PSI.
- (8) After check is complete, remove pressure from system, remove pressure gage, install cap on tee (28), pull landing gear circuit breaker, remove jumper wire, push landing gear circuit breaker back in, and return system to original configuration.

- b. Thermal Relief Valve.

- (1) With aircraft on jacks and pressure gage installed at tee (28) fitting on left side of power pack, pull landing gear circuit breaker.
- (2) Select landing gear to DOWN position.
- (3) Extend emergency gear pump handle.
- (4) Pump emergency gear pump handle and monitor pressure. Thermal relief valve should open at 2200 PSI, -0 or +50 PSI.
- (5) After check is complete, remove pressure from system, remove pressure gage, and install cap on tee (28).
- (6) Push in landing gear circuit breaker, and return system to original configuration.

- c. Pressure Switch.

- (1) With aircraft on jacks and pressure gage installed at tee (28) fitting on left side of power pack, pull landing gear circuit breaker.
- (2) Select landing gear UP and DOWN several times to relieve pressure in landing gear system.
- (3) Select landing gear UP, and push in landing gear circuit breaker.
- (4) After gear raising cycle is complete, check pressure. Pressure should be 1500 PSI.
- (5) Select gear DOWN. After gear lowering cycle is complete, pressure should be 1500 PSI.
- (6) After check is complete, remove pressure from system, remove pressure gage, install cap on tee, and return system to original configuration.

5A-6. REMOVAL. (Refer to figure 5A-3.)

- a. Jack aircraft in accordance with procedures outlined in Section 2 of this manual.
- b. Turn master switch OFF and place gear selector handle in a neutral position to relieve system pressure. After 15 seconds, return gear selector handle to DOWN position.

NOTE

As hydraulic lines are disconnected or removed, plug or cap all openings to prevent entry of foreign material into the lines or fittings.

- c. Remove front seats and spread drip cloth over front carpet.
- d. Remove decorative cover from pedestal as outlined in Section 9 of this manual.
- e. Remove upper panel assembly from aft face of pedestal.
- f. Remove screws attaching indicator assembly at top of pedestal; remove indicator assembly.
- g. Remove four bolts attaching wheel and gear box assembly; remove wheel and gear box assembly.

MODEL 210 & T210 SERIES SERVICE MANUAL

- h. Loosen idler sprocket assembly by loosening bolt and sliding sprocket inboard in slot.
- i. Disconnect chain at connecting link.
- j. Remove left-hand and right-hand chain guards.
- k. Allow chain to remain on gimbal assembly in lower pedestal area.
 - l. Position gallon container under drain elbow at right-hand side of pedestal.
 - m. Remove cap from elbow and attach drain hose.
 - n. Using hand pump, drain reservoir fluid into container.
 - o. Disconnect and cap or plug all hydraulic lines at power pack.
 - p. Disconnect wiring at pressure switch.
 - q. Remove three mounting bolts, one at the forward side of power pack, and two, attaching power pack bracket to sides of pedestal.
 - r. Remove power pack and bracket from pedestal as a unit.

NOTE

It should not be necessary to disturb studs on left and right sides of pedestal to remove power pack.

- 5A-7. **DISASSEMBLY.** (Refer to figure 5A-3.)
- a. Remove bolts (24), washers (25), and packing (26) from reservoir (1).
 - b. Remove reservoir (1) from body assembly (19).

NOTE

If reservoir (1) will not disengage from body assembly (19), install a capped fitting in the pressure and return openings of the power pack assembly and attach an air hose to vent fitting at top of body assembly (19). Apply air pressure (not to exceed 15 PSI, reservoir proof pressure), and remove reservoir (1). A strap clamp is not recommended as clamp may damage reservoir (1).

- c. Remove packing (20) from body assembly (19).

NOTE

Disassembly of relief valves (5) and (23) is normally not required. Refer to applicable paragraphs for specific instructions regarding relief valves. Before removal, tag each relief valve (primary) or (thermal) to ensure correct reinstallation.

- d. Cut safety wire and remove relief valve assemblies (5) and (23) from body assembly (19).
- e. Remove dipstick (15) and fluid filter screen (16) from body assembly (19).
- f. Remove retainer (12), self relieving check valve filter assembly (11), back-up ring (13), packing (14), packing (10) and check valve (9) from body assembly (19).

NOTE

If check valve (9) will not fall from hole in body assembly (19), place a drift or punch made of soft material into the pressure opening of body assembly (19) and tap spacer from body assembly (19).

- g. Remove pressure switch (17) and packing (18) from body assembly (19).
- h. Cut safety wire, serial 21064588 and on, and remove bolts (4) attaching hydraulic pump (6) to body assembly (19), and remove pump (6) and coupling (8) from body assembly (19). Remove packings (20) and (22).
- i. Remove motor assembly from body assembly (19) by removing attaching bolts (4).

- 5A-8. **INSPECTION.** (Refer to figure 5A-3.)
- a. Wash all parts in cleaning solvent (Federal Specification P-S-611, or equivalent) and dry with filtered air.
 - b. Inspect all threaded surfaces for serviceable condition and cleanliness.
 - c. Inspect all parts for scratches, scores, chips, cracks, and indications of excessive wear.
 - d. Clean to ensure that all screens and filters are completely clean and undamaged.


- 5A-9. **REASSEMBLY.** (Refer to figure 5A-3.)

NOTE

During assembly, lubricate new packings, back-up rings, and threaded surfaces with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

- a. Using new packing (22), install hydraulic pump (6) and coupling (8) into body assembly (19) with bolts (4). Beginning with 21064588, safety wire bolts (4).


MODEL 210 & T210 SERIES SERVICE MANUAL



21062955 thru 21064772

Figure 5A-1. Landing Gear System Schematic (Sheet 1 of 4)

MODEL 210 AND T210 SERIES SERVICE MANUAL



21062955 thru 21064772

Figure 5A-1. Landing Gear System Schematic (Sheet 2 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5A-1. Landing Gear System Schematic (Sheet 3 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5A-1. Landing Gear System Schematic (Sheet 4 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 5A-2. Landing Gear System Component Locator


MODEL 210 & T210 SERIES SERVICE MANUAL

- * THRU SERIAL 21063964 PLUS
SERIAL 21063973
- * SERIAL 21063965 THRU SERIAL 21063972
AND 21063974 & ON
- 21062955 THRU 21064587
- * REFER TO SERVICE INFORMATION
LETTER #SE82-46.



A - A

1. Reservoir
2. Union
3. Packing
4. Bolt
5. Primary Relief Valve
6. Hydraulic Pump
7. Packing
8. Coupling
9. Self-Relieving Check Valve
10. Packing
11. Filter Assembly - Self-Relieving Check Valve
12. Retainer
13. Back-Up Ring
14. Packing
15. Dipstick
16. Fluid Filter Screen
17. Pressure Switch
18. Packing
19. Body Assembly
20. Packing
21. Packing
22. Packing
23. Thermal Relief Valve
24. Bolt
25. Washer
26. Packing
27. Flat Washer
28. Tee



NOTE

Assemble new packings and back-up rings lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

Figure 5A-3. Hydraulic Power Pack Assembly (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5A-3. Hydraulic Power Pack Assembly (Sheet 2 of 2)

- b. Install motor assembly on top of body assembly (19) after aligning coupling (8) to match mating connection in motor. Secure motor to body with bolts. Safety wire bolts as shown in View A-A.
- c. Using new packing (18), install and tighten pressure switch (17) onto body assembly (19).
- d. Using new back-up ring (13), and packings (14) and (10), install and tighten check valve (9), filter assembly (11), and retainer (12) into body assembly (19).
- e. Install primary relief valve (5) and thermal relief valve (23) assemblies along with packings (7) and (21) onto body assembly (19).

CAUTION

Ensure that relief valves are installed in their correct location. Refer to view A-A.

- f. Install fluid filter screen (16) and dipstick (15) into body assembly (19).

NOTE

Safety wire primary relief valve (5) and thermal relief valve (23) to hydraulic pump mounting bolts (4) as shown in view A-A.

- g. Using new packings (20) and (26) and washers (25) and (27), install bolts (24), and tighten reservoir (1) onto body assembly (19).

5A-10. INSTALLATION. (Refer to figure 5A-3.)

- a. Work power pack and bracket assembly into position and install three bolts, securing power pack to pedestal.

MODEL 210 & T210 SERIES SERVICE MANUAL

- b. Connect all hydraulic lines to power pack fittings. Ensure that all fittings are properly installed, with jamnuts tight, after lines are tightened.
- c. Install wheel and gear box assembly and indicator assembly in top of pedestal.
- d. Install left and right chain guards for rudder trim chain.
- e. Connect chain at connecting link after stringing chain over idler sprocket.
- f. Tighten idler sprocket assembly by sliding sprocket outboard in slot and tightening bolt.
- g. Connect ground wire to pressure switch (17), and wire to motor.
- h. Connect power pack wiring to plug.
- i. Install upper panel assembly on pedestal.
- j. Fill reservoir (1) on right side of power pack with clean hydraulic fluid in accordance with procedures outlined in Section 2 of this manual.
- k. Operate gear through several cycles to bleed system. Check for correct operation and signs of fluid leakage. A 28 volt power supply should be used to augment the ship's battery.

5A-11. PRIMARY AND THERMAL RELIEF VALVE ASSEMBLIES. (REFER TO FIGURE 5A-3.) The primary relief valve (5), located between the check valve (9) and pump (6), serves to limit that amount of pressure which can be generated by the pump (6). The thermal relief valve (23), located on the system side of the check valve (9), serves to limit the system pressure. System pressure can increase due to thermal expansion. Both valves are identical except for differing pressure relief settings (refer to figure 5A-4).

5A-11A. BENCH CHECK OF PRIMARY AND THERMAL RELIEF VALVES. (Refer to figure 5A-4.)

NOTE

The hydraulic power pack primary relief valve, thermal relief valve, and pressure switch can be operationally checked on the aircraft without power pack removal from the aircraft or disassembly. Refer to paragraph 5A-5A for specific instructions.

If on-aircraft pressure checking of the power pack reveals out-of-tolerance relief valve opening, it may be necessary to determine if relief valve disassembly or adjustment is necessary. Once removed from power pack, individual relief valves can be bench checked.

NOTE

Adequate precautions should be taken to recover hydraulic fluid which will be expelled from the primary relief valve while under pressure.

CAUTION

As primary and thermal relief valves are identical except for differing pressure relief settings, special care should be exercised to ensure relief valves are reinstalled in their correct locations. (Refer to figure 5A-3, view A-A.)

- a. Primary Relief Valve.
 - (1) Using a hydraulic pump with a flow rate of 0.5 to 0.7 gallons per minute connected to a hydraulic reservoir, a pressure gage with 2500 psi capacity, and a hose with appropriate fittings, connect hydraulic pump to adapter (2) of the primary relief valve.
 - (2) Apply pressure slowly to ensure that relief valve assembly opens at correct pressure reading. Primary relief valve should open at 1800 PSI, + 0 or -50 PSI. Refer to paragraph 5A-15 for adjustment instructions.
- b. Thermal Relief Valve.
 - (1) Using a hand pump connected to a hydraulic reservoir, a pressure gage with 2500 PSI capacity, and a hose with appropriate fittings, connect hand pump to adapter (2) of the thermal relief valve.
 - (2) Manually pump pressure up slowly to ensure that relief valve assembly opens at correct pressure reading. Thermal relief valve should open at 2200 PSI, -0 or + 50 PSI. Refer to paragraph 5A-15 for adjustment instructions.

5A-12. REMOVAL. (Refer to figure 5A-3.)

- a. Cut safety wire and remove primary relief valve (5) and thermal relief valve (23) from body assembly (19).

5A-13. DISASSEMBLY. (Refer to figure 5A-4.)

NOTE

Relief valve assemblies (5) and (23) are preset by the factory and normally will not require disassembly.

- a. Remove jamnut (13) and adjustment screw (12) from housing (8).
- b. Remove spring (11), guide (10), balls (6), and piston (9) from housing (8).
- c. Loosen jamnut (7) and remove adapter (2) from housing (8).
- d. Remove poppet (4) and orifice (3) from adapter (2).

5A-14. INSPECTION. (Refer to figure 5A-4.)

- a. Wash all parts in cleaning solvent (Federal Specification P-S-611 or equivalent) and dry with filtered air.
- b. Inspect all threaded surfaces for serviceable condition and cleanliness.
- c. Inspect all parts for scratches, scores, chips, cracks, and indications of excessive wear.

5A-15. ASSEMBLY AND ADJUSTMENT. (Refer to figure 5A-4.)

NOTE

Use new packings during reassembly. Lubricate all packings with MIL-H-5606 hydraulic fluid. Lubricate threads with Petrolatum.

- a. Install orifice (3) and poppet (4) into adapter (2). (New packing [5] must be installed on poppet [4].)
- b. Install jamnut (7) and housing (8) on adapter (2).
- c. Tighten adapter (2) into housing (8) and torque to 100-150 lb-in.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5A-4. Relief Valve Assembly

- d. Tighten jamnut (7) against housing (8), and torque to 100-150 lb-in.
- e. Install one ball (6) into housing (8), so that it rests on poppet (4). Install piston (9) into housing (8), then install remaining ball (6) into end of piston (9).
- f. Insert guide (10) and spring (11) into housing (8), making sure that balls (6) and piston (9) remain in correct position.
- g. Turn adjustment screw (12) into housing (8) until it just contacts spring (11), then turn in one additional turn. Start jamnut (13) onto adjustment screw (12) and snug against housing (8).
- h. Connect hydraulic pump with a flow rate of 0.5 to 0.7 gallons-per-minute and a pressure gage with 2500 PSI capacity to relief valve. Apply pressure slowly to ensure that relief valve assembly opens at correct pressure reading. Primary relief valve opens at 1800 PSI, +0 or -50 PSI and reset at 1500 PSI MINIMUM (no leakage). Thermal relief valve opens at 2200 PSI, +50 or -0 PSI.
- i. If adjustment of either relief valve is necessary, loosen jamnut (13) and turn adjustment screw (12) in to increase pressure or back adjustment screw (12) out to decrease pressure. Tighten jamnut (13) against housing (8) and torque to 100-150 lb-in. Recheck pressure adjustments.

- 5A-16. **INSTALLATION.** (Refer to figure 5A-3.)
 a. Install relief valve assemblies (5) and (23) along with new packings (7) and (21) onto body assembly (19).

CAUTION

Ensure that relief valves are installed in their correct locations. (Refer to view A-A.)
 Safety wire relief valves as shown in view A-A.

- 5A-17. **PRESSURE SWITCH.** (Refer to figure 5A-5.)

5A-18. **DESCRIPTION.** A pressure switch is located in the cover of the power pack. The switch opens the electrical circuit to the pump solenoid when the pressure in the system increases to approximately 1500 PSI. The pressure switch will continue to hold the electrical circuit open until pressure in the system drops to approximately 1000 PSI, at which time the pump will again to operate to build up pressure to approximately 1500 PSI, regardless of gear selector handle position.

NOTE

The hydraulic power pack primary relief valve, thermal relief valve, and pressure switch can be operationally checked on the aircraft without power pack removal from the aircraft or disassembly. Refer to paragraph 5A-5A for specific instructions.

- 5A-19. **REMOVAL.** (THRU 21063964 PLUS 21063973.) (Refer to figures 5A-3 and 5A-5.)

- a. Move left seat to full aft position.
- b. Remove decorative cover from pedestal as outlined in Section 9 of this manual.
- c. Remove upper panel assembly from aft face of pedestal.
- d. Through opening created by removal of upper panel assembly, and assuring that master switch is off, disconnect wires from pressure switch.
- e. Disconnect and remove pressure switch and packing from power pack.

- 5A-20. **DISASSEMBLY.** (Refer to figure 5A-5.)

- a. Remove pin (11).
- b. Unscrew cap and housing assembly (10) from fitting (2).
- c. Remove spring (9).
- d. Remove washers (8) from flange of stop (7).

NOTE

Chart in figure 5A-5 lists washers (8) by part number, thickness and effect on operating pressure (psi).

- e. Unscrew guide (6) from fitting (2), do not damage lip of guide.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5A-5. Pressure Switch

- f. Remove piston (4).
- g. Remove seal (3) and packing (5).
- h. Remove snubber (1) from fitting (2).

CAUTION

Threads of snubber (1) and guide (6) are primed with Loctite grade T primer and sealed with Loctite grade AV sealant.

5A-21. INSPECTION AND REPAIR. (Refer to figure 5A-5.)

- a. Clean sealant from threads of snubber (1), fitting (2) and guide (6) with wire brush.
- b. Clean all parts with cleaning solvent (Federal Specification P-S-661, or equivalent) and dry thoroughly.
- c. Discard seal (3) and packing (5) and replace with new parts.
- d. Inspect all pressure switch parts for scratches, scores, chips, cracks and indications of wear.
- e. All damaged parts shall be replaced with new parts.
- f. Snubber (1) can be cleaned with solvent, then blown out with high pressure compressed air.
- g. Assure that 0.062-inch vent hole is open in stop (7).

5A-22. REASSEMBLY. (Refer to figure 5A-5.)

- a. Prime threads of snubber (1) and guide (6) with Loctite grade T primer and allow to dry for a minimum of three minutes. After primer has dried, apply Loctite grade AV sealant to snubber (1), install snubber into fitting (2), tighten with a slotted screwdriver and allow to cure from five to 40 minutes.

NOTE

Install new seals and packings and the re-

maining internal parts, lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7. Do not lubricate threads on guide (6).

- b. Install packing (5) in fitting (2).
- c. Install packing (3) in guide (6). Apply Loctite AV sealant to threads of guide, install guide in fitting (2) and finger-tighten. Allow sealant to cure from five to 40 minutes.

NOTE

It is possible to assemble, fill and test the pressure switch in the aircraft. This can be accomplished by the installation of a test fitting, located on the side of the power pack, and pumping the emergency hand pump. Master switch must be off and selector handle in down position.

- e. After installing test fitting and assuring that sealant in snubber (1) and guide (6) is dry, screw fitting assembly into power pack.
- f. Pump emergency hand pump just enough for fluid to seep from top of guide (6). (Refer to Section 2.)
- g. Insert piston (4) into hole in guide (6).
- h. Install stop (7) over guide (6).
- i. Install exact number and thickness of washers removed.

NOTE

If same number of washers (8) is installed as was removed, pressure should not require readjustment. If readjustment is necessary, a chart of washer part numbers, thickness and effect in pressure adjustment is shown in figure 5A-5.

MODEL 210 & T210 SERIES SERVICE MANUAL

5A-23. ADJUSTMENT. (Refer to figure 5A-5.)

- a. Jack aircraft in accordance with procedure outlined in Section 2 of this manual.
- b. Screw cap and housing (10) assembly on fitting (2) enough to bottom piston out in stop (7).
- c. Turn cap and housing assembly (10) back from full-thread engagement one turn, plus 0, minus one-fourth turn to locate hole in fitting (2) in slot in skirt of cap and housing assembly.
- d. Attach electrical connections to pressure switch and attach external power source.
- e. Turn on master switch.
- f. Pump hand pump to obtain 1500 psi on test gage.
- g. Switch should open electrical circuit to pump solenoid when pressure in system increases to approximately 1500 psi.
- h. If switch opens electrical circuit to solenoid prematurely, disassemble pressure switch down to washers (8) and add shims as necessary to obtain desired pressure; repeat steps (b) and (c).

NOTE

Chart in figure 5A-5 lists washers by part number, thickness and effect in psi each washer will have on switch operation.

- i. If switch opens electrical circuit to solenoid later than 1500 ± 50 psi, disassemble pressure switch down to washers (8) and remove washers as necessary to obtain desired pressure; repeat steps (b) and (c).
- j. Turn off master switch.
- k. Lower aircraft to ground.

5A-24. INSTALLATION. (Refer to figure 5A-3.) Since pressure switch will normally be left in power pack after adjustment, described in the preceding paragraph, all that needs to be accomplished is to reassemble the center console. This may be accomplished by installing the upper panel assembly on the aft face of the pedestal and installing the decorative cover as outlined in Section 9 of this manual.

5A-24A. REMOVAL AND INSTALLATION. (21063965 thru 21063972 & 21063974 & ON.) (See figure 5A-3.)

- a. Move left seat to full aft position and spread a drip cloth beneath power pack.
- b. Assure that master switch is OFF, and disconnect leads at terminals at pressure switch.
- c. Remove pressure switch from power pack.
- d. Reverse procedures for installation.

5A-24B. DISASSEMBLY. (See figure 5A-5A.)

- a. Remove pin (10).
- b. Unscrew housing (11) from fitting (2).
- c. Remove spring (9).
- d. Remove washers (8) from flange of stop (7).

NOTE

Chart in figure 5A-5A lists washers by part number, thickness and effect on operating pressure (psi).

- e. Unscrew guide (5) from fitting (2), do not damage lip of guide.

5A-24C. INSPECTION AND REPAIR. (See figure 5A-5A.)

- a. Clean sealant from threads of snubber (1), fitting (2) and guide (5) with wire brush.
- b. Clean all parts with cleaning solvent (Federal Specification P-S-661, or equivalent and dry thoroughly.
- c. Discard seal (3) and packing (4), and replace with new parts.
- d. Inspect all pressure switch parts for scratches, scores, chips, cracks and indications of wear.
- e. All damaged parts shall be replaced with new parts.

NOTE

Thorough cleaning is important. Dirt and chips are the greatest single cause of malfunctions in hydraulic systems. Carefulness and proper handling of parts to prevent damage must be observed at all times.

- f. Snubber (1) can be cleaned with solvent, then blown out with high pressure compressed air.
- g. Assure that 0.062-inch vent hole is open in stop (7).

5A-24D. REASSEMBLY. (See figure 5A-5A.)

NOTE

Threads of snubber (1) and guide (5) are to be primed with Loctite grade T primer and sealed with Loctite grade AV sealant. Allow primer to dry for a minimum of three minutes before sealant application. Allow sealant to cure from five to 40 minutes after snubber and guide are assembled.

NOTE

Install new seals and packings and existing internal parts, lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7. Do not lubricate threads on guide (5).

- a. Install snubber (1) into fitting (2) and tighten with slotted screwdriver.
- b. Install packing (4) in fitting (2).
- c. Install seal (3) in guide (5).
- d. Install guide (5) into fitting (2), and finger-tighten.

NOTE

It is possible to assemble, fill and test the pressure switch in the aircraft. This can be accomplished by the installation of a test gage in the capped port of the tee fitting on the right-hand side of the power pack, and pumping the emergency hand pump. Master switch must be OFF and selector handle must be in DOWN position.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5A-5A. Pressure Switch

e. After installing test fitting and assuring that sealant in snubber (1) and guide (5) is dry, screw fitting assembly into power pack body.

f. Pump emergency hand pump just enough for fluid to seep from top of guide (5). (Refer to Section 2 of this manual.)

g. Insert needle roller into hole in guide (5).

h. Install stop (7) over guide (6).

i. Install exact number and thickness of washers removed.

NOTE

If same number of washers (8) are installed as were removed, pressure should not require readjustment. If readjustment is necessary, a chart of washer part numbers, thickness and effect in pressure adjustment is shown in the figure.

j. Install spring (9) over washers (8).

k. Screw housing assembly (11) on fitting (2).

l. Check fluid level in power pack reservoir. (Refer to Section 2 of this manual.)

5A-24E. ADJUSTMENT. (See figure 5A-5A.)

a. Jack aircraft as outlined in Section 2 of this manual.

b. Screw housing assembly (11) on fitting (2), enough to bottom needle roller out in stop (7).

c. Turn housing (11) back from full-thread engagement one turn, plus 0, minus one-fourth turn to locate hole in fitting (2) in slot in skirt of housing.

d. Attach electrical connections to pressure switch and attach external power source.

e. Turn master switch ON.

f. Pump hand pump to obtain 1500 ± 50 psi on test gage.

g. The switch should open the electrical circuit to the pump solenoid when pressure in the system increases to approximately 1500 ± 50 psi.

h. If switch opens electrical circuit prematurely, disassemble pressure switch down to washers (8) and add washers as necessary to obtain desired pressure; repeat steps (b) and (c).

i. If switch opens electrical circuit later than 1500 ± 50 psi, disassemble pressure switch down to washers (8) and remove washers as necessary to obtain desired pressure; repeat steps (b) and (c).

j. Turn master switch OFF.

5A-25. EMERGENCY HAND PUMP. (Refer to figure 5A-6.)

5A-26. DESCRIPTION. The emergency hand pump is mounted below the floor between the pilot and co-pilot seats. The pump handle extends to the cabin. The pump supplies a flow of pressurized hydraulic

MODEL 210 & T210 SERIES SERVICE MANUAL

fluid to extend the landing gear in the event of normal hydraulic pump failure.

5A-27. REMOVAL AND INSTALLATION.

- a. Remove seats as required for access.
- b. Remove screws attaching cover over hand pump and remove cover.
- c. Peel back carpet as required for access to pump mounting bolts.
- d. Wedge cloth under hydraulic fittings to absorb fluid, then disconnect the two hydraulic lines and plug or cap open fittings to prevent entry of foreign material.
- e. Remove two bolts, washers and nuts securing pump to mounting bracket.
- f. Work pump from aircraft.
- g. Install hand pump by reversing the preceding steps, bleeding lines and pump as lines are connected.
- h. Fill reservoir as required.

5A-28. DISASSEMBLY. (Refer to figure 5A-6.)

NOTE

After emergency hand pump has been removed from aircraft, and ports are capped or plugged, spray with cleaning solvent (Federal Specification P-S-611, or equivalent) to remove all accumulated dust or dirt. Dry with filtered compressed air.

- a. Remove hand pump handle by removing pivot and linkage pins after removing cotter pins.
- b. Remove fitting (10) from pump body (16).
- c. Push piston (15) from pump body (16).
- d. Remove back-up ring (7) from fitting (10) to remove check valve (8) and KEP-O-SEAL valve (14) assemblies.
- e. Remove and discard all O-rings and back-up rings.

5A-29. INSPECTION AND REPAIR.

- a. Inspect seating surfaces of valves.
- b. Inspect piston for scores, burrs or scratches which could cut O-rings. This is a major cause of external and internal leakage. The piston may be polished with extremely fine emery paper. Never use paper coarser than No. 600 to remove scratches or burrs. If defects do not polish out, replace piston.

5A-30. REASSEMBLY. (Refer to figure 5A-6).

Assemble the emergency hand pump, using the figure as a guide. Also, for detailed instructions, reverse the procedures outlined in paragraph 5A-28. During assembly, prime fitting (10) with Loctite grade T primer, allow primer to dry for a minimum of three minutes. Apply Loctite hydraulic sealant to threads of pump body (16) and first two threads of the fitting (10). After installing fitting in pump body, allow the sealant to cure from five to 40 minutes.


NOTE

Install new back-up rings and packings, lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

5A-31. LANDING GEAR SELECTOR VALVE. (Refer to figure 5A-7.)

5A-32. DESCRIPTION. A mechanical gear position selector valve is located in the switch panel. The pilot shuttles the valve mechanically when he changes

MODEL 210 & T210 SERIES SERVICE MANUAL



NOTE

Install new back-up rings and packings lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7.

- | | | |
|-------------|-----------------|-----------------------|
| 1. Roll Pin | 7. Back-Up Ring | 12. Setscrew |
| 2. Stop | 8. Check Valve | 13. Spacer |
| 3. Handle | 9. Packing | 14. KEP-O-SEAL Valve |
| 4. Fork | 10. Fitting | 15. Piston |
| 5. Spring | 11. Washer | 16. Pump Body |
| 6. Knob | | 17. Union and Packing |

Figure 5A-6. Emergency Hand Pump Disassembly

gear handle position. The handle must be pulled out prior to selecting gear position. Moving the selector rod opens and closes ports in the valve, enabling fluid under pressure to flow to the various system components to retract or extend the gear.

5A-33. REMOVAL AND INSTALLATION. (Refer to figure 5A-7.)

- a. Loosen nut (15) and remove knob (16).

CAUTION

As hydraulic lines are disconnected, fluid

will leak. Precautions must be taken to prevent excessive leakage, such as spreading drip cloths under fittings and capping lines and fittings.


- b. Disconnect hydraulic lines routed to valve.
- c. Remove screws attaching valve to instrument panel.
- d. Remove selector valve.
- e. Reverse preceding steps to install gear selector valve.

5A-34. DISASSEMBLY AND REASSEMBLY. (Refer

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

Beginning with 21063812, steel disc (9) is replaced by aluminum disc (9). Bearing (5) and race (4) are replaced by teflon washer (17) at the same aircraft serial.



- | | |
|-------------------|-------------------|
| 1. Cover | 9. Disc |
| 2. Retaining Ring | 10. Packing |
| 3. Cap | 11. Pucks |
| 4. Bearing Race | 12. Spring |
| 5. Thrust Bearing | 13. Body Assembly |
| 6. Washer | 14. Rod |
| 7. Spring | 15. Nut |
| 8. Packing | 16. Knob |
| | 17. Washer |

Figure 5A-7. Landing Gear Position Selector Valve

to figure 5A-7.)

- a. Remove cover (1), retaining ring (2) and cap (3). Thru 21063811, remove race (4) and bearing (5). Beginning with 21063812, remove washer (17).
- b. Remove cotter pin, washer (6) and spring (7).
- c. Pull rod (14) from disc (9); remove disc.
- d. Remove packs (11) and springs (12).
- e. Reverse preceding steps for reassembly.

5A-35. INSPECTION AND REPAIR. (Refer to figure 5A-7.) Replace packings (8) and (10). Check valve for wear, foreign or abrasive materials. Disc (9) may be refaced (lapped) if worn or abraded. Check rollers in bearings (5).

5A-36. RIGGING THROTTLE-OPERATED GEAR WARNING HORN MICRO-SWITCH. (Refer to figure 5A-8.) Rigging procedures for sea level or turbo-charged aircraft are outlined in figure 5A-8.)

5A-37. MAIN LANDING GEAR. (Refer to figure

5A-9.)

5A-38. DESCRIPTION. The tubular main gear struts rotate aft and inboard to stow the main wheels beneath the baggage compartment. The main gear utilizes hydraulic pressure for positive uplock and mechanical downlocks. Main gear uplock pressure is maintained automatically by the pump assembly. Rotation of the gear to extend or retract the struts is achieved through pivot assemblies which in turn are bolted through a splined shaft, to the hydraulic main gear rotary actuators.

CAUTION

Use of recapped tires or new tires not listed on the aircraft equipment list are not recommended due to possible interference between the tire and structure when landing gear is in the retracted position.

MODEL 210 & T210 SERIES SERVICE MANUAL


SETTING THROTTLE SWITCHES

1. During flight at 120 MPH (IAS), 2500', prop control full forward for maximum RPM, and with the gear and flaps up, mark the throttle control position corresponding to the following manifold pressures:

Model 210M _____ 12.0" \pm .5"
Model T210M _____ 15.0" \pm 1.0"

2. Then adjust the gear warning horn throttle switch on the ground to activate at the throttle control position as marked in flight.

"For each 1000 feet above 2500' MSL, decrease the manifold pressure at which the throttle control position is marked by 0.5 inches."



1. Switch Cover
2. Switch Cover
3. Spacer
4. Switch
5. Switch Spacer

6. Switch Mounting Bracket
7. Arm Assembly
8. Gear Warning Cam
9. Fuel Pump Cam
10. Bushing

Figure 5A-8. Rigging Throttle-Operated Gear Warning Horn Switch

MODEL 210 & T210 SERIES SERVICE MANUAL

5A-39. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
AIRCRAFT LEANS TO ONE SIDE.	Incorrect tire inflation.	Inflate to correct pressure.
	Sprung main gear strut.	Remove and replace strut.
	Bent axle.	Install new axle.
UNEVEN OR EXCESSIVE TIRE WEAR.	Incorrect tire inflation.	Inflate to correct pressure.
	Wheel out of alignment.	Align wheels.
	Wheels out of balance.	Balance wheels.
	Sprung main gear strut.	Replace strut.
	Bent axle.	Install new axle.
	Dragging brakes.	Jack wheel and check brake.
	Wheel bearings not adjusted properly.	Tighten axle nut properly.

5A-40. REMOVAL. (Refer to figure 5A-9.)

- a. Jack aircraft in accordance with procedures outlined in Section 2 of this manual.
- b. Bleed fluid from brake line at wheel brake cylinder.
- c. Turn master switch off; move gear position selector valve to up position, then turn master switch on until main gear downlocks disengage. Turn master switch off and pull pump motor circuit breaker to ensure that pump cannot be actuated accidentally. Place gear position selector handle in a neutral position so that gear rotates freely.

NOTE

If the pump motor cannot be used to unlock the main gear because of an opening in the hydraulic system, the spring-loaded main gear downlocks can be manually unlocked by pushing them forward with a screwdriver or other similar tool, and holding them forward, until the main gear has rotated past.

WARNING

It is advisable to have an assistant hold the gear strut up while the locks are pushed forward to prevent the strut from rotating suddenly, possibly causing personal injury. Ensure that master switch is OFF and pump motor circuit breaker pulled.

- d. Remove strut attach bolt (26) and work strut (29) and plug (25) from pivot assembly (14).
- e. Disconnect brake line from union (23) and plug union and brake line.

- f. Remove packings (24) from plug (25) and clean plug and strut (29).

5A-41. INSTALLATION. (Refer to figure 5A-9.)

NOTE

The following procedure installs the landing gear as a complete assembly. Refer to applicable paragraphs for installation of individual components.

- a. Lubricate new O-rings (24) and end of strut (29) with Petrolatum VV-P-236, hydraulic fluid MIL-L-5606, or Corning DC-7 (keep DC-7 away from areas to be painted) before installation. Install O-rings (24) on plug (25).
- b. Remove caps from union (23) and brake line (22), attach brake line (22) to union (23), and work plug (25) and strut (29) into pivot (14).

NOTE

When installing a new pivot (14), burnishing the 2.100-inch I. D. bore may be required to facilitate assembly of landing gear strut (29).

- c. Align hole in plug (25) with holes in pivot assembly (14) using special tool No. SE934.

NOTE

Special tool No. SE934 is available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations. This tool is designed to install strut attaching bolt (26) without damaging the packings (24) in the plug (25).

MODEL 210 & T210 SERIES SERVICE MANUAL






Figure 5A-9. Main Landing Gear

MODEL 210 & T210 SERIES SERVICE MANUAL



● Install internal tooth washer under bolt heads.

* Prime bolts with Locktite grade T primer, allow to dry for a minimum of three minutes, and seal with CV Locktite Catalog #85 or #83. Allow sealant to cure from five to 40 minutes.



- | | |
|------------------------------|------------------------|
| 1. Tie | 11. Eyebolt |
| 2. Boot | 12. Shim |
| 3. Pin | 13. Support Assembly |
| 4. Spacer | 14. Landing Gear Strut |
| 5. Arm Assembly | 15. Shell Assembly |
| 6. Downlock Adjustment Screw | 16. Stud |
| 7. Hook | 17. Pivot Assembly |
| 8. Setscrew | 18. Bolt |
| 9. Down Limit Switch | 19. Rod End |
| 10. Spring Assembly | 20. Actuator |

NOTE

Stud (16) and downlock support shell (15) attaching screws shall be sealed with grade AV Locktite 271, or Locktite Catalog #87. Allow sealant to cure for 12 hours before service use.

Figure 5A-10. Rigging Main Landing Gear (Sheet 1 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5A-10. Rigging Main Landing Gear (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5A-10. Rigging Main Landing Gear (Sheet 3 of 3)

d. Install bolt (26) by pushing tool SE934 through the aligned holes of pivot (14), strut (29), and plug (25), with the threaded end of the bolt (26). Install and tighten nut and washer on the bolt (26).

e. Fill and bleed brake system in accordance with paragraph 5-77 in this manual.

f. Rig landing gear in accordance with procedures outlined in this Section.

5A-42. RIGGING. (Refer to figure 5A-10.)

NOTE

All of the following rigging adjustments shall be accomplished with the aircraft on jacks and in a level condition, using the ship's power pack to supply pressure. A ground power source should augment the ship's battery.

a. With main gear unlocked and main landing gear support forging assembled loose to the outboard support assembly, bring main landing gear strut into DOWN position and adjust as follows:

1. Center and shim simultaneously main landing gear support, using shims (P/N 1241629) between outboard forging and landing gear support assembly as shown on sheet 1, to level wings and assure that end points of main landing gear wheel axles are

within $\pm .25$ -inch of a water line plate. Total of shims to be within .025-inch to .075-inch. Check landing gear spring-to-support pad surface contact, and maintain surface contact at 75% or better. The following shims are available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations:

1241629-1	0.016-inch
1241629-2	0.025-inch
1241629-3	0.050-inch
1241629-4	0.071-inch

b. Adjust downlock setscrew (8) to stop hook assembly .040 to .090-inch over center as shown on sheet 2.

NOTE

The downlock hook shall have positive clearance with both inboard and outboard ears of the gear pivot, in all conditions of hook operation, locked, normal operation and malfunction operation. Adjust downlock hook inboard or outboard as required, by locating spacers, installed on the required side of the hook. In some cases, all of the spacers will be installed on one side of the downlock hook to achieve the required clearance.

c. A new downlock actuator assembly is received

MODEL 210 & T210 SERIES SERVICE MANUAL

with a preassembled length of 12.45-inches, and the three hydraulic ports in the same plane. Install actuator assembly (20), attaching it to fuselage structure and arm assembly (5).

d. With landing gear free, hydraulic pressure off, and downlock systems in position shown on sheet 1, swing landing gear into the DOWN position and adjust adjusting screw as follows:

NOTE

To relieve hydraulic pressure, pull hydraulic pump circuit breaker off, and move gear selector handle up and down two or three times.

1. If downlock locks, turn adjusting screw 1/4 turn out at a time until lock will not lock; then turn back in 1/4 turn and secure pin.

2. If downlock does not lock, turn adjusting screw 1/4 turn in at a time until lock will lock, then secure pin.

e. Readjust setscrew (8) to stop hook assembly .040 to .090-inch overcenter. When checking overcenter measurement of arm assembly (5), landing gear should be as shown on sheet 2, with nut, washer, and spacer removed, which retains the arm assembly (5). Use downlock overcenter gages (P/N SE960) to determine if hook (7) is still within tolerances shown on sheet 2. Use gages as follows:

NOTE

Overcenter gages (P/N SE960) are available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations.

1. Remove nut, washer and spacer which retain arm assembly to support assembly.

2. Install 0.090-inch downlock gage (SE960) on inboard side of downlock hook as shown on sheet 2. Upper portion of gage should rest against head of pin attaching adjusting screw. If downlock hook is under maximum overcenter tolerance, green area of gage will contact spacer on gear pivot, while red area will not make contact with 0.50-inch diameter shoulder, as shown in the figure. When downlock hook is in maximum overcenter tolerance, both green and red areas will make contact. If red area makes contact and green area does not, the downlock hook setscrew should be adjusted INWARD to bring overcenter dimension within tolerance.

3. Install 0.040-inch downlock gage (SE960) on inboard side of downlock hook as shown on sheet 2. If downlock hook is over minimum overcenter tolerance, green area of gage will contact shoulder, while red area will not make contact with spacer.

4. When downlock hook is in minimum overcenter tolerance, both red and green areas will make contact.

5. If overcenter tolerance is less than 0.040-inch, the red area will make contact, while the green area will not. If this condition exists, the next step is to determine if the downlock adjustment screw (6) is making contact with the setscrew (8). This is accomplished by lifting the landing gear spring upward off the hook assembly and checking for possible rotation of the hook assembly, by hand, with hydraulic pressure off.

6. If a slight rotation is possible, setscrew (8) is not contacting downlock adjustment screw (6). If contact is not being made, downlock actuator will have to be readjusted by backing off actuator's rod end (19) one-half turn at a time (one-and-one-half turns maximum adjustment) until hook assembly is 0.040-inch or more overcenter, and contact is being made between setscrew (8) and downlock adjustment screw. If contact is being made, setscrew (8) should be adjusted outward to increase overcenter measurement to within tolerance.

NOTE

For correct rigging, downlock hook setscrew (8) must make contact with downlock adjustment screw (6) and green areas of both gages must contact as shown on sheet 2.

f. Now that downlock adjustment screw (6) has been adjusted following procedures outlined in step "e.", check downlock actuator rod end (19) adjustment as follows:

1. Connect all hydraulic lines, fill system with MIL-H-5606 hydraulic fluid and purge system of air by cycling gear through several cycles.

NOTE

Check fluid level in power pack reservoir frequently during purging and rigging procedures.

2. Pull hydraulic pump circuit breaker off.


3. With gear in down and locked position, move gear selector handle to GEAR UP position and note actuation of main gear downlock hooks.

4. As soon as left downlock hook is actuated to unlock the left gear, move gear selector handle back to GEAR DOWN position to simulate what would occur if the pilot were to select gear down before the gear was fully retracted. If downlock hooks do not lock the gear in the down position, check downlock system for misalignment.

5A-43. RIGGING MAIN GEAR DOWN LIMIT SWITCHES. (Refer to figure 5A-10, sheets 1 and 2.) The main gear down limit switches (9) are attached to brackets which are welded to the spring assembly (10). Adjustment is accomplished by loosening the lock nut and either tightening or loosening the adjustment nut and retightening the lock nut against the bracket behind the adjustment nut. Down limit switches (9) are to be adjusted to the dimension stipulated in Sheet 2.

5A-44. RIGGING MAIN GEAR UP LIMIT SWITCHES. (Refer to figure 5A-10, Sheet 3.) The main gear up limit switches (6) are mounted in indicator light brackets (2) which are attached to the underside of the removable floorboards (1), immediately above the main landing gear pivot assemblies. The switches are contacted by actuators, bonded to clamps, which are attached to the aft leg of the landing gear strut pivot assembly. When replacing a clamp/actuator assembly, adjust the actuator tab prior to bonding, so that it actuates the gear-up indicator light switch. Bond the actuator to the clamp with HYSOL EA-9309 or 3M EC-2216

MODEL 210 & T210 SERIES SERVICE MANUAL



PLACE CARPENTER'S SQUARE AGAINST STRAIGHTEDGE AND LET IT TOUCH WHEEL JUST BELOW AXLE NUT

ALUMINUM PLATES, APPROXIMATELY 18" SQUARE, PLACED UNDER WHEELS

GREASE BETWEEN PLATES


NOTE

Rock wheels before checking wheel alignment.

BLOCK STRAIGHTEDGE AGAINST TIRES JUST BELOW AXLE HEIGHT


TOP VIEW OF TOE-IN CHECK

Measure toe-in at edges of wheel flange. Difference in measurements is toe-in for one wheel. (half of toe-in.)



FRONT VIEW OF CAMBER CHECK

Measure camber by reading protractor level held vertically against outboard flanges of wheel.




NOTE

See Section 1, figure 1-1 for toe-in and camber tolerances. Setting toe-in and camber within these tolerances while the cabin and fuel tanks are empty will give approximately zero toe-in and zero camber at gross weight. Therefore, if normal operation is at less than gross weight and abnormal tire wear occurs, realign the wheels to attain the ideal setting for the load conditions. Refer to sheet 2 of this figure for shims availability. Always use the least number of shims possible to obtain the desired result.

Figure 5A-11 Wheel Alignment (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL



NOTE

To assure adequate thread engagement of the mounting bolts, use 0541111-2 or 0441139-6 shim alone and/or 0541157-1, -2, -3 or 0441139-5 shims in any combination as required to get zero toe-in and zero camber at normal operating weight. Total thickness of shims at upper bolts must not exceed .195. If any tapered shims are used, all AN960 washers must be removed from the upper bolts.

Figure 5A-11. Wheel Alignment (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5A-12. Main Landing Gear Actuator

adhesive. Trim off excess end tab of clamp and position clamp helix approximately as shown in the figure, to avoid interference with gear-up switch wiring. Additional up limit switch (6) adjustment is provided by slotted holes in the switch indicated light brackets (2). Adjust actuator tab-to-switch clearance to dimension stipulated in Sheet 3.

5A-45. MAIN WHEEL AND TIRE ASSEMBLY.

5A-46. DESCRIPTION. The aircraft may be equipped with either Cleveland or McCauley wheel and tire assemblies. Separate disassembly, inspection and reassembly instructions are provided for each type in Section 5 of this manual.

CAUTION

Use of recapped tires or new tires not listed on the aircraft equipment list are not recommended due to possible interference between the tire and structure when landing gear is in the retracted position.

5A-47. MAIN WHEEL BALANCING AND ALIGNMENT. Wheel alignment procedures are outlined in figure 5A-11.)

5A-48. MAIN WHEEL AND AXLE. Main wheel and axle removal and installation procedures are outlined in Section 2 of this manual.

5A-49. MAIN GEAR ACTUATOR. (Refer to figure 5A-12.)

5A-50. REMOVAL.

- Remove seats and peel back carpet as necessary to gain access to plate above actuator; remove access plate.
- Remove access plate from bulkhead forward of actuator.
- Disconnect and drain hydraulic fluid at wheel brake cylinders.
- Place landing gear control handle UP, with master switch OFF, and operate emergency hand pump until main gear downlocks release.
- Disconnect and cap or plug all hydraulic lines at the actuator.
- Remove bolts attaching actuator mounting flange to bulkhead forging.
- Work actuator free of forging and pivot assembly; remove actuator.

5A-51. DISASSEMBLY. (Refer to figure 5A-12.)

- Remove setscrew (8) and remove end gland (7)

MODEL 210 & T210 SERIES SERVICE MANUAL

- by unscrewing from actuator body (3).
- b. Remove cap (1) from end of actuator.
 - c. Using a small rod, push piston (12) from actuator body.

NOTE

Unless defective, do not remove nameplate, bearings (2) or roller (13).

- d. Remove packing (5) and back-up ring (4) from cylinder body (3). Discard packing (10).
- e. Remove packing (10) and back-up ring (9) from end gland (8). Discard packing (10).
- f. Remove and discard packing (11) from piston (12).

5A-52. INSPECTION.

- a. Thoroughly clean all parts in cleaning solvent (Federal Specification PS-661, or equivalent.)
- b. Inspect all threaded surfaces for cleanliness, cracks and wear.
- c. Inspect cap (1), piston (12), roller (13), if removed, and actuator body (3) for cracks, chips, scratches, scoring, wear or surface irregularities which may affect their function or the overall operation of the actuator.
- d. Inspect bearings (2), if removed, for freedom of motion, scores, scratches or Brinell marks.

5A-53. PARTS REPAIR/REPLACEMENT. Repair of small parts of the main landing gear actuator is impractical. Replace all defective parts. Minor scratches or score marks may be removed by polishing with abrasive crocus cloth (Federal Specification P-C-458), providing their removal does not affect operation of the unit. During assembly, install all new packings.

5A-54. REASSEMBLY. (Refer to figure 5A-12.)

NOTE

Install new packings and back-up rings lubricated with a film of Petrolatum VV-P-236, hydraulic fluid MIL-H-5606, or Dow-Corning DC-7. If roller (13) and bearings (2) have been removed, lubricate with MIL-G-2116C lubricant.

- a. If bearings (2) and roller (13) were removed, press one bearing into actuator body until it is flush. Install roller and press second bearing in place to hold roller. Use care to prevent damage to bearings or roller.
- b. Install back-up ring (4) and packing (5) in actuator body core. Install new packing (11) and back-up rings (6) on piston (12).

NOTE

Lubricate piston rack gears with MIL-G-21164C lubricant. Apply lubricant sparingly. Over-greasing might cause contamination of hydraulic cylinder assembly with grease which might work past packing.

- c. Slide piston (12) into cylinder body (3).
- d. Install back-up ring (9) and new packing (10) on end gland.
- e. Install end gland in cylinder and tighten until end

of gland is flush with end of cylinder body. Install and tighten setscrew (8).

- f. Install cap (1) at end of actuator assembly.

5A-55. INSTALLATION.

- a. With main landing gear in the down and locked position, install actuator into bulkhead forging so that piston rack gear and sector gear engage as shown in figure 5A-9, Section A-A.
- b. Lubricate swivel fitting on actuator with MIL-G-21164 lubricant, install packing in fitting.
- c. Install cap (4), washer (3), retainer (2) and swivel fitting on actuator as shown in figure 5A-9.
- d. Install bolts (1) and torque to 60-85 lb in. Safewire swivel fitting to shaft (8).
- e. Connect all hydraulic lines to their source locations. Lubricate threads with Petrolatum, VV-P-236.
- f. Connect brake line at wheel cylinder. Fill and bleed brake system in accordance with procedures outlined in applicable paragraph in this section.
- g. Rig landing gear in accordance with procedures outlined in applicable paragraph in this section.
- h. Remove aircraft from jacks and install access covers, carpeting and seats removed for access.

5A-56. MAIN GEAR PIVOT ASSEMBLY.

5A-57. REMOVAL. (Refer to figure 5A-9.)

- a. Remove strut from pivot assembly in accordance with procedures outlined in applicable paragraph in this section.
- b. Remove actuator in accordance with procedures outlined in applicable paragraph in this section.
- c. Remove setscrew from sector gear (7).
- d. Bend tangs of washer (21) from notches in nut (20) and completely unscrew nut (20) from threaded area of shaft (17).
- e. Push shaft (17) into pivot assembly (14) and pull pivot assembly free of shaft (8).

5A-58. INSPECTION AND REPAIR. (Refer to figure 5A-9.)

- a. Thoroughly clean all parts in cleaning solvent (Federal Specification PS-661 or equivalent.)
- b. Inspect all parts for indications of damage, cracks or excessive wear and replace as necessary.
- c. Inspect outboard pivot bushing and inboard pivot bearing (10) (pressed into bulkhead forgings in aircraft) for damage and excessive wear. Replace bushing or bearing as required.

NOTE

The outboard pivot bushing is locked into the bulkhead forging by a setscrew located above the bushing. This setscrew must be turned out several turns before the bushing can be removed.

5A-59. INSTALLATION. (Refer to figure 5A-9.)

- a. Lubricate all bushings and bearings with MIL-G-21164 grease. Slide shaft (17) into pivot assembly (14).
- b. Install pivot with bearing (12) and race (11) installed, into inboard bearing in bulkhead forging. Pull shaft from pivot and install washer (21) and nut (20) on shaft.

MODEL 210 & T210 SERIES SERVICE MANUAL

c. Insert end of shaft into outboard bushing in bulk-head forging. Hand-tighten nut to remove all end play and safety in place by bending corresponding tang of washer into notch of nut. Pivot must rotate freely.

d. Install seal (9) and sector gear (7) on inboard end of pivot assembly so that setscrew hole in sector gear lines up with setscrew hole in shaft (8); install setscrew into sector gear and shaft with Loctite 242 locking compound and tighten screw.

5A-60. GEAR POSITION INDICATOR SWITCHES.

5A-61. DESCRIPTION. The gear down indicator switches are attached to brackets which are welded to the downlock hooks. The main gear up limit switches are mounted in brackets which are attached to the underside of the removable floorboards immediately above the main landing gear pivot assemblies. Refer to the paragraphs in this section which outline procedures for rigging the main gear up and down switches.

5A-62. MAIN GEAR DOWNLOCK ACTUATOR. (Refer to Section 5.)

5A-63. DESCRIPTION. The main gear downlock actuators for the 1979 Models is the same actuator used on Models thru 1978. Function and operation are the same. The only difference between the actuators is the replacement of the MS28778-4 fitting with a hose assembly. Refer to Section 5 for actuator removal, disassembly, inspection and repair and installation. Adjustment of the actuator rod end is discussed in the main landing gear rigging paragraph in Section 5A.

5A-64. MAIN GEAR STRUT STEP. (Refer to figure 5A-9.)

5A-65. DESCRIPTION. The step is constructed of Uralite 3121 polyurethane casting, with a molded depression area, located in the top of the step. An adhesive-backed "Walkway" material with rough surface is pressed into the depressed area of the strut.

5A-66. REMOVAL.

NOTE

Step is bonded to gear spring with Uralite 3121 or 3M EC-2216 adhesive.

- Using a heat gun, heat step at a temperature of 200°-250° F, until step material becomes pliable.
- Using a sharp knife, remove step material down to the metal strut.
- Clean off remaining step material with a wire wheel and sandpaper. Leave surface slightly rough or abraded. Clean oil and grease from strut with solvent, wipe off excess solvent with dry cloth and let surface dry.
- Apply zinc chromate, primer - green or yellow to cleaned area on struts. Dry film thickness to be .0003 to .0005 inch.

5A-67. INSTALLATION.

- Jack aircraft in accordance with procedures outlined in Section 2 of this manual.

b. Mark position of removed step so new step will be installed in approximately the same position on the strut.

c. Check that bonding surfaces are clean and thoroughly dry.

d. Mix adhesive (Uralite 3121 or 3M EC-2216 per manufacturer's instructions. Note pot life.

e. Spread a coat of mixed adhesive on bonding surfaces of strut and step; install step on strut.

NOTE

Top of strut should be parallel to the ground ($\pm 5^\circ$) when gear is in down position.

f. Cycle landing gear to check clearance of step in tunnel.

g. Form a small fillet of adhesive at all edges of bonding surfaces. Remove excess adhesive.

h. Remove aircraft from jacks.

i. Allow adhesive to thoroughly cure according to manufacturer's recommendations before flexing gear spring or applying loads to step.

j. Paint gear spring and step after curing is completed.

5A-68. NOSE GEAR SYSTEM.

5A-69. DESCRIPTION. The nose gear consists of a pneumatic shock assembly, mounted in a trunion assembly, a steering arm and bungee, shimmy dampener, nose wheel, tire and tube, hub cap, bearing, seals and a double-acting hydraulic actuator for extension and retraction. A claw-like hook on the actuator serves as a downlock for the nose gear.

5A-70. OPERATION. The nose gear shock strut is pivoted just forward of the firewall. Retraction and extension of the nose gear is accomplished by a double-acting hydraulic cylinder, the forward end of which contains the nose gear downlock. Initial action of the cylinder disengages the downlock before retraction begins. Nose gear doors are mechanically closed as the nose gear retracts. As the nose gear extends, the doors are mechanically opened.

5A-71. TROUBLE SHOOTING. Refer to the nose gear system trouble shooting chart in Section 5.

5A-72. REMOVAL OF NOSE GEAR ASSEMBLY. Refer to applicable paragraphs in Section 5, outlining nose gear removal, disassembly, inspection and repair, reassembly and installation, disregarding the installation step regarding rigging of the retractable step.

5A-73. SHIMMY DAMPENER. Refer to applicable paragraphs in Section 5 outlining description, removal, disassembly, inspection, repair and reassembly of the shimmy dampener.

5A-74. TORQUE LINKS. Refer to applicable paragraphs in Section 5 outlining removal of torque links and squat switch.

5A-75. SQUAT SWITCH. Refer to applicable paragraphs in Section 5 outlining removal and installation of torque links for squat switch removal.

MODEL 210 & T210 SERIES SERVICE MANUAL

5A-76. NOSE GEAR DOWNLOCK MECHANISM.

Refer to applicable paragraphs in Section 5 outlining description, removal, disassembly, inspection, repair and reassembly of the nose gear actuator.

5A-77. NOSE GEAR ACTUATOR. Refer to applicable paragraphs in Section 5 outlining description, removal, disassembly, inspection, repair and reassembly of the nose gear actuator.

5A-78. NOSE GEAR DOOR SYSTEM. (Refer to figure 5A-13.)

5A-79. DESCRIPTION. The nose gear door system consists of a right and left forward door, actuated by push-pull rods and a torque tube assembly. The aft doors are attached to the torque tube assembly with springs.

5A-80. REMOVAL AND INSTALLATION. (Refer to figure 5A-13.)

- a. Remove hinge bolts, nuts, washers and bushings.
- b. Remove nuts from push-pull rods and remove forward doors.
- c. Disconnect spring from aft door eyebolt, and remove aft doors.
- d. Reverse preceding steps to install nose gear doors.

NOTE

Upon completion of installation, safety wire bolts (*) to clips (23).

NOTE

Check nose gear door-to-cowling clearance to be 0.12-inch to 0.15-inch on the left and right sides of the nose gear doors each time the turbine access door on turbocharged models is re-installed.

5A-81. NOSE WHEEL STEERING SYSTEM.

5A-82. DESCRIPTION. Refer to applicable paragraphs in Section 5, outlining description, removal, installation and rigging of the nose wheel steering system.

5A-83. RIGGING NOSE LANDING GEAR. (Refer to figure 5A-14.)

NOTE

Nose gear shock strut must be correctly inflated prior to rigging the nose gear. Refer to Section 1 of this manual for correct nose gear shock strut inflation pressure.

- a. Jack aircraft in accordance with procedures outlines in Section 2 of this manual.
- b. Actuator locking hooks (1) on the nose gear actuator shall completely engage downlock pins (2) without drag, and cross bar (3) shall rotate freely to indicate it is not bearing on either side of slot in rod end (4). Adjust rod end of actuator as re-

quired.

CAUTION

The piston rod is flattened near the threads to provide a wrench pad. Do not grip the piston rod with pliers, as tool marks will cut the O-ring seal in the actuator.

5A-84. RIGGING NOSE GEAR DOWN LIMIT SWITCH. (Refer to figure 5A-14.) The nose gear down limit switch is mounted on a tab which is a part of the bearing end (5) of the nose gear actuator. The switch is actuated by the right-hand actuator locking hook (1). Switch adjustment is accomplished by loosening the lock nut and either tightening or loosening the adjustment nut and re-tightening the lock nut against the tab behind the adjustment nut. Down limit switch is to be adjusted to the dimension stipulated in the figure.

5A-85. RIGGING NOSE GEAR UP LIMIT SWITCH. (Refer to figure 5A-14.) The nose gear up limit switch is mounted to a bracket, located in the left-hand forward area of the nose wheel well. The switch is activated by the left-hand arm of the bellcrank weld assembly. Switch adjustment is provided by slots in the switch mounting bracket. Up limit switch is to be adjusted to the dimension stipulated in the figure.

5A-86. RIGGING OF NOSE GEAR SQUAT SWITCH. (Refer to figure 5A-14.) The nose gear squat (safety) switch is mounted in a bracket, attached to the upper nose gear torque link. The switch is operated by an actuator, attached to the nose gear lower torque link. Adjust squat switch so that contacts close when nose gear strut is .12 to .25-inch from fully-extended position.

5A-87. RIGGING OF NOSE GEAR DOORS. (See figure 5A-13.) Nose gear door adjustments are accomplished by adjusting push-pull rod ends as required to cause the doors to close snugly. Doors must fair when the nose gear is fully retracted. Link rods are to be adjusted so that the doors, when in the open position, clear any part of the nose gear assembly by a minimum of 0.25-inch during retraction. Adjust stop bolts on stop assemblies (12) as required to contact arms (9) on bellcrank weld assembly (15) when forward nose gear doors are in FULL-OPEN position. Adjust barrel assemblies (4) as required to fair forward nose gear doors in closed position. Pack bearings (16) with MIL-G-21164 grease. Trim outboard edge of forward nose gear doors so that door-to-skin clearance is 0.18-inch minimum to 0.21-inch maximum. Safety wire bolts (*) to clips (23).

5A-88. FINAL LANDING GEAR SYSTEMS CHECK. After landing gear systems have been installed and rigged, prior to removal from jacks, cycle landing gear through 25 cycles using the system's emergency hand pump.

NOTE

Check fluid level in power pack reservoir frequently during purging and system checks.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5A-13. Nose Gear Doors

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5A-14. Rigging Nose Landing Gear (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5A-14. Rigging Nose Landing Gear (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

One of the 25 cycles shall consist of a downlock malfunction check, consisting of the following procedure, using a 28 volt DC, 60 amp electrical power supply.

- a. Pull hydraulic circuit breaker off.
- b. With gear in down and locked position, move gear selector handle to GEAR UP position and note actuation of main gear downlock hooks.
- c. As soon as left downlock hook is actuated to unlock the left gear, move gear selector handle back to GEAR DOWN position to simulate what would occur if the pilot were to select gear down before the gear was fully retracted. If downlock hooks do not lock the gear in the down position, check downlock system for misalignment.

NOTE

This malfunction check is in addition to the check used during the rigging procedure.

- d. Remove aircraft from jacks.

5A-89. NOSE WHEEL AND TIRE. Refer to applicable paragraphs in Section 5, outlining description, removal, disassembly, inspection, repair, reassembly and installation of nose wheels and tires.

5A-90. BRAKE SYSTEM. Refer to applicable paragraphs in Section 5 for description, trouble shooting, removal, disassembly, inspection, repair, reassembly, installation, checking lining wear, lining installation and bleeding of the brake system. Refer to the following note.

NOTE

Approximately 200 of the initial 1979 production model aircraft may be equipped with brake assemblies having 1/4-inch fittings in lieu of 3/16-inch fittings. Refer to the Model 210 Parts Catalog for replacement parts.

5A-91. BRAKE MASTER CYLINDER. (Refer to figure 5A-15.)

5A-92. DESCRIPTION. The brake master cylinders, located immediately forward of the pilot's rudder pedals, are actuated by applying pressure at the top of the rudder pedals. A small reservoir is incorporated into each master cylinder for the fluid supply. When dual brakes are installed, mechanical linkage permits the copilot pedals to operate the master cylinders.

5A-93. REMOVAL.

- a. Remove bleeder screw at wheel brake assembly and drain hydraulic fluid from brake cylinders.
- b. Remove front seats and rudder bar shield for access to brake master cylinders.
- c. Disconnect parking brake linkage and disconnect brake master cylinders from rudder pedals.
- d. Disconnect hydraulic hose from brake master cylinders and remove cylinders.
- e. Plug or cap hydraulic fittings, hose and lines to prevent entry of foreign material.

5A-94. DISASSEMBLY. (Refer to figure 5A-15.)

- a. Unscrew clevis (1) and jam nut (2).
- b. Remove filler plug (3).
- c. Unscrew cover (4) and remove up over piston (5).
- d. Remove piston (5) and spring (8).
- e. Remove packing (7) and back-up ring (6) from piston (5).

5A-95. INSPECTION AND REPAIR. (Refer to figure 5A-15.) Repair is limited to installation of new parts and cleaning. Use clean hydraulic fluid (MIL-H-5606) as a lubricant during reassembly of the cylinder. Replace packings and back-up rings. Filler plug (3) must be vented so pressure cannot build up during brake operation. Remove plug and drill 1/16-inch hole, 30° from vertical, if plug is not vented. Refer to view A-A for location of hole.

5A-96. REASSEMBLY. (Refer to figure 5A-15.)

- a. Install spring (8) into cylinder body (9).
- b. Install back-up ring (6) and packing (7) in groove of piston (5).
- c. Install piston (5) in cylinder body (9).
- d. Install cover (4) over piston (5) and screw cover into cylinder body (9).
- e. Install nut (2) and clevis (1).
- f. Install filler plug (3), making sure vent hole is open.

5A-97. INSTALLATION.

- a. Connect hydraulic hoses to brake master cylinders.
- b. Connect brake master cylinders to rudder pedals and connect parking brake linkage.
- c. Install rudder bar shield and install front seats.
- d. Install bleeder screw at wheel brake assembly and fill and bleed brake system in accordance with applicable paragraph in Section 5.

5A-96. PARKING BRAKE SYSTEM. Refer to applicable paragraphs in Section 5 for description, removal, installation, and inspection and repair of components of the parking brake system.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 5A-15. Master Brake Cylinder

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 6

AILERON CONTROL SYSTEM

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
AILERON CONTROL SYSTEM	1K16/6-1	Repair	1L1/6-10
Description	1K16/6-1	Ailerons	1L1/6-10
Trouble Shooting	1K16/6-1	Removal and Installation	1L1/6-10
Control Column	1K17/6-2	Repair	1L1/6-10
Description	1K17/6-2	Aileron Trim Tab	1L1/6-10
Removal and Installation	1K17/6-2	Removal and Installation ..	1L1/6-10
Repair	1K24/6-9	Adjustment	1L2/6-11
Bearing Roller Adjustment	1K24/6-9	Cables and Pulleys	1L2/6-11
Aileron Bellcrank	1K24/6-9	Removal and Installation ..	1L2/6-11
Removal	1K24/6-9	Rigging	1L2/6-11
Installation	1L1/6-10		

6-1. AILERON CONTROL SYSTEM. (Refer to figure 6-1.)

6-2. DESCRIPTION. The aileron control system is

6-3. TROUBLE SHOOTING.

comprised of push-pull rods, bellcranks, cables, pulleys, quadrants and components forward of the instrument panel, all of which link the control wheels to the ailerons.

NOTE

Due to remedy procedures in the following trouble shooting chart it may be necessary to rerig system. Refer to paragraph 6-17.

TROUBLE	PROBABLE CAUSE	REMEDY
LOST MOTION IN CONTROL WHEEL.	Loose control cables.	Check cable tension. Adjust cables to proper tension.
	Broken pulley or bracket, cable off pulley or worn rod end bearings.	Check visually. Replace worn or broken parts, install cables correctly.
RESISTANCE TO CONTROL WHEEL MOVEMENT.	Cables too tight.	Check cable tension. Adjust cables to proper tension.
	Pulleys binding or cable off.	Observe motion of the pulleys. Check cables visually. Replace defective pulleys. Install cables correctly.
	Bellcrank distorted or damaged.	Check visually. Replace defective bellcrank.
	Defective quadrant assembly.	Check visually. Replace defective quadrant.
	Clevis bolts in system too tight.	Check connections where used. Loosen, then tighten properly and safety.

MODEL 210 & T210 SERIES SERVICE MANUAL

6-3. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
CONTROL WHEELS NOT LEVEL WITHAILERONS NEUTRAL.	Improper adjustment of cables.	Refer to paragraph 6-17.
	Improper adjustment of aileron push-pull rods.	Adjust push-pull rods to obtain proper alignment.
DUAL CONTROL WHEELS NOT COORDINATED.	Cables improperly adjusted.	Refer to paragraph 6-17.
INCORRECTAILERON TRAVEL.	Push-pull rods not adjusted properly.	Refer to paragraph 6-17.
	Incorrect adjustment of travel stop bolts.	Refer to paragraph 6-17.

6-4. CONTROL COLUMN (Refer to figure 6-2.)

6-5: DESCRIPTION. (Refer to figure 6-2, Sheets 1 and 2.) Rotation of the control wheel rotates four bearing roller assemblies (15) on the end of the control wheel tube (14), which in turn, rotates a square control tube assembly (20) inside and extending from the control wheel tube (14). Attached to this square control tube assembly (20) is a quadrant (29) which operates the aileron system. This same arrangement is provided for both control wheels. Synchronization of the control wheels is obtained by the interconnect cable (32), interconnect cable turnbuckle (33), and interconnect cable adjustment terminals (28). The forward end of the square control tube assembly (20) is mounted in a bearing block (31) on firewall (34) and does not move fore-and-aft, but rotates with the control wheel. The four bearing roller assemblies (15) on the end of the control wheel tube (14) reduce friction as the control wheel is moved fore-and-aft for elevator system operation. A sleeve weld assembly (11), containing bearings which permit the control wheel tube (14) to rotate within it, is secured to the control wheel tube (14) by a sleeve and retaining ring in such a manner that it moves fore-and-aft with the control wheel tube. This movement allows the push-pull tube (22), attached to the sleeve weld assembly (11), to operate an elevator arm assembly (23), to which one elevator control cable (24) is attached. A torque tube (37) connects this elevator arm assembly (23) to the one on the opposite end of the torque tube (37), to which the other elevator cable is attached. When dual controls are installed, the copilot's control wheel is linked to the aileron and elevator control systems in the same manner as the pilot's control wheel.

6-6. REMOVAL AND INSTALLATION.

a. (Refer to figure 6-2, Sheet 3.) Slide cover (2) toward instrument panel to expose adapter (3). Remove bolts securing adapter (3) to control wheel tube (1).

- b. Disconnect electrical wiring to map light, mike switch, and electric trim switch at connector (4), if installed. Slide cover (2) off control wheel tube (1).
- c. (Refer to figure 6-2, Sheets 1 and 2.) Remove decorative cover from instrument panel.
- d. Remove screw securing glide plug (18) to control tube assembly (20) and remove glide plug (18) and glide (19).
- e. Disconnect push-pull tube (22) at sleeve weld assembly (11).
- f. Remove screws securing cover plate (5) at instrument panel.
- g. Using care, pull control wheel tube (14) aft and work assembly out through instrument panel.


NOTE

To ease removal of control wheel tube (14), snap rings (7) may be removed from their locking grooves to allow sleeve weld assembly (11) additional movement.

If removal of control tube assembly (20) or quadrant (29) is necessary, proceed to step "h."

- h. Remove safety wire and relieve direct cable tension at turnbuckles (Index 5, figure 6-1).
 - i. Remove safety wire, relieve interconnect cable turnbuckle (33) tension, and remove cables from quadrant (29).
 - j. Remove safety wire and remove roll pin (25) through quadrant (29) and control tube assembly (20).
 - k. Remove pin, nut (30), and washer from control tube assembly (20) protruding through bearing block (31) on forward side of firewall (34).
 - l. Using care, pull control tube assembly (20) aft and remove quadrant (29).
 - m. Reverse the preceding steps for reinstallation.
- Rig aileron, interconnect and elevator control systems

MODEL 210 & T210 SERIES SERVICE MANUAL



- 1. Bracket
- 2. Pulley
- 3. Cable Guard
- 4. Cable (Direct)
- 5. Turnbuckle (Direct Cable)
- 6. Bushing
- 7. Cable (Carry-Thru)
- 8. Turnbuckle (carry-Thru Cable)
- 9. Pivot Bolt

- 10. Upper Wing Skin
- 11. Upper Support
- 12. Brass Washer
- 13. Bushing
- 14. Needle Bearing
- 15. Travel Stop Bolt
- 16. Push-Pull Rod
- 17. Lower Support
- 18. Bellcrank

CAUTION

MAINTAIN SPECIFIED CONTROL
CABLE TENSION

CABLE TENSION:
40 LBS ± 10 LBS ON AILERON CARRY-
THRU CABLE (AT AVERAGE TEMPER-
ATURE FOR THE AREA.)
REFER TO FIGURE 1-1 FOR TRAVEL.

Figure 6-1. Aileron Control System

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 6-2. Control Column Installation (Sheet 1 of 5)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 6-2. Control Column Installation (Sheet 2 of 5)


MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES

Plugs (12 and 15) are used when mike switch (11) and electric trim switch (14) are not used.

* NOTE


TORQUE BOLT TO 30 LB-IN.



- | | |
|-----------------------|--------------------------------------|
| 1. Control Wheel Tube | 13. Insulator |
| 2. Cover | 14. Electric Trim Switch |
| 3. Adapter | 15. Plug |
| 4. Connector | 16. Disengage Switch - Electric Trim |
| 5. Plate | 17. Disengage Switch - Autopilot |
| 6. Map Light Rheostat | 18. Switch Housing |
| 7. Lamp | 19. Knob |
| 8. Map Light Assembly | 20. Bearing Block |
| 9. Control Wheel | 21. Firewall |
| 10. Pad | 22. Guard Assembly |
| 11. Mike Switch | 23. Quadrant |
| 12. Plug | 24. Cover Strap |

Figure 6-2. Control Column Installation (Sheet 3 of 5)

MODEL 210 & T210 SERIES SERVICE MANUAL




- 1. Housing
- 2. Screw
- 3. Spacer
- 4. Connector - Socket
- 5. Cable Assembly
- 6. Washer
- 7. Nut
- 8. Sta-Strap
- 9. Bracket
- 10. Circuit Board
- 11. Control Tube
- 12. Map Light Rheostat
- 13. Transponder Identification
- 14. Pitch Sync
- 15. Control Wheel
- 16. Mike Switch
- 17. Go Around
- 18. Electric Trim Switch
- 19. Map Light Assembly
- 20. Knob
- 21. Trim Disengage
- 22. Auto Pilot Disengage
- 23. Cover

Thru 21064535 install screws (2), spacers (3), washers (6) and nuts (7) as shown. Do Not reverse direction of screws (2).

Detail B
BEGINNING WITH 21064536

Figure 6-2. Control Column Installation (Sheet 4 of 5)

MODEL 210 & T210 SERIES SERVICE MANUAL




1. Cable (Aileron Interconnect)
2. Clamp
3. Turnbuckle
4. Spacer
5. Bracket
6. Tube
7. Spring
8. Pulley
9. Strap
10. Rudder Bar
11. Bushing
12. Bolt
13. Fitting
14. Cable (Left Rudder)
15. Cable (Right Rudder)
16. Cable (Rudder Interconnect)
17. Cable Guard

NOTES

The aileron-rudder interconnect cables do not require adjustment. The cable slack is removed by the springs aft of the rudder bar attachment.

The 0.33" dimension shown applies only with the aileron and rudder controls in the neutral position.

Fitting (13) must be free to rotate with bolt (12) tightened.



Detail C

Figure 6-2. Control Column Installation (Sheet 5 of 5)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 6-3. Aileron Installation

in accordance with paragraphs 6-17 and Section 8 respectively. Safety turnbuckles and all other items previously safetied. Tighten nut (30) securing control tube assembly (20) to firewall snugly, then loosen nut to 0.030-inch maximum clearance between nut and bearing block, align cotter pin hole, and install pin.

6-7. REPAIR. Worn, damaged, or defective shafts, bearings, quadrants, cables, or other components should be replaced. Refer to Section 2 for lubrication requirements.

6-8. BEARING ROLLER ADJUSTMENT. (Refer to figure 6-2, Sheet 1.) Each bearing roller assembly (6) has an 0.062-inch eccentric adjustment, when installed, for aligning the control wheel tube (14) and push-pull tube (22) with the guide assembly (21). For alignment, proceed as follows:

- Remove control wheel assembly in accordance with paragraph 6-6.
- Install cover plate (5) backwards (bearings on aft side) and leave loose with instrument panel.

- Align control wheel tube (14) for free travel of push-pull tube (22) along full length of guide assembly (21).

- Center cover plate (5) over control wheel tube (14) and bearing roller assembly (6) and secure cover plate to instrument panel.

- Adjust each bearing roller assembly (6) to control wheel tube assembly (14), and tighten bearings in place.

- Remove cover plate (5) and reinstall with bearings facing forward.

6-9. AILERON BELLCRANK. (Refer to figure 6-1.)

6-10. REMOVAL.

- Remove access plate inboard of each bellcrank (18) on underside of wing.


- Remove safety wire and relieve cable tension at turnbuckles (5).

- Disconnect cables (4) and (7) from bellcrank (18).

- Disconnect push-pull rod (16) at bellcrank (18).

- Remove pivot bolts (9) securing bellcrank (18) to wing structure.

MODEL 210 & T210 SERIES SERVICE MANUAL



AVAILABLE FROM CESSNA PARTS DISTRIBUTION (CPD 2)
THROUGH CESSNA SERVICE STATIONS (TOOL NO. SE 716)

Figure 6-4. Inclinometer for Measuring Control Surface Travel

- f. Remove bellcrank through access opening, using care that bushing (13) is not dropped from bellcrank.

NOTE

Brass washers (12) may be used as shims between each end of bellcrank (18) and supports (11) and (17). Retain these brass washers (shims). Tape open ends of bellcrank (18) to prevent dust and dirt from entering bellcrank needle bearings (14).

6-11. INSTALLATION.

- Connect control cables (4 and 7) to bellcrank (18) prior to installing bellcrank.
- Place bushing (13) in bellcrank and position bellcrank in wing.
- Install brass washers (12) as required between upper and lower end of bellcrank and wing supports to shim out excess clearance.
- Install pivot bolt (9).
- Connect push-pull rod (16) to bellcrank (18).
- Rerig aileron system in accordance with paragraph 6-17, safety turnbuckles, and reinstall all items removed for access.

6-12. REPAIR. Repair of bellcranks consists of replacement of defective parts. If needle bearings are dirty or in need of lubrication, clean thoroughly and lubricate as outlined in Section 2.

6-13. AILERONS. (Refer to figure 6-3.)

6-14. REMOVAL AND INSTALLATION

- Remove access plate (4) and disconnect push-pull rod (5) at aileron.
- Remove wing tip for access to outboard hinge bolt.
- Run flaps to full down position for access to in-board hinge bolt.
- Remove hinge bolts (6) securing aileron and carefully remove aileron from wing.
- Reverse the preceding steps for reinstallation. Rig system, if necessary, in accordance with paragraph 6-17 and reinstall all items removed for access.

NOTE

If rigging was correct and push-pull rod adjustment was not disturbed, it should not be necessary to rerig system.

6-15. REPAIR. Aileron repair and static balance may be accomplished in accordance with instructions outlined in Section 18. Before installation, ensure balance weights and hinges are securely attached.

6-16. AILERON TRIM TAB. (Refer to figure 6-3.)

6-17. REMOVAL AND INSTALLATION.

- Remove screws on lower side of trim tab (1).
- Drill out rivets on upper side of trim tab (1) and remove tab.
- Reverse the preceding steps for reinstallation.

MODEL 210 & T210 SERIES SERVICE MANUAL

6-18. **ADJUSTMENT.** Adjustment is accomplished by loosening the screws, shifting tab trailing edge up to correct for a wing-heavy condition or down to correct for a wing-light condition. Divide correction equally on both tabs. When installing a new wing or aileron, set tab in neutral and adjust as necessary after flight test.

6-19. **CABLES AND PULLEYS.** (Refer to figure 6-1.)

6-20. **REMOVAL AND INSTALLATION.**

- a. Remove access plates, wing root fairings and upholstery as required.
- b. Remove safety wire and relieve cable tension at turnbuckles (5 and 8).
- c. Disconnect cables from aileron bellcranks (18) and quadrants (Index 29, figure 6-2, Sheet 2).
- d. Remove cable guards and pulleys as necessary to work cables free from aircraft.

NOTE

To ease routing of cables during reinstallation, a length of wire may be attached to end of the cable before being withdrawn from aircraft. Leave wire in place, routed through structure; then attach the cable being installed, and use it to pull cable into position.

- e. Reverse the preceding steps for reinstallation.
- f. After cables are routed in position, install pulleys and cable guards. Ensure cables are positioned in pulley grooves before installing guards.
- g. Rerig aileron system in accordance with paragraph 6-17, safety turnbuckles (5) and (8), and install access plates, fairings, and upholstery removed in step "a."

6-17. **RIGGING.**

- a. (Refer to figure 6-1.) Remove access plates and upholstery as required.

b. Remove safety wire and relieve all cable tension at turnbuckles (5) and (8).

c. Disconnect push-pull rods (16) at bellcranks (18).

d. (Refer to figure 6-2, Sheet 2.) Adjust turnbuckle (33) and interconnect cable adjustment terminal (28) nuts on interconnect cable (32) to remove slack, acquire proper tension (30 pounds, \pm 10 pounds), and position both control wheels (1) level (synchronized).

e. Tape a bar across both control wheels to hold them in neutral position.

f. (Refer to figure 6-1.) Adjust direct cable turnbuckles (5) and carry-thru cable turnbuckle (8) to position bellcranks (18) approximately in neutral while maintaining 40 ± 10 pounds tension on carry-thru cable (7).

f. Streamline ailerons with reference to flaps (flaps full UP and disregarding aileron trim tabs), then adjust push-pull rods (16) to fit and install.

g. With ailerons streamlined, mount an inclinometer on trailing edge of aileron and set pointer to 0° .

NOTE

An inclinometer for measuring control surface travel is available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations. Refer to figure 6-4.

- h. Remove bar from control wheels and adjust travel stop bolts (15) to degree of travel specified in Figure 1-1.
- i. Ensure all turnbuckles (5) and (8) are safetied, all cables and cable guards are properly installed, and all nuts are tight, and replace all parts removed for access.

WARNING

Be sure ailerons move in correct direction when operated by the control wheels.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 7

WING FLAP CONTROL SYSTEM

TABLE OF CONTENTS	Page No. Aerofiche/Mannual
WING FLAP CONTROL SYSTEM	1L3/7-1
Description	1L3/7-1
Operational Check	1L3/7-1
Trouble Shooting	1L4/7-2
Flap Motor, Transmission and	
Actuator Assembly	1L5/7-3
Removal and Installation	1L5/7-3
Repair	1L5/7-3
Flap Control Lever	1L5/7-3
Removal and Installation	1L5/7-3
Drive Pulleys	1L5/7-3
Removal and Installation	1L5/7-3
Repair	1L9/7-7
Bellcranks	1L9/7-7
Removal and Installation	1L9/7-7
Repair	1L9/7-7
Flaps	1L9/7-7
Removal and Installation	1L9/7-7
Repair	1L9/7-7
Cables and Pulleys	1L9/7-7
Removal and Installation	1L9/7-7
Rigging	1L9/7-7

7-1. WING FLAP CONTROL SYSTEM. (Refer to figure 7-1.)

7-2. DESCRIPTION. The wing flap control system consists of an electric motor and transmission assembly, drive pulleys, synchronizing push-pull tubes, bellcranks, push-pull rods, cables, pulleys and a follow-up control. Power from the motor and transmission assembly is transmitted to the flaps by a system of drive pulleys, cables and synchronizing tubes. Electrical power to the motor is controlled by two microswitches mounted on a "floating" arm, a control lever and a follow-up control. As the control lever is moved to the desired flap setting, a switch is tripped actuating the flap motor. As the flaps move, the floating arm is rotated by the follow-up control until the active switch clears the control lever cam, breaking the circuit. To reverse the direction of flap travel, the control lever is moved in the opposite direction. When the control lever cam contacts the second switch the flap motor is energized in the opposite direction. Likewise, the follow-up control moves the floating arm until the second switch is clear of the control lever cam.

7-3. OPERATIONAL CHECK.

- a. Operate flaps through their full range of travel,

observing for uneven or jumpy motion, binding, and lost motion in the system. Ensure flaps are moving together through their full range of travel.

- b. Check for positive shut-off of motor at the flap travel extremes, FLAP MOTOR MUST STOP OR DAMAGE WILL RESULT.

- c. Check wing flaps for sluggish operation on the ground with engine running.

- d. With flaps full UP, mount an inclinometer on one flap and set to 0°. Lower flaps to full DOWN position and check flap angle as specified in figure 1-1. Check approximate mid-range percentage setting against degrees as indicated on inclinometer. Repeat the same procedure for the opposite flap.

NOTE

An inclinometer for measuring control surface travel is available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations. Refer to Section 6.

- e. Remove access plates and attempt to rock drive pulleys and bellcranks to check for bearing wear.
- f. Inspect flap rollers and tracks for evidence of binding and defective parts.

MODEL 210 & T210 SERIES SERVICE MANUAL

7-4. TROUBLE SHOOTING.

NOTE

Due to remedy procedures in the following trouble shooting chart, it may be necessary to rerig system. Refer to paragraph 7-21.

TROUBLE	PROBABLE CAUSE	REMEDY
BOTH FLAPS FAIL TO MOVE.	Popped circuit breaker.	Reset and check continuity. Replace breaker if defective.
	Defective switch.	Place jumper across switch. Replace switch if defective.
	Defective motor.	Remove and bench test. Replace motor if defective.
	Broken or disconnected wires.	Run continuity check of wiring. Connect or repair wiring as necessary.
	Disconnected or defective transmission.	Connect transmission. Remove, bench test and replace transmission if defective.
	Defective limit switch.	Check continuity of switches. Replace switches found defective.
	Follow-up control disconnected or slipping.	Secure control or replace if defective.
BINDING IN SYSTEM AS FLAPS ARE RAISED AND LOWERED.	Cables not riding on pulleys.	Open access plates and observe pulleys. Route cables correctly over pulleys.
	Bind in drive pulleys.	Check drive pulleys in motion. Replace drive pulleys found defective.
	Broken or binding pulleys.	Check pulleys for free rotation or breaks. Replace defective pulleys.
	Frayed cable.	Check condition of cables. Replace defective cables.
	Flaps binding on tracks.	Observe flap tracks and rollers. Replace defective parts.
LEFT FLAP FAILS TO MOVE.	Disconnected or broken cable.	Check cable tension. Connect or replace cable.
	Disconnected push-pull rod.	Attach push-pull rod.
FLAPS FAIL TO RETRACT.	Disconnected or defective UP operating switch.	Check continuity of switch. Connect or replace switch.

MODEL 210 & T210 SERIES SERVICE MANUAL

7-4. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
FLAPS FAIL TO EXTEND.	Disconnected or defective DOWN operating switch.	Check continuity of switch. Connect or replace switch.
INCORRECT FLAP TRAVEL.	Incorrect rigging.	Refer to paragraph 7-21.
	Defective limit switch.	Check continuity of switches. Replace switches found defective.

7-5. FLAP MOTOR, TRANSMISSION AND ACTUATOR ASSEMBLY. (Refer to figure 7-1, sheet 2.)

7-6. REMOVAL AND INSTALLATION.

- a. Run flaps to full DOWN position.
- b. Disconnect battery cables at the battery and insulate cable terminals as a safety precaution.
- c. Remove access plates from under actuator assembly on left wing and adjacent to the drive pulleys on both wings.
- d. Relieve cable tension at turnbuckles (indexes 6, 7, 8 and 9, sheet 1.)

NOTE

Remove motor (3), transmission (18), actuator assembly (17) and lower support as a unit.

- e. Disconnect cables from actuator cable drive assembly (17).
- f. Remove bolt (11) securing follow-up control bell-crank (10) to actuator assembly (17). Retain spacer (9).
- g. Disconnect flap motor and microswitch wiring and tag for reference on reinstallation.
- h. Remove bolts (12 and 20) securing lower support to upper support. Retain spacer (9), bushing (19) and washers.
- i. Remove bolt (21) securing motor and transmission assembly to upper support (7).

NOTE

Although not required, nuts (2) securing motor (3) to transmission (18) may be removed to swing motor clear of working area for easier removal of bolt (21).

- j. Using care, work assembly out of wing through access opening.
- k. Reverse the preceding steps for reinstallation. Rig system in accordance with paragraph 7-21, safety turnbuckles and reinstall all items removed for access.

7-7. REPAIR. Repair consists of replacement of motor, transmission or coupling. Lubricate in accordance with Section 2.

7-8. FLAP CONTROL LEVER. (Refer to figure 7-1, sheet 2.)

7-9. REMOVAL AND INSTALLATION.

- a. Remove follow-up control (8) from switch mounting arm (30).
- b. Remove flap operating switches (28 and 29) from switch mounting arm (30). DO NOT disconnect electrical wiring at switches.
- c. Remove knob (27) from control lever (26).
- d. Remove remaining items by removing bolt (32). Use care not to drop parts into tunnel area.
- e. Reverse the preceding steps for reinstallation. Do not overtighten bolt (32) causing lever (26) to bind. Rig system in accordance with paragraph 7-21.


7-10. DRIVE PULLEYS. (Refer to figure 7-1, sheet 1.)

7-11. REMOVAL AND INSTALLATION.

- a. Run flaps to full DOWN position.
- b. Remove access plates adjacent to drive pulley (11).
- c. Relieve cable tension at turnbuckles (7 and 8) for removal of left hand drive pulley and relieve cable tension at turnbuckles (6 and 9) for removal of right hand drive pulley.
- d. Remove bolt securing flap push-pull rod (17) to drive pulley.
- e. Remove bolt securing synchronizing push-pull tube (13) to drive pulley.
- f. Remove cable guards (14).
- g. Remove cable lock pins (16) and disconnect cables (10 and 18) from drive pulley. Tag cables for reference on reinstallation.
- h. Remove pivot bolt (15) attaching drive pulley to wing structure.
- i. Remove drive pulley (11) through access opening, using care not to drop bushing (12). Retain brass washer between drive pulley and wing structure. Tape open ends of pulley to protect bearings.
- j. Reverse the preceding steps for reinstallation. Rig system in accordance with paragraph 7-21, safety turnbuckles and reinstall all items removed for access.

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE
Brass washer may be used between drive pulley and wing structure.



- | | |
|-------------------------------|----------------------------------|
| 1. Cable Guard | 13. Synchronizing Push-Pull Tube |
| 2. Pulley | 14. Cable Guard |
| 3. Bracket | 15. Pivot Bolt |
| 4. Bushing | 16. Lock Pin |
| 5. Spacer | 17. Inboard Push-Pull Rod |
| 6. Turnbuckle (Right Direct) | 18. Cable (Retract) |
| 7. Turnbuckle (Left Direct) | 19. Pivot Bolt |
| 8. Turnbuckle (Left Retract) | 20. Bushing |
| 9. Turnbuckle (Right Retract) | 21. Bellcrank |
| 10. Cable (Direct) | 22. Bolt |
| 11. Drive Pulley | 23. Outboard Push-Pull Rod |
| 12. Bushing | 24. Bolt |
| | 25. Brass Washer |

CAUTION

MAINTAIN SPECIFIED CONTROL CABLE TENSION

CABLE TENSION:
50 LBS ± 10 LBS (AT THE AVERAGE TEMPERATURE FOR THE AREA.)
REFER TO FIGURE 1-1 FOR TRAVEL.

Figure 7-1. Wing Flap Control System (Sheet 1 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 7-1. Wing Flap Control System (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 7-1. Wing Flap Control System (Sheet 3 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL

7-12. **REPAIR.** Repair is limited to replacement of bearings. Cracked, bent or excessively worn drive pulleys must be replaced. Lubricate drive pulley bearings as outlined in Section 2.

7-13. **BELLCRANKS.** (Refer to figure 7-1, sheet 1.)

7-14. **REMOVAL AND INSTALLATION.**

- a. Run flaps to full DOWN position.
- b. Remove access plates adjacent to bellcrank (21).
- c. Remove bolt (24) securing outboard push-pull rod (23) to bellcrank (21).
- d. Remove bellcrank pivot bolt (19) and position bellcrank as necessary to expose synchronizing push-pull tube attach point.
- e. Remove bolt (22) securing synchronizing push-pull tube (13) to bellcrank (21) and work bellcrank out through access opening using care not to drop bushing (20). Tape open ends of bellcrank to protect needle bearings.

NOTE

To remove synchronizing push-pull tube (13), disconnect synchronizing push-pull tube at bellcrank (21) and drive pulley (11). Position synchronizing push-pull tube through lightening holes until removal is possible through access opening.

f. Reverse the preceding steps for reinstallation. If the outboard push-pull rod (23) and synchronizing push-pull tube (13) adjustments are not disturbed, rerigging of the system should not be necessary. Check flap travel and rig in accordance with paragraph 7-21, if necessary, and reinstall all items removed for access.

7-15. **REPAIR.** Repair is limited to replacement of bearings. Cracked, bent or excessively worn bellcranks must be replaced. Lubricate in accordance with Section 2.

7-16. **FLAPS.** (Refer to figure 7-2.)

7-17. **REMOVAL AND INSTALLATION**

- a. Run flaps to full DOWN position.
- b. Remove access plate (7) outboard of the inboard flap track.
- c. Disconnect push-pull rod (3) at both flap attach points.
- d. Remove bolt (6) at each aft flap track, pull flap aft and remove remaining bolts. As flap is removed from wing, all washers, rollers and bushings will fall free. Retain these for reinstallation.
- e. If the push-pull rod adjustment is not disturbed, rerigging of the system should not be necessary. Check flap travel and rig in accordance with paragraph 7-21, if necessary.

7-18. **REPAIR.** Flap repair may be accomplished in accordance with instructions outlined in Section 18.

7-19. **CABLES AND PULLEYS.** (Refer to figure 7-1, sheet 1.)

7-20. **REMOVAL AND INSTALLATION.**

- a. Remove access plates, fairings and upholstery as required for access.

- b. Relieve cable tension at turnbuckles (6, 7, 8 and 9).
- c. Disconnect cables at drive pulleys (11).
- d. Disconnect cables at actuator cable drive assembly (index 17, sheet 2).
- e. Remove cable guards and pulleys as necessary to work cables free of aircraft.

NOTE

To ease routing of cables, a length of wire may be attached to the end of cable being withdrawn from the aircraft. Leave wire in place, routed through structure; then attach the cable being installed and use wire to pull cable into position.

- f. Reverse preceding steps for reinstallation.
- g. After cable is routed in position, install pulleys and cable guards. Ensure cable is positioned in pulley grooves before installing guards.
- h. Rerig flap system in accordance with paragraph 7-21, safety turnbuckles, and reinstall all items removed in step "a."

7-21. **RIGGING.**

- a. (Refer to figure 7-1, sheet 1.) Using care, run flaps to full DOWN position.
- b. Disconnect cables at turnbuckles (6, 7, 8, and 9).
- c. Disconnect inboard push-pull rods (17) at drive pulleys (11).
- d. Disconnect outboard push-pull rods (23) at bellcranks (21).
- e. Disconnect synchronizing push-pull tubes (13) from drive pulleys (11) and bellcranks (21).
- f. If cables are being replaced with drive pulleys (11) installed, rotate drive pulleys beyond their normal range of travel to permit cable attachment. If drive pulleys are not installed, it may be easier to attach the cables prior to installing the drive pulleys in the wings.
- g. Attach the 1/8" direct cable to the forward side of drive pulleys and the 3/32" retract cable to the aft side of drive pulleys. (Refer to figure 7-3.)
- h. Adjust synchronizing push-pull tubes (13) to 41.87" between centers of rod end holes, tighten jamnuts and install.
- i. Adjust inboard push-pull rods (17) to 10.81" and outboard push-pull rods (23) to 10.39" between centers of rod end holes, tighten jamnuts, and install. These dimensions may vary in order to obtain snug fitting of flap in "UP" position.
- j. Ensure cables are properly routed and in pulley grooves, and adjust turnbuckles to obtain specified cable tension.
- k. (Refer to figure 7-1, Sheets 2 and 3.)

NOTE

The ball screw assembly does not have a free-wheeling feature. Therefore, the flap actuator motor **MUST** be shut-off at travel extremes or structural deformation will occur.

Carefully run flaps to full UP position and adjust.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 7-2. Flap Installation

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 7-3. Flap System Schematic

up-limit switch (13) to operate and shut-off motor at degree of travel specified in figure 1-1.

1. Mount an inclinometer on one flap and set to 0°.

NOTE

An inclinometer for measuring control surface travel is available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations. Refer to Section 6.

m. Carefully run flaps to DOWN position and adjust down-limit switch (16) to operate and shut off motor to 0.12 +.03 -.03-inches between actuator cable drive assembly (17) and transmission as illustrated in VIEW A-A.

n. Operate control lever (26) and run flaps to full UP position.

o. Disconnect follow-up control (8) at switch mounting arm (30).

p. Without moving control lever (26), move switch mounting arm (30) until cam (25) is centered between flaps down and up operating switches (28) and (29). Ensure switches are centered in their respective adjustment slots prior to centering cam (25).

q. Adjust flaps down operating switch (28) in slotted holes until roller just clears cam (25) and secure. This adjustment should provide flaps down operation to 10° + 0° - 2° and 20° + 2° - 2°. If not, readjust flaps down operating switch (28) as necessary.

NOTE

The flaps must NEVER exceed 10° when the control lever (26) is moved from the 0° to 10° position.

r. Adjust flaps up operating switch (29) in slotted holes to 0.062-inch clearance between switch roller and cam (25) when the flaps down operating switch (28) has just opened in the 10° + 0° - 2° and 20° + 2° - 2° position.

NOTE

Flap travel on UP cycle may deviate a maximum of 4° from indicated position.

s. Turn master switch ON and run flaps through several cycles, stopping at various mid-range settings and checking that cable tension is within limits. Retract cable tension may increase to 90 pounds when flaps are fully retracted.

NOTE

Since flap rollers may not bottom in tracks with flaps fully extended, some free play may be noticed in this position.

t. Check all rod ends and clevis ends for sufficient thread engagement and that all jamnuts are tight, and reinstall all items removed for access.

u. Flight test aircraft and check that follow-up control does not cause automatic cycling of flaps. If cycling occurs, readjust operating switches as necessary per steps "q" and "r".

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 8

ELEVATOR CONTROL SYSTEM

TABLE OF CONTENTS	Page No. Aerofiche/Manual	
ELEVATOR CONTROL SYSTEM	2A2/8-1	Bellcrank 2A3/8-2
Description	2A2/8-1	Removal and Installation. 2A7/8-6
Trouble Shooting	2A2/8-1	Arm Assembly 2A7/8-6
Control Column	2A3/8-2	Removal and Installation. 2A7/8-6
Elevators	2A3/8-2	Cables and Pulleys 2A7/8-6
Removal and Installation.	2A3/8-2	Removal and Installation 2A7/8-6
Repair.	2A3/8-2	Rigging 2A8/8-7

8-1. ELEVATOR CONTROL SYSTEM. (Refer to figure 8-1.)

8-2. DESCRIPTION. The elevators are operated by power transmitted through fore-and-aft movement of the pilot or copilot control wheels. The system is comprised of control columns, an elevator torque

tube, cables and pulleys. The elevator control cables, at their aft ends, are attached to a bellcrank mounted on a bulkhead in the tailcone. A push-pull tube connects this bellcrank to the elevator arm assembly, installed between the elevators. An elevator trim tab is installed in the trailing edge of the right elevator and is described in Section 9.

8-3. TROUBLE SHOOTING.

NOTE

Due to remedy procedures in the following trouble shooting chart, it may be necessary to rerig system. Refer to paragraph 8-14.

TROUBLE	PROBABLE CAUSE	REMEDY
NO RESPONSE TO CONTROL WHEEL FORE-AND-AFT MOVEMENT.	Forward or aft end of push-pull tube disconnected.	Check visually. Attach push-pull tube correctly.
	Cables disconnected.	Check visually. Attach cables and rig system in accordance with paragraph 8-14.

MODEL 210 & T210 SERIES SERVICE MANUAL

8-3. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
BINDING OR JUMPY MOTION FELT IN MOVEMENT OF ELEVATOR SYSTEM.	Defective bellcrank or arm assembly pivot bearings or push-pull tube attach bearings.	Move bellcrank or arm to check for play or binding. Disconnect push-pull tube and check that bearings rotate freely. Replace defective parts.
	Cables slack.	Check and adjust to tension specified in figure 8-1.
	Cables not riding correctly on pulleys.	Check visually. Route cables correctly over pulleys.
	Defective control column bearing rollers.	Check visually. Replace defective rollers.
	Defective control column torque tube bearings.	Disconnect necessary items and check that bearings rotate freely. Replace defective bearing.
	Control guide on aft end of control square tube adjusted too tightly.	Loosen screw and tapered plug in end of control tube enough to eliminate binding.
	Defective elevator hinges.	Disconnect push-pull tube and move elevators by hand. Replace defective hinges.
	Defective pulleys or cable guards.	Check visually. Replace defective parts and install guards properly.
ELEVATORS FAIL TO ATTAIN PRESCRIBED TRAVEL.	Stops incorrectly set.	Rig in accordance with paragraph 8-14.
	Cables tightened unevenly.	Rig in accordance with paragraph 8-14.
	Interference at instrument panel.	Rig in accordance with paragraph 8-14.

8-4. CONTROL COLUMN.

Section 6 outlines removal, installation and repair of control column.

8-5. ELEVATORS. (Refer to figure 8-2.)

8-6. REMOVAL AND INSTALLATION.

- a. Remove stinger.
- b. Disconnect trim tab push-pull tube at tab actuator. (Refer to Section 9.)

NOTE

If trim system is not moved and actuator screw is not turned, rerigging of trim system should not be necessary after reinstallation of elevator.

- c. Remove bolts (13) securing torque tubes (7) to arm assembly (8). A heat gun may be required to soften epoxy adhesive on bolt (13).

- d. Remove bolts (6) from elevator hinges (5).

- e. Using care, remove elevator.

- f. To remove left elevator use same procedure, omitting step "b".

- g. Reverse the preceding steps for reinstallation.

- h. Set right hand elevator maintaining 0.18-inch dimension specified in figure 8-2.

- i. When reinstalling bolts (13) install a washer under the head of each bolt and under each nut. Apply Adhesive EA-9309 from Hysol Division, Dexter Corp., or its equivalent, only to the shanks of bolts (13). Wipe off excess adhesive after installation.

8-7. REPAIR. Repair may be accomplished as outlined in Section 18. Hinge bearings may be replaced as necessary. If repair has affected static balance, check and rebalance as required.

8-8. BELLCRANK. (Refer to figure 8-3.)

8-9. REMOVAL AND INSTALLATION.

- a. Remove access plate below bellcrank on tailcone.

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 8-1. Elevator Control System

MODEL 210 & T210 SERIES SERVICE MANUAL



1. Trim Tab
2. Right Elevator
3. Left Elevator
4. Balance Weight
5. Hinge Assembly
6. Bolt
7. Torque Tube
8. Arm Assembly
9. Needle Bearing
10. Bolt
11. Push-Pull Tube
12. Pivot Bolt
13. Bolt

Figure 8-2. Elevator Installation

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

A turnbuckle (4) in the down-spring cable is provided for adjustment. With elevators in full DOWN position, adjust turnbuckle to obtain an overall down-spring length of 6.37 inches.

1. Bracket
2. Spacer
3. Down-Spring
4. Turnbuckle
5. Pulley
6. Cable Guard
7. Down-Spring Cable
8. Stop Block
9. Bracket
10. Pivot Bolt
11. Push-Pull Tube
12. Bolt
13. Bearing
14. Bellcrank
15. Link Assembly
16. Link
17. Turnbuckle
18. Elevator DOWN Cable
19. Elevator UP Cable




Figure 8-3. Elevator Bellcrank Installation

NOTE

Holes are drilled off center in bellcrank stops to provide elevator travel adjustments. 90° rotation of bellcrank stop provides approximately 1° of elevator travel.




Figure 8-4. Elevator Bellcrank Travel Stop Adjustment

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 8-5. Control Column Neutral Position Rigging Tool

CAUTION

Position a support stand under tail tie-down ring to prevent the tailcone from dropping while working inside.

b. Remove safety wire, relieve cable tension at turnbuckles (17) and disconnect turnbuckle eyes at bellcrank links (16).

c. Remove safety wire, relieve cable tension at turnbuckle (4) and disconnect cable (7) at link assembly (15).

d. Remove bolt (12) securing push-pull tube (11) to bellcrank (14).

e. Remove pivot bolt (10) attaching bellcrank (14) to brackets (9) and remove bellcrank.

f. Reverse the preceding steps for reinstallation. Rig system in accordance with paragraph 8-14, safety turnbuckles and reinstall all items removed for access.

8-10. ARM ASSEMBLY. (Refer to figure 8-2.)

8-11. REMOVAL AND INSTALLATION.

a. Remove stinger.

b. Remove bolt (10) securing push-pull tube (11) to arm assembly (8).

c. Remove bolts (13) securing elevator torque tubes (7) to arm assembly (8). A heat gun may be required to soften epoxy adhesive on bolts (13).

d. Remove pivot bolt (12) securing arm assembly (8) and slide assembly from between elevator torque tubes.

e. Reverse the preceding steps for reinstallation and reinstall all items removed for access.

f. Set right hand elevator maintaining 0.18" dimension specified in figure 8-2.

g. When reinstalling bolts (13) install a washer under the head of each bolt and under each nut. Apply Adhesive EA-9309 from Hysol Division, Dexter Corp., or its equivalent, only to the shanks of bolts (13). Wipe off excess adhesive after installation.

8-12. CABLES AND PULLEYS. (Refer to figure 8-1.)

8-13. REMOVAL AND INSTALLATION.

CAUTION

Position a support stand under tail tie-down ring to prevent the tailcone from dropping while working inside.

a. Remove seats, upholstery and access plates as necessary.

b. Remove safety wire and relieve cable tension at turnbuckles (9).

c. Disconnect cables at control column arm assemblies (3) and disconnect balance weight (5).

d. Disconnect cables at bellcrank links (index 16, figure 8-3).

e. Remove fairleads, cable guards and pulleys as necessary to work cables free of aircraft.

NOTE

To ease routing of cables, a length of wire may be attached to the end of cable being withdrawn from aircraft. Leave wire in place, routed through structure; then attach the cable being installed and pull cable into position.

MODEL 210 & T210 SERIES SERVICE MANUAL

- f. Reverse the preceding steps for reinstallation.
- g. After cables are routed in position, install fair-
leads, pulleys and cable guards. Ensure cables are
positioned in pulley grooves before installing guards.
- h. Re-rig system in accordance with paragraph
8-14, safety turnbuckles and reinstall all items re-
moved in step "a".

8-14. RIGGING. (Refer to figure 8-3.)

CAUTION

Position a support stand under tail tie-down
ring to prevent the tailcone from dropping
while working inside.

- a. Lock control column in neutral position using
neutral rigging tool (Index 2, figure 8-5).
- b. Adjust turnbuckles (17) equally to streamline
LEFT elevator with horizontal stabilizer (RIGHT
elevator will be higher than the left as illustrated in
figure 8-2) and to obtain 30±10 lbs cable tension.
Safety turnbuckles.

NOTE

Disregard counterweight areas of elevators
when streamlining. These areas are con-
toured to be streamlined at cruising speed
(elevators approximately 3° down).

- c. With LEFT elevator streamlined, mount an in-
clinometer on elevator and set to 0°.

SHOP NOTES:

NOTE

An inclinometer for measuring control
surface travel is available from Cessna Parts
Distribution (CPD 2) through Cessna Service
Stations. Refer to Section 6.

- d. Adjust bellcrank travel stop blocks (8) to obtain
degree of elevator travel as specified in figure 1-1.

NOTE

The bellcrank stop blocks (8) are four-sided
bushings, drilled off-center so they may be
rotated to any one of four positions to attain
correct elevator travel. Each 90-degree
rotation of the stop changes the elevator
travel approximately one degree.

- e. Move control wheel through full range of travel
and check cable tension in various positions. Ten-
sion should not be less than 20 pounds or more than
40 pounds in any position.
- f. Check all turnbuckles are safetied and all parts
are secured, then reinstall all parts removed for
access.

WARNING

Be sure elevators move in the correct direc-
tion when operated by the control wheels.

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 9

ELEVATOR TRIM TAB CONTROL SYSTEM

TABLE OF CONTENTS	Page No. Aerofiche/Manual	
ELEVATOR TRIM TAB CONTROL SYSTEM		
SYSTEM	2A17/9-1	Trim Tab Free-Play Inspection
Description	2A17/9-1	Pedestal Cover
Trouble Shooting	2A17/9-1	Removal and Installation
Trim Tab	2A18/9-2	Rigging Manual Trim
Removal and Installation	2A18/9-2	Electric Trim Assist Installation
Trim Tab Actuator	2A18/9-2	Description
Removal and Installation	2A18/9-2	Trouble Shooting
Trim Tab Control Wheel	2A18/9-2	Removal and Installation
Removal and Installation	2A18/9-2	Clutch Adjustment
Cables and Pulleys	2A20/9-4	Trim Tab Simulated Air Load
Removal and Installation	2A20/9-4	Test
		Rigging - Electric Trim Assist.

9-1. ELEVATOR TRIM TAB CONTROL SYSTEM.
(Refer to figure 9-1.)

9-2. DESCRIPTION. The elevator trim tab, located on the trailing edge of the right elevator, is controlled by a trim wheel mounted in the pedestal. Power to operate the tab is transmitted from the trim control wheel by means of roller chains, cables, an actuator and a push-pull tube. A mechanical pointer,

adjacent to the trim wheel indicates nose attitude of the aircraft. Forward rotation of the wheel trims the nose down and aft rotation of the wheel trims the nose up. An electric trim assist may be installed and is described in paragraph 9-17. When de-energized the electric trim assist has no effect on manual operation.

9-3. TROUBLE SHOOTING.

NOTE

Due to remedy procedures in the following trouble shooting chart, it may be necessary to rerig system. Refer to appropriate rigging paragraphs.

TROUBLE	PROBABLE CAUSE	REMEDY
TRIM CONTROL WHEEL MOVES WITH EXCESSIVE RESISTANCE.	Cable tension too high.	Check cable tension and adjust.
	Pulleys binding or rubbing.	Check pulleys visually. Repair or replace as necessary.
	Cables not in place on pulleys.	Check visually. Install cables correctly.
	Trim tab hinge binding.	Disconnect actuator and move tab up and down to check hinge resistance. Lubricate or replace hinge as necessary.
	Defective trim tab actuator.	Remove chain from actuator sprocket and operate actuator manually. Replace defective actuator.
	Rusty chain.	Check visually. Replace rusty chain.

MODEL 210 & T210 SERIES SERVICE MANUAL

9-3. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
TRIM CONTROL WHEEL MOVES WITH EXCESSIVE RESISTANCE (CONT).	Damaged sprocket.	Check visually. Replace damaged sprockets.
	Bent sprocket shaft.	Observe motion of sprockets. Replace defective shafts.
LOST MOTION BETWEEN CONTROL WHEEL AND TRIM TAB.	Cable tension too low.	Check cable tension and adjust.
	Broken pulley.	Check visually. Replace defective pulley.
	Cables not in place on pulleys.	Check visually. Install cables correctly.
	Worn trim tab actuator.	Disconnect trim tab and check for play in actuator. Replace defective actuator.
	Actuator attachment loose.	Check actuator for security and tighten.
TRIM INDICATION INCORRECT.	Indicator incorrectly engaged on wheel track.	Check visually. Reset indicator.
INCORRECT TRIM TAB TRAVEL.	Stop blocks loose or incorrectly adjusted.	Adjust stop blocks on cables. Refer to figure 9-5.
	Incorrect rigging.	Refer to paragraph 9-15.

9-4. TRIM TAB. (Refer to figure 9-2.)

9-5. REMOVAL AND INSTALLATION.

- a. Disconnect push-pull tube (9) from hone assembly (6).

NOTE

If trim system is not moved and actuator screw is not turned, rerigging of trim system should not be necessary after reinstallation of tab.

- b. Remove screw (11) securing hinge pin (10), pull pin until free of tab, and remove tab.

NOTE

It is not necessary to completely remove hinge pin.

- c. Reverse the preceding steps for reinstallation. Rig system, if necessary, in accordance with paragraph 9-15.

9-6. TRIM TAB ACTUATOR. (Refer to figure 9-1.)

9-7. REMOVAL AND INSTALLATION.

- a. Relieve cable tension at turnbuckle (8).
 b. Disconnect tube assembly (15) at actuator (19).
 c. Remove access plate beneath actuator (19).
 d. Remove chain guard (21) and disengage chain (23) from sprocket (20).

- e. Remove screws attaching mounting bracket (24) to support bracket (18), and remove actuator (19) through access opening.


- f. Reverse the preceding steps for reinstallation. Rig system in accordance with paragraph 9-15, safety turnbuckle (8), and reinstall all items removed for access.

9-8. TRIM TAB CONTROL WHEEL. (Refer to figure 9-4.)

9-9. REMOVAL AND INSTALLATION.

- a. Remove pedestal cover as outlined in paragraph 9-14.
 b. Remove screws (13) and nuts (9) securing chain guard (10) to pedestal structure (6).
 c. Remove bolt (1) securing position indicator (3) to pedestal structure (6). Retain washers (2) and spacer (4) for reinstallation.
 d. Loosen bolts (11) securing idler sprockets (16) to pedestal structure (6), slide idler sprockets in slotted holes, and disengage chain (19) from idler sprockets (16).
 e. Remove bolts (11), chain guard (10), and position indicator (3), using care not to bend position indicator (3) or drop parts into tunnel area.
 f. Remove roller chain (19) from trim wheel sprocket and carefully slide trim wheel (7) from pivot stud (8).
 g. Reverse the preceding steps for reinstallation.

MODEL 210 & T210 SERIES SERVICE MANUAL



1. Sprocket
2. Bearing
3. Bushing
4. Cable Guard
5. Spacer
6. Pulley
7. Right Aft Cable
8. Turnbuckle
9. Right Forward Cable
10. Cable Ends
11. Left Forward Cable
12. Left Aft Cable
13. Travel Stop Block

CAUTION

MAINTAIN SPECIFIED CONTROL CABLE TENSION.

CABLE TENSION:
 20 +0, -5 LBS. (AT AVERAGE TEMPERATURE FOR THE AREA)
 REFER TO FIGURE 1-1 FOR TRAVEL.

Figure 9-1. Elevator Trim Tab Control System (Sheet 1 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL

Remove roller chain (19) slack by adjusting idler sprockets (16) in slotted holes and reinstall all items removed for access.

9-10. CABLES AND PULLEYS.

9-11. REMOVAL AND INSTALLATION.

a. FORWARD CABLE. (Refer to figure 9-1.)

1. Peel back carpeting as necessary to expose access plates in cabin and baggage areas and remove plates.

2. Remove safety wire, relieve cable tension and disconnect turnbuckle (8).

3. Disconnect cable ends (10).

4. (Refer to figure 9-4.) Remove pedestal cover as outlined in paragraph 9-14.

5. Remove lower pedestal panel (14) and disengage roller chain (21) from drive sprocket assembly (18).

6. (Refer to figure 9-1.) Remove cable guards (4) and pulleys (6) as necessary to work cable free of aircraft.

NOTE

To ease routing of cable, during reinstallation, a length of wire may be attached to the end of cable before its being withdrawn from aircraft. Leave wire in place, routed through structure; then attach the cable being installed and pull cable into position.

7. Reverse the preceding steps for reinstallation.

8. After cable is routed into position, install pulleys (6) and cable guards (4). Ensure cable is positioned in pulley grooves before installing cable guards (4). Ensure roller chain (Index 21, figure 9-4) is positioned correctly over drive sprocket (Index 18, figure 9-4).

9. Rerig system in accordance with paragraph 9-15, safety turnbuckle (8), and reinstall all items removed for access.

b. AFT CABLE. (Refer to figure 9-1.)

1. Peel back carpeting as necessary to expose access plates in baggage area and remove plates.

2. Remove rear baggage compartment wall.

3. Remove safety wire, relieve cable tension and disconnect turnbuckle (8).

CAUTION

Position a support stand under tail tie-down ring to prevent tailcone from cropping while working inside.

4. Disconnect cable ends (10).

5. Remove travel stop blocks (13).

6. Disconnect electric trim clamps and keepers (Indexes 15 and 16, figure 9-6), if installed.

7. Remove access plate beneath trim tab actuator (19) and remove chain guard (21).

8. Disengage roller chain (23) from actuator sprocket (20).

9. Remove cable guards and pulleys as necessary to work cable free of aircraft.





Figure 9-1. Elevator Trim Tab Control System (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL



Detail J

BEGINNING WITH SERIAL 21062383

Figure 9-1. Elevator Trim Tab Control System (Sheet 3 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 9-2. Elevator Trim Tab Installation




Figure 9-3. Elevator Trim Tab Actuator Assembly

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 9-4. Elevator Trim Wheel Installation

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

To ease routing of cable, a length of wire may be attached to the end of cable before being withdrawn from aircraft. Leave wire in place, routed through structure; then attach the cable being installed and pull cable into position.

10. Reverse the preceding steps for reinstallation.

11. After cable is routed in position, install pulleys and cable guards. Ensure cable is positioned in pulley grooves before installing guards. Ensure roller chain (23) is positioned correctly over actuator sprocket (20).

12. Re-rig system in accordance with paragraph 9-15, safety turnbuckle (8) and reinstall all items removed for access.

9-12. TRIM TAB FREE-PLAY INSPECTION. (Refer to figure 9-5A.)

a. Place elevators and trim tab in neutral position and secure from movement.
b. Determine maximum allowable free-play using the following instructions.

1. Measure chord length of extreme inboard end of the trim tab as shown in detail A, figure 9-5A.

2. Multiply chord length by 0.025 to obtain maximum allowable free-play.

c. Using moderate pressure, move the trim tab trailing edge up and down by hand to check free-play.

NOTE

Measure free-play at the same point on trim tab that chord length was measured. Total free-play must not exceed maximum allowable. Refer to detail B, figure 9-5A.

d. If the trim tab free-play is less than the maximum allowable the system is within the prescribed limits.

e. If the trim tab free-play is more than the maximum allowable, check the following items, for looseness while moving the trim tab up and down.

1. Check push-pull tube to trim tab horn assembly attachment for looseness.

2. Check push-pull tube to actuator assembly threaded rod end attachment for looseness.

3. Check actuator assembly threaded rod end for looseness in actuator assembly with push-pull tube disconnected.

f. If looseness is apparent while checking steps e-1 and e-2, repair by installing new parts.

g. If looseness is apparent while checking step e-3, refer to paragraphs 9-7 through 9-8. Recheck trim tab free-play.




Figure 9-5. Elevator Trim Tab Travel Stop Adjustment

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 9-5A. Trim Tab Free-Play Inspection

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

9-13. PEDESTAL COVER.

9-14. REMOVAL AND INSTALLATION.

- a. Turn fuel selector valve to OFF position and drain fuel from strainer and lines.
- b. Remove knurled nut from engine primer if installed and pull plunger from primer body. Protect primer from dirt.
- c. Remove fuel selector handle and placard.
- d. Remove cowl flap handle knob.
- e. Remove electric trim circuit breaker nut and microphone mounting bracket, if installed.
- f. Fold carpet back as necessary and remove screws securing cover to floor and pedestal.
- g. Disconnect electrical wiring to pedestal lights.
- h. Carefully work cover from pedestal to prevent damage.
- i. Reverse the preceding steps for reinstallation.

9-15. RIGGING MANUAL TRIM. (Refer to figure 9-1.)

CAUTION

Position a support stand under tail tie-down ring to prevent tailcone from dropping while working inside.

- a. Remove rear baggage compartment wall and access plates as necessary.
- b. Loosen travel stop blocks (13) on trim tab cables (7 and 12).
- c. Disconnect push-pull tube (15) from actuator (19).
- d. Check cable tension for 20 +0 -5 pounds, and readjust turnbuckle (8) if necessary.

NOTE

If roller chains and/or cables are being installed, permit actuator screw to rotate freely as roller chains and cables are connected. Adjust cable tension and safety turnbuckle (8).

- e. (Refer to figure 9-4.) Rotate trim wheel (7) full forward (nose down). Ensure position indicator (3) does not restrict trim wheel movement. If necessary to reposition indicator, proceed as follows:
 1. Remove pedestal cover as outlined in paragraph 9-14.
 2. Loosen nut (9) at trim, wheel pivot stud (8).
 3. Loosen screws (13) securing chain guard (10) far enough that trim wheel (7) can be moved approximately 1/8-inch, then reposition position indicator (3) using a thin screwdriver to pry trailing leg of pointer out of groove in trim wheel. Reposition position indicator as required.

4. Tighten nut (9) and screws (13) but do not reinstall pedestal cover until rigging is complete.

NOTE

Full forward (nose down) position of trim wheel is where further movement is prevented by the roller chain or cable ends contacting sprockets or pulleys.

- f. With elevator and trim tab both in neutral (split the non-faired difference between the in-board and outboard ends), mount an inclinometer on trim tab and set to 0°. Disregard counterweight areas of elevators when streamlining. These areas are contoured so they will be approximately 3° down when the elevators are streamlined.

NOTE

An inclinometer for measuring control surface travel is available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations. Refer to Section 6.

- g. Rotate actuator screw in or out as required to place trim tab up with a maximum of 2° overtravel, with actuator screw connected to push-pull tube (Index 15, figure 9-1).

- h. Rotate trim wheel to position trim tab up and down, readjusting actuator screw as required to obtain overtravel in both directions.

- i. Position stop blocks (Indexes 1, 2, and 3, figure 9-5.) as illustrated in figure 9-5 to degree of trim tab travel specified in figure 1-1.

- j. Install pedestal cover and adjust trim tab position indicator (3) as follows:

1. Rotate trim wheel (7) to place tab at 10° up position.
2. Locate position indicator (3) at the TAKE-OFF triangle as viewed from the pilot seat. (Refer to step "e." and reposition pointer if necessary.)

3. Bend position indicator (3) as required to clear pedestal cover. (Position indicator must NOT rub against pedestal cover or clear cover more than 0.125-inch maximum.)

- k. Safety turnbuckle (Index 8, figure 9-1) and reinstall all items removed in step "a."

WARNING

Be sure trim tab moves in correct direction when operated by trim control wheel. Nose down trim corresponds to tab up position.

MODEL 210 & T210 SERIES SERVICE MANUAL

9-16. **ELECTRIC TRIM ASSIST INSTALLATION.** (Refer to figure 9-6.)

9-17. **DESCRIPTION.** The electric elevator trim assist installation consists of two switches mounted on the pilot's control column, a circuit breaker mounted on the center pedestal cover, wiring running

aft to the electric drive assembly and a chain connecting the drive assembly to an additional sprocket mounted on the standard manual elevator trim actuator. When the clutch (16) is not energized, the drive assembly "free wheels" and has no effect on manual trim operation.

9-18. **TROUBLE SHOOTING.**

TROUBLE	PROBABLE CAUSE	REMEDY
SYSTEM INOPERATIVE.	Circuit breaker out.	Check visually. Reset breaker.
	Defective circuit breaker.	Check continuity. Replace defective breaker.
	Defective wiring.	Check continuity. Repair wiring.
	Defective trim switch.	Check continuity. Replace defective switch.
	Defective trim motor.	Remove and bench test. Replace defective motor.
TRIM MOTOR OPERATING - TRIM TAB FAILS TO MOVE.	Defective clutch solenoid.	Check continuity. Replace solenoid.
	Improperly adjusted clutch tension.	Check and adjust spanner nuts for proper tension.
	Disconnected or broken cable.	Operate manual trim wheel. Connect or replace cable.
	Defective actuator.	Check actuator operation. Replace actuator.

9-19. **REMOVAL AND INSTALLATION.** (Refer to figure 9-6.)

- a. Remove aft baggage compartment wall.

NOTE

Position a support stand under tail tie-down ring to prevent the tailcone from dropping while working inside.

- b. Remove cover (29) below drive assembly (6).
- c. Remove cover (28) with voltage regulator attached and carefully disconnect wiring at connectors.
- d. Remove sprocket guard (Index 5, figure 9-3) from trim tab actuator (3).
- e. Remove mounting bolts from drive assembly and tab actuator and remove from aircraft.
- f. Reverse preceding steps for reinstallation. Check system rigging in accordance with paragraph 9-23.

9-20. **CLUTCH ADJUSTMENT.** (Refer to figure 9-6.)

- a. Remove access covers (28) & (29) below actuator.
- b. Remove safety wire and relieve cable tension at turnbuckle (31).
- c. Disconnect electric motor by unplugging the "quick-disconnect" connectors leading to the motor assembly.
- d. Remove mounting bolts from drive assembly (6). It is necessary to remove from stabilizer to make the necessary adjustments to clutch.


NOTE

Step "c" isolates the motor assembly from the remainder of the electric trim system so it cannot be engaged during clutch adjustment.

- e. Remove screws securing covers (17) and (18).

MODEL 210 & T210 SERIES SERVICE MANUAL

- REFER TO
FIGURE 9-7
1. Trim Tab
 2. Voltage Regulator
 3. Trim Switch
 4. Disengage Switch
 5. Circuit Breaker
 6. Drive Assembly
 7. Washer
 8. Shaft
 9. Sprocket
 10. Chain Assembly
 11. Washer Assembly
 12. Spring Washer
 13. Washer
 14. Nut
 15. Shaft Assembly
 16. Clutch
 17. Cover Assembly
 18. Rub Strip
 19. Sprocket
 20. Bushing
 21. Chain
 22. Gear Motor
 23. Mounting Plate
 24. Sprocket
 25. Pin
 26. Housing Assembly
 27. Cover
 28. Mounting Plate Assembly
 29. Cover
 30. Cover
 31. Turnbuckle



*** SAFETY WIRE THESE ITEMS**





Figure 9-6. Electric Elevator Trim Assist Installation (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

- 32. Support Bracket
- 33. Screw
- 34. Noise Filter



*NOTE

BEGINNING WITH 1980 MODEL YEAR
A-374A Noise filter must be installed
with the 400 Autopilot.

Figure 9-6. Electric Elevator Trim Assist Installation (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 9-7. Dual Voltage Regulator

to housing (26) and slide the cover down over electrical wiring far enough to expose the clutch assembly.

f. Ensure the electric trim circuit breaker on the pedestal cover is pushed in and place master switch in the ON position.

g. Operate control wheel-mounted trim switch (3) UP or DOWN to energize the solenoid clutch (16).

h. Attach the spring scale to chain and pull scale slowly until slippage is noted.

i. Repeat Steps "g" and "h" several times to break the initial friction of the clutch.

j. Repeat Step "h" very slowly, carefully watching the indicator on the spring scale.

Slippage should occur between 38.6 to 42.5 lbs.

k. IF tension is not within tolerance, loosen OUTSIDE spanner nut (14) which acts as a lock. Tighten INSIDE spanner nut to increase clutch tension and loosen nut to decrease clutch tension.

l. When clutch slippage torque is within tolerance (step "j"), then tighten outside spanner nut against inside nut.

m. Connect electrical wiring to motor assembly which was removed in Step "c", re-rig trim system in accordance with paragraphs 9-15 and 9-24 and reinstall all items removed for access.

9-21. VOLTAGE REGULATOR ADJUSTMENT. (Refer to figure 9-6.)

a. Remove access cover (27)

b. Connect an external power source of 27.5 volts dc continuous to the aircraft electrical system, or if an external power supply is not available, run the aircraft engine at approximately 1000 RPM to maintain the normal operating aircraft voltage.

c. Disconnect the electrical power leads to the

motor by unplugging the connectors installed in the RED and BLACK wire leading to the motor assembly.

CAUTION

Ensure CTR adjustments (Index 1 and 2, Figure 9-7) are both turned fully CCW to limit initial voltage to motor and voltmeter.

d. Using 18 ga. jumper wires or equivalent, connect one lead of a dc voltmeter capable of measuring the aircraft voltage to either the RED or BLACK wire leading to the motor and the other voltmeter lead to a good aircraft ground.

e. Operate the electric trim switch to the NOSE UP and NOSE DOWN positions and check voltage present at the RED and BLACK wires.

f. Adjust CTR 1 and CTR 2 adjustment screws on the voltage regulator counterclockwise (CCW), then slowly turn adjustment screws clockwise (CW) until a 11 volt output is obtained for both (RED and BLACK) lead.

g. Check to see if full "NOSE UP" to full "NOSE DOWN" and full "NOSE DOWN" to full "NOSE UP" is 39±1 seconds.

h. Remove voltmeter and reconnect the motor assembly power leads. Be sure to connect RED to RED and BLACK to BLACK when reconnecting leads.

i. Check trim system for proper operation and reinstall all items removed for access.

CAUTION

The trim motor should be allowed to cool

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 9-8. Trim Tab Simulated Air Load Test

between voltage regulator adjustments approximately 5 minutes if several actuations of the motor becomes necessary during adjustment.

9-22. TRIM TAB SIMULATED AIR LOAD TEST. (Refer to figure 9-8.)

NOTE

The manual elevator trim control system must be properly rigged, the aircraft electrical operating voltage must be normal, the electric trim assist clutch must be properly adjusted and the elevator must be in neutral position prior to completing the following steps.

- Attach two angles approximately 18 inches in length to the trailing edge of the trim tab with clamps as illustrated to prevent bending of tab trailing edge.
- Attach a cable directly aft of the trim tab horn assembly.

- Attach 14 pounds minimum to 22 pounds maximum of weight (including the angles, clamps and cable) to the cable and operate the trim switch to place the tab in the UP position. The clutch **MUST** lift 15 pounds weight to the FULL UP position but must slip at 18 pounds.

NOTE

If the electric trim clutch slips prior to lifting the required weight to the full up position, **DO NOT READJUST CLUTCH**, refer to step "d" or step 5 to locate and remove the reason for excessive friction in the elevator trim control system.

- Check the trim tab hinge and linkage for binding, check the trim system cables and chains for proper tension, check system pulleys and actuator for binding.
- After the trim system has been thoroughly checked and excessive friction removed, repeat step "c", or step 3.

MODEL 210 & T210 SERIES SERVICE MANUAL

9-23. RIGGING - ELECTRIC TRIM ASSIST. (Refer to figure 9-6.)

a. The standard manual elevator trim control system **MUST** be rigged in accordance with paragraph 9-15 prior to rigging the electric trim assist.

b. Move elevator trim tab to full "NOSE UP" position.

c. Remove access cover (29) located in under side of right stabilizer.

d. Locate turnbuckle (31) terminal point 0.75 inches from drive assembly housing and adjust until chain deflection between sprockets is approximately 0.25 inches.

e. Resafety turnbuckle and reinstall all items removed for access.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 10

RUDDER CONTROL SYSTEM

TABLE OF CONTENTS	Page No. Aerofiche/Manual	
RUDDER CONTROL SYSTEM	2B13/10-1	
Description	2B13/10-1	Removal and Installation 2B17/10-5
Trouble Shooting	2B13/10-1	Repair 2B17/10-5
Rudder Pedal Assembly	2B17/10-5	Cables and Pulleys 2B17/10-5
Removal and Installation	2B17/10-5	Removal and Installation 2B17/10-5
Rudder	2B17/10-5	Rigging 2B20/10-8

10-1. RUDDER CONTROL SYSTEM. (Refer to figure 10-1.)

10-2. DESCRIPTION. Rudder control is maintained through use of conventional rudder pedals which also control nose wheel steering. The system is com-

prised of the rudder pedals installation, cables and pulleys, all of which link the pedals to the rudder and nose wheel steering. When dual controls are installed, stowable rudder pedals are provided at the copilot's position through 1977 models.

10-3. TROUBLE SHOOTING.

NOTE

Due to remedy procedures in the following trouble shooting chart, it may be necessary to rerig system. Refer to paragraph 10-11.


TROUBLE	PROBABLE CAUSE	REMEDY
RUDDER DOES NOT RESPOND TO PEDAL MOVEMENT.	Broken or disconnected cables.	Open access plates and check visually. Connect or replace cables.

MODEL 210 & T210 SERIES SERVICE MANUAL

10-3. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
BINDING OR JUMPY MOVEMENT OF RUDDER PEDALS.	Cables too tight.	Refer to figure 10-1 for cable tension. Rig system in accordance with paragraph 10-11.
	Cables not riding properly on pulleys.	Open access plates and check visually. Route cables correctly over pulleys.
	Binding, broken or defective pulleys or cable guards.	Open access plates and check visually. Replace defective pulleys and install guards properly.
	Pedal bars need lubrication.	Refer to Section 2.
	Defective rudder bar bearings.	If lubrication fails to eliminate binding. Replace bearing blocks.
	Defective rudder hinge bushings.	Check visually. Replace defective bushings.
	Clevis bolts too tight.	Check and readjust bolts to eliminate binding.
	Steering rods improperly adjusted.	Rig system in accordance with paragraph 10-11.
LOST MOTION BETWEEN RUDDER PEDALS AND RUDDER.	Insufficient cable tension.	Refer to figure 10-1 for cable tension. Rig system in accordance with paragraph 10-11.
INCORRECT RUDDER TRAVEL.	Incorrect rigging.	Rig in accordance with paragraph 10-11.
STOWABLE PEDALS DO NOT DISENGAGE.	Broken or defective control.	Disengage control and check manually. Replace control.
STOWABLE PEDALS DO NOT STOW.	Defective cover, catch or latch pin.	Check visually. Replace defective parts.
STOWABLE PEDALS DO NOT RE-ENGAGE.	Binding control.	Check control operation. Repair or replace control.
	Misaligned or bent mechanism.	Check visually. Repair or replace defective parts.

MODEL 210 & T210 SERIES SERVICE MANUAL



Detail A

Detail B

Detail C

Detail D

NOTE

Shaded pulleys are used for this system only.

REFER TO SECTION 11

REFER TO FIGURE 10-2

CAUTION

MAINTAIN SPECIFIED CONTROL CABLE TENSION

CABLE TENSION:
30 LBS ± 10 LBS (AT AVERAGE TEMPERATURE FOR THE AREA.)
REFER TO FIGURE 1-1 FOR TRAVEL.


- | | |
|------------------------|----------------------|
| 1. Right Rudder Bar | 8. Clip |
| 2. Left Rudder Bar | 9. Fairlead |
| 3. Right Forward Cable | 10. Turnbuckle |
| 4. Left Forward Cable | 11. Right Rear Cable |
| 5. Cable Guard | 12. Left Rear Cable |
| 6. Spacer | 13. Stop Bolt |
| 7. Pulley | 14. Bellcrank |

Figure 10-1. Rudder Control System

MODEL 210 & T210 SERIES SERVICE MANUAL


NOTE

Brake links (5), bellcranks (22), brake torque tubes (19) and attaching parts for the RIGHT-HAND rudder pedals are replaced with hubs (8) when dual controls are NOT installed. These hubs are attached to each end of the forward rudder bars.




* THRU 21064806

* BEGINNING WITH 21064807




Detail A

1. Anti-Rattle Spring
2. Pedal
3. Shaft
4. Spacer
5. Brake Link
6. Cable (Left Forward)
7. Cable (Right Forward)
8. Single Controls Hub
9. Pin (Stowable Pedals Only)
10. Stowable Pedals Controls
11. Bearing Block
12. Right Rudder Cable Arm
13. Left Rudder Cable Arm
14. Aft Rudder Bar
15. Nosewheel Steering Arm
16. Rudder Trim Bungee Arm
17. Forward Rudder Bar
18. Master Cylinder
19. Brake Torque Tube
20. Bracket
21. Bearing
22. Bellcrank
23. Washer
24. Pedal Extension
25. Shaft



CLEARANCE HOLE FORWARD

CLEARANCE HOLE AFT




Detail B

STOWABLE RUDDER PEDALS INSTALLATION THRU 1977 MODELS

* NOTE

At least one washer (23) must be installed at the location shown.



Detail C

Figure 10-2. Rudder Pedal Installation

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 10-3. Nose Gear Steering Installation

10-4. RUDDER PEDAL ASSEMBLY.

10-5. REMOVAL AND INSTALLATION. (Refer to figure 10-2.)

- a. Remove carpeting, shields and soundproofing from the rudder pedal and tunnel areas as necessary for access.
- b. Disconnect brake master cylinders (18) and parking brake cables at pilot's rudder pedals.
- c. Remove rudder pedals (2) and brake links (5).
- d. Disconnect stowable rudder pedal controls (10).
- e. Remove fairing from either side of vertical fin, remove safety wire and relieve cable tension by loosening turnbuckles (index 10, figure 10-1).
- f. Disconnect cables (6 and 7) from rudder bar arms (12 and 13).
- g. Disconnect rudder trim bungee from rudder bar arm (16).
- h. (Refer to figure 10-3.) Disconnect whiffletree link rod assemblies (5) at rudder bar arms (9 and 10).
- i. (Refer to figure 10-2.) Remove bolts securing bearing blocks (11) and carefully work rudder bars out of tunnel area.

NOTE

The two inboard bearing blocks contain clearance holes for the rudder bars at one end and a bearing hole at the other. Tag these bearing blocks for reference on reinstallation.

- j. Reverse the preceding steps for reinstallation. Lubricate rudder bar assemblies as outlined in Section 2. Rig system in accordance with paragraph 10-11, safety turnbuckles and reinstall all items removed for access.

10-6. RUDDER. (Refer to figure 10-4.)

10-7. REMOVAL AND INSTALLATION.

- a. Remove stinger.
- b. Disconnect tail navigation light wire.
- c. Remove fairing from either side of vertical fin, remove turnbuckles (index 10, figure 10-1.)
- d. Disconnect cables (4 and 6) from rudder bellcrank (3).
- e. With rudder supported, remove all hinge bolts (2) and using care, lift rudder free of vertical fin.
- f. Reverse the preceding steps for reinstallation. Rig system in accordance with paragraph 10-11, safety turnbuckles and reinstall all items removed for access.

10-8. REPAIR. Repair may be accomplished as outlined in Section 18.

10-9. CABLES AND PULLEYS. (Refer to figure 10-1.)

10-10. REMOVAL AND INSTALLATION.

- a. Remove seats, upholstery and access plates as necessary.

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 10-4. Rudder Installation

MODEL 210 & T210 SERIES SERVICE MANUAL



1. Establish neutral position of rudder by clamping straightedge (such as wooden 2 × 4) on each side of fin and rudder and blocking trailing edge of rudder half the distance between straightedges as shown.
2. Tape a length of soft wire to the stinger in such a manner that it can be bent to index at the lower corner of the rudder trailing edge.
3. Using soft lead pencil, mark rudder at point corresponding to soft wire indexing point (neutral).
4. Remove straightedges and blocks.
5. Hold rudder against right, then left, rudder stop. Measure distance from pointer to pencil mark on rudder in each direction of travel. Distance should be between 8.12" and 8.72".

Figure 10-5. Checking Rudder Travel

MODEL 210 & T210 SERIES SERVICE MANUAL

- b. Remove safety wire, relieve cable tension and disconnect cables at turnbuckles (10).
- c. Disconnect cables (3 and 4) at rudder bar arms.
- d. Remove cable guards, pulleys and fairleads as necessary to work cables free of aircraft.

NOTE

To ease routing of cables, a length of wire may be attached to end of the cable before being withdrawn from aircraft. Leave wire in place, routed through structure; then attach cable being installed and pull the cable into position.

- e. Reverse the preceding steps for reinstallation.
- f. After cable is routed in position, install pulleys, fairleads and cable guards. Ensure cable is positioned in pulley grooves before installing guards.
- g. Re-rig system in accordance with paragraph 10-11, safety turnbuckles and reinstall all items removed in step "a".

10-11. RIGGING.

- a. Remove fairing from either side of vertical fin, remove safety wire and relieve cable tension at turnbuckles (index 10, figure 10-1).
- b. Open landing gear doors. (Refer to Section 5.)
- c. Tie down or weight tail to raise nosewheel free of ground.
- d. Extend strut and ensure nose gear is centered against the external centering lug. (Neutral position.)
- e. (Refer to figure 10-3.) Disconnect steering bungee adjustable rod end (3) from whiffletree (4).

- f. Remove pedestal cover in accordance with Section 9.
- g. Remove lower pedestal panel (index 14, figure 9-4).
- h. Disconnect rudder trim bungee from rudder bar arm (index 16, figure 10-2).
- i. Clamp rudder pedals in neutral position.
- j. Adjust turnbuckles (index 10, figure 10-1) to streamline rudder with 30 ± 10 lbs tension on cables.
- k. Remove clamps from rudder pedals.
- l. Adjust travel stop bolts (index 13, figure 10-1) to obtain degree of travel specified in figure 1-1. Figure 10-5 illustrates correct travel and one method of checking.
- m. Adjust length of rod end (3) to align with whiffletree (4) and install bolt. **DO NOT PRELOAD BUNGEE.**
- n. Connect rudder trim bungee and rig trim system as outlined in Section 11.
- o. Operate rudder system, checking for ease of movement and full travel. Check cable tension with rudder in various positions. Cable tension should not be less than 20 pounds or more than 40 pounds in any position.
- p. Check that all turnbuckles are safetied and reinstall all items removed for access.
- q. Lower nosewheel to ground.

WARNING

Be sure rudder moves in the correct direction when operated by the rudder pedals.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 11

RUDDER TRIM CONTROL SYSTEM

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
RUDDER TRIM CONTROL SYSTEM	2C1/11-1		Wheel and Gear Box
Description	2C1/11-1		Assembly
Trouble Shooting	2C1/11-1		Chain Assembly
Removal and Installation of			Gimbal Assembly
System Components	2C3/11-3		Bungee Assembly
Indicator Assembly	2C3/11-3		Rigging Rudder Trim System ..
			2C3/11-3

11-1. **RUDDER TRIM CONTROL SYSTEM.** (Refer to figure 11-1.)

11-2. **DESCRIPTION.** The rudder trim system is comprised of a trim control wheel and gear box assembly located in the upper control pedestal, which is connected by a chain assembly to a gimbal assembly in the lower pedestal. The gimbal assembly is

attached to a stop bracket, which is attached to the rudder trim bungee. The bungee's push-rod assembly is attached to the right-hand rudder bar assembly. The rudder control system, rudder trim control system, and the nosewheel steering system are interconnected and adjustments to any one system will affect the others.

11-3. **TROUBLE SHOOTING.**

NOTES

This trouble shooting chart should be used in conjunction with the chart shown in Section 10.

Due to remedy procedures in the following trouble shooting chart, it may be necessary to rerig system. Refer to paragraph 11-5.

TROUBLE	PROBABLE CAUSE	REMEDY
FALSE READING ON TRIM POSITION INDICATOR.	Improper rigging.	Refer to note above.
	Worn, bent or disconnected linkage.	Check visually. Repair or replace parts as necessary.
HARD OR SLUGGISH OPERATION OF TRIM WHEEL.	Worn, bent or binding linkage.	Check visually. Repair or replace parts as necessary.
	Incorrect rudder cable tension.	Check and adjust rudder cable tension.
FULL TRIM TRAVEL NOT OBTAINED.	Rudder trim system improperly rigged.	Refer to note above.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 11-1. Rudder Trim Control System

MODEL 210 & T210 SERIES SERVICE MANUAL

11-4. REMOVAL AND INSTALLATION OF SYSTEM COMPONENTS. (Refer to figure 11-1.)

a. INDICATOR ASSEMBLY.

1. Remove pedestal cover in accordance with procedures outlined in Section 9.
2. Remove four screws attaching mounting bracket assembly (19) to pedestal assembly (2).
3. Remove indicator assembly as a unit.
4. Reverse preceding steps for installation.

b. WHEEL AND GEAR BOX ASSEMBLY.

1. Remove pedestal cover as outlined in Section 9.
2. Loosen chain (27) by loosening bolt securing idler sprocket (14) and sliding sprocket inboard in slot in support angle (15).
3. Remove upper panel (3) and disconnect chain (27) at connecting link.
4. Remove four bolts attaching gear box assembly (18) to pedestal assembly (2).
5. Remove bolts attaching idler sprocket (14) and chain guards (12) and (28).
6. Remove wheel and gear box assembly as a unit.

NOTE

If wheel and gear box assembly is disassembled, install washers (16) and (23) as required to nest sprockets and prevent end play.

7. Reverse preceding steps for installation.

c. CHAIN ASSEMBLY.

1. Remove pedestal cover as outlined in Section 9.
2. Remove upper panel (3).
3. Remove access cover directly below and aft of pedestal in floor.
4. Remove fuel selector shaft, then remove lower panel (4).
5. Loosen chain (27) by loosening bolt securing idler sprocket (14) and sliding sprocket inboard in slot in support angle (15).
6. Disconnect chain at connecting link.
7. Remove bolt attaching bungee (13) to stop bracket (11).
8. Pull gimbal assembly (items 5, 6, 7, 8, 9, 10 and 11) aft away from bungee (13).
9. Remove chain (27) from sprocket drive nut (8).
10. Reverse preceding steps for installation.

d. GIMBAL ASSEMBLY.

1. Remove pedestal cover as outlined in Section 9.
2. Remove access cover directly below and aft of pedestal in floor.
3. Remove fuel selector shaft, then remove lower panel (4).
4. Loosen chain (27) by loosening bolt securing idler sprocket (14) and sliding sprocket inboard in slot in support angle (15).
5. Disconnect chain at connecting link.
6. Remove bolt attaching bungee (13) to stop bracket (11).
7. Pull gimbal assembly (items 5, 6, 7, 8, 9, 10 and 11) aft; remove from aircraft.

NOTE

If gimbal assembly is to be disassembled, upon reassembly, shims (9) should be installed between gimbal half assembly (6) and cover plate assembly (10) to maintain .002 to .004-inch end play on sprocket.

8. Reverse preceding steps for installation.

e. BUNGEE ASSEMBLY.

1. Remove pedestal cover as outlined in Section 9.
2. Remove upper panel (3).
3. Remove access cover directly below and aft of pedestal in floor.
4. Remove fuel selector shaft, then remove lower panel (4).
5. Loosen chain (27) by loosening bolt securing idler sprocket (14) and sliding sprocket inboard in slot in support angle (15).
6. Disconnect chain at connecting link.
7. Remove bolts attaching idler sprocket (14) and chain guards (12) and (28) to support angle (15).
8. Remove bolts attaching chain guard to stop bracket (11); remove chain guards.
9. Remove bolt attaching bungee (13) to stop bracket (11).
10. Pull gimbal assembly (items 5, 6, 7, 8, 9, 10 and 11) aft; remove from aircraft.
11. Disconnect bungee push-rod assembly from right-hand rudder bar assembly.
12. Using care, remove bungee from tunnel area, aft, through pedestal.
13. Reverse preceding steps for installation.

NOTE

Upon installation, lubricate bungee screw and sprocket drive nut threads per Section 2.

11-5. RIGGING RUDDER TRIM SYSTEM. (Refer to Figure 11-1.)

NOTE

Rudder control system and nose wheel steering system must be correctly rigged prior to rigging the rudder trim system.

- a. Remove pedestal cover as outlined in Section 9.
- b. Remove upper pedestal panel.
- c. Remove access cover directly below and aft of pedestal in floor.
- d. Remove fuel selector shaft, then remove lower pedestal panel.
- e. Loosen chain by loosening bolt securing idler sprocket, and sliding sprocket inboard in slot in support angle; disconnect chain.
- f. Remove bolt attaching bungee to stop bracket; unscrew gimbal assembly from actuator drive screw.
- g. Disconnect bungee push-pull rod from right-hand rudder bar assembly.
- h. Tie down or weight tail to raise nose wheel free of ground.
- i. Ensure rudder pedals and rudder are in neutral position.

MODEL 210 & T210 SERIES SERVICE MANUAL

j. Attach bungee push-pull rod to right-hand rudder bar assembly.

k. Install lower panel assembly and bearing brackets.

l. Screw gimbal assembly onto bungee drive screw until studs on gimbal half assembly align with holes in bearing brackets and nutplate on stop bracket aligns with approximate center of slot in bungee stop arm.

m. Install and tighten bolts, washers and nuts.

n. String chain over idler sprocket and sprocket in wheel and gear box assembly; connect chain at connecting link.

rudder pedals in neutral position. If indicator does not line up with centerline of aircraft, bend indicator left or right as required.

o. Tighten chain by moving idler sprocket outboard in slot in support angle.

p. Install full selector shaft.

q. Install upper panel.

r. Install floor access covers and pedestal cover.

s. Remove blocking from rudder and pedals.

t. Lower aircraft.

WARNING

Be sure rudder moves in correct direction when operated by the trim control wheel.

NOTE

Indicator assembly should be installed with

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 12

ENGINE

(NORMALLY ASPIRATED)

REFER TO SECTION 12A FOR TURBOCHARGED

WARNING

When performing any inspection or maintenance that requires turning on the master switch, installing a battery, or pulling the propeller through by hand, treat the propeller as if the ignition switch were ON. Do not stand nor allow anyone else to stand, within the arc of the propeller, since a loose or broken wire or a component malfunction could cause the propeller to rotate.

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
ENGINE COWLING	2C15/12-2A	Full-Flow Oil Filter	2D4/12-16
Description	2C15/12-2A	Description	2D4/12-16
Removal and Installation	2C15/12-2A	Removal and Installation (Filter Element)	2D4/12-16
Cleaning and Inspection	2C15/12-2A	Full-Flow Oil Filter (Beginning with Serial 21064136)	2D6/12-18
Repair	2C15/12-2A	Description	2D6/12-18
Cowl Flaps	2C15/12-2A	Removal	2D6/12-18
Description	2C15/12-2A	Installation	2D7/12-18A
Removal and Installation	2C15/12-2A	Filter Adapter. 210 Thru Serial 21064780; T210 Thru Serial 21064781	2D7/12-18A
Rigging	2C15/12-2A	Removal	2D7/12-18A
ENGINE	2C15/12-2A	Disassembly, Inspection, and Reassembly	2D7/12-18A
Description	2C15/12-2A	Installation	2D9/12-20
Engine Data	2C16/12-3	Filter Adapter. 210, Beginning with 21064781; T210, Beginning with 21064782	2D9/12-20
Time Between Overhaul (TBO)	2C17/12-4	Oil Cooler	2D9/12-20
Overspeed Limitations	2C17/12-4	Description	2D9/12-20
Trouble Shooting	2C18/12-5	ENGINE FUEL SYSTEM	2D9/12-20
Static Run-Up Procedures	2C20/12-7	Description	2D9/12-20
Removal	2C20/12-7	Fuel-Air Control Unit	2D10/12-21
Cleaning	2C22/12-9	Description	2D10/12-21
Accessories Removal	2C22/12-9	Removal and Installation	2D11/12-22
Inspection	2C22/12-9	Cleaning and Inspection	2D11/12-22
Buildup	2C22/12-9	Adjustments	2D11/12-22
Installation	2C22/12-9	Fuel Manifold Valve	2D11/12-22
Flexible Fluid Hoses	2C24/12-11	Description	2D11/12-22
Pressure Test	2C24/12-11	Removal	2D11/12-22
Replacement	2C24/12-11	Cleaning	2D11/12-22
Engine Baffles	2D1/12-12	Installation	2D12/12-23
Description	2D1/12-12	Fuel Discharge Nozzles	2D12/12-23
Cleaning and Inspection	2D1/12-12		
Removal and Installation	2D1/12-12		
Repair	2D1/12-12		
ENGINE OIL SYSTEM	2D1/12-12		
Description	2D1/12-12		
Trouble Shooting	2D2/12-13		

MODEL 210 & T210 SERIES SERVICE MANUAL

Removal 2D12/12-23
Cleaning and Inspection 2D12/12-23
Installation 2D12/12-23
Fuel Injection Pump 2D12/12-23
Description 2D12/12-23
Removal 2D13/12-24
Installation 2D13/12-24
Adjustment 2D13/12-24
Auxiliary Electric Fuel Pump Flow
Rate Adjustment 2D14/12-25
INDUCTION AIR SYSTEM 2D14/12-25
Description 2D14/12-25
Airbox 2D14/12-25
Removal and Installation 2D14/12-25
Cleaning and Inspection 2D14/12-25
Induction Air Filter 2D14/12-25
Description 2D14/12-25
Removal and Installation 2D14/12-25
Cleaning and Inspection 2D14/12-25
IGNITION SYSTEM 2D14/12-25
Description 2D14/12-25
Trouble Shooting 2D16/12-27
Magnetos 2D17/12-29
Description 2D17/12-29
Removal 2D17/12-29
Internal Timing 2D17/12-29
Installation and Timing-to-
Engine 2D17/12-29
Maintenance 2D18/12-30
Magneto Check 2D19/12-31
Spark Plugs 2D20/12-32
ENGINE CONTROLS 2D20/12-32
Description 2D20/12-32
Rigging 2D20/12-32
Throttle Control 2D20/21-32
Mixture Control 2D21/12-33
Throttle-Operated Microswitch 2D21/12-33
Landing Gear Warning Horn 2D21/12-33
Propeller Control 2D23/12-35
STARTING SYSTEM 2D23/12-35
Description 2D23/12-35
Trouble Shooting 2D23/12-35
Primary Maintenance 2D24/12-36
Starter Motor 2D24/12-36
Removal and Installation 2D24/12-36
EXHAUST SYSTEM 2D24/12-36
Description 2D24/12-36
Economy Mixture Indicator (EGT) 2D24/12-36
Removal and Installation 2D24/12-36
Inspection 2D24/12-36
EXTREME WEATHER MAINTENANCE 2E2/21-38
Cold Weather 2E2/12-38
Hot Weather 2E2/21-38
Seacoast and Humid Areas 2E2/21-38
Dusty Areas 2E2/12-38
Ground Service Receptacle 2E2/12-38

SHOP NOTES:

Horizontal lines for shop notes.

MODEL 210 & T210 SERIES SERVICE MANUAL

12-1. ENGINE COWLING.

12-2. DESCRIPTION. The engine cowling is divided into four major removable segments. The left upper cowling segment has two access doors, one at the upper front provides access to the oil filler neck and one at the left aft side provides access to the oil dipstick. The right and left nose caps are fastened to the lower engine nacelle and to each other with screws. The right and left upper cowl segments are secured with quick-release fasteners and either segment may be removed individually. The lower engine nacelle is an extension of the fuselage and provides fairing for the nose wheel in its retracted position.

12-3. REMOVAL AND INSTALLATION.

- a. Release the quick-release fasteners attaching the cowling to the fuselage and at the parting surfaces of the left and right segments.
- b. Remove screws securing the left and right nose cap together and to the lower engine nacelle.
- c. Disconnect air ducts from nose caps and remove caps.
- d. Reverse the preceding steps for reinstallation. Ensure the baffle seals are turned in the correct direction to confine and direct air flow around the engine. The vertically installed seals must fold forward and the side seals must fold upwards.

12-4. CLEANING AND INSPECTION. Wipe the inner surfaces of the cowling segments with a clean cloth saturated with cleaning solvent (Stoddard or equivalent). If the inside surface of the cowling is coated heavily with oil or dirt, allow solvent to soak until foreign material can be removed. Wash painted surfaces of the cowling with a solution of mild soap and water and rinse thoroughly. After washing, a coat of wax may be applied to the painted surfaces to prolong paint life. After cleaning, inspect cowling for dents, cracks, loose rivets and spot welds. Repair all defects to prevent spread of damage.

12-5. REPAIR. If cowling skins are extensively damaged, new complete sections of the cowling should be installed. Standard insert-type patches may be used for repair if repair parts are formed to fit contour of cowling. Small cracks may be stop-drilled and small dents straightened if they are reinforced on the inner surface with a doubler of the same material as the cowling skin. Damaged reinforcement angles should be replaced with new parts. Due to their small size, new reinforcement angles are easier to install than to repair the damaged part.

12-6. COWL FLAPS.

12-7. DESCRIPTION. Cowl flaps are provided to aid in controlling engine temperature. Two cowl flaps, operated by a single control in the cabin, are located at the lower aft end of the engine nacelle. The engine exhaust tailpipes extend through cutouts in the aft portion of each cowl flap.

12-8. REMOVAL AND INSTALLATION. (See figure 12-1.)

- a. Place control lever (2) in the OPEN position.
- b. Disconnect control clevises (12) from shock-mounts (13).
- c. Remove safety wire securing hinge pins (9) to cowl flaps, pull pins from hinges and remove flaps.
- d. Reverse the preceding steps for reinstallation. Rig cowl flaps, if necessary, in accordance with paragraph 12-9.

12-9. RIGGING. (See figure 12-1.)

- a. Disconnect control clevises (12) from shock-mounts (13).
- b. Check to make sure that the flexible controls reach their internal stops in each direction. Mark controls so that full travel can be readily checked and maintained during the remaining rigging procedures.
- c. Place control lever (2) in the CLOSED position. If the control lever cannot be placed in the closed position, loosen clamp (5) at upper end of controls and slip housings in clamp or adjust controls at upper clevis (4) to position control lever in bottom hole of position bracket (3).
- d. With the control lever in CLOSED position, hold one cowl flap closed (against the rubber bumpers on the fuselage), loosen jam nut and adjust clevis (12) on the control to hold cowl flap in this position and install bolt.

NOTE

If the lower control clevis (12) cannot be adjusted far enough to streamline flap and still maintain sufficient thread engagement, loosen the lower control housing clamp (8) and slide housing in clamp as necessary. Be sure threads are visible in clevis inspection holes.

- e. Repeat the preceding step for the opposite cowl flap. Cowl flaps should open approximately 5.00 inches when measured in a straight line from the aft edge of door to firewall.
- g. Check that all clamps and jam nuts are tight.

12-10. ENGINE.

12-11. DESCRIPTION. An air cooled, wet-sump, six-cylinder, horizontally-opposed, direct-drive, fuel injected, Continental IO-520-L series engine driving a constant-speed-propeller is used to power the aircraft. The cylinders, numbered from rear to front are staggered to permit a separate throw on the crankshaft for each connecting rod. The right rear cylinder is number 1 and cylinders on the right side are identified by odd numbers 1, 3 and 5. The left rear cylinder is number 2 and the cylinders on the left side are identified as numbers 2, 4 and 6. Refer to paragraph 12-12 for engine data. For repair and overhaul of the engine, accessories and propeller, refer to the appropriate publications issued by their manufacturer's. These publications are available from the Cessna Supply Division.

MODEL 210 & T210 SERIES SERVICE MANUAL

12-12. ENGINE DATA.

Aircraft Series	210
Model (Continental)	IO-520-L
BHP Maximum for Take-Off (5 Minutes) at RPM	300 2850
BHP Maximum Except Take-Off RPM (Max. Continuous)	285 2700
Number of Cylinders	6-Horizontally Opposed
Displacement	520 Cubic Inches
Bore	5.25 Inches
Stroke	4.00 Inches
Compression Ratio	8.5:1
Magnetos	Slick Model 662 thru 1979 Models Slick Model 6210 Beginning with 1980 Models
Right Magneto	Fires 22° BTC Upper Right and Lower Left
Left Magneto	Fires 22° BTC Upper Left and Lower Right
Firing Order	1-6-3-2-5-4
Spark Plugs	18mm (Refer to Continental Service Bulletin M77-10 for factory approved spark plugs and required gap) 330 ±30 LB-IN.
Torque	
Fuel Metering System	Continental Fuel Injection
Unmetered Fuel Pressure	9.0 to 11.0 PSI at 600 RPM 31.0 to 33.0 PSI at 2850 RPM
Nozzle Pressure	3.5 to 4.0 PSI at 600 RPM 17.5 to 18.5 PSI at 2850 RPM
Oil Sump Capacity	10 U.S. Quarts
With External Filter	11 U.S. Quarts
Tachometer	Mechanical Drive
Oil Pressure (PSI)	10
Minimum Idling	30 to 60
Normal	100
Maximum (Cold Oil Starting)	Between No. 2 and No. 4 Cylinders
Connection Location	
Oil Temperature	Within Green Arc
Normal Operating	Red Line (240°F)
Maximum Permissible	Below Oil Cooler
Probe Location	
Cylinder Head Temperature	Within Green Arc
Normal Operating	Red Line (460°F)
Maximum	Lower Side of Number 3 Cylinder thru 21062273
Probe Location	Lower Side of Number 1 Cylinder 21062274 & on Lower Side of Number 4 Cylinder 21064064 & on Without A/C Lower Side of Number 1 Cylinder 21064064 & on With A/C
Economy Mixture Indicator (EGT)	Exhaust Collector L.H. Side
Probe Location	
Approximate Dry Weight	471 LB. (Weight is approximate and will vary with optional accessories installed.)

MODEL 210 & T210 SERIES SERVICE MANUAL

12-12A. TIME BETWEEN OVERHAUL (TBO). Teledyne Continental Motors recommends engine overhaul at 1700 hours operating time for the IO-520-L series engines. Refer to Continental Aircraft Engine Service Bulletin M81-22, and to any superseding bulletins, revisions or supplements thereto, for further recommendations. At the time of overhaul, engine accessories should be overhauled. Refer to Section 14 for propeller and governor overhaul periods.

12-12B. OVERSPEED LIMITATIONS. The engine must not be operated above specified maximum continuous RPM. However, should inadvertent overspeed occur, refer to Continental Aircraft Engine Service Bulletin M75-16, and to any superseding bulletins, revisions or supplements thereto, for further recommendations.




Figure 12-1. Cowl Flaps Installation

MODEL 210 & T210 SERIES SERVICE MANUAL

12-13. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
ENGINE FAILS TO START.	Improper use of starting procedure.	Refer to Pilot's Operating Handbook
	Defective aircraft fuel system.	Refer to Section 13.
	Spark plugs fouled.	Remove and clean. Check gaps and insulators. Use new gaskets. Check cables to persistently fouled plugs.
	Defective magneto switch or grounded magneto leads.	Check continuity, repair or replace switch or leads.
	Defective ignition system.	Refer to paragraph 12-79.
	Excessive induction air leaks.	Check visually. Correct cause of air leaks.
	Dirty screen in fuel control unit or defective fuel control unit.	Check screen visually. Check fuel flow through control unit. Replace defective fuel control unit.
	Defective electric fuel pump.	Refer to Section 13.
	Defective fuel manifold valve or dirty screen.	Check fuel flow through valve. Remove and clean. Replace if defective.
	Clogged fuel injection lines or discharge nozzles.	Check fuel through lines and nozzles. Clean lines and nozzles. Replace if defective.
	Fuel pump not permitting fuel from auxiliary pump to bypass.	Check fuel flow through engine-driven fuel pump. Replace engine-driven pump.
	Vaporized fuel in system.	Refer to Pilot's Operating Handbook
	Fuel tanks empty.	Visually inspect tanks. Fill with proper grade and quantity of gasoline.
	Fuel contamination or water in fuel system.	Open fuel strainer drain and check for water. Drain all fuel and flush out fuel system. Clean all screens, fuel lines, strainer, etc.
	Mixture control in the IDLE CUT-OFF position.	Move control to the full RICH position.
Engine flooded.	Refer to Pilot's Operating Handbook	
Fuel selector valve in OFF position. (Thru Serial 21064535).	Place selector valve in the ON position to a cell known to contain gasoline.	
Fuel ON-OFF valve in OFF position (21064536 and on).	Place valve in ON position.	

MODEL 210 & T210 SERIES SERVICE MANUAL

12-13. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
ENGINE STARTS BUT DIES, OR WILL NOT IDLE.	Idle stop screw or idle mixture incorrectly adjusted.	Refer to paragraph 12-46.
	Spark plugs fouled or improperly gapped.	Remove, clean and regap plugs. Replace if defective.
	Water in fuel system.	Open fuel strainer drain and check for water. If water is present, drain fuel tank sumps, lines and strainer.
	Defective ignition system.	Refer to paragraph 12-79.
	Vaporized fuel. (Most likely to occur in hot weather with a hot engine.)	Refer to Pilot's Operating Handbook
	Induction air leaks.	Check visually. Correct the cause of leaks.
	Manual primer leaking.	Disconnect primer outlet line. If fuel leaks through primer, repair or replace primer.
	Dirty screen in fuel control unit or defective fuel control unit.	Check screen visually. Check fuel flow through control unit. Clean screen. Replace fuel control unit if defective.
	Defective manifold valve or clogged screen.	Check fuel flow through valve. Replace if defective. Clean screen.
	Defective engine-driven fuel pump.	If engine continues to run with electric pump turned on, but stops when it is turned off, the engine-driven pump is defective. Replace pump.
	Defective engine.	Check compression. Listen for unusual engine noises. Engine repair is required.
	Propeller control set in high pitch position (low RPM).	Use low pitch (high RPM) position for all ground operation.
	Defective aircraft fuel system.	Refer to Section 13.
ENGINE RUNS ROUGHLY, WILL NOT ACCELERATE PROPERLY, OR LACKS POWER.	Restricted fuel injection lines or discharge nozzles.	Check fuel flow through lines and nozzles. Clean lines and nozzles. Replace if defective.
	Propeller control in high pitch (low RPM) position.	Use low pitch (high RPM) for all ground operations.
	Restriction in aircraft fuel system.	Refer to Section 13.
	Restriction in fuel injection system.	Clean system. Replace any defective units.

MODEL 210 & T210 SERIES SERVICE MANUAL

12-13. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
ENGINE RUNS ROUGHLY. WILL NOT ACCELERATE PROPERLY, OR LACKS POWER. (Cont.)	Engine-driven fuel pump pressure improperly adjusted.	Refer to paragraph 12-61.
	Worn or improperly rigged throttle or mixture control.	Check visually. Rig properly. Replace worn linkage.
	Spark plugs fouled or improperly gapped.	Clean and regap. Replace if defective.
	Defective ignition system.	Refer to paragraph 12-79.
	Defective engine.	Check compression. Listen for unusual engine noises. Engine repair is required.
POOR IDLE CUT-OFF.	Worn or improperly rigged mixture control.	Rig properly. Replace worn linkage.
	Defective or dirty manifold valve.	Operate electric fuel pump and check that no fuel flows through manifold valve with mixture control in IDLE CUT-OFF. Remove and clean. Replace if defective.
	Fuel leakage through primer.	Repair or replace primer.
	Auxiliary fuel pump ON.	Turn to OFF position.
	Defective fuel control unit.	If none of the preceding causes corrects the problem, the control unit is probably at fault. Replace control unit.

12-13A. STATIC RUN-UP PROCEDURES. In a case of suspected low engine power, a static RPM run-up should be conducted as follows:

- a. Run-up engine, using take-off power and mixture settings, with the aircraft facing 90° right and then left to the wind direction.
- b. Record the RPM obtained in each run-up position.

NOTE

Daily changes in atmospheric pressure, temperature and humidity will have a slight effect on static run-up.

- c. Average the results of the RPM obtained. It should be within 50 RPM of 2825 RPM.
- d. If the average results of the RPM obtained are lower than stated above, the following recommended checks may be performed to determine a possible deficiency.
 1. Check governor control for proper rigging. It should be determined that the governor control arm travels to the high RPM stop on the governor and that the high RPM stop screw is adjusted properly. (Refer to Section 14 for procedures).

NOTE

If verification of governor operation is necessary the governor may be removed from the engine and a flat plate installed over the engine pad. Run-up engine to determine that governor was adjusted properly.

2. Check operation of alternate air door spring or magnetic lock.
3. Check magneto timing, spark plugs and ignition harness for settings and conditions.
4. On fuel injection engines, check fuel injection nozzles for restriction and check for correct unmetered fuel flow.
5. Check condition of induction air filter. Clean if required.
6. Perform an engine compression check (Refer to engine Manufacturer's Manual).

12-14. REMOVAL. If an engine is to be placed in storage or returned to the manufacturer for over-

MODEL 210 & T210 SERIES SERVICE MANUAL

haul, proper preparatory steps should be taken for corrosion prevention prior to beginning the removal procedure. Refer to Section 2 for storage preparation. The following engine removal procedure is based upon the engine being removed from the aircraft with the lines and hoses being disconnected at the firewall.

NOTE

Tag each item when disconnected to aid in identifying wires, hoses, lines and control linkages when engine is reinstalled. Likewise, shop notes made during removal will often clarify reinstallation. Protect openings, exposed as a result of removing or disconnecting units, against entry of foreign material by installing covers or sealing with tape.

- a. Place all cabin switches in the OFF position.
- b. Place fuel selector valve on fuel ON-OFF control in the OFF position.
- c. Remove engine cowling in accordance with paragraph 12-3.
- d. Disconnect battery cables and insulate terminals as a safety precaution.
- e. Drain fuel strainer and lines.

NOTE

During the following procedures, remove any clamps or lacings which secure controls, wires, hoses or lines to the engine, engine nacelle or attached brackets, so they will not interfere with engine removal. Some of the items listed can be disconnected at more than one place. It may be desirable to disconnect some of these items at other than the places indicated. The reason for engine removal should be the governing factor in deciding at which point to disconnect them. Omit any of the items which are not present on a particular engine installation.

- f. Drain the engine oil sump and oil cooler.
- g. Disconnect magneto primary lead wires at magnetos.

WARNING

The magnetos are in a SWITCH ON condition when the switch wires are disconnected. Ground the magneto points or remove the high tension wires from the magnetos or spark plugs to prevent accidental firing.

- h. Remove the spinner and propeller in accordance with Section 14. Cover exposed end of crankshaft flange and propeller flange to prevent entry of foreign material.

1. Disconnect throttle, mixture and propeller controls from their respective units. Remove clamps

attaching controls to engine and pull controls aft clear of engine. Use care to avoid bending controls too sharply. Note EXACT position, size and number of attaching washers and spacers for reference on reinstallation.

- j. Disconnect all hot and cold air flexible ducts and remove.
- k. Remove exhaust system in accordance with paragraph 12-97.
- l. Disconnect wires and cables as follows:
 1. Disconnect tachometer drive shaft at adapter.

CAUTION

When disconnecting starter cable do not permit starter terminal bolt to rotate. Rotation of the bolt could break the conductor between bolt and field coils causing the starter to be inoperative.

2. Disconnect starter electrical cable at starter.
3. Disconnect cylinder head temperature wire at probe.
4. Disconnect oil temperature wire at probe below oil cooler.
5. Disconnect electrical wires and wire shielding ground at alternator.
6. Disconnect exhaust gas temperature wires at quick-disconnects.
7. Disconnect electrical wires at throttle micro-switches.
8. Remove all clamps and lacings attaching wires or cables to engine and pull wires and cables aft to clear engine.
- m. Disconnect lines and hoses as follows:
 1. Disconnect vacuum hose at firewall.
 2. Disconnect oil breather and vacuum system oil separator vent lines where secured to the engine.

WARNING

Residual fuel and oil draining from disconnected lines and hoses constitutes a fire hazard. Use caution to prevent accumulation of such fuel and oil when lines or hoses are disconnected.

3. Disconnect fuel supply and vapor return hoses at fuel pump.
4. Disconnect primer line at firewall fitting.
5. Disconnect fuel-flow gage hose at firewall.
6. Disconnect oil pressure line at firewall fitting.
7. Disconnect manifold pressure hose at firewall.
8. Disconnect manifold and balance tube drain lines.
- n. Carefully check the engine again to ensure ALL hoses, lines, wires, cables, clamps and lacings are disconnected or removed which would interfere with the engine removal. Ensure all wires, cables and engine controls have been pulled aft to clear the engine.

MODEL 210 & T210 SERIES SERVICE MANUAL

CAUTION

Place a suitable stand under tail tie-down ring before removing engine. The loss of engine weight will cause the aircraft to be tail heavy.

- o. Attach a hoist to the lifting lug at the top center of the engine crankcase. Lift engine just enough to relieve the weight from the engine mounts.
- p. Remove bolts, ground strap and heat deflectors.
- q. Slowly hoist engine out of nacelle and clear of aircraft checking for any items which would interfere with the engine removal. Balance the engine by hand and carefully guide the disconnected parts out as the engine is removed.
- r. Remove engine shock-mounts and ground strap.

NOTE

If shock-mounts will be reused, mark each one so it will be reinstalled in exactly the same position. If new shock-mounts will be installed, position them as illustrated in figure 12-2.

12-15. **CLEANING.** Clean engine in accordance with instructions in Section 2.

12-16. **ACCESSORIES REMOVAL.** Removal of engine accessories for overhaul or for engine replacement involves stripping the engine of parts, accessories and components to reduce it to the bare engine. During the removal process, removed items should be examined carefully and defective parts should be tagged for repair or replacement with new components.

NOTE

Items easily confused with similar items should be tagged to provide a means of identification when being installed on a new engine. All openings exposed by the removal of an item should be closed by installing a suitable cover or cap over the opening. This will prevent entry of foreign material. If suitable covers are not available, tape may be used to cover the openings.

12-17. **INSPECTION.** For specific items to be inspected, refer to the engine manufacturer's manual.

- a. Visually inspect the engine for loose nuts, bolts, cracks and fin damage.
- b. Inspect baffles, baffle seals and brackets for cracks, deterioration and breakage.
- c. Inspect all hoses for internal swelling, chafing

through protective plys, cuts, breaks, stiffness, damaged threads and loose connections. Excessive heat on hoses will cause them to become brittle and easily broken. Hoses and lines are most likely to crack or break near the end fittings and support points.

- d. Inspect for color bleaching of the end fitting or severe discoloration of the hoses.

NOTE

Avoid excessive flexing and sharp bends when examining hoses for stiffness.

- e. Refer to Section 2 for replacement intervals for flexible fluid carrying hoses in the engine compartment.
- f. For major engine repairs, refer to the engine manufacturer's overhaul and repair manual.

12-18. **BUILDUP.** Engine buildup consists of installation of parts, accessories and components to the basic engine to build up an engine unit ready for installation on the aircraft. All safety wire, lock-washers, nuts, gaskets and rubber connections should be new parts.

12-19. **INSTALLATION.** Before installing the engine on the aircraft, install any items which were removed from the engine or aircraft after the engine was removed.

NOTE

Remove all protective covers, plugs, caps and identification tags as each item is connected or installed. Omit any items not present on a particular engine installation.

- a. Hoist the engine to a point just above the nacelle.
- b. Install engine shock-mounts and ground strap as illustrated in figure 12-2.
- c. Carefully lower engine slowly into place on the engine mounts. Route controls, lines, hoses and wires in place as the engine is positioned on the engine mounts.


NOTE

Be sure engine shock-mounts, spacers and washers are in place as the engine is lowered into position.

- d. Install engine-to-mount bolts, then remove the hoist and support stand placed under tail tie-down fitting. Torque bolts to 300 +50 -0 lb-in.
- e. Route throttle, mixture and propeller controls to their respective units and connect. Secure controls in position with clamps.

MODEL 210 & T210 SERIES SERVICE MANUAL

REINFORCED MOUNTS CONTAIN MOULDED-IN WASHER AT THIS LOCATION



LEFT REAR ONLY

Detail A

NOTES

ON ALL MODELS:

It is important that the correct engine mounts be installed in the correct positions. Install upper mounts with beveled edge at the top, except as noted below for turbocharged engines. Install lower mounts with beveled edge at the front, except as noted below for turbocharged engines. In addition, be sure that the two reinforced mounts are used at the upper, forward positions.

To determine which two of the eight mounts are the reinforced ones, use fingernail to feel whether moulded-in washer is present.

Torque bolts (1) to 300 +50 -00 lb-in.

ON TURBOCHARGED ENGINES:

Barrel nuts (8) are replaced with turbine support shafts at the right mounts of turbocharged engines.

Install left, forward, lower mount with beveled edges at the front and at the top on turbocharged engines.

If shock-mounts will be re-used, mark each one so it will be reinstalled in exactly the same position. If new shock-mounts will be installed, position them as noted above.

1. Bolt
2. Ground Strap
3. Tab Lockwasher
4. Lower Mount
5. Engine Mount Support
6. Spacer
7. Upper Mount
8. Barrel Nut
9. Heat Shield




Figure 12-2. Engine Mount Installation

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

Throughout the aircraft fuel system, from the fuel bays to the engine-driven fuel pump, use NS-40 (RAS-4) (Snap-On Tools Corp., Kenosha, Wisconsin), MIL-T-5544 (Thread Compound, Antiseize, Graphite Petrolatum), USP Petrolatum or engine oil as a thread lubricant or to seal a leaking connection. Apply sparingly to male threads only, omitting the first two threads, exercising extreme caution to avoid "stringing" sealer across the end of the fitting. Always ensure that a compound, the residue from a previously used compound, or any other foreign material cannot enter the system. Throughout the fuel injection system, from the engine-driven fuel pump through the discharge nozzles, use only a fuel-soluble lubricant, such as engine oil, on fitting threads. Do not use any other form of thread compound on the injection system.

- f. Connect lines and hoses as follows:
 1. Connect manifold and balance tube drain lines.
 2. Connect manifold pressure hose at firewall.
 3. Connect oil pressure line at firewall fitting.
 4. Connect fuel-flow gage hose at firewall.
 5. Connect primer line at firewall fitting.
 6. Connect fuel supply and vapor return hose at pump.
 7. Connect oil breather and vacuum system oil separator vent lines where secured to the engine.
 8. Connect vacuum hose at firewall.
 9. Install clamps and lacings securing hoses and lines to the engine to prevent chafing.
- g. Connect wires and cables as follows:
 1. Connect electrical wires and wire shielding ground at alternator.
 2. Connect cylinder head temperature wire at probe.

CAUTION

When connecting starter cable, do not permit starter terminal bolt to rotate. Rotation of the bolt could break the conductor between bolt and field coils causing the starter to be inoperative.

3. Connect starter electrical cable at starter.
4. Connect tachometer drive shaft at adapter. Be sure drive cable engages drive in adapter. Torque housing attach nut to 100-lb.in.
5. Connect exhaust gas temperature wires at quick-disconnects.
6. Connect electrical wires at throttle micro-switches.
7. Connect oil temperature wire to probe below oil cooler.
8. Install clamps and lacings securing wires and cables to engine, engine mount and brackets.
- h. Install exhaust system in accordance with paragraph 12-97.

- i. Connect all hot and cold air flexible ducts.
- j. Install propeller and spinner in accordance with instructions outlined in Section 14.
- k. Complete a magneto switch ground-out and continuity check, then connect primary lead wires to the magnetos. Remove the temporary ground or connect spark plug leads, whichever procedure was used during removal.

WARNING

Be sure magneto switch is in OFF position when connecting switch wires to magnetos.

- l. Clean and install induction air filter in accordance with Section 2.
- m. Service engine with proper grade and quantity of engine oil. Refer to Section 2 if engine is new, newly overhauled or has been in storage.
- n. Check all switches are in the OFF position and connect battery cables.
- o. Rig engine controls in accordance with paragraphs 12-85, 12-86, 12-87 and 12-88.
- p. Inspect engine installation for security, correct routing of controls, lines, hoses and electrical wiring, proper safetying and tightness of all components.
- q. Install engine cowling in accordance with paragraph 12-3.
- r. Perform an engine run-up and make final adjustments on the engine controls.

12-20. FLEXIBLE FLUID HOSES.

- 12-21. PRESSURE TEST. Refer to Section 2 for pressure test intervals. Perform pressure test as follows:
- a. Place mixture control in the idle cut-off position.
 - b. Operate the auxiliary fuel pump in the high position.
 - c. Examine the exterior of hoses for evidence of leakage or wetness.
 - d. Hoses found leaking should be replaced.
 - e. After pressure testing fuel hoses, allow sufficient time for excess fuel to drain overboard from the engine manifold before attempting an engine start.
 - f. Refer to paragraph 12-17 for detailed inspection procedures for flexible hoses.

12-22. REPLACEMENT.

- a. Hoses should not be twisted on installation. Pressure applied to a twisted hose may cause failure or loosening of the nut.
- b. Provide as large a bend radius as possible.
- c. Hoses should have a minimum of one-half inch clearance from other lines, ducts, hoses or surrounding objects or be butterfly clamped to them.
- d. Rubber hoses will take a permanent set during extended use in service. Straightening a hose with a bend having a permanent set will result in hose cracking. Care should be taken during removal so that hose is not bent excessively, and during reinstallation to assure hose is returned to its original position.
- e. Refer to Advisory Circular 43.13, Chapter 10, for additional installation procedures for flexible fluid hose assemblies.

MODEL 210 & T210 SERIES SERVICE MANUAL

12-23. ENGINE BAFFLES.

12-24. DESCRIPTION. The sheet metal baffles installed on the engine direct the flow of air around the cylinders and other engine components to provide optimum cooling. These baffles incorporate rubber-asbestos composition seals at points of contact with the engine cowling and other engine components to help confine and direct the airflow to the desired area. It is very important to engine cooling that the baffles and seals are in good condition and installed correctly. The vertical seals must fold forward and the side seals must fold upwards. Removal and installation of the various baffle segments is possible with the cowling removed. Be sure that any new baffles seal properly.

12-25. CLEANING AND INSPECTION. The engine baffles should be cleaned with a suitable solvent to remove oil and dirt.

NOTE

The rubber-asbestos seals are oil and grease resistant but should not be soaked in solvent for long periods.

Inspect baffles for cracks in the metal and for loose and/or torn seals. Repair or replace any defective parts.

12-26. REMOVAL AND INSTALLATION. Removal and installation of the various baffle segments is possible with the cowling removed. Be sure that any replaced baffles and seals are installed correctly and that they seal to direct the airflow in the correct direction. Various lines, hoses, wires and controls are routed through some baffles. Make sure that these parts are reinstalled correctly after installation of baffles.

12-27. REPAIR. Repair of an individual segment of engine baffle is generally impractical, since, due to the small size and formed shape of the part, replacement is usually more economical. However, small cracks may be stop-drilled and a reinforcing doubler installed. Other repairs may be made as long as strength and cooling requirements are met. Replace sealing strips if they do not seal properly.

12-28. ENGINE OIL SYSTEM.

12-29. DESCRIPTION. The oil system is of the full pressure wet sump type. Refer to applicable engine manufacturer's overhaul manual for specific details and descriptions.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

12-30. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
NO OIL PRESSURE.	No oil in sump.	Check with dipstick. Fill sump with proper grade and quantity of oil. Refer to Section 2.
	Oil pressure line broken, disconnected or pinched.	Inspect pressure lines. Replace or connect lines as required.
	Oil pump defective.	Remove and inspect. Examine engine. Metal particles from damaged pump may have entered engine oil passages.
	Defective oil pressure gage.	Check with a known good gage. If second reading is normal, replace gage.
	Oil congealed in gage line.	Disconnect line at engine and gage; flush with kerosene. Pre-fill with kerosene and install.
	Relief valve defective.	Remove and check for dirty or defective parts. Clean and install; replace valve if defective.
LOW OIL PRESSURE.	Low oil supply.	Check with dipstick. Fill sump with proper grade and quantity of oil. Refer to Section 2.
	Low viscosity oil.	Drain sump and refill with proper grade and quantity of oil.
	Oil pressure relief valve spring weak or broken.	Remove and inspect spring. Replace weak or broken spring.
	Defective oil pump.	Check oil temperature and oil level. If temperature is higher than normal and oil level is correct, internal failure is evident. Remove and inspect. Examine engine. Metal particles from damaged pump may have entered oil passages.
	Secondary result of high oil temperature.	Observe oil temperature gage for high indication. Determine and correct reason for high oil temperature.
	Dirty oil screens.	Remove and clean oil screens.

MODEL 210 & T210 SERIES SERVICE MANUAL

12-30. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
HIGH OIL PRESSURE.	High viscosity oil.	Drain sump and refill with proper grade and quantity of oil.
	Relief valve defective.	Remove and check for dirty or defective parts. Clean and install; replace valve if defective.
	Defective oil pressure gage.	Check with a known good gage. If second reading is normal, replace gage.
LOW OIL TEMPERATURE.	Defective oil temperature gage or temperature bulb.	Check with a known good gage. If second reading is normal, replace gage. If reading is similar, the temperature bulb is defective.
	Oil cooler thermostatic bypass valve defective or stuck.	Remove valve and check for proper operation. Replace valve if defective.
HIGH OIL TEMPERATURE.	Oil cooler air passages clogged.	Inspect cooler core. Clean air passages.
	Oil cooler oil passages clogged.	Drain oil cooler and inspect for sediment. Remove cooler and flush thoroughly.
	Thermostatic bypass valve damaged or held open by solid matter.	Feel front of cooler core with hand. If core is cold, oil is bypassing cooler. Remove and clean valve and seat. If still inoperative, replace.
	Low oil supply.	Check with dipstick. Fill sump with proper grade and quantity of oil. Refer to Section 2.
	Oil viscosity too high.	Drain sump and refill with proper grade and quantity of oil.
	Prolonged high speed operation on the ground.	Hold ground running above 1500 rpm to a minimum.
	Defective oil temperature gage.	Check with a known good gage. If second reading is normal. Replace gage.
	Defective oil temperature bulb.	Check for correct oil pressure, oil level and cylinder head temperature. If they are correct, check oil temperature gage for being defective; if similar reading is observed, bulb is defective. Replace bulb.

MODEL 210 & T210 SERIES SERVICE MANUAL

12-30. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
HIGH OIL TEMPERATURE (Cont.)	Secondary effect of low oil pressure.	Observe oil pressure gage for low indication. Determine and correct reason for low oil pressure.
	Oil congealed in cooler.	This condition can occur only in extremely cold temperatures. If congealing is suspected, use an external heater or a heated hangar to warm the congealed oil.
OIL LEAK AT FRONT OF ENGINE.	Damaged crankshaft seal.	Replace.
OIL LEAK AT PUSH ROD HOUSING.	Damaged push rod housing oil seal.	Replace.

12-31. FULL-FLOW OIL FILTER.

12-32. DESCRIPTION. An external oil filter may be installed on the engine. The filter and filter adapter replace the engine oil pressure screen. Beginning with the 1980 models a spin-on filter is used, previous models used a replacement filter element and filter can. The filter adapter incorporates a bypass valve which will open allowing pressure oil from the oil pump to flow to the engine oil passages if the oil filter should become clogged on prior to 1980 models. The 1980 models have the bypass valve in the spin-on oil filters.

12-33. REMOVAL AND INSTALLATION (FILTER ELEMENT) (See figure 12-4).

NOTE

Filter element replacement kits and spin-on filters are available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations.

- a. Remove engine cowling in accordance with paragraph 12-3.
- b. Remove both safety wires from filter can and unscrew hollow stud (1) to detach filter assembly from adapter (11) as a unit. Remove filter assembly from aircraft and discard gasket (9). Oil will drain from filter as assembly is removed from adapter.
- c. Press downward on hollow stud (1) to remove from filter element (5) and can (4). Discard metal gasket (2) on stud (1).
- d. Lift lid (7) off can (4) and discard lower gasket (6).
- e. Pull filter element (5) out of can (4).

NOTE

Before discarding removed filter element (5), remove the outer perforated paper cover; using a sharp knife, cut through the folds of the filter element at both ends. Then, carefully unfold the pleated element and examine the material trapped in the element for evidence of internal engine damage, such as chips or particles from bearings. In new or newly overhauled engines, some small particles or metallic shavings might be found, these are generally of no consequence and should not be confused with particles produced by impacting, abrasion or pressure. Evidence of internal damage found in the oil filter element justifies further examination to determine the cause.

- f. Wash lid (7), hollow stud (1), and can (4) in solvent and dry with compressed air.

NOTE

When installing a new filter element (5), it is important that all gaskets are clean, lubricated and positioned properly. Apply a thin coating of Dow Corning compound, DC-4, on the base gasket by brushing or wiping. Also check that the correct amount of torque is applied to the hollow stud (1). If the stud is under-torqued, oil leakage will occur. If the stud is over-torqued, the filter can might possibly be deformed, again causing oil leakage.

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

Do NOT substitute automotive gaskets for any gaskets used in this assembly. Use only approved gaskets listed in the Parts Catalogs.




Figure 12-4. Full-Flow Oil Filter

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 12-5. Oil Filter Adapter Wrench Fabrication

- Lubricate all rubber grommets in the new filter element, lid gaskets and metal gasket with clean engine oil or general purpose grease before installation. Dry gaskets may cause false torque readings, again resulting in oil leaks.
 - Before assembly, place a straight edge across the bottom of the filter can. Check for distortion or out-of-flat condition greater than 0.010 inch. Install a new filter can if either of these conditions exist.
 - After installing a new gasket on the lid, turn lid over. If gasket falls off, try a different gasket and repeat test. If this gasket falls off, install a new lid.
- g. Inspect the adapter gasket seat for gouges, deep scratches, wrench marks and mutilation. If any of these conditions are found, install a new adapter.
- h. Place a new filter element (5) in can (4) and insert the hollow stud (1) with a new metal gasket (2) in place, through the filter can and element.
- i. Position a new gasket (6) inside flange of lid (7) and place lid in position on filter can.
- j. With a new gasket (9) on face of lid, install filter can assembly on adapter (11). While holding filter can to prevent turning, tighten hollow stud (1) and torque to 20-25 lb-ft (240-300 lb-in), using a torque wrench.
- k. Install all parts removed for access and service the engine with the proper grade and quantity of engine oil. One additional quart of oil is required each time the filter element is changed.
- l. Start engine and check for proper oil pressure. Check for oil leakage after warming up the engine.
- m. Again check for oil leakage after engine has been run at high power setting.
- n. Check to make sure filter can has not been making contact with any adjacent parts due to engine torque.
- o. While engine is still warm, recheck torque on hollow stud (1) then safety stud to lower tab (3) on filter can and safety adapter (11) to upper tab on filter can.
- 12-33A. FULL-FLOW OIL FILTER. BEGINNING WITH SERIAL 21064136.**
- 12-33B. DESCRIPTION.** A disposable, spin-on oil filter attaches to a threaded fitting on either an add-on type adapter (See figure 12-4) or an integral adapter on the oil pump casting. The filter contains an internal bypass valve.
- 12-33C. REMOVAL.**
- a. Remove engine cowl in accordance with paragraph 12-3.
 - b. Cut safety wire and turn filter counterclockwise to remove it from the adapter.
- NOTE
- Before discarding filter, remove filter element

MODEL 210 & T210 SERIES SERVICE MANUAL

from can and cut off both ends. Carefully unfold the element and inspect for evidence of internal engine damage such as chips or metal from bearings. In new or newly overhauled engines chips and bearing metal may be found, and generally are of no consequence. However, particles produced by impact, abrasion, or pressure are evidence of internal engine damage and justify further examination to determine the cause.

12-33D. INSTALLATION.

- a. Lightly lubricate filter gasket with engine oil or Dow Corning Compound (DC-4).
- b. Attach filter to adapter by turning clockwise until it contacts base of adapter; then tighten $\frac{3}{4}$ to one turn or torque to 15 to 20 FT-LBS. Safety wire.
- c. Start engine and check for proper oil pressure; warm up engine and check for filter leakage.
- d. Check that engine torque does not cause filter to contact adjacent parts.
- e. Replace engine cowl in accordance with paragraph 12-3.
- f. Check oil level and filter leakage after operating engine at high power setting, or after a flight around the field.

12-34. FILTER ADAPTER. 210 THRU SERIAL 21064780, T210 THRU SERIAL 21064781.

12-35. REMOVAL. (Refer to figure 12-4.)

- a. Remove filter assembly in accordance with paragraph 12-33.

NOTE

A special wrench adapter for adapter nut (13) (Part No. SE-709) is available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations, or one may be fabricated as shown in figure 12-5. Remove any engine accessory that interferes with removal of the adapter.

- b. Note angular position of adapter (11), then remove safety wire and loosen adapter nut (13).
- c. Unscrew adapter and remove from engine. Discard adapter O-ring (14).

12-36. DISASSEMBLY, INSPECTION AND REASSEMBLY. Figure 12-4 shows the relative position of the internal parts of the filter adapter and may be used as a guide during installation of parts. The bypass valve is to be installed as a complete unit, with the valve being staked three places. The heli-coil type insert (8) in the adapter may be replaced, although special tools are required. Follow instructions of the tool manufacturer for their use. Inspect threads on adapter and engine for damage. Clean adapter in solvent and dry with compressed air. Make sure all passages in the adapter are open and free of dirt. Check that bypass valve is seating properly.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 12-6. Fuel Injection Schematic

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 12-7. Idle Speed and Idle Mixture Adjustment

on adapter and in engine for damage. Clean adapter in solvent and dry with compressed air. Ascertain that all passages in the adapter are open and free of foreign material. Also, check that bypass valve is seated properly.

12-37. INSTALLATION.

a. Assemble adapter nut (14) and new O-ring (15) on adapter (11) in sequence illustrated in figure 12-4.

b. Lubricate O-ring on adapter with clean engine oil. Tighten adapter nut until O-ring is centered in its groove on the adapter.

c. Apply anti-seize compound sparingly to the adapter threads, then simultaneously screw adapter and adapter nut into engine until O-ring seats against engine boss without turning adapter nut (14). Rotate adapter to approximate angular position noted during removal. Do not tighten adapter nut at this time.

d. Temporarily install filter assembly on adapter, and position so adequate clearance with adjacent parts is attained. Maintaining this position of the adapter, tighten adapter nut to 50-60 lb-ft (600-720 lb-in.) and safety. Use a torque wrench, extension and adapter as necessary when tightening adapter nut.

e. Using new gaskets, install filter assembly as outlined in paragraph 12-33. Be sure to service the engine oil system.

12-37A. FILTER ADAPTER. 210, BEGINNING WITH 21064781; T210 BEGINNING WITH 21064782. The oil filter adapter is an integral part of the oil pump casting, located at the rear of the engine on the right side.

12-38. OIL COOLER.

12-39. DESCRIPTION. A non-congealing oil cooler may be installed on the aircraft. Ram air passes through the oil cooler and is discharged into the engine compartment. Oil circulating through the engine is allowed to circulate continuously through warm-up passages to prevent the oil from congealing when operating in low temperatures. On the standard and non-congealing oil coolers, as the oil increases to a certain temperature, the thermostat valve closes, causing the oil to be routed to all of the cooler passages for cooling. Oil returning to the engine from the cooler is routed through the internally drilled oil passages.

12-40. ENGINE FUEL SYSTEM. (Refer to figure 12-6.)

12-41. DESCRIPTION. The fuel injection system is a low pressure system of injecting fuel into the intake valve port of each cylinder. It is a multi-nozzle, continuous-flow type which controls fuel flow to match engine airflow. Any change in throttle position, engine speed, or a combination of both, causes changes in fuel flow in the correct relation to engine airflow. A manual mixture control and a fuel flow indicator are provided for leaning at any combination of altitude and power setting. The fuel flow indicator is calibrated in gallons per hour and indicates approximately the gallons of fuel consumed per hour. The continuous-flow system uses a typical rotary vane fuel pump. There are no running parts in this system except for the engine-driven fuel pump.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 12-8. Fuel Injection Pump Adjustment Test Harness

NOTE

Throughout the aircraft fuel system, from the fuel bays to the engine-driven pump, use NS-40 (RAS-4) (Snap-On-Tools Corp., Kenosha, Wisconsin), MIL-T-5544 (Thread Compound Antiseize, Graphite Petrolatum), USP Petrolatum or engine oil as a thread lubricator or to seal a leaking connection. Apply sparingly to male threads only, omitting the first two threads, exercising extreme caution to avoid "stringing" sealer across the end of the fitting. Always ensure that a compound, the residue from a previously used compound, or any other foreign material cannot enter the system.

12-42. FUEL-AIR CONTROL UNIT.

12-43. DESCRIPTION. This unit occupies the position ordinarily used for a carburetor, at the intake manifold inlet. The function of this unit is to control engine air intake and to set the metered fuel pressure for proper fuel-air ratio. There are three control elements in this unit, one for air and two for fuel. One of the fuel control elements is for fuel mixture and the other is for fuel metering. Fuel enters the control unit through a strainer and passes to the metering valve. The position of the metering valve controls this fuel passed to the manifold valve and nozzles. A linkage connecting the metering valve to the air throttle proportions airflow to fuel flow. The position of the mixture valve determines the amount of fuel returned to the fuel pump. The fuel control portion of the fuel-air control unit is enclosed in a shroud and is blast-air cooled to help prevent vapor lock.

MODEL 210 & T210 SERIES SERVICE MANUAL

12-44. REMOVAL AND INSTALLATION.

- a. Place all cabin switches and fuel selector or fuel ON-OFF valve in the OFF position.
- b. Remove cowling in accordance with paragraph 12-3.
- c. Remove induction airbox in accordance with paragraph 12-65.
- d. Disconnect engine controls at throttle and mixture control arms.

NOTE

Cap all disconnected hoses, lines and fittings.

e. The three fuel lines which attach to the fuel control unit are routed inside flexible tubing to help cool the fuel. Loosen tubing clamps at the control unit and slide tubing back to gain access to the fuel line fittings.

- f. Disconnect fuel lines at control unit.
- g. Loosen hose clamps which secure the control unit to the right and left intake manifolds.
- h. Remove control unit.
- i. Cover the open ends of the intake manifold piping to prevent entry of foreign matter.
- j. Reverse the preceding steps for reinstallation. Use new gaskets when installing control unit. Rig throttle and mixture controls in accordance with paragraphs 12-85 and 12-86 respectively. Rig throttle-operated microswitch in accordance with Section 13.

12-45. CLEANING AND INSPECTION.

- a. Check control connections, levers and linkage for security, safetying and for lost motion due to wear.
- b. Remove the fuel screen assembly and clean in solvent (Stoddard or equivalent). Reinstall and safety.
- c. Check the air control body for cracks and control unit for overall condition.

12-46. ADJUSTMENTS. (Refer to figure 12-7.) The idle speed adjustment is a conventional spring-loaded screw located in the air throttle lever. The idle mixture adjustment is the locknut at the metering valve end of the linkage. Tightening the nut to shorten the linkage provides a richer mixture. A leaner mixture is obtained by backing off the nut to lengthen the linkage. Idle speed and mixture adjustment should be accomplished after the engine has been warmed up. Since idle rpm may be affected by idle mixture adjustment, it may be necessary to readjust idle rpm after setting the idle mixture correctly.

- a. Set the throttle stop screw to obtain 600 ± 25 rpm, with throttle control pulled full out against idle stop.

NOTE

Engine idle speed may vary among different engines. An engine should idle smoothly, without excessive vibration and the idle speed should be high enough to maintain idling oil pressure and to preclude any possibility of engine stoppage in flight when the throttle is closed.

b. Advance throttle to increase engine speed to 1000 rpm.

c. Pull mixture control knob slowly and steadily toward the idle cut-off position, observing tachometer, then return control full IN (RICH) position before engine stops.

d. Adjust mixture adjusting nut to obtain a slight and momentary gain of 25 to 50 rpm at 1000 rpm engine speed as mixture control is moved from full IN (RICH) toward idle cut-off position. Return control to full IN (RICH) to prevent engine stoppage.

e. If mixture is set too LEAN, engine speed will drop immediately, thus requiring a richer mixture. Tighten adjusting nut (clockwise) for a richer mixture.

f. If mixture is set too RICH, engine speed will increase above 50 rpm, thus requiring a leaner mixture. Back off adjusting nut (counterclockwise) for a leaner mixture.

NOTE

After each adjustment to the idle mixture, run engine up to approximately 2000 rpm to clear engine of excess fuel to obtain a correct idle speed.

12-47. FUEL MANIFOLD VALVE (FUEL DISTRIBUTOR).

12-48. DESCRIPTION. Metered fuel flows to the fuel manifold valve, which provides a central point for distributing fuel to the individual cylinders. An internal diaphragm, operated by fuel pressure, raises or lowers a plunger to open and close the individual cylinder supply ports simultaneously. A needle valve in the plunger ensures that the plunger fully opens the outlet ports before fuel flow starts and closes the ports simultaneously for positive engine shut-down. A fine-mesh screen is included in the fuel manifold valve.

NOTE

The fuel manifold valves are supplied in two flow ranges. When replacing a valve assembly, be sure the replacement valve has the same suffix letter as the one stamped on the cover of the valve removed.

12-49. REMOVAL.

NOTE

Cap all disconnected lines, hoses and fittings.

- a. Disconnect all fuel and fuel injection lines at the fuel manifold.
- b. Remove bolts which secure fuel manifold and remove manifold.

12-50. CLEANING.

- a. Remove manifold valve from engine in accordance with paragraph 12-49 and remove safety wire from cover attaching screws.

MODEL 210 & T210 SERIES SERVICE MANUAL

- b. Hold the top cover down against internal spring until all four cover attaching screws have been removed, then gently lift off the cover. Use care not to damage the spring-loaded diaphragm below cover.
- c. Remove the upper spring and lift the diaphragm assembly straight up.

NOTE

If the valve attached to the diaphragm is stuck in the bore of the body, grasp the center nut, rotate and lift at the same time to work gently out of the body.

CAUTION

Do not attempt to remove needle or spring from inside plunger valve. Removal of these items will disturb the calibration of the valve.

- d. Using clean gasoline, flush out the chamber below the screen.
- e. Flush above the screen and inside the center bore making sure that outlet passages are open. Use only a gentle stream of compressed air to remove dust and dirt and to dry.

CAUTION

The filter screen is a tight fit in the body and may be damaged if removal is attempted. It should be removed only if a new screen is to be installed.

- f. Clean diaphragm, valve and top cover in the same manner. Be sure the vent hole in the top cover is open and clean.
- g. Carefully replace diaphragm and valve. Check that valve works freely in body bore.
- h. Position diaphragm so that horizontal hole in plunger valve is 90 degrees from the fuel inlet port in the valve body.
- i. Place upper spring in position on diaphragm.
- j. Place cover in position so that vent hole in cover is 90 degrees from inlet port in valve body. Install cover attaching screws and tighten to 20±1 lb-in. Install safety wire on cover screws.
- k. Install fuel manifold valve assembly on engine in accordance with paragraph 12-51 and reconnect all lines and hoses to valve.
- l. Inspect installation and install cowling.

12-51. INSTALLATION.

- a. Secure the fuel manifold to the crankcase with the two crankcase bolts.
- b. Connect the fuel lines and the six fuel injection lines. Inspect completed installation and install cowling.

12-52. FUEL DISCHARGE NOZZLES.

12-53. DESCRIPTION. From the fuel manifold valve, individual, identical size and length fuel lines carry metered fuel to the fuel discharge nozzles lo-

cated in the cylinder heads. The outlet of each nozzle is directed into the intake port of each cylinder. The nozzle body contains a drilled central passage with a counterbore at each end. The lower end is used as a chamber for fuel-air mixture before the spray leaves the nozzle. The upper bore contains an orifice for calibrating the nozzles. Near the top, radial holes connect the upper counterbore with the outside of the nozzle body for air admission. These radial holes enter the counterbore above the orifice and draw outside air through a cylindrical screen fitted over the nozzle body. This screen prevents dirt and foreign material from entering the nozzle. A press-fit shield is mounted on the nozzle body and extends over the greater part of the filter screen, leaving a small opening at the bottom of the shield. This provides an air bleed into the nozzle which aids in vaporizing the fuel by breaking the high vacuum in the intake manifold at idle rpm and keeps the fuel lines filled. The nozzles are calibrated in several ranges. All nozzles furnished for one engine are the same range and are identified by a number and a suffix letter stamped on the flat portion of the nozzle body. When replacing a fuel discharge nozzle be sure it is of the same calibrated range as the rest of the nozzles in the engine. When a complete set of nozzles is being installed, the number must be the same as the one removed, but the suffix letters may be different, as long as they are the same for all nozzles being installed on a particular engine.

12-54. REMOVAL.

NOTE

Plug or cap all disconnected lines and fittings.

- a. Disconnect the fuel injection lines at the fuel discharge nozzles. Remove nozzles with a 1/2 inch deep well socket wrench.

12-55. CLEANING AND INSPECTION. To clean nozzles, immerse in clean solvent and use compressed air to dry them. When cleaning, direct air through the nozzle in the direction opposite of normal fuel flow. Do not remove the nozzle shield or distort it in any way. Do not use a wire or other metal object to clean the orifice or metering jet. After cleaning, check the shield height from the hex portion of the nozzle. The bottom of the shield should be approximately 1/16 inch above the hex portion of the nozzle.

12-56. INSTALLATION.

- a. Install nozzles in the cylinders and tighten to a torque value of 60 to 80 lb-in.
- b. Connect the fuel lines at discharge nozzles.
- c. Check installation for crimped lines, loose fittings, etc.

12-57. FUEL INJECTION PUMP.

12-58. DESCRIPTION. The fuel pump is a positive-displacement, rotating vane type, connected to the accessory drive section of the engine. Fuel enters the pump at the swirl well of the pump vapor separa-

MODEL 210 & T210 SERIES SERVICE MANUAL

tor. Here, vapor is separated by a swirling motion so that only liquid fuel is fed to the pump. The vapor is drawn from the top center of the swirl well by a small pressure jet of fuel and is fed into the vapor return line, where it is returned to the aircraft fuel system. Since the pump is engine-driven, changes in engine speed affects total pump flow proportionally. A check valve allows the auxiliary fuel pump pressure to bypass the engine-driven fuel pump for starting, or in the event of engine-driven fuel pump failure. The pump supplies more fuel than is required by the engine; therefore, a spring-loaded, diaphragm type relief valve is provided, with an adjustable orifice installed in the fuel passage to the relief valve to maintain desired fuel pressure for engine power setting. The adjustable orifice allows the exact desired pressure setting at full throttle. The fuel pump is equipped with a manual mixture control to provide positive mixture control throughout the range required by the injection system. This control limits output of the pump from full rich to idle cut-off. Non-adjustable mechanical stops are located at these positions. The fuel pump is ram-air cooled to help prevent high fuel temperatures. The ram air is picked up at the upper left engine baffle and directed through a flexible tube to the fuel pump shroud. The fuel supply and return lines from the fuel pump to the control unit are routed inside flexible tubes to help prevent vaporized fuel at these points.

12-59. REMOVAL.

- a. Place fuel selector or fuel ON-OFF valve in OFF position and mixture control in IDLE CUT-OFF position.
- b. Remove cowling in accordance with paragraph 12-3.
- c. Loosen the clamps and slide the flexible tubes free of the horns on the fuel pump shroud to gain access to the fuel lines.
- d. Remove the alternator drive belt.
- e. Tag and disconnect all lines and fittings attached to the fuel pump.

NOTE

Plug or cap all disconnected lines, hoses and fittings.

- f. Remove the shroud surrounding the fuel pump.
- g. Remove the nuts and washers attaching the fuel pump to the engine.
- h. Remove fuel pump and gasket.

WARNING

Residual fuel draining from lines and hose constitutes a fire hazard. Use caution to prevent accumulation of fuel when lines or hoses are disconnected.

1. If a replacement pump is not being installed immediately, a temporary cover should be installed on the fuel pump mount pad.

12-60. INSTALLATION.

- a. Position a new gasket and fuel pump on the mounting studs with fuel pump inlet to the left. Be sure pump drive aligns with drive in the engine.
- b. Secure pump to engine with plain washers, internal tooth lock washers and nuts. Tighten nuts evenly.
- c. Install cooling shroud on fuel pump.
- d. Install all fittings and connect all lines.
- e. Install the flexible ram air tube on the air horn of the fuel pump shroud and install clamp
- f. Replace the alternator drive belt and tighten the nuts on the adjusting arm so that the drive belt has proper tension. Refer to Section 17.
- g. Inspect completed installation.

12-61. ADJUSTMENT. The full rich performance of the fuel injection system is controlled by manual adjustment of the air throttle, fuel mixture and pump pressure at idle and only by pump pressure at full throttle. To make full rich adjustments, proceed as follows:

- a. Remove engine cowling in accordance with paragraph 12-3.

NOTE

Inspect the slot-headed adjustable orifice needle valve (located just below the fuel pump inlet fitting) to see if it is epoxy sealed or safety wired to the brass nut. If the needle valve is epoxy sealed, Continental Aircraft Engine Service Bulletin No. 70-10 must be complied with before calibration of the unit can be performed.

- b. Disconnect the engine-driven fuel pump outlet fitting or the fuel metering unit inlet fitting and "tee" the test gage into the fuel injection system as illustrated in figure 12-8.

NOTE

Cessna Service Kit No. SK320-2J provides a test gage, line and fittings for connecting the test gage into the system to perform accurate calibration of the engine-driven fuel pump.

- c. The test gage MUST be vented to atmosphere and MUST be held as near to the level of the engine-driven fuel pump as possible. Bleed air from test gage line prior to taking readings.

NOTE

The test gage should be checked for accuracy at least every 90 days or anytime an error is suspected. The tachometer accuracy should also be determined prior to making any adjustments to the pump.

- d. Start engine and warm-up thoroughly. Set mixture control to full rich position and propeller control full forward (low pitch, high rpm).

MODEL 210 & T210 SERIES SERVICE MANUAL

e. Adjust engine idle speed to 600 rpm and check test gage for 9-11 PSI. Refer to figure 12-7 for idle mixture adjustment.

NOTE

Do not adjust idle mixture until idle pump pressure is obtained.

WARNING

DO NOT make fuel pump pressure adjustments while engine is operating.

f. If the pump pressure is not 9 to 11 PSI, stop engine and turn the fuel pump relief valve adjustment, on the centerline of the fuel pump clockwise (CW) to increase pressure and counterclockwise (CCW) to decrease pressure.

g. Maintaining idle pump pressure and idle RPM, obtain correct idle mixture in accordance with paragraph 12-46.

h. Completion of the preceding steps have provided:

1. Correct idle pump pressure.

2. Correct fuel flow.

3. Correct fuel metering cam to throttle plate orientation.

i. Advance to full throttle and maximum rated engine speed with the mixture control in full rich position and propeller control in full forward (low pitch, high rpm).

j. Check test gage for pressures specified in paragraph 12-12. If pressure is incorrect, stop engine and adjust pressure by loosening locknut and turning the slotheaded needle valve located just below the fuel pump inlet fitting clockwise (CW) to increase pressure and counterclockwise (CCW) to decrease pressure.

NOTE

If at static run-up, rated RPM cannot be achieved at full throttle, adjust pump pressure slightly below limits making certain the correct pressures are obtained when rated RPM is achieved during take-off roll.

k. After correct pressures are obtained, safety adjustable orifice and orifice locknut.

l. Remove test equipment, run engine to check for leaks and install cowling.

12-61A. AUXILIARY ELECTRIC FUEL PUMP FLOW RATE ADJUSTMENT. Refer to Section 13.

12-62. INDUCTION AIR SYSTEM. (Refer to Figure 12-9.)

12-63. DESCRIPTION. Ram air enters the induction air system through a filter at the upper left en-

gine baffle. A spring-loaded alternate air door is incorporated in the airbox and will open by engine suction if the air filter should become clogged. This permits unfiltered induction air to be drawn from within the engine compartment.

12-64. AIRBOX.

12-65. REMOVAL AND INSTALLATION.

a. Remove cowling in accordance with paragraph 12-3.

b. Remove induction air filter.

c. Disconnect electrical wiring at throttle-operated micro-switch and tape terminals as a safety precaution.

d. Remove clamps attaching lines, wires and controls to airbox.

e. Remove bolts securing airbox to fuel-air control unit and engine and remove airbox and gasket.

f. Install a cover over fuel-air control opening.

g. Reverse the preceding steps for reinstallation. Adjust throttle operated switch in accordance with Section 13.

12-66. CLEANING AND INSPECTION. Clean metal parts of the induction airbox with Stoddard solvent or equivalent. Inspect for cracks, dents, loose rivets, etc. Minor cracks may be stop-drilled. In case of continued or severe cracking, replace airbox. Inspect alternate spring-loaded door for freedom of operation and complete closing.

12-67. INDUCTION AIR FILTER.

12-68. DESCRIPTION. An induction air filter, mounted at the airbox inlet, removes dust particles from the ram air entering the engine.

12-69. REMOVAL AND INSTALLATION.

a. Remove cowling in accordance with paragraph 12-3.

b. Remove bolts securing filter to the upper left engine baffle and induction airbox inlet.


c. Reverse the preceding steps for reinstallation. Make sure the gasket is in place between the filter and airbox intake.

12-70. CLEANING AND INSPECTION. Clean and inspect filter in accordance with instructions in Section 2.


12-71. IGNITION SYSTEM. (Refer to Figure 12-10.)

12-72. DESCRIPTION. The ignition system is comprised of two magnetos, two spark plugs in each cylinder, an ignition wiring harness, an ignition switch mounted on the instrument panel and required wiring between the ignition switch and magnetos.

MODEL 210 & T210 SERIES SERVICE MANUAL



- 1. Duct
- 2. Bolt
- 3. Gasket
- 4. Spring
- 5. Arm
- 6. Pin
- 7. Shaft
- 8. Bushing Assembly
- 9. Air Filter
- 10. Retainer
- 11. Door Assembly
- 12. Adaptor
- 13. Bracket



Detail A

Figure 12-9. Airbox Installation

MODEL 210 & T210 SERIES SERVICE MANUAL

12-73. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
ENGINE FAILS TO START.	Defective ignition switch.	Check switch continuity. Replace if defective.
	Spark plugs defective, improperly gapped or fouled by moisture or deposits.	Clean, regap and test plugs. Replace if defective.
	Defective ignition harness.	If no defects are found by a visual inspection, check with a harness tester. Replace defective parts.
	Magneto "P" lead grounded.	Check continuity. "P" lead should not be grounded in the ON position, but should be grounded in OFF position. Repair or replace "P" lead.
	Failure of impulse coupling.	Impulse coupling pawls should engage at cranking speeds. Listen for loud clicks as impulse couplings operate. Remove magnetos and determine cause. Replace defective magneto.
	Defective magneto.	Refer to paragraph 12-79.
	Broken drive gear.	Remove magneto and check magneto and engine gears. Replace defective parts. Make sure no pieces of damaged parts remain in engine or engine disassembly will be required.
ENGINE WILL NOT IDLE OR RUN PROPERLY.	Spark plugs defective, improperly gapped or fouled by moisture or deposits.	Clean, regap and test plugs. Replace if defective.
	Defective ignition harness.	If no defects are found by a visual inspection, check with a harness tester. Replace defective parts.
	Defective magneto.	Refer to paragraph 12-79.
	Impulse coupling pawls remain engaged.	Listen for loud clicks as impulse coupling operates. Remove magneto and determine cause. Replace defective magneto.
	Spark plugs loose.	Check and install properly.

MODEL 210 & T210 SERIES SERVICE MANUAL

12-74. MAGNETOS.

12-75. DESCRIPTION. The airplane may be equipped with either 662 series or 6200 series Slick magnetos. The magnetos contain a conventional two-pole rotating magnet (rotor), mounted in ball bearings. Driven by the engine through an-impulse coupling at one end, the rotor shaft operates the breaker points at the other end of the shaft. The nylon rotor gear drives a nylon distributor gear which transfers high tension current from the wedge-mounted coil to the proper outlet in the distributor block. A coaxial capacitor is mounted in the distributor block housing to serve as the condenser as well as a radio noise suppressor. Both nylon gears are provided with timing marks for clockwise or counterclockwise rotation. The distributor gear and distributor block having timing marks, visible through the air vent holes, for timing to the engine. A timing hole is located in the 662 series magneto in the bottom of the magneto adjacent to the flange. In the 6200 series, the timing hole is located in the distributor block. A timing pin or 6-penny nail can be inserted through this timing hole into the mating hole in the rotor shaft to lock the magneto approximately in the proper firing position. The breaker assembly is accessible only after removing the screws fastening the magneto halves together and disconnecting the capacitor slip terminal. Do not separate magneto halves while it is installed on the engine.

12-76. REMOVAL.

- a. Remove engine cowling in accordance with paragraph 12-3.
- b. Tag for identification and remove high tension wires from the magneto being removed.

WARNING

The magneto is in a SWITCH ON condition when the switch wire is disconnected. Remove the high tension wires from magneto or disconnect spark plug leads from the spark plugs to prevent accidental firing.

- c. Disconnect switch wire from condenser terminal at magneto. Tag wire for identification so it may be installed correctly.
- d. Rotate propeller in direction of normal rotation until No. 1 cylinder is coming up on its compression stroke.

NOTE

To facilitate the installation of a replacement magneto, it is good practice to position the crankshaft at the advanced firing angle for No. 1 cylinder during step "d." Any standard timing device or method can be used, or if the magneto being removed is correctly timed to the engine, the crankshaft can be rotated to a position at which the breaker points will be just opening to fire No. 1 cylinder.

- e. Remove magneto retainer clamps, nuts and washers and pull magneto from crankcase mounting pad.

NOTE

As the magneto is removed from its mounting, be sure that the drive coupling rubber bushing and retainer do not become dislodged from the gear hub and fall into the engine.

12-77. INTERNAL TIMING.

- a. Whenever the gear on the rotor shaft or the cam (which also serves as the key for the gear) has been removed, be sure that the gear and cam are installed so the timing mark on the gear aligns with the "O" etched on the rotor shaft.
- b. When replacing breaker assembly or adjusting contact breaker points, place a timing pin (or 0.093 inch 6-penny nail) through the timing hole into the mating hole in the rotor shaft. Adjusting contact breaker points so they are just starting to open in this position will give the correct point setting. Temporarily assemble the magneto halves and capacitor slip terminal and use a timing light to check that the timing marks, visible through the ventilation plug holes are approximately aligned.

NOTE

The side of the magneto with the manufacturer's insignia has a red timing mark and the side opposite to the insignia has a black timing mark viewed through the vent plug holes. The distributor gear also has a red timing mark and a black timing mark. These marks are used for reference only when installing magneto on the engine. Do not place red and black lines together on the same side.

- c. Whenever the large distributor gear and rotor gear have been disengaged, they must be engaged with their timing marks aligned for correct rotation. Align the timing mark on the rotor gear with the "RH" on the distributor gear. Care must be taken to keep these two gears meshed in this position until the magneto halves are assembled.

12-78. INSTALLATION AND TIMING TO ENGINE. The magneto MUST be installed with its timing marks correctly aligned, with the number one cylinder on its compression stroke and with number one piston at its advanced firing position. Refer to paragraph 12-12 for the advanced firing position of number one piston.

WARNING

The magneto is grounded through the ignition switch, therefore, any time the switch (primary) wire is disconnected from the magneto, the magneto is in a switch ON or HOT condition. Before turning the propeller by hand, remove the high tension wires from the mag-

MODEL 210 & T210 SERIES SERVICE MANUAL

neto or disconnect all spark plug leads to prevent accidental firing of the engine.

To locate the compression stroke of number one cylinder, remove the lower spark plugs from each cylinder except number one cylinder. Remove the top plug from number one cylinder. Place thumb of one hand over the number one cylinder spark plug hole and rotate the crankshaft in the direction of normal rotation until the compression stroke is indicated by positive pressure inside the cylinder lifting the thumb off the spark plug hole. After the compression stroke is obtained, locate number one piston at its advanced firing position. Locating the advanced firing position of number one cylinder may be obtained by use of a timing disc and pointer, Timrite, protractor and piston locating gage or external engine timing marks alignment.

NOTE

External engine timing marks are located on a bracket attached to the starter adapter, with a timing mark on the alternator drive pulley as the reference point.

In all cases, it must be definitely determined that the number one cylinder is at the correct firing position and on the compression stroke, when the crankshaft is turned in its normal direction of rotation. After the engine has been placed in the correct firing position, install and time the magneto to the engine in the following manner.

NOTE

Install the magneto drive coupling retainer and rubber bushings into the magneto drive gear hub slot. Insert the two rubber bushings into the retainer with the chamfered edges facing toward the front of the engine.

a. Turn the magneto shaft until the timing marks, visible through the ventilation plug holes are aligned, (red-to-red or black-to-black). Insert a timing pin or .093 inch diameter 6-penny nail through the timing hole on the bottom of the magneto adjacent to the flange (662 series); or in the distributor block (6200 series). Next, push the timing pin through the mating hole in the rotor shaft. This locks the magneto close to the firing position during installation on the engine.

NOTE

If the magneto drive gear was disengaged during magneto removal, hold the magneto in the horizontal position it will occupy when installed, make certain that the drive gear coupling slot is aligned with the magneto coupling lugs. If it is not aligned, pull the magneto drive gear out of mesh with its drive gear and rotate it to the aligned angle,

then push it back into mesh. DO NOT WITHDRAW THE MAGNETO DRIVE GEAR FROM ITS OIL SEAL.

b. After magneto gasket is in place, position the magneto on the engine and secure, then remove the timing pin from the magneto. Be sure to remove this pin before turning the propeller.

c. Connect a timing light to the capacitor terminal at the front of the magneto and to a good ground.

d. Turn propeller back a few degrees (opposite of normal rotation) to close the contact points.

NOTE

Do not turn the propeller back far enough to engage the impulse coupling or the propeller will have to be turned in normal direction of rotation until the impulse coupling releases, then backed up to slightly before the firing position.

e. Slowly advance the propeller in the normal direction of rotation until the timing light indicates the contact points breaking. Magneto mounting clamps may be loosened so that the magneto may be shifted to break the points at the correct firing position.

f. Tighten magneto mounting nuts and recheck timing.

g. Repeat steps "a" through "f" for the other magneto.

h. After both magnetos have been timed, check synchronization of both magnetos. Magnetos must fire at the same time.

i. Remove timing devices from magneto and engine.

j. Connect spark plug leads to their correct magneto outlets.

NOTE

The No. 1 magneto outlet is the one closest to the ventilation plug on the side of the magneto having the manufacturer's insignia. The magneto fires at each successive outlet in clockwise direction. Connect No. 1 magneto outlet to No. 1 cylinder spark plug lead, No. 2 outlet to the next cylinder to fire, etc. Engine firing order is listed in paragraph 12-12.

k. Connect ignition switch (primary) leads to the capacitor terminals on the magnetos.

1. Inspect magneto installation and install engine cowling in accordance with paragraph 12-3.

12-79. MAINTENANCE. At the first 25-hour inspection and at each 100-hour inspection thereafter, the breaker compartment should be inspected. Magneto-to-engine timing should be checked at the first 25-hour inspection, first 50-hour inspection, first 100-hour inspection and thereafter at each 100-hour

MODEL 210 & T210 SERIES SERVICE MANUAL

inspection. If timing is as specified in paragraph 12-12, internal timing need not be checked. If timing is out of tolerance, remove magneto and set internal timing, then install and time to the engine. In the event the magneto internal timing marks are off more than plus or minus five degrees when the breaker points open to fire number one cylinder, remove the magneto and check the magneto internal timing. Whenever the magneto halves are separated the breaker point assembly should always be checked. As long as internal timing and magneto-to-engine timing are within the preceding tolerances, it is recommended that the magneto be checked internally only at 500 hour intervals. It is normal for contact points to burn and the cam to wear a comparable amount so the magneto will remain in time within itself. This is accomplished by having a good area making contact on the surface between the points and the correct amount of spring pressure on the cam. The area on the points should be twenty-five percent of the area making contact. The spring pressure at the cam should be 10.5 to 12.5 ounces. When the contact points burn, the area becomes irregular, which is not detrimental to the operation of the points unless metal transfer is too great which will cause the engine to misfire. Figure 12-11 illustrates good and bad contact points. A small dent will appear on the nylon insulator between the cam follower and the breaker bar. This is normal and does not require replacement.

NOTE

If ignition trouble should develop, spark plugs and ignition wiring should be checked first. If the trouble definitely is associated with a magneto, use the following to help disclose the source of trouble without overhauling the magneto.

a. Moisture Check.

1. Remove magneto from engine and remove screws securing the magneto halves together, disconnect capacitor slip terminal and remove distributor. Inspect for moisture.

2. Check distributor gear finger and carbon brush for moisture.

3. Check breaker point assembly for moisture, especially on the surfaces of the breaker points.

4. If any moisture is evident in the preceding places, wipe with a soft, dry, clean, lint-free cloth.

b. Breaker Compartment Check.

1. Check all parts of the breaker point assembly for security.

2. Check breaker point surface for evidence of excessive wear, burning, deep pits and carbon deposits. Breaker points may be cleaned with a hard-finish paper. If breaker point assembly is defective, install a new assembly. Make no attempt to stone or dress the breaker points. Clean new breaker points with clean, unleaded gasoline and hard-finish paper before installing.

3. Check capacitor mounting bracket for cracks or looseness.

4. Check the carbon brush on the distributor gear for excessive wear. The brush must extend a minimum of 1/32 inch beyond the end of the gear shaft. The spring which the carbon brush contacts should be bent out approximately 20 degrees from vertical, since spring pressure on the brush holds the distributor gear shaft against the thrust bearing in the distributor block.

5. Oil the bearings at each end of the distributor gear shaft with a drop of SAE 20 oil. Wipe excess oil from parts.

6. Make sure internal timing is correct and reassemble magneto. Install and properly time magneto to engine.

12-80. **MAGNETO CHECK.** Advanced timing settings in some cases, is the result of the erroneous practice of bumping magnetos up in timing in order to reduce RPM drop on single ignition. **NEVER ADVANCE TIMING BEYOND SPECIFICATIONS IN ORDER TO REDUCE RPM DROP.** Too much importance is being attached to RPM drop on single ignition. RPM drop on single ignition is a natural characteristic of dual ignition design. The purpose of the following magneto check is to determine that all cylinders are firing. If all cylinders are not firing, the engine will run extremely rough and cause for investigation will be quite apparent. The amount of RPM drop is not necessarily significant and will be influenced by ambient air temperature, humidity, airport altitude, etc. In fact, absence of RPM drop should be cause for suspicion that the magneto timing has been bumped up and is set in advance of the setting specified. Magneto checks should be performed on a comparative basis between individual right and left magneto performance.

- a. Start and run engine until the oil and cylinder head temperature is in the normal operating range.

- b. Place the propeller control in the full low pitch (high RPM) position.

- c. Advance engine speed to 1700 RPM.

- d. Turn the ignition switch to the "R" position and note the RPM drop, then return the switch to the "BOTH" position to clear the opposite set of plugs.

- e. Turn the switch to the "L" position and note the RPM drop, then return the switch to the "BOTH" position.

- f. The RPM drop should not exceed 150 RPM on either magneto or show greater than 50 RPM differential between magnetos. A smooth RPM drop-off past normal is usually a sign of a too lean or too rich mixture. A sharp RPM drop-off past normal is usually a sign of a fouled plug, a defective harness lead or a magneto out of time. If there is doubt concerning operation of the ignition system, RPM checks at a leaner mixture setting or at higher engine speeds will usually confirm whether a deficiency exists.

NOTE

An absence of RPM drop may be an indication of faulty grounding of one side of the ignition system, a disconnected ground lead at magneto or possibly the magneto timing is set too far in advance.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 12-11. Magneto Contact Breaker Points

12-81. **SPARK PLUGS:** Two spark plugs are installed in each cylinder and screw into helicoil type thread inserts. The spark plugs are shielded to prevent spark plug noise in the radios and have an internal resistor to provide longer terminal life. Spark plug service life will vary with operating conditions. A spark plug that is kept clean and properly gapped will give better and longer service than one that is allowed to collect lead deposits and is improperly gapped.

NOTE

Refer to Section 2 for inspection intervals. Remove, clean, inspect and regap all spark plugs at these intervals. At this time, install lower spark plugs in upper portion of cylinders and install upper spark plugs in lower portion of cylinders. Since deterioration of lower spark plugs is usually more rapid than that of the upper spark plugs, rotating helps prolong spark plug life.

12-82. **ENGINE CONTROLS.** (Refer to figure 12-11.)

12-83. **DESCRIPTION.** The throttle, mixture and propeller controls are of the push-pull type. The propeller and mixture controls are equipped to lock in any position desired. To move the control, the spring-loaded button, located in the end of the control knob, must be depressed. When the button is released, the control is locked. The propeller and mixture controls also have a vernier adjustment. Turning the control knob in either direction will change the control setting. The vernier is primarily for precision control setting. The throttle control has neither a locking button nor a vernier adjustment, but contains a knurled friction knob which is rotated

for more or less friction as desired. The friction knob prevents vibration induced "creeping" of the control. A "Nut" type locknut is installed in back of the existing locknut at the engine end of the throttle, mixture and propeller controls.

12-84. **RIGGING.** When adjusting any engine control, it is important to check that the control slides smoothly throughout its full travel, that it locks securely if equipped with a locking device and the arm or lever which it operates moves through its full arc of travel.

CAUTION

Whenever engine controls are being disconnected, pay particular attention to the EXACT position, size and number of attaching washers and spacers. Be sure to install attaching parts as noted when connecting controls.

NOTE

Refer to inspection and lubrication charts in Section 2 of this manual for inspection, lubrication and/or replacement intervals for engine controls.

12-85. **THROTTLE CONTROL.**

- a. Push throttle control full in, then pull control out approximately 1/8 inch for cushion.
- b. Check that throttle control arm is against the mechanical stop. If necessary, loosen locknut and screw rod end IN or OUT as necessary to align with attachment hole while throttle arm is against the mechanical stop.
- c. Pull control full out and check that throttle arm contacts the idle stop.
- d. The throttle arm must contact the stops in each direction and the control should have approximately 1/8 inch cushion when pushed full in.

MODEL 210 & T210 SERIES SERVICE MANUAL

12-86. MIXTURE CONTROL.

- a. Push mixture control full in, then pull control out approximately 1/8 inch for cushion.
- b. Check that mixture control arm is in full rich position (against stop). If necessary, loosen locknut and screw rod end IN or OUT as necessary to align with attachment hole while mixture arm is against the mechanical stop.
- c. Pull control full out and check that mixture arm contacts the idle cut-off stop.
- d. The mixture arm must contact the stops in each direction and the control should have approximately 1/8 inch cushion when pushed full in.

NOTE

Refer to the inspection chart in Section 2 for inspection and/or replacement interval for the mixture control.

12-87. THROTTLE-OPERATED MICROSWITCH. Refer to Section 13.

12-87A. LANDING GEAR WARNING HORN. Refer to Section 5.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 12-12. Engine Controls

MODEL 210 & T210 SERIES SERVICE MANUAL

12-88. PROPELLER CONTROL. Refer to Section 14.

12-89. STARTING SYSTEM.

12-90. DESCRIPTION. The automatically-engaged starting system employs an electrical starter motor mounted to a 90-degree adapter. A solenoid is activated by the ignition switch on the instrument panel. When the solenoid is activated, its contacts close and electrical current energizes the motor. Initial rotation of the motor engages the starter through an over-

running clutch in the starter adapter, which incorporates worm reduction gears. The starter motor is located just aft of the right rear cylinder.

CAUTION

Never operate the starter motor more than 12 seconds at a time. Allow starter motor to cool between cranking periods to avoid overheating. Longer cranking periods without cooling time will shorten the life of the starter motor.

12-91. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
STARTER WILL NOT OPERATE.	Defective master switch or circuit.	Check continuity. Install new switch or wires.
	Defective starter switch or switch circuit.	Check continuity. Install new switch or wires.
	Defective starter motor.	Check electrical power to motor. Repair or replace starter motor.
STARTER MOTOR RUNS, BUT DOES NOT TURN CRANK-SHAFT.	Defective overrunning clutch or drive.	Check visually. Install new starter adapter.
	Starter motor shaft broken.	Check visually. Install new starter motor.
STARTER MOTOR DRAGS.	Low battery.	Check battery. Charge or install new battery.
	Starter switch or relay contacts burned or dirty.	Install serviceable unit.
	Defective starter motor power cable.	Check visually. Install new cable.
	Loose or dirty connections.	Remove, clean and tighten all terminal connections.
	Defective starter motor.	Check starter motor brushes, brush spring tension, thrown solder on brush cover. Repair or install new starter motor.
	Dirty or worn commutator.	Check visually. Clean and turn commutator.
STARTER EXCESSIVELY NOISY.	Worn starter pinion.	Remove and inspect. Replace starter drive.
	Worn or broken teeth on crankshaft gears.	Check visually. Replace crankshaft gear.

MODEL 210 & T210 SERIES SERVICE MANUAL

12-92. PRIMARY MAINTENANCE. The starting circuit should be inspected at regular intervals, the frequency of which should be determined by the amount of service and conditions under which the equipment is operated. Inspect the battery and wiring. Check battery for fully charged condition, proper electrolyte level with approved water and terminals for cleanliness. Inspect wiring to be sure that all connections are clean and tight and that the wiring insulation is sound. Check that the brushes slide freely in their holders and make full contact on the commutator. When brushes are worn to one-half of their original length, install new brushes (compare brushes with new brushes). Check the commutator for uneven wear, excessive glazing or evidence of excessive arcing. If the commutator is only slightly dirty, glazed or discolored, it may be cleaned with a strip of No. 00 or No. 000 sandpaper. If the commutator is rough or worn, it should be turned in a lathe and the mica undercut. Inspect the armature shaft for rough bearing surfaces. New brushes should be properly seated when installing by wrapping a strip of No. 00 sandpaper around the commutator (with sanding side out) 1-1/4 to 1-1/2 times maximum. Drop brushes on sandpaper covered commutator and turn armature slowly in the direction of normal rotation. Clean sanding dust from motor after sanding operations.

12-93. STARTER MOTOR.

12-94. REMOVAL AND INSTALLATION.

a. Remove engine cowling in accordance with paragraph 12-3.

CAUTION

When disconnecting starter electrical cable, do not permit terminal bolt to rotate. Rotation of the bolt could break the conductor between bolt and field coils causing the starter to be inoperative.

- b. Disconnect battery cables and insulate as a safety precaution.
- c. Disconnect electrical cable at starter motor.
- d. Remove nuts and washers securing motor to starter adapter and remove motor. Refer to engine manufacturer's overhaul manual for adapter removal.
- e. Reverse the preceding steps for reinstallation. Install a new O-ring seal on motor, then install motor. Be sure motor drive engages with the adapter drive when installing.

12-95. EXHAUST SYSTEM.

12-96. DESCRIPTION. The exhaust system consists of two exhaust stack assemblies, for the left and right bank of cylinders. Each cylinder has a riser pipe attached to the exhaust port. The three risers at each bank of cylinders are joined together into a collector pipe forming an exhaust stack assembly. The center riser on each bank is detachable, but the front and aft risers are welded to the collector pipe. The left muffler is enclosed in a shroud which captures exhaust heat which is used to heat the cabin.

12-96A. ECONOMY MIXTURE INDICATOR (EGT)
Refer to Section 16.

12-97. REMOVAL AND INSTALLATION. (Refer to figure 12-12.)

- a. Remove engine cowling in accordance with paragraph 12-3.
- b. Disconnect ducts from heater shroud on left muffler assembly and EGT wires at quick-disconnects.
- c. Disconnect tailpipe braces from shock-mounts at firewall brackets.
- d. Remove nuts, springs and bolts attaching tailpipe and muffler to collector pipe and remove muffler and tailpipe assemblies.
- e. Remove nuts attaching exhaust stack assemblies to the cylinders and remove exhaust stacks and gaskets.
- f. Reverse the preceding steps for reinstallation. Install a new copper-asbestos gasket between each riser and its mounting pad on each cylinder, regardless of apparent condition of those removed. Torque exhaust stack nuts at cylinders to 100-110 pound-inches.

12-98. INSPECTION. Refer to Section 2 for inspection intervals. Since exhaust systems of this type are subject to burning, cracking and general deterioration from alternate thermal stresses and vibrations, inspection is important and should be accomplished as specified in the Inspection Charts in Section 2. A thorough inspection of the engine exhaust system is required to detect cracks which could cause leaks and result in loss of engine power. To inspect the engine exhaust system, proceed as follows:

- a. Remove engine cowling as required so that ALL surfaces of the exhaust assemblies can be visually inspected.

NOTE

Especially check the areas adjacent to welds and slip joints. Look for gas deposits in surrounding areas, indicating that exhaust gases are escaping through a crack or hole or around the slip joints.

- b. After visual inspection, an air leak check should be made on the exhaust system as follows:
1. Attach the pressure side of an industrial vacuum cleaner to the tailpipe opening, using a rubber plug to effect a seal as required.

NOTE

The inside of the vacuum cleaner hose should be free of any contamination that might be blown into the engine exhaust system.

2. With vacuum cleaner operating, all joints in the exhaust system may be checked manually by feel, or by using a soap and water solution and watching for bubbles. Forming of bubbles is considered acceptable, if bubbles are blown away system is not considered acceptable.
- c. Where a surface is not accessible for a visual inspection, or for a more positive test, the following procedure is recommended.
1. Remove exhaust stack assemblies.
 2. Use rubber expansion plugs to seal openings.
 3. Using a manometer or gage, apply approxi-

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 12-13. Exhaust System

MODEL 210 & T210 SERIES SERVICE MANUAL

mately 1-1/2 psi (3 inches of mercury) air pressure while each stack assembly is submerged in water. Any leaks will appear as bubbles and can be readily detected.

4. It is recommended that exhaust stacks found defective be replaced before the next flight.

d. After installation of exhaust system components, perform the air leak check as specified in step "b" of this paragraph to make sure that the system is acceptable.

e. In addition to the above inspections, at 200 hours (after the mufflers have accumulated more than 1000 hours time in service) perform the following inspection:

1. Remove engine cowling in accordance with paragraph 12-3.

2. Remove the mufflers from the collector assemblies.

3. Remove the tailpipes from the mufflers.

4. Using a flashlight and a mirror, inspect the baffles and cones from both ends of the mufflers. Check for general deterioration and make sure the baffles are intact and not separated from the support rods.

5. If defects are found, replace the mufflers before further flight.

6. If no defects are found, reinstall the mufflers and tailpipes.

12-99. EXTREME WEATHER MAINTENANCE.

12-100. COLD WEATHER. Cold weather starting will be made easier by the installation of an engine primer system and a ground service receptacle. The primer system is manually operated from the cabin. Fuel is supplied by a line from the fuel strainer to the plunger. Operating the primer forces fuel to the engine. With an external power receptacle installed, an external power source may be connected to assist in cold weather or low battery starting. Refer to paragraph 12-104 for use of the external power receptacle. The following may also be used to assist engine starting in extremely cold weather. After the last flight of the day, drain the engine oil into a clean container so the oil can be preheated. Cover the engine to prevent ice or snow from collecting inside the cowling. When preparing the aircraft for flight or engine run-up after these conditions have been followed, preheat the drained engine oil.

WARNING

Do not heat the oil above 121°C (250°F). A flash fire may result. Before pulling the propeller through, ascertain that the magneto switch is in the OFF position to prevent accidental firing of the engine.

After preheating the engine oil, gasoline may be mixed with the heated oil in a ratio of 1 part gasoline to 12 parts engine oil before pouring into the engine oil sump. If the free air temperature is below minus 29°C (-20°F), the engine compartment should be preheated by a ground heater. Pre-heating the engine compartment is accomplished by inducing heated air up through the cowl flap openings; thus heating both the oil and cylinders. After the engine compartment

has been preheated, inspect all engine drain and vent lines for presence of ice. After this procedure has been complied with, pull propeller through several revolutions by hand before attempting to start the engine.

CAUTION

Due to the desludging effect of the diluted oil, engine operation should be observed closely during the initial warm-up of the engine. Engines that have considerable amount of operational hours accumulated since their last dilution period may be seriously affected by the dilution process. This will be caused by the diluted oil dislodging sludge and carbon deposits within the engine. This residue will collect in the oil sump and possibly clog the screened inlet to the oil sump. Small deposits may actually enter the oil sump and be trapped by the main oil filter screen. Partial or complete loss of engine lubrication may result from either condition. If these conditions are anticipated after oil dilution, the engine should be run for several minutes at normal operating temperatures and then stopped and inspected for evidence of sludge and carbon deposits in the oil sump and oil filter screen. Future occurrence of this condition can be prevented by diluting the oil prior to each engine oil change. This will also prevent the accumulation of the sludge and carbon deposits.

12-101. HOT WEATHER. Refer to Pilot's Operating Handbook.

12-102. SEACOAST AND HUMID AREAS. In salt water areas special care should be taken to keep the engine, accessories and airframe clean to prevent oxidation. In humid areas, fuel and oil should be checked frequently and drained of condensation to prevent corrosion.

12-103. DUSTY AREAS. Dust induced into the intake system of the engine is probably the greatest single cause of early engine wear. When operating in high dust conditions, service the induction air filters daily as outlined in Section 2. Also change engine oil and lubricate airframe items more often than specified.

12-104. GROUND SERVICE RECEPTACLE. Refer to Section 17.

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 12A

ENGINE

TURBOCHARGED

WARNING

When performing any inspection or maintenance that requires turning on the master switch, installing a battery, or pulling the propeller through by hand, treat the propeller as if the ignition switch were ON. Do not stand nor allow anyone else to stand, within the arc of the propeller, since a loose or broken wire or a component malfunction could cause the propeller to rotate.

NOTE

For additional information covering turbocharger and component maintenance, overhaul and trouble shooting refer to the Manufacturer's Overhaul Manual.

	Page No.		Page No.
TABLE OF CONTENTS	Aerofiche/Manual		Aerofiche/Manual
ENGINE COWLING	2E7/12A-2	Installation	2E18/12A-12
Description	2E7/12A-2	Oil Cooler	2E18/12A-12
Removal and Installation	2E7/12A-2	Description	2E18/12A-12
Cleaning and Inspection	2E7/12A-2	ENGINE FUEL SYSTEM	2E18/12A-12
Repair	2E7/12A-2	Description	2E18/12A-12
Cowl Flaps	2E7/12A-2	Fuel-Air Control Unit	2E18/12A-12
Description	2E7/12A-2	Description	2E18/12A-12
Removal and Installation	2E7/12A-2	Removal	2E18/12A-12
Rigging	2E7/12A-2	Cleaning and Inspection	2E20/12A-15
ENGINE	2E8/12A-3	Installation	2E20/12A-15
Description	2E8/12A-3	Adjustments	2E20/12A-15
Engine Data	2E8/12A-3	Fuel Manifold Valve	2E20/12A-15
Time Between Overhaul (TBO)	2E9/12A-4	Description	2E20/12A-15
Overspeed Limitations	2E9/12A-4	Removal	2E20/12A-15
Trouble Shooting	2E10/12A-4A	Cleaning	2E20/12A-15
Static Run-Up Procedures	2E14/12A-8	Installation	2E20/12A-15
Removal	2E14/12A-8	Fuel Discharge Nozzles	2E20/12A-15
Cleaning	2E16/12A-10	Description	2E20/12A-15
Accessories Removal	2E16/12A-10	Removal	2E20/12A-15
Inspection	2E16/12A-10	Cleaning and Inspection	2E20/12A-15
Buildup	2E16/12A-10	Installation	2E20/12A-15
Installation	2E16/12A-10	Fuel Injection Pump	2E20/12A-15
Flexible Fluid Hoses	2E17/12A-11	Description	2E20/12A-15
Pressure Test	2E17/12A-11	Removal	2E21/12A-16
Replacement	2E17/12A-11	Installation	2E21/12A-16
Engine Baffles	2E17/12A-11	Adjustment (1977 thru 1982	
Description	2E17/12A-11	Models)	2E21/12A-16
Cleaning and Inspection	2E17/12A-11	Adjustment (Beginning with	
Removal and Installation	2E17/12A-11	1983 Models	2E22/12A-16A
Repair	2E17/12A-11	INDUCTION AIR SYSTEM	2E24/12A-17
ENGINE OIL SYSTEM	2E18/12A-12	Description	2E24/12A-17
Description	2E18/12A-12	Airbox	2F1/12A-18
Trouble Shooting	2E18/12A-12	Removal and Installation	2F1/12A-18
Full-Flow Oil Filter	2E18/12A-12	Cleaning and Inspection	2F1/12A-18
Description	2E18/12A-12	Induction Air Filter	2F1/12A-18
Removal and Installation	2E18/12A-12	Description	2F1/12A-18
Filter Adapter	2E18/12A-12	Removal and Installation	2F1/12A-18
Removal	2E18/12A-12	Cleaning and Inspection	2F1/12A-18
Disassembly, Inspection and		Installation of Induction Air	
Reassembly	2E18/12A-12	System Ducts	2F2/12A-18A

MODEL 210 & T210 SERIES SERVICE MANUAL

IGNITION SYSTEM	2F2/12A-18A	EXHAUST SYSTEM	2F3/12A-19
Description	2F2/12A-18A	Description	2F3/12A-19
Trouble Shooting	2F2/12A-18A	Removal	2F3/12A-19
Magnetos	2F2/12A-18A	Installation	2F3/12A-19
Pressurized Magnetos	2F2/12A-18A	Inspection	2F6/12A-22
Description	2F2/12A-18A	TURBOCHARGER	2F7/12A-23
Removal	2F2/12A-18A	Description	2F7/12A-23
Internal Timing	2F2/12A-18A	Removal and Installation	2F7/12A-23
Installation and Timing-to-		CONTROLLER AND WASTE-GATE	
Engine	2F2/12A-18A	ACTUATOR	2F7/12A-23
Maintenance	2F2/12A-18A	Functions	2F7/12A-23
Magneto Check	2F2/12A-18A	Operation	2F7/12A-23
Spark Plugs	2F2/12A-18A	Trouble Shooting	2F10/12A-26
ENGINE CONTROLS	2F2/12A-18A	Controller and Turbocharger Oper-	
Description	2F2/12A-18A	ational Flight Check	2F14/12A-30
Rigging	2F2/12A-18A	Removal and Installation of	
Throttle Control	2F2/12A-18A	Turbocharger Controller	2F15/12A-31
Mixture Control	2F2/12A-18A	Absolute Controller Adjustment	2F15/12A-31
Propeller Control	2F2/12A-18A	Removal and Installation of Waste-	
Throttle Operated Microswitch	2F3/12A-19	Gate and Actuator	2F15/12A-31
Auxiliary Electric Fuel Pump		Adjustment of Waste-Gate	
Flow Adjustment	2F3/12A-19	Actuator	2F16/12A-32
Landing Gear Warning Horn	2F3/12A-19	EXTREME WEATHER MAINTENANCE	2F16/12A-32
STARTING SYSTEM	2F3/12A-19	Cold Weather	2F16/12A-32
Description	2F3/12A-19	Hot Weather	2F16/12A-32
Trouble Shooting	2F3/12A-19	Seacoast and Humid Areas	2F16/12A-32
Primary Maintenance	2F3/12A-19	Dusty Areas	2F16/12A-32
Starter Motor	2F3/12A-19	Ground Service Receptacle	2F16/12A-32
Removal and Installation	2F3/12A-19		

12A-1. ENGINE COWLING.

12A-2. DESCRIPTION. The engine cowling is similar to that described in Section 12, except it is wider at the front, with additional ram air openings in the right and left nose caps. The opening in the right side supplies ram air to the turbocharger. The opening in the left side supplies ram air to the cabin heating system.

12A-3. REMOVAL AND INSTALLATION. Refer to paragraph 12-3.

12A-4. CLEANING AND INSPECTION. Refer to paragraph 12-4.

12A-5. REPAIR. Refer to paragraph 12-5.

12A-6. COWL FLAPS.

12A-7. DESCRIPTION. The cowl flaps are similar to that described in Section 12, except the overboard exhaust tube for the cabin heater extends through the cutout in the aft portion of the left cowl flap.

12A-8. REMOVAL AND INSTALLATION. Refer to paragraph 12-8.

12A-9. RIGGING.

a. Disconnect cowl flap control clevises from cowl flaps.

b. Check to make sure that the flexible controls reach their internal stops in each direction. Mark controls so that full control travel can readily be checked and maintained during the remaining rigging procedures.

c. Place cowl flap control lever in the OPEN position, which is the top hole in the bracket. Be sure that correct hole in bracket is used. If control lever cannot be placed in correct hole in bracket, loosen clamp at upper end of controls and slip housings in clamp or adjust controls at upper clevis to position control lever in correct hole in bracket.

d. THRU 1979 MODELS. Adjust clevis at lower end of control so cowl flaps are streamlined in the closed position. BEGINNING WITH 1980 MODELS. Set cowl open .98 inch from cowl contour in the closed position. Measure at outboard trailing edge of cowl flap and 90° to cowl skin. If full travel of the control is obtained the open position will be correct.

f. Check that locknuts are tight, clamps are secure and all bolts and nuts are installed.

NOTE

In all cases, the flexible controls must reach their internal stops in each direction to assure full travel of the controls.

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-10. ENGINE.

12A-11. DESCRIPTION. An air-cooled, horizontally-opposed, direct-drive, fuel-injected, six-cylinder, turbocharged, Continental TSIO-520-R series engine, driving a constant-speed propeller, is used to power the aircraft. The cylinders, numbered from rear to front, are staggered to permit a separate throw on the crankshaft for each connecting rod. The right rear cylinder is number 1 and cylinders on the

right side are identified by odd numbers 1, 3 and 5. The left rear cylinder is number 2 and the cylinders on the left side are identified as 2, 4 and 6. Refer to paragraph 12A-12 for engine data. For repair and overhaul of the engine, accessories and propeller, refer to the appropriate publications issued by their manufacturer's. These publications are available from the Cessna Supply Division.

12A-12. ENGINE DATA.

Aircraft Series

T210

Model (Continental)

TSIO-520-R

BHP Maximum for Take-Off
(5 Minutes) at RPM

310
2700

BHP Maximum Except Take-Off
RPM (maximum Continuous)

285
2600

Limiting Manifold Pressure (Sea Level)

36.5 Inches Hg.

Number of Cylinders

6-Horizontally Opposed

Displacement

520 Cubic Inches

Bore

5.25 Inches

Stroke

4.00 Inches

Compression Ratio

7.5:1

Magnetos

Slick Model No. 662 (1977-1982 Models)

Right Magneto

Slick Model No. 6220 (Beginning with 1983 Models)

Left Magneto

Fires 22° BTC Upper Right and Lower Left

Fires 22° BTC Upper Left and Lower Right

Firing Order

1-6-3-2-5-4

Spark Plugs

18mm (Refer to Continental Service Bulletin M77-10 for factory approved spark plugs and required gap)
330±30 Lb-In.

Torque

Fuel Metering System

Continental Fuel Injection

Unmetered Fuel Pressure

5.5 to 6.5 PSI at 600 RPM

33 to 37 PSI at 2700 RPM (1977-1982 Models)

32 to 36 PSI at 2600 RPM (Beginning with 1983 Models)

Nozzle Pressure

3.5 to 4.0 PSI at 600 RPM

19.0 to 20.0 PSI at 2700 RPM

Oil Sump Capacity

10 U.S. Quarts

With Filter Element Change

11 U.S. Quarts

Tachometer

Mechanical Drive

Oil Pressure (PSI)

Minimum Idling

10

Normal

30-60

Maximum (Cold Oil Starting)

100

Connection Location

Between No. 2 and No. 4 Cylinders

Oil Temperature

Normal Operating

Within Green Arc

Maximum Permissible

Red Line (240°F)

Probe Location

In front of No. 5 Cylinder base

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-13. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
ENGINE FAILS TO START.	Engine flooded or improper use of starting procedure.	Use proper starting procedure. Refer to Pilot's Operating Handbook.
	Defective aircraft fuel system.	Refer to Section 13.
	Fuel tanks empty.	Service fuel tanks.
	Spark plugs fouled or defective.	Remove, clean, inspect and regap. Use new gaskets. Check cables to persistently fouled plugs. Replace if defective.
	Magneto impulse coupling failure.	Repair or install new coupling.
	Defective magneto switch or grounded magneto leads.	Repair or replace switch and leads.
	Defective ignition system.	Refer to paragraph 12-79.
	Induction air leakage.	Correct cause of air leakage.
	Clogged fuel screen in fuel control unit or defective unit.	Remove and clean. Replace defective unit.
	Clogged fuel screen in fuel manifold valve or defective valve.	Remove and clean screen. Replace defective valve.
	Clogged fuel injection lines or discharge nozzles.	Remove and clean lines and nozzles. Replace defective units.
	Defective auxiliary fuel pump.	Refer to Section 13.
	Engine-driven fuel pump not permitting fuel from auxiliary pump to bypass.	Install new engine-driven fuel pump.
ENGINE STARTS BUT DIES, OR WILL NOT IDLE PROPERLY.	Vaporized fuel in system. (Most likely to occur in hot weather with a hot engine.)	Refer to paragraph 12A-115.
	Propeller control in high pitch (low RPM) position.	Use low pitch (high RPM) position for all ground operations.
	Improper idle speed or idle mixture adjustment.	Refer to paragraph 12-46.
	Defective aircraft fuel system.	Refer to Section 13.
	Spark plugs fouled or defective.	Remove, clean, inspect and regap. Use new gaskets. Check cables to persistently fouled plugs. Replace if defective.
	Water in fuel system.	Drain fuel tank sumps, lines and fuel strainer.
	Defective ignition system.	Refer to paragraph 12-79.

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-13. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
ENGINE STARTS BUT DIES, OR WILL NOT IDLE PROPERLY (CONT).	Induction air leakage.	Correct cause of air leakage.
	Clogged fuel screen in fuel control unit or defective unit.	Remove and clean. Replace defective unit.
	Clogged fuel screen in fuel manifold valve or defective valve.	Remove and clean. Replace defective valve.
	Restricted fuel injection lines or discharge nozzles.	Remove, clean lines and nozzles. Replace defective units.
	Defective engine-driven fuel pump.	Install and calibrate new pump.
	Vaporized fuel in system. (Most likely to occur in hot weather with a hot engine.)	Refer to paragraph 12A-115.
	Manual engine primer leaking.	Disconnect primer outlet line. If fuel leaks through primer, repair or replace primer.
	Obstructed air intake.	Remove obstruction; service air filter, if necessary.
	Discharge nozzle air vent manifolding restricted or defective.	Check for bent lines or loose connections. Tighten loose connections. Remove restrictions and replace defective components.
ENGINE HAS POOR ACCELERATION, RUNS ROUGHLY AT SPEEDS ABOVE IDLE OR LACKS POWER.	Defective engine.	Check compression and listen for unusual engine noises. Check oil filter for excessive metal. Repair engine as required.
	Idle mixture too lean.	Refer to paragraph 12-46.
	Propeller control in high pitch (low RPM) position.	Use low pitch (high RPM) position for all ground operations.
	Incorrect fuel-air mixture, worn control linkage or restricted air filter.	Replace worn elements of control linkage. Service air filter.
	Defective ignition system.	Refer to paragraph 12-79.
	Malfunctioning turbocharger.	Check operation, listen for unusual noise. Check operation of wastegate valve and for exhaust system defects. Tighten loose connections.
Improper fuel-air mixture.	Check intake manifold connections for leaks. Tighten loose connections. Check fuel controls and linkage for setting and adjustment.	

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-13. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
ENGINE HAS POOR ACCELERATION, RUNS ROUGHLY AT SPEEDS ABOVE IDLE OR LACKS POWER (CONT).	Spark plugs fouled or defective.	Remove, clean, inspect and regap. Use new gaskets. Check cables to persistently fouled plugs. Replace if defective.
	Fuel pump pressure improperly adjusted.	Refer to paragraph 12A-62.
	Restriction in fuel injection system.	Clean out restriction. Replace defective items.
	Propeller out of balance.	Check and balance propeller.
	Defective engine.	Check compression, check oil filter for excessive metal. Listen for unusual noises. Repair engine as required.
	Exhaust system leakage.	Refer to paragraph 12A-100.
	Turbocharger wheels rubbing.	Replace turbocharger.
	Improperly adjusted or defective waste-gate controller.	Refer to paragraph 12A-112.
	Leak in turbocharger discharge pressure system.	Correct cause of leaks. Repair or replace damaged parts.
	Manifold pressure overshoot. (Most likely to occur when engine is accelerated too rapidly.)	Move throttle about two-thirds open. Let engine accelerate and peak. Move throttle to full open.
Engine oil viscosity too high for ambient air.	Refer to Section 2 for proper grade of oil.	
POOR IDLE CUT-OFF.	Mixture control linkage improperly rigged.	Refer to paragraph 12-86.
	Defective or dirty fuel manifold valve.	Remove and clean manifold valve.
	Fuel contamination.	Drain all fuel and flush out fuel system. Clean all screens, fuel strainers, fuel manifold valves, nozzles and fuel lines.
	Defective mixture control valve in fuel pump.	Replace fuel pump.
ENGINE LACKS POWER, REDUCTION IN MAXIMUM MANIFOLD PRESSURE OR CRITICAL ALTITUDE.	Incorrectly adjusted throttle control, "sticky" linkage or dirty air filter.	Check movement of linkage by moving control through range of travel. Make proper adjustments and replace worn components. Service air filter.

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-13. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
ENGINE LACKS POWER, REDUCTION IN MAXIMUM MANIFOLD PRESSURE OR CRITICAL ALTITUDE (CONT).	Defective ignition system.	Inspect spark plugs for fouled electrodes, heavy carbon deposits, erosion of electrodes, improperly adjusted electrode gaps and cracked porcelains. Test plugs for regular firing under pressure. Replace damaged or misfiring plugs.
	Improperly adjusted waste-gate valve.	Refer to paragraph 12A-112.
	Loose or damaged exhaust system.	Inspect entire exhaust system to turbocharger for cracks and leaking connections. Tighten connections and replace damaged parts.
	Loose or damaged manifolding.	Inspect entire manifolding system for possible leakage at connections. Replace damaged components, tighten all connections and clamps.
	Fuel discharge nozzle defective.	Inspect fuel discharge nozzle vent manifolding for leaking connections. Tighten and repair as required. Check for restricted nozzles and lines and clean and replace as necessary.
	Malfunctioning turbocharger.	Check for unusual noise in turbocharger. If malfunction is suspected, remove exhaust and/or air inlet connections and check rotor assembly, for possible rubbing in housing, damaged rotor blades or defective bearings. Replace turbocharger if damage is noted.
BLACK SMOKE EXHAUST.	Turbo coking, oil forced through seal of turbine housing.	Clean or change turbocharger.
HIGH CYLINDER HEAD TEMPERATURE.	Defective cylinder head temperature indicating system.	Refer to Section 16.
	Improper use of cowl flaps.	Refer to Pilot's Operating Handbook.
	Engine baffles loose, bent or missing.	Install baffles properly. Repair or replace if defective.
	Dirt accumulated on cylinder cooling fins.	Clean thoroughly.
	Incorrect grade of fuel.	Drain and refill with proper fuel.

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-13. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
HIGH CYLINDER HEAD TEMPERATURE (CONT).	Incorrect ignition timing.	Refer to paragraph 12-78.
	Improper use of mixture control.	Refer to Pilot's Operating Handbook.
	Defective engine.	Repair as required.
HIGH OR LOW OIL TEMPERATURE OR PRESSURE.		Refer to paragraph 12-30.
<p>NOTE</p> <p>Refer to paragraph 12A-107 for trouble shooting of controller and waste-gate actuator.</p>		

12A-13A. STATIC RUN-UP PROCEDURES. In a case of suspected low engine power, a static run-up should be conducted as follows:

a. Run-up engine, using take-off power and mixture settings, with the aircraft facing 90° right and then left to the wind direction.

b. Record the RPM obtained in each run-up position.

NOTE

Daily changes in atmospheric pressure, temperature and humidity will have a slight effect on static run-up.

c. Average the results of the RPM obtained. It should be within 50 RPM of 2680 RPM.

d. If the average results of the RPM obtained are lower than stated above, the following recommended checks may be performed to determine a possible deficiency.

1. Check governor control for proper rigging. It should be determined that the governor control arm travels to the high RPM stop on the governor and that the high RPM stop screw is adjusted properly. (Refer to Section 14 for procedures).

NOTE

If verification of governor operation is necessary the governor may be removed from the engine and a flat plate installed over the engine pad. Run-up engine to determine that governor was adjusted properly.

2. Check operation of alternate air door spring or magnetic lock to make sure door will remain closed in normal operation.

3. Check magneto timing, spark plugs and ignition harness for settings and conditions.

4. On fuel injection engines, check fuel injection nozzles for restriction and check for correct-unmetered fuel flow.

5. Check condition of induction air filter. Clean if required.

6. Perform an engine compression check (Refer to engine Manufacturer's Manual).

12A-14. REMOVAL. If an engine is to be placed in storage or returned to the manufacturer for overhaul, proper preparatory steps should be taken for corrosion prevention prior to beginning the removal procedure. Refer to Section 2 for storage preparation. The following engine removal procedure is based upon the engine being removed from the aircraft as a complete unit with the turbocharger and accessories installed.

NOTE

Tag each item when disconnected to aid in identifying wires, hoses, lines and control linkages when engine is reinstalled. Likewise, shop notes made during removal will often clarify reinstallation. Protect openings, exposed as a result of removing or disconnecting units, against entry of foreign material by installing covers or sealing with tape.

- Place all cabin switches in the OFF position.
- Place fuel selector valve or fuel ON-OFF control in the OFF position.
- Remove engine cowling in accordance with paragraph 12-3.
- Disconnect battery cables and insulate terminals as a safety precaution. Remove battery and battery box for additional clearance, if desired.
- Drain fuel strainer and lines with strainer drain control.

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

During the following procedures, remove any clamps or lacings which secure controls, wires, hoses or lines to the engine, engine nacelle or attached brackets, so they will not interfere with engine removal. Some of the items listed can be disconnected at more than one place. It may be desirable to disconnect some of these items at other than the places indicated. The reason for engine removal should be the governing factor in deciding at which point to disconnect them. Omit any of the items which are not present on a particular engine installation.

- f. Drain the engine oil sump and oil cooler.
- g. Disconnect magneto primary lead wires at magnetos.

WARNING

The magnetos are in a SWITCH ON condition when the switch wires are disconnected. Ground the magneto points or remove the high tension wires from the magnetos or spark plugs to prevent accidental firing.

h. Remove the spinner and propeller in accordance with Section 14. Cover exposed end of crankshaft flange and propeller flange to prevent entry of foreign material.

i. Disconnect throttle, mixture and propeller controls from their respective units. Remove clamps attaching controls to engine and pull controls aft clear of engine. Use care to avoid bending controls too sharply. Note EXACT position, size and number of attaching washers and spacers for reference on reinstallation.

- j. Disconnect wires and cables as follows:
 - 1. Disconnect tachometer drive shaft at adapter.

CAUTION

When disconnecting starter cable do not permit starter terminal bolt to rotate. Rotation of the bolt could break the conductor between bolt and field coils causing the starter to be inoperative.

- 2. Disconnect starter electrical cable at starter.
- 3. Disconnect cylinder head temperature wire at probe.
- 4. Disconnect oil temperature wire at probe below oil cooler.
- 5. Disconnect electrical wires and wire shielding ground at alternator.
- 6. Disconnect exhaust gas temperature wires at quick-disconnects.
- 7. Disconnect electrical wires at throttle micro-switches.
- 8. Remove all clamps and lacings attaching wires or cables to engine and pull wires and cables aft to clear engine.
- k. Disconnect lines and hoses as follows:

- 1. Disconnect vacuum hose at vacuum pump and remove oil separator vent line.

WARNING

Residual fuel and oil draining from disconnected lines and hoses constitutes a fire hazard. Use caution to prevent accumulation of such fuel and oil when lines or hoses are disconnected.

- 2. Disconnect fuel supply and vapor return hoses at fuel pump. Disconnect and remove fuel pump drain line.
- 3. Disconnect manifold pressure line at intake manifold.
- 4. Disconnect the fuel-flow gage line at firewall.
- 5. Disconnect the oil pressure line at the engine.
- 6. Disconnect and remove the right and left manifold drain lines and the balance tube drain line.
- 7. Disconnect air and oil lines at the waste-gate controller, located on the firewall.
- 8. Disconnect the air vent line to fuel-flow gage, at firewall.
- 9. Disconnect engine primer lines at right and left intake manifolds.
- 10. Disconnect the oil drain line from oil deflector under external oil filter.
 - 1. Disconnect flexible ducting from heater shroud and cabin valve.
 - m. Carefully check the engine again to ensure ALL hoses, lines, wires, cables, clamps and lacings are disconnected or removed which would interfere with the engine removal. Ensure all wires, cables and engine controls have been pulled aft to clear the engine.

CAUTION

Place a suitable stand under tail tie-down ring before removing engine. The loss of engine weight will cause the aircraft to be tail heavy.

- n. Attach a hoist to the lifting lug at the top center of the engine crankcase. Lift engine just enough to relieve the weight from the engine mounts.
 - o. Remove mount bolts, ground strap and heat shields.
 - p. Slowly hoist engine out of nacelle and clear of aircraft checking for any items which would interfere with the engine removal. Balance the engine by hand and carefully guide the disconnected parts out as the engine is removed.
 - q. Remove engine shock-mounts.

NOTE

If shock-mounts will be re-used, mark each one so it will be reinstalled in exactly the same position. If new shock-mounts will be installed, position them as illustrated in figure 12-2.

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-15. CLEANING. Refer to paragraph 12-15.

12A-16. ACCESSORIES REMOVAL. Refer to paragraph 12-16.

12A-17. INSPECTION. Refer to paragraph 12-17.

12A-18. BUILDUP. Refer to paragraph 12-18.

12A-19. INSTALLATION. Before installing the engine on the aircraft, install any items which were removed from the engine or aircraft after the engine was removed.

NOTE

Remove all protective covers, plugs, caps and identification tags as each item is connected or installed. Omit any items not present on a particular engine installation.

- a. Hoist the engine to a point just above the nacelle.
- b. Install engine shock-mounts and ground strap as illustrated in figure 12-2.
- c. Carefully lower engine slowly into place on the engine mounts. Route controls, lines, hoses and wires in place as the engine is positioned on the engine mounts.

NOTE

Be sure engine shock-mounts, spacers and washers are in place as the engine is lowered into position.

- d. Attach ground strap under engine sump bolt and install engine mount bolts. Torque bolts to 300 + 50 -0 lb-in. Bend tab washers to form lock for mount bolts. Install heat shields.
- e. Remove support stand placed under tail tie-down fitting and remove hoist.

NOTE

If the exhaust system was loosened or removed, refer to paragraph 12A-99.

- f. Connect flexible ducting on heater shroud and cabin valve.
- g. Route propeller governor control along left side of engine and secure with clamps.

NOTE

Throughout the aircraft fuel system, from the fuel bays to the engine-driven fuel pump, use NS-40 (RAS-4) (Snap-On Tools Corp., Kenosha, Wisconsin), MIL-T-5544 (Thread Compound, Antiseize, Graphite Petrolatum), USP Petrolatum or engine oil as a thread lubricant or to seal a leaking connection. Apply sparingly to male threads only, omitting the first two threads, exercising extreme caution to avoid "stringing" sealer across the end of the fitting. Always ensure that a compound, the residue from a previously used compound, or any other foreign material cannot enter the system. Throughout the fuel injection system, from the engine-driven fuel pump through the discharge nozzles, use only a fuel-soluble lubricant, such as engine oil, on fitting threads. Do not use any other form of thread compound on the injection system.

- h. Connect lines and hoses as follows:
 1. Install and connect the left and right manifold drain lines and the balance tube drain line.
 2. Connect the oil pressure line at its fitting.
 3. Connect the fuel-flow gage line at firewall.
 4. Connect the fuel supply and the vapor return lines at the fuel pump. Connect and install fuel pump drain line.
 5. Connect manifold pressure line at intake manifold.
 6. Connect vacuum line at the vacuum pump, and install oil separator vent line.
 7. Connect air and oil lines at waste-gate controller on firewall.
 8. Connect air vent line to fuel-flow gage line at firewall.
 9. Connect engine primer lines at right and left intake manifolds.
 10. Connect oil drain line to oil deflector under external oil filter.
 11. Install all clamps securing lines and hoses to engine or structure.
 - i. Connect wires and cables as follows:
 1. Connect oil temperature wire at probe below oil cooler.
 2. Connect tachometer drive to adapter and torque to 100 lb-in.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

WARNING

When connecting starter cable, do not permit starter terminal bolt to rotate. Rotation of the bolt could break conductor between terminal and field coils causing starter to be inoperative.

3. Connect starter electrical lead.
4. Connect cylinder head temperature wire at probe.
5. Connect electrical wires and wire shielding ground to alternator.
6. Connect electrical wiring to throttle switches.
7. Connect exhaust gas temperature wires at quick-disconnects.
8. Install clamps that attach wires or cables, to engine or structure.
- j. Connect engine controls and install block clamps.
- k. Rig engine controls in accordance with paragraphs 12-85, 12-86, 12-87 and 12-88.
- l. Install propeller and spinner in accordance with instructions outlined in Section 14.
- m. Complete a magneto switch ground-out and continuity check, then connect primary lead wires to the magnetos. Remove the temporary ground or connect spark plug leads, whichever procedure was used during removal.

WARNING

Be sure magneto switch is in OFF position when connecting switch wires to magnetos.

- n. Clean and install induction air filter in accordance with Section 2.
- o. Service engine with proper grade and quantity of engine oil. Refer to Section 2 if engine is new, newly overhauled or has been in storage.
- p. Check all switches are in the OFF position and connect battery cables.
- q. Inspect engine installation for security, correct routing of controls, lines, hoses and electrical wiring, proper safetying and tightness of all components.

NOTE

When installing a new or newly overhauled engine, and prior to starting the engine, tag and disconnect the oil inlet line at the controller and the oil outlet line at the controller. Connect these oil lines to a full flow oil filter, allowing oil to bypass the controller. With the filter connected, operate the engine approximately 15 minutes to filter out any foreign particles from the oil. This is done to prevent foreign material from entering the controller. After this run period disconnect the full-flow filter and re-connect the lines to the controller as tagged.

- r. Install engine cowling in accordance with paragraph 12-3.
 - s. Perform an engine run-up and make final adjustments on the engine controls.
- 12A-20. FLEXIBLE FLUID HOSES. Refer to paragraph 12-20.
- 12A-21. PRESSURE TEST. Refer to paragraph 12-21.
- 12A-22. REPLACEMENT. Refer to paragraph 12-22.
- 12A-23. ENGINE BAFFLES. Refer to paragraph 12-23.
- 12A-24. DESCRIPTION. Refer to paragraph 12-24.
- 12A-25. CLEANING AND INSPECTION. Refer to paragraph 12-25.
- 12A-26. REMOVAL AND INSTALLATION. Refer to paragraph 12-26.
- 12A-27. REPAIR. Refer to paragraph 12-27.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-28. ENGINE OIL SYSTEM.

12A-29. DESCRIPTION. The oil system is of the full pressure wet sump type. Refer to applicable engine manufacturer's overhaul manual for specific details and descriptions.

12A-30. TROUBLE SHOOTING. Refer to paragraph 12-30.

12A-31. FULL-FLOW OIL FILTER. Refer to paragraph 12-31.

12A-32. DESCRIPTION. Refer to paragraph 12-32.

12A-33. REMOVAL AND INSTALLATION. Refer to paragraph 12-33.

12A-34. FILTER ADAPTER. Refer to paragraph 12-34.

12A-35. REMOVAL. Refer to paragraph 12-35.

12A-36. DISASSEMBLY, INSPECTION AND RE-ASSEMBLY. Refer to paragraph 12-36.

12A-37. INSTALLATION. Refer to paragraph 12-37.

12A-38. OIL COOLER. Refer to paragraph 12-38.

12A-39. DESCRIPTION. Refer to paragraph 12-39.

12A-40. ENGINE FUEL SYSTEM. Refer to figure 12A-2.

12A-41. DESCRIPTION. The fuel injection system is a low pressure system of injecting fuel into the intake valve port of each cylinder. It is a multi-nozzle, continuous-flow type which controls fuel flow to match engine airflow. Any change in throttle position, engine speed, or combination of both, causes changes in fuel flow in the correct relation to engine airflow. A manual mixture control and a fuel flow indicator are provided for leaning at any combination of altitude and power setting. The fuel flow indicator is calibrated in gallons per hour and indicates approximately the gallons of fuel consumed per hour. The continuous-flow system uses a typical rotary vane fuel pump. There are no running parts in this system except for the engine-driven fuel pump. The four major components of the system are: the fuel injection pump, fuel-air control unit, fuel mani-

fold valve and the fuel discharge nozzles. The fuel injection pump incorporates an adjustable aneroid sensing unit which is pressurized from the discharge side of the turbocharger compressor. Turbocharger discharge air pressure is also used to vent the fuel discharge nozzles and the vent port of the fuel-flow gage.

NOTE

Throughout the aircraft fuel system, from the fuel bays to the engine-driven fuel pump, use NS-40 (RAS-4, Snap-On Tools Corp., Kenosha, Wisconsin), MIL-T-5544 (Thread Compound, Antiseize, Graphite-Petrolatum) or equivalent, as a thread lubricant or to seal a leaking connection. Apply sparingly to male fittings only, omitting the first two threads. Always ensure that a compound, the residue from a previously used compound or any other foreign material cannot enter the system. Throughout the fuel injection system, from the engine-driven fuel pump through the discharge nozzles, use only a fuel soluble lubricant, such as engine lubricating oil, on the fitting threads. Do not use any other form of thread compound on the injection system fittings.

12A-42. FUEL-AIR CONTROL UNIT. Refer to paragraph 12-42.

12A-43. DESCRIPTION. Refer to paragraph 12-43.

12A-44. REMOVAL.

- a. Place all cabin switches and fuel selector or fuel ON-OFF valve in the OFF position.
- b. Remove cowling in accordance with paragraph 12-3.
- c. Loosen clamp and disconnect flexible duct from elbow at top of air throttle.
- d. Tag and disconnect electrical wires from electric fuel pump microswitch.
- e. Disconnect throttle and mixture control rod ends at fuel-air control unit.

NOTE

Cap or plug all disconnected hoses, lines and fittings.

- f. Disconnect cooling air blast tube from fuel control valve shroud.
- g. Disconnect and tag all fuel lines at the fuel control valve.
- h. Remove nuts and washers securing triangular brace to fuel-air control unit and engine, at lower end of control unit. Remove brace.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 12A-2. Fuel System Schematic

MODEL 210 & T210 SERIES SERVICE MANUAL

- i. Remove bolt attaching fuel-air control unit to brace at top of control unit.
- j. Loosen hose clamps which secure fuel-air control unit to right and left intake manifold assemblies and slip hoses from fuel-air control unit.
- k. Remove fuel-air control unit.

12A-45. CLEANING AND INSPECTION. Refer to paragraph 12-45.

12A-46. INSTALLATION.

- a. Place control unit in position at rear of engine.
- b. Install bolt attaching control unit to brace at top of unit. Ascertain that shock-mount is in place and in good condition.
- c. Install triangular brace at lower end of control unit.
- d. Install hoses and clamps which secure control unit to right and left intake manifold assemblies. Tighten hose clamps.
- e. Connect fuel lines to unit and connect air blast tube at fuel control shroud.
- f. Connect throttle and mixture control rod ends to control unit.
- g. Connect electrical wiring to throttle-operated microswitch. Check switch rigging in accordance with Section 13.
- h. Install induction air duct to elbow at top of control unit.
- i. Inspect installation and install cowling.

12A-47. ADJUSTMENTS. Refer to paragraph 12-46.

12A-48. FUEL MANIFOLD VALVE (FUEL DISTRIBUTOR). Refer to paragraph 12-47.

12A-49. DESCRIPTION. Refer to paragraph 12-48.

12A-50. REMOVAL. Refer to paragraph 12-49.

12A-51. CLEANING. Refer to paragraph 12-50.

12A-52. INSTALLATION. Refer to paragraph 12-51.

12A-53. FUEL DISCHARGE NOZZLES.

12A-54. DESCRIPTION. From the fuel manifold valve, individual, identical size and length fuel lines carry metered fuel to the fuel discharge nozzles located in the cylinder heads. The outlet of each nozzle is directed into the intake port of each cylinder. An air bleed and nozzle pressurization arrangement is incorporated in each nozzle to aid in vaporization of the fuel. The nozzles are calibrated in several ranges. All nozzles furnished for one engine are of the same calibrated range and are identified by a number and suffix letter stamped on the flat portion of the nozzle body. When replacing a fuel discharge nozzle, be sure that it is of the same calibrated range as the rest of the nozzles in that engine. When a complete set of nozzles is being replaced, the number must be the same as the one removed but the suffix letter may be different, as long as they are the same for all nozzles being installed in a particular engine.

12A-55. REMOVAL.

- a. Remove engine cowling in accordance with paragraph 12-3.

NOTE

Plug or cap all disconnected lines and fittings.

- b. Disconnect nozzle pressurization line at nozzles and disconnect pressurization line at "tee" fitting so that pressurization line may be moved away from discharge nozzles.
- c. Disconnect fuel injection line at fuel discharge nozzle.
- d. Using care to prevent damage or loss of washers and O-rings, lift sleeve assembly from fuel discharge nozzle.
- e. Using a standard 1/2-inch deep socket, remove fuel discharge nozzle from cylinder.

12A-56. CLEANING AND INSPECTION. Refer to paragraph 12-55.

12A-57. INSTALLATION.

- a. Using a standard 1/2-inch deep socket, install nozzle body in cylinder and tighten to a torque value of 60-80 lb-in.
- b. Install O-rings, sleeve assembly and washers.
- c. Align sleeve assembly and connect pressurization line to nozzles. Connect pressurization line to "tee" fitting.
- d. Install O-ring and washer at top of discharge nozzle and connect fuel injection line to nozzle.
- e. Inspect installation for crimped lines and loose fittings.
- f. Inspect nozzle pressurization vent system for leakage. A tight system is required, since turbo-charger discharge pressure is applied to various other components of the injection system.
- g. Install cowling.

12A-58. FUEL INJECTION PUMP.

12A-59. DESCRIPTION. The fuel pump is a positive displacement, rotating vane type. It has a splined shaft for connection to the accessory drive section of the engine. Fuel enters the pump at the swirl well of the pump vapor separator. Here, vapor is separated by a swirling motion so that only liquid fuel is fed to the pump. The vapor is drawn from the top center of the swirl well by a small pressure jet of fuel and is fed into the vapor return line where it is returned to the fuel tank. Since the pump is engine-driven, changes in engine speed affect total pump flow proportionally. A check valve allows the auxiliary fuel pump pressure to bypass the engine-driven pump for starting, or in the event of engine-driven fuel pump failure in flight. The pump supplies more fuel than is required by the engine; therefore, a relief valve is provided to maintain a constant fuel pump pressure. The engine-driven fuel pump is equipped with an aneroid. The aneroid and relief valve are pressurized from the

MODEL 210 & T210 SERIES SERVICE MANUAL

discharge side of the turbocharger compressor to maintain a proper fuel/air ratio at altitude. The aneroid is adjustable for fuel pump outlet pressure at full throttle and the relief valve is adjustable for fuel pump outlet pressure at idle.

12A-60. REMOVAL.

- a. Place fuel selector or fuel ON-OFF valve in OFF position.
- b. Remove engine cowling in accordance with paragraph 12-3.
- c. Remove alternator and left rear intake elbow.
- d. Hoist engine far enough to remove weight from engine mount and remove left rear engine mount leg, shock-mount and alternator bracket.
- e. Remove flexible duct and shroud, removing fuel lines and fittings as necessary. Tag each fitting and line for identification and cap or seal to prevent entry of foreign material. Flanges of shroud may be straightened to facilitate removal and installation, but must be re-formed after installation. Note angular position of fittings before removal.
- f. Remove nuts and washers attaching fuel pump to engine and pull pump aft to remove. Remove thin gasket.
- g. Place temporary cover on pump mounting pad.

12A-61. INSTALLATION.

- a. Install and align any fittings removed after pump removal.
- b. Using new thin gasket, install pump with aneroid chamber down.
- c. Install cooling shroud and remainder of fittings, bending flanges of shroud to their original positions and aligning fittings as noted during removal.
- d. Connect all fuel lines and shroud flexible duct.
- e. Install alternator bracket, shock-mount and engine mount leg. Remove hoist, then adjust alternator drive belt tension. Refer to Section 17.
- f. Install intake elbow.
- g. Start engine and perform an operational check, adjusting fuel pump if required.
- h. Install cowling.

12A-62. ADJUSTMENT. (1977 thru 1982 Models).

Adjustments of the fuel injection pump requires special equipment and procedures. Adjustment to the aneroid applies only to the full throttle setting. Adjustment of the idle position is obtained through the relief valve. To adjust the pump to the pressures specified in paragraph 12A-12, proceed as follows:

- a. Remove engine cowling in accordance with paragraph 12-3.
- b. Disconnect the existing engine-driven fuel pump pressure hose at the fuel metering unit and connect the test gage pressure hose and fittings into the fuel injection system as shown in figure 12A-3. Gage MUST be vented to atmosphere.

NOTE

Cessna Service Kit No. SK320-2K provides a test gage, line and fittings for connecting the test gage into the system to perform accurate calibration of the engine-driven fuel pump.

- c. The test gage MUST be held as near to the level of the engine driven fuel pump as possible. Bleed air from test gage line prior to taking readings.

NOTE

The test gage should be checked for accuracy at least every 90 days or anytime an error is suspected. The tachometer accuracy should also be determined prior to making any adjustments to the pump.

- d. Start engine and warm-up thoroughly. Set mixture control to full rich position and propeller control full forward (low pitch, high rpm).
- e. Adjust engine idle speed to 600 ± 25 rpm and check test gage for 5.5 - 6.5 PSI. Refer to figure 12-7 for idle mixture adjustment.

NOTE

Do not adjust idle mixture until idle pump pressure is obtained.

WARNING

DO NOT make fuel pump pressure adjustments while engine is operating.

- f. If the pump pressure is not 5.5 - 6.5 PSI, stop engine and turn the pump relief valve adjustment, on the fuel pump clockwise (CW) to increase pressure and counterclockwise (CCW) to decrease pressure.

- g. Maintaining idle pump pressure and idle RPM, obtain correct idle mixture in accordance with paragraph 12-46.

- h. Completion of the preceding steps have provided:
 1. Correct idle pump pressure.
 2. Correct fuel flow.
 3. Correct fuel metering cam to throttle plate orientation.

- i. Advance to full throttle and maximum rated engine speed (propeller control full forward) with the mixture control in the full rich position and verify that maximum limit manifold pressure (36.5±.5) is indicated. If manifold pressure is incorrect or static RPM is not at least 2650 RPM refer to paragraph 12A-13A or 12A-110.

NOTE

If a static run-up, rated RPM (2700) cannot be achieved at full throttle, adjust pump flow slightly below limits (-1 PPH for each 10 RPM low). Verify that correct pressures are obtained when rated RPM is achieved during take-off roll.

- j. Check ships fuel flow gage for 186 - 190 PPH. If fuel flow is incorrect, stop engine and adjust flow. This is accomplished by loosening the locknut and turning the adjusting screw located at the rear of the aneroid counterclockwise (CCW) to increase flow or clockwise (CW) to decrease flow. When fuel flow is correct, verify the unmetered pressure is within the limits specified in paragraph 12A-12.

MODEL 210 & T210 SERIES SERVICE MANUAL

k. After correct pressures are obtained, shut down engine and tighten locknut on fuel pump adjustment screw.

l. Remove test equipment, run engine to check for leaks and install cowling.

12A-62A. ADJUSTMENT. (Beginning with 1983 Models.) Adjustments of the fuel injection pump requires special equipment and procedures. Adjustment to the aneroid applies only to the full throttle setting. Adjustment of the idle position is obtained through the relief valve. To adjust the pump to the pressures specified in paragraph 12A-12, proceed as follows:

a. Remove engine cowling in accordance with paragraph 12-3.

b. Disconnect the existing engine-driven fuel pump pressure hose at the fuel metering unit or fuel limiter unit and connect the test gage pressure hose and fittings into the fuel injection system as shown in figure 12A-3. Gage MUST be vented to atmosphere.

NOTE

Cessna Service Kit No. SK320-2K provides a test gage, line and fittings for connecting the test gage into the system to perform accurate calibration of the engine-driven fuel pump.

c. The test gage MUST be held as near to the level of the engine driven fuel pump as possible. Bleed air from test gage line prior to taking readings.

NOTE

The test gage should be checked for accuracy at least every 90 days or anytime an error is suspected. The tachometer accuracy should also be determined prior to making any adjustments to the pump.

d. Disconnect line from the return (center) port of fuel flow limiter, plug line and cap port. See figure 12A-2A.

CAUTION

Do not plug side port (inlet) of pressure limiter or limiter may be damaged during adjustment.

e. Start engine, warm up and run until oil temperature reads 40% to 70% in the green arc range. Oil cooler inlet may have to be partially blocked in cold weather. Set mixture control to full rich position and propeller control full forward (low pitch, high RPM).

NOTE

DO NOT make fuel pump pressure adjustments while engine is operating.

g. If the pump pressure is not 5.5 - 6.5 PSI, stop engine and turn the pump relief valve adjustment, on the centerline of the fuel pump clockwise (CW) to increase pressure and counterclockwise (CCW) to decrease pressure.

h. Maintaining idle pump pressure and idle RPM, obtain correct idle mixture in accordance with paragraph 12-46.

i. Completion of the preceding steps have provided:

1. Correct idle pump pressure.

2. Correct fuel flow.

3. Correct fuel metering cam to throttle plate orientation.

j. Advance to full throttle and maximum rated engine speed (propeller control full forward) with the mixture control in the full rich position and verify that maximum limit manifold pressure ($36.5 \pm .5$) is indicated. If manifold pressure is incorrect or static RPM is not at least 2650 RPM refer to paragraphs 12A-13A and 12A-110.

k. Retard the propeller control to obtain 2600 ± 25 RPM stabilized.

l. Check ships fuel flow gage for 186 - 190 PPH. If fuel flow is incorrect, stop engine and adjust flow by loosening locknut and turning the adjusting screw located at the aneroid counterclockwise (CCW) to increase flow or clockwise (CW) to decrease flow. When fuel flow is correct, verify the unmetered pressure is within the limits specified in paragraph 12A-12.

m. After correct pressures are obtained, shut down engine and tighten locknut on fuel pump adjustment screw.

n. Reconnect line to return (center) port of fuel flow limiter.

o. Start engine and advance to full throttle with mixture control full rich and the propeller control full forward. Check the ships fuel flow gage for 186 - 190 PPH. If fuel flow is incorrect, shut down the engine and adjust fuel flow set screw on fuel flow limiter (clockwise (CW) to increase, counterclockwise (CCW) to decrease to obtain proper fuel flow.

p. Remove test equipment, run engine, check for leaks and install cowling.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 12A-2A. Fuel-Injection Pump Adjustment/Test

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 12A-3. Fuel Injection Pump Adjustment Test Harness (Turbocharged Engine)

12A-63. INDUCTION AIR SYSTEM.

12A-64. DESCRIPTION. Ram air to the engine enters an induction air duct at the right side of the nose cap. The air is filtered through a dry filter, located in the induction airbox. From the filter, the air passes through a flexible duct to the inlet of the turbocharger compressor. The pressurized air is then routed through a duct to the fuel-air control unit mounted behind the engine and is then supplied to the cylinders through the intake manifold piping. The fuel-air control unit is connected to the cylinder intake manifold by elbows, hoses and clamps. The intake manifold is attached to each cylinder by four bolts through a welded flange, which is sealed by a gasket. A balance tube passes around the front side of the engine to complete the manifold assembly. An

alternate air door, mounted in the duct between the filter and the turbocharger compressor, is held closed by a small magnet. If the induction air filter should become clogged, suction from the turbocharger compressor will open the door permitting the compressor to draw heated, unfiltered air from within the engine compartment. The alternate air door, Serial 21061574 thru 21063489, should be checked every 100 hours of operation for hinge wear, ease of operation, and complete closing. If excessive hinge wear is found, the hinge and magnetic catches should be replaced. Refer to Service Information Letter #SE80-12 for part numbers. The induction air filter should be removed and cleaned at each 50-hour inspection, or more frequently when operating under dusty conditions. Refer to Section 2.

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-65. AIRBOX.

12A-66. REMOVAL AND INSTALLATION.

- a. Remove engine cowling in accordance with paragraph 12-3.
- b. Loosen clamp at lower end of airbox and remove flexible duct.
- c. Remove two screws, washers and nuts attaching airbox to upper rear engine baffle.
- d. Remove four screws attaching airbox to induction air duct and work airbox and filter from duct.
- e. Remove screws attaching clips on duct to clips on rocker box covers.
- f. Remove screws attaching lower side of induction air duct to the two front cylinder rocker box covers.
- g. Loosen clamp and remove air duct from flexible inlet air duct and remove duct.
- h. Reverse the preceding steps for reinstallation.

NOTE

Clean filter and ascertain that induction air ducts and airbox are clean when installing.

12A-67. CLEANING AND INSPECTION. Refer to paragraph 12-66.

12A-68. INDUCTION AIR FILTER.

12A-69. DESCRIPTION. An induction air filter, mounted in the aft end of the airbox removes dust particles from the ram air entering the engine.

12A-70. REMOVAL AND INSTALLATION.

- a. Remove right half of engine cowling in accordance with paragraph 12-3.
- b. Remove screws attaching airbox to upper rear baffle.
- c. Loosen clamp and disconnect flexible air duct to airbox.
- d. Remove four screws attaching airbox to forward air duct and work airbox and filter from aircraft.
- e. Remove four bolts, washers and nuts attaching filter between airbox halves.

NOTE

When installing filter, note direction of air flow. Inspect and install gasket at aft face of filter assembly. Also, when tightening bolts fastening filter, push inward on lower end of the upper duct (where turbocharger inlet connects to the upper duct). This is done so that inlet hose doesn't chafe against the cowling.

- f. Reverse the preceding steps for reinstallation.

12A-71. CLEANING AND INSPECTION. Clean and inspect filter in accordance with Section 2.

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-71A. INSTALLATION OF INDUCTION AIR SYSTEM DUCTS. When cutting induction air system ducts to length, the support wire should be cut back far enough to bend back (Minimum bend radius, 1/8 inch) under the clamp and protrude 1/4 inch. Do not break the bond between the wire and the fabric. Before tightening clamps, make sure there is no twist or torque on the duct. If the duct is supported with MIL-Y-1140 cord in place of wire, the preceding installation applies except; MIL-Y-1140 cord has no minimum bend radius requirements.

The minimum installed bend radii for wire-supported ducts in plane of bend, measured from the wall of the duct, are as follows:

1. Neoprene - one ply, 1/4 diameter of the maximum duct dimension.
2. Neoprene - two ply, and silicone - one ply. 1/3 diameter of the maximum duct dimension.
3. Silicone - two ply. 1/2 diameter of the maximum duct dimension.

NOTE

Ducts carrying filtered induction air may not have local areas hand-formed to a different cross section.

12A-72. IGNITION SYSTEM. Refer to paragraph 12-71.

12A-73. DESCRIPTION. Refer to paragraph 12-72.

12A-74. TROUBLE SHOOTING. Refer to paragraph 12-73.

12A-75. MAGNETOS. Refer to paragraph 12-74.

12A-75A. PRESSURIZED MAGNETOS (Beginning with 1983 Model T210). Pressurized air is taken from the throttle body adaptor assembly and directed by a hose, through a filter, to a tee and then to each magneto. The filter material is enclosed in a transparent case, with a flow arrow imprinted on it. The filter should be replaced when the filtering material is dirty.

12A-76. DESCRIPTION. Refer to paragraph 12-75.

12A-77. REMOVAL. Refer to paragraph 12-76.

12A-78. INTERNAL TIMING. Refer to paragraph 12-77.

12A-79. INSTALLATION AND TIMING-TO-ENGINE. Refer to paragraph 12-78.

12A-80. MAINTENANCE. Refer to paragraph 12-79.

12A-81. MAGNETO CHECK. Refer to paragraph 12-80.

12A-82. SPARK PLUGS. Refer to paragraph 12-81.

12A-83. ENGINE CONTROLS. Refer to paragraph 12-82.

12A-84. DESCRIPTION. Refer to paragraph 12-83.

12A-85. RIGGING. Refer to paragraph 12-84.

12A-86. THROTTLE CONTROL. Refer to paragraph 12-85.

12A-87. MIXTURE CONTROL. Refer to paragraph 12-86.

12A-88. PROPELLER CONTROL. Refer to Section 14.

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-89. RIGGING THROTTLE-OPERATED MICRO-SWITCH. Refer to Section 13.

12A-89A. AUXILIARY ELECTRIC FUEL PUMP FLOW ADJUSTMENT. Refer to Section 13.

12A-89B. LANDING GEAR WARNING HORN. Refer to Section 5.

12A-90. STARTING SYSTEM. Refer to paragraph 12-89.

12A-91. DESCRIPTION. Refer to paragraph 12-90.

12A-92. TROUBLE SHOOTING. Refer to paragraph 12-91.

12A-93. PRIMARY MAINTENANCE. Refer to paragraph 12-92.

12A-94. STARTER MOTOR.

12A-95. REMOVAL AND INSTALLATION.

- a. Remove cowling in accordance with paragraph 12-3.
- b. Remove induction airbox in accordance with paragraph 12A-66.
- c. Disconnect electrical power cable at starter and insulate terminal as a safety precaution.
- d. Remove nuts securing starter and remove starter.
- e. Reverse the preceding steps for reinstallation. Install a new O-ring and be sure the starter drive engages with the drive in the adapter.

12A-96. EXHAUST SYSTEM. Refer to figure 12A-4.

12A-97. DESCRIPTION. The exhaust system consists of two exhaust stack assemblies, one for the left and one for the right bank of cylinders. These exhaust stack assemblies are joined together to route the exhaust from all cylinders through the waste-gate or turbine. The three risers on the left bank of cylinders are joined together into a common pipe to form the left stack assembly. The right rear cylinder exhaust is routed down and aft to the rear of the engine where it connects to the left stack assembly. The risers on the two right front cylinders are connected to a common pipe to form the right stack assembly. The right stack assembly connects to the left stack assembly at the front of the engine. Mounting pads for the waste-gate and turbine are provided on the right stack assembly. From the exhaust port of the turbine, a tailpipe routes the exhaust overboard through the lower fuselage. The exhaust port of the waste-gate is routed into the tailpipe so the exhaust gas can be expelled from the system when not needed at the turbine. The waste-gate is actuated by the waste-gate actuator which, in turn, is controlled by the waste-gate controller. Also, sleeving is installed on the fuel hose from the engine-driven pump to the fuel metering body and on the hose from the auxiliary fuel pump to the engine-driven pump. This is to prevent excessive heat on these fuel hoses as they route close to the exhaust stack.

12A-98. REMOVAL.

- a. Remove engine cowling and right and left nose caps in accordance with paragraph 12-3.
- b. Remove intake manifold balance tube from front of engine.
- c. Remove heat shield at front of engine.
- d. Loosen clamp and disconnect flexible duct at aft end of cabin heater shroud on left exhaust stack assembly.
- e. Remove clamps and bolts securing rear heat shield to engine and remove heat shield.
- f. Remove clamps attaching left exhaust stack assembly to riser pipes and to rear crossover pipe on left side of engine.
- g. Work left exhaust stack assembly down from risers and out of crossover pipes at front and rear of engine.
- h. Remove four nuts and washers attaching exhaust riser pipe to each cylinder on left bank of cylinders and remove riser pipes and gaskets.
- i. Remove clamp attaching exhaust tailpipe to exhaust port of turbine.
- j. Remove bolts attaching waste-gate to right exhaust stack assembly. Work tailpipe from turbine and lower waste-gate and tailpipe into cowling.
- k. Remove bolts attaching turbocharger to mounting brackets.
- l. Remove bolts and nuts attaching turbocharger to right exhaust stack assembly. Lower turbocharger into cowling.
- m. Remove bolts, nuts and clamps attaching right exhaust stack assembly to riser pipes on right side of engine.
- n. Work right exhaust stack assembly down from risers and remove.
- o. Remove nuts and washers attaching riser pipes to front two cylinders on right side of engine and remove riser pipes and gaskets.
- p. Remove nuts and washers attaching exhaust pipe to rear cylinder on right side of engine and remove pipe and gasket.

12A-99. INSTALLATION.

NOTE

It is important that the complete exhaust system, including the turbocharger and waste-gate, be installed without pre-loading any section of the exhaust stack assembly.

- a. Use new gaskets between exhaust stacks and engine cylinders, at each end of waste-gate and between turbocharger and exhaust stack.
- b. Place all sections of exhaust stacks in position and torque nuts attaching them to the cylinders evenly to 100-110 lb-in., while riser clamps are loose.
- c. Manually check that crossover pipe slip-joints do not bind. Tighten clamp attaching left risers to left stack assembly. Tighten the clamp attaching right stack to right front riser.
- d. Raise turbocharger into position and install bolts and nuts attaching turbocharger to right exhaust stack and those attaching turbocharger to front and rear turbocharger supports (figure 12A-6). Tighten bolts.

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 12A-4. Exhaust System (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL



HEAT DEFLECTORS AND INSULATORS

- | | | |
|---------------------------------|----------------|--------------------|
| 1. Clamp | 6. Heat Shield | 10. Right Nosecap |
| 2. Crankcase | 7. Bolt | 11. Insulation |
| 3. Intake Manifold Balance Tube | 8. Lockwasher | 12. Retaining Skin |
| 4. Heat Deflector | 9. Washer | 13. Left Nosecap |
| 5. Rivet | | 14. Screw |

Figure 12A-4. Exhaust System (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

- e. Install bolts and nuts attaching waste-gate to right hand exhaust stack and tighten securely.
- f. While applying an upward force of one G to counteract weight of turbocharger and waste-gate assembly, tighten clamp attaching exhaust stack to riser.
- g. Tighten clamp securing tailpipe to turbocharger.
- h. Be sure all parts are secure and safetied as required, then perform step "b" of paragraph 12A-100 to check for air leaks.
- i. Install heater shroud duct and heat shields.
- j. Install intake manifold balance tube at front of engine and install heat shields at front of engine, then install nose caps and cowling.

NOTE

The lower sections of turbocharger supports (index 8, figure 12A-6) are supplied as service parts with their upper holes omitted. These undrilled parts are also supplied when a new turbocharger inlet stack, right front stack, or either of the two right front risers is ordered. The following steps outline the proper procedure for drilling and installing the supports.

- k. Install all parts but do not tighten attaching clamps or bolts.
 - 1. Torque nuts attaching risers to cylinders evenly to 100-110 lb-in.
- m. Tighten bolts and clamps per steps "d" through "g".

NOTE

It is important that weight of turbocharger and waste-gate assembly be counteracted, as listed in step "f", when tightening clamps attaching stacks to risers.

- n. Make hole locations in undrilled supports to match existing holes in upper supports.
- o. Remove lower supports, leaving all other parts tight.
- p. Drill the marked holes with a 3/8-inch drill.
- q. Reinstall supports, install bolts fastening upper and lower supports together, then tighten all bolts securely. If any exhaust system bolts or clamps were loosened while lower supports were not installed, loosen all clamps and bolts and repeat the installation procedure to be sure no pre-loading is present.
- r. Be sure all parts are secure and safetied as required, reinstall any parts removed for access, then install nose caps and cowling.

12A-100. INSPECTION. Since exhaust systems of this type are subject to burning, cracking and general deterioration from alternate thermal stresses and vibrations, inspection is important and should be accomplished every 50 hours of operation. Also, a thorough inspection of the engine exhaust system should

be made to detect cracks causing leaks which could result in loss of optimum turbocharger efficiency and engine power. To inspect the engine exhaust system proceed as follows:

- a. Remove engine cowling as required and remove heater shroud so that ALL surfaces of the exhaust assemblies can be visually inspected.

WARNING

Never use highly flammable solvents on engine exhaust systems. Never use a wire brush or abrasives to clean exhaust systems or mark on the system with lead pencils.

NOTE

Especially check the areas adjacent to welds and slip joints. Look for gas deposits in surrounding areas, indicating that exhaust gases are escaping through a crack or hole or around the slip joints.

- b. After visual inspection, an air pressure test should be made on the exhaust system as follows:
 - 1. Attach the pressure side of an industrial vacuum cleaner to the tailpipe opening, using a rubber plug to effect a seal as required.

NOTE

The inside of the vacuum cleaner hose should be free of any contamination that might be blown into the engine exhaust system.

- 2. With vacuum cleaner operating, all joints in the exhaust system and the heat exchanger area may be checked manually by feel, or by using a soap and water solution and watching for bubbles. The exhaust manifold in the heat exchanger area must be free of air leaks. In other areas, forming of bubbles is acceptable; however, if bubbles are blown away system is not acceptable. Also, some bubbles will appear at the joint of the turbocharger turbine and compressor bearing housing.

- c. Where a surface is not accessible for a visual inspection, or for a more positive test, the following procedure is recommended.

- 1. Remove exhaust stack assemblies.
- 2. Use rubber expansion plugs to seal openings.
- 3. Using a manometer or gage, apply approximately 1-1/2 psi (3 inches of mercury) air pressure while each stack assembly is submerged in water. Any leaks will appear as bubbles and can be readily detected.
- d. It is recommended that any components of the exhaust system found defective be replaced before the next flight.
- e. After installation of exhaust system components, recheck by performing the air pressure test to make sure that system is acceptable.

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-101. TURBOCHARGER.

12A-102. DESCRIPTION. The turbocharger is an exhaust gas-driven compressor, or air pump, which provides high velocity air to the engine intake manifold. The turbocharger is composed of a turbine wheel, compressor wheel, turbine housing and compressor housing. The turbine, compressor wheel and interconnecting drive shaft comprise one complete assembly and are the only moving parts in the turbocharger. Turbocharger bearings are lubricated with filtered oil supplied from the engine oil system. Engine exhaust gas enters the turbine housing to drive the turbine wheel. The turbine wheel, in turn, drives the compressor wheel, producing a high velocity of air entering the engine induction intake manifold. Exhaust gas is then dumped overboard through the exhaust outlet of the turbine housing and exhaust tailpipe. Air is drawn into the compressor through the induction air filter and is forced out of the compressor housing through a tangential outlet to the intake manifold. The degree of turbocharging is varied by means of a waste-gate valve, which varies the amount of exhaust gas allowed to bypass the turbine.

12A-103. REMOVAL AND INSTALLATION. (Refer to figure 12A-6).

- a. Remove engine cowling as required.
- b. Remove waste-gate to tailpipe clamp.
- c. Loosen clamp at turbine exhaust outlet and work tailpipe from turbine outlet.
- d. Loosen clamps and remove air inlet and outlet ducts from turbocharger compressor.
- e. Disconnect oil pressure and scavenger lines from turbocharger. Plug or cap open oil lines and fittings. Remove clamp on oil supply line to the turbocharger.
- f. Loosen clamp and remove induction air inlet elbow at turbocharger compressor.
- g. Remove right cowl flap by disconnecting control at cowl flap and removing hinge pin.
- h. Cut safety wire and remove two bolts attaching turbine to forward mounting bracket.
- i. Remove three bolts attaching turbine to turbine rear mounting bracket.
- j. Remove three remaining bolts, washers and nuts attaching turbine to exhaust manifold.
- k. Work turbocharger from aircraft through cowl flap opening in lower cowling.

1. Reverse the preceding steps for reinstallation. When installing the turbocharger, install a new gasket between exhaust manifold and turbine exhaust inlet. Reinstall safety wire.

CAUTION

When installing cowling or turbine access door, check that the clearance between cowling or turbine access door and nose gear doors is within prescribed limits of .12 to .15 inches. Refer to SE77-15 for details.

12A-104. CONTROLLER AND WASTE-GATE ACTUATOR.

12A-105. FUNCTIONS. The waste-gate actuator and controller uses engine oil for power supply. The turbocharger is controlled by the waste-gate, waste-gate actuator, the absolute pressure and overboost control valve. The waste-gate bypasses engine exhaust gas around the turbocharger turbine inlet. The waste-gate actuator, which is physically connected to the waste-gate by mechanical linkage, controls the position of the waste-gate butterfly valve. The absolute pressure controller controls the maximum turbocharger compressor discharge pressure, the overboost control valve prevents an excessive pressure increase from the turbocharger compressor.

12A-106. OPERATION. The waste-gate actuator is spring-loaded to position the waste-gate to the normally open position when there is not adequate oil pressure in the waste-gate actuator power cylinder during engine shut down. When the engine is started, oil pressure is fed into the waste-gate actuator power cylinder through the capillary tube. This automatically fills the waste-gate actuator power cylinder and lines leading to the controllers, blocking the flow of oil by normally closed metering and/or poppet valves. As oil pressure builds up in the waste-gate actuator power cylinder, it overcomes the force of the waste-gate open spring, closing the waste-gate. When the waste-gate begins to close, the exhaust gases are routed through the turbocharger turbine. As the engine increases its power and speed, the increase of

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 12A-5. Turbocharger System Schematic

MODEL 210 & T210 SERIES SERVICE MANUAL

temperature and pressure of the exhaust gases causes the turbocharger to rotate faster, raising the turbocharger compressor outlet pressure. As the compressor outlet pressure rises, the aneroid bellows and the absolute pressure controller sense the increase in pressure. When at high engine speed and load and the proper absolute pressure is reached, the force on the aneroid bellows opens the normally closed metering valve. When the oil pressure in the waste-gate actuator power cylinder is lowered sufficiently, the waste-gate actuator open spring forces the mechanical linkage to open the waste-gate. A portion of the exhaust gases then bypasses the turbocharger turbine, thus preventing further increase of turbocharger speed and holding the compressor discharge absolute pressure to the desired value. Con-

versely, at engine idle, the turbocharger runs slowly with low compressor pressure output; therefore, the low pressure applied to aneroid bellows is not sufficient to affect the unseating of the normally closed metering valve. Consequently, engine oil pressure keeps the waste-gate closed. The overboost control valve acts as a pressure relief valve and will open to prevent an excessive pressure increase from the turbocharger compressor. Above 17,000 feet, the absolute pressure controller will continue to maintain $36.5 \pm .5$ inches of mercury manifold pressure at full throttle. It is necessary to reduce manifold pressure with the throttle to follow the maximum manifold pressure versus altitude schedule shown on the instrument panel placard.

CAUTION

This turbocharged engine installation is equipped with a controller system which automatically controls the engine within prescribed manifold pressure limits. Although these automatic controller systems are very reliable and eliminate the need for manual control through constant throttle manipulation, they are not infallible. For instance, such things as rapid throttle manipulation (especially with cold oil), momentary waste-gate sticking, air in the oil system of the controller, etc. can cause overboosting.

Consequently, it is still necessary that the pilot observe and be prepared to control the manifold pressure, particularly during take-off and power changes in flight.

The slight overboosting of manifold pressure beyond established maximums, which is occasionally experienced during initial take-off roll or during a change to full throttle operation in flight, is not considered detrimental to the engine as long as it is momentary. Momentary overboost is generally in the area of 2 to 3 inches and can usually be controlled by slower throttle movement. No corrective action is required where momentary overboosting corrects itself and is followed by normal engine operation. However, if overboosting of this nature persists, or if the amount of overboost goes as high as 6 inches, the controller and overboost control should be checked for necessary adjustment or replacement of the malfunctioning component.

OVERBOOST EXCEEDING 6 INCHES beyond established maximums, is excessive and can result in engine damage. It is recommended that overboosting of this nature be reported to your Cessna Dealer, who will be glad to determine what, if any, corrective action needs to be taken.

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-107. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
UNABLE TO GET RATED POWER BECAUSE MANIFOLD PRESSURE IS LOW.	Controller not getting enough oil pressure to close the waste-gate.	Check oil pump outlet pressure, oil filter and external lines for obstructions. Clean lines and replace if defective. Replace oil filter.
	Controller out of adjustment or defective.	Refer to paragraph 12A-110. Replace controller if defective.
	Defective actuator.	Refer to paragraph 12A-112. Replace actuator if defective.
	Leak in exhaust system.	Check for cracks and other obvious defects. Replace defective components. Tighten clamps and connections.
	Leak in intake system.	Check for cracks and loose connections. Replace defective components. Tighten all clamps and connections.
ENGINE SURGES OR SMOKES.	Defective controller.	Refer to paragraph 12A-110. Replace if not adjustable.
	Waste-gate actuator linkage binding.	Refer to paragraph 12A-112.
	Waste-gate actuator leaking oil.	Replace actuator.
TURBOCHARGER NOISY WITH PLENTY OF POWER.	Turbocharger overspeeding from defective or improperly adjusted controller.	Refer to paragraph 12A-110. Replace if defective.
	Waste-gate sticking closed.	Correct cause of sticking. Refer to paragraph 12A-110. Replace defective parts.
	Controller drain line (oil return to engine sump) obstructed.	Clean line. Replace if defective.
ENGINE POWER INCREASES SLOWLY OR SEVERE MANIFOLD PRESSURE FLUCTUATIONS WHEN THROTTLE ADVANCED RAPIDLY.	Overboost control valve out of adjustment or defective.	Replace if defective.
	Waste-gate operation is sluggish.	Refer to paragraph 12A-112. Replace if defective. Correct cause of sluggish operation.
ENGINE POWER INCREASES RAPIDLY AND MANIFOLD PRESSURE OVERBOOSTS WHEN THROTTLE ADVANCED RAPIDLY.	Overboost control valve out of adjustment or defective.	Replace if defective.
	Waste-gate operation is sluggish.	Refer to paragraph 12A-112. Replace if defective. Correct cause of sluggish operation.

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-107. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
FUEL PRESSURE DECREASES DURING CLIMB, WHILE MANIFOLD PRESSURE REMAINS CONSTANT.	Compressor discharge pressure line to fuel pump aneroid restricted.	Check and clean out restrictions.
	Leaking or otherwise defective engine-driven fuel pump aneroid.	Replace engine-driven fuel pump.
MANIFOLD PRESSURE DECREASES DURING CLIMB AT ALTITUDES BELOW NORMAL PART THROTTLE CRITICAL ALTITUDE, OR POOR TURBOCHARGER PERFORMANCE INDICATED BY CRUISE RPM FOR CLOSED WASTE-GATE. (Refer to paragraph 12A-107.)	Leak in intake system.	Check for cracks and other obvious defects. Tighten all hose clamps and fittings. Replace defective components.
	Leak in exhaust system.	Check for cracks and other obvious defects. Tighten all clamps and fittings. Replace defective components.
	Leak in compressor discharge pressure line to controller.	Check for cracks and other obvious defects. Tighten all clamps and fittings. Replace defective components.
	Controller seal leaking.	Replace controller.
	Waste-gate actuator leaking oil.	Replace actuator.
	Waste-gate butterfly - closed gap is excessive.	Refer to paragraph 12A-112.
	Intake air filter obstructed.	Service air filter. Refer to Section 2 for servicing instructions.
FUEL FLOW DOES NOT DECREASE AS MANIFOLD PRESSURE DECREASES AT PART-THROTTLE CRITICAL ALTITUDE.	Defective engine-driven fuel pump aneroid mechanism.	Replace engine-driven fuel pump.
	Obstruction or leak in compressor discharge pressure line to engine-driven fuel pump.	Check for leaks or obstruction. Clean out lines and tighten all connections.
FUEL FLOW INDICATOR DOES NOT REGISTER CHANGE IN POWER SETTINGS AT HIGH ALTITUDES.	Moisture freezing in indicator line.	Disconnect lines, thaw ice and clean out lines.
SUDDEN POWER DECREASE ACCOMPANIED BY LOUD NOISE OF RUSHING AIR.	Intake system air leak from hose becoming detached.	Check hose condition. Install hose and hose clamp securely.
MANIFOLD PRESSURE GAGE INDICATION WILL NOT REMAIN STEADY AT CONSTANT POWER SETTINGS.	Defective controller.	Replace controller.
	Waste-gate operation is sluggish.	Refer to paragraph 12A-112. Replace if defective. Correct cause of sluggish operation.

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 12A-6. Turbocharger System (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL



- | | | |
|-------------------------------------|---------------------------------|------------------------------|
| 1. Turbocharger Discharge Duct | 16. Waste-Gate | 31. Seal |
| 2. Coupler | 17. Tail Pipe | 32. Wire Guard |
| 3. O-Ring Seal | 18. Oil Outlet Adapter-Assembly | 33. Nose Cap Flexible Duct |
| 4. Overboost Control Valve | 19. Check Valve | 34. Turbocharger Inlet Elbow |
| 5. Throttle Body Adapter | 20. Turbine Housing | 35. Aft Duct |
| 6. Absolute Controller | 21. Compressor Housing | 36. Gasket |
| 7. Vacuum System Oil Separator | 22. Oil Inlet Adapter Assembly | 37. Support |
| 8. Turbocharger Support (FWD & AFT) | 23. Turbocharger Inlet Hose | 38. Bolt |
| 9. Washer | 24. Doubler | 39. Screw |
| 10. Cotter Pin | 25. Magnet | 40. Shield Assembly |
| 11. Check Valve | 26. Door | 41. Clamp |
| 12. Tube | 27. Induction Air Filter | 42. Sleeve |
| 13. Shaft Assembly | 28. Baffle Assembly | 43. Support |
| 14. Exhaust System | 29. Center Duct | 44. Fitting |
| 15. Waste-Gate Actuator | 30. Forward Duct | 45. Waste-Gate Drain Line |

Figure 12A-6. Turbocharger System (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

12A-108. CONTROLLER AND TURBOCHARGER OPERATIONAL FLIGHT CHECK. The following procedure details the method of checking the operation of the absolute controller overboost control valve, and a performance check of the turbocharger.

TAKE-OFF-ABSOLUTE CONTROLLER CHECK.

- a. Cowl Flaps - Open.
- b. Airspeed - 105 KIAS.
- c. Oil Temperature - Middle of green arc.
- d. Engine Speed - 2700 \pm 25 RPM.
- e. Fuel Flow - 192 LBS/HR \pm 6 LBS/HR (Full Rich Mixture).
- f. Full Throttle M. P. - Absolute controller should maintain 36.5 \pm .5 in. Hg (stabilized).

Climb 2000 feet after take-off to be sure manifold pressure has stabilized. It is normal on the first take-off of the day for full throttle manifold pressure to decrease 1/2 to 1.0 inch of mercury within one minute after the initial application of full power. Refer to paragraph 12A-109 for absolute controller adjustment.

CLIMB - ABSOLUTE CONTROLLER AND TURBOCHARGER PERFORMANCE CHECK.

- a. Cowl Flaps - Open.
- b. Airspeed - 105 KIAS.
- c. Engine Speed - 2500 RPM.
- d. Fuel Flow - Adjust mixture for 120.0 LBS/HR.
- e. Part-Throttle M. P. - 30.0 in. Hg.
- f. Climb to 17,000 feet - Check part-throttle critical altitude during climb.

This part-throttle critical altitude is where manifold pressure starts decreasing during the climb at a rate of approximately 1.0 inch of mercury per 1000 feet. After noting this altitude and the outside air temperature the desired manifold pressure should be maintained by advancing the throttle during the remainder of the climb.

Once the climb power setting is established after take-off, the controller should maintain a steady manifold pressure up to the part-throttle critical altitude indicated in the following chart. If part-throttle critical altitude has not been reached by 17,000 feet, discontinue check and proceed to cruise check.

Outside Air Temperature

Standard or Colder
20°F Above Standard
40°F Above Standard

Part-Throttle Critical Altitude (80% Power)

Above 21,000 feet
13,000 to 19,000 feet
7,000 to 13,000 feet

Part-throttle critical altitudes lower than those listed indicate the turbocharger system is not operating properly (refer to the trouble shooting chart in paragraph 12A-107). Critical altitudes above those listed indicate turbocharger performance better than normal. Also check that fuel flow decreases as manifold pressure decreases at critical altitude. Refer to the trouble shooting chart if fuel flow does not decrease.

CRUISE - TURBOCHARGER PERFORMANCE CHECK.

- a. Cowl Flaps - Closed.
- b. Airspeed - Level flight.
- c. Pressure Altitude - 17,000 feet.
- d. Engine Speed - 2700 RPM (5 minute limit).
- e. Part-Throttle M. P. - 30.0 in. Hg.
- f. Fuel Flow - Lean to 130.0 LBS/HR.
- g. Propeller Control -
 - (1) Slowly decrease RPM until manifold pressure starts to drop, indicating waste gate is closed.

NOTE

If the waste gate closes at engine speeds lower than shown on the chart in figure 12A-7, the turbocharger performance is normal. If the waste gate closes at engine speeds higher than shown in figure 12A-7, refer to the trouble shooting chart in paragraph 12A-107.

- (2) Note outside air temperature and RPM as manifold pressure starts to drop, which should be in accordance with the chart in figure 12A-7.
- (3) After noting temperature and RPM, increase engine speed 50 RPM to stabilize manifold pressure, with the waste gate modulating exhaust flow to control compressor output.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 12A-7. Operational Flight Check

12A-109. REMOVAL AND INSTALLATION OF TURBOCHARGER CONTROLLER.

- Disconnect and tag oil lines from controller and plug or cap open lines and fittings.
- Disconnect compressor outlet pressure sensing line from controller and plug or cap open line and fitting.
- Remove two bolts attaching controller to mounting bracket on firewall.
- Remove controller from aircraft, being careful not to drop controller unit.
- Installation of the controller may be accomplished by reversing the preceding steps. Resafety bolts attaching controller to bracket.

12A-110. ABSOLUTE CONTROLLER ADJUSTMENTS. (Refer to figure 12A-8.)

- With engine oil temperature at middle of green arc, slowly open throttle and note maximum manifold pressure obtainable. Do not exceed $36.5 \pm .5$ in. Hg.
- Cut safety wire and remove plug from bottom of absolute controller (the vertical unit).
- Using a flat-bladed screwdriver, rotate metering valve seat clockwise to increase manifold pressure and counterclockwise to decrease manifold pressure. Lightly tap the unit after each adjustment to seat internal parts.

NOTE

When adjusting, rotate in VERY small increments as this is an extremely sensitive adjustment. Approximately 13 degrees rotation will change the manifold pressure reading about one inch Hg.

- Install and safety plug in absolute unit, then operate engine as in step "a" to ascertain that adjustment has not caused radical change in manifold pressure.

NOTE

When making adjustment on the ground, the hotter the engine gets, the lower the manifold pressure will be.

- After each adjustment, the aircraft must be flight tested to check results.
- Repeat this procedure until desired results are obtained.

12A-111. REMOVAL AND INSTALLATION OF WASTE-GATE AND ACTUATOR.

- Disconnect and tag oil lines from actuator and plug or cap open lines and fittings.

MODEL 210 & T210 SERIES SERVICE MANUAL

- b. Remove bolts, washers and nuts attaching waste-gate and actuator assembly to tailpipe.
- c. Loosen clamp attaching tailpipe to turbine exhaust outlet and work tailpipe from turbine.
- d. Remove bolts, washers and nuts attaching the assembly to the exhaust manifold.
- e. Remove the assembly from aircraft, being careful not to drop the unit.
- f. Installation may be accomplished by reversing the preceding steps.

NOTE

When installing the assembly, be sure the gaskets at inlet and outlet of valve are installed and are in good condition. Replace gaskets if damaged.

12A-112. ADJUSTMENT OF WASTE-GATE ACTUATOR. (Refer to figure 12A-9.)

- a. Remove waste-gate actuator in accordance with paragraph 12A-111.
- b. Plug actuator outlet port and apply a 50 to 60 psig air pressure to the inlet port of the actuator.
- c. Check for 0.00 inch gap between butterfly and waste-gate body as shown in figure 12A-9.
- d. If adjustment is required, remove pin from actuator shaft.
- e. Hold clevis end and turn shaft clockwise to increase gap or counterclockwise to decrease gap of butterfly. Install pin through clevis and shaft, securing pin with washer and cotter pin.
- f. After adjusting closed position and with zero pressure in cylinder, check butterfly for a clearance of $1.100 + .000 - .125$ inch in the full-open position as shown in figure 12A-9.
- g. If adjustment is required, loosen locknut and turn stop screw clockwise to decrease or counterclockwise to increase clearance of butterfly.
- h. Recheck butterfly in the closed position to ascertain that gap tolerance has been maintained.

NOTE

To assure correct spring loads, actuate butterfly with air pressure. Actuator shaft and butterfly should move freely. Actuator shaft should start to move at 15 ± 2 psig and fully extend at 35 ± 2 psig. Two to four psi hysteresis is normal, due to friction of O-ring against cylinder wall.

- i. Remove air pressure line and plug from actuator.
- j. Install waste-gate and actuator as outlined in paragraph 12A-111.




Figure 12A-8. Controller Adjustment

12A-113. EXTREME WEATHER MAINTENANCE. Refer to paragraph 12-99.

12A-114. COLD WEATHER. Refer to paragraph 12-100.

12A-115. HOT WEATHER. Refer to Pilot's Operating Handbook.

12A-116. SEACOAST AND HUMID AREAS. Refer to paragraph 12-102.

12A-117. DUSTY AREAS. Refer to paragraph 12-103.

12A-118. GROUND SERVICE RECEPTACLE. Refer to Section 17.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 12A-9. Waste-Gate Adjustment

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 13

FUEL SYSTEM

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
FUEL SYSTEM	2F20/13-2	Fuel Strainer (THRU 21064535)	2G12/13-18
Description (THRU 21064535)	2F20/13-2	Description	2G12/13-18
Precautions	2F20/13-2	Disassembly and Assembly	2G14/13-20
Trouble Shooting	2F21/13-3	Removal and Installation	2G14/13-20
Fuel Bays	2G2/13-8	FUEL SYSTEM (BEGINNING WITH	
Description	2G2/13-8	21064536)	2G14/13-20
Leaks	2G2/13-8	Description	2G14/13-20
Classification of Fuel Leaks	2G2/13-8	Fuel Selector Valve	2G14/13-20
Purging	2G2/13-8	Description	2G14/13-20
Sealant	2G3/13-9	Removal and Installation	2G14/13-20
Mixing	2G3/13-9	Disassembly, Repair and	
Sealing	2G3/13-9	Reassembly	2G14/13-20
Sealing Fuel Leaks	2G3/13-9	Leak Test	2G19/13-25
Curing Time	2G6/13-12	Alternate Method	2G19/13-25
Testing Fuel Bay	2G6/13-12	Fuel Reservoir	2G19/13-25
Fuel Vents	2G6/13-12	Description	2G19/13-25
Description	2G6/13-12	Removal and Installation	2G19/13-25
Removal and Installation	2G7/13-13	Fuel ON-OFF Valve	2G21/13-27
Checking	2G7/13-13	Description	2G21/13-27
Fuel Quantity Indicating System	2G8/13-14	Removal and Installation	2G21/13-27
Description	2G8/13-14	Disassembly, Repair and	
Removal and Installation	2G8/13-14	Reassembly	2G21/13-27
Fuel Reservoirs (THRU 21064535)	2G8/13-14	Fuel Strainer	2G21/13-27
Description	2G8/13-14	Description	2G21/13-27
Removal and Installation	2G8/13-14	Disassembly, Assembly and	
Fuel Selector Valve (THRU 210-		Reassembly	2G21/13-27
64535)	2G8/13-14	Vented Fuel Filler Caps	2G24/13-30
Description	2G8/13-14	Description	2G24/13-30
Removal and Installation	2G8/13-14	Metal "Flush-Type"	
Repair	2G8/13-14	Filler Caps	2G24/13-30
Auxiliary Fuel Pump	2G10/13-16	Inspection	2G24/13-30
Description	2G10/13-16	Cleaning	2G24/13-30
Removal and Installation	2G10/13-16	Reassembly	2G24/13-30
Circuit	2G10/13-16	Red Plastic "Flush-Type"	
Rigging Throttle Operated		Filler Caps	2G24/13-30
Microswitches	2G10/13-16	Inspection	2G24/13-30
Flow Rate Adjustment	2G10/13-16	Cleaning	2H3/13-33
Maximum High Boost Check	2G12/13-18	Reassembly	2H3/13-33
		Leak Testing Metal or Red	
		Plastic Filler Caps	2H3/13-33

MODEL 210 & T210 SERIES SERVICE MANUAL

13-1. FUEL SYSTEM. The fuel system as defined by this manual includes all components up to and including the fuel line connecting to the engine driven pump inlet. Engine mounted components are covered in Section 12 or 12A.

13-2. DESCRIPTION. (THRU 21064535.) The fuel system is essentially a gravity-flow system from the bay outlets to the selector valve and a pump augmented system from the selector valve to the engine. The fuel system is comprised of the wing bays, reservoirs, selector valve, auxiliary fuel pump, fuel strainer, and associated plumbing. The fuel bay outlets are located at the inboard end of the bays with lines subsequently routed down the front and rear doorposts, under the floorboard, to the reservoirs. The fuel line from the lower forward corner of each bay to the reservoir serves as a combination fuel feed and vapor return line. Fuel bypasses the auxiliary pump when the pump is not in operation. The bays are individually vented overboard through vent lines with a check valve located at each wing tip. Beginning with T210, 21063661 and earlier aircraft modified by SK210-93 the following changes have been made. The fuel lines from the firewall to the strainer and the strainer to the tunnel fitting will be changed from aluminum to stainless steel with insulating sleeving. The fuel hose from the fuel pump to the check valve and from the check valve to the firewall and fuel pump to the tunnel fitting will be changed from nonsleeved hose to fire sleeved hose. The check valve is also fire sleeved.

13-3. PRECAUTIONS. During maintenance on the fuel system the following precautions should be observed:

- a. Aircraft should be properly GROUNDED prior to performing maintenance on the fuel system or components.
- b. Drain all lines or hoses when disconnected, because residual fuel draining constitutes a fire hazard, and accumulation of this drainage increases the hazard.
- c. Cap open lines and cover connections to prevent entry of foreign material in the former case, and to prevent damage to threads in the latter.

NOTE

Use NS-40(RAS-4) (Snap-On-Tools Corp., Kenosha, Wisconsin), MIL-T-5544 (Thread Compound, Antiseize, Graphite Petrolatum), USP Petrolatum or engine oil as a thread lubricant or to seal a leaking connection. Apply sparingly to male threads only, omitting first two to prevent entry into fuel system. Use only a fuel soluble lubricant on fitting threads, and use NO compound on the injection system.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

13-4. TROUBLE SHOOTING.

Use this trouble shooting chart in conjunction with the engine trouble shooting chart in Section 12 or 12A.

TROUBLE	PROBABLE CAUSE	REMEDY
NO FLOW TO ENGINE-DRIVEN FUEL PUMP.	Fuel selector or fuel ON-OFF valve not turned on.	Turn selector or fuel ON-OFF valve on.
	Fuel bays empty.	Service with proper grade and amount of fuel.
	Fuel line disconnected or broken.	Connect or repair fuel lines.
	Fuel bay outlet screens plugged.	Remove and clean screens and flush out fuel bays.
	Defective fuel selector valve.	Repair or replace selector valve.
	Plugged fuel strainer.	Remove and clean strainer and screen.
	Defective check valve in electric fuel pump.	Repair or replace pump.
	Fuel line plugged.	Clean or replace fuel line.
FUEL STARVATION AFTER STARTING.	Partial fuel flow from the preceding causes.	Use the preceding remedies.
	Malfunction of engine-driven fuel pump or fuel injection system.	Refer to Section 12 or 12A.
	Plugged fuel vent.	Refer to paragraph 13-19.
	Water in fuel.	Drain fuel bays, lines and strainer.
NO FUEL FLOW WHEN ELECTRIC PUMP OPERATED.	Defective fuel pump switch.	Replace defective switch.
	Loose connections or open circuit.	Tighten connections; repair or replace wiring.
	Defective electric fuel pump.	Replace defective pump.
	Defective engine-driven fuel pump bypass or defective fuel injection system.	Refer to Section 12 or 12A.
NO FUEL QUANTITY INDICATION.	Fuel bays empty.	Service with proper grade and amount of fuel.
	Open or defective circuit breaker.	Reset. Replace if defective.
	Loose connections or open circuit.	Tighten connections; repair or replace wiring.
	Defective fuel quantity indicator or transmitter.	Refer to Section 16.
FLUCTUATING FUEL PRESSURE INDICATIONS. (T210).	Obstructed filter in fuel inlet strainer of metering unit.	Remove and clean.
	Manifold valve.	Replace.
	Fuel flow indicator.	Replace.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 13-1 Fuel System Schematic.

MODEL 210 & T210 SERIES SERVICE MANUAL

All fuel hose should be replaced at engine overhaul or after 5 years, whichever comes first.




Figure 13-2. Fuel System (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 13-2. Fuel System (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

This detail is applicable beginning with T210, 21063661 and earlier aircraft modified by SK210-93




Figure 13-3. Fuel System

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 13-4. Classification of Fuel Leaks

13-5. FUEL BAYS.

13-6. DESCRIPTION. Aircraft with cantilever wings have an inboard section of each wing forward of the main spar sealed to form an integral fuel bay area. The bay consists of a front and rear fuel spar, inboard, outboard and intermediate ribs and stringers. Usable fuel in each bay is 43.5 gallons when completely filled. A standpipe at the bay filler acts as a visual aid, when loading fuel, to indicate quantity of fuel in the bay. For a reduced fuel load of 32 gallons of usable fuel in each bay, fill each bay to the bottom edge of the filler collar.

13-7. FUEL BAY LEAKS.

13-8. CLASSIFICATION OF FUEL LEAKS. Fuel leaks which do not constitute a flight hazard are stains, seeps and heavy seeps NOT in an enclosed area. However, they should be repaired when the aircraft is grounded for other maintenance. Fuel leaks which constitute a flight hazard are running leaks in any area, seeps, heavy seeps or stains in an enclosed area, such as the wing leading edge, the sections of wing inboard and outboard of the fuel bay and the area between the rear fuel spar and the main spar. These leaks must be repaired before that bay is used for another flight. The wet or stained spot on the wing in the area of the bay is an indication of

the intensity of the leak. Fuel leak classifications are shown in figure 13-4.

NOTE

Stains and seeps that are not considered a flight hazard must be inspected after each flight to ensure that they have not grown in intensity to the point of causing a flight hazard.

Should a flight-hazard leak occur in an area where there are no adequate repair facilities, then the affected bay should be drained, the leak temporarily repaired, and the aircraft flown immediately to an adequate repair facility by using the opposite fuel supply.

13-9. FUEL BAY PURGING.

WARNING

Prior to the repair of fuel bays, to reduce the possibility of an explosion, purge the bay with an inert gas, such as argon or carbon dioxide.

MODEL 210 & T210 SERIES SERVICE MANUAL

The following procedure may be used to purge the bay with argon or carbon dioxide.

- a. Ground the aircraft to a suitable ground stake.
- b. Set fuel selector valve handle in "OFF" position.
- c. Drain all fuel from bay being repaired. (Observe the precautions in paragraph 13-3.)
- d. Remove access doors and insert hose to each end of bay simultaneously.
- e. Allow inert gas to flow into bay for several minutes (time dependent upon hose size, rate of flow, etc.) to remove all fuel vapors.

Since argon or carbon dioxide are heavier than air, these gases will remain in the bay during the repair. The repair shall be made using non-sparking tools (air motors, plastic scrapers, etc.)

NOTE

Portable vapor detectors are available to determine presence of explosive mixtures and are calibrated for leaded fuel. These detectors can be used to determine when it is safe to make repairs.

13-10. **FUEL BAY SEALANT.** Two type sealants are used in integral fuel bay construction. A pliable type for access doors, and the rigid type for sealing ribs and spars to the skin. Service Kit SK210-56C, available through Cessna Supply Division, contains these sealants with the proper ratio of accelerators for each.

WARNING

Keep sealants away from heat and flame. Use only in a well ventilated area. Avoid skin and eye contact. **WEAR EYE SHIELDS.** In case of eye contact, flush generously with clean water, and secure prompt medical attention.

13-11. **MIXING SEALANT.** Mix sealant according to service kit instructions.

13-12. **SEALING.** (Refer to Section 18 for repair procedures).

CAUTION

Protect drains and fuel outlet screens when applying sealants to fuel bays.

Any repair that breaks the fuel bay seal will necessitate resealing of that area of the bay. Repair parts that need sealing must be installed and riveted during the sealing operation. All joints within the boundary of the bay, but which do not provide a direct fuel path out of the bay, such as stringers and rib flanges within the bay, must be fay surface sealed only. Joints which provide a direct fuel path out of the bay area, such as fuel spar flanges and inboard and outboard rib flanges, must be fay surface sealed and fillet sealed on the fuel side. Fay surface sealing is applying sealant to one mating part before assembly. Enough sealant must be applied so it will squeeze out

completely around the joint when the parts are riveted or fastened together. The fillet seal is applied after the joint is fay surface sealed and riveted or fastened together. Fillet sealing is applying sealant to the edge of all riveted joints, joggles, bend reliefs, voids, rivets or fasteners through the boundary of the bay and any place that could produce a fuel leak. The fay sealant need not be cured before the fillet seal is applied, but the squeezed out sealant, to which the fillet sealant is applied, must be free of dirt and contamination. Fillets laid on intersecting joints shall be joined together to produce a continuous fillet. Filler sealant must be pressed into the joint, working out all entrapped air. The best method of applying sealant is with an extrusion gun. Then work the sealant into the joint with a small paddle, being careful to eliminate all air bubbles.

NOTE

During structural repair, parts must be pre-drilled, countersunk or dimpled and cleaned before being sealed and positioned for final installation.

a. Remove all existing sealant from area to be sealed, leaving a taper on the remaining sealant. The taper will allow a scarf bond and a continuous seal when the new sealant is applied.

NOTE

The best method for removing sealant is with a chisel tool made of hard fiber. Remaining sealant is then removed with aluminum wool. Neither steelwool nor sandpaper can be used.

b. Vacuum thoroughly to remove all chips, filings, and other foreign material from bay areas.

c. All surfaces and areas to be sealed shall be thoroughly cleaned by wiping with a clean cloth dampened with Methyl Ethyl Ketone (MEK), acetone or similar solvent, and dried with a clean cloth prior to solvent evaporation. Always pour the solvent on the cloth. Never use contaminated solvent. The cloth shall not be so saturated that dripping occurs.

13-13. **SEALING FUEL LEAKS.** First determine the source of the fuel leak. Fuel can flow along a seam or structure of the wing for several inches, making the leak source difficult to find. A stained area is an indication of the leak source. Fuel leaks can be found by testing the complete bay as described in paragraph 13-15. Another method of detecting the source of a fuel leak is to remove access doors and blow with an air nozzle from the inside of the bay in the area of the leak while soap bubble solution is applied to the outside of the bay. After the leak source has been found, proceed as follows:

- a. Remove existing sealant in the area of the leak.
- b. Clean the area and apply a fillet seal. Press sealant into leaking area with a small paddle, working out all air bubbles.
- c. If leakage occurs around a rivet or bolt, restrike the rivet or loosen bolt, retorque, and reseal around nutplate.

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE



Refer to paragraph 13-12.

TYPICAL INSPECTION PLATE




1. Fuel Side
2. Nutplate
3. Fillet Seal
4. Faying
5. Rivet and Fastener Seal


TYPICAL FASTENER



TYPICAL RIB SECTION



TYPICAL FUEL BAY SPAR



TYPICAL END SECTION

Figure 13-5. Fuel Bay Sealing (typical) (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

d. Apply fay surface door sealant to access doors, fuel quantity transmitters, etc., if removed, and install.

e. Test fuel bay for leakage.

13-14. **CURING TIME.** Service Kit SK210-56 contains SP654706B2 Access Door Sealant Kit and SP654890B2 Fuel Bay Sealant Kit. Normal curing time for each seal is 24 hours. These values are based on a standard condition of 77°F (25°C) and 50% relative humidity. Curing time may be accelerated as shown in the following chart.

NOTE

Temperature shall not exceed 160°F (71°C).
Bay must be vented to relieve pressure during accelerated curing.

ACCELERATED CURING TIME

* F of Sealant	Time in Hours
160	3
140	4
130	5 1/2
120	7

Service Kit SK210-101 contains PR1321B 1/2 Access Cover Sealant Kit and PR1422B 1/2 Fuel Bay Sealant Kit. Normal curing time for PR1321B 1/2 seal based on a standard condition of 75°F (23.9°C) and 60% relative humidity is 18 hours. Normal curing time for PR1422B 1/2 seal based on a standard condition of 75°F (23.93C) and 50% relative humidity is 45

hours. Curing time may be accelerated by applying heat up to 120°F on the PR1321B 1/2, and by applying heat up to 130°F on the PR1422B 1/2. Refer to Accelerated Curing Time Chart above.

13-15. TESTING INTEGRAL FUEL BAY.

- Remove vent line from vent fitting and cap fitting.
- Disconnect fuel lines from bay.
- To one of the bay fittings, attach a water manometer capable of measuring twenty inches of water.
- To the other bay fitting, connect a well regulated supply of air (1/2 PSI MAXIMUM, or 13.8 INCHES of water). Nitrogen may be used where the bay might be exposed to temperature changes while testing.
- Make sure filler cap is installed and sealed.

CAUTION

Do not attempt to apply pressure to the bay without a good regulator and a positive shut-off in the supply line. Do not inflate the fuel bay to more than 1/2 psi or damage may occur.

- Apply pressure slowly until 1/2 PSI is obtained.
- Apply soap solution as required.
- Allow 15 to 30 minutes for pressure to stabilize.
- If bay holds for 15 minutes, without pressure loss, bay is acceptable.
- Reseal and retest if any leaks are found.

13-16. FUEL VENTS.

13-17. **DESCRIPTION.** The fuel bay vent line extends from the upper aft outboard corner of each fuel bay to the wing tip. This vent line contains a check valve to prevent fuel drainage through the vent line, but

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 13-6. Fuel Bay Vents

still allow the positive pressure from expanding fuel to escape from the bays. Check all fittings and clamps for tightness and vent line for clearance to prevent chafing against inner wing structure. The fuel vent line at the trailing edge of the wing tip should be checked daily for evidence of foreign matter.

13-18. REMOVAL AND INSTALLATION.

- Remove wing tip and access covers on underside of wing as necessary for access.
- Disconnect vent line at fuel bay and disconnect clamps attaching vent line to wing structure.
- Disconnect vent line from the check valve at wing tip.
- Remove vent line by carefully pulling it from the outboard end of the wing.
- Reverse the preceding steps for installation.

CAUTION

The vent line check valve must be installed as shown in figure 13-5.

13-19. CHECKING. Field experience has demonstrated that the vents can become plugged, causing possible fuel starvation of the engine. Also, the bleed hole in the vent valve assembly could possibly become plugged, allowing pressure from expanding fuel to pressurize the bay areas. The following pro-

cedure may be used to check the vent and bleed hole in the vent valve assembly.

- Cover .040 drilled holes approximately 6 inches from end of vent lines at trailing edges of wing tips.
- Attach a rubber tube to the end of the vent line at the trailing edge of one wing tip.
- Turn off fuel selector valve and check that both fuel filler caps are securely installed.
- Blow into tube to slightly pressurize the fuel bay. If air can be blown into bay, the vent line is open.
- After the fuel bay is slightly pressurized, insert end of rubber tube into a container of water and watch for a continuous stream of bubbles, which indicates the bleed hole in valve assembly is open and relieving pressure.
- Repeat this procedure for fuel vent at opposite wing tip.

NOTE

Remember that a plugged vent line or bleed hole can cause either fuel starvation or the pressurizing of the bay by fuel expansion. Therefore, any fuel vent found plugged or restricted must be corrected before returning aircraft to service.

CAUTION

Be sure to uncover drilled holes in vent lines at wing tips after completion of check.

MODEL 210 & T210 SERIES SERVICE MANUAL

13-20. FUEL QUANTITY INDICATING SYSTEM.

13-21. DESCRIPTION. The system is comprised of two sensing elements in each fuel bay (thru serial 21062273), control monitor, located inside the right cabin wing root area, two quantity indicators located in a cluster on the instrument panel, and associated wiring. Beginning serial 21062274, the dual sensing elements have been changed to variable resistive single element type, one in each bay, which eliminates the control monitor. Refer to Section 16 for operation, removal, installation, and calibration.

13-22. REMOVAL AND INSTALLATION OF SYSTEM COMPONENTS. Refer to Section 16 for procedures.

13-23. FUEL RESERVOIRS. (Thru 21064535.)

13-24. DESCRIPTION. There are two reservoirs installed in the lower fuselage, one on each side of the aircraft, immediately outboard of the selector valve. Each reservoir has four fuel line connections; two from the fuel bay, one to the selector valve and one from the selector valve, utilized for vapor return. A drain valve is installed in the bottom of each reservoir for draining trapped water and sediment from the fuel system.

13-25. REMOVAL AND INSTALLATION.

- Place selector valve in "OFF" position.
- Drain all fuel from wing bay, reservoir and lines for the reservoir being removed. (Observe precautions in paragraph 13-3.)
- Remove front seat, carpeting and plates as necessary to gain access to reservoir.
- Disconnect and cap or plug all fuel lines at reservoir.
- Remove screws securing tank mounting legs to fuselage structure.
- Lift reservoir out.
- Reverse the preceding steps for installation. Prior to reinstalling equipment removed for access, service fuel bays and check for leaks.

13-26. FUEL SELECTOR VALVE. (Thru 21064535.)

13-27. DESCRIPTION. A three position fuel selector valve is located in the lower fuselage between the pilot and copilot positions. The positions on the placard are labeled "OFF, LEFT ON and RIGHT ON." Valve repair consists of replacement of seals, springs balls and other detail parts. Figure 13-7 illustrates the proper relationship of parts and may be used as a guide during disassembly and assembly.

13-28. REMOVAL AND INSTALLATION.

- Drain all fuel from wing bays, reservoir tanks, strainer and lines. (Observe precautions in paragraph 13-3.)
- Remove selector valve handle.
- Remove pedestal cover.
- Remove access plates in floorboard and fuselage skin in area of selector valve.
- Disconnect and cap or plug all fuel lines at valve.
- Disconnect square shaft from valve by removing attached roll pin.
- Remove bolts or screws attaching valve to support bracket and remove valve.

h. Reverse preceding steps for installation. Prior to reinstalling equipment removed for access, service fuel bays and check for leaks.

13-29. REPAIR. (See figure 13-6.) The fuel selector valve may be repaired by disassembly, replacement of defective parts and reassembly as follows:

- Mark sump plate (23) and body (1) to ensure correct reassembly, then remove sump plate (23) and O-ring (22) after removing four screws.
- Drive out roll pin (5) securing yoke (6) to rotor shaft (21). As yoke is lifted off, balls (8) and springs (7) are free. Retain them.
- Lift off brass washer (9).
- Mark cover (4) and body to assure later alignment of parts and remove screws (3).
- With fine emery paper, sand off any burrs or sharp edges on rotor shaft (21). Apply petrolatum to rotor shaft as a lubricant, then work cover off shaft.
- Drive back roll pin (13) and remove rotor (12). Teflon seal (14), O-rings (15), washers (16) and springs (17) are now free to be removed. Check all parts carefully for defects.
- Remove burrs or sharp edges on rotor shaft (21), lubricate and slide it down, out of body (1). Remove teflon seals (20) and O-rings (19).
- Remove O-ring (18) within body and O-ring (10) within cover.
- Replace all O-rings, lap or replace teflon seals and lubricate O-rings before installation.

CAUTION

Install all parts in the relative position illustrated in figure 13-6, otherwise the valve will not operate correctly.

- Install O-ring (18) in body rotor shaft hole. Install O-rings (19) and teflon seals (20), then slide rotor shaft into place. Position rotor in exact relative position shown in figure 13-6, then install O-ring (22) and sump plate (23).
- Install .169" diameter pins in body ports, then slide springs (17), washers (16), O-rings (15) and teflon seals over pins. Slide rotor (21) over shaft. Remove .169" diameter pins and, readjusting rotor (12) vs. rotor shaft (21) position as necessary, tap roll pin (13) into place, letting it protrude on the side illustrated.

NOTE


This roll pin (13) serves also as a stop, limiting valve rotor shaft travel.

- Install O-ring (10) in cover (4), lubricate rotor shaft (21) with petrolatum, install large O-ring (11) in cover (4) and slide down into place.

CAUTION

Make sure cover (4) is installed in relative position illustrated. A lug on the cover serves as a stop detent and if the cover is not installed correctly, the valve will not operate properly.

MODEL 210 & T210 SERIES SERVICE MANUAL



Detail **A**

● Safety wire after installation. Serial 21061574 thru 21064535

THRU 21064535

- 1. Valve Body
- 2. Lockwasher
- 3. Screw
- 4. Cover
- 5. Roll Pin
- 6. Yoke
- 7. Spring
- 8. Ball
- 9. Brass Washer
- 10. O-Ring
- 11. O-Ring

- 12. Rotor
- 13. Roll Pin
- 14. Seal
- 15. O-Ring
- 16. Washer
- 17. Spring
- 18. O-Ring
- 19. O-Ring
- 20. Seal
- 21. Rotor
- 22. O-Ring
- 23. Sump Plate

- 24. Screw
- 25. Washer
- 26. Spring
- 27. Cap
- 28. Screw
- 29. Washer
- 30. Handle
- 31. Placard
- 32. Selector Shaft
- 33. Grommet
- 34. Selector Valve

Figure 13-7. Fuel Selector Valve Assembly

MODEL 210 & T210 SERIES SERVICE MANUAL

m. Install brass washer (9) and yoke (6). Note the position of the small hole in the squared, upper portion of the yoke. If this is reversed, the valve linkage will not attach properly.

13-30. AUXILIARY FUEL PUMP.

13-31. DESCRIPTION. An electric auxiliary fuel pump is located immediately forward of the left fuel reservoir. An integral bypass and check valve incorporated in the pump assembly permits fuel flow through the pump even when inoperative but prevents reverse flow. A separate overboard drain line from the pump prevents entry of fuel into the electric motor, in the event of pump internal leakage. The auxiliary pump is used in engine starting and in the event of engine-driven pump malfunction.

13-32. REMOVAL AND INSTALLATION.

- Place fuel selector valve in "OFF" position.
- Drain fuel from pump, lines and strainer with quick-drain control.
- Ensure master switch and pump switch are in "OFF" position.
- Remove pilot's seat, carpeting and plates at left side of pedestal as necessary for access to pump.
- Disconnect and cap or plug all fuel lines and electrical connections at pump. (Observe precautions in paragraph 13-3.)
- Loosen the two securing clamps and lift pump out.
- Reverse the preceding steps for installation. Prior to reinstalling equipment removed for access, place selector valve to "ON" position and check for leaks and proper pump operation.

13-33. AUXILIARY FUEL PUMP CIRCUIT. The auxiliary fuel pump switch is a yellow and red split-rocker type switch. The yellow right half of the switch is labeled "START," and its upper "ON" position, is used for normal starting and minor vapor purging during taxi. The red left half of the switch is labeled "EMERG," and its upper "HI" position is used in the event of an engine-driven fuel pump failure during take-off or high power operation. The "HI" position may also be used for extreme vapor purging. With the right half of the switch in the "ON" position, the pump operates at one of two flow rates that are dependent upon the setting of the throttle. With the throttle open to a cruise setting, the pump operates at a high capacity to supply sufficient fuel flow to maintain flight. When the throttle is moved toward the closed position (as during letdown, landing and taxiing), the fuel pump flow rate is automatically reduced, preventing an excessively rich mixture during these periods of reduced engine speed. Maximum fuel flow is produced when the left half of the switch is held in the spring-loaded "HI" position. In the "HI" position, an interlock within the switch automatically trips the right half of the switch to the "ON" position. When the spring-loaded left half of the switch is released, the right half will remain in the "ON" position until manually returned to the OFF position. When the

engine-driven fuel pump is functioning and the auxiliary fuel pump is placed in the "ON" position, a fuel/air ratio considerably richer than best power is produced unless the mixture is leaned. If the auxiliary fuel pump switch is accidentally placed in the "ON" position with the master switch "ON" and the engine stopped, the intake manifolds will be flooded. A throttle shaft-operated microswitch adds a resistance to the high circuit to slow down the pump when the throttle is retarded to prevent an excessively rich mixture. Refer to paragraph 13-34 for rigging instructions.

13-34. RIGGING THROTTLE-OPERATED MICRO-SWITCHES. (Refer to figure 13-7.) These aircraft are equipped with a throttle-operated microswitch which slows down the electric fuel pump whenever the throttle is retarded while the electric pump is being used. The electric fuel pump microswitch should slow down the pump as the throttle is retarded to approximately 19 inches of mercury manifold pressure (sea level aircraft) and 23 inches of mercury manifold pressure (turbocharged aircraft).

NOTE

These settings must be established during ground run-up only. These values will not apply in flight.

- Start engine and set throttle to obtain 19 inches of mercury manifold pressure (sea level aircraft) or 23 inches of mercury manifold pressure (turbocharged aircraft).
- Mark position of throttle control at instrument panel and shut down engine.
- Remove cover (1) and adjust cam (3) to activate fuel pump switch (6) at throttle position marked in step "b".
- With mixture control in "IDLE CUT-OFF," electrical fuel pump switch in "ON," and master switch in "ON" position, listen for change in sound of electric fuel pump as the throttle is retarded to the marked position.

13-35. AUXILIARY ELECTRIC FUEL PUMP FLOW RATE ADJUSTMENT. (Refer to figure 13-8.)

WARNING

During this test, raw fuel will drain from the engine compartment, therefore, proper safety precautions should be taken. Conduct test in well ventilated area, use drip pans, insure aircraft is properly grounded, and keep ignition source, (cigarettes, lighters, matches, etc.) away from area.

NOTE

These tests are to be conducted with the engine stopped and external power supplied to the aircraft bus.

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 13-8. Throttle-Operated Microswitches

MODEL 210 & T210 SERIES SERVICE MANUAL



- | | | |
|-----------------------------|---------------------|------------------------|
| 1. High-Boost Resistor (#1) | 3. Spacer (Typical) | 6. Battery Box Support |
| 2. Low-Boost Resistor (#2) | 4. Adjustable Slide | 7. Firewall |
| | 5. Bracket Assembly | |

Figure 13-9. Auxiliary Fuel Pump Resistors

- a. Apply an external source of 27.75VDC \pm .25V to the aircraft bus.
- b. Set mixture control at "FULL RICH."
- c. Turn master switch "ON," and fuel pump rocker switch "ON."
- d. Advance throttle to full open position.
- e. Check metered fuel pressure/flow on ship's gage for a flow of 88-98 pounds/hour (14.7 - 16.0 gallons/hour).
- f. Adjust number one resistor (1) if required.
- g. Retard throttle slowly from the full "OPEN" position until the speed of the fuel pump can be audibly detected to change due to microswitch activation.
- h. Wait momentarily for the fuel flow gage to respond.
- i. The metered fuel pressure/flow on the ship's gage should read on the low end red line or approximately one red line width above.
- j. Adjust number two resistor (5) if required.

13-36. MAXIMUM HIGH BOOST CHECK. To verify high position function, momentarily depress

spring-loaded rocker and verify a noticeable increase in indicated fuel flow on the fuel flow gage.

13-37. FUEL STRAINER. (Thru 21064535.)


13-38. DESCRIPTION. The fuel strainer is located in the nose wheel well and is readily accessible with the nose gear doors open. The strainer is equipped with a quick-drain valve which provides a means of draining trapped water and sediment from the fuel system. The quick-drain control is located adjacent to the oil dipstick.

NOTE

The fuel strainer can be disassembled, cleaned and reassembled without removing the assembly from the aircraft.

Beginning with T210, 21063661 thru 21064535 and those aircraft modified by SK210-93 the fuel strainer is in-

MODEL 210 & T210 SERIES SERVICE MANUAL



- | | |
|------------------|----------------|
| 1. Spring | 9. Filter |
| 2. Washer | 10. Collar |
| 3. Plunger | 11. Standpipe |
| 4. Top | 12. O-Ring |
| 5. Drain Control | 13. Bowl |
| 6. Plate | 14. O-Ring |
| 7. O-Ring | 15. Nut |
| 8. Gasket | 16. Drain Line |

Figure 13-10. Fuel Strainer

MODEL 210 & T210 SERIES SERVICE MANUAL

sulated. The insulation material consists of a split top and a bowl covering. This insulation material must be removed prior to disassembly and reinstalled upon reassembly of the fuel strainer.

13-39. DISASSEMBLY AND ASSEMBLY. (Refer to figure 13-9.)

- a. Place fuel selector valve in "OFF" position.
- b. Open landing gear doors.
- c. Drain fuel from strainer with quick-drain control. (Observe precautions in paragraph 13-3.)
- d. Disconnect strainer drain tube and remove safety wire, nut and washer at bottom of filter bowl and remove bowl.
- e. Carefully unscrew standpipe and remove.
- f. Remove filter screen and gasket. Wash filter screen and bowl in solvent (Federal Specification P-S-661 or equivalent) and dry with compressed air.
- g. Using a new gasket between filter screen and top assembly, install screen and standpipe. Tighten standpipe only finger tight.
- h. Using all new O-rings, install bowl. Note that step-washer at bottom of bowl is installed so that step seats against O-ring. Connect strainer drain tube.
- i. Place selector valve in "ON" position, close strainer drain and check for leaks and proper operation.
- j. Safety wire bottom nut to top assembly. Wire must have right hand wrap, at least 45 degrees.

13-40. REMOVAL AND INSTALLATION.

- a. Place selector valve in "OFF" position.
 - b. Open landing gear doors.
 - c. Drain fuel from strainer and lines with quick-drain control.
 - d. Disconnect and cap or plug all fuel lines at strainer. (Observe precautions in paragraph 13-3.)
 - e. Loosen clamp and clamp bolt attaching quick-drain control.
 - f. Disconnect primer line. (If installed.)
 - g. Remove attaching bolts and remove strainer.
 - h. Reverse preceding steps for installation.
- Place selector valve to "ON" position and check for leaks and proper operation of quick-drain valve.

13-41. FUEL SYSTEM.

BEGINNING WITH 21064536

13-42. DESCRIPTION. The fuel system is essentially a gravity-flow system from the bay outlets to the selector valve and a pump augmented system from the selector valve to the engine. The fuel system is comprised of wing bays, a selector valve, fuel strainer, and associated plumbing. Fuel bay outlets are located at the inboard end of the bays. A single fuel supply line is routed down the rear doorposts to the fuel selector valve. A fuel supply line, interconnected with a vent line, and a separate drain line are routed down the front doorposts. A combination drain, and vent line is routed down the left, forward, doorpost, from the vent crossover line to the reservoir. The fuel bays are vented by a crossover vent line, wing tip vents, and vented fuel caps.

The upper segment of the three position (LEFT ON, BOTH ON, RIGHT ON) fuel selector valve handles fuel from the bays. The lower segment handles vapor, along with returned and excess fuel from the engine-driven fuel pump.

The reservoir accepts fuel from the selector valve, bay drain and vent lines. The fuel flows from the reservoir through a by-pass in the auxiliary fuel pump (when the pump is not in operation) to the fuel ON-OFF valve.

The fuel ON-OFF valve provides a means of stopping fuel flow to the STRAINER and the engine driven fuel pump. The fuel ON-OFF control is mounted on the left side of the pedestal.

The fuel STRAINER, mounted on the firewall incorporates a remote drain valve. This valve, is mounted on the lower, left, engine cowling. The drain valve is activated by the fuel sampler cup.

13-43. FUEL SELECTOR VALVE. (See figure 13-13.)

13-44. DESCRIPTION. A three position, six port fuel selector valve is located beneath the floorboard. A shaft links the fuel selector valve to a handle mounted on the pedestal structure. The positions of the handle are labeled "BOTH ON, LEFT ON, RIGHT ON". Valve repair is limited to replacement of component parts only. Figure illustrates the proper relationship of parts and may be used as a guide during disassembly and assembly.

13-45. REMOVAL AND INSTALLATION.

- a. Drain all fuel from wing bays, reservoir, strainer and lines. (Observe precautions in paragraph 13-3.)
- b. Remove selector valve handle.
- c. Remove pedestal cover.
- d. Remove center access plate.
- e. Tag, and then disconnect or plug all six lines at valve.
- f. Remove screws attaching elevator cable bracket to valve.
- g. Remove nuts, washers, and bolts attaching valve to its bracket.
- h. Remove valve.
- i. Reverse preceding steps for installation. Prior to reinstalling equipment removed for access, secure fuel bays and check all lines and fittings for leaks in all selector valve positions.

13-46. DISASSEMBLY, REPAIR AND REASSEMBLY.

- a. Remove pin (31) and shaft (30).
- b. Remove spring retainer (24) spring (23) packing (22) and seal (21) from each part of the lower body (20).
- c. Remove screw (2) holding upper body (4) and lower body (20) together.
- d. Remove lower body (20) with a twisting motion. Remove and tag washer(s) (16).
- e. Cover upper body (4) and detent insert (17) with a clean shop cloth.

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 13-11. Fuel System Schematic

MODEL 210 & T210 SERIES SERVICE MANUAL




- | | |
|-------------------------|---------------------------|
| 1. Right-Hand Fuel Line | 9. ON-OFF Valve |
| 2. Crossvent Line | 10. Strainer Drain Valve |
| 3. Left-Hand Fuel Line | 11. Fuel Strainer |
| 4. Vent Line | 12. Fuel Selector Valve |
| 5. Fuel Line | 13. Vent Line Drain Valve |
| 6. Drain Line | 14. Drain Line |
| 7. Reservoir | 15. Fuel Line |
| 8. Auxiliary Fuel Pump | 16. Vent Line |

Figure 13-12. Fuel System.

MODEL 210 & T210 SERIES SERVICE MANUAL



1. Elevator Cable Bracket
2. Screws
3. Stop Pin
4. Upper Body
5. Packing
6. Packing
7. Washer, 1358-11
8. Washer, 1358-12
9. Spring
10. Washer
11. Packing
12. Seal
13. Rotor
14. Spring
15. Ball
16. Washer, 1358-10 or -11
17. Detent Insert
18. Packing
19. Packing
20. Lower Body
21. Seal
22. Packing
23. Spring
24. Spring Retainer
25. Plug
26. Screw
27. Washer
28. Handle
29. Screw
30. Shaft
31. Pin
32. Spring Compressor



BEGINNING WITH 21064536

Figure 13-13. Fuel Selector Valve. (Sheet 1 of 2).

MODEL 210 & T210 SERIES SERVICE MANUAL



Fabricate spring compressor (32) from 1/16 inch diameter #1 OXWELD AC welding rod or equivalent according to dimensions shown.




Figure 13-13. Fuel Selector Valve. (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

The shop cloth will contain ball (15) and spring (14) when detent insert (17) is removed.

- f. Carefully pry detent insert (17) from upper body (4).
- g. Remove ball (15) and spring (14) from shop cloth.
- h. Remove stop pin (3) from rotor (13).
- i. Cover upper body (4) completely with a clean shop cloth.

NOTE

The shop cloth will contain seals (12), packings (11), washers (10) and springs (9) when the rotor is removed.

- j. Push the rotor (13) out of the upper body (4).
 - k. Remove the rotor (13), seals (12), packings (11), washers (10), and springs (9) from the shop cloth.
 - l. Check detent holes in detent insert (17) for excessive wear.
 - m. Replace all seals and packings.
 - n. Insert rotor (13), in upper body (4), place detent insert (17), over rotor (13), place washer (16) in lower body (20), place lower body (20), over rotor (13) insert three screws (2) and torque to 30 lbs-in. Check end play between rotor and valve bodies.
- If end play is:
- (1) .008 or greater, add S-1358-11 and/or S-1358-12 washers to decrease end play to .001 to .007.
 - (2) .007 to .004 add (1) S-1358-12 washer.
 - (3) .003 or less, disassemble valve and reassemble with different parts, recheck end play.
- o. When end play is within tolerance disassemble, retain washers.

NOTE

Reassembly of the selector valve is facilitated by mounting upper body (4) in a bench vise or equivalent bench support making certain upper body (4) is protected from damage. Fabrication of spring compressors (32) three required is necessary.

- p. Place upper body (4) upside down in bench vise or support.
- q. Replace packing (6). Lubricate spring (14) with petrolatum and insert in rotor (13).
- r. Insert spring (9) and compress with spring compressor (32) then insert washer (10), packing (11) and seal (12). The concave portion of the seal must fit the convex surface of the rotor (13). Complete this for each port.
- s. While holding the three springs (9) with the spring compressors (32), place washers (7) and/or (8) on the shaft end of rotor (13) and insert rotor (13) into the upper body (4). The seals (12) must fit flush against the rotor (13). Release the spring compressors (32).

- t. Remove the upper body (4) from bench vise or support.
- u. Insert stop pin (3) into rotor shaft.
- v. Place detent insert (17) on rotor (13) with slots for ball (15) toward upper body (4).
- w. Place ball (15) on spring (14) align one of the slots, with the ball (15) and depress the ball (15). While pushing the detent insert (17) toward the upper body (4) as the ball (15) enters the slot the detent insert (17) may be pushed on to rotor (13) until it is flush with the upper body (4). Rotate the detent insert (17) until all four of its bolt holes align with four of the holes on the upper body (4).
- x. Roll packing (18) over end of rotor (13) and push into cutout between rotor (13) and detent insert (17). Packing (18) must not protrude beyond lip of detent insert (17). Care must be exercised to avoid damage to packing.
- y. Place packing (19) in groove on outer edge of detent insert (17).
- z. Place lower body (20) over rotor (13). The five bolt holes in the lower body (20) must align with the five bolt holes in the upper body (4).

13-47. LEAK TEST

- a. With valve assembled remove stop pin (3).
- b. Set valve in a closed position.
- c. Apply 6-10 psi Stoddard solvent to each port separately.
- d. Maximum internal leakage 10 drops per minute. No external leakage allowed.

13-48. ALTERNATE METHOD.

- a. With valve assembled remove stop pin (3).
 - b. Set valve in a closed position.
 - c. Apply 6-10 psi air to each port while valve is submerged in water.
 - d. Maximum internal leakage equivalent to 10 drops per minute Stoddard solvent. No external leakage allowed.
- Add two drops of Loctite 242 to end of each spring retainer (24) after pressure test.


13-49. FUEL RESERVOIR. (See figure 13-14.)

13-50. DESCRIPTION. There is one reservoir installed in the lower fuselage, on the pilot's side outboard of the fuel selector valve. The reservoir has four fuel line connections; one from the fuel selector valve, one from the lower right hand crossover drain line, one from the left hand crossover drain line and one to the engine by way of the auxiliary fuel pump, ON-OFF valve and fuel strainer. A drain valve is installed in the bottom of the reservoir for draining.

13-51. REMOVAL AND INSTALLATION.

- a. Drain all fuel from wing bays, reservoir, strainer and lines. Observe precautions in paragraph 13-3).
- b. Remove carpeting and access plate.
- c. Disconnect and cap or plug all fuel lines at the reservoir.
- d. Remove screws securing mounting legs to fuselage.

MODEL 210 & T210 SERIES SERVICE MANUAL



BEGINNING WITH 21064536

1. Lower Right-Hand Crossover Drain Line
2. From Fuel Selector Valve
3. Drain Line Left-Hand Crossvent Line
4. Drain Valve
5. To Engine

Torque Drain Valve (4) 15-35 lbs-in.

Figure 13-14. Fuel Reservoir

MODEL 210 & T210 SERIES SERVICE MANUAL

- e. Lift reservoir out.
 - f. Reverse the preceding steps for installation.
- Prior to replacing the access plate, secure fuel bays and check all connections for leaks.

NOTE

The clearance between the elevator cables and the drain line is .37 inch minimum and .50 maximum.

Lower Right Hand Crossover Drain Line
From Fuel Selector Valve
Left Hand Crossvent Drain Line
To Engine

13-52. FUEL ON-OFF VALVE. (See figure 13-15).

13-53. DESCRIPTION. The fuel ON-OFF valve is a two position valve located just forward of the auxiliary fuel pump under the pilot's floorboard. The valve control knob is located on the left lower area of the pedestal. Valve repair consists of replacement of component parts.

13-54. REMOVAL AND INSTALLATION.

- a. Drain all fuel from wing bays, reservoir, strainer and lines. (Observe precautions in paragraph 13-3).
 - b. Remove carpeting and access plate.
 - c. Remove control cable from clamp on valve and control wire from valve arm.
 - d. Disconnect and cap or plug both the inlet and outlet fuel lines.
 - e. Remove bolts from bracket and remove valve.
 - f. Reverse the preceding steps for installation.
- Prior to replacing the access plate, service the fuel bays and check all connections for leaks. The valve must also be checked for positive on and off position.

NOTE

When installing the valve make certain the arrow on the valve points with the direction of normal fuel flow. (Toward the engine).

13-55. DISASSEMBLY, REPAIR AND REASSEMBLY.

- a. Remove screws (13) securing cover (14) to valve body (19); carefully remove cover.
- b. Remove ball (15) and spring (16) from rotor (17).
- c. Slowly withdraw rotor (17) from valve body (19).

NOTE

Removal of rotor (17) from valve body (19) will allow seal (23), packing (22) washer (21), and spring (20) to pop free.

- d. Remove seal (23), packing (22), washer (21), and spring (20) from valve body (19).
- e. Remove packing (18) from valve body (19).

NOTE

Reassembly of valve is facilitated by mounting in a bench vise or equivalent bench support, making sure valve body (19) is protected from damage. Fabrication of a spring compressor is recommended before reassembly. Replace packings (21) and (18) whenever rotor (17) is removed from valve body.

- f. Ensure all component parts are clean, then coat sparingly with lightweight oil.
- g. Install new packing (18) into recess at top of valve body (19).
- h. Insert spring (20) into valve body (19).
- i. With spring compressor, compress spring (20).
- j. Install washer (21), new packing (22), and seal (23) into port.
- k. Holding spring (20) compressed, carefully insert rotor (17) into valve body (19), release spring compressor, and visually inspect assembly for proper seating of seal (23) to rotor.
- l. Lubricate spring (16) and ball (15) with Petro-latum.
- m. Insert spring (16) into rotor (17).
- n. Place ball (15) on top of spring (16).
- o. Position cover (14) on valve body and turn rotor (17) as required to index one of detents in cover.
- p. Secure cover (14) to valve body (19) with screws (13).
- q. Test rotation of rotor (17) for ease of operation and positive detent engagement.

13-56. FUEL STRAINER. (See figure 13-16.)

13-57. DESCRIPTION. The fuel strainer is located on the left forward side of the firewall. It is accessible through the left cowl flap opening or from above by removing the upper engine cowling. The fuel strainer incorporates a quick drain valve. The valve protrudes from the lower left side of the engine cowling.


NOTE

The fuel strainer can be disassembled, cleaned and reassembled without removing the assembly from the aircraft.

13-58. DISASSEMBLY, ASSEMBLY AND REASSEMBLY.

- a. Place ON-OFF fuel control in OFF position
- d. Drain fuel from strainer and lines with drain valve (16).
- c. Disconnect strainer drain line (10) from strainer bowl (6) and drain valve (16).
- d. Remove nut (9), step washer (8) and O-ring (7) at bottom of bowl (6) and remove bowl (6) remove O-ring (5).
- e. Carefully unscrew Standpipe (4) and remove.


MODEL 210 & T210 SERIES SERVICE MANUAL



- | | |
|------------------------|--------------------------|
| 1. Packing | 18. Packing |
| 2. Fitting | 19. Valve Body |
| 3. Line Assembly | 20. Spring |
| 4. Fuel Pump Bracket | 21. Washer |
| 5. Screw | 22. Packing |
| 6. Nut | 23. Seal |
| 7. Fuel Pump Vent Line | 24. Stop Pin |
| 8. Packing | 25. Hose Assembly |
| 9. Line Assembly | 26. Nut |
| 10. ON-OFF Control Arm | 27. Washer |
| 11. Washer | 28. Bolt |
| 12. Nut | 29. ON-OFF Valve Bracket |
| 13. Screw | 30. ON-OFF Control Cable |
| 14. Cover | 31. Cable Clamp |
| 15. Bell | 32. Fitting |
| 16. Spring | 33. Auxiliary Fuel Pump |
| 17. Rotor | |

Figure 13-15. Auxiliary Fuel Pump and ON-OFF Valve.

MODEL 210 & T210 SERIES SERVICE MANUAL



BEGINNING WITH 21064536

1. Top
2. Gasket
3. Filter Screen
4. Standpipe
5. O-Ring
6. Bowl
7. O-Ring
8. Step Washer
9. Nut
10. Drain Line
11. Nut
12. Washer
13. Bracket
14. Fitting
15. O-Ring
16. Drain Valve
17. Washer
18. Screw

Figure 13-16. Fuel Strainer.

MODEL 210 & T210 SERIES SERVICE MANUAL

f. Remove filter screen (3) and gasket (2). Wash filter screen and bowl in solvent (p-S-661) and dry with compressed air.

g. Using a new gasket (2) install filter screen (3) and standpipe (4). Tighten standpipe finger tight.

h. Using new O-rings (5) and (7) install bowl (6). The step washer (8) must be installed so that the step seats against the O-ring (7), connect drain line (10).

i. Place ON-OFF fuel control in ON position.

j. Check for fuel leaks.

k. Check drain valve (16) for operation.

13-59. VENTED FUEL FILLER CAPS.

13-60. DESCRIPTION. The filler cap assemblies may be constructed of either metal or red plastic. Both cap assemblies incorporate a vent safety valve that provides vacuum and positive pressure relief for their respective fuel tanks. It is important that both type caps to be cleaned on as required basis, if proper filler cap sealing is to be maintained.

13-61. METAL "FLUSH-TYPE" FILLER CAPS. Except for minor differences in construction and weight, metal fuel filler caps perform the same function as red plastic fuel filler caps. The caps are interchangeable and will fit the same adapter assembly.

13-62. INSPECTION.

NOTE

If fuel collects in the handle well it could indicate stem O-ring leakage. Fuel collecting around perimeter of cap could indicate cap O-ring or check valve leakage.

a. Remove fuel cap from adapter (7), remove safety chain (9) from cap and cover or plug fuel opening to keep out foreign matter.

b. Remove nut (10) and, observing position of lock plate (6) in relation to stem (14) disassemble cap.

c. Note resiliency of O-rings (3 & 13) and condition of grooves. If the O-rings (3 & 13) have deteriorated they must be replaced.

13-63. CLEANING.

a. Using a cotton swab and Stoddard solvent or equivalent, gently lift edges of rubber umbrella (5) and clean stainless steel seat and umbrella removing all contaminants. Using a second swab wipe seat and umbrella thoroughly, removing all cotton fibers. Repeat until swabs show no discoloration.

b. If O-ring grooves appear contaminated, clean with Stoddard solvent or equivalent and cotton swabs.

c. Ascertain that all vent holes in check valve are unobstructed.

d. Clean cap body and lock plate, check for defects.

e. If the umbrella continues to leak or is deteriorated it must be replaced.

f. To remove umbrella, lubricate the umbrella stem with (MIL-H-5606) hydraulic fluid to prevent tearing the stem.

g. To replace the umbrella, lubricate the umbrella stem with (MIL-H-5606) hydraulic fluid and use a small blunt tool to insert the retaining knob on the umbrella stem into the check valve body to prevent damaging the stem.

13-64. REASSEMBLY.

a. Place split washer (16) in cap well correctly.

b. With handle (1) and O-ring installed on stem (14), insert stem (14) through split washer (16) on cap body (2).

c. Place spring (15) on stem (14).

d. Position cap handle (1) to full "OPEN" position.

e. Place lock plate (6) on threaded end of stem (14) and align all three lugs (12) with three guide bosses on the cap body (2).

f. Check that square hole in bottom of lock plate (6) is aligned with square surface on threaded end of stem (14).

NOTE

It is possible to install the lock plate (6) 180° out of the desired position, if the alignment procedures in steps "d" and "f" are not followed. If the cap will not fit when assembled, remove the lock plate (6) and reassemble after rotating it 180°.

g. Compress the lock plate (6) and fuel cap body (2) and secure with washer (11) and nut (10).

h. Connect fuel cap assembly to safety chain (9) and reinstall in tank.

13-65. RED PLASTIC "FLUSH-TYPE" FILLER CAPS. A red plastic "Flush-Type" vented filler cap may be used. Extra care is required when reinstalling plastic filler caps in the fuel filler adapter assembly. An improperly installed filler cap could cause a loss of fuel from the tanks during flight.

13-66. INSPECTION.

NOTE

If fuel collects in the handle well it could indicate stem O-ring leakage. Fuel collecting around perimeter of cap could indicate cap outer seal or check valve leakage.

a. Remove fuel cap from adapter (8), remove safety chain (10) from cap and cover or plug fuel opening to keep out foreign matter.

b. Rotate cap handle (1) to the "OPEN" position, compress cap body (2) and lock plate (6) to expose the .125 inch diameter handle pin (17).

c. Using a small wire push out the handle pin (17).

d. Note resilience of O-ring (13) and outer seal (3) and condition of grooves. If the O-ring (13) or the outer seal (3) have deteriorated they must be replaced.

e. Note condition of tabs on lock plate (6) for signs of abnormal wear, if such wear is evident replace the complete cap assembly.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 13-17. Fuel Filler Cap-Metal (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 13-17. Fuel Filler Cap-Plastic (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

13-67. CLEANING.

a. Using a cotton swab and Stoddard solvent or equivalent, gently lift edges of rubber umbrella (5) and clean stainless steel seat and umbrella removing all contaminants. Using a second swab wipe seat and umbrella thoroughly, removing all cotton fibers. Repeat until swabs show no discoloration.

b. If O-ring or outer seal grooves appear contaminated, clean with Stoddard solvent or equivalent and cotton swabs.

c. Ascertain that all vent holes in check valve are unobstructed.

d. Clean cap body and lock plate, check for defects.

e. If the umbrella continues to leak or is deteriorated it must be replaced.

f. To remove umbrella, lubricate the umbrella stem with (MIL-H-5606) hydraulic fluid to prevent tearing the stem.

g. To replace umbrella, lubricate the umbrella stem with (MIL-H-5606) hydraulic fluid and use a small blunt tool to insert the retaining knob on the umbrella stem into the check valve body to prevent damaging the stem.

13-68. REASSEMBLY.

NOTE

If fuel was observed leaking around the cap periphery prior to disassembly and the leakage was not due to a bad O-ring or outer seal an additional split washer (16) may be added for a total of two, prior to reassembling cap. To make sure that these washers are not installed upside down, check to see that edges of the split parallel the respective sides of the cap well. The addition of a washer under the cap handle will increase the effort required to uncap the fuel tank.

a. Install spring (15) on stem (14).

b. Install fuel cap body (2) on stem (14).

c. Check that three metal plates (12) on top rim of lock plate (6) are aligned with three guide bosses on fuel cap body (2).

CAUTION

It is possible to install the handle pin in the pin hole 180° out of the desired position, if the alignment procedure in step "c" is not followed. If the handle (1) is not installed properly the FWD arrow on the cap will not align with the arrow on the placard (9) when the cap is reinstalled.

d. Compress cap body (2) and lock plate (6), install split washer(s) (16) as required.

e. Install cap handle (1) on stem (14) so that the handle (1) will be in the open position.

f. Insert handle pin (17) through handle (1) and stem (14).

g. Connect fuel cap assembly to safety chain (10) and reinstall fuel cap. Make certain that the arrow on the fuel cap body (2) and the arrow on the placard (9) align.

13-69. LEAK TESTING METAL OR RED PLASTIC FILLER CAPS. The following procedure may be used to detect fuel filler cap leakage.

a. Service the aircraft with approved fuel, filling each fuel bay.

b. Place the fuel selector in the OFF position.

c. Plug one of the fuel bay vent lines (where it protrudes beneath the wing) with a small rubber plug or tape.

d. Connect a rubber hose to the other vent. Then tee into this hose a pressure measuring device, such as a water manometer, manifold pressure gage or airspeed indicator.

e. Blow into the open end of the hose. The pressure must not exceed .7 psi which equals 20 inches of water on a water manometer, or 1.43 inches Hg on a manifold pressure gage, or 174 kts on an airspeed indicator.

WARNING

Do not inhale fuel vapor while blowing into the rubber hose.

f. It may take several applications of pressure to bring the bay to the desired pressure.

WARNING

Do not apply regulated or unregulated air pressure from an air compressor to the fuel vent. Over inflation and major structural damage will occur if more than .7 psi is applied.

g. Pinch or close the rubber hose to sustain pressure in the fuel bay.

h. Apply a soap solution to the fuel filler caps and inspect for leakage around the rubber seal to filler neck junction, the fuel cap vent, and the fuel cap handle stem. Load the cap sideways in all directions by pressing on the fuel cap vent housing by hand.

NOTE

No leakage is permissible. If leaks are present, replace the cap with a new unit or repair in accordance with Cessna Service Information Letter SE80-59, Supplement #1, dated, June 23, 1980.

CAUTION

Care must be exercised in removing the fuel filler caps until the system has been depressurized.

i. After replacement of either fuel filler cap, repeat the inspection.

j. Remove the rubber hose, unplug or remove the tape from the other fuel vent, and place the fuel selector in the desired position.

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 14

PROPELLER AND GOVERNOR

WARNING

When performing any inspection or maintenance that requires turning on the master switch, installing a battery, or pulling the propeller through by hand, treat the propeller as if the ignition switch were ON. Do not stand nor allow anyone else to stand, within the arc of the propeller, since a loose or broken wire or a component malfunction could cause the propeller to rotate.

TABLE OF CONTENTS	Page No. Aerofiche/Manual	
PROPELLER	2H6/14-1	Trouble Shooting 2H13/14-6
Description	2H6/14-1	Removal 2H13/14-6
Repair	2H6/14-1	Control Arm and Bearing Assembly. 2H13/14-6
Trouble Shooting	2H7/14-2	Removal and Installation. 2H13/14-6
Removal.	2H9/14-2B	Governor Installation 2H13/14-6
Installation	2H9/14-2B	High-RPM Adjustment 2H14/14-7
Time Between Overhaul (TBO)	2H10/14-3	Rigging Governor Control 2H14/14-7
GOVERNOR	2H10/14-3	Time Between Overhaul (TBO) 2H15/14-8
Description	2H10/14-3	

14-1. PROPELLER.

14-2. DESCRIPTION. The aircraft is equipped with an all-metal, constant-speed, governor-regulated propeller. The constant-speed propeller is single-acting, in which engine oil pressure, boosted and regulated by the governor is used to obtain the correct blade pitch for the engine load. Engine lubricating oil is supplied to the power piston in the propeller hub through the crankshaft. The amount and pressure of the oil supplied is controlled by the engine-driven governor. An increase or decrease in throttle setting or a change in aircraft attitude will affect the balance which maintains a given RPM. If the throttle is opened further or if aircraft speed is increased, engine RPM will try to increase. The governor senses this and directs oil pressure to the forward side of the piston. The blades will be moved to a

higher pitch and engine speed will remain constant. Conversely, if the throttle opening or the aircraft speed is decreased, the engine RPM will try to decrease. The governor senses this and allows oil to drain from the forward side of the piston. Spring tension and centrifugal twisting moment will move the blades to a lower pitch to maintain the selected engine speed.

14-3. REPAIR. Metal propeller repair first involves evaluating the damage and determining whether the repair will be a major or minor one. Federal Aviation Regulations, Part 43 (FAR 43), and Federal Aviation Agency, Advisory Circular No. 43.13 (FAA AC No. 43.13), define major and minor repairs, alterations and who may accomplish them. When making repairs or alterations to a propeller FAR 43, FAA AC No. 43.13 and the propeller manufacturer's instructions must be observed.

MODEL 210 & T210 SERIES SERVICE MANUAL

14-4. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
FAILURE TO CHANGE PITCH.	Governor control disconnected or broken.	Check visually. Connect or replace control.
	Governor not correct for propeller. (Sensing wrong.)	Check that correct governor is installed. Replace governor.
	Defective governor.	Refer to paragraph 14-9.
	Defective pitch changing mechanism inside propeller or excessive propeller blade friction.	Propeller repair or replacement is required.
FAILURE TO CHANGE PITCH FULLY.	Improper rigging of governor control.	Check that governor control arm and control have full travel. Rig control and arm as required.
	Defective governor.	Refer to paragraph 14-9.
SLUGGISH RESPONSE TO PROPELLER CONTROL.	Excessive friction in pitch changing mechanism inside propeller or excessive blade friction.	Propeller repair or replacement is required.
STATIC RPM TOO HIGH OR TOO LOW.	Improper propeller governor adjustments.	Perform static RPM check Refer to section 12 and 12A for procedures.
ENGINE SPEED WILL NOT STABILIZE.	Sludge in governor.	Refer to paragraph 14-9.
	Air trapped in propeller actuating cylinder.	Trapped air should be purged by exercising the propeller several times prior to take-off after propeller has been reinstalled or has been idle for an extended period.
	Excessive friction in pitch changing mechanism inside propeller or excessive blade friction.	Propeller repair or replacement is required.
	Defective governor.	Refer to paragraph 14-9.
OIL LEAKAGE AT PROPELLER MOUNTING FLANGE.	Damaged O-ring and seal between engine crankshaft flange and propeller.	Check visually. Remove propeller and install O-ring seal.
	Foreign material between engine crankshaft flange and propeller mating surfaces or mounting nuts not tight.	Remove propeller and clean mating surfaces; install new O-ring and tighten mounting nuts evenly to torque value in para 14-6, e.
OIL LEAKAGE AT ANY OTHER PLACE.	Defective seals, gaskets, threads, etc., or incorrect assembly.	Propeller repair or replacement is required.

MODEL 210 & T210 SERIES SERVICE MANUAL

THIS PAGE INTENTIONALLY LEFT BLANK

MODEL 210 & T210 SERIES SERVICE MANUAL

14-5. REMOVAL. Refer to figure 14-1.

- a. Remove spinner attaching screws (2) and remove spinner (1), spinner support (3) and spacers (4). Retain spacers (4).
- b. Remove cowling as required for access to mounting nuts (9).
- c. Loosen all mounting nuts (9) approximately 1/4 inch and pull propeller (15) forward until stopped by nuts.

WARNING

Be certain that magneto is GROUNDED before turning propeller.

NOTE

As the propeller (15) is separated from the engine crankshaft flange, oil will drain from the propeller and engine cavities.

- d. Remove all propeller mounting nuts (9) and pull propeller forward to remove from engine crankshaft (12).

- e. If desired, the spinner bulkhead (11) can be removed by removing screws (10), which attach the spinner bulkhead to the propeller.

NOTE

If the optional propeller anti-ice system is installed, use caution when removing propeller. Removing the propeller without the anti-ice slip ring requires disconnecting nine wires at spinner bulkhead, since the slip ring is mounted to the bulkhead. Wires should be identified according to wiring diagram to facilitate reassembly. During removal, installation, or other maintenance, use care to prevent damaging slip ring and brushes.

14-6. INSTALLATION.

- a. If the spinner bulkhead was removed, position bulkhead so the propeller blades will protrude thru the spinner with ample clearance. Install spinner bulkhead attaching screws (10), which attach the spinner to bulkhead.

CAUTION

Avoid scraping metal from bore of spinner bulkhead and wedging scrapings between engine flange and propeller. Trim the inside diameter of the bulkhead as necessary when installing a new spinner bulkhead.

- b. Clean propeller hub cavity and mating surfaces of propeller and crankshaft.
- c. Lightly lubricate a new O-ring (13) and the crankshaft pilot with clean engine oil and install the O-ring in the propeller hub.

NOTE

If aircraft is configured with optional propeller anti-ice system, the slip ring assembly must be installed with or prior to propeller. Use care to prevent damaging brushes and slip ring, and insure proper alignment. Reconnect slip ring wires according to applicable wiring diagram.

WARNING

Be certain that magneto is GROUNDED before turning propeller.

MODEL 210 & T210 SERIES SERVICE MANUAL

- d. Lubricate the hub mounting studs with A-1637-16 (MIL-T-83483) grease.

CAUTION

ALL PROPELLER STUDS AND NUTS ARE REQUIRED TO BE INSTALLED WITH LUBRICATION ON THE HUB MOUNTING STUDS.

- e. Align propeller mounting studs and dowel pins with proper holes in engine crankshaft flange and slide propeller carefully over crankshaft pilot until mating surfaces of propeller and crankshaft flange are approximately 1/4 inch apart.
- f. Install propeller attaching washers and new nuts (9) and work propeller aft as far as possible, then tighten nuts evenly.

WARNING

DO NOT USE ALL STEEL LOCKNUTS. USE ONLY NEW ELASTIC ELEMENT LOCKNUTS WHEN INSTALLING PROPELLER.

- g. Torque nuts 45 to 50 lb-ft. LUBRICATED TORQUE ONLY. Refer to McCauley Service Bulletin 227, or latest revision, as applicable for propeller stud and nut torque and lubrication requirements.

CAUTION

USE OF CROW FOOT OPEN-ENDED TORQUE WRENCHES CAN CAUSE SLIPPAGE AND LEAVE MARKS ON THE ENGINE OUTPUT FLANGE IF CARE IS NOT USED DURING THE TORQUE PROCESS.

USE PROPER CALCULATIONS WHEN USING TORQUE ADAPTERS TO ENSURE CORRECT INSTALLATION TORQUE.

TO PRODUCE CONSISTENT AND ACCURATE INSTALLATION TORQUE, MCCAULEY RECOMMENDS AN ADJUSTABLE "CLICK" TYPE WRENCH WITH NON RACHETING, INTERCHANGEABLE, 12 POINT BOX-END WRENCH HEADS.

IT MAY BE NECESSARY TO USE VARIOUS ADAPTERS IN CERTAIN APPLICATIONS. HOWEVER, IT IS STRONGLY RECOMMENDED THAT EXTREME CAUTION BE EXERCISED TO ENSURE THAT ACCURATE TORQUE IS BEING APPLIED FOR MAXIMUM RETENTION.

ON MOST AIRPLANES, A TORQUE WRENCH CANNOT BE FITTED DIRECTLY ON THE PROPELLER MOUNTING NUT BECAUSE OF THE LACK OF CLEARANCE BETWEEN THE FLANGE AND ENGINE CASE. AN ADAPTER MUST BE USED ON THE TORQUE WRENCH.

THE USE OF A TORQUE WRENCH WITH ANY FORM OF EXTENSION REQUIRES THE TORQUE READING ON THE WRENCH TO BE CHANGED TO OBTAIN THE CORRECT TORQUE APPLIED AT THE NUT. TO OBTAIN CORRECT RESULTS REFER TO THE FORMULA IN SECTION 1.

- h. Install spacers (4) and spinner support (3) on propeller cylinder (5). If spacers (4) are not centered mechanically (piloted), visually center and hold them until spinner support (3) is forced firmly in place.
- i. Hold spinner (1) snug against spinner support (3) and check alignment of holes in spinner (1) with holes in spinner bulkhead(11). Add or remove spacers (4) from propeller cylinder (5) until holes are within .050 of alignment.
- j. Push hard on spinner (1) to align holes and install screws and washers (if required) in three (3) or more equal spacers around the spinner bulkhead (11). Relax pressure on spinner and install remaining screws and washers (if required) in spinner.
- k. Tighten all screws uniformly around the spinner.

14-6A. TIME BETWEEN OVERHAUL (TBO). Propeller overhaul shall coincide with engine overhaul, but shall not exceed limits specified in McCauley Service Bulletin 137 and all revisions and supplements thereto. Refer to Sections 12 and 12A for engine overhaul periods.


14-7. GOVERNOR.

14-8. DESCRIPTION. The propeller governor is a single-acting, centrifugal type, which boosts oil pressure from the engine and directs it to the propeller where the oil is used to increase blade pitch. A single-acting governor uses oil pressure to effect a pitch change in one direction only; a pitch change in the opposite direction results from a combination of centrifugal twisting moment of rotating blades and compressed springs. Oil pressure is boosted in the governor by a gear type oil pump. A pilot valve, flyweight and speeder spring act together to open and close governor oil passages as required to maintain a constant engine speed.

NOTE

Outward physical appearance of specific governors is the same, but internal parts determine whether it uses oil pressure to increase or decrease blade pitch. The propellers used on these aircraft require governors which "sense" in a certain manner. "Sensing" is determined by the type pilot valve installed inside the governor. Since the basic governor may be sent to

MODEL 210 & T210 SERIES SERVICE MANUAL



- 1. Propeller Spinner
- 2. Screw
- 3. Spinner Support
- 4. Spacer
- 5. Cylinder
- 6. Screw
- 7. Stud
- 8. Washer
- 9. Nut


- 10. Screw
- 11. Spinner Bulkhead
- 12. Engine Crankshaft
- 13. O-Ring
- 14. Dowel Pin
- 15. Propeller
- 16. Tube
- 17. Ring

NOTE:

Additional spacers (4) may be required when installing a new spinner (1) to ensure a snug fit between spinner (1) and support (3). THRU SERIAL 21062003: Order Cessna Part Number 0752620-2. DO NOT USE more than 6 spacers in this installation BEGINNING WITH SERIAL NUMBER 21062004: Order Cessna Part Number 0752620-3. DO NOT USE more than 14 spacers in this installation.

Figure 14-1. Propeller installation (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL



- 1. Propeller Spinner
- 2. Screw
- 3. Spinner Support
- 4. Spacer
- 5. Cylinder
- 6. Screw
- 7. Stud
- 8. Nut
- 9. Nut

- 10. Washer
- 11. Spinner Bulkhead
- 12. Engine Crankshaft
- 13. O Ring
- 14. Dowel Pin
- 15. Propeller
- 16. Tube
- 17. Safety Wire
- 18. Ring
- 19. Bolt

NOTE

Additional spacers (4), Cessna Part Number 0752620-3, may be required when installing a new spinner (1), to ensure a snug fit between spinner (1) and support (3). DO NOT USE more than 14 spacers in this installation.

USED ON TURBOCHARGED ENGINES

THREE-BLADED (THREADLESS)

Figure 14-1. Propeller Installation (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 14-2. Governor Control Arm and Bearing Assembly

"sense" oppositely, it is important to ascertain that the governor is correct for the propeller being used.

14-9. **TROUBLE SHOOTING.** When trouble shooting the propeller-governor combination, it is recommended that a governor known to be in good condition be installed to check whether the propeller or the governor is at fault. Removal and replacement, rigging, high-speed stop adjustment, desludging and replacement of the governor mounting gasket are not major repairs and may be accomplished in the field. Repairs to propeller governors are classed as propeller major repairs in Federal Aviation Regulations, which also define who may accomplish such repairs.

14-10. GOVERNOR REMOVAL.

- Remove cowling, nose cap and engine baffles as required for access to governor.
- Disconnect governor control from governor.

NOTE

Note EXACT position of all washers so that washers may be installed in the same position on reinstallation.

- Disconnect intake manifold balance tube at front of engine and move as required for clearance.
- Remove nuts and washers securing governor to engine and pull governor from mounting studs.
- Remove gasket from between governor and engine mounting pad.

14-11. **CONTROL ARM AND BEARING ASSEMBLY.** Refer to figure 14-2.

14-12. REMOVAL AND INSTALLATION.

- Using a scribe, make aligning index marks on governor arm (8) and end of governor serrated shaft.

NOTE

The governor arm (8) must be installed on the governor shaft in the same serration or the governor speed will be changed approximately 200 rpm.

- Remove safety wire from governor arm screw and from screws attaching governor head to governor.
- Remove the two screws (7) that pass through the non-notched holes in the retainer (6).
- Loosen, but do not remove, the four remaining screws so that retainer (6) may be rotated.
- Loosen screw in governor arm (8) so that arm may be slipped toward end of serrated shaft.
- Slip governor arm toward end of serrated shaft and work retainer (6) and control arm (8) from governor (1).

NOTE

If governor arm (8) becomes disengaged from serrated shaft, align index marks and install arm on serrated shaft. The control arm spring has approximately 1-1/2 turns preload.

- Reverse the preceding steps for reinstallation.

14-13. GOVERNOR INSTALLATION.

- Wipe governor and engine mounting pad clean.
- Install a new gasket on the mounting studs. Install gasket with raised surface of the gasket screen toward the governor.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 14-3. Governor and Control Adjustments

WARNING

Be certain that magneto is GROUNDED before turning propeller.

- c. Position governor on mounting studs, aligning governor drive splines with splines in the engine and install mounting nuts and washers. Do not force spline engagement. Rotate engine crankshaft slightly so splines will engage smoothly as soon as properly aligned.
- d. Connect governor control to governor, and rig as instructed in paragraph 14-15.
- e. Connect intake manifold balance tube, if removed. Insure all clamps are tight.
- f. Reinstall all items removed for access.

14-14. HIGH-RPM STOP ADJUSTMENT. figure 14-3.

- a. Remove engine cowling.
- b. Disconnect cabin heater inlet air duct from nose cap.
- c. Remove plug button from left front baffle.
- d. Remove safety wire and loosen the high-speed stop screw locknut.
- e. Turn the stop screw IN to decrease maximum rpm and OUT to increase maximum rpm. One full turn of the stop screw causes a change of approximately 25 rpm.
- f. Tighten stop screw locknut, safety wire stop screw and make propeller control linkage adjustment as necessary to maintain full travel.
- g. Install cabin heater inlet air duct or plug button and install cowling.
- h. Test operate propeller and governor.

NOTE

It is possible for either the propeller low pitch (high-rpm) stop or the governor high-rpm stop to be the high-rpm limiting factor. It is desirable for the governor stop to limit the high-rpm at the maximum rated rpm for a particular aircraft. Due to climatic conditions, field elevation, low-pitch blade angle and other considerations, an engine may not reach rated rpm on the ground. It may be necessary to readjust the governor stop after test flying to obtain maximum rated rpm when airborne.

14-15. RIGGING PROPELLER GOVERNOR CONTROL.

- a. Disconnect control end (5) from governor (1).
- b. Place propeller control in cabin, full forward, then pull it back approximately 1/8 inch and lock in this position. This will allow "cushion" to assure full contact with governor high-rpm stop screw.
- c. Place governor arm against high-rpm stop screw.
- d. Loosen jam nuts and adjust control rod end until attaching holes align while governor arm is against high-rpm stop screw. Be sure to maintain sufficient thread engagement of the control and rod end. If necessary, shift control in the clamps to achieve this.
- e. Attach rod end to the governor. Be sure all washers are installed correctly.
- f. Operate the control to see that the governor arm bottoms out against the low pitch stop and bottoms out against the high pitch stop on the governor before reaching the end of control cable travel.

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 15

UTILITY SYSTEMS

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
UTILITY SYSTEMS	2H18/15-2A	Trouble Shooting	2I14/15-22
Heating System	2H18/15-2A	De-Ice Flow Valve	2I14/15-22
Description	2H18/15-2A	Description	2I14/15-22
Operation	2H18/15-2A	De-Ice Flow Valve	
Trouble Shooting	2H18/15-2A	Overhaul	2I14/15-22
Removal and Installation of		Functional Check	
Components	2H18/15-2A	(Known Icing)	2I23/15-31
Defrosting System	2H18/15-2A	Boot Repair (Cold Patch)	2I24/15-32
Description	2H18/15-2A	De-Ice Boot Types of Damage	
Operation	2H18/15-2A	and Repair	2I24/15-32
Trouble Shooting	2H18/15-2A	Materials Required for	
Removal and Installation of		Installation	2I24/15-32
Components	2H18/15-2A	Boot Replacement	2I24/15-32
Ventilating System	2H18/15-2A	Timer	2I24/15-32
Description	2H18/15-2A	Description	2I24/15-32
Operation	2H18/15-2A	Functional Test (Thru	
Trouble Shooting	2H19/15-3	1982 Models)	2I24/15-32
Removal and Installation of		Functional Test	
Components	2H19/15-3	(Beginning with	
De-Ice and Anti-Ice Systems	2I3/15-11	1983 Models)	2I24/15-32
Wing and Horizontal Stabilizer		Propeller Anti-Ice Boots (Known	
One-Cycle De-Ice System		Icing)	2J1/15-33
(Thru 21062968)	2I3/15-11	Windshield Anti-Ice Panel (Known	
Description	2I3/15-11	Icing)	2J1/15-33
System Operation	2I3/15-11	Pitot Tube and Stall Warning	
Removal and Installation of		Heaters (Known Icing)	2J1/15-33
Components	2I3/15-11	Description	2J1/15-33
Trouble Shooting	2I3/15-11	Removal and Installation	2J1/15-33
Operational Check	2I5/15-13	Ice Detector Light	2J1/15-33
Adhesion Test	2I6/15-14	Description	2J1/15-33
Cleaning	2I6/15-14	95-Amp Alternator Installation	2J2/15-34
Boot Protective Products	2I6/15-14	Dual 60-Amp Alternator	
Approved Repairs (Cold Patch)	2I7/15-15	Installation	2J2/15-34
Approved Repairs (Damage to		Control Surface	
Tube Area)	2I7/15-15	Dischargers	2J2/15-34
Approved Repairs (Damage to		Description	2J2/15-34
Fillet Area)	2I7/15-15	Resistance Check	2J2/15-34
Approved Repairs (Damaged		Propeller Anti-Ice System	2J3/15-34A
Veneer	2I8/15-16	Trouble Shooting	2J3/15-34A
Materials Required for		Slip Ring Removal	2J4/15-35
Installation of Boots	2I8/15-16	Slip Ring Installation	2J4/15-35
Replacement of Boots	2I8/15-16	Slip Ring Alignment Check	2J4/15-35
Wing and Horizontal Stabilizer		Removal of Propeller	
Three-Cycle De-Ice System		Anti-Ice Timer	2J7/15-38
(Beginning with 21062969)	2I9/15-17	Installation of Propeller	
Description	2I9/15-17	Anti-Ice Timer	2J8/15-39
System Operation	2I9/15-17	Propeller Anti-Ice Ammeter	2J8/15-39
Flight into Known Icing Equipment		Description	2J8/15-39
and Systems (Beginning with		Removal	2J8/15-39
21063253)	2I9/15-17	Installation	2J8/15-39
Description	2I9/15-17	Trouble Shooting	2J8/15-39
Wing, Horizontal Stabilizer		Timer Test	2J8/15-39
and Vertical Fin De-Ice		Installation and Alignment of	
System (Beginning with		Brush Block Assembly	2J9/15-40
21063253)	2I9/15-17	Replacement of De-Ice Boots	2J9/15-40
Description	2I14/15-22		

MODEL 210 & T210 SERIES SERVICE MANUAL

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
Windshield Anti-Ice Panel (Removable)	2J10/15-40A	Service Requirements ...	2J22/15-47
Description	2J10/15-40A	Inspection	
Removal and Installation	2J10/15-40A	Requirements	2J22/15-47
Windshield Anti-Ice Panel (Fixed) .	2J10/15-40A	System Components Service	
Description	2J10/15-40A	Requirements	2J22/15-47
Removal and Installation	2J10/15-40A	Inspection Requirements	2J22/15-47
Trapped Moisture	2J14/15-40E	Masks and Hose	2J23/15-48
Oxygen System	2J15/15-40F	Maintenance and	
Description	2J15/15-40F	Cleaning	2J23/15-48
Maintenance Precautions	2J16/15-41	System Purging	2J23/15-48
Replacement of Components ..	2J16/15-41	Functional Testing	
Oxygen Cylinder General		System Leak Test	2J24/15-49
Information	2J18/15-43	System Charging	2J24/15-49

MODEL 210 & T210 SERIES SERVICE MANUAL

15-1. UTILITY SYSTEMS.

15-2. HEATING SYSTEM. (See Figure 15-1.)

15-3. DESCRIPTION. On non-turbocharged aircraft, the heating system is comprised of the heat exchange section of the left exhaust muffler, a heater valve, mounted on the left forward side of the firewall, a duct across the aft side of the firewall, a push-pull control on the instrument panel, and flexible ducts connecting the system. On aircraft with turbocharged engines, the heating system consists of an opening in the left side of the nose cap, an exhaust shroud, a heater valve, mounted on the left forward side of the firewall, to which is attached an adapter and a tube extending downward and overboard. The system also includes a duct across the aft side of the firewall, a push-pull control on the instrument panel, and flexible ducts connecting the system.

15-4. HEATER OPERATION. On aircraft with non-turbocharged engines, ram air is ducted through an engine baffle and the heat exchange section of the left exhaust muffler, to the heater valve at the firewall. On aircraft with turbocharged engines, ram air is ducted through an opening in the left side of the nose cap, through an exhaust shroud, to the heater valve at the firewall. On both models, heated air flows from the heater valve into a duct across the aft side of the firewall, where it is distributed into the cabin. The heater valve, operated by a push-pull control marked "CABIN HEAT", located on the instrument panel, regulates the volume of heated air entering the system. Pulling the heater control full out supplies maximum flow, and pushing it in gradually decreases flow, shutting off flow completely when the control is pushed full in.

15-5. TROUBLE SHOOTING. Most of the operational troubles in the heating system are caused by sticking or binding air valves and their controls, damaged air ducting, or defects in the exhaust muffler. In most cases, valves or controls can be freed by proper lubrication. Damaged or broken parts should be repaired or replaced. When checking controls, be sure valves respond freely to control movement, that they move in the correct direction, and that they move through their full range of travel and seal properly. Check that hose are properly secured and replace hose that are burned, frayed or crushed. If fumes are detected in the cabin, a very thorough inspection of the exhaust muffler should be accomplished. Refer to the applicable paragraph in Section 12 for the non-turbocharged engine exhaust system inspection, or for the turbocharged engine, refer to Section 12A. Since any holes or cracks may permit exhaust fumes to enter the cabin, replacement of defective parts is imperative because fumes constitute an extreme danger. Seal any gaps in heater ducts across the firewall with Pro-Seal #700 (Coast Pro-Seal Co., Los Angeles, California) compound, or equivalent compound.

15-6. REMOVAL AND INSTALLATION OF COMPONENTS. Figures 15-1 and 15-2 may be used as a guide for removal and installation of components of

the heater system. Cut replacement hose to length and install in the original routing. Trim hose winding shorter than the hose to allow hose clamps to be fitted. Defective heater valves should be repaired or replaced. Check for proper operation of valves and their controls after installation or repair.

15-7. DEFROSTING SYSTEM. (See figure 15-1.)

15-8. DESCRIPTION. The system is composed of a duct across the aft side of the firewall, a defroster outlet, mounted in the left side of the cowl deck immediately aft of the windshield, a defroster control knob on the instrument panel, and flexible ducting connecting the system.

15-9. DEFROSTER OPERATION. Air from the duct across the aft side of the firewall flows through a flexible duct to the defroster outlet. The defroster control operates a damper in the outlet to regulate the amount of air deflected across the inside surface of the windshield. The temperature and volume of this air is controlled by the settings of the cabin heating system control.

15-10. TROUBLE SHOOTING. Most of the operational troubles in the defrosting system are caused by sticking or binding of the damper in the defroster outlet or its control. Since the defrosting system depends on proper operation of the cabin heating system, refer to paragraph 15-5 for trouble shooting the heating and defrosting system.

15-11. REMOVAL AND INSTALLATION OF COMPONENTS. Figure 15-1 and 15-2 may be used as a guide for removal and installation of components of the defrosting system. Cut replacement hose to length and install in the original routing. Trim hose winding shorter than the hose to allow hose clamps to be fitted. A defective defroster outlet should be repaired or replaced. Check for proper operation of defroster outlet and its control after installation or repair.

15-12. VENTILATING SYSTEM. (See figure 15-3.)

15-13. DESCRIPTION. The system is comprised of an airscoop, mounted in the inboard leading edge of each wing, outlet control valves, installed in overhead consoles, located on the aircraft centerline, control valves, located above each rear doorpost, two fresh airscoop doors, one on each side of the fuselage, just forward of the front seats, a control on the instrument panel for each of these scoop doors, and flexible ducting connecting the systems. On 1977 thru 1980 models, fixed inlet scoops are installed in the lower forward cabin. The scoops are ducted to the avionics equipment to aid in cooling, and under the cabin floor to help prevent exhaust fumes from entering the cabin.

15-14. VENTILATING SYSTEM OPERATION. Air received from scoops mounted in the inboard leading edges of the wings is ducted to individually-controlled control valves, two of which are mounted in each of

MODEL 210 & T210 SERIES SERVICE MANUAL

two overhead consoles and one mounted in a console located above each rear door post. Each control valve meters the incoming cabin ventilation air, and provides an expansion chamber which reduces inlet air noise. Filters at the air inlets are primarily noise reduction filters. Air volume from the louvers in the outlet control valves is controlled by knobs located on the end of each valve. Beginning with 1982 models, outside air is routed from the wing-mounted scoops through valves in each wing root to four lever-adjusted ventilators in the cabin. The lever-adjusted ventilators replace the outlet control valves and are located in the same areas. Airflow from the wing root valves is controlled by a lever in the overhead console labeled: **OVERHEAD AIR VENTS ON OFF**. Beginning with 1983 models without air conditioning, the fresh air scoops and wing root valves are replaced by ducts equipped with adjustable doors located on the underside of each wing near the root. The adjustable doors in the ducts are controlled by the lever labeled: **OVERHEAD AIR VENTS**. Cabin ventilation is provided by two fresh air scoop doors, one on each side of the fuselage, just forward of the front seats. The left scoop door is operated by a knob on the instrument panel labeled: **CABIN AIR**, and the right scoop door is controlled by a knob adjacent to the **CABIN AIR** knob labeled: **AUX CABIN AIR**. Fresh air from the scoops is routed to a duct running across the aft side of the firewall, where it is distributed to the cabin. As long as the **CABIN HEAT** knob is pushed full in, no heated air can enter the firewall duct, however, as the **CABIN HEAT** knob is gradually pulled out, more and more heated air will blend with fresh air from the scoops. Any of the knobs may be set to any desired position to provide comfortable cabin temperatures.

15-15. TROUBLE SHOOTING. Most of the operational troubles in the ventilating system are caused by sticking or binding of the lever in the inlet scoop door or its control. The inner tube in the control valve could also bind or stick, requiring repair or replacement of the control valves. Check the filter elements in the airscoops in the leading edges of the wings for obstructions. The elements may be removed and cleaned or replaced. Since air passing through the filters is admitted into the cabin, do not use a cleaning solution which would contaminate cabin air. The filters may be removed to increase air flow. However their removal could cause a slight increase in noise level.

15-16. REMOVAL AND INSTALLATION OF COMPONENTS. Figure 15-3 may be used as a guide for removal and installation of components of the ventilating system. Cut replacement hose to length and install in the original routing. Trim hose winding shorter than the hose to allow hose clamps to be fitted. A defective control valve should be repaired or replaced. Check for proper operation of ventilating system controls after installation or repair.

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 15-1. Model 210 Heating and Defrosting System (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL



1. Defrost Nozzle
2. Valve Assembly
3. Shaft
4. Lever Assembly
5. Valve Body
6. Arm Assembly
7. Valve Plate Assembly
8. Valve Seat Assembly
9. Cabin Heat Control
10. Defrost Control
11. Valve Door Assembly

Figure 15-1. Model 210 Heating and Defrosting System (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-2. Model T210 Heating and Defrosting System (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-2. Model T210 Heating and Defrosting System (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 15-3. Ventilating System (Sheet 1 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL



Detail D

Detail A

Detail C
Used Without Air Conditioning
Thru 21064772

Detail E


Detail B

- 1. Louver
- 2. Bezel
- 3. Duct
- 4. Duct
- 5. Valve Assembly
- 6. Spring
- 7. Clamp Support Bracket
- 8. Control
- 9. Clamp Bolt
- 10. Sta-Strap
- 11. Cable Assembly
- 12. Lever
- 13. Knob


Beginning with 21064136

Figure 15-3. Ventilating System (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL



Detail C
Used With Air Conditioning



Detail C
Used Without Air Conditioning
Beginning with 21064773

1. Connector
2. Sta-Strap
3. Hose
4. Duct Assembly
5. Door Assembly
6. Cover Assembly
7. Hinge
8. Fresh Air Vent Control Arm
9. Bellcrank Support Assembly
10. Bellcrank
11. Ventilation System Control
12. Clamp Bolt
13. Push Rod
14. Bellcrank Support Strap

Figure 15-3. Ventilating System (Sheet 3 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL

15-17. DE-ICE AND ANTI-ICE SYSTEMS.

15-17A. WING AND HORIZONTAL STABILIZER ONE-CYCLE DE-ICE SYSTEM. (Thru 21062968.)

15-18. DESCRIPTION. The de-ice system consists of an engine-driven pneumatic pump, an annunciator light to monitor system operation, a timer, control valves, pneumatic de-icing boots, installed on the leading edges of the wings and horizontal stabilizer and the necessary hardware to complete the system.

CAUTION

Always allow sufficient ice build-up for efficient ice removal before actuating the de-ice system. If de-ice system is actuated continuously, or before ice has reached sufficient thickness, the ice will build up over the boots instead of cracking off.

15-19. SYSTEM OPERATION. The boots expand and contract, using pressure or vacuum from the engine-driven vacuum pump. Normally, vacuum is applied to all boots to hold them against the leading edge surfaces. When a de-icing cycle is initiated,


the vacuum is removed, and a pressure is applied to "blow up" the boots. The resulting change in contour of the boot will break the ice accumulated on the leading edges. The ice will then be removed by normal in-flight air forces. Controls for the de-icing system consist of a spring-loaded on-off rocker switch on the left switch and control panel, a pressure indicator light on the upper left side of the instrument panel, and a 5-amp circuit breaker switch on the left sidewall circuit breaker panel. The two-position de-ice switch, labeled DE-ICE PRESS, is spring-loaded to the normal off (lower) position. When pushed to the ON (upper) position and released, the system timer (located on the glove box) is energized which in turn activates one de-icing cycle. Each time a cycle is desired, the switch must be pushed to the ON position and released. The pressure indicator light, labeled DE-ICE PRESSURE, should come on within four seconds after the cycle is initiated and remain on for two or three seconds if the system is operating properly.

15-20. REMOVAL AND INSTALLATION OF DE-ICE SYSTEM COMPONENTS. For removal and installation of de-ice system components, see figure 15-4. See figure 15-5 for ice detector light installation.

15-21. TROUBLE SHOOTING -- WING AND HORIZONTAL STABILIZER ONE-CYCLE DE-ICE SYSTEM.

TROUBLE	PROBABLE CAUSE	REMEDY
DE-ICE BOOTS DO NOT INFLATE OR INFLATE SLOWLY.	Loose or faulty wiring.	Repair or replace wiring.
	Loose or damaged hose.	Tighten or replace hose.
	Loose or missing gasket.	Tighten fitting and/or replace gasket.
	Shuttle valve malfunction.	Replace shuttle valve.
	Pressure relief valve set too low.	Reset or replace valve.
	Pressure relief valve malfunction.	Replace pressure relief valve.
	Defective timer.	Replace timer.
DE-ICE BOOTS DO NOT DEFLATE OR DEFLATE SLOWLY.	Pressure relief valve malfunction.	Replace pressure relief valve.
	Shuttle valve malfunction.	Replace shuttle valve.
	Defective timer.	Replace timer.

MODEL 210 & T210 SERIES SERVICE MANUAL



- 1. Wing De-Ice Boot
- 2. Coupling
- 3. Union
- 4. Stabilizer De-Ice Boot
- 5. Tee
- 6. Pressure Switch
- 7. Fitting
- 8. Press-To-Test Lamp
- 9. Bracket
- 10. Shuttle Valve
- 11. O-Ring
- 12. Filter
- 13. Control Valve
- 14. Elbow
- 15. Vacuum Pump
- 16. Hose
- 17. Tie
- 18. Vacuum Relief Valve
- 19. Firewall
- 20. Timer and Control Switch
- 21. Timer Module

Figure 15-4. Wing and Horizontal Stabilizer One-Cycle De-Ice System

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-5. Ice Detector Light System

15-22. DE-ICE SYSTEM OPERATIONAL CHECK. (See figure 15-4.)

NOTE

Thru 21062273, the de-icing switch, located on the right-hand electroluminescent panel, is a three-position switch, spring-loaded to the normal OFF center position. When turned to ON up position and released, it will activate one de-icing cycle. Each time a cycle is desired, the switch must be pushed to the ON position and released. When pushed to the OFF down position and released, the switch will stop the system in any point in its cycle. Beginning with 21062274, the de-icing switch, located on the left-hand switch panel, is a two-position switch, spring-loaded to the normal OFF lower position. When pushed to the ON up position and released, it will activate one de-icing cycle. Each time a cycle is desired, the switch must be pushed to the ON position and released. The pressure indicator light is labeled DE-ICE PRESSURE, and is located on the upper left side of the instrument panel. It should come on within four seconds after the cycle is initiated, and remain on for two or three seconds if the system is operating properly.

a. Electrical Check:

1. Check that WING DE-ICE circuit breaker is closed.
2. Actuate DE-ICE PRESS switch (20) to ON position, release and check that it returns to the off position.
3. Turn master switch on.
4. Check press-to-test function of DE-ICE PRESSURE light to check bulb and circuit. Make

sure dimming lens on indicator light is open.

5. Activate DE-ICE PRESS switch on and check DE-ICE PRESSURE light.

6. If light fails to illuminate, recheck circuit breaker; if closed, check for short in electrical system.

7. Turn master switch off.

b. Air Pressure Test:

NOTE

This test can be performed in the engine compartment.

1. Disconnect pressure hose (16) from vacuum relief valve (18).

2. Disconnect discharge elbow (14) from control valve (13) and plug control valve port with AN933-4 plug.

3. Connect a source of clean, regulated, dry compressed air equipped with an inline hand-operated valve and pressure gage to pressure hose (16).

4. Apply 18-20 psi and trap the pressure in the system with the inline valve. Observe the system for leakage. Maximum allowable leakage is 2 psi per minute. If excess leakage is noted use a soap and water solution to locate leaks. Tighten connections as required.

5. To check pressure switch (6), turn master switch on while system is pressurized. Check that DE-ICE PRESSURE light (8) illuminates.

6. Remove test equipment and reconnect pressure hose (16) to vacuum relief valve (18).

7. Remove AN933-4 plug from control valve port (13) and replace with elbow (14).

NOTE

Refer to test kit #343 for air pressure testing and trouble shooting of 3-cycle de-ice system. This kit is available from Airborne, 711 Taylor Street, Elyria, Ohio 44035.

c. Vacuum Relief Valve Adjustment.

1. Adjust vacuum relief valve as outlined in Section 16 of this manual.

2. With vacuum relief valve adjusted and engine operating at 2400 rpm, place WING DE-ICE switch to ON position and observe de-ice system operation. System is functioning satisfactorily if the WING DE-ICE indicator light illuminates within 4.0 seconds after turning WING DE-ICE switch on.

d. Timer Cycle Check:

1. The timer cycle can be checked with the engine operating at 2100 rpm. Place WING DE-ICE switch to ON position and note time elapsed when WING DE-ICE indicator light goes out. This should be 6 seconds. Indicator light will not come on for 3 or 4 seconds after the switch is activated and will remain on until the DE-ICE control valve is deactivated by the automatic timer and control switch.

2. If it appears that the timer is defective, apply 28 VDC to Red wire of timer and ground the black and listen to action of stepping switch.

MODEL 210 & T210 SERIES SERVICE MANUAL

CAUTION

The negative ground must be applied to the black wire; red is positive. A reverse voltage will ruin timer diode. The 28 VDC must be filtered if it is rectified from AC. If possible use a battery.

15-22A. ADHESION TEST.

- a. Using excess material trimmed from ends of any wing or empennage de-ice boot, prepare one test specimen for each de-ice boot installed.
- b. This specimen should be one-inch wide and four or more inches long.
- c. Cement specimen to installation surface adjacent to installed de-ice boot, following the identical procedure used for boot installation.
- d. Leave one-inch of the strip uncemented to attach a clamp.
- e. Four hours or more after de-ice boot installation, attach a spring scale to uncemented end of each strip and measure force required to remove the strip at a rate of one-inch per minute. The pull shall be applied 180° to the surface. (Strip doubled back on itself).
- f. A minimum of five pounds tension (pull) shall be required to remove test strip.

NOTE

If less than five pounds is required acceptability of the de-ice boot adhesion shall be based on carefully lifting one corner of the de-ice boot in question sufficiently to attach a spring clamp and attaching a spring scale to this clamp. Pull with force 180° to the surface, and in such a direction that the de-ice boot tends to be removed on the diagonal. If a force of five pounds per inch of width can be exerted under these conditions, the installation shall be considered satisfactory. Width increases as corner peels back.

- g. Re-cement corner following installation procedure.

CAUTION

Failure to achieve five pounds adhesion per inch of width requires reinstallation of the de-ice boot.

NOTE

Possible reasons for failure are: dirty surfaces, cement not mixed thoroughly. Corrosion of metal skin may occur if good adhesion is not attained, especially around rivet heads and metal skin splices. If these adhesion requirements are met, the aircraft may be flown immediately. Do not inflate de-ice boots within 48 hours of installation.

15-23. CLEANING.

CAUTION

Use only the following instructions when cleaning de-ice/anti-ice boots. Disregard instructions which recommend petroleum base liquids (MEK, non-leaded gasoline, etc.) which can harm the boot material.

- a. Clean boots with mild soap and water, then rinse thoroughly with clean water.

NOTE

Isopropyl alcohol can be used to remove grime which cannot be removed using soap. If isopropyl alcohol is used for cleaning, wash area with mild soap and water, then rinse thoroughly with clean water.

15-23A. DE-ICE AND ANTI-ICE BOOT PROTECTIVE PRODUCTS. Two rubber treatment products, Age Master #1, and Icx are approved for use on de-ice boots and anti-ice boots of Cessna aircraft. Age Master #1 protects the rubber against deterioration from ozone, sunlight weathering, oxidation and pollution. Icx helps retard ice adhesion and keeps the boots looking new longer; both products are produced and recommended by B. F. Goodrich. Age Master #1 (part #74-451-127) and Icx (part #ICEX) are available from the Cessna Supply Division.

- a. Mask surrounding areas before applying Age Master #1 to clean, dry boot surfaces. Apply with a cheesecloth swab. **DO NOT SPRAY** this product; a rubbing or brushing action is required for the protective agent to penetrate the rubber surfaces. Apply three or more coats allowing a 5 to 10 minute drying period between applications. However, the total amount applied should not exceed 0.3 to 0.4 ounce per square foot of boot surface.

- b. Mask surrounding areas before applying a light coat of Icx with a cheesecloth swab to clean, dry boot surfaces. A heavy coat of Icx will result in a sticky surface which collects dust and dirt. One quart of Icx will cover approximately 500 square feet. If boots have been treated with Age Master #1, allow it to dry for a minimum of 24 hours before applying the Icx. Apply Icx Spanwise in a single continuous back and forth motion.

CAUTION

Protect adjacent areas, clothing, and wear plastic or rubber gloves during application. Age Master stains clothing and Icx contains silicone which makes paint touch-up nearly impossible. Waterless hand cleaner is beneficial for cleaning hands, equipment and clothing.

Age Master #1 and Icx coatings last approximately 150 hours on wing and stabilizer boots and 15 hours on propeller boots.

MODEL 210 & T210 SERIES SERVICE MANUAL

15-24. APPROVED REPAIRS. (Cold Patch for Scuff or Surface Damage.)

NOTE

Surface coatings and surface refurbishing kits will not repair leaks. Use repair kit materials.

NOTE

When repairing de-ice boots and replacement layers are being installed, exercise care to prevent trapping air beneath the replacement layers. If air blisters appear after material is applied, they may be removed with a hypodermic needle. Should air blisters appear after boots have been installed for a length of time, it is permissible to cut a slit in the de-ice boot, apply adhesive and repair in accordance with the following cold patch repair procedures. An alternate method of repair is to peel the de-ice boot back using Toluol and reapply using 1300L cement.

- a. Select a patch of ample size to cover damaged area.
- b. Clean area to be repaired with a cloth slightly dampened with cleaner.
- c. Buff area around damage with steel wool so that area is moderately but completely roughened
- d. Wipe buffed area clean with a cloth slightly dampened with cleaner to remove all loose particles.
- e. Apply one even, thorough coat of 1300L cement to the patch and to the corresponding damaged area of the de-ice boot. Allow cement to set until it becomes tacky.
- f. Apply patch to the de-ice boot with an edge or the center adhering first, then work remainder of patch down, being careful to avoid trapping air pockets.
- g. Roll patch thoroughly with a stitcher roller, and allow to set for ten or fifteen minutes.
- h. Wipe patch and surrounding area from center of patch outward with a cloth slightly dampened with MEK.
- i. Apply one light coat of A-56-B conductive cement (B. F. Goodrich part number 74-451-11) to restore conductivity.

NOTE

Satisfactory adhesion should be obtained in four hours; however, if the patch is allowed to cure for a minimum of twenty minutes, the de-ice boots may be inflated to check the repair.

15-24A. APPROVED REPAIRS. (Damage to Tube Area.)

NOTE

This type of damage consists of cuts, tears or ruptures to the inflatable tube area, and a fabric-reinforced patch must be used.

- a. Select a patch of ample size to extend at least 5/8-inch beyond the damaged area.

NOTE

If the correct size patch cannot be obtained, one may be cut to the size desired from a larger patch. If this is done, the edges should be beveled by cutting with the shears at an angle. These patches are manufactured so they will stretch in one direction only. Be sure to cut the patch selected so that the stretch is in the width wise direction of the inflatable tube.

- b. Clean the area to be repaired with a cloth slightly dampened with cleaner.
- c. Buff the area around damage with steel wool so that area is moderately but completely roughened.
- d. Wipe buffed area clean with a cloth slightly dampened with cleaner to remove all loose particles.
- e. Apply one even, thorough coat of 1300L cement to the patch and to the corresponding damaged area of the de-ice boot. Allow cement to set until it becomes tacky.
- f. Apply patch to de-ice boot with the stretch in the width-wise direction of the inflatable tubes, sticking edge of patch in place first, and working remainder down with a very slight pulling action so the rupture is closed. Use care not to trap air between patch and de-ice boot.
- g. Roll patch thoroughly with a stitcher roller and allow to set for ten or fifteen minutes.
- h. Wipe patch and surrounding area, from the center of patch outward with a cloth slightly dampened with cleaner.
- i. Apply one light coat of A-56-B conductive cement (B. F. Goodrich part number 74-451-11) to restore conductivity.

NOTE

Satisfactory adhesion of patch to de-ice boot should be reached in four hours; however, if patch is allowed to cure for a minimum of twenty minutes, de-ice boots may be inflated to check the repair.

15-24B. APPROVED REPAIRS. (Damage to Fillet Area.)

NOTE

This damage includes any tears or cuts to the tapered area aft of the inflatable tubes.

- a. Trim damaged area square and remove excess material. Cut must be sharp and clean to permit a good butt joint of the inlay.
- b. Cut inlay from tapered fillet B. F. Goodrich part number 74-451-21) to match cut out area.
- c. Using Toluol, loosen edges of de-ice boot around area approximately one and one-half inches from all edges.
- d. Clean area to be repaired with a cloth slightly dampened with cleaner.

MODEL 210 & T210 SERIES SERVICE MANUAL

e. Lift back edges of cutout and apply one coat of 1300L cement to underneath side of loosened portion of de-ice boot.

f. Apply one coat of 1300L cement to wing skin underneath loosened edges of de-ice boot and extending one and one-half inches beyond edges of de-ice boot into cutout area.

g. Apply second coat of 1300L cement to underneath side of de-ice boot as outlined in step (e).

h. Apply one coat of 1300L cement to one side of a two-inch wide neoprene-coated fabric tape (B. F. Goodrich part number 74-451-22), allow to dry and trim to size.

i. Reactivate cemented surfaces with Toluol and apply reinforcing tape to wing skin, exercising care to center tape under all edges of cutout.

j. Roll down tape on wing skin with stitcher roller to assure good adhesion, being careful to avoid creating air pockets.

k. Apply one coat of 1300L cement to top surface of tape and allow to dry approximately five to ten minutes.

l. Reactivate cemented surfaces with toluol. Working toward cutout, roll down edges of loosened de-ice boot, being careful to avoid creating air pockets.

Edges should overlap on tape approximately one inch.

m. Roughen back surface of inlay repair material, previously cut to size, clean with cleaner and apply one coat of 1300L cement.

n. Apply one coat of 1300L cement to wing skin inside of cutout area and allow to dry.

o. Apply second coat of 1300L cement to back side of inlay material and allow to dry.

p. Reactivate cemented surfaces with Toluol and carefully insert inlay material with feathered edge aft. Working from wing leading edge aft, roll down inlay material carefully to avoid trapping air.

q. Roughen area on outer surface of de-ice boot and inlay with steel wool, one and one-half inches on each side of splice. Clean with cleaner and apply one coat of 1300L cement to this area.

r. Apply one coat of 1300L cement to one side of two-inch wide neoprene-coated fabric tape, trim to size and center tape over splice on all three sides.

s. Roll down tape on de-ice boot with stitcher roller to assure good adhesion, being careful to avoid creating air pockets.

t. Apply one light coat of A-56-B conductive cement (B. F. Goodrich part number 74-451-11) to restore conductivity.

15-24C. APPROVED REPAIRS. (Damaged Veneer, loose from De-ice Boot.)

a. Peel and trim loose veneer to the point where adhesion of veneer to de-ice boot is good.

b. Roughen area in which veneer is removed, with steel wool, rubbing parallel to cut edge of veneer ply to prevent loosening it.

c. Taper edges of veneer down to tan rubber ply by rubbing parallel to edges with steel wool and MEK.

d. Cut a piece of veneer material (B. F. Goodrich part number 74-451-23) to cover damaged area and extend at least one-inch beyond, in all directions.

e. Mask off an area one-half inch larger in length and width than size of veneer patch.

f. Apply one coat of 1300L cement to damaged area,

and one coat to veneer ply. Allow cement to set until it becomes tacky.

g. Roll veneer ply to de-ice boot with a two-inch rubber roller, applying a slight tension on veneer ply when applying, to prevent trapping air.

h. Wipe patch and surrounding area from center of patch outward with a cloth slightly dampened with cleaner.

i. Apply one light coat of A-56-B conductive cement (B. F. Goodrich part number 74-451-11) to restore conductivity.

NOTE

B. F. Goodrich Repair Kit No. 74-451-C, for repairing de-ice boots, is available from Cessna Parts Distribution (CPD 2) through Cessna Service Stations.

15-25. MATERIALS REQUIRED FOR INSTALLATION OF DE-ICE BOOTS.

1. No. EC-1300L (EC-1403) Cement, Minnesota Mining & Manufacturing Company.
2. Methyl-Isobutyl Ketone (MIBK).
3. Cleaning Solvent - Toluol.
4. Cleaning Solvent - Hexane.
5. Clean, lint-free cleaning cloths.
6. Four yards clean, heavy canvas duck fabric 48 inches wide.
7. Several empty tin cans.
8. Three-inch paint brushes.
9. Two-inch rubber hand rollers.
10. 1/4-inch metal hand stitcher roller, B. F. Goodrich Company (Part Number 3306-10).
11. Carpenters' chalk line.
12. One-inch masking tape.
13. Steel measuring tape.
14. Sharp knives.
15. Fine sharpening stone.
16. No. EC-539 Sealing Compound, Minnesota Mining & Manufacturing Company.
17. No. A-56-B Cement, B. F. Goodrich Company (Part Number 3306-15).
18. GACO-700-A Coating, Gates Engineering Co., Wilmington, Delaware 19899.

15-26. REPLACEMENT OF DE-ICE BOOTS. To remove or loosen installed de-ice boots, use toluol or toluene to soften the "cement" line. Apply a minimum amount of this solvent to the cement line as tension is applied to peel back the boot. Removal should be slow enough to allow the solvent to undercut the cement so that parts will not be damaged. To install a wing de-icer boot, proceed as follows:

a. Clean the metal surfaces and the bottom side of the de-icer thoroughly with Methyl Ethyl Ketone or Methyl Isobutyl Ketone. This shall be done by wiping the surfaces with a clean, lint-free rag soaked with the solvent and then wiping dry with a clean, dry, lint-free rag before the solvent has time to dry.

b. Place one inch masking tape on wing to mask off boot area allowing 1/2-inch margin. Take care to mask accurately so that clean-up time will be reduced.

c. Stir EC-1300L cement thoroughly before using. Brush one even, light coat onto leading edge and to rough side of boot, brushing well into rubber. Allow cement to air dry until cement does not transfer to

MODEL 210 & T210 SERIES SERVICE MANUAL

fingers when touched. Then apply a second coat to each of the surfaces and allow to dry. Apply a vacuum to the boots when they are installed to help smooth out wrinkles.

d. Place a straight line along the leading edge line and a corresponding line on the inside of the de-icer boot if it does not have a centerline. Securely attach hoses to de-icer connections. Position centerline of boot with leading edge line, using a clean, lint-free cloth, heavily moistened with toluol, reactivate surface of cement on wing and the boot in small, spanwise areas approximately 6-inches wide. Avoid excessive rubbing of cement, which would remove it from the surface of the wing. Utilize enough help to hold boot steady during installation, and caution them against handling cemented surfaces. Roll boot firmly against leading edge, being careful not to trap any air between boot and leading edge surface. Always roll parallel to the inflatable tubes. Should the boot attach "off course", pull it up immediately with a quick motion, and reposition properly. Avoid twisting or sharp bending of boot. Finally, roll the entire surface of the boot parallel to tubes, applying pressure. Use the metal stitcher roller between tubes and around connections. Should an air pocket be encountered, carefully insert a hypodermic needle and allow air to escape. Do not puncture the inflatable tubes at any time. Fill any gaps between adjoining boots with GACO N-700-A Neoprene coating (Gates Engineering Co., Wilmington, Delaware 19899). Apply a coat of the Neoprene coating along trailing edge of boot to the surface of the skin to form a neat, straight fillet.

e. Remove masking tape and clean surfaces with toluol.

15-26A. WING AND HORIZONTAL STABILIZER THREE-CYCLE DE-ICE SYSTEM. (Beginning with 21062969.) (See figure 15-5A.)

15-26B. DESCRIPTION. The system consists of pneumatically-operated boots, an engine-driven pneumatic pump, an annunciator light to monitor system operation, system controls and the hardware necessary to complete the system.

15-26C. SYSTEM OPERATION. The boots expand and contract, using pressure or vacuum from the engine-driven vacuum pump. Normally, vacuum is applied to all boots to hold them against the leading edge surfaces. When a de-icing cycle is initiated, the vacuum is removed and a pressure is applied to "blow up," the boots. Ice on the boots will then be removed by normal in-flight air forces. Controls for the system consist of a spring-loaded on-off rocker switch on the left switch and control panel, a pressure indicator light on the upper left side of the instrument panel, and a 5-amp "pull-off" type circuit breaker on the left sidewall circuit breaker panel. The two-position de-icing switch, labeled DE-ICE PRESS, is spring-loaded to the normal off (lower) position. When pushed to the ON (upper) position and released, it will activate one de-icing cycle. Each time a cycle is desired, the switch must be pushed to the ON position and released. If necessary, the system can be stopped at any point in the cycle (de-

flating the boots) by pulling out the circuit breaker labeled WING, DE-ICE. During a normal de-icing cycle, the boots will inflate according to the following sequence: first, the horizontal stabilizer boots will inflate for approximately six seconds, then the in-board boots inflate for the next six seconds, followed by the outboard wing boots for another six seconds. The total time required for one cycle is approximately 18 seconds. The pressure indicator light, labeled DE-ICE PRESSURE, should illuminate when the horizontal stabilizer boots reach proper operating pressure. At lower altitudes, it should come on within one to two seconds after the cycle is initiated and remain on for approximately 17 seconds if the system is operating properly. At higher altitudes, the light will come on initially within three seconds and will go off for one to three seconds during sequencing. The system may be recycled six seconds after the light goes out. The absence of illumination during any one of the three sequences of a cycle indicates insufficient pressure for proper boot inflation and effective de-icing ability. An ice detector light is also installed to facilitate detection of wing ice at night or during reduced visibility. The ice detector light system consists of a light installed on the left side of the cowl deck forward of the windshield which is positioned to illuminate the leading edge of the wing, and a rocker-type switch, labeled DE-ICE LIGHT, located on the left switch and control panel.

15-26D. FLIGHT INTO KNOWN ICING EQUIPMENT AND SYSTEMS. (Beginning with serial 21063253.) (See figure 15-5B.)


15-26E. DESCRIPTION. A flight into known icing equipment package may be installed on the airplane. For operations in known icing conditions as defined by the FAA, the following Cessna (drawing number 1200254) and FAA approved equipment must be installed and operational:

1. Wing horizontal stabilizer and vertical fin leading edge pneumatic de-ice boots.
2. Propeller anti-ice boots.
3. Windshield anti-ice panel.
4. Heated pitot tube (high capacity).
5. Heated stall warning transducer (high capacity).
6. Ice detector light.
7. 95-amp alternators. (Thru 1982 models).
8. Dual 60-amp alternators. (Beginning with 1983 models).
9. Control surface static dischargers.
10. High capacity vacuum pump (thru 1981 models).
11. Dual vacuum pumps. (Beginning with 1982 models).

Service information on this equipment when installed on known icing certified aircraft is contained in the following paragraphs.

15-26F. WING, HORIZONTAL STABILIZER AND VERTICAL FIN DE-ICE SYSTEM. (Beginning with serials 21063253.) (See figures 15-5C and 15-5D.)

MODEL 210 & T210 SERIES SERVICE MANUAL



- 1. Wing De-Ice Boot
- 2. De-Ice Pressure Light
- 3. Switch and Circuit Breaker Panel
- 4. Vacuum Pump
- 5. Pressure Valve
- 6. Timer
- 7. Cross
- 8. Pressure Switch
- 9. Stabilizer De-Ice Boot
- 10. Flow Control Valve
- 11. Grommet
- 12. Tube Assembly
- 13. Cover Assembly
- 14. Lens
- 15. Lens Doubler
- 16. Bracket
- 17. Lamp Socket
- 18. De-Ice Bulb

BEGINNING WITH 21062969

Figure 15-5A. Wing and Horizontal Stabilizer Three-Cycle De-Ice System

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 15-5B. Known Icing Equipment Installation (Sheet 1 of 3)


MODEL 210 & T210 SERIES SERVICE MANUAL

21063641 THRU 21064535


21064536 THRU 21064772



THRU 21063640





Detail E




6 24 23 22 25 21

- 6. Circuit Breaker Panel
- 7. Switch Panel
- 8. Propeller De-Ice Gage
- 9. De-Ice Press. Indicator Light




Detail F

- 21. Stall Warning Circuit Breaker
- 22. Pitot Heat Circuit Breaker
- 23. Windshield Anti-Ice Circuit Breaker
- 24. Propeller Anti-Ice Circuit Breaker
- 25. Wing De-Ice Circuit Breaker



21062274 THRU 21064535


Detail G



21064536 THRU 21064772

Detail G

- 27. Pitot Heat Switch
- 28. Propeller Anti-Ice Switch
- 29. Windshield Anti-Ice Switch
- 30. De-Ice Light Switch
- 31. De-Ice Pressure Switch
- 32. Master Switch
- 33. Alternator Hi-Voltage Light
- 34. Alternator Lo-Voltage Light
- 35. Alternator Off Lights



6 24 23 22 25 21


Detail E

● USED WITH DUAL ALTERNATORS
21064536 THRU 21064772

Figure 15-5B. Known Icing Equipment Installation (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL

BEGINNING WITH 1983 MODELS
SERIAL 21064773 & ON



- 36. Lo-Vacuum Warning Light
- 37. Heated Stall Warning Circuit Breaker
- 38. Stall Warning Heat Switch

Figure 15-5B. Known Icing Equipment Installation (Sheet 3 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL


NOTE

A few aircraft which are not certified for flight into known icing conditions may have this system installed.

15-26G. DESCRIPTION. The system consists of an engine-driven vacuum pump, pressure control valve, vacuum relief valve, flow control valves, pressure switch, timer and boots mounted on the leading edge of each wing, horizontal stabilizer and the vertical fin. The aircraft vacuum system components also serve the de-ice vacuum system, and the vacuum

relief valve adjustment should be maintained in accordance with procedures outlined in the applicable paragraph in Section 16 of this manual. If the vacuum relief valve is set too low, suction to the gyros will drop momentarily during the boot inflation cycle. This suction variation can be corrected with proper vacuum relief valve adjustment. The standard vacuum pump is replaced with a larger capacity vacuum pump. Beginning with 1982 models dual vacuum pumps and dual control valves are components of the system. An ice detector light is incorporated in the left side of the cowl deck below the windshield to aid in checking for ice formations during night operation.

15-26H. TROUBLE SHOOTING -- WING, HORIZONTAL STABILIZER AND VERTICAL FIN DE-ICE SYSTEM.



15-26J. DE-ICE FLOW VALVE. (Serial 21062969 thru 21064802.) B. F. Goodrich part number 3D2357-01.

15-26K. DESCRIPTION. The system is equipped with three de-ice flow valves (Figure 15-5C, items 13 and 25.) The valves are electrical solenoid operated and route pressure and vacuum from the vacuum pumps to the de-ice boots.


15-26L. DE-ICE FLOW VALVE OVERHAUL. If it becomes necessary to overhaul a de-ice flow valve (B. F. Goodrich part number 3S2357-01), follow the procedures outlined in Service Information Letter #SE83-12.

MODEL 210 & T210 SERIES SERVICE MANUAL

21063253 Thru 21064535

NOTE

This installation is a required component for flight in known icing certified aircraft.



- | | | |
|-----------------------------------|-------------------------------|------------------------|
| 1. LH Wing De-Ice Boot | 9. Vertical Fin De-Ice Boot | 16. Cover Assembly |
| 2. De-Ice Pressure Light | 10. LH Stabilizer De-Ice Boot | 17. Flow Control Valve |
| 3. Switch & Circuit Breaker Panel | 11. De-Ice Bulb | 18. Pressure Switch |
| 4. Vacuum Pump | 12. Lamp Socket | 19. Grommet |
| 5. Pressure Valve | 13. Bracket | 20. Tube Assembly |
| 6. Timer | 14. Lens Doubler | 21. Cross Assembly |
| 7. RH Wing De-Ice Boot | 15. Lens | 22. Nut |
| 8. RH Stabilizer De-Ice Boot | | 23. Screw |

Figure 15-5C. Wing, Horizontal Stabilizer and Vertical Fin De-Ice System (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-5C. Wing, Horizontal Stabilizer and Vertical Fin De-Ice System (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

Beginning with 21064536




Figure 15-5D. Wing, Horizontal Stabilizer and Vertical Fin De-Ice System (Sheet 1 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-5D. Wing, Horizontal Stabilizer and Vertical Fin De-Ice System (Sheet 2 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-5D. Wing, Horizontal Stabilizer and Vertical Fin De-Ice System (Sheet 3 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-5D. Wing, Horizontal Stabilizer and Vertical Fin De-Ice System (Sheet 4 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-5E. Surface De-Ice System Components (Known Icing)(Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-5E. Surface De-Ice System Components (Known Icing)(Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

15-26M. DE-ICE SYSTEM FUNCTIONAL CHECK (KNOWN ICING). (See figure 15-5E.)

- a. Electrical Controls Check:
 1. Check wing de-ice circuit breaker is closed.
 2. Check de-ice pressure switch is off (spring-loaded to off position).
 3. Turn master switch on.
 4. Press de-ice pressure light to check light circuit and bulb. Make sure dimming shutter is open.
 5. Turn master switch off.
- b. Vacuum Relief Valve(s) Adjustment.
 1. Refer to Section 16 of this manual for vacuum relief valve(s) adjustment.
- c. Preflight System Check:
 1. With vacuum relief valve(s) adjusted and engine running from 2200 to 2500 rpm, check both buttons on the suction gage are retracted out of sight and vacuum is normal.
 2. Place de-ice pressure switch on and release.
 3. Check that de-ice pressure light comes on within one second, remains on for 18 seconds, then off.
 4. Check boots for inflation during 18 second cycle as follows: first six seconds tail section boots, then inboard wing boots for next six seconds, finally the outboard wing boots inflate for six seconds completing one cycle.
 5. The absence of or slow illumination of the de-ice pressure light during any one of the three sequences of a cycle indicates insufficient pressure for proper system operation.
- d. Timer Check:
 1. Refer to paragraph 15-26U for timer check.
- e. Air Pressure Check (See figure 15-5E):

NOTE

This check may be performed in the engine

1. Disconnect both pump pressure hoses (8) from vacuum pumps (1).

Connect a source of clean regulated dry air pressure (21 ± 1 psig) fitted with a hand-operated valve or check valve and an in-line air pressure gauge to right pump pressure hose (8).

NOTE

A test kit (No. 343) for testing vacuum and pneumatic de-ice system is available from Airborne, 711 Taylor Street, Elyria, Ohio 44035, or from Cessna Parts Distribution (CPD 2) through Cessna Service Stations. This kit contains the necessary equipment and supplemental instructions to perform this check.

3. Disconnect left and right vacuum inlet hoses from left and right vacuum pumps (1).
4. Disconnect electrical leads from pressure control valves (3).

CAUTION

Do not attempt air pressure check with de-ice timer module connected into the circuit.

5. Connect a vacuum source (5.6 in. Hg minimum) to right pump vacuum hose.
6. Connect a switched 28VDC electrical source to right pressure control valve (3).
7. Insert pressure probe equipped with vacuum pressure gage into the rubber hose connecting tail boots with tail boot flow valve.
8. Turn on pressure and vacuum sources. Verify that pressure flow is being vented overboard at right pressure control valve and no flow is present either in or out of disconnected hoses at left vacuum pump. Pressure gage on probe should read 4.5-4.6 in. Hg vacuum.
9. Switch on electrical power to right pressure control valve and actuate tail boot flow control manually.

NOTE

Flow valves can be actuated mechanically by depressing the solenoid plunger inward using the fingers. This procedure eliminates the necessity of disconnecting and reconnecting electrical leads.

10. Overboard flow at pressure control valve should stop and pressure air should inflate tail boots. Pressure gage should show 18 ± 5 psi with audible venting of pressure air from pressure regulator valve (7) evident. Recheck for absence of airflow out of left pressure control valve.
11. With pressure control valve energized turn off pressure source using hand-operated valve. Pressure leak-down as shown by probe pressure gage should be 2 psi per minute or less. Use soap and water solution to locate leaks, turn off power to left pressure control valve, repair leaks and retest until leak-down rate is within tolerance.
12. Insert pressure probe into hose connecting outboard wing boots with outboard boot flow control valve and repeat steps 8 thru 11 noting leaks.
13. Insert pressure probe into hose connecting inboard wing boots with inboard boot flow control valve and repeat steps 8 thru 11 noting leaks.
14. Disconnect pressure and vacuum sources from right vacuum pump hoses and connect to left pump hoses.
15. Turn on pressure and vacuum sources. Verify that pressure flow is being vented overboard at left pressure control valve and no flow is present either in or out of disconnected hoses at right pump. Probe pressure gage should read 4.5-5.6 in. Hg vacuum.
16. Switch on electrical power to left pressure control valve. Overboard flow at pressure control valve should stop. Check for no airflow from right pressure control valve and audible venting of pressure air from pressure regulator valve (7) evident.
17. With probe air pressure gage inserted into hose connecting any flow valve with its associated de-ice boot, actuate flow valve manually, and recheck probe air pressure gage reads 18 ± 5 psi.
18. Disconnect test equipment and reconnect pressure and vacuum lines to vacuum pumps.
19. Reconnect wiring to pressure control valves.

MODEL 210 & T210 SERIES SERVICE MANUAL

15-26N. DE-ICE BOOT REPAIR. (COLD PATCH.) Follow procedures outlined in paragraph 15-24.

15-26P. DE-ICE BOOT TYPES OF DAMAGE AND REPAIR. Follow procedures outlined in paragraphs 15-24A, 15-24B, and 15-24C.

15-26Q. MATERIALS REQUIRED FOR INSTALLATION OF DE-ICE BOOTS. Use the materials listed in paragraph 15-25.

15-26R. REPLACEMENT OF DE-ICE BOOTS. Follow the procedures outlined in paragraph 15-26.

15-26S. TIMER (See figure 15-5E.)

15-26T. DESCRIPTION. The timer, located on the underside of the glove box, controls the time the de-ice boots are inflated.

15-26U. FUNCTIONAL TEST OF TIMER. (Thru 1982 Models) (See figure 15-5E, Sheet 1.)

- Connect timer as shown in the wiring schematic.
- Set voltage at 28 VDC, and turn control switch on.
- Record the time each light is on.
- The recorded times shall be as shown in the chart $\pm 10\%$ at 28 VDC.
- Turn control switch on, then release to off.

f. Timer output shall complete the cycle then shut off all outputs.

NOTE

Do not check voltage levels without a load attached; readings may be erroneous.

15-26V. FUNCTIONAL TEST OF TIMER. (1983 Models and on) (See figure 15-5E, Sheet 2.)

- Connect timer as shown in wiring schematic.
- Set the voltage at 28 VDC and turn the control switch on.
- Record the time each light is on.
- The recorded times shall be as shown in the chart (sheet 2) $\pm 10\%$ at 28 VDC.
- Turn control switch on, then release to off.
- The timer output shall complete the cycle and then shut off all outputs.

NOTE

Do not check voltage levels without a load attached; readings may be erroneous.

- Vary the voltage from 22-31 VDC and repeat step f. Timer must continue to operate at these voltages within the time frame shown in chart.


NOTE

Black wire is the ground wire.

The unit shall, once control switch is activated, complete one cycle. Reactivation of the control switch during the initial cycle, shall not interrupt or reset unit until one cycle is completed.

TIMING CHART

WIRE COLOR CODE	TIME ON (SECONDS)
BLUE	18 SECONDS
YELLOW	6 SEC.
WHITE/BLUE	6 SEC.
VIOLET	6 SEC.




* .1 AMP LAMP

* 20 Ω RESISTOR, 50 WATT OR 24 - 32 VDC SOLENOID (20 Ω)

Figure 15-5E. Wing, Horizontal Stabilizer and Vertical Fin De-Ice System Timer Test (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL



TIMING CHART

WIRE COLOR	TIME ON (SECONDS)
BLUE	18 SECONDS
YELLOW	6 SEC. [Hatched]
WHITE/BLUE	[Hatched] 6 SEC.
VIOLET	[Hatched] 6 SEC.
GREEN	18 SECONDS

Figure 15-5E. Wing, Horizontal Stabilizer and Vertical Fin De-Ice System Timer Test (Sheet 2 of 2)

15-26W. PROPELLER ANTI-ICE BOOTS (KNOWN ICING EQUIPMENT). Aircraft certified for flight into known icing conditions must have propeller anti-ice boots installed and operational. Refer to paragraph 15-27 for this installation.

15-26X. WINDSHIELD ANTI-ICE PANEL (KNOWN ICING EQUIPMENT). Aircraft certified for flight into known icing conditions must have a windshield anti-ice panel installed and operational. Refer to paragraph 15-32D for this installation.

15-26Y. PITOT TUBE AND STALL WARNING HEATERS. (KNOWN ICING) (See figure 15-5B.)

15-26A. DESCRIPTION. A special pitot tube with a larger inlet and a higher capacity heating element and a higher capacity heated stall warning transducer are installed in the left wing on aircraft certified for flight into known icing conditions. These systems assure proper airspeed indications and stall warning in the event icing conditions are encountered. They are designed to prevent ice formation rather than remove it once formed. Thru 1982 models both systems are controlled by a rocker switch, labeled PITOT HEAT, on the left switch and control panel.

Beginning with 1983 models, separate switches, labeled PITOT HEAT and STALL HEAT, on the left switch and control panel operate the heaters. Two 10-amp "push-to-reset" type circuit breakers, labeled PITOT HEAT and STALL HEAT, on the left sidewall circuit breaker panel protect the systems. When the aircraft is on the ground, a resistor is introduced into the stall warning heater circuit by the nose wheel squat switch in order to prevent overheating.

15-26AA. REMOVAL AND INSTALLATION. (See Section 17.)

15-26AB. ICE DETECTOR LIGHT.

15-26C. DESCRIPTION. An ice detector light is flush-mounted on the left side of the cowl deck to facilitate the detection of wing ice at night or during reduced visibility by lighting the leading edge of the wing. Components of the system include the ice detector light, a two-position rocker-type switch, labeled DE-ICE LIGHT, on the left switch and a 5-amp "push-to-reset" type circuit breaker, labeled CABIN LIGHTS on the left sidewall circuit breaker panel. The rocker switch is spring-loaded to the

MODEL 210 & T210 SERIES SERVICE MANUAL

off (lower) position and must be held in the ON (upper) position to keep the ice detector light illuminated.

15-26AD. 95-AMP ALTERNATOR INSTALLATION. (thru 1982 Models) (See Section 17.)

15-26AE. DUAL 60-AMP ALTERNATOR INSTALLATION. (Beginning with 1983 Models.) To provide electrical system redundancy dual 60-amp alternators must be installed and fully operational on aircraft certified for flight into known icing conditions. See Section 17.

15-26AF. CONTROL SURFACE DISCHARGERS.

15-26AG. DESCRIPTION. Wick type static dischargers may be installed on the trailing edge surfaces of the ailerons, elevators and rudder of the aircraft. One type discharger is fabricated with the wick and base combined into an integral unit; in the other type, the wick is attached to the base by a threaded fitting, and may be replaced without removing the base from the aircraft. The installation of static dischargers reduces the build-up of static electricity on the airframe as a consequence of flying through haze, dust, rain, snow or ice crystals. In some cases, if dischargers are not installed or not functioning as a result of age or repeated exposure static electricity, static build-up can result in the loss of usable radio signals on all communication and navigation equipment. Whenever static dischargers are installed, replaced, and at regular intervals during their service life, resistance checks should be performed to determine their effectiveness in reducing static build-up.

15-26AH. RESISTANCE CHECK. Since static dischargers lose their effectiveness with age and exposure to static electricity, they should be checked with a 500 to 1000 volt capacity megohmmeter every 500 hours or annually; whichever occurs first. Megohmmeters may be purchased from the following source:

James G. Biddle Co.
Plymouth Meeting, PA 19462

NOTE

A GOOD aircraft ground must be established in order to perform RELIABLE resistance checks on the control surface dischargers.

Perform the following resistance checks on each control surface discharger and replace those which do not conform to the resistance requirements.

- a. If the wick and base of the discharger are an integral unit, the resistance from the base of the discharger to a good aircraft ground should check 2.5 milliohms maximum.
- b. If the wick can be separated from the base, the resistance from the base to a good aircraft ground should check 1.0 ohm maximum.
- c. Connect the EARTH terminal to the base of the discharger and check the resistance at the tip of the wick. The resistance should check 1 to 100 megohms for both types of dischargers.

WARNING

So not bend the wick during the preceding check, since wicks have a higher resistance when bent.

MODEL 210 & T210 SERIES SERVICE MANUAL

15-27. PROPELLER ANTI-ICE SYSTEM. The system is of an electrothermal type, consisting of electrically-heated de-ice boots bonded to each propeller blade, a slip ring assembly for power distribution to the propeller de-ice boots, a brush block assembly to transfer electrical power to the rotating slip ring, and a timer to cycle electrical power to the de-ice boots in proper sequence. A rocker switch labeled PROP A/ICE, located on the pilot's lower left-hand panel, controls the propeller de-ice system. A circuit breaker labeled PROP A/ICE, located in the left circuit breaker panel, protects the propeller de-ice system. A propeller de-ice ammeter, located on the upper left instrument panel, indicates amperage for the propeller de-ice system.

The de-ice system applies heat to the surfaces of the propeller blades where ice would normally adhere. This heat, plus centrifugal force and the blast from the airstream, removes accumulated ice. Each de-ice boot has two separate electrothermal heating ele-

ments, and inboard and an outboard section. Each boot has three leads extending from a tab at the bottom of the boot. Each electrical lead is identified by a letter. The letter "G" stands for ground. The letter "I" stands for inboard, and the letter "O" stand for outboard. When the PROP A/ICE switch is turned on, the timer provides power through the brush block and slip ring to the outboard element of the propeller for approximately 20 seconds \pm 1 second. The timer then switches power to the inboard element of the propeller for approximately 20 seconds \pm 1 second. The complete cycle is then repeated. This outboard-inboard sequence is very important since the loosened ice, through centrifugal force, moves outboard. Heating may begin at any phase in the cycle, depending on timer position when the switch was turned off from previous use. Ground checkout of the system is permitted with the engine not running. Propeller removal is necessary before propeller de-ice system components, except for the brush block assembly, timer, ammeter, circuit breaker and switch can be removed or installed.

15-27A. TROUBLE SHOOTING --- PROPELLER ANTI-ICE SYSTEM.

TROUBLE	PROBABLE CAUSE	REMEDY
ELEMENTS DO NOT HEAT.	Circuit breaker out or defective.	Reset circuit breaker. If it pops out again, determine cause and correct. Replace defective parts.
	Defective wiring.	Repair or replace wiring.
	Defective switch.	Replace switch.
	Defective timer.	Replace timer.

MODEL 210 & T210 SERIES SERVICE MANUAL

15-27A. TROUBLE SHOOTING --- PROPELLER DE-ICE SYSTEM (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
ELEMENTS DO NOT HEAT.	Defective brush-to-slip ring connection.	Check alignment. Replace defective parts.
SOME ELEMENTS DO NOT HEAT.	Incorrect wiring.	Correct wiring.
	Defective wiring.	Repair or replace wiring.
	Defective timer.	Replace timer.
	Defective brush-to-slip ring connection.	Check alignment. Replace defective parts.
	Defective element.	Replace element.
CYCLING SEQUENCE NOT CORRECT OR NO CYCLING.	Crossed connections.	Correct wiring.
	Defective timer.	Replace timer.
RAPID BRUSH WEAR, FREQUENT BREAKAGE, SCREECHING OR CHATTERING.	Brush block or slip ring out of alignment.	Align properly.

15-27B. SLIP RING REMOVAL. (See figure 15-6.)

WARNING

Be certain magneto is grounded before turning propeller.

- a. Remove spinner attaching screws (22) and remove spinner (12), spinner support (20) and spacers (21). Retain spacers (21).
- b. Remove engine cowling as required for access to propeller mounting nuts (24) and washers (23).
- c. Loosen all propeller mounting nuts (24) approximately 1/4-inch and pull propeller forward until stopped by mounting nuts (24).

NOTE

As propeller is separated from engine crankshaft flange, oil will drain from propeller and engine cavities.

CAUTION

Use caution when removing propeller. Removing propeller without the de-ice slip ring requires disconnecting nine wires at the spinner bulkhead, since the slip ring is mounted to the bulkhead. Wires should be identified according to wiring diagrams to facilitate reassembly. During removal, installation or other maintenance, use care to prevent damaging slip ring and brushes.

- d. Remove safety wire and loosen clamps (13).

- e. Remove nuts, washers, de-ice lead wires and slip ring lead wires from screws in aft spinner bulkhead (7). Tag lead wires to facilitate reinstallation.
- f. Remove all propeller mounting nuts (24) and washers (23) and pull propeller forward to remove from engine crankshaft (25).
- g. Remove slip ring (6).

15-27C. SLIP RING INSTALLATION. (See figure 15-6.)

- a. Install slip ring (6) and aft spinner bulkhead (7).
- b. Install de-ice boot lead wires and slip ring lead wires, screws, washers and nuts in aft spinner bulkhead (7).
- c. Install propeller and install washers (23) and propeller mounting nuts (24).
- d. Secure aft spinner bulkhead (7) to propeller with screws.
- e. Tighten propeller mounting nuts to a torque of 55 to 60 lb. ft.
- f. Tighten clamps (13) with clamp screw housings 180° apart to maintain balance. Safety wire clamp screw housings to clamps as shown in view B-B.
- g. Install spacer (21) and spinner support (20) in spinner (12) and install spinner on propeller.

15-28. SLIP RING ALIGNMENT CHECK. After installation, slip ring must be checked for run-out.


NOTE

Excessive slip ring run-out will result in severe arcing between slip ring and brushes, and cause rapid brush wear. If allowed to continue, this condition will result in rapid deterioration of slip ring and brush contact


MODEL 210 & T210 SERIES SERVICE MANUAL

● TORQUE NUTS TO 55-60 LB-FT.

SAFETY WIRE SCREWS AS SHOWN



1. Brush Block Assembly
2. Timer
3. Switch
4. Ammeter
5. Cable
6. Slip Ring
7. Spinner Bulkhead
8. Clip Assembly
9. Propeller
10. Boot
11. Restrainer Strap
12. Spinner
13. Clamp
14. Rubber Spacer
15. Cup
17. Spacer
18. Mounting Bracket
19. Support
20. Spinner Support
21. Spacer
22. Spinner Attaching Screw
23. Washer
24. Propeller Mounting Nut
25. Engine Crankshaft



B-B

Apply ice-repellant (MI-903) (Glidden Mfg. Co.) to leading edge surfaces, landing light covers and windshield to retard ice build-up.

Figure 15-6. Propeller Anti-Ice System (Sheet 1 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-6. Propeller Anti-Ice System (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-6. Propeller Anti-Ice System (Sheet 3 of 3)

surfaces, and lead to the eventual failure of the propeller de-icing system.

- a. Securely attach a dial indicator gage to the engine and place the pointer on the slip ring.
- b. Rotate the propeller slowly by hand, noting the deviation of the slip ring from a true plane as indicated on the gage.
- c. Check that the total run-out does not exceed 0.010 inch (± 0.005 inch), and that the total is not exceeded within any four inches of slip ring travel.

NOTE

Care must be taken to exert a uniform push or pull on the propeller to avoid a considerable error in the readings caused by loose

fitting thrust bearings.

- d. If slip ring run-out is within the limits specified, no corrective action is required. If the run-out is not within limits specified, the slip ring will have to be removed and returned to the claims department of Cessna Supply Division, and a new part ordered.

15-29. REMOVAL OF PROPELLER ANTI-ICE TIMER. (See figure 15-6.)

- a. Ensure that aircraft electrical power is off and PROP A/ICE circuit breaker is pulled.
- b. Gain access to left elevator control torque tube support (19), forward of left instrument panel.
- c. Remove screws, timer (2) and spacers (17) from nutplates.

MODEL 210 & T210 SERIES SERVICE MANUAL

15-29A. INSTALLATION OF PROPELLER ANTI-ICE TIMER. (See figure 15-6.)

- a. Install spacers (17), timer (2) and screws in nutplates in left elevator control torque tube support (19).
- b. Push in PROP A/ICE circuit breaker.

15-29B. PROPELLER ANTI-ICE SYSTEM AMMETER. (See figure 15-6.)

15-29C. DESCRIPTION. An ammeter is utilized in the propeller anti-ice system to visually monitor the amperage being applied to that system.

15-29D. REMOVAL. (See figure 15-6.)

- a. Ensure that aircraft electrical power is off and

PROP A/ICE circuit breaker is pulled.

- b. Gain access to forward side of instrument panel (right side thru 21062273; left side beginning with 21062274).
- c. Unscrew bezel (26) and remove along with O-ring (27).
- d. Remove body (29) forward out of instrument panel (28).

15-29E. INSTALLATION. (See figure 15-6.)

- a. Install body (29) aft through hole in instrument panel (28):
- b. Install O-ring (27) and screw bezel (26) on threads of body (29).
- c. Push in PROP A/ICE circuit breaker.

15-29F. TROUBLE SHOOTING -- PROPELLER ANTI-ICE SYSTEM AMMETER.

TROUBLE	PROBABLE CAUSE	REMEDY
AMMETER READING BELOW GREEN ARC.	Open anti-ice boot element.	Replace boot.
AMMETER READING ABOVE GREEN ARC.	Shorted anti-ice boot element.	Replace boot.
NO AMMETER READING. (Boots are heating)	Faulty ammeter shunt	Replace ammeter shunt.
	Open circuits in wiring to ammeter.	Repair wiring.
	Faulty ammeter.	Replace ammeter.
NO AMMETER READING. (Boots not heating)	Faulty system component.	Determine cause and correct.

15-30. TIMER TEST.

- a. Remove connector plug of wire harness from timer and jump power input socket of wire harness to timer

input pins. (Refer to chart following this step for pin identification.)

Timer P/N	Power Input Pin & Socket	Ground Pin	Output Sequence, Time, Voltage	Time Repeat Cycle Time (sec)
3E1540-1 C165020-0101	B (14VDC)	A (14VDC)	C, D 34 seconds each	74
	B (28VDC) (24-32)	G (28VDC)	C, D 20 seconds each	40

- b. Jump timer ground pin to ground.
- c. Turn on De-Icing System.
- d. Check timer operation per the chart preceding step "b." (Use a voltmeter.)
- e. Check volts to ground in each case. If engine is not running, and auxiliary power is not used, voltage will be battery voltage and cycle time may be slightly longer than indicated.
- f. Hold voltmeter probe on the pin until the voltage

drops to 0. Move the probe to the next pin in the sequence shown in the chart. Check voltage at each pin in sequence. When correctness of the cycling sequence is established, turn propeller De-Icing switch off at the beginning of one of the on-time periods, and record the letter of the pin at which the voltage supply is present.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-7. Brush Face Alignment and Projection and Angular Brush Alignment

NOTE

Timers do not home to pin "C" when turned off.

15-31. INSTALLATION AND ALIGNMENT OF BRUSH BLOCK ASSEMBLY. (Refer to figure 15-7.)

NOTE

Installation of the brush block should be deferred, when possible, until after the slip ring, propeller, and related components are installed. However, the brush block assembly may be replaced without removing the propeller. To avoid breakage when installing the brush block assembly, keep brushes retracted in brush block until slip ring and propeller assemblies have been installed.

CAUTION

Make sure that slip ring run-out has been corrected before attempting to align brushes on slip ring.

a. In order to get smooth, efficient and quiet transfer of electric power from the brushes to the slip ring, brush alignment must be checked and adjusted, if necessary to meet the following requirements.

1. Projection must be such that the distance between the brush block and the slip ring is $.06'' \pm .03''$.

2. The brushes must be lined up with the slip ring so that the entire face of each brush is in contact with the slip ring throughout the full 360° of slip ring rotation.

3. The brushes must contact the slip ring at an angle of approximately 2° from perpendicular to the slip ring surface, measured toward the direction of rotation of the slip ring.

b. Brush projection can normally be adjusted by loosening hardware attaching the brush block and holding the brushes in the desired location while re-tightening the hardware. Slotted holes are provided.

c. One method for face alignment is described in step "b". Another is to use shims between brush block and bracket. Laminated metal shims are generally provided. Layers of metal .003" are used to make up shims which are approximately 0.20" thick overall. Shims may be fabricated locally.

d. Loosen mounting bolts and twist block while tightening to attain proper angular adjustment.

CAUTION

Use care not to disturb other adjustments when adjusting angular alignment.

15-32. REPLACEMENT OF DE-ICE BOOTS. To remove or loosen installed de-ice boots, use toluol to soften the "cement line." Apply a minimum amount of this solvent to the cement line as tension is applied to peel back the boot. Removal should be slow enough to allow the solvent to undercut the cement so that parts will not be damaged. To install a propeller anti-ice boot, proceed as follows:

a. Clean the metal to be bonded with Methyl Ethyl Ketone, (MEK). For final cleaning, wipe the solvent film off quickly with a clean, dry cloth before it has time to dry.

b. Prepare a pattern the size of the boot, including three inches of the boot strap. Draw a centerline (lengthwise) through the pattern.

MODEL 210 & T210 SERIES SERVICE MANUAL

c. Draw a line on the centerline of the leading edge of the blade. Position the pattern centerline over the leading edge centerline. Position pattern so bottom of boot is 1/2" below spinner cutout. Draw a line on the propeller hub on each side of the pattern boot strap where it crosses the hub. Check boot strap position by fitting restraining strap on the hub and comparing its position with the marked position of the strap.

d. Mask off an area 1/2" from each side and outer end of the pattern, and remove the pattern.

e. Mix EC-1300L cement (Minnesota Mining & Mfg. Co.) thoroughly. Surfaces shall be above 60° F (15° Centigrade) prior to applying cement. During periods of high humidity, care shall be taken to prevent moisture condensation due to the cooling effect of the evaporating solvent. This can be done by warming the area with a heat gun or heat lamp. Apply one even brush coat of EC-1300L cement to the cleaned metal surface. Allow to air dry for a minimum of one hour, then apply a second even brush coat of EC-1300L cement.

f. Moisten a clean cloth with Methyl Ethyl Ketone and clean the unglazed back surface of the boot, changing cloths frequently to avoid contamination of the cleaned area.

g. Apply one even coat of EC-1300L cement to back surface of boot. It is not necessary to cement more than 1/2" of the boot strap.

h. Using a silver-colored pencil, mark a centerline along the leading edge of the propeller blade and a corresponding centerline on the cemented side of the boot.

i. Reactivate the surface of the cement using a clean, link-free cloth, heavily moistened with toluol. Avoid excessive rubbing of cement, which would remove the cement.

j. Position the boot centerline on the propeller leading edge, starting at the hub end at the position marked. Make sure that boot strap will fall in the position marked. Tack the boot centerline to the leading edge of the propeller blade. If the boot is allowed to get off-center, pull up with a quick motion and replace properly. Roll firmly along centerline with a rubber roller.

k. Gradually tilting the roller, work the boot carefully over either side of the blade contour to avoid trapping air in pockets.

l. Roll outwardly from the centerline to the edges. If excess material at the edges tends to form wrinkles, work them out smoothly and carefully with fingers.

m. Apply one even coat of EC-539 (Minnesota Mining & Mfg. Co.), mixed per manufacturer's instructions, around the edges of the installed boot.

n. Remove masking tape from the propeller and clean the surface of the propeller by wiping with a clean cloth dampened with toluol.

o. Place restraining strap in position and secure with screws, washers and sleeves.

15-32A. WINDSHIELD ANTI-ICE PANEL (REMOVABLE.) (See figure 15-7B.)

15-32B. DESCRIPTION. Thru 1977 models, the panel is constructed of two sheets of plate glass covering a layer of vinyl. Imbedded in the vinyl is a fine resis-

tance wire which provides the heat for windshield de-icing. The lower edge of the panel is mounted on the deck skin just forward of the windshield. The upper end of the panel is supported by a rubber bumper which holds the panel off the windshield. The lower mounting bracket is hinged for easy cleaning between the panel and windshield. The hinge pins are spring loaded so the panel may be easily removed. Power to the windshield panel is provided through a plug located in a housing assembly just left of the lower support bracket. A drain tube is provided for the housing assembly also a plug button is provided, which is painted the same color as the deck skin, to plug connector hole in the deck skin when the anti-ice assembly is removed. A circuit breaker switch located on the instrument panel is a off-on switch and a circuit breaker to protect the system. Beginning with 1978 models the panel extends the full height of the windshield. The upper and lower ends of the panel are held in place by retainers and screws. The system is controlled by a rocker switch on the instrument panel which connects power to the controller from a 15 amp circuit breaker on the bus bar. The controller is mounted on the glove box. Power is also fed from the circuit breaker to a normally open relay, also mounted on the glove box. The controller senses the temperature of the panel and closes which feeds power to the relay coil, closing the relay and power is fed to the panel. When not in use the panel may be removed and stowed in the aircraft.

15-32C. REMOVABLE AND INSTALLATION. (See figure 15-7B.) Beginning with 1978 Models, when the panel is removed and stowed, replace the AN 509-8R16 screws with AN509-8R12 screws. Also, replace cover (8) with cover (11) (Figure 15-7B, sheet 3.)

15-32D. HEATED WINDSHIELD PANEL (FIXED.)

15-32E. DESCRIPTION. An optional heated panel is provided to prevent ice formation on the windshield. The system consists of an electrically heated panel attached to the windshield, a controller and a relay mounted on the glove box. The system is controlled by a rocker type switch on the pilot's switch panel. A circuit breaker on the circuit breaker panel protects the system.

15-32F. REMOVAL AND INSTALLATION. (See figure 15-7B, sheet 3.)

a. Panel Removal.

1. Ensure aircraft electrical power is "OFF".
2. Disconnect housing plug and cap, located forward of instrument panel on the left hand side.
3. Remove screws securing cover and gasket to deck skin, then pull housing plug up through skin.
4. Remove screws from retainers at top and bottom of heated panel.
5. Remove heated panel, retainers and shims at top and bottom of panel.
6. Remove any sealer that may have parted sticking to the windshield. A sharpened (Wood) spatula may be used, exercising care.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-7B. Windshield Anti-Ice Panel Installation (Sheet 1 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-7B. Windshield Anti-Ice Panel Installation (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-7B. Windshield Anti-Ice Panel Installation (Sheet 3 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

Do Not use any tool, abrasive or cleaner which may damage the windshield.

b. Panel Installation.

1. Apply a strip of masking tape on the LH windshield, from top to bottom with outboard edge of tape located 6.60 inches to the left and parallel with the windshield centerline, as viewed looking forward.

2. Apply a strip of masking tape at the bottom of heated panel location with edge running parallel with, and .55 inch below the center of the three open fastener locations. However, this dimension may vary as lower edge of heated panel may be trimmed to match aircraft contours. A minimum of .35 inch edge margin must be maintained.

3. Locate heated panel with lower end and inboard side against edge of masking tape. Using a hole finder, locate and mark the three hole locations at the lower end of the panel.

4. Drill three .172 holes on the lower end of the panel where marked.

5. Place lower spacer in position and temporarily secure the lower end of heated panel with three screws.

6. Press the heated panel to the windshield contour working up from the bottom so that panel seal is compressed against windshield, firmly tape heated panel to the windshield.

NOTE

The inner and outer lip of the heated panel seal should be in positive contact with the surface of the windshield over the full periphery of the panel. It is permissible to vary thickness of the spacers to facilitate proper sealing.

7. Using a hole finder, mark the center hole location at the upper end of panel.

NOTE

Before drilling three .172 diameter holes in the upper end of panel, place a metal shield between the panel and windshield of aircraft to protect the windshield from damage.

8. Locate and drill one (.172) diameter hole 0.10 inch down from the mark on the heated panel.

9. Remove drilling shield.

10. Use an ice pick to align hole in heated panel with open hole in windshield retainer, and pull panel up to align holes.

NOTE

Take precaution to prevent damage to windshield and/or doubler nutplates when tightening heated panel on windshield.

11. Using a hole finder, mark the remaining two holes at the upper end of the panel.

12. Place the drilling shield between heated panel and windshield retainer and drill (.172) holes at the marked locations.

13. Place the upper spacer in position between heated panel and windshield and temporarily secure using three screws.

14. Check the temporary installation to ensure that heated panel is in proper relation to the windshield. Check to see if panel seal is in contact with windshield.

15. Remove the masking tape applied to windshield for locating heated panel. Apply new strips of masking tape on each side of the panel with edge aligned with and against outer lip of seal to facilitate final installation. Also apply strips of tape at upper and lower edge of heated panel.

16. Remove heated panel and deburr all parts.

17. Remove protective cover from the heated panel. Do not remove masking tape aligning guides. Clean thoroughly with a soft cloth or sponge. Wash with a mild soap and water, a 50/50 solution of isopropanol and water, or aliphatic naphtha type 2. Do not use any abrasive materials, strong acid or base, methanol or methyl-ethyl-ketone. After cleaning, rinse thoroughly and dry.

18. After cleaning, plastic surfaces may be polished by applying a thin coat of hard polishing wax. Rub lightly with a soft cloth using a circular motion.

19. Apply a bead of RTV108 sealer to the groove of heated panel.

NOTE

Do not allow the RTV108 sealer to be pressed out of the seal upon installation. If this happens, remove heated panel, wipe the sealer off the windshield and the seal on the heated panel with isopropyl alcohol. Reapply RTV108 sealer in groove, correcting the amount of bead, and reinstall the heated panel.

20. Install heated panel on windshield exercising care to prevent smearing of sealer.

21. Ensure proper location of spacers at upper and lower ends of heated panel. (See note after step 5).

22. Install screws at top and bottom of heated panel.

23. Route heated panel electrical leads through the deck skin and gaskets then connect.

24. Install cover and apply a strip of tape around opening to keep sealer off of deck skin. Apply RTV108 sealer, potting wire bundle in cover.

NOTE

Allow 24 hours for full cure of RTV108 sealer.

25. Remove all tape around heated panel and lead cover.

26. Operational check the heated panel as follows:
a. Turn windshield de-ice switch momentarily ON, check ammeter for discharge.

15-32G. TRAPPED MOISTURE. To eliminate moisture trapped between the heated windshield panel and

MODEL 210 & T210 SERIES SERVICE MANUAL

the windshield, proceed as follows:

- a. Fabricate two probes from .125 diameter tube approximately three inches long. Cut one end of tubes off at approximately a 30° or less angle. File to a sharp edge.
- b. Insert one tube through the upper outboard corner of the heated panel and the other through the lower inboard corner. Move lower tube to the outboard corner as required to release all trapped water. Insert tubes through the rubber seal.
- c. Connect upper tube to a source of low pressure dry air, or bottled nitrogen. Flow air between the heated panel and windshield until all visible moisture is gone. Activate heated panel for short periods to accelerate removal of moisture.
- d. Apply soap and water mixture to edges of the heated panel. Restrict exit air, noting and marking leakage from under panel. Do not overpressure; use no more than 2.0 psi.
- e. Clean windshield and edge of heated panel with mild soap and water and a 50/50 solution of isopropyl alcohol and water. Wipe dry and apply masking tape along leak area approximately .06-inch from seal. Lift edge of seal and insert RTV. Fill gap at upper and lower ends of heated panel between panel seat and windshield retainer with RTV if leak is in this area. Remove tubes from windshield; fill holes with RTV and remove masking tape. Use clear RTV-108 only.

15-33. OXYGEN SYSTEM. (See figure 15-8.)

WARNING

Under No circumstances, turn the ON-OFF control to the "ON" position with the outlet (low pressure) ports open to atmosphere. This action will induce serious damage to the regulator, with the following results:

1. Loss of outlet set pressure.
2. Loss of oxygen flow through the regulator which will result in inadequate oxygen being fed through the aircraft system.
3. Internal leakage of oxygen through regulator.

Opening of the control lever with the outlet ports open to atmosphere, results in an "overshoot" of the regulator metering device due to the extreme flow demand through the regulator. After overshooting, the metering poppet device goes into oscillation, creating serious damage to the poppet seat and diaphragm metering probe. This condition can occur even by turning the control lever on and then turning it quickly off.

A potential hazard exists to aircraft in the field where inexperienced personnel might remove the cylinder and regulator assembly from the aircraft and for some reason, attempt to turn the regulator to the "ON" position with the outlet ports open. Unfortunately, after the units have been improperly operated as noted, there is no outward appearance indicating that damage has occurred.

Testing these regulators should be accomplished only after installation in the aircraft, with the "downstream" low pressure line attached.

15-34. DESCRIPTION. The system is comprised of four oxygen cylinders, mounted in the cabin top area, in front of and behind the main carry-thru spar. Of the four cylinders, only one is a cylinder-regulator assembly. Remaining components of the system include a filler valve, located in the lower inboard surface of the right wing, cabin outlets, mask assemblies, and a pressure gage at the pilot's position. The pilot's supply line is designed to receive a greater flow of oxygen than the passengers. The pilot's

MODEL 210 & T210 SERIES SERVICE MANUAL

mask is equipped with a microphone, keyed by a switch button on the pilot's control wheel. An ON-OFF control is provided at the pilot's position.

WARNING

Oil, grease or other lubricants in contact with high-pressure oxygen, create a serious fire hazard and such contact should be avoided. Do not permit smoking or open flame in or near aircraft while work is performed on oxygen systems.

15-35. MAINTENANCE PRECAUTIONS.

- a. Working area, tools and hands must be clean.
- b. Keep oil, grease, water, dirt, dust and all other foreign matter from system.
- c. Keep all lines dry and capped until installed.
- d. Use only MIL-T-5542 thread compound or teflon lubricating tape on threads of oxygen valves, tubing connectors, fittings, parts of assemblies which might under any conditions, come in contact with oxygen. The thread compound must be applied sparingly and carefully to only the first three threads of the male fitting. No compound shall be used on aluminum flared fittings or on the coupling sleeves or on the outside of the tube flares. The teflon tape shall be used in accordance with the instructions listed following this step, Extreme care must be exercised to prevent the contamination of the thread compound or teflon tape with oil, grease or other lubricant.
 1. Place tape on threads close to end of fitting. Wrap clockwise on RH threads, counterclockwise on LH threads.
 2. Apply enough tension while winding so tape forms into thread grooves.
 3. After wrap is complete, maintain tension and tear tape by pulling apart in direction it was applied. Resulting ragged end is the key to the tape staying in place. (If sheared or cut, tape may unwind.)
 4. Press tape well into threads.
 5. Make connections.
- e. Fabrication of oxygen pressure lines is not recommended. Lines should be replaced by part numbers called out in the aircraft Parts Catalog.
- f. Lines and fittings must be clean and dry. One of the following methods may be used.
 1. Clean by degreasing with stabilized trichlorethylene, conforming to Federal Specifications O-T-634 or MIL-T-27602. These items can be obtained from American Mineral Spirits of Houston, Texas.

NOTE

Most air compressors are oil lubricated, and a minute amount of oil may be carried by the airstream. If only an oil lubricated air compressor is available, drying must be accomplished by heating at a temperature of 250° to 300°F (121° to 149°C) for a suitable period.

2. Flush with naphtha, conforming to Specification TT-N-95 (aliphatic naphtha). Blow clean and dry off all solvents with clean, dry, oil-free, filtered air. Flush with anti-icing fluid conforming to Specification TT-T-735 or anhydrous ethyl alcohol. Rinse thoroughly with fresh water. Dry thoroughly with a stream of clean, dry, oil-free, filtered air.

3. Flush with hot inhibited alkaline cleaner until free from oil and grease. Rinse with fresh water and dry with clean, dry, filtered air.

NOTE

Cap lines at both ends immediately after drying to prevent contamination.

15-36. REPLACEMENT OF COMPONENTS. Removal, disassembly, assembly and installation of system components may be accomplished while using figure 15-8 as a guide.

CAUTION

Oxygen cylinders and regulators are furnished as assemblies by Cessna Parts Distribution (CPD 2). Attempting to remove, repair, and reinstall oxygen regulators in the field provides opportunity for contaminants to enter the system. Faulty regulators or regulators otherwise in need of disassembly should be exchanged for replacement oxygen bottle and regulator assemblies through CPD 2. Regulator and cylinder assembly shall be disassembled, repaired, inspected, cleaned, hydrostatically tested, reassembled, and serviced by manufacturer or other FAA-approved facility.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-8. Oxygen System

CAUTION

The pressure regulator, pressure gage and line and filler valve should be removed and

replaced only by personnel familiar with high-pressure fittings. Observe the maintenance precautions listed in the preceding paragraph.

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

Oxygen cylinder and regulator assemblies may not always be installed in the field exactly as illustrated in figure 15-8, which shows factory installation. Important points to remember are as follows.

a. Before removing cylinder, release low-pressure line by opening cabin outlets. Disconnect push-pull control cable, filler line, pressure gage line and outlet line from regulator. **CAP ALL LINES IMMEDIATELY.**

b. If it is necessary to replace filler valve O-rings, remove parts necessary for access to filler valve. Remove line from quick-disconnect valve at the regulator, then disconnect chain, but do not remove cap from filler valve. Remove screws securing valve and disconnect pressure line. Referring to applicable figure, cap pressure line and seat. Disassemble valve, replace O-rings and reassemble valve. Install filler valve by reversing procedures outlined in this step.

c. To remove entire oxygen system, headliner must be lowered and soundproofing removed to expose lines. Refer to Section 3 for headliner removal.

15-37. OXYGEN CYLINDER GENERAL INFORMATION. The following information is permanently steel stamped on the shoulder, top head or neck of each oxygen cylinder:

a. Cylinder specification, followed by service pressure (e. g. "ICC-3AA1800" and "ICC-3HT1850" for standard and light weight cylinders respectively).

NOTE

Effective 1 January 1970, all newly-manufactured cylinders are stamped "DOT" (Department of Transportation), rather than "ICC" (Interstate Commerce Commission). An example of the new designation would be: "DOT-3HT1850".

b. Cylinder serial number is stamped below or directly following cylinder specification. The symbol of the purchaser, user or maker, if registered with the Bureau of Explosives, may be located directly below or following the serial number. The cylinder serial number may be stamped in an alternate location on the cylinder top head.

c. Inspector's official mark near serial number.

d. Date of manufacture: This is the date of the first hydrostatic test (such as 4-69 for April 1969). The dash between the month and the year figures may be replaced with the mark of the testing or inspection agency (e. g. 4L69).

e. Hydrostatic test date: The dates of subsequent hydrostatic tests shall be steel stamped (month and year) directly below the original manufacture date. The dash between the month and year figures can be replaced with the mark of the testing agency.

f. A Cessna identification placard is located near the center of the cylinder body.

g. Halogen test stamp: "Halogen Tested", date of test (month, day and year) and inspector's mark

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-9. Aft Oxygen System

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-10. Emergency Oxygen System (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 15-10. Emergency Oxygen System (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

appears directly underneath the Cessna identification placard.

15-38. OXYGEN CYLINDER SERVICE REQUIREMENTS.

- a. Hydrostatic test requirements:
 1. Standard weight (ICC or DOT-3AA1800) cylinders must be hydrostatically tested to 5/3 their working pressure every five years commencing with the date of the last hydrostatic test.
 2. Light weight (ICC or DOT-3HT1850) cylinders must be hydrostatically tested to 5/3 their working pressure every three years commencing with the date of the last hydrostatic test.
- b. Service life requirements:
 1. Standard weight (ICC or DOT-3AA1800) cylinders have no age life limitations and may continue to be used until they fail hydrostatic test.
 2. Light weight (ICC or DOT-3HT 1850) cylinders must be retired from service after 24 years or 4,380 filling cycles after date of manufacture, whichever occurs first. If a cylinder is recharged more than an average of once every other day, an accurate record of the number of rechargings must be maintained. Refer to paragraph 15-39 for determining service life of DOT-3HT1850 cylinders.

NOTE

These test periods and life limitations are established by the Department of Transportation Code of Federal Regulations; Title 49, Chapter 1, Para. 73.34.

15-39. OXYGEN CYLINDER INSPECTION REQUIREMENTS.

- a. Inspect the entire exterior surface of the cylinder for indication of abuse, dents, bulges and strap chafing.
- b. Examine the neck of cylinder for cracks, distortion or damaged threads.
- c. Check the cylinders to determine if markings are legible.
- d. Check date of last hydrostatic test. If the periodic retest date is past, do not return the cylinder to service until the test has been accomplished.
- e. Inspect the cylinder mounting bracket, bracket hold-down bolts and cylinder holding straps for cracks, deformation, cleanliness, and security of attachment.
- f. In the immediate area where the cylinder is stored or secured, check for evidence of any types of interference, chafing, deformation or deterioration.
- g. A cylinder manufactured prior to January 17, 1978, and not yet marked with a rejection elastic expansion (REE), must be marked with that REE in cubic centimeters near the marked original elastic expansion prior to the next retest date. The REE for a cylinder is 1.05 times its original elastic expansion.
- h. Some cylinders manufactured to DOT special permit 5957 in the past, were incorrectly marked with "DOT 3HT" in addition to "SP5957". Cylinders made under SP5957 are not DOT3HT cylinders, and the service life extension from 15 years to 24 years, effective

January 17, 1978, does not apply to SP5957 cylinders, even if these cylinders are marked as 3HT cylinders. Such cylinders can be identified by the marking "SP5957", which will appear on the shoulder of the cylinder. Any cylinder so marked, regardless of any other markings that may also appear, is not a DOT 3HT cylinder, and the service life extension from 15 years to 24 years does not apply.

15-40. OXYGEN SYSTEM COMPONENT SERVICE REQUIREMENTS.

- a. PRESSURE REGULATOR. The regulator shall be removed and overhauled by manufacturer or an FAA approved facility during hydrostatic testing.

CAUTION

Oxygen cylinders and regulators are furnished as assemblies by Cessna Parts Distribution (CPD 2). Attempting to remove, repair, and reinstall oxygen regulators in the field provides opportunity for contaminants to enter the system. Faulty regulators or regulators otherwise in need of disassembly should be exchanged for replacement oxygen bottle and regulator assemblies through CPD 2. Regulator and cylinder assembly shall be disassembled, repaired, inspected, cleaned, hydrostatically tested, reassembled, and serviced by manufacturer or other FAA-approved facility.

- b. FILLER VALVE. The valve should be disassembled, inspected and the O-rings replaced, regardless of condition, every 3 years or 3000 flight hours, whichever occurs first.
- c. QUICK-RELEASE COUPLING. The coupling shall be functionally tested every two years and overhauled every five years or at time of hydrostatic test.
- d. PRESSURE GAGE. The gage shall be replaced when found to be faulty. No re-conditioning or overhaul of the gage is authorized.
- e. INDIVIDUAL OUTLETS. The outlets shall be disassembled and inspected and the O-rings replaced, regardless of condition, every 3 years or 3000 flight hours, whichever occurs first.

15-41. OXYGEN SYSTEM COMPONENT INSPECTION REQUIREMENTS.

- a. Examine all parts for cracks, nicks, damaged threads or other apparent damage.
- b. Actuate regulator controls and valve to check for ease of operation.
- c. Determine if the gage is functioning properly by observing the pressure buildup and the return to zero when the system oxygen is bled off.
- d. Replace any oxygen line that is chafed, rusted, corroded, dented, cracked or kinked.
- e. Check fittings for corrosion around the threaded area where lines are joined together. Pressurize the system and check for leaks.

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

Each interconnected series of oxygen cylinders is equipped with a single gage. The trailer type cascade may also be equipped with a nitrogen cylinder (shown reversed) for filling landing gear struts, accumulators, etc. Cylinders are not available for direct purchase, but are usually leased and refilled by a local compressed gas supplier.

Service Kit SK310-32 (available from Cessna Parts Distribution [CPD 2] through Cessna Service Stations) contains an adapter, pressure gage, and hose, and lines and fittings for equipping two oxygen cylinders to service oxygen systems. As noted in the Service Kit, a tee (Part No. 11844) and a pigtail (Part No. 1243-2) should be ordered for each additional cylinder to be used in the cascade of cylinders. Be sure to ground the airplane and ground servicing equipment before use.




Figure 15-11. Typical Portable Oxygen Cascades

15-42. MASKS AND HOSE.

a. Check oxygen masks for fabric cracks and rough face seals. If the mask is a full-faced model, inspect glass or plastic for cleanliness and state of repair.

b. Flex the mask hose gently over its entirety and check for evidence of deterioration or dirt.

c. Examine mask and hose storage compartment for cleanliness and general condition.

15-43. MAINTENANCE AND CLEANING.

a. Clean and disinfect mask assemblies after use, as appropriate.

NOTE

Use care to avoid damaging microphone assembly while cleaning and sterilizing.

b. Wash mask with a mild soap solution and rinse it with clear water.

c. To sterilize, swab mask thoroughly with a gauze or sponge soaked in a water/merthiolate solution. This solution should contain 1/5 teaspoon of merthiolate per one quart of water. Wipe the mask with a clean cloth and let air dry.

d. Observe that each mask breathing tube end is free of nicks and that the tube end will slip into the cabin oxygen receptacle with ease and will not leak.

e. If a mask assembly is defective (leaks, does not allow breathing or contains a defective microphone) it is advisable to return the mask assembly to the manufacturer or a repair station.

f. Replace hose if it shows evidence of deterioration.

g. Hose may be cleaned in the same manner as the mask.

15-44. SYSTEM PURGING. Whenever components have been removed and reinstalled or replaced, it is advisable to purge the system. Charge oxygen system in accordance with procedures outlined in paragraph 15-47. Plug masks into all outlets and turn the pilot's control to ON position and purge system by allowing oxygen to flow for at least 10 minutes. Smell oxygen flowing from outlets and continue to purge until system is odorless. Refill cylinders as required during and after purging.

15-45. FUNCTIONAL TESTING. Whenever the regulator and cylinder assembly has been replaced or overhauled, perform the following flow and internal leakage tests to check that the system functions properly.

a. Fully charge oxygen system in accordance with procedures outlined in paragraph 15-47.

b. Disconnect line and fitting assembly from pilot's mask and line assembly. Insert outlet end of line and fitting assembly into cabin outlet and attach opposite end of line to a pressure gage (gage should be calibrated in one-pound increments from 0 to 100 PSI). Place control lever in ON position. Gage pressure should read 70±10 PSI.

c. Insert mask and line assemblies into all remaining cabin outlets. With oxygen flowing from all outlets, test gage pressure should still be 70±10 PSI.

MODEL 210 & T210 SERIES SERVICE MANUAL

d. Place oxygen control lever in OFF position and allow test gage pressure to fall to 0 PSI. Remove all adapter assemblies except the one with the pressure gage. The pressure must not rise above 0 PSI when observed for one minute. Remove pressure gage and adapter from oxygen outlet.

NOTE

If pressures specified in the foregoing procedures are not obtained, the oxygen regulator is not operating properly. Remove and replace cylinder-regulator assembly with another unit and repeat test procedure.

e. Connect mask and line assemblies to each cabin outlet and check each mask for proper operation.

f. Check pilot's mask microphone and control wheel switch for proper operation. After checking, return all masks to mask case.

g. Recharge oxygen system in accordance with procedures outlined in paragraph 15-47.

15-46. SYSTEM LEAK TEST. When oxygen is being lost from a system through leakage, a sequence of steps may be necessary to locate the opening. Leakage may often be detected by listening for the distinct hissing of escaping gas. If this check proves negative, it will be necessary to soap-test all lines and connections with a castile soap and water solution or specially compounded leak-test material. Make the solution thick enough to adhere to the contours of the fittings. At the completion of the leakage test, remove all traces of the leak detector or soap and water solution.

CAUTION

Do not attempt to tighten any connections while the system is charged.

15-47. SYSTEM CHARGING.

WARNING

BE SURE TO GROUND AIRCRAFT AND GROUND SERVICING EQUIPMENT BEFORE CHARGING OXYGEN SYSTEM.

a. Do not attempt to charge oxygen cylinders if servicing equipment fittings or filler valve are corroded or contaminated. If in doubt, clean with stabilized trichlorethylene and let air dry. Do not allow solvent to enter any internal parts.

b. If cylinder is completely empty, do not charge, as the cylinder must then be removed, inspected and cleaned.

CAUTION

A cylinder which is completely empty may well be contaminated. The regulator and cylinder assembly must then be disassembled, inspected and cleaned by an FAA approved facility, before filling. Contamination, as used here, means dirt, dust or any other foreign material, as well as ordinary air in large quantities. If a gage line or filler line is disconnected and the fittings capped immediately, the cylinder will not become contaminated unless temperature variation has created a suction within the cylinder. Ordinary air contains water vapor which could condense and freeze. Since there are very small orifices in the system, it is very important that this condition not be allowed to occur.

c. Connect cylinder valve outlet or outside filler valve to manifold or portable oxygen cascade.

d. Slowly open valve on cascade cylinder or manifold with lowest pressure, as noted on pressure gage, allow pressure to equalize, then close cascade cylinder valve.

e. Repeat this procedure, using a progressively higher pressure cascade cylinder, until system has been charged to the pressure indicated in the chart immediately following step "f" of this paragraph.

f. Ambient temperature listed in the chart is the air temperature in the area where the system is to be charged. Filling pressure refers to the pressure to which aircraft cylinders should be filled. This table gives approximations only and assumes a rise in temperature of approximately 25°F. due to heat of compression. This table also assumes the aircraft cylinders will be filled as quickly as possible and that they will only be cooled by ambient air; no water bath or other means of cooling be used.

Example: If ambient temperature is 70°F., fill aircraft cylinders to approximately 1,975 psi or as close to this pressure as the gage may read. Upon cooling, cylinders should have approximately 1,850 psi pressure.

TABLE OF FILLING PRESSURES

Ambient Temp. °F	Filling Press. psig	Ambient Temp. °F	Filling Press. psig
0	1650	70	1975
10	1700	80	2000
20	1725	90	2050
30	1775	100	2100
40	1825	110	2150
50	1875	120	2200
60	1925	130	2250

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 16

INSTRUMENTS AND INSTRUMENT SYSTEMS

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
INSTRUMENTS AND INSTRUMENT SYSTEMS		Cylinder Head Temperature Gage	
General	2K1/16-1	Description	2K22/16-18
Instrument Panel	2K7/16-3	Trouble Shooting	2K22/16-18
Description	2K7/16-3	Oil Pressure Gage	2K23/16-19
Removal and Installation	2K7/16-3	Description	2K23/16-19
Shock-Mounts	2K7/16-3	Trouble Shooting	2K23/16-19
Instruments	2K7/16-3	Oil Temperature Gage	2K24/16-20
Removal	2K7/16-3	Description	2K24/16-20
Installation	2K7/16-3	Fuel Quantity Indicating System (Thru 21062273)	2K24/16-20
Pitot and Static Systems	2K7/16-3	Indicators	2K24/16-20
Description	2K7/16-3	Sending Units	2K24/16-20
Maintenance	2K7/16-3	Control Monitor	2K24/16-20
Static Pressure System		Removal and Installation	2K24/16-20
Inspection and Leakage Test	2K10/16-6	Calibration	2K24/16-20
Pitot System Inspection and Leakage Test	2K10/16-6	Trouble Shooting	2K24/16-20
Blowing Out Lines	2K10/16-6	Fuel Quantity Indicating System (Beginning with 21062274)	2L1/16-21
Removal and Installation of Components	2K11/16-7	Description	2L1/16-21
Trouble Shooting - Pitot-Static System	2K11/16-7	Trouble Shooting	2L1/16-21
True Airspeed Indicator	2K11/16-7	Removal and Installation	2L2/16-22
Trouble Shooting	2K11/16-7	Transmitter Calibration	2L2/16-22
Trouble Shooting - Altimeter	2K13/16-9	Stewart Warner Gage	
Trouble Shooting - Vertical Speed Indicator	2K13/16-9	Transmitter Calibration	2L2/16-22
Trouble Shooting - Pitot Tube Heater	2K14/16-10	Rochester Gage	
Vacuum System	2K14/16-10	Transmitter	2L2/16-22
Description	2K14/16-10	Hourmeter	2L5/16-23
Trouble Shooting - Vacuum System	2K14/16-10	Description	2L5/16-23
Trouble Shooting - Gyros	2K15/16-11	Economy Mixture Indicator	2L5/16-23
Trouble Shooting - Vacuum Pump	2K16/16-12	Description	2L5/16-23
Maintenance Practices	2K16/16-12	Trouble Shooting	2L5/16-23
Removal of Vacuum Pump	2K16/16-12	Calibration	2L5/16-23
Mounting Pad Inspection	2K16/16-12	Removal and Installation	2L6/16-24
Installation of Vacuum Pump	2K16/16-12	Magnetic Compass	2L6/16-24
Cleaning	2K19/16-15	Description	2L6/16-24
Low-Vacuum Warning Light	2K19/16-15	Stall Warning Horn	2L6/16-24
Vacuum Relief Valve		Description	2L6/16-24
Adjustment	2K20/16-16	Turn Coordinator	2L6/16-24
Engine Indicators	2K20/16-16	Description	2L6/16-24
Tachometer	2K20/16-16	Trouble Shooting	2L6/16-24
Description	2K20/16-16	Turn and Slip Indicator	2L8/16-26
Manifold Pressure/Fuel Flow Indicator	2K20/16-16	Description	2L8/16-26
Description	2K20/16-16	Trouble Shooting	2L8/16-26
Trouble Shooting - Manifold Pressure Indicator	2K21/16-17	Electric Clock	2L9/16-27
Trouble Shooting - Fuel Flow Indicator	2K22/16-18	Description	2L9/16-27
		Fuel Computer/Digital Clock	2L9/16-27
		Description	2L9/16-27
		Fuel Computer Operation	2L9/16-27
		Digital Clock Operation	2L11/16-29
		Trouble Shooting	2L11/16-29
		Fuel Flow Transducer	2L12/16-30
		Installation	2L12/16-30
		Removal and Replacement	2L13/16-31
		Calibration	2L14/16-32

16-1. INSTRUMENTS AND INSTRUMENT SYSTEMS.

16-2. GENERAL. This section describes typical instrument installations and their respective operating systems. Emphasis is placed on trouble shooting and corrective measures only. It does NOT deal with specific instrument repairs since this usually requires special equipment and data and should be handled by instrument specialists. Federal Aviation Regulations

require malfunctioning instruments be sent to an approved instrument overhaul and repair station or returned to manufacturer for servicing. Our concern here is with preventive maintenance on various instrument systems and correction of system faults which result in instrument malfunctions. The descriptive material, maintenance and trouble shooting information in this section is intended to help the mechanic

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 16-1. Instrument Panel (Typical)

MODEL 210 & T210 SERIES SERVICE MANUAL

determine malfunctions and correct them, up to the defective instrument itself, at which point an instrument technician should be called in. Some instruments, such as fuel quantity and oil pressure gages, are so simple and inexpensive, repairs usually will be more costly than a new instrument. On the other hand, aneroid and gyro instruments usually are well worth repairing. The words "replace instrument" in the text, therefore, should be taken only in the sense of physical replacement in the aircraft. Whether replacement is to be with a new instrument, an exchange one, or the original instrument is to be repaired must be decided on basis of individual circumstances.

16-3. INSTRUMENT PANEL. (Refer to figure 16-1.)

16-4. DESCRIPTION. The instrument panel assembly consists of a stationary panel, a removable flight instrument panel and a shock-mounted panel. The stationary panel, containing fuel and engine instruments is secured to the engine mount stringers and a forward fuselage bulkhead. The removable panel, containing flight instruments such as airspeed, vertical speed and altimeter is secured to the stationary panel with screws. The shock-mounted panel, containing major flight instruments such as the horizontal and directional gyros is secured to the removable panel with rubber shock-mounted assemblies. Most of the instruments are screw mounted on the panel backs.

16-5. REMOVAL AND INSTALLATION.

a. FLIGHT INSTRUMENT PANEL.

1. Unscrew threaded buttons holding decorative cover.
2. Pull decorative cover back and disconnect post light wires, if installed, and remove decorative cover.
3. Tag and disconnect plumbing and wiring.
4. Remove screws securing flight instrument panel to stationary panel and pull panel straight back.
5. Reverse preceding steps for reinstallation.

b. SHOCK-MOUNTED PANEL.

NOTE

Due to the difficulty encountered when removing the shock-mounted panel with the gyros installed, it is recommended that the directional gyro be disconnected and removed prior to removal of the shock-mounted panel.

1. Complete steps 1 and 2 above.
2. Tag and disconnect gyro plumbing.
3. Remove directional gyro mounting screws and remove gyro from shock-mounted panel.
4. Remove shock-mount nuts and work shock-mounted panel out from behind flight instrument panel. The horizontal gyro may also be removed from shock-mounted panel, if desired.
5. Reverse preceding steps for reinstallation.

16-6. SHOCK-MOUNTS. Service life of shock-mounted instruments is directly related to adequate shock-mounting of the panel. If removal of shock-mounted panel is necessary, check mounts for deterioration and replace as necessary.

16-7. INSTRUMENTS. (Refer to figure 16-1.)

16-8. REMOVAL. Most instruments are secured to the panel with screws inserted through the panel face, under the decorative cover. To remove an instrument, remove decorative cover, disconnect wiring or plumbing to instrument, remove mounting screws and take instrument out from behind, or in some cases, from front of panel. Instrument clusters are installed as units and are secured by a screw at each end. A cluster must be removed from the forward side of the stationary panel to replace an individual gage. In all cases when an instrument is removed, disconnected lines or wires should be protected. Cap open lines and cover pressure connections on instrument to prevent thread damage and entrance of foreign matter. Wire terminals should be insulated or tied up to prevent accidental grounding or short-circuiting.

16-9. INSTALLATION. Generally, installation procedure is the reverse of removal procedure. Ensure mounting screw nuts are tightened firmly, but do not over-tighten, particularly on instruments having plastic cases. The same rule applies to connecting plumbing and wiring.

NOTE

All instruments (gages and indicators), requiring a thread seal or lubricant, shall be installed using teflon tape on male fittings only. This tape is available from Cessna Parts Distribution (CPD) through Cessna Service Stations.

When replacing an electrical gage in an instrument cluster assembly, avoid bending pointer or dial plate. Distortion of dial or back plate could change the calibration of gages.

16-10. PITOT AND STATIC SYSTEMS. (Refer to figure 16-2.)

16-11. DESCRIPTION. The pitot system conveys ram air pressure to the airspeed indicator. The static system vents vertical speed indicator, altimeter and airspeed indicator to atmospheric pressure through plastic tubing connected to the static ports. A static line sump is installed at each source button to collect condensation in the static system. A pitot tube heater and stall warning heater may be installed. The heating elements are controlled by a switch at the instrument panel and powered by the electrical system. A static pressure alternate source valve may be installed in the static system for use when the external static source is malfunctioning. This source is to be used only in emergencies. When used as a static source, cabin pressure is substituted for atmospheric pressure, causing the instrument readings to vary from normal. This valve also permits draining condensate from the static lines. Refer to Pilot's Operating Handbook for flight operation using alternate static source pressure.

16-12. MAINTENANCE. Proper maintenance of the pitot and static system is essential for proper opera-

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 16-2. Pitot-Static System (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 16-2. Pitot-Static System (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

tion of altimeter, vertical speed and airspeed indicators. Leaks, moisture and obstructions in the pitot system will result in false airspeed indications, while static system malfunctions will affect the readings of all three instruments. Under instrument flight conditions, these instrument errors could be hazardous. Cleanliness and security are the principal rules for system maintenance. The pitot tube and static ports **MUST** be kept clean and unobstructed.

16-13. STATIC PRESSURE SYSTEM INSPECTION AND LEAKAGE TEST. The following procedure outlines inspection and testing of the static pressure system, assuming the altimeter has been tested and inspected in accordance with current Federal Aviation Regulations.

- a. Ensure that the static system is free from entrapped moisture and restrictions.
- b. Ensure that no alterations or deformations of the airframe surface have been made which would affect the relationship between air pressure in the static pressure system and true ambient static air pressure for any flight configuration.
- c. Seal one static source port with pressure sensitive tape. This seal must be air tight.
- d. Close the static pressure alternate source valve, if installed.
- e. Attach a source of suction to the remaining static pressure source opening. Figure 16-3 shows one method of obtaining suction.
- f. Slowly apply suction until the altimeter indicates a 1000-foot increase in altitude.

CAUTION

When applying or releasing suction, do not exceed the range of vertical speed indicator or airspeed indicator.

- g. Cut off the suction source to maintain a "closed" system for one minute. Leakage shall not exceed 100 feet of altitude loss as indicated on the altimeter.
- h. If leakage rate is within tolerance, slowly release the suction source and remove the tape from static port.

NOTE

If leakage rate exceeds the maximum allowable, first tighten all connections, then repeat leakage test. If leakage rate still exceeds the maximum allowable, use the following procedure.

- i. Disconnect the static pressure lines from airspeed indicator and vertical speed indicator. Use suitable fittings to connect the lines together so the altimeter is the only instrument still connected into the static pressure system.
- j. Repeat the leakage test to check whether the static pressure system or the bypassed instruments are the cause of leakage. If the instruments are at fault, they must be repaired by an "appropriately rated repair station" or replaced. If the static pressure system is at fault, use the following procedure to locate leakage.
- k. Attach a source of positive pressure to the static

source opening. Figure 16-3 shows one method of obtaining positive pressure.

CAUTION

Do not apply positive pressure with the airspeed indicator or vertical speed indicator connected to the static pressure system.

- l. Slowly apply positive pressure until the altimeter indicates a 500-foot decrease in altitude and maintain this altimeter indication while checking for leaks. Coat line connections and static source flange with LEAK-TEC or a solution of mild soap and water, watching for bubbles to locate leaks.
- m. Tighten leaking connections. Repair or replace parts found defective.
- n. Reconnect the airspeed and vertical speed indicators into the static pressure system and repeat leakage test per steps "c" thru "h".

16-14. PITOT SYSTEM INSPECTION AND LEAKAGE TEST. To check the pitot system for leaks, place a piece of tape over the small hole in the lower aft end of pitot tube, fasten a piece of rubber or plastic tubing over pitot tube, close opposite end of tubing and slowly roll up tube until airspeed indicator registers in cruise range. Secure tube and after a few minutes recheck airspeed indicator. Any leakage will have reduced the pressure in system, resulting in a lower airspeed indication. Slowly unroll tubing before removing it, so pressure is reduced gradually. Otherwise instrument may be damaged. If test reveals a leak in system, check all connections for tightness.

16-15. BLOWING OUT LINES. Although the pitot system is designed to drain down to the pitot tube opening, condensation may collect at other points in the system and produce a partial obstruction. To clear the line, disconnect it at the airspeed indicator. Using low pressure air, blow from the indicator end of line toward the pitot tube.

Like the pitot lines, static pressure lines must be kept clear and connections tight. Static source sumps collect moisture and keeps system clear. However, when necessary, disconnect static line at first instrument to which it is connected, then blow the line clear with low pressure air.

CAUTION

Never blow through pitot or static lines toward instruments. Insure that (avionics) altitude sensor line is disconnected from static lines before blowing out lines, or damage to sensor may occur.

NOTE

On aircraft equipped with an alternate static source, use the same procedure, opening the alternate static source valve momentarily to clear line, then close valve and clear the remainder of system.

Check all static pressure line connections for tightness. If hose or hose connections are used, check them for general condition and clamps for security.

MODEL 210 & T210 SERIES SERVICE MANUAL

Replace hose which have cracked, hardened or show other signs of deterioration.

16-16. REMOVAL AND INSTALLATION OF COMPONENTS. (Refer to figure 16-2). To remove the pitot mast, remove the four mounting screws on the side of connector (19) and pull mast out of connector far enough to disconnect pitot line (5). Electrical connections to the heater assembly (if installed) may be disconnected through the wing access opening just inboard of mast. Pitot and static lines are removed in the usual manner, after removing wing access plates, lower wing fairing strip and upholstery as

required. Installation of tubing will be simpler if a guide wire is drawn in as tubing is removed from wing. The tubing may be removed intact by drawing it out through cabin and right door. When replacing components of pitot and static pressure systems, use anti-seize compound sparingly on male threads on both metal and plastic connections. Avoid excess compound which might enter lines. Tighten connections firmly, but avoid overtightening and distorting fittings. If twisting of plastic tubing is encountered when tightening fittings, VV-P-236 (USP Petrolatum), may be applied sparingly between tubing and fittings.

16-17. TROUBLE SHOOTING--PITOT-STATIC SYSTEM.

TROUBLE	PROBABLE CAUSE	REMEDY
LOW OR SLUGGISH AIRSPEED INDICATION. Normal altimeter and vertical speed.	Pitot tube deformed, leak or obstruction in pitot line.	Straighten tube, repair or replace damaged line.
INCORRECT OR SLUGGISH RESPONSE. All three instruments.	Leaks or obstruction in static line.	Repair or replace line.
	Alternate static source valve open.	Close for normal operation.

16-18. TRUE AIRSPEED INDICATOR. A true airspeed indicator may be installed. This indicator, equipped with a conversion ring, may be rotated until pressure altitude is aligned with outside air temperature, then airspeed indicated on the instrument is read as true airspeed on the adjustable ring. Refer to figure 16-2 for removal and installation. Upon in-

stallation, before tightening mounting screws (14), calibrate the instrument as follows: Rotate ring (12) until 105 knots on adjustable ring aligns with 105 knots on indicator. Holding this setting, move retainer (13) until 60°F aligns with zero pressure altitude, then tighten mounting screws (14) and replace decorative cover (15).


16-19. TROUBLE SHOOTING.

NOTE

Refer to paragraph 16-15 before blowing out pitot or static lines.

TROUBLE	PROBABLE CAUSE	REMEDY
HAND FAILS TO RESPOND.	Pitot pressure connection not properly connected to pressure line from pitot tube.	Repair or replace damaged line, tighten connections.
	Pitot or static lines clogged.	Blow out lines.
INCORRECT INDICATION OR HAND OSCILLATES.	Leak in pitot or static lines.	Repair or replace damaged lines, tighten connections.
	Defective mechanism.	Replace instrument.
	Leaking diaphragm.	Replace instrument.
	Alternate static source valve open.	Close for normal operation.

MODEL 210 & T210 SERIES SERVICE MANUAL



NOTE

Air bulb with check valves may be obtained locally from a surgical supply company. This is the type used in measuring blood pressure.

TO APPLY SUCTION:

1. Squeeze air bulb to expel as much air as possible.
2. Hold suction hose firmly against static pressure source opening.
3. Slowly release air bulb to obtain desired suction, then pinch hose shut tightly to trap suction in system.
4. After leak test, release suction slowly by intermittently allowing a small amount of air to enter static system. To do this, tilt end of suction hose away from opening, then immediately tilt it back against opening. Wait until vertical speed indicator approaches zero, then repeat. Continue to admit this small amount of air intermittently until all suction is released, then remove test equipment.

TO APPLY PRESSURE:

CAUTION

Do not apply positive pressure with airspeed indicator or vertical speed indicator connected into static system.

1. Hold pressure hose firmly against static pressure source opening.
2. Slowly squeeze air bulb to apply desired pressure to static system. Desired pressure may be maintained by repeatedly squeezing bulb to replace any air escaping through leaks.
3. Release pressure by slowly opening pressure bleed-off screw, then remove test equipment.

Figure 16-3. Static System Test Equipment

MODEL 210 & T210 SERIES SERVICE MANUAL

16-19. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
HAND VIBRATES.	Excessive vibration caused by loose mounting screws.	Tighten mounting screws.
	Excessive tubing vibration.	Tighten clamps and connections, replace tubing with flexible hose.

16-20. TROUBLE SHOOTING -- ALTIMETER.

NOTE

Refer to paragraph 16-15 before blowing out pitot or static lines.

TROUBLE	PROBABLE CAUSE	REMEDY
INSTRUMENT FAILS TO OPERATE.	Static line plugged.	Blow out lines.
	Defective mechanism.	Replace instrument.
INCORRECT INDICATION.	Hands not carefully set.	Reset hands with knob.
	Leaking diaphragm.	Replace instrument.
	Pointers out of calibration.	Replace instrument.
HAND OSCILLATES.	Static pressure irregular.	Blow out lines, tighten connections.
	Leak in airspeed or vertical speed indicator installations.	Blow out lines, tighten connections.

16-21. TROUBLE SHOOTING--VERTICAL SPEED INDICATOR.

NOTE

Refer to paragraph 16-15 before blowing out pitot or static lines.

TROUBLE	PROBABLE CAUSE	REMEDY
INSTRUMENT FAILS TO OPERATE.	Static line plugged.	Blow out lines.
	Static line broken.	Repair or replace damaged line, tighten connections.
INCORRECT INDICATION.	Partially plugged static line.	Blow out lines.
	Ruptured diaphragm.	Replace instrument.
	Pointer off zero.	Reset pointer to zero.

MODEL 210 & T210 SERIES SERVICE MANUAL

16-21. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
POINTER OSCILLATES.	Partially plugged static line.	Blow out lines.
	Leak in static line.	Repair or replace damaged lines, tighten connections.
	Leak in instrument case.	Replace instrument.

16-22. TROUBLE SHOOTING--PITOT TUBE HEATER.

NOTE

Refer to paragraph 16-15 before blowing out pitot or static lines.

TROUBLE	PROBABLE CAUSE	REMEDY
TUBE DOES NOT HEAT OR CLEAR ICE.	Switch turned "OFF."	Turn switch "ON."
	Popped circuit breaker.	Reset breaker.
	Break in wiring.	Repair wiring.
	Heating element burned out.	Replace element.

16-23. VACUUM SYSTEM. (See figure 16-4.)

16-24. DESCRIPTION. A dry vacuum system is installed on the aircraft. The system utilizes a sealed bearing engine-driven vacuum pump. A discharge tube is connected to the pump to expell air from the pump overboard. A suction relief valve is used to control system vacuum and is connected between the pump inlet and the instruments. A central air filtering system is utilized. The reading of the suction gage indicates net difference in suction before and after air passes through a gyro. This

differential pressure will gradually decrease as the central air filter becomes dirty, causing a lower reading on the suction gage. Effective 21064126 barb type fittings are used in the vacuum system to eliminate the use of hose clamps.

BEGINNING WITH 21064536 a dual pump system is available. The system plumbing and installation is illustrated in figure 16-4 sheets 2 of 3 and 3 of 3. With this system dual vacuum relief valves are utilized. Both are mounted at Station 3.85, and right or left buttock lines 8.35.

16-25. TROUBLE SHOOTING -- VACUUM SYSTEM.

TROUBLE	PROBABLE CAUSE	REMEDY
HIGH SUCTION GAGE READINGS. (Gyros function normally.)	Relief valve filter clogged, relief valve malfunction.	Replace filter, reset valve. Replace gage.
LOW SUCTION GAGE READINGS.	Leaks or restriction between instruments and relief valve, relief valve out of adjustment, defective pump.	Repair or replace lines, adjust or replace relief valve, repair or replace pump.
	Central air filter dirty.	Clean or replace filter.

MODEL 210 & T210 SERIES SERVICE MANUAL

16-25. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
SUCTION GAGE FLUCTUATES.	Defective gage or sticking relief valve.	Replace gage. Clean sticking valve with Stoddard solvent. Blow dry and test. If valve sticks after cleaning, replace it.

16-26. TROUBLE SHOOTING -- GYROS.

TROUBLE	PROBABLE CAUSE	REMEDY
HORIZON BAR FAILS TO RESPOND.	Central air filter dirty.	Clean or replace filter.
	Suction relief valve improperly adjusted.	Adjust or replace relief valve.
	Faulty suction gage.	Replace suction gage.
	Vacuum pump failure.	Replace pump.
	Vacuum line kinked or leaking.	Repair or replace damaged lines, tighten connections.
HORIZON BAR DOES NOT SETTLE.	Defective mechanism.	Replace instrument.
	Insufficient vacuum.	Adjust or replace relief valve.
	Excessive vibration.	Replace defective shock panel mounts.
HORIZON BAR OSCILLATES OR VIBRATES EXCESSIVELY.	Central air filter dirty.	Clean or replace filter.
	Suction relief valve improperly adjusted.	Adjust or replace relief valve.
	Faulty suction gage.	Replace suction gage.
	Defective mechanism.	Replace instrument.
	Excessive vibration.	Replace defective shock panel mounts.
EXCESSIVE DRIFT IN EITHER DIRECTION.	Central air filter dirty.	Clean or replace filter.
	Low vacuum, relief valve improperly adjusted.	Adjust or replace relief valve.
	Faulty suction gage.	Replace suction gage.
	Vacuum pump failure.	Replace pump.
	Vacuum line kinked or leaking.	Repair or replace damaged lines, tighten connections.

MODEL 210 & T210 SERIES SERVICE MANUAL

16-26. TROUBLE SHOOTING GYRO'S (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
DIAL SPINS IN ONE DIRECTION CONTINUOUSLY.	Operating limits have been exceeded.	Replace instrument.
	Defective mechanism.	Replace instrument.

16-27. TROUBLE SHOOTING -- VACUUM PUMP

TROUBLE	PROBABLE CAUSE	REMEDY
OIL IN DISCHARGE.	Damaged pump drive seal.	Replace gasket.
HIGH SUCTION.	Suction relief valve filter clogged.	Replace filter.
LOW SUCTION.	Relief valve leaking.	Replace relief valve.
	Vacuum pump failure.	Replace vacuum pump.

16-28. MAINTENANCE PRACTICES.

NOTE

When replacing a vacuum system component, ensure all connections are made correctly to avoid damage to gyro system. When a component is removed, cap off and identify all open lines, hoses, and fittings to prevent dirt from entering system, and to ensure proper reinstallation. Upon component replacement, Check all hoses carefully to be sure they are clean and free of debris, oil, solvent, collapsed inner liners, and external damage. Replace old, hard, cracked, or brittle hoses, particularly on pump inlet, to avoid possible pump damage. On vacuum pump, where hose clearance is tight, making it difficult to re-install hoses, apply a light film of petrolatum to the fitting. Install hoses by pushing them straight on, and do not wiggle hoses from side to side as this could cause particles to be cut from inside of hose, allowing particles to enter system.

CAUTION

Do not use teflon tape, pipe dope, or thread lubricants of any type on fitting threads, and avoid over-tightening of connections. All filters in vacuum system must be changed when installing a new pump. Failure to do so will void pump warranty. **DO NOT CONNECT A PUMP BACKWARDS** since the manifold check valves provide no pressure relief, the pump will be destroyed within a matter of seconds after starting the engine.

16-28A. REMOVAL OF VACUUM PUMP.

- Remove upper engine cowling in accordance with procedures in Sections 12 of 12A.
- Disconnect, cap off and identify hose on inlet side of vacuum pump.
- Identify and disconnect hose on outlet side of vacuum pump.
- Remove nuts, lockwashers, and flat washers securing vacuum pump to engine.
- Remove vacuum pump from mounting studs on engine.
- Remove elbow from pump and retain if it is reusable.

NOTE

Discard any twisted fittings or nuts with rounded corners.

16-28B. MOUNTING PAD INSPECTION.

- Check condition of the AND 20000 pad seal. If the seal shows any signs of oil leakage, replace the seal. Replace seal if there is any doubt as to its serviceability.


16-28C. INSTALLATION OF VACUUM PUMP.

- Before installing a new vacuum pump purge all lines in the system to remove carbon particles or pump components that may have been deposited in the lines by a previous pump.
- Consult the applicable Parts Catalog, the pump vendor's application list, or the PMA label on the pump box to verify that the pump is the correct model for the engine and/or system.

NOTE

Before installing vacuum pump on engine.

MODEL 210 & T210 SERIES SERVICE MANUAL



☆ THRU 21064772


● BEGINNING WITH 21064773

1. Vent Line
2. Tube Locator
3. Vacuum Pump
4. Suction Relief Valve
5. Firewall
6. Cross Assembly
7. Suction Gage
8. Gyro Horizon
9. Directional Gyro
10. Bracket
11. Central Filter
12. Vacuum Switch
13. Tube
14. Hose

SINGLE PUMP TYPICAL

Figure 16-4. Vacuum System (Sheet 1 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL



NOTE


(5) is rotated 180° clockwise for clarity.

DUAL VACUUM PUMP SYSTEM

- 1. Gyro Horizon
- 2. Directional Gyro
- 3. Suction Gage
- 4. Central Filter
- 5. Manifold Check Valve

Figure 16-4. Vacuum System (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL



★ BEGINNING WITH 21064773

Figure 16-4. Vacuum System (Sheet 3 of 3)

ensure that mating surfaces are clean and free of any old gasket material.

c. Position the vacuum pump in a jaw-protected vise, with drive coupling downward.

CAUTION

Pump housing should never be placed directly in a vise, since clamping across center housing will cause an internal failure of carbon rotor. Protect pump mounting flange with soft metal or wood. NEVER INSTALL a pump that has been dropped.

NOTE

Do not use teflon tape, pipe dope, or thread lubricants of any type, and avoid over-tightening of connections.

d. Install elbow in pump; hand-tighten only.

NOTE

Use only a box wrench to tighten fittings to desired position. Do not make more than one and one half (1-1/2) turns beyond hand-tighten position.

NOTE

Before installing vacuum pump on engine, ensure that mating surfaces are clean and free of any old gasket material.

e. Position new mounting pad gasket on mounting studs on engine.

f. Position vacuum pump on mounting studs.

g. Secure pump to engine with flat washers, new lockwashers, and nuts.

CAUTION

Always replace all lockwashers with new ones when installing a new vacuum pump. Tighten all four mounting nuts (4) to 50 to 70 pound-inches.

h. Connect hose to inlet side of vacuum pump.
i. Install upper engine cowling in accordance with procedures in Sections 12 or 12A.

16-29. CLEANING. Remove and discard suction relief valve filter. Wash relief valve with Stoddard solvent and dry with low pressure, dry compressed air. Install new filter. Check hoses for external damage and collapsed inner liners.

CAUTION

Never apply compressed air to lines or components installed in aircraft. The excessive pressures will damage gyros. If an obstructed line is to be blown out, disconnect at both ends and blow from instrument panel out.

16-29A. LOW-VACUUM WARNING LIGHT. (See figure 16-4, sheet 1 of 3.) A red low-vacuum warning light is installed on the instrument panel. This light is used in conjunction with the single pump system only. The light is controlled by a vacuum switch which is teed into the line between the suction gage and the directional gyro. The switch contacts

MODEL 210 & T210 SERIES SERVICE MANUAL

are normally closed. The light may be checked by turning ON the master switch. With the engine running the light should illuminate when the vacuum drops below $3\pm .5$ inches Hg.

16-30. VACUUM RELIEF VALVE ADJUSTMENT. A suction gage reading of 5.3 inches Hg is desirable for gyro instruments. However a range of 4.6 to 5.4 inches Hg is acceptable.

Single pump adjustment. Remove central air filter, run engine at 2200 RPM, adjust relief valve to $5.3\pm .1$ inches Hg.

Dual pump adjustment. Remove central air filter, with engine at 1900 set relief valves at lower end of green arc (4.8 inches Hg) with individual pump only on the line. Combined reading (both pumps on line) not to exceed 5.4 inches Hg at 1900 RPM.

CAUTION

Do not exceed maximum engine temperature.

NOTE

With either a single or dual vacuum pump, if vacuum drops noticeably after replacing central air filter, remove and replace existing filter with a new filter.

16-31. ENGINE INDICATORS.

16-32. TACHOMETER.

16-33. DESCRIPTION. The tachometer is a mechanical indicator driven at half crankshaft speed by a flexible shaft. Most tachometer difficulties will be found in the drive-shaft. To function properly, the shaft

housing must be free of kinks, dents and sharp bends. There should be no bend on a radius shorter than six inches and no bend within three inches of either terminal. If a tachometer is noisy or the pointer oscillates, check the cable housing for kinks, sharp bends and damage. Disconnect cable at tachometer and pull it out of housing. Check cable for worn spots, breaks and kinks.

NOTE

Before replacing a tachometer cable in the housing, coat the lower two thirds with AC Type ST-640 speedometer cable grease or Lubriplate No. 110. Insert the cable in housing as far as possible, then slowly rotate cable to make sure it is seated in the engine fitting. Insert cable in tachometer, making sure it is seated in drive shaft, then reconnect housing and torque to 50 pound-inches (at instrument).

16-34. MANIFOLD PRESSURE/FUEL FLOW INDICATOR.

16-35. DESCRIPTION. The manifold pressure and fuel flow indicators are in one instrument case, however, each instrument operates independently. The manifold pressure gage is a barometric instrument which indicates absolute pressure in the intake manifold in inches of mercury. The fuel flow indicator is a pressure instrument calibrated in pounds per hour, indicating approximate pounds of fuel metered per hour to the engine. Pressure for operating the indicator is obtained through a hose from the fuel manifold valve. The fuel flow indicator is vented to atmospheric pressure on standard engine installations and to turbocharger outlet pressure on turbocharged engine installations.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

16-36. TROUBLE SHOOTING--MANIFOLD PRESSURE INDICATOR.

TROUBLE	PROBABLE CAUSE	REMEDY
EXCESSIVE ERROR AT EXISTING BAROMETRIC PRESSURE.	Pointer shifted.	Replace instrument.
	Leak in vacuum bellows.	Replace instrument.
	Loose pointer.	Replace instrument.
	Leak in pressure line.	Repair or replace damaged line, tighten connections.
	Condensate or fuel in line.	Blow out line.
JERKY MOVEMENT OF POINTER.	Excessive internal friction.	Replace instrument.
	Rocket shaft screws tight.	Replace instrument.
	Link springs too tight.	Replace instrument.
	Dirty pivot bearings.	Replace instrument.
	Defective mechanism.	Replace instrument.
	Leak in pressure line.	Repair or replace damaged line, tighten connections.
SLUGGISH OPERATION OF POINTER.	Foreign matter in line.	Blow out line.
	Damping needle dirty.	Replace instrument.
	Leak in pressure line.	Repair or replace damaged line, tighten connections.
EXCESSIVE POINTER VIBRATION.	Tight rocker pivot bearings.	Replace instrument.
IMPROPER CALIBRATION.	Faulty mechanism.	Replace instrument.
NO POINTER MOVEMENT.	Faulty mechanism.	Replace instrument.
	Broken pressure line.	Repair or replace damaged line.

MODEL 210 & T210 SERIES SERVICE MANUAL

16-37. TROUBLE SHOOTING--FUEL FLOW INDICATOR.

TROUBLE	PROBABLE CAUSE	REMEDY
DOES NOT REGISTER.	Pressure line clogged.	Blow out line.
	Pressure line broken.	Repair or replace damaged line.
	Fractured bellows or damaged mechanism.	Replace instrument.
	Clogged snubber orifice.	Replace instrument.
	Pointer loose on staff.	Replace instrument.
POINTER FAILS TO RETURN TO ZERO.	Foreign matter in line.	Blow out line.
	Clogged snubber orifice.	Replace instrument.
	Damaged bellows or mechanism.	Replace instrument.
INCORRECT OR ERRATIC READING.	Damaged or dirty mechanism.	Replace instrument.
	Pointer bent, rubbing on dial or glass.	Replace instrument.
	Leak or partial obstruction in pressure or vent line.	Blow out dirty line, repair or tighten loose connections.

16-38. CYLINDER HEAD TEMPERATURE GAGE.

16-39. DESCRIPTION. The temperature sending unit regulates electrical power through the cylinder head temperature gage. The gage and sender require little or no maintenance other than cleaning, making sure lead is properly supported, and all connections are clean, tight, and properly insulated. Rochester and Stewart Warner gages are connected the same but the Rochester gage does not have a calibration pot and cannot be adjusted. Refer to Table 2 on page 16-22A when trouble shooting the cylinder head temperature gage.

NOTE

Torque used to tighten wire lead nut not to exceed 4 inch-pounds.

16-40. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
GAGE INOPERATIVE.	No current to circuit.	Repair electrical circuit.
	Defective gage or sender.	Repair or replace defective items.
GAGE FLUCTUATES RAPIDLY.	Loose or broken wire permitting alternate make and break of gage circuit.	Repair or replace defective wire.
GAGE READS TOO HIGH ON SCALE.	High voltage.	Check voltage supply.
	Gage off calibration.	Replace gage or sender. Check ground connection.

MODEL 210 & T210 SERIES SERVICE MANUAL

16-40. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
GAGE READS TOO LOW ON SCALE.	Low voltage.	Check voltage supply and "D" terminal.
	Gage off calibration.	Replace defective items.
	Defective gage or sender.	Replace defective items.
GAGE READS OFF SCALE AT HIGH END.	Defective gage or sender.	Replace defective items.
OBVIOUSLY INCORRECT READING.	Defective gage or sender.	Replace defective items.
	Incorrect calibration.	Replace defective items.
GAGE READS FULL SCALE WITH ENGINE COOL OR COLD. (21064064 & ON)	Wire between sender and gage grounded.	Repair or replace wire as required.
	Defective gage or sender.	Replace defective items.
GAGE READS ZERO WHEN ENGINE IS HOT. (21064064 & ON)	Wire between gage and sender is open or disconnected.	Repair or replace wire as required.
	Defective gage or sender.	Replace defective items.

16-41. OIL PRESSURE GAGE.

16-42. DESCRIPTION. The Bourdon tube-type oil pressure gage is a direct-reading instrument, operated by a pressure pickup line connected to the engine

main oil gallery. The oil pressure line from the instrument to the engine should be filled with kerosene, especially during cold weather operation, to attain an immediate oil indication.

16-43. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
GAGE DOES NOT REGISTER.	Pressure line clogged.	Clean line.
	Pressure line broken.	Repair or replace damaged line.
	Fractured Bourdon tube.	Replace instrument.
	Gage pointer loose on staff.	Replace instrument.
	Damaged gage movement.	Replace instrument.
GAGE POINTER FAILS TO RETURN TO ZERO.	Foreign matter in line.	Clean line.
	Foreign matter in Bourdon tube.	Replace instrument.
	Bourdon tube stretched.	Replace instrument.

MODEL 210 & T210 SERIES SERVICE MANUAL

16-43. TROUBLE SHOOTING. (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
GAGE DOES NOT REGISTER PROPERLY.	Faulty mechanism.	Replace instrument.
GAGE HAS ERRATIC OPERATION.	Worn or bent movement.	Replace instrument.
	Foreign matter in Bourdon tube.	Replace instrument.
	Dirty or corroded movement.	Replace instrument.
	Pointer bent and rubbing on dial, dial screw or glass.	Replace instrument.
	Leak in pressure line.	Repair or replace damaged line.

16-44. OIL TEMPERATURE GAGE.

16-45. DESCRIPTION. On some airplanes, the oil temperature gage is a Bourdon tube type pressure instrument connected by armored capillary tubing to a temperature bulb in the engine. The temperature bulb, capillary tube, and gage are filled with fluid and sealed. Expansion and contraction of fluid in the bulb with temperature changes operates the gage. Checking capillary tube for damage and fittings for security is the only maintenance required. Since the tube's inside diameter is small, small dents and kinks, which would be acceptable in larger tubing, may partially or completely close off the capillary, making the gage inoperative. Some airplanes are equipped with gages that are electrically actuated and are not adjustable. Refer to Table 1 on page 16-22A when trouble shooting the oil temperature gage.

16-46. FUEL QUANTITY INDICATING SYSTEM. (THRU 21062273).

16-47. INDICATORS. Two fuel quantity indicators, graduated in pounds/gallons are located in the instrument cluster. These electromagnetic type indicators are used in conjunction with a control monitor and capacitance type sensing units. Refer to paragraph 16-8 for removal and installation of indicators.

16-48. SENDING UNITS. Two fuel quantity sending units are located in each fuel bay. These sending units are basically tubular capacitors with two electrodes fixed in one position. Any change in fuel quantity between full and empty produces a corresponding change in the capacitance of the electrodes. These changes in capacitance are amplified by the control monitor and actuates the fuel quantity indicators.

16-48A. REMOVAL AND INSTALLATION. (Refer to figure 13-2.)

- Completely drain all fuel from wing bays at bay sump drain valves. (Observe precautions in Section 13, Paragraph 13-3.)
- Remove plates on top of wing bays for access to sensing units. (Refer to Section 13.)
- Remove safety wire from probe clips.

d. Disconnect probe electrical connections and lift probe out.

e. Reverse the preceding steps for installation. Prior to reinstalling access plates, calibrate system in accordance with procedures outlined in paragraph 16-51.

CAUTION

Access plates must be resealed after removal. Refer to Section 13 for sealing instructions.

16-49. CONTROL MONITOR. The control monitor is located above the right cabin door, behind the headliner. A zipper is installed in the headliner for easy access. The monitor incorporates adjustment provisions for system calibration.

16-50. REMOVAL AND INSTALLATION.

- Open zipper in headliner above right door and remove insulation as necessary.
- Disconnect all wiring and tag connections for reference on installation.
- Remove mounting screws and remove monitor.
- Reverse preceding steps for installation and calibrate system in accordance with paragraph 16-51.

16-51. CALIBRATION.

NOTE

Use field fuel quantity system test box, PN 2548H, which is available from Barfield (phone: 800-321-1039). This test box is sold with an operating instructions manual, or one may be purchased separately. The field calibration test box, formerly Cessna PN 9910111-10, is no longer available.

16-52. TROUBLE SHOOTING.

NOTE

For additional trouble shooting and testing, use field fuel quantity system test box, PN 2548H, which is available from Barfield (phone: 800-321-1039) and comes with an operating instructions manual. The field calibration test box, formerly Cessna PN 9910111-10, is no longer available.

MODEL 210 & T210 SERIES SERVICE MANUAL

16-52. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
NO FUEL QUANTITY INDICATION.	Fuel bays empty.	Service with proper grade and amount of fuel.
	Circuit breaker open or defective.	Reset. Replace if defective.
	Defective fuel quantity indicator or sending unit.	Substitute known-good indicator or sending unit. Replace the instrument if defective.
	Loose connections or open circuit.	Tighten connections; repair or replace wiring.

16-52A. FUEL QUANTITY INDICATING SYSTEM. (BEGINNING 21062274)

16-52B. DESCRIPTION. The magnetic type fuel quantity indicators are used in conjunction with a float-operated variable-resistance transmitter in each fuel tank. The full position of float produces a mini-

imum resistance through transmitter, permitting maximum current flow through the fuel quantity indicator and maximum pointer deflection. As fuel level is lowered, resistance in transmitter is increased, producing a decreased current flow through fuel quantity indicator and a smaller pointer deflection.

16-52C. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
FAILURE TO INDICATE.	No power to indicator or transmitter. (Pointer stays below E.)	Check fuse and inspect for open circuit. Replace fuse, repair or replace defective wire.
	Grounded wire. (Pointer stays above F.)	Check for partial ground between transmitter and gage. Repair or replace defective wire.
	Low voltage.	Check voltage at indicator. Correct voltage.
	Defective indicator.	Substitute known-good indicator. Replace indicator.
OFF CALIBRATION.	Defective indicator.	Substitute known-good indicator. Replace indicator.
	Defective transmitter.	Substitute known-good transmitter. Recalibrate or replace.
	Low or high voltage.	Check voltage at indicator. Correct voltage.
STICKY OR SLUGGISH INDICATOR OPERATION.	Defective indicator.	Substitute known-good indicator. Replace indicator.
	Low voltage.	Check voltage at indicator. Correct voltage.

MODEL 210 & T210 SERIES SERVICE MANUAL

16-52C. TROUBLE SHOOTING. (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
ERRATIC READINGS.	Loose or broken wiring on indicator or transmitter.	Inspect circuit wiring. Repair or replace defective wire.
	Defective indicator or transmitter.	Substitute known-good component. Replace indicator or transmitter.
	Defective master switch.	Replace switch.

16-52D. REMOVAL AND INSTALLATION. (Refer to figure 13-2.)

- Remove access plates on the underside of wing forward of the flap bellcrank.
- Drain enough fuel from bay to lower fuel level below transmitter. (Observe precautions in paragraph 12-3.)
- Disconnect electrical lead and ground strap from transmitter.
- Remove safety wire from transmitter attaching bolts, remove bolts and carefully remove transmitter from fuel spar, **DO NOT BEND FLOAT ARM.**
- To install transmitter, reverse preceding steps, using a new gasket around opening in fuel bay and new sealing washers.

NOTE

Insure that transmitter is grounded per figure 16-4A.

- Service fuel bay. Check for leaks and correct fuel quantity indication.




Figure 16-4A. Ground Strap Installation

16-52E. TRANSMITTER CALIBRATION.

WARNING

Using the following fuel transmitter calibration procedure on components other than the originally installed (Stewart Warner) components will result in a faulty fuel quantity reading.

16-52F. STEWART WARNER GAGE TRANSMITTER CALIBRATION. Chances of transmitter calibration changing in normal service is remote; however, it is possible that float arm or float arm stops may become bent if transmitter is removed from cell. Transmitter calibration is obtained by adjusting float travel. Float travel is limited by float arm stops.

WARNING

Use extreme caution while working with electrical components of the fuel system. The possibility of electrical sparks around an "empty" fuel cell creates a hazardous situation.

Before installing transmitter, attach electrical wires and place master switch "ON" position. Allow float arm to rest against lower float arm stop and read indicator. The pointer should be on E (empty) position. Adjust the float arm against lower stop so pointer indicator is on E. Raise float until arm is against upper stop and adjust upper stop to permit indicator pointer to be on F (full). Install transmitter in accordance with paragraph 16-52D.

16-52G. ROCHESTER GAGE TRANSMITTER. Do not attempt to adjust float arm or stop. No adjustment is allowed.

MODEL 210 & T210 SERIES SERVICE MANUAL

Table 1

NOTE

Select the oil temperature sending unit part number that is used in your aircraft from the left column and the temperature from the column headings. Read the ohms value under the appropriate temperature column.

Part Number	Type	72°F	120°F	165°F	220°F	250°F
S1630-1	Oil Temp				46.4	
S1630-3	Oil Temp		620.0			52.4
S1630-4	Oil Temp		620.0			52.4
S1630-5	Oil Temp			192.0		
S2335-1	Oil Temp	990.0				34.0

Table 2

NOTE

Select the cylinder head temperature sending unit part number that is used in your aircraft from the left column and the temperature from the column headings. Read the ohms value under the appropriate temperature column.

Part Number	Type	200°F	220°F	450°F	475°F
S1372-1	CHT		310.0	34.8	
S1372-2	CHT		310.0	34.8	
S1372-3	CHT			113.0	
S1372-4	CHT			113.0	
S2334-3	CHT	745.0			38.0
S2334-4	CHT	745.0			38.0

MODEL 210 & T210 SERIES SERVICE MANUAL

15-51C. FUEL QUANTITY INDICATING SYSTEM OPERATIONAL TEST

A. For airplane serials 21061574 thru 21062273:

WARNING: REMOVE ALL IGNITION SOURCES FROM THE AIRPLANE AND VAPOR HAZARD AREA. SOME TYPICAL EXAMPLES OF IGNITION SOURCES ARE STATIC ELECTRICITY, ELECTRICALLY POWERED EQUIPMENT (TOOLS OR ELECTRONIC TEST EQUIPMENT - BOTH INSTALLED ON THE AIRPLANE AND GROUND SUPPORT EQUIPMENT), SMOKING AND SPARKS FROM METAL TOOLS.

WARNING: OBSERVE ALL STANDARD FUEL SYSTEM FIRE AND SAFETY PRACTICES.

1. Disconnect all electrical power from the airplane. Attach maintenance warning tags to the battery connector and external power receptacle stating:

DO NOT CONNECT ELECTRICAL POWER, MAINTENANCE IN PROGRESS.

2. Electrically ground the airplane.
3. Level the airplane and drain all fuel from wing fuel tanks.
4. With the fuel selector valve in the "OFF" position, add unusable fuel to each fuel tank.
5. Apply electrical power as required to verify the fuel quantity indicator indicates "EMPTY".
 - A. If "EMPTY" is not indicated, adjust, troubleshoot, repair and/or replace fuel indicating components as required until the "EMPTY" indication is achieved.
6. Fill tanks to capacity, apply electrical power as required and verify fuel quantity indicator indicates "FULL".
 - A. If "FULL" is not indicated, adjust, troubleshoot, repair and/or replace fuel indicating components as required until the "FULL" indication is achieved.
7. Install any items and/or equipment removed to accomplish this procedure, remove maintenance warning tags and connect the airplane battery.

B. For airplane serials 21062274 thru 21064897:

WARNING: REMOVE ALL IGNITION SOURCES FROM THE AIRPLANE AND VAPOR HAZARD AREA. SOME TYPICAL EXAMPLES OF IGNITION SOURCES ARE STATIC ELECTRICITY, ELECTRICALLY POWERED EQUIPMENT (TOOLS OR ELECTRONIC TEST EQUIPMENT - BOTH INSTALLED ON THE AIRPLANE AND GROUND SUPPORT EQUIPMENT), SMOKING AND SPARKS FROM METAL TOOLS.

WARNING: OBSERVE ALL STANDARD FUEL SYSTEM FIRE AND SAFETY PRACTICES.

1. Disconnect all electrical power from the airplane. Attach maintenance warning tags to the battery connector and external power receptacle stating:

DO NOT CONNECT ELECTRICAL POWER, MAINTENANCE IN PROGRESS.

2. Electrically ground the airplane.
3. Level the airplane and drain all fuel from wing fuel tanks.

MODEL 210 & T210 SERIES SERVICE MANUAL

4. Gain access to each fuel transmitter float arm and actuate the arm through the transmitter's full range of travel.
 - A. Ensure the transmitter float arm moves freely and consistently through this range of travel. Replace any transmitter that does not move freely or consistently.

WARNING: USE EXTREME CAUTION WHILE WORKING WITH ELECTRICAL COMPONENTS OF THE FUEL SYSTEM. THE POSSIBILITY OF ELECTRICAL SPARKS AROUND AN "EMPTY" FUEL CELL CREATES A HAZARDOUS SITUATION.

- B. While the transmitter float arm is being actuated, apply airplane battery electrical power as required to ensure that the fuel quantity indicator follows the movement of the transmitter float arm. If this does not occur, troubleshoot, repair and/or replace components as required until the results are achieved as stated.

NOTE: Stewart Warner fuel quantity indicating systems can be adjusted. Refer to Paragraph 16-52F for instructions to calibrate a Stewart Warner fuel indicating system. Rochester fuel quantity indicating system components are not adjustable, only component replacement or standard electrical wiring system maintenance practices are permitted.

5. With the fuel selector valve in the "OFF" position, add unusable fuel to each fuel tank.
6. Apply electrical power as required to verify the fuel quantity indicator indicates "EMPTY".
 - A. If "EMPTY" is not indicated, adjust, troubleshoot, repair and/or replace fuel indicating components as required until the "EMPTY" indication is achieved.

NOTE: Stewart Warner fuel quantity indicating systems can be adjusted. Refer to Paragraph 16-52F for instructions to calibrate a Stewart Warner fuel indicating system. Rochester fuel quantity indicating system components are not adjustable, only component replacement or standard electrical wiring system maintenance practices are permitted.

7. Fill tanks to capacity, apply electrical power as required and verify fuel quantity indicator indicates "FULL".
 - A. If "FULL" is not indicated, adjust, troubleshoot, repair and/or replace fuel indicating components as required until the "FULL" indication is achieved.

NOTE: Stewart Warner fuel quantity indicating systems can be adjusted. Refer to Paragraph 16-52F for instructions to calibrate a Stewart Warner fuel indicating system. Rochester fuel quantity indicating system components are not adjustable, only component replacement or standard electrical wiring system maintenance practices are permitted.

8. Install any items and/or equipment removed to accomplish this procedure, remove maintenance warning tags and connect the airplane battery.

MODEL 210 & T210 SERIES SERVICE MANUAL

16-53. HOURMETER.

16-54. DESCRIPTION. The hourmeter is an electrically operated instrument, actuated by a pressure switch in the oil pressure gage line. Electrical power is supplied through a one-amp fuse from the electrical clock circuit, and therefore will operate independent of the master switch. A diode incorporated into the meter prevents interruption of avionics operation. This type hourmeter is identified by a white + above the positive terminal.

NOTE

When installing the hourmeter, the positive (red) wire must be connected to the white + terminal. Connecting wires incorrectly will damage the meter.

16-55. ECONOMY MIXTURE INDICATOR.

16-56. DESCRIPTION. The economy mixture indicator is an exhaust gas temperature (EGT) sensing device which is used to aid the pilot in selecting the most desirable fuel-air mixture for cruising flight at less than 75% power. Exhaust gas temperature (EGT) varies with ratio of fuel-to-air mixture entering the engine cylinders. Refer to the Pilot's Operating Handbook for operating procedure of the system.

16-57. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
GAGE INOPERATIVE	Defective gage, probe or circuit.	Repair or replace defective part.
INCORRECT READING.	Indicator needs calibrating.	Calibrate indicator in accordance with paragraph 16-57.
FLUCTUATING READING.	Loose, frayed or broken lead, permitting alternate make and break of circuit.	Tighten connections and repair or replace defective leads.

16-58. CALIBRATION. A potentiometer adjustment screw is provided either on the front or back of the instrument for calibration. This adjustment screw is used to position the pointer over the reference increment line (4/5 of scale) at peak EGT. Establish

75% power in level flight, then carefully lean the mixture to peak EGT. After the pointer has peaked, using the adjustment screw, position pointer over reference increment line (4/5 of scale).

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

This setting will provide relative temperature indications for normal cruise power settings within range of the instrument.

Turning the screw clockwise increases the meter reading and counterclockwise decreases the meter reading. There is a stop in each direction and damage can occur if too much torque is applied against stops. Approximately 600°F total adjustment is provided. The adjustable yellow pointer on the face of the instrument is a reference pointer only.

16-59. REMOVAL AND INSTALLATION. Removal of the indicator is accomplished by removing the mounting screws and disconnecting the leads. Tag leads to facilitate installation. The thermocouple probe is secured to the exhaust stack with a clamp. When installing probe, tighten clamp to 45 pound-inches and safety as required.

16-60. MAGNETIC COMPASS. (Refer to figure 16-5.)

16-61. DESCRIPTION. The magnetic compass is liquid-filled, with expansion provisions to compensate for temperature changes. It is equipped with compensating magnets adjustable from the front of the case. The compass is internally lighted, controlled by the instrument lights rheostat switch. No maintenance is required on the compass except an occasional check on a compass rose and replacement of the lamp. The compass mount is attached by three screws to a base plate which is bonded to the wind-

16-66. TROUBLE SHOOTING.

shield with methylene chloride. A tube containing the compass light wires is attached to the metal strip at the top of the windshield. Removal of the compass is accomplished by removing the screw at the forward end of the compass mount, unfastening the metal strip at the top of the windshield and cutting the two wire splices. Removal of the compass mount is accomplished by removing the outside air temperature probe and removing the three screws attaching mount to the base plate. Access to the inner screw is gained through a hole in the bottom of mount, through which a thin screwdriver may be inserted. When installing the compass, it will be necessary to splice the compass light wires.

16-62. STALL WARNING HORN AND TRANSMITTER.


16-63. DESCRIPTION. The stall warning horn is contained in the dual warning unit mounted on the right hand wing root rib. It is electrically operated and controlled by a stall warning transmitter mounted on the leading edge of the left wing. For further information on the warning horn and transmitter, refer to Section 17.

16-64. TURN COORDINATOR.

16-65. DESCRIPTION. The turn coordinator is an electrically operated, gyroscopic, roll-turn rate indicator. Its gyro simultaneously senses rate of motion roll and yaw axis which is projected on a single indicator. The gyro is a non-tumbling type requiring no caging mechanism and incorporates an ac brushless spin motor with a solid state inverter.


TROUBLE	PROBABLE CAUSE	REMEDY
INDICATOR DOES NOT RETURN TO CENTER.	Friction caused by contamination in the indicator dampening.	Replace instrument.
	Friction in gimbal assembly.	Replace instrument.
DOES NOT INDICATE A STANDARD RATE TURN (TOO SLOW).	Low voltage.	Correct voltage.
	Inverter frequency changed.	Replace instrument.
NOISY MOTOR.	Faulty bearings.	Replace instrument.
ROTOR DOES NOT START.	Faulty electrical connection.	Correct voltage or replace faulty wire.
	Inverter malfunctioning.	Replace instrument.
	Motor shorted.	Replace instrument.
	Bearings frozen.	Replace instrument.

MODEL 210 & T210 SERIES SERVICE MANUAL



NOTE

• Torque to 10-15 lb inches to prevent compass rotation in flight.



Detail **A**

1. Windshield
2. Base Plate
3. Insert
4. Tube
5. Nut
6. Outside Air Temperature Gage
7. Washer
8. Rubber Washer
9. Screw
10. Compass Card
11. Compass
12. Compass Mount
13. Metal Strip
14. Lockwasher
15. Electrical Wire

NOTE

Seal temperature probe at windshield with General Electric RTV 103 sealant. All sealant must be between phenolic tube and windshield. Ensure no sealant touches shaft.

Figure 16-5. Magnetic Compass

MODEL 210 & T210 SERIES SERVICE MANUAL

16-66. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLE CAUSE	REMEDY
IN COLD TEMPERATURES, HAND FAILS TO RESPOND OR IS SLUGGISH.	Oil in indicator becomes too thick.	Replace instrument.
	Insufficient bearing end play.	Replace instrument.
	Low voltage.	Correct voltage.

16-67. TURN-AND-SLIP INDICATOR.

operates **ONLY** when the master switch is on. Its circuit is protected by an automatically-resetting circuit breaker.

16-68. DESCRIPTION. The turn-and-slip indicator is operated by the aircraft electrical system and

16-69. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
INDICATOR POINTER FAILS TO RESPOND.	Automatic resetting circuit breaker defective.	Replace circuit breaker.
	Master switch "OFF" or switch defective.	Replace defective switch.
	Broken or grounded lead to indicator.	Repair or replace defective wiring.
	Indicator not grounded.	Repair or replace defective wire.
	Defective mechanism.	Replace instrument.
HAND SLUGGISH IN RETURNING TO ZERO.	Defective mechanism.	Replace instrument.
	Low voltage.	Correct voltage.
POINTER DOES NOT INDICATE PROPER TURN.	Defective mechanism.	Replace instrument.
HAND DOES NOT SIT ON ZERO.	Gimbal and rotor out of balance.	Replace instrument.
	Hand incorrectly sits on rod.	Replace instrument.
	Sensitivity spring adjustment pulls hand off zero.	Replace instrument.
IN COLD TEMPERATURES, HAND FAILS TO RESPOND OR IS SLUGGISH.	Oil in indicator becomes too thick.	Replace instrument.
	Insufficient bearing end play.	Replace instrument.
	Low voltage.	Correct voltage.

MODEL 210 & T210 SERIES SERVICE MANUAL

16-69. TROUBLE SHOOTING (Cont).

TROUBLE	PROBABLY CAUSE	REMEDY
NOISY GYRO.	High voltage.	Correct voltage.
	Loose or defective rotor bearings.	Replace instrument.

16-70. ELECTRIC CLOCK.

16-71. DESCRIPTION. The electric clock is connected to the battery through a one-ampere fuse mounted adjacent to the battery box. The electrical circuit is separate from the aircraft electrical system and will operate when the master switch is "OFF." Beginning with 21062955 a digital clock may be installed. Refer to Pilots Operating Handbook for operating instructions.

16-72. FUEL COMPUTER/DIGITAL CLOCK.

16-73. DESCRIPTION. The Astro Tech FT-2 is a dual function instrument providing a complete fuel management system and a multi-purpose time keeping device in a single instrument with each function sharing a common display panel. The instrument may be used as a replacement for the digital or electric clock, and may be mounted in the same location on the instrument panel.

The fuel computer portion of the instrument displays the following selections; fuel flow as measured by an engine mounted transducer, total fuel used, current fuel remaining and time remaining based on fuel remaining at the current flow rate. Fuel quantities are displayed in pounds with a gallon display available by utilizing a push button located below and to the right of the display. When time remaining at the correct flow rate reaches 45 minutes or less, the display will be blanked from one-tenth to three-tenths of a second per second in all of the selections.

The digital clock portion of the instrument displays the following selections; current time of day in either local (LCL) or Greenwich Mean Time (GMT) in hours and minutes, cumulative flight time in minutes and seconds (first hour) and hours and minutes (up to 100 hours) whenever fuel flow is greater than 25 to 30 pounds per hour (PPH) and elapsed time in minutes and seconds (first hour) and hours and minutes (up to 100 hours).

Fuel selections and time selections are made by utilizing a rotary-type selector switch common to both functions. Two pushbuttons, located below the display, are used to program the fuel computer digital clock.

16-74. FUEL COMPUTER OPERATION. The fuel computer contains five selections. They are selected by rotating the selector switch to the positions labeled ADD, FLOW, LB USD, LB REM, and TIME REM.

These selections, when used in proper sequence with the programming buttons, will correctly program the computer.

The fuel quantity added during servicing of the airplane must be entered in the computer so that the LB REM position accurately represents the correct amount of usable fuel on board for each flight. The fuel quantity added is entered in the computer as follows:

To enter fill-up:

- Rotate the selector switch to the ADD position.
- Press left and right programming buttons together until display panel reads FULL.
- Rotate the selector switch to LB REM position to display the usable fuel quantity in pounds on board.

NOTE

The usable fuel quantity for each airplane is programmed into the instrument at the factory. A battery disconnect or other power interruption will not alter this quantity.

To enter less than fill-up:


- Rotate the selector switch to the ADD position.
- Press right programming button, labeled GAL, until the right digit represents the correct units of gallons of fuel added.
- Press left programming button, labeled RST, until the left two digits represent the correct tens and hundreds of gallons of fuel added.
- Rotate the selector switch to LB REM position to display the correct usable fuel quantity in pounds on board.

If an error has been made, resulting in an incorrect display of LB REM, the correct amount may be entered as follows:

- Leave the selector switch in the ADD position.
- Enter the corrected fuel quantity in gallons.
- Rotate the selector switch to FLOW, then press and hold the left programming button.
- While holding the left button pressed, slowly rotate the selector switch to the LB REM position. The set-in amount in gallons, multiplied by six, will now appear as LB REM.

When the selector switch is placed in the FLOW position, the display indicates the current fuel flow rate in pounds per hour (PPH). Press the GAL programming button to display the flow rate in gallons per hour (GPH).

MODEL 210 & T210 SERIES SERVICE MANUAL



1. Programming Button
2. Fuel Computer Selections
3. Selector Switch
4. Reset Switch
5. Digital Clock Selections
6. Display Panel
7. Programming Button

Figure 16-6. Fuel Computer/Digital Clock

Placing the selector switch in the LB USD position displays the current fuel quantity used (in pounds) since the last addition of fuel to the airplane. Press the GAL programming button to display the fuel used in gallons.

NOTE

Any entry of additional fuel to LB REM will reset the LB USD to zero.

The LB REM position displays the current total remaining fuel (in pounds) on board the airplane, based on the takeoff amount minus the fuel used as computed using fuel flow rates. Press the GAL programming button to display the remaining fuel in gallons.

NOTE

When the display is changed from pounds to gallons in the FLOW, LB USD, and LB REM positions, the gallons shown are computed on the ratio of 6 pounds per gallon and no volumetric correction for temperature change is made. Therefore maximum accuracy may be obtained by referring to the gallons functions.

The TIME REM position displays the flight time remaining in hours and minutes as computed using the current fuel flow rate and fuel remaining amounts. Since this displayed value is dependent upon flow rate, a reduction in engine power will show an increase in time remaining.

NOTE

With the selector switch in the TIME REM position, power settings of less than 25 to 30 PPH flow rate will cause the word OFF to be displayed.

If it is desired to test the display, rotate the selector switch to TIME REM position, then press the right programming button. This will cause all 8's to be shown, thereby testing each segment of each digit.

Any power interruption that might alter a memory value or activation of the reset switch will erase a line of dashes to be displayed in all selector switch positions. Pressing the right programming button will clear the dashes from the display and show the current selector switch position. All memory values will be erased and must be re-entered. However, the usable fuel quantity will not be altered, since it is permanently entered in the instrument.

NOTE

If an abnormally low voltage condition should occur, such as during a cold weather engine start or if power is interrupted during programming sequences, such as the reset sequence, it is possible for the instrument to enter a "locked up" condition in which the display will not change with selector switch selection. Should this occur, it will be necessary to clear the condition by pressing the reset switch with a pencil or similar small

MODEL 210 & T210 SERIES SERVICE MANUAL

diameter tool. The reset switch is in a small diameter hole located between the words "EL TIME" and "FLT TIME" near the outer periphery of the instrument face. The instrument should now operate normally, but will have to be reprogrammed.

16-75. DIGITAL CLOCK OPERATION. The digital clock contains four selections. They are selected by rotating the selector switch to the positions labeled SET, EL TIME, FLT TIME, and LCL/GMT. These selections, when used in proper sequence with the programming buttons, will correctly program the digital clock.

NOTE

Some models may have an unmarked detent position between the ADD and SET positions. This position performs the same function as the SET position.

The digital clock may be set to the local (LCL) and Greenwich Mean Time (GMT) as follows:

- a. Rotate the selector switch to the SET position.
- b. Press the left programming button until local hours advance to the correct value.
- c. Press both programming buttons together until Greenwich Mean Time hours advance to the correct value.
- d. Press right programming button until minutes advance to correct value. This action sets and holds seconds to zero.
- e. Rotate selector switch from SET to start seconds from zero hold.

16-76. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
FUEL COMPUTER FUNCTION INOPERATIVE	Faulty wiring from transducer to instrument. Faulty transducer	Repair or replace wiring. Replace transducer
NO DISPLAY	Faulty wiring or open fuse.	Repair or replace wiring. Replace fuse.
DISPLAY WILL NOT CHANGE WITH SELECTOR SWITCH SELECTION	Low voltage or power interruption.	Correct low voltage condition. Connect power supply. Depress reset switch to reset instrument.

To display the local time-of-day in hours and minutes, rotate the selector switch to LCL/GMT. If a minutes and seconds display is desired, press the right programming button, labeled SEC. If Greenwich Mean Time in hours and minutes is desired, press the left programming button, labeled GMT.

NOTE

Local or Greenwich Mean Time hours may be changed without resetting the minutes and seconds.


To display accumulated flight time, rotate the selector switch to FLT TIME. After the first hour, if a minutes and seconds display is desired in place of the hours and minutes display, press the right (SEC) programming button. Flight time may be reset to zero by pressing the left (RST) programming button.

NOTE

Accumulated flight time may be zeroed only when the instrument is not counting (whenever fuel flow is less than 25-30 PPH) to prevent accidentally zeroing flight time in the air.

Elapsed time (since pressing the RST button) is displayed by rotating the selector switch to the EL TIME position. After the first hour, if a minutes and seconds display is desired in place of the hours and minutes display, press the right (SEC) programming button. Elapsed time may be reset to zero by pressing the left (RST) programming button.

MODEL 210 & T210 SERIES SERVICE MANUAL



1. Line to Flow Divider
2. Adapter
3. Transducer
4. Washers
5. Nuts
6. Adapter
7. Line to Throttle Body
Metering Unit
8. Vertical Baffle
9. Bolts

Figure 16-7. Fuel Flow Transducer

16-77. FUEL FLOW TRANSDUCER. The fuel flow transducer, located in the engine fuel line, measures the fuel flow rate (in pounds or gallons) to the throttle body metering unit. Fuel flow rate is measured by a turbine within the unit, mounted tangentially to the inlet port. Liquid fuel follows a helical flow path through the turbine and exits vertically to the outlet port, thereby venting any trapped vapor bubbles. The rotating turbine emits current pulse signals to the fuel computer section of the fuel computer/digital clock where they are displayed in pounds or gallons.

16-78. FUEL FLOW TRANSDUCER INSTALLATION. (See figure 16-7). A filter should be located upstream of the inlet port to prevent dirt from entering the turbine bearings. There should be a reasonable length of straight line between the inlet port and a valve, elbow or other turbulence producing device. Since upstream turbulence affects the performance of the instrument, turbulence should be held to a minimum. Be sure to install the transducer in a horizontal position with the wire leads

MODEL 210 & T210 SERIES SERVICE MANUAL

or tabs UP and the turbine totally immersed in fuel.

NOTE

Whenever a transducer is installed it must be calibrated. See paragraph 16-80 for calibration procedures.

16-79. TRANSDUCER REMOVAL AND REPLACEMENT (See figure 16-7).

CAUTION

When performing any maintenance on the fuel system, the precautions in Section 13 must be observed.


- a. Place the fuel selector in the OFF position.
- c. Remove the fuse from the clock fuse holder mounted on the battery contactor bracket.

- d. Disconnect the electrical connector, connecting the transducer to the instrument.
- e. Disconnect and cap both fuel lines (1 and 7).
- f. Remove nuts (5), washers (4), bolts (9) and remove transducer (3).
- g. Reverse these steps for reinstallation.

NOTE

When replacing the inlet and outlet pipe fittings they are to be turned 3 times past hand tight or torqued to 25-30 lbs-ft whichever occurs first.


The transducer must be mounted horizontally with the electrical leads on top.



● Torque to 25-30 Lbs/Ft.

TRANSDUCER

* This letter determines the specific setting of the 3 switches on the back of the fuel computer/digital clock.



FUEL COMPUTER/DIGITAL CLOCK

- 1. Fuel Computer/Digital Clock
- 2. Fuel Computer/Digital Clock Switches
- 3. Transducer
- 4. Wire Leads

* As an example, the setting shown on the fuel computer/digital clock switches (2) would be correct if the boss on top of the transducer (3) had an "F" stamped on it.

Figure 16-8. Transducer Markings and Fuel Computer/Digital Clock Switches.

MODEL 210 & T210 SERIES SERVICE MANUAL

16-80. FUEL TRANSDUCER CALIBRATION. (See figures 16-8 and 16-9.) The fuel computer/digital clock (1) has a 3-section switch (2) located on the back of the unit under a tape cover. Remove the cover and set the switches as shown on the fuel transducer table, figure 16-9. The fuel transducer (3) may have one or two letters (stamped or raised), located on the boss adjacent to the inlet

port. If the boss contains two letters, DISREGARD the first letter. The second letter, near the mounting bolt hole, is the calibration "K" factor letter and determines the switch setting on the fuel computer/digital clock. After setting the 3 switches to the transducer marking designation, replace the tape cover.

TRANSDUCER "K" FACTOR (PULSES PER GALLON)	SWITCH #1	SWITCH #2	SWITCH #3	TRANSDUCER MARKING DESIGNATION
81,500 - 82,375	ON	ON	ON	A
82,376 - 83,250	OFF	ON	ON	B
83,251 - 84,125	ON	OFF	ON	C
84,126 - 85,000	OFF	OFF	ON	D
85,001 - 85,875	ON	ON	OFF	E
85,876 - 86,750	OFF	ON	OFF	F
86,751 - 87,625	ON	OFF	OFF	G
87,626 - 88,500	OFF	OFF	OFF	H

Figure 16-9. Fuel Transducer Table.

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 17 ELECTRICAL SYSTEMS

WARNING

When performing any inspection or maintenance that requires turning on the master switch, installing a battery, or pulling the propeller through by hand, treat the propeller as if the ignition switch were ON. Do not stand nor allow anyone else to stand, within the arc of the propeller, since a loose or broken wire or a component malfunction could cause the propeller to rotate.

TABLE OF CONTENTS	Page No. Aerofiche/Manual	
ELECTRICAL SYSTEMS.	3A4/17-3	
General	3A4/17-3	
Electrical Power Supply System	3A4/17-3	
Description	3A4/17-3	
Split Bus Bar	3A4/17-3	
Description	3A4/17-3	
Removal and Installation.	3A4/17-3	
Master Switch	3A4/17-3	
Description	3A4/17-3	
Ammeter	3A4/17-3	
Description	3A4/17-3	
Battery Power System	3A4/17-3	
Battery	3A4/17-3	
Description	3A4/17-3	
Trouble Shooting	3A5/17-4	
Removal and Installation.	3A10/17-9	
Cleaning the Battery	3A10/17-9	
Adding Electrolyte or		
Water to the Battery	3A10/17-9	
Testing the Battery	3A10/17-9	
Charging the Battery	3A10/17-9	
Battery Box	3A11/17-10	
Description	3A11/17-10	
Removal and Installation.	3A11/17-10	
Maintenance	3A11/17-10	
Battery Contactor	3A11/17-10	
Description	3A11/17-10	
Removal and Installation.	3A11/17-10	
Battery Contactor Closing		
Circuit	3A11/17-10	
Ground Service Receptacle	3A11/17-10	
Description	3A11/17-10	
Trouble Shooting	3A20/17-19	
Removal and Installation.	3A21/17-20	
Alternator Power System	3A21/17-20	
Description	3A21/17-20	
Alternator	3A21/17-20	
Description	3A21/17-20	
Alternator Reverse Volt		
Damage	3A20/17-20	
Trouble Shooting	3B1/17-24	
Removal and Installation.	3B6/17-29	
Alternator Voltage Regulator	3B7/17-30	
Description	3B7/17-30	
Removal and Installation	3B7/17-30	
Alternator Control Unit		
(Beginning with 1979 Models)	3B7/17-30	
Description	3B7/17-30	
Removal and Installation	3B7/17-30	
Over-Voltage Sensor and		
Warning Light	3B7/17-30	
Description	3B7/17-30	
Removal and Installation.	3B7/17-30	
Rigging Throttle-Operated		
Microswitch	3B7/17-30	
Auxiliary Fuel Pump Flow Rate		
Adjustment	3B7/17-30	
Standby Generator System	3B11/17-34	
Description	3B11/17-34	
Removal and Installation.	3B11/17-34	
Dual Alternator System	3B11/17-34	
Description	3B11/17-34	
Alternators	3B11/17-34	
Description	3B11/17-34	
Removal and Installation.	3B11/17-34	
Alternator Control Units	3B11/17-34	
Description	3B11/17-34	
Removal and Installation.	3B11/17-34	
Alternator Contactors and		
Shunts	3B11/17-34	
Description	3B11/17-34	
Removal and Installation.	3B11/17-34	
Volt-Ammeter	3B11/17-34	
Description	3B11/17-34	
Alternator Restart System	3B11/17-34	
Aircraft Lighting System	3B21/17-44	
Description	3B21/17-44	
Switches	3B21/17-44	
Description	3B21/17-44	
Trouble Shooting	3B21/17-44	
Landing and Taxi Lights	3C1/17-48	
Description	3C1/17-48	
Removal and Installation.	3C1/17-48	
Navigation Lights	3C1/17-48	
Description	3C1/17-48	
Removal and Installation.	3C1/17-48	
Anti-Collision Strobe Lights	3C1/17-48	
Description	3C1/17-48	
Operational Requirements		
(Thru 1977 Models)	3C1/17-48	
Removal and Installation	3C3/17-50	
Vertical Tail Flood Lights	3C3/17-50	
Description	3C3/17-50	
Removal and Installation	3C3/17-50	
Flashing Beacon	3C3/17-50	
Description	3C3/17-50	
Removal and Installation	3C3/17-50	
Instrument Lighting	3C3/17-50	

MODEL 210 & T210 SERIES SERVICE MANUAL

TABLE OF CONTENTS	Page No. Aerofiche/Manual		
Description	3C3/17-50	Stall Warning Unit	3C14/17-61
Removal and Installation.	3C3/17-50	Description	3C14/17-61
Removal and Installation of		Removal and Installation.	3C16/17-63
Overhead Console Instru-		Stall Warning Switch	3C16/17-63
ment Panel Lights	3C9/17-56	Description	3C16/17-63
Vertical Adjustment of Over-		Removal and Installation.	3C16/17-63
head Console Instrument		Pitot and Stall Warning	
Panel Lights	3C9/17-56	Heaters	3C16/17-63
Lateral Adjustment of Over-		Description	3C16/17-63
head Console Instrument		Removal and Installation.	3C16/17-63
Panel Lights	3C9/17-56	Landing Gear Indicator Lights	3C16/17-63
Electroluminescent Panel		Description	3C16/17-63
Lighting	3C9/17-56	Removal and Installation.	3C17/17-64
Description	3C9/17-56	Landing Gear Warning Horn	3C17/17-64
Transistorized Light Dimming	3C9/17-56	Cigar Lighter	3C17/17-64
Description	3C9/17-56	Description	3C17/17-64
Removal and Installation.	3C9/17-56	Removal and Installation	3C17/17-64
Pedestal Lights	3C9/17-56	Emergency Locator Transmitter.	
Description	3C9/17-56	Thru 21061715	3C19/17-66
Removal and Installation.	3C9/17-56	Description	3C19/17-66
Instrument Post Lighting	3C9/17-56	Operation	3C19/17-66
Description	3C9/17-56	Operational Test of Emergency	
Removal and Installation.	3C9/17-56	Locator System	3C19/17-66
Oxygen Lights	3C9/17-56	Removal and Installation	
Description	3C9/17-56	of Transmitter	3C21/17-68
Removal and Installation.	3C9/17-56	Removal and Installation	
Courtesy Lights	3C12/17-59	of Antenna	3C21/17-68
Description	3C12/17-59	Removal and Installation	
Removal and Installation.	3C12/17-59	of Lithium Four-Cell	
Baggage Compartment Light	3C12/17-59	Battery Pack	3C21/17-68
Description	3C12/17-59	Trouble Shooting	3C22/17-68A
Removal and Installation.	3C12/17-59	Emergency Locator Transmitter.	
Interior Lighting	3C12/17-59	Beginning with 21061716	3C23/17-69
Description	3C12/17-59	Description	3C23/17-69
Removal and Installation.	3C12/17-59	Operation	3C24/17-70
Control Wheel Map Light	3C14/17-61	Operational Test of Emergency	
Description	3C14/17-61	Locator System	3C24/17-70
Removal and Installation.	3C14/17-61	Removal and Installation	
Compass and Radio Dial		of Transmitter	3C24/17-70
Lights	3C14/17-61	Removal and Installation	
Description	3C14/17-61	of Antenna	3D4/17-74
		Removal and Installation	
		of Battery Pack	3D4/17-74
		Trouble Shooting	3D5/17-75
		Electrical Load Analysis Chart	3D6/17-76

MODEL 210 & T210 SERIES SERVICE MANUAL

17-1. ELECTRICAL SYSTEMS.

17-2. GENERAL. This section contains service information necessary to maintain the Aircraft Electrical Power Supply System, Battery and External Power Supply System, Alternator Power System, Aircraft Lighting System, Pitot Heater, Stall Warning, Cigar Lighter, and Electrical Load Analysis.

17-3. ELECTRICAL POWER SUPPLY SYSTEM.

17-4. DESCRIPTION. Energy for the aircraft is supplied by a 28-volt, direct-current, single wire, negative ground electrical system. A 24-volt battery supplies power for starting and furnishes a reserve in event of alternator failure. An alternator is the normal source of power during flight and maintains a battery charge controlled by a voltage regulator. An external power source receptacle may be installed to supplement the battery alternator system for starting and ground operation.

17-5. SPLIT BUS BAR.

17-6. DESCRIPTION. Electrical power is supplied through two bus bars. Thru 1977 Models one bus bar is located on the lower left hand side of the instrument panel. This bus bar supplies power to the electrical equipment. The other bus bar powers the electronic equipment, and is located on the left hand cabin side forward of the cabin door. Beginning with 1978 Models both bus bars are located on the cabin side forward of the left hand door. A avionics master switch is installed on the electronic bus bar to prevent transient voltages from damaging the semiconductor circuitry in the electronic installations.

17-7. REMOVAL AND INSTALLATION. (Refer to figure 17-1.)

17-8. MASTER SWITCH.

17-9. DESCRIPTION. The operation of the battery and alternator systems is controlled by a master switch. The switch is an interlocking split rocker with the battery mode on the right-hand side and the alternator mode on the left-hand side. This arrangement allows the battery to be on the line without the alternator, however, operation of the alternator without the battery on the line is not possible. The switch is labeled "BAT" and "ALT" below the switch and is located on the left-hand side of the switch panel.

17-10. AMMETER.

17-11. DESCRIPTION. The ammeter is connected between the battery and the aircraft bus. The meter indicates the amount of current flowing either to or from the battery. With a low battery and the engine operating at cruise speed the ammeter will show the full alternator output when all electrical equipment is off. When the battery is fully charged and cruise RPM is maintained with all electrical equipment off, the ammeter will show a minimum charging rate.

17-12. BATTERY POWER SYSTEM.

17-13. BATTERY.

17-14. DESCRIPTION. The battery is 24 volts and thru 21062273 a 14 ampere-hour capacity battery is installed as standard, a 17 ampere-hour capacity battery is optional. Beginning with 21062274 the battery is 24 volts with a 12.75 ampere-hour capacity as standard and a 15.5 ampere-hour capacity battery as optional. The battery is mounted on the forward left side of the firewall and is equipped with non-spill caps.

MODEL 210 & T210 SERIES SERVICE MANUAL

17-15. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
BATTERY WILL NOT SUPPLY POWER TO BUS OR IS INCAPABLE OF CRANKING ENGINE	Battery discharged.	1. Measure voltage at "BAT" terminal of battery contactor with master switch and a suitable load such as a taxi light turned on. Normal battery will indicate 23 volts. If voltage is low proceed to step 2. If voltage is normal proceed to step 3.
	Battery faulty.	2. Check fluid level in cells and charge at 28 volts for approximately 30 minutes or until battery voltage rises to 28 volts. If tester indicates a good battery, the malfunction may be assumed to be a discharged battery. If tester indicates a faulty battery, replace the battery.
	Faulty contactor or wiring between contactor and master switch.	3. Measure voltage at master switch terminal (smallest) on contactor with master switch closed. Normal indication is zero volts. If voltage reads zero, proceed to step 4. If a voltage reading is obtained, check wiring between contactor and master switch. Also check master switch.
	Open coil on contactor.	4. Check continuity between "BAT" terminal and master switch terminal of contactor. Normal indication is 50-70 ohms. If ohmmeter indicates an open coil, replace contactor. If ohmmeter indicates a good coil, proceed to step 5.
	Faulty contactor contacts.	5. Check voltage on "BUS" side of contactor with master switch closed. Meter normally indicates battery voltage. If voltage is zero or intermittent, replace contactor. If voltage is normal, proceed to step 6.
	Faulty wiring between contactor and bus.	6. Inspect wiring between contactor and bus. Repair or replace wiring.

MODEL 210 & T210 SERIES SERVICE MANUAL






Figure 17-1. Circuit Breaker Installation (Sheet 1 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL



Detail B



1978 AND 1979 MODELS


VIEWED FROM THE BACK SIDE OF THE SWITCH PANEL (TYPICAL INSTALLATION)

Detail A

- | | |
|--------------------------------------|--|
| 1. Rheostat | 17. Alternator Circuit Breaker |
| 2. Instrument Panel | 18. Alternator Regulator Circuit Breaker |
| 3. E L Panel | 19. Fuel Pump Circuit Breaker |
| 4. Set Screw | 20. Fuel Quantity Circuit Breaker |
| 5. Engine and Radio Light Control | 21. Pitot Heat Circuit Breaker |
| 6. E L Panel Light Control | 22. Windshield Anti-Ice Circuit Breaker |
| 7. Flood Light Control | 23. Prop Anti-Ice Circuit Breaker |
| 8. Post Light Control | 24. Wing De-Ice Circuit Breaker |
| 9. Resistor | 25. Gear Pump Circuit Breaker |
| 10. Landing Light Circuit Breaker | 26. Landing Gear Circuit Breaker |
| 11. Taxi Light Circuit Breaker | 27. Turn Coordinator Circuit Breaker |
| 12. Strobe Light Circuit Breaker | 28. Stall Warning Circuit Breaker |
| 13. Flashing Beacon Circuit Breaker | 29. Electric Trim Circuit Breaker |
| 14. Navigation Light Circuit Breaker | 30. Flap Circuit Breaker |
| 15. Cabin Light Circuit Breaker | 31. Bus Bar |
| 16. Instrument Light Circuit Breaker | |

Figure 17-1. Circuit Breaker Installation (Sheet 2 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL



1980 THRU 1982 MODELS


VIEWED FROM THE BACK SIDE OF THE CIRCUIT BREAKER PANEL (TYPICAL INSTALLATION)

Detail A

- | | |
|--|--|
| 1. Bus Bar | 16. Avionics Fan Circuit Breaker |
| 2. Avionics Master Switch | 17. Wing De-ice Circuit Breaker |
| 3. Landing Gear Circuit Breaker | 18. Gear Pump Circuit Breaker |
| 4. Taxi Light Circuit Breaker | 19. Electric Trim Circuit Breaker |
| 5. Tail Floodlight Circuit Breaker | 20. Alternator Circuit Breaker |
| 6. Beacon Circuit Breaker | 21. Alternator Regulator Circuit Breaker |
| 7. Strobe Light Circuit Breaker | 22. Landing Gear Circuit Breaker |
| 8. Navigation Light Circuit Breaker | 23. Stall Warning Circuit Breaker |
| 9. Instrument Light Circuit Breaker | 24. Fuel Quantity Circuit Breaker |
| 10. Cabin Light Circuit Breaker | 25. Turn Coordinator Circuit Breaker |
| 11. Radio & Instrument Light Circuit Breaker | 26. Engine Instrument Circuit Breaker |
| 12. Flap Circuit Breaker | 27. Fuel Pump Circuit Breaker |
| 13. Air Condition Circuit Breaker | 28. Pitot Heat Circuit Breaker |
| 14. A/C Fan Circuit Breaker | 29. Windshield Anti-ice Circuit Breaker |
| 15. Vent Fan Circuit Breaker | 30. Prop Anti-ice |

Figure 17-1. Circuit Breaker Installation (Sheet 3 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL



BEGINNING WITH 1983 MODELS

VIEWED FROM THE BACK SIDE OF THE CIRCUIT BREAKER PANEL (TYPICAL INSTALLATION)

- | | |
|--|---|
| 1. Gear Lights Circuit Breaker | 16. Wing De-Ice Circuit Breaker |
| 2. Alternators Low Volt Lights Circuit Breaker | 17. Gear Pump Circuit Breaker |
| 3. Stall/Gear Horn Circuit Breaker | 18. Trim Circuit Breaker |
| 4. Radio and Instrument Lights Circuit Breaker | 19. Flap Circuit Breaker |
| 5. Cabin Lights Circuit Breaker | 20. Cond Fan Circuit Breaker |
| 6. Instrument Flood Lights Circuit Breaker | 21. Prop Anti-Ice Circuit Breaker |
| 7. Navigation Light Circuit Breaker | 22. Windshield Anti-Ice Circuit Breaker |
| 8. Strobe Flood Circuit Breaker | 23. Pitot Heat Circuit Breaker |
| 9. Flashing Beacon Circuit Breaker | 24. Stall Heat Circuit Breaker |
| 10. Taxi Light Circuit Breaker | 25. Fuel Pump Circuit Breaker |
| 11. Landing Light Circuit Breaker | 26. Engine Instrument Circuit Breaker |
| 12. Alternator 2 Regulator Circuit Breaker | 27. Turn Coordinator Circuit Breaker |
| 13. Alternator 1 Regulator Circuit Breaker | 28. Fuel Quantity Circuit Breaker |
| 14. Alternator 2 Circuit Breaker | 29. Bus Bar |
| 15. Alternator 1 Circuit Breaker | |

Figure 17-1. Circuit Breaker Installation (Sheet 4 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL

17-16. REMOVAL AND INSTALLATION OF THE BATTERY. (Refer to figure 17-2).

- a. To gain access to the battery, remove the upper left half of cowling.
- b. Remove the battery box lid and disconnect the battery ground cable.

CAUTION

Always remove the ground cable first and connect it last to prevent accidentally shorting the battery to the airframe with tools.

- c. Disconnect the positive cable from the battery and remove the battery from the aircraft.
- d. To install a battery, reverse this procedure.

17-17. CLEANING THE BATTERY. For maximum efficiency, the battery and connections should be kept clean at all times.

- a. Remove the battery in accordance with preceding paragraph.
- b. Tighten battery cell filler caps to prevent the cleaning solution from entering the cells.
- c. Wipe battery cable ends, battery terminals and entire surface of the battery with a clean cloth moistened with a solution of bicarbonate of soda (baking soda) and water.
- d. Rinse with clear water, wipe off excess water and allow battery to dry.
- e. Brighten up cable ends and battery terminals with emery cloth or a wire brush.
- f. Install the battery according to the preceding paragraph.
- g. Coat the battery terminals and the cable ends with petroleum jelly.

17-18. ADDING ELECTROLYTE OR WATER TO THE BATTERY. A battery being charged and discharged with use will decompose the water from the electrolyte by electrolysis. When the water is decomposed, hydrogen and oxygen gases are formed which escape into the atmosphere through the battery vent system. The acid in the solution chemically combines with the plates of the battery during discharge or is suspended in the electrolyte solution during charge. Unless the electrolyte has been spilled from a battery, acid should not be added to the solution. The water will decompose into gases and should be replaced regularly. Add distilled water as necessary to maintain the electrolyte level, (thru 21062273 the 12-GCAB-9 battery) 3/8 inch above separators, (beginning with 21062274 the G-240 and G-242 batteries) to the bottom of split ring. When "dry charged" batteries are put into service, fill as directed with electrolyte. However as the electrolyte level falls below normal with use add only distilled water to maintain the proper level. The battery electrolyte contains approximately 25% sulphuric acid by volume. Any change in this volume will hamper the proper operation of the battery.

CAUTION

Do not add any type of "battery rejuvenator"

to the electrolyte. When acid has been spilled from a battery, the acid balance may be adjusted by following instructions published by the Association of American Battery Manufacturers.

17-19. TESTING THE BATTERY. The specific gravity check method of testing the battery is preferred when the condition of the battery is in a questionable state-of-charge. However, when the aircraft has been operated for a period of time with an alternator output voltage which is known to be correct, the question of battery capability may be answered more correctly with a load type tester. If testing the battery is deemed necessary, the specific gravity should be checked first and compared with the following chart.

BATTERY HYDROMETER READINGS

1. 280 Specific Gravity	100% Charged
1. 250 Specific Gravity	75% Charged
1. 220 Specific Gravity	50% Charged
1. 190 Specific Gravity	25% Charged
1. 160 Specific Gravity	Practically Dead

NOTE

All readings shown are for an electrolyte temperature of 80°F (27°C). For higher temperatures the readings will be slightly lower. For cooler temperatures the readings will be slightly higher. Some hydrometers have a built-in temperature compensation chart and a thermometer. If this type tester is used, disregard this chart.

If the specific gravity reading indicates the battery is not fully charged the battery should be charged. The charging rate for the 12-GCAB-9 battery is 2 amps to start and finish at 1 amp, on the G-240 battery, 2 amps and on the G-242 battery, 3 amps.

17-20. CHARGING THE BATTERY. When the battery is to be charged, the level of electrolyte should be checked and adjusted by adding distilled water to cover the tops of the internal battery plates. The battery cables and connections should be clean. Remove the battery from the aircraft and place in a well ventilated area for charging.

WARNING

When a battery is charging, hydrogen and oxygen gases are generated. Accumulation of these gases can create a hazardous explosive condition. Always keep sparks and open flame away from the battery. Allow unrestricted ventilation of the battery area during charging.

The main points of consideration during a battery charge are excessive battery temperature and violent gassing. Under a reasonable rate of charge, the battery temperature should not rise over 115°F (46°C) (see paragraph 17-19), nor should gassing be so violent that acid is blown from the vents.

MODEL 210 & T210 SERIES SERVICE MANUAL

17-21. BATTERY BOX.

17-22. DESCRIPTION. The battery is completely enclosed in a box which is painted with acid proof paint. The box has a vent tube which protrudes through the bottom of the aircraft allowing battery gases and spilled electrolyte to escape. The battery box is riveted to the left forward side of the firewall.

17-23. REMOVAL AND INSTALLATION. (Refer to figure 17-2.) The battery box is riveted to the firewall. The rivets must be drilled out to remove the box. When a battery box is installed and riveted into place, all rivets and scratches inside the box should be painted with acid-proof lacquer, available from Pratt and Lambert United - Performance Coatings Division, P. O. Box 2153, Wichita, KS 67201.

17-24. MAINTENANCE. The battery box should be inspected and cleaned periodically. The box and cover should be cleaned with a strong solution of bicarbonate of soda (baking soda) and water. Hard deposits may be removed with a wire brush. When all corrosive deposits have been removed from the box, flush it thoroughly with clean water.

WARNING

Do not allow acid deposits to come in contact with skin or clothing. Serious acid burns may result unless the affected area is washed immediately with soap and water. Clothing will be ruined upon contact with battery acid.

Inspect the cleaned box and cover for physical damage and for areas lacking proper acid proofing. A badly damaged or corroded box should be replaced. If the box or lid require acid proofing, paint the area with acid-proof black lacquer, available from Pratt and Lambert United - Performance Coatings Division, P. O. Box 2153, Wichita, KS 67201.

17-25. BATTERY CONTACTOR.

17-26. DESCRIPTION. The battery contactor is bolted to the firewall below the battery box. The contactor is a solenoid plunger type, which is actuated by turning the master switch on. When the master switch is off, the battery is disconnected from the electrical system. A silicon diode is used to eliminate spiking of the transistorized radio equipment. The cathode (+) terminal of the diode connects to the battery terminal of the battery contactor. The anode (-) terminal of the diode connects to the same terminal of the diode connects to the same terminal on the contactor as the master switch wire. This places the diode directly across the contactor solenoid coil so that inductive spikes originating in the coil are clipped when the master switch is opened. (Refer to figure 17-2).

17-27. REMOVAL AND INSTALLATION. (Refer to figure 17-2.)

a. Open battery box (2) and disconnect ground cable (8) from negative battery terminal. Pull cable clear of battery box.

b. Remove the nut, lockwasher, and two plain washers securing the battery cables to the battery contactor (4).

c. Remove nut, lockwasher, and two plain washers securing the wire which is routed to the master switch.

d. Remove bolt, washer, and nut securing each side of the battery contactor (4). The contactor will now be free for removal.

e. To replace the contactor, reverse this procedures.

17-28. BATTERY CONTACTOR CLOSING CIRCUIT. (Refer to figure 17-3). This circuit consists of a 5-amp fuse, a resistor and a diode mounted on the ground service receptacle bracket. This serves to shunt a small charge around the battery contactor so that ground power may be used to close the contactor when the battery is too low to energize the contactor by itself.

17-29. GROUND SERVICE RECEPTACLE.

17-30. DESCRIPTION. A ground service receptacle is installed to permit the use of external power for cold weather starting or when performing lengthy electrical maintenance. A reverse polarity protection system is utilized whereby ground power must pass through an external power contactor to be connected to the bus. A silicon junction diode is connected in series with the coil on the external power contactor so that if the ground power source is inadvertently connected with a reversed polarity, the external power contactor will not close. This feature protects the diodes in the alternator, and other semiconductor devices used in the aircraft, from possible reverse polarity damage.

NOTE

Maintenance of the electronic installations cannot be performed when using external power. Application of external power opens the relay supplying voltage to the electronics bus. For lengthy ground testing of electronic systems, connect a well regulated and filtered power supply directly to the battery side of the battery contactor. Adjust the supply for 28 volts and close the master switch.

NOTE

When using ground power to start aircraft, close the master switch before removing ground power plug. This will ensure closure of battery contactor and excitation of the alternator field.

CAUTION

Failure to observe polarity when connecting an external power source directly to the battery or directly to the battery side of the battery contactor, will damage the diodes in the alternator and other semiconductor devices in the aircraft.

NOTE

On Aircraft Serials 21061574 thru 21062334 refer to Cessna Single-engine Service Letter SE78-19, dated March 27, 1978.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 17-2. Battery and Electrical Equipment Installation (Sheet 1 of 5)

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 17-2. Battery and Electrical Equipment Installation (Sheet 2 of 5)

MODEL 210 & T210 SERIES SERVICE MANUAL



Detail A
(Cover Removed)
THRU 21064135

* BEGINNING WITH 21062274

* BEGINNING WITH 1979 MODELS

Figure 17-2. Battery and Electrical Equipment Installation (Sheet 3 of 5)

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 17-2. Battery and Electrical Equipment Installation (Sheet 4 of 5)

MODEL 210 & T210 SERIES SERVICE MANUAL



Detail **B**

BEGINNING WITH 21064136

Figure 17-2. Battery and Electrical Equipment Installation (Sheet 5 of 5)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 17-3. Ground Service Receptacle Installation (Sheet 1 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 17-3. Ground Service Receptacle Installation (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 17-3. Ground Service Receptacle Installation (Sheet 3 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL

17-31. TROUBLE SHOOTING.

TROUBLE	PROBABLE CAUSE	REMEDY
GROUND POWER WILL NOT CRANK ENGINE.	Ground service connector wired incorrectly.	1. Check for voltage at all three terminals of external power contactor with ground power connected and master switch off. If voltage is present on input and coil terminals but not on the output terminal, proceed to step 4. If voltage is present on the input terminal but not on the coil terminal, proceed to step 2. If voltage is present on all three terminals, check wiring between contactor and bus.
		2. Check for voltage at small terminal of ground service receptacle. If voltage is not present, check ground service plug wiring. If voltage is present, proceed to step 3.
	Open or mis-wired diode on ground service diode board assembly.	3. Check polarity and continuity of diode on diode board at rear of ground service receptacle. If diode is open or improperly wired, replace diode board assembly.
	Faulty external power contactor.	4. Check resistance from small (coil) terminal of external power contactor to ground (master switch off and ground power unplugged). Normal indication is 50-70 ohms. If resistance indicates an open coil, replace contactor. If resistance is normal, proceed to step 5.
	Faulty contacts in external power contactor.	5. With master switch off and ground power applied, check for voltage drop between two large terminals of external power (turn on taxi light for a load). Normal indication is zero volts. If voltage is intermittently present or present all the time, replace contactor.

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 17-4. Alternator Installation (Sheet 1 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




* TORQUE TO 165 ± 10 IN LBS.

* TORQUE TO 450 - 500 IN LBS.

BEGINNING WITH 21062650,
21062662 AND 21062667 & ON

Figure 17-4. Alternator Installation (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL



* TORQUE 165 ± 10 in. lb.

* TORQUE 450 to 500 in. lb.

**NON-SHOCKMOUNTED
95 AMP ALTERNATOR**

BEGINNING WITH 1978 MODELS

1. Arm-Adjusting
2. Washer
3. Bolt
4. Safety Wire
5. Drive Belt
6. Support
7. Nut
8. Alternator

NOTE

On Aircraft Serials 21062274
thru 21062716 refer to Cessna
Single -Engine Service Letter
SE78-65 Dated November 6,
1978.

Figure 17-4. Alternator Installation (Sheet 3 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL

17-38. TROUBLE SHOOTING THE ALTERNATOR SYSTEM (THRU 1978 MODELS).

a. ENGINE NOT RUNNING.

TROUBLE	PROBABLE CAUSE	REMEDY
AMMETER INDICATES HEAVY DISCHARGE OR ALTERNATOR CIRCUIT BREAKER OPENS. (Battery Switch ON, Alternator Switch OFF, all other electrical switches OFF.)	Shorted diode in alternator.	Turn off Battery Switch and remove "B" Lead from alternator. Check resistance from "B" Terminal of alternator to alternator case. Reverse leads and check again. Resistance reading may show continuity in one direction but should show an infinite reading in the other direction. If an infinite reading is not obtained in at least one direction, repair or replace alternator.
ALTERNATOR REGULATOR CIRCUIT BREAKER OPENS WHEN BATTERY AND ALTERNATOR SWITCHES ARE TURNED ON.	Short in Over-Voltage sensor.	Disconnect Over-Voltage Sensor plug and recheck. If circuit breaker stays in replace Over-Voltage Sensor.
	Short in alternator voltage regulator.	Disconnect regulator plug and recheck. If circuit breaker stays in, replace regulator.
	Short in alternator field.	Disconnect "F" terminal wire and recheck. If circuit breaker stays in, replace alternator.

b. ENGINE RUNNING.

ALTERNATOR CIRCUIT BREAKER OPENS WHEN BATTERY AND ALTERNATOR SWITCHES ARE TURNED ON, OVER-VOLTAGE LIGHT DOES NOT COME ON.	Defective circuit breaker.	Replace circuit breaker.
ALTERNATOR REGULATOR CIRCUIT BREAKER OPENS WHEN BATTERY AND ALTERNATOR SWITCHES ARE TURNED ON, OVER-VOLTAGE LIGHT DOES NOT COME ON	Shorted field in alternator.	Check resistance from "F" terminal of alternator to alternator case. if resistance is less than 5 ohms repair/replace.

CAUTION

This malfunction frequently causes a shorted regulator which will result in an over-voltage condition when system is again operated.

MODEL 210 & T210 SERIES SERVICE MANUAL

17-38. TROUBLE SHOOTING THE ALTERNATOR SYSTEM (THRU 1978 MODELS) (Cont.) b. ENGINE RUNNING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
ALTERNATOR MAKES ABNORMAL WHINING NOISE.	Shorted diode in alternator.	Turn off Battery Switch and remove "B" Lead from alternator. Check resistance from "B" Terminal of alternator to alternator case. Reverse leads and check again. Resistance reading may show continuity in one direction but should show an infinite reading in the other direction. If an infinite reading is not obtained in at least one direction, repair or replace alternator.
OVER-VOLTAGE LIGHT DOES NOT GO OUT WHEN ALTERNATOR AND BATTERY SWITCHES ARE TURNED ON.	Shorted regulator.	Replace regulator.
	Defective over-voltage sensor.	Replace sensor.
AFTER ENGINE START WITH ALL ELECTRICAL EQUIPMENT TURNED OFF CHARGE RATE DOES NOT TAPER OFF IN 1-3 MINUTES	Regulator faulty or high resistance in field circuit.	With engine not running turn off all electrical loads and turn on battery and alternator switches. Measure bus voltage to ground, then measure voltage from terminal of alternator to ground. If there is more than 2 volts difference check field circuit wiring shown on alternator system wiring diagram in Section 19. Clean all contacts. Replace components until there is less than 2 volts difference between bus voltage and field voltage.
<p>NOTE</p> <p>Also refer to battery power system trouble shooting chart.</p>		
ALTERNATOR SYSTEM WILL NOT KEEP BATTERY CHARGED.	Alternator output voltage insufficient.	1. Connect voltmeter between D. C. Bus and ground. Turn off all electrical loads. Turn on Battery Switch, start engine and adjust for 1500 RPM. Voltage should read approximately 24 volts. Turn on alternator switch, voltage should read between 27.4 and 28.0 volts. Ammeter should indicate a heavy charge rate which should taper off in 1-3 minutes. If charge rate tapers off very

MODEL 210 & T210 SERIES SERVICE MANUAL

17-38. TROUBLE SHOOTING THE ALTERNATOR SYSTEM (THRU 1978 MODELS) (Cont.)
 b. ENGINE RUNNING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
ALTERNATOR SYSTEM WILL NOT KEEP BATTERY CHARGED. (Cont.)	Alternator output voltage insufficient (cont).	quickly and voltage is normal, check battery for malfunction. If ammeter shows a low charge rate or any discharge rate, and voltage does not rise when alternator switch is turned on proceed to Step 2.
		2. Stop engine, turn off all switches. Connect voltmeter between "F" terminal of alternator and ground. Do NOT start engine. Turn on battery switch and alternator switch. Battery voltage should be present at "F" terminal, less 1 volt drop thru regulator, if not refer to Step 3.
		3. Starting at "F" terminal of alternator trace circuit to voltage regulator, at "B" terminal of regulator trace circuit to over-voltage sensor, to master switch, to Bus Bar. Replace component which does not have voltage present at output. Refer to alternator system wiring diagram in Section 19.
	Alternator field winding open.	1. If voltage is present turn off alternator and battery switches. Check resistance from "F" terminal of alternator to alternator case, turning alternator shaft during measurement. Normal indication is 12-20 ohms. If resistance is high or low, repair or replace alternator. If ok refer to Step 2.
		2. Check resistance from case of alternator to airframe ground. Normal indication is very low resistance. If reading indicates no, or poor continuity, repair or replace alternator ground wiring.

MODEL 210 & T210 SERIES SERVICE MANUAL

17-38A. TROUBLE SHOOTING THE ALTERNATOR SYSTEM (BEGINNING WITH 1979 MODELS).

a. ENGINE NOT RUNNING.

TROUBLE	PROBABLE CAUSE	REMEDY
<p>AMMETER INDICATES HEAVY DISCHARGE OR ALTERNATOR CIRCUIT BREAKER OPENS. (Battery Switch ON, Alternator Switch OFF, all other electrical switches OFF.)</p>	Shorted diode in alternator.	Turn off Battery Switch and remove "B" Lead from alternator. Check resistance from "B" Terminal of alternator to alternator case. Reverse leads and check again. Resistance reading may show continuity in one direction but should show an infinite reading in the other direction. If an infinite reading is not obtained in at least one direction, repair or replace alternator.
<p>ALTERNATOR REGULATOR CIRCUIT BREAKER OPENS WHEN BATTERY AND ALTERNATOR SWITCHES ARE TURNED ON.</p>	Short in alternator control unit.	Disconnect Over-Voltage Sensor plug and recheck. If circuit breaker stays in replace Over-Voltage Sensor.
	Short in alternator field.	Disconnect alternator control unit plug and recheck. If circuit breaker stays in, replace alternator control unit.
		Disconnect "F" terminal wire and recheck. If circuit breaker stays in, replace alternator
<p>b. ENGINE RUNNING.</p> <p>ALTERNATOR CIRCUIT BREAKER OPENS WHEN BATTERY AND ALTERNATOR SWITCHES ARE TURNED ON. LOW-VOLTAGE LIGHT DOES NOT COME ON.</p>	Defective circuit breaker	Replace circuit breaker.
<p>ALTERNATOR REGULATOR CIRCUIT BREAKER OPENS WHEN BATTERY AND ALTERNATOR SWITCHES ARE TURNED ON, LOW-VOLTAGE LIGHT MAY OR MAY NOT COME ON.</p>	Shorted field in alternator.	Check resistance from "F" terminal of alternator to alternator case, if resistance is less than 5 ohms repair/replace.
<p>CAUTION</p> <p>This malfunction may cause a shorted alternator control unit, which will result in an over-voltage condition when system is again operated.</p>		

MODEL 210 & T210 SERIES SERVICE MANUAL

17-38A. TROUBLE SHOOTING THE ALTERNATOR SYSTEM (BEGINNING WITH 1979 MODELS) (Cont.)

b. ENGINE RUNNING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
ALTERNATOR MAKES ABNORMAL WHINING NOISE.	Shorted diode in alternator.	Turn off Battery Switch and remove "B" Lead from alternator. Check resistance from "B" Terminal of alternator to alternator case. Reverse leads and check again. Resistance reading may show continuity in one direction but should show an infinite reading in the other direction. If an infinite reading is not obtained in one direction, repair or replace alternator.
LOW-VOLTAGE LIGHT DOES NOT GO OUT WHEN ALTERNATOR AND BATTERY SWITCHES ARE TURNED ON.	Shorted alternator control unit.	Replace alternator control unit.
	Defective low-voltage sensor.	Replace alternator control unit.
AFTER ENGINE START WITH ALL ELECTRICAL EQUIPMENT TURNED OFF CHARGE RATE DOES NOT TAPER OFF IN 1-3 MINUTES	Alternator control unit faulty or high resistance in field circuit	With engine not running turn off all electrical loads and turn on battery and alternator switches. Measure bus voltage to ground, then measure voltage from terminal of alternator to ground. If there is more than 2 volts difference check field circuit wiring shown in alternator system wiring diagram in Section 19. Clean all contacts. Replace components until there is less than 2 volts difference between bus voltage and field voltage.
<p>NOTE</p> <p>Also refer to battery power system trouble shooting chart.</p>		
ALTERNATOR SYSTEM WILL NOT KEEP BATTERY CHARGED.	Alternator output voltage insufficient.	<p>1. Connect voltmeter between D. C. Bus and ground. Turn off all electrical loads. Turn on Battery Switch, start engine and adjust for 1500 RPM, voltage should read approximately 24 volts. Turn on alternator switch, voltage should read between 28.4 and 28.9 volts. Ammeter should indicate a heavy charge rate which should taper off in 1-3 minutes. If charge rate tapers off very quickly and voltage is normal, check battery for malfunction. If ammeter shows a low charge rate or any discharge rate, and voltage does not rise when alternator switch is turned on proceed to Step 2.</p>

MODEL 210 & T210 SERIES SERVICE MANUAL

17-38A. TROUBLE SHOOTING THE ALTERNATOR SYSTEM (BEGINNING WITH 1979 MODELS) (Cont.) b. ENGINE RUNNING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
ALTERNATOR SYSTEM WILL NOT KEEP BATTERY CHARGED. (Cont.)	Alternator output voltage insufficient (cont.)	<p>2. Stop engine. turn off all switches. Connect voltmeter between "F" terminal of alternator and ground. Do NOT start engine. Turn on battery switch and alternator switch. Battery voltage should be present at "F" terminal, less 1 volt drop thru regulator. if not refer to Step 3.</p> <p>3. Starting at "F" terminal of alternator. trace circuit to alternator control unit at Pin 1 (Blue Wire). Trace circuit from Pin 3 (Red Wire) to master switch. to Bus Bar. Trace circuit from alternator control unit Pin 2 (Orange Wire) to alternator "BAT" terminal. Check connections and replace component which does not have voltage present at output. Refer to alternator system wiring diagram in Section 19.</p>
	Alternator field winding open.	<p>1. If voltage is present turn off alternator and battery switches. Check resistance from "F" terminal of alternator to alternator case. turning alternator shaft during measurement. Normal indication is 12-20 ohms. If resistance is high or low. repair or replace alternator. If OK refer to Step 2.</p>
	Alternator output voltage insufficient.	<p>2. Check resistance from case of alternator to airframe ground. Normal indication is very low resistance. If reading indicates no. or poor continuity. repair or replace alternator ground wiring.</p>

17-39. REMOVAL AND INSTALLATION. (Refer to figure 17-4, Sheet 3, typical.)

- a. Make sure that master switch remains in the off position, or disconnect negative lead from battery.
- b. Disconnect wiring from the alternator.
- c. Remove safety wire (4) from the upper adjusting bolt (3), and remove bolt from alternator.
- d. Remove nut (7) and washer (2) from the lower mounting bolt.
- e. Remove alternator drive belt (5) and lower bolt (3) to remove alternator.
- f. To replace alternator, reverse this procedure.

- g. Adjust belt tension to obtain 3/8-inch deflection at the center of the belt when applying 12 pounds of pressure to the belt. After the belt is adjusted and the bolt is safety wired, tighten the bottom bolt to 100-140 lb-in torque on the 60 ampere alternator and 450-500 lb-in torque on the 95 ampere alternator to remove any play between the alternator mounting foot and the U-shaped support assembly.

CAUTION

On new aircraft or whenever a new belt is installed, belt tension should be checked within 10 to 25 hours of operation.

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

When tightening the alternator belt, apply pry bar pressure only to the end of the alternator nearest to the belt pulley.

17-40. ALTERNATOR VOLTAGE REGULATOR.

17-41. DESCRIPTION. A transistorized voltage regulator is installed on the aircraft. The regulator is adjustable, but adjustment on the aircraft is not recommended. A bench adjustment procedure is outlined in the Cessna Alternator Charging Systems Service/Parts Manual. A Cessna Alternator Charging System Test Box Assembly (Part No. 9870005-1) is available from Cessna Parts Distribution (CPD 2), through Cessna Service Stations, for use in isolating failures in the 28-volt transistorized voltage regulator (C611002-0105) and the 28-volt alternator.

17-42. REMOVAL AND INSTALLATION. (Refer to figure 17-5).

- a. Ensure that the master switch is off.
- b. Remove upper cowl to gain access to the regulator.
- c. Remove the connector plug from the regulator.
- d. Remove the three bolts holding the regulator on the firewall.
- e. To reinstall the regulator, reverse the preceding steps.

17-42A. ALTERNATOR CONTROL UNIT. (BEGINNING WITH 1979 MODELS.)

17-42B. DESCRIPTION. The alternator control unit is a solid state voltage regulator with an over-voltage sensor and a low-voltage sensor incorporated in the unit. The control unit is not adjustable and is a remove-and-replace item. A Cessna Alternator Charging System Test Box Assembly (Part No. 9870005-1) is available from Cessna Parts Distribution (CPD 2), through Cessna Service Stations, for use in isolating failures in the 28-volt alternator control units (C611005-0101 and C611005-0102) and the 28-volt alternator.

17-42C. REMOVAL AND INSTALLATION. (Refer to figure 17-5.)

- a. Thru 1980 Models remove upper half of engine cowl. Beginning with 1981 Models the control unit is mounted on the aft side of the battery box, under the instrument panel.
- b. Place master switch in the "OFF" position.
- c. Disconnect negative lead from the battery.
- d. Disconnect housing plug from the alternator control unit.
- e. Remove screws securing the control unit to the firewall.
- f. To install control unit reverse the preceding steps. Be sure the connections for grounding are clean and bright before assembly. Otherwise faulty voltage regulation and/or excessive radio noise may result.

17-43. OVER-VOLTAGE SENSOR AND WARNING LIGHT.

17-44. DESCRIPTION. The over-voltage system consists of a over-voltage sensor switch and a red warning light labeled, HIGH VOLTAGE, on the instrument panel. When an over-voltage tripoff occurs the over-voltage sensor turns off the alternator system and the red warning light comes on. The ammeter will show a discharge. Turn off the alternator portion of the master switch to recycle the over-voltage sensor. If the over-voltage condition was transient, the normal action is necessary. If the over-voltage tripoff recurs, then a generating system malfunction has occurred such that the electrical accessories must be operated from the aircraft battery only. Conservation of electrical energy must be practiced until the flight can be terminated. The over-voltage red warning light filament may be tested at any time by turning off the alternator portion of the master switch and leaving the battery portion turned on. This test does not induce an over-voltage condition on the electrical system. Beginning with 1979 Models the over-voltage sensor is contained within the alternator control unit. The unit also contains a low-voltage sensor. A red warning light labeled "LOW VOLTAGE" is installed on the instrument panel. When an over-voltage condition occurs the over-voltage sensor turns off the alternator and the voltage in the system drops. When system voltage drops below 24.8 volts the low-voltage sensor turns on the low-voltage light indicating a drain on the battery and the ammeter will show a discharge. Turn off both sections of the master switch to recycle the over-voltage sensor. If the over-voltage condition was transient, the normal alternator charging will resume and no further action is necessary. If the over-voltage tripoff recurs, then a generating system malfunction has occurred such that the electrical accessories must be operated from the aircraft battery only. Conservation of electrical energy must be practiced until the flight can be terminated. The over-voltage light filament may be tested at any time by turning off the "Alternator" portion of the master switch and leaving the battery portion on. This test does not induce an over-voltage condition on the electrical system.

NOTE

On 1979 thru 1982 models if the alternator low voltage light comes on when a COM radio transmitter is keyed, refer to Cessna Single Engine Customer Care Service Information Letter SE82-17 Dated April 30, 1982.


17-45. REMOVAL AND INSTALLATION. (Refer to figure 17-6.)

- a. Turn master switch (BATT side) to OFF position.
- b. Disconnect plug.
- c. Remove mounting screws and remove relay.
- d. To install reverse the procedure.

17-46. TIGGING THROTTLE-OPERATED MICRO-SWITCH. Refer to Section 13.

17-47. AUXILIARY FUEL PUMP FLOW RATE ADJUSTMENT. Refer to Section 13.


MODEL 210 & T210 SERIES SERVICE MANUAL



- | | |
|--------------------------------|---------------------------------------|
| 1. Housing - Cap | 9. Alternator Control Unit |
| 2. Wire (to Alternator Ground) | 10. Terminal Block |
| 3. Voltage Regulator | 11. Spiral Wrap |
| 4. Screw | 12. Wire (to Circuit Breaker) |
| 5. Housing - Plug | 13. Wire (to Alternator Control Unit) |
| 6. Cover | 14. Wire (to Alternator) |
| 7. Sta-strap | 15. Ground Wire |
| 8. Clamp | 16. Spacer |

Figure 17-5. Voltage Regulator/Alternator Control Unit Installation (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL



Detail **A**

1. Sta-strap
2. Housing Cap
3. Housing Plug
4. Alternator Control Unit
5. Bracket
6. Battery Box
7. Ground Wire
8. Bolt

BEGINNING WITH 1981 MODELS

Figure 17-5. Voltage Regulator/Alternator Control Unit Installation (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 17-6. Over-Voltage Sensor Installation

MODEL 210 & T210 SERIES SERVICE MANUAL

17-47A. STANDBY GENERATOR SYSTEM.

17-47B. DESCRIPTION. The standby generator system may be installed on the aircraft beginning with 1980 models. The system provides a 24 volt DC, 7-amp capacity of standby power for the following essential electrical and avionic equipment in the event the main electrical system cannot be used; gear warning, stall warning, fuel quantity, turn coordinator, engine oil and cylinder head temp, also circuit breaker (radio 3) and (radio 1 or 2). The system consists of a standby generator, mounted on the engine accessory case, a voltage regulator, mounted on the upper right hand portion of the firewall, a two-position toggle OFF-ON switch and a two-position toggle radio selector switch (labeled NC1/NC2) installed on the circuit breaker panel. For trouble shooting and adjustments refer to the Standby Generator Charging Systems Manual, D5021-13, dated 15 September 1979.

17-47C. REMOVAL AND INSTALLATION. Refer to figure 17-6A.

17-47D. DUAL ALTERNATOR SYSTEM.

17-47E. DESCRIPTION. The dual alternator system consists of two belt-driven, 28 volt, 60 amp alternators, two alternator control units, two shunt and fuse assemblies, two line contactors, two alternator switches, two circuit breakers, a volt ammeter, a three light indicating system and a alternator restart system. An isolation circuit breaker is installed with the dual alternator system. Refer to the Pilots Operating Handbook for operational procedures.

17-47F. ALTERNATORS.

17-47G. DESCRIPTION. The alternators are belt-driven, 28 volt, 60 amp, three-phase, Delta connected stator windings with integral silicon diode rectifiers and a stator tap.

NOTE

Alternators are equal in function & capability, and normally operate under equal loads. Each may operate independently, but should not be thought of or operated as, a primary and secondary (or standby) system.

17-47H. REMOVAL AND INSTALLATION. (See figure 17-6B.)

17-47I. ALTERNATOR CONTROL UNITS.

17-47J. DESCRIPTION. The alternator control units are solid state voltage regulators with low voltage sensing internal paralleling circuitry in the alternator control units controls load sharing between the alternators.

17-47K. REMOVAL AND INSTALLATION. (See figure 17-6B.)

17-47L. ALTERNATOR CONTACTORS AND SHUNTS

17-47M. DESCRIPTION. Each alternator is equipped with a contactor and shunt. The shunt directs power through two fuses to the alternator control unit remote sensing and current sensing circuits. The shunt is also connected through fuses to the volt-ammeter selector switch which enables the pilot to monitor the electrical system operation.

17-47N. REMOVAL AND INSTALLATION. (See figure 17-6B.)

17-47O. VOLT-AMMETER.

17-47P. DESCRIPTION. The volt-ammeter is mounted on the left side of the instrument panel. A selector switch is provided for the pilot to monitor the electrical system operation. The selector switch allows the pilot to monitor the current supplied by each alternator, the battery charge or discharge current, or the system voltage.

17-47Q. ALTERNATOR RESTART SYSTEM. The alternator restart system consists of a battery pack and a switch. When the restart switch, on the circuit breaker panel is actuated, power is directed from the battery pack through the restart switch to the alternator switch. With the alternator switch closed power is directed to the alternator control unit then to the alternator field for excitation of the alternator.


NOTE

Batteries should be changed at yearly intervals or sooner if function test shows need. Correct polarity must be observed when installing batteries. No. 814 Ray-O-Vac or No. MN1400 Mallory or equivalent to No. E-93 Everready Batteries are recommended.

WARNING

Do not rely on contact between battery holder (78) and plate (79) to maintain spring contact on batteries. If required, end plates of the battery holder may be reformed inward slightly to increase contact pressure on batteries. Check continuity of battery pack before installation with battery pack suspended from plate and with curvature of plate reversed as in normal installation.

MODEL 210 & T210 SERIES SERVICE MANUAL



- 1. Bolt
- 2. Voltage Regulator
- 3. Rivnut

- 4. Generator
- 5. Clamp
- 6. Cooling Hose
- 7. Engine Baffle

- 8. Circuit Breakers
- 9. OFF-ON Switch
- 10. NC 1/NC 2 Switch

Figure 17-6A. Standby Generator System Installation.

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 17-6B. Dual Alternator System Installation (Sheet 1 of 8)

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 17-6B. Dual Alternator System Installation (Sheet 2 of 8)

MODEL 210 & T210 SERIES SERVICE MANUAL

● TORQUE 450 - 500 IN-LBS

* TORQUE 160 - 190 IN-LBS

* TORQUE 155 - 175 IN-LBS



Detail **B**

THRU 21064569

- 20. Bolt
- 21. Mount
- 22. Belt
- 23. Noise Filter
- 24. Nut
- 25. Washer
- 26. Bolt
- 27. Adjustment Bracket
- 28. Nipple
- 29. Wire (Alternator Shunt)
- 30. Wire (Field)
- 31. Wire (Remote Sense)
- 32. Wire (Ground)
- 33. Bolt
- 34. Wire (Alt OFF Sense)
- 35. Resistor
- 36. Insulator
- 37. Resistor
- 38. Washer
- 39. Screw
- 40. Alternator


Figure 17-6B. Dual Alternator System Installation (Sheet 3 of 8)

MODEL 210 & T210 SERIES SERVICE MANUAL

● TORQUE 450 - 500 IN-LBS

*TORQUE 160 - 190 IN-LBS

*TORQUE 155 - 175 IN-LBS




Detail B

BEGINNING WITH 21064570

- 20. Bolt
- 21. Mount
- 22. Belt
- 23. Noise Filter
- 24. Nut
- 25. Washer
- 26. Bolt
- 27. Adjustment Bracket
- 28. Nipple
- 29. Wire (Alternator Shunt)
- 30. Wire (Field)
- 31. Wire (Remote Sense)
- 32. Wire (Ground)
- 33. Bolt
- 34. Wire (Alt OFF Sense)
- 35. Resistor
- 36. Insulator
- 37. Resistor
- 38. Washer
- 39. Screw
- 40. Alternator
- 41. Safety Wire

Figure 17-6B. Dual Alternator System Installation (Sheet 4 of 8)

MODEL 210 & T210 SERIES SERVICE MANUAL



- 41. Cover
- 42. Wire (Circuit Breaker)
- 43. Contactor (Alternator No. 2)
- 44. Bracket
- 45. Bus Bar
- 46. Shunt (Alternator No. 2)
- 47. Shunt (Alternator No. 1)
- 48. Wire (to Alternator No. 1)
- 49. Wire (to Alternator No. 2)
- 50. Wire (Circuit Breaker)

Figure 17-6B. Dual Alternator System Installation (Sheet 5 of 8)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 17-6B. Dual Alternator System Installation (Sheet 6 of 8)

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 17-6B. Dual Alternator System Installation (Sheet 7 of 8)

MODEL 210 & T210 SERIES SERVICE MANUAL



Detail J

- 74. Clamp
- 75. Housing Cap
- 76. Housing Plug
- 77. Spacer
- 78. Bracket
- 79. Cover
- 80. Battery Holder
- 81. Battery Holder
- 82. Plate
- 83. Grommet

Figure 17-6B. Dual Alternator System Installation (Sheet 8 of 8)

MODEL 210 & T210 SERIES SERVICE MANUAL

17-48. AIRCRAFT LIGHTING SYSTEM.

17-49. DESCRIPTION. The aircraft lighting system consists of landing and taxi lights, navigation lights, flashing beacon light, anti-collision strobe lights, interior and instrument panel flood lights, electroluminescent panel lighting, instrument post lighting, pedestal lights, oxygen lights, courtesy lights, de-ice light, control wheel map light, baggage compartment light, compass and radio dial lights.

17-52. TROUBLE SHOOTING.

17-50. SWITCHES.

17-51. DESCRIPTION. The instrument panel switches used are snap-in type rocker switches. These switches have a design feature which permits them to snap into the panel from the panel side and can subsequently be removed for easy maintenance. These switches also feature spade type slip-on terminals.

TROUBLE	PROBABLE CAUSE	REMEDY
LANDING AND TAXI LIGHTS OUT.	Short circuit in wiring.	1. Inspect circuit breaker. If circuit breaker is open, proceed to step 2. If circuit breaker is OK, proceed to step 3.
	Defective wiring.	2. Test each circuit separately until short is located. Repair or replace wiring.
	Defective switch.	3. Check voltage at lights with master and landing and taxi light switches ON. Should read battery voltage. Replace switch.
LANDING OR TAXI LIGHT OUT.	Lamp burned out.	1. Test lamp with ohmmeter or new lamp. Replace lamp.
	Open circuit in wiring.	2. Test wiring for continuity. Repair or replace wiring.
FLASHING BEACON DOES NOT LIGHT.	Short circuit in wiring.	1. Inspect circuit breaker. If circuit breaker is open, proceed to step 2. If circuit breaker is OK, proceed to step 3.
	Defective wiring.	2. Test circuit until short is located. Repair or replace wiring.
	Lamp burned out.	3. Test lamp with ohmmeter or a new lamp. Replace lamp. If lamp is good, proceed to step 4.
	Open circuit in wiring.	4. Test circuit from lamp to flasher for continuity. If no continuity is present, repair or replace wiring. If continuity is present, proceed to step 5.
	Defective switch.	5. Check voltage at flasher with master and beacon switch on. Should read battery voltage. Replace switch. If voltage is present, proceed to step 6.
	Defective flasher.	6. Install new flasher.
FLASHING BEACON CONSTANTLY LIT.	Defective flasher.	1. Install new flasher.

MODEL 210 & T210 SERIES SERVICE MANUAL

17-52. TROUBLE SHOOTING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
ALL NAV LIGHTS OUT.	Short circuit in wiring.	1. Inspect circuit breaker. If circuit breaker is open, proceed to step 2. If circuit breaker is OK, proceed to step 3.
	Defective wiring.	2. Isolate and test each nav light circuit until short is located. Repair or replace wiring.
	Defective switch.	3. Check voltage at nav light with master and nav light switches on. Should read battery voltage. Replace switch.
ONE NAV LIGHT OUT.	Lamp burned out.	1. Inspect lamp. Replace lamp.
	Open circuit in wiring.	2. Test wiring for continuity. Repair or replace wiring.
<div style="border: 1px solid black; padding: 5px; display: inline-block; margin-bottom: 10px;">WARNING</div> <p>The anti-collision system is a high voltage device. Do not remove or touch tube assembly while in operation. Wait at least 5 minutes after turning off power before starting work.</p>		
BOTH ANTI-COLLISION STROBE LIGHTS WILL NOT LIGHT.	Open circuit breaker.	1. Check, if open reset. If circuit breaker continues to open proceed to step 2.
		2. Disconnect red wire between aircraft power supply (battery/external power) and strobe power supplies, one at a time. If circuit breaker opens on one strobe power supply, replace strobe power supply. If circuit breaker opens on both strobe power supplies proceed to step 3. If circuit breaker does not open proceed to step 4.
		3. Check aircraft wiring. Repair or replace as necessary.
		4. Inspect strobe power supply ground wire for contact with wing structure.

MODEL 210 & T210 SERIES SERVICE MANUAL

17-52. TROUBLE SHOOTING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
<p>CAUTION</p> <p>Extreme care should be taken when exchanging flash tube. The tube is fragile and can easily be cracked in a place where it will not be obvious visually. Make sure the tube is seated properly on the base of the nav light assembly and is centered in the dome.</p> <p>NOTE</p> <p>When checking defective power supply and flash tube, units from opposite wing may be used. Be sure power leads are protected properly when unit is removed to prevent short circuit.</p>		
ONE ANTI-COLLISION STROBE LIGHT WILL	Defective Strobe Power Supply, or flash tube.	<ol style="list-style-type: none"> 1. Connect voltmeter to red lead between aircraft power supply (battery/external power) and strobe power supply, connecting negative lead to wing structure. Check for 12/24 volts. If OK proceed to step 2. If not, check aircraft power supply (battery/external power).
		<ol style="list-style-type: none"> 2. Replace flash tube with known good flash tube. If system still does not work, replace strobe power supply.
DOME LIGHT TROUBLE.	Short circuit in wiring.	<ol style="list-style-type: none"> 1. Inspect circuit breaker. If circuit breaker is open, proceed to step 2. If circuit breaker is OK, proceed to step 3.
	Defective wiring.	<ol style="list-style-type: none"> 2. Test circuit until short is located. Repair or replace wiring. 3. Test for open circuit. Repair or replace wiring. If no short or open circuit is found, proceed to step 4.
	Lamp burned out.	<ol style="list-style-type: none"> 4. Test lamp with ohmmeter or new lamp. Replace lamp.
	Defective switch.	<ol style="list-style-type: none"> 5. Check for voltage at dome light with master and dome light switch on. Should read battery voltage. Replace switch.

MODEL 210 & T210 SERIES SERVICE MANUAL

17-52. TROUBLE SHOOTING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
ELECTROLUMINESCENT PANELS WILL NOT LIGHT.	Short circuit in wiring.	1. Inspect circuit breaker. If circuit breaker is open, proceed to step 2. If circuit breaker is OK, proceed to step 3.
	Defective wiring.	2. Test circuit until short is located. Repair or replace wiring. 3. Test for open circuit. Repair or replace wiring. If no open or short circuit is found, proceed to step 4.
	Defective resistor.	4. Check resistor for continuity. (Located in line between rheostat and inverta-pak.) Replace resistor.
	Defective rheostat.	5. Check input voltage at inverta-pak with master switch on. Voltmeter should give a smoothly varied reading over the entire control range of the rheostat. If no voltage is present or voltage has a sudden drop before rheostat has been turned full counterclockwise, replace rheostat.
	Defective inverta-pak.	6. Check output voltage at inverta-pak with ac voltmeter. Should read about 125 volts ac with rheostat set for full bright. Replace inverta-pak.
INSTRUMENT LIGHTS WILL NOT LIGHT.	Short circuit wiring.	1. Inspect circuit breaker. If circuit breaker is open, proceed to step 2. If circuit breaker is OK, proceed to step 3.
	Defective wiring.	2. Test circuit until short is located. Repair or replace wiring. 3. Test for open circuit. Repair or replace wiring. If no short or open circuit is found, proceed to step 4.
	Faulty section in dimming potentiometer.	4. Lights will work when control is placed in brighter position. Replace potentiometer.
	Faulty light dimming transistor.	5. Test both transistors with new transistor. Replace faulty transistor.
	Faulty selector switch.	6. Inspect. Replace switch.

MODEL 210 & T210 SERIES SERVICE MANUAL

17-52. TROUBLE SHOOTING (Cont.)

TROUBLE	PROBABLE CAUSE	REMEDY
INSTRUMENT LIGHTS WILL NOT DIM.	Open resistor or wiring in minimum intensity end of potentiometer.	1. Test for continuity. Replace resistor or repair wiring.
	Shorted transistor.	2. Test transistor by substitution. Replace defective transistor.
CONTROL WHEEL MAP LIGHT WILL NOT LIGHT.	Nav light switch turned off.	1. Nav light switch has to be ON before map light will light.
	Short circuit in wiring.	2. Check lamp fuse on terminal board located on back of stationary panel with ohmmeter. If fuse is open, proceed to step 3. If fuse is OK, proceed to step 4.
	Defective wiring.	3. Test circuit until short is located. Repair or replace wiring. 4. Test for open circuit. Repair or replace wiring. If a short or open circuit is not found, proceed to step 5.
	Defective map light assembly.	5. Check voltage at map light assembly with master and nav switches on. If battery voltage is present, replace map light assembly.

17-53. LANDING AND TAXI LIGHTS.

17-54. DESCRIPTION. The landing and taxi lights are mounted in the lower nose cap. Both lamps are used for landing and only the right hand for taxi thru 1977 models and the left beginning with 1978 models. The lamps are controlled by two rocker switches with a diode assembly installed across the switches which enable the landing light switch to turn on both the landing and taxi lamps. The taxi light switch will turn on only the taxi lamp.

17-55. REMOVAL AND INSTALLATION. (Refer to figure 17-7.)

- Remove screws securing retainer (2) to nose cap.
- Pull light assembly forward from nose cap and disconnect lamp wires.
- Remove tinnerman screws (6) from bracket (5) and remove bracket and lamp.
- Install new lamp and reassemble.

17-56. NAVIGATION LIGHTS.

17-57. DESCRIPTION. The navigation lights are located on each wing tip and the stinger. Operation of the lights is controlled by a single two position switch. A plastic light detector on each wing tip allows the pilot to determine if the lamps are working properly during flight.

17-58. REMOVAL AND INSTALLATION. Refer to figure 17-8 for removal and installation of navigation light components.

17-59. ANTI-COLLISION STROBE LIGHTS.

17-60. DESCRIPTION. A white strobe light may be installed on each wing tip with the navigation light. These lights are vibration resistant and operate on the principle of a capacitor discharge into a xenon tube, producing an extremely high intensity flash. Each strobe light has its own power supply mounted on the wing tip ribs.


17-61. OPERATIONAL REQUIREMENTS. (THRU 1977 MODELS).

WARNING

The capacitors in the strobe light power supplies must be reformed if not used for a period of six (6) months. The following procedure must be used.

Connect the power supply, red wire to plug, black to ground to 6 volt DC source. Do Not connect strobe tube. Turn on 6 volt supply. Note current draw after one minute. If less than 1 ampere, continue operation for 24 hours. Turn off DC power source. Then connect to the proper voltage, 24 volt. Connect tube

MODEL 210 & T210 SERIES SERVICE MANUAL



NOTE

A maximum of two washers may be added between retainer (2) and Plate (3) for adjustment.

- | | |
|-------------|-------------|
| 1. Screw | 7. Nose Cap |
| 2. Retainer | 8. Gasket |
| 3. Plate | 9. Nutplate |
| 4. Lamp | 10. Shield |
| 5. Bracket | 11. Screw |
| 6. Screw | |

Figure 17-7. Landing and Taxi Light Installation

MODEL 210 & T210 SERIES SERVICE MANUAL

to output of strobe power supply and allow to operate, flashing, for 15 minutes. Remove strobe tube. Operating power supply at 24 volts, note the current drain after one minute. If less than 0.5 amperes, operate for 6 hours. If current draw is greater than 0.5 amperes, reject the unit.

WARNING

This anti-collision system is a high voltage device. Do not remove or touch tube assembly while in operation. Wait at least 5 minutes after turning off power before starting work.

17-62. REMOVAL AND INSTALLATION. Refer to figure 17-8 for removal and installation of strobe light components.

- a. Remove wing tip disconnecting navigation and strobe light wires.
- b. Disconnect power supply wires.
- c. Remove the four mounting screws and remove power supply.
- d. To reinstall reverse the preceding steps.

17-62A. VERTICAL TAIL FLOOD LIGHTS.

17-62B. DESCRIPTION. A flood light assembly is mounted on each end of the stabilizer, on the upper side. These lights are used to illuminate the vertical tail. A switch on the switch panel controls the lights and a circuit breaker on the breaker panel protects the circuit.

17-62C. REMOVAL AND INSTALLATION. Refer to figure 17-8. for removal and installation.

NOTE

To properly secure the lens (4) to the fixture, 5 in-lbs (min) to 6 in-lbs (max) should be used. The screw should be tightened to the point that the lens is properly seated on the gasket and the "O" ring under the hold down screw washer is compressed without undue strain on the glass.

NOTE

Aircraft equipped with light assemblies using either 28 volt lamps or 14 volt lamps connected in series. 14 volt lamps assemblies are identified by rubber stamping "14V" on the lamp base. Refer to applicable wiring diagram if in doubt. It is imperative that 14 volt lamps are not installed in the 28 volt light assemblies as this will result in the immediate burn out of the lamp. Should 28 volt lamps be installed in the 14 volt light assemblies, there will be a considerable reduction of light output.

17-63. FLASHING BEACON.

17-64. DESCRIPTION. The flashing beacon light is attached to the vertical fin tip. The flashing beacon has a iodine-vapor lamp electrically switched by a solid-state flasher assembly. The flasher assembly is mounted inside the fin tip. The switching frequency of the flasher assembly operates at approximately 45 flashes per minute. A resistor is installed and connected to the unused flasher lead to eliminate a pulsing effect on the cabin lighting and ammeter.


17-65. REMOVAL AND INSTALLATION. Refer to figure 17-9 for removal and installation of flashing beacon components.

17-66. INSTRUMENT LIGHTING.

17-67. DESCRIPTION. The instrument panel lighting consists of two separate sections. The lower two-thirds of the panel is illuminated by two lights mounted in the overhead console. The lighting for the upper one-third of the panel is provided by four lights mounted in the under side of the instrument glare shield. The intensity of the lighting is controlled by the instrument light dimming rheostat located on the switch panel.

17-68. REMOVAL AND INSTALLATION. Refer to figure 17-10 for removal and installation of instrument brow lights.

MODEL 210 & T210 SERIES SERVICE MANUAL




● Thru 1977 Model
 * Beginning with 1978 Model

- | | | | |
|---------------------|-------------------|-------------------|-------------------|
| 1. Electrical Leads | 7. Housing - Plug | 13. Gasket | 19. Wing Tip Rib |
| 2. Cap | 8. Housing - Cap | 14. Screw | 20. Bracket |
| 3. Washer | 9. Wing Tip | 15. Lens Retainer | 21. Power Supply |
| 4. Insulated Washer | 10. Socket | 16. Lens | 22. Screw |
| 5. Spring | 11. Spacer | 17. Bulb | 23. Socket - Tial |
| 6. Insulator | 12. Flash Tube | 18. Seal | 24. Stinger |

Figure 17-8. Navigation, Flood and Anti-Colission Strobe Lights Installation (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL



Detail A

21063641 THRU 21064127

1. R H Light Assembly
2. L H Light Assembly
3. Clamp
4. Lens
5. Grommet
6. Doubler
7. Gasket
8. Switch & Circuit Breaker

Detail A

BEGINNING WITH 21064128

Figure 17-8. Navigation, Flood and Anti-Collision Strobe Lights Installation (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 17-9. Flashing Beacon Light Installation (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

When installing lamp be sure socket assembly is installed in mounting plate so lamp may be installed with filament perpendicular to the longitudinal axis of the aircraft.



Detail C

Figure 17-9. Flashing Beacon Light Installation (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 17-10. Instrument Panel Glare Shield Light Installation

MODEL 210 & T210 SERIES SERVICE MANUAL

17-69. REMOVAL AND INSTALLATION OF OVERHEAD CONSOLE INSTRUMENT PANEL LIGHTS. (Refer to figure 17-11).

- a. Unscrew metal oxygen port covers, if installed.
- b. Unscrew oxygen gage lens, if installed.
- c. Remove screw from oxygen control knob and remove knob.
- d. Remove the screws in the recess area of the fresh air vents.
- e. Pull out the two oxygen post lights, if installed.
- f. Remove remaining screws the over-head console cover and remove cover.
- g. Twist lamp for removal from socket assembly.
- h. For installation, reverse the preceding steps.

17-70. VERTICAL ADJUSTMENT OF OVERHEAD CONSOLE INSTRUMENT PANEL LIGHTS. (Refer to figure 17-11).

- a. Pry the plug button from the overhead console cover to gain access to the adjustment screw.
- b. Turn the screw clockwise to advance the light beam up the panel.
- c. Turn the screw counterclockwise to advance the light down the panel.
- d. Upon completing adjustment, reinstall plug button.

17-71. LATERAL ADJUSTMENT OF OVERHEAD CONSOLE INSTRUMENT PANEL LIGHTS. (Refer to figure 17-11).

- a. To gain access to the lights, remove the overhead console cover as outlined in paragraph 17-69.
- b. Slide the light sockets inboard along the mounting bracket to advance the light beam outboard on the instrument panel. To advance the light beam inboard on the instrument, slide the light socket outboard along the mounting bracket.

NOTE

Should sliding the light sockets along the mounting bracket prove difficult, the screws attaching the light socket assembly to the mounting bracket may be loosened to permit the light socket assembly to slide along the mounting bracket. Once the adjustment is completed, ensure that the screws are tight enough to resist vibrating out of adjustment.

17-72. ELECTROLUMINESCENT PANEL LIGHTING.

17-73. DESCRIPTION. The electroluminescent lighting consists of two "EL" panels; the switch panel and the comfort control panel. The ac voltage required to drive the "EL" panels is supplied by a small inverta-pak (power supply) located behind the instrument panel. The intensity of the "EL" panel lighting is controlled by a rheostat located on the instrument panel. These "EL" panels have an expected life of over 16,000 hours and no replacement should be necessary during the life of the aircraft.

17-74. TRANSISTORIZED LIGHT DIMMING.

17-75. DESCRIPTION. The light dimming circuit

consists of a two-circuit transistorized dimming assembly, mounted on the right hand side of the cabin forward of the instrument panel, and two controls on the lower left hand side of the panel. The left control is a dual rheostat with a concentric knob arrangement. The center portion controls lower panel lighting, the outer portion controls engine instrument and radio lighting. The right hand control is a single rheostat and controls instrument lighting. This includes, glare shield lights, instrument flood lights, compass light and post lighting if installed. Beginning with 1978 Models a three-circuit transistorized dimming assembly is installed with post lighting. The controls go from three to four with the post light installation. The center portion of the left hand control, controls the post lights, the outer portion controls flood lights, the center portion of the right hand control, controls E L panel lighting and the outer portion controls engine and radio lighting.

17-76. REMOVAL AND INSTALLATION. For removal and installation of transistorized dimming, refer to figure 17-12.

17-77. PEDESTAL LIGHTS.

17-78. DESCRIPTION. The pedestal lights consist of three post type lights mounted on the pedestal to illuminate the fuel selector handle, rudder and elevator trim controls. The pedestal lights are controlled by the instrument light rheostat.

17-79. REMOVAL AND INSTALLATION. For removal and installation of pedestal lamps, slide the cap and lens assembly from the base. Slide the lamp from the socket and replace.

17-80. INSTRUMENT POST LIGHTING.

17-81. DESCRIPTION. Individual post lighting may be installed as optional equipment to provide for non-glare instrument lighting. The post light consists of a cap and a clear lamp assembly with a tinted lens. The intensity of the instrument post lights is controlled by the instrument light dimming rheostat located on the switch panel.


17-82. REMOVAL AND INSTALLATION. For removal and replacement of the instrument post lamps, slide the cap and the lens assembly from the base. Slide the lamp from the socket and replace.

17-83. OXYGEN LIGHTS.

17-84. DESCRIPTION. The oxygen lights consist of two post type lights installed in the overhead oxygen console. The intensity of the oxygen lights is controlled by the radio light dimming rheostat located on the switch panel.

17-85. REMOVAL AND INSTALLATION. Refer to figure 17-11 and paragraph 17-82 for removal and installation of oxygen post lights.

MODEL 210 & T210 SERIES SERVICE MANUAL



- | | | |
|------------------------------------|----------------------------|-------------------|
| 1. Bracket | 7. Washer | 12. Slide Knob |
| 2. Housing Assembly - Panel Lights | 8. Screw | 13. Plug Button |
| 3. Speaker | 9. Lamp | 14. Screw |
| 4. Speaker Grill | 10. Overhead Console Cover | 15. Mounting Base |
| 5. Nut | 11. Screw | 16. Lamp |
| 6. Socket | | 17. Cap and Prism |

Figure 17-11. Instrument Panel Light - Overhead Console

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 17-12. Transistorized Light Dimming and Electroluminescent Inverter Installations

MODEL 210 & T210 SERIES SERVICE MANUAL

17-86. COURTESY LIGHTS.

17-87. DESCRIPTION. The lights consist of one light located on the underside of each wing to provide ground lighting around the cabin area. The courtesy lights have clear lens and are controlled by a single slide switch labeled "Utility Lights," located on the left rear door post.

17-88. REMOVAL AND INSTALLATION. Refer to figure 17-13 for removal and installation of courtesy lights.

17-89. BAGGAGE COMPARTMENT LIGHT.

17-90. DESCRIPTION. The baggage compartment is illuminated by a lamp mounted in the top of the baggage compartment. The light is controlled by the "Utility Lights" switch located on the left door post.

17-91. REMOVAL AND INSTALLATION. (Refer to figure 17-16.)

- a. Ensure that the master switch is "OFF".
- b. To gain access to the baggage compartment lamp, remove the screws attaching the retainer and lens to the reflector assembly.
- c. Twist the lamp from the socket.
- d. To replace the bulb, reverse this procedure.

17-92. INTERIOR LIGHTING

17-93. DESCRIPTION. Interior lighting consists of a dome light installed in the overhead console aft of rear wing spar. A slide switch located forward of the light controls the lamp.

17-94. REMOVAL AND INSTALLATION.

- a. Snap lens out of cover.
- b. Remove lamp and replace with new lamp.
- c. Reinstall lens.





Figure 17-13. Courtesy Light Installation

MODEL 210 & T210 SERIES SERVICE MANUAL



THRU 1977 MODELS

BEGINNING WITH 1978 MODELS

- | | |
|--------------------------|------------------------|
| 1. Control Tube Assembly | 8. Pad |
| 2. Cover | 9. Mike Switch |
| 3. Adapter | 10. Plug |
| 4. Connector | 11. Insulator |
| 5. Plate | 12. Map Light Assembly |
| 6. Map Light Rheostat | 13. Lamp |
| 7. Control Wheel | 14. Knob (Map Light) |

Figure 17-14. Control Wheel Map Light Installation

MODEL 210 & T210 SERIES SERVICE MANUAL

17-95. CONTROL WHEEL MAP LIGHT.

17-96. DESCRIPTION. The control wheel map light is internally mounted in the control wheel. A rheostat on the lower left hand side of the wheel controls the light.

17-97. REMOVAL AND INSTALLATION. (Refer to figure 17-14.) To remove lamp, push upward on the lamp and turn. The lamp and reflector are replaced as a unit.

17-98. COMPASS AND RADIO DIAL LIGHTS.

17-99. DESCRIPTION. The compass and radio dial lights are contained within the individual units. The light intensity is controlled by the instrument light dimming rheostat mounted on the lower left side of the instrument panel.

17-100. Deleted

17-101. Deleted

17-102. Deleted

17-103. STALL WARNING UNIT.


17-104. DESCRIPTION. A solid state warning unit is installed on the right hand wing root rib. The warning signal is transmitted through the radio speaker in the overhead console.

NOTE

On Aircraft Serials 21061040 thru 21062249 if false signals are experienced Refer to Cessna Single-engine Service Letter SE78-50 dated August 7, 1978.

Figure 17-15. Deleted

MODEL 210 & T210 SERIES SERVICE MANUAL



- 1. Screw
- 2. Grommet
- 3. Sta. 138 Bulkhead
- 4. Bracket

- 5. Nutplate
- 6. Reflector
- 7. Nut

- 8. Retainer
- 9. Lens
- 10. Lamp
- 11. Socket

Figure 17-16. Baggage Compartment Light Installation

MODEL 210 & T210 SERIES SERVICE MANUAL

17-105. **REMOVAL AND INSTALLATION.** Refer to figure 17-17 for removal and installation.

17-106. STALL WARNING SWITCH.

17-107. **DESCRIPTION.** The stall warning switch is installed in the leading edge of the left wing and is actuated by airflow over the surface of the wing. The switch will close as a stall condition is approached, actuating the stall warning horn. The horn should sound at approximately five to ten miles per hour above the actual stall speed. Initial installation of the switch should be with the lip of the warning switch approximately one sixteenth of an inch below the center line of the wing skin cutout. Test fly the aircraft to determine if the horn sounds at the desired speed. If the horn sounds too soon, move the unit down slightly; if too late, move the unit up slightly.

17-108. **REMOVAL AND INSTALLATION.** Refer to figure 17-17 for removal and installation.

17-109. PITOT AND STALL WARNING HEATERS.

17-110. **DESCRIPTION.** Electrical heater units are incorporated in some pitot tubes and stall warning switch units. The heaters offset the possibility of ice formation on the pitot tube and stall warning actuator switch. The heaters are integrally mounted in the pitot tube and stall warning actuator switch. Both heaters are controlled by the pitot heat switch.

17-111. **REMOVAL AND INSTALLATION.** Refer to figures 17-17 and 17-18 for removal and installation.

17-112. LANDING GEAR INDICATOR LIGHTS.

17-113. **DESCRIPTION.** The position of the landing gear is indicated by two press-to-test lamp assemblies mounted on the right side of the switch panel. The green light is on when all the wheels are down and locked; the amber is on when all the wheels are




Figure 17-17. Stall Warning Unit

MODEL 210 & T210 SERIES SERVICE MANUAL

up and locked. If any wheel assumes an intermediate position of neither up and locked or down and locked, both lights will be dark. The hood of each light is removable for bulb replacement, and has a dimming shutter.

17-114. REMOVAL AND INSTALLATION.

a. Remove the hood on either light by unscrewing counterclockwise. The lamp bulb is in the hood and may be replaced by pulling it out and inserting a new lamp.

b. To remove the lamp socket assembly, remove the nut from the assembly on the front side of the panel.

c. Tag and unsolder the wires from the socket assembly.

d. To replace a lamp socket assembly, reverse the above procedure.

17-115. LANDING GEAR WARNING HORN.
Refer to Section 5.

17-116. CIGAR LIGHTER. (THRU 21064536)

17-117. DESCRIPTION. A special circuit breaker

is contained in a small cylinder screwed directly on the back of the cigar lighter socket. The circuit breaker is a bi-metallic type and is resettable. To reset a breaker, make sure that the master switch is off, then insert a small diameter pin (end of a paper clip works) into the hole in the phenolic back plate of the breaker and apply pressure. A small click will be heard when the breaker resets.

CAUTION

Make sure the master switch is "OFF" before inserting probe into the circuit breaker on cigar lighter to reset.

17-118. REMOVAL AND INSTALLATION. (Refer to figure 17-20).

- Ensure that the master switch is "OFF."
- Remove cigar lighter element.
- Disconnect wire on back of lighter.
- Remove shell that screws on socket back of panel.
- The socket will then be free for removal.
- To install a cigar lighter, reverse this procedure.




Figure 17-18. Stall Warning Switch.

SHOP NOTES:

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 17-19. Pitot Heater




Figure 17-20. Cigar Lighter Installation

MODEL 210 & T210 SERIES SERVICE MANUAL

17-119. Deleted.

17-120. Deleted.

17-121. Deleted.

17-122. Deleted.

17-123. EMERGENCY LOCATOR TRANSMITTER. THRU 21061715.

17-124. DESCRIPTION. The ELT is a self-contained, solid state unit, having its own power supply, with an externally mounted antenna. The C589510-0209 transmitter is designed to transmit simultaneously on dual emergency frequencies of 121.5 and 243.0 Megahertz. The C589510-0211 transmitter used for Canadian registry, operates on 121.5 only. The unit is mounted in the tailcone, aft of the baggage curtain on the right hand side. The transmitters are designed to provide a broadcast tone that is audio modulated in a swept manner over the range of 1600 to 300 Hz in a distinct, easily recognizable distress signal for reception by search and rescue personnel and others monitoring the emergency frequencies. Power is supplied to the transmitter by a battery pack which has the service life of the batteries placarded on the batteries and also on the outside end of the transmitter. ELT's are equipped with a battery pack containing four lithium "D" size batteries which are stacked in two's (See figure 17-23). The ELT exhibits line of sight transmission characteristics which correspond approximately to 100 miles at a search altitude of 10,000 feet. When battery inspection and replacement schedules are adhered to, the transmitter will broadcast an emergency signal at rated power (75 MW-minimum), for a continuous period of time as listed in the following table.

TRANSMITTER LIFE
TO 75 MILLIWATTS OUTPUT

Temperature	4-Cell Lithium Battery Pack
+130°F	115 hrs
- 70°F	115 hrs
- 4°F	95 hrs
- 40°F	23 hrs

Battery packs have a normal shelf life of five to ten (5-10) years and must be replaced at half of normal shelf life in accordance with TSO-C91. Cessna specifies 5 years replacement of lithium (4-cell) battery packs.

17-125. OPERATION. A three position switch on the forward end of the unit controls operation. Placing the switch in the ON position will energize the unit to start transmitting emergency signals. In the OFF position, the unit is inoperative. Placing the switch in the ARM position will set the unit to start transmitting emergency signals only after the unit has received a 5g (tolerances are +2g and -0g) impact force, for a duration of 11-16 milliseconds.

CAUTION

Do not leave the emergency locator transmitter in the ON position longer than 5 seconds or you may activate downed aircraft procedures by C. A. P., D. O. T. or F. A. A. personnel.

17-126. OPERATIONAL TEST OF EMERGENCY LOCATOR SYSTEM. The ELT, its battery pack, and its antenna must be inspected and tested each 100 hours. The operational test of the airplane's emergency locator system should check both radiated signal strength and the ELT G-switch. The airplane's VHF receiver is located very close to the ELT and is very sensitive. Consequently, using the airplane's VHF receiver to monitor ELT transmission does not provide same level of confidence in verifying ELT signal as using AM radio or performing control tower check.

CAUTION

Tests with the antenna connected should be approved by the nearest control tower. The FAA/DOT allows free space transmission tests from the airplane only within first five minutes after each hour. The test time allowed is limited to three sweeps of the warble tone or approximately one second. The control tower should be notified that a test is about to be conducted.

NOTE

After accumulated test or operation time equals one hour, battery pack replacement is required.

a. Operational test of radiated signal with control tower monitoring.

- (1) Turn airplane master switch ON.
- (2) Verify that test is conducted within first five minutes of the hour.
- (3) Turn airplane transceiver ON, request permission from nearest control tower and flight service station to conduct operational test of ELT, and request control tower monitoring.

(4) Place ELT function selector to the ON position for one second or less (no more than three sweeps of the audio signal). Immediately replace the ELT function selector to the ARM position after testing ELT.


(5) Contact control tower and confirm proper locator beacon operation.

(6) Restore switches to normal.

b. Operational test of radiated signal with handheld AM radio monitoring.

- (1) Turn airplane master switch ON.
- (2) Verify that test is conducted within first five minutes of the hour.
- (3) Turn airplane transceiver ON and request permission from nearest control tower and flight service station to conduct operational test of ELT.
- (4) Position a small hand held AM radio tuned to any frequency within six inches of the ELT antenna.

MODEL 210 & T210 SERIES SERVICE MANUAL



1. Tailcone Skin
2. Bracket
3. Fabric Fastener - Hook
4. Fabric Fastener - Pile
5. Transmitter
6. Cover
7. Connector
8. Arm Switch
9. Coaxial Cable
10. Sta-strap
11. Metal Strap
12. Antenna
13. Doubler
14. Rubber Boot
15. Rubber Washer
16. Placard
17. Baggage Curtain

Figure 17-22. Emergency Locator Transmitter Installation

MODEL 210 & T210 SERIES SERVICE MANUAL

(5) Place ELT function selector to the ON position for one second or less (no more than three sweeps of the audio signal). Immediately replace the ELT function selector to the ARM position after testing ELT.

(6) Verify that ELT signal has been detected on hand held AM radio.

(7) Restore switches to normal.

c. Operational test of the TSO-C91 ELT G-switch.

(1) Remove ELT from airplane.

(2) While holding ELT in one hand, sharply strike the end of the case in the direction of activation indicated on the case of the transmitter.

(3) Using either radiated signal test method described above, verify that the G-switch has been activated and ELT is transmitting.

(4) Reset the G-switch, and restore other disturbed switches to normal.

(5) Reinstall ELT in airplane.

d. Operational test of the TSO-C91a ELT G-switch.

(1) Remove ELT from airplane.

(2) While holding ELT firmly in one hand, make a throwing motion followed by a sudden reversal of the transmitter.

(3) Using either radiated signal test method described above, verify that the G-switch has been activated and ELT is transmitting.

(4) Reset the G-switch, and restore other disturbed switches to normal.

(5) Reinstall ELT in airplane.

e. Check calendar date for replacement of battery pack. This date is supplied on a sticker attached to the outside of the ELT case and to each battery.

17-127. REMOVAL AND INSTALLATION OF TRANSMITTER. (Refer to figure 17-22.)

a. Remove baggage curtain to gain access to the transmitter and antenna.

b. Disconnect coaxial cable from end of transmitter.

c. Cut sta-strap securing antenna cable and unlatch metal strap to remove transmitter.

NOTE

Transmitter is also attached to the mounting bracket velcro strips; pull transmitter to free from mounting bracket and velcro.

NOTE

To replace velcro strips, clean surface thoroughly with clean cloth saturated in one of the following solvents: Trichloric thylene, Aliphatic Napthas, Methyl Ethyl Ketone, or Enmar 6094 Lacquer Thinner. Cloth should be folded each time the surface is wiped to present a clean area and avoid redepositing of grease. Wipe surface immediately with clean, dry cloth, and do not allow solvent to dry on surface. Apply Velcro #40 adhesive to each surface in a thin even coat and allow to dry until quite tacky, but no longer transfers to the finger when touched (usually between 5 and 30 minutes). Porous surfaces may require two coats. Place the two surfaces in contact and press firmly together to ensure intimate contact. Allow 24 hours for complete cure.

d. To reinstall transmitter, reverse preceding steps.

NOTE

An installation tool is required to properly secure sta-strap. This tool may be purchased locally or ordered from the Panduit Corporation, Tinley Park, Ill, Part No. GS-2B (conforms to MS90387-1).

CAUTION

Ensure that the direction of flight arrows (placarded on the transmitter) are pointing towards the nose of the aircraft.

17-128. REMOVAL AND INSTALLATION OF ANTENNA. (Refer to figure 17-22.)

a. Disconnect coaxial cable (9) from base of antenna (12).

b. Remove nut and lockwasher attaching antenna base to fuselage, and the antenna (12) will be free for removal.

c. To reinstall the antenna, reverse the preceding steps.

NOTE

Upon reinstallation of antenna, cement rubber boot (14) using RTV102, General Electric Co., or equivalent, to antenna whip only; do not apply adhesive to fuselage skin or damage to paint may result.

17-129. REMOVAL AND INSTALLATION OF LITHIUM FOUR-CELL BATTERY PACK. (Refer to figure 17-23.)

NOTE

Transmitters equipped with the 4-cell battery pack can only be replaced with another 4-cell battery pack..

NOTE

When existing battery fails or exceeds normal expiration date, convert ELT System to new D/M alkaline powered ELT per Avionics Service Letter AV78-31, dated November 20, 1978.

a. After the transmitter has been removed from aircraft in accordance with paragraph 17-127, place the transmitter switch in the OFF position.

b. Remove the nine screws attaching the cover to the case and then remove the cover to gain access to the battery pack.

NOTE

Retain the rubber gasket and screws for reinstallation.

c. Disconnect the battery pack electrical connector and remove battery pack.

d. Place new battery pack in the transmitter with four batteries as shown in the case in figure 17-23.

e. Connect the electrical connector as shown in figure 17-23.

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE

Before installing a new 4-cell battery pack, check to ensure that its voltage is 11.2 volts or greater.

CAUTION

If it is desirable to replace adhesive material on the 4-cell battery pack, use only 3M Jet Melt Adhesive #3738. Do not use other adhesive materials since other materials may corrode the printed circuit board assembly.

- f. Replace the transmitter cover and gasket.
- g. Remove the old battery pack placard from end of transmitter and replace with battery pack placard supplied with the new battery pack.

WARNING

The battery pack is pressurized contents. Do NOT recharge, short circuit, dispose of in fire or compact.

CAUTION

Be sure to enter the new battery pack expiration date in the aircraft records. It is also recommended this date be placed in your ELT Owner's Manual for quick reference.




Figure 17-23. Lithium 4-Cell

17-130. TROUBLE SHOOTING. Should your Emergency Locating Transmitter fail the 100 Hours performance checks, it is possible to a limited degree to isolate the fault to a particular area of the equipment. In performing the following trouble shooting

MODEL 210 & T210 SERIES SERVICE MANUAL

17-130. TROUBLE SHOOTING (Cont.)

procedures to test peak effective radiated power, you will be able to determine if battery replacement is necessary or if your unit should be returned to your dealer for repair.

TROUBLE	PROBABLE CAUSE	REMEDY
*POWER LOW	Low battery voltage.	<ol style="list-style-type: none"> 1. Set toggle switch to off. 2. Remove plastic plug from the remote jack and by means of a Switchcraft #750 jackplug, connect a Simpson 260 model voltmeter and measure voltage. If the battery pack transmitters is 11.2 volts or less, the battery pack is below specification.
	Faulty transmitter.	<ol style="list-style-type: none"> 3. If the battery pack voltage meets the specifications in step 2, the battery pack is O.K. If the battery is O.K., check the transmitter as follows: <ol style="list-style-type: none"> a. Remove the voltmeter. b. By means of a Switchcraft 750 jackplug and 3-inch maximum long leads, connect a Simpson Model 1223 ammeter to the jack. c. Set the toggle switch to ON and observe the ammeter current drain. If the current drain is in the 85-100 ma range, the transmitter or the coaxial cable is faulty.
	Faulty coaxial antenna cable.	<ol style="list-style-type: none"> 4. Check coaxial antenna cable for high resistance joints. If this is found to be the case, the cable should be replaced.

*This test should be carried out with the coaxial cable provided with your unit.

17-131. EMERGENCY LOCATOR TRANSMITTER. BEGINNING WITH 21061716.

17-132. DESCRIPTION. The ELT is a self-contained, solid state unit, having its own power supply with an externally mounted antenna. The unit is mounted in the tailcone, aft of the baggage curtain on the right hand side. The transmitters are designed to provide a broadcast tone that is audio modulated in a swept manner over the range of 1600 to 300 Hz in a distinct, easily recognizable distress signal for reception by search and rescue personnel and others monitoring the emergency frequencies. The ELT exhibits line of sight transmission characteristics which correspond approximately to 100 miles at a search altitude of 10,000 feet. The C589511-0103 transmitter, and the C589511-0104 transmitter on aircraft with Canadian registry, are used thru 21062954. The C589511-0117 transmitter, and the C589511-0113 transmitter on aircraft with Canadian registry, are used on 210-62955 thru 21064780. Beginning with 21064781 the C589512-0103 transmitter is used on all aircraft.

The C589511-0104 transmits on 121.5 MHz at 25 mw rated power output for 100 continuous hours in the temperature range of -40° to +131°F (-40°C to +55°C). The C589511-0113 transmits on 121.5 MHz at 25 mw rated power output for 100 continuous hours in the temperature range of -4°F to +131°F (-20°C to +55°C). The C589511-0103 transmits on 121.5 and 243.0 MHz simultaneously at 75 mw rated power output for 48 continuous hours in the temperature range of -40°F to +131°F (-40°C to +55°C). The C589511-0117 and C589512-0103 transmits on 121.5 and 243.0 MHz at 75 mw rated power output for 48 continuous hours in the temperature range of -4°F to +131°F (-20°C to +55°C).

Power is supplied to the transmitter by a battery pack. The C589511-104 and C589511-0103 ELT's equipped with a lithium battery pack must be modified by SK185-20 as outlined in Avionics Service Letter AF78-31, dated 20 November 1981 to incorporate

MODEL 210 & T210 SERIES SERVICE MANUAL

alkaline battery packs. The C589511-0114 alkaline battery packs have the service life of the battery pack stamped on the battery pack, on the end of the transmitter below the switch and on top of the transmitter. The C589512-0107 alkaline battery packs have the replacement date and date of installation on the top of the transmitter.

17-133. OPERATION. A three-position switch on the forward end of the unit controls operation. Placing the switch in the ON position will energize the unit to start transmitting emergency signals. In the OFF position, the unit is inoperative. Placing the switch in the ARM position will set the unit to start transmitting emergency signals only after the unit has received a 5g (tolerances are +2g and -0g) impact force, for a duration of 11-16 milliseconds.

CAUTION

Do not leave the emergency locator transmitter in the ON position longer than 1 second (3 sweeps of the warble tone) or you may activate downed aircraft procedures by C.A.P., D.O.T., or F.A.A. personnel.

17-134. OPERATIONAL TEST OF EMERGENCY LOCATOR SYSTEM. The ELT, its battery pack, and its antenna must be inspected and tested each 100 hours. The operational test of the airplane's emergency locator system should check both radiated signal strength and the ELT G-switch. The airplane's VHF receiver is located very close to the ELT and is very sensitive. Consequently, using the airplane's VHF receiver to monitor ELT transmission does not provide same level of confidence in verifying ELT signal as using AM radio or performing control tower check.

CAUTION

Tests with the antenna connected should be approved by the nearest control tower. The FAA/DOT allows free space transmission tests from the airplane only within first five minutes after each hour. The test time allowed is limited to three sweeps of the warble tone or approximately one second. The control tower should be notified that a test is about to be conducted.

NOTE

After accumulated test or operation time equals one hour, battery pack replacement is required.

- a. Operational test of radiated signal with control tower monitoring.
 - (1) Turn airplane master switch ON.
 - (2) Verify that test is conducted within first five minutes of the hour.
 - (3) Turn airplane transceiver ON, request permission from nearest control tower and flight service

station to conduct operational test of ELT, and request control tower monitoring.

- (4) Place ELT function selector to the ON position for one second or less (no more than three sweeps of the audio signal). Immediately replace the ELT function selector to the ARM position after testing ELT.

- (5) Contact control tower and confirm proper locator beacon operation.

- (6) Restore switches to normal.

- b. Operational test of radiated signal with handheld AM radio monitoring.

- (1) Turn airplane master switch ON.

- (2) Verify that test is conducted within first five minutes of the hour.

- (3) Turn airplane transceiver ON and request permission from nearest control tower and flight service station to conduct operational test of ELT.

- (4) Position a small hand held AM radio tuned to any frequency within six inches of the ELT antenna.

- (5) Place ELT function selector to the ON position for one second or less (no more than three sweeps of the audio signal). Immediately replace the ELT function selector to the ARM position after testing ELT.

- (6) Verify that ELT signal has been detected on hand held AM radio.

- (7) Restore switches to normal.

- c. Operational test of the TSO-C91 ELT G-switch.

- (1) Remove ELT from airplane.

- (2) While holding ELT in one hand, sharply strike the end of the case in the direction of activation indicated on the case of the transmitter.

- (3) Using either radiated signal test method described above, verify that the G-switch has been activated and ELT is transmitting.

- (4) Reset the G-switch, and restore other disturbed switches to normal.

- (5) Reinstall ELT in airplane.

- d. Operational test of the TSO-C91a ELT G-switch.

- (1) Remove ELT in airplane.

- (2) While holding ELT firmly in one hand, make a throwing motion followed by a sudden reversal of the transmitter.

- (3) Using either radiated signal test method described above, verify that the G-switch has been activated and ELT is transmitting.

- (4) Reset the G-switch, and restore other disturbed switches to normal.

- (5) Reinstall ELT in airplane.

- e. Check calendar date for replacement of battery pack. This date is supplied on a sticker attached to the outside of the ELT case and to each battery.

17-135. REMOVAL AND INSTALLATION OF TRANSMITTER. (Refer to figure 17-24).

- a. Remove baggage curtain to gain access to the transmitter and antenna.

- b. Disconnect coaxial cable from end of transmitter.


- c. Remove the two #10 screws from the baseplate of the ELT and remove ELT.

- d. To reinstall transmitter, reverse preceding steps.

CAUTION

Ensure that the direction of flight arrows (placarded on the transmitter) are pointing towards the nose of the aircraft.

MODEL 210 & T210 SERIES SERVICE MANUAL



- | | |
|---|--|
| <ol style="list-style-type: none"> 1. Cabin Skin 2. Bracket 3. Transmitter 4. Cover 5. Screw 6. Battery Pack 7. Arm Switch | <ol style="list-style-type: none"> 8. Coaxial Cable 9. Rubber Washer 10. Rubber Boot 11. Antenna 12. Doubler 13. Safety Wire 14. Stringer |
|---|--|

Figure 17-24. Emergency Locator Transmitter Installation (Sheet 1 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 17-24. Emergency Locator Transmitter Installation (Sheet 2 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 17-24. Emergency Locator Transmitter Installation (Sheet 3 of 3)

MODEL 210 & T210 SERIES SERVICE MANUAL

17-136. REMOVAL AND INSTALLATION OF ANTENNA (Refer to figure 17-24.)

- Disconnect coaxial cable from base of antenna.
- Remove the nut and lockwasher attaching the antenna base to the fuselage and the antenna will be free for removal.
- To reinstall the antenna, reverse the preceding steps.

CAUTION

The C589511-0111 and C589511-0119 coaxial cable must be installed as indicated on the cable sleeve. Cable end marked "TO ANT" must be connected to the ELT antenna, and the end marked "TO ELT" must be connected to the C589511-0113/-0117 and C589511-0103/-0104 transmitters.

NOTE

Upon reinstallation of antenna, cement rubber boot (14) using RTV 102, General Electric Co. or equivalent, to antenna whip only; do not apply adhesive to fuselage skin or damage to paint may result.

17-137. REMOVAL AND INSTALLATION OF BATTERY PACK (See figure 17-25).

NOTE

Transmitters equipped with C589511-0105 or C589511-0106 battery packs can be replaced with a C589511-0114 after modification by SK185-20 has been completed.

CAUTION

Lithium battery pack must be replaced with alkaline battery packs per SK185-20.

- After the transmitter has been removed from aircraft in accordance with paragraph 17-135, place the transmitter switch in the OFF position.
- Remove the four screws attaching the cover to the case and then remove the cover to gain access to the battery pack.
- Disconnect the battery pack electrical connector and remove battery pack.
- Place new battery pack in the transmitter with four batteries as shown in the case in figure 17-25.
- Connect the electrical connector as shown in figure 17-25.

Before installing the C589511-0105 pack, check to ensure that its voltage is 7.5 volts or greater.

- Replace the transmitter baseplate on the unit and pressing the baseplate and unit together attach baseplate with four nylok patch screws.

- Stamp the new replacement date on the outside of the ELT. The date should be noted on the switching nameplate on the side of the unit as well as on the instruction nameplate on top of the unit.

WARNING

The battery pack has pressurized contents. Do not recharge, short circuit, or dispose of in fire.

CAUTION

Be sure to enter the new battery pack expiration date in the aircraft records. It is also recommended this date be placed in your ELT Owner's Manual for quick reference. DO NOT use a substitute battery pack.




Figure 17-25. Battery Pack Installation.

MODEL 210 & T210 SERIES SERVICE MANUAL

17-138. **TROUBLE SHOOTING.** Should your Emergency Locating Transmitter fail the 100 Hours performance checks, it is possible to a limited degree to isolate the fault to a particular area of the equipment. In performing the following trouble shooting

procedures to test peak effective radiated power, you will be able to determine if battery replacement is necessary or if your unit should be returned to your dealer for repair.

TROUBLE	PROBABLE CAUSE	REMEDY
* POWER LOW	Low battery voltage.	<ol style="list-style-type: none"> 1. Set toggle switch to off. 2. Disconnect the battery pack from the transmitter and connect a Simpson 260 model voltmeter and measure voltage. If the battery pack transmitters is 7.5 volts or less, the battery pack is below specification.
	Faulty transmitter.	<ol style="list-style-type: none"> 3. If the battery pack voltage meets the specifications in step 2, the battery pack is O.K. If the battery is O.K., check the transmitter as follows: <ol style="list-style-type: none"> a. Reconnect battery pack to the transmitter. b. Using E. F. Johnson 105-0303-001 jackplugs and 3-inch maximum long leads, connect a Simpson Model 1223 ammeter to the jack. c. Set the toggle switch to AUTO and observe the ammeter current drain. If the current drain is in the 15-25 ma range, the transmitter or the coaxial cable is faulty.
	Faulty coaxial antenna cable.	<ol style="list-style-type: none"> 4. Check coaxial antenna cable for high resistance joints. If this is found to be the case, the cable should be replaced.

* This test should be carried out with the coaxial cable provided with your unit.

MODEL 210 & T210 SERIES SERVICE MANUAL

ELECTRICAL LOAD ANALYSIS CHART

STANDARD EQUIPMENT (RUNNING LOAD)	AMPS						
	1977	1978	1979	1980	1981	1982	1983
Battery Contactor41	0.5	0.5	0.5	0.5	0.5	0.33
Clock	†	†	†	†	†	†	†
Cylinder Head Temperature05						
Fuel Quantity Indicators11						.05
Engine Instruments		0.2	0.2	0.2	0.2	0.2	0.1
Flashing Beacon	6.0	6.0	6.0	6.0	6.0	6.0	7.0
Instrument Lights							
a. Electroluminescent Panel02						
b. Cluster16						
c. Console * *	1.14						
d. Compass04						
Instrument Lights		2.2	2.2	2.2	2.2	2.2	2.2
EL Panels		0.7	0.7	0.7	0.7	0.7	0.3
Solenoid Valve - Gear Doors & Warning		0.6					
Lamp - Gear Up or Gear Down	0.4	0.4	0.4	0.4	0.4	.04	0.04
Solenoid Valve - Gear Handle Lock	2.0						
Position Lights	1.97	2.5	2.5	2.5	2.5	2.5	2.8
Turn Coordinator28	0.3	0.3	0.3	0.2	0.2	0.30
Turn & Bank Indicator (Optional)	0.2	0.2	0.2	0.2	0.2	0.2	0.24
Alternator Control Unit							2.0
ITEMS NOT CONSIDERED AS PART OF RUNNING LOAD							
Heated Pitot and Stall Warning Heaters	5.80	5.8	5.8	5.8	5.8	5.8	5.8
Windshield Anti-Ice	4.4	4.4	4.4	4.4	4.4	4.4	4.4
Wing De-Ice	1.6	1.6	1.6	1.6	1.6	1.6	3.0
Propeller Anti-Ice	18.0 ●	18.0 ●	18.0 ●	18.0 ●	18.0 ●	18.0 ●	18.0 ●
Strobe Lights	2.0	3.0	3.0	3.0	3.0	3.0	2.0
Post Lights76	0.8	0.8	0.8	0.8	0.8	0.8
Cessna 200A Navomatic (Type AF-295B)	2.5	2.5	2.5	2.5	2.5	2.5	2.5
Cessna 300 ADF (Type R-546E)	1.0	1.0	1.0	1.0	1.0	1.0	1.0
Cessna 300 Nav/Com (360 Channel-Type RT-308C)	1.5						
Cessna 300 Nav/Com (Type RT-328T)	1.5						
Cessna 300 Transponder (Type RT-359A)	2.0	2.0	2.0	2.0	2.0	2.0	2.0
Cessna 300A Navomatic (Type AF-395A)	2.5	2.5	2.5	2.5	2.5	2.5	2.5
With Unslaved HSI (IG-832C)		2.8					
Cessna 300 Nav/Com (RT-385A)		1.0 ☆	1.0 ☆	1.0 ☆	1.0 ☆	1.0 ☆	1.0 ☆
Cessna 400 R-Nav (RN-478A)	0.5	0.5	0.5	0.5	0.5		
Cessna 400 ADF (Type R-446A)	1.0	1.6	1.6	1.6	1.6	1.6	1.6
Cessna 400 Nav/Com (RT-485A, RT-485B)		1.6 ☆	1.6 ☆	1.6 ☆	1.6 ☆	1.6 ☆	1.6 ☆
Cessna 400 Transponder (RT-459A)	2.0	2.0	2.0	2.0	2.0	2.0	2.0
Cessna 400 DME (Type RT-476A, Type 478A)	2.5	2.5	2.5	2.5	2.5	2.5	
Cessna 400 Encoding Altimeter (EA-401A)07	0.1	0.1	0.1	0.1	0.1	0.1
Bendix GM-247A Marker Beacon10						
Cessna 400 Marker Beacon (Type R-402A, R-402B)10	0.1	0.1	0.1	0.1	0.1	0.1
Sunair SSB Transceiver (Type ASB-125)	2.5 ☆	2.5 ☆	2.5 ☆	2.5 ☆	2.5 ☆	2.5 ☆	2.5 ☆
Pantronics PT-10A HF Transceiver	1.5 ☆	1.0 ☆	1.0 ☆	1.0 ☆			
Altitude Alert/Select (AA-801A)		0.6	0.6	0.6	0.6	0.6	0.6
Cessna 400 Nav-O-Matic (Type AF-420A)	1.2	1.2	1.2	1.2	1.2	1.2	
With Slaved Directional Gyro System	1.4	1.4	1.4	1.4			
Cessna 400B IFCS (Type IF-550A) (Includes HSI & Course Datum)	5.1	6.0	6.0	6.0	6.0	6.0	6.0

MODEL 210 & T210 SERIES SERVICE MANUAL

OPTIONAL EQUIPMENT (RUNNING LOAD)	AMPS						
	1977	1978	1979	1980	1981	1982	1983
Cessna 400B Nav-O-Matic (Type AF-550A)	5.0	5.0	5.0	5.0	5.0	5.0	5.0
(Includes Unslaved DG GS-502A)							
With Slaved Directional Gyro System	5.2	5.2	5.2	5.2	5.2	5.2	5.2
(CS-504A)							
With Slaved D. G. & Course Datum	5.4	5.4	5.4	5.4	5.4	5.4	5.4
(CS-504A)							
With Unslaved HSI (IG-832C)		5.5	5.5	5.5	5.3	5.3	5.3
With Slaved HSI System (CS-832A)	5.8	5.8	5.8	. . .	5.8	5.8	5.8
With Slaved HSI & Course Datum	6.0	6.0	6.0	6.0	6.0	6.0	6.0
(CS-832A)							
Stereo Avionics West					1.0	1.0	1.0
Cessna 400 DME (RT-477A)							1.50
Cessna 400 R-Nav (RN-479A)							1.00
EC-100 Stereo					1.0	1.0	1.0
Bonzer Radar Altimeter						0.5	0.5
DME - 190					2.9		
DME - 451					1.2	1.2	
ANS - 351 RNAV					0.65	0.65	
Altitude Encoder (Blind)					0.1	0.1	0.10
High Altitude Encoder (Blind)					0.1	0.1	0.10
De-Ice System (Certified for Flight in Icing Conditions)					46.2	46.2	40.65
Prop De-Ice				18.0			
Windshield De-Ice				16.0			
RDR-160 Weather Radar		3.5	3.5	3.5	3.5	3.5	3.5
Cessna 400 Glideslope (Type R-443B)	0.32	9.5	0.5	0.5	0.5	0.5	0.5
Cessna 400 Nav/Com (Type RT-428A)	1.5						
HSI System (IG-832A)	8 or *1.0						
Slaved Directional Gyro (G-504A)	15 or *.35						
Foster RNAV 511			1.0	1.0	1.0		
400 RMI			0.35	.35	0.4	0.4	0.4
Avionics Cooling Fan					1.0	1.0	1.0
Interphone System						†	†
ITEMS NOT CONSIDERED AS PART OF RUNNING LOAD							
Cessna 300 Nav/Com (RT-385A)		2.3⊕	2.3⊕	2.3⊕	2.3⊕	2.3⊕	2.3⊕
Cessna 400 Nav/Com (RT-485A, RT-485B)		4.0⊕	4.0⊕	4.0⊕	2.3⊕	2.3⊕	2.3⊕
ASB-125 SSB HF Transceiver	7.5⊕	7.5⊕	7.5⊕	7.5⊕	7.5⊕	7.5⊕	7.5⊕
PT-10A Transceiver	9.0⊕	9.0⊕	9.0⊕	9.0⊕			
Auxiliary Fuel Pump	3.0	3.0	3.0	3.0	3.0	3.0	3.0
Cigarette Lighter	7.0	7.0	7.0	7.0	7.0		
Flap Motor	8.5	10.0	10.0	10.0	8.5	8.5	1.8
Landing Lights (Each)	3.57	3.6ea	3.6ea	3.6ea	3.6ea	3.6ea	3.6ea
Stall Warning Horn28	.28	.28	.28	.28		.40
Wing Courtesy Lights and Cabin Lights	1.2	1.2	1.2	1.2	1.2		1.5
Ice Detector Light	1.43	1.5	1.5	1.5	1.5	1.5	1.5
Hydraulic Power Pack	8.0□	8.0□	17.5	17.5	17.5	17.5	14.0
	40.0□	40.0□					
Electric Elevator Trim	0.7	0.7	0.7	0.7	0.7	0.7	.51
Map Light (Glare Shield or Control Wheel)	0.1	0.1	0.1	0.1	0.1	0.1	0.1
Recognition Lights				5.35	5.3	5.3	3.6
Air Conditioning					22.8	22.8	22.8
*Console Lights not used with post lights.							
*Only one or the other may be used at one time.							
†Negligible							
● In flight running load *With Bootstrap ⊕ Transmit ☆ Receive □ Minimum to Maximum							

MODEL 210 & T210 SERIES SERVICE MANUAL

ELECTRICAL LOAD ANALYSIS CHART

STANDARD EQUIPMENT (RUNNING LOAD)	AMPS 1984
Battery Contactor	0.33
Clock	
Cylinder Head Temperature	
Fuel Quantity Indicators05
Engine Instruments10
Flashing Beacon	7.0
Instrument Lights	
a. Electroluminescent Panel	
b. Cluster	
c. Console * *	
Instrument Lights	2.2
EL Panels	0.3
Solenoid Valve - Gear Doors & Warning	
Lamp - Gear Up or Gear Down	0.04
Solenoid Valve - Gear Handle Lock	
Position Lights	2.8
Turn Coordinator	0.30
Turn & Bank Indicator (Optional)	0.24
Alternator Control Unit	2.0
OPTIONAL EQUIPMENT (RUNNING LOAD)	
Heated Pitot and Stall Warning Heaters	5.8
Windshield Anti-Ice	4.4
Wing De-Ice	3.0
Propeller Anti-Ice	18.0 ●
Strobe Lights	2.0
Post Lights	0.8
Cessna 200A Navomatic (Type AF-295B)	2.5
Cessna 300 ADF (Type R-546E)	1.0
Cessna 300 Nav/Com (360 Channel-Type RT-308C)	
Cessna 300 Nav/Com (Type RT-328T)	
Cessna 300 Transponder (Type RT-359A)	2.0
Cessna 300A Navomatic (Type AF-395A)	2.5
With Unslaved HSI (IG-832C)	
Cessna 300 Nav/Com (RT-385A)	1.0 ☆
Cessna 400 R-Nav (RN-478A)	
Cessna 400 ADF (Type R-446A)	1.6
Cessna 400 Nav/Com (RT-485A, RT-485B)	1.6 ☆
Cessna 400 Transponder (RT-459A)	2.0
Cessna 400 DME (Type RT-476A, Type 478A)	
Cessna 400 Encoding Altimeter (EA-401A)	0.1
Bendix GM-247A Marker Beacon	
Cessna 400 Marker Beacon (Type R-402A, R-402B)	0.1
Sunair SSB Transceiver (Type ASB-125)	2.5 ☆
Pantronics PT-10A HF Transceiver	
Altitude Alert/Select (AA-801A)	0.6
Cessna 400 Nav-O-Matic (Type AF-420A)	
With Slaved Directional Gyro System	
Cessna 400B IFCS (Type IF-550A) (Includes HSI & Course Datum)	6.0

MODEL 210 & T210 SERIES SERVICE MANUAL

OPTIONAL EQUIPMENT (RUNNING LOAD)	AMPS 1984
Cessna 400B Nav-O-Matic (Type AF-550A)	5.0
(Includes Unslaved DG GS-502A)	
With Slaved Directional Gyro System	5.2
(CS-504A)	
With Slaved D. G. & Course Datum	
(CS-504A)	
With Unslaved HSI (IG-832C)	5.3
With Slaved HSI System (CS-832A)	5.8
With Slaved HSI & Course Datum	6.0
(CS-832A)	
Cessna 400 DME (RT-477A)	1.50
Cessna 400 R-Nav (RN-479A)	1.00
EC-100 Stereo	1.0
Bonzer Radar Altimeter	0.5
DME - 190	
DME - 451	
ANS - 351 RNAV	
Altitude Encoder (Blind)	0.10
High Altitude Encoder (Blind)	0.10
De-Ice System (Certified for Flight in Icing Conditions)	40.65
Prop De-Ice	
Windshield De-Ice	
RDR-160 Weather Radar	3.5
Cessna 400 Glideslope (Type R-443B)	0.5
Cessna 400 Nav/Com (Type RT-428A)	
HSI System (IG-832A)	
Slaved Directional Gyro (G-504A)	
Foster RNAV 511	
400 RMI	0.4
Avionics Cooling Fan	1.0
Interphone System	†
Primus 100 WX Radar	2.0
King KRA-10A Radar Altimeter	0.20
King KMA-24-03 Audio Panel W/MKR	0.16
King KX-165 Nav/Comm W/GS	0.4
King KY-196 Comm Transceiver	0.4
King KNS-81 RNAV/G. S.50
King KN-63 DME60
King K12-87 ADF43
King KT-79 Transponder36
King KI-229 RMI	1.00
King KT-96 Radio Telephone	0.50
King KWX-56 Color WX Radar	3.0
ITEMS NOT CONSIDERED AS PART OF RUNNING LOAD	
Cessna 300 Nav/Com (RT-385A)	2.3 ★
Cessna 400 Nav/Com (RT-485A, RT-485B)	2.3 ★
ASB-125 SSB HF Transceiver	7.5 ★
PT-10A Transceiver	
Auxiliary Fuel Pump	3.0
Cigarette Lighter	
Flap Motor	1.8
Landing Lights (Each)	3.6 EA
Stall Warning Horn40

MODEL 210 & T210 SERIES SERVICE MANUAL

ITEMS NOT CONSIDERED AS PART OF RUNNING LOAD	AMPS 1984
Wing Courtesy Lights and Cabin Lights	1.5
Ice Detector Light	1.5
Hydraulic Power Pack	14.0
Electric Elevator Trim51
Map Light (Glare Shield or Control Wheel)	0.1
Recognition Lights	3.6
Air Conditioning	22.8
King KX165	4.5
King KY196	5.0
KT-96 Radio Telephone	3.0
<p>*Console Lights not used with post lights.</p> <p>*Only one or the other may be used at one time.</p> <p>†Negligible</p> <p>● In flight running load *With Bootstrap ⊕ Transmit ☆ Receive □ Minimum to Maximum</p>	

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 18

STRUCTURAL REPAIR

TABLE OF CONTENTS	Page No. Aerofiche/Manual
STRUCTURAL REPAIR	3D12/18-2
Repair Criteria	3D12/18-2
Equipment and Tools	3D12/18-2
Support Stands	3D12/18-2
Fuselage Repair Jigs	3D12/18-2
Wing Jigs	3D12/18-2
Repair Materials	3D12/18-2
Wing Twist and Stabilizer	
Angle-of-Incidence	3D12/18-2
Wing	3D12/18-2
Description	3D12/18-2
Wing Skin	3D12/18-2
Negligible Damage	3D12/18-2
Repairable Damage	3D12/18-2
Damage Necessitating Replace- ment of Parts	3D13/18-3
Wing Stringers	3D13/18-3
Negligible Damage	3D13/18-3
Repairable Damage	3D13/18-3
Damage Necessitating Replace- ment of Parts	3D13/18-3
Wing Ribs	3D13/18-3
Negligible Damage	3D13/18-3
Repairable Damage	3D13/18-3
Damage Necessitating Replace- ment of Parts	3D13/18-3
Wing Spar	3D13/18-3
Negligible Damage	3D13/18-3
Repairable Damage	3D13/18-3
Damage Necessitating Replace- ment of Parts	3D13/18-3
Wing Fuel Bay Spars and Ribs	3D13/18-3
Negligible Damage	3D13/18-3
Repairable Damage	3D13/18-3
Damage Necessitating Replace- ment of Parts	3D13/18-3
Ailerons	3D13/18-3
Negligible Damage	3D13/18-3
Repairable Damage	3D13/18-3
Damage Necessitating Replace- ment of Parts	3D13/18-3
Aileron Balancing	3D13/18-3
Wing Flaps	3D14/18-4
Negligible Damage	3D14/18-4
Repairable Damage	3D14/18-4
Damage Necessitating Replace- ment of Parts	3D14/18-4
Elevators and Rudder	3D14/18-4
Negligible Damage	3D14/18-4
Repairable Damage	3D14/18-4
Damage Necessitating Replace- ment of Parts	3D14/18-4
Elevator and Rudder	
Balancing	3D14/18-4
Fin and Stabilizer	3D14/18-4
Negligible Damage	3D14/18-4
Repairable Damage	3D14/18-4
Damage Necessitating Replace- ment of Parts	3D14/18-4
Bonded Doors	3D14/18-4
Repairable Damage	3D14/18-4
Fuselage	3D14/18-4
Description	3D14/18-4
Negligible Damage	3D14/18-4
Repairable Damage	3D15/18-5
Damage Necessitating Replace- ment of Parts	3D15/18-5
Bulkheads	3D15/18-5
Landing Gear Bulkheads	3D15/18-5
Repair After Hard Landing	3D15/18-5
Firewall Damage	3D15/18-5
Fasteners	3D15/18-5
Rivets	3D15/18-5
Replacement of Hi-Shear	
Rivets	3D15/18-5
Substitution of Rivets	3D16/18-6A
Baffles	3D19/18-6D
Engine Cowling	3D19/18-6D
Repair of Cowling Skins	3D19/18-6D
Repair of Reinforcement	
Angles	3D20/18-7
Repair of Glass-Fiber	
Constructed Components	3D20/18-7

MODEL 210 & T210 SERIES SERVICE MANUAL

18-1. STRUCTURAL REPAIR.

18-2. REPAIR CRITERIA. Although this section outlines repair permissible on structure of the aircraft, the decision of whether to repair or replace a major unit of structure will be influenced by such factors as time and labor available and by a comparison of labor costs with the price of replacement assemblies. Past experience indicates that replacement, in many cases, is less costly than major repair. Certainly, when the aircraft must be restored to its airworthy condition in a limited length of time, replacement is preferable. Restoration of a damaged aircraft to its original design strength, shape and alignment involves careful evaluation of the damage, followed by exacting workmanship in performing the repairs. This section suggests the extent of structural repair practicable on the aircraft and supplements Federal Aviation Regulation, Part 43. Consult the factory when in doubt about a repair not specifically mentioned here.

18-3. EQUIPMENT AND TOOLS.

18-4. SUPPORT STANDS. Padded, reinforced sawhorse or tripod type support stands, sturdy enough to support any assembly placed upon them, must be used to store a removed wing or tailcone. Plans for local fabrication of support stands are contained in figure 18-1. The fuselage assembly, from the tailcone to the firewall, must NOT be supported from the underside, since the skin bulkheads are not designed for this purpose. Adapt support stands to fasten to the wing-attach points or landing gear attach-points when supporting a fuselage.

18-5. FUSELAGE REPAIR JIGS. Whenever a repair is to be made which could affect structural alignment, suitable jigs must be used to assure correct alignment of major attach points, such as fuselage, firewall, wing and landing gear. These fuselage repair jigs are obtainable from the factory.

18-6. WING JIGS. These jigs serve as a holding fixture during extensive repair of a damaged wing, and locates the root rib, leading edge and tip rib of the wing. These jigs are also obtainable from the factory.

18-7. REPAIR MATERIALS. Thickness of a material on which a repair is to be made can easily be determined by measuring with a micrometer. In general, material used in Cessna aircraft covered in this manual is made from 2024 aluminum alloy, heat treated to a -T3, -T4, or -T42 condition. If the type of material cannot readily be determined, 2024-T3 may be used in making repairs, since the strength of -T3 is greater than -T4 or -T42 (-T4 and -T42 may be used interchangeably, but they may not be substituted for -T3. When necessary to form a part with a smaller bend radius than the standard cold bending radius for 2024-T4, use 2024-0 and heat treat to 2024-T42 after forming. The repair material used in making a repair must equal the gauge of the material being repaired unless otherwise noted.

It is often practical to cut repair pieces from service parts listed in the Parts Catalog. A few components (empennage tips, for example) are fabricated from thermo-formed plastic or glass fiber constructed material.

18-8. WING TWIST AND STABILIZER ANGLE-OF-INCIDENCE. Wing twist (washout) and stabilizer angle of incidence are shown below. Stabilizers do not have twist. The cantilever wing has a uniform twist from the root rib to the tip rib. Refer to figure 18-2 for wing twist measurement.

WING	
Twist (Washout)	3°
STABILIZER	
Angle-of-incidence	-3° ± 15'

18-9. WING.

18-10. DESCRIPTION. The wing is sheet-metal constructed, with a single main spar, two fuel spars, formed ribs and stringers. The front fuel spar also serves as an auxiliary spar and is the forward wing attaching point. An inboard section forward of the main spar is sealed to form an integral fuel bay area. The main spar consists of milled spar caps and attaching fittings joined by a web section. The aft fuel spar is a formed channel. The front fuel spar is a built-up assembly consisting of a formed channel, doubler, attach strap and support angle. Stressed skin, riveted to the ribs, spars and stringers, completes the wing structure. Access openings (hand holes with removable cover plates) are located in the underside of the wing between the wing root and tip section. These openings afford access to the flap and aileron bellcranks, flap drive pulleys, flap actuator in left wing, flap and aileron control cable disconnect points, fuel adapter plate, air scoop connectors and electrical wiring.

18-11. WING SKIN.

18-12. NEGLIGIBLE DAMAGE. Any smooth dents in the wing skin that are free from cracks, abrasions and sharp corners, which are not stress wrinkles and do not interfere with any internal structure or mechanism, may be considered as negligible damage in any area of the wing. Outboard of wing station 40.00 in areas of low stress intensity, cracks, deep scratches or sharp dents, which after trimming or stop drilling can be enclosed by a two-inch circle, can be considered negligible if the damaged area is at least one diameter of the enclosing circle away from all existing rivet lines and material edges. The area on the lower surface of the wing between the two stringers adjacent to the main spar is not considered low stress intensity. Stop drilling is considered a temporary repair and a permanent repair should be made as soon as practicable.

18-13. REPAIRABLE DAMAGE. Repairs must not be made to the upper or lower wing skin inboard of station 40.00 without factory approval. However, an

MODEL 210 & T210 SERIES SERVICE MANUAL

entire skin may be replaced without factory approval. Refer to Section 1 for wing station locations. Figure 18-4 outlines typical repairs to be employed in patching skin. Before installing a patch, trim the damaged area to form a rectangular pattern, leaving at least a one-half inch radius at each corner and deburr. The sides of the hole should lie span-wise or chord-wise. A circular patch may also be used. If the patch is in an area where flush rivets are used, make a flush patch type of repair; if in an area where flush rivets are not used, make an overlapping type of repair. Where optimum appearance and airflow are desired, the flush patch may be used. Careful workmanship will eliminate gaps at butt-joints; however, an epoxy type filler may be used at such joints.

18-14. DAMAGE NECESSITATING REPLACEMENT OF PARTS. If a skin is badly damaged, repair must be made by replacing an entire skin panel, from one structural member to the next. Repair seams must be made to lie along existing structural members and each seam must be made exactly the same in regard to rivet size, spacing and pattern as the manufactured seams at the edges of the original sheet. If the manufactured seams are different, the stronger must be copied. If the repair ends at a structural member where no seam is used, enough repair panel must be used to allow an extra row of staggered rivets, with sufficient edge margin, to be installed.

18-15. WING STRINGERS.

18-16. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12.

18-17. REPAIRABLE DAMAGE. Figure 18-5 outlines a typical wing stringer repair. Two such repairs may be used to splice a new section of stringer material in position, without the filler material.

18-18. DAMAGE NECESSITATING REPLACEMENT OF PARTS. If a stringer is so badly damaged that more than one section must be spliced, replacement is recommended.

18-19. WING RIBS.

18-20. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12.

18-21. REPAIRABLE DAMAGE. Figure 18-6 illustrates typical wing rib repairs.

18-22. DAMAGE NECESSITATING REPLACEMENT OF PARTS. Any wing rib damaged extensively should be replaced. However, due to the necessity of disassembling so much of the wing in order to replace a rib, especially in the fuel bay area which involves sealing, wing ribs should be repaired if practicable.

18-23. WING SPAR.

18-24. NEGLIGIBLE DAMAGE. Due to the stresses which the wing spar encounters, very little damage can be considered negligible. Smooth dents, light

scratches and abrasions may be considered negligible.

18-25. REPAIRABLE DAMAGE. All cracks, stress wrinkles, deep scratches and sharp dents must be repaired. However, repairs must not be made to the main wing spar inboard of wing station 155.00 without factory approval. Refer to Section 1 for wing station locations. Figure 18-7 outlines a typical main wing spar repair.

18-26. DAMAGE NECESSITATING REPLACEMENT OF PARTS. An entire wing spar may be replaced without factory approval.

18-27. WING FUEL BAY SPARS AND RIBS.

18-28. NEGLIGIBLE DAMAGE. Any smooth dents in the fuel spars that are free from cracks, abrasions and sharp corners, which are not stress wrinkles and do not interfere with any internal structure or mechanism, may be considered as negligible damage in any area of the spar.

18-29. REPAIRABLE DAMAGE. The type of repair outlined in figure 18-7 also applies to fuel bay spars outboard of wing station 124.0. Inboard of station 124.0, factory approval of proposed repairs is required. Refer to Section 13 for sealing procedures when working in fuel bay areas.

18-30. DAMAGE NECESSITATING REPLACEMENT OF PARTS. Due to the amount of fuel bay sealant which must be removed from fuel bay components to facilitate repair, individual parts are not available to replace fuel bay spars or ribs. The entire fuel bay area must be replaced as a unit.

18-31. AILERONS.

18-32. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12.

18-33. REPAIRABLE DAMAGE. The repair shown in figure 18-8 may be used to repair damage to aileron leading edge skins. The flush-type skin patches shown in figure 18-4 may be used to repair damage to the remaining skins. Following repair, the aileron must be balanced. Refer to paragraph 18-35 and figure 18-3 for balancing the aileron.

18-34. DAMAGE NECESSITATING REPLACEMENT OF PARTS. If the damage would require a repair which could not be made between adjacent ribs, complete skin panels must be replaced. Ribs and spars may be repaired, but replacement is generally preferable. Where extensive damage has occurred, replacement of the aileron assembly is recommended. After repair or replacement, balance aileron in accordance with paragraph 18-35 and figure 18-3.

18-35. AILERON BALANCING. Following repair, replacement or painting, the aileron must be balanced. A flight control surface balancing fixture kit is available (P/N 5180002-1). See figure 18-3 for procedures pertaining to the use of this kit.

MODEL 210 & T210 SERIES SERVICE MANUAL

18-36. WING FLAPS.

18-37. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12.

18-38. REPAIRABLE DAMAGE. Flap repairs should be similar to aileron repairs discussed in paragraph 18-33. A flap leading edge repair is shown in figure 18-9.

18-39. DAMAGE NECESSITATING REPLACEMENT OF PARTS. Flap repairs which require replacement of parts should be similar to aileron repairs discussed in paragraph 18-34. Since the flap is not considered a movable control surface, no balancing is required.

18-40. WING LEADING EDGE.

18-41. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12.

18-42. REPAIRABLE DAMAGE. A typical leading edge skin repair is shown in figure 18-8. Also, wing skin repairs, outlined in paragraph 18-13, may be used to repair leading edge skins, although the flush-type patches should be used. Extra access holes, described in figure 18-10, must not be installed in the wing without factory approval. Where extreme damage has occurred, replace complete skin panels.

18-43. DAMAGE NECESSITATING REPLACEMENT OF PARTS. An entire leading edge skin may be replaced without factory approval.

18-44. ELEVATORS AND RUDDER.

18-45. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12. The exception to negligible damage on the elevator surfaces is the front spar, where a crack appearing in the web at the hinge fittings or in the structure which supports the overhanging balance weight is not considered negligible. Cracks in the overhanging tip rib, in the area at the front spar intersection with the web of the rib, also cannot be considered negligible.

18-46. REPAIRABLE DAMAGE. Skin patches illustrated in figure 18-4 may be used to repair skin damage. Following repair, the elevators and rudder must be balanced. Refer to paragraph 18-48 and figure 18-3 for balancing the elevators and rudder. If damage would require a repair which could not be made between adjacent ribs, see the following paragraph.

18-47. DAMAGE NECESSITATING REPLACEMENT OF PARTS. If the damaged area would require a repair which could not be made between adjacent ribs, complete skin panels must be replaced. Ribs and spars may be repaired, but replacement is generally preferable. Where extensive damage has occurred, replacement of the entire assembly is recommended. After repair and/or replacement, balance elevators and rudder in accordance with paragraph 18-48 and figure 18-3.

18-48. ELEVATOR AND RUDDER BALANCING. Following repair, replacement or painting, the elevators and rudder must be balanced. A flight control surface balancing fixture kit is available (P/N 5180002-1). See figure 18-3 for procedures pertaining to the use of this kit.

18-49. FIN AND STABILIZER.

18-50. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12.

18-51. REPAIRABLE DAMAGE. Skin patches illustrated in figure 18-4 may be used to repair skin damage. Access to the dorsal area of the fin may be gained by removing the horizontal closing rib at the bottom of the fin. Access to the internal fin structure is best gained by removing skin attaching rivets on one side of the rear spar and ribs, and springing back the skin. Access to the stabilizer structure may be gained by removing skin attaching rivets on one side of the rear spar and ribs, and springing back the skin. If the damaged area would require a repair which could not be made between adjacent ribs, or a repair would be located in an area with compound curves, see the following paragraph.

18-52. DAMAGE NECESSITATING REPLACEMENT OF PARTS. If the damaged area would require a repair which could not be made between adjacent ribs, or the repair would be located in an area with compound curves, complete skin panels must be replaced. Ribs and spars may be repaired, but replacement is generally preferable. Where damage is extensive, replacement of the entire assembly is recommended.

18-52A. BONDED DOORS.

18-52B. REPAIRABLE DAMAGE. Bonded doors may be repaired by the same methods used for riveted structure. Rivets are a satisfactory substitute for bonded seams on these assemblies. The strength of the bonded seams in doors may be replaced by a single 3/32, 2117-AD rivet per running inch of bond seam. The standard repair procedures outlined in AC43.13-1 are also applicable to bonded doors.

18-53. FUSELAGE.

CAUTION

Repairs must not be made to the main wing spar carry-thru section of the cantilever wing without factory approval.

18-54. DESCRIPTION. The fuselage is of semi-monocoque construction consisting of formed bulkheads, longitudinal stringers, reinforcing channels and skin platings.

18-55. NEGLIGIBLE DAMAGE. Refer to paragraph 18-12. Mild corrosion appearing upon alclad surfaces does not necessarily indicate incipient failure of the base metal. However, corrosion of all types must be carefully considered and approved remedial action taken. Small cans appear in the skin structure of all metal aircraft. It is strongly recommended,

MODEL 210 & T210 SERIES SERVICE MANUAL

however, that wrinkles which appear to have originated from other sources, or which do not follow the general appearance of the remainder of the skin panels, be thoroughly investigated. Except in the landing gear bulkhead area, wrinkles occurring over stringers which disappear when the rivet pattern is removed may be considered negligible. However, the stringer rivet holes may not align perfectly with the skin holes because of a permanent "set" in the stringer. If this is apparent, replacement of the stringer will usually restore the original strength characteristics of the area.

NOTE

Wrinkles occurring in the skin of the main landing gear bulkhead areas must not be considered negligible. The skin panel must be opened sufficiently to permit a thorough examination of the lower portion of the landing gear bulkhead and its tie-in structure.

Wrinkles occurring on open areas which disappear when the rivets at the edge of the sheet are removed, or a wrinkle which is hand removable, may often be repaired by the addition of a 1/2 x 1/2 x .060 inch 2024-T4 extruded angle, riveted over the wrinkle and extended to within 1/16 to 1/8 inch of the nearest structural members. Rivet pattern must be identical to the existing manufactured seam at the edge of the sheet.

18-56. REPAIRABLE DAMAGE. Fuselage skin repairs may be accomplished in the same manner as wing skin repairs outlined in paragraph 18-13. Stringers, formed skin flanges, bulkhead channels and similar parts may be repaired as shown in figure 18-5.

18-57. DAMAGE NECESSITATING REPLACEMENT OF PARTS. Fuselage skin major repairs may be accomplished in the same manner as wing skin repairs outlined in paragraph 18-14. Damaged fittings must be replaced.

18-58. BULKHEADS.

18-59. LANDING GEAR BULKHEADS. Since these bulkheads are highly stressed members irregularly formed to provide clearance for control lines, actuators, fuel lines, etc., patch type repairs will be, for the most part, impractical. Minor damage consisting of small nicks or scratches may be repaired by dressing out the damaged area, or by replacement of rivets. Any other such damage must be repaired by replacing the landing gear support assembly as an aligned unit.

18-60. REPAIR AFTER HARD LANDING. Buckled skin or floorboards and loose or sheared rivets in the area of the main gear support will give evidence of damage to the structure from an extremely hard landing. When such evidence is present, the entire support structure must be carefully examined and all support forgings must be checked for cracks, using a dye penetrant and proper magnification. Bulkheads in the area of possible damage must be

checked for alignment and a straightedge must be used to determine deformation of the bulkhead webs. Damaged support structure, buckled floorboards and skins and damaged or questionable forgings must be replaced.

18-61. FIREWALL DAMAGE. Firewalls may be repaired by removing the damaged material and splicing in a new section. The new portion must be lapped over the old material, sealed with Pro-Seal #700 (Coast Pro-Seal Co., Chemical Division, 2235 Beverly Blvd., Los Angeles, California) compound, or equivalent and secured with MS16535 (steel) or MS-20613 (corrosion-resistant steel) rivets. The heater valve assembly is attached with MS16535 and MS-20613 rivets. Firewall plates, firewall doublers, and nutplates are attached to the firewall with MS-20470 (aluminum) rivets. Damaged or deformed angles and stiffeners may be repaired as shown in figure 18-11, or they may be replaced. A severely damaged firewall must be replaced as a unit.

18-62. FASTENERS. Fasteners used in the aircraft are generally solid aluminum rivets, blind rivets, and steel-threaded fasteners. Usage of each is primarily a function of the loads to be carried, accessibility, and frequency of removal. Rivets used in aircraft construction are usually fabricated from aluminum alloys. In special cases, monel, corrosion-resistant steel and mild steel, copper, and iron rivets are used.

18-63. RIVETS. Standard solid-shank MS rivets are those generally used in aircraft construction. They are fabricated in the following head types: roundhead, flathead, countersunk head, and brazier head. Flathead rivets are generally used in the aircraft interior where head clearance is required. MS20426 countersunk head rivets are used on the exterior surfaces of the aircraft to minimize turbulent airflow. MS20470 brazier head rivets are used on the exterior surfaces of the aircraft where strength requirements necessitate a stronger rivet head than that of the countersunk head rivet. Both the brazier head and the countersunk head rivets are used on the exterior of the aircraft where head clearance is required. Hi-shear rivets are special, patented rivets having a hi-shear strength equivalent to that of standard AN bolts. They are used in special cases in locations where hi-shear loads are present, such as in spars, wings, and in heavy bulkhead ribs. This rivet consists of a cadmium-plated pin of alloy steel. Some have a collar of aluminum alloy. Some of these rivets can be readily identified by the presence of the attached collar in place of the formed head on standard rivets. Blind rivets are used, where strength requirements permit, where one side of the structure is inaccessible, making it impossible or impractical to drive standard solid-shank rivets.

18-64. REPLACEMENT OF HI-SHEAR RIVETS. Replacement of hi-shear rivets with close-tolerance bolts or other commercial fasteners of equivalent strength properties is permissible. Holes must not be elongated, and the hi-shear substitute must be a smooth, push-fit. Field replacement of main landing gear forgings on bulkheads may be accomplished by

MODEL 210 & T210 SERIES SERVICE MANUAL

using the following fasteners.

a. NAS464P-* bolt, MS21042-* nut and AN960-* washer in place of Hi-shear rivets for forgings with machined flat surfaces around attachment holes.

b. NAS464P-* bolt, ESNA2935-* mating base washer and ESNA RM52LH2935-* self-aligning nut for forgings (with draft angle of up to a maximum of 8°) without machined flat surfaces around attachment holes.

*Dash numbers to be determined according to the size of the holes and the grip lengths required. Bolt grip length should be chosen so that no threads remain in the bearing area.

18-65. SUBSTITUTION OF RIVETS.

a. Solid-shank rivets (MS20426AD and MS20470AD).

When placing rivets in installations which require raised head rivets, it is desirable to use rivets identical to the type of rivet removed. Countersunk-head rivets (MS20426) are to be replaced by rivets of the same type and degree of countersink. When rivet holes become enlarged, deformed, or otherwise damaged, use the next larger size rivet as a replacement. Replacement shall not be made with rivets of lower strength material.

b. Hi-shear Rivets. When hi-shear rivets are not available, replacement of sizes 3/16-inch or greater rivets shall be made with bolts of equal or greater strength than the rivet being replaced, and with self-locking nuts of the same diameter.

c. The following pages contain approved solid-shank and hi-shear rivet substitutions.

Replace	In thickness (or thicker)	With
MS20470AD3	.025	NAS1398B4, NAS1398D4 NAS1738B4, NAS1738D4, NAS1768D4, CR3213-4, CR3243-4
	.020	
MS20470AD4	.050	NAS1398B4, NAS1398D4 NAS1398B5, NAS1398D5, NAS1738B4, NAS1738E4, NAS1768D4, CR3213-4 NAS1738B5, NAS1738E5, NAS1768D5, CR3213-5, CR3243-4 CR3243-5
	.040	
	.032	
	.025	
MS20470AD5	.063	NAS1398B5, NAS1398D5 NAS1398B6, NAS1398D6, NAS1398B5, NAS1738E5, CR3213-5 NAS1738B6, NAS1738E6, NAS1768D5, CR3213-6, CR3243-5 CR3243-6
	.050	
	.040	
	.032	
MS20470AD6	.080	NAS1398B6 NAS1398D6 NAS1738B6, NAS1738D6, NAS1768D6, CR3213-6 CR3243-6
	.071	
	.063	
	.050	
MS20426AD3 (Countersunk)	.063	NAS1399B4, NAS1399D4 NAS1769D4, CR3212-4
	.040	
(See Note 1)	.025	NAS1769B4, NAS1739E4, CR3242-4

MODEL 210 & T210 SERIES SERVICE MANUAL

Replace	In thickness (or thicker)	With
MS20426AD4 (Countersunk)	.080	NAS1399B4, NAS1399D4
	.063	NAS1739B4, NAS1739D4, CR3212-4
	.050	NAS1769D4
	.040	CR3242-4
(See Note 1)	.050	CR3212-5
	.040	NAS1739B5, NAS1739D5, NAS1769D4
	.032	CR3242-5
MS20426AD4 (Dimpled)	.063	NAS1739B4, NAS1739D4
MS20426AD5 (Countersunk)	.090	NAS1399B5, NAS1399D5
	.080	CR3212-5
	.071	NAS1739B5, NAS1739E5
	.063	NAS1769D5
	.050	CR3242-5
(See Note 1)	.063	NAS1739B6, NAS1739D6, NAS1769D6,
	.040	CR3212-6
	.032	CR3242-6 AN509-10 Screw with MS20365 Nut
MS20426AD5 (Dimpled)	.071	NAS1739B5, NAS1739D5
	.090	NAS1739B6, NAS1739D6, CR3212-6
MS20426AD6 (Countersunk)	.071	NAS1769D6
	.063	CR3242-6
	.032	AN509-10 Screw with MS20365 Nut
MS20426AD6 (Dimpled)	.090	NAS1739B6, NAS1739D6
	.032	AN509-10 Screw with MS20365 Nut

NOTE 1: Rework required. Countersink oversize to accommodate oversize rivet.

NOTE 2: Do not use blind rivets in high-vibration areas or to pull heavy sheets or extrusions together. High-vibration areas include the nacelle or engine compartment including the firewall. Heavy sheets or extrusions include spar caps.

MODEL 210 & T210 SERIES SERVICE MANUAL

REPLACE		DIAMETER	WITH	
Fastener	Collar		Fastener	Collar
<ul style="list-style-type: none"> ● NAS178 	<ul style="list-style-type: none"> NAS179 	<ul style="list-style-type: none"> (See Note 1) (See Note 1) (See Note 1) (See Notes 1 and 2) (See Note 1) (See Note 1) 	<ul style="list-style-type: none"> ● NAS1054 ● NAS14XX ● NAS529 ★ NAS1446 ★ NAS7034 □ NAS464 □ NAS1103 □ NAS1303 □ NAS6203 □ AN173 	<ul style="list-style-type: none"> NAS179, NAS528 NAS1080C, NAS1080E, NAS1080G NAS524A NAS1080C, NAS1080A6 NAS1080K AN364, MS20364, MS21042 AN305, MS20305, MS21044, MS21045
<ul style="list-style-type: none"> ● NAS1054 	<ul style="list-style-type: none"> NAS179, NAS528 	<ul style="list-style-type: none"> (See Note 2) 	<ul style="list-style-type: none"> ● NAS14XX ● NAS529 ★ NAS1446 ★ NAS7034 □ NAS464 □ NAS1103 □ NAS1305 □ NAS6203 	<ul style="list-style-type: none"> NAS1080C, NAS1080E NAS524A NAS1080C, NAS1080A6 NAS1080K AN364, MS20304, MS21042
<ul style="list-style-type: none"> ● NAS14XX 	<ul style="list-style-type: none"> NAS1080C NAS1080E NAS1080G 		<ul style="list-style-type: none"> ● NAS529 ★ NAS1446 ★ NAS7034 □ NAS464 □ NAS1103 □ NAS1303 □ NAS6203 	<ul style="list-style-type: none"> NAS524A NAS1080C, NAS1080A6 NAS1080K AN364, MS20364, MS21042
<ul style="list-style-type: none"> ● NAS529 	<ul style="list-style-type: none"> NAS524A 	<ul style="list-style-type: none"> (See Note 3) 	<ul style="list-style-type: none"> □ NAS1446 	<ul style="list-style-type: none"> NAS1080C, NAS1080A6

NOTE 1: See appropriate tables for nominal diameters available.

NOTE 2: Available in oversize for repair of elongated holes. Ream holes to provide a .001 inch interference fit.

NOTE 3: NAS1446 oversize only permitted as a replacement for NAS529.

● Steel shank fastener designed for drive-on collars.

★ Steel shank fastener designed for squeeze-on collars. Installation requires sufficient space for the tool and extended shank of the fastener.

□ Threaded fastener.

MODEL 210 & T210 SERIES SERVICE MANUAL





Figure 18-1. Wing and Fuselage Support Stands

18-66. **BAFFLES.** Baffles ordinarily require replacement if damaged or cracked. However, small plate reinforcements riveted to the baffle will often prove satisfactory both to the strength and cooling requirements of the unit.

18-67. **ENGINE COWLING.**

18-68. **REPAIR OF COWLING SKINS.** If extensively damaged, complete sections of cowling must be re-

MODEL 210 & T210 SERIES SERVICE MANUAL



ALL WING TWIST OCCURS BETWEEN STA. 26.50 AND STA. 205.00.

CHECKING WING TWIST

If damage has occurred to a wing, it is advisable to check the twist. The following method can be used with a minimum of equipment, which includes a straightedge (42" minimum length of angle or equivalent), three modified bolts and a protractor head with level.

1. Check chart for applicable dimension for bolt length (A or B).
2. Grind bolt shanks to a rounded point as illustrated, checking length periodically.
3. Tape two bolts to straightedge according to dimension C.
4. Locate inboard wing station to be checked and make a pencil mark approximately one-half inch aft of first lateral row of rivets, aft of wing leading edge.
5. Holding straightedge parallel to wing station, (staying as clear as possible from "cans"), place bolt on pencil mark and set protractor head against lower edge of straightedge.
6. Set bubble in level to center and lock protractor to hold this reading.
7. Omitting step 6, repeat procedure for outboard wing station, using dimensions specified in chart. Check to see that protractor bubble is still centered.
8. Proper twist is present in wing if protractor readings are the same (parallel). Forward or aft bolt may be lowered from wing .10 inch maximum to attain parallelism.

Figure 18-2. Checking Wing Twist


placed. Standard insert-type patches, however, may be used if repair parts are formed to fit. Small cracks may be stop-drilled and dents straightened if they are reinforced on the inner side with a doubler of the same material. Bonded cowling may be repaired by the same methods used for riveted structure. Rivets are a satisfactory substitute for bonded seams on these assemblies. The strength of the bonded seams in cowling may be replaced by a single 3/32, 2117-AD rivet per running inch of bond seam. The standard repair procedures outlined in Advisory Circular 43.13-1 are also applicable to cowling.

18-69. REPAIR OF REINFORCEMENT ANGLES. Cowl reinforcement angles, if damaged, must be replaced. Due to their small size they are easier to replace than to repair.

18-70. REPAIR OF GLASS-FIBER CONSTRUCTED COMPONENTS. Glass-fiber constructed components on the aircraft may be repaired as stipulated in instructions furnished in SK182-12. Observe the resin manufacturer's recommendations concerning mixing and application of the resin. Epoxy resins are preferable for making repairs, since epoxy compounds are usually more stable and predictable than polyester and give better adhesion.

MODEL 210 & 1210 SERIES SERVICE MANUAL

FLIGHT CONTROL SURFACE BALANCING FIXTURE KIT (PART NUMBER 5180002-1)



GENERAL NOTES

1. Balance control surfaces in a draft-free area.
2. Place hinge bolts through control surface hinges and position on knife edge balancing mandrels. Be sure hinge bolt shank rests on knife edge.
3. Make sure all control surfaces are in their approved flight configurations: painted (if applicable), trim tabs installed, all foreign matter removed from inside of control surface, elevator trim tab push-pull rod installed and all tips installed.
4. Place balancing mandrels on a table or other suitable flat surface.
5. Adjust trailing edge support to fit control surface being balanced while center of balancing beam is directly over hinge line. Remove balancing beam and balance the beam itself by moving the adjustable weight (fastened by bolt and washer). Fine balance may be accomplished by use of washers at long screw on end of beam.
6. When positioning balancing beam on control surface, avoid rivets to provide a smooth surface for the beam and keep the beam 90° to the hinge line of the control surface.

Figure 18-3. Control Surface Balancing (Sheet 1 of 5)

MODEL 210 & T210 SERIES SERVICE MANUAL

7. Paint is a considerable weight factor. In order to keep balance weight to a minimum, it is recommended that existing paint be removed before adding paint to a control surface. Increase in balance weight will also be limited by the amount of space available and clearance with adjacent parts. Good workmanship and standard repair practices should not result in unreasonable balance weight.
8. The approximate amount of weight needed may be determined by taping loose weight at the balance weight area.
9. Lighten balance weight by drilling off part of weight.
10. Make balance weight heavier by fusing bar stock solder to weight after removal from control surface. The ailerons should have balance weight increased by ordering additional weight and gang channel, listed in applicable Parts Catalog and installing next to existing inboard weight the minimum length necessary for correct balance, except that a length which contains at least two attaching screws must be used. If necessary, lighten new weight or existing weights for correct balance.




Figure 18-3. Control Surface Balancing (Sheet 2 of 5)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 18-3. Control Surface Balancing (Sheet 3 of 5)

MODEL 210 & T210 SERIES SERVICE MANUAL

AILERONS




Figure 18-3. Control Surface Balancing (Sheet 4 of 5)

MODEL 210 & T210 SERIES SERVICE MANUAL

CONTROL SURFACE BALANCE REQUIREMENTS

NOTE

Balance limits for control surfaces are expressed for "Approved Flight" configuration. "Approved Flight" configuration is that condition of the control surface as prepared for flight of the airplane whether it be painted or unpainted.

"Approved Flight" limits must never be exceeded when the surface is in its final configuration for flight.

DEFINITIONS:

UNDERBALANCE is defined as the condition that exists when surface is trailing edge heavy and is defined by a symbol (+). If the balance beam sliding weight must be on the leading edge side of the hinge line (to balance the control surface), the control surface is considered to be underbalanced.



OVERBALANCE is defined as the condition that exists when surface is leading edge heavy and is defined by a symbol (-). If the balance beam sliding weight must be on the trailing edge side of the hinge line (to balance the control surface), the control surface is considered to be overbalanced.




CONTROL SURFACE	APPROVED FLIGHT CONFIGURATION BALANCE LIMITS (Inch-Pounds)
AILERON	4.25 to 11.16
RUDDER	-4.0 to 3.0
RIGHT ELEVATOR	0.0 to 12.1
LEFT ELEVATOR	0.0 to 12.1


Figure 18-3. Control Surface Balancing (Sheet 5 of 5)

MODEL 210 & T210 SERIES SERVICE MANUAL


PATCHES AND DOUBLERS — 2024-T3 ALCLAD



PATCH REPAIR FOR 3 INCH DIAMETER HOLE



PATCH REPAIR FOR 2 INCH DIAMETER HOLE



PATCH REPAIR FOR 1 INCH DIAMETER HOLE






Figure 18-4. Skin Repair (Sheet 1 of 6)




MODEL 210 & T210 SERIES SERVICE MANUAL



SECTION THRU ASSEMBLED PATCH

A-A




-  ORIGINAL PARTS
-  REPAIR PARTS
-  REPAIR PARTS IN CROSS SECTION

OVERLAPPING REC-TANGULAR PATCH

RIVET TABLE	
SKIN GAGE	RIVET DIA.
.020	1/8
.025	1/8
.032	1/8
.040	1/8
.051	5/32


Figure 18-4. Skin Repair (Sheet 2 of 6)




MODEL 210 & T210 SERIES SERVICE MANUAL



NOTE

For optimum appearance and airflow, use flush rivets, dimpled skin and patch and counter-sunk doubler.



-  ORIGINAL PARTS
-  REPAIR PARTS
-  REPAIR PARTS IN CROSS SECTION

FLUSH RECTANGULAR PATCH
(CIRCULAR FLUSH PATCH IS SIMILAR)

RIVET TABLE	
SKIN GAGE	RIVET DIA.
.020	1/8
.025	1/8
.032	1/8
.040	1/8
.051	5/32

Figure 18-4. Skin Repair (Sheet 3 of 6)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 18-4. Skin Repair (Sheet 4 of 6)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 18-4. Skin Repair (Sheet 5 of 6)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 18-4. Skin Repair (Sheet 6 of 6)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 18-5. Stringer and Channel Repair (Sheet 1 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 18-5. Stringer and Channel Repair (Sheet 2 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 18-5. Stringer and Channel Repair (Sheet 3 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 18-5. Stringer and Channel Repair (Sheet 4 of 4)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 18-6. Rib Repair (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 18-6. Rib Repair (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 18-7. Wing Spar Repair

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

1. Dimple leading edge skin and filler material; countersink the doubler.
2. Use MS20426AD4 rivets to install doubler.
3. Use MS20426AD4 rivets to install filler, except where bucking is impossible. Use CR162-4 Cherry (blind) rivets where regular rivets cannot be bucked.
4. Contour must be maintained; after repair has been completed, use epoxy filler as necessary and sand smooth before painting.
5. On cantilever wing, vertical size is limited by ability to install doubler clear of front fuel spar or stringers outboard of spar. On flaps and ailerons, vertical size is limited by ability to install doubler clear of front spar. (Also refer to figure 18-9.)
6. Lateral size is limited to seven inches across trimmed out area.
7. Number of repairs is limited to one in each bay. On cantilever wings, consider a bay in the area forward of front fuel spar as if ribs extended to leading edge.




Figure 18-8. Leading Edge Repair

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 18-9. Flap Leading Edge Repair

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 18-10. Access Hole Installation

MODEL 210 & T210 SERIES SERVICE MANUAL




Figure 18-11. Firewall Angle Repair

MODEL 210 & T210 SERIES SERVICE MANUAL

① Use rivet pattern at wing station 25.25 for repair from wing station 25.25 to wing station 96.00. Use rivet pattern at wing station 110.00 for lap splice patterns from wing station 110.00 to 189.00. See figure 1-2 for wing stations.

② Use rivet spacing similar to the pattern at wing station 110.00 at leading edge ribs between lap splices.


Select number of flush rivets to be used at each wing station leading edge rib from table.

RIBS AND STRINGERS:

Blind rivets may be substituted for solid rivets in proportionally increased numbers in accordance with the table.

SPARS:


Blind rivets may be installed in wing spars only in those locations where blind rivets were used during original manufacture, ie fuel bay area of front spars on aircraft with integral fuel bays.



NUMBER OF FLUSH RIVETS IN DIMPLED SKIN REQUIRED IN REPLACEMENT LEADING EDGE SKIN

WING STATION RIB	SOLID MS20426-4	BLIND CR2248-4
124	18	22
136	15	18
155	11	13
172	10	12
189	10	12

EXISTING TACK RIVET



PATCH

EXISTING RIVET PATTERN

TYPICAL LEADING EDGE SECTION

Figure 18-12. Bonded Leading Edge Repair

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 19

EXTERIOR PAINTING

	Page No. Aerofiche/Manual		
TABLE OF CONTENTS			
MATERIALS LISTING	3E21/19-1	APPLICATION	3E24/19-4
APPLICATION	3E22/19-2	Cleanup	3E24/19-4
Interior Parts	3E22/19-2	Prepriming	3F1/19-5
Exterior Parts Acrylic	3E22/19-2	Priming	3F1/19-5
Exterior Parts Epoxy or		Prepainting	3F1/19-5
Polyurethane	3E22/19-2	Painting Overall -- White or Color	3F2/19-6
MATERIALS LISTING	3E23/19-3	Stripes	3F2/19-6
FACILITY	3E24/19-4	Touchup	3F2/19-6
		Repair of Dents	3F2/19-6

NOTE

Acrylic Lacquer is standard through serial 21061849

NOTE

This section contains a listing of standard factory materials and shows the area of their application. To determine the paint number and color, refer to the aircraft trim plate and parts catalog. In all cases, determine the type of paint because some types are not compatible with others. Contact Cessna Parts Distribution (CPD 2) or a Cessna Service Station for materials acquisition information.

19-1. MATERIALS LISTING.

MATERIAL	NO. /TYPE	AREA OF APPLICATION
PAINT	ACRYLIC LACQUER	Used on exterior airframe. (THRU SERIAL 21061849)
PRIMER	ER-7 WITH ER-4 ACTIVATOR	Used with acrylic lacquer.
PRIMER	P60G2 WITH R7K44 ACTIVATOR	Used with acrylic lacquer.
THINNER	T-8402A	Used to thin acrylic lacquer and for burndown.
SOLVENT	#2 SOLVENT	Used to clean aircraft exterior prior to priming.

NOTE

Do not paint Pitot Tube, Gas Caps or Antenna covers which were not painted at the factory.

NOTE

When stripping paint from aircraft, do not allow stripper to contact ABS parts.

MODEL 210 & T210 SERIES SERVICE MANUAL

19-2. APPLICATION

9-3. INTERIOR PARTS (Finish Coat of Lacquer)

a. Painting of Spare Parts.

1. Insure a clean surface by wiping with Form Tech AC to remove surface contamination.

CAUTION

Do not use strong solvents such as Xylol, Toluol or Lacquer Thinner since prolonged exposure can soften or embrittle ABS.

2. After the part is thoroughly dry it is ready or the lacquer topcoat. Paint must be thinned with lacquer thinner and applied as a wet coat to insure adhesion.

b. Touch Up of Previously Painted Parts.

1. Light sanding is acceptable to remove scratches and repair the surface but care must be exercised to maintain the surface texture or grain.
2. Insure a clean surface by wiping with Form Tech AC to remove surface contamination.

CAUTION

Do not use strong solvents such as Xylol, Toluol or Lacquer Thinner since prolonged exposure can soften or embrittle ABS.

3. After the part is thoroughly dry it is ready for the lacquer topcoat. Paint must be thinned with lacquer thinner and applied as a wet coat to insure adhesion.

NOTE

Lacquer paints can be successfully spotted in.

19-4. EXTERIOR PARTS (Acrylic Topcoat)

a. Painting of Spare Parts.

1. Lightly scuff sand to remove scratches and improve adhesion.
2. Insure a clean surface by wiping with Form Tech AC to remove surface contamination.

CAUTION

Do not use strong solvents such as Xylol, Toluol or Lacquer Thinner since prolonged exposure can soften or embrittle ABS.

3. After the part is thoroughly dry it is ready for the topcoat. Paint must be thinned with appropriate acrylic thinner and applied as a wet coat to insure

adhesion.

b. Touch Up of Previously Painted Parts.

1. Lightly scuff sand to remove scratches and improve adhesion.
2. Insure a clean surface by wiping with Form Tech AC to remove surface contamination.

CAUTION

Do not use strong solvents such as Xylol, Toluol or Lacquer Thinner since prolonged exposure can soften or embrittle ABS.

3. Apply a compatible primer - surfacer and sealer.

4. After the part is thoroughly dry it is ready for the topcoat. Paint must be thinned and applied as a wet coat to insure adhesion.

NOTE

Acrylic topcoats can be successfully spotted in.

19-5. EXTERIOR PARTS (Epoxy or Polyurethane Topcoat)

a. Painting of Spare Parts and Touch Up of Painted Parts.

1. Lightly scuff sand to remove scratches and improve adhesion.
2. Insure a clean surface by wiping with Form Tech AC to remove surface contamination.

CAUTION

Do not use strong solvents such as Xylol, Toluol or Lacquer Thinner since prolonged exposure can soften or embrittle ABS.

3. Apply a primer compatible with Epoxy or Polyurethane topcoat.

4. After the part is thoroughly dry it is ready for the topcoat.

NOTE

Epoxy or Polyurethane topcoats cannot be successfully spotted in - finish should be applied in areas with natural breaks such as skin laps or stripe lines.

When painting interior and exterior polycarbonate parts, or where the part material is questionable, a "barrier primer" should be applied prior to the Enamel, Lacquer, Epoxy or Polyurethane topcoat.

MODEL 210 & T210 SERIES SERVICE MANUAL

19-6. MATERIALS LISTING.

NOTE

Enflex III is standard beginning 21061850 thru 21062000 and 21062002 thru 21062009, 21062011, 21062012, 21062019, 21062023 thru 21062025, 21062027 thru 21062029, 2106231 thru 2106233, 21062035, 21062037 thru 21062039, 21062043, 21062044, 21062046 thru 21062049, 21062054, 21062055, 21062057, 21062059, 21062065, 21062069, and 21062072.

ENMAR MODIFIED URETHANE

MATERIAL	NO/TYPE	AREA OF APPLICATION
PAINT	ENFLEX III ENAMEL	Standard Exterior, and Stripe Only configuration
	ENFLEX III ADDUCT	Catalyst for Enflex III Enamel
ACCELERATOR	URETHANE ACCELERATOR 120-975	Used to speed curing on stripes
PRIMER	WASH PRIMER EX-ER-7	Used to prime aircraft for Enflex III topcoat
REDUCER	T-ER-4	Used to thin EX-ER-7
THINNER	Jet Glo 86T-10399 (110-655)	Used to thin Enflex III
	110-805	Used to thin Enflex III
RETARDER	110-996	Used to slow curing time

NOTE

Imron is Standard beginning with 21062001, 21062010, 21062013 thru 21062018, 21062020 thru 21062022, 21062026, 21062030, 21062034, 21062036, 21062040 thru 21062042, 21062045, 21062050 thru 21062053, 21062056, 21062058, 21062060 thru 21062064, 21062066 thru 21062068, 21062070, 21062071, 21062073 and all 1978 Models.

IMRON MODIFIED URETHANE

MATERIAL	NO/TYPE	AREA OF APPLICATION
PAINT	IMRON ENAMEL	Used as corrosion proof topcoat
	IMRON 192S Activator	Catalyst for Imron Enamel
PRIMER	WASH PRIMER P60G2	Used to prime aircraft for Imron Enamel
REDUCER, THINNER	IMRON Y8485S Reducer	Used to thin Imron Enamel
	Catalyst Reducer R7K44	Used to reduce P60G2

NOTE

Do not paint pitot tube, gas caps, or aileron gap seals. Also do not paint antenna covers which were not painted at the factory.

MODEL 210 & T210 SERIES SERVICE MANUAL

MATERIAL	NO/TYPE	AREA OF APPLICATION
STRIPPER	Strypeeze Stripper	Used to strip primer overspray
CLEANER	Form Tech AC	Used to clean aircraft exterior and to remove grease, bug stains, etc.
	Klad Polish	Used to clean aluminum finish
	808 Polishing Compound	Used to rub out overspray
SOLVENT	(MEK) Methyl Ethyl Ketone	Used to tack aircraft prior to topcoat
CLOTH	HEX Wiping Cloth	Used with solvent to clean aircraft exterior
FILLER	White Streak	Used to fill small dents
MASKING	Class A Solvent Proof Paper	Used to mask areas not to be painted
	Tape Y218	Used for masking small areas
	Tape Y231	Used for masking small areas

19-7. FACILITY. Painting facilities must include the ability to maintain environmental control; temperature at 65°F., and a positive pressure inside to preclude the possibility of foreign material damage. All paint equipment must be clean, and accurate measuring containers available for mixing protective coatings. Modified Urethane has a pot life of four to eight hours, depending on ambient temperature and relative humidity. Use of approved respirators while painting is a must, for personal safety. All solvent containers should be grounded to prevent static build-up. Catalyst materials are toxic, therefore, breathing fumes or allowing contact with skin can cause serious irritation. Material stock should be rotated to allow use of older materials first, because its useful life is limited. All supplies should be stored in an area where temperature is higher than 50°F., but lower than 90°F. Storage at 90°F is allowable for no more than sixty days providing it is returned to room temperature for mixing and use.

Modified urethane paint requires a minimum of seven days to cure under normal conditions, if humidity and temperature is lower, curing time will be extended a maximum of 14 days. During the curing period, indiscriminate use of masking tape, abrasive polishes, or cleaners can cause damage to finish. Desirable curing temperature for modified urethane is 60°F. for a resulting satisfactory finish.

19-8. APPLICATION.

19-9. CLEAN UP.

a. Inspect airplane for any surface defects, such as dents or unsatisfactory previous repairs, and correct according to Paragraph 18-9.

b. Wipe excess sealer from around windows and skin laps, using Form Tech AC. Mask windows, ABS parts and any other areas not to be primed, with 3M tape and Class A Solvent-Proof Paper. Care must be exercised to avoid cuts, scratches or gouges by metal objects to all plexiglass surfaces, because cuts and scratches may contribute to crazing and failure of plexiglass windows.

c. Methyl Ethyl Ketone (MEK) solvent should be used for final cleaning of airplanes prior to painting. The wiping cloths shall be contaminant and lint free HEX. Saturate cloth in the solvent and wring out so it does not drip. Wipe the airplane surface with the solvent saturated cloth in one hand, and immediately dry with a clean cloth in the other hand. It is important to wipe dry solvent before it evaporates. Avoid contact of MEK with plexiglass, as crazing will result.

When an airplane has paint or zinc chromate overspray on the exterior, stripper may be used to remove the overspray. The stripped may be applied by brush and will require a few minutes to soften the overspray. Heavy coatings may require more than one application of the stripper. Use extreme care to prevent stripper from running into faying surfaces on corrosion proofed airplanes. After removal of the overspray, clean the airplane with Methyl Ethyl Ketone (MEK) solvent in the prescribed manner.

NOTE

It is imperative that clean solvent be used in cleaning airplanes. Dispose of contaminated solvent immediately. Fresh solvent should be used on each airplane.

WARNING

Use explosion proof containers for storing wash solvents and other flammable materials.

MODEL 210 & T210 SERIES SERVICE MANUAL

19-10. PREPRIMING.

NOTE

Enflex III is standard beginning 21061850 thru 21062000 and 21062002 thru 21062009, 21062011, 21062012, 21062019, 21062023 thru 21062025, 21062027 thru 21062029, 2106231 thru 2106233, 21062035, 21062037 thru 21062039, 21062043, 21062044, 21062046 thru 21062049, 21062054, 21062055, 21062057, 21062059, 21062065, 21062069, and 21062072.

a. Above serialized aircraft have Enmar Wash Primer EX-ER-7, Enflex III Enamel for overall color and stripes.

b. Mix one to one, EX-ER-7 primer with T-ER-4 Reducer by volume. Mix only in stainless steel or lined containers only. After mixing allow primer to set for 30 minutes before spraying. Pot life of the mixed primer is six (6) hours. All mixed material should be discarded if not used within this time.

Pot pressure during spraying should be approximately 10 PSI \pm 1 PSI. Air pressure should be 40 to 50 PSI at the gun. Blow loose contaminant of the aircraft with clean, dry air. Check all tapes to make sure it adheres properly. Cover the flap tracks, nose gear strut tube, wheels, and shimmy dampener rod ends. ABS parts and other preprimed parts do not receive wash primer.

NOTE

Imron is Standard beginning with 21062001, 21062010, 21062013 thru 21062018, 21062020 thru 21062022, 21062026, 21062030, 21062034, 21062036, 21062040 thru 21062042, 21062045, 21062050 thru 21062053, 21062056, 21062058, 21062060 thru 21062064, 21062066 thru 21062068, 21062070, 21062071, 21062073 and all 1978 Models.

c. Corrosion proofed and standard aircraft will receive Sherwin Williams Primer P60G2, DuPont Imron Enamel for over all color, and for stripes.

d. Mix 1 part P60G2 primer with 1 1/2 parts R7K44 catalyst reducer, by volume. Mix in stainless steel or lined containers only. After mixing allow primer to set for 30 minutes before spraying. Pot life of the mixed primer is six (6) hours, all mixed materials should be discarded if not used within that time limit. Pot pressure during spraying should be approximately 10 PSI \pm 1 PSI. Air pressure should be 40 to 50 PSI at the gun. Blow loose contaminant off the airplane with clean, dry air. Check all tapes to make sure they adhere properly. Cover the flap tracks, nose gear strut tube, wheels, and shimmy dampener rod ends. ABS parts and other preprimed parts do not receive wash primer.

WARNING

AIRCRAFT SHOULD BE GROUNDED
PRIOR TO PAINTING TO PREVENT STATIC
ELECTRICITY BUILDUP AND DISCHARGE.

19-11. PRIMING.

a. Apply primer in one wet even coat. Dry film thickness to be .0003 to .0005 inches. Do not top-coat until sufficiently cured. When scratching with firm pressure of the fingernail does not penetrate the coating, the primer is cured. Primer should be topcoated within four hours after application.

19-12. PREPAINTING.

NOTE

Enflex III is standard beginning 21061850 thru 21062000 and 21062002 thru 21062009, 21062011, 21062012, 21062019, 21062023 thru 21062025, 21062027 thru 21062029, 2106231 thru 2106233, 21062035, 21062037 thru 21062039, 21062043, 21062044, 21062046 thru 21062049, 21062054, 21062055, 21062057, 21062059, 21062065, 21062069, and 21062072.

a. On above serialized aircraft, mix the required amount of Enflex III with Enflex III Adduct in a 4 to 1 ratio by volume. Mix thoroughly, and allow to stand for approximately 30 minutes before spraying. Enflex III can be thinned with Jet Glo thinner 86T-10399 (110-655) to obtain spraying viscosity, which should be checked after four hours and adjusted if necessary.

NOTE

Imron is Standard beginning with 21062001, 21062010, 21062013 thru 21062018, 21062020 thru 21062022, 21062026, 21062030, 21062034, 21062036, 21062040 thru 21062042, 21062045, 21062050 thru 21062053, 21062056, 21062058, 21062060 thru 21062064, 21062066 thru 21062068, 21062070, 21062071, 21062073 and all 1978 Models.

b. On standard aircraft mix the required amount of Imron with Imron 192S Activator in a 3 to 1 ratio by volume. Mix thoroughly, and begin spraying immediately, because there is no induction time requirement. Imron can be thinned to spraying viscosity with Y8485S Imron Reducer. Viscosity should be checked and adjusted after four hours if necessary.

c. When applying modified urethane finishes, the painter should wear an approved respirator, which has a dust filter and organic vapor cartridge, or an air supplied respirator. All modified urethane finishes contain some isocyanate, which may cause irritation to the respiratory tract or an allergic reaction. Individuals may become sensitized to isocyanates.

d. The pot life of the mixture is approximately 6-8 hours at 75°F (24°C). Pot pressure should be approximately 12 PSI during application. Air pressure at the gun should be 40 to 50 PSI.

e. Scuff sand the primer only where runs or dirt particles are evident. Minor roughness or grit may be removed by rubbing the surface with brown Kraft

MODEL 210 & T210 SERIES SERVICE MANUAL

paper which has been thoroughly wrinkled. Unmask ABS and other preprimed parts and check tapes. Clean surface with a jet of low pressure-dry air.

19-13. PAINTING OVERALL -- WHITE OR COLOR.

a. Complete painting of the plane should be done with two or three wet, even coats. Dry coats will not reflow and will leave a grainy appearance.

b. Allow a five minute period for the finish to flash off before moving aircraft to the oven.

c. Move to the force dry oven and dry for approximately 1 1/2 hours at 120°F to 140°F (49°C to 60°C).

d. Dry film thickness of the overall color should be between 1.3 and 2.0 mils. Films in excess of 3.0 mils are not desirable.

19-14. STRIPES.

a. Remove airplane from the oven. Allow airplane to cool to room temperature before masking.

b. Mask stripe area using 3M Tape Y231 or 3M Tape Y218 and Class A solvent proof paper. Double tape all skin laps to prevent blow by.

c. Airplanes which will have a stripe only configuration shall be masked, cleaned, and primed, in stripe area only.

d. If the base coat is not over 72 hours old, the stripe area does not require sanding. If sanding is necessary because of age or to remove surface defects, use #400 or #600 sand paper. Course paper will leave sand marks which will decrease gloss and depth of gloss of the finish. The use of power sanders should be held to a minimum; if used, exercise care to preclude sanding through the white base coat. Wipe surface to be striped with a tack cloth and check all tapes.

e. Stripe colors on Enflex III, Jet Glo, or acrylic base coat will be Acry Glo, and on Imron modified urethane base coat will be Imron Enamel. When mixing tints for stripes, stir the containers for at least 20 minutes before weighing out the required masses. Mix Acry Glo using three volumes of 571 Series Base with one volume of 581-091 catalyst; thin mixture with 110-701 or 110-755 thinners 20% to 25% by volume (18 to 25 seconds in a No. 2 Zahn cup). Mix Imron using eight volumes of base with one volume VG-Y-1421 catalyst (ratio three to one if 1925 activator used); thin with Cessna Thinner No. 1 (18 to 20 seconds in a No. 2 Zahn cup).

f. Painting of the stripe should be done with two or three wet, even coats. Dry coats will not reflow and will leave a grainy appearance. Stripes may be force dried or air dried. Film thickness of a stripe is approximately 1.0 mil.

g. Do not remove masking tape and paper until the paint has dried to a "dry to touch" condition. Care should be exercised in removal of the masking to prevent damage to the finish.

h. Uncured urethane finishes are sensitive to moisture, therefore, should be stored out of rain until cured.

19-15. TOUCHUP.

When necessary to touch up or refinish an area, the defect should be sanded with #400 and followed by #600 sand paper. Avoid, if possible, sanding through the primer. If the primer is penetrated over an area 1/2 inch square or larger, repriming is necessary. Avoid spraying primer on the adjacent paint as much as possible. Since urethane finishes cannot be "spotted in" repairs should be in sections extending to skin laps or stripe lines.

a. Dry overspray and rough areas may be compounded out with DuPont #808 rubbing compound.

b. Grease, bug stains, etc., may be removed from painted surfaces with Form Tech AC. Klad Polish may be used on bare aluminum to remove stains, oxides, etc.

c. Rework areas, where paint or primer removal is required, may be stripped with Strypeeze Paint Removal. All traces of stripper must be removed before refinishing.

19-16. REPAIR OF DENTS.

a. To repair dents use White Streak Filler or equivalent. Mix White Streak in the correct proportion as recommended by the manufacturer.

b. Do not apply White Streak Filler over paint. All paint shall be removed in the repair area and the aluminum surface sanded lightly to increase adhesion. Apply the White Streak to a level slightly above the surrounding skin. After drying for 10 - 15 minutes, sand the filler flush with the skin surface, using care to feather the edges.

MODEL 210 & T210 SERIES SERVICE MANUAL

SECTION 20 WIRING DIAGRAMS

TABLE OF CONTENTS	Page No. Aerofiche/Manual	OTHER INSTRUMENTS	
Circuit Function and Specific		Clock	3H22/20-62
Circuit Code Letters	3F7/20-2A	Ammeter	3H23/20-63
Circuit Function and Wires	3F8/20-3	Ammeter	3H24/20-64
Wiring Diagram Serial Numbers		Digital Clock (OPT)	3I1/20-65
Vs. Aircraft Serial Numbers	3F8/20-3	Ammeter	3I2/20-66
D.C. POWER		LIGHTING	
Battery Circuit	3F10/20-5	Electroluminescent Panel	3I3/20-67
Ground Service Receptacle (OPT)	3F11/20-6	Electroluminescent Panel	3I4/20-68
Alternator System	3F12/20-7	Instrument Lights	3I5/20-69
Circuit Breakers	3F14/20-9	Instrument Lights	3I7/20-71
Alternator System	3F15/20-10	Landing Lights	3I8/20-72
Alternator System, 95 Amp (OPT)	3F16/20-11	Navigation Lights	3I9/20-73
Circuit Breakers	3F17/20-12	Dome, Courtesy, & Baggage Lights	3I11/20-75
Alternator System, 60 Amp	3F19/20-14	Console & Compass Lights	3I13/20-77
Alternator System, 95 Amp (OPT)	3F21/20-16	Eyebrow Lights	3I15/20-79
Circuit Breakers	3F23/20-18	Wing Tip Strobe Lights (OPT)	3I17/20-81
Battery Circuit	3F24/20-19	Wing Tip Strobe Lights (OPT)	3I19/20-83
Circuit Breakers	3G1/20-20	Flashing Beacon Light	3I20/20-84
Circuit Breakers	3G3/20-22	Flashing Beacon Light	3I22/20-86
Circuit Breakers	3G4/20-23	Post Lighting (OPT)	3I23/20-87
Standby Generator (OPT)	3G5/20-24	Map Light, Control Wheel	3J1/20-89
Ground Service (OPT)	3G7/20-26	Instrument Lights	3J2/20-90
Battery Circuit	3G8/20-27	Instrument Lights	3J4/20-92
Alternator System, 60 Amp	3G9/20-28	Electroluminescent Panel (OPT)	3J5/20-93
Standby Generator (OPT)	3G10/20-29	Electroluminescent Panel (OPT)	3J6/20-94
Dual Alternator	3G11/20-30	Post Lighting (OPT)	3J7/20-95
Dual Alternator	3G13/20-32	Post Lighting (OPT)	3J8/20-96
Dual Alternator	3G14/20-32A	Post Lighting (OPT)	3J9/20-97
Dual Alternator	3G15/20-33	Map Light, Control Wheel	3J10/20-98
Volt-Ammeter (OPT)	3G16/20-34	Flood, Engine Instr. & Radio	
Battery Circuit - OPT (With Dual		Dial Lights	3J11/20-99
Alternators)	3G17/20-35	Console & Compass Lights	3J12/20-100
Alternator System, 95 Amp (OPT)	3G19/20-37	Console & Compass Lights	3J14/20-102
Circuit Breakers	3G20/20-38	Vertical Tail Illumination	
Circuit Breakers	3G21/20-38A	Light (OPT)	3J15/20-103
Circuit Breakers	3G22/20-38B	Flood, Engine Instr. & Radio	
Volt-Ammeter (OPT)	3G23/20-39	Dial Lights	3J16/20-104
IGNITION		Map Light, Control Wheel	3J17/20-105
Magneto	3G24/20-40	LANDING GEAR	
ENGINE CONTROLS		Landing Gear Control System	3J18/20-106
Starter System	3H1/20-41	Landing Gear Control System	3J19/20-107
Starter System	3H2/20-42	Landing Gear Control System	3J21/20-109
FUEL OIL		Landing Gear Control System	3J22/20-110
Fuel Pump System	3H3/20-43	Landing Gear Control System	3J24/20-112
ENGINE INSTRUMENTS		Landing Gear Control System	3K1/20-113
Cylinder Head Temp	3H5/20-45	Landing Gear Control System	3K2/20-114
Hourmeter (OPT)	3H6/20-46	Landing Gear Control System	3K3/20-115
Hourmeter (OPT)	3H7/20-47	Landing Gear Control System	3K4/20-116
Fuel Gage System	3H8/20-48	HEATING, VENTILATING, & DE-ICING	
Instrument Cluster	3H9/20-49	Cigar Lighter	3K6/20-118
Fuel Gages	3H11/20-51	Heated Pitot Tube and Heated	
Fuel Gages	3H13/20-53	Stall Warning System	3K7/20-119
Oil Temp & Cylinder Head		Light, Ice Detector (OPT)	3K8/20-120
Temperature	3H14/20-54	Wing De-Icing System (OPT)	3K9/20-121
Oil Temp & Cylinder Head		Windshield Anti-Ice System (OPT)	3K10/20-122
Temperature	3H15/20-55	Prop De-Icing System 3 Blade (OPT)	3K11/20-123
Fuel Gages	3H16/20-56	Cigar Lighter	3K13/20-125
Fuel Gages	3H17/20-57	Wing & Stabilizer De-Icing	
Fuel Totalizer/Clock (OPT)	3H18/20-58	System (OPT)	3K14/20-126
Oil Temp & Cylinder Head		Heated Pitot Tube & Heated	
Temperature	3H19/20-59	Stall Warning System -	
FLIGHT INSTRUMENTS		Known Icing (OPT)	3K15/20-127
Turn Indicator	3H20/20-60	Heated Pitot Tube & Heated	
Encoding Altimeter	3H21/20-61	Stall Warning System -	
		Known Icing (OPT)	3K16/20-128

MODEL 210 & T210 SERIES SERVICE MANUAL

TABLE OF CONTENTS	Page No. Aerofiche/Manual	CONTROL SURFACES	
Heated Pitot & Heated Stall Warning System - Known Icing (OPT)	3K17/20-129	Wing Flaps	3L1/20-136
Windshield Anti-Ice System Known Icing (OPT)	3K18/20-130	Electric Elevator Trim (OPT)	3L3/20-138
Wing & Stabilizer De-Ice System - 3 Cycle (OPT)	3K19/20-131	Electric Elevator Trim (OPT)	3L5/20-140
Wing & Stabilizer De-Ice System - 3 Cycle (OPT)	3K20/20-132	Electric Elevator Trim (OPT)	3L7/20-142
Air Conditioner (OPT)	3K22/20-133	Electric Elevator Trim (OPT)	3L9/20-144
Air Conditioner (OPT)	3K23/20-134	Electric Elevator Trim (OPT)	3L10/20-145
Heated Pitot Tube & Heated Stall Warning System	3K24/20-135	Wing Flaps	3L12/20-147
		WARNING AND EMERGENCY	
		Dual Warning Unit	3L13/20-148
		Dual Warning System	3L15/20-150
		Dual Warning System	3L17/20-152
		Dual Warning Unit	3L18/20-153
		Dual Warning Unit	3L20/20-155
		Dual Warning Unit	3L21/20-156
		Low Vacuum Warning Light (OPT)	3L22/20-157

MODEL 210 & T210 SERIES SERVICE MANUAL

CIRCUIT FUNCTION AND SPECIFIC CIRCUIT CODE LETTERS

- A - Armament
- B - Photographic
- C - Control Surface
 - CA - Automatic Pilot
 - CC - Wing Flaps
 - CD - Elevator Trim
- D - Instrument (Other Than Flight or Engine Instrument)
 - DA - Ammeter
 - DB - Flap Position Indicator
 - DC - Clock
 - DD - Voltmeter
 - DE - Outside Air Temperature
 - DF - Flight Hour Meter
- E - Engine Instrument
 - EA - Carburetor Air Temperature
 - EB - Fuel Quantity Gage and Transmitter
 - EC - Cylinder Head Temperature
 - ED - Oil Pressure
 - EE - Oil Temperature
 - EF - Fuel Pressure
 - EG - Tachometer
 - EH - Torque Indicator
 - EJ - Instrument Cluster
- F - Flight Instrument
 - FA - Bank and Turn
 - FB - Pitot Static Tube Heater and Stall Warning Heater
 - FC - Stall Warning
 - FD - Speed Control System
 - FE - Indicator Lights
- G - Landing Gear
 - GA - Actuator
 - GB - Retraction
 - GC - Warning Device (Horn)
 - GD - Light Switches
 - GE - Indicator Lights
- H - Heating, Ventilating and De-Icing
 - HA - Anti-icing
 - HB - Cabin Heater
 - HC - Cigar Lighter
 - HD - De-ice
 - HE - Air Conditioners
 - HF - Cabin Ventilation
- J - Ignition
 - JA - Magneto
- K - Engine Control
 - KA - Starter Control
 - KB - Propeller Synchronizer
- L - Lighting
 - LA - Cabin
- LB - Instrument
- LC - Landing
- LD - Navigation
- LE - Taxi
- LF - Rotating Beacon
- LG - Radio
- LH - De-ice
- LJ - Fuel Selector
- LK - Tail Floodlight
- M - Miscellaneous
 - MA - Cowl Flaps
 - MB - Electrically Operated Seats
 - MC - Smoke Generator
 - MD - Spray Equipment
 - ME - Cabin Pressurization Equipment
 - MF - Chem O₂ - Indicator
- P - D. C. Power
 - PA - Battery Circuit
 - PB - Generator Circuits
 - PC - External Power Source
- Q - Fuel and Oil
 - QA - Auxilliary Fuel Pump
 - QB - Oil Dilution
 - QC - Engine Primer
 - QD - Main Fuel Pumps
 - QE - Fuel Valves
- R - Radio (Navigation and Communication)
 - RA - Instrument Landing
 - RB - Command
 - RC - Radio Direction Finding
 - RD - VHF
 - RE - Homing
 - RF - Marker Beacon
 - RG - Navigation
 - RH - High Frequency
 - RJ - Interphone
 - RK - UHF
 - RL - Low Frequency
 - RM - Frequency Modulation
 - RP - Audio System and Audio Amplifier
 - RR - Distance Measuring Equipment (DME)
 - RS - Airborne Public Address System
- S - Radar
- U - Miscellaneous Electronic
 - UA - Identification - Friend or Foe
- W - Warning and Emergency
 - WA - Flare Release
 - WB - Chip Detector
 - WC - Fire Detection System
- X - A. C. Power

MODEL 210 & T210 SERIES SERVICE MANUAL

FUNCTION CIRCUITS	GAUGE	BASE COLOR (or solid)	STRIPE COLOR
A + Power	16	Red	None
	18	Red	Black
	20	Red	White
		Red	Green
		Red	Yellow
Ground	16	Black	None
	18	Black	White
Mike Ground	22	Black	None
Radio Lights Dim	18	Yellow	None
Mike Audio	22	Tan	None
		Tan (Shielded)	None
Mike Key	22	White	Black
Radio Speaker	20	Green	None
Headphones	22	Blue	None
Dev + ●	22	Gray	Red
Dev - ●	22	Gray	Green

● "Dev+" and "Dev-" circuits are for use in Nav-o-matic 300 autopilots and any associated omni indicator circuit to which it connects.

NOTE

All other color coded wires are for general use in multi-conductor radio and autopilot harness assemblies.

CROSS REFERENCE LISTING OF SERIAL REQUEST NUMBERS LISTED ON DIAGRAMS VS. AIRCRAFT SERIAL NUMBERS.

SR No.	AIRCRAFT SERIAL No.	SR No.	AIRCRAFT SERIAL No.
SR6755	21059503	SR7650	21060540
SR7038	21059720	SR7677	21060319
SR7126	21059853	SR7724	21060130
SR7320	21059864	SR7913	21061040
SR7381	21060090	SR7922	21060356
SR7473	21059882	SR7997	21060526, T21060544
SR7486	21059852	SR8082	21060612
SR7639	21060316	SR8143	21061574

MODEL 210 & T210 SERIES SERVICE MANUAL


CROSS REFERENCE LISTING OF SERIAL REQUEST NUMBERS LISTED ON DIAGRAMS VS. AIRCRAFT SERIAL NUMBERS (CONT).

SR No.	AIRCRAFT SERIAL No.	SR No.	AIRCRAFT SERIAL No.
SR8153	21060719	SR9310	T21063641, *P21000386
SR8259	21061041	*SR9361	P21000151
SR8297	21061103	SR9384	21062955
SR8394	21061315	SR9427	21062969, *P21000120
SR8426	21061296	SR9429	21063299, *P21000257
SR8464	21062274	SR9465	21063369, *P21000279
*SR8465	P21000001 thru P21000150	SR9556	21063953, T21067300 & *P21000405
SR8482	21061230	SR9583	21063547, P21000344
SR8499	21061574	SR9634	21064136
SR8552	21061617	*SR9635	P21000591
SR8633	21061984	SR9711	21064064, *P21000535
SR8656	21061627	SR9742	21064038, *P21000553
SR8784	21062954	SR9785	21064136, *P21000591
*SR8785	P21000151	SR9953	21064536
SR8861	21062274, *P21000001	*SR9954	P21000761
SR8863	21062274 thru 21062953 *P21000001 thru P21000150	SR10056	21064536, *P21000761
SR8938	21062250	SR10122	21064536, *P21000761
SR8970	21062250, *P21000001	SR10250	21064559, *P21000771
SR9014	21062727, *P21000041	SR10061	21064198
SR9080	21062699, *P21000031	SR10101	21064773
SR9114	21063641	*SR10102	P21000812
SR9115	*P21000386	SR10148	21064340, *P21000692
SR9140	21062828, *P21000085	SR10254	21064602, *P21000785
SR9142	21062717, *P21000065	SR10396	21064773, *P21000812
SR9169	21062739, *P21000065	SR10563	21064805, *P21000822
SR9187	21062955, *P21000151	SR10650	21064777, *P21000812 & P21000814 AND ON
SR9195	21062942, *P21000122		
SR9221	21063477, *P21000345		


NOTE

Effectivity of diagrams are designated as follows: Eff thru (SRxxxx) denotes effectivity to the serial number prior to the (SRxxxx) serial. Ser (SRxxx) & on denotes effectivity for the (SRxxxx) serial and on. Diagrams and/or portions of, may be individually serialized and not designated by a (SRxxxx) number.

MODEL 210 & T210 SERIES SERVICE MANUAL



REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD WIRE LENGTHS (NOW SHOW PRACTICE)	JLD 5-3-75	<i>[Signature]</i>
B	BY REV: ADD DETAIL A SER: 226A WAS 186A/PAG4PA17 (SR6755)(REF)(SRB143)	GDS 5-6-76	<i>[Signature]</i>
C	BY REV: C614001-0101 WAS 0870060-1; ADD WIRES JAI1(REF),PC8(REF),PC9(REF),DA6(REF) (SR8840)(SR8465)	GDS 6-6-77	<i>[Signature]</i>
D	BY REV: C614001-0105 WAS C614001-0101 (SR9149)	RLY 5-23-78	<i>[Signature]</i>




EQUIPMENT TABLE		WIRE TABLE		
PART NO.	DESCRIPTION	WIRE CODE NO.	GA MATERIAL LG TERMINALS SERIALS	
6	S-1994-1-1 MASTER SWITCH	F-PA17	22	30 S-1967-10 S-N83-7
5	0770719-2 DIODE ASSY	F-PA16	2	15 S-1967-21 S-1967-15
4	S-1577-1 STARTER CONTACTOR	F-PA15	2	99 S-1967-71 S-1967-1
3	S-1580-1 BAT CONTACTOR	F-PA14	22	6 S-N83-7 S-1967-6
2	0770728-1 DIODE ASSY	F-PA1	2	14 S-1967-12 S-1967-13
1	C614001-0105 BATTERY ASSY			


CONTRACT NO.		COMMERCIAL AIRCRAFT DIV 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	YB SIPS	1-28-71	TITLE
GROUP	W. H. W.	2-26-71	WIRING DIAGRAM -
DRAWN	YB SIPS	2-18-71	BATTERY CIRCUIT
CHECK	LY WHITE	2-24-71	
STRESS			
PROJ	N. H. White	2-24-71	SIZE
APPD			CODE IDENT
OTHER			NO.
			71379
			DWG NO
			1270709
			SCALE: NONE
			210
			PAGE 1

(SR6755) II


MODEL 210 & T210 SERIES SERVICE MANUAL



DETAIL B
THRU SER (SR8143)
(21061573)



DETAIL A
THRU SER (SR8259)
(21061038)



(APPLIES TO 210 ONLY)
THRU SER (SR9384)

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	JLO 5-3-73	JLO
B	BY REV: S-1367-6-13/PA18 WAS S-1367-7-13/PA18; S-1367-6-14/PA18 WAS S-1367-7-13/PA18 ADD WIRE LENGTH/ F-PA18 (NOW SHOP PRACTICE)	JEF 11-8-73	JEF
C	BY REV: ADD DETAIL 'A' & SER 1 SECOND DIODE (SR8259)	RS 6-11-73	RS
D	BY REV: ADD DETAIL 'B' & SER; 22GA WAS 18GA F-PC3, F-PC5, F-PC7, MS3506-1 WAS MS3502-3A MOD IN-2070; S-1370-2 WAS S-1371-2 (SR8143)	GDS 5-12-76	GDS
E	BY REV: ADD P 4.2.1 PCB THRU PC13, S-1637(-11-2), 2170009 (SR8463)	GDS 6-6-77	GDS
F	BY REV: SER OUT 210/P 4.2; ADD 210/P 4.2.1 & SER; PC11 WAS TO MS3506-1 (SR9384) (NOW SHOP PRACT)	DLP 7-13-78	DLP

15	2170009	BUS BAR ASSY							
14	S-1637-2	HOUSING							
13	S-1637-1	HOUSING							
12	X26263	RESISTOR .75Ω (SR310)	F-PC7	22	20	SOLDER	S-1367-12	S-1367-12	THRU SER (SR9384)
11	20H3P	DIODE (SR970)	F-PC5	22	5	SOLDER	S-1367-11	S-1367-11	(SR9384)
10	1270633-1	BUS BAR	F-PC9	18	63	S-1367-10	S-1367-10	S-1367-10	(SR8143)
9	IN-2070	DIODE	F-PC3	22	5	S-1367-9	S-1367-9	S-1367-9	(SR9384)
8	S-1570043	DIODE ASSY	F-PA18	4	15	S-1367-8	S-1367-8	S-1367-8	THRU SER (SR9384)
7	0770728	DIODE ASSY	WIRE CODE NO	GA					
6	0312155	GROUND STRAP							
5	MS 3506-1	RECEPTACLE							
4	S-1577-1	CONTACTOR							
3	S-1580-1	BAT CONTACTOR							
2	S-1090-2	FUSEHOLDER							
1	S-1091-5	FUSE							

EQUIPMENT TABLE			WIRE TABLE				COMMERCIAL AIRCRAFT DIV		
PART NO.	DESCRIPTION	VENDOR	CONTRACT NO.	NAME	DATE	5800 E. PAWNEE WICHITA, KANSAS			
				DESIGN	VRS/PEB	1-28-71	Cessna AIRCRAFT CO. WIRING DIAGRAM - GROUND SERVICE RECEPTACLE (OPT)		
				GROUP	H. White	2-25-71			
				DRAWN	VRS/PEB	2-18-71			
				CHECK	L. WHITE	2-24-71			
				STRESS					
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESNA SPEC. NO. S-XXX OR CMXXX-CESNA STD. NO.			SUPERSEDED: 12210-1073 SUPERSEDED BY: 1270709 P 4.15			PROJ APPD OTHER	SIZE CODE IDENT. NO. C 71379	DWG NO 1270709	SCALE: NONE 210 P.210 PAGE: 4.2

(SA 6755) II (21059503)

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: DELETE TEL (REF), 070719-2 ADD BLS (REF), HE ROUTE = P831 (SR7639)	DLY 10-1-71	WJW 1/11/71
B	BY REV: ADD DETAIL "A" & "B", ITEMS 7, 11 E12 TO F/D/E/T, S-1635-2 WAS S-1370-0 N W/T. SER 21059553 FOW	VRG 11/22/71	WJW 1/11/71
C	BY REV: MAKE (REF) WAS DAW, ADD WIRE LENGTHS (NOW SHOP PRACTICE)	WJW 5-3-73	WJW 1/11/71
D	BY REV: ADD DETAIL "C", P834 & SER; SER OUT P826 (SR7639) BY REV: S-1593003-0101 WAS 0333 (NOW SHOP PRACTICE)	ZAM 7-31-73	WJW 1/11/71
E		EF 11-8-73	WJW 1/11/71
F	BY REV: S-1367-3-12 WAS S-1943-1, S-1367-3-10 WAS S-1367-4-12 (MER 210-E00108)	MEM 6-25-74	WJW 1/11/71
G	BY REV: SER INF-P835, SER OUT F-P835 ADD DETAIL "C" SER (210-60401) MER 177-80105	BRF 6-19-74	WJW 1/11/71
H	BY REV: ADD DETAIL "D" SER, ADD CURRENT CONFIGURATION TO MAIN VIEW FROM DETAIL "A" & "B"; MAKE DETAIL "A" & "B" OLD CON- FIGURATION; 8 GA WAS 10 GA / F-LB29, 22 GA WAS 20 GA / F-LB27, F-LB28, F-LB30 THRU F-LB33; S-1635-1 WAS S-1635-2, S-1636-1 WAS S-1636-2, S-1367-1-10 WAS S-1367-3-10 S-1367-4(-10 & -12) WAS S-1367-3(-10 & -12) (SR8143)	GDS 5-6-76	WJW 1/11/71

INACTIVE
 EFF THRU (SR0004) 4-21-77
 GJK (WJW) & MA

ITEM NO	PART NO.	DESCRIPTION	VENDOR
12	TVA-1315	CAPACITOR	56289
11	S-1637-1	HOUSING-PIN	
10	S-1360-5L	CIRCUIT BREAKER	
9	S-1596-60L	CIRCUIT BREAKER	
8	S-1994-1-1	MASTER SWITCH	
7	S-1637-2	HOUSING-SOCKET	
6	S-2185-2	LIGHT	
5	1593003-0101	OVER VOLT UNIT	
4	S-1638-2	HOUSING-CAP	
3	S-1638-1	HOUSING-PLUG	
2	CG1503-0102	ALTERNATOR	
1	CG1002-0103	VOLTAGE REGULATOR	

F-P835	8	S-1562-8-9	24	S-1483-2	S-1367-4-12		
F-P834	8	S-1562-8-9	24	S-1943-3	S-1367-4-12		SER 21060316 THRU 210-60400
F-P833	22		60	S-1635-1	S-1493-1		
F-P832	22		26	S-1635-1	S-1493-1		
F-P831	22		60	S-1635-1	S-1493-1		
F-P830	22		10	S-1367-1-6	S-1993-1		
F-P829	8		60	S-1367-4-12	S-1367-4-10		
F-P828	22		23	S-1636-1	S-1635-1		
F-P827	22		69	S-1635-1	S-1635-1		
F-P826	10		24	S-1367-3-10	S-1367-3-10		THRU SER 21060315



WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS

CONTRACT NO:		WIRE TABLE	
DESIGN	VR SIPS	DATE	1-28-71
GROUP	H. M. White	DATE	2-28-71
DRAWN	VE SIPS	DATE	2-18-71
CHECK	LK WHITE	DATE	2-24-71
STRESS			
PROJ	H. M. White	DATE	2-27-71
APPD	WJW		
OTHER			


EQUIPMENT TABLE		SUPERSEDES:	
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESBNA SPEC. NO. S-XXX OR CMXXXX-CESBNA STD. NO.		12210-1073	
		SUPERSEDED BY: PG 4.6	

Cessna AIRCRAFT CO.		COMMERCIAL AIRCRAFT DIV. 3800 E PAWNEE WICHITA, KANSAS	
SIZE	CODE IDENT NO	DWG NO	
G	71379	1270709	
SCALE	NONE	Z10	PAGE 4, 3


MODEL 210 & T210 SERIES SERVICE MANUAL




DETAIL A
THRU SER 21059553




DETAIL B
THRU SER 21059553



DETAIL C
THRU SER 21060315




DETAIL D
SER 21060316 THRU



DETAIL E
THRU SER (SR 6143)
(21061573)

WIRE TABLE					
CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 8800 E. PAWNEE WICHITA, KANSAS		
NAME			Cessna AIRCRAFT CO.		
DATE			TITLE		
DESIGN	V E Sipes	1-28-71	WIRING DIAGRAM -		
GROUP	21 Wial	2-28-71	ALTERNATOR SYSTEM		
DRAWN	V E Sipes	2-18-71			
CHECK	L X WHITE	2-24-71			
STRESS					
PROJ	N. M. Galt	2-27-71	SIZE	CODE IDENT.	DWG NO
APPD	WRS		C	71379	1270709
OTHER			SCALE: NONE	210	PAGE: A, 3

MODEL 210 & T210 SERIES SERVICE MANUAL



INACTIVE
EFF THRU SER (SR0468)
REG 10/11/74
4-28-77

NOTES:

- 1. INSTALL 18.0 IN. OF IMPERIAL EASTMAN (30327) POLY-FLO TUBING 66-P-38 OVER F-PA25 WIRE BEFORE INSTALLING TERMINALS

EQUIPMENT TABLE		WIRE TABLE					
PART NO.	DESCRIPTION	WIRE CODE NO.	GA.	MATERIAL	LG.	TERMINALS	SERIALS
8	1270831	BUS BAR					
7	S-2281-1	SWITCH					
6	S-1596-60L	CIRCUIT BREAKER					
5	S-1232-30L	CIRCUIT BREAKER					
4	S-1360-20L	CIRCUIT BREAKER					
3	S-1360-15L	CIRCUIT BREAKER					
2	S-1360-8L	CIRCUIT BREAKER					
1	S-1360-5L	CIRCUIT BREAKER					

CONTRACT NO:		COMMERCIAL AIRCRAFT DIV. 8800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE
GROUP	W. H. Anderson	5-21-76	WIRING DIAGRAM — CIRCUIT BREAKERS
DRAWN	G. SCHIFFELBEIN	5-12-76	
CHECK	J. YOUBL	5-13-76	
STRESS			
PROJ	P. W. DRKE	5-21-76	SIZE
APPD	JRG		CODE IDENT NO
OTHER			DWG NO
			C 71379
			1270709
			SCALE: NONE
			210
			PAGE. 4 5



(SR 8143)
21061574

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE:

THIS CAPACITOR IS TO BE ADDED ONLY WHEN REQD TO PREVENT OVERVOLT SENSOR TRIPOUT DURING GEAR CYCLING & IS TO BE INSTALLED ONLY WITH THE C693003-0101 OVERVOLT SENSOR

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV. ADDED DETAIL A SER IN PB47 & PB48 SER OUT PB35 & PB36 (SR9140) INACTIVATE DWG	G D M 12-15-77	JAS 108A
B	BY REV. ADDED NOTE 1, TYA 1315 CAPACITOR, & C693003-0103 OVERVOLT SENSOR; C611004-0102 WAS C611002-0105 & C611004-0101(ALT) (SR9140) (SR9169)	TFS 4-12-78	JAS with 1



INACTIVE
THRU SER (SR9014) (SR9140)
CAS USE 4/28/78

EQUIPMENT TABLE		WIRE TABLE	
PART NO.	DESCRIPTION	CONTRACT NO.	TITLE
12	C693003-0103 OVERVOLT SENSOR (ALT)		Cessna AIRCRAFT CO. PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS
11	TYA1315 CAPACITOR		
10	S-1360-5L CIRCUIT BREAKER		
9	S-1994-1-1 MASTER SWITCH		
8	M525041-2 INDICATOR LIGHT		
7	M525237-327 LAMP		
6	S-1707-60 CIRCUIT BREAKER		
5	C693003-0101 OVERVOLT UNIT		
4	S-1638-2 HOUSING - CAP		
3	S-1638-1 HOUSING - PLUG		
2	C611503-0102 ALTERNATOR		
1	C611004-0102 VOLTAGE REGULATOR		
		DESIGN SPENCER 4-25-77	
		DRAWN GL RYAN 4-21-77	
		CHECK J. YUCEL 4-22-77	
		PROJ PLU & DRUK 4-26-77	
SUPERSEDES: PG 4.3		SIZE C	CODE IDENT. NO. 71379
SUPERSEDED BY: PG 4.3		DWG NO. 1270709	SCALE: NONE
		PAGE: 4.6	



(SR8464)

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTE:

1. THIS CAPACITOR IS TO BE ADDED ONLY WHEN REQD TO PREVENT OVERVOLT SENSOR TRIP-OUT DURING GEAR CYCLING & IS TO BE INSTALLED ONLY WITH THE C593003-0101 OVERVOLT SENSOR.

LET	DESCRIPTION	DATE	APPRO
A	BY REV: 18 GA WAS 22 GA/PB42; 42281-2 WAS 5-1493-1 / PB42 (SR 8464)	TMS 6-21-77	JAB WLB
B	BY REV: 5-2326-1 WAS 45-2-S-N2 .SR 8464 (SR 8465)	JJB 8-29-77	JAB WLB
C	BY REV: ADD DETAIL 'A', TVA1315 CAPACITOR, C593003-0103 OV SENSOR & NOTE 1; SER IN PB58 & PB59; SER OUT PB40 & PB41; C611004-0102 WAS C611002-0105 & C611004-0101/2 (SR 9140); (SR 9142) (SR 9144)	TFS 4-8-78	JAB WLB



INACTIVE

THRU SER (SR 8789) (SR 8785)
CAS 2-28-77
JAB WLB
1/2
RJ

DETAIL A
THRU SER (SR 9142)

PART NO.	DESCRIPTION	QUANTITY	WIRE GA	MATERIAL	LG	TERMINALS	SERIALS
13	C593003-0103 OVERVOLT SENSOR (ALT)	1					(SR 9142) (ON ALL SPRES)
12	TVA1315 CAPACITOR	1					(SR 9142) (ON ALL SPRES)
11	D20B-1489-KA CONNECTOR	1					
10	5-1560-5L CIRCUIT BREAKER	1					
9	5-1994-1-1 MASTER SWITCH	1					THRU SER (SR 9142)
8	M525041-2 INDICATOR LIGHT	1					THRU SER (SR 9142)
7	M525237-327 LAMP	1					
6	5-2326-1 CIRCUIT BREAKER	1					
5	C593003-0101 OVERVOLT UNIT	1					
4	5-1638-2 HOUSING - CAP	1					
3	5-1638-1 HOUSING - PLUG	1					
2	C611505-0101 ALTERNATOR	1					
1	C611004-0102 VOLTAGE REGULATOR	1					

CONTRACT NO:		WIRE TABLE	
DESIGN	SPENCER	DATE	4-25-77
GROUP	WILLIAMS	DATE	4-26-77
DRAWN	G.L. RYAN	DATE	4-21-77
CHECK	J. YONEL	DATE	4-22-77
STRESS			
PROJ	PLW/DRIOL	DATE	4-23-77
APPO			
OTHER			

Cessna, AIRCRAFT CO.
 PAWNEE DIVISION
 3800 E. PAWNEE
 WICHITA, KANSAS

WIRING DIAGRAM -
ALTERNATOR SYSTEM -
95 AMP (OPT)

SIZE: **C** CODE IDENT. NO: **71379** DWG NO: **1270709**

SCALE: NONE 210 P210 PAGE: 4.7

PART NO.	DESCRIPTION
1270709	PG 4.10

CES-1000 IS APPLICABLE
 VENDOR CODES PER S-1400
 CES-XXX-CESBNA SPEC. NO.
 S-XXX OR CMXXX-CESBNA
 STD. NO.

(SR 8464)

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

1. S-1360-15L CKT BKR REQD WITH KNOWN ICING W/S A/ICE SYSTEM
2. APPLIES TO P210 ONLY


INACTIVE

THRU SER (SR9361)

MLS 8-10-78

AD 2nd Pgs
580

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD CLG FAN CKT BKR - NOTE 142. S1360-5L WAS S1360-10L/W/S A/ICE. S-2326-1 WAS 45-2-5-N2. ADD CABIN PRESS CKT BKR, S-1232-5 WAS S-1360-5L /TRIM PULL OFF; S-1232-15 WAS S-1360-15L /AIP ACT-PULL OFF (SR8464) (SR8465)	GDS 6-6-77	JAB/DAH JRE
B	BY REV: INACTIVATE DWG KNOWN ICING WAS SIERRACIN (NOTE 1) (SR9361)	MLS 8-10-78	JAB/DAH JRE SEP



ITEM NO	PART NO.	DESCRIPTION	QUANTITY	UNIT	REMARKS
12	S-1232-15	CIRCUIT BKR			
11	S-2326-1	CIRCUIT BKR			
10	2113158-1	BUS BAR			
9	2113043-1	BUS BAR			
8	S-2281-1	SWITCH			
7	S-1232-30	CIRCUIT BKR			
6	S-1360-20L	CIRCUIT BKR			
5	S-1707-60	CIRCUIT BKR			
4	S-1360-15L	CIRCUIT BKR			
3	S-1360-10L	CIRCUIT BKR			
2	S-1360-5L	CIRCUIT BKR			
1	S-1232-5	CIRCUIT BKR			

WIRE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
WIRE TABLE					
CONTRACT NO:					
DESIGN			NAME		
GROUP			DATE		
DRAWN			CHECK		
STRESS			OTHER		
PROJ			APPO		
APPO			OTHER		

DESIGN	NAME	DATE	TITLE
GROUP	W. J. ...	6-14-77	Cessna AIRCRAFT CO. PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS
DRAWN	R.E. GOWIN	4-28-77	
CHECK	J. YOWEL	4-28-77	
STRESS			
WIRING DIAGRAM - CIRCUIT BREAKERS			

PROJ	APPO	OTHER	SIZE	CODE IDENT. NO.	DWG NO
PLA-DET-1111	Dig		C	71379	1270709
SUPERSEDED BY:			SCALE: NONE		
1270709 P.4.11			210 210 PAGE: 4.8		

MODEL 210 & T210 SERIES SERVICE MANUAL


INACTIVE

THRU SER (SR9361)

MLS 8-10-78

AD 11/11/78 JAS

150



DETAIL A
FOR USE WITH 25 AMP ALT SYSTEM (OPT)

CONTRACT NO:			Cessna AIRCRAFT CO. PAWNEE DIVISION 3800 E PAWNEE WICHITA KANSAS		
DESIGN	NAME	DATE			
GROUP	<i>W. H. ...</i>	<i>4-14-77</i>	WIRING DIAGRAM — CIRCUIT BREAKERS		
DRAWN	R.E. GOWIN	4-28-77			
CHECK	J. YONEL	4-28-77			
STRESS					
PROJ	PLAEDRILL	5-1-77	SIZE	CODE IDENT. NO.	DWG NO
APPD	JIG		C	71379	1270709
OTHER			SCALE: NONE		
			210 210 PAGE: 4.8		

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

1. PART OF BASIC AVIONICS KIT

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: SER OUT PB 47 SER IN PB 67 SER (SR 9429); ADD DETAIL 'A'	HMG 9-14-78	JAB
B	BY REV: ADD DETAIL 'B' & 'C', PB 67 SER 51232-60 (SR 914)(SR 915)	HMG 2-8-79	JAB
C	BY REV: 20GA WAS 22GA/PB 49, PB 50 PB 55; 16GA WAS 22GA/PB 31; 5-2099-8 WAS 5-2099-6, 5-1367-2-10 WAS 5-1367-1-10 (NOW SHOP PRACTICE) YEL (PB 49) WAS PB 49, RED (PB 53) WAS PB 53 ORN (PB 52) WAS PB 52, BLU (PB 53) WAS PB 53 (USE EXISTING STOCK) ADD DETAIL 'A', PB 60 WIRE & SER (SR 9572)	RLK HMG 9-5-79	JAB
		NTL	JAB

INACTIVE:
 THRU SER (SR 2334)(SR 9333)
 SER (SR 9788)
 SER 3-24-80
 BY JAB

PB 80	8	5-1562-8-9	5-2484-1	5-1943-2	SER (SR 9572) (ON ALL SPARES)
PB 67	8	5-1562-8-9	5-1943-2	5-1367-1-8	SER (SR 914)(SR 915) (ON
PB 64	8	5-1562-8-9	5-1943-3	5-1943-2	SER (SR 9429) THRU (SR 9572)
PB 46	22				SOLDER 5-1367-1-8
PB 54	8	5-1562-8-9	5-1943-2	5-1943-2	
PB 53	8	5-1562-8-9	5-1943-2	5-1367-4-8	THRU SER (SR 914)(SR 915)
ORN (PB 52)	20	-20-3		5-2099-6	5-1367-1-12
BLU (PB 53)	16	-16-6		5-2099-8	5-1367-2-10
PB 50	20			5-2099-6	5-1367-1-10
TEL (PB 49)	20	-20-4			SOLDER 5-2099-6
PB 56	22				5-1367-1-6 SOLDER
RECY (PB 55)	20	-20-2			5-2099-6
PB 38	22				5-1367-1-6
PB 37	22				5-1367-1-10
PB 47	8	5-1562-8-9			5-1367-1-6
PB 47	8	5-1562-8-9			5-1367-4-12
					5-1943-3

13	5-1232-60	CIRCUIT BREAKER
12	C611005-0102	ALT CONTROL UNIT (ALTERNATE)
11	0570314	TERMINAL BOARD
10	5-1707-60	CIRCUIT BREAKER
9	5-1360-5L	CIRCUIT BREAKER
8	MS25041-2	INDICATOR LIGHT
7	MS25237-327	LAMP
6	5-1994-1-1	MASTER SWITCH
5	5-1915-1	CAPACITOR
4	C611503-0102	ALTERNATOR ASSY
3	5-2373-2	CONNECTOR
2	5-2373-1	CONNECTOR
1	C611005-0101	ALT CONTROL UNIT

WIRE TABLE			
WIRE CODE NO	GA	MATERIAL	TERMINALS
			SERIALS
CONTRACT NO:			
NAME		DATE	
DESIGN		TITLE	
GROUP		DRAWN	
CHECK		DATE	
STRESS		OTHER	
PROJ		SIZE	
APPRO		CODE IDENT. NO.	
OTHER		DWG NO.	
SCALE: NONE		PAGE: 4.9	

PART NO.	DESCRIPTION
EQUIPMENT TABLE	
SUPERSEDES: 1270709 P. 4.6 SUPERSEDED BY: 1270709 P. 4.15	

CES-1000 IS APPLICABLE
 VENDOR CODES PER S-1400
 CES-1000-CESNA SPEC. NO.
 S-100X OR CM1000-CESNA
 STD. NO.


Cessna AIRCRAFT CO.

WIRING DIAGRAM —
ALTERNATOR SYSTEM
60 AMP

71379 **1270709**

SCALE: NONE 210 P210 PAGE: 4.9

MODEL 210 & T210 SERIES SERVICE MANUAL



CONTRACT NO.		Cessna AIRCRAFT CO.		PAWNEE DIVISION 5800 E PAWNEE WICHITA, KANSAS	
DESIGN	SPENCER	3-2-78	TITLE		
GROUP	W. J. Anderson	3-6-78	WIRING DIAGRAM —		
DRAWN	SHAVER	2-28-78	ALTERNATOR SYSTEM		
CHECK	BORLESKE	3-1-78	60 AMP		
STRESS					
PROJ	PUNDRILL	3-9-78	SIZE	CODE IDENT. NO.	DWG NO.
APPD	ARS		C	71379	1270709
OTHER			SCALE: NONE		210 P210 PAGE: 4.9

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION				REVISION			
LET	DESCRIPTION	DATE	APPRO	LET	DESCRIPTION	DATE	APPRO
J	BY REV: ADD BLK (PB47) (REF) & S-2527-18-2 (SR1010) (SR1012), S-2376-2 WAS -1) / PB37 (REWORK IN WORK & FINISHED PARTS)	ALT TMS 12-21-81	JEFF WALKER	A	BY REV: PB58 WAS PB41, S-2402-1 WAS S-1367-6-10 / PB58, S-2402-2 WAS S-1367-6-12 / PB 56 (SR 942)	TFS 4-8-78	JAB WALKER TFS
K	BY REV: DELETE S-2527 18-2, BLK (PB47) (REF); INACT DWG (SR1010) (SR1012)	MKT 1-27-82	JAB WALKER TFS	B	BY REV: PB56 (REF) WAS PB48 (REF), PB55 (REF) WAS PB47 (REF), 20GA WAS 18 GA / PB57, S-2376-1 WAS 422B1-2, PB61 WAS PB56 PB 60 WAS PB55 (NOW SHOP PRACTICE) (SR8784) (SR8785)	CMK 8-14-78	JAB WALKER TFS
				C	BY REV: SER OUT PB 58, PB60, PB 61 SER IN PB62, PB63, PB65 ; ADD DETAIL A'	HHG 9-14-78	JAB WALKER TFS
				D	BY REV: ADD DETAIL B, C, PB66 & SER (SR914) (SR915)	HHG 2-8-79	JAB WALKER TFS
				E	BY REV: 18 GA WAS 20GA / PB57 S-2099-8 WAS S-2099-6 (NOW SHOP PRACTICE) ADD DETAIL "D" (SR9607) YEL (PB43) (REF) WAS PB49 (REF), RED (PB55) (REF) WAS PB53 (REF), ORN (PB52) (REF) WAS PB52 (REF), BLU (PB57) WAS PB 57 (USE EXISTING STOCK)	RLK HHG 9-5-79	JAB WALKER TFS
				F	BY REV: SER OUT PB43 & ADD PB37 (REF) (SR9607)	RAO 1-2-80	JAB WALKER TFS
				G	BY REV: ADD DETAIL "E" 0570315 WAS 0570314 (SR963A) (SR9635)	NAL 3-10-80	JAB WALKER TFS
				H	BY REV: ADD PB91, NOTE 2 & NOTE 3 MRA 210E0927 (SR10061)	LPB 11-19-80	JAB WALKER TFS

NOTES:

- 1. PART OF BASIC ANIONICS KIT
- 2. PB63 WIRE USED ON P210 ONLY AFTER SER (SR10061)
- 3. PB91 WIRE USED ON Z10 & T210 SER (SR10061) & ON

99
98
98
1-80

INACTIVE
THRU SER (SR10061) (SR10062)
MKT 1-29-82
JAB WALKER

PB91	4	S-1562-4-9	S-2402-2	S-2402-2	SER (SR10061) 60N BALL SPARES
BLU (PB37)	18	-18-6	S-2099-8	S-2376-2	SER (SR963A) (SR9635) & ON
PB66	4	S-1562-4-9	S-1367-6-12	S-1367-6-10	SER (SR914) (SR915) & ON
PB65	4	S-1562-4-9	S-2402-2	S-2402-1	SER (SR9429) & ON ALL SPARES
PB63	4	S-1562-4-9	S-2402-2	S-2402-2	SER (SR9429) & ON ALL SPARES
PB62	4	S-1562-4-9	S-2402-2	S-1367-6-12	SER (SR9429) & ON ALL SPARES
BLU (PB57)	18	-18-6	S-2099-8	S-2376-1	THRU SER (SR963A) (SR9635)
PB61	4	S-1562-4-9	S-1367-6-12	S-2402-2	OBsolete THRU SER (SR9429)
PB60	4	S-1562-4-9	S-1367-6-12	S-1367-6-12	OBsolete THRU SER (SR9429)
PB43	22		S-1367-1-6	S-1367-1-12	THRU SER (SR9607)
PB58	4	S-1562-4-9	S-1367-6-12	S-2402-1	OBsolete THRU SER (SR9429)
PB39	4	S-1562-4-9	S-1367-6-12	S-1367-6-10	THRU SER (SR914) (SR915)

13	C611005-0102	ALT CONTROL UNIT (ALTERNATE)
12	0570315	TERMINAL BOARD
11	S-2326-1	CIRCUIT BREAKER
10	S-1360-5L	CIRCUIT BREAKER
9	S-1994-1-1	MASTER SWITCH
8	MS25041-2	INDICATOR LIGHT
7	MS25237-327	LAMP
6	S-1915-1	CAPACITOR
5	D20B-14489-KA	CONNECTOR
4	C611505-0101	ALTERNATOR ASSY
3	S-2373-2	CONNECTOR
2	S-2373-1	CONNECTOR
1	C611005-0101	ALT CONTROL UNIT

EQUIPMENT TABLE			WIRE TABLE		
PART NO.	DESCRIPTION		CONTRACT NO.	NAME	DATE
				Spencer	3-2-78
				Shaver	8-6-78
				Borleske	3-1-78
				Dr. Hedrick	5-8-79
				JAB	

Cessna AIRCRAFT CO.

WIRING DIAGRAM - ALTERNATOR SYSTEM 95 AMP (OPT)


PAWNEE DIVISION
5800 E. PAWNEE
WICHITA, KANSAS

TITLE

SIZE **C** CODE IDENT. NO. **71379** DWG NO. **1270709**

SCALE: NONE Z10 P210 PAGE: 4.10

MODEL 210 & T210 SERIES SERVICE MANUAL




MODEL 210 & T210 SERIES SERVICE MANUAL


NOTES:

- 1. S-1360-15L CXT BKR REQD WITH KNOWN ICING W/S A/ICE SYSTEM
- 2. APPLIES TO P210 ONLY

REVISION			
LET	DESCRIPTION	DATE	APPD



INACTIVE
 OFF THE SYSTEM (S-1360-15L)
 H.H.G. with 1/28
 2-9-78




ITEM NO.	PART NO.	DESCRIPTION
12	S-1232-15	CIRCUIT BKR
11	S-2326-1	CIRCUIT BKR
10	2113158	BUS BAR
9	2113043	BUS BAR
8	S-2281-1	SWITCH
7	S-1232-30	CIRCUIT BKR
6	S-1360-20L	CIRCUIT BKR
5	S-1707-60	CIRCUIT BKR
4	S-1360-15L	CIRCUIT BKR
3	S-1360-10L	CIRCUIT BKR
2	S-1360-5L	CIRCUIT BKR
1	S-1232-5L	CIRCUIT BKR

CONTRACT NO:			Cessna AIRCRAFT CO.		PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS
DESIGN	SPENCER	DATE	8-23-78	TITLE	
GROUP	D. J. Henderson	DATE	8-25-78	WIRING DIAGRAM -	
DRAWN	SHEFFIELD	DATE	8-10-78	CIRCUIT BREAKERS	
CHECK	CORLESKE	DATE	8-6-78		
STRESS					
PROJ	P. J. ...	DATE	8-25-78	SIZE	CODE IDENT. NO.
APPD	J.P.S.			C	71379
OTHER				DWG NO.	1270709
			SCALE: NONE	(SR936)	PAGE: 4.11

EQUIPMENT TABLE	
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1100-CESNA SPEC. NO. S-1001 OR CES1000-CESNA STD. NO.	SUPERSEDES: 1270709 P.4.B SUPERSEDED BY: PAGE 4.13.0 + 4.13.1

MODEL 210 & T210 SERIES SERVICE MANUAL



34-0916
35-0916

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

- 1. APPLIES TO P210 ONLY
- 2. S-1360-15L CKT BKR REQD WITH KNOWN CING A/S A/ICE SYSTEM
- 3. S-1360-15L CKT BKR REQD WITH KNOWN CING PITOT HEAT SYSTEM
- 4. APPLIES TO P210 ONLY THRU SER (SR9954)

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD DETAIL "D" (SR9607)	RLY 9-26-79	JAS WWH 1/8
B	BY REV: PB 37 (REF) WAS PB 43 (REF) / DETAIL A (SR9607)	RAO 1-2-80	JAS WWH 1/8
C	BY REV: ADD S1232-35 & DETAIL "E" (SR10122)	GW 2-13-81	JAS WWH 1/8
D	BY REV: ADD DETAIL F & DETAIL G, PB THRU PB WIRES ADD NOTE 4 ADD PG 4.13.2. SER OUT DETAILS BIC (SR9953)(SR9954)	WHH 3-21-81	JAS WWH 1/8
E	BY REV: ADD S-1232-2 & DETAIL "H" (SR9953)(SR9954)	GLS 7-6-81	JAS WWH 1/8
F	BY REV: ADD DETAIL "J" & "K" (SR10101) (SR10102)	MKT 1-27-82	JAS WWH 1/8
G	BY REV: DELETE DETAILS J & K; INACT DWG (SR10101)(SR10102)	MKT 4-28-82	JAS WWH 1/8

INACTIVE
THRU SER (SR10101)(SR10102)
MKT 4-28-82
2-7 WWH 1/8

02-00916
01-00916

17	S-1232-2	CIRCUIT BREAKER							
16	2170029	BUSBAR							
15	M525306222	SWITCH							
4	S-1232-35	CIRCUIT BREAKER							
13	0713854	BUS BAR	PB96	10	S-1562-10-9	S-1367-3-8	S-1367-3-8		
12	S-2326-1	CIRCUIT BREAKER	PB95	10		S-1367-3-8	S-1367-3-8		
11	1270742	BUS BAR	PB94	10		S-1367-3-8	S-1367-3-8		
10	1270741	BUS BAR	PB93	10		S-1367-3-8	S-1367-3-8		
9	S-1232-15	CIRCUIT BREAKER	PB69	10	S-1562-10-9	S-1367-3-8	S-1367-3-8		
8	S-2281-1	SWITCH	PB68	10	S-1562-10-9	S-1367-3-8	S-1367-3-8		
7	S-1360-20L	CIRCUIT BREAKER							
6	S-1232-60								
5	S-1232-30								
4	S-1232-5								
3	S-1360-15L								
2	S-1360-10L								
1	S-1360-5L	CIRCUIT BREAKER							


WIRE TABLE									
WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS				

CONTRACT NO.			Cessna AIRCRAFT CO.		PAWNEE DIVISION 3600 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE			
SPENCER		2-19-79	WIRING DIAGRAM — CIRCUIT BREAKERS			
GROUP	H. Ghazarian	2-7-79				
DRAWN	H. GHAZARIAN	2-9-79				
CHECK	BORLESKE	2-12-79				
STRESS						
PROJ		2-5-79	SIZE	CODE IDENT. NO.	DWG NO	
APPO	JAS WWH		C	71379	1270709	
OTHER			SCALE: NONE	(SR914)(SR9115)	PAGE: 4.13.0	

ITEM NO.	PART NO.	DESCRIPTION

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESBNA SPEC. NO. S-XXX OR CXXXX-CESBNA STD. NO.	SUPERSEDES: P. 4.11 SUPERSEDED BY: P. 4.13.3
---	---


MODEL 210 & T210 SERIES SERVICE MANUAL




CONTRACT NO:			Cessna AIRCRAFT CO.			PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	TITLE					
GROUP	SPENCER	2-14-79	WIRING DIAGRAM —					
DRAWN	H. GHAZARIAN	2-9-79	CIRCUIT BREAKERS					
CHECK	BORLESKE	2-12-79						
STRESS								
PROJ			SIZE	CODE IDENT. NO.	DWG NO			
APPD			C	71379	1270709			
OTHER			SCALE: NONE		(SR 914)(SR 915)		PAGE: 1 of 2	

MODEL 210 & T210 SERIES SERVICE MANUAL



REVISION			
LET	DESCRIPTION	DATE	APPRO
G	SEE SHT 4.13.0 FOR REV		



DETAIL A
 APPLIES WITH 95 AMP ALT SYSTEM (OPT)
 SER (SR9607) & ON




DETAIL D
 APPLIES WITH 45 AMP ALT SYSTEM (OPT)
 THRU SER (SR9607)




DETAIL E
 THRU SER (SR10122)

DETAIL B
 APPLIES WITH STDBY GEN (OPT)
 THRU SER (SR9953) (SR9954)



DETAIL C
 APPLIES WITH STDBY GEN (OPT)
 THRU SER (SR9953) (SR9954)




DETAIL H
 THRU SER (SR9953) (SR9954)

INACTIVE
 THRU SER (SR10101)†
 (SR10102)
 MKT 4-28-82
 2-7-84

53-00916
 54-00916


CONTRACT NO:			Cessna AIRCRAFT CO.			PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	SPENCER	2-14-79	TITLE	WIRING DIAGRAM CIRCUIT BREAKERS				
GROUP	<i>D. H. Spencer</i>	3-2-79						
DRAWN	H. GHAZARIAN	2-9-79						
CHECK	BORLESKE	2-12-79						
STRESS								
PROJ	<i>25-1000</i>	2-5-79	SIZE	CODE IDENT NO	DWG NO.			
APPRO	<i>[Signature]</i>		C	71379	1270709			
OTHER			SCALE: NONE	SR3114(SR9115)	PAGE: 413.1			

MODEL 210 & T210 SERIES SERVICE MANUAL



9100-10
 9100-20

MODEL 210 & T210 SERIES SERVICE MANUAL




CONTRACT NO:			Cessna AIRCRAFT CO.			PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	TITLE					
GROUP	SPENCER	2-14-79	WIRING DIAGRAM —					
DRAWN	<i>H. Ghazarian</i>	3-2-79	STANDBY GENERATOR					
CHECK	BORLESKE	2-12-79	(OPT)					
STRESS								
PROJ	<i>J. S. ...</i>	3-5-79	SIZE	CODE IDENT. NO.	DWG NO.			
APPD	<i>J. B. ...</i>		C	71379	1270709			
OTHER			SCALE: NONE			SR914(SR9115) PAGE: J. 14		

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

① PLACE 35.00 IN. LENGTH OF S-292-14 SLEEVING OVER WIRE BEFORE INSTALLING WIRE TERMINATION.

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD DETAIL A BLK (PA 40) S-2527-1 (-2) (SR10101)(SR10102)	MKT 1-27-80	JAS UHH HCS
B	BY REV: ADD S-2593-2 SWITCH (SR10101)(SR10102)	UHH 4-27-82	CSA HCS



DETAIL A
THRU SER (SR10101)(SR10102)

02-00916
01-00910


ITEM NO	PART NO.	DESCRIPTION	QUANTITY	WIRE NO.	GA.	MATERIAL	LG.	TERMINALS	SERIALS
8	S-2593-2	MASTER SWITCH							
7	S-2527-2	GND CONNECTOR							
6	S-2527-1	LH GND BLOCK							
5	S-2443-1	CONTACTOR							
4	S-1994-1-1	SWITCH							
3	S-2475-1	CONTACTOR							
2	0710728	DIODE ASSY							
1	C614001-0105	BATTERY ASSY							

WIRE TABLE									
WIRE NO.	GA.	MATERIAL	LG.	TERMINALS	SERIALS				
BLK(PA40) 22	-22-0								
PA35	2	S-1562-2-9	52.2	5-1367-7-13	5-1367-7-13				
PA32	2	S-1562-2-9	71.7	5-1367-7-12	5-1367-7-13				
PA33	2	S-1562-2-9	10.4	5-2447-2	5-1367-7-13				
PA17	22			5-1367-1-10	5-1493-1				
PA6	22			5-1493-1	5-1367-1-8				

EQUIPMENT TABLE		
ITEM NO	PART NO.	DESCRIPTION
1	C614001-0105	BATTERY ASSY


CONTRACT NO.		NAME		DATE	TITLE		
		TJADEN		1-22-80	WIRING DIAGRAM - BATTERY CIRCUIT		
DESIGN		D. WILCOX		3-5-80			
DRAWN		LEVERENZ		3-10-80			
CHECK		BORLESKE		3-11-80			
STRESS							
PROJ		SVC		3-27-80	SIZE	CODE IDENT.	DWG NO
APPD		JRG			C	71379	1270709
OTHER					SCALE	NONE (SR9634)	PAGE: 4-16

MODEL 210 & T210 SERIES SERVICE MANUAL



REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV. ADD BLK(PB148) S-2527-1 & 2 & DETAIL 'A' (SR1010) (SR1012)	MKT 1-27-82	JAB:DNM APB
B	BY REV. ADD DETAIL 'B' SER OUT PB 37 ADD S-2527-2 SWITCH (SR1010) (SR1012)	WHH 4-22-82	REH APB

NOTES:
 PART OF BASIC AVIONICS KIT



91600-10
91600-20

DETAIL 13
 THRU SER(SR1010)
 (SR1012)

QTY	PART NO.	DESCRIPTION	WIRE CODE NO.	MATERIAL	LG	TERMINALS	SERIALS
16	S-2527-2	MASTER SWITCH					
15	S-2527-2	GND CONNECTOR					
14	S-2527-1	LN GND BLOCK					
13	S-1232-60	CIRCUIT BREAKER					
12	C611005-0102	ALT CONTROL UNIT (ALTERNATE)					
11	0570315	TERMINAL BOARD					
10	S-1707-60	CIRCUIT BREAKER					
9	S-1360-5L	CIRCUIT BREAKER					THRU SER(SR1010)(SR1012)
8	MS25041-2	INDICATOR LIGHT					
7	MS25237-327	LAMP					THRU SER(SR1010)(SR1012)
6	S-1994-1-1	MASTER SWITCH					
5	S-1915-1	CAPACITOR					
4	C611503-0102	ALTERNATOR ASSY					
3	S-2373-2	CONNECTOR					
2	S-2373-1	CONNECTOR					
1	C611005-0101	ALT CONTROL UNIT					

WIRE CODE NO.	MATERIAL	LG	TERMINALS	SERIALS
22	-22-0			
20	-20-2			
20	-20-4			
16	-16-6			
20				
20	20-3			
8	S-1562-8-9			
8	S-1562-8-9			
8	S-1562-8-9			
22				
22				
22				
22				
22				
22				
22				

EQUIPMENT TABLE	
PART NO.	DESCRIPTION
1270709	PG. 4.9.0

CONTRACT NO:

Cessna AIRCRAFT CO. PAWNEE DIVISION
 5800 E. PAWNEE WICHITA, KANSAS


DESIGN NAME DATE
 ABRAHAM
 GROUP *D.H. Hair* 4-3-80
 DRAWN S. BURRIS 3-31-80
 CHECK *FE HAIR* 3-31-80

TITLE
WIRING DIAGRAM — ALTERNATOR SYSTEM 60 AMP


SIZE CODE IDENT DWG NO
 C 71379 1270709

SCALE NONE (SR 9634)(SR 9635) PAGE: 4.17
 (SR 9785)

MODEL 210 & T210 SERIES SERVICE MANUAL



INACTIVE
 THROUGH SER (S-1232-15) (S-1232-30)
 WMA 4-19-82 REL 1/80



18					
17	1270864	BUS BAR			
16	057C442	AUDIO CONT PNL			
15	2470033	AUDIO CONT PNL			
14	87149-7	CONNECTOR			
13	S-2281-1	SWITCH			
12	S-1232-30	CKT BKR			
11	S-1232-15	CKT BKR			
10	S-1638-2	CONNECTOR			
9	S-1638-1	CONNECTOR			
8	S-1360-54	CKT BKR			
7	0713E54	BUS BAR			
6	1270742	BUS BAR			
5	1270741	BUS BAR			
4	S-382-3	SWITCH			
3	7664K5	SWITCH			
2	C611006-0101	VOLTAGE REGULATOR			
1	C611507-0101	GENERATOR			

PB89	12			S1367-3-6	S1367-3-6
PB88	12			S1367-3-6	S1367-3-6
PB77	12			S1367-3-6	S1367-3-6
PB76	12			S1367-3-6	S1367-3-6
PB75	16			S1367-2-6	S1367-2-6
PB74	16			S1367-2-6	S1367-2-6
PB73	16			S1367-2-6	S1367-2-6
BLK (PB72)	20	-20-0		S-1367-1-8	S-1636-1
PB71	20			S-1367-1-10	S-1636-1
PB70	20			S-1367-1-2	S-1636-1
WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS

ITEM NO	PART NO.	DESCRIPTION
EQUIPMENT TABLE		

CONTRACT NO:			Cessna AIRCRAFT CO.		
DESIGN	NAME	DATE			
GROUP	TJADEN	7-16-80	WIRING DIAGRAM - STANDBY GENERATOR (OPT)		
DRAWN	TJADEN	7-28-80			
CHECK	BORLESKE	7-16-80			
STRESS					
PROJ	JH MOORE	7-28-80	SIZE	CODE IDENT. NO.	DWG NO.
APPD	ARS		C	71379	1270709
OTHER			SCALE: NONE (SR9793)		

CES-1000 IS APPLICABLE
 CES-XXXX-CESNA SPEC. NO.
 S-XXX OR CMXXXX-CESNA
 STD. NO.

SUPERSEDES:
 SUPERSEDED BY:
 1270709 P4.14

PAWNEE DIVISION
 5800 E. PAWNEE
 WICHITA, KANSAS

SCALE: NONE (SR9793)

PAGE: 4. 18

MODEL 270 & 1270 SERIES SERVICE MANUAL

REVISION				REVISION				
LET	DESCRIPTION	DATE	APPD	LET	DESCRIPTION	DATE	APPD	
C	BY REV: ADD S2527-2 S2527-1, PM1, PM10, PB149, PB150, PB155, PB156, PB157, S2593-2 ADD PAGE 4.19.2 SER OUT PB112, PB113, PB128, PB129, PB141, PB142, PB143 (SR10101)(SR10102)	1-27-82	MKT JMS JMS/whl RNT	A	BY REV: FN-DA15(REF) WAS FN-PS108 FN-DA14(REF) WAS FN-PS107 FN-DA12(REF) WAS FN-PS104 & FN-DA15(REF) WAS FN-PS105. DELETE FN-PS106, FN-PS104 FN-PS105 & FN-PS107 WIRES FROM WIRE TABLE. ON PS102 & PS103 WIRES SOLDER WIRE S-1495-1. ON PS112 & PS113 WIRES SOLDER WAS S167-6 S1367-1-6 WAS S1498-1. ON PS128 & PS129 WIRES S-1367-1-6 WAS S-1495-1. ADD 20 GA JUMPER AT ALT. RESTART SW. ON PS106 WIRE SOLDER WAS S167-6 S1367-1-6 DELETE 2170024 FROM EQUIPMENT TABLE (SR5953)(SR9954)	4-8-81	WHM 4-8-81	whl RNT PRG
D	BY REV: ADD DETAIL "C" (SR10101)(SR10102)	A-22-82	WHM A-22-82					
E	BY REV: FN-DA24(REF) WAS FN-DA14(REF) FN-DA22(REF) WAS FN-DA15(REF) FN-DA25(REF) WAS FN-DA12(REF) FN-DA23(REF) WAS FN-DA13(REF) PG 4.4.1 (SR10784)	07-83	WHM 07-83					
				B	BY REV: ADD NUMBERS ON TERMINALS/ MS25041-2 & MS25041-4. ADD MS25041-4; PD117/S1367-1-6 WAS S2099-4, PB155/S1367-1-6 WAS SOLDER (SR9953)(SR9954)	JPO 9-16-81 MKT 10-6-81	JMS JMS MKT RNT	

▷ TO AMMETER SEL. SW.

21	S2593-2	SWITCH							
20	S2527-2	GND CONNECTOR							
19	S2527-1	LH GND BLOCK							
18	MS25041-4	LIGHT ASSY							
17	2101055	BATTERY ASSY							
16	MS25237-927	LAMP							
15	MS25041-2	LIGHT ASSY							
14	S2349-1	CONNECTOR							
13	C611007-0101	ALT CONTROL UNIT							
12	S1790-2-1	SWITCH							
11	C611503-0104	ALTERNATOR							
10	S2035-2	PLUG							
9	83-0057	RESISTOR							
8									
7	S1890-1	SWITCH							
6	20H3P	DIODE							
5	S2558-1	SHUNT							
4	2170027	BUS BAR							
3	S1360-5L	CKT BREAKER							
2	S1232-60	CKT BREAKER							
1	S2475-1	CONTACTOR							
	PART NO.	DESCRIPTION							
EQUIPMENT TABLE									
CEP-1000 IS APPLICABLE VENDOR CODES PER S-1400 CEP-1000-CESSNA SPEC. NO. S-XXX OR CXXXX-CESSNA STD. NO.			SUPERSEDES: SUPERSEDED BY:		PROJ J.H. MOORE/A 3-25-81 APPD JMS/whl OTHER		WIRE TABLE CONTRACT NO: NAME DATE DESIGN TITLE GROUP W/whl/whl 3-24-81 DRAWN ACKERSON 3-24-81 CHECK BORLESKE 3-24-81 STRESS SIZE CODE IDENT. DWG NO C 71379 1270709 MATERIAL NONE (SR9953)(SR9954) PAGE: 4-19,0		02-00916 01-00916

MODEL 210 & T210 SERIES SERVICE MANUAL


BLK(PB157)	22	-22-O		SOLDER	S2099-4	SER(SR1010)(SR10102) ON
BLK(PB156)	22	-22-O		SOLDER	S2099-4	SER(SR1010)(SR10102) ON
BLK(PB155)	22	-22-O		SOLDER	S2099-4	SER(SR1010)(SR10102) ON
PB 150	20			S1493-1	S2099-4	SER(SR1010)(SR10102) ON
PB 149	20			S1493-1	S2099-4	SER(SR1010)(SR10102) ON
PB 148	20			SOLDER	S1493-1	SER(SR1010)(SR10102) ON
PB 147	20			SOLDER	S1493-1	SER(SR1010)(SR10102) ON
PB 146	6			S1943-4	S1943-5	
PB 145	20			SOLDER	SOLDER	
PB 144	20			S1361-8	SOLDER	
PB 143	22			SOLDER	S1367-8	THRU SER(SR1010)(SR10102)
PB 142	22			SOLDER	S1367-8	THRU SER(SR1010)(SR10102)
PB 141	22			SOLDER	S1367-8	THRU SER(SR1010)(SR10102)
PB 140	22			SOLDER	S2099-4	
PB 139	22			SOLDER	SOLDER	
PB 138	22			SOLDER	SOLDER	
PB 137	22			S2099-4	SOLDER	
PB 136	22			S2099-4	SOLDER	
PB 135	22			S2099-4	S1367-1-6	
PB 134	20			S2099-4	S1367-1-8	
PB 133	20			S1367-8	S2099-4	
PB 132	20			S2099-4	S2099-4	
PB 131	20			S2099-4	S2099-4	
PB 130	20			S2099-4	S2099-4	
PB 129	20			S1367-6	S2099-4	THRU SER(SR1010)(SR10102)
PB 128	20			S1367-6	S2099-4	THRU SER(SR1010)(SR10102)
PB 127	185			S1943-4	S2099-4	
PB 126	20			S1367-8	S2099-4	
PB 125	20			S1367-10	S2099-4	
CODE	GA	MATERIAL	LG	TERMINALS		SERIALS

WIRE TABLE

CONTRACT NO:			Cessna AIRCRAFT CO.			PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	TITLE					
GROUP	<i>W. H. ...</i>	<i>3-24-81</i>	WIRING DIAGRAM — DUAL ALTERNATOR					
DRAWN	<i>ACKERSON</i>	<i>3-24-81</i>						
CHECK	<i>BORLESKE</i>	<i>3-24-81</i>						
STRESS								
PROJ	<i>J. H. ...</i>	<i>3-24-81</i>	SIZE	CODE IDENT. NO.	OWG NO.			
APPD	<i>...</i>		C	71379	1270709			
OTHER			SERIALS: NONE (SR9953)(SR9954) PAGE: A-19,0					

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
E	SEE SHEET 4.19.0 FOR REV		




CONTRACT NO:		NAME		DATE	CESSNA AIRCRAFT CO.			FAWNEE DIVISION 5800 E. FAWNEE WICHITA, KANSAS		
DESIGN GROUP	W. J. Anderson		3-24-81		TITLE					
DRAWN ACKERSON 3-24-81					WIRING DIAGRAM - DUAL ALTERNATOR					
CHECK BORLESKE 3-24-81										
STRESS										
PROJ	J.H. MOORE		3-25-81		SIZE	CODE IDENT. NO.	DWG. NO.			
APPD	P. J. G.				C	71379	1270709			
OTHER					SCALE: NONE			PAGE: 4.19.1		

Dual Alternator (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

See Sheet 1




See Sheet 1


CONTRACT NO:		Cessna AIRCRAFT CO.		PAWNEE DIVISION 5800 E PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE		
GROUP	W. J. HENDERSON	3-24-81	WIRING DIAGRAM - DUAL ALTERNATOR		
DRAWN	ACKERSON	3-24-81			
CHECK	BORLESKE	3-24-81			
STRESS					
PROJ	J. MUGGER	3-25-81	SIZE	CODE IDENT NO.	DWG NO.
APPD	P. J. G.		C	71379	1270709
OTHER			SCALE: NONE		PAGE 4.19.1

MODEL 210 & T210 SERIES SERVICE MANUAL


REVISION			
LET	DESCRIPTION	DATE	APPD
D	SEE PG 4.19.D FOR REV.		



DETAIL A
THRU SER (SR 10101)(SR 10102)



DETAIL B
THRU SER (SR 10101)(SR 10102)



DETAIL C
THRU SER (SR 10101)(SR 10102)

71600-10
1600-20


CONTRACT NO.			Cessna AIRCRAFT CO.		PAWNEE DIVISION 3800 E PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE			TITLE WIRING DIAGRAM DUAL ALTERNATOR	
GROUP	<i>W.H. Thompson</i>	<i>3-30-82</i>				
DRAWN	<i>M. THOMPSON</i>	<i>1-27-82</i>				
CHECK	<i>BORLESKE</i>	<i>1-28-82</i>				
STRESS						
PROJ	<i>J. J. M0012 E</i>	<i>33382</i>	SIZE	CODE IDENT NO.	DWG NO.	
APPD	<i>TLC/WHT</i>		C	71379	1270709	
OTHER						
			SCALE	NONE	(SR10101)(SR10102)	PAGE 4 OF 2

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES


▲ ALTERNATOR CHART FUSE ASSYS ARE PART OF 2170024 MODULE ASSY.

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV' DELETE BLK(1), 2170030 FN-DA2 & FN-DA1, BRN(1), YEL(1), ORN(1) GRN(1) WAS 20 GA (SR9953) (SR9954)	MKT 8-17-81	AS 311 /AS
B	6, 7, 8, 9 W/S 2, 3, 4 / SWITCH TERMINALS (SR10513) ADD S-2558-2 SHUNT (HOUSEHOP PRACTICE)	TMS 5-27-82	1007/AS /



BRN(1)	22	-22-1	SOLDER	S1963-2		
YEL(1)	1	-22-4				
ORN(1)	1	-22-3				
GRN(1)	22	-22-5	SOLDER	S1963-2		
BLK(1)	22	-22-6	SOLDER	S1963-2		
GRN(1)	1	-22-8				
VIOL(1)	1	-22-7				
WHT(1)	1	-22-9				
RED(1)	1	-22-2	SOLDER	S1963-2		
BLK		-22-0	S1963-1	S156-140		
BRN		-22-2		S156-110		
FN-DA1				S156-110		
FN-DA2				S156-110		
FN-DA3				S156-110		
FN-DA4				S156-110		
FN-DA5				S156-110		
FN-DA6				S156-110		
FN-DA7				S156-110		
FN-DA8				S156-110		
FN-DA9				S156-110		
FN-DA10				S156-110		
WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS		SERIALS

53-00-03
53-00-04



PART NO.	DESCRIPTION	QUANTITY
6	S-2558-1 SHUNT	
5	S-2558-2 SHUNT	
4	669563 INSTR. CLUSTER	
3	S1961-2-0 HOUSING	
2	S1961-1-0 HOUSING	
1	2570044 SELECTOR SW. ASSY	

WIRE TABLE		
DESIGN	NAME	DATE
GROUP	<i>W. Harden</i>	3-24-81
DRAWN	<i>HARDEN</i>	3-24-81
CHECK	<i>BORLESKE</i>	3-24-81
STRESS		

Cessna AIRCRAFT CO. PAWNEE DIVISION
3800 E. PAWNEE WICHITA, KANSAS

WIRING DIAGRAM — VOLT-AMMETER (OPT)

EQUIPMENT TABLE	
PART NO.	DESCRIPTION

CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX-CESNA SPEC. NO.
S-XXXX OR CHXXXX-CESNA
STD. NO.

SUPERSEDES:
SUPERSEDED BY:
PG. 4.22

PROJ: TH 1400LE/A 3-15-81
APPD: *ESB*
OTHER:

SIZE: C CODE IDENT. NO.: 71379 DWG NO.: 1270709
SCALE: NONE (SR9953) (SR9954) PAGE: 4, 20

MODEL 210 & T210 SERIES SERVICE MANUAL

LET	DESCRIPTION	DATE	APPD
A	BY REV: FN-PA38 WAS FN-PA17 (REF) FN-PA39 WAS FN-PA6 (REF) (SR9953)(SR9954)	WHA 4-9-81	REH <i>[Signature]</i>
B	BY REV: S-2558-2 WAS S-2558-1 ADD FN-PB17 BATTERY - SHUNT (SR9953)(SR9954)	MKT 10-6-81	REH <i>[Signature]</i> /RS
C	BY REV: ADD DETAIL 'A' S2527-2, S2527-1, BK (FN-PA41); SER OUT FN-PA39, FN-PA38, S1790-1; ADD S2593-2, FN-PA17 (SR1010)(SR1012)	MKT 1-27-82 RNT	REH <i>[Signature]</i>
D	BY REV: CHANGE PICTURE OF S-2593-2 MASTER SWITCH TO SHOW PROPER LOCATION OF A11 P ALT 2. (SR1010)(SR1012)	WHA 4-22-82	REH <i>[Signature]</i> /RS
E	BY REV: ADD DETAIL 'B' 4" 150" CIRCUIT BREAKER (SR1010)(SR1012)	WHA 5-26-82	REH <i>[Signature]</i> /RS
F	BY REV: DA17(REF) WAS DA16(REF); DA16(REF) WAS DA17(REF); FUSE WAS RESISTOR TO CONNECTION 2 OF S-2558-2 (SR9953)(REF)(SR9954)(REF)	GLS 7-14-82	REH <i>[Signature]</i> /RS
G	BY REV: FN-DA20(REF) WAS FN-DA17(REF) FN-DA21(REF) WAS FN-DA16(REF) (SR10784)	WHA 10-17-83	REH <i>[Signature]</i> /RS

ITEM NO	PART NO.	DESCRIPTION	WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
10	S-2593-2	MASTER SWITCH	FN-PA17	22			S1367-10	S-1493-1
9	S2527-2	GND CONNECTOR	FN-PA39	22	-22-0		S1367-16	S2099-9
8	S2527-1	LH GND BLOCK	FN-PA38	22			S1367-16	S1367-18
7	S-2558-2	SHUNT-BATTERY	FN-PA37	6	S-1562-6-9		S1367-110	S1367-16
6	S-1232-60	CIRCUIT BREAKER	FN-PA36	6	S-1562-6-9		S1367-512	S1367-512
5	S-2443-1	CONTACTOR						
4	S1790-1	MASTER SWITCH						
3	S2475-1	CONTACTOR						
2	0770728	DIODE ASSY						
1	CG14001-0105	BATTERY ASSY						

WIRE TABLE			
CONTRACT NO:	NAME	DATE	TITLE
			Cessna AIRCRAFT CO.
			WIRING DIAGRAM -
			BATTERY CIRCUIT-OPT
			(WITH DUAL ALTERNATORS)

DESIGN	GROUP	DRAWN	CHECK	STRESS	PROJ	APPD	OTHER	SIZE	CODE IDENT. NO.	DWG NO
					J. H. MOORE			C	71379	1270709

EQUIPMENT TABLE	
ITEM NO	DESCRIPTION
10	S-2593-2 MASTER SWITCH
9	S2527-2 GND CONNECTOR
8	S2527-1 LH GND BLOCK
7	S-2558-2 SHUNT-BATTERY
6	S-1232-60 CIRCUIT BREAKER
5	S-2443-1 CONTACTOR
4	S1790-1 MASTER SWITCH
3	S2475-1 CONTACTOR
2	0770728 DIODE ASSY
1	CG14001-0105 BATTERY ASSY



SUPERSEDES:	
ITEM NO	DESCRIPTION

SUPERSEDED BY:	
ITEM NO	DESCRIPTION

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
FN-PA17	22			S1367-10	S-1493-1
FN-PA39	22	-22-0		S1367-16	S2099-9
FN-PA38	22			S1367-16	S1367-18
FN-PA37	6	S-1562-6-9		S1367-110	S1367-16
FN-PA36	6	S-1562-6-9		S1367-512	S1367-512

PAWNEE DIVISION	3800 E. PAWNEE	WICHITA, KANSAS
PAGE: 4 21		

MODEL 210 & T210 SERIES SERVICE MANUAL



DETAIL A
THRU SER(SR10101)(SR10102)

CONTRACT NO:				PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE		
GROUP	<i>W. H. Moore</i>	<i>3-24-81</i>	WIRING DIAGRAM— BATTERY CIRCUIT—OPT (WITH DUAL ALTERNATORS)		
DRAWN	<i>HARDEN</i>	<i>3-24-81</i>			
CHECK	<i>DORLESKE</i>	<i>3-29-81</i>			
STRESS					
PROJ	<i>J. H. MOORE</i>	<i>3-25-81</i>	SIZE	CODE IDENT. NO.	DWG NO.
APPD	<i>J. H. MOORE</i>		C	71379	1270709
OTHER					
			SCALE	NONE	
			PAGE: 4/21		


Battery Circuit (OPT) (With Dual Alternators) (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

- 1 PART OF BASIC AVIONICS KIT
- 2 PB63 WIRE USED ON P210 ONLY AFTER SER (SR100W)
- 3 PB91 WIRE USED ON 210 & T210 SER (SR100W) & ON

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD DETAIL 'A' & S-2593-2 SWITCH (SR1001)(SR20102)	WJH 4-22-82	RAJ / JAG
B	BY REV: BLU (PB92) WAS BLU (PB87) (SR9953) (REF) (SR9954) (REF)	GLS 9-14-82	RAJ / JAG



02-00916
01-00916

DETAIL A
SER (SR10101) (SR10102)

ITEM NO	PART NO.	DESCRIPTION	QUANTITY	WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
16	S-2593-2	MASTER SWITCH							
15	S-2527-2	GND CONNECTOR							
14	S-2527-1	LH GND BLOCK							
13	C611005	ALT CONTROL UNIT (ALTERNATE)	PB91 4	S-1562-4-9		S-2402-2	S-2402-2	3	
12	O570315	TERMINAL BOARD	BLU (PB92) 18	-18-6		S-2099-8	S-2376-1		
11	S-2326-1	CIRCUIT BREAKER	PB66 4	S-1562-4-9		S-1367-6-12	S-1367-6-10		
10	S-1360-5L	CIRCUIT BREAKER	PB65 4	S-1562-4-9		S-2402-2	S-2402-1		
9	S-1994-1-1	MASTER SWITCH	PB63 4	S-1562-4-9		S-2402-2	S-2402-2	2	
8	MS25041-2	INDICATOR LIGHT	PB62 4	S-1562-4-9		S-2402-2	S-1367-6-12		
7	MS25237-327	LAMP							
6	S-1915-1	CAPACITOR							
5	D208-19489-KA	CONNECTOR							
4	C611505	ALTERNATOR ASSY							
3	S-2373-2	CONNECTOR							
2	S-2373-1	CONNECTOR							
1	C611005	ALT CONTROL UNIT							

EQUIPMENT TABLE		WIRE TABLE		
CONTRACT NO:		Cessna AIRCRAFT CO.		
DESIGN		PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS		
GROUP		TITLE		
DRAWN		WIRING DIAGRAM - ALTERNATOR SYSTEM 95 AMP (OPT)		
CHECK		SIZE		
STRESS		CODE IDENT. NO.		
PROJ.		DWG NO		
APPD		C 71379 - 1270709		
OTHER		SCALE NONE (SERVIC) (SR10102) PAGE: 4/22		

CES1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX-CESSNA SPEC. NO.
S-XXX OR CMXXXX-CESSNA
STD. NO.

SUPERSEDES:
1270709 P4.10
SUPERSEDED BY:


NOTES:

- 1. APPLIES TO P810 ONLY
- 2. 5-1360-15L CKT BKR RECD WITH KNOWN ICING W/S A/ICE SYSTEM
- 3. 5-1360-10L CKT BKR RECD WITH KNOWN ICING PITOT HEAT SYSTEM & STALL WARN. HEAT SYSTEM.

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: STRB/FLOOD CKT BKR WAS STROBE CKT BKR; ISOL CKT BKR WAS CABIN FAN CKT BKR; RELOCATE CABIN FAN, LDG & TAXI CKT BKR; DELETE 0713854 / ITEM 13; NACT R 4230 ADD PAGE 4.23.2 (SR10563)(SR10101)(SR10102)(REF)	GLS 3/20/82	RLH 1/13/82

INACTIVE

THRU SER (SR10563)
H.I. 8/20/82
24 JAN 1/13/82



02-0096
01-00916

12	5-1252-35	CIRCUIT BREAKER
11	2170035	BUS BAR
9	M25506222	SWITCH
8	5-2526-1	CIRCUIT BREAKER
7	5-1360-20L	
6	5-1238-60	
5	5-1232-15	
4	5-1232-3	
3	5-1232-2	
2	5-1360-10L	
1	5-1360-5L	CIRCUIT BREAKER

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
FN-PB96	10	5-1562-10-9		51367305136738 (OPT)	
FN-PB95	10			51367305136736 (OPT)	
FN-PB94	10			51367305136738 (OPT)	
FN-PB93	10	5-1362-10-9		51367305136736 (OPT)	

WIRE TABLE


CONTRACT NO.			Cosna AIRCRAFT CO.		PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE			
	HARDEN	4-29-82	WIRING DIAGRAM - CIRCUIT BREAKERS			
GROUP	W.H. HENDERSON	4-29-82				
DRAWN	M. THOMPSON	4-28-82				
CHECK	R. YOUNGERS	4-28-82				
STRESS						

PART NO.	DESCRIPTION
EQUIPMENT TABLE	
CES-000 IS APPLICABLE VENDOR CODES PER S-1400 CES-0000-CESNA SPEC. NO. S-100X OR C00000-CESNA STD. NO.	
SUPERSEDES: 4.13.0	
SUPERSEDED BY:	

PROJ	APPD	OTHER	SIZE	CODE IDENT. NO.	DWG NO
J.M. MOWAT	AR6		C	71379	1270709
			SCALE NONE (SR10101)(SR10102) PAGE: 4.23.0		

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD



DETAIL A
 APPLIES WITH 95 AMP ALT SYSTEM (OPT)

07-008/6
07-008/6


CONTRACT NO.			PAWNEE DIVISION 5800 E PAWNEE WICHITA, KANSAS	
NAME	DATE	TITLE		
DESIGN	HARDEN 4-25-82	WIRING DIAGRAM - CIRCUIT BREAKERS		
GROUP	W. Henderson 4-25-82			
DRAWN	M. THOMPSON 4-28-82			
CHECK	R. YOUNGERS 4-28-82			
STRESS				
PROJ	...NDONE 4-29-82	SIZE	CODE IDENT. NO.	DWG NO.
APPD	DRS	C	71379	1270709
OTHER		SCALE	NONE	(SR101)(SR102) PAGE: 4.23.1

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

- 1 APPLIES TO P210 ONLY
- 2 S-1360-15L CKT BKR REQD WITH KNOWN ICING W/S A/ICE SYSTEM
- 3 S-1360-10L CKT BKR REQD WITH KNOWN ICING PITOT HEAT SYSTEM & STALL WARN HEAT SYSTEM.
- 4 WIRE CUT LENGTH TOLERANCE OF ± .10 INCH MUST BE MAINTAINED. REFER TO WIRE TABLE FOR PB158, PB159, PB160, AND PB161 WIRE LENGTHS.

REVISION			
LET	DESCRIPTION	DATE	APPO
A	SEE PG 4.23.0 FOR REV		



ITEM NO	PART NO.	DESCRIPTION
11	Z170035	BUS BAR
10	S-1232-35	CIRCUIT BREAKER
9	M525306-222	SWITCH
8	S-2326-1	CIRCUIT BREAKER
7	S-1360-20L	
6	S-1232-60	
5	S-1232-15	
4	S-1232-5	
3	S-1232-2	
2	S-1360-10L	
1	S-1360-5L	CIRCUIT BREAKER

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
FN-PB161	10	S-1562-10-9	6.25	S-1367-3-6	S-1367-3-6 (OPT)
FN-PB160	10	S-1562-10-9	3.5	S-1367-3-6	S-1367-3-6 (OPT)
FN-PB159	10	S-1562-10-9	8.0	S-1367-3-6	S-1367-3-6 (OPT)
FN-PB158	10	S-1562-10-9	8.0	S-1367-3-6	S-1367-3-6 (OPT)

WIRE TABLE

CONTRACT NO: _____

Cessna AIRCRAFT CO. PAWNEE DIVISION
3800 E. PAWNEE WICHITA, KANSAS

DESIGN: _____ NAME: _____ DATE: _____

GROUP: *W.N. Swanson* 8-27-82

DRAWN: *G. STAMM* 8/20/82

CHECK: *R. YOUNGERS* 8-23-82

STRESS: _____

PROJ: *J.H. Moore* 8-27-82

APPO: *DRS*

OTHER: _____

TITLE: **WIRING DIAGRAM — CIRCUIT BREAKERS**

SIZE: **C** CODE IDENT. NO: **71379** DWG NO: **1270709**

SCALE: **NONE** (SRI0563) PAGE: 4.23.2

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESNA SPEC. NO. S-XXX OR CXXXX-CESNA STD. NO.

SUPERSEDES: _____



SUPERSEDED BY: _____

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

1. ALTERNATOR SHUNT & FUSE ASSYS ARE PART OF 2170024 MODULE ASSY

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD SWITCH DECK DESIGNATIONS. ON FIRST DECK 1 THRU 4 WAS 6 THRU 9 (SR 10734)	12/1/83	KEL JHN PFS



WIRE	GA	MATERIAL	LG	TERMINALS	SERIALS
RED (2)	22	-22-2		SOLDER S-2341-1	
WHT (2)	22	-22-9		SOLDER S-2341-1	
VIU (2)	22	-22-7		SOLDER S-2341-1	
GRY (2)	22	-22-8		S-2341-1 SOLDER	
BLU (2)		-22-6			
GRN (2)		-22-5			
ORN (2)		-22-3			
YEL (2)		-22-4			
BRN (2)		-22-1		S-2341-1 SOLDER	
BLK (FN-DA27)		-22-0		S-2415-1 S-1367-1-10	
RED (FN-DA26)		-22-2		S-1367-1-10	
FN-DA25				S-1367-1-8	
FN-DA24					
FN-DA23					
FN-DA22					
FN-DA21					
FN-DA20	22			S-2415-1 S-1367-1-8	

ITER NO.	PART NO.	DESCRIPTION
6	S-2558-1	SHUNT BATTERY
5	S-2558-1	SHUNT ALTERNATOR
4	CG69563	INSTR CLUSTER
3	S-2349-A	HOUSING
2	S-2350-G	HOUSING
1	2570100	SELECTOR SW ASSY

WIRE TABLE

CONTRACT NO: _____

DESIGN: SPENCER NAME: _____ DATE: 10-17-83

GROUP: _____

DRAWN: SPENCER DATE: 10-17-83

CHECK: REHAUER DATE: 10-19-83

STRESS: _____

PROJ: 1174001E DATE: 11-29-83

APPD: PFS

OTHER: _____

SIZE: C CODE IDENT. NO.: 71379 DWG NO.: 1270709

SCALE: NONE (SR10734) (SR10715) PAGE: 4-24

Cessna AIRCRAFT CO.
 PAWNEE DIVISION
 5800 E. PAWNEE
 WICHITA, KANSAS

WIRING DIAGRAM - VOLT-AMMETER (OPT)

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESSNA SPEC. NO. S-XXX OR CMXXXX-CESSNA STD. NO.

SUPERSEDES: PG. 4-20

SUPERSEDED BY:


MODEL 210 & T210 SERIES SERVICE MANUAL

E BY REV: ADD DETAIL 'A' & SER (SR914) (SR915)		HHG	JAS	REVISION		
LET	DESCRIPTION	DATE	APPD			
A	BY REV: SER OUT C292501-0101; SER IN C292501-0105 (SR7126)	ELY 2-29-71	LYW	210		
B	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	JLO 5-3-73	BY REV	210		
C	BY REV: 51360-5L WAS 51360-8L (SR8143)	GDS 5-12-76	BY REV	210		
D	BY REV: ADD DETAIL 'A' & SER & F-JAB (SR 8464)	REG 4-28-77	BY REV	210		

NOTES:

- 1 ▷ 5-1367-1-6 FOR CENTER CONDUCTOR
5-1367-2-6 FOR SHIELDING
- 2 ▷ 5-1367-1-10 FOR CENTER CONDUCTOR
5-1367-3-10 FOR SHIELDING

THRU SER 21059852
SER 21059853 & ON & ALL SPARES



WIRE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
F-JA8	20				SER (SR8464) & ON
F-JA7	183	64	1	2	
F-JA5	183	65	1	2	
F-JA9	20	7	5-1367-1-6	5-1367-1-6	
F-JA3	20	13	5-1367-1-6	5-1367-1-6	THRU SER (SR8464)

WIRE TABLE



CONTRACT NO:	NAME	DATE
4	C292501-0105	IGNITION SWITCH
3	SLICK 7662	MAGNETO (09035)
2	C292501-0101	SWITCH
1	5-1360-5L	CIRCUIT BREAKER
PART NO.	DESCRIPTION	VENDOR
EQUIPMENT TABLE		
SUPERSEDES: 12210-1073		
SUPERSEDED BY:		
PROJ	11/10/77	2-2-77
APPD		
OTHER		

DESIGN VR SIPES 1-28-71		TITLE	
GROUP W. W. W. 2-28-71		WIRING DIAGRAM - MAGNETO SYSTEM	
DRAWN VR SIPES 2-18-71		Cessna AIRCRAFT CO. COMMERCIAL AIRCRAFT DIV. 5600 E. PAWNEE WICHITA, KANSAS	
CHECK LY. WHITE 2-29-71		SIZE CODE IDENT. DWG NO	
STRESS		C 71379 1270709	
SCALE: NONE		210 PAGE: 5/1	

(SR 6755) IX
21059503

MODEL 210 & T210 SERIES SERVICE MANUAL

				REVISION			
LET	DESCRIPTION	DATE	APPD.	LET	DESCRIPTION	DATE	APPD.
G	BY REV: 5-1367-1-10 WAS 5-1493-1/JA11 (SR 9221)	PSM 1-19-79	JAS JRS	A	BY REV: SER OUT C292501-0101; SER IN C292501-0105 (SER 1216)	RLV 2-29-72	JRS
H	BY REV: 5-1367-6-13 WAS 5-1367-7-13/PA12 (NOW SHOP PRACTICE)	HHG 8-1-79	JAS JRS	B	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	JLD 8-3-79	JRS
				C	BY REV: ADD DETAIL "A" & SER 6 SECOND DIODE	RS 6-11-75	JRS
				D	BY REV: ADD DETAIL "B" (SER: 226A WAS 206A/F-JA9, 51360-5L WAS 51360-8L (SR 8143))	GDS 5-12-76	JRS
				E	BY REV: F-JAB (REF) WAS F-JAS (REF) (SR 8464)	REG 4-28-77	JRS
				F	BY REV: ADD WIRE JAH	GDS 6-6-77	JRS



ITEM NO.	PART NO.	DESCRIPTION	WIRE CODE NO.	MATERIAL	LG	TERMINALS	SERIALS
5	C292501-0106	IGNITION SWITCH					
1	5-1577-1	STARTER CONTACTOR					
3	5-1360-5L	CIRCUIT BREAKER					
2	C292501-0101	SWITCH					THRU SER (SR 8143)
7	1570043	DIODE ASSY					

ITEM NO.	PART NO.	DESCRIPTION
5	C292501-0106	IGNITION SWITCH
1	5-1577-1	STARTER CONTACTOR
3	5-1360-5L	CIRCUIT BREAKER
2	C292501-0101	SWITCH
7	1570043	DIODE ASSY

CONTRACT NO.			WIRE TABLE		
DESIGN	NAME	DATE	DESIGN	NAME	DATE
YR SIDES	YR SIDES	1-28-71	YR SIDES	YR SIDES	1-28-71
GROUP	YR SIDES	2-25-71	YR SIDES	YR SIDES	2-19-71
DRAWN	L.K. WHITE	2-24-71	YR SIDES	YR SIDES	2-24-71
CHECK					
STRESS					

EQUIPMENT TABLE	
CES-1000 IS APPLICABLE	SUPERSEDES
VENDOR CODES PER S-1400	12710-1073
CES-XXXX-CESSNA SPEC NO	SUPERSEDED BY
S-XXX OR CMXXXX-CESSNA	1270709 P 6.2
BTD. NO.	

PROJ	APPD	OTHER	SIZE	CODE IDENT NO	DWG NO
			C	71379	1270709

CESSNA AIRCRAFT CO. COMMERCIAL AIRCRAFT DIV.
8800 E. PAWNEE WICHITA KANSAS


WIRING DIAGRAM — STARTER SYSTEM

SCALE NONE 210 (P210) PAGE 6.1

(SR 6755) II (21059503)

MODEL 210 & T210 SERIES SERVICE MANUAL

REV	DESCRIPTION	DATE	APPRO
A	BY REV: ADD DETAIL A (SR9114)(SR9115)	DDH 12-9-78	<i>[Signature]</i>
B	BY REV: ADD JA12 & JA13; DELETE JA9 & JA11 (SR9221)	PSM 1-19-79	<i>[Signature]</i>
C	BY REV: S-1367-6-13 WAS S-1367-7-13/ PA29 (NOW SHOP PRACTICE)	HHG 8-1-79	<i>[Signature]</i>
D	BY REV: SER OUT JA12, JA13; ADD JA14, DETAIL B (MER P210 EO 870) (SR9634)(SR9635)	DFG 7-4-80	<i>[Signature]</i>



WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
JA-14	20			S-1367-1-6 S1367-1-10	SER(SR9634)(SR9635)(OH)
N-JA13	20			S-1367-1-6 S1367-1-10	THRU SER (SR9635)
F-JA12	20			S-1367-1-6 S1367-1-10	THRU SER (SR9634)
F-PA31	22			S-1367-1-0 S1367-1-0	
F-PA29	4	S-1862-4-9		S-2447-4 S-2447-6-13	

ITEM NO	PART NO.	DESCRIPTION
5	C292501-0106	IGNITION SWITCH
4	S-2443-1	STARTER CONTACTOR
3	S-1360-SL	CIRCUIT BREAKER

WIRE TABLE			EQUIPMENT TABLE		
CONTRACT NO:			EQUIPMENT TABLE		
DESIGN	NAME	DATE	EQUIPMENT TABLE		
GROUP	NAME	DATE	EQUIPMENT TABLE		
DRAWN	NAME	DATE	EQUIPMENT TABLE		
CHECK	NAME	DATE	EQUIPMENT TABLE		
STRESS			EQUIPMENT TABLE		
PROJ	NAME	DATE	EQUIPMENT TABLE		
APPRO	NAME	DATE	EQUIPMENT TABLE		
OTHER			EQUIPMENT TABLE		

CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-1000-CESNA SPEC. NO.
S-1000 OR CM1000-CESNA
STD. NO.

SUPERSEDES:
1270709 P 6.1
SUPERSEDED BY:

PROJ: *[Signature]* 12-28-78
APPRO: *[Signature]*
OTHER:

COMMERCIAL AIRCRAFT DIV.
CESSNA AIRCRAFT CO.
3800 E. PAWNEE
WICHITA, KANSAS

TITLE
**WIRING DIAGRAM -
STARTER SYSTEM**

SIZE: C CODE IDENT. NO. 71379 DWG NO. 1270709
SCALE: NONE SR9221 PAGE: 6.2

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION (CON'T)			
LET	DESCRIPTION	DATE	APPD
L	BY REV: ADD DETAIL "C" & SER & F-QD33 (SR8464)	REG 4-28-77	PPS


REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADDED NOTE 1	3-9-73	WJ
B	BY REV: "F" PREFIX WAS "H"; ADD F-GC21(REF), F-GC13(REF) & :250706 (NOW SHOP PRACTICE)	JLO 6-20-73	WJ
C	BY REV: S-1370-1/QD31 WAS SEE QD24, SOLDER/QD24 WAS S-1370-1 (MER E0034) (NOW SHOP PRACTICE)	JEF 2-8-74	WJ
D	BY REV: S-1856-1 WAS :250706-1 F-GC22(REF) WAS F-GC13(REF) (SR7997)	JLO 6-25-74	WJ
E	BY REV: DELETE NOTE 1; ADD NOTE 2 & 3; ADD JUMPERS AT RESISTOR AMOR-20-10	BLA 11-28-74	WJ
F	BY REV: ADD S-1637-1 & -2 TO QD24 & QD31, ALL WIRE LENGTHS; S-1635-1/QD31 & S-1636-1/QD24 WERE SOLDER NOW SHOP PRACTICE MER E0408	TMS 2-28-75	WJ
G	BY REV: REVISE NOTE 2 AND ADD DETAIL "A"	GN 7-30-75	WJ
H	BY REV: 2LM-E WAS S-1856-1; ADD DETAIL B, QD32 & SER MER 207E0436 (SR8115, SR8426)	JMS 1-14-76	WJ
J	BY REV: 20GA WAS 18GA/F-QD23 THRU F-QD32 & JUMPER WIRES (SR8143)	GDS 5-6-76	WJ
K	BY REV: S-2035-1 WAS S-1637-1; S-2035-2 WAS S-1637-2 (NOW SHOP PRACTICE) MER E0523	PH 8-27-76	WJ

NOTES:


1. PLACE YELLOW POKER SWITCH IN HIGH BOOST POSITION. ADJUST RESISTORS WITH ENGINE OFF & 27.6 VDC APPLIED TO BUS. OPEN TO FULL THROTTLE & ADJUST 1/2" RESISTOR TO PRODUCE 125 LBS/Hr INDICATION ON FUEL FLOW METER. ADJUST 2" RESISTOR WITH THROTTLE CLOSED TO PRODUCE 65 LBS/Hr INDICATION ON FUEL FLOW METER. RESISTORS ARE IN SERIES WHEN THROTTLE IS CLOSED.

▶ ADJUST AMOR-20-10 TO 3.57.5 OHMS PRIOR TO INSTALLATION


▶ READJUST RESISTANCE AS REQUIRED AFTER INSTL TO COMPLY WITH FUEL FLOW REQUIREMENTS PER CES 1243



DETAIL B
THRU SER (SR8426)



DETAIL C
THRU SER (SR8464)



DETAIL A
EFF THRU SER (SR8297)

9	S-2035-2	HOUSING
8	S-2035-1	HOUSING
7	C291504-0201	PUMP
6	AMOR20-10	RESISTOR
5	2-LM-E	SWITCH
4	S-1637-1	HOUSING
3	S-1637-2	HOUSING
2	S-1846-3-2	SWITCH
1	S-1360-5L	CXT BKR

ITEM NO	PART NO.	DESCRIPTION
EQUIPMENT TABLE		

CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX-CESBNA SPEC. NO.
S-XXX OR CMXXXX-CESBNA
STD. NO.


SUPERSEDES:
D 7.1
SUPERSEDED BY:

F-QD33	20		S-1367-1-6	S-1493-1	SER (SR8464) & ON	
F-QD32	20		60	S-1493-1	S-1635-1	SER (SR8426) & ON
F-QD31			54	S-1635-1	S-1370-1	
F-QD30			60	S-1635-1	SOLDER	
F-QD29			12	SOLDER	S-1636-1	
F-QD28			60	S-1635-1	SOLDER	
F-QD27			12	SOLDER	S-1636-1	
F-QD26			12	S-1635-1	SOLDER	
F-QD25			90	S-1493-1	S-1636-1	
F-QD24			60	S-1493-1	S-1636-1	THRU SER (SR8426)
F-QD23	20		17	S-1367-1-6	S-1493-1	THRU SER (SR8464)

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
WIRE TABLE					

CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	WIRING DIAGRAM — FUEL PUMP SYSTEM		
GROUP	W. STIPES	11-30-72			
DRAWN	PAPE	1-3-73			
CHECK	R. YOUNGERS	12-30-72			
STRESS			SIZE	CODE IDENT	DWG NO
PROJ	W. Stipes	1-3-73	C	71379	1270709
APPD	PLH		SCALE: NONE		
OTHER			Z10 PAGE 7.1.1		

MODEL 210 & T210 SERIES SERVICE MANUAL




CONTRACT NO:		COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS				
DESIGN	NAME	DATE	Cessna AIRCRAFT CO. WIRING DIAGRAM — FUEL PUMP SYSTEM			
GROUP						
DRAWN						
CHECK						
STRESS						
PROJ			SIZE	CODE IDENT NO.	DWG NO.	
APPD			C	71379	1270709	
OTHER			SCALE	NONE	210	PAGE: 7.1.1

MODEL 210 & T210 SERIES SERVICE MANUAL


NOTES:

- ▷ MATERIAL IS PRESTOLITE NO. 110691 BGA, TEFLON INSULATED CONDUCTOR
- ▷ CRIMP S-1636-5 TERMINAL AROUND WIRE INSULATION, BEND .25 OF STRIPPED WIRE BACK OVER CRIMP & SOLDER PER CES 1040. USE MOLEX HT-1921 CRIMPING TOOL ONLY

REV	DESCRIPTION	DATE	APPD
A	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	260 5-3-75	SRB 1/10
B	BY REV: (SR8065) WAS (SR7990) & (SR8311)	RAM 9-25-74	DLT 9/26/74
C	BY REV: SER OUT BROWN 1 S-1372-1, SER IN EC1 & S-1372-2, ADD DETAIL A & NOTE 2 (SR8085)	RAM 11-2-74	JCY 1/10
D	BY REV: (SR7913) WAS (SR8065) PER REV B (SR8311)	C J H 1-27-75	JCY 1/10
E	BY REV: (SR8311) WAS (SR7913) PER REV S, D & INACTIVATION (SR8311)	GS 8-27-75	JCY 1/10
F	BY REV: G-810958 WAS G-1810958 (NEW SHOP PRACTICE)	EM 11-22-76	JCY 1/10
G	BY REV: ADD 1 SER (SR 8311) THRU SER (SR 8464), PG 86 WAS PG 84 C669502-0304 WAS C669502-0301 (SR 8311)	SEB 7-29-80	JCY 1/10



INACTIVE:
EFF THRU SER (SR 8311)
& SER (SR 8311) THRU (SR 8464)
BAH JCY JRS URS PLA NMC
2-1-74



WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
BRN (EC1)	18	-18-4	66	S-1367-6 S-1696-5	SER (SR8085) & ON
BROWN	18		66	S-1367-6 S-1367-9	THRU SER (SR8085)
FEB1	18		44	S-1367-6 S-1367-8	

ITEM NO	PART NO.	DESCRIPTION	VENDOR
6	S-1372-1	BULB - CYLHD TEMP	
5	S-1637-4	HOUSING - PLUG	
4	G-810958	RESISTOR (57333)	
3	S-1372-2	BULB-CYL HEAD TEMP	
2	C669502-0304	INST CLUSTER	
1	S-1360-BL	CIRCUIT BREAKER	

WIRE TABLE

CONTRACT NO. _____

DESIGN: V R SIPS 1-28-71
 GROUP: H W 2-29-71
 DRAWN: V R SIPS 2-18-71
 CHECK: L K WHITE 2-24-71
 STRESS: _____

PROJ: N. H. 2-27-71
 APPD: JCY

OTHER: _____

COMMERCIAL AIRCRAFT DIV
 5800 E PAWNEE
 WICHITA KANSAS

Cessna AIRCRAFT CO.

TITLE: **WIRING DIAGRAM - CYLINDER HEAD TEMP**

SIZE: C
 CODE IDENT NO: 71379
 DWG NO: 1270709
 SCALE: NONE
 210 PAGE: 8.1


CES-1000 IS APPLICABLE	SUPERSEDES:
VENDOR CODES PER S-1400	12210-1073
CES-XXXX-CESSNA SPEC. NO.	SUPERSEDED BY
S-XXX OR CMXXXX-CESSNA	P B 6
STD. NO.	

(SR 6755) II (21059503)


MODEL 210 & T210 SERIES SERVICE MANUAL

H	BY REV: C664503-0101 WAS C664502-0101; ADD DFB, NOTE 1, S1637-1, 2, C664511-0101, S1360-5L, DETAIL B & PG B.2.1 (SR9080)(REF) (SR9187)	CMK 7-13-78	ADD WIRE DFB
J	BY REV: ADD DETAIL C / C664511-0102 (SR9583)	HMG 2-13-80	ADD WIRE DFB
K	BY REV: ADD DETAIL D; S2527-2, S2527-1, BLK(FN-DF9), BLK(F-DC13)(REF) WAS BLK(F-DC11)(REF) BLK(F-DC12)(REF) WAS DC3(REF) (SR1010)(SR1002)	MKT 1-27-82	ADD WIRE DFB
L	BY REV: S1367-1B/DF1, DF3, DFB, DF7, DFB WAS S1367-1G (NOW SHOP PRACTICE)(MER: S2E0967)	GW 7-8-82	ADD WIRE DFB

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	DLO 5-3-73	BY REV
B	BY REV: C664502-0101 WAS C664501-0103 ADD S-2023-1 (SR 7913)(REF)	2-10-76 GDS	BY REV
C	BY REV: 22 GA WAS 20GA/F-DF1, F-DF3 F-DF4 (SR8143)	GDS 5-6-76	BY REV
D	BY REV: RED (F-DF5) WAS F-DF5 (SR8656)	PH 9-21-76	BY REV
E	BY REV: ADD RED(F-DF5), F-DF6 & DETAIL A & SER (SR8464)	GLR 4-18-77	BY REV
F	BY REV: ADD PCB REF (SR8465)	GDS 6-6-77	BY REV
G	BY REV ADD DF7 & SER. SER OUT DF1 (SR8464)(REF)(SR8465)(REF)	DLP 12-9-77	BY REV



NOTES:
 1. READ ONLY WHEN OPT DIGITAL CLOCK C664511 IS INSTALLED



15	S2527-2	GND CONNECTOR	22	-22-0	S1493-1	S2099-4	SER(SR1010)(SR1002) ON
14	C664511-0102	DIGITAL CLOCK	22	-22-2	S1367-1B	S1436-2	
13	S-1360-5L	CIRCUIT BREAKER	F-DF7	22	S1367-1-B	S1367-1-B	SER(SR8464)(SR8465) ON
12	C664511-0101	DIGITAL CLOCK	F-DF6	22	S1493-1	S1367-1-B	THRU SER(SR8464)
11	S-1637-2	HOUSING	F-DF3	22	S1367-1-B	S1493-1	SER(SR8464) ON
10	S-1637-1	HOUSING	F-DF4	22	S-1493-1	S-1367-1-B	THRU SER(SR8464)
9	C664508-0101	CLOCK	22	-22-2	50	S-1367-1-B	THRU SER(SR8464)
8	S-2023-1	ADAPTOR	F-DF1	22	80	SOLDER	THRU SER(SR8464)
7	C664503001	HOURLMETER	GA	MATERIAL	LG	TERMINALS	SERIALS
6	0770728-1	DIODE ASSY					
5	S-1711-1	OIL PRESS. SWITCH					
4	S-1580-1	BATTERY CONTACTOR					
3	S-2527-1	LN GND BLOCK					
2	S-1081-1	FUSE					
1	S-1090-22	FUSEHOLDER					

WIRE TABLE

CONTRACT NO:		
DESIGN	NAME	DATE
GROUP		
DRAWN		
CHECK		
STRESS		
PROJ		
APPD		
OTHER		

COMMERCIAL AIRCRAFT DIV.
 3800 E. PAWNEE
 WICHITA, KANSAS


Cessna AIRCRAFT CO.
 TITLE
**WIRING DIAGRAM —
 HOURMETER (OPT)**

PART NO.	DESCRIPTION
EQUIPMENT TABLE	


SIZE	CODE IDENT. NO.	DWG NO.
C	71379	1270709
SCALE: NONE	210 P210	PAGE: 8.2.0

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
K	SEE PG 8.2.0 FOR REVISION		



DETAIL 13
(REQD WHEN OPT DIGITAL CLOCK IS INSTALLED)



DETAIL C
THRU SER(SR9583)

CONTRACT NO:		PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS	
DESIGN	G STAMM	DATE	7-21-78
GROUP	J.P. Smith	DATE	7-24-78
DRAWN	C KING	DATE	7-13-78
CHECK	BORLESKE	DATE	7-14-78
STRESS			
PROJ	J.P. Smith	DATE	8-1-78
APPD		SIZE	C
OTHER		CODE IDENT NO.	71379
		DWG NO.	1270709
		SCALE	NONE (SR9187)
		PAGE	8 2.1


07-00916
07-00916

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES

- 1 S-1367-1-6 TERMINAL ON EXISTING WIRE
- 2 THIS WIRING DIAGRAM FOR CIRCUIT REFERENCE USE ONLY. ALL WIRES SHOWN ARE VENDOR SUPPLIED AS PART OF A GAGE INSTL KIT.

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: RED LG GS WAS 2.5 (NOW SHOP PRACTICE)	JLO 5-3-73	JLO
B	BY REV: (SR8065) WAS (SR7650) PER INACTIVATION (SR7913)	RAM 9-25-74	RAM
C	BY REV: (SR7913) WAS (SR8065) PER REV "B" INACTIVATION (SR7913)	C J H 1-27-75	C J H
D	BY REV: (SR8311) WAS (SR7913) PER REV "B", "C" & INACTIVATION (SR8311)	GS 8-27-75	GS
E	BY REV: REACTIVATE DWG & INACTIVATE DWG (SR8311)(REF) (SR8464)	GLE 4-21-77	GLE
F	BY REV: DWG WAS INACT. THRU SER (SR 8464); ADD DETAIL "A", PG 8.5 WAS PG 8.4; C669502-0304 WAS C669502-0301 (SR 8311)	SEB 7-29-80	SEB



QTY	PART NO.	DESCRIPTION	VENDOR	PROJ	APPO	OTHER	SIZE	CODE IDENT. NO.	DWG NO
9	2381	CABLE ASSY	(05808)						
8	C669502-0304	INST CLUSTER		RED	1B	-1B-2	GS	S-1367-1-6-1370-1	
7	C668003-0101	RANGE & CABLE ASSY							
6	C668004-0101	MONITOR - FUEL							
5	C668003-0102	SENSOR - INBD							
4	C668003-0101	SENSOR - OUTBD							
3	S-1638-2	HOUSING - CAP							
2	S-1638-1	HOUSING - PLUG							
1	S-1360-8L	CIRCUIT BREAKER							

EQUIPMENT TABLE		WIRE TABLE	
PART NO.	DESCRIPTION	CONTRACT NO.	COMMERCIAL AIRCRAFT DIV.
			Cessna AIRCRAFT CO.
			3800 E. PAWNEE
			WICHITA, KANSAS
		DESIGN	V R Sipes 1-28-71
		GROUP	H. W. Lind 2-26-71
		DRAWN	V R Sipes 2/18/71
		CHECK	L.K. WHITE 2-24-71
		STRESS	
		PROJ	H. W. Lind 2-27-71
		APPO	
		OTHER	
SUPERSEDES: 12210-1073		SIZE	C
SUPERSEDED BY: P. 85		CODE IDENT. NO.	71379
		DWG NO	1270709
		SCALE: NONE	210
		PAGE: 8.3	

(SR 6755) II (21059503)

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

- 1. CRIMP S1636-5 TERMINAL AROUND WIRE INSULATION, BEND .25 OF STRIPPED WIRE BACK OVER CRIMP AND SOLDER PER CES 1040. USE MOLEX HT-1921 CRIMPING TOOL ONLY
- 2. MATERIAL IS ALPHA 5857-7 (VENDOR CODE 92194) OR BELDEN 83009-1 (VENDOR CODE 70903)

INACTIVE
EFF THRU (SRB311)
GLR/MLK 4-21-77
Jey
Z

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: (SRB045) WAS (SR7630) (SRB311)	RAM 9-25-74	RAM
B	BY REV: (SR7913) WAS (SR8065) PER REV 'A' (SRB311)	C J H 1-27-75	C J H
C	BY REV: (SRB311) WAS (SR7913) PER REV 'A', 'B' & DWG SER; OBSOLETE NEVER USED EB10, EB11, EB12, EB9; S-2252-2 S-2251-1 & S-2253-1 WERE C669520-(O103, O104 & O105) RESPECTIVELY; S1636-5 WAS S1367-1-6; ADD NOTE 1 (SRB311)	GS 8-27-75	GS
D	BY REV: REVERSE S-1638-1 & 2; S-1638-1 / EBB, EBA, EBA EBB WAS S-1638-1; DELETE K4 (REV) MER 210-80476 (SRB311)	DLP 11-8-75	DLP
E	BY REV: ADD NOTE 2 (NOW SHOP PRACTICE)	1-29-76 GDS	GDS
F	BY REV: ADD EB15 (EB16 DETAIL 'A') (SER; 226A WAS 206A/EB3 THRU EBB, ED1, BRN(EB4), EE1; S-1367-1-6 WAS S-1367-2-6, S-1635-1 WAS S-1636-1; ADD S-1360-5L (SRB143)	GDS 5-6-76	GDS
G	BY REV: DELETE DETAIL 'A'; OBS. NEVER USED EB-15 (EB-16); EB-13 WAS EB-15. EB-2 WAS EB-16; SUP. BY WAS P.B. & B. (SRB311)	EEB 7-29-80	EEB

EB16	22		S-1636-1	S-1367-1-6	OBSOLETE NEVER USED
EB15	22		S-1636-1	S-1367-1-6	OBSOLETE NEVER USED
EE1	22		S-1635-1	S-1367-1-10	
ED1	22	2	S-1635-1	S-1367-1-10	
EB13	20		S-1635-3	S-1636-1	
EB12	20		S-1636-1	S-1367-1-6	OBSOLETE NEVER USED
EB11	20		S-1636-1	S-1367-1-6	OBSOLETE NEVER USED
EB10	20		S-1635-1	S-1367-1-10	OBSOLETE NEVER USED
EB9	20		S-1635-1	S-1367-1-10	OBSOLETE NEVER USED
EB8	22		S-1635-1	S-1367-1-10	
EB7	1		S-1635-1	S-1367-1-10	
EB6	1		S-1635-1	S-1367-1-10	
EB5	1		S-1635-1	S-1367-1-10	
EB4	1		S-1635-1	S-1367-1-10	
EB3	22		S-1635-1	S-1367-1-10	
EB2	20		SEE EB13	S-1636-1	
EJ2	18		S-1635-1	S-1367-1-6	
EJ1	20		S-1367-1-6	S-1635-1	

15	S-1360-5L	CIRCUIT BREAKER
14	C668003-0101	FUEL XMTR
13	C668003-0102	FUEL XMTR
12	S-1641-6	HOUSING
11	S-1640-6	HOUSING
10	S-1641-9	HOUSING
9	S-1638-1	HOUSING
8	S-1638-2	HOUSING
7	C669520-0110	ELECTRONICS UNIT
6	S-2252-2	CYL HD TEMP PROBE
5	S-2251-1	OIL PRESS SENDER
4	S-2253-1	OIL TEMP PROBE
3	S-1360-8L	CIRCUIT BREAKER
2	S-1640-9	HOUSING
1	C669520-0102	INST CLUSTER

WIRE TABLE

CONTRACT NO: _____

DESIGN: _____ NAME: _____ DATE: _____

GROUP: *SRB* 2-4-74

DRAWN: *B. HARRISON* 1-30-74

CHECK: *YOUEL* 2-4-74

STRESS: _____

PROJ: *Instrument* 3-19-74

APPD: *PLP*

OTHER: _____

SCALE: NONE

SIZE: **C** CODE IDENT NO: **71379** DWG NO: **1270709**

COMMERCIAL AIRCRAFT DIV.
5800 E. PAWNEE
WICHITA, KANSAS

Cessna AIRCRAFT CO.

TITLE: **WIRING DIAGRAM - INSTRUMENT CLUSTER**


210 PAGE: 3.4

PART NO.	DESCRIPTION
EQUIPMENT TABLE	

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESSNA SPEC. NO. S-XXX OR CMXXXX-CESSNA STD. NO.

SUPERSEDES: P.B.1, 10.2, B.3
SUPERSEDED BY: PG B.1, 10.2, B.3

MODEL 210 & T210 SERIES SERVICE MANUAL



CONTRACT NO:			WIRE TABLE		
			COMMERCIAL AIRCRAFT DIV. 8800 E. FAWCETT WICHITA, KANSAS		
			CSSDA AIRCRAFT CO.		
DESIGN	NAME	DATE	TITLE		
GROUP	IR5	2-9-74	WIRING DIAGRAM — INSTRUMENT CLUSTER		
DRAWN	S. HARRISON	1-30-74			
CHECK	Y. UEL	2-4-74			
STRESS					
PROJ	M. Carter	2-14-74	SIZE	CODE IDENT. NO.	DWG NO.
APPD	PLP		C	71379	1270709
OTHER			SCALE: NONE		ZIO PAGE: 8.4

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

COVER S-493-1 TERMINAL WITH S-1694 6-10 HEAT SHRINK TUBING. TERMINAL DESIGNATIONS (OR SL I) TO BE STAMPED ON TUBING WITH WHITE INK.

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD S-2349(-1 & -2), S-2350(-1 & -2), WIRES EB 22, EB 23, YEL (EB 24 & YEL (EB 25) (SR8464)	GDS 6 6 77	JAS/mt
B	BY REV: S-2099-7 WAS 60331-5/YEL (EB 24 EB 25), S-2353-2 HAS 60332-5/EB 22 & EB 23 (SR8464)(SR8465)	JJB 8 29 77	JAB UH
C	BY REV: ADD BLACK (EB 26); S 2376 1 WAS S 493 1 (SR8464) REF, (SR8465) PLF,	CRS DLF 11 30 77	JAS UH 9/25
D	BY REV: ADD DETAIL A: SER, EB 27, EB 28, 205841-1, 205838-1 (SR9427)	CS 4-10-78	AD UH
E	BY REV: ADD EB 29 & EB 30 (NOW SHOP PRACT)	TFS 8-16-78	AP
F	BY REV: (SR9427) WWS (SR8866) / REV D; DETAIL "A", EB 22, EB 24, EB 26 & EB 27 (SR9427)	GDA 10 4 78	JAS UH
G	BY REV: PG 8 3 WAS PG 8.4 (NOW SHOP PRACTICE) BY REV: ADD 78.5: (EB 51, EB 52, EB 53 EB 34 & EB 35, NOTE D, & DETAILS BIC & SER (SR9742)	NAG 1-19-80	NOR UH

INACTIVE
EFF THRU SER (SR10148)
GW 3581
MB 1/11/80 / RB

EB 35	Z0		S-1367-1-B	S-1493-1	1	SER (SR9742) (CN)
EB 54	Z0		S-1493-1	S-1636-1	1	
EB 53	Z0		S-1493-1	S-1636-1	1	
EB 52	Z0		S-1493-1	S-2415-1	1	
EB 31	Z0		S-1493-1	S-2353-2	1	SER (SR 9742) (CN)
YEL (EB 30)	Z2		S-1367-1-B	S-1367-1-10		
YEL (EB 27)	Z0	-22-4	S-1367-1-10	S-2341-1		SER (SR9427) (CN)
EB 28	Z0		S-1367-1-10	S-2415-1		SER (SR 9427) THRU SER (SR 7742)
YEL (EB 24)	Z2	-22-0	S-1367-1-B	S-1367-1-B		
YEL (EB 24)	Z0	-20-4	S-2099-7	S-1367-1-10		
YEL (EB 24)	Z0	-20-4	S-2099-7	S-1367-1-10		THRU SER (SR 9427)
EB 23	Z0		S-2376-1	S-2353-2		THRU SER (SR 9742)
EB 22	Z0		S-2376-1	S-2353-2		THRU SER (SR 9427)
YEL (EB 21)	Z0	-20-4	S-1635-1	S-1367-1-10		
YEL (EB 20)	Z0	-20-4	S-1635-1	S-1367-1-10		
EB 19	Z0		S-2376-1	S-1636-1		THRU SER (SR 9742)
EB 18	Z0		S-2376-1	S-1636-1		THRU SER (SR 9742)
EB 17	Z2		S-1367-1-B	S-2376-1		THRU SER (SR 9742)

13	205-41-1	CONNECTOR
12	205-38-1	CONNECTOR
11	S-2343-2	HOUSING
10	S-2350-2	HOUSING
9	S-2349-1	CONNECTOR
8	S-2350-1	CONNECTOR
7	S-5164	CONNECTOR
6	S-493-1	AMTR
5	S-1636-1	AMTR
4	S-1641-1	HOUSING
3	S-1640-1	HOUSING
2	S-4150-1	NST CLUSTER
1	S-1522 SL	CIRCUIT BREAKER

ITEM NO	PART NO.	DESCRIPTION
EQUIPMENT TABLE		


CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX-CESSNA SPEC. NO.
S-XXX OR CMXXXX-CESSNA
STD. NO.

SUPERSEDES
Pg 8 3



SUPERSEDED BY:
Pg 8.50 & 8.81

CONTRACT NO:			WIRE TABLE	
DESIGN	NAME	DATE	SIZE	CODE IDENT. NO.
			C	71379
GROUP	W. H. RYAN	4-21-77		
DRAWN	GL RYAN	4-21-77		
CHECK	J. YOUNG	4-22-77		
STRESS				
PROJ	W. H. RYAN	4-21-77		
APPD				
OTHER				
Cessna AIRCRAFT CO. PAWNEE DIVISION 5800 E PAWNEE WICHITA, KANSAS			DWG NO 1270709	
TITLE WIRING DIAGRAM - FUEL GAUGES			SCALE: NONE 210 = 210 PAGE: 85.0	

MODEL 210 & T210 SERIES SERVICE MANUAL



(APPLIES TO P210 ONLY)




DETAIL A
THRU SER(SA9427)


CONTRACT NO:		Cessna AIRCRAFT CO.		PAWNEE DIVISION 9000 E. PAWNEE WICHITA, KANSAS	
DESIGN	WHITSON	DATE	4-22-77	TITLE	
GROUP	<i>W. H. ...</i>	DATE	4-21-77	WIRING DIAGRAM --	
DRAWN	GL RYAN	DATE	4-21-77	FUEL GAUGES	
CHECK	J YOUNG	DATE	4-22-77		
STRESS					
PROJ	PLAEDRICK	DATE	4-21-77	SIZE	CODE IDENT.
APPO				C	71379
OTHER				DWG NO	1270709
SCALE: NONE		210 P210		PAGE: 8.5	

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION		
LET	DESCRIPTION	DATE
G	SEE PAGE 8-S.0 FOR REVISIONS	



DETAIL B RE 8.5
THRU SER (SR 9742)



DETAIL C RE 8.5
THRU SER (SR 9742)

INACTIVE
EFF THRU SER (10148)
DW 8-5-81
MD 4/14/81


CONTRACT NO:			Cessna AIRCRAFT CO.			PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	TITLE WIRING DIAGRAM - FUEL GAUGES					
GROUP	W. H. Anderson	3-1-80						
DRAWN	W. E. EDINGS	1-23-80						
CHECK	MD RANDALL	1-23-80						
STRESS								
PROJ	20002A	3-10-80	SIZE	CODE IDENT.	DWG NO			
APPD	JR		C	71379	1270709			
OTHER			SCALE: NONE		Z10 / P210		PAGE: 8-S.1	

MODEL 210 & T210 SERIES SERVICE MANUAL


NOTES:

- 1. MATERIAL IS ALPHA 5857-7 OR BELDEN 83009-1
- 2. CRIMP S-1636-5 TERMINAL AROUND WIRE INSULATION. BEND .25 OF STRIPPED WIRE BACK OVER CRIMP & SOLDER PER CES1040. USE MOLEX HT-1921 CRIMPING TOOL ONLY
- 3. MATERIAL IS ALPHA 5857-6 (VENDOR CODE 92194) OR BELDEN 83009-6 (VENDOR CODE 70903)


REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD EC3 & EE4/P210 (SR8464)	DLP 6-6-77	JAS
B	BY REV S-2376-1 WAS S-1493-1 (SR8464)(REF) (SR8465)(REF)	DLP 12-9-77	JAS
C	BY REV: ADD DETAIL A SER EES, EE6, & NOTE 3 (SR8785)(SR8784)	MLS 8-10-78	JAS
D	BY REV: ADD DETAIL B' & SER (SR9114)(SR9115)	HMG 2-12-79	JAS
E	BY REV: PG B.1 WAS PG B.4 NOW SHOP PRACTICE	SEB 7-29-80	JAS



DETAIL B3
THRU SER (SR9114)(SR9115)



DETAIL A1
THRU SER (SR8784)(SR8785)



INACTIVE
EFF THRU (SR9711)
11-7-79
JAS

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
BLU (EE5)	18		S-2376-1	S-1367-1-10	SER (SR8784) - ON
BLU (EE6)	18		S-2376-1	S-1367-1-10	SER (SR8785) - ON
BRN (EC3)	18		S-2376-1	S-1636-5	
BRN (EE4)	18		S-2376-1	S-1367-1-10	THRU SER (SR8785)
EES	22		S-1367-1-6	S-2376-1	
BRN (EC2)	18		S-2376-1	S-1636-5	
BRN (EE2)	18		S-2376-1	S-1367-1-10	THRU SER (SR8784)

ITEM NO.	PART NO.	DESCRIPTION
6	S-1637-4	HOUSING
5	2965164	CONNECTOR
4	S-1372-4	XMTR
3	S-1630-5	XMTR
2	C669526-0101	INST CLUSTER
1	S-1360-5L	CIRCUIT BREAKER

EQUIPMENT TABLE

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESBNA SPEC. NO. S-1001 OR CM1000-CESBNA STD. NO.

SUPERSEDES:
PG B.1
SUPERSEDED BY:
PG B.7

CONTRACT NO:		
NAME	DATE	TITLE
DESIGN	NH ITSON 4-22-77	WIRING DIAGRAM - OIL TEMP & CYL HEAD TEMP
GROUP	W.D. Haslam (4-21-77)	
DRAWN	G.L. RYAN 4-21-77	
CHECK	J. YOUNG 4-22-77	
STRESS		
PROJ	PLH REDICIL 4-26-77	SIZE
APPD	RL	CODE IDENT. NO.
OTHER		DWG NO

Cessna AIRCRAFT CO.
PAWNEE DIVISION
5800 E. PAWNEE
WICHITA, KANSAS


SCALE: NONE
210 P210 | PAGE: B.6
(SR8464)

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES

- 1 MATERIAL IS ALPHA 9857-7 OR BELDEN 83009-1
- 2 CRIMP S-1636-B TERMINAL AROUND WIRE INSULATION. BEND 25 OF STRIPPED WIRE BACK OVER CRIMP & SOLDER PER CES1040. USE MOLEX MT-1921 CRIMPING TOOL ONLY
- 3 MATERIAL IS ALPHA 9857-6 (VENDOR CODE 9294) OR BELDEN 83009-6 (VENDOR CODE 70903)

REVISION			
LET	DESCRIPTION	DATE	APPD



INACTIVE

THE DATA IN THIS MANUAL IS OBSOLETE
 DATE 11-9-79 BY 718
 718

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
BLU (EE9)	18			S-1367-10 S-1367-1-10	
BLU (EE10)	18			S-1367-10 S-1367-1-10	
EE8	22			S-1367-10 S-1367-1-10	
EE7	22			S-1367-1-6 S-1367-1-10	
BRN (EC5)	18			S-1367-10 S-1636-B	
BRN (EC4)	18			S-1367-1-10 S-1636-B	

ITEM NO	PART NO.	DESCRIPTION
5	S-1637-4	HOUSING
4	S-2334-4	AMTR
3	S-2335-1	XMTR
2	S-1561-2102	INST CLUSTER
1	S-1360-5L	CIRCUIT BREAKER

WIRE TABLE		
CONTRACT NO:	NAME	DATE
	J. H. TJADEN	11-8-79
DESIGN	J. H. TJADEN	11-8-79
GROUP	J. H. TJADEN	11-8-79
DRAWN	J. H. TJADEN	11-8-79
CHECK	BORLESKE	12-8-79
STRESS		

CES-1000 IS APPLICABLE
 VENDOR CODES PER S-1400
 CES-XXXX-CESSNA SPEC. NO.
 S-XXX OR CMXXXX-CESSNA
 STD. NO.

SUPERSEDED BY:
 PG 8.10

PHOU
 APPD
 OTHER

CESSNA AIRCRAFT CO. PAWNEE DIVISION
 1800 E. PAWNEE WICHITA, KANSAS
WIRING DIAGRAM —
OIL TEMP & CYL HEAD TEMP
 SIZE CODE IDENT. DWG NO
C 71379 1270709
 SCALE: NONE 2 OF 210 PAGE: 7.7
 (SR9711)

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD DETAIL "A", BLK (EB42), ADD S2527-1-2 (SR10101)(SR10102)	MKT 1-27-82	JAB (MKT) 1/23 J

07-88818

ITEM NO.	PART NO.	DESCRIPTION	QUANTITY	MATERIAL	LG	TERMINALS	SERIALS
	BLK(EB42)	20 -20-0		S1367-1-6	S2099-9		SER(SR10101)(SR10102)(ON)
	EB41	20		S1367-1-10	S1367-1-10		
	EB40	20		S1367-1-10	S1636-1		
	EB39	20		S1367-1-10	S1636-1		
	EB38	20		S1367-1-10	S2415-1		
	EB37	20		S1367-1-10	S2353-2		
	EB36	20		S1367-1-6	S1367-1-10		
	BLK(EB30)	22 -22-0		S1367-1-8	S1367-1-10		
	BLK(EB29)	22 -22-0		S1367-1-8	S1367-1-10		
	YEL(EB27)	20 -20-4		S2341-1	S1367-1-10		
	BLK(EB26)	22 -22-0		S1367-1-8	S1367-1-8		THRU SER(SR10101)(SR10102)
	YEL(EB25)	20 -20-4		S2099-7	S1367-1-10		
	YEL(EB21)	20 -20-4		S1635-1	S1367-1-10		
	YEL(EB20)	20 -20-4		S1635-1	S1367-1-10		
	CG68050-0602	RH SENDING UNIT					
	CG68050-0601	LH SENDING UNIT					
	S1641-6	CONNECTOR					
	S1640-6	CONNECTOR					
	CG69562	INST CLUSTER					
	S1360-5L	CIRCUIT BREAKER					

EQUIPMENT TABLE		WIRE TABLE		TITLE	
CONTRACT NO:		NAME	DATE	PAWNEE DIVISION 1800 E. PAWNEE WICHITA, KANSAS	
DESIGN					
GROUP					
DRAWN	WHITSON	2-5-81			
CHECK	BORLESKE	3-6-81		WIRING DIAGRAM - FUEL GAGES	
STRESS				SIZE: C CODE IDENT: 71379 DWG NO: 1270709	
PROJ	LR	3-6-81		(SR10148) PAGE: 8.8.0	
APPD	JWA				
OTHER					

CES-1000 IS APPLICABLE
 VENDOR CODES PER S-1400
 CES-1000-CESMA SPEC. NO.
 S-1001 OR C10000-CESMA
 STD. NO.


SUPERSEDES:
 1270709 PGS 8.50 & 8.5.1
 SUPERSEDED BY:

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

TERMINATE 22 GA JUMPER WITH S-1636-1

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD JUMPER WIRE (NOTE 1; S-1370-1 WAS S-1636-1 / BLK (DC17) (SR9953)(REF)(SR9954) (REF)(MER210E0977) ADD S-2527-1&S-2527-2; SER IN BLK (DC21) SER OUT BLK (DC18) (SR10101) (SR10102)	CLS 1-27-82	JAS JAS JAS



DETAIL A
THRU SER (SR10101) (SR10102)

91600-20
91600-10

ITEM NO	PART NO.	DESCRIPTION
14	S-2527-2	GND CONNECTOR
13	S-2527-1	LH GND BLOCK
12	C913001	FLOW TRANSDUCER
11	C662060	INDICATOR
10	S-641-6	HOUSING
9	S-1640-6	HOUSING
8	S2475-1	BATT. CONTACTOR
7	070728	DIODE ASSY
6	S1090-22	FUSE HOLDER
5	S1091-1	FUSE
4	S1637-1	HOUSING
3	S1637-2	HOUSING
2	34004-818	TERMINAL BLOCK
1	S1360-5L	CIRCUIT BREAKER

WIRE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
BLK (DC21)	22	-22-0		SEE BLK (17) S2099-4	SER (SR10101) (SR10102) & CN
BLK (DC18)	22	-22-0		SEE BLK (17) S1367-1 B	THRU SER (SR10101) (SR10102)
BLK (DC17)	22	-22-0		S1370-1 S1370-1	
BLK (DC16)	22S	S1461-22-9		S1636-1 S1370-1	
RED (DC15)	22	-22-2		S1636-1 S1370-1	
RED/WHT (DC14)	22	-22-2-9		S1636-1 S1636-1	
YEL (DC13)	22	-22-4		S1636-1 S1829-1	
RED/GRN (DC12)	22	-22-2-5		S1367-1 G S1636-1	

WIRE TABLE

CONTRACT NO:	
DESIGN	NAME DATE
GROUP	W.H. HANCOCK 4-30-81
DRAWN	WHITSON 4-28-81
CHECK	REHAR 4-28-81
STRESS	
PROJ	REHAR 4-30-81
APPRO	
OTHER	

Cessna AIRCRAFT CO. PAWNEE DIVISION
3800 E. PAWNEE WICHITA, KANSAS

TITLE
WIRING DIAGRAM -- FUEL TOTALIZER/CLOCK (OPT)



SIZE CODE IDENT. NO. DWG NO
C 71379 1270709

OTHER NONE (SR9953)(SR9954) PAGE: 8,9


EQUIPMENT TABLE	
PART NO.	DESCRIPTION
SUPERSEDES:	
SUPERSEDED BY:	

CESS-1000 IS APPLICABLE VENDOR CODES PER S-1400 CESS-XXXX-CESSNA SPEC. NO. S-XX OR CMXXXX-CESSNA STD. NO.

MODEL 210 & T210 SERIES SERVICE MANUAL



DETAIL A
THRU SER (SR 8464)



DETAIL B
THRU SER (SR 1010) (SR 1012)

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD WIRE LENGTHS (NOW SHOD PRACTICE)	2LO 5-3-73	211 W 11/11
B	BY REV: 22 GA WAS 20/ FA3, FA4 (SR 8143)	GDS 5-6-76	SRB 1/13
C	BY REV: ADD DETAIL A & SER & FA5 (SR 8464)	REG 4-28-77	SRB 1/13
D	BY REV: ADD DETAIL B S2527 (1.5.2) BLK (FN-FA6) SER OUT FA4 (SR 1010) (SR 1012)	MKT 1-27-82	SRB 1/13

9/600-10
02-009/6

WIRE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
FA5	22				
FA4	22		20		
FA3	22		16		

EQUIPMENT TABLE		WIRE TABLE	
5	52527-2	GND CONNECTOR	
4	52527-1	LH GND BLOCK	
3	6661003-050	TURN COORDINATOR	
2	M5306A105L3	CONNECTOR	
1	5-1360-5L	CIRCUIT BREAKER	

CONTRACT NO:		COMMERCIAL AIRCRAFT DIV. CESSNA AIRCRAFT CO. 3800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE
GROUP	H. WILSON	2-18-71	WIRING DIAGRAM - TURN COORDINATOR
DRAWN	V.R. SIPES	2-18-71	
CHECK	L.K. WHITE	2-24-71	
STRESS			
PROJ	N. McCanta	2-27-71	SIZE
APPD	WRB		CODE IDENT. NO.
OTHER			DWG NO.
			C 71379
			1270709
			SCALE: NONE
			210
			PAGE: 9.2

CESS-1000 IS APPLICABLE
VENDOR CODES PER S-400
CESS-KXXX-CESSNA SPEC. NO.
S-XXX OR CMXXX-CESSNA
STD. NO.

SUPERSEDES:
12210-1073

SUPERSEDED BY:


(SR 6755) IX (21059503)

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

1. FOR WIRE & WIRE TERMINALS REFER TO 157000 PAGE 9.2
2. CONNECT TRANSPONDER AND ENCODING ALTIMETER TO NO. 4 RADIO CIRCUIT BREAKER.
3. TRANSPONDER CONNECTOR HOUSING IS PART OF TRANSPONDER CABLE ASSY
4. FOR WIRING DIAGRAM OF 300 & 400 TRANSPONDER REFER TO 3920143
5. PINS ARE CRIMP TYPE (ARE FURNISHED BY VENDOR WITH CONNECTOR

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: REVISED NOTE 2; (SR 7922) WAS (SR 7962). ADD 1570312-1 (SR 7922)	M.E.M. 3-5-74	DLO PWA C.A.
B	BY REV: ADD WIRE TABLE (NOTE 5); 1570312 WAS 1570312-1; DELETE NOTE 1 (SR 7922) (REF)	605 6-18-76	PWA C.A.



INACTIVE:
 EFF THRU SER (SR8464)
 DLP 10/15 2
 JAS 1/15 2W

WIRE CODE NO.	MATERIAL	LG	TERMINALS	SERIALS
RED/WHT 20	20-2-9	60	5-1367-1-8	5
BLK/YEL 22	22-0-4	60	5-1367-1-8	
BLK/BLU	22-0-6	43	5-2190-1	
GRY/BLK	22-8-0			
GRY/RED	22-8-2			
GRY/YEL	22-8-4			
GRY/GRN	22-8-5			
GRY/BLU	22-8-6			
GRY/TAN	22-8-10			
TAN/YEL	22-10-4			
TAN/RED	22-10-2			
TAN/BLU	22-10-6			
TAN/WHT 22	22-10-9	43	5-2190-1	5

PART NO.	DESCRIPTION
7 1570312	CABLE ASSY
6 EA-401A	ALT DIGITIZER
5 RT-359A	TRANSPONDER
4 RT-459A	TRANSPONDER
3 S-2189-1	CONNECTOR
2 42816	CONNECTOR
1 S-1360-SL	CKT BKR

CONTRACT NO:			COMMERCIAL AIRCRAFT DIV 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	Cessna AIRCRAFT CO.	
GROUP	H. W. W.	9-25-73	WIRING DIAGRAM — ENCODING ALTIMETER	
DRAWN	MERRICK	9-29-73		
CHECK	J. YOWEL	9-24-73		
STRESS				
PROJ	W. H. W.	1-26-73	SIZE	CODE IDENT.
APPO	PWA		C	71379
OTHER			DWG NO	1270709
			SCALE: NONE	(SR 7922) PAGE: 3.2


CES-1000 IS APPLICABLE
 VENDOR CODES PER S-1400
 CES-XXXX-CESBNA SPEC. NO.
 S-XXX OR CMXXX-CESBNA
 STD. NO.

SUPERSEDES:
 SUPERSEDED BY:
 3920220

MODEL 210 & T210 SERIES SERVICE MANUAL



NOTES:

1 CAUTION: POWER WIRE MUST BE CONNECTED TO "BATT" TERMINAL OF CLOCK OTHERWISE INTERNAL DAMAGE TO UNIT WILL RESULT



DETAIL A
THRU SER (SR9195)

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	DLO 5-3-75	WJW
B	BY REV: 22 GA WAS 20/ F-DC3, F-DC4 F-DC5 (SR8143)	GDS 5-6-76	SWAN
C	BY REV: ADD P210 (SR8465)	DLP 6-6-77	JAS
D	BY REV: ADD NOTE 1, RED (F-DC7), RED F-DC8, S-1637-1, -2 & DETAIL A; SER OUT F-DC6; C664508-0102 WAS C664508-0101 (SR9195)	BGK CMK 7-13-78	JAS
E	BY REV: ADD DETAIL B - BLK (F-DC19), S2527(-14-2); SER OUT F-DC3 F-PA35 (REF) WAS F-PA15 (REF), S-2475-J WAS S-1580-1. (NOW SHOP PRACT) (SR10101) (SR10102)	MKT 1-27-82	JAS



DETAIL B
THRU SER (SR10101) (SR10102)

02 00916
01-00216

PART NO.	DESCRIPTION
9	S-2527-2 GND CONNECTION
8	S-2527-1 LH GND BLD'G
7	S-1637-1 HOUSING
6	S-1637-2 HOUSING
5	S-2475-1 BATTERY CONTACTOR
4	C664508-0102 CLOCK
3	S-1091-1 FUSE
2	S-1090-22 FUSE HOLDER
1	0770728 DIODE ASSY

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
F-DC6	22	-22-0	64	SOLDER S-1367-16	THRU SER (SR9195) (ON)
F-DC7	22	-22-2	18	SOLDER S-1367-16	THRU SER (SR9195) (ON)
F-DC4	22	-22-5	6	SOLDER S-1367-16	THRU SER (SR9195) (ON)
F-DC3	22	-22-2	18	SOLDER S-1367-16	THRU SER (SR9195) (ON)

EQUIPMENT TABLE	
PART NO.	DESCRIPTION
12210-1073	SUPERSEDED BY:


WIRE TABLE		
CONTRACT NO.	NAME	DATE
Cessna AIRCRAFT CO.		
DESIGN	VR SIPES	1-28-71
GROUP	H Wier	2-26-71
DRAWN	VR SIPES	2-18-71
CHECK	LK WHITE	2-24-71
STRESS		
PROJ	J. Miller	6-27-71
APPD	JAS	
OTHER		
SIZE	CODE IDENT. NO.	DWG NO.
C	71379	1270709
SCALE: NONE	210 P210	PAGE: 10.1

(SR6755) 2

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: ADD DAG / P210 (SR8465)	6-6-77	JAS [Signature]

INACTIVE
 T1ARU SER (SR 9221)
 DDW - 12-9-78
 JAS with [Signature]



DAG	B	5-1562-8-9	5-1367-4-10	5-1367-4-13	
DAS	B	5-1562-8-9	5-1367-4-10	5-1367-4-10	
DA4	B	5-1562-8-9	5-1367-4-10	5-1367-4-13	
WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS

WIRE TABLE

CONTRACT NO:		NAME		DATE	<p>FAWNEE DIVISION 2600 E. FAWNEE WICHITA, KANSAS</p>
DESIGN		WHITSON	4-22-77	TITLE	
GROUP		D. H. [Signature]	4-22-77	WIRING DIAGRAM — AMMETER	
DRAWN		G.L. RYAN	4-21-77		
CHECK		J. YUCEL	4-22-77		
STRESS					

PART NO.	DESCRIPTION
3	C669527-0101 INST CLUSTER
2	S-1577-1 STARTER CONTACTOR
1	S-1707-60 CIRCUIT BREAKER

EQUIPMENT TABLE

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-1024 OR C66000-CESNA STD. NO.	SUPERSEDES: PG 10.2
	SUPERSEDED BY: 1270709 P 10.5

PROJ	PL [Signature]	4-24-77	SIZE	C	CODE IDENT. NO.	71379	DWG NO.	1270709
APPO			SCALE:	NONE	210 P210		PAGE:	10.3
OTHER								

(OR 8464)


MODEL 210 & T210 SERIES SERVICE MANUAL

D	BY REV: ADD DETAIL B S2527-(2-1), BLK(DC20; SER OUT BLK(DC11); S-2475-1 WAS S-1580-1 (NOW SHOP PRCT) (SR1010)(SR10102)	MKT 1-27-82	<i>JAS</i>
---	--	-------------	------------

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: WHITE (REF) WAS RED (REF); RED (REF) WAS BLU (REF); RED DC7 WAS BLU DC8; GRN (DC9) (REF) WAS GRN (DC9); DC11 WAS DC7 (SR9167)	CMK 7-13-78	JAS 1/85
B	BY REV: ADD DETAIL A (C664511-0102 (SR9583))	HHG 2-3-80	JAS 1/85
C	BY REV: (DC7) RED (REF) WAS (DC7) RED; (DC4) GRN WAS (DC9) GRN (NOW SHOP PRCT)	MKM 8-18-80	JAS 1/85

NOTES:

- ▶ INSTALL S-1636-1 ON VENDOR WIRE
- ▶ INSTALL S-1635-1 ON VENDOR WIRE



02-00916
01-00916

WIRE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
BLK (DC11)	18	18-0	S-1635-1	S-1636-1	SER(SR1010)(SR10102) ON THRU SER(SR9583)
DC10	18		S-1637-1	S-1636-1	THRU SER(SR9583)
BLK (REF)					
WHT (REF)					
RED (REF)					THRU SER(SR9583)

ITEM NO	PART NO.	DESCRIPTION
10	S2527-2	GND CONNECTOR
9	S2527-1	LH GND BLOCK
8	C664511-0102	DIGITAL CLOCK
7	S-2475-1	CONTACTOR
6	S-1091-1	FUSE
5	S-1090-22	FUSEHOLDER
4	S-1360-5L	CIRCUIT BREAKER
3	S-1637-1	HOUSING
2	S-1637-2	HOUSING
1	C664511-0101	DIGITAL CLOCK


CONTRACT NO.			Cessna AIRCRAFT CO.					
DESIGN	NAME	DATE	PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS					
	G STAMM	4-12-78	WIRING DIAGRAM — DIGITAL CLOCK (OPT)					
GROUP	V. J. Hardman	4-12-78						
DRAWN	R. YOUNGERS	4-11-78						
CHECK	BORLESKE	4-11-78						
STRESS			PROJ	PUNDRKX	4-14-78	SIZE	CODE IDENT.	DWG NO
APPD	JAS		C	71379		C	71379	1270709
OTHER			SCALE: NONE		(SR9167)	PAGE: 10.4		

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESSNA SPEC. NO. S-XXX OR CMXXXX-CESSNA STD. NO.

SUPERSEDES:
SUPERSEDED BY:

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD DETAIL A; DA7; SER OUT DAS (SR9114)(SR9115)	11-16 12-12-78	ASB JRS
B	BY REV: ADD C669560-0102 (SR9711)	SEB 11-1-79	ASB JRS
C	BY REV: SER OUT DAS, DA9; SER IN DA10, DA11; ADD DETAIL B (MER P210EQ870) (SR9634)(SR9635)	DFS 7-14-80	ASB JRS



DETAIL B
THRU SER(SR9634)(SR9635)

WIRE	GA	MATERIAL	LG	TERMINALS	SERIALS
DA11	8	S-1562-B-9		S-1367-4-10 S-1367-4-10	SER (SR9635) CON
DA10	8	S-1562-B-9		S-1367-4-10 S-1367-4-10	SER (SR9635) CON
DA9	8	S-1562-B-9		S-2447-8 S-1367-4-10	THRU SER(SR9634)
DAS	8	S-1562-B-9		S-2447-8 S-1367-4-10	THRU SER(SR9635)
DA7	8	S-1562-B-9		S-1367-4-10 S-1367-4-8	SER(SR9114)(SR9115) CON
DAS	8	S-1562-B-9		S-1367-4-10 S-1367-4-10	THRU SER(SR9114)(SR9115)

EQUIPMENT TABLE			WIRE TABLE		
4	C669560-0102	INST CLUSTER	CONTRACT NO:		
3	C669527-0101	INST CLUSTER	DESIGN: WILKINSON DATE: 12-14-78		
2	S-2443-1	STARTER CONTACTOR	GROUP: <i>W. H. Anderson</i> DATE: 12-7-78		
1	S-1707-60	CIRCUIT BREAKER	DRAWN: HAUJ DATE: 12-9-78		
PART NO.		DESCRIPTION	CHECK: BORLESKE DATE: 12-12-78		
SUPERSEDED BY: 1270709 P 10.3			STRESS:		
SUPERSEDED BY:			PROJ: <i>J. P. ...</i> DATE: 12-20-78		
OTHER:			APPD: <i>JRS</i>		
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-100 OR C6000-CESNA STD. NO.			TITLE: WIRING DIAGRAM - AMMETER SIZE: C CODE IDENT. NO. 71379 DWG NO. 1270709 SCALE: NONE SER 9221 PAGE: 10.3		

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION				REVISION			
LET	DESCRIPTION	DATE	APPD	LET	DESCRIPTION	DATE	APPD
H	BY REV: ADD PG 1111, S-1367-1 (ORN (LB113) WIRE (SR 8499))	GDS 8-3-76	JCY	A	BY REV: ADD S 2160-1, RED(2) & SER: SER OUT S 1844-1-2 LBIG: RED(1) SER 21059720	JLP 1-9-75	JCY
				E	BY REV: ADD WIRE LENGTHS. 270 OHM 1/2 W WAS 270 OHM 1/2 W: ADD ORIENT TERM BLOCK (NOW SHOP PRACTICE)	JLO 7-28-75	JCY
				C	BY REV: S 1404-2 WAS S 1404-3, S 2091-3 WAS S 2091-7, 200 OHM 1/2 W WAS 270 OHM 1/2 W (NOW SHOP PRACTICE)	BAH 10-25-75	JCY
				D	BY REV: DELETE 5LH-2W ADD: 18 GA JUMPER S-1370-2 WAS S-1370-1 / LBW: DELETE 270HM 1/2 W ON FRONT RHEOSTAT; ADD: 1213757-1 / ITEM 11, LB17 WIRING; 1213722-1 WAS 121392-20: 1213723-1 WAS 1213307-7; 18 GA JUMPER WAS 200 OHM WATT SER 21060012 (SR 815) MERED 2 SER (SR 7913)	CTH 1-4-75	JCY
				E	BY REV: 34003-B17 WAS 34002-55 (UNDO) 34004-B18 WAS 34002-55 (OUT BD) (SR 7913)	GW 9-17-75	JCY
				F	BY REV: BLU (REF) WAS BRN (REF); TAN (REF) WAS WHT (REF) (NOW SHOP PRACTICE)	JLP 11-21-75	JCY
				G	BY REV: 22 GA WAS 18 GA F-LB10 THRU F-LB 15, F-LB17 JUMPER WIRES; S-1635-1 WAS S-1635-2, S-1370-1 WAS S-1370-2, S-1829-1 WAS S-1829-2, S-1635-2 WAS S-1635-3, 1213722-4 WAS 1213722-1 (SR 814)	GDS 5-6-76	JCY

NOTES:

- 1. THESE WIRES VENDOR FURNISHED
- 2. THIS END OF RESISTOR TERMINATED WITH S-1367-1-14 TERMINAL & INSTALLED ON SHAFT OF TANDEM POT ASSY. DUE TO HEAT DISSIPATION RESISTOR MUST BE KEPT FROM WIRE BUNDLE

INACTIVE

EFF THRU (SR 8464) 4-21-77
GLR JMW
JCY & PJA

ORN (LB 113)	20	20-3	REF	5-1636-1	SER (SR 814) 10N
LB17	22		S-1370-1	S-1370-1	SER 210610906 ON
BLK(3)	22	-22-0	S-1367-1		
RED(2)	22	-22-2	65 S-1370-1	S-1829-1	SER 21059720 ON
LB16	18		65 S-1493-1	S-1367-1	THRU SER 21059719
BLK(2)	22	-22-0	S-1367-1		
RED(1)	18	-18-2	65 S-1370-1	S-1493-1	THRU SER 21059719
F-LB 15	22		65 S-1370-1	SOLDER	
F-LB 14	22		62 S-1370-1	S-1370-1	
F-LB 13	18		72 S-1635-2	S-1829-1	
F-LB 12	22		65 S-1635-1	SOLDER	
F-LB 11	22		65 S-1635-1	SOLDER	
F-LB 10	22		65 S-1635-1	SOLDER	
F-LB 1	18		65 S-1635-2	S-1829-1	

WIRE	GA	MATERIAL	LG	TERMINALS	SERIALS
17	5-1637-2	HOUSING			
16	34003-B17	TERMINAL BLOCK			
15	S-2160-1	SWITCH			
14	S-1844-1-2	SWITCH			
13	VAL-S-6000	RESISTOR			
12	34004-B18	TERMINAL BLOCK			
11	1213757-1	EL PANEL			
10	S-2000C201W	RESISTOR			
9	S-2091-3	POT ASSY			
8	S-1904-2	POT ASSY			
7	S-1641-6	HOUSING-SOCKET			
6	S-1640-6	HOUSING-PIN			
5	S-1360-5L	CIRCUIT BREAKER			
4	CG13001-01Q1	POWER SUPPLY			
3	1570166-1	DIMMING ASSY			
2	1213722-6	EL PANEL			
1	1213723-1	EL PANEL			

EQUIPMENT TABLE			WIRE TABLE		
PART NO.	DESCRIPTION		CONTRACT NO.	NAME	DATE
				Cessna. AIRCRAFT CO.	
				TITLE	
				WIRING DIAGRAM -	
				ELECTRO LUMINESCENT PANEL	
				DESIGN	V R SIDES 1-28-71
				GROUP	N. W. 2-25-71
				DRAWN	V R SIDES 2-18-71
				CHECK	L.K. WHITE 2-24-71
				STRESS	
				PROJ	N. W. 2-27-71
				APPD	JCY
				OTHER	


DESIGN	GROUP	DRAWN	CHECK	STRESS	PROJ	APPD	OTHER	SIZE	CODE IDENT NO	DWG NO
V R SIDES	N. W.	V R SIDES	L.K. WHITE		N. W.	JCY		C	71379	1270709

CES-1000 IS APPLICABLE	SUPERSEDES:	PROJ	SIZE	CODE IDENT NO	DWG NO
VENDOR CODES PER S-1400	12210-1073	N. W.	C	71379	1270709
CES-XXXX-CESSNA SPEC. NO.	SUPERSEDED BY:				
S-XXX OR CMXXXX-CESSNA	PG 11.18 2 11.19				
STD. NO.					

(SR 6755) 3 (21057503)

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
H	SEE PG 1110 FOR REV		



DETAIL A
THRU SER 21059719

INACTIVE
EFF THRU 58044-4
BY 2.0

CONTRACT NO:			Cessna AIRCRAFT CO.			PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	TITLE WIRING DIAGRAM — ELECTRO LUMINESCENT PANEL					
GROUP								
DRAWN	SCHIFFELBEIN	8-13-76						
CHECK	Yonel	8-16-76						
STRESS								
PROJ	PL Hedrick	8-16-76	SIZE	CODE IDENT. NO.	DWG NO.			
APPD			C	71379	1270709			
OTHER			SCALE	NONE	210	PAGE: 11.1.1		

SUPERSEDED BY:
PG 11.18 & 11.19

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

1. OXYGEN LIGHTS ARE STANDARD ON T210, OPTIONAL ON 210

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: ADD WIRE LENGTHS DELETE LB99 BLK 3/1 213319 10 TER OUT-LBS: 22 IN F-LB95 (SR7381)	JLO 7-28-73	JLP H/W VAC
B	BY REV: ADD DETAIL B, LB92 S-1637, S-1637-2 C669520-0102. (SR8311)	BAN 4-30-74	JCY 7/1 H/W
C	BY REV: ADD DETAIL C, D, E, F, WHITE BLK, 18 GA JUMPER & POST LIGHT (SR7650) ^B	JCP 4-30-74	JCY H/W
D	BY REV: (SR8065) WAS (SR7650) PER REV "B" (SR8311)	EAM 7-25-74	JCY H/W
E	BY REV: 34003-55 WAS 34002-55; ADD S-1370-2 RED WIRE: BLK (REF) WAS DMF-LB83 DELETE 18 GA JUMPER; ADD DETAIL D; RED/BLU (1) RED/BLU (2) WAS RED/BLU; ADD SHT 2; F-LB112 MER-20E0377(SR 7913) SER 21060585	LJM 11-27-74	JCY H/W
F	BY REV (SR7913) WAS (SR8065) PER REV "B" & "D" (SR8311)	CJM 1-27-75	JCY JRS H/W
G	BY REV: 34004-B1B WAS 34003-B17, (SR8311) WAS (SR7913) PER REV "B, D & F" (SR7913) (SR8311)	GW GS 8-27-75	JCY JRS H/W
H	BY REV: DELETE DETAIL B, S-1637-1 & 2; OBSOLETE NEVER USED LB92 LB95 WAS (SR7650) (NOW SHOP PRACTICE)	JLP 11-23-75	JCY H/W
J	BY REV: 22GA WAS 18 GA / F-LA90, F-LA91, BLK F-LB95, DMF-LB83, BLK(2), RED, RED/BLUE(1) RED/BLUE(2), F-LB112, BLK(3) (SR8143)	GDS 5-6-76	JCY H/W

INACTIVE

EFF THRU (SR8464)
4/21/77
JCY W/H
PLA

BLK(3)	22	-22-0	SOLDER	S-1370-2	SER 21060585 f ON	
F-LB112	22		S-1829-1	S-1370-2	SER 21060585 f ON	
F-LB92	18		S-1829-1	S-1635-2	OBS NEVER USED	
RED/BLU	22	-22-2 G	SOLDER	SOLDER		
RED/BLU	22	-22-2 G	SOLDER	S-1370-2		
RED	22	-22-2	S-1370-2	SOLDER	SER 21060585 f ON	
BLK(2)	22	-22-0	25	SOLDER S-1367-8		
BLK(1)	22	-22-0	25	SOLDER SOLDER		
DMF-LB83	22		35	SOLDER S-1367-8		
F-LB95	22		50	S-1829-1	S-1370-1	SER (SR7381) f ON
F-LB82	18		35	S-1829-1	SOLDER	THRU SER 21060584
F-LB51	18		50	S-1829-1	S-301-2	THRU SER (SR7381)
F-LA91	22		10	SOLDER S-1367-8		
F-LA90	22		190	S-1829-1	SOLDER	
WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS	

ITEM NO	PART NO.	DESCRIPTION
6	C669520-0102	INSTRUMENT CLUSTER
5	S-1899-7	LIGHT ASSY
4	34004-B1B	TERMINAL BOARD
2	C669502-0304	INST CLUSTER KIT
1	127079-A	LIGHT ASSY

EQUIPMENT TABLE


CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX-CESNA SPEC. NO
S-XXX OR CMXXXX-CESNA
STD. NO.

SUPERSEDES:
R210-1073

SUPERSEDED BY:
PG 1117

CONTRACT NO:			COMMERCIAL AIRCRAFT DIV 5800 E PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	Cessna AIRCRAFT CO.		
YR SIPES		1-28-71	<p style="text-align: center; font-weight: bold;">WIRING DIAGRAM -- INSTRUMENT LIGHTS</p>		
GROUP	H W W	2-26-71			
DRAWN	V B SIPES	2-18-71			
CHECK	L K WHITE	2-14-71			
STRESS					
PROJ	Wichita	2-27-71	SIZE	CODE IDENT NO	DWG NO
APPD			C	71379	1270709
OTHER			SCALE	NONE	210 PAGE 1.2

MODEL 210 & T210 SERIES SERVICE MANUAL




INACTIVE
EFF THRU (SRBAW)
DATE 2-21-77
JCY/WJ/SJ
719



CONTRACT NO.			WIRE TABLE		
DESIGN	V.B. SIPPES	1-28-71		COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS	
GROUP	H. WIND	2-26-71		TITLE	
DRAWN	V.B. SIPPES	2-18-71		WIRING DIAGRAM — INSTRUMENT LIGHTS	
CHECK	L.K. WHITE	2-24-71			
STRESS					
PROJ	H. WIND	1-27-71	SIZE	CODE IDENT. NO.	DWG NO.
APPRO			C	71379	1270709
OTHER			SCALE: NONE	210	PAGE: 11.2

MODEL 210 & T210 SERIES SERVICE MANUAL


REVISION (CONT)				REVISION			
LET	DESCRIPTION	DATE	APPD	LET	DESCRIPTION	DATE	APPD
E	BY REV: ADD DETAIL "B" & SER, F-LC17, F-LC18 & F-LC19 (SR8464)	REG 4-28-77	TO	A	BY REV: DELETE S-2094-1, GRAY, TAN, BLK (3) & BLK (4); 18 GA WAS 18 GA / F-LC 3 & F-LC 4; 16 GA WAS 14 GA / F-LC 15; S-1367-2-B WAS S-1493-3 / F-LC 13, F-LC 14, BLK (1) & BLK (2) (SR6755)	RLY 9-2-71	W/W
F	BY REV: 18 GA WAS 16 GA / BLK (2); F-LC18 TO LDG WAS TAXI; F-LC17 TO TAXI WAS LDG (SR8464) (SR8465)	JJB 8-29-77	JAB W/HP 9/8	B	BY REV: ADD S-2160-1, 12700BZ-1 (SER); SER OUT S-1846-1-3 SER (SR7486)	JLP 1-9-73	W/W
				C	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	JLO 5-3-75	W/W
				D	BY REV: ADD F-LC16, S1360-5L; 20 GA WAS 16 GA / F-LC13, BLK (1); S-1493-1 WAS S-1493-2, 1367-1-B WAS 1367-2-B / LC13; S-1367-1-B WAS S-1367-2-B / BLK (1); SER OUT 14 GA JUMPER WIRE (SR8143)	GDS 5-6-76	W/W



DETAIL A THRU SER (SR7486) (21059851)



DETAIL B THRU SER (SR8464)



DETAIL A THRU SER (SR8143) (21061573)

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
F-LC19	18			S-1493-1	S-1367-1-B SER (SR8464) & ON
F-LC18	18			S-1493-1	S-1367-1-B SER (SR8464) & ON
F-LC17	20			S-1493-1	S-1367-1-B SER (SR8464) & ON
F-LC16	20			S-1493-1	S-1367-1-B SER (SR843) THRU SER (SR8464)
BLK (2)	18	-18-0	16	S-1367-1-B	S-1367-1-B
BLK (1)	20	-20-0	16	S-1367-1-B	S-1367-1-B
F-LC15	16		6	S-1493-2	S-867-2-B THRU SER (SR8464)
F-LC14	16		175	S-1493-2	S-867-2-B THRU SER (SR8464)
F-LC13	20		175	S-1493-1	S-1367-1-B

PART NO.	DESCRIPTION
7	S-1360-10L CIRCUIT BREAKER
6	S-1360-5L CIRCUIT BREAKER
5	12700BZ-1 DIODE ASSY
4	S-1846-1-3 SWITCH
3	GE 4591 LIGHT
2	S-2160-1 SWITCH
1	S-1360-15L CIRCUIT BREAKER

EQUIPMENT TABLE

CONTRACT NO:			COMMERCIAL AIRCRAFT DIV.		
DESIGN	NAME	DATE	Cessna, AIRCRAFT CO.		
YR SIPS		1-28-71	3800 E. PAWNEE WICHITA, KANSAS		
GROUP		2-26-71	TITLE		
DRAWN	YR SIPS	2-18-71	WIRING DIAGRAM -		
CHECK	LK. WHITE	2-24-71	LANDING LIGHTS		
STRESS			SIZE	CODE IDENT NO.	DWG NO
PROJ		2-27-71	C	71379	1270709
APPO			SCALE: NONE 210 P210 PAGE: 11.4		
OTHER					

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1333-CESNA SPEC. NO. S-1360 OR CES-1000-CESNA STD. NO.

SUPERSEDES: 12210-1073
SUPERSEDED BY:

(SR6755) II
21059503

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISIONS (CONT)				REVISION			
LET	DESCRIPTION	DATE	APPD	LET	DESCRIPTION	DATE	APPD
F	BY REV: ADD DETAIL "C" & SER 4 F-LD52; S-1360-5L WAS S-1360-5 (SR 8464)	REG 4-28-77	<i>REG</i>	A	BY REV: ADD S-2160-1, 3400Z-55 LD-1 LD42, LD43, LD44 & SER; SER OUT = 1844-2, LD23, LD25 & LD26 SER 21059720	DLP 5-9-73	<i>DLP</i>
				B	BY REV: ADD WIRE LENGTHS & ORIENT TERM BLOCK (NOW SHOP PRACTICE)	DLP 7-28-72	<i>DLP</i>
				C	BY REV. 34003-817 WAS 34002-55. ADD DETAIL 'B' & SER'S & F LD 10 (SR 7913)	GW 9-17-75	<i>GW</i>
				D	BY REV: EFF OF DET 'B' WAS THRU (SR 7913) (SR 8482)	JCS 3-15-76	<i>JCS</i>
				E	BY REV: 22 GA WAS 18 GA/F-LD43, F-LD42, RED(2), RED(1), F-LD22; S-1635-1 WAS S-1635-2; S-1636-1 WAS S-1636-2 (SR 8464)	TMS 5-21-76	<i>TMS</i>

12	34003-817	TERM BLOCK	F-LD10	22		S-1637-6	S-1493-1	SER (SR 8464) & ON
11	S-1637-2	HOUSING - PLUG	F-LD44	22		G S-1493-1	S-1829-1	SER 21059720 (ON)
10	S-1637-1	HOUSING - CAP	F-LD43	22		180 S-1829-1	S-1636-1	SER 21059720 & ON
9	1270705-1	CABLE ASSY	F-LD42	22		Z00 S-1829-1	S-1636-1	SER 21059720 & ON
8	S-1360-5L	CIRCUIT BREAKER	F-LD41	18		160 S-1829-1	S-1635-2	SER 21059720 THRU 21061229
7	S-1874-1-2	SWITCH	RED(2)	22	-22-2	220 S-1635-1	S-1636-1	
6	S-1641-9	HOUSING-SOCKET	RED(1)	22	-22-2	220 S-1635-1	S-1636-1	
5	S-1640-9	HOUSING - PIN	F-LD34	18		100 S-1635-2	S-1636-2	THRU SER 2 061 229
4	S-1638-2	HOUSING-CAP	F-LD10	22		S-1829-1	S-1636-1	SER 21061230 & ON
3	S-2160-1	SWITCH	F-LD26	18		180 S-1636-2	S-1636-2	THRU SER 21059719
2	CG22001-0202	LIGHT ASSY	F-LD25	18		200 S-1636-2	S-1636-2	THRU SER 21059719
1	CG22001-0102	LIGHT ASSY	F-LD23	18		160 S-1635-1	S-1635-2	THRU SER 21059719
			F-LD22	22		G S-1637-6	S-1635-1	THRU SER (SR 8464)

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS






EQUIPMENT TABLE			WIRE TABLE		
PART NO.	DESCRIPTION		CONTRACT NO:	NAME	DATE

SUPERSEDES:		TITLE	
12210-1073		CESSNA AIRCRAFT CO.	
SUPERSEDED BY:		COMMERCIAL AIRCRAFT DIV 5800 E. PAWNEE WICHITA, KANSAS	
		WIRING DIAGRAM - NAVIGATION LIGHTS	

DESIGN	GROUP	DATE	SIZE	CODE IDENT NO	DWG NO
V R SIPES		1-28-71	C	71379	1270709
H W LAD		2-26-71			
V R SIPES		2-18-71			
L K WHITE		2-25-71			
PROJ	V. McFater				
APPD	W				
OTHER					


CES-1000 IS APPLICABLE		SCALE	
VENDOR CODES PER S-1400		NONE	2/0
CES-XXX-CESSNA SPEC. NO.			
S-XXX OR CMXXXX-CESSNA			
STD. NO.			

MODEL 210 & T210 SERIES SERVICE MANUAL



CONTRACT NO:				WIRE TABLE		
NAME		DATE		COMMERCIAL AIRCRAFT DIV. CESSNA AIRCRAFT CO. 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	V R SIPS	1-28-71	TITLE			
GROUP	21 W 141	2-25-71	WIRING DIAGRAM —			
DRAWN	V R SIPS	2-18-71	NAVIGATION LIGHTS			
CHECK	L.K. WHITE	2-25-71				
STRESS				SIZE	CODE IDENT.	DWG NO
PROJ	N. McFadden	2-27-71	C	71379	1270709	
APPD	JWB		SCALE: NONE		PAGE: 11.5	
OTHER						

MODEL 210 & T210 SERIES SERVICE MANUAL



REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD 51637-2 TO FIELD & WIRE LENGTHS & TERMINALS; SER OUT F-LA2, F-LA10 & F-LA11, SER IN F-LA92, F-LA93 & F-LA94: 122103-2 WAS 0700615-5 (NOW SHOT FRAGILE) (SR6155) (SR7361)	5/18/75	LCP HFW
B	BY REV: 22 GA WAS 186A/F-LA1, F-LA2, F-LA8, F-LA9, F-LA92, F-LA93, F-LA94, GRN(1) & GRN(2); 5-1635-1 WAS 5-1635-2, 5-1636-1 WAS 5-1636-2, 5-1636-3 WAS 5-1636-2 (SR8143)	GDS 5-6-76	Shunt JRS
C	BY REV: ADD DETAIL 'C' & SER, F-LA95 & F-LA96 (SR8464)	REG 4-28-77	JRS out

See Sheet 2

F-LA96	22			S-1830-1	S-1367-6		SER (SR8464) & ON
F-LA95	22			S-1830-1	S-1367-6		SER (SR8464) & ON
F-LA94	22		97	S-1830-1	S-1367-6		SER 21060080 & ON
F-LA93	22		5	S-1635-1	SOLDER		SER 21060090 & ON
F-LA92	22		43	S-1636-1	S-1370-1		SER 21060090 & ON
F-LA11	18		97	S-1830-1	S-341-1		THRU SER 21060089
GAM(1)	22	-22-5	20	S-1635-1	S-1636-1		
GRN(1)	22	-22-5	18	S-1635-1	S-1636-1		
F-LA10	18		5	S-341-1	SOLDER		THRU SER 21060089
F-LA9	22		53	S-1636-1	F-LA8		
F-LA8	22		53	S-1830-1	S-1636-2		
F-LA3	18		93	S-341-2	S-1370-1		THRU SER 21060089
F-LA2	22		186	S-1830-1	S-1367-6		THRU SER (SR8464)
F-LA1	22		196	S-1637-6	S-1830-1		THRU SER (SR8464)

ITEM NO	PART NO.	DESCRIPTION
12	GE313	LAMP
11	5-1637-2	HOUSING-PLUG
10	0413140-5	REFLECTOR
9	0413138	SOCKET
8	5-1831-1	SWITCH
6	5-1641-9	HOUSING-SOCKET
5	5-1640-9	HOUSING-PIN
4	5-1831-1	SWITCH
3	5-1367-1	HOUSING-PIN
2	5-1360-5L	CIRCUIT BREAKER
1	122103-2	LIGHT ASSY

EQUIPMENT TABLE			WIRE TABLE		
SUPERSEDED BY			CONTRACT NO:		
12210-1073			DESIGN	VR SIPS	1-28-71
SUPERSEDED BY			GROUP	H Will	2-26-71
			DRAWN	VR SIPS	2-18-71
			CHECK	V.V. WHITE	2-24-71
			STRESS		
			PROJ	4.11/1/71	2-21-71
			APPO		
			OTHER		
			SIZE	CODE IDENT	DWG NO
			C	71379	1270709
			SCALE	NONE	210
					PAGE 11.6





CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX-CESNA SPEC. NO.
S-XXX OR CMXXXX-CESNA
STD. NO.

SUPERSEDED BY
12210-1073
SUPERSEDED BY

COMMERCIAL AIRCRAFT DIV
CESSNA AIRCRAFT CO.
5800 E PAWNEE
WICHITA, KANSAS

TITLE
**WIRING DIAGRAM —
DOME, COURTESY & BAGGAGE
LIGHTS**

MODEL 210 & T210 SERIES SERVICE MANUAL



WIRE TABLE						
CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. Cessna AIRCRAFT CO. 5800 E. PAWNEE WICHITA, KANSAS			
DESIGN	VR SIPS	1-28-71	TITLE			
GROUP	H. White	2-26-71	WIRING DIAGRAM —			
DRAWN	VR SIPS	2-18-71	DOME, COURTESY & BAGGAGE			
CHECK	L.K. WHITE	2-24-71	LIGHTS			
PROJ	H.M. Carter	2-22-71	SIZE	CODE IDENT. NO.	DWG NO	
APPD			C	71379	1270709	
OTHER			SCALE: NONE	210	PAGE: 11.6	


Dome, Courtesy & Baggage Lights (Sheet 2 of 2)

(SR 6755) II
21057503

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

- 1. S-1493-1 TERMINAL REPLACES S-1829-1 WHEN OPT POST LIGHTS ARE INSTALLED.
- 2. TERMINATE VENDOR FURNISHED WIRES WITH S-1635-1 & S-1367-1-B.



DETAIL A
(APPLIES WHEN OPT POST LTS ARE INSTL)
SER 21059720 & ON

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: ADD MS155B4-16 & NOTE 2, 0513208-3 WAS 0513208-1 (SR7650) II	MEM 5-14-79	MEM TO MEM
B	BY REV: 34003-55 WAS 34002-55; SER (SR7913)	CJM 11-27-74	SCY AS TO MEM
C	BY REV: ADD RED TO LB103 & LB104 & WIRE LENGTHS MER E0404	TMS 2-25-75	SCY AS TO MEM
D	BY REV: 34003-817 WAS 34003-55 (SR7913)	GW 9-17-75	MEM AS
E	BY REV: 20 GA WAS 18 GA / F-LB5, 22 GA WAS 18 GA / F-LB100, F-LB101, F-LB102. RED (F-LB103), RED (F-LB104), F-LB105, F-LB106. BLK (F-LB107); JUMPER WIRE: F-LB105 WAS F-LB90, S-1635-1 WAS S-1635-2, S-1636-1 WAS S-1636-2, 34004-818 WAS 34003-817 ADD 34002-55 (SR8143)	GOS 5-6-76	EXLDR AS
F	BY REV: DELETE F-LB106 & LB107 / 1215319-15; DELETE 34002-55; 34003-817 WAS 34004-818 MER 210E0552	GLR PH 8-26-76	EXLDR AS
G	BY REV: ADD LB129 / LB130 / PZ10 (SR8465)	DLP 6-6-77	JAS UNK AS
H	BY REV: SER OUT DETAIL "A" (SR8469) (SR8468)	JJB 8-29-77	MEM AS
J	BY REV: DELETE LB129, LB130 / SR8469 / DETAIL "A"; INACT. DWS. (SR8469) (SR8468)	GDM 11-28-77	JAS UNK AS

INACTIVE

THRU SER (SR8469) (REF)
GDM 11-28-77
MEM



QTY	PART NO.	DESCRIPTION	WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
16	MS155B4-16	MINIATURE LAMP						
15	S-1637-1	HOUSING						
14	S-2035-1	HOUSING - CAP						
13	S-2035-2	HOUSING - PLUG						
12	S-2160-2	SWITCH						
11	1213319	LIGHT ASBY						
10	S-1695-2	SWITCH						
9	34003-817	TERMINAL BLOCK						
8	MS155B4-8	MINIATURE LAMP						
7	0513208	SOCKET						
6	S-1637-2	HOUSING						
5	S-1641-6	HOUSING - SOCKET						
4	S-1640-6	HOUSING - PIN						
3	S-1360-5L	CIRCUIT BREAKER						
2	C660501-0102	COMPASS ASSY						
1	1870166	DIMMING ASSY						

CONTRACT NO:		NAME		DATE	COMMERCIAL AIRCRAFT DIV.	
		Cessna Aircraft Co.		2-28-74	3800 E. PAWNEE WICHITA, KANSAS	
DESIGN	VR	GROUP	J. FINCH	2-27-74	TITLE	
DRAWN	J. FINCH	CHECK	J. YOUNG	2-13-74	WIRING DIAGRAM - CONSOLE & COMPASS LIGHTS	
STRESS		PROJ	NM/Instn	3-11-74	SIZE	C
APPD	PLB	APPD	PLB		CODE IDENT NO.	71379
OTHER		OTHER			DWG NO.	1270709
		SCALE: VONE				PAGE: 11.7.1

MODEL 210 & T210 SERIES SERVICE MANUAL

INACTIVE

THRU SER (SRBAG)(REF)
GDM 11-25-77
JRS



CONTRACT NO:		COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE
GROUP	VR PIPE'S	7-28-74	WIRING DIAGRAM - CONSOLE & COMPASS LIGHTS
DRAWN	J. FINCH	2-27-74	
CHECK	J. YOUNG	2-13-74	
STRESS			
PROJ	H.M. Carter	3-1-74	SIZE
APPO	JLS		CODE IDENT. NO.
OTHER			71379
		SCALE: NONE	DWG NO
		210	1270709
		PAGE: 11.7.1	

Console & Compass Lights (Sheet 2 of 2) (SR 7381)(REF)(21060090)

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION				REVISION			
LET	DESCRIPTION	DATE	APPD	LET	DESCRIPTION	DATE	APPD
J	BY REV: ADD DETAIL 'C' S2527-2; -16 BLK(FN-LB163); SER OUT BLK(FN-LB88) (SR1001)(SR1002)	MKT 1-27-82	JAS, DM JRS	A	BY REV: ADD WIRE LENGTHS & ORIENT TERM BOARD (NOW SHOP PRACTICE)	DLO 7-22-73	DLP WVW 10
				B	BY REV: ADD RH10-10, HF-10-10, S-1637-1, S-1637-2, F-LB111, F-LB108, F-LB109 & F-LB110 (SR7650)II	MEM 5-17-74	DLO JRS
				C	BY REV: 34003-55 WAS 34002-55; SER (SR 7913)	CJH 11-27-74	JCY JRS
				D	BY REV: 34003-817 WAS 34003-55. INBOARD TERM BLOCK / DETAIL 'A' WAS OUTBOARD TERM BLOCK; ADD SER'S TO .38, .39, LB10, LB11 (SR7650)(REF): NOW SHOP PRACTICE (SR7913)	GW 9-17-75	JRS
				E	BY REV: 22 GA WAS 18 GA / F-LB88, F-LB111, F-LB108, F-LB109, F-LB110; S-1636-1 WAS S-1636-2 (SR 8143)	GDS 5-6-76	JRS
				F	BY REV: ADD F-LB140, DETAIL 'B'; SER OUT F-LB108, F-LB109, F-LB110 & F-LB111, RH-10-10, HF-10-10, S-637-1, S-1637-2 (SR8464)(SR8465)	JJB 8-29-77	JAS, DM JRS
				G	BY REV: 1213319 (S) WAS (4) (SR8464)(REF), (SR8465) (REF)	DLP 2-9-77	JAS, DM JRS
				H	BY REV: ADD RED LB145; BLK F-LB88 WAS F-LB88, MER 210E0667 (NOW SHOP PRACTICE)	HMG 2-2-79	JAS, DM JRS



02-888/8

QTY	REP	DESCRIPTION	GA	MATERIAL	LG	TERMINALS	SERIALS
22	F-LB163	-22-0		S-1370-1	52099-9		SER(SR1001)(SR1002)FCN
22	F-LB145	-22-2		S-1370-1	5EELB140		
22	F-LB140			S-1829-1	S-1370-1		(SR8464) CON
22	F-LB110			S-1370-1	S-1635-1		(SR7650) THRU (SR8464)
22	F-LB109			6	SOLDER	S-1635-1	(SR7650) THRU (SR8464)
22	F-LB108			6	S-1636-1	SOLDER	(SR7650) THRU (SR8464)
22	F-LB111			S-1636-1	S-1829-1		(SR7650) THRU (SR8464)
22	BLK F-LB88	-22-0		90	S-1370-1	S-1627-1	THRU SER(SR1001)(SR1002)
18	F-LB88			90	S-1370-1	S-1829-1	THRU SER 210E0667


EQUIPMENT TABLE		WIRE TABLE	
9	S2527-2 GND CONNECTOR	CONTRACT NO:	
8	S2527-1 LH GND BLOCK	NAME	DATE
7	34003-817 TERMINAL BLOCK	DESIGN	VR SIPS 1-28-71
6	S-1637-2 HOUSING-SOCKET	GROUP	H. W. 2-25-71
5	S-637-1 HOUSING	DRAWN	VR SIPS 2-18-71
4	HF-10-10 RESISTOR (MNI)	CHECK	OK WHITE 2-24-71
3	RH-10-10 RESISTOR (DALE)	STRESS	
2	34002-55 TERMINAL BLOCK	PROJ	127-71
1	1213319 LIGHT ASSY	APPD	JRS
PART NO. DESCRIPTION EQUIPMENT TABLE		TITLE WIRING DIAGRAM - EYEBROW LIGHTS	
SUPERSEDES: 12210-1073 SUPERSEDED BY:		COMMERCIAL AIRCRAFT DIV Cessna AIRCRAFT CO. 5800 E. PAWNEE WICHITA, KANSAS	
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESSNA SPEC. NO. S-XXX OR CMXXXX-CESSNA STD. NO.		SIZE CODE IDENT DWG NO C 71379 1270709	
		SCALE NONE 210 P210 PAGE 11 E	

(SR 6755) II (21059503)


MODEL 210 & T210 SERIES SERVICE MANUAL



DETAIL **A**
THRU SER (SR 7450)
(21060539)



DETAIL **B**
SER (SR 7650) THRU
SER (SR 8464)




DETAIL **C**
THRU SER (SR 10101) (SR 10102)

CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS		
Cessna AIRCRAFT CO.			TITLE		
DESIGN	VR SIZES	1-28-71	WIRING DIAGRAM — EYEBROW LIGHTS		
GROUP	W. W. W.	2-26-71			
DRAWN	VR SIZES	2-18-71			
CHECK	L. K. WHITE	2-24-71			
STRESS					
PROJ	J. M. Carter	2-27-71	SIZE	CODE IDENT NO.	DWG NO.
APPD	JWB		C	71379	1270709
OTHER			SCALE: NONE	210 P210	PAGE: 11.8

(SA 6755) (21059503)

MODEL 210 & T210 SERIES SERVICE MANUAL


REVISION				REVISION			
LET	DESCRIPTION	DATE	APPD	LET	DESCRIPTION	DATE	APPD
F	BY REV: ADD DETAIL B; LD53 WAS LD41 (SR8464)(SR8465)	DLP 6-6-77	JAS JAB	A	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	-LO	
G	BY REV: RED/WHT LD62 & LD61 WAS LD45 & LD44, LD60 WAS LD43, LD59 WAS LD42, LD58 WAS LD53; S-2099-7 WAS 66331-9 RED/WHT LD62 & LD61; S-2353-2 WAS 66332-3/LD59 & LD60 (SR8464)(SR8465)	JJB 8-29-77	JAB	B	BY REV: REACTIVATE WNG (SR7913)	GW 6-12-75	
K	REV. CONT. ON P. 11.12.1			C	BY REV: 22 GA WAS 18GA LD36 THRU LD40 S-1635-1 WAS S-1635-2, S-1636-1 WAS S-1636-2 (SR8143)	GOS 5-6-76	
				D	BY REV: ADD (RED/WHT) TO LD39 & LD40 (NOW SHOP PRACTICE)	PH 8-25-76	
				E	BY REV: ADD DETAIL 'A' & SER (SR8464)	REG 4-28-77	



NOTES:

1 S-1360-5L CKT. BRK. REPLACED WITH S-1360-10L CKT. BRK. WHEN TAIL FLOODLIGHT IS INSTALLED.

See Sheet 2




ITEM NO.	PART NO.	DESCRIPTION
15	S-1360-10L	CIRCUIT BREAKER
14	205841-1	CONNECTOR
13	205838-1	CONNECTOR
12	S-2349-2	CONNECTOR
11	S-2350-2	CONNECTOR
10	S-2349-1	CONNECTOR
9	S-2350-1	CONNECTOR
8	C622006-007	LAMP ASSY
7	C622008-0102	POWER SUPPLY
6	S-1637-1	HOUSING
5	S-1637-2	HOUSING
4	S-1640-6	HOUSING
3	S-1641-6	HOUSING
2	S-2160-1	SWITCH
1	S-1360-5L	CIRCUIT BREAKER

REV/WHT	TERMS	DATE	REV/WHT	TERMS	DATE	REV/WHT	TERMS	DATE
LD63	1B	-1B-2-9	S-1636-1	S-2391-1		SER(SR9427) & ON		
LD62	1B	-1B-2-9	S-1493-1	S-2415-1		SER(SR9427) & ON		
LD59	20	-20-2-9	S-2099-7	S-1636-1	STD			
LD58	1B	-1B-2-9	S-2099-7	S-1636-1	STD	THRU SER(SR9427)		
LD60	1B	-1B-2-9	S-1493-1	S-2353-2				
LD59	20	-20-2-9	S-1493-1	S-2353-2		THRU SER(SR9427)		
LD58	1B	-1B-2-9	S-1367-6	S-1493-1		SER(SR8464) & ON		
LD61	1B	-1B-2-9	S-1636-1	S-1635-1	STD			
LD62	1B	-1B-2-9	S-1636-1	S-1635-1	STD			
LD38	1B	-1B-2-9	180	S-1635-1	S-1493-1			
LD37	1B	-1B-2-9	200	S-1635-1	S-1493-1			
LD36	22	-22-2-9	18	S-1367-6	S-1493-1		THRU SER(SR8464)	


WIRE TABLE			CONTRACT NO:		TITLE	
WIRE CODE NO.	G.A.	MATERIAL	LG	TERMINALS	SERIALS	
EQUIPMENT TABLE			DESIGN: VR SIPES 3/29/72		WIRING DIAGRAM - WING TIP STROBE LIGHTS (OPT)	
SUPERSEDED BY: PG 11.11			GROUP: VR SIPES 5/22/72		DRAWN: VR SIPES 5/22/72	
SUPERSEDED BY:			CHECK: KX WHITE 5/17/72		STRESS:	
CES-1000 IS APPLICABLE			PROJ: 71 (2-6)		SIZE: C	
VENDOR CODES PER S-1400			APPD:		CODE IDENT. NO: 71379	
CES-XXXX-CESSNA SPEC. NO.			OTHER:		DWG NO: 1270709	
S-XXX OR CMXXXX-CESSNA					SCALE: NONE	
STD. NO.					PAGE: 11.12.0	

MODEL 210 & T210 SERIES SERVICE MANUAL



DETAIL 13
(APPLIES TO P210)


See Sheet 1



WIRE TABLE					
CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS		
NAME			Cessna AIRCRAFT CO.		
DATE			TITLE		
DESIGN	VE SIPES	3/29/72	WIRING DIAGRAM —		
GROUP	H. Wain	5-22-72	WING TIP STROBE		
DRAWN	VE SIPES	4/18/72	LIGHTS (OPT)		
CHECK	L.K. WHITE	5-22-72			
STRESS					
PROJ	H.M. White	5-23-72	SIZE	CODE IDENT. NO.	DRG NO
APPO			C	71379	1270709
OTHER			SCALE: NONE	Z10 P210	PAGE: 11.12.0

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
H	BY REV: C622006-0107 WAS - 0102 C622008-0102 WAS C622007 - 0103; ADD DETAIL C SER, ADD 205838-1, 205841-1, LD63, LD64, P 11.12.1 SR9927 (SR8930XREF) 20 SA WAS 20 SA/LD37, LD38, LD39, LD40, LD58, LD59, LD60, LD61, LD62, LD63, LD64	CS 4-10-78 JLP	<i>JLP</i>
J	BY REV: (SR9927) WAS (SR8843)/REVH; DETAIL C; LD59, LD61, LD63, LD64 (SR9927)	GDA 10-20-80	<i>GDA</i>
K	BY REV: ADD FLAG NOTE 1 THRU 5 PARTS TO BE USED AS STROBE LIGHTS TABLE 2 SA WAS 20 SA (SR9927)	10/11 5-27-82	<i>REL</i>



DETAIL C P 11.12.0
THRU SER(SR9927)

11-11-78 916-0-916 02-00316

CONTRACT NO:			Cessna AIRCRAFT CO. PAWNEE DIVISION 5800 E PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE			
DESIGN	SPENCER	9-17-78	TITLE WIRING DIAGRAM - WING TIP STROBE LIGHTS (OPT)		
GROUP					
DRAWN	C SHAVER	4-10-78			
CHECK	RE HAIR	5-27-82			
STRESS					
PROJ			SIZE	CODE IDENT NO.	DWG NO.
APPD	<i>JLP</i>		C	71379	1270709
OTHER			SCALE: NONE	(SR9927)	PAGE 11.12.1

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD RED, YEL, GRN, BLK & SER; SER OUT LF10, LF11, LF12, LF13 & LF14; ADD NOTE 1 (SR8464)	DLP 1-10-73	BY REV
B	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	2LO 5-3-73	BY REV
C	BY REV: ADD DETAIL 'A' & SER'S; SER OUT LFG & LF7; SER IN LF15 (SR7913)	GW 9-17-75	BY REV
D	BY REV: EFF OF DET 'A' WAS THRU (SR7913) (SR8482)	JCS 3-15-76	BY REV
E	BY REV: 18 GA WAS 16 GA/LF15, BLK(LF14), BLK(LF13), GRN(LF12), YELL(LF11), RED(LF10), LF5; S-1367-18 WAS S-1367-2-8, S-1493-1 WAS S-1493-2 (SR8463)	TMS 5-21-76	BY REV
F	BY REV: C594502-0102 WAS C594502-0101 (SR8552)	GDS 8-2-76	BY REV
G	BY REV: ADD DETAIL 'B' & SER; LF16 & S-1360-10L (SR8464)	REG 4-28-77	BY REV
H	BY REV: ADD WIRE LF17/P210 (SR8465)	GDS 6-6-77	BY REV
J	BY REV: ADD PAGE 11.13.1, 16 GA JUMPER S-1640-6, S-1641-6 & FLAG NOTE 2; SER OUT LF13 & LF14; SER IN LF18, LF19, LF20 & LF21 (SR9310)	LWF 2-15-79	BY REV
K	(CONTINUED ON PAGE 11.13.1)		


WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS	
LF22	18	-18-0	5-1635-1	5-1367-1-8	SER(SR9310) ON	
LF21	18	-18-0	5-1635-1	5-1367-1-8	SER(SR9310) ON	
LF20	18	-18-0	LF18	LF19	SER(SR9310) ON	
LF19	18	-18-0	5-1635-1	5-1636-3	SER(SR9310) ON	
LF18	18	-18-0	5-1635-3	5-1493-1	SER(SR9310) ON	
LF17	18		5-1493-1	5-1636-2	SER(SR8465) ON	
LF16	18		5-1367-2-6	5-1493-1	SER(SR8464) ON	
LF15	18		5-1493-1	5-1636-2	SER21061230 & ON	
LF14	18	-18-0	5-1635-2	5-1367-1-8	SER21059882 THRU(SR9310)	
LF13	18	-18-0	5-1493-1	5-1367-1-8	SER21059882 THRU(SR9310)	
LF12	18	-18-0	75	5-1636-2	5-1493-1	SER21059882 ON
LF11	18	-18-4	75	5-1636-2	5-1635-2	SER21059882 ON
LF10	18	-18-2	65	5-1635-2	5-1636-2	SER21059882 ON
LF9	16		5-1635-2	5-1367-2-8	THRU SER21059881	
LF8	16		5-1493-2	5-1367-2-8	THRU SER21059891	
LF7	16		75	5-1636-2	5-1493-2	THRU SER21059881
LFG	16		65	5-1635-2	5-1636-2	THRU SER21059881
LF5	18		75	5-1635-2	5-1636-2	THRU SER21061229
LF4	18		7	5-1367-2-4	5-1493-1	THRU SER(SR8464)

13	S-2035-1	HOUSING-PLUG
12	S-2035-2	HOUSING-CAP
11	S-1360-10L	CIRCUIT BREAKER
10	C621001-0102	LIGHT ASSY
9	C594502-0102	FLASHER ASSY
8	OR95-6	RESISTOR
7	S-1638-1	HOUSING-PLUG
6	S-1637-1	HOUSING-CAP
5	S-1637-2	HOUSING-PLUG
4	1270705	CABLE ASSY
3	S-1638-2	HOUSING-CAP
2	S-2160-1	SWITCH
1	S-1360-8L	CIRCUIT BREAKER

EQUIPMENT TABLE			WIRE TABLE		
PART NO.	DESCRIPTION		CONTRACT NO:	COMMERCIAL AIRCRAFT DIV. 3800 E. FAWNEE WICHITA, KANSAS	
			DESIGN	VR S1PES	3/25/72
			GROUP	H. W. H.	5-22-72
			DRAWN	VR S1PES	5-22-72
			CHECK	W.H.P.	5-22-72
			STRESS		
			PROJ	A.M.C.	5-23-72
			APPRO		
			OTHER		
SUPERSEDES: PG 11.3			SIZE	CODE IDENT. NO.	DWG NO.
SUPERSEDED BY:			C	71379	1270709
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1001-CESBNA SPEC. NO. S-1001 OR CM1001-CESBNA STD. NO.			SCALE: NONE	210 P210	PAGE: 11.13.0


WIRING DIAGRAM - FLASHING BEACON LIGHT

MODEL 210 & T210 SERIES SERVICE MANUAL



NOTES: SEE SHT 11.13.

DETAIL **B**
THRU SER (SR 8464)



DETAIL **A**
EFF THRU SER (SR 8482)
(21061229)

CONTRACT NO:			WIRE TABLE		
DESIGN	VR Sipes	3/25/72	COMMERCIAL AIRCRAFT DIV. CESSNA AIRCRAFT CO. 5800 E. PAWNEE WICHITA, KANSAS		
GROUP	H. Wied	5-22-72	TITLE WIRING DIAGRAM — FLASHING BEACON LIGHT		
DRAWN	VR Sipes	5-22-72	SIZE	CODE IDENT NO	DWG NO
CHECK	WHITS	5-22-72	C-	71379	1270709
STRESS			SCALE	NONE	210 P210
PROJ					PAGE 11.13
APPD					(SR 7038) (21053720)
OTHER					

MODEL 210 & T210 SERIES SERVICE MANUAL


NOTES:

1. COLORED WIRES BEARING CES 1100 CODING IN PARENTHESIS SHALL NOT BE STAMPED. CES 1100 CODING ON THESE WIRES IS FOR PARTS LIST USE ONLY

2. INTERTWINED WIRE (LF19) WITH (LF15), (LF18) WITH (LF12) & (LF20) WITH (LF10) FROM COMPONENTS TO A-16416 HOUSING PLUG. INTERTWINED (LF21) WITH (LF15) / 210 & (LF17) / P210

3. INTERTWINE (LF19) WITH (LF11), (LF18) WITH (LF12) & (LF20) WITH (LF10) & INTERTWINE (LF21) & (LF22) / P210 WITH (LF15) / 210 & (LF17) / P210

REVISIONS			
LTR	DESCRIPTION	DATE	APPROVED
K	BY REV: DELETE NOTE 2. ADD NOTE 3, BLK N-LF22 WIRE. S-2035-2 WAS S-1640-6 & S-2035-1 WAS S-1641-6. BLK WIRES (LF18), (LF19), (LF20), & (LF21) WERE WHT WIRES. (SR9310)	MDR 7-31-79	<i>[Signature]</i>



DETAIL C SH-11.13.0
THRU SER (SR 9310)

CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS		
			Cessna AIRCRAFT CO.		
DESIGN	LWPINE	2-15-79	TITLE		
GROUP	LWPINE	2-15-79	WIRING DIAGRAM—		
DRAWN	LWPINE	2-15-79	FLASHING BEACON		
CHECK	C KING	2-15-79	LIGHT		
STRESS			SIZE	CODE IDENT. NO.	DWG NO.
PROJECT	210-210	2-15-79	C	71379	1270709
APPD			SCALE: NONE 210 P210 PAGE: 11.13.1		

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

- 1. TYP 2 PLACES
- 2. TYP 15 PLACES
- 3. WHEN POST LIGHTS ARE INSTALLED, F-LB100, F-LB5 & F-LB105 ARE CONNECTED TO S-2160-2 SWITCH. AN 18GA JUMPER IS INSTALLED BETWEEN SWITCH & OUTBOARD TERM BOARD. SWITCH SIDE OF JUMPER HAS AN S-1493-1 TERMINAL. TERMINAL BOARD SIDE OF JUMPER HAS AN S-1829-1 TERMINAL. REPLACE S-1829-1 TERMINAL ON F-LB5, F-LB100 & F-LB105 WITH AN S-1493-1

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: CHANGE ROUTING OF 18 GA. JUMPER. NOW SHOP PRACTICE	RJP 4-26-74	JCY 1/25
B	BY REV: 34003-55 WAS 34003-55 SER (SR7913)	CSH 11-27-74	JCY 1/25 JAS
C	BY REV: 34003-817 WAS 34003-55 (SR7913)	GW 9-17-75	JCY 1/25
D	BY REV: 34004 B18 WAS 34003-817. LBS5 REF. WAS LBS2 (REF) (NOW SHOP PRACTICE)	GLR 11-25-75	JCY 1/25
E	BY REV: 22 GA WAS 18 GA / F-LB96 THRU F-LB99 & JUMPER WIRE (SR 8143)	GOS 5-6-76	JCY 1/25
F	BY REV: F-LB105 IN NOTE 3 WAS F-LB10; 34004-817 WAS 34004-818 (NOW SHOP PRACTICE)	PH 8-15-76	JCY 1/25

INACTIVE


EFF THRU (SRBA4) 4-18-77
GLR
JCY

RED(2)	22	B	SOLDER	SOLDER	2
RED(1)	22	B	SOLDER	S-1635-1	1
BLK(2)	22	B	SOLDER	SOLDER	2
BLK(1)	22	B	SOLDER	S-1636-1	1
F-LB99	22	25	S-1493-1	S-1636-1	
F-LB98	22	65	S-1493-1	S-1636-1	
F-LB97	22	12	S-1367-1	S-1635-1	
F-LB96	22	15	S-1367-1	S-1635-1	

8	1270479-5	LIGHT ASSY
7	S-2023-1	TERM. ADAPTER
6	S-2160-2	SWITCH
5	34004-817	TERMINAL BLOCK
4	S-1899-4	POST LIGHT ASSY
3	S-1899-3	POST LIGHT ASSY
2	S-1637-2	HOUSING
1	S-1637-1	HOUSING

CONTRACT NO:			WIRE TABLE				
DESIGN	NAME	DATE	GA	MATERIAL	LG	TERMINALS	SERIALS
<p style="text-align: center;">Cessna AIRCRAFT CO. COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS</p>			<p style="text-align: center;">WIRING DIAGRAM — POST LIGHTING (OPT)</p>				
GROUP	H. Wiese	8-13-73	<p style="text-align: center;">TITLE</p>				
DRAWN	JL OLLER	7-28-73	<p style="text-align: center;">SIZE CODE IDENT. DWG NO</p>				
CHECK	DAPE	7-28-73	<p style="text-align: center;">C 71379 1270709</p>				
STRESS			<p style="text-align: center;">SCALE: NONE (SR7381) PAGE 11.14</p>				
PROJ	Supercedes	11-7-73	<p style="text-align: center;">SUPERSEDES: PG 11.9</p>				
APPO	PH		<p style="text-align: center;">SUPERSEDED BY: PG 11.9 & 11.9.1</p>				
OTHER			<p style="text-align: center;">CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESNA SPEC. NO. S-XXX OR CMXXXX-CESNA STD. NO.</p>				

MODEL 210 & T210 SERIES SERVICE MANUAL



INACTIVE
EFF THRU (SR8464)
GUR (M)/ JCY JLR
4-16-77

CONTRACT NO:				WIRE TABLE	
NAME			COMMERCIAL AIRCRAFT DIV. 8800 E. PAWNEE WICHITA, KANSAS		
DATE			Cessna AIRCRAFT CO.		
DESIGN	TITLE		WIRING DIAGRAM - POST LIGHTING (OPT)		
GROUP	H. W. [unclear]	8-13-73			
DRAWN	J. O. [unclear]	7-28-73			
CHECK	PAGE	7-28-73			
STRESS					
PROJ	[unclear]	8-13-73	SIZE	CODE IDENT. NO.	DWG NO
APPO	[unclear]		C	71379	1270709
OTHER			SCALE: NONE	(SR73B)	PAGE: 11.14


Post Lighting (OPT) (Sheet 2 of 2)

(21060090)

MODEL 210 & T210 SERIES SERVICE MANUAL

INACTIVE
EFF THRU (SR8464)
4-18-77
BY REV
J.C. J.W.F.
X
KEM

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: 14003 SER. NA 14002 55 SER. NA 14003 55 SER. NA 14004 55	11 11-27-74	BY JRS
B	BY REV: 34003 B17 NAS 34003-55 (K7913)	3 3-17-75	BY JRS
C	BY REV: ADD RED/GRN (5), OYL A SERIAL SER OUT RED/GRN (1), RED/GRN (2), ADD S-1960-2-O, S-962-2-C & 1570307 (SR8633XSR7677XREF)	PH 8-24-76	BY JRS



DETAIL A
EFF THRU SER (SR8633)

15	S-1962-2-O	HOUSING
14	S-1960-2-O	HOUSING
13	1570307	CABLE ASSY
12	1570308	CABLE ASSY
11	AGC-1/2	FUSE
10	Z4RB	LAMP
9	S-1360-5L	CIRCUIT BREAKER
8	S-2660-1	SWITCH
7	34003-B17	TERM BLOCK
6	HHJ-A	FUSEHOLDER
5	1570308-1	CABLE ASSY
4	3421-0000	SOCKET
3	1570307-1	CONNECTOR ASSY
2	3859AKW-15ZA	RHEOSTAT
1	4157-001	SOCKET

RED/GRN	22	-22-2-5	SOLDER	S-1829-1	THRU SER (SR8633) 1 ON
WHT	22	-22-9	SOLDER	SOLDER	
BLK	22	-22-0	SOLDER	SOLDER	
BLU	22	-22-6	SOLDER	SOLDER	
RED/GRN	22	-22-2-5	SOLDER	S-1829-1	THRU SER (SR8633)
RED/GRN	22	-22-2-5	SOLDER	SOLDER	THRU SER (SR8633)
WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS

WIRE TABLE


CONTRACT NO:			COMMERCIAL AIRCRAFT DIV		
DESIGN			Cessna AIRCRAFT CO.		
GROUP			5800 E. PAWNEE		
DRAWN			WICHITA, KANSAS		
CHECK			TITLE		
STRESS			WIRING DIAGRAM -		
PROJ			MAP LIGHT, CONTROL WHEEL		
APPD					
OTHER					

ITEM NO.	PART NO.	DESCRIPTION
EQUIPMENT TABLE		
SUPERSEDES: P1110		
SUPERSEDED BY: PG 11-20		

SIZE	CODE IDENT NO.	DWG NO
C	71379	1270709
SCALE: NONE	327677	PAGE: 11.15

(E1060319)

MODEL 210 & T210 SERIES SERVICE MANUAL




CONTRACT NO:			Cessna AIRCRAFT CO.			PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS		
DESIGN	WHITSON	4-22-77	TITLE					
GROUP	W.H. Anderson	4-21-77	WIRING DIAGRAM —					
DRAWN	G.L. RYAN	4-21-77	INSTRUMENT LIGHTS					
CHECK	J. YOUNG	4-22-77						
STRESS								
PROJ	PLHEDRICK	4-26-77	SIZE	CODE IDENT. NO.	DWG NO.			
APPD			C	71379	1270709			
OTHER			SCALE: NONE		210 P210		PAGE: 117	


Instrument Lights (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
F	BY REV: FN-LB53 WAS LB143 (SR9187) (REF) ADD DETAIL A, C669360-0102 & C669361-0102 (SR9711) FN-LB70 WAS F-LB70, FN-LB71 WAS F-LB71 FN-LB72 WAS F-LB72, FN-LB112 WAS F-LB112, RED (FN-LB114) WAS RED (LB114) (NOW SHIP PRACTICE)	SA 11-21-79	<i>JAS</i> <i>JAS</i>
G	BY REV: ADD SER (SR9556) & ON TO LA123, LA124, LA121 & LA122 WIRES (SR9556)	WHH 1-28-80	<i>WHH</i> <i>JAS</i>
H	BY REV: ADD DETAIL 'B' & SERIALS (SR10148)	GW 3-5-81	<i>GW</i> <i>JAS</i>



DETAIL **A** P. 117.0
THRU SER (SR 9710)



DETAIL **B**
EFF THRU SER (SR10148)

LB154	22		SEE LB112	51367-1-B	SER (SR100148) & ON
WIRE CODE NO.	GA	MATERIAL	WG	TERMINALS	SERIALS
WIRE TABLE					
CONTRACT NO.			Cessna AIRCRAFT CO. PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
NAME	DATE				
DESIGN	ABRAHAM	12-11-79	TITLE WIRING DIAGRAM - INSTRUMENT LIGHTS		
GROUP					
DRAWN	ABRAHAM	11-21-79			
CHECK	BORLESKE	12-8-79			
STRESS					
PROJ			SIZE	CODE IDENT NO.	DWG NO.
APPD	<i>JAS</i>		C	71379	1270709
OTHER			SCALE: NONE	210 P210	PAGE: 11.17.1


(SR9711)

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
C	SEE PAGE 11.18.0 FOR REVISION		



DETAIL 13 PG 11.18.0
THRU SER (SR10101)(SR10102)




DETAIL C PG 11.18.0
THRU SER (SR10101)(SR10102)

91600-10
02-00916

CONTRACT NO:			Cessna AIRCRAFT CO.			PAWNEE DIVISION			
						5800 E. PAWNEE			WICHITA, KANSAS
DESIGN	NAME	DATE	TITLE						
GROUP			WIRING DIAGRAM						
DRAWN	M. THOMPSON	1-27-82	ELECTROLUMINESCENT PANEL						
CHECK	BORLESKE	1-28-82	(OPT)						
STRESS			SIZE	CODE IDENT. NO.	DWG NO.				
PROJ	J. H. MORRIS	3-26-82			1270709				
APPD	ARZ		C	71379					
OTHER			SCALE: NONE			PAGE: 11.18.1			

(SR10101)(SR10102)

MODEL 210 & T210 SERIES SERVICE MANUAL



REVISION			
LET	DESCRIPTION	DATE	APPD
A	SEE PAGE 11.19.2 FOR REVISION		

DETAIL 13
THRU SER(SR10101)(SR10102)

DETAIL 13
THRU SER(SR10101)(SR10102)

02-00916
10-00910


CONTRACT NO:			PAWNEE DIVISION Cessna AIRCRAFT CO. 3800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	TITLE		
GROUP	SPENCER	4-25-77	WIRING DIAGRAM - POST LIGHTING (OPT)		
DRAWN	E. YOUNGERS	4-18-77	PROJ	SIZE	CODE IDENT.
CHECK	J. YOUNG	4-19-77	PLHEDRLK	C	71379
STRESS			APPD	EWG NO.	1270709
OTHER			SCALE: NONE	PAGE: 11.19.1	

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

1. WHEN POST LT OPTION IS INSTALLED 1570301-1 DIMMING ASSY REPLACES 1570166 & 15-2091-7 POT ASSY REF. PLACES 15-1904-2
2. THIS POT IS PART OF 15-2091-7 DUAL POT ASSY WHEN OPTIONAL E.L. LIGHTING IS INSTALLED

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV. ADD DETAIL "A" & "B", S2527-1, 2; BLK (FN-LB167), BLK (FN-LB168); SER OUT LB125, LB127 (SR1111) (SR10102)	MKT 1-27-82	JAB JAW JRS



WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
FN-LB167	22	-22-0		S-1635-1	S2099-4
FN-LB168	22	-22-0		S-1635-1	S2099-4
LB133	22			S-1635-1	SOLDER
LB138				S-1635-1	S-1829-1
LB127				S-1635-1	SOLDER
LB123				S-1635-1	S-1829-1
LB125				S-1636-1	S-1367-1-8
LB127				S-1636-1	S-1367-1-8
BLK(2)		-22-0		SOLDER	SOLDER
BLK(1)(LB167)		-22-0		SOLDER	S-1636-1
RED(2)		-22-2		SOLDER	SOLDER
RED(LB126)		-22-2		SOLDER	S-1635-1
LB126				S-1829-1	S-1636-1
LB124	22			S-1829-1	S-1636-1

QTY	PART NO.	DESCRIPTION
14	52527-2	GND CONNECTOR
13	52527-1	LN GND BLOCK
12	5-2000C201J	RESISTOR
11	1513837	POST LT ASSY
10	5-1637-1	HOUSING
9	5-1637-2	HOUSING
8	5-2091-7	POT ASSY
7	5-1904-2	POT ASSY
6	5-1360-5L	CIRCUIT BREAKER
5	34004-818	TERMINAL BLOCK
4	34003-817	TERMINAL BLOCK
3	5-1640-9	HOUSING
2	5-1641-9	HOUSING
1	1570301	DIMMER ASSY

EQUIPMENT TABLE	
PART NO.	DESCRIPTION
14	52527-2 GND CONNECTOR
13	52527-1 LN GND BLOCK
12	5-2000C201J RESISTOR
11	1513837 POST LT ASSY
10	5-1637-1 HOUSING
9	5-1637-2 HOUSING
8	5-2091-7 POT ASSY
7	5-1904-2 POT ASSY
6	5-1360-5L CIRCUIT BREAKER
5	34004-818 TERMINAL BLOCK
4	34003-817 TERMINAL BLOCK
3	5-1640-9 HOUSING
2	5-1641-9 HOUSING
1	1570301 DIMMER ASSY

WIRE TABLE		
CONTRACT NO.	NAME	DATE
	SPENCER	2-19-79
	W. HAZAKI	2-12-79
	BORLESKE	2-13-79
	SPENCER	3-5-79

Cessna AIRCRAFT CO.		
DESIGN	NAME	DATE
	SPENCER	2-19-79
	W. HAZAKI	2-12-79
	BORLESKE	2-13-79
	SPENCER	3-5-79

TITLE		
SCALE	CODE IDENT. NO.	DWG NO.
SCALE: NONE	71379	1270709

SUPERSEDES:	
PAGE	SUPERSEDED BY:
11.19.0	

PAWNEE DIVISION
3800 E. PAWNEE
WICHITA, KANSAS


1570301-1
1570301-2
1570301-3

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

- FOR INTERCONNECTION WITH ELECTRIC ELEVATOR TRIM SEE PAGE 4.4.2

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: BLK(REF) WAS BLK ADD S-1985-1; WHT(REF) WAS RED(1) (SR8464)(REF)(SR8465)(REF)	CRS 11-21-77	<i>[Signature]</i>



INACTIVE
 EFF THRU SER(SR9953) (SR9954)
 3/10/81
 REHALL EN for JEC

65-0916
64-0916

ITEM NO.	PART NO.	DESCRIPTION	WIRE CODE NO.	MATERIAL	LG	TERMINALS	SERIALS
15	S-1985-1	MIKE SWITCH					
14	S-1360-SL	CIRCUIT BREAKER					
13	S-2160-1	SWITCH					
12	34003-817	TERMINAL BLOCK					
11	S-1961-2-C	HOUSING	BLK(1)	22	-22-0	S-1963-2	S-1367-1-B
10	S-1961-1-0	HOUSING					
9	570307	CABLE	RED/GRN	22	-22-2-5	S-1963-2	S-1829-1
8	570307	CONNECTOR ASSY	RED	22	8569-2	SOLDER	SOLDER
7	3421-0000	CONNECTOR SOCKET					
6	270944	CABLE					
5	3473-3000	CONNECTOR SOCKET					
4	127084L	CONNECTOR ASSY					
3	8859A161-152A	RHEOSTAT					
2	242B	LAMP					
1	4157-001	SOCKET					

WIRE TABLE

CONTRACT NO:		
DESIGN	NAME	DATE
GROUP	SPENCER	4-25-77
DRAWN	R. YOUNGERS	4-18-77
CHECK	J. YOUNGERS	4-19-77
STRESS		
PROJ	PL. HEDRILL	4-24-77
APPD	J. YOUNGERS	
OTHER		

Cessna. AIRCRAFT CO.
 PAWNEE DIVISION
 3800 E. PAWNEE
 WICHITA, KANSAS

WIRING DIAGRAM —
MAP LIGHT, CONTROL WHEEL

EQUIPMENT TABLE


CES-1000 IS APPLICABLE
 VENDOR CODES PER S-1400
 CES-XXXX-CESNA SPEC. NO.
 S-XXXX OR CXXXX-CESNA
 STD. NO.

SUPERSEDES:
 P 11.15
 SUPERSEDED BY:
 P 11.27

SIZE: C
 CODE IDENT. NO.: 71379
 DWG NO.: 1270709
 SCALE: NONE
 (SR8464)(SR8465) PAGE: 11.20

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD N-LB132, N-LB133, N-LB134, N-LB135, N-LB136, N-LB137; F-LB131 HAS F-LB1 (SRB464)(SRB465)	JJB 8-20-77	JAS/WH HIS



N-LB137	22			S-1635-1	SOLDER		
N-LB136	22			S-1635-1	SOLDER		
N-LB135	18			S-1829-1	S-1635-1		
N-LB134	22			S-1635-1	SOLDER		
N-LB133	18			S-1635-1	S-1829-1		
N-LB132	18			S-1635-3	S-1367-1-4		
F-LB5	18		65	S-1829-1	S-1635-1		
F-LB12	22		65	S-1635-1	SOLDER		
F-LB11	22		65	S-1635-1	SOLDER		
F-LB10	22		65	S-1635-1	SOLDER		
F-LB131	18		65	S-1635-3	S-1367-1-4		
F-LB13	18		72	S-1635-1	S-1829-1		

8	52000C2011	RESISTOR
7	51904-2	POT ASSY
6	34003-817	TERMINAL BLOCK
5	51360-5L	CIRCUIT BREAKER
4	34004-518	TERMINAL BLOCK
3	51640-6	HOUSING-PIN
2	51641-6	HOLDING-SOCKET
1	15TC166	DIMMING ASSY

CONTRACT NO:			WIRE TABLE				
DESIGN	NAME	DATE	WIRE CODE NO	MATERIAL	LG	TERMINALS	SERIALS
DLH/ALDEN		4-21-77	GA				
GROUP	DLH/ALDEN	4-21-77					
DRAWN	G.L. RYAN	4-21-77					
CHECK	J. YOUNG	4-22-77					
STRESS							
PROJ	DLH/FRICK	4-26-77					
APPD							
OTHER							

EQUIPMENT TABLE	
PART NO.	DESCRIPTION
8	52000C2011 RESISTOR
7	51904-2 POT ASSY
6	34003-817 TERMINAL BLOCK
5	51360-5L CIRCUIT BREAKER
4	34004-518 TERMINAL BLOCK
3	51640-6 HOUSING-PIN
2	51641-6 HOLDING-SOCKET
1	15TC166 DIMMING ASSY

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESNA SPEC. NO. S-XXX OR CMXXXX-CESNA STD. NO.	SUPERSEDES: PG 11.1.0 & 11.1.1 SUPERSEDED BY: P 11.2.0
--	---

Cessna AIRCRAFT CO.			PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS		
TITLE WIRING DIAGRAM — FLOOD, ENGINE INSTR & RADIO DIAL LIGHTS					
SIZE	CODE IDENT. NO.	DWG NO			
C	71379	1270709			
SCALE: NONE		210 P210	PAGE: 1, 2		

(SRB464)
(SRB465)

MODEL 210 & T210 SERIES SERVICE MANUAL

- 1. TERMINATE VENDOR FURNISHED WIRES WITH S-1685-1
- 2. TERMINATE VENDOR FURNISHED WIRES WITH S-1567-1-B
- 3. TERMINATE VENDOR FURNISHED WIRE W/51636-1

LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD BLK TO(N-LB141) (SR8464)(REF)(SR8465)(REF)	LSG 8-10-78	JAS DICK MS TCC
B	BY REV: ADD BLK(L888)(REF), WHT(REF) WAS BLK(REF), BLK(REF) WAS WHT(REF) LB103 WAS RED LB103, LB104 WAS RED LB104, S-1370-1 WAS S-1636-1 MER 210 E0667	HGG 3-21-79	MS
C	BY REV: ADD 2315-1, GE1495, F-LB146, N-LB147, BLK(FN-LB148), DETAIL A. (SR9114)(SR9115)	MDR 4-6-79	EF
D	BY REV: ON DETAIL A: SER(SR9553) THRU WAS SER(SR9114) (SR9115) THRU (SR9556)	WHH 1-28-80	WHH MS MS MS
D	BY REV: ADD DETAIL B. ADD LB155 THRU-LB162 WIRES. ADD (R204), (R205) BLK(1) BLK(2) WIRES. ADD POST LTS FOR TACH, TWO RADIO IND. & SECOND ALT AS STANDARD. (SR9555)(SR9554)	WHH 5-24-81	WHH MS MS MS
G	SEE PAGE 11.24.1 FOR REVISION		

PART NO.	QUANTITY	DESCRIPTION	TERMINALS	SERIALS
BLK(2)	22	-22-0	SOLDER	SER(SR9553)(SR9554) ON
BLK(1)	1	-22-0	SOLDER	
RED(2)	1	-22-2	SOLDER	
RED(1)	1	-22-2	SOLDER	
N-LB162	1		S-1636-1 S-1637-1-B	SER(SR9553)(SR9554) ON
F-LB161	1		S-1635-1 S-1637-1-B	SER(SR9554) THRU SER(SR10102)
N-LB160	1		S-1635-1 S-1637-1-B	SER(SR9553) THRU SER(SR1011)
F-LB159	1		S-1635-1 S-1635-1	SER(SR9554) ON
N-LB158	1		S-1635-1 S-1635-1	SER(SR9553) ON
F-LB157	1		S-1636-1 S-1637-1-B	SER(SR9554) THRU SER(SR10102)
N-LB156	1		S-1636-1 S-1637-1-B	SER(SR9553) THRU SER(SR10101)
F-LB156	22	-22-0	S-1636-1 S-1635-1	SER(SR9553) ON
N-LB149	22	-22-0	S-1636-1 S-1637-1-B	(OPT) SER(SR9556) ON
N-LB147	22		S-1636-1 S-1829-1	(OPT) SER(SR9556) ON
F-LB146	22		S-1636-1 S-1829-1	(OPT) SER(SR9556) ON
N-LB144	22	-22-0	S-1635-1 S-1637-1-B	SER(SR9556) ON
N-LB140	1		S-1636-1 S-1829-1	THRU SER(SR10101)(SR10102)
N-LB129	1		S-1636-2 S-1829-1	
LB105	1		S-1829-1 S-1635-1	
LB104	1		SOLDER S-1636-1	
LB103	1		SOLDER S-1370-1	
F-LB102	1		S-1636-2 S-1829-1	
F-LB101	1		S-1635-1 S-1637-1-B	THRU SER(SR10101)(SR10102)
F-LB100	22		S-1829-1 S-1636-1	

ID	PART NO.	DESCRIPTION
10	S2527-2	GND CONNECTOR
17	S2527-1	LH GND BLOCK
16	2113026	COVER ASSY RH
15	1513857	POST LT ASSY
14	2113025	COVER ASSY LH
13	GE1495	BULB
12	2315-1	LIGHT ASSY
11	34004-818	TERMINAL BLOCK
10	1213313	LIGHT ASSY
9	S-1635-2	SWITCH
8	S-1637-2	HOUSING
7	S-1637-1	HOUSING
6	34003-817	TERMINAL BLOCK
5	S-2038-2	HOUSING - PLUG
4	S-2038-1	HOUSING - CAP
3	C660301	COMPASS ASSY
2	ME15504-16	MINIATURE LAMP
1	OS13208	SOCKET

CONTRACT NO:	NAME	DATE	TITLE
	SPENCER	12-1-77	WIRING DIAGRAM - CONSOLE & COMPASS LIGHTS
	WILLIAM DICK	3-17-78	
	G. MOTYKO	11-28-77	
	BORLESKE	11-29-77	
	PLHEDRILL	3-31-77	

WIRE TABLE

Cessna AIRCRAFT CO.
PAWNEE DIVISION
3800 E. PAWNEE
WICHITA, KANSAS

WIRING DIAGRAM - CONSOLE & COMPASS LIGHTS

PART NO.	DESCRIPTION

EQUIPMENT TABLE

CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-1000-CESNA SPEC. NO.
S-100X OR CXXXX-CESNA
STD. NO.

SUPERSEDED:
PAGE 11.7.1
SUPERSEDED BY:


PROJ PLHEDRILL 3-31-77
APPO MS
OTHER

SIZE CODE IDENT. DWG NO
C 71379 1270709

SCALE: NONE 210. P210 PAGE: 11.24.8

(SR8464)(SR8465)



MODEL 210 & T210 SERIES SERVICE MANUAL



CONTRACT NO:		CROSSIA AIRCRAFT CO.		PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS	
DESIGN	SPENCER	DATE	12-1-77	TITLE	
GROUP	W. H. H. H. H.	DATE	3-17-78	WIRING DIAGRAM - CONSOLE & COMPASS LIGHTS	
DRAWN	S. NOTMKO	DATE	11-28-77		
CHECK	BORLESKE	DATE	11-29-77		
STRESS					
PROJ	DLNEDRICK	DATE	3-21-78	SIZE	CODE IDENT
APPD	LR			C	71379
OTHER				DWG NO	1270709
				SCALE: NONE	210 P210
				PAGE: 24	

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
E	BY REV. ADD 1513837 (4) & PAGE 11.24.1 (SR9953)(SR9954)	MKT 8-18-81	JAS MKT JTB
F	BY REV. ADD DETAIL "C"; BLK(F-LB169), BLK(N-LB170), SER OUT BLK(N-LB141), F-LB101; ADD 52527(-11-2), C660501 WAS C660501-D102 (SR1001)(SR1002)	MKT 1-27-82	JAS MKT JTB
G	BY REV. ADD DETAIL "D" (SR10101)(SR10102)	GLS 6-28-82	JAS MKT JTB



01-0076 02-00916

QTY	GA	MATERIAL	LG	TERMINALS	SERIALS
22	-22-0	5-1634-1	5-2099-4	SER(SR10102) & ON	
22	-22-0	5-1634-1	5-2099-4	SER(SR10101) & ON	
22	-22-0	5-1636-1	5-2099-4	SER(SR10102) & ON	
22	-22-0	5-1636-1	5-2099-4	SER(SR10101) & ON	
22	-22-0	5-1635-1	5-2099-4	SER(SR10101) & ON	
22	-22-0	5-1635-1	5-2099-4	SER(SR10102) & ON	

CONTRACT NO:			WIRE TABLE		
DESIGN	NAME	DATE	Cessna AIRCRAFT CO.		
GROUP	W. J. Thompson	8-18-81	TITLE		
DRAWN	M. Thompson	8-18-81	WIRING DIAGRAM -		
CHECK	BORLESKE	8-21-81	CONSOLE & COMPASS		
STRESS			LIGHTS		
PROJ	OR3	4-28-81	SIZE	CODE IDENT.	DWG NO
APPD			C	71379	1270709
OTHER			SERIALS		
			NONE 210, P210 PAGE 11.24.1		



PART NO.	DESCRIPTION
EQUIPMENT TABLE	
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-1000 OR CESNA-CESNA STD. NO.	
SUPERSEDES:	
SUPERSEDED BY:	

MODEL 210 & T210 SERIES SERVICE MANUAL


NOTES:

▶ INSTALL S-1636-1 ON VENDOR WIRE

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD NOTE 1, DETAIL 'A', LK7 & LK8 BLK(LK9) & BLK(LK10) (SR9884)	DEC 14 80	WMA
B	BY REV: ADD DETAILS (SR10101, SR10102)	WMA 7-16-82	WMA



DETAIL A
THRU SER(SR9884)



DETAIL B
THRU SER(SR10101, SR10102)

02-00916
16-00-01

WIRE	GA	MATERIAL	LG	TERMINALS	SERIALS
BLK(LK10)	18	-18-0		S-1367-4 S-1367-6	SER(SR9884) ON CALL SPARES
BLK(LK9)	18	-18-0		S-1367-4 S-1367-6	
LK8				S-1635-1 SEE LK7	
LK7				S-1635-1 S-1636-3	SER(SR9884) ON CALL SPARES
BLK(LK6)	-18-0			S-1367-16 S-1367-1-8	THRU SER(SR9884)
BLK(LK5)	-18-0			S-1367-1-8	
LK4				SEE LK3	
LK3				S-1367-1-6 S-1636-3	THRU SER(SR9884)
LK2				S-1493-1 S-1635-1	
LK1	18			S-1367-1-6 S-1493-1	

ITEM NO.	PART NO.	DESCRIPTION
6	00033092	LIGHT ASSY
5	S-1637-2	HOUSING
4	S-1637-1	HOUSING
3	S-1360-10L	CKT BKR
2	00033051	LIGHT ASSY
1	S-2160-1	SWITCH

EQUIPMENT TABLE

CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX-CESSNA SPEC. NO.
S-XXX OR CMXXXX-CESSNA
STD. NO.

SUPERSEDES:

SUPERSEDED BY:

CONTRACT NO:

DESIGN	NAME	DATE
GROUP	W. HAZARD	3-3-79
DRAWN	H. GHAZARIAN	2-9-79
CHECK	SOLESKE	2-12-79
STRESS		
PROJ		3-1-79
APPD		
OTHER		

WIRE TABLE

Cessna AIRCRAFT CO.

PAWNEE DIVISION
3686 E. PAWNEE
WICHITA, KANSAS


TITLE
**WIRING DIAGRAM —
VERTICAL TAIL
ILLUMINATION LIGHT (OPT)**

SIZE CODE IDENT. DWG NO
C 71379 1270709

SCALE: NONE (SR9114)(SR9115) PAGE: 11-25

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LIST	DESCRIPTION	DATE	APPD



N-LB137	22	S-1635-1	SOLDER
F-LB12	22	S-1635-1	SOLDER
N-LB135	18	S-1829-1	S-1635-1
F-LB5	18	S-1829-1	S-1635-1
N-LB136	22	S-1635-1	SOLDER
F-LB11	22	S-1635-1	SOLDER
N-LB134	22	SEE N-LB132	SOLDER
F-LB10	22	SEE F-LB13	SOLDER
N-LB132	18	S-1635-3	S-1367-14
F-LB131	18	S-1635-3	S-1367-14
N-LB133	18	S-1635-1	S-1829-1
F-LB13	18	S-1635-1	S-1829-1
N-LB145	22	SEE N-LB143	SOLDER
F-LB144	22	SEE F-LB142	SOLDER
N-LB143	18	S-1635-3	S-1367-14
F-LB142	18	S-1635-3	S-1367-14

QTY	PART NO.	DESCRIPTION
8	S-20000201J	RESISTOR
7	S-1904-2	POT ASSY
6	34003-817	TERMINAL BLOCK
5	S-1360-5L	CIRCUIT BREAKER
4	34004-818	TERMINAL BLOCK
3	S-1640-6	HOUSING-PIN
2	S-1641-6	HOUSING-SOCKET
1	1570166	DIMMING ASSY

QTY	PART NO.	DESCRIPTION

CS-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CS-1000-CESNA SPEC. NO.
S-30X OR C8000-CESNA
STD. NO.

SUPERSEDES:
P 11.21
SUPERSEDED BY:



CONTRACT NO:			Cessna AIRCRAFT CO.		PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE	SIZE	CODE IDENT.	DWG NO
GROUP	SPENCER	2-14-79	WIRING DIAGRAM — FLOOD, ENGINE INST & RADIO LIGHTS	C	71379	1270709
DRAWN	B. J. HENDERSON	3-27-79				
CHECK	HAZARIAN	2-12-79				
STRESS	BORLESKE	2-12-79				
PROJ		3-5-79	SCALE: NONE	SR914(SR915)	PAGE: 11. 26	

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

1. MATERIAL IS RCF51303 COIL CORD VENDOR CODE (096906)

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD DETAIL "A" SER(SR10101) SER(SR10102) BLK(FN-LB171) SER OUT BLK (SR10101) (SR10102)	MKT 1-27-82	JAS L'HOE JAS



INACTIVE
EFF THRU SER(SR10101)
TMS 9-8-83
264-1/13

01-00916 02-00916

ITEM NO.	PART NO.	DESCRIPTION	WIRE CODE NO.	G.A.	MATERIAL	LG	TERMINALS	SERIALS
12	52527-2	GND CONNECTOR						
11	52527-1	LH GND BLOCK						
10	227J030	CABLE ASSY						
9	24RB	LAMP	22	-22-0	5-1963-2	52099-4		SER(SR10101) (SR10102)
8	4157-001	SOCKET	24	1.	5-1370-1	5-1963-3		THRU SER(SR10101) (SR10102)
7	3859A161-152A	RHEOSTAT	24	1.	5-1963-3	SOLDER		
6	5-1370-1	SPLICE	22	-22-2-5	5-1829-1	5-1963-2		
5	5-1962-2-0	HOUSING						
4	5-1962-1-0	HOUSING						
3	34003-B17	TERMINAL BLOCK						
2	5-2160-1	SWITCH						
1	5-1360-5L	CIRCUIT BREAKER						

EQUIPMENT TABLE			WIRE TABLE		
CONTRACT NO.	NAME	DATE	DESIGN	GROUP	DRAWN
	G. STAMM	3/10/81		10.11	3-20-81
	G. STAMM	3/10/81			
	RE HAIR	3-11-81			

PROJ	APPD	OTHER	SIZE	CODE IDENT NO.	DWG NO
J. H. MOORE			C	71379	1270709

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESNA SPEC. NO. S-XXX OR CMXXXX-CESNA STD. NO.	SUPERSEDES: P 11 20	SUPERSEDED BY: PG 11.2B	CONTRACT NO.	NAME	DATE	TITLE
				G. STAMM	3/10/81	WIRING DIAGRAM - MAP LIGHT, CONTROL WHEEL

CONTRACT NO.	NAME	DATE	DESIGN	GROUP	DRAWN	CHECK	STRESS	PROJ	APPD	OTHER	SIZE	CODE IDENT NO.	DWG NO
	G. STAMM	3/10/81		10.11	3-20-81			J. H. MOORE			C	71379	1270709

CESNA DIVISION	3800 E. PAWNEE	WICHITA, KANSAS

SCALE	NONE	(SR9953) (SR9954)	PAGE: 11-27

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION				REVISION			
LET	DESCRIPTION	DATE	APPD	LET	DESCRIPTION	DATE	APPD
H	BY REV: DELETE DETAIL "B"/REV G, GEB, GE9, GD25 & GD26; INACT DWG (SRB464)	DLP 6-6-77	JASON 1/19/75	C	BY REV: REVISED & REDRAWN	DLP 7-30-73	
				D	BY REV: ADD COLOR CODES TO GD-9, GO-10, & GO-24 SER OUT: GO-8 & GO-9 (NOW SHOP PRACTICE) (SR724) (REF)	RS 11-28-73	
				E	BY REV: RED (REF) WAS WHT (REF)/2 PLCS BLK (REF) WAS WHT (REF)/2 PLCS (NOW SHOP PRACTICE)	MEM 4-2-74	
				F	BY REV: ADD DETAIL "B" SER; 226A WAS 186A TAN (GD9), BLK (GD10), F-GD11 THRU F-GD14; 226A WAS 2D GA / F-GD5, F-GD7, F-GD15, F-GD17, F-GD18, F-GD19, F-GD21, F-GD23, WHITE (GD24), F-GD1 THRU F-GD6; SER OUT F-GD1 & F-GD2, SER IN F-GE7; 5-1635-1 WAS 5-1635-2, 5-1636-1 WAS 5-1636-2 (SRB143)	GDS 5-6-76	
				G	BY REV: ADD DETAIL "B" & SER'S, F-GEB, F-GE9, F-GD25 & F-GD26 (SRB464)	REG 4-28-77	

NOTES:

▶ INSTALL 1Z70717-1 DIODE ASSY WITH SYMBOL POINTING TO POSITIVE TERM. ON MOTOR

INACTIVE:
 EFF THRU SER (SRB464)
 DLP 1/19/75
 6-6-77

F-GE7	12		5-1367-3-13	5-1367-3-13	SER 21061574 & ON
F-GE6	22	21	5-1367-1-8	SOLDER	
F-GE5		24	SOLDER	5-1367-1-6	
F-GE4		4	SOLDER	SOLDER	
F-GE3		24	SOLDER	5-1367-1-6	
F-GE2		4	SOLDER	SOLDER	
F-GE1	22	24	SOLDER	5-1367-1-8	

F-GD23	22	- 22 - 0	10	5-1370-1	5-1635-1
F-GD21	22		230	5-1367-1-6	5-1367-1-6
F-GD19	22		110	5-1367-1-6	5-1367-1-6
F-GD18	22		35	5-1370-1	5-1367-1-10
F-GD17	22		240	5-1367-1-6	5-1367-1-6
F-GD15	22		155	5-1367-1-6	5-1367-1-6
F-GD14	22		77	5-1367-1-6	5-1367-1-6
F-GD13	22		47	5-1367-1-6	5-1636-1
F-GD12	22		40	5-1367-1-6	5-1636-1
F-GD11	22		30	5-1367-1-6	5-1367-1-8
F-GD9	22	- 22 - 0	10	5-1635-1	5-1370-1
F-GD8	22	- 22 - 10	13	5-1635-1	5-1370-1
F-GD7	22		27	5-1635-2	SOLDER THRU SER 21060129
F-GD6	20		27	5-1635-2	SOLDER THRU SER 21060129
F-GD5	22		15	5-1367-1-10	5-1636-1
F-GD4	12		8	5-1367-3-10	5-1367-3-8
F-GD3	12		12	5-1367-3-10	5-1367-3-13
F-GD2	12		46	5-1367-3-13	5-1367-3-13 THRU SER 21061573
F-GD1	12		33	5-1367-3-8	5-1367-3-8 THRU SER 21061573

18	1ZB0800	POWER PACK ASSY
17	MS27212-1-3	TERM. BOARD
16	MS27212-1-6	TERM. BOARD
15	1Z70717-1	DIODE ASSY
14	1N2070	DIODE
13	1ZB0810-1	PRESSURE SWITCH
12	1ZB0811-1	MOTOR
11	1ZB0830-1	SOLENOID
10	5-1641-9	HOUSING
9	5-1640-9	HOUSING
8	1Z70034-1	SQUAT SWITCH
7	5-1377-1	SWITCH
6	8059K44	SWITCH
5	VM970M-3	LIGHT
4	VM911M-4A	LIGHT
3	5-1577-1	CONTACTOR
2	5-1232-30	CKT BRK
1	5-1360-5L	CKT BRK


PART NO.	DESCRIPTION	GA	MATERIAL	LG	TERMINALS	SERIALS
WIRE TABLE						
CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 8800 E. PAWNEE WICHITA, KANSAS			
DESIGN		NAME		DATE		
GROUP		H WISE		3-22-71		
DRAWN		VZ SIFES		5-11-71		
CHECK		L.K. WHITE		5-11-71		
STRESS						
PROJ		H McCARTER		5-11-71		
APPD						
OTHER						
TITLE		WIRING DIAGRAM - LANDING GEAR CONTROL SYSTEM				
SIZE	CODE IDENT. NO.	DWG NO				
C	71379	1270709				
SCALE: NONE		210		PAGE: 12.2.0		

EQUIPMENT TABLE CES-1000 IS APPLICABLE VENDOR CODES PER 8-1400 CES-1000-CESNA SPEC. NO. 8-100X OR CES1000-CESNA STD. NO.		SUPERSEDES: REV. "B" SUPERSEDED BY: P 12.3.0
--	--	---



SER 21059503

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISIONS			
LTR	DESCRIPTION	DATE	APPROVED
H	SEE P 12 Z.O FOR REVISION		




See Sheet 2



INACTIVE
EFF THRU SER (SR8464)
6.6.77
DLP
AS
7/4

CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS		
Cessna AIRCRAFT CO.			TITLE		
DESIGN	VR SIPES	3-22-71	WIRING DIAGRAM — LANDING GEAR CONTROL SYSTEM		
GROUP	H. WISE	5-11-71			
DRAWN	VR SIPES	5-7-71			
CHECK	L.K. WHITE	5-11-71			
STRESS					
PROJECT	H. McCARTER	5-11-71	SIZE	CODE IDENT. NO.	DWG. NO.
APPD			C	71379	1270709
SCALE NONE			210	PAGE. 2.2.1	

MODEL 210 & T210 SERIES SERVICE MANUAL



CONTRACT NO:			Cessna AIRCRAFT CO. COMMERCIAL AIRCRAFT DIV. 3800 E. PAWNEE WICHITA, KANSAS		
DESIGN	VE SIPES	3-22-71			
GROUP	H. WISE	5-11-71	WIRING DIAGRAM — LANDING GEAR CONTROL SYSTEM		
DRAWN	VE SIPES	5-7-71	SIZE		
CHECK	L.K. WHITE	5-11-71	CODE IDENT. NO.		
STRESS			DWG NO.		
PROJECT	H. McCARTER	5-11-71	C 71379 1270709		
APPD			SCALE: NONE 2:10 PAGE: 12.2.1		

Landing Gear Control System (Sheet 2 of 2)

SER 21059503

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES

1. INSTALL 1270717 DIODE ASSY WITH SYMBOL POINTING TOWARD POSITIVE TERMINAL ON MOTOR

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REVISION: ADD N-GD 364 N-GD37; F-GD21 HAS GD-21. F-GD30 HAS GD30 (SRB464)(SRB465)	JJB 8-29-77	JAD 1/80

INACTIVE


THRU SERIALS SR8784X(SR8785)
2-28-78
NOW IN QAS
CS
2-28

	GD37	22			S-1367-1-6	S-1367-1-6	
	GD36	22			S-1367-1-6	SOLDER	
	GD35	22			S-1370-1	S-1370-1	
	GD34	22			S-1367-1-6	S-1370-1	
	GD33	22			S-1367-1-6	S-1370-1	
	GD21	22			S-1367-1-6	S-1367-1-6	
	GD17	22			S-1367-1-6	S-1367-1-6	
	GD17 (GD1)	22	-22-10		S-1635-1	S-1370-1	
	GD4	12			S-1367-3-10	S-1367-3-8	
	GD3	12			S-1367-3-10	S-1367-3-13	
	GE4	22			SOLDER	SOLDER	
	GE2	22			SOLDER	SOLDER	
	GE1	22			SOLDER	S-1367-1-6	
	GE8	12			S-1367-3-13	S-1367-3-13	
	GE9	22			S-1367-1-8	SOLDER	
	GE10				SOLDER	SOLDER	
	GE11				SOLDER	SOLDER	
	GD25				S-1367-1-8	S-1636-1	
	GD26				S-1367-1-8	S-1367-1-6	
	GD27				S-1367-1-6	S-1370-1	
	GD28				S-1367-1-6	SOLDER	
	GD29				S-1367-1-6	S-1367-1-10	
	GD30				S-1367-1-6	SOLDER	
	GD31				SOLDER	S-1636-1	
	GD32	22			SEE GD27	S-1636-1	
	WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS		SERIALS
18	280800		POWER PACK ASSY				
16	VM920M-3		LIGHT				
15	VM911M-4A		LIGHT				
14	1N2070		DIODE				
13	S-2313		SWITCH				
12	S-1638-2		HOUSING				
11	280840		PRESSURE SW				
10	S-1638-3		HOUSING				
9	1280830		SOLENOID				
8	1270717		DIODE ASSY				
7	MS27212-1-3		TERMINAL BOARD				
6	MS27212-1-6		TERMINAL BOARD				
5	280811		MOTOR				
4	S-1377-1		SWITCH				
3	1270034		SQUAT SW				
2	S-1232-30		CKT BKR				
1	S-1360-5L		CKT BKR				
	PART NO.		DESCRIPTION				
EQUIPMENT TABLE				WIRE TABLE			
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESBNA SPEC. NO. S-XXX OR CMXXXX-CESBNA STD. NO.				SUPERSEDES: P 2.2.0		CONTRACT NO.:	
				SUPERSEDED BY: 270709 P 1240 & 1241		Cessna AIRCRAFT CO. PAWNEE DIVISION 5800 E PAWNEE WICHITA, KANSAS	
				DESIGN SPENCER 6-20-77	TITLE WIRING DIAGRAM — LANDING GEAR CONTROL SYSTEM		
				DRAWN PAPE 6-25-77			
				CHECK BORLESKE 6-7-77			
				STRESS			
				PROJ PLATEDRILL 6-25-77	SIZE C	CODE IDENT 71379	DWG NO 1270709
				APPD JJB			
				OTHER			
				SCALE: NONE	210 P2.0	PAGE 2 OF 3	

(SRB464, SRB465)

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO
A	SEE PAGE 12.3.0 FOR REVISION		




INACTIVE
 THRU SER(SR8784)(SR8785)
 2-28-78
 JAC WLM / RS
 PLD


CONTRACT NO:		PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS	
NAME	DATE	Cessna AIRCRAFT CO.	
DESIGN SPENCER	6-20-77	TITLE	
GROUP Ed Hardin	6-23-77	WIRING DIAGRAM - LANDING GEAR CONTROL SYSTEM	
DRAWN PAPE	6-6-77	SIZE	CODE IDENT
CHECK BORLESKE	6-7-77	C	71379
STRESS		OWG NO.	1270709
PROJ Ed Hardin	6-24-77	SCALE	NONE
APPO		210 P210	PAGE: 12.3.1
OTHER			

Landing Gear Control System (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL



DETAIL **AL**
(APPLIES TO P210)



INACTIVE

THRU SER(SR8784)(SR8785)
2-28-78 CS
JAS JAW/RS
P.O.

CONTRACT NO.			PAWNEE DIVISION 5800 E PAWNEE WICHITA KANSAS																				
<table border="1"> <thead> <tr> <th>NAME</th> <th>DATE</th> </tr> </thead> <tbody> <tr> <td>SPENCER</td> <td>6-20-77</td> </tr> <tr> <td>W.H. Hardman</td> <td>6-23-77</td> </tr> <tr> <td>PAPE</td> <td>6-6-77</td> </tr> <tr> <td>BORLESKE</td> <td>6-7-77</td> </tr> <tr> <td>STRESS</td> <td></td> </tr> <tr> <td>PROJ</td> <td>1-24-77</td> </tr> <tr> <td>APPD</td> <td></td> </tr> <tr> <td>OTHER</td> <td></td> </tr> </tbody> </table>			NAME	DATE	SPENCER	6-20-77	W.H. Hardman	6-23-77	PAPE	6-6-77	BORLESKE	6-7-77	STRESS		PROJ	1-24-77	APPD		OTHER		Cessna AIRCRAFT CO. TITLE WIRING DIAGRAM - LANDING GEAR CONTROL SYSTEM		
NAME	DATE																						
SPENCER	6-20-77																						
W.H. Hardman	6-23-77																						
PAPE	6-6-77																						
BORLESKE	6-7-77																						
STRESS																							
PROJ	1-24-77																						
APPD																							
OTHER																							
SIZE C		CODE IDENT NO 71379	DWG NO 1270709																				
SCALE NONE		210 P20	PAGE 2.3																				

Landing Gear Control System (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: 1670034 WAS 1270717 ; S-1367-3-12 WAS S-1367-1-12/GAI MER 210E0736 (NOW SHOP PRACTICE)	H HG 3-15-79	10/10/79 1/83
B	BY REV: MS27212-1-7 WAS MS27212-1-6. 1270717 WAS 1670034 (SR8863)(REF)	MDR 6-22-79	10/10/79 1/83
C	BY REV: ADD DETAIL "B", NOTE 5, GD49, GD50 9880710 (SR9738) S-1367-1-6 WAS S-1367-1-8/ GEG : GD26 (NOW SHOP PRACT)	RAO 12-19-79	10/10/79 1/83
D	BY REV: REACTIVATE DRAWING SR9634(REF)SR9635(REF) 38211-1 WAS 382125 (SR 3828)	DFS 7-25-80	10/10/79 1/83
E	BY REV: ADD DETAIL "C" & 51232-35 (SR10122)	JN 2-13-81	10/10/79 1/83
F	BY REV: ADD DETAIL D, & GA3 (SR10254)	TMS 10-29-81	10/10/79 1/83

NOTES :

- SYSTEM SHOWN WITH LANDING GEAR DOWN & LOCKED, ACFT ON GROUND, & POWER OFF
- PRESSURE SWITCH OPENS WHEN GEAR IS UP & HYDRAULIC PRESSURE BUILDS UP TO PROPER LEVEL
- INSTALL 1270717 DIODE ASSY WITH MARKING BAND ON DIODE TO POSITIVE TERMINAL ON PUMP MOTOR
- TERMINATE VENDOR FURNISHED WIRES WITH S-1636-1
- USE S-1694-S-0.0 SHRINKABLE TUBING OVER S-1830-1 TERMINAL

INACTIVE
THRU SER (SR1000) (SR1002)
WKT 1-27-82
JAS 8/17/84

GA3	10	S-1562-10-9	S-1367-3-12	S-1367-3-6	SER(SR10254) (ON)
GA2	10	S-1562-10-9	S-1367-3-13	S-1367-3-12	SER(SR1022) (ON)
GE10	10	S-1562-10-9	S-1367-3-13	S-1367-3-8	SER(SR1022) (ON)
GD46	22		S-1367-1-6	S-1367-1-6	
GD45			S-1367-1-6	SOLDER	
GD44			S-1367-1-6	S-1367-1-6	
GD43			S-1367-1-6	S-1367-1-6	
GD42			SOLDER	S-1370-1	
GD41			S-1367-1-6	SOLDER	
GD40	22		S-1367-1-6	SOLDER	
GAI	12		S-1367-3-13	S-1367-3-12	THRU SER(SR1022)
GD39	22	22-6-4	S-1636-1	S-1830-1	SER (SR9738) (ON)
GD38			S-1636-1	S-1830-1	SER (SR9738) (ON)
GD37			S-1367-1-6	S-1367-1-6	
GD36			S-1367-1-6	S-1367-1-6	
GD35			S-1367-1-6	S-1367-1-6	
GD34			S-1367-1-6	S-1367-1-6	
GD33			S-1367-1-6	S-1370-1	
GD32			S-1367-1-6	S-1370-1	
GD29			S-1367-1-6	S-1367-1-6	
GD26			S-1367-1-6	S-1367-1-6	
GD17			S-1367-1-6	S-1367-1-6	
GE9	22		S-1367-1-6	SOLDER	
GE8	12		S-1367-3-13	S-1367-3-13	THRU SER(SR10122)
GE4	22		SOLDER	SOLDER	
GE2	22		SOLDER	SOLDER	
GE1	22		SOLDER	S-1367-1-8	THRU SER(SR10122) (SR1002)

02-00915
0-00915

17	S-1232-35	CIRCUIT BREAKER	
16	9880710	PRESSURE SWITCH	2
15	Y2-2RN7T	SWITCH	
14	9881141	MOTOR	
13	1270717	DIODE ASSY	
12	S-1577-1	POWER PACK CONT	
11	VM920M-3	LIGHT	
10	VM911M-4A	LIGHT	
9	MS27212-1-3	TERMINAL BOARD	
8	MS27212-1-7	TERMINAL BOARD	
7	S-1377-1	SWITCH	
6	1270034	SQUAT SWITCH	
5	9880700	PRESSURE SWITCH	2
4	S-1637-1	HOUSING	
3	S-1637-2	HOUSING	
2	S-1232-30	CIRCUIT BREAKER	
1	S-1360-5L	CIRCUIT BREAKER	


WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
GA3	10	S-1562-10-9		S-1367-3-12	S-1367-3-6
GA2	10	S-1562-10-9		S-1367-3-13	S-1367-3-12
GE10	10	S-1562-10-9		S-1367-3-13	S-1367-3-8
GD46	22			S-1367-1-6	S-1367-1-6
GD45				S-1367-1-6	SOLDER
GD44				S-1367-1-6	S-1367-1-6
GD43				S-1367-1-6	S-1367-1-6
GD42				SOLDER	S-1370-1
GD41				S-1367-1-6	SOLDER
GD40	22			S-1367-1-6	SOLDER
GAI	12			S-1367-3-13	S-1367-3-12
GD39	22	22-6-4		S-1636-1	S-1830-1
GD38				S-1636-1	S-1830-1
GD37				S-1367-1-6	S-1367-1-6
GD36				S-1367-1-6	S-1367-1-6
GD35				S-1367-1-6	S-1370-1
GD34				S-1367-1-6	S-1370-1
GD29				S-1367-1-6	S-1367-1-6
GD26				S-1367-1-6	S-1367-1-6
GD17				S-1367-1-6	S-1367-1-6
GE9	22			S-1367-1-6	SOLDER
GE8	12			S-1367-3-13	S-1367-3-13
GE4	22			SOLDER	SOLDER
GE2	22			SOLDER	SOLDER
GE1	22			SOLDER	S-1367-1-8

PART NO.	DESCRIPTION
EQUIPMENT TABLE	
CES-1000 IS APPLICABLE	
VENDOR CODES PER S-1400	
CES-XXXX-CESNA SPEC. NO.	
S-XXX OR CMXXX-CESNA	
STD. NO.	
SUPERSEDES: 1270709 P 12.3.0 & 12.3.1	
SUPERSEDED BY: 1270709 P 12.6.0, P 12.6.1	

CONTRACT NO.			WIRE TABLE		
DESIGN	NAME	DATE	Cessna AIRCRAFT CO.		
DESIGN	SPENCER	3-2-78	PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS		
GROUP	W. H. H. H. H.	3-6-78	TITLE		
DRAWN	SMYER	2-28-78	WIRING DIAGRAM - LANDING GEAR CONTROL SYSTEM		
CHECK	BORLESKE	3-1-78	SIZE		
STRESS			C		
PROJ	P. H. H. H. H.	3-8-78	CODE IDENT. NO.	DWG NO	
APPD	1/83		71379	1270709	
OTHER			SCALE: NONE		
			210 P210 PAGE: 12.4.0		


(SR 8784 (SR 8785))

MODEL 210 & T210 SERIES SERVICE MANUAL




MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
F	SEE PAGE 12.4.0 FOR REVISION		



DETAIL C
EFF THRU SER (SR10122)



DETAIL D
EFF THRU SER (SR10254)

INACTIVE
THRU SER (SR10102) 1-29-82
MKT JAS J26/whit

02-80812

CONTRACT NO:		Cessna AIRCRAFT CO.		PAWNEE DIVISION 8800 E. PAWNEE, WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE		
GROUP			WIRING DIAGRAM— LANDING GEAR CONTROL SYSTEM		
DRAWN	WHITSON	2-13-81			
CHECK	BORLECKE	2-17-81			
STRESS					
PROJ	STANLEY E	3-4-81	SIZE	CODE IDENT. NO.	DWG NO.
APPD	JRS	3-3-81	C	71379	1270709
OTHER			SCALE: NONE	(SR10122)	PAGE: 12.4.2

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	PR REV: GE13 WAS GE9, GD67 WAS GD26 & GD68 WAS GD38 (SR1010)(SK0102)	JMH 4-22-82	[Signature] 1/89
B	BY REV: MS27212-1-B WAS MS27212-1-1 OBSOLETE GD64 & GD65 WIRES REVISE DETAIL A, ON GD63 WIRE. S1367-1-6 WAS S-1370-1 ADD NOTE 5, ADD N-GD63 WIRE. (SR1010)(SR10102)	GLS JMH 6-30-82	[Signature] 1/89

NOTES:

1. SYSTEM SHOWN WITH LANDING GEAR DOWN & LOCKED, ACFT ON GROUND, & POWER OFF
2. PRESSURE SWITCH OPENS WHEN GEAR IS UP & HYDRAULIC PRESSURE BUILDS UP TO PROPER LEVEL
3. INSTALL 1270717 DIODE ASSY WITH MARKING BAND ON DIODE TO POSITIVE TERMINAL ON PUMP MOTOR
4. USE S-1694-S-0.8 SHRINKABLE TUBING OVER S-1830-1 TERMINAL
5. TERMINATE VENDOR FURNISHED WIRE WITH S1367-1-6 TERMINAL.

N-GD63	22		S1367-1-6	S1367-1-6	
GD68	22		S1367-1-6	S1367-1-6	
GD67	22		S1367-1-6	S1367-1-6	
GE13	22		S1367-1-6	FOLDER	
GA3	10	S1562-10-9	S1367-3-8	S1367-3-8	
N-GD66	22		S1367-1-6	SOLDER	
N-GD63	22		S1367-1-6	S1367-1-6	
GA2	10	S1562-10-9	S1367-3-8	S1367-3-8	
GE10	10	S1562-10-9	S1367-3-8	S1367-3-8	
N-GD44	22		S1367-1-6	S1367-1-6	
F-GD43	1		S1367-1-6	S1367-1-6	
N-GD42	1		SOLDER	S1370-1	
F-GD41	22		S1367-1-6	SOLDER	

19									
18	S2527-2	GND CONNECTOR		GD62	22		S1493-1	SOLDER	
17	S2527-1	LH GND BLOCK		F-GD61	1		S1367-1-6	S1367-1-6	
16	MS25041-2	LIGHT ASSY		F-GD60	1		S1367-1-6	S1367-1-6	
15	15700-43	DIODE ASSY		F-GD59			S1367-1-6	S1367-1-6	
14	S-1232-35	CIRCUIT BREAKER		F-GD58			S1367-1-6	S1367-1-6	
13	9880710	PRESSURE SWITCH	<2>	F-GD57			SOLDER	S1367-1-6	
12	S-8506-1	SWITCH-UP LOCK		GD56			S1367-1-6	S1367-1-6	
11	9881141	MOTOR		GD55	1		S1367-1-6	SOLDER	
10	1270717	DIODE ASSY		BUSBAR	22	-22-6-4	S1636-1	S1830-1	<4>
9	S-1577-1	POWER PACK CONT		WIRE	1	-22-6-4	S1636-1	S1830-1	<4>
8	YM920M-3	LIGHT		GD48	1		S1367-1-6	S1367-1-6	
7	MS27212-1-5	TERMINAL BOARD		GD47	22		S1367-1-6	S1367-1-6	
6	MS27212-1-B	TERMINAL BOARD		GD39	1		S1635-1	S1367-1-6	
5	S-1377-2	SWITCH							
4	1270034	SQUAT SWITCH							
3	S-1637-1	HOUSING		N-GD35			S1370-1	S1370-1	
2	S-1637-2	HOUSING		N-GD33			S1367-1-6	S1370-1	
1	S1360-5L	CIRCUIT BREAKER		GD29			S1367-1-6	S1367-1-6	

EQUIPMENT TABLE		WIRE TABLE	
ITEM NO	PART NO.	DESCRIPTION	SERIALS

CONTRACT NO: _____

Cessna AIRCRAFT CO.
PAWNEE DIVISION
3800 E. PAWNEE
WICHITA, KANSAS

DESIGN: _____ NAME: _____ DATE: _____

GROUP: *Wiring* TITLE: **WIRING DIAGRAM - LANDING GEAR CONTROL SYSTEM**

DRAWN: *M. THOMPSON* 2-2-82

CHECK: *BORLESKE* 2-2-82

STRESS: _____

PROJ: *J. M. DOWE* 4-2-82

APPD: *JR6/WNH* 4-2-82

OTHER: _____

SIZE: **C** CODE IDENT. NO. **71379** DWG NO. **1270709**

SCALE: **NONE** (SR1010)(SR10102) PAGE: 12 of 60


CES-1000 IS APPLICABLE
 VENDOR CODES PER S-1400
 CES-XXXX-CESSNA SPEC. NO.
 S-XXX OR CMXXXX-CESSNA
 STD. NO.

SUPERSEDES: *P12.4.0*
1270709 *P12.4.1*
P12.4.2

SUPERSEDED BY:

MODEL 210 & T210 SERIES SERVICE MANUAL


REVISION			
LET	DESCRIPTION	DATE	APPD
B	SEE PG 12.6.0 FOR REV		



CONTRACT NO:			Cessna AIRCRAFT CO.			PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	TITLE WIRING DIAGRAM LANDING GEAR CONTROL SYSTEM					
GROUP	<i>D.H. Anderson</i>	<i>2-2-82</i>	SIZE C CODE IDENT NO. 71379 DWG NO. 1270709 SCALE NONE (SR1010)(SR1002) PAGE 12.6.1					
DRAWN	<i>M. THOMPSON</i>	<i>2-2-82</i>						
CHECK	<i>BORLESKE</i>	<i>2-2-82</i>						
STRESS								
PROJ	<i>J.W. MOORE</i>	<i>4.2.82</i>						
APPD	<i>PRS</i>							
OTHER								

Landing Gear Control System (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL




DETAIL A
(APPLIES TO P210 ONLY)


CONTRACT NO:			PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE			
GROUP	<i>W. H. ...</i>	<i>1-2-82</i>	WIRING DIAGRAM		
DRAWN	M. THOMPSON	2-2-82	LANDING GEAR		
CHECK	BORLESKE	2-2-82	CONTROL SYSTEM		
STRESS			SIZE	CODE IDENT NO	DWG NO.
PROJ	J. W. MOORE	4-2-82	C	71379	1270709
APPD	<i>JRG</i>		SCALE NONE (SR1010) (SR1002) PAGE 12 6.1		
OTHER					

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: ADD WIRE LENGTH (NOW SHOP PRACTICE)	JLO 5-3-75	JCY 11/10/75 V.M.
B	BY REV: C669520-0102 WAS C669502-0301 (SR7913)	BAH 1-30-74	JCY 1/15/74
C	BY REV: S-2041-50-1.6 WAS RH-50; DELETE ILGA JUMPER; 7 WAS 15/F-HC9 ADD F-HC5 (NOW SHOP PRACTICE) (MER 410-E0102)	MEM 9-3-74	JLO 7/1/74 1/10/74 JAS
D	BY REV: (SR8065) WAS (SR7050) PER REV 'B' (SR7913)	RAM 9-25-74	JCY 1/15/74
E	BY REV: SER IN F-HC6 S-1360-15L, SER OUT F-HC5 (SR7913)(MER E0820)	BLA 10-30-74	JCY 1/15/74 1/10/74
F	BY REV: (SR7913) WAS (SR8065) PER REV 'B' (SR7913)	CJH 27-75	JCY 1/15/75
G	BY REV: C669502-0301 WAS C669520-0102 (SR7913)	GS 8-27-75	JCY 1/15/75 1/10/75



SER (SR7913) & ON
(21061040)



THRU SER (SR7913)
(21061039)

INACTIVE
EFF THRU (SR8065)
SEE W/M 4-18-77
JCY 2/74

F-HC6	16			SOLDER	S-1367-2-B	SER 21061040 & ON
F-HC5	16		10	S-1367-2-A	S-1367-2-B	THRU SER 21061039
F-HC4	16		17	SOLDER	S-1367-2-B	
WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS		SERIALS

QTY	PART NO.	DESCRIPTION
6	S-1360-15L	CIRCUIT BREAKER
5	S-2041-50-1.6	RESISTOR
4	OS/3032-3	CIGAR LIGHTER
3	C669302-0301	INST CLUSTER
2	60232-1	CIRCUIT BREAKER
1	S-1396-20L	CIRCUIT BREAKER

EQUIPMENT TABLE			WIRE TABLE		TITLE	
CONTRACT NO:	NAME	DATE	COMMERCIAL AIRCRAFT DIV. CESSNA AIRCRAFT CO. 5800 E. PAWNEE WICHITA, KANSAS		WIRING DIAGRAM — CIGAR LIGHTER	
DESIGN	VR SIPES	1-28-71	SIZE		CODE IDENT NO.	
GROUP	H. WILSON	2-26-71	C		71379	
DRAWN	VR SIPES	2-18-71	DWG NO.		1270709	
CHECK	L.K. WHITE	2-24-71	SCALE		NONE	
STRESS			PAGE		210	
PROJ	Nim Carter	2-27-71	OTHER		PAGE 13/1	
APPO						

CESS-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CESS-1000-CESSNA SPEC. NO.
S-1001 OR CESSNA-CESSNA
STD. NO.


SUPERSEDES:
12210-1073
SUPERSEDED BY:
P13.1

(SR6755) II (21059503)



MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:


1. S-1369-3 TERMINAL ADDED TO VENDOR SUPPLIED WIRE
2. HEATER CIRCUIT SHOWN ONLY, FOR STALL WARNING CIRCUIT SEE PAGE 15.1
3. S-1637-1 HOUSING & S-1635-1 PIN ADDED TO VENDOR SUPPLIED WIRE.



INACTIVE



REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: SER OUT BLU(1), BLU(2) BLK SER IN BLU(3), BLU(4) & BLK(1); ADD DETAIL 'A' & SER. (SR7320)	JCY 11-6-72	JAB
B	BY REV: ADD NOTE 3; S-1636-2 WAS S-1369-2 (BLU(3)); (NOW SHOP PRACTICE)	MEM 5-9-74	JAB
C	BY REV: 18 GA WAS 16 GA / F-HAG, F-HA7, BLUE(3), BLUE(4), S-1493-1 WAS S-1493-2, S-1367-1 WAS S-1367-2 & S-1636-1 WAS S-1366-2... (SR8143)	GDS 5-6-76	JAB
D	BY REV: ADD DETAIL B (C) SER (SR8464)(SR8465)	LSS DUB 6-6-77	JAB
E	BY REV: S-2099-5/ BLU (HAG4) WAS 660007, S-2353-1/N-HAG4 WAS 66098-7 (SR8464)(SR8465)	JJB 8-29-77	JAB



12	S-2349-1	CONNECTOR	
11	S-2350-1	CONNECTOR	
10	S-2160-1	SWITCH	
9	S-1350-10L	CIRCUIT BREAKER	
8	S-1637-2	HOUSING - PLUG	
7	S-1637-1	HOUSING - CAP	
6	0721105-18	PITOT TUBE, HEATED	
5	S-1641-9	HOUSING-SOCKET	
4	S-1640-9	HOUSING - PIN	
3	S-845-1-2	SWITCH	
2	1221095-3	HEATED STALL DETECTOR	
1	S-1360-8L	CIRCUIT BREAKER	

BLU (HAG5)	18		S-1636-2	S-2099-5	
HAG5	18		S-1367-6	S-1493-1	
N-HAG4	18		S-1493-1	S-2353-1	
BLK (1)	18	S-1460-18-0	S-1636-2	S-1367-8	SER21059864 & ON
BLU (4)	18	S-1460-18-6	S-1635-2	S-1636-2	SER21059864 & ON
BLU (3)	18	S-1460-18-6	S-1636-2	S-1636-2	SER21059864 & ON
BLACK	18	S-1460-18-0	S-1369-1	S-1367-8	THRU SER 21059863
BLU(2)	16	S-1460-16-6	S-1635-2	S-1369-2	THRU SER 21059863
BLU(1)	16	S-1460-16-6	S-1635-2	S-1369-2	THRU SER 21059863
F-HA7	18		S-1493-1	S-1636-1	
F-HAG	18		S-1367-1	S-1493-1	




PART NO.	DESCRIPTION
EQUIPMENT TABLE	
CES-1000 IS APPLICABLE	SUPERSEDES: 12210-1073
VENDOR CODES PER S-1400	SUPERSEDED BY: 23 3. 6
CES-XXX-CESSNA SPEC. NO.	
S-XXX OR CMXXX-CESSNA	
STD. NO.	

CONTRACT NO:			WIRE TABLE	
DESIGN	NAME	DATE	SIZE	CODE IDENT NO.
VR SIPES		1-28-71	C	71379
GROUP	N. White	2-26-71		
DRAWN	VR SIPES	2-18-71		
CHECK	L.K. WHITE	2-24-71		
STRESS				
PROJ	11-1-71	2-27-71		
APPD	JAB			
OTHER				
COMMERCIAL AIRCRAFT DIV 5800 E. PAWNEE WICHITA, KANSAS			Cessna AIRCRAFT CO. WIRING DIAGRAM - HEATED PITOT TUBE & HEATED STALL WARNING SYSTEM	
SCALE: NONE			210 P210	
			PAGE: 13 2	

(SR 6755) J
21059863

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	JLO 3-2-73	BY 7/10/73
B	BY REV: 226A WAS 186A/ HA 31, HA 32, HA 33 (SR843)	GDS 5-6-76	BY 7/10/73
C	BY REV. ADD DETAIL "A" / SER (8465)(SR8464)	LSS 6-6-77	JAD W/RE 7/10/73
D	BY REV: S-2160-3 WAS S-2160-1 (SR8464)(REF)(SR8465)(REF)	DLP 12-9-77	JAD W/RE 7/10/73
E	BY REV: ADD DETAIL "B" S2527-1), BLK(F-NHA113); SER OUT F-NHA 55 (SR1010) (SR1012)	MKT 1-27-82	JAD W/RE 7/10/73
F	BY REV: BLK(FN-HA125) WAS BLK(FN-HA113) (SR1010) (SR1012)	RNJ 5-5-82	JAD W/RE 7/10/73



HA 32	22	-22-0	S-1367-6	S-2079-4	SER(SR8464) / ON	
HA 71	22		S-1370-1	S-1493-1	SER(SR8464) / ON	
HA 70	22		S-1367-6	S-1493-1	SER(SR8464) / ON	
F-HA33	22		12	S-1367-1	S-1367-1	THRU SER(SR1010)(SR1012)
F-HA32	22		29	SOLDER	S-1370-1	THRU SER(SR8464)
F-HA31	22		18	S-1367-6	SOLDER	THRU SER(SR8464)

PART NO.	DESCRIPTION	VENDOR
7	S2527-2 GND CONNECTOR	
6	S2527-1 LH GND BLOCK	
5	S-2160-3 SWITCH	
4	M625338-7079 LAMP	
3	#11-225 LAMPHOLDER	(95263)
2	S-1284-1 SWITCH	
1	S-1360-BL CIRCUIT BREAKER	

EQUIPMENT TABLE			WIRE TABLE		
CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN V R SIPS 1-28-71			TITLE WIRING DIAGRAM - LIGHT, ICE DETECTOR (OPT)		
GROUP W N LAD 2-25-71			DRAWN V R SIPS 2-18-71		
CHECK L. WHITE 2-24-71			STRESS		
PROJ W. White 2-27-71			SIZE C		
APPD			CODE IDENT. NO. 71379		
OTHER			DWG NO. 1270709		
SCALE: NONE			210 P210 PAGE: 13 5		

CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX-CESNA SPEC. NO.
S-XXX OR CMXXX-CESNA
STD. NO.


SUPERSEDES:
12210-1073

SUPERSEDED BY:

(5A6755) II
21059503

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: 226A WAS 20 GA / HA16 THRU HA19 (SR8143)	GDS 5-6-76	JUN /
B	BY REV: ADD HA 76,77(78, DETAIL "A"; DWG BECOMES INACTIVE (SR8464)(SR8465)(SR8863)	LSS 6-21-77	JAN /
C	BY REV: DELETE DETAIL "A"; DWG INACTIVE THRU SR8464, WAS SR8863, HA16 WAS HA77, HA18 WAS HA78, HA20 WAS HA76 (SR8464)	CRS 9-14-77	JAN /



INACTIVE
THRU SER(SR8464)
LSS 1/16/78
JAN 1/85

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
HA20 18		SEE HA16	S-1370-1		
HA18 22		SOLDER	SOLDER		
HA16 22		S-1367-24	SOLDER		
F-HA23 18		S-1367-18	SOLDER		
F-HA22 18		S-1370-1	SOLDER		
F-HA21 18		S-1370-1	S-1367-18		
F-HA20 18		SEE HA16	S-1370-1		
F-HA19 22		SOLDER	S-1367-18		
F-HA18 22		SOLDER	SOLDER		
F-HA17 22		SOLDER	S-1367-18		
F-HA16 22		S-1367-24	SOLDER		

PART NO	DESCRIPTION	VENDOR
7 301748-2	SWITCH & TIMER (25472)	
6 301542-03	CONTROL VALVE (25472)	
5 101194-1	PRESSURE SWITCH(25472)	
4 S-1360-5L	CIRCUIT BREAKER	
3 MS3106ARS-3	CONNECTOR	
2 MS25041-3	INDICATOR LIGHT	
1 MS25237-327	LAMP	


CONTRACT NO:			Cessna AIRCRAFT CO.		COMMERCIAL AIRCRAFT DIV 5800 E. PAWNEE WICHITA KANSAS
DESIGN	NAME	DATE	TITLE		
VR SIPS		1-28-71	WIRING DIAGRAM -		
GRQP	H. Will	2-26-71	WING DE-ICING SYSTEM		
DRAWN	VR SIPS	2-18-71	(OPTIONAL)		
CHECK	L.E. WHITE	2-24-71			
STRESS					

PART NO	DESCRIPTION	VENDOR
EQUIPMENT TABLE		
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESNA SPEC. NO S-XXX OR CMXXXX-CESNA STD. NO.		
SUPERSEDES 12210-1073		
SUPERSEDED BY P 13.10		


PROJ	APPD	OTHER	SIZE	CODE IDENT NO	DWG NO
J. Will	J. Will		C	71379	1270709
SCALE NONE			210	PAGE 3.3	

SR 6755, II
210595C3

MODEL 210 & T210 SERIES SERVICE MANUAL



REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: SER OUT HD1, HD2, HD3 & 112-507-101 SER IN 5-382-2 ADD HD4, HD5, HD6, 5-1360-8L & 5-382-2 (SR8143)	RS 4-1-74	JAY HRS
B	BY REV: ADD DETAIL "A" (SER (SR8143) THRU SER (SR8464), HD7 & HD8 (SR8464) (SR8465)	LSS 6-6-77	JAS HRS
C	BY REV: REACTIVATE DWG (SR818A) (SR818B)	CMK 7-6-78	JAS HRS
D	BY REV: ADD DETAIL "B" (52527-2) & BLK (FN-HD20); SER OUT HD-6 (SR10101) (SR10102)	MKT 1-27-82	MS HRS



01-00916 02-00916

PART NO.	DESCRIPTION
9	52527-2 GND CONNECTOR
8	52527-1 LH GND BLOCK
7	5-1360-5L CIRCUIT BREAKER
6	5-2160-1 SWITCH
5	5-382-2 SWITCH
4	5-1360-8L CKT BREAKER
3	1513460 HEATER
2	HPT07E8-25 RECEPTACLE
1	5-382-2 CIRCUIT BREAKER SW

WIRE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
20	-20-0	SOLDER	52099-4		SER (SR10101) (SR10102) / ON
HD8	20	SOLDER	5-1493-1		SER (SR8143) / ON
HD7	20	5-1367-1-6	5-1493-1		SER (SR8143) / ON
HD6	20	SOLDER	5-1367-1-6	SER (SR8143)	THRU SER (SR10101) (SR10102)
HD5	20	5-1367-1-6	5-1367-1-6		SER (SR8143) THRU SER (SR8464)
HD4	20	5-1367-1-6	5-1367-1-6		SER (SR8143) THRU SER (SR8464)
HD3	18	SOLDER	5-1367-1-6		THRU SER (SR8143)
HD2	18	5-1367-1-6	SOLDER		THRU SER (SR8143)
HD1	18	5-1367-1-6	5-1367-1-6		THRU SER (SR8143)

EQUIPMENT TABLE	
PART NO.	DESCRIPTION
SUPERSEDES:	
SUPERSEDED BY:	
PG. 13.12	

CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE	
DESIGN	VR SIPS	12-11-74	WIRING DIAGRAM -	
GROUP	W. Handman	12-12-74	WINDSHIELD ANTI-ICE SYSTEM	
DRAWN	CT HESSMAN	12-3-74	(OPT)	
CHECK	J. Youel	12-10-74		
STRESS				
PROJ	U. Miller	12-18-74	SIZE	CODE IDENT.
APPD	JK		C	71379
OTHER			DWG NO	1270709
SCALE: NONE			210 (SR 7913)	PAGE: 13.7

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

1. FOR COMPLETE INSTL (3) THREE EACH OF THESE WIRES ARE REQUIRED
2. THESE WIRES TO BE PER MIL-W-8044/12-18-9

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD DETAIL "A", F-HA66, F-HA67, S-2160-1 (SER; C662503-0103 WAS C622503-0106 (SRB465)(SRB464)	LSS 6-6-77	JAS DWR JAS
B	BY REV: ADD F-HA79, ADD F-HA39, C662503-0103 (22-310-20/DETAIL "B"; F-HA79 WAS F-HA39; SER OUT 1201080 (SRB464)(SRB465)	JJB 8-29-77	JAS DWR JAS
C	BY REV: S-1367-2-6 WAS S-1367-2-13/ HA41, HA42 & HA43 (NOW SHOP PRACTICE)	HGG 2-20-79	JAS DWR JAS
D	BY REV: ADD RED (F-HA106), BLK (F-HA107), S-1637-1, & S-1637-2. RED (F-HA66) WAS HA66 & BLK (F-HA67) WAS HA67. S-1367-2-8 & S-1636-2 WAS SOLDER/HA66 & HA67 (MER 206 EOTTD) HA6A WAS 22 GA/HA66, HA67, HA107, HA106. (USE AS IS PARTS IN WORK, & FINISHED PARTS)	MDR 5-22-79	JAS DWR JAS
E	BY REV: ADD DETAIL "B" (NOW SHOP PRACTICE)	BLY 8-7-80	JAS DWR JAS

15	C40055	BRUSH BLOCK
14	C40057	BRACKET
13	S-1637-2	CONNECTOR
12	S-1637-1	CONNECTOR
11	S-2160-1	SWITCH
10	D40106	SLIP RING ASSY
9	C40010	BRUSH BLOCK ASSY
8	C165020-0101	TIMER
7	M53106AD20-15.5	PLUG
6	M53057-12A	CLAMP
5	1201080	CABLE ASSY
4	22-370-20	SHUNT
3	C662503-0103	AMMETER
2	S-382-2	SWITCH
1	S-1360-20L	CKT BREAKER

BLK (F-HA107)	14	-14-0	SOLDER	S-1635-2	
RED (F-HA106)	14	-14-2	SOLDER	S-1635-2	
F-HA79	14		S-1367-2-8	SOLDER	
F-HA67	14	-14-0	S-1367-2-8	S-1636-2	
F-HA66	14	-14-2	S-1367-2-8	S-1636-2	
F-HA73	14		S-1367-2-12	S-1493-2	
F-HA72	14		S-1367-2-14	S-1493-2	
F-HA36	1B	2	S-1367-1-6	S-1367-1-6	
F-HA35	1B	2	S-1367-1-6	S-1367-1-6	
F-HA34	1B	2	S-1367-1-6	S-1367-1-6	
F-HA43	14		S-1367-2-10	S-1367-2-6	
F-HA42	14		105 SOLDER	S-1367-2-6	
F-HA41	14		105 SOLDER	S-1367-2-6	
F-HA40	14		25 SOLDER	S-1367-2-8	
F-HA39	14		70 S-1367-2-12	SOLDER	
F-HA38	14		27 S-1367-2-10	S-1367-2-12	
F-HA37	14		32 S-1367-2-10	S-1367-2-10	

ITEM NO	PART NO.	DESCRIPTION
EQUIPMENT TABLE		

WIRE TABLE		
CONTRACT NO:	NAME	DATE
DESIGN		
GROUP	JRS	4-28-76
DRAWN	SWANSON	4-1-76
CHECK	YOWEL	4-7-76
STRESS		
PROJ	RHODELICK	4-28-76
APPD	JAS	
OTHER		

COMMERCIAL AIRCRAFT DIV.
5800 E. PAWNEE
WICHITA, KANSAS

Cessna AIRCRAFT CO.

TITLE
**WIRING DIAGRAM -
PROP DE-ICING SYSTEM
3 BLADE (OPTIONAL)**


SCALE: NONE	SRB143	PAGE: 3 B
-------------	--------	-----------

CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX-CESSNA SPEC. NO.
S-XXX OR CMXXXX-CESSNA
STD. NO.

SUPERSEDES:
PG. 13. 4

SUPERSEDED BY:



MODEL 210 & T210 SERIES SERVICE MANUAL



CONTRACT NO:		COMMERCIAL AIRCRAFT DIV. 8800 E. PAWNEE WICHITA, KANSAS	
NAME	DATE	Cessna AIRCRAFT CO.	
DESIGN		TITLE	
GROUP	4-1-76	WIRING DIAGRAM—	
DRAWN	SWANSON	PROP DE-ICING SYSTEM	
CHECK	YOUNG	3 BLADE (OPTIONAL)	
STRESS			
PROJ	ALBRECHT	SIZE	CODE IDENT. DWG NO
APPD	WIS	C	71379 1270709
OTHER		SCALE: NONE	SR8143 PAGE: 13. B

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD HC10 SR8464(SR8465)	CRS 9-14-77	AS DUB 1/15
B	BY REV: ADD DETAIL A & SER: SER OUT HC7 & HCB; SER IN HC11 & HC12 (SR8784)(REF)(SR8785)(REF)	CRS 10-9-79	GSA EMP. K.C.



INACTIVE
THRU SER(SR10033)
SW 112-81
1/1

WIRE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
HC12	18			SOLDER SOLDER	SER(SR8784)(SR8785) & ON
HC11	18			SOLDER SOLDER	SER(SR8784)(SR8785) & ON
HC10	18			S-1493-1 S-1367-1-B	
HC9	18			SOLDER	S-1367-1-B
HCB	18			SOLDER SOLDER	THRU SER(SR8784)(SR8785)
HC7	18			SOLDER	S-1367-1-B THRU SER(SR8784)(SR8785)

PART NO.	DESCRIPTION
5	S-1360-10L CIRCUIT BREAKER
4	S-2375-7.5 FUSE
3	S-2374-7.5 FUSEHOLDER
2	S-2041-50-1.6 RESISTOR
	OS13CSZ CIGAR LTR ASSY

CONTRACT NO: _____

Cessna AIRCRAFT CO. PAWNEE DIVISION, 3800 E. PAWNEE, WICHITA, KANSAS

DESIGN: SPENCER 5-2-77
 GROUP: D.J. Anderson 4-28-77
 DRAWN: P. YOUNGERS 4-28-77
 CHECK: J. YOUEL 4-28-77
 STRESS: _____
 PROJ: _____ 5-2-77
 APPD: _____
 OTHER: _____

TITLE: **WIRING DIAGRAM - CIGAR LIGHTER**

SIZE: C CODE IDENT. NO. 71379 DWG NO. 127C709

SCALE: NONE (SR8464)(SR8465) PAGE 3-9


EQUIPMENT TABLE	
CES-1000 IS APPLICABLE	SUPERSEDED BY:
VENDOR CODES PER S-1400	P 13-1
CES-XXXX-CESSNA SPEC. NO.	SUPERSEDED BY:
S-XXX OR CMXXXX-CESSNA	
STD. NO.	

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPRO
A	BY REV: ADD DETAIL "A" (SR9927)(SR8464)(SR8465)	CRS 9-14-77	JAS [Signature]
B	BY REV: DELETE DETAIL A, DELETE HAS2, DELETE NOTE 2; DELETE 3D2346-01 DWG BECOMES INACTIVE	CRS 11-22-77	JAS [Signature]
C	BY REV: (SR9927) WAS (SR8863)/REV "B" INACT VATION SR (SR9927)	GDA 10-4-78	REV [Signature]

NOTES:

▷ TERMINATE VENDOR FURNISHED WIRE WITH S-1557-2 CAP



INACTIVE
THRU SER (SR9927)
CRS 11-22-77
JAS [Signature]
PLD

HA 84	22		S-1493-1	SOLDER		
HA 80	20		S-1367-1-B	SOLDER		
HA 82			SEE HA50	SOLDER		
HA 51			S-1367-1-B	S-1370-1		
HA 50			S-1493-2	S-1370-1		
HA 49			SEE HA48	S-1370-1		
HA 48	20		S-1367-1-B	S-1493-2		
HA 47	22		S-1493-1	S-1367-1-B		
HA 46			S-1493-1	SOLDER		
HA 45			SOLDER	S-1367-1-B		
HA 44	22		S-1367-1-B	SOLDER		

PART NO.	DESCRIPTION
9 MS3106A-123-33	CONNECTOR
8 3D1542-03	CONTROL VALVE
7 3D2495-02	TIMER MODULE
6	
5 S-2160-3	SWITCH
4 1D1194-1	PRESSURE SWITCH
3 MS25041-3	INDICATOR LIGHT
2 MS25237-327	LAMP
1 S-1232-5	CIRCUIT BREAKER

WIRE TABLE			
CONTRACT NO:	NAME	DATE	TITLE
	SPENCER	6-20-77	WIRING DIAGRAM — WING & STABILIZER DE-ICING SYSTEM (OPT)
	L. STOREY	6-6-77	
	BOXLESKE	6-7-77	
Cessna, AIRCRAFT CO. PAWNEE DIVISION 3000 E. PAWNEE WICHITA, KANSAS			
DESIGN	DATE	GROUP	SIZE
DRAWN	DATE	CHECK	CODE IDENT. NO.
STRESS	DATE	APPRO	DWG NO.
		OTHER	1270709
CEBS-1000 IS APPLICABLE VENDOR CODES PER S-1400 CEBS-1000-CESBNA SPEC. NO. S-1001 OR CH1000-CESBNA STD. NO.		SUPERSIDES: PG. 136 SUPERSIDED BY: 1270709 P 13.13.0; 13.13.1	
SCALE: NONE		(SR8464)(SR8465) PAGE: 3/10	

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

1. HEATER CIRCUIT SHOWN ONLY. FOR STALL WARNING CIRCUIT SEE PAGE 15.5
2. TERMINATE VENDOR LEAD WITH S-1635-1
3. TERMINATE VENDOR LEAD WITH S-1367-1-6
4. S-1557-2 CAP UNUSED VENDOR LEADS FROM SWITCH
5. INTERTWINE HA108, HA109 & HA110 WITH HAS3, HAS4, HAS5 & HA60 PER P210. INTERTWINE HA111, HA112 & HA110 WITH HAS3, N-HA64 & NHA69. PER P210.

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: S-2099-5/ORN(U-HA74) WAS 66100-7, S-2353-1/N-HA68 WAS 66098-7 (SR846)(SR8465)	JJB 8-29-77	JAB 108 JKS 212
B	BY REV: 186-9 WAS S-1672-4 (NOW SHOP PRACTICE)	PSM 12-6-78	JAB 108 JKS 212
C	BY REV: SER OUT DETAIL A, DETAIL B; SER IN DETAIL A, HA100, HA101, HA102 HA103, HA104; ADD FLAGNOTE & C PG 13.11-2 (SR930)	LWF 2-13-79	CMK 108 JKS 212
D	BY REV: MS 27212-1-7 WAS MS27212-1-6 REWARE SQUAT SWITCH & RESISTOR. S-1367-2-6 WAS SOLDER/HAS5. S-1367-2-6 WAS S-1370-2/HA56. S-1367-2-6 WAS S-1370-2/HA57. S-1367-2-6 WAS SOLDER/HA58. S-1367-2-6 WAS SOLDER/HA68. S-1367-2-8 WAS SOLDER/HA103. REVISE PIN #'S/S-1640-9, S-441-3 S-2349-1, S-2350-1 (SR8863)(AEF)	MDR 6-22-79	JAB 108 JKS 212
E	BY REV: HA-108 WAS HA-100, HA109 WAS HA-101, HA110 WAS HA-102, HA-111 WAS HA-103, HA-112 WAS HA-104. (SR 931)(REV)	MKM 8-1-80	JAB 108 JKS 212
F	BY REV: ADD DETAIL C & SERIALS. ADD HA113 WIRE & STALL WARN WENT SWITCH & CIRCUIT BREAKER. (SR10356)	WHA 1-15-82	JAB 108 JKS 212
G	BY REV: MS27212-1-8 WAS MS27212-1-7/ITEM 12 (SR10101)(SR10102)	GLS 6/28/82	JAB 108 JKS 212

10.00016.02.00010.11

ITEM NO	DESCRIPTION	QTY	MATERIAL	LG	TERMINALS	SERIALS
HA113	16		S-1367-2-6	S-1493-2		SER(SR10356) & ON
HA112	16		S-1636-2	S-2099-5	5	SER(SR930) & ON
HA111	16		S-1367-2-6	S-2353-1	5	SER(SR930) & ON
HA110	16		S-1635-2	SOLDER	5	SER(SR930) & ON
HA109	16		S-1635-2	S-1636-2	5	SER(SR930) & ON
HA108	16		S-1367-2-6	S-1636-2	5	SER(SR930) & ON
N-HA68	16		S-1367-2-6	S-2353-1		
ORN (U-HA74)	16	-16-3	S-1636-2	S-2099-5		
BLK (HA62)	20	-20-0	S-1636-2	S-1367-1-B		
BLU (HA62)	16	-16-6	S-1635-2	S-1636-2		
BLK (HA62)	20	-20-0	SOLDER	S-1367-1-B		THRU SER(SR930)
HA60	16		S-1635-2	SOLDER	5	
HAS9			S-1635-2	S-1636-2	5	
HAS8			S-1367-2-6	S-1636-2		
HAS7			SOLDER	S-1367-2-6		
HAS6			SOLDER	S-1367-2-6		
HAS5			SEE HAS4	S-1367-2-6		
HAS4			S-1493-2	S-1636-2	5	
HAS3	16		S-1367-2-6	S-1493-2	5	

17	S-1360-10L	CIRCUIT BREAKER
16	S-2349-1	CONNECTOR
15	S-2350-1	CONNECTOR
14	S-1641-6	HOUSING - PIN
13	S-1640-6	HOUSING - PIN
12	MS 27212-1-8	TERMINAL BOARD
11	1CH1-6	SQUAT SWITCH
10	S-2091-50-15	RESISTOR
9	186-9	HEATED STALL DETECTOR
8	ANSB12-1	HEATED PITOT TUBE
7	AN 3115-1	RECEPTACLE
6	S-1637-1	HOUSING - CAP
5	S-1637-2	HOUSING - PLUG
4	S-1640-9	HOUSING - PIN
3	S-1641-9	HOUSING - SOCKET
2	S-2160-1	SWITCH
1	S-1360-15L	CIRCUIT BREAKER

WIRE TABLE


CONTRACT NO:		Cessna AIRCRAFT CO.		PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	SPENCER	DATE	6-20-77	TITLE	
GROUP	W.H. Harsh	DATE	6-25-77	HEATED PITOT TUBE & HEATED STALL	
DRAWN	L. STOREY	DATE	6-6-77	WARNING SYSTEM - KNOWN ICING (OPT)	
CHECK	BOKLESKE	DATE	6-7-77		
STRESS					
PROJ	D. HERRICK	DATE	6-24-77	SIZE	CODE IDENT. NO.
APPD	JAB			C	71379
OTHER				DWG NO	1270709
SCALE: NONE				210 P/EO PAGE: 13 11.0	

ITEM NO	PART NO.	DESCRIPTION
EQUIPMENT TABLE		
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESSNA SPEC. NO. S-XXX OR CMXXXX-CESSNA STD. NO.		
SUPERSEDES:		
SUPERSEDED BY:		


(SR8863)

MODEL 210 & T210 SERIES SERVICE MANUAL


REVISIONS			
LTR	DESCRIPTION	DATE	APPROVED
F	SEE PAGE 13.11.0		




DETAIL **A**
(APPLIES TO 210 & T210)
THRU SER (SR9310)



DETAIL **A**
(APPLIES TO P210)
SER (SR9310) & ON



DETAIL **B**
THRU SER (SR9310)



DETAIL **C**
THRU SER (SR1099)


CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE			
GROUP	LW FINE	4-5-79	WIRING DIAGRAM		
DRAWN	LW FINE	2-22-77	HEATED PITOT & HEATED STALL		
CHECK	CKING	2-15-79	WARNING SYSTEM-KNOWN KING (OPT)		
STRESS			SIZE	CODE IDENT. NO.	DWG NO.
PROJECT	210 P210	2-22-79	C	71379	1270709
APPD			SCALE: NONE T210 P210 PAGE: 13.11.2		

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

- 1. TERMINATE VENDOR FURNISHED WIRES WITH S-1635-2
- 2. TERMINATE VENDOR FURNISHED WIRES WITH S-1635-1
- 3. INTERTWINE HD19 WITH HD16 & HD12 FROM POINT OF ORIGIN TO TERMINATION POINT

LET	DESCRIPTION	DATE	APPRO
A	BY REV'S ADD S-1636-4, S-1638-5, NOTES 1 & 2, ADD HD15, HD16, HD17 & HD18; NPH43501 WAS SKES67; IN TITLE BLOCK: KNOWN ICING W/S SERVICE (SR8863)	CRS 11-22-77	JAS JAS
B	BY REV: ADD FLA NOTE 8; SER OUT HD16; SER IN HD19 (SR8810)	LWF 2-15-78	CMK JAS
C	BY REV: ADD DETAIL "B" & SER (SR 9806)	NRL 8-8-80	JAS JAS
D	BY REV: DELETE DETAIL "B" & THRU SER (SR9806) "NOW SHOP PRACTICE"	DES 7-21-81	JAS JAS
E	BY REV: ADD S-2527-1 & 2, S-2099-4 WAS S-1367-2-10/HAS & HALL (SR1001) (SR1002) (SR1003) (SR1004) (SR1005) (SR1006) (SR1007) (SR1008) (SR1009) (SR1010) (SR1011) (SR1012) (SR1013) (SR1014) (SR1015) (SR1016) (SR1017) (SR1018) (SR1019) (SR1020)	TWE 7-21-83	JAS JAS



DETAIL A THRU SER (SR 9810)

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
HD19	16			S-1636-2 S-1367-2-8	SER (SR9810) EON
HD18	22			S-1367-2-8 S-1636-1	
HD17	22			S-1367-2-8 S-1636-1	
HD16	16			S-1636-8 S-1367-3-10	THRU SER (SR9810)
HD15	16			S-1367-2-8 S-1636-2	
HD14	16			S-1493-2 S-1367-2-8	
HD13	16			S-1367-2-6 S-1493-2	
HD12	16			S-1367-2-6 S-1367-2-8	
HD11	16			S-1367-2-8 S-2099-4	
HD10	16			S-1367-2-8 S-1367-2-8	
HD9	16			S-1367-2-8 S-2099-4	

PART NO.	DESCRIPTION
10	S-2527-2 GND CONNECTOR
9	S-2527-1 LH GND BLOCK
8	NPH43501 PANEL
7	S-1638-4 HOUSING - CAP
6	S-1638-5 HOUSING - PLUG
5	1N-2070 DIODE
4	KRP3DH RELAY
3	9910216 CONTROLLER
2	S-2160-1 SWITCH
1	S-1360-15L CIRCUIT BREAKER

WIRE TABLE

CONTRACT NO: _____

DESIGN: SPENCER 6-20-77
 GROUP: W. H. D. 6/23/77
 DRAWN: L. STOREY 6-6-77
 CHECK: BORLESKE 6-7-77
 STRESS: _____
 PROJ: PINE DRILL 6-24-77
 APPD: JAS
 OTHER: _____

Cessna AIRCRAFT CO. PAWNEE DIVISION
 5800 E. PAWNEE WICHITA, KANSAS

TITLE: **WIRING DIAGRAM - WINDSHIELD ANTI-ICE SYSTEM KNOWN ICING (OPT)**

SIZE: C CODE IDENT: 71379 DWG. NO: 1270709

SCALE: NO. 1/E 210 P210 PAGE: 13.12

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESNA SPEC. NO. S-1000 OR C10000-CESNA STD. NO.

SUPERSEDED BY: PG 13-16

MODEL 210 & T210 SERIES SERVICE MANUAL

D	BY REV: ADD HA127 WIRE, GND (REF) & CIG5022-0101. (SR10650)	WHAH 3-22-85	BY REV: <i>MS</i>	REVISION			
				LET	DESCRIPTION	DATE	APPRO
E	BY REV: HA126 WAS HA14/FIELD & REV 'B' (NOW SHOP PRACTICE) ADD HA128, HA129; BLU (REF) & WHT (REF) WAS BLK (REF) (SR10396) (REF) THRU SER (SR9953) (SR9954) WAS THRU SER (SR10396) / DETAIL 'B'; ADD DETAIL 'B' & HA130 (SR9953) (REF) (SR9954) (REF) ADD GND BLOCK, S-2099-4 WAS S-1367-1-B/HAS1 MER210ED1022. (SR10101) (REF) (SR10102) (REF) MER P210E01046 MER210ED989	TMS 7-21-83	RE: <i>WHT</i> <i>MS</i>	A	BY REV: S-1370-1 WAS SEE HAS0/HAS2 YEL (REF) WAS BLU/WHT (REF); VIO (REF) WAS BLU (REF); WHT/BLU (REF) WAS YEL (REF); MOVED 3D2346-01 FROM S-2160-3 TO 3D2600-03; 3D2366-01 WAS 3D2346-01; (SR9927) WAS (SR0863) / 13.13.0 & 13.13.15 S-2915-1 WAS 1-66504-3, S-2341-1 WAS 1-66506-3 (NOW SHOP PRACTICE) (SR9927)	CSK 10-9-78 CS 7-7-78	REF: <i>WHT</i> <i>MS</i>
				B	BY REV: ADD DETAIL "A" S2527-2, BLK (FN-HA126); SER. OUT. HAAS (SR10101) (SR10102) BY REV: ADD 2H48-22, DETAIL 'B' & SECOND 2H48-22 PRESS CONT VALVE (SR0863) (REF) (SR10396)	MKT 1-27-82 WHAH 3-6-84	REF: <i>WHT</i> <i>MS</i>
				C	BY REV: BLK (FN-HA126) WAS BLK (FN-HA126) (SR10101) (SR10102)	RNJ 5-5-82	REF: <i>WHT</i> <i>MS</i>

NOTES:

1. TERMINATE VENDOR FURNISHED WIRE WITH S-1367-1-B

BLK (FN-HA126)	20	-20-0	S-1370-1	S-1367-1-B	(SR9953) (SR9954) THRU (SR10396) & ON
N-HA129	20		S-1367-1-B	S-1370-1	(SR10396) & ON
N-HA128	20		S-1367-1-B	S-1370-1	(SR10396) & ON
HA127	20		S-1370-1	S-1370-1	(SR10650) (REF)
BLK (FN-HA126)	22	-22-0	SOLDER	S2099A	(SR10101) (REF)
F-HA105	22		S-1493-1	S-1367-1-B	
N-HA104			S-1493-1	S-1367-1-B	
F-HA103			S-1493-2	S-1493-1	
N-HA102			SOLDER	S-2415-1	
F-HA101	22		SOLDER	S-1636-1	
N-HA100	20		S-1370-1	S-1367-1-B	
F-HA99				S-1367-1-B	
N-HA98				S-2341-1	
F-HA97				S-1635-1	
N-HA96				S-2341-1	
F-HA95				S-1635-1	
N-HA94				S-1370-1	
F-HA93				S-1370-1	
N-HA92				S-2415-1	
F-HA91				S-1636-1	
N-HA90				S-2415-1	
F-HA89	20		S-1370-1	S-1636-1	
N-HA88	20		S-1370-1	S-1367-1-B	
F-HA87	22		S-1493-1	S-1367-1-B	
N-HA84			S-1493-1	SOLDER	
F-HA85			SOLDER	S-1493-1	
N-HA84			S-2341-1	N-HA126	
F-HA83	22		S-1635-1	S-1635-1	
HAS2	20		S-1370-1	S-1370-1	
HAS1			S-2099-4	S-1370-1	
HA50			S-1493-2	S-1370-1	
HA49			SEE HAS8	S-1370-1	
HA48	20		S-1367-1-B	S-1493-2	
HA45	22		SOLDER	S-1367-1-B	THRU SER (SR10101) (REF)
HA44	22		S-1367-1-B	SOLDER	

16	CIG5022-0101	TIME MODULE							
15	2H48-22	PRESSURE CONT VALVE							
14	S2527-2	GND CONNECTOR							
13	S2527-1	LH GND BLOCK							
12	205838-1	CONNECTOR	P210						
11	S-1640-9	CONNECTOR	Z10						
10	S-1641-9	CONNECTOR	Z10						
9	205841-1	CONNECTOR	P210						
8	1D1194-1	PRESSURE SWITCH							
7	MS25041-3	INDICATOR LIGHT							
6	MS25237-327	LAMP							
5	3D2357-01	DE-ICE FLOW VALVE							
4	3D2346-01	PRESSURE CONT VALVE							
3	3D2600-03	TIME MODULE							
2	S-2160-3	SWITCH							
1	S-1232-5	CIRCUIT BREAKER							

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS



EQUIPMENT TABLE		
PART NO.	DESCRIPTION	

CONTRACT NO:		
DESIGN	NAME	DATE
GROUP	W. J. HENDERSON	1-16-78
DRAWN	C. SHAWER	11-22-77
CHECK	GORLESKE	11-30-77
STRESS		
PROJ	PLUMBRECH	1-17-78
APPRO	W. J. HENDERSON	
OTHER		

WIRE TABLE		
SIZE	CODE IDENT. NO.	DWG NO
C	71379	1270709

FAIRBANKS DIVISION	
3800 E. FAIRBANKS WICHITA, KANSAS	
Cessna AIRCRAFT CO.	
WIRING DIAGRAM - WING & STABILIZER DE-ICE SYSTEM - 3 CYCLE (OPT)	
SCALE: NONE	PAGE: 13.13.0

MODEL 210 & T210 SERIES SERVICE MANUAL



DETAIL 13
THRU SER (S99153)(S99154)



DETAIL 13
SER(S99153)(S99154) THRU SER(S910396)

2100-28

CONTRACT NO:				PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE		
GROUP	WILLIAMSON	1-14-78	WING & STABILIZER DE-ICE SYSTEM - 3 CYCLE (OPT)		
DRAWN	C. SHAWER	11-22-77			
CHECK	DORLESKE	11-30-77			
STRESS					
PROJ	PL. HEDRIGUE	1-17-78	SIZE	CODE IDENT. NO.	OWG NO.
APPD	PL. HEDRIGUE		C	71379	1270709
OTHER			SCALE: NONE	(S9927)	PAGE: 13,13,1

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

1. REMOVE & DISCARD /ENDOR FURNISHED TERMINALS. TERMINATE WITH S-1636-2 TERMINALS.
2. TERMINATE VENDOR FURNISHED WIRE WITH S-1635-2 TERMINAL
3. TERMINATE VENDOR FURNISHED WIRE WITH S-1636-1 TERMINAL
4. INTERTWINE HE21 WITH HE3/210, HE22 WITH HE20/P210, HE16 WITH HE2, HE3, HE4 & HE1/20, HE17 WITH HE2, HE3, HE4, & HE18/P210, HE15 WITH HE12, HE13, & HE14

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: TITLE BLOCK SERIALS WERE (SR9114) & (SR9115) (SR9556)	HHG 8-9-79	CAB W/HA
B	BY REV: HE 10 WAS CONN TO PIN 4 / S-1917-2, HE 6 & HE 19 WAS CONN TO PIN 1 / S-2035-1, S-1493-1 WAS SEE HE 10 / F-HE 6 & N-HE 9 NOW SHOP PRACTICE (VIEW 2:1:1) (SR 9556)	SEB 1-25-80	JAB W/HA RFS
C	BY REV ADD ULTIMATE (S-1635-1)	LW 4-30-81	JAB W/HA RFS

54 00916

QTY	DESCRIPTION	UNIT	TERMINALS	SERIALS
1	N-HE22	16	-16-0	S-1636-2 S-1367-2-8
1	F-HE21	16	-16-0	S-1636-2 S-1367-2-8
1	N-HE20	16		S-1493-2 S-1635-2
1	N-HE19	18		S-1493-1 S-1493-1
1	N-HE18			S-1367-1 S-1493-1
1	N-HE17		-18-0	SEE HE15 S-1367-1-8
1	F-HE16		-18-0	SEE HE15 S-1367-1-8
1	HE15		-18-0	S-1635-1 S-1635-1
1	HE14			S-1635-1 SEE HE4
1	HE13			S-1635-1 SEE HE3
1	HE12			S-1635-1 SEE HE2
1	HE11			S-1493-1 S-1367-1-8
1	HE10	18		S-1635-1 S-1493-1
1	F-HE9	16		S-1493-2 S-1635-2
1	HE8	16		S-1367-2 S-1493-2
1	HE7	18		S-1635-1 S-1635-1
1	F-HE6			S-1493-1 S-1493-1
1	HE5			S-1493-1 S-1493-1
1	HE4			S-1635-1 S-1493-1
1	HE3			S-1635-1 S-1493-1
1	HE2			S-1635-1 S-1493-1
1	F-HE1	18		S-1367-1-6 S-1493-1

3	S-1917-2	RELAY
4	0882362	HIGH PRESSURE SW
3	5057-	COMPRESSOR
2	S-2035-2	HOUSING
1	S-2035-1	HOUSING
2	S-323-1	COOLING FAN
2	S-1637-2	HOUSING
2	S-1637-1	HOUSING
1	S-1360-5L	CKT BRK
1	S-1360-10L	CKT BRK
1	247200	TEMP. STAT SW (ARA)
4	0882530	SWITCH (ARA)
3	S-1338-4	HOUSING
2	S-1338-5	HOUSING
1	2101020	BOARD

ITEM NO.	PART NO.	DESCRIPTION

EQUIPMENT TABLE

WIRE TABLE

CONTRACT NO. _____

DESIGN	NAME	DATE
GROUP	W. H. HAZARD	3-3-79
DRAWN	H. GHAZARIAN	2-12-79
CHECK	BORLESKE	2-14-79
STRESS		
PROJ	S. J. HAN	7-27-79
APPD	R. J. S.	
OTHER		

Cessna AIRCRAFT CO.
 PAWNEE DIVISION
 5800 E. PAWNEE
 WICHITA, KANSAS

TITLE

WIRING DIAGRAM —
AIR CONDITIONER
(OPT)

SIZE	CODE IDENT. NO.	DWG NO.
C	71379	1270709

SCALE: NONE (SR 9556) PAGE: 1

CES-1000 IS APPLICABLE
 VENDOR CODES PER S-1400
 CES-XXXX-CESSNA SPEC. NO.
 S-XXX OR CMXXXX-CESSNA
 STD. NO.



SUPERSEDES:

 SUPERSEDED BY:

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:
 1. ONLY HEATER CIRCUITS ARE SHOWN.
 FOR STALL WARNING CIRCUIT SEE PAGE 15.3
 2. S1637-1 HOUSING & S1635-1 PIN ADDED
 TO VENDOR SUPPLIED WIRE.

REVISION			
LET	DESCRIPTION	DATE	APPD



DETAIL APPLIES TO P210

ITEM NO.	PART NO.	DESCRIPTION
10	S2349-1	CONNECTOR
9	S2350-1	CONNECTOR
8	S1637-2	HOUSING - PLUG
7	S1637-1	HOUSING - TAP
6	0721105	PITOT TUBE-HEATED
5	E-641-9	HOUSING - SOCKET
4	S1640-9	HOUSING - PIN
3	S2140-1	SWITCH
2	1221095	HEATED STALL DETECTOR
1	S1360-5L	CIRCUIT BREAKER

EQUIPMENT TABLE

CES-1000 IS APPLICABLE
 VENDOR CODES PER S-1400
 CES-XXXX-CESSNA SPEC. NO.
 S-XXX OR CMXXXX-CESSNA
 STD. NO.

SUPERSEDES: *Fig 13.2*

SUPERSEDED BY:

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
N-HA124	18			S2099-7	S1636-1
N-HA123	18			S1493-1	S2353-2
N-HA122				S2099-7	S1636-1
N-HA121				S1493-1	S2553-2
F-HA120				S1635-1	S1636-1
F-HA119				S1493-1	S1636-1
F-HA118				S1367-6	S1493-1
F-HA117				S1636-1	S1367-1-B
F-HA116				S1635-1	S1636-1
F-HA115				S1493-1	S1636-1
F-HA114	18			S1367-6	S1493-1


WIRE TABLE

CONTRACT NO:			COMMERCIAL AIRCRAFT DIV 8800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	TITLE		
GROUP	W.H. HANSEN	2-28-82	WIRING DIAGRAM -		
DRAWN	J.L. NEERSON	2-9-82	HEATED PITOT TUBE & HEATED		
CHECK	COBLESKY	3-12-82	STALL WARNING SYSTEM		
STRESS					


PROJ	APPD	OTHER	SIZE	CODE IDENT. NO.	DWG NO.
			C	71379	1270709
SCALE: NONE			PAGE: 11.16		

S1600-10
S1600-20

MODEL 210 & T210 SERIES SERVICE MANUAL



DETAIL A
THRU SER 21060089



DETAIL B
THRU SER (SRB464)

INACTIVE
EFF THRU SER (SR914)(SR915)
HWG JAB WITH JRS 2-9-79

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	JLO 5-3-73	JAB WITH JRS
B	BY REV: ADD DETAIL "A" & SER (SR1381) X	DLP 6-22-73	JAB WITH JRS
C	BY REV: ADD COLOR TO CC34, CC35, CC36, CC37, CC38 & CC39 & REVISED WIRE LENGTHS (NOW SHOP PRACTICE)	RS 4-4-75	JAB WITH JRS
D	BY REV: ADD P 14.1.1, DETAIL "B", WIRES CC40 THRU CC48, S-1360-15L, S-2349-1, S-2350-1, SER OUT CC20; SER IN CC49; MOTOR WIRE BLK(REF) WAS ORN(REF), RED(REF) WAS BLK(REF), PINS 1 WAS 3, 3 WAS 1, 4 WAS 2, 1 WAS 4, 2 WAS 6 PER S1640 & S1641, PINS 1 WAS 2 & 2 WAS 1 PER S1638, WIRES BLK(CC39) WAS RED (CC39), RED(U) WAS BLK(U) (SRB464) MER 498 (NOW SHOP PRACTICE) (SRB465)	GDS 6-6-77	JAB WITH JRS
E	BY REV: S-2099-5 WAS 66100-7/U-CC44, U-CC45, U-CC46, U-CC47; S-2353-1 WAS 66098-7/U-CC40, U-CC41, U-CC42, U-CC43 (SRB464)(SRB465)	JJB 8-29-77	JAB WITH JRS

WIRE CODE NO	GA	MATERIAL	LG	TERMINALS	SERIALS
F-CC49	16			S-1367-2-B S-1367-2-4	SER (SRB464) & ON
N-CC48				S-1636-2 S-1493-2	
N-CC47				S-1636-2 S-2099-5	
N-CC46				S-1493-2 S-2099-5	
N-CC45				S-1493-2 S-2099-5	
N-CC44				S-1493-2 S-2099-5	
N-CC43				S-1367-2-4 S-2353-1	
N-CC42				S-1367-2-4 S-2353-1	
N-CC41				S-1367-2-4 S-2353-1	
N-CC40	16			S-1367-2-4 S-2353-1	SER(SRB464) & ON
RED(U)	16	-16-2	13	S-1493-2 S-1636-2	SER 21060090 & ON
RED(U)	16	-16-7	19	S-1493-2 S-1367-2-8	
RED(U)	16	-16-7	19	S-1493-2 S-1367-2-8	
ORANGE (CC39)	16	-16-5	13	S-1635-2 S-1493-2	
ORANGE (CC39)	16	-16-3	13	S-1635-2 S-1493-2	
ORANGE (CC39)	16	-16-6	13	S-1635-2 S-1493-2	SER 21060090 & ON
BLK (CC39)	16	-16-0	13	S-1635-2 S-1636-2	
BLK (CC39)	16	-16-0	13	S-1367-2-4 S-1636-2	THRU SER 21060089
F-CC33	16		220	S-1367-2-4 S-1636-2	
F-CC32	16		220	S-1367-2-4 S-1636-2	
F-CC31	16		4	S-1367-2-4 S-1367-2-8	THRU SER 21060089
F-CC30	16		18	S-1635-2 S-1367-2-4	THRU SER 21060089
F-CC27	16		220	S-1367-2-4 S-1636-2	
F-CC26	16		220	S-1367-2-4 S-1636-2	
F-CC25	16		4	S-1367-2-4 S-1367-2-4	
F-CC24	16		10	S-1367-2-4 S-1367-2-8	
F-CC23	16		4	S-1367-2-4 S-1367-2-8	THRU SER 21060089
F-CC22	16		20	S-1635-2 S-1367-2-8	THRU SER 21060089
F-CC21	16		20	S-1635-2 S-1367-2-8	THRU SER 21060089
F-CC20	16		36	S-1367-2-8 S-1367-2-4	THRU SER (SRB464)


PART NO.	DESCRIPTION
11	S-2349-1 CONNECTOR
10	S-2350-1 CONNECTOR
9	S-1360-15 CIRCUIT BREAKER
8	S-1906-1 SWITCH
7	C301002-0802 FLAP MOTOR
6	S-1360-8L CIRCUIT BREAKER
5	S-1906-2 SWITCH
4	S-1641-6 HOUSING-SOCKET
3	S-1640-6 HOUSING-PIN
2	S-1638-2 HOUSING-SOCKET
1	S-1638-1 HOUSING-PLUG

CONTRACT NO:			WIRE TABLE	
DESIGN	NAME	DATE	TITLE	
DESIGN	YR SIFES	3-5-71	WIRING DIAGRAM -	
GROUP	H W L	3-5-71	WING FLAPS	
DRAWN	YR SIFES	3-5-71		
CHECK	L.K. WHITE	3-5-71		
PROJ			SIZE	CODE IDENT.
APPD			C	71379
OTHER			DWG NO	1270709
			SCALE: NONE	210 P110 PAGE: 1.1.0

CEB-1000 IS APPLICABLE
VENDOR CODES PER 8-1400
CEB-1000-CEBNA SPEC. NO.
8-1001 OR CMBXXX-CEBNA
STD. NO.

SUPERSEDES:
12210-1073
SUPERSEDED BY:
1270709 Pg 14.12

MODEL 210 & T210 SERIES SERVICE MANUAL



INACTIVE
 EFF THRU SER (SR914)(SR915)
 2-9-79
 HNG
 JAG
 JAG

CONTRACT NO.			COMMERCIAL AIRCRAFT DIV. 5900 E. PAWNEE WICHITA, KANSAS																													
<table border="1"> <thead> <tr> <th>DESIGN</th> <th>NAME</th> <th>DATE</th> </tr> </thead> <tbody> <tr> <td>VR SIFES</td> <td></td> <td>3-5-71</td> </tr> <tr> <td>GROUP</td> <td>H. W. W.</td> <td>3-5-71</td> </tr> <tr> <td>DRAWN</td> <td>VR SIFES</td> <td>3-5-71</td> </tr> <tr> <td>CHECK</td> <td>L.K. WHITE</td> <td>3-5-71</td> </tr> <tr> <td>STRESS</td> <td></td> <td></td> </tr> <tr> <td>PROJ</td> <td></td> <td></td> </tr> <tr> <td>APPD</td> <td></td> <td></td> </tr> <tr> <td>OTHER</td> <td></td> <td></td> </tr> </tbody> </table>			DESIGN	NAME	DATE	VR SIFES		3-5-71	GROUP	H. W. W.	3-5-71	DRAWN	VR SIFES	3-5-71	CHECK	L.K. WHITE	3-5-71	STRESS			PROJ			APPD			OTHER			Cessna AIRCRAFT CO. WIRING DIAGRAM — WING FLAPS		
DESIGN	NAME	DATE																														
VR SIFES		3-5-71																														
GROUP	H. W. W.	3-5-71																														
DRAWN	VR SIFES	3-5-71																														
CHECK	L.K. WHITE	3-5-71																														
STRESS																																
PROJ																																
APPD																																
OTHER																																
SIZE C		CODE IDENT. NO 71379		DWG NO 1270709																												
SCALE: NONE			210 P210		PAGE: 110																											

Wing Flaps (Sheet 2 of 2)

(SA 6755) IX (21059503)

MODEL 210 & T210 SERIES SERVICE MANUAL

F-CD53	20		S-1963-2	S-1636-1		SEP (SR8482) † ON
F-CD52	20		S-1963-2	S-1636-1		SER (SR8482) † ON
F-CD51	20		S-1963-2	S-1636-1		SER (SR8482) † ON
F-CD50	20		S-1636-1	S-1367-6		SER (SR8482) † ON
VIO (3)	20	-20-7	SOLDER	SOLDER		SER (SR7677) † ON
GBU (3)	20	-20-5				
ORN (8)	20	-20-3				
YEL (3)	20	-20-4				
RED (3)	20	-20-2				
BRN (5)	20	-20-1				
BRN (4)	20	-20-1	SOLDER	SOLDER		SER (SR7677) † ON
F-CD31	20		S-1963-2	S-1635-1		SER (SR7677) THRU SER (SR8482)
F-CD30	20		S-1963-2	S-1635-1		SER (SR7677) THRU SER (SR8482)
F-CD29	20		S-1963-2	S-1635-1		SER (SR7677) THRU SER (SR8482)
F-CD28	20	-20-0	S-1963-2	S-1637-8		SER (SR7677) † ON

F-CD23	20			S-1635-1	S-1636-1	THRU SER (SR8482)
F-CD22	20			S-1635-1	S-1636-1	
F-CD21	20			S-1635-1	S-1636-1	
F-CD20	20			S-1635-1	S-1636-1	THRU SER (SR8482)
VIO (2)		4	SOLDER	3		THRU SER (SR7677)
VIO (1)						
GBU (2)						
GBU (1)						
YEL (2)						
YEL (1)						
ORN (2)						
ORN (1)						
RED (2)						
RED (1)						
BRN (3)						
BRN (2)						
BRN (1)		4	SOLDER	3		THRU SER (SR7677)

INACTIVE
 SEE THRU SER (SR8482)
 REG. JULY 4-18-77

32	1270705-2	CABLE ASSY
31	S-1636-2	HOUSING
30	S-1636-1	HOUSING
29	S-1637-1	HOUSING
28	S-1360-5L	CKT. BKR.
27	1570307-2	CABLE ASSY
26	S-1962-2-0	HOUSING
25	S-1962-1-0	HOUSING
24	S-1960-2-0	HOUSING
23	S-1960-1-0	HOUSING
22	1570308-1	CABLE ASSY
21	3421-0000	SOCKET
20	1570307-1	CONNECTOR ASSY
19	S-1635-2	SWITCH
18	1270705-11	CABLE ASSY
17	S-1637-2	HOUSING
16	1270062-1	CKT BOARD
15	1270061-1	CKT BOARD
14	1270060-1	CABLE ASSY
13	1270705-1	CABLE ASSY
12	35111-05-001	TERM. BD
11	S-1641-6	HOUSING
10	S-1640-6	HOUSING
9	255 10 30 190	CONNECTOR
8	562364-9	SOCKET
7	5F-1030-BX	CABLE
6	S-1985-1	MIKE SW
5	S-2030-1	PITCH TRIM SW
4	C611003-0101	VOLTAGE REG
3	7271-8-5	CKT BKR
2	C610502-0101	MOTOR ASSY
1	TCS-208	CLUTCH

F-CD23	20			S-1635-1	S-1636-1	THRU SER (SR8482)
F-CD22	20			S-1635-1	S-1636-1	
F-CD21	20			S-1635-1	S-1636-1	
F-CD20	20			S-1635-1	S-1636-1	THRU SER (SR8482)
VIO (2)		4	SOLDER	3		THRU SER (SR7677)
VIO (1)						
GBU (2)						
GBU (1)						
YEL (2)						
YEL (1)						
ORN (2)						
ORN (1)						
RED (2)						
RED (1)						
BRN (3)						
BRN (2)						
BRN (1)		4	SOLDER	3		THRU SER (SR7677)
F-CD23	20	-20-5		S-1635-1	S-1636-1	
F-CD22	20	-20-3		S-1635-1	S-1636-1	
F-CD21	20	-20-2		S-1635-1	S-1636-1	
F-CD20	20	-20-0		S-1367-8	S-1636-1	
F-CD16	20			S-1370-1	S-1367-8	
F-CD15	20	-20-6		S-1635-1	S-1636-1	
F-CD14	20		137	2	S-1635-1	THRU SER (SR7677)
F-CD13	22	-22-0		2	S-1637-8	THRU SER (SR7677)
F-CD12	18	-18-5	8	S-1635-1	S-1636-1	
F-CD7	18		35	S-1367-8	S-1367-8	THRU SER (SR8143)
F-CD3	20		137	2	S-1635-1	THRU SER (SR7677)
F-CD2	20	-20-6	8	S-1635-1	S-1636-1	
F-CD1	20	-20-4	137	S-1636-1	S-1636-1	
F-CD19	20		137	2	S-1635-1	THRU SER (SR7677)
F-CD18	20			S-1635-1	S-1367-8	THRU SER (SR8482)

EQUIPMENT TABLE	
PART NO.	DESCRIPTION
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESNA SPEC. NO. S-XXX OR CXXXX-CESNA STD. NO.	
SUPERSEDES: P 14.4	
SUPERSEDED BY: P 14.11.0	

WIRE TABLE		
CONTRACT NO:	NAME	DATE
DESIGN	V.R. SIPS	
GROUP	H. Wier	1-9-73
DRAWN	PAPE	2-28-72
CHECK	EXCHANGERS	2-25-72
STRESS		
PROJ	H. Miller	1-15-73
APPO	PA	
OTHER		
SIZE	CODE IDENT NO.	DWG NO.
C	71379	1270709
SCALE: NONE	210	PAGE: 14.4.1

Cessna AIRCRAFT CO.
 COMMERCIAL AIRCRAFT DIV.
 5800 E. PAWNEE
 WICHITA, KANSAS
**WIRING DIAGRAM —
 ELECTRIC ELEVATOR
 TRIM (OPTIONAL)**

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:


1. 329636 TERMINAL (00779)
2. PART OF SF-1030-BX CABLE (0BZ61)
3. IF MIKE SWITCH IS INSTALLED WITH ELECTRIC TRIM SWITCH, DELETE YELLOW WIRE TO PIN D OF TRIM SWITCH & ADD JUMPER TO MIKE SWITCH. REFER TO 127070B FOR MIKE SWITCH WIRING
4. PART NO. 60215-4LP, VENDOR CODE IS 00779

REVISION			
LET	DESCRIPTION	DATE	APPO
A	BY REV: ADD WIRE LENGTHS (NOW SHOP PRACTICE)	JLO 5-3-73	<i>[Signature]</i>
B	BY REV: C611003-0101 WAS 4285; ALSO DETAIL 'A'; SER OUT 582304-3, 1270062-1, 1270060-1, 1270061-1, 255-10-30-150, SF-1030-BX, 35-11-05-00, CD12, CD13, CD14, CD25, BROW1, BROW2, BROW3, BROW4, RED12, ORN14, ORN12, YEL11, YEL10, GRN14, GRN22, VIO12, VIO2; SER IN 1570301-1, 1570303-1, 3421-0000, CD28, CD29, CD30, CD31, BROW4, BROW5, RED13, YEL13, ORN14, GRN14, VIO13; ADD PG 14.4.2 (NOW SHOP PRACTICE) (SR7677)	JLO 11-6-73	<i>[Signature]</i>
C	BY REV: ADD WIRE COLORS ORN(F-CD9), RED (F-CD24), GRN(F-CD8), BLK(F-CD7), YEL(F-CD3, BLK(F-CD17), C611003-0101 WAS 4285A (SR 7380 (DEF)	DEF - 1-74	<i>[Signature]</i>
D	BY REV: ADD SHT 14.4.3 & 1570307-2; S-1363-2 WAS SOLDER F-CD29, F-CD30, F-CD31 & F-CD28; ADD S-1370-5 (SR7677), (SR7651, 2)	MEM 5-14-74	<i>[Signature]</i>
E	BY REV: ADD S-1637-1; S-1636-1 WAS S-1370-1/F-CD3 (MER 206 E0361) (NOW SHOP PRACTICE)	RTP 1-23-75	<i>[Signature]</i>
F	BY REV: ADD DETAIL 'A' & SER'S. SER OUT CD-19, CD-29, CD 30, & CD 31, SER IN CD 50, CD 51, CD 52, CD 53 (SR8482)	GW 9-17-73	<i>[Signature]</i>
G	BY REV: DET 'B' WAS DET 'A'; SER OUT DET 'B' SR8482 WAS SR7913; ADD S-1638-1 & -2, 1270705-2; S-1638-1 WAS S-1641-6; S-1638-2 WAS S-1640-6; 1270705-1 WAS 1270705-10; SER OUT CD20, CD21, CD22, & CD23, REVISE & REDRAWN PAGE 14.4.3; ADD DETAIL 'C'; S-1360-5L WAS S-1370-5L (SR8482) (SR8143)	JCS 605 5-12-76	<i>[Signature]</i>
H	BY REV: BLU (F-CD27) WAS RED (F-CD27), GRN (F-CD26) WAS BLK (F-CD26) MER E0551 (NOW SHOP PRACTICE)	PH 8-16-76	<i>[Signature]</i>

CONTRACT NO:			Cessna AIRCRAFT CO. COMMERCIAL AIRCRAFT DIV. 3800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	WIRING DIAGRAM — ELECTRIC ELEVATOR TRIM (OPTIONAL)		
GROUP	<i>H. Wynn</i>	1-4-73			
DRAWN	<i>FAPE</i>	12-28-72			
CHECK	<i>R. YOUNGERS</i>	2-20-74			
STRESS					
PROJ	<i>H. McFadden</i>	1-15-73	SIZE	CODE IDENT. NO.	DWG NO.
APPO			C	71379	1270709
OTHER			SCALE	NONE	210
					PAGE 14.4.1

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISIONS			
LTR	DESCRIPTION	DATE	APPROVED
H	SEE PAGE 14.4.1 FOR REVISION		




INACTIVE
 REG. EFF. THRU SER. (SR-464)
 4-18-77

CONTRACT NO:		Cessna AIRCRAFT CO.		COMMERCIAL AIRCRAFT DIV. 5000 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE	WIRING DIAGRAM— ELECTRIC ELEVATOR TRIM (OPTIONAL)	
GROUP	OS	5-16-74			
DRAWN	MCBRIDE	5-14-74			
CHECK	J. YOWEL	5-15-74			
STRESS					
PROJECT	41114		SIZE	CODE IDENT. NO.	OWG NO.
APPO			C	71379	1270709
			SCALE: NONE	210 (SR7677)	PAGE: 14.4.2

Electric Elevator Trim (OPT) (Sheet 1 of 2)

(21060319)

MODEL 210 & T210 SERIES SERVICE MANUAL



INACTIVE
 IN USE THRU SER (SR8464)
 4-18-77


CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE			
GROUP	79	5-16-74	TITLE WIRING DIAGRAM— ELECTRIC ELEVATOR TRIM (OPTIONAL)		
DRAWN	MCBRIDE	5-14-74			
CHECK	J. YOWEL	5-15-74			
STRESS					
PROJECT	A.H.C.		SIZE	CODE IDENT. NO.	DWG NO.
APPD			C	71379	1270709
			SCALE: NONE	210 (SR7677)	PAGE: 14.4.2

Electric Elevator Trim (OPT) (Sheet 2 of 2)

(210602)

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISIONS			
LTR	DESCRIPTION	DATE	APPROVED
H	SEE PAGE 14.4.1 FOR REVISION		



INACTIVE
 EFF THRU SER (SR 8464)
 REG
 BY 4/24
 4-18-77


DETAIL **A** PG 14.4.2
 EFF THRU SER (SR 7677)
 21060318

CONTRACT NO:		PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS	
DESIGN GROUP	NAME	DATE	Cessna AIRCRAFT CO.
DRAWN	J.L. OLLER	11-6-73	TITLE
CHECK	PAPE	11-7-73	WIRING DIAGRAM ELECTRIC ELEVATOR TRIM (OPTIONAL)
PROJ	H McCARTER	11-17-73	SIZE
APPD			CODE IDENT NO.
OTHER			71379
			DWG NO
			1270709
			SCALE: NONE
			210
			PAGE: 4.4.3


Electric Elevator Trim (OPT) (Sheet 1 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPO
G	SEE PAGE 14.4.1 FOR REV		



DETAIL C PG 14.4.2
THRU SER (SR8143)
(210-61573)



DETAIL B PG 14.4.2
SER (SR7677) THRU SER (SR8482)
21060319 21061229

INACTIVE
EFF THRU SER (SR8482)
REG 4-18-77

CONTRACT NO.			PAWNEE DIVISION 3800 E PAWNEE WICHITA KANSAS		
NAME			Cessna AIRCRAFT CO.		
DATE			TITLE		
DESIGN			WIRING DIAGRAM		
GROUP			ELECTRIC ELEVATOR TRIM		
DRAWN			(OPTIONAL)		
CHECK			SIZE		
STRESS			CODE IDENT		
PROJ			DWG NO		
APPO			C 71379 1270709		
OTHER			SCALE NONE		
			210		
			PAGE 4.4.3		

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

1. CG11003-0101 TRIM REGULATOR WITH MOD "A" OR LATER WILL BE REQD AT SER (SR9369) & ON ALL SPARES. MOD DESIGNATION WILL BE A SUFFIX TO THE VENDOR PART NUMBER

2. WHEN A 374A FILTER IS INSTALLED, REMOVE 3/16" DIA TERMINALS FROM WIRES & TERMINALS FROM MOTOR LEADS & SOLDER DIRECTLY TO FILTER AS SHOWN IN DETAIL A

3. MATERIAL IS RCF51308 COIL CORD VENDOR CODE 096906

REVISION			
LET	DESCRIPTION	DATE	APPD
A	BY REV: ADD N-CD58, N-CD59, N-CD60 (N-CD61, S-1232-5 WAS S-1360-5L (SR9465))	DLP 6-6-77	JAS H. J. J.
B	BY REV: S-1963-2 WAS S-1636-1/F-CD55 F-CD56, F-CD57, U-CD59, U-CD60, U-CD61 (SR8464)(SR8465)	JJB 8-29-77	JAS H. J. J.
C	BY REV: ADD NOTE 1 (SR9369)	CMK 7-13-78	JAS H. J. J.
D	BY REV: ADD DETAIL A, NOTE 2 A374A FILTER, RED(F-CD62) & BLK(F-CD63) (SR9438)	HGG 10-25-78	JAS H. J. J.
E	BY REV: DELETE DETAIL A, NOTE 2 A374A FILTER & (SR9438) (100% SHOP PRACTICE) ADD NOTE 3, DETAIL A 98, EQUIPMENT ITEMS 19, 20, 21 & 22, RCF51308 COIL CORD, SERIAL OUT WIRES, RED (2), BRN (1) (SR9953)(SR9954)	DTL 2-2-81 GLS 2-27-81	JAS H. J. J.
F	BY REV: WHT/BLK WAS WHT/YEL WIRE WHT/YEL WAS WHT/BLK IN DETAIL A (SR9953)(SR9954)	GLS 3/13/81	JAS H. J. J.
G	BY REV: ADD S2527-21-1, BLK(RN-LB17) WAS BLK(REF (SR1001)(SR10102))	MKT 1-27-82	JAS H. J. J.

01-00916 02-00916

WHT/BLK	24	← 3	SOLDER	S-1963-3	SER(SR9953)(SR9954)904
ORN					SER(SR9953)(SR9954)904
WHT/ORN					SER(SR9953)(SR9954)904
RED	24	← 3	SOLDER	S-1963-3	SER(SR9953)(SR9954)904

(P-2563)	22	-22-0	SOLDER	S-1370-1	
N-CD61	20		S-1636-1	S-1963-2	
N-CD60	20		S-1636-1	S-1963-2	
N-CD59	20		S-1636-1	S-1963-2	
N-CD58	20		S-1636-1	S-1367-16	
BLK (1)	22	8568-10	SOLDER	SOLDER	
ORN (1)	22	8568-3	SOLDER	SOLDER	THRU SER (SR9953)(SR9954)
BRN (1)	22	8568-1	SOLDER	SOLDER	THRU SER (SR9953)(SR9954)
RED (2)	22	8568-2	SOLDER	SOLDER	THRU SER (SR9953)(SR9954)
RED (1)	22	8568-2	SOLDER	SOLDER	
RED (F-CD62)	22	-22-2	SOLDER	S-1635-1	
F-CD57	20		S-1636-1	S-1963-2	
F-CD56	20		S-1636-1	S-1963-2	
F-CD55	20		S-1636-1	S-1963-2	
F-CD54	20		S-1636-1	S-1367-16	
(F-CD27)	20	-20-6	S-1635-1	S-1636-1	
(F-CD26)	20	-20-5	S-1635-1	S-1636-1	
RED (F-CD24)	20	-20-2	S-1635-1	S-1636-1	
BLK (F-CD17)	20	-20-0	18	S-1367-18	S-1636-1
F-CD16	20		18	S-1370-1	S-1367-18
(F-CD5)	20	-20-3	8	S-1635-1	S-1636-1
BRN (F-CD8)	18	-18-5	8	S-1635-1	S-1636-1
RED (F-CD4)	20	-20-6	8	S-1635-1	S-1636-1
YEL (F-CD3)	20	-20-4	137	S-1636-1	S-1636-1

24	S2527-2	GND CONNECTOR	
23	S2527-1	LN GND BLOCK	
22	Z270030	CABLE ASSY	
21	S-1967-1-0	HOUSING	
20	S-1962-2-0	HOUSING	
19	S-1232-2	CIRCUIT BREAKER	
18	S-1985-1	SWITCH-MIKE KEY	
17	3473-3000	CONNECTOR SOCKET	
16	3421-0000	CONNECTOR SOCKET	
15	1570307	CONNECTOR ASSY	
14	S-1961-1-0	HOUSING	
13	S-1961-2-0	HOUSING	
12	S-1637-2	HOUSING	
11	S-1637-1	HOUSING	
10	CG11003-0101	VOLTAGE REG	← 1
9	S-1640-6	HOUSING	
8	S-1641-6	HOUSING	
7	S-1232-5	CIRCUIT BREAKER	
6	1260243	MAP LIGHT INSTL	
5	S-2030-1	PITCH TRIM SW	
4	7101-P1	SWITCH	
3	1270844	CABLE	
2	1570307	CABLE ASSY	
1	1270842	CONNECTOR ASSY	


CONTRACT NO:					PASSENGER DIVISION 3800 E. PASSENGER WICHITA, KANSAS	
DESIGN	SPENCER	4-25-77			TITLE	
GROUP	W. J. J.	4-26-77	DRAWN		R. E. GOWIN	
CHECK	J. YOWEL	4-9-77	STRESS			
PROJ	P. H. B. BLUE	4-26-77	OTHER			
APPD	J. G.		SIZE	CODE IDENT. NO.	DWG NO.	
			C	71379	1270709	
			SCALE: NONE		210 P210	PAGE: 14.11.0

EQUIPMENT TABLE	
CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-1000-CESBNA SPEC. NO. S-1000 OR CMC1000-CESBNA STD. NO.	SUPERSEDES: P. 14.4.1 SUPERSEDED BY:

(SR 8464)


MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
G	SEE P 14110 FOR REVISION		




CONTRACT NO:			PAWNEE DIVISION 3800 E PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	Cessna AIRCRAFT CO. TITLE WIRING DIAGRAM ELECTRIC ELEVATOR TRIM (OPTIONAL)		
GROUP	W.H. Handman	4-26-77			
DRAWN	R.E. GOWIN	4-19-77			
CHECK	J. Youel	4-19-77			
STRESS					
PROJ	PLH/ST/MLL	4-26-77	SIZE	CODE IDENT	DWG NO
APPD	W.G.		C	71379	1270709
OTHER			SCALE	NONE	210 C PAGE 14 11

MODEL 210 & T210 SERIES SERVICE MANUAL




DETAIL **A**
THRU SER. (SR9953) (SR9954)



CONTRACT NO.			PAWNEE DIVISION 8800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE		
GROUP	SPENCER	4-25-77	WIRING DIAGRAM	
DRAWN	<i>R.E. Gowin</i>	4-26-77	ELECTRIC ELEVATOR	
CHECK	J. YOUNG	4-19-77	TRIM (OPTIONAL)	
STRESS				
PROJ	PLANNED BLK	4-26-77	SIZE	
APPD	<i>R.E. Gowin</i>		CODE IDENT. NO.	
OTHER			DWG NO.	
			C 71379 1270709	
			SCALE: NONE	
			210 P210	
			PAGE: 14.11.1	

MODEL 210 & T210 SERIES SERVICE MANUAL



WIRE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
BLK(FN-CC33)	16	-16-0		S-1367-2-4 S-2099-3	SER(SR10101)(SR10102)(ON)
ORN(CC45)	16	-16-3		S-1493-2 S-2099-5	
BLU(CC44)		-16-6		S-1493-2 S-2099-5	
CC43				S-1367-2-4 S-2353-1	
CC40				S-367-2-4 S-2353-1	
CC50				S-1367-2-4 S-1367-2-4	
VIO(CC37)		-16-7		S-1493-2 S-1367-2-8	
VIO(CC38)		-16-7		S-1367-2-8	
GRN(CC51)		-16-5		S-1636-2	
RED(CC48)		-16-2		S-1493-2 S-1636-2	
ORN(CC35)		-16-3		S-1635-2 S-1493-2	
BLU(CC34)		-16-6		S-1635-2 S-1493-2	
CC49				S-1367-2-8 S-1367-2-4	
CC33				S-367-2-4 S-1636-2	
CC27				S-1636-2	
CC25				S-1367-2-4	
CC24	16			S-1367-2-4 S-1367-2-8	THRU SER(SR10101)(SR10102)


EQUIPMENT TABLE			
ITEM NO.	PART NO.	DESCRIPTION	
12	S2527-2	GND CONNECTOR	
11	S2527-1	LH GND BLOCK	
10	S-2349-1	CONNECTOR	
9	S-2350-1	CONNECTOR	
8	C301002-0202	FLAP MOTOR	
7	S-1906-2	SWITCH	
6	S-1638-2	HOUSING	
5	S-1638-1		
4	S-1640-6		
3	S-1641-6	HOUSING	
2	S-1906-1	SWITCH	
1	S-1360-10L	CIRCUIT BREAKER	

CONTRACT NO:			WIRE TABLE	
DESIGN	NAME	DATE	SIZE	CODE IDENT. DWG NO
			C	71379
GROUP	W.H. Handley	3-2-79		1270709
DRAWN	H.GHAZARIAN	2-9-79		
CHECK	PORLESKE	2-12-79		
STRESS				
PROJ		2-1-79		
APPD	QAS			
OTHER				

CES-1000 IS APPLICABLE VENDOR CODES PER S-1400 CES-XXXX-CESSNA SPEC. NO. S-XXX OR CMXXXX-CESSNA STD. NO.		SUPERSEDES: 1270709 PGS 14.10 (14.11)	SUPERSEDED BY:
--	--	--	----------------

Cessna AIRCRAFT CO. FAWNEE DIVISION 5800 E. FAWNEE WICHITA, KANSAS	
WIRING DIAGRAM - WING FLAPS	
SCALE: NONE (SR914)(SR915) PAGE: 14.12	

MODEL 210 & T210 SERIES SERVICE MANUAL




INACTIVE
EFF THRU SER. (SR0910)
JJB 9-15-77
RJS 10/11/78

CONTRACT NO.			COMMERCIAL AIRCRAFT DIV CESSNA AIRCRAFT CO. 5800 E. PAWNEE WICHITA, KANSAS		
DESIGN	VR SIPS	11-15-74	TITLE WIRING DIAGRAM — SCHEMATIC DUAL WARNING UNIT		
GROUP	JRS	11-15-74	DWG NO 1270709		
DRAWN	G. WHITSON	11-6-74	CODE IDENT NO 71379		
CHECK	W. YOUEL	11-8-74	SCALE NONE		
STRESS			210		
PROJ	W. YOUEL	21-74	PAGE 15 4		
APPD			SR7913122 (SR0910)		
OTHER					

Schematic Dual Warning System (Sheet 2 of 2)


MODEL 210 & T210 SERIES SERVICE MANUAL




CONTRACT NO:			COMMERCIAL AIRCRAFT DIV 3800 E. PAWNEE WICHITA, KANSAS		
NAME	DATE		Cessna AIRCRAFT CO.		
DESIGN	URS/PCS	11-19-74	TITLE		
GROUP	URS/PCS	11-18-74	WIRING DIAGRAM —		
DRAWN	G. WHITSON	11-11-74	DUAL WARNING SYSTEM		
CHECK	J. YOUNG	11-17-74			
STRESS					
PROJ	URS/PCS	11-21-74	SIZE	CODE IDENT NO	DWG NO
APPD			C	71379	1270709
OTHER			SCALE: NONE	210 P210	PAGE 15.5.0

MODEL 210 & T210 SERIES SERVICE MANUAL


REVISION			
LET	DESCRIPTION	DATE	APPRO
G	BY REV: F-FC13 WAS F-FC5; F-GC36 WAS F-GC28; FGC38 WAS F-GC24; GC37 WAS F-GC23 (REF) (SR9953)	MLV 10-12-81	<i>[Signature]</i>
H	BY REV: ADD S2527-21-1) BLK(FN-GE12)(REF) WAS GE1(REF) (SR10101)(SR10102)	MKT 1-27-82	JAB JMW <i>[Signature]</i>
J	BY REV: ADD DETAIL H & DETAIL J SER OUT GC29 & GC36 SER IN GC39 & GC40 (SR10101)(SR10102)	JMW 4-22-82	<i>[Signature]</i>




DETAIL A
(APPLIES WHEN HIGH CAPACITY HEATED STALL DETECTOR IS INSTALLED)




DETAIL B
(APPLIES TO P210 ONLY)





DETAIL C
THRU (SR 9860)




DETAIL H
THRU SER (SR 001) (SR 0102)



DETAIL I
THRU SER (SR 8464)



DETAIL J
THRU SER (SR 10101) (SR 10102)




DETAIL L
(APPLIES TO P210 ONLY)

CONTRACT NO:		Cessna AIRCRAFT CO.		PAWNEE DIVISION 3800 E. PAWNEE WICHITA, KANSAS	
DESIGN	SPENCER	DATE	6-21-77	TITLE	
GROUP	<i>[Signature]</i>	DATE	6-25-77	WIRING DIAGRAM -	
DRAWN	SCHFFELBEIN	DATE	6-6-77	DUAL WARNING SYSTEM	
CHECK	BORLESKE	DATE	6-7-77		
STRESS					
PROJ	PLAFORICK	DATE	6-24-77	SIZE	CODE IDENT.
APPRO	<i>[Signature]</i>			C	71379
OTHER				DWG NO.	1270709
SCALE: NONE		210	P210	PAGE: 15.5.1	

(SR 8464) (SR 8465)

02-00916
02-00916

MODEL 210 & T210 SERIES SERVICE MANUAL




CONTRACT NO:			COMMERCIAL AIRCRAFT DIV. 8800 E. PAWNEE WICHITA, KANSAS		
DESIGN	NAME	DATE	CROSSNA AIRCRAFT CO.		
GROUP	W. J. Anderson	10-3-77	TITLE		
DRAWN	BLISS	9-16-77	WIRING DIAGRAM —		
CHECK	BORLESKE	9-19-77	SCHEMATIC DUAL WARNING		
STRESS			UNIT		
PROJ	P. K. H. ...	10-3-77	SIZE	CODE IDENT. NO.	DWG NO
APPD	APG		C	71379	1270709
OTHER			SCALE: NONE	2104 PZ10	PAGE: 15.6

Schematic Dual Warning Unit (Sheet 2 of 2)

MODEL 210 & T210 SERIES SERVICE MANUAL

REVISION			
LET	DESCRIPTION	DATE	APPD
A	SEE PAGE 15.7.0 FOR REVISIONS		




CONTRACT NO.:		Cessna AIRCRAFT CO.		PAWNEE DIVISION 5800 E. PAWNEE WICHITA, KANSAS	
DESIGN	NAME	DATE	TITLE		
GROUP			SCHEMATIC - DUAL WARNING UNIT		
DRAWN	ACKER, J.N.	7-23-81	SIZE	CODE IDENT.	DWG NO.
CHECK	BORLESKE	7-31-81	C	71379	1270709
STRESS			SCALE: — (SRI0250) PAGE 15.7.1		
PROJ	V.R. [unclear] 11/81				
APPD	[unclear]				
OTHER					

MODEL 210 & T210 SERIES SERVICE MANUAL

NOTES:

1. VACUUM SWITCH CONTACTS ARE NORMALLY CLOSED.

LET	REVISION	DATE	APPO



01-00816

WIRE CODE NO.	GA	MATERIAL	LG	TERMINALS	SERIALS
F-WE4	22	-22-0		S-1493-1	SOLDER
F-WE3	22	-22-0		SOLDER	2294-4
F-WE2	22	-22-0		S-1493-1	SOLDER
F-WE1	22	-22-0		S-1367-16	S-1493-1

PART NO.	DESCRIPTION
6 S-2527-2	GND CONNECTOR
5 S-2527-1	LH GND BLOCK
4 MS-250412-327	LAMP ASSY
3 S-357-1	VACUUM SWITCH
2 S-2023-1	ADAPTER
1 S-1207-3	CIRCUIT BREAKER

CONTRACT NO:		Cessna AIRCRAFT CO.		PAWNEE DIVISION 5800 E PAWNEE WICHITA KANSAS	
DESIGN	G STAMM	DATE	3/15/82	TITLE	
GROUP	<i>104/104</i>	DATE	2-26-82	WIRING DIAGRAM — LOW VACUUM WARNING LIGHT (OPT)	
DRAWN	G STAMM	DATE	3/15/82		
CHECK	<i>R-104</i>	DATE	3-5-82	SIZE	
STRESS				CODE IDENT	DWG NO
PROJ	111A08E	DATE	3-5-82	NO	71379-1270709
APPO	<i>JRS</i>			SCALE	NONE
OTHER				PAGE	1

CES-1000 IS APPLICABLE
VENDOR CODES PER S-1400
CES-XXXX-CESSNA SPEC. NO.
S-XXX OR CMXXXX-CESSNA
STD. NO.

SUPERSEDES:

SUPERSEDED BY:

(SR.CIG)