



Cisco Unified IP Phone 7975G Phone Guide for Cisco Unified Communications Manager 6.1 (SCCP and SIP)

Americas Headquarters

Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA

http://www.cisco.com Tel: 408 526-4000

800 553-NETS (6387)

Fax: 408 527-0883

Contents

Getting Started 1 Using this Guide 1 Finding Additional Information 2 Accessing Cisco Unified IP Phone 7900 Series eLearning Tutorials 2 Safety and Performance Information 2 Cisco Product Security Overview 3 Accessibility Features 3 **Connecting Your Phone 4** An Overview of Your Phone 8 Understanding Buttons and Hardware 8 Understanding Lines and Calls 11 Understanding Line and Call Icons 11 Understanding Touchscreen Features 12 Choosing Touchscreen Items 13 Cleaning and Maintaining the Touchscreen 13 Understanding Feature Buttons and Menus 14 Accessing the Help System on Your Phone 15 Understanding Feature Availability 15 Understanding SIP vs. SCCP 16 **Basic Call Handling 17** Placing a Call—Basic Options 17 Placing a Call—Additional Options 18 Answering a Call 20 Ending a Call 21

Using Hold and Resume 22

```
Using Mute 23
Switching Between Multiple Calls 23
Switching an In-Progress Call to Another Phone 24
Viewing Multiple Calls 24
Transferring Calls 25
Sending a Call to a Voice Message System 26
Forwarding Calls to Another Number 26
Using Do Not Disturb 27
Making Conference Calls 28
   Using Conference Features 28
      Using Conference 29
      Using Join 30
      Using cBarge 30
      Using Meet-Me 31
   Viewing or Removing Conference Participants 32
Placing or Receiving Intercom Calls 32
Advanced Call Handling 34
Speed Dialing 34
Picking Up a Redirected Call on Your Phone 35
Storing and Retrieving Parked Calls 36
Logging Out of Hunt Groups 37
Using a Shared Line 37
   Understanding Shared Lines 38
   Using Barge to Add Yourself to a Shared-Line Call 38
      Understanding Barge Features 38
      Using Barge Features 39
   Preventing Others from Viewing or Barging a Shared-Line Call 40
Using BLF to Determine a Line State 41
Making and Receiving Secure Calls 41
Tracing Suspicious Calls 42
Prioritizing Critical Calls 42
Using Cisco Extension Mobility 44
```

iv OL-14621-01

Using a Handset, Headset, and Speakerphone 47

Obtaining a Headset 48
Using AutoAnswer 48

Changing Phone Settings 49

Customizing Rings and Message Indicators 49
Customizing the Touchscreen 50
50

Using Call Logs and Directories 51

Using Call Logs 51

Directory Dialing 53

Using Corporate Directory on Your Phone 53

Using Personal Directory on Your Phone 54

Accessing Voice Messages 57

Using the User Options Web Pages 58

Accessing Your User Options Web Pages 58
Configuring Features and Services on the Web 59
Using Personal Directory on the Web 59
Using Your Personal Address Book on the Web 59
Configuring Fast Dials on the Web 60
Using the Address Book Synchronization Tool 61
Setting Up Speed Dials on the Web 61
Setting Up Phone Services on the Web 62
Controlling User Settings on the Web 63
Controlling Line Settings on the Web 64
Setting Up Phones and Access Lists for Mobile Connect 66
Using Cisco WebDialer 69

Understanding Additional Configuration Options 71

Troubleshooting Your Phone 73

General Troubleshooting 73
Viewing Phone Administration Data 74
Using the Quality Reporting Tool 74

Cisco One-Year Limited Hardware Warranty Terms 75

Index 77

vi OL-14621-01

Common Phone Tasks

| View online help on phone | Press ? |
|--|---|
| Place a call | Go off-hook before or after dialing a number. |
| Redial a number | Press Redial. Or press the Navigation button while on-hook to see your Placed Calls log. |
| Switch to handset during a call | Pick up the handset. |
| Switch to speaker or headset during a call | Press or o, then hang up the handset. |
| Mute your phone | Press . |
| Use your call logs | Press to choose a call log. To dial, highlight a listing and go off-hook. |
| Edit a number | Press EditDial, << or >>. |
| Hold/resume a call | Press Hold or Resume. |
| Transfer call to new number | Press Transfer, enter the number, then press Transfer again. |
| Place an intercom call | Press intercom button, enter a number if necessary, and speak after you hear the tone. |
| Start a standard (ad hoc) conference call | Press more > Confrn, dial the participant, then press Confrn again. |



Cisco, Cisco Systems, the Cisco logo, and the Cisco Systems logo are registered trademarks or trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries. All other trademarks

mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0705R)

© 2007 Cisco Systems, Inc. All rights reserved.



QUICK REFERENCE

Cisco Unified IP Phone 7975G Phone Guide for **Cisco Unified Communications** Manager 6.1 (SCCP and SIP)

Softkey Definitions Phone Screen Icons **Button Icons** Common Phone Tasks

Softkey Definitions

| AbbrDial | Dial using a speed dial index number | |
|------------------------|---|--|
| Answer | Answer a call | |
| Back | Return to the previous Help topic | |
| Barge | Add yourself to a call on a shared line | |
| CallBack | Receive notification when a busy extension becomes available | |
| Cancel | Cancel an action or exit a screen without applying changes | |
| cBarge | Add yourself to a call on a shared line and establish a conference | |
| CFwdALL | Setup/cancel call forwarding | |
| Clear | Delete records or settings | |
| Close | Close the current window | |
| ConfList | View conference participants | |
| Confrn | Create a conference call | |
| Delete | Remove characters to the right of the cursor when using EditDial | |
| Details (SCCP only) | Open the Details record for a multiparty call in the Missed Calls and Received Calls logs | |
| Dial | Dial a phone number | |
| DirTrfr (SCCP only) | Transfer two calls to each other | |
| DND | Turn on/off Do Not Disturb (DND) | |
| EditDial | Edit a number in a call log | |
| EndCall | Disconnect the current call or the current intercom call | |
| Erase | Reset settings to their defaults | |
| Exit | Return to the previous screen | |

| GPickUp | Answer a call ringing in another |
|------------------------|--|
| | group |
| iDivert | Divert or redirect a call to a voice |
| | message system |
| Join | Join together existing calls to |
| (SCCP only) | |
| Links | View related Help topics |
| Main | Display the Help main menu |
| MeetMe | Host a Meet-Me conference call |
| more | Display additional softkeys |
| New Call | Make a new call |
| OPickUp | Answer a call ringing in an |
| | associated group |
| Park | Store a call using Call Park |
| PickUp | Answer a call in your group |
| QRT | Submit call problems to the system |
| | administrator |
| Redial | Redial the most recently dialed number |
| Remove | Remove a conference participant |
| Resume | Resume a call on hold |
| RmLstC | Drop the last party added to a conference call |
| Save | Save the chosen settings |
| Search | Search for a directory listing |
| Select | Select a menu item or call |
| Transfer | Transfer a call |
| Update | Refresh content |
| VidMode (SCCP only) | Choose a video display mode |
| << | Delete entered characters |
| >> | Move through entered characters |
| | |

Phone Screen Icons

| Line and | Call Status |
|---------------------------|---|
| | Call Forwarding enabled |
| G ₁ | Call on hold |
| 6 | Connected call |
| 6 2 | Incoming call |
| <u>C</u> | Off-hook |
| | On-hook |
| & <u></u> ✓ | Shared line in use |
| \times | Message waiting |
| 6 | Authenticated call |
| € | Encrypted call |
| | Busy line in a speed-dial, call log, or directory listing (BLF feature) |
| \$ | Idle line in a speed-dial, call log, or directory listing (BLF feature) |
| # | Speed-dial, call log, or directory listing (line status unknown) |
| ** | Line in Do Not Disturb (BLF feature) |
| | Intercom line in idle state |
| ₹_ | Intercom line in one-way audio |
| ₹ | Intercom line in two-way audio |
| Audio or | Video Mode |
| P | Handset in use |
| O | Headset in use |
| 4 | Speakerphone in use |

| | Video enabled (SCCP only) |
|------------------|---|
| Feature A | Access |
| \triangleright | Feature assigned to button |
| | Mobility assigned to button |
| | Hold assigned to button |
| ₩ | Conference assigned to button |
| R | Transfer assigned to button |
| (3) | Phone service URL assigned to button |
| @ | URL entry in a call log is ready to edit (SIP only) |
| ~ | Option selected |
| 0 | Feature enabled |
| | |

Button Icons

| | Messages |
|------------|-------------|
| (3) | Services |
| ? | Help |
| T | Directories |
| T | Settings |
| - 0 | Volume |
| 4 | Speaker |
| 1 | Mute |
| (1) | Headset |

Getting Started

Using this Guide

This guide provides you with an overview of the features available on your phone. You can read it completely for a solid understanding of your phone's capabilities or refer to the table below for pointers to commonly used sections.

| If you want to | Then | |
|--------------------------------------|---|--|
| Explore your phone on your own | Press on the phone when you need assistance. | |
| Review safety information | See Safety and Performance Information, page 2. | |
| Connect your phone | See Connecting Your Phone, page 4. | |
| Use your phone after it is installed | Start with An Overview of Your Phone, page 8. | |
| Learn what the button lights mean | See Understanding Buttons and Hardware, page 8. | |
| Learn about the touchscreen | See Understanding Touchscreen Features, page 12. | |
| Make calls | See Placing a Call—Basic Options, page 17. | |
| Put calls on hold | See Using Hold and Resume, page 22. | |
| Mute calls | See Using Mute, page 23. | |
| Transfer calls | See Transferring Calls, page 25. | |
| Make conference calls | See Making Conference Calls, page 28. | |
| Set up speed dialing | See Speed Dialing, page 34. | |
| Share a phone number | See Using a Shared Line, page 37. | |
| Use your phone as a speakerphone | See Using a Handset, Headset, and Speakerphone, page 47. | |
| Change the ring volume or tone | See Changing Phone Settings, page 49. | |
| View your missed calls | See Using Call Logs, page 51. | |
| Listen to your voice messages | See Accessing Voice Messages, page 57. | |
| See softkey and icon definitions | Refer to the Quick Reference Card in the front of this guide. | |

Finding Additional Information

You can access the most current Cisco Unified IP Phone documentation on the World Wide Web at this URL:

http://www.cisco.com/en/US/products/hw/phones/ps379/products_user_guide_list.html

You can access the Cisco website at this URL:

http://www.cisco.com/

International Cisco websites can be accessed from this URL:

http://www.cisco.com/public/countries_languages.shtml

Accessing Cisco Unified IP Phone 7900 Series eLearning Tutorials

(SCCP phones only.)

The Cisco Unified IP Phone 7900 Series eLearning tutorials use audio and animation to demonstrate basic calling features. You can access eLearning tutorials online (for several phone models) from your personal computer. Look for the eLearning tutorial (English only) for your phone model in the documentation list at the following location:

http://www.cisco.com/en/US/products/hw/phones/ps379/products_user_guide_list.html



Although a eLearning tutorials for the 7975G Cisco Unified IP Phone does not exist, refer to the Cisco Unified IP Phone 7900 Series eLearning tutorials for an overview of the common IP phone features and functionality.

Safety and Performance Information

Refer to these sections for information about the impact of power outages and other devices on your Cisco Unified IP Phone.

Power Outage

Your accessibility to emergency service through the phone is dependent on the phone being powered. If there is an interruption in the power supply, Service and Emergency Calling Service dialing will not function until power is restored. In the case of a power failure or disruption, you may need to reset or reconfigure equipment before using the Service or Emergency Calling Service dialing.

Using External Devices

The following information applies when you use external devices with the Cisco Unified IP Phone:

Cisco recommends the use of good quality external devices (such as headsets) that are shielded against unwanted radio frequency (RF) and audio frequency (AF) signals.

Depending on the quality of these devices and their proximity to other devices such as mobile phones or two-way radios, some audio noise may still occur. In these cases, Cisco recommends that you take one or more of the following actions:

- Move the external device away from the source of the RF or AF signals.
- Route the external device cables away from the source of the RF or AF signals.
- Use shielded cables for the external device, or use cables with a better shield and connector.
- Shorten the length of the external device cable.
- Apply ferrites or other such devices on the cables for the external device.

Cisco cannot guarantee the performance of the system because Cisco has no control over the quality of external devices, cables, and connectors. The system will perform adequately when suitable devices are attached using good quality cables and connectors.



In European Union countries, use only external headsets that are fully compliant with the EMC Directive [89/336/EC].

Cisco Product Security Overview

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at: http://www.cisco.com/wwl/export/crypto/tool/stqrg.html. If you require further assistance please contact us by sending email to export@cisco.com.

Accessibility Features

A list of accessibility features is available upon request.


Connecting Your Phone

Your system administrator will likely connect your new Cisco Unified IP Phone to the corporate IP telephony network. If that is not the case, refer to the graphic and table below to connect your phone.

| 1 | DC adaptor port (DC48V) | 5 | Access port (10/100/1000 PC) |
|---|-------------------------------|---|------------------------------|
| 2 | AC-to-DC power supply | 6 | Handset port |
| 3 | AC power cord | 7 | Headset port |
| 4 | Network port (10/100/1000 SW) | 8 | Footstand button |


Removing the Hookswitch Clip (Required)

Before you use your phone, remove the hookswitch clip from the cradle area. With the clip removed, the hookswitch lifts slightly when you pick up the handset.



Adjusting the Handset Rest (Optional)

Cisco recommends adjusting the handset rest, particularly when wall-mounting the phones, as this will ensure that the receiver will not readily slip out of the cradle. See the table below for instructions.



- 1 Set the handset aside and pull the square plastic tab from the handset rest.
- **2** Rotate the tab 180 degrees.
- 3 Slide the tab back into the handset rest. An extension protrudes from the top of the rotated tab. Return the handset to the handset rest.

Adjusting the Footstand (Optional)

To change the angle of the phone base, adjust the footstand while pressing the footstand button.

Registering with TAPS

After your phone is connected to the network, your system administrator might ask you to auto-register your phone using TAPS (Tool for Auto-Registered Phones Support). TAPS might be used either for a new phone or to replace an existing phone.

To register with TAPS, pick up the handset, enter the TAPS extension provided by your system administrator, and follow the voice prompts. You might need to enter your entire extension, including the area code. After your phone displays a confirmation message, hang up. The phone will re-start.

Headset Information

To use a headset, connect it to the headset port on the back of your phone.

Although Cisco Systems performs some internal testing of third-party headsets for use with the Cisco Unified IP Phones, Cisco does not certify or support products from headset or handset vendors. Because of the inherent environmental and hardware inconsistencies in the locations where Cisco Unified IP Phones are deployed, there is not a single "best" solution that is optimal for all environments. Cisco recommends that customers test the headsets that work best in their environment before deploying a large number of units in their network.

In some instances, the mechanics or electronics of various headsets can cause remote parties to hear an echo of their own voice when they speak to Cisco Unified IP Phone users.

Cisco Systems recommends the use of good quality external devices, like headsets that are screened against unwanted radio frequency (RF) and audio frequency (AF) signals. Depending on the quality of these devices and their proximity to other devices such as cell phones and two-way radios, some audio noise may still occur.

The primary reason that support of a headset would be inappropriate for the Cisco Unified IP Phone is the potential for an audible hum. This hum can either be heard by the remote party or by both the remote party and you, the Cisco Unified IP Phone user. Some potential humming or buzzing sounds can be caused by a range of outside sources, for example, electric lights, being near electric motors, large PC monitors. In some cases, a hum experienced by a user may be reduced or eliminated by using a local power cube or power injector.

Audio Quality Subjective to the User

Beyond the physical, mechanical and technical performance, the audio portion of a headset must sound good to you (the user) and to the party on the far end. Sound is subjective and Cisco cannot guarantee the performance of any headsets or handsets, but some of the headsets and handsets on the sites listed below have been reported to perform well with Cisco Unified IP Phones.

Nevertheless, it is ultimately still the customer's responsibility to test this equipment in their own environment to determine suitable performance.

For information about headsets, see:

http://www.vxicorp.com/cisco

http://www.plantronics.com/cisco

http://www.jabra.com

An Overview of Your Phone

Your 7975G Cisco Unified IP Phone is a full-feature telephone that provides voice communication over the same data network that your computer uses, allowing you to place and receive phone calls, put calls on hold, transfer calls, make conference calls, and so on.

In addition to basic call-handling features, your 7975G Cisco Unified IP Phone can provide enhanced productivity features that extend your call-handling capabilities. Depending on configuration, your phone supports:

- Access to network data, XML applications, and web-based services.
- Online customizing of phone features and services from your User Options web pages.
- A comprehensive online help system that displays information on the phone screen.

Understanding Buttons and Hardware

You can use the graphic below to identify buttons and hardware on your phone.



| | Item | Description | For more information, see |
|---|---|---|---|
| 1 | Programmable buttons Depending on configuration, programmable buttons provide access to: Phone lines and intercom lines (line buttons) Speed-dial numbers (speed-dial buttons, including the BLF speed-dial feature) Web-based services (for example, a Personal Address Book button) | | Understanding Touchscreen Features, page 12 Basic Call Handling, page 17 Speed Dialing, page 34 Using a Shared Line, page 37 Using BLF to |
| | | Phone features (for example, a Privacy, Hold, or Transfer button) Buttons illuminate to indicate status: Green, steady—Active call or two-way intercom call Green, flashing—Held call Amber, steady—Privacy in use, one-way intercom call, DND active, or logged into Hunt Group Amber, flashing—Incoming call or reverting call Red, steady—Remote line in use (shared line or BLF status) | Determine a Line State, page 41 Placing or Receiving Intercom Calls, page 32 |
| 2 | Footstand button | Allows you to adjust the angle of the phone base. | Adjusting the Handset Rest (Optional), page 5 |
| 3 | Display button | Awakens the touchscreen from sleep mode or disables it for cleaning. No color—Ready for input Green flashing—Disabled Green steady—Sleep mode | Cleaning and Maintaining the Touchscreen, page 13 |
| 4 | Messages button | Auto-dials your voice message service (varies by service). | Accessing Voice Messages, page 57 |
| 5 | Directories button | Opens/closes the Directories menu. Use it to access call logs and directories. | Using Call Logs, page 51 |

| 6 | Help button | Activates the Help menu. | Accessing the Help System on Your Phone, page 15 |
|----|---|---|---|
| 7 | Settings button | Opens/closes the Settings menu. Use it to change touchscreen and ring settings. | Changing Phone Settings, page 49 |
| 8 | Services button | Opens/closes the Services menu. | Using the User Options Web Pages, page 58 |
| 9 | Volume button | Controls the handset, headset, and speakerphone volume (off-hook) and the ringer volume (on-hook). | Using a Handset, Headset, and Speakerphone, page 47 |
| 10 | Speaker button | Toggles the speakerphone on or off. When the speakerphone is on, the button is lit. | Using a Handset, Headset, and Speakerphone, page 47 |
| 11 | Mute button | Toggles the microphone on or off. When the microphone is muted, the button is lit. | Using Mute, page 23 |
| 12 | Headset button | Toggles the headset on or off. When the headset is on, the button is lit. | Using a Handset, Headset, and Speakerphone, page 47 |
| 13 | 4-way navigation pad and Select button (center) | Allows you to scroll through menus and highlight items. Use the Select button to select an item that is highlighted on the screen. Navigation button Scroll up and down to see menus and highlight items. Scroll right and left to scroll horizontally in multi-column displays. Select button—scroll to highlight a line using the Navigation button, and then: Press to open a menu. Press to play a ringer item. Press to access other features as described on the screen. | Using Call Logs, page 51 |
| 14 | Keypad | Allows you to dial phone numbers, enter letters, and choose menu items. | Basic Call Handling, page 17 |
| 15 | Softkey buttons | Each activates a softkey option (displayed on your touchscreen). | Understanding Touchscreen Features, page 12 |

| 16 | | C . | Accessing Voice Messages, page 57 |
|----|-------------|-----|--|
| 17 | Touchscreen | * | Understanding Touchscreen Features, page 12 |

Understanding Lines and Calls

To avoid confusion about lines and calls, refer to these descriptions:

- Lines—Each corresponds to a directory number or intercom number that others can use to call you. Your phone can support up to eight lines. To see your phone lines, look at the right side of your touchscreen. You have as many lines as you have directory numbers and phone line icons:
- Calls—Each line can support multiple calls. By default, your phone supports four connected calls per line, but your system administrator can adjust this number according to your needs. Only one call can be active at any time; other calls are automatically placed on hold.

Understanding Line and Call Icons


Your phone displays icons to help you determine the line and call state.

| Icon | Line or call state | Description | |
|-----------|--------------------|---|--|
| | On-hook line | No call activity on this line. | |
| E | Off-hook line | You are dialing a number or an outgoing call is ringing. | |
| 6 | Connected call | You are connected to the other party. | |
| | Ringing call | A call is ringing on one of your lines. | |
| € | Call on hold | You have put the call on hold. See Using Hold and Resume, page 22. | |
| ₽ | Remote-in-use | Another phone that shares your line has a connected call. See Using a Shared Line, page 37. | |
| | Reverting call | A holding call is reverting to your phone. See Using Hold and Resume, page 22. | |
| € | Authenticated call | See Making and Receiving Secure Calls, page 41. | |
| € | Encrypted call | See Making and Receiving Secure Calls, page 41. | |
| \$ | Idle line (BLF) | See Using BLF to Determine a Line State, page 41. | |

| lcon | Line or call state | Description | |
|----------|---------------------------------|--|--|
| | Busy line (BLF) | See Using BLF to Determine a Line State, page 41. | |
| | Line in Do Not Disturb (BLF) | See Using BLF to Determine a Line State, page 41. | |
| | Idle Intercom line | The intercom line is not in use. See Placing or Receiving Intercom Calls, page 32. | |
| 5 | One-way intercom | The intercom line is sending or receiving one-way audio. See Placing or Receiving Intercom Calls, page 32. | |
| • | Two-way intercom call | The recipient pressed the intercom line to activate two-way audio with the caller. See Placing or Receiving Intercom Calls, page 32. | |

Understanding Touchscreen Features

This is what your main touchscreen might look like with active calls and several feature menus open.



| 1 | Primary phone line | Displays the phone number (directory number) for your primary phone line. |
|---|--------------------------------------|---|
| 2 | Programmable button indicators | Programmable buttons acan serve as phone line buttons, intercom line buttons, speed-dial buttons, phone service buttons or phone feature buttons. Icons and labels indicate how these buttons are configured. For an icon reference, see the "Phone Screen Icons" section in the Quick Reference Card at the front of this guide. |
| 3 | Softkey labels | Each displays a softkey function. Softkey labels are touch-sensitive. |

| 4 | Status line | Displays audio mode icons, status information, and prompts. | | |
|--|--|--|--|--|
| area for the highlighted line (standard view). Items in this area are to | | Displays current calls per line, including caller ID, call duration, and call state for the highlighted line (standard view). Items in this area are touch-sensitive. See Understanding Line and Call Icons, page 11, and Viewing Multiple Calls, page 24. | | |
| 6 | Phone tab Indicates call activity. Press this tab to return to the call activity area, if ne | | | |
| 7 | Feature tabs | Each indicates an open feature menu. Tabs are touch-sensitive. See Understanding Feature Buttons and Menus, page 14. | | |

Choosing Touchscreen Items

There are three ways to choose items on your phone's touchscreen.

| To choose a touchscreen item | Do this | | |
|------------------------------|--|--|--|
| By touch | Press (or tap) touch-sensitive items on the touchscreen with your fingertip. | | |
| | Use only your fingertip to press the touchscreen, as using any other objects could damage the display. Be aware that pressing a phone number can cause the phone to dial the number. | | |
| By item number | Press the corresponding number on your keypad. For example, press 4 to choose the fourth item in a menu. | | |
| By scrolling | Use the Navigation button to highlight an item. Press the Select button to select the item, or a softkey to finish the action. | | |

Cleaning and Maintaining the Touchscreen

You can use the Display button to disable and enable the touchscreen. The Display button illuminates to indicate changes in touchscreen status:

Green, steady—Touchscreen is in sleep mode
Green, flashing—Touchscreen is disabled

| If you want to | Then | |
|-------------------------|---|--|
| Disable the touchscreen | Press and hold for more than one second. flashes. | |
| for cleaning | The screen remains disabled for about a minute, unless you enable it. | |

| If you want to | Then | | |
|---|---|--|--|
| Enable the touchscreen (after disabling it) | Press (flashing) and hold for more than one second. | | |
| Wake the touchscreen from sleep mode | Press the touchscreen or any button, or lift the handset. After a period of inactivity (determined by your system administrator), the touchscreen enters sleep mode to save power. In this mode, the touchscreen appears blank and the Display button remains lit. | | |



Use only a soft, dry cloth to wipe the touchscreen. Do not use any liquids or powders on the phone, as they can contaminate phone components and cause failures.

Understanding Feature Buttons and Menus

Press a feature button to open or close a feature menu.

| If you want to | Then |
|--|---|
| Open or close a feature | Press a feature button: |
| menu | Messages |
| | Services |
| | Help |
| | Directories |
| | Settings |
| Scroll through a list or | Press the Navigation button. |
| menu | |
| Go back one level in a feature menu | Press Exit. Pressing Exit from the top level of a menu closes the menu. |
| Switch between open feature menus Press a feature tab on your touchscreen. Each feature menu has corresponding tab. The tab is visible when the feature menu is of the seature menu is | |

Accessing the Help System on Your Phone

Your phone provides a comprehensive online help system. Help topics appear on the touchscreen.

| If you want to | Then | | |
|---------------------------------|---|--|--|
| View the main menu | Press on your phone and wait a few seconds for the menu to display. Main menu topics include: | | |
| | About Your Cisco Unified IP Phone—Details about your phone | | |
| | How do I?—Procedures for common phone tasks | | |
| | Calling Features—Descriptions and procedures for calling features | | |
| Learn about a button or softkey | Press (2), then quickly press a button or softkey. | | |
| Learn about a menu item | Press ②, then quickly press the menu item on the touchscreen. Or, press twice quickly with the menu item highlighted. | | |
| Get help using Help | Press ?. After a second or two, press ? again, or choose Help from the main menu. | | |

Understanding Feature Availability

Depending on your phone system configuration, features included in this Phone Guide might not be available to you or might work differently on your phone. Contact your support desk or system administrator for information about feature operation or availability.

You can access many features either by using a softkey or by pressing a line button. You can configure some features but your system administrator controls most of them.

Here are some details about using softkeys and line buttons to access features:

| Feature | Softkey | Line Button Label and Icon | |
|-----------------|----------|---|--|
| Call Back | CallBack | CallBack > | |
| Call Forward | CFwdALL | Forward All | |
| Call Park | Park | Park ⊳ | |
| Call PickUp | PickUp | PickUp ⊳ | |
| Conference | Confrn | Conference 🚻 | |
| Conference List | ConfList | Conference List | |
| Do Not Disturb | DND | Do Not Disturb O or Do Not Disturb O | |
| End Call | EndCall | End Call > | |

| Feature | Softkey Line Button Label and Icon | |
|---------------------------------|------------------------------------|------------------------------|
| Group Pickup | GPickUp | Group PickUp▶ |
| Hold | Hold | Hold 📵 |
| Hunt Group | HLog | Hunt Group O or Hunt Group O |
| Malicious Call Identification | MCID | Malicious Call ID ⊳ |
| Meet Me Conferencing | MeetMe | MeetMe > |
| Mobility | Mobility | Mobility |
| New Call | New Call | New Call > |
| Other PickUp | OPickUp | Other PickUp > |
| Quality Reporting Tool | QRT | Quality Reporting Tool ⊳ |
| Redial | Redial | Redial ⊳ |
| Remove Last Conference Party | RmLstC | Remove Last Participant > |
| Transfer | Transfer | Transfer 📞 |
| Video Mode Command | VidMode | Video ⊳ |

Understanding SIP vs. SCCP

Your phone can be configured to work with one of two signaling protocols: SIP (Session Initiation Protocol) or SCCP (Skinny Call Control Protocol). Your system administrator determines this configuration.

Phone features can vary depending on the protocol. This Phone Guide indicates which features are protocol-specific. To learn which protocol your phone is using, you can ask your system administrator or you can choose Model Information > Call Control Protocol on your phone.

Basic Call Handling

You can perform basic call-handling tasks using a range of features and services. Feature availability can vary; see your system administrator for more information.

Placing a Call—Basic Options

Here are some easy ways to place a call on your Cisco Unified IP Phone.

| If you want to | Then | For more information, see |
|---|--|---|
| Place a call using the handset | Pick up the handset and enter a number. | An Overview of Your Phone, page 8 |
| Place a call using the speakerphone | Press and enter a number. | Using a Handset, Headset, and Speakerphone, page 47 |
| Place a call using a headset | Press and enter a number. Or, if is lit, press New Call and enter a number. | Using a Handset, Headset, and Speakerphone, page 47 |
| Redial a number | Press Redial to dial the last number, or press the Navigation button (with the phone idle) to see your Placed Calls. | Using Call Logs, page 51 |
| Place a call while another call is active (using the same line) | 1. Press Hold. | Using Hold and Resume, page 22 |
| is active (asing the same line) | Press New Call. Enter a number. | Page 22 |
| Dial from a call log | 1. Choose > Missed Calls, Received Calls, or Placed Calls. | Using Call Logs, page 51 |
| _ | 2. Press the listing on the touchscreen. | |

Tips

- When you pre-dial, your phone tries to anticipate the number you are dialing by displaying matching numbers (if available) from your Placed Calls log. This is called Auto Dial. To call a number displayed with Auto Dial, press the number, or scroll to it and go off-hook.
- If you make a mistake while dialing, press << to erase digits.

Placing a Call—Additional Options

You can place calls using special features and services that might be available on your phone. See your system administrator for more information about these additional options.

| If you want to | Then | For more information, see |
|--|--|--|
| Place a call while another call is active (using a different line) | Press for a new line. The first call is automatically placed on hold. Enter a number. | Using Hold and Resume, page 22 |
| Speed dial a number | Do one of the following: Press (a speed-dial button). Use the Abbreviated Dial feature. Use the Fast Dial feature. | Speed Dialing, page 34 |
| Dial from a corporate directory on your phone | Choose > Corporate Directory (name can vary). Enter a name and press Search. Highlight a listing and go off-hook. | Using Call Logs, page 51 |
| Dial from a corporate directory on your personal computer using Cisco WebDialer | Open a web browser and go to a WebDialer-enabled corporate directory. Click the number that you want to dial. | Setting Up Phones and Access Lists for Mobile Connect, page 66 |
| Use Cisco CallBack to receive notification when a busy or ringing extension is available | Press CallBack while listening to the busy tone or ring sound. Hang up. Your phone alerts you when the line is free. Place the call again. | Your system administrator |
| See if a line associated with a speed-dial, call record, or directory listing is busy before placing a call to that line | Look for Busy Line Feature indicators. | Using BLF to Determine a Line State, page 41 |
| Make a priority (precedence) call (SCCP phones only) | Enter the MLPP access number, then enter a phone number. | Prioritizing Critical Calls, page 42 |

| If you want to | Then | For more information, see |
|---|--|--|
| Dial from a Personal Address Book (PAB) entry | 1. Choose > Personal Directory to log in. | Using Personal Directory on Your Phone, page 54 |
| | 2. Choose Personal Address Book and search for a listing. | |
| Place a call using a billing or | 1. Dial a number. | Your system |
| tracking code (SCCP phones only) | 2. After the tone, enter a client matter code (CMC) or a forced authorization code (FAC). | administrator |
| Place a call using your Extension Mobility profile | Log in to the Extension Mobility service on a phone. | Using Cisco Extension Mobility, page 44 |
| Make a call from a cellular phone using Mobile Voice Access | 1. Obtain your Mobile Voice Access number and end-user PIN from your system administrator. | Using Cisco Extension Mobility, page 44 |
| | 2. Dial your assigned Mobile Voice access number. | |
| | 3. Enter your cellular phone number (if requested) and PIN. | |
| | 4. Press 1 to make a call to an enterprise IP phone. | |
| | 5. Dial a desktop phone number other than your desktop phone number). | |

Answering a Call

You can answer a call by simply lifting the handset, or you can use other options if they are available on your phone.

| If you want to | Then | For more information, see |
|---|---|--|
| Answer with a headset | Press (a), if unlit. Or, if (a) is lit, press Answer or (flashing). | Using a Handset, Headset, and Speakerphone, page 47 |
| Answer with the speakerphone | Press , Answer, or (flashing). | Using a Handset, Headset, and Speakerphone, page 47 |
| Switch from a connected call to answer a new call | Press Answer or, if the call is ringing on a different line, press (flashing). | Using Hold and Resume, page 22 |
| Answer using call waiting | Press Answer. | Using Hold and Resume, page 22 |
| Send a call to a voice message system | Press iDivert. | Sending a Call to a Voice Message System, page 26 |
| Auto-connect calls | Use AutoAnswer. | Using AutoAnswer, page 48 |
| Retrieve a parked call on another phone | Use Call Park or Directed Call Park. | Storing and Retrieving Parked Calls, page 36 |
| Use your phone to answer a call ringing elsewhere | Use Call Pickup. | Picking Up a Redirected Call on Your Phone, page 35 |
| Answer a priority call (SCCP phones only) | Hang up the current call and press Answer. | Prioritizing Critical Calls, page 42 |

| If you want to | Then | For more information, see |
|---|--|--|
| Answer a call on your cellular phone or other | Set up Mobile Connect and answer your phone. | Using Cisco Extension Mobility, page 44 |
| remote destination | When you enable Mobile Connect: | |
| | Your desktop and remote destinations receive calls simultaneously. | |
| | When you answer the call on your desktop phone, the remote destinations stop ringing, are disconnected, and display a missed call message. | |
| | • When you answer the call on one remote destination, the other remote destinations stop ringing, are disconnected, and a missed call message is shown on the other remote destinations. | |

Tip

If parties on a call hear a beep tone, the call might be monitored or recorded. Ask your system administrator for more information.

Ending a Call

To end a call, simply hang up. Here are some more details.

| If you want to | Then |
|--|---|
| Hang up while using the handset | Return the handset to its cradle. Or press EndCall. |
| Hang up while using a headset | Press O. Or, to keep headset mode active, press EndCall. |
| Hang up while using the speakerphone | Press or EndCall. |
| Hang up one call, but preserve another call on the same line | Press EndCall. If necessary, remove the call from hold first. |

Using Hold and Resume

If the Hold Reversion feature is enabled for your phone, a call that you put on hold reverts back to ringing after a certain period of time. The 'reverting' call remains on hold until you resume it or until Hold Reversion times out.

Your phone indicates the presence of a reverting call by:

- Alerting you at intervals with a single ring (or flash or beep, depending on your phone line setting).
- Briefly displaying a "Hold Reversion" message in the status bar at the bottom of the phone screen.
- Displaying the animated Hold Reversion icon next to the caller ID for the held call.
- Displaying a flashing amber line button (depending on the line state).

| If you want to | The | en |
|---|-----|--|
| Put a call on hold | 1. | Make sure the appropriate call is highlighted. |
| | 2. | Press Hold. |
| Remove a call from | 1. | Make sure the appropriate call is highlighted. |
| hold on the current line | 2. | Press Resume. |
| Remove a call from hold on a different line | | Press the appropriate line button: or (flashing). Doing so might cause a held call to resume automatically: |
| | | • If there is a reverting call on the line, that call will resume. |
| | | If there is more than one reverting call on the line, the oldest reverting call will resume. |
| | | If a non-reverting held call is the only call on the line, it will resume. |
| | 2. | If necessary, scroll to the appropriate call and press Resume. |

Tips

- Engaging the Hold feature typically generates music or a beeping tone.
- If you receive an alert for an incoming call and a reverting call at the same time, by default your phone will shift the focus of the phone screen to display the incoming call. Your system administrator can change this focus priority setting.
- If you use a shared line, Hold Reversion rings only on the phone that put the call on hold, not on the other phones that share the line.
- Your system administrator determines the duration between Hold Reversion alerts.

Using Mute

With Mute enabled, you can hear other parties on a call but they cannot hear you. You can use Mute with the handset, speakerphone, or a headset.

| If you want to | Then |
|-----------------------|---------|
| Toggle Microphone on | Press . |
| Toggle Microphone off | Press . |

Switching Between Multiple Calls

You can switch between multiple calls on one or more lines. If the call that you want to switch to is not automatically highlighted, press the call appearance on your touchscreen or scroll to it.

| If you want to | Then |
|---|--|
| Switch between connected calls on one line | Make sure the call that you want to switch to is highlighted. Press Resume. |
| <u>. </u> | Any active call is placed on hold and the selected call is resumed. |
| Switch between | Press for the line that you are switching to. |
| connected calls on different lines | If a single call is holding on the line, the call automatically resumes. If multiple calls are holding, highlight the appropriate call and press Resume . |
| Switch from a connected call to answer a ringing call | Press Answer , or if the call is ringing on a different line, press (flashing). Any active call is placed on hold and the selected call is resumed. |

Switching an In-Progress Call to Another Phone

You can switch in-progress calls between the desktop phone and your cellular phone or other remote destination.

| If you want to | Then |
|--|---|
| Switch an in-progress call on your desktop phone to a cellular phone | Press the Mobility softkey and select Send call to mobile. Answer the in-progress call on your cellular phone. The desktop phone line button turns red and handset icons and the calling party number appear on the phone display. You cannot use same phone line for any other calls, but if your desk phone supports multiple lines, you can use another line to make or receive calls. |
| Switch an in-progress call from a cellular phone to your desktop phone | Hang up the call on your cellular phone to disconnect the cellular phone, but not the call. Press Resume on your desk phone within 4 seconds and start talking on the desk phone. |

Viewing Multiple Calls

Understanding how multiple calls are displayed on your phone can help you organize your call-handling efforts.

In standard viewing mode, your phone displays calls as follows for the highlighted line:

- Calls with the highest precedence and longest duration display at the top of the list.
- Calls of a similar type are grouped together. For example, calls that you have interacted with are grouped near the top, and calls on hold are grouped last.

You can use these additional methods to view multiple calls on multiple lines:

| If you want to | Then |
|------------------------------|---|
| View calls on another line | Press ?. Immediately press the line button |
| Switch to call overview mode | Press for the highlighted line. The phone switches to call overview mode, displaying only one call per line. The displayed call is either the active call or the held call with the longest duration. To return to standard viewing mode, press , then immediately press the line button. |

Transferring Calls

Transfer redirects a connected call. The *target* is the number to which you want to transfer the call.

| If you want to | Then |
|---|--|
| Transfer a call without talking to the transfer | 1. From an active call, press Transfer. |
| | 2. Enter the target number. |
| recipient | 3. Press Transfer again to complete the transfer or EndCall to cancel. |
| | Note If your phone supports on-hook transfer, you can alternately complete the transfer by hanging up. |
| Talk to the transfer | 1. From an active call, press Transfer. |
| recipient before transferring a call (consult transfer) | 2. Enter the target number. |
| a can (consuit transfer) | 3. Wait for the transfer recipient to answer. |
| | 4. Press Transfer again to complete the transfer or EndCall to cancel. |
| | Note If your phone supports on-hook transfer, you can alternately complete the transfer by hanging up. |
| Transfer two current calls | 1. Scroll to highlight any call on the line. |
| to each other | 2. Press Select. |
| (direct transfer) without staying on the line (SCCP | 3. Repeat this process for the second call. |
| phones only) | 4. With one of the selected calls highlighted, press DirTrfr . (To display DirTrfr you might need to press more .) |
| | The two calls connect to each other and drop you from the call. |
| | Note If you want to stay on the line with the callers, use Join instead. |
| Redirect a call to a voice message system | Press iDivert. For more information, see Sending a Call to a Voice Message System, page 26. |

Tips

- If your phone has on-hook transfer enabled, complete the call by hanging up.
- If on-hook transfer is *not* enabled on your phone, hanging up without pressing **Transfer** again places the call on hold.
- You cannot use **Transfer** to redirect a call on hold. Press **Resume** to remove the call from hold before transferring it.

Sending a Call to a Voice Message System

You can use iDivert to send an active, ringing, or on-hold call to your voice message system. Depending on the type of call and your phone configuration, you can also use iDivert to send the call to another party's voice message system.

- If the call was originally sent to someone else's phone, iDivert allows you to redirect the call either to your own voice message system or to the original called party's voice message system. Your system administrator must make this option available to you.
- If the call was sent to you directly (not transferred or forwarded to you), or if your phone does not support the option described above, using iDivert redirects the call to your voice message system.

| If you want to | Then |
|--|---|
| Send an active, ringing, or on-hold call | Press iDivert. One of two things occurs: |
| to a voice message system | The call is transferred to your voice message system. Your phone screen displays a menu that allows you to choose between your voice message system or the voice message system of the original called party. Choose an option to redirect the call. |

Tip

If your phone displays a menu that disappears before you make your selection, you can press iDivert again to re-display the menu. You can also ask your system administrator to configure a longer timeout value.

Forwarding Calls to Another Number

You can use the call forwarding features to redirect incoming calls from your phone to another number.

Your system administrator might allow you to choose from two types of call forwarding features:

- Unconditional call forwarding (Call Forward All)—Applies to all calls that you receive.
- Conditional call forwarding (Call Forward No Answer, Call Forward Busy, Call Forward No Coverage)—Applies to certain calls that you receive, according to conditions.

You can access Call Forward All on your phone; other call forwarding features are accessible only on your User Options web pages. Your system administrator determines which call forwarding features are available to you.

| If you want to | Then |
|--|--|
| Set up Call Forward All on your primary line | Press CFwdALL or Forward All and enter a target phone number. |
| Cancel Call Forward All on your primary line | Press CFwdALL or Forward All. |
| Verify that Call Forward All is enabled on your primary line | Look for: The call forward icon above the primary phone number. The call forward target number in the status line. |

Tips

- Enter the call forward target number exactly as you would dial it from your phone. For example, enter an access code or the area code, if necessary.
- You can forward your calls to a traditional analog phone or to another IP phone, although your system administrator might restrict the call forwarding feature to numbers within your company.
- Call forwarding is phone line specific. If a call reaches you on a line where call forwarding is not enabled, the call will ring as usual.
- Your system administrator can enable a call forward override feature that allows the person receiving your forwarded calls to reach you. With override enabled, a call placed from the target phone to your phone is not forwarded, but rings through.
- Your system administrator can change call forwarding conditions for your phone lines.

Using Do Not Disturb

You can use the Do Not Disturb (DND) feature to block incoming calls from ringing your phone. Your system administrator enables DND for your phone.

When DND and Call Forward are both enabled on your phone, calls are forwarded and the caller does not hear a busy tone.

Your intercom lines still ring when DND is active.

| If you want to | Then |
|----------------|---|
| Turn on DND | Press DND or Do Not Disturb Q. |
| | "Do Not Disturb" displays on the phone, the DND lights, and the ring tone is turned off. |

| Turn off DND | Press DND or Do Not Disturb . | |
|------------------------|---|--|
| Customize DND settings | If your system administrator configured DND settings to appear on the User Options page, follow these steps: | |
| | 1. Log in to your User Options web pages. See Accessing Your User Options Web Pages, page 58. | |
| | 2. From the drop-down menu, choose User Options > Device. | |
| | 3. You can set the following options: | |
| | Do Not Disturb—Turn DND on/off. | |
| | DND Incoming Call Alert—Set the alert to beep only, flash only, or disable all visible and audible alert notifications. | |

Making Conference Calls

Your Cisco Unified IP Phone allows you to talk simultaneously with multiple parties in a conference call.

Using Conference Features

You can create a conference in various ways, depending on your needs and the features that are available on your phone.

- Conference—Allows you to create a standard (ad hoc) conference by calling each participant. Use the **Confrn** softkey or the **Conference** button. Conference is available on most phones.
- Join—Allows you to create a standard (ad hoc) conference by combining existing calls. Use the **Join** softkey or button. Join is available on SCCP phones only.
- cBarge—Allows you to create a standard (ad hoc) conference by adding yourself to a call on a shared line. Press a line button or use the **cBarge** softkey or button. cBarge is only available on phones that use shared lines.
- Meet-Me—Allows you to create or join a conference by calling a conference number. Use the MeetMe softkey or button.

Using Conference

Conference allows you to call each participant. Conference is available on most phones.

| If you want to | Then |
|---|---|
| Create a conference | 1. From a connected call, press Confrn or Conference. (You may need to press the more softkey to see Confrn.) |
| | 2. Enter the participant's phone number. |
| | 3. Wait for the call to connect. |
| | 4. Press Confrn or Conference again to add the participant to your call. |
| | 5. Repeat to add additional participants. |
| Add new participants to an | Repeat the steps listed above. |
| existing conference | Your system administrator determines whether non-initiators of a conference can add or remove participants. |
| See a list of participants or remove participants | See Viewing or Removing Conference Participants, page 32. |

Using Join

(SCCP phones only)

Join allows you to combine two or more existing calls to create a conference in which you are a participant.

| If you want to | Then |
|---|--|
| Create a conference by joining together existing calls that are | 1. From an active call, highlight another call that you want to include in the conference and press Select. |
| on a single phone line | Selected calls display this icon 🗹. |
| | 2. Repeat this step for each call that you want to add. |
| | 3. Press Join. (You may need to press the more softkey to see Join.) |
| Create a conference by joining together existing calls that are on multiple phone lines | 1. From an active call, press Join. (You may need to press the more softkey to see Join.) |
| | 2. Press the green flashing line button of for the call(s) that you want to include in the conference. |
| | One of the following occurs: |
| | The calls are joined. |
| | • A window opens on your phone screen prompting you to select the call(s) that you want to join. Highlight the call(s) and press Select, then press Join to complete the action. |
| | Note If your phone does not support Join for calls on multiple lines, transfer the calls to a single line before using Join. |
| Join together two existing conferences | Use the Join or DirTrfr softkeys. |
| | Check with your system administrator to see if this feature is available to you. |
| See a list of participants or remove participants | See Viewing or Removing Conference Participants, page 32. |

Using cBarge

You can create a conference by using cBarge to add yourself to a call on a shared line.

| If you want to | Then |
|--|---|
| Create a conference by barging a call on a shared line | Press the line button for the shared line. In some cases, you must highlight the call and press cBarge to complete the action. |
| | See Using Barge to Add Yourself to a Shared-Line Call, page 38 for more information. |
| See a list of participants or remove participants | See Viewing or Removing Conference Participants, page 32. |

Using Meet-Me

Meet-Me conferencing allows you to start or join a conference by calling the conference number.

| If you want to | Then | |
|----------------------------|---|--|
| Start a Meet-Me conference | 1. Obtain a Meet-Me phone number from your system administrator. | |
| | 2. Distribute the number to participants. | |
| | 3. When you are ready to start the meeting, go off-hook to get a dial tone, then press MeetMe . | |
| | 4. Dial the Meet-Me conference number. | |
| | Participants can now join the conference by dialing in. | |
| | Note Participants hear a busy tone if they call the conference before the initiator has joined. In this case, participants must call back. | |
| Join a Meet-Me conference | Dial the Meet-Me conference number (provided by the conference initiator). | |
| | Note You will hear a busy tone if you call the conference before the initiator has joined. In this case, try your call again. | |
| End a Meet-Me conference | All participants must hang up. | |
| | The conference does not automatically end when the conference initiator disconnects. | |

Tip

If you call a secure Meet-Me conference number from a non-secure phone, your phone displays the message, "Device Not Authorized." For more information, see Making and Receiving Secure Calls, page 41.

Viewing or Removing Conference Participants

During a standard (ad hoc) conference, you can view a list of participants and remove participants.

| View a list of conference | Press ConfList or Conference List. |
|--|---|
| participants | Participants are listed in the order in which they join the conference with the most recent additions at the top. |
| Get an updated list of conference participants | While viewing the conference list, press Update. |
| See who initiated the conference | While viewing the conference list, locate the participant listed at the bottom of the list with an asterisk (*) next to the name. |
| Remove any conference participant | While viewing the conference list, highlight the participant's name and press Remove. |
| Drop the last participant added to the conference | While viewing the conference list, press RMLstC or Remove Last Participant. |
| Verify that a conference call is secure | Look for the or icon after "Conference" on the phone screen. |
| Verify that a participant is calling from a secure phone | Look for the or icon beside the participant's name on the phone screen. |
| Add more participants | See Using Conference, page 29. |

Placing or Receiving Intercom Calls

You can make an intercom call to a target phone that auto-answers the call in speakerphone mode with mute activated. The one-way intercom call allows you to deliver a short message to the recipient. If the recipient's handset or headset is in use, the audio is sent to the device that is use. Any current call activity that your recipient is engaged in continues simultaneously.

The target destination receives an intercom-alert tone and can then choose to:

- Listen to the caller with your microphone muted (you can hear the caller but the caller cannot hear you).
- End the intercom call by pressing the EndCall softkey with the intercom call in focus. Do this if you do not want to hear the message.
- Talk to the caller by pressing the active intercom button, and use either the handset, headset or speaker. The intercom call becomes a two-way connection so that you can converse with the caller.

When using the intercom feature, be aware of the following:

- From an intercom line, you can only dial other intercom lines.
- You can use only one intercom line at a time.
- When your active call is being monitored or recorded, you cannot receive or place intercom calls.

• You cannot place an intercom call on hold.



If you log into your desk phone every day using your Extension Mobility profile, make sure that your system administrator configures your Extension Mobility profile to include the intercom feature.

| If you want to | Then |
|---|--|
| Place an intercom call to a preconfigured intercom target | Press (intercom target line) and, after you hear the intercom-alert tone, begin speaking. |
| Place an intercom call to any intercom number | Press (an intercom line). Enter the intercom target number or press a speed-dial number for your target. After you hear the intercom-alert tone, begin speaking. |
| Receive an intercom call | When you hear the intercom-alert tone, handle the call in one of these ways: Listen to the message in one-way audio. Speak to the caller by pressing (the active intercom line). Press EndCall with the intercom call in focus. |

Advanced Call Handling

Advanced call-handling tasks involve special features that your system administrator might configure for your phone depending on your call-handling needs and work environment.

Speed Dialing

Speed dialing allows you to enter an index number, press a button, or select a phone screen item to place a call. Depending on configuration, your phone can support several speed-dial features:

- Speed-dial buttons
- Abbreviated Dialing
- Fast Dials



- To set up speed-dial buttons and Abbreviated Dial, you must access your User Options web pages. See Accessing Your User Options Web Pages, page 58.
- To set up Fast Dials, you must access the Personal Directory feature. See Using Personal Directory on Your Phone, page 54.
- Alternately, your system administrator can configure speed-dial features for you.

| If you want to | Then | |
|-------------------------|---|--|
| Use speed-dial buttons | 1. Set up speed-dial buttons. See the "Setting Up Speed Dials on the Web" section on page 61. | |
| | 2. To place a call, press (a speed-dial button). | |
| | Note If your phone supports the Busy Lamp Field (BLF) speed-dial feature, you can see if the speed-dial number is busy before dialing. See Using BLF to Determine a Line State, page 41. | |
| Use Abbreviated Dial | 1. Set up Abbreviated Dialing codes. See Setting Up Speed Dials on the Web, page 61. | |
| | 2. To place a call, enter the Abbreviated Dialing code and press AbbrDial. | |
| Use Fast Dial | 1. Create a Personal Address Book entry and assign a Fast Dials code. See Using Personal Directory on the Web, page 59. | |
| | 2. To place a call, access the Fast Dial service on your phone. See Using Personal Directory on Your Phone, page 54. | |

Picking Up a Redirected Call on Your Phone

Call PickUp allows you to answer a call that is ringing on a coworker's phone by redirecting the call to your phone. You might use Call PickUp if you share call-handling with coworkers.

| If you want to | Then |
|---|--|
| Answer a call that is ringing on | 1. Do one of the following: |
| another extension within your call pickup group | If the PickUp button or softkey is available, press it. |
| | If the PickUp button or softkey is not available, go off-hook to display the PickUp softkey, then press it. |
| | If your phone supports auto-pickup, you are now connected to the call. |
| | 2. If the call rings, press Answer to connect to the call. |
| Answer a call that is ringing on | 1. Do one of the following: |
| another extension outside of your group | If the GPickUp softkey or Group PickUp button is available, press it. |
| | If the GPickUp softkey or Group PickUp button is not available, go off-hook to display the GPickUp softkey, then press it. |
| | 2. Enter the group pickup code. |
| | If your phone supports auto-pickup, you are now connected to the call. |
| | 3. If the call rings, press Answer to connect to the call. |
| Answer a call that is ringing on | 1. Do one of the following: |
| another extension in your group or in an associated group | If the OPickUp softkey or Other PickUp button is available, press it. |
| | If the OPickUp softkey or Other PickUp button is not available, go off-hook to display the OPickUp softkey, then press it. |
| | If your phone supports auto-pickup, you are now connected to the call. |
| | 2. If the call rings, press Answer to connect to the call. |

Tips

• Depending on how your phone is configured, you might receive an audio and/or visual alert about a call to your pickup group.

- Pressing PickUp, GPickUp, or Group PickUp connects you to the call that has been ringing for the longest time.
- Pressing OPickUp or Other PickUp connects you to the call in the pickup group with the highest priority.
- If you have multiple lines and want to pick up the call on a non-primary line, first press of for the desired line, then press a Call PickUp button or softkey.

Storing and Retrieving Parked Calls

You can park a call when you want to store the call so that you or someone else can retrieve it from another phone in the Cisco Unified Communications Manager system (for example, a phone at a co-worker's desk or in a conference room). You can park a call by using these methods:

- Call Park—Use the Park softkey to store the call. Your phone displays the call park number where the system stored your call. You must record this number and then use the same number to retrieve the call.
- Directed Call Park—Use the Transfer softkey to direct the call to an available directed call park
 number that you dial or speed dial. To retrieve the call from a directed call park number, dial the
 park retrieval prefix, then dial or speed dial the same directed call park number.
 You can use a Directed Call Park button to speed-dial the directed call park number and to
 monitor whether a directed call park number is occupied or available.

| If you want to | Then |
|---|---|
| Store an active call using Call Park | 1. During a call, press Park. (You may need to press the more softkey to see Park.) |
| | 2. Note the call park number displayed on your phone screen. |
| | 3. Hang up. |
| Retrieve a parked call | Enter the call park number from any Cisco Unified IP Phone in your network to connect to the call. |
| Direct and store an | 1. During a call, press Transfer. |
| active call at a directed call park number | 2. Press Directed Call Park with the park-unoccupied icon to speed dial the directed call park number. |
| | A Directed Call Park (flashing) with park-occupied icon indicates the directed call park number is not available. |
| | 3. Press Transfer again to finish storing the call. |
| Retrieve a parked call from a directed call park number | From any Cisco Unified IP Phone in your network, enter the park retrieval prefix and dial the directed call park number. Or after entering the park retrieval prefix, press the (flashing) with to connect to the call. |

Tips

- You have a limited time to retrieve a parked call before it reverts to ringing at the original number. See your system administrator for details.
- Your system administrator can assign Directed Call Park buttons to available line buttons on your 7975G Cisco Unified IP Phone or on your Cisco Unified IP Phone 7914 Expansion Module.
- You can dial directed call park numbers if you do not have Directed Call Park buttons on your phone. However, you will not be able to see the status of the directed call park number.

Logging Out of Hunt Groups

If your organization receives a large number of incoming calls, you might be a member of a hunt group. A hunt group includes a series of directory numbers that share the incoming call load. When the first directory number in the hunt group is busy, the system hunts for the next available directory number in the group and directs the call to that phone.

When you are away from your phone, you can prevent hunt group calls from ringing your phone by logging out of hunt groups.

| If you want to | Then |
|--|--|
| Log out of hunt groups to temporarily block hunt group calls | Press HLog or Hunt Group . Your phone screen displays, "Logged out of Hunt Group." |
| Log in to receive hunt group calls | Press HLog or Hunt Group softkey. When logged in, the Hunt Group button is lit. |

Tip

Logging out of hunt groups does not prevent non-hunt group calls from ringing your phone.

Using a Shared Line

Your system administrator might ask you to use a shared line if you:

- Have multiple phones and want one phone number
- Share call-handling tasks with coworkers
- Handle calls on behalf of a manager

Understanding Shared Lines

Remote-in-Use Icon

The remote-in-use icon papears when another phone that shares your line has a connected call. You can place and receive calls as usual on the shared line, even when the remote-in-use icon appears.

Sharing Call Information and Barging

Phones that share a line each display information about calls that are placed and received on the shared line. This information might include caller ID and call duration. (See the Privacy section for exceptions.)

When call information is visible in this way, you and coworkers who share a line can add yourselves to calls using either Barge or cBarge. See Using Barge to Add Yourself to a Shared-Line Call, page 38.

Privacy

If you do not want coworkers who share your line to see information about your calls, enable the Privacy feature. Doing so also prevents coworkers from barging your calls. See Preventing Others from Viewing or Barging a Shared-Line Call, page 40.



The maximum number of calls that a shared line supports can vary by phone.

Using Barge to Add Yourself to a Shared-Line Call

You can use barge features (cBarge or Barge) to add yourself to calls on your shared line. (Calls must be non-private calls. See Using a Shared Line, page 37.)

Understanding Barge Features

cBarge and Barge

Depending on how your phone is configured, you can add yourself to a call on a shared line using either cBarge or Barge:

- cBarge converts the call into a standard conference, allowing you to add new participants. (See Making Conference Calls, page 28 for information about standard conferences.)
- Barge allows you to add yourself to the call but does not convert the call into a conference or allow you to add new participants.

Single-button and Multi-touch Barge

Your system administrator determines whether the barge feature on your phone operates as a single-button or multi-touch feature.

- Single button barge allows you to press a line button to barge a call.
- Multi-touch barge allows you to view call information before barging.

Using Barge Features

The table below describes how to use barge features (cBarge or Barge) to add yourself to a call on a shared line.

| If you want to | Then |
|---|---|
| See if the shared line is in use | Look for the remote-in-use icon property next to a red line button. |
| Add yourself to a call on a shared line | Press the red line button of for the shared line. |
| | One of the following occurs: |
| | You are added to the call. |
| | • A window opens on your phone screen prompting you to select the call that you want to barge. Press Barge or cBarge to complete the action. (You may need to press the more softkey to display Barge or cBarge.) |
| View conference participants (if you used cBarge) | See Viewing or Removing Conference Participants, page 32. |

Tips

- When you barge a call, other parties hear a beep tone announcing your presence. With cBarge, other parties hear a brief audio interruption and the phone screen changes to display conference details.
- If a phone that is using the shared line has Privacy enabled, call information and barge softkeys will not appear on the other phones that share the line.
- You will be disconnected from a call that you have joined using Barge if the call is put on hold, transferred, or turned into a conference call.

Preventing Others from Viewing or Barging a Shared-Line Call

If you share a phone line, you can use the Privacy feature to prevent others who share the line from viewing or barging (adding themselves to) your calls.

| If you want to | Then |
|---|--|
| Prevent others from viewing or barging calls on a shared line | Press Private To verify that Privacy is on, look for the feature-enabled icon on next to an amber line button |
| Allow others to view or barge calls on a shared line | Press Private To verify that Privacy is off, look for the feature-disabled icon next to an unlit line button |

Tips

- If the phone that shares your line has Privacy enabled, you can make and receive calls using the shared line as usual.
- The Privacy feature applies to all shared lines on your phone. Consequently, if you have multiple shared lines and Privacy is enabled, coworkers cannot view or barge calls on any of your shared lines.

Using BLF to Determine a Line State

Depending on configuration, you can use the Busy Lamp Field (BLF) feature to determine the state of a phone line associated with a speed-dial button, call log, or directory listing on your phone. You can place a call to this line, regardless of the BLF status. This feature does not prevent dialing.

| If you want to | Then |
|-----------------------------------|---|
| See the state of a | Look for one of these indicators next to the line number: |
| speed-dial line | + Line is in-use. |
| | + Line is idle. |
| | BLF indicator unavailable for this line. |
| | + Line is in Do Not Disturb state. |
| See the state of a line | Look for one of these indicators next to the line number: |
| listed in a call log or directory | Line is in-use. |
| directory | Line is idle. |
| | BLF indicator unavailable for this line. |
| | Line is in Do Not Disturb state. |

Making and Receiving Secure Calls

Depending on how your system administrator has configured your phone system, your phone might support making and receiving secure calls.

Your phone can support these types of calls:

- Authenticated call—The identities of all phones participating in the call have been verified.
- *Encrypted* call—The phone is receiving and transmitting encrypted audio (your conversation) within the Cisco IP network. Encrypted calls are also authenticated.

• *Non-secure* call—At least one of the participating phones or the connection does not support these security features, or the phones cannot be verified.

| If you want to | Then |
|---|--|
| Check the security level of a call or conference | Look for a security icon in the top right corner of the call activity area, next to the call duration timer: |
| | Authenticated call or conference Encrypted call or conference Non-secure call or conference |
| Determine if secure calls can be made in your company | Contact your system administrator. |



There are interactions, restrictions, and limitations that affect how security features work on your phone. For more information, ask your system administrator.

Tracing Suspicious Calls

(SCCP phones only.)

If you are receiving suspicious or malicious calls, your system administrator can add the Malicious Call Identification (MCID) feature to your phone. This feature enables you to identify an active call as suspicious, which initiates a series of automated tracking and notification messages.

| If you want to | Then |
|---|---|
| Notify your system administrator about a suspicious or harassing call | Press MCID or Malicious Call ID . Your phone plays a tone and displays the message, "MCID successful." |

Prioritizing Critical Calls

(SCCP phones only.)

In some specialized environments, such as military or government offices, you might need to make and receive urgent or critical calls. If you have the need for this specialized call handling, your system administrator can add Multilevel Precedence and Preemption (MLPP) to your phone.

Keep these terms in mind:

• Precedence indicates the priority associated with a call.

• *Preemption* is the process of ending an existing, lower priority call while accepting a higher priority call that is sent to your phone.

| If you | Then |
|--|--|
| Want to choose a priority (precedence) level for an outgoing call | Contact your system administrator for a list of corresponding precedence numbers for calls. |
| Want to make a priority (precedence) call | Enter the MLPP access number (provided by your system administrator) followed by the phone number. |
| Hear a special ring (faster than usual) or special call waiting tone | You are receiving a priority (precedence) call. An MLPP icon on your phone screen indicates the priority level of the call. |
| Want to view priority level of a call | Look for an MLPP icon on your phone screen: |
| | Priority call |
| | Medium priority (immediate) call |
| | High priority (flash) call |
| | Highest priority (flash override) or Executive Override call |
| | Higher priority calls are displayed at the top of your call list. If you do not see an MLPP icon, the priority level of the call is normal (routine). |
| Hear a continuous tone interrupting your call | You or the other party are receiving a call that must preempt the current call. Hang up immediately to allow the higher priority call to ring through. |

Tips

- When you make or receive an MLPP-enabled call, you will hear special ring tones and call waiting tones that differ from the standard tones.
- If you enter an invalid MLPP access number, a verbal announcement will alert you of the error.
- An MLPP-enabled call retains its priority and preemptive status when you:
 - Put the call on hold
 - Transfer the call
 - Add the call to a three-way conference
 - Answer the call using PickUp
- MLPP overrides the Do Not Disturb (DND) feature.

Using Cisco Extension Mobility

Cisco Extension Mobility (EM) allows you to temporarily configure a Cisco Unified IP Phone as your own. Once you log in to EM, the phone adopts your user profile, including your phone lines, features, established services, and web-based settings. Your system administrator must configure EM for you.

| If you want to | Then |
|----------------|--|
| Log in to EM | 1. Choose > EM Service (name can vary). |
| | 2. Enter your user ID and PIN (provided by your system administrator). |
| | 3. If prompted, select a device profile. |
| Log out of EM | 1. Choose > EM Service (name can vary). |
| | 2. When prompted to log out, press Yes. |

Tips

- EM automatically logs you out after a certain amount of time. Your system administrator establishes this time limit.
- Changes that you make to your EM profile from your User Options web pages take effect
 immediately if you are logged in to EM on the phone; otherwise, changes take effect the next time
 you log in.
- Changes that you make to the phone from your User Options web pages take effect immediately if you are logged out of EM; otherwise, changes take effect after you log out.
- Local settings controlled by the phone are not maintained in your EM profile.

Managing Business Calls Using a Single Phone Number

With Mobile Connect and Mobile Voice Access installed, you can use your cellular phone to handle calls associated with your desktop phone number. A *smartphone* is a mobile phone with personal computer capabilities such as web browsing, email, address book, and calendar.

| If you want to | Then |
|---|--|
| Configure Mobile Connect | Use the User Options web pages to set up remote destinations and create access lists to allow or block calls from specific phone numbers from being passed to the remote destinations. See Setting Up Phones and Access Lists for Mobile Connect, page 66. |
| Answer a call using your cellular phone | See Answering a Call, page 20. |
| Switch an in-progress call between your desk phone and cellular phone | See Switching an In-Progress Call to Another Phone, page 24. |

| If you want to | Then |
|--|---|
| Put a call that has been picked up on a smartphone | 1. Press the <i>Enterprise Hold</i> (exact softkey name can vary) softkey on the smartphone. |
| on hold | The other party is placed on hold. |
| | 2. Press the <i>Resume</i> (exact softkey name can vary) softkey on the smartphone. See Switching an In-Progress Call to Another Phone, page 24. |
| Transfer a call that has been picked up on a smartphone to another number | 1. Press the <i>Enterprise Transfer</i> (exact softkey name can vary) softkey on the smartphone. |
| | 2. Dial your enterprise access code for transferring calls to initiate a new call. The other party is placed on hold. |
| | 3. Press the <i>Enterprise Transfer</i> softkey to complete the call transfer. |
| Initiate a conference call on a call that has been picked up on a smartphone | 1. Press the <i>Enterprise Conference</i> (exact softkey name can vary) softkey on the smartphone. |
| | 2. Dial your enterprise access code for conferencing to initiate a new call. The other party is placed on hold. |
| | 3. Press the <i>Enterprise Conference</i> softkey to complete the conference set-up and include both callers in the conference. |
| Connect to Mobile Voice | 1. From any phone, dial your assigned Mobile Voice Access number. |
| Access | 2. Enter the number you are calling from, if prompted, and your PIN. |
| Turn on Mobile Connect | 1. Dial your assigned Mobile Voice access number. |
| from your cellular phone | 2. Enter your cellular phone number (if requested) and PIN. |
| | 3. Press 2 to enable Mobile Connect. |
| | 4. Choose whether to turn Mobile Connect on for all configured phones or just one: |
| | - All phones—Enter 2. |
| | One phone—Enter 1 and enter the number you want to add as a remote destination, followed by #. |

| If you want to | Then |
|--------------------------------------|---|
| Make a call from your cellular phone | See Placing a Call—Additional Options, page 18. |
| Turn off Mobile Connect | 1. Dial your assigned Mobile Voice access number. |
| from your cellular phone | 2. Enter your cellular phone number (if requested) and PIN. |
| | 3. Press 3 to disable Mobile Connect. |
| | 4. Choose whether to turn Mobile Connect off for all configured phones or just one: |
| | - All phones—Enter 2. |
| | One phone—Enter 1 and enter the number you want to remove as a remote destination, followed by #. |

Tips

- When calling Mobile Voice Access, you need to enter the number you are call from in addition to the PIN if any of the following are true:
 - The number you are calling from is not one of your remote destinations.
 - The number is blocked by you or your carrier (shown as "Unknown Number").
 - The number is not accurately matched in the Cisco Unified Communications Manager database; for example, if your number is 510-666-9999, but it is listed as 666-9999 in the database, or your number is 408-999-6666, but it is entered as 1-408-999-6666 in the database.
- If you incorrectly enter any requested information (such as cellular phone number or PIN) three times in a row, the Mobile Voice Access call disconnects, and you are locked out for a period of time. Contact your system administrator if you need assistance.

Using a Handset, Headset, and Speakerphone

You can use your phone with a handset, headset, or speakerphone.

| If you want to | Then |
|--|--|
| Use the handset | Lift it to go off-hook; replace it to go on-hook. |
| Use a headset | Press to toggle headset mode on and off. You can use a headset with all of the controls on your phone, including and |
| | If you use AutoAnswer, see Using AutoAnswer, page 48. |
| | If you use a headset that supports wideband, you might experience improved audio sensitivity if you enable the wideband setting on your phone (this setting is disabled by default). To access the setting, choose > User Preferences > Audio Preferences > Wideband Headset. If the Wideband Headset setting is disabled (shows as dimmed), then this setting is not user controllable. |
| | Check with your system administrator to be sure your phone system is configured to use wideband. If the system is not configured for wideband, you may not detect any additional audio sensitivity even when using a wideband headset. To learn more about your headset, refer to the headset documentation or ask your system administrator for assistance. |
| Use the speakerphone | Press (1) to toggle speakerphone mode on or off. |
| | Many of the actions you can take to dial a number or answer a call will automatically trigger speakerphone mode, assuming that the handset is in its cradle and (a) is not lit. |
| Switch to the speakerphone or a headset (from the handset) during a call | Press or or, then hang up the handset. |
| Switch to the handset (from the speakerphone or headset) during a call | Lift the handset (without pushing any buttons). |
| Adjust the volume level for a | Press during a call or after invoking a dial tone. |
| call | This action adjusts the volume for the handset, speakerphone, or headset, depending on which device is in use. |
| | Press Save to preserve the volume level for future calls. |

Obtaining a Headset

Your phone supports four- or six-wire headset jacks. For information about purchasing headsets, see Headset Information, page 6.

Using AutoAnswer

When AutoAnswer is enabled, your phone answers incoming calls automatically after a few rings. Your system administrator configures AutoAnswer to use either the speakerphone or a headset. You might use AutoAnswer if you receive a high volume of incoming calls.

| If you | Then |
|--------------------------------------|---|
| Use AutoAnswer with a headset | Keep headset mode active (in other words, keep (illuminated), even when you are not on a call. |
| | To keep headset mode active, do the following: |
| | Press EndCall to hang up. |
| | Press New Call or Dial to place new calls. |
| | If your phone is set up to use AutoAnswer in headset mode, calls are automatically answered only if is illuminated. Otherwise, calls ring normally and you must manually answer them. |
| Use AutoAnswer with the speakerphone | Keep the handset in the cradle and headset mode inactive (unlit). |
| | Otherwise, calls ring normally and you must manually answer them. |

Tip

AutoAnswer is disabled when Do Not Disturb is active.

Changing Phone Settings

You can personalize your Cisco Unified IP Phone by adjusting the ring tone, background image, and other settings.

Customizing Rings and Message Indicators

You can customize how your phone indicates an incoming call and a new voice mail message. You can also adjust the ringer volume for your phone.

| If you want to | Then |
|---|---|
| Change the ring tone per line | Choose Subset Viser Preferences > Rings. Choose a phone line or the default ring setting. Choose a ring tone to play a sample of it. Press Select and Save to set the ring tone, or press Cancel. |
| Change the ring pattern per line (flash-only, ring once, beep-only, etc.) | Log in to your User Options web pages. (See Accessing Your User Options Web Pages, page 58.) Access your call ring pattern settings. (See Controlling Line Settings on the Web, page 64.) |
| | Note Before you can access this setting, your system administrator might need to enable it for you. |
| Adjust the volume level for the phone ringer | Press while the handset is in the cradle and the headset and speakerphone buttons are off. The new ringer volume is saved automatically. |
| Change the way that the voice message light on your handset works | Log in to your User Options web pages. (See Accessing Your User Options Web Pages, page 58.) Access your message indicator settings. (See Controlling Line Settings on the Web, page 64.) |
| | Note Typically, the default system policy is to indicate a new voice message by displaying a steady light on the handset light strip. |

Customizing the Touchscreen

You can adjust the characteristics of the touchscreen.

| If you want to | Then |
|--|--|
| Change the touchscreen brightness | Choose Super Preferences > Brightness. To make adjustments, press Up, Down or Super Preferences > Brightness. |
| Change the background image | Press Save, or press Cancel. Choose > User Preferences > Background Images. Scroll through available images and press Select to choose an image. Press Preview to see a larger view of the background image. Press Exit to return to the selection menu. Press Save to accept the new image, or press Cancel. |
| Enable or disable the touchscreen | See Cleaning and Maintaining the Touchscreen, page 13. |
| Change the language on your touchscreen | 1. Log in to your User Options web pages. (See Accessing Your User Options Web Pages, page 58.) |
| | 2. Access your user settings. (See Controlling User Settings on the Web, page 63.) |
| Change the line text label | 1. Log in to your User Options web pages. (See Accessing Your User Options Web Pages, page 58.) |
| | 2. Access your line label settings. (See Controlling Line Settings on the Web, page 64.) |
| Adjust contrast for your Cisco Unified IP Phone Expansion Module 7914 (SCCP phones with Expansion Modules only) | Choose > User Preferences > Contrast. To make adjustments, press Up, Down or Press Save, or press Cancel. |
| Turn off illumination of the touchscreen | Contact your system administrator to see if this optional feature is available to you. This feature allows you to turn off touchscreen illumination for a pre-determined time (as set by your system administrator). |

Using Call Logs and Directories

This section describes how you can use call logs and directories. To access both features, use the Directories button ...

Using Call Logs

Your phone maintains call logs. Call logs contain records of your missed, placed, and received calls.

| If you want to | Then |
|--|---|
| View your call logs | Choose > Missed Calls, Placed Calls, or Received Calls. Each stores up to 100 records. |
| Display details for a single call record | Choose > Missed Calls, Placed Calls, or Received Calls. Highlight a call record. Press Details. Doing so displays information such as called number, calling number, time of day, and call duration (for placed and received calls only). |
| Erase all call records in all logs | Press , then press Clear. |
| Erase all call records in a single log | Choose > Missed Calls, Placed Calls, or Received Calls. Highlight a call record. Press Clear. (You may need to press the more softkey to display Clear.) |
| Erase a single call record | Choose > Missed Calls, Placed Calls, or Received Calls. Highlight a call record. Press Delete. |
| Dial from a call log (while not on another call) | Choose > Missed Calls, Placed Calls, or Received Calls. Highlight a call record. Note If the Details softkey appears, the call is the primary entry of a multiparty call. See the Tip section below. If you need to edit the displayed number, press EditDial followed by << or |
| | >>. To delete the number, press EditDial followed by Delete. (You may need to press the more softkey to display Delete.) 4. Go off-hook to place the call. |

| If you want to | Then |
|--|---|
| Dial from a call log (while connected to another call) | Choose |
| See if the line in the call log is busy before placing a call to that line | • EndCall—Disconnects the first call and dials the second. Look for Busy Lamp Field indicators. See Using BLF to Determine a Line State, page 41. |
| Place a call from a URL entry in a call log (SIP phones only) | Choose > Missed Calls, Placed Calls, or Received Calls. Highlight the URL entry that you want to dial. If you need to edit the entry, press EditDial. The ② icon appears to indicate that you can begin editing characters in the URL entry. Press Dial. |
| View intercom call history | Choose > Intercom History. Details of the 25 most recent intercom calls are logged. You cannot dial intercom numbers from this screen. |

Tip

(SCCP phones only)

To view the complete call record of a multiparty call (for example, of call that has been forwarded or transferred to you), highlight the call record and press **Details**. The Details record shows two entries for each missed or received multiparty call. The entries are listed in reverse chronological order:

• The first logged entry is the name/number of the last completed call of a multiparty call received on your phone.

• The second logged entry is the name/number of the first completed call of a multiparty call received on your phone.

Directory Dialing

Depending on configuration, your phone can provide corporate and personal directory features:

- Corporate Directory—Corporate contacts that you can access on your phone. Your system administrator sets up and maintains your Corporate Directory.
- Personal Directory—If available, personal contacts and associated speed-dial codes that you can configure and access from your phone and User Options web pages. Personal Directory is comprised of Personal Address Book (PAB) and Fast Dials:
 - PAB is a directory of your personal contacts.
 - Fast Dials allows you to assign codes to PAB entries for quick dialing.

Using Corporate Directory on Your Phone

You can use a corporate directory to place calls to coworkers.

| If you want to | Then |
|--|--|
| Dial from a corporate directory (while not on | 1. Choose > Corporate Directory (exact name can vary). |
| | 2. User your keypad to enter a full or partial name and press Search. |
| another call) | 3. To dial, press the listing, or scroll to the listing and go off-hook. |
| Dial from a corporate | 1. Choose Corporate Directory (exact name can vary). |
| directory (while on another call) | 2. User your keypad to enter a full or partial name and press Search. |
| another can) | 3. Scroll to a listing and press Dial. |
| | 4. Choose a menu item to handle the original call: |
| | Hold—Puts the first call on hold and dials the second. |
| | • Transfer—Transfers the first party to the second and drops you from the call. (Press Transfer again after dialing to complete the action.) |
| | • Conference—Creates a conference call with all parties, including you. (Press Confrn or Conference again after dialing to complete the action.) |
| | • EndCall—Disconnects the first call and dials the second. |
| See if the phone line in the directory is busy | Look for Busy Lamp Field (BLF) indicators. See Using BLF to Determine a Line State, page 41. |

Tip

Use the numbers on your keypad to enter characters on your phone screen. Use the Navigation button on your phone to move between input fields.

Using Personal Directory on Your Phone

The Personal Directory feature set contains your Personal Address Book (PAB) and Fast Dials. This section describes how to set up and use Personal Directory on your phone. Alternately, see the "Using Personal Directory on the Web" section on page 59.

| If you want to | Then |
|---|--|
| Access Personal Directory (for PAB and Fast Dial codes) | 1. Choose > Personal Directory (exact name can vary). |
| | 2. Enter your Cisco Unified Communications Manager user ID and PIN, then press Submit. |
| Search for a PAB | 1. Access Personal Directory, then choose Personal Address Book. |
| entry | 2. Enter search criteria and press Submit. |
| | 3. You can choose Previous or Next to move through listings. |
| _ | 4. Highlight the PAB listing that you want and press Select . |
| Dial from PAB entry | 1. Search for a listing. |
| | 2. Highlight the listing and press Select. |
| | 3. Press Dial. (You may need to press the more softkey to see Dial.) |
| | 4. Enter the participant's phone number. |
| | 5. Highlight the number that you want to dial and press OK. |
| | 6. Press OK again to dial the number. |
| Delete a PAB entry | 1. Search for a listing. |
| | 2. Highlight the listing and press Select. |
| | 3. Press Delete. |
| | 4. Choose OK to confirm the deletion. |
| Edit a PAB entry | 1. Search for a listing. |
| | 2. Highlight the listing and press Edit to modify a name or email address. |
| | 3. If necessary, choose Phones to modify a phone number. |
| | 4. Press Update. |

| If you want to | Then |
|-----------------------|---|
| Add a new PAB entry | 1. Access Personal Directory, then choose Personal Address Book. |
| | 2. Access the Search page by choosing Submit . (You do not need to input search information first.) |
| | 3. Press New. |
| | 4. Use your phone keypad to enter a name and email information. |
| | 5. Choose Phones and use the keypad to enter phone numbers. Be sure to include any necessary access codes such as a 9 or 1. |
| | 6. Choose Submit to add the entry to the database. |
| Assign a Fast Dial | 1. Search for a PAB entry. |
| code to a PAB entry | 2. Highlight the listing and press Select. |
| | 3. Press Fast Dial. |
| | 4. Highlight the number that you want to dial and press Select. |
| | 5. Highlight the Fast Dial code that you want to assign to the number and press Select . |
| Add a new Fast Dial | 1. Choose Personal Directory > Personal Fast Dials. |
| code (not using a PAB | 2. Press Fast Dial. |
| entry) | 3. Highlight a Fast Dial code that is unassigned and press Select. |
| | 4. Press Assign. |
| | 5. Enter a phone number. |
| | 6. Press Update. |
| Search for Fast Dial | 1. Choose Personal Directory > Personal Fast Dials. |
| codes | 2. You can choose Previous or Next to move through listings. |
| | 3. Highlight the listing that you want and press Select. |
| Place a call using a | 1. Search for a Fast Dial code. |
| Fast Dial code | 2. Highlight the listing you want and press Select. |
| | 3. Press Dial. |
| | 4. Choose OK to complete the action. |
| Delete a Fast Dial | 1. Search for a Fast Dial code. |
| code | 2. Highlight the listing you want and press Select. |
| | 3. Press Remove. |
| Log out of Personal | 1. Choose Personal Directory (exact name can vary). |
| Directory | 2. Choose Logout. |

Tips

- Your system administrator can provide you the user ID and PIN that you need to log in to Personal Directory.
- Personal Directory automatically logs you out after a certain amount of time. This time limit can vary. Ask your system administrator for more information.
- Use the numbers on your keypad to enter characters on your phone screen. Use the Navigation button on your phone to move between input fields.

Accessing Voice Messages





Your company determines the voice message service that your phone system uses. For the most accurate and detailed information, refer to the documentation that came with your voice message service.

| If you want to | Then |
|--|--|
| Set up and personalize | Press and follow the voice instructions. |
| your voice message service | If a menu appears on your touchscreen, choose an appropriate menu item. |
| Check for your new | Look for: |
| voice messages | • A steady red light on your handset. (This indicator can vary. See Customizing Rings and Message Indicators, page 49.) |
| | A flashing message waiting icon and text message on your touchscreen. |
| | Note The red light and message waiting icon display only when you have a voice message on your primary line, even if you receive voice messages on other lines. |
| | Listen for: |
| | • A stutter tone from your handset, headset, or speakerphone when you place a call. |
| | Note The stutter tone is line-specific. You hear it only when using the line with the waiting messages. |
| Listen to your voice | Press . |
| messages or access the voice messages menu | Depending on your voice message service, doing so either auto-dials the message service or provides a menu on your touchscreen. |
| Send a call to a voice message system | Press iDivert. For more information, see the Sending a Call to a Voice Message System, page 26. |

Using the User Options Web Pages

Your Cisco Unified IP Phone is a network device that can share information with other network devices in your company, including your personal computer. You can use your computer to log in to your Cisco Unified CM User Options web pages, where you can control features, settings, and services for your Cisco Unified IP Phone. For example, you can set up speed-dial buttons from your User Options web pages.

Accessing Your User Options Web Pages

This section describes how to log in and select a phone device.

| If you want to | Then do this |
|--|---|
| Log in to your User Options web pages | 1. Obtain a User Options URL, user ID, and default password from your system administrator. |
| | 2. Open a web browser on your computer, enter the URL, and log on. |
| | 3. If prompted to accept security settings, click Yes or Install Certificate. |
| | The Cisco Unified Communications Manager User Options main web page displays. From this page you can choose User Options to access User Settings, Directory features, a Personal Address Book, and Fast Dials. |
| | Or, to access phone-specific options, select a device (see below). |
| Select a device after logging in | 1. After you have logged in to your User Options web pages, choose User Options > Device. |
| | The Device Configuration page displays. |
| | 2. If you have multiple devices assigned to you, choose the appropriate device (phone model, Extension Mobility profile, or Remote Destination profile) from the Name drop-down menu. |
| | Note Toolbar buttons located at the top of the Device Configuration page are specific to the selected device type. |
| Select a configuration option after logging in | 1. After you have logged in to your User Options web pages, choose User Options to access User Settings, Directory, Personal Address Book, Fast Dials, and Mobility Settings. |
| | 2. To return to the Device Configuration page from another page, choose User Options > Device. |

Configuring Features and Services on the Web

The topics in this section describe how to configure features and services from your User Options web pages after logging in. See Accessing Your User Options Web Pages, page 58.

Using Personal Directory on the Web

The Personal Directory feature set that you can access on your computer consists of:

- A Personal Address Book (PAB)
- Fast Dials
- Cisco Unified Communications Manager Address Book Synchronizer



You can also access PAB and Fast Dials from your phone. See Using Personal Directory on Your Phone, page 54.

Using Your Personal Address Book on the Web

This section describes how to use your PAB from your User Options web pages.

| If you want to | Then do this after you log in |
|------------------------|---|
| Add a new PAB entry | 1. Choose User Options > Personal Address Book. |
| | 2. Click Add New. |
| | 3. Enter information for the entry. |
| | 4. Click Save. |
| Search for a PAB entry | 1. Choose User Options > Personal Address Book. |
| | 2. Specify search information and click Find. |
| Edit a PAB entry | 1. Search for a PAB entry. |
| | 2. Click a name or nickname. |
| | 3. Edit the entry as needed and click Save. |
| Delete a PAB entry | 1. Search for a PAB entry. |
| | 2. Select one or more entries. |
| | 3. Click Delete Selected. |

Configuring Fast Dials on the Web

This section describes how to assign Fast Dials from your User Options web pages.

| If you want to | Then do this after you log in |
|--|--|
| Assign a Fast Dial code to a PAB entry | 1. Create a PAB entry. See Using Your Personal Address Book on the Web, page 59. |
| | 2. Choose User Options > Fast Dials. |
| | 3. Click Add New. |
| | 4. Use the Search Options area to find the appropriate PAB entry. |
| | 5. Click a phone number in the Search Results area. |
| | 6. Change the Fast Dial code, if desired. |
| | 7. Click Save. |
| Assign a Fast Dial code | 1. Choose User Options > Fast Dials. |
| to a phone number | 2. Click Add New. |
| (without using a PAB entry) | 3. Change the Fast Dial code, if desired. |
| ,, | 4. Enter a phone number. |
| | 5. Click Save. |
| Search for a Fast Dial | 1. Choose User Options > Fast Dials. |
| entry | 2. Specify search information and click Find. |
| Edit a Fast Dial phone | 1. Choose User Options > Fast Dials. |
| number | 2. Search for the Fast Dial entry that you want to edit. |
| | 3. Click on a component of the entry. |
| | 4. Change the phone number. |
| | 5. Click Save. |
| Delete a Fast Dial entry | 1. Search for a Fast Dial. |
| | 2. Select one or more entries. |
| | 3. Click Delete Selected. |

Tips

- You can create up to 500 Fast Dial and PAB entries.
- You can create a new Fast Dial entry without using a PAB entry. Such Fast Dial entries are labeled "raw" in the User Options web pages and do not display a configurable text label.

Using the Address Book Synchronization Tool

You can use the Address Book Synchronization Tool (TABSynch) to synchronize your existing Microsoft Windows Address Book (if applicable) with your PAB. Entries from your Microsoft Windows Address Book will then be accessible on your Cisco Unified IP Phone and User Options web pages. Your system administrator can give you access to TABSynch and provide detailed instructions.

Setting Up Speed Dials on the Web

Depending on configuration, your phone can support several speed-dial features:

- Speed-dial buttons
- Abbreviated Dialing
- Fast Dials



For help using speed-dial features, see Speed Dialing, page 34.

| If you want to | Then do this after you log in |
|--------------------|--|
| Set up speed-dial | 1. Choose User Options > Device. |
| buttons | 2. Choose a phone from the Name drop-down menu. |
| | 3. Click Speed Dials. |
| | 4. Enter a number and label for a speed-dial button (programmable button) on your phone. |
| | 5. Click Save. |
| | Note Your phone uses the ASCII Label field. |
| Set up Abbreviated | 1. Choose User Options > Device. |
| Dialing | 2. Choose a phone from the Name drop-down menu. |
| | 3. Click Speed Dials. |
| | 4. Enter a number and label for an Abbreviated Dialing code. |
| | 5. Click Save. |
| Set up Fast Dials | See Configuring Fast Dials on the Web, page 60. |
| _ | You can also set up Fast Dials on your phone. See Using Personal Directory on Your Phone, page 54. |



You can set up a speed-dial button for each programmable button on your phone that is not reserved as line button. Alternately, use Abbreviated Dial or Fast Dial.

Setting Up Phone Services on the Web

Phone services can include special phone features, network data, and web-based information (such as stock quotes and movie listings). You must first subscribe to a phone service before accessing it on your phone.

| If you want to | Then do this after you log in |
|------------------------|--|
| Subscribe to a service | 1. Choose User Options > Device. |
| | 2. Choose a phone from the Name drop-down menu. |
| | 3. Click Phone Services. |
| | 4. Click Add New. |
| | 5. Choose a service from the drop-down list and click Next. |
| | 6. Change the service label and/or enter additional service information, if available (optional). |
| | 7. Click Save. |
| Search for services | 1. Select a device. |
| | 2. Click Phone Services. |
| | 3. Click Find. |
| Change or end services | 1. Search for services. |
| | 2. Select one or more entries. |
| | 3. Click Delete Selected. |
| Change a service name | 1. Search for services. |
| | 2. Click on the service name. |
| | 3. Change the information and click Save. |

| If you want to | Then do this after you log in |
|--------------------------------|--|
| Add a service to an | 1. Choose User Options > Device. |
| available programmable phone | 2. Choose a phone from the Name drop-down menu. |
| button | 3. Click Service URL. |
| | Note If you do not see this option, ask your system administrator to configure a service URL button for your phone. |
| | 4. Choose a service from the Button Service drop-down list. |
| | 5. If you want to rename the service, edit the label fields. |
| | Note Your phone uses the ASCII Label field if the phone does not support double-byte character sets. |
| | 6. Click Save. |
| | 7. Click Reset to reset your phone (necessary to see the new button label on your phone). |
| Access a service on your phone | Choose (⊕) > Services. |

Controlling User Settings on the Web

User settings include your password, PIN, and language (locale) settings.

| If you want to | Then do this after you log in |
|--|--|
| Change your password | 1. Choose User Options > User Settings. |
| | 2. In the Browser Password area, enter information. |
| | 3. Click Save. |
| Change your PIN | 1. Choose User Options > User Settings. |
| | 2. In the Phone PIN area, enter information. |
| | 3. Click Save. |
| Change the language (locale) for your User Options web pages | 1. Choose User Options > User Settings. |
| | 2. In the User Locale area, choose an item from the Locale drop-down list. |
| | 3. Click Save. |
| Change the language (locale) for your phone screen | 1. Choose User Options > User Settings. |
| | 2. Choose an item from the User Locale drop-down list. |
| | 3. Click Save. |

Tip

Your PIN and password allow you to access different features and services. For example, use your PIN to log in to Cisco Extension Mobility or Personal Directory on your phone. Use your password to log in to your User Options web pages and Cisco WebDialer on your personal computer. For more information, ask your system administrator.

Controlling Line Settings on the Web

Line settings affect a specific phone line (directory number) on your phone. Line settings can include call-forwarding, voice message indicators, ring patterns, and line labels.

You can set up other line settings directly on your phone:

- Set up call forwarding for your primary phone line—see Forwarding Calls to Another Number, page 26.
- Change rings, display, and other phone-model specific settings—see Changing Phone Settings, page 49.

| If you want to | Then do this after you log in |
|--|---|
| Set up call forwarding per line | 1. Choose User Options > Device. |
| | 2. Choose a phone from the Name drop-down menu. |
| | 3. Click Line Settings. |
| | 4. If you have more than one directory number (line) assigned to your phone, choose a line from the Line drop-down menu. |
| | 5. In the Incoming Call Forwarding area, choose call forwarding settings for various conditions. |
| | 6. Click Save. |
| Change the voice message indicator (lamp) setting per line | 1. Choose User Options > Device. |
| | 2. Choose a phone from the Name drop-down menu. |
| | 3. Click Line Settings. |
| | 4. If you have more than one directory number (line) assigned to your phone, choose a line from the Line drop-down menu. |
| | 5. In the Message Waiting Lamp area, choose from various settings. |
| | Note Typically, the default message waiting setting prompts your phone to display a steady red light from the handset light strip to indicate a new voice message. |
| | 6. Click Save. |

| If you want to | Then do this after you log in |
|--|---|
| Change the audible voice message indicator | 1. Choose User Options > Device. |
| | 2. Choose a phone from the Name drop-down menu. |
| setting per line | 3. Click Line Settings. |
| | 4. If you have more than one directory number (line) assigned to your phone, choose a line from the Line drop-down menu. |
| | 5. In the Audible Message Waiting Indicator area, choose from various settings. |
| | Note Typically, the default message waiting setting prompts your phone to display a steady red light from the handset light strip to indicate a new voice message. |
| | 6. Click Save. |
| Change or create a line | 1. Choose User Options > Device. |
| text label that appears | 2. Choose a phone from the Name drop-down menu. |
| on your phone screen | 3. Click Line Settings. |
| | 4. If you have more than one directory number (line) assigned to your phone, choose a line from the Line drop-down menu. |
| | 5. In the Line Text Label area, enter a text label. |
| | 6. Click Save. |
| | Note Your phone uses the ASCII Label field if the phone does not support double-byte character sets. |

Setting Up Phones and Access Lists for Mobile Connect

When using Cisco Mobile Connect, you must add your cellular and other phones that you want to use to make and receive calls using the same directory numbers as your desk phone. These phones are called *remote destinations*. You can also define access lists to restrict or allow calls from certain numbers to be sent to your cellular phone.

| If you want to | nen do this after you log in | |
|-----------------------|--|-------|
| Create an access list | . Choose User Options > Mobility Settings > Access Lists. | |
| | . Click Add New. | |
| | . Enter the following information: | |
| | - Name—Identifies the access list. | |
| | - Description—Describes the access list. | |
| | . Choose one of these options: | |
| | - Blocked Access List—Creates list for numbers to be blocked | |
| | - Allowed Access List—Creates list for numbers that will be permit | itted |
| | . Click Save. | |

| If you want to | The | en do this after you log in |
|-------------------|-----|--|
| Add members to an | | Create an access list. |
| access list. | 2. | Click Add Member to add phone numbers or filters to the list. |
| | 3. | Select an option from the Filter Mask drop-down list box. You can filter a directory number, calls with restricted caller ID (Not Available), or calls with anonymous caller ID (Private). |
| | 4. | If you select a directory number from the Filter Mask drop-down list box, enter a phone number or filter in the DN Mask field. You can use the following wild cards to define a filter: |
| | | X (upper or lower case)—Matches a single digit. For example, 408555123X matches any number between 4085551230 and 4085551239. |
| | | !—Matches any number of digits. For example, 408! matches any number starts with 408. |
| | | #—Used as a single digit for exact match. |
| | 5. | To add this member to the access list, click Save. |
| | 6. | To save the access list, click Save. |

| If you want to | Then do this after you log in |
|------------------|---|
| Add a new remote | 1. Choose User Options > Mobility Settings > Remote Destinations. |
| destination | 2. Select the device from the Name drop-down list box. |
| | 3. Click Remote Destinations. |
| | 4. Click Add New. |
| | 5. Enter the following information: |
| | - Name—Enter a name for the cellular (or other) phone. |
| | - Destination Number—Enter your cellular phone number. |
| | Answer Too Soon Timer—Enter the amount of time before you can pick up a call on the remote destination (in milliseconds). |
| | Answer Too Late Timer—Enter the amount of time after which it is too late to pick up a call on the remote destination (in milliseconds). |
| | Delay Before Ringing Timer—Enter the amount of time before the call rings on the remote destination (in milliseconds). |
| | Remote Destination Profile—Select a remote destination profile, which contains the settings that apply to all of your remote destinations. |
| | Allowed Access List—Select a phone number or rule that allows your cellular phone to ring when a call comes in to your desktop phone. You can select an allowed access list or blocked access list, but not both. |
| | Blocked Access List—Select a phone number or rule for which your cellular phone does not ring when a call comes in to your desktop phone. You can select an allowed access list or blocked access list, but not both. |
| | Mobile Phone—Select to allow your cellular phone can accept a call sent from your desktop phone. |
| | Enable Mobile Connect—Select to allow your cellular phone to ring simultaneously with your desktop phone. |
| | Smart Client Installed—Select to indicate that the remote destination you are setting up is a smartphone. |
| | 6. Click Save. |

Using Cisco WebDialer

Cisco WebDialer allows you to make calls on your Cisco Unified IP Phone to directory contacts by clicking items in a web browser. Your system administrator must configure this feature for you.

| If you want to | The | Then | |
|---|-----|---|--|
| Use WebDialer with your User Options | 1. | Log in to your User Options web pages. See Accessing Your User Options Web Pages, page 58. | |
| directory | 2. | Choose User Options > Directory and search for a coworker. | |
| | 3. | Click the number that you want to dial. | |
| | 4. | If this is your first time using WebDialer, set up preferences and click Submit . (See the last row in this table for details.) | |
| | 5. | If the Make Call page appears, click Dial . (See the last row in this table to learn how to suppress this page in the future, if desired.) | |
| | | The call is now placed on your phone. | |
| | 6. | To end a call, click Hangup or hang up from your phone. | |
| Use WebDialer with another online corporate directory (not your User Options directory) | 1. | Log in to a WebDialer-enabled corporate directory and search for coworkers. | |
| | 2. | Click the number that you want to dial. | |
| | 3. | When prompted, enter your user ID and password. | |
| | 4. | If this is your first time using WebDialer, set up preferences and click Submit . (See the last row in this table for details.) | |
| | 5. | If the Make Call page appears, click Dial . (See the last row in this table to learn how to suppress this page in the future, if desired.) | |
| | | The call is now placed on your phone. | |
| | 6. | To end a call, click Hangup or hang up from your phone. | |

| If you want to | Then | |
|---|---|--|
| Log out of WebDialer | Click the logout icon in the Make Call or Hang Up page. | |
| Set up, view, or change WebDialer preferences | Access the Preferences page. | |
| | The Preferences page appears the first time that you use WebDialer (after you click the number that you want to dial.) | |
| | To return to Preferences in the future, click the preferences icon from the Make Call or Hang Up page. | |
| | The Preferences page contains the following options: | |
| | • Preferred language—Determines the language used for WebDialer settings and prompts. | |
| | • Use permanent device—Identifies the Cisco Unified IP Phone and directory number (line) that you will use to place WebDialer calls. If you have one phone with a single line, the appropriate phone and line are automatically selected. Otherwise, choose a phone and/or line. Phones are specified by host name. (To display the host name on your phone, choose > Network Configuration > Host Name.) | |
| | • Use Extension Mobility—If selected, prompts WebDialer to use the Cisco Unified IP Phone that is associated with your Extension Mobility profile (if available). | |
| | • Do not display call confirmation—If selected, prompts WebDialer to suppress the Make Call page. This page appears by default after you click a phone number in a WebDialer-enabled online directory. | |

Understanding Additional Configuration Options

Your system administrator can configure your phone to use specific button and softkey templates along with special services and features, if appropriate. This table provides an overview of some configuration options that you might want to discuss with your phone system administrator based on your calling needs or work environment.



You can locate Phone Guides and other documents listed in this table on the web: http://www.cisco.com/en/US/products/hw/phones/ps379/tsd_products_support_series_home.html

| If you | Then | For more information |
|--|---|---|
| Need to handle more calls on your phone line | Ask your system administrator to configure your line to support more calls. | Talk to your system administrator or phone support team. |
| Need more than one phone line | Ask your system administrator to configure one or more additional directory numbers for you. | Talk to your system administrator or phone support team. |
| Need more speed-dial buttons | First make sure that you are using all of your currently available speed-dial buttons. If you need additional speed-dial buttons, try using Abbreviated Dialing or subscribing to the Fast Dial service. Another option is to attach the Cisco Unified IP Phone Expansion Module 7914 to your Cisco Unified IP Phone 7975G. | See: • Speed Dialing, page 34 • Cisco Unified IP Phone Expansion Module 7914 Phone Guide. |
| Work with (or work as) an administrative assistant | Consider using: • Cisco Unified Communications Manager Assistant • A shared line | See: Using a Shared Line, page 37 Cisco Unified |
| Want to use one extension for several phones | Request a shared line. This allows you to use one extension for your desk phone and lab phone, for example. | See Using a Shared Line, page 37. |

| If you | Then | For more information |
|---|--|--|
| Share phones or office space with coworkers | Consider using: Call Park to store and retrieve calls without using the transfer feature. Call Pickup to answer calls ringing on another phone. A shared line to view or join coworkers' calls. Cisco Extension Mobility to apply your phone number and user profile to a shared Cisco Unified IP Phone. | Ask your system administrator about these features and see the: Advanced Call Handling, page 34. Using a Shared Line, page 37. Using Cisco Extension Mobility, page 44. |
| Answer calls frequently or handle calls on someone's behalf | Ask your system administrator to set up the AutoAnswer feature for your phone. | See Using AutoAnswer, page 48. |
| Need to make video calls (SCCP phones only) | Consider using Cisco Unified Video Advantage, which enables you to make video calls using your Cisco Unified IP Phone, your personal computer, and an external video camera. | Contact your system administrator for additional assistance and see the Cisco Unified Video Advantage Quick Start Guide and User Guide. |
| Determine the state of a phone line associated with a speed-dial button, call log, or directory listing on your phone Ask your administrator to set up the Busy Lamp Field (BLF) feature for your phone. | | See Using BLF to Determine a Line State, page 41. |
| Want to temporarily apply your phone number and settings to a shared Cisco Unified IP Phone | Ask your system administrator about the Cisco Extension Mobility Service. | See Using Cisco Extension Mobility, page 44. |

Troubleshooting Your Phone

This section provides troubleshooting information for your Cisco Unified IP Phone.

General Troubleshooting

This section provides information to help you troubleshoot general problems with your phone. For more information, see your system administrator.

| Symptom | Explanation | |
|--|---|--|
| You cannot hear a dial tone or complete a call | One or more of the following factors might apply: | |
| | You must log into the Extension Mobility service. | |
| | • You must enter a client matter code (CMC) or forced authorization code (FAC) after dialing a number. (SCCP phones only) | |
| | • Your phone has time-of-day restrictions that prevent you from using some features during certain hours of the day. | |
| The Settings button is unresponsive | Your system administrator might have disabled on your phone. | |
| The phone screen appears blank | The touchscreen has gone into sleep mode to save power after a period of inactivity. Wake the touchscreen by pressing it, by lifting the handset, or by pressing any button, such as See Cleaning and Maintaining the Touchscreen, page 13. | |
| The phone screen does not illuminate under any circumstances | You might have disabled touchscreen illumination on your phone. Contact your system administrator to determine if this feature is available to you. | |
| The softkey that you want to use does not appear | One or more of the following factors might apply: | |
| | You must press more to reveal additional softkeys. | |
| | • You must change the line state (for example, go off-hook or have a connected call). | |
| | • Your phone is not configured to support the feature associated with that softkey. | |
| Barge fails and results in a fast busy tone | You cannot barge an encrypted call if the phone you are using is not configured for encryption. When your barge attempt fails for this reason, your phone plays a fast busy tone. | |

| Symptom | Explanation |
|--|---|
| You are disconnected from a call that you joined using Barge | You will be disconnected from a call that you have joined using Barge if the call is put on hold, transferred, or turned into a conference call. |
| Cisco CallBack fails | The other party might have call forwarding enabled. |

Viewing Phone Administration Data

Your system administrator might ask you to access administration data on your phone for troubleshooting purposes.

| If you are asked to | Then | |
|---|---|--|
| Access network configuration data | Choose Network Configuration and select the network configuration item that you want to view. | |
| Access status data | Choose > Status and select the status item that you want to view. | |
| Access phone model information | Choose > Model Information. | |
| Access phone call and voice quality information | Choose Status > Call Statistics. | |

Using the Quality Reporting Tool

Your system administrator may temporarily configure your phone with the Quality Reporting Tool (QRT) to troubleshoot performance problems. You can press QRT or Quality Reporting Tool to submit information to your system administrator. Depending on configuration, use the QRT to:

- Immediately report an audio problem on a current call.
- Select a general problem from a list of categories and choose reason codes.

Cisco One-Year Limited Hardware Warranty Terms

There are special terms applicable to your hardware warranty and various services that you can use during the warranty period. Your formal Warranty Statement, including the warranties and license agreements applicable to Cisco software, is available on Cisco.com. Follow these steps to access and download the *Cisco Information Packet* and your warranty and license agreements from Cisco.com.

1. Launch your browser, and go to this URL:

http://www.cisco.com/univercd/cc/td/doc/es_inpck/cetrans.htm

The Warranties and License Agreements page appears.

- **2.** To read the *Cisco Information Packet*, follow these steps:
 - **a.** Click the **Information Packet Number** field, and make sure that the part number 78-5235-03B0 is highlighted.
 - **b.** Select the language in which you would like to read the document.
 - c. Click Go.

The Cisco Limited Warranty and Software License page from the Information Packet appears.

d. Read the document online, or click the PDF icon to download and print the document in Adobe Portable Document Format (PDF).

Note You must have Adobe Acrobat Reader to view and print PDF files. You can download the reader from Adobe's website: http://www.adobe.com

- 3. To read translated and localized warranty information about your product, follow these steps:
 - **a.** Enter this part number in the Warranty Document Number field:

78-10747-01C0

- **b**. Select the language in which you would like to view the document.
- c. Click Go.

The Cisco warranty page appears.

d. Read the document online, or click the PDF icon to download and print the document in Adobe Portable Document Format (PDF).

You can also contact the Cisco service and support website for assistance:

http://www.cisco.com/public/Support_root.shtml.

Duration of Hardware Warranty

One (1) Year

Replacement, Repair, or Refund Policy for Hardware

Cisco or its service center will use commercially reasonable efforts to ship a replacement part within ten (10) working days after receipt of a Return Materials Authorization (RMA) request. Actual delivery times can vary, depending on the customer location.

Cisco reserves the right to refund the purchase price as its exclusive warranty remedy.

To Receive a Return Materials Authorization (RMA) Number

Contact the company from whom you purchased the product. If you purchased the product directly from Cisco, contact your Cisco Sales and Service Representative.

Complete the information below, and keep it for reference.

| Company product purchased from | |
|--------------------------------|--|
| Company telephone number | |
| Product model number | |
| Product serial number | |
| Maintenance contract number | |

Index

| A | call logs |
|--------------------------------------|--------------------------------|
| | dialing from a URL entry in 52 |
| Abbreviated Dialing 34, 61 | erasing 51 |
| Address Book Synchronization Tool 61 | viewing and dialing from 51 |
| answering calls 20 | call overview mode 24 |
| ASCII label field support 61 | call park 36 |
| audible message waiting indicator 57 | call pickup 35 |
| audio, quality of 6 | call waiting 20 |
| authenticated calls 41 | CallBack 18 |
| Auto Dial 17 | caller ID 13 |
| AutoAnswer 48 | call-handling |
| | advanced 34 |
| В | basic 17 |
| | calls |
| barge | answering 20 |
| and privacy 40 | barging 38 |
| and shared lines 38 | blocking 27 |
| using 38 | compared to lines 11 |
| BLF 41 | conference features for 28 |
| Busy Lamp Field 41 | ending 21 |
| button 33 | forwarding 64 |
| buttons, identifying 8 | handling multiple 23 |
| | holding and resuming 22 |
| C | icons for 11 |
| | maximum per line 11 |
| call activity area 12 | multiple parties on 28 |
| call forwarding | multiple, switching between 23 |
| configuring from web page 64 | |

| muting 23 | removing participants from 32 |
|---|--|
| parking 36 | security-level for 32 |
| placing 17, 18 | types of 28 |
| prevent barging of 40 | viewing participants for 32 |
| prioritizing 42 | connected 12 |
| redirecting while ringing 35 | corporate directory |
| reporting problems with 74 | using from web page 69 |
| secure 41 | using on phone 51, 53 |
| storing and retrieving 36 | |
| transferring 25 using DND 27 | D |
| viewing 12, 24 | Details softkey, viewing multiparty calls with |
| Cisco Extension Mobility 44 | 51, 52 |
| Cisco Unified Communications Manager | device configuration page 58 |
| Address Book Synchronizer 61 | dialing, options for 17, 18 |
| Cisco Unified IP Phone | directories button 9 |
| adjusting height of 6 | directory |
| connecting 4 | corporate 53 |
| documentation for 2 | personal 53, 54 |
| feature configuration for 15, 71 | using from web page 69 |
| illustration of 8 | using on phone 53 |
| online help for 15 | display button 9, 13 |
| registering 6 | DND 27 |
| securing handset rest 5 | Do Not Disturb 27 |
| troubleshooting 73 | documentation, accessing 2 |
| web-based services for 58 | |
| Cisco Unified IP Phone Expansion Module 7914 37, 50, 71 | E |
| Cisco Unified Video Advantage 72 | EM 44 |
| Cisco WebDialer 69 | encrypted calls 41 ending a call, options for 21 |
| Client Matter Code, see CMC | |
| CMC 19, 73 | Extension Mobility 44 |
| conference calls | Excusion widding 44 |
| Meet-Me 31 | |

| r | hanging up with 21 |
|------------------------------------|---|
| FAC 19, 73 | placing calls with 17 |
| Fast Dials | using 47 |
| configuring from web page 60 | headset performance, general 6 |
| using on phone 54 | help button 10, 24 |
| feature buttons | help, using 15 |
| directories 9 | hold |
| display of 14 | and switching calls 23 |
| help 10 | and transferring 25 |
| messages 9 | using 22 |
| services 10 | hold reversion indicators, reverting calls 22 |
| settings 10 | hookswitch clip, removing 5 |
| feature menus 14 | Hunt groups, logging out 37 |
| feature tabs 12 | |
| features, availability of 15, 71 | I |
| footstand | • |
| adjusting 6 | icons |
| button for 9 | for call states 11 |
| Forced Authorization Code, see FAC | for lines 11 |
| | idle 12 |
| G | installing, Cisco Unified IP Phone 4 |
| | intercom calls 32 |
| group call pickup 35 | intercom line 12, 33 |
| н | K |
| handset | keypad 10 |
| light strip 11 | 7.1 |
| securing in cradle 5 | |
| using 47 | L |
| hanging up, options for 21 | language (locale) settings 63 |
| headset | line buttons 9 |
| answering calls with 20 | inc buttons v |

| lines | mute button 10 |
|--|---|
| and call forwarding 64 | mute, using 23 |
| and call states 11 | |
| and using BLF 41 | N |
| buttons for 9 | |
| description of 11 | Navigation button 10 |
| icons for 11 | network configuration data, locating 73 |
| number of calls supported on 11,71 | |
| ring patterns for 64 | 0 |
| ring tones for 49 | • |
| shared 37 | one-way 12 |
| switching between 23 | on-hook dialing 17 |
| text label for 64 | online help, using 15 |
| viewing 12 | |
| voice message indicator setting for 64 | P |
| logging out of hunt groups 37 | r |
| | PAB |
| М | using from web page 59 |
| | using on phone 54 |
| Malicious Call Identification 42 | password, changing 63 |
| MCID 42 | Personal Address Book, see PAB |
| Meet-Me conferences 31 | Personal Directory |
| menus, using 14 | using from web page 59 |
| messages | using on phone 54 |
| indicator for 49, 57 | phone lines |
| listening to 57 | buttons for 9 |
| messages button 9 | description of 11 |
| missed calls, records of 51 | viewing 12 |
| MLPP, using 42 | phone services |
| multiparty calls | configuring |
| identifying in call logs 51, 52 | see also User Options web pages |
| viewing details of 51, 52 | phone tab 12 |
| multiple calls, handling 23 | PIN, changing 63 |

| placed calls, records of 51 | secure conferences 32 |
|--|--|
| placing calls, options for 17, 18 | security, for calls 41 |
| pre-dial 17 | Select button 10 |
| prioritizing calls 42 | services button 10 |
| privacy | services, subscribing to 62 |
| and shared lines 38 | settings button 10 |
| using 40 | settings, customizing 49 |
| programmable buttons | shared lines |
| description of 9 | and remote-in-use icon 38 |
| labels for 12 | description of 37 |
| | with barge 38 |
| Q | with privacy 40 |
| | sleep mode, waking touchscreen from 13 |
| QRT 74 | softkey buttons |
| Quality Reporting Tool 74 | description of 10 |
| | labels for 12 |
| R | speakerphone |
| n | answering calls with 20 |
| received calls, records of 51 | button for 10 |
| redial 17 | hanging up with 21 |
| remote-in-use icon for shared lines 38 | placing calls with 17 |
| resume, using 22 | using 47 |
| ring patterns, changing 64 | speed dial |
| ring tones, changing 49 | buttons for 9 |
| ringer | configuring 34, 61 |
| customizing 49 | description of 34 |
| indicator for 11 | labels 12, 61 |
| volume for 49 | using 18 |
| | using BLF with 34 |
| S | status data, locating 73 |
| | status line, viewing 12 |
| safety, warnings 2 | subscriptions, for phone services 62 |
| secure calls 41 | suspicious calls, tracing 42 |
| | |

V switching calls 23 voice message indicator T changing setting for 64 description of 57 tabs, on touchscreen 12 voice message service 57 TABSynch 61 volume TAPS 6 for handset, headset or speakerphone 47 telephony features for phone ringer 49 audible message waiting indicator 57 volume button 10 Tool for Auto-Registered Phones Support 6 touchscreen adjusting contrast 50 W changing language 50 warnings, safety 2 cleaning 13 web-based services disabling/enabling 13 configuring 58 features of 12 see also User Options web pages illumination setting 50 WebDialer 69 sleep mode 13 whisper 12 transferring, options for 25 wideband headset 47 troubleshooting general 73 see also QRT two-way 12 U URL dialing, from call log 52 User Options web pages accessing 58

82 OL-14621-01

configuring features and services with 59 subscribing to phone services with 62



Americas Headquarters Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA www.cisco.com

Tel: 408 526-4000 800 553-NETS (6387)

Fax: 408 527-0883

Asia Pacific Headquarters Cisco Systems, Inc. 168 Robinson Road

#28-01 Capital Tower Singapore 068912 www.cisco.com

Tel: +65 6317 7777 Fax: +65 6317 7799 Europe Headquarters Cisco Systems International BV Haarlerbergpark

Haarlerbergpark Haarlerbergweg 13-19 1101 CH Amsterdam The Netherlands www-europe.cisco.com

Tel: 31 0 800 020 0791 Fax: 31 0 20 357 1100

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.

CCVP, the Cisco logo, and the Cisco Square Bridge logo are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn is a service mark of Cisco Systems, Inc.; and Access Registrar, Aironet, BPX, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Pistems, Cisco Systems, Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherPasite, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, iQuick Study, LightStream, Linksys, MeetingPlace, MGX, Networking Academy, Network Registrar, PIX, ProConnect, ScriptShare, SMARTnet, StackWise, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States ducertain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0709R)

© 2007 Cisco Systems, Inc. All rights reserved.

Java The Java logo is a trademark or registered trademark of Sun Microsystems, Inc. in the U.S. or other countries.