



Linear **SECURITY**

DVS 2408

SUPERVISED WIRELESS SECURITY CONTROL PANEL



Installation & Programming Instructions

Linear[®]

(760) 438-7000 • FAX (760) 438-7043
USA & Canada (800) 421-1587 & (800) 392-0123
Toll Free FAX (800) 468-1340

INTRODUCTION

CONGRATULATIONS for selecting Linear's DVS-2408 Security System. The Model DVS-2408P Control Panel and the Model DVS-2408KP Keypad incorporate many advanced and sophisticated features. The system can be expanded and customized to fit the installation's specific needs.

The DVS-2408P Control Panel and its accessories are designed and manufactured by the oldest wireless security company in North America. You can look ahead to many years of reliable service with this Control Panel and its accessories.

Many insurance companies offer discounts on homeowners and renters policies when a security system is installed. Discount credits vary with different companies and generally increase in savings with an increase in the level of protection. Inform the user to ask their insurance agent about savings available.


For a UL smoke alarm system, there must be at least one smoke detector programmed into the Control Panel to meet National Fire Protection Association (NFPA) Rule 72 Chapter 2 and UL 217 requirements. Many insurance companies require these conditions to be met to qualify for a discount. Only use the Model DXS-71 or DXS-72 smoke detectors with this Control Panel for a UL smoke alarm system.

NOTE: Some cities and municipalities may require an alarm system permit. Check with the local authorities before installing this system.


In this manual, the bullets preceding the text help to define the step. For example:

- ◆ This symbol indicates a feature.
- This symbol indicates an action to perform and provides a box to check when the action is completed.
- ※ This symbol is for lit indications or system sounds.
- ⚡ This symbol is for important notes.


DVS-2408 SYSTEM



CONTROL PANEL
MODEL DVS-2408P



KEYPAD
MODEL DVS-2408KP




Control Panel Wiring Diagram


TABLE OF CONTENTS

1. THE DVS-2408 SECURITY SYSTEM	2	13. ADVANCED PROGRAMMING	29
CONTROL PANEL	2	SETUP MODE	29
DOOR/WINDOW SENSORS	3	CHANGING A SENSORS SUPERVISION	30
WIRELESS KEYPAD	3	CHANGING A SENSORS RESTORE REQUIREMENTS	30
SMOKE DETECTORS	3	ENTRY DELAY TIME	30
REMOTE CONTROLS	3	EXIT DELAY TIME	30
PANIC BUTTONS	3	BURGLARY SIREN TIME	30
BILL TRAP	3	EMERGENCY SIREN TIME	30
PASSIVE INFRARED MOTION DETECTOR	3	FIRE SIREN TIME	31
GLASS BREAK DETECTOR	3	AUTOMATION OUTPUT TIME	31
2. SECURITY SYSTEM FLOOR PLAN	4	REMOTE CONTROL & HARDWIRE ARMING LEVEL	31
EXAMPLE SYSTEM	4	REMOTE CONTROL & HARDWIRE DISARMING LEVEL	31
DESIGN THE INSTALLATION	4	ENTRY DELAY BEEPS	31
3. OVERVIEW OF KEYPADS	5	EXIT DELAY BEEPS	31
HARDWIRED KEYPAD	5	SILENT BURGLARY ALARMS	32
WIRELESS KEYPAD	5	SILENT EMERGENCY ALARMS	32
4. HARDWIRED KEYPAD FEATURES	6	DISABLING QUICK ARMING	32
5. CONTROL PANEL FEATURES	7	AUTOMATIC RESTORAL OF BYPASSED SENSORS	32
6. CONTROL PANEL INSTALLATION	8	AUTOMATIC BYPASSING OF OPEN SENSORS	32
SYSTEM LOCATION	8	AUTOMATION OUTPUT MODE DURING ALARM	33
WALL MOUNTING	8	AUTOMATION ACTIVATION TONE	33
EXTERNAL ANTENNA	8	REMOTE CONTROL & HARDWIRE ARM/DISARM CHIRP	33
HARDWIRED KEYPAD INSTALLATION	9	AUTOMATION OUTPUT ON DURING AND AFTER ALARM	33
HARDWIRED LOOP WIRING	10	AUTOMATION OUTPUT ON DURING ALARM	33
EXTERNAL ALARM SIREN CONNECTION	11	AUTOMATION OUTPUT WHILE ARMED	34
TELEPHONE LINE CONNECTION	11	AUTOMATION OUTPUT DURING EXIT/ENTRY DELAYS	34
AUTOMATION OUTPUT CONNECTION	12	AUTOMATION OUTPUT POLARITY	34
VOICE RESPONSE MODULE	12	REMOTE ACCESS PASSWORD	34
CONTROL PANEL POWER CONNECTION	13	DURESS CODE	34
BACKUP BATTERY INSTALLATION	13	MASTER USER CODE	34
7. BASIC CONTROL PANEL PROGRAMMING	14	RESTRICTED USER CODES	35
CREATE THE MASTER USER CODE	14	REMOVING USER CODES	35
PROGRAM THE HARDWIRED LOOPS	15	CONTROL PANEL MASTER RESET	35
PROGRAM THE WIRELESS SENSORS	15	14. COMMUNICATOR PROGRAMMING	36
PROGRAMMING DIFFERENT SENSOR TYPES	16	SETUP MODE	36
8. BASIC SENSOR INSTALLATION	18	GENERAL COMMUNICATOR OPTIONS	37
DXS-10 WIRELESS KEYPAD	18	COMMUNICATOR ENABLE	37
DXS-31 DOOR/WINDOW SENSORS	19	2-WAY AUDIO	37
TEST SENSORS	19	VOICE RESPONSE	37
9. CUSTOMIZING THE SYSTEM	20	REMOTE LOCKOUT	37
LABELING THE SENSORS	20	SWINGER ELIMINATOR	38
10. SYSTEM OPERATING MODES	21	DIALING DELAY	38
OFF MODE	21	DIALING METHOD	38
CHIME MODE	21	COMMUNICATOR REPORTING OPTIONS	39
HOME MODE	22	REPORTING FORMAT	39
SECURE EXIT	22	CALL ROUTING	39
HOME INSTANT MODE	22	ACCOUNT NUMBER	40
MANUAL BYPASSING OF SENSORS	22	PRIMARY TELEPHONE NUMBER	40
AWAY MODE	23	SECONDARY TELEPHONE NUMBER	40
MANUAL BYPASSING OF SENSORS	23	SUPERVISORY TELEPHONE NUMBER	40
TEST MODE	24	REPORT CONTROL PANEL TROUBLE	41
11. SYSTEM TROUBLE INDICATIONS	25	REPORT FORCE ARMING	41
CONTROL PANEL LOW BATTERY	25	OPENING AND CLOSING REPORTS	41
WIRELESS SENSOR LOW BATTERIES	25	POINT ID REPORTING	41
SENSOR TROUBLE	25	COMMUNICATOR REPORTING CODES	42
12. CUSTOMIZING THE SYSTEM	26	GENERAL REPORTING CODES	42
ADDING SENSORS TO THE SYSTEM	26	SYSTEM REPORTING CODES	42
REMOVING SENSORS FROM THE SYSTEM	26	FORCE ARMING REPORTING CODE	43
MAKING A SENSOR A 24-HOUR DOOR CHIME	27	DURESS REPORTING CODE	43
MAKING A SENSOR INTERIOR	27	4 BY 2 FORMAT POINT ID REPORTING CODES	44
MAKING A SENSOR A DIFFERENT SENSOR TYPE	28	4 BY 2 FORMAT POINT ID ALARM REPORT CODES	44
		4 BY 2 FORMAT POINT ID TROUBLE REPORT CODES	44
		IMPORTANT INFORMATION	46
		LINEAR LIMITED WARRANTY	46
		WIRELESS PRODUCT NOTICE	46
		FCC NOTICE	46
		FCC TELEPHONE RULES AND REGULATIONS	46
		FIRE EVACUATION PLANNING	46
		INDUSTRY CANADA NOTICES	46

1. THE DVS-2408 SECURITY SYSTEM



DVS-2408P
CONTROL
PANEL



DVS-2408KP
HARDWIRED
KEYPAD



DXS-10
WIRELESS
KEYPAD



DXT-21 & DXT-23
REMOTES 1



DXT-61
REMOTE 1



DXT-41 & DXT-42
REMOTES



DXS-72
SMOKE DETECTOR



DXS-71
SMOKE DETECTOR



DXS-31
DOOR/WINDOW
SENSOR



DXS-61
BILL TRAP 1



DXS-54
PIR



DXS-91 GLASS
BREAK DETECTOR 1

† NOTE: These accessories
are not listed by UL.

CONTROL PANEL

The DVS-2408P Control Panel is the heart of the system. It monitors all of the system's wireless sensors, hardwired loops, and controls the alarm sirens and Model DVS-2408KP hardwired keypads.

The Control Panel constantly monitors the condition of the system's sensors and hardwired contacts, displaying which protected doors and windows are open or closed. If an alarm occurs, the keypads display which sensor(s) caused it. When a sensor has a low battery, the keypads display which sensor needs a new battery. Sensors that send hourly status transmissions keep the Control Panel informed of their operating condition.

Up to eight different custom user codes can be used to operate the system. For security, a user code must be entered to disarm (turn off) the system. The system can be armed (turned on) by entering a user code, or with the unique "Quick Arm" feature. The six restricted user codes can only arm and disarm the system, no programming changes (except changing user and duress codes) are allowed. The master user code is allowed to program the Control Panel, and a duress code can be selected for emergency disarming of the system with a duress report to the Central Station.

The Control Panel's memory will retain the user codes and all of the system's programming, even during a total power loss. An optional backup battery can be installed to power the system during short power failures.

The built-in digital communicator connects the Control Panel to a Central Alarm Monitoring Station through the telephone. With a monitored system, the central station can dispatch authorities in case of burglary, fire or other emergency. The central station can also call family, friends, neighbors, or anyone else designated on a custom call list. System arming (closing) and disarming (opening) reports by user can also be sent.

Each sensor can report directly to the Central Station using the digital communicator's Point ID feature. If a sensor triggers an alarm or experiences supervisory trouble, a unique report code can be sent for immediate identification of the event.

The optional Models VB-2 or VB-3 digital voice response modules can be installed in the Control Panel. The VB-2 module provides three exciting features: 2-way audio monitoring capability at the Central Station through the communicator, local human voice prompts from the keypad's speaker, and voice prompted remote system control using in-house or off-site TouchTone® telephones. The Model VB-3 is the same as the VB-2 without 2-way Central Station audio capability.

The system has 24-hour capabilities that are always ready to operate, even when the system is disarmed. They can be triggered by buttons on the hardwired keypads, a wireless keypad, portable remote controls and smoke detectors. Pressing the [EMERGENCY] or [FIRE] button for two seconds will cause an immediate siren and call the central station. **IMPORTANT: For personal emergency use only. Not for use as a UL Listed Medical Alert System.**

The Control Panel's Environmental sensor types are active 24-hours. They can be triggered with sensors connected to devices such as water flow detectors, over/under temperature sensors, flood sensors, toxic gas detectors, etc. The Environmental sensors activate the chime annunciator without sounding the siren or triggering the communicator.


An Automation Output in the Control Panel provides an easy way to connect external devices to the Control Panel. The output is fully programmable to activate on a variety of conditions, such as when the system is armed, during alarms, and during exit/entry delays. The Automation Output can connect to lighting control modules, relays, noisemakers, and indicators. The Control Panel's and wireless keypad's [(A)] key and any system sensors can control the Automation Output.

The Control Panel can be programmed locally using its own keypad or remotely, over the telephone, using Linear's Model RA-2400 Remote Access software program. The RA-2400 upload/download program is a Windows™ application that runs on a personal computer and communicates with the Control Panel through a modem.

A total of 24 sensors of the types listed on the next page can be used with each DVS-2408P Control Panel. Up to eight hardwired loops and two hardwired keypads can be used.

DOOR/WINDOW SENSORS

The DXS-31 sensors monitor doors and windows. They send radio signals to the Control Panel. One type of signal is sent when the door or window is opened, and a different type of signal is sent when the door or window is closed. If the system is armed, a sensor can trigger the Control Panel's burglary siren when its door or window is opened. The DXS-31 is supervised, it sends hourly status reports and monitors its battery condition.



WIRELESS KEYPAD



The DXS-10 wireless keypad is used to operate the system remotely. It can be placed in a convenient spot so the user doesn't have to go to the hardwired keypad to operate the system. The wireless keypad can also trigger the emergency or fire siren and actuate the Automation Output. Pressing [*] will cause the hardwired keypad(s) to sound Beeps corresponding to the current operating mode. The DXS-10 is supervised, it sends hourly status reports and monitors its battery condition. **IMPORTANT: For personal emergency use only. Not for use as a UL Listed Medical Alert System.**



SMOKE DETECTORS




The DXS-71 and DXS-72 are high quality smoke detectors with built-in radio transmitters: As soon as smoke is detected, the unit will sound its local noisemaker. Then, 20 seconds after the local noisemaker sounds, the transmitter sends an alarm signal to the Control Panel. The alarm signal will be repeated every 20 seconds as long as smoke is still present. A restoral signal will be sent when the smoke detection chamber clears. The DXS-71 and DXS-72 are supervised, they send hourly status reports and monitor their battery condition.

NOTE: A Model DXS-71 or DXS-72 Smoke Detector is required to create a UL Listed smoke alarm system. See Page 26 for details on adding a smoke detector sensor to the system.



REMOTE CONTROLS

The DXT-41, DXT-61 single-button and DXT-42 two-button units can be used to remotely arm and disarm the system. Each comes with a key ring. The DXT-42's right button controls the automation output, both buttons trigger emergency. Each transmitter can be programmed to activate various other system modes. These transmitters are **not** supervised.



‡ NOTE: These accessories not listed by UL.


PANIC BUTTONS

The DXT-21 and DXT-23 transmitters can be used as portable "panic buttons". Pressing the front or top button on the DXT-21 at any time will trigger the emergency siren. Pressing **both** front buttons **simultaneously** on the DXT-23 at any time will trigger the emergency siren. Both transmitters can be programmed to activate various other system modes. These transmitters are **not** supervised.




BILL TRAP

The DXS-81 bill trap can be used with the Control Panel in non-UL small commercial hold-up installations. The unit is concealed in a cash drawer under a stack of currency, with a single "bait" bill secured in its money clip. During a hold-up, the cashier removes the stack of currency along with the "bait" bill. When a "bait" bill is removed, the transmitter sends a signal to the Control Panel. Four additional signals are sent within the first minute after the "bait" bill is removed. When the "bait" bill is replaced, a restore signal is sent. The DXS-81 is supervised, it can send hourly status reports (optional) and monitors its battery condition.




PASSIVE INFRARED MOTION DETECTOR

The DXS-54 is a passive infrared (PIR) motion detector with a built-in radio transmitter. The PIR detects motion in its detection pattern by measuring the infrared emission levels of objects that it "sees". If the infrared levels change quickly, as when a person moves across the detection pattern, the PIR will recognize the change as an intrusion and send an alarm signal to the Control Panel. An alarm will be triggered if the system is in the Away Mode. The DXS-54 is supervised, it sends hourly status reports and monitors its battery condition.



GLASS BREAK DETECTOR

The DXS-91 is a glass break detector with an audio sound discriminator and a built-in radio transmitter. The unit "listens" for the sound of breaking glass. When glass breakage is detected, the unit sends an alarm signal to the Control Panel. The DXS-91 is supervised, it sends hourly status reports and monitors its battery condition.




2. SECURITY SYSTEM FLOOR PLAN

EXAMPLE SYSTEM

- ◆ The example shows a typical DVS-2408 system.
- ◆ Any or all of the accessories shown can be used.
- ◆ A total of 24 sensors can be used with each Control Panel. Each wireless sensor, hardwired loop, and wireless keypad used occupies a sensor location.

DESIGN THE INSTALLATION

- Create a floor plan of the installation.
- Consider the security needs of the premises.
- Determine which doors and windows are vulnerable to intrusion.
- Figure which interior areas an intruder might go to if unlawful entrance is gained.
- Indicate locations for door/window sensors, interior motion detectors, wireless and hardwired keypads, glass break detectors and external siren speakers.
- Decide on a centralized location for the security Control Panel.




Example Residential Security System Floor Plan

3. OVERVIEW OF KEYPADS


HARDWIRED KEYPAD

- ◆ One or two hardwired keypads can be used for controlling the system.
 - ◆ Three system status indicators (POWER, BATTERIES, & TROUBLE).
 - ◆ Five system mode indicators (OFF, CHIME, HOME, AWAY & TEST).
 - ◆ 24 system sensor indicators with locations for supplied sensor identification labels.
 - ◆ Press [(A)] to activate the automation output.
 - ◆ Pressing [*] clears the keypad.
 - ◆ Pressing [*] for two seconds sounds the mode Beeps from the hardwired keypad(s).
 - ✓ Off Mode: 1 "Gong".
 - ✓ Chime Mode: 1 "Gong" & 1 "Beep".
 - ✓ Home Mode: 1 "Gong" & 2 "Beeps".
 - ✓ Away Mode: 1 "Gong" & 3 "Beeps".
 - ✓ Test Mode: 1 "Gong" & 4 "Beeps".
 - ◆ Emergency and fire alarm can be triggered from the keypad at any time.
- ⚠ **UL NOTE: For personal emergency use only. Not for use as a UL Listed Medical Alert System.**




WIRELESS KEYPAD

- ◆ For controlling the system remotely.
 - ◆ Green operation light.
 - ◆ Internal 9-volt battery is monitored by the Control Panel.
 - ◆ Keypad's Beeper will buzz during transmissions when the battery is low.
 - ◆ Up to 3 years battery life (depends on frequency of activation). (UL tested for 1 year minimum.)
 - ◆ Sends hourly status reports to the Control Panel.
 - ◆ Press [(A)] to activate the automation output.
 - ◆ Pressing [*] clears the keypad.
 - ◆ Pressing [*] for two seconds sounds the mode Beeps from the hardwired keypad(s).
 - ✓ Off Mode: 1 "Gong".
 - ✓ Chime Mode: 1 "Gong" & 1 "Beep".
 - ✓ Home Mode: 1 "Gong" & 2 "Beeps".
 - ✓ Away Mode: 1 "Gong" & 3 "Beeps".
 - ✓ Test Mode: 1 "Gong" & 4 "Beeps".
 - ◆ Emergency and fire alarm can be triggered from wireless keypad at any time.
- ⚠ **UL NOTE: For personal emergency use only. Not for use as a UL Listed Medical Alert System.**



4. HARDWIRED KEYPAD FEATURES



1 24-HOUR BUTTONS

- ★ Pressing [FIRE] for two seconds sounds the fire siren and sends a "fire" message to a central monitoring station through the digital communicator (if the system is monitored).
- ★ Pressing [EMERGENCY] for two seconds sounds the emergency siren and sends an "emergency" message to a central monitoring station through the digital communicator (if the system is monitored).
- ★ Both work even when system is disarmed.
- ★ **IMPORTANT: For personal emergency use only. Not for use as a UL Listed Medical Alert System.**

2 SYSTEM STATUS INDICATORS

- ★ Shows the current status of the system.

POWER LIGHT

- ★ Glows when AC power is on.
- ★ Dims when AC power is off and backup battery is installed.
- ★ Blinks when the backup battery is low, recharging or missing.
- ★ Off when AC power is off and no backup battery is installed (system disabled).

BATTERIES LIGHT

- ★ Blinks when one or more sensors have a low battery.
- ★ Press [*] for one second to view sensor status. Sensor status indicator for any sensor with a low battery will light along with the BATTERIES indicator. Any trouble indications will follow during the five second status cycle.
- ★ Switch to Test Mode after replacing the sensor battery and completely test the system (see Test Mode). Switching to Test Mode clears the low battery indication.

TROUBLE LIGHT

- ★ Blinks when one or more sensors have not reported status during the eight hour status time period.
- ★ Press [*] for one second to view sensor status. Sensor status indicator for any sensor that has not reported in will light along with the TROUBLE indicator. Any low battery indications will follow during the five second status cycle.
- ★ Switch to Test Mode after servicing the sensor and completely test the system (see Test Mode). Switching to Test Mode clears the trouble indication.

3 MODE INDICATORS

- ★ Specific indicator will light showing the current mode the system is in.
- ★ HOME indicator will blink during Secure Exit and Home Instant modes.
- ★ AWAY indicator will blink during the exit delay in the Away Mode.

4 SENSOR STATUS INDICATORS

- ★ Indicates the status of each of the system's wireless sensors and hardwired loops.
- ★ Lights show which doors and windows are open.
- ★ Lights flash to display sensors that have caused an alarm.
- ★ Stick-on labels are provided to identify the custom sensor locations.

5 SPEAKER

- ★ Makes unique sounds for burglary, fire and emergencies.
- ★ Alarm sirens stop automatically after five minutes.
- ★ Sounds advisory tones to confirm keystrokes from the keypad.
- ★ Sounds mode selections tones.
- ★ Sounds alarm memory tones.
- ★ Beeps when Automation Output is activated.
- ★ Speaks the system status information when optional VB-2 or VB-3 digital voice response module is installed.
- ★ The Control Panel has terminals available for an external siren.

6 MODE BUTTONS

- ★ Used to operate the system.

OFF

- ★ Off Mode disarms the system.
- ★ Switching to Off Mode stops the alarm siren.
- ✓ Multiple Beeps sound and sensor status lights flash if an alarm has occurred.
- ☒ **Multiple Beeps mean caution. AN INTRUDER MAY STILL BE PRESENT.**

CHIME

- ★ Chime Mode disarms the system.
- ★ Switching to Chime Mode stops the alarm siren.
- ✓ Multiple Beeps sound and sensor status lights flash if an alarm has occurred.
- ☒ **Multiple Beeps mean caution. AN INTRUDER MAY STILL BE PRESENT.**
- ★ Chime Mode is for monitoring doors and windows.
- ✓ Use this mode as an "automatic door chime" when at home.
- ✓ Opening any protected door or window causes the keypad(s) to "ding-dong".

HOME

- ★ Home Mode arms the perimeter sensors, but not the interior sensors.
- ✓ Use this mode when anyone is staying behind.
- ✓ Interior motion detectors and interior door sensors are not armed.
- ✓ Home secure mode makes all delayed perimeter sensors instant.
- ✓ Secure exit mode starts an exit delay while remaining in Home Mode.

AWAY

- ★ Away Mode arms the entire system.
- ✓ Use this mode when leaving home.
- ✓ Door sensors set for delayed will have a time delay that allows the user to leave and enter the premises without sounding the alarm.
- ✓ Entry Delay Beeps warn the user to disarm the system before the siren starts.

TEST

- ★ Test Mode is for testing the system sensors.
- ✓ All sensor status lights blink when the Test Mode is entered.
- ✓ Each sensor status light will stop blinking when its sensor is tested.
- ★ Hold the [TEST] button down to test all of the keypad's indicator lights.


7 KEYPAD

- ★ Backlit keys for easy viewing in low light conditions.
- ★ For entering the user's user code (numerically or alphabetically).
- ★ Used when programming system options.
- ★ Press [(A)] to activate Automation Output.
- ★ Press [*] to clear keypad if the wrong key is pressed.
- ★ Press [*] for one second to view sensor battery and supervisory status (see BATTERIES and TROUBLE indicator description).

8 MICROPHONE HOLE

- ★ Location for the high sensitivity microphone used with the Model VB-2.
- ★ Detects room audio when communicator is reporting to the Central Station in 2-way audio mode (Model VB-2 digital voice response module must be installed).

5. CONTROL PANEL FEATURES



1 BATTERY FUSE

- ★ Type 2AG, 3-amp fuse for the backup battery.
- ★ If the keypad's POWER light is flashing and the optional backup battery is installed and charged, check this fuse.
- ⚠ **WARNING:** For continued protection against the risk of fire, replace only with the same type and rating of fuse.

2 CONDUIT KNOCKOUTS

- ★ Four cabinet knockouts are provided for wiring using conduit.
- ★ The 3/4" knockouts fit standard 3/4" conduit fittings.

3 WIRING ACCESS SLOT

- ★ Provides access for wiring through a hole in the mounting wall.
- ★ Route cables for power, telephone, external speaker, etc. through this slot.

4 MAIN TERMINAL BLOCK

- ★ Terminals for hardwired loop inputs.
- ★ Terminals for Automation Output to connect to an automation controller.
- ★ Terminals for external relay output for "dry" contacts (Form C, normally open/normally closed, 1 amp @ 24 volts maximum).
- ★ Terminals for fused auxiliary 12 volt output and common ground.
- ★ Terminals for connection to one or two Model DVS-2408KP keypads.
- ★ Terminals for connection to the plug-in AC transformer.

5 AUXILIARY FUSE

- ★ Type 2AG, 1-amp fuse.
- ★ Protects the auxiliary power output and siren driver circuit.
- ★ Fuse will blow when load exceeds 1 amp total.
- ⚠ **WARNING:** For continued protection against the risk of fire, replace only with the same type and rating of fuse.

6 TELEPHONE TERMINAL BLOCK

- ★ Provides telephone connections for the digital communicator.
- ★ Provides telephone connection for voice prompted telephone remote control (optional VB-2 or VB-3 digital voice response module required).
- ★ Provides seized ring and tip connections for local telephone instruments. Communicator will disconnect local telephones while on-line.

7 WALL-MOUNT KEYHOLE SLOTS

- ★ Four slots used when mounting Control Panel to the wall.
- ★ Used as a template for the Control Panel when it is mounted to the wall.

8 DIGITAL VOICE RESPONSE MODULE (OPTIONAL)

- ★ Two voice response modules are available, the Model VB-2 and VB-3.
- ★ Both modules allow remote command of the system using a standard pushbutton telephone, on or off site.
- ★ Both modules provide optional human voice prompts from the keypad(s) speaker.
- ★ The Model VB-2 gives the Control Panel's digital communicator listen-only, manual 2-way and full duplex 2-way audio capability with the Central Station.

9 ANTENNA KNOCKOUT

- ★ A cabinet knockout is provided for mounting an external antenna connector.
- ★ For an external antenna, use Linear's Model LA-P antenna kit.
- ★ The antenna kit can also be used to connect the Control Panel to co-ax for a remote antenna.

10 ANNUNCIATOR VOLUME CONTROL

- ★ Varies the volume of the advisory tones that come from the keypad(s) speaker.
- ★ Does not affect keypad's sirens (they are always full volume).

11 ALC JUMPER

- ★ Enables the receiver's automatic level control when jumper is installed.
- ★ Leave jumper installed for normal operation.
- ★ Remove jumper only during radio interference troubleshooting while listening to the receiver's audio with an amplifier at the radio test points.

12 RADIO TEST POINTS

- ★ Used to monitor the Control Panel's radio receiver during troubleshooting.
- ★ Provides connection for an audio amplifier to listen to the receiver's output.
- ★ Helpful to determine sources of radio interference.

13 ANTENNA TERMINALS

- ★ Antenna and shield (ground) terminals for receiving signals from the system's sensors.
- ★ Pre-wired to the Control Panel's internal wire dipole antenna.
- ★ Alternately connects to the Model LA-P local whip and remote antenna kit.

14 OPTIONAL BACKUP BATTERY

- ★ Space for 12-volt, 4 amp/hour backup battery. (Highly recommended.)
- ★ Backup battery is automatically charged and monitored by the Control Panel.
- ★ Backup battery can power the Control Panel for up to 6 hours.
- ★ **UL NOTE:** Normal estimated battery life should be 3 to 4 years.

15 REMOVABLE CABINET COVER

- ★ The cabinet cover can be removed for easy system wiring and setup.
- ★ Two screws secure cabinet cover when closed.
- ★ An optional cabinet lock can be installed for additional security.

6. CONTROL PANEL INSTALLATION

SYSTEM LOCATION

⚠ **NOTE:** *Wireless sensor signals must be able to reach the Control Panel.*

- ✓ Try to centrally locate the Control Panel.
- ✓ Keep Control Panel away from large metal appliances.
- ✓ Maximum recommended sensor range is 400 feet (system tested at 1000 feet).

⚠ **NOTE:** *If you don't use the wireless keypad, a hardwired keypad should be easily accessible to the usual entrance.*

- ✓ When the Control Panel is set in the Away Mode, the user has 45 seconds to switch to Off Mode before the burglary siren sounds.

⚠ **NOTE:** *Make sure a hardwired keypad is in a place where the alarm can be heard during the night hours.*

- ✓ Optional remote external sirens (up to 150 feet from the Control Panel) can be used to make alarms louder and remote the sound location.

- Locate the Control Panel near a 115 VAC outlet that's not controlled by a light switch.
- Locate the Control Panel near a telephone outlet (if using the digital communicator).

WALL MOUNTING


- Use the Control Panel's case bottom as a template and mark the locations for the four mounting screws.
- Mark the wiring access slot if the wiring is being routed from behind the cabinet.
- Use a hole saw to cut out the location for the wiring access slot (if used) or punch out selected cabinet wiring knockouts for conduit wiring.
- Use four screws and appropriate screw anchors to mount the unit to the wall.

EXTERNAL ANTENNA






- ◆ Linear's Model LA-P antenna kit can be used with the DVS-2408P Control Panel to replace the standard internal antenna.
- ◆ The antenna can be mounted on the cabinet, or the kit can be used to connect to co-ax for a remote antenna.
- Remove the two standard white antenna wires attached to the ANT and SHIELD terminals.
- Punch out the antenna knockout.
- Mount the antenna connector in the antenna knockout.
- Route the antenna co-ax down to the Control Panel's antenna connector.
- Connect the antenna's co-ax center conductor to the ANT terminal.
- Connect the antenna's co-ax shield to the SHIELD terminal.
- Route the two antenna ground wires as shown.

USE THE CASE BOTTOM AS A TEMPLATE TO MARK THE FOUR KEYHOLE MOUNTING HOLES

FOR RECESSED WIRING, MARK WIRING SLOT, THEN CUT OUT HOLE WITH DRYWALL SAW




FOR CONDUIT WIRING, PUNCH OUT REQUIRED KNOCKOUTS AND INSTALL 3/4" CONDUIT HUBS IN HOLES



HARDWIRED KEYPAD INSTALLATION

- ◆ One or two Model DVS-2408KP keypads can be used with the DVS-2408P Control Panel (one keypad is included in the DVS-2408 system package).
- ◆ The keypad is supplied with a short wiring harness and connector.
- Use a flat blade screwdriver to open the keypad case. Identify the keypad internal components.
- Set the keypad select jumper to KEYPAD 1 if this is the first, or only, keypad installed. Set the jumper to KEYPAD 2 if this is the second keypad installed.
- Select an indoor location with easy wiring access to the Control Panel and use the keypad's mounting plate as a template to mark the mounting holes for the keypad.
- Route 6-conductor 22 AWG (or larger) wire from the Control Panel to the keypad(s). Up to 100 feet of wire total can be used with this system. If installing two keypads, each keypad can be "home-run" or "daisy-chained".
- ↳ *If a Model VB-2 voice response module is going to be used with the system, route two-conductor shielded cable from the Control Panel to the keypad(s), then install and wire the microphone(s) in the keypad(s).*
- Connect the 6-conductor wire to the Control Panel's keypad terminals, noting wire colors.
- Noting wire colors, connect the keypad's wiring harness to the wire from the Control Panel.
- If using the VB-2 voice response module and microphone, press the microphone into the keypad case as shown. Connect the microphone wiring as shown.
- ↳ **NOTE: When using two keypads and two microphones, each shielded microphone cable must be home run to the VB-2 terminal block.**
- Plug the keypad wiring harness into the keypad connector and snap the keypad case closed.







MOUNT KEYPAD INDOORS AT A CONVENIENT HEIGHT AND LOCATION FOR THE USERS

NOTE: MAXIMUM RECOMMENDED WIRE RUN IS 100 FEET COMBINED TOTAL FOR ALL KEYPADS



USE MOUNTING PLATE AS TEMPLATE TO MARK SCREW LOCATIONS

USE SCREWS AND ANCHORS OR APPROPRIATE FASTENERS TO AFFIX MOUNTING PLATE




USE 6-CONDUCTOR 22 AWG WIRE OR LARGER (ALSO RUN 2-CONDUCTOR SHIELDED CABLE IF VB-2 VOICE RESPONSE MODULE AND MICROPHONE ARE USED)

ROUTE WIRING CONNECTOR THROUGH MOUNTING PLATE HOLE



INSERT CONNECTOR INTO THE KEYPAD SOCKET ON THE KEYPAD UNTIL IT SNAPS TOGETHER

ALIGN TOP OF CASE FIRST, THEN SNAP BOTTOM TOGETHER



HARDWIRED LOOP WIRING

- ◆ The DVS-2408 supports up to eight normally open/closed hardwired loops each with 2.2K end-of-line resistor supervision.
- ◆ Each hardwired loop that is wired and programmed uses one sensor location.
- ◆ Each hardwired loop can be programmed to any sensor number.
- ◆ Each hardwired loop can be programmed as any sensor type, including arm/disarm toggle.
- ◆ Four COM terminals are shared as loop returns for the eight loops.
- ◆ Each hardwired loop has a 400 millisecond response time.




⚠ **NOTE:** For UL installations, use UL Listed cable for all hardwired loop wiring.

- Route wiring from the Control Panel to each hardwired switch contact, sensor, or device. Route the wires through the wiring slot or through a knockout for conduit wiring.

⚠ **NOTE:** Maximum recommended hardwired loop length is 500 feet (250' out, and 250' back) for each loop. Maximum loop resistance (excluding the EOL resistor) is 100 ohms.


- Connect the loop wires to LOOP # and COM terminals. For powered devices connect power wires to +12 VDC and any COM terminal.
- On the sensor end, connect each normally closed sensor **in series** with the loop wires. Connect each normally open sensor **in parallel** with the loop wires.
- After the last sensor on the loop, connect a 2.2K end-of-line resistor across the loop.

⚠ **NOTE:** Before the hardwired loops will function, they will need to be programmed. This will be covered in the Basic Control Panel Programming section of this manual.




Arm/Disarm Key Station Wiring

- ◆ Any of the hardwired loops can be used with a momentary keyswitch to arm and disarm the system.
- Connect the loop as shown to the keyswitch and end-of-line resistor.
- Connect an LED indicator from the switchplate to the H/A- and H/A+ terminals.
- When programming the system, set the loop sensor type to "Type 9, Arm/Disarm Toggle" and set the Automation output to "Active while Armed".





EXTERNAL ALARM SIREN CONNECTION

- ◆ An external siren alerts occupants and neighbors with a loud siren during alarm.
- ◆ Use a 12 volt, 1 amp maximum rated weather-resistant horn speaker with a built-in siren driver. Do not use a plain speaker.
- ⚠ **NOTE:** Connection of an electromechanical bell or motor bell is not recommended because of the radio interference generated when the bell is running.
- ⚠ **UL NOTE:** Only one external siren is allowed in UL Installations.
- Mount the external siren.
- Route the wires from the external siren to the Control Panel.
- Route the siren wires up through the wiring access slot or through a knockout when using conduit.
- Connect a jumper wire from the +12 VDC terminal to the RLY COM terminal.
- Connect the positive siren wire to the RELAY N/O terminal.
- Connect the negative siren wire to one of the COM terminals.
- ⚠ **NOTE:** The relay contacts are isolated. Use the RLY N/O & RLY COM terminals alone to switch an externally powered load.





EXTERNAL ALARM SIREN



TELEPHONE LINE CONNECTION

- ◆ Connect the Control Panel to the telephone line if the system is monitored, requires 2-way audio, or for remote computerized programming or telephone remote command.
- ◆ Telephone RING & TIP terminals are for connection to the incoming telephone line.
- ◆ Seized telephone ring & tip (R1 & T1) are for connection to local telephone sets. When the communicator activates, all the local telephone sets will be disconnected to prevent an off-hook telephone on the premises from blocking the communicator call.
- Install a USOC RJ31-X or RJ38-X jack to the telephone system near the Control Panel.
- Route an appropriate modular telephone line cord from the jack to the Control Panel.
- Route the line cord through the Control Panel's wiring access slot or through a knockout for conduit wiring.
- Connect the incoming telephone line wires to the Control Panel's telephone terminal block TIP and RING terminals.
- Connect the local telephone set wires to the Control Panel's telephone terminal block T1 and R1 terminals.




AUTOMATION OUTPUT CONNECTION


- ◆ The Control Panel provides a Automation Output to control lights, devices and appliances.
- ◆ Automation Output can connect to most popular home automation devices and other simple electronic devices (see figure).
- Press [(A)] to turn the Automation Output on, press [(A)] again to turn it off.

Programmable Options

- ◆ There are many programmable options for the Automation Output.
- ◆ The Automation Output can be programmed for a variety of useful functions, such as: flashing during alarm, flashing after an alarm, on while armed, or, on during exit/entry delays.
- ◆ See the "Advanced Programming" section of this manual for details on changing the function of the Automation Output.



EXAMPLE AUTOMATION OUTPUT HOOK-UPS



VOICE RESPONSE MODULE


- ◆ The DVS-2408P circuit board has a plug-in location for a Model VB-2 or VB-3 voice response module.
- ◆ Both modules can sound human voice prompts through the keypad(s) speaker(s).
- ◆ Both modules allow remote command of the system locally and remotely through a pushbutton telephone.
- ◆ The VB-2 module supports listen-only audio, two-way manual audio, and full duplex two-way audio communication with the Central Station.

For VB-2 Module Only


- Identify the audio module components, noting the terminal block positions.
- Connect the shielded microphone wire from the keypad to the audio module terminals. Connect the shield and negative microphone wire to the center terminal, connect the positive microphone wire to either of the other two terminals.
- If using two keypads for audio monitoring (or a Model RSM-1 remote speaker/microphone) connect the second shield and microphone negative to the center terminal, and the positive microphone wire to the remaining open terminal.

For VB-2 & VB-3 Modules

- **WITHOUT POWER APPLIED TO THE CONTROL PANEL**, plug the voice response module into the sockets on the Control Panel's circuit board. Be sure the arrows on the module board are pointing up.






BE SURE CONTROL PANEL POWER IS DISCONNECTED!
CAREFULLY PLUG VOICE MODULE INTO THE TWO CIRCUIT BOARD SOCKETS
BE SURE ALL PINS ARE ALIGNED




CONTROL PANEL POWER CONNECTION

- ◆ The Control Panel is powered by a low voltage plug-in transformer.
- ◆ Use up to 25 feet of 20 AWG or larger two-conductor wire to connect the transformer to the Control Panel.
- Route the power wires from the plug-in transformer to the Control Panel.
- Connect the wires to the transformer terminals (do not plug the transformer in until the wiring is complete).
- Route the power wires through the Control Panel's wiring access slot or through a knockout for conduit wiring.
- Connect the power wires from the transformer to the Control Panel's main terminal block AC & AC terminals.
- Plug transformer into an **unswitched** AC outlet.
- Secure transformer with screw to prevent un-plugging.



BACKUP BATTERY INSTALLATION

- ◆ A 12 volt backup battery may be installed and is highly recommended.
- ◆ The backup battery will power the system for up to 6 hours during AC power loss.
- ◆ The backup battery is automatically charged by the Control Panel when AC power is present.
- ◆ A low backup battery will cause the keypad's POWER indicator to flash as it is being charged.
- Position the battery as shown. Connect the black battery lead to the negative battery terminal. Connect the red battery lead to the positive battery terminal.
- ⚠ **WARNING: DO NOT REVERSE THE BATTERY LEADS! THE BATTERY FUSE WILL BLOW.**



7. BASIC CONTROL PANEL PROGRAMMING

- ◆ In a new installation, after power is first applied the Control Panel will be waiting to set the "master" user code.
- ◆ After the Control Panel's master user code is entered, all of the system's modes can be selected.
- ◆ The Setup Mode is used by the installer to - program the system's sensors into the Control Panel's memory and can only be accessed with the master user code. Setup Mode can be used to change any of the system options.
- ◆ The restricted user codes can only access the Code Mode, which can be used to change restricted and duress user codes only.

CREATE THE MASTER USER CODE



- ◆ When power is first applied, a master user code must be entered.
- ↳ **NOTE: The master user code must be entered on a hardwired keypad, not on a wireless remote keypad.**
- Choose a one to five digit user code to use for arming, disarming and programming the system.
- ↳ **NOTE: For maximum security, a three to five digit code is recommended.**
- Press [*] (clears keypad if any other keys have been pressed).
- Enter any combination of one to five digits for the master user code, then press [OFF].
- Test the new master user code by entering it then pressing [TEST].
- Log the master user code in the box below.

MASTER USER CODE

↳ **NOTE: If you forget the code, see "Control Panel Master Reset" area in the "Advanced Programming" section of this manual.**


- ◆ The Control Panel will treat this user code as a "master" code. To create "restricted" user codes, see the "Advanced Programming" section of this manual.

↳ **NOTE: Only the master user code can be used to enter Setup Mode. The restricted user codes cannot enter Setup Mode and can only enter Code Mode for programming.**




PROGRAM THE HARDWIRED LOOPS

- ◆ Each hardwired loop used must be programmed into the Control Panel's memory.
- ◆ Each hardwired loop programmed uses one of the twenty four available sensor locations.
- Start with the system in Test Mode (enter the master user code and press [TEST]).
- Enter the Setup Mode **from Test Mode**, enter the **master user code** then press [TEST].
- * A "Gong" and five "Beeps" will sound.
- * The sensor status indicators will light for any sensors already programmed into the Control Panel.
- Enter programming Step #301-308 (301=loop 1, 302=loop 2, etc.) for the hardwired loop desired.
- Press [HOME] to program.
- Enter an unused sensor number from 01-24 for the loop (you must enter two digits, example: 5 = 05).
- Press [AWAY] to store.
- * A single "Bing" tone will sound and the sensor status indicator for that sensor will stay lit. A double "Buzz" will sound if that sensor location is already in use.
- ◆ Repeat four above steps to enable all of the hardwired loops used.
- ↳ **NOTE: The default sensor type for the hardwired loops is Perimeter (Type 5). Any sensor type can be selected for each hardwired loop, refer to the "Customizing the System" section of this manual.**



PROGRAM THE WIRELESS SENSORS

- ◆ Each wireless sensor used must be programmed into the Control Panel's memory.
- ◆ Each wireless sensor programmed uses one of the twenty four available sensor locations.
- Start with the system in Test Mode (enter the master user code and press [TEST]).
- Enter the Setup Mode **from Test Mode**, enter the **master user code** then press [TEST].
- * A "Gong" and five "Beeps" will sound.
- * The sensor status indicators will light for any sensors programmed into the Control Panel.
- Enter an unused sensor number from 01-24 (you must enter two digits, example: 5 = 05)
- * The sensor indicator light will flash for the sensor number selected.
- Activate the sensor by sending a test or alarm signal (be sure the sensor's battery is connected or that its battery protection strip is removed).
- * A single "Bing" tone will sound and the sensor status indicator for that sensor will stay lit. A double "Buzz" will sound if that sensor location is already in use.
- ◆ Repeat the above two steps for each additional wireless sensor.



PROGRAMMING DIFFERENT SENSOR TYPES

- ◆ Follow the instructions on the previous page to select a sensor number to program the sensor into.

↳ **NOTE:** A sensor can be programmed into more than one location. Be sure to choose an **UNUSED** sensor number. If a sensor gets entered into more than one location, delete the duplicates using the remove sensor function.

Model DXS-10

- To add DXS-10 wireless keypads, press and hold the keypad's [*] key until programmed into the Control Panel.


Model DXS-31

↳ **IMPORTANT NOTE:** The DXS-31 door/window sensors are pre-set at the factory for delayed burglary response. If the sensor is going to be used on a non-entry portal (window, sliding glass door, etc.) a jumper can be changed in the sensor to select instant response. The jumper should be changed before programming the sensor so the Control Panel will assign the sensor to the proper sensor type. See the "Basic Sensor Installation" section of this manual for details on changing the jumper.


- For DXS-31 door/window sensors, press the case or move the magnet away from the side of the sensor.

Models DXS-81, DXS-91, DXS-54, DXS-71 & DXS-72


- For DXS-81, DXS-91, DXS-54, DXS-71 & DXS-72 accessory sensors, simply send a test transmission (refer to the sensor's instructions for details on sending a test transmission).



DXS-10



DXS-31




DXS-81

Models DXT-61, DXT-21 & DF-41

- For DXT-61, DXT-21 & DF-41 single-button remotes, simply press the unit's button. The unit will function as an arm/disarm remote.

🔗 **NOTE:** After the Control Panel recognizes the transmitter, single-button remotes can easily be re-programmed as "panic buttons" or home automation controllers. Refer to the "Customizing the System" section of this manual.




DXT-21

Models DXT-23 & DF-42

- For DXT-23 & DF-42 two-button remotes, program the transmitter by pressing the *left* button. The remote will arm/disarm the system with the left button and activate/deactivate the home automation output with the right button. Labels are provided with the DF-42 for identifying the buttons.

🔗 **NOTE:** After the Control Panel recognizes the transmitter, two-button remotes can easily be re-programmed to have the left button arm the system and the right button disarm the system. Refer to the "Customizing the System" section of this manual.

SEND SIGNAL WITH LEFT BUTTON



LEFT = ARM/DISARM
RIGHT = AUTOMATION

DF-42

All Models

- * A single "Bing" tone will sound and the sensor status indicator will stay lit when the sensor is programmed into the Control Panel.
- * A double "Buzz" tone will sound if there is already another sensor programmed to that sensor number.
- Exit Setup Mode by pressing the [*] key then hold [OFF] for three seconds. Reminder: The system will automatically exit the Setup Mode and return to Off Mode after three minutes of keypad inactivity.
- 🔗 **NOTE:** To remove sensors from the Control Panel's memory, see the "Customizing the System" section of this manual.

8. BASIC SENSOR INSTALLATION



- ◆ Each accessory sensor is packaged with its own set of installation instructions specific to the model of sensor.
- ◆ Refer to the sensor's instructions for details on installing, operating, and testing of the sensor.
- ◆ Following are basic instructions for installing two popular DVS-2408 accessories: The Model - DXS-10 Wireless Remote Keypad and the Model DXS-31 Door/Window Transmitter.

DXS-10 WIRELESS KEYPAD


- ◆ The DXS-10 is used to remotely operate the system.
- ◆ The keypad can be simply set on a table or mounted to a flat surface.

TABLE-TOP USE

- ◆ Four anti-mar pads are provided as scratch deterrent "feet" for the keypad.
- ⚠ **NOTE: Do not use the adhesive "feet" if the keypad is going to be wall mounted.**
- Peel off the adhesive tape backing on the "feet" and stick them to the back of the keypad.
- ◆ The wireless keypad can be used as a portable keypad. Because of the hourly supervisory transmissions, if the unit is taken out of range from the Control Panel for more than eight hours, the hardwired keypad will indicate "radio trouble" for the wireless keypad. The keypad's sensor number can be programmed for "non-supervised" if required. See the "Advanced Programming" section of this manual.




USE THE FOUR SCRATCH DETERRENT PADS PROVIDED FOR TABLE-TOP USE



WALL MOUNT USE

- ◆ The wireless keypad can be wall mounted in a convenient location.
- Open the keypad by inserting a small screwdriver in one of the top slots in the keypad case. Gently twist the screwdriver until the case pops open.
- Attach the rear case to the wall using the two screws provided.
- ⚠ **NOTE: For best signal transmission, the keypad should be mounted at least three feet above ground level.**
- Hook the top edge of the keypad case together and snap the keypad onto the rear case.
- ⚠ **WARNING: The wireless keypad is designed for indoor use only.**

ATTACH REAR CASE TO WALL WITH THE TWO SCREWS PROVIDED



MOUNT AT A CONVENIENT LOCATION NEAR PRIMARY ENTRY/EXIT DOOR

DXS-31 DOOR/WINDOW SENSORS

- ◆ The DXS-31 sensors can be used to monitor doors, windows, cabinets, crawl space doors, gates, freezer doors, and many other moving objects that could be used for intrusion or need to be monitored.
- ◆ A built-in magnetic switch triggers the sensor when its magnet (mounted on the moving part or the door or window) moves away from the sensor.
- ◆ External normally closed switches can be wired to the sensor for remote triggering.
- ◆ The door/window sensor can connect directly to a glass break detector.

SET SENSOR JUMPER

- ◆ A jumper inside the door/window sensor selects instant or delayed response.
- If the sensor is going to be used on the primary entry/exit door make sure that the jumper is in the DELAY position.
- If the sensor is going to be used on a window or a door that is not going to be used to enter and exit the premises, set the jumper to the INSTANT position.

APPLY DOUBLE-STICK TAPE

- Apply double-stick tape (supplied) to back of sensors and magnets.
- ◆ Screws are also provided to mount sensors and magnets.
- ◆ Screws are preferred over the double-stick tape in permanent installations.
- ⚠ **UL NOTE: Double-stick tape is not allowed in UL installations.**



ATTACH SENSORS AND MAGNETS

- On doors, mount sensor to door frame and magnet to door.
- ⚠ **NOTE: Magnet must line up with mark on sensor case both horizontally & vertically.**
- Allow a maximum of 1/2" between magnet and sensor when door/window is closed.
- Snap sensor onto mounting plate.
- On windows, mount sensor to window frame and magnet to window.
- Snap sensor onto mounting plate.
- The magnet height is adjustable and an optional magnet spacer is provided for uneven surfaces.


TEST SENSORS

- * In Chime Mode, the hardwired keypad(s) should "ding-dong" when the sensor sends a signal.
- Open door or window.
- * Verify that light on the sensor glows momentarily when door/window is opened.
- * Status indicator on the hardwired keypad(s) should remain lit for each door/window sensor that is left open.


EXAMPLE INSTALLATIONS




INSTANT/DELAY OPTION JUMPER




SELECTS INSTANT



ATTACH MOUNTING PLATES USING THE SCREWS OR DOUBLE-STICK TAPE PROVIDED




NOTE: ATTACHING THE TRANSMITTER WITH DOUBLE-STICK TAPE IS NOT ALLOWED IN UL INSTALLATIONS



9. CUSTOMIZING THE SYSTEM


- ◆ The system can be customized for the specific installation.
- ◆ A label sheet with sensor location names is provided with DVS-2408KP keypads.
- ◆ Labeling the sensors allows quick and easy identification of where a door or window is open, where any alarms have occurred, where a sensor with a low battery is, or where a sensor with trouble is.



REMOVE SNAP-ON BEAUTY COVER TO REVEAL THE SENSOR IDENTIFICATION LABEL AREA


LABELING THE SENSORS

- Remove the keypad's snap-on plastic beauty cover to reveal the sensor identification label area.
- Open one protected door/window to light its sensor status light on the keypad(s).
- Choose a label that describes the sensor location, or write the location on a blank label, and stick it in the area next to the sensor number.
- Close the protected opening that you just labeled.
- Repeat for each protected opening.
- Stick the WIRELESS KEYPAD label in the sensor number location for the wireless keypad (if used).
- Replace the beauty cover when finished.




OPEN DOOR OR WINDOW TO LIGHT SENSOR STATUS INDICATOR ON KEYPAD(S)

USE SENSOR LABELS SUPPLIED TO IDENTIFY EACH SENSOR LOCATION



USE AN INK PEN TO CUSTOMIZE BLANK LABELS

APPLY THE PRE-PRINTED SENSOR LOCATION LABELS TO THE KEYPAD(S) TO SUIT THE INSTALLATION




10. SYSTEM OPERATING MODES

OFF MODE

- ◆ Use this mode to disarm the burglary portion of the system.
- ◆ Switching to Off Mode stops any alarms in progress.
- ◆ The 24-hour functions are still active in Off Mode and can be triggered by pressing the [FIRE] or [EMERGENCY] on the keypad(s).
- Switch to Off Mode by entering the user code, and pressing [OFF].
- ⚡ **NOTE:** The keypad's [*] key resets the keypad's keyboard and can be used before entering any code to assure that any digits recently pressed will not be added to the correct code. Pressing [*] first is optional because the keypad will reset itself after 10 seconds of keyboard inactivity.
- * When the system is disarmed to Off Mode, the keypad(s) will sound one "Gong".
- * If an alarm has occurred, multiple Beeps will sound after disarming and the sensor light for the sensor(s) that caused the alarm will flash.
- ⚡ **NOTE:** In Off Mode, protected doors and windows cannot trigger the burglary alarm.



OFF MODE



CHIME MODE

- ◆ Chime Mode is for monitoring entries and exits without causing alarms.
- ◆ Use Chime Mode as an "automatic door chime" when at home.
- * Opening any protected door or window causes the keypad(s) to sound a "ding-dong".
- Select the Chime Mode by entering a user code, then press [CHIME].
- The user can enter Chime Mode from Off Mode by pressing [CHIME] for two seconds.
- * When the system is switched to the Chime Mode, the keypad(s) will sound a "Gong" and one "Beep".
- ◆ Going to Chime Mode disarms the system and stops any alarms in progress.
- ⚡ **NOTE:** In Chime Mode, protected doors and windows cannot trigger the burglary alarm.

CHIME MODE



HOME MODE

- ◆ Use this mode when sleeping or when anyone is staying inside.
- ◆ Home Mode causes an instant alarm when any perimeter sensor is triggered.
- ◆ Home Mode causes a delayed alarm when any exit/entry sensor is triggered (except in Home Instant Mode when they are instant).
- ◆ Alarm siren stops automatically after five minutes and the system will remain armed.
- ◆ Home Mode ignores all interior sensors (motion detectors, etc.).
- Arm to Home Mode by entering a user code, and pressing [HOME].
- The user can "Quick Arm" to Home Mode from Off or Chime Mode by pressing [HOME] for two seconds. (Quick arming can be disabled; see the "Advanced Programming" section of this manual.)
- ※ When the system is armed to the Home Mode, the keypad(s) will sound a "Gong" and two "Beeps".
- Enter a user code and press [OFF] or [CHIME] to disarm from Home Mode and/or stop the alarm siren.
- ※ If an alarm has occurred, multiple Beeps will sound after disarming and the sensor light for the sensor(s) that caused the alarm will flash (switch to Off Mode again or re-arm the system to stop the flashing alarm memory).

SECURE EXIT

- If the system is already in the Home Mode and the user wants to exit the premises while leaving someone inside *with the system still in Home Mode*, enter a user code and press the [HOME] key.
- ※ A "Gong" and two "Beeps" will sound and the HOME light will blink for 30 seconds. No exit delay Beeps will sound during the Exit Delay.
- ◆ The user can leave through a door with a delayed perimeter sensor during the 30 second Exit Delay without causing the Control Panel to begin an Entry Delay.
- ↳ **NOTE: The Exit Delay time can be changed; see the "Advanced Programming" section of this manual.**


HOME INSTANT MODE

- If the system is already in the Home Mode and the user wants to make all exit/entry sensors instant, press [HOME] for two seconds.
- ※ A "Gong" and two "Beeps" will sound and the HOME light will blink continuously.
- ◆ Because all exit/entry sensors will now cause an instant alarm when in Home Mode, the system must be disarmed before opening any exit/entry delay door.
- ↳ **NOTE: If quick arming is disabled the Home Instant Mode is unavailable.**


MANUAL BYPASSING OF SENSORS

- ◆ Manual bypassing of sensors in the Home Mode allows arming of the system at night with open windows, while still having perimeter protection with other closed doors and windows.
- ◆ The system will resist arming with open door or window sensors.
- ※ Four high-low Beeps to warn the user that something is open and the system will remain in the previous mode.
- ※ Lit sensor status indicators show which sensors are open.
- To manually bypass the open sensors, arm the system again *within five seconds*.
- ※ A "Gong" and two "Beeps" will sound, the HOME indicator will light, and the open sensors will be bypassed.
- ↳ **WARNING: Bypassed sensors cannot cause an alarm.**


HOME MODE




SECURE EXIT



QUICK ARM



HOME INSTANT MODE



AWAY MODE

- ◆ Use this mode when no one will be staying home.
- ◆ Away Mode causes an **instant** alarm when any perimeter sensor is triggered.
- ◆ Away Mode causes a **delayed** alarm when any exit/entry sensor is triggered.
- ◆ Away Mode causes an **instant** alarm when any interior sensors (motion detectors, etc.) are triggered. The interior sensors will be **delayed** if a perimeter delayed sensor is triggered first.
- ◆ Alarm siren stops automatically after five minutes and the system will remain armed. This can occur an unlimited number of times.
- Arm to Away Mode by entering a user code, and pressing [AWAY].
- The user can "Quick Arm" to Away Mode from Home, Chime or Off Mode by pressing [AWAY] for two seconds. (Quick arming can be disabled; see the "Advanced Programming" section of this manual.)

EXIT DELAY (For Leaving the Premises)

- * When the system is armed to the Away Mode, the keypad(s) will sound a "Gong" and three "Beeps".
- * During the 30 second Exit Delay, the keypad(s) will sound "Beeps" and the AWAY light will blink.
- ◆ The Exit Delay gives the user **30 seconds** to leave the premises through an exit/entry door without triggering an alarm.
- * When the Exit Delay is over, the keypad(s) will sound one "Gong" to warn the user that the system is fully armed.

🔊 **NOTE: The Exit Delay time can be changed; see the "Advanced Programming" section of this manual.**

ENTRY DELAY (For Entering the Premises)


- ◆ The Entry Delay gives the user **45 seconds** to enter the premises through an exit/entry door without triggering an alarm.
- ◆ If a exit/entry sensor is triggered, starting the Entry Delay, the interior sensors will also become **delayed** (this allows motion in the premises during the Entry Delay).
- * During the 45 second Entry Delay, the keypad(s) will sound "Beeps".
- ◆ When the Entry Delay is over, the system will go into full alarm and sound the siren if it is not disarmed to the Off or Chime Mode.
- * If an alarm has occurred while the user was gone, multiple Beeps will sound after disarming and the sensor light for the sensor(s) that caused the alarm will flash (switch to Off Mode again or re-arm the Control Panel to stop the flashing alarm memory).

🔊 **NOTE: The Entry Delay time can be changed; see the "Advanced Programming" section of this manual.**


MANUAL BYPASSING OF SENSORS

- ◆ Manual bypassing of sensors in the Away Mode allows arming of the system with open doors and windows, while still having perimeter protection with other closed doors and windows.
- ◆ The system will resist arming with open door or window sensors.
- * Four high-low Beeps to warn the user that something is open and the system will remain in the previous mode.
- * Lit sensor status indicators show which sensors are open.
- To manually bypass the open sensors, arm the system again *within five seconds*.
- * A "Gong" and three "Beeps" will sound, the AWAY indicator will light, and the open sensors will be bypassed.
- 🔊 **WARNING: Bypassed sensors cannot cause an alarm.**

AWAY MODE




QUICK ARM



TEST MODE

- * Even though this is a self-monitoring supervised system, the National Burglar and Fire Alarm Association recommends that all security systems be tested manually on a regular basis.
- ◆ The system must be in Off Mode before going to Test Mode.
- Switch the system into Test Mode by entering a user code and pressing [TEST].
- * When the system is switched to the Test Mode, the keypad(s) will sound a "Gong" and four "Beeps".
- Holding down the [TEST] button in Test Mode will light all of the keypad(s) indicators.
- * The sensor status lights will flash for each sensor programmed into the Control Panel.
- Go to each sensor and press its test button or open and close the protected opening.
- To test the wireless keypad, press the [(A)] key.
- * The keypad(s) will make a "Bing" sound as each sensor is tested.
- * As each sensor is tested, the sensor status light for the sensor will stop flashing and return to showing the current status of the sensor.
- Continue testing until there are no flashing sensor status lights.
- ⚠ **NOTE: If the system is left unattended in Test Mode, it will automatically switch back to Off Mode after three minutes.**



SENSOR FUNCTION IN EACH SYSTEM MODE				
SENSOR TYPE	OFF MODE	CHIME MODE	HOME MODE	AWAY MODE
AUTOMATION	ACTIVATES AND DEACTIVATES THE AUTOMATION OUTPUT			
EMERGENCY	ARMED 24-HOURS - TRIGGERS EMERGENCY ALARM			
PANIC	ARMED 24-HOURS - TRIGGERS SILENT PANIC ALARM			
FIRE	ARMED 24-HOURS - TRIGGERS FIRE ALARM			
PERIMETER	DEACTIVATED	CHIME	INSTANT BURGLARY ALARM	
EXIT/ENTRY	DEACTIVATED	CHIME	DELAYED BURGLARY ALARM	
INTERIOR	DEACTIVATED	DEACTIVATED	DEACTIVATED	FOLLOWER (INSTANT BURGLARY ALARM UNLESS ACTIVATED DURING ENTRY DELAY)
CHIME	CHIME			
2-BUTTON ARM/DISARM (LEFT) 2-BUTTON AUTOMATION (RIGHT)	LEFT BUTTON SWITCHES SYSTEM TO AWAY OR HOME MODE (PROGRAMMING FUNCTION 50) IF ALARM MEMORY IS ACTIVE, SWITCHES SYSTEM TO OFF OR CHIME MODE (PROGRAMMING FUNCTION 51)		LEFT BUTTON SWITCHES TO OFF OR CHIME MODE (PROGRAMMING FUNCTION 51)	
2-BUTTON ARM (LEFT) 2-BUTTON DISARM (RIGHT)	LEFT BUTTON SWITCHES SYSTEM TO AWAY OR HOME MODE (PROGRAMMING FUNCTION 50) IF ALARM MEMORY IS ACTIVE, SWITCHES SYSTEM TO OFF OR CHIME MODE (PROGRAMMING FUNCTION 51)		RIGHT BUTTON SWITCHES TO OFF OR CHIME MODE (PROGRAMMING FUNCTION 51)	
ENVIRONMENTAL	ARMED 24-HOURS - TRIGGERS ANNUNCIATION ONLY			

Sensor Type Table

11. SYSTEM TROUBLE INDICATIONS

- ◆ The DVS-2408P Control Panel is a self-monitoring supervised wireless system. If the Control Panel detects a problem with any of the supervised system sensors or backup battery, it will display the appropriate trouble indication and, if monitored, report the trouble to the Central Station through the communicator (depending on communicator programming).

CONTROL PANEL LOW BATTERY

- ◆ The Control Panel constantly charges and monitors the optional backup battery (if installed).
- ◆ If the backup battery condition is abnormal, the keypad's POWER light will indicate the trouble.
- ※ The POWER indicator normally glows when AC power is on.
- ※ With a charged backup battery installed, if the Control Panel loses AC power, the POWER indicator will dim as the Control Panel runs on the backup battery.
- ※ If the backup battery is low, recharging, or not installed, the POWER indicator blinks when AC power is present.
- ※ If the AC power is off and no backup battery is installed, the POWER indicator will be off (in this case, the system has no power and is disabled).
- Normal battery life for the type of backup battery used in the Control Panel is 3-4 years. If the battery does not take a charge in 72 hours, it should be replaced.

WIRELESS SENSOR LOW BATTERIES

- ※ When the BATTERIES indicator blinks, one or more wireless sensors have a low battery.
- Press [*] for one second to view sensor status. Sensor status indicator for any sensor with a low battery will light along with the BATTERIES indicator. Any trouble indications will follow during the five second status cycle.
- Replace the wireless sensor's battery as described in its instructions.
- Switch to Test Mode after replacing the wireless sensor battery and completely test the system (see Test Mode). Switching to Test Mode clears the low battery indication.

SENSOR TROUBLE


- ※ When the TROUBLE indicator blinks, one or more wireless sensors have not reported status during the eight hour status time period.
- Press [*] for one second to view sensor status. Sensor status indicator for any sensor with trouble will light along with the TROUBLE indicator. Any low battery indications will follow during the five second status cycle.
- Switch to Test Mode after servicing the sensor and completely test the system (see Test Mode). Switching to Test Mode clears the trouble indication.

POWER INDICATOR

ON WITH AC POWER AND CHARGED BACKUP BATTERY

BLINKS WITH LOW, RECHARGING OR MISSING BACKUP BATTERY


DIM WHEN AC POWER IS ABSENT AND CONTROL PANEL IS RUNNING ON BACKUP BATTERY



BATTERIES INDICATOR

BLINKS WHEN ONE OR MORE WIRELESS SENSORS HAVE A LOW BATTERY


LIGHTS WITH SENSOR INDICATOR DURING LOW BATTERY STATUS CHECK (PRESS * FOR 1 SECOND)



TROUBLE INDICATOR

BLINKS WHEN ONE OR MORE WIRELESS SENSORS HAVE NOT REPORTED STATUS DURING THE EIGHT HOUR STATUS TIME WINDOW

LIGHTS WITH SENSOR INDICATOR DURING TRANSMITTER STATUS CHECK (PRESS * FOR 1 SECOND)




12. CUSTOMIZING THE SYSTEM

- ◆ Adding additional sensors will increase the protection provided by the system. -
- ◆ All ground-level perimeter openings and accessible upper-story openings need protection.
- ◆ Motion detectors can protect interior areas and areas where valuables are kept.


ADDING SENSORS TO THE SYSTEM

- Always start with the system in Test Mode (enter a user code and press [TEST]).
- Enter the **master** user code then press [TEST].
 - * A "Gong" and five "Beeps" will sound.
 - * The sensor status indicators will light for each sensor programmed into the Control Panel.
- Enter an **unused** sensor number from 01-24 (you must enter two digits, example: 5 = 05).
 - ⚠ **NOTE: A sensor can be programmed into more than one location. Be sure to choose an UNUSED sensor number. If a sensor gets entered into more than one location, delete the duplicates using the remove sensor function.**
 - * The sensor indicator light will flash for the sensor number selected.
- Activate the sensor. (To add a wireless keypad, press the keypad's [*] key.)
 - * A single "Bing" tone will sound when the sensor is programmed into the Control Panel and the sensor status indicator will stay lit.
 - * A double "Buzz" tone will sound if there is already another sensor programmed to that sensor number.
- Enter another sensor number or exit Setup Mode by pressing the [*] key then hold [OFF] for three seconds.




REMOVING SENSORS FROM THE SYSTEM

- ◆ If a previously programmed sensor isn't going to be used with the system anymore, or it's a duplicate that has been entered into more than one sensor location, it should be removed from the Control Panel's memory.
- ◆ Start with the system in Test Mode.
 - Enter the **master** user code then press [TEST].
 - * A "Gong" and five "Beeps" will sound.
 - * The sensor status indicators will light for each sensor programmed into the Control Panel.
 - Enter the sensor number (from 01-24) that you want to remove (you must enter two digits, example: 5 = 05)
 - * The sensor indicator light will flash for the sensor number selected.
 - Press [TEST].
 - * A single "Bing" tone will sound when the sensor has been removed and the sensor status indicator will turn off.
 - Enter another sensor number or exit Setup Mode by pressing the [*] key then hold [OFF] for three seconds.




MAKING A SENSOR A 24-HOUR DOOR CHIME

- ◆ Sensors can be programmed to cause the keypad(s) to chime any time they're activated.
 - ◆ Chime-only sensors **will not** be able to trigger the alarm in any system mode.
 - ◆ The sensor must have already been programmed into the Control Panel (see "Adding Sensors to the System" for details).
- Start with the system in Test Mode.
 - Enter the **master** user code then press [TEST].
 - * A "Gong" and five "Beeps" will sound.
 - * The sensor status indicators will light for each sensor programmed into the Control Panel.
 - Enter the sensor number from 01-24 (you must enter two digits, example: 5 = 05)
 - * The sensor indicator light will flash for the sensor number selected.
 - Press [HOME], 8, then [AWAY]. A "Bing" tone will sound.
 - Enter another sensor number or exit Setup Mode by pressing the [*] key then hold [OFF] for three seconds.




MAKING A SENSOR INTERIOR

- ◆ Wireless motion detectors are automatically programmed as interior sensors. Any other sensor can also be programmed as an interior sensor.
 - ◆ Interior sensors can only trigger an alarm when the system is in Away Mode.
 - ◆ The sensor must have already been programmed into the Control Panel (see "Adding Sensors to the System" for details).
- Start with the system in Test Mode.
 - Enter the **master** user code then press [TEST].
 - * A "Gong" and five "Beeps" will sound.
 - * The sensor status indicators will light for each sensor programmed into the Control Panel.
 - Enter the sensor number from 01-24 (you must enter two digits, example: 5 = 05)
 - * The sensor indicator light will flash for the sensor number selected.
 - Press [HOME], 7, then [AWAY]. A "Bing" tone will sound.
 - Enter another sensor number or exit Setup Mode by pressing the [*] key then hold [OFF] for three seconds.



MAKING A SENSOR A DIFFERENT SENSOR TYPE

- ◆ Any sensor can be re-programmed to be any sensor type.
- ◆ Each sensor type causes the Control Panel to react in different ways depending on the current system mode.
- ◆ The sensor must have already been programmed into the Control Panel (see "Adding sensors to the System" for details).
- Start with the system in Test Mode.
- Enter the **master** user code then press [TEST].
- ✱ A "Gong" and five "Beeps" will sound.
- ✱ The sensor status indicators will light for each sensor programmed into the Control Panel.
- Enter the sensor number from 01-24 (you must enter two digits, example: 5 = 05)
- ✱ The sensor indicator light will flash for the sensor number selected.
- Choose a sensor type number from the Sensor Type Table.
- Press [HOME], the new sensor type number, then [AWAY]. A "Bing" tone will sound.
- Enter another sensor number or exit Setup Mode by pressing the [*] key then hold [OFF] for three seconds.






PROGRAMMING INFORMATION		SENSOR FUNCTION IN EACH SYSTEM MODE			
TYPE #	SENSOR TYPE	OFF MODE	CHIME MODE	HOME MODE	AWAY MODE
1	AUTOMATION	ACTIVATES AND DEACTIVATES THE AUTOMATION OUTPUT			
2	EMERGENCY	ARMED 24-HOURS - TRIGGERS EMERGENCY ALARM			
3	PANIC	ARMED 24-HOURS - TRIGGERS SILENT PANIC ALARM			
4	FIRE	ARMED 24-HOURS - TRIGGERS FIRE ALARM			
5	PERIMETER	DEACTIVATED	CHIME	INSTANT BURGLARY ALARM	
6	EXIT/ENTRY	DEACTIVATED	CHIME	DELAYED BURGLARY ALARM	
7	INTERIOR	DEACTIVATED	DEACTIVATED	DEACTIVATED	FOLLOWER (INSTANT BURGLARY ALARM UNLESS ACTIVATED DURING ENTRY DELAY)
8	CHIME	CHIME			
9	2-BUTTON ARM/DISARM (LEFT) 2-BUTTON AUTOMATION (RIGHT)	LEFT BUTTON SWITCHES SYSTEM TO AWAY OR HOME MODE (PROGRAMMING FUNCTION 50) IF ALARM IS ACTIVE, SWITCHES SYSTEM TO OFF OR CHIME MODE (PROGRAMMING FUNCTION 51)		LEFT BUTTON SWITCHES TO OFF OR CHIME MODE (PROGRAMMING FUNCTION 51)	
10	2-BUTTON ARM (LEFT) 2-BUTTON DISARM (RIGHT)	LEFT BUTTON SWITCHES SYSTEM TO AWAY OR HOME MODE (PROGRAMMING FUNCTION 50) IF ALARM IS ACTIVE, SWITCHES SYSTEM TO OFF OR CHIME MODE (PROGRAMMING FUNCTION 51)		RIGHT BUTTON SWITCHES TO OFF OR CHIME MODE (PROGRAMMING FUNCTION 51)	
11	ENVIRONMENTAL	ARMED 24-HOURS - TRIGGERS ANNUNCIATION ONLY			

Sensor Type Table

13. ADVANCED PROGRAMMING

- ◆ To perform any of the advanced programming steps, the system must be in the Setup Mode.
- ◆ Each programming function is performed with similar keystrokes. After the system is in Setup Mode, enter the programming step number, press [HOME] (HOME = program), enter the new value, and press [AWAY] (AWAY = store). Follow the figures next to the programming steps.

 = PROGRAM	 = REMOVE
 = STORE	

SETUP MODE

- Start with the system in Test Mode (Setup Mode cannot be reached from any other mode).
- From Test Mode, enter the master user code then press [TEST].
 - ↳ *NOTE: Only the master user code can be used to put the system into the Setup Mode. The restricted user codes cannot access Setup Mode, only Code Mode.*
- * A "Gong" and five "Beeps" will sound, signaling that the system is in Setup Mode.
- Press the [*] key then hold [OFF] for three seconds when you want to exit Setup Mode.
 - ↳ *NOTE: If the system is left unattended in Setup Mode, it will automatically switch back to Off Mode after three minutes.*

CONTROL PANEL PROGRAMMING OPTIONS


STEP #	PROGRAMMING FUNCTION	POSSIBLE VALUES	FACTORY VALUE	INSTALLATION VALUE
25	ENTRY DELAY	1-255 SECONDS	45	
26	EXIT DELAY	1-255 SECONDS	30	
30	BURGLARY SIREN TIME	1-30 MINUTES	5	
31	EMERGENCY SIREN TIME	1-30 MINUTES	5	
32	FIRE SIREN TIME	1-30 MINUTES	5	
40	AUTOMATION OUTPUT TIME	0-2500 SECONDS (0 = TOGGLE ON/OFF)	0	
50	REMOTE ARMING MODE	2 = HOME MODE; 3 = AWAY MODE	3	
51	REMOTE DISARMING MODE	0 = OFF MODE; 1 = CHIME MODE	0	
61	ENTRY DELAY BEEPS	0 = OFF; 1 = ON	1	
62	EXIT DELAY BEEPS	0 = OFF; 1 = ON	1	
63	SILENT BURGLARY ALARM	0 = AUDIBLE; 1 = SILENT	0	
64	SILENT EMERGENCY ALARM	0 = AUDIBLE; 1 = SILENT	0	
65	QUICK ARMING	0 = OFF; 1 = ON	1	
66	AUTO RESTORE	0 = OFF; 1 = ON	0	
67	AUTO BYPASS	0 = OFF; 1 = ON	0	
68	AUTOMATION MODE DURING ALARM	0 = FLASH (ENABLED BY FUNCTION 72) 1 = STEADY (ENABLED BY FUNCTION 72)	0	
69	AUTOMATION BING TONE	0 = NO BINGS 1 = BINGS	1	
70	REMOTE ARM/DISARM CHIRP	0 = NO CHIRPS 1 = CHIRPS (1 CHIRP = ARMED, 2 CHIRPS = DISARMED)	1	
71	AUTOMATION FLASHES AFTER ALARM	0 = STANDARD 1 = FLASHING AFTER ALARM	0	
72	AUTOMATION ACTIVE DURING ALARM	0 = STANDARD 1 = AUTOMATION ACTIVE DURING ALARM (FLASH OR STEADY PROGRAMMED BY FUNCTION 68)	0	
73	AUTOMATION ON WHILE ARMED	0 = STANDARD 1 = ON WHILE ARMED	0	
74	AUTOMATION ON DURING EXIT/ENTRY	0 = STANDARD 1 = ON DURING EXIT/ENTRY DELAYS	0	
75	AUTOMATION POLARITY	0 = + WHEN OFF; 1 = + WHEN ON	1	
87	REMOTE ACCESS PASSWORD	6 DIGITS	987654	
92	DURESS CODE	1-5 DIGITS	REMOVED	
93	RESTRICTED USER CODE #1	1-5 DIGITS	REMOVED	
94	RESTRICTED USER CODE #2	1-5 DIGITS	REMOVED	
95	RESTRICTED USER CODE #3	1-5 DIGITS	REMOVED	
96	RESTRICTED USER CODE #4	1-5 DIGITS	REMOVED	
97	RESTRICTED USER CODE #5	1-5 DIGITS	REMOVED	
98	RESTRICTED USER CODE #6	1-5 DIGITS	REMOVED	
99	MASTER USER CODE	1-5 DIGITS	REMOVED	

Control Panel Programming Table

CHANGING A SENSORS SUPERVISION

- ◆ When a wireless sensor is programmed, the Control Panel automatically recognizes it as supervised or non-supervised. The hardwire loops are always supervised for end-of-line resistor termination.
- ◆ The Control Panel expects hourly status transmissions from any wireless sensor programmed as supervised.
- ◆ Any wireless sensor can be programmed as supervised or non-supervised.


⚠ **NOTE: Don't program a wireless sensor that doesn't send status transmissions as supervised.**



CHANGING A SENSORS RESTORE REQUIREMENTS

- ◆ When a wireless sensor is programmed, the Control Panel automatically recognizes it as manual or automatic restoring. The hardwired loops are always manual restoring.
- ◆ The Control Panel expects restoral signals from any wireless sensor programmed as manual restore.
- ◆ Any wireless sensor can be programmed as manual or automatic restore.

⚠ **NOTE: Don't program a wireless sensor that doesn't send restoral transmissions as manual restore.**




ENTRY DELAY TIME

- ◆ The factory-set Entry Delay time is 45 seconds.
- ◆ The Entry Delay time can be adjusted from one to 255 seconds.


⚠ **NOTE: Don't make the Entry Delay too short. The user may not have enough time to disarm the system before an alarm.**

- Write the new Entry Delay time in the User's Guide.




EXIT DELAY TIME

- ◆ The factory-set Exit Delay time is 30 seconds.
- ◆ The Exit Delay time can be adjusted from one to 255 seconds.
- Write the new Exit Delay time in the User's Guide.




BURGLARY SIREN TIME

- ◆ The factory-set burglary siren time is five minutes (UL installation maximum).
- ◆ The burglary siren time can be adjusted from one to 30 minutes.




EMERGENCY SIREN TIME

- ◆ The factory-set emergency siren time is five minutes (UL installation maximum).
- ◆ The emergency siren time can be adjusted from one to 30 minutes.




FIRE SIREN TIME

- ◆ The factory-set fire siren time is five minutes (UL installation maximum).
- ◆ The fire siren time can be adjusted from one to 30 minutes.




AUTOMATION OUTPUT TIME

- ◆ The factory setting causes the Automation Output to toggle between on and off with each activation.
- ◆ The Automation Output can be programmed to turn on, then automatically turn off after one to 2500 seconds (42 minutes).




REMOTE CONTROL & HARDWIRE ARMING LEVEL

- ◆ The factory setting causes the portable remote controls to arm to the Away Mode.
- ◆ Alternately, the portable remote controls can arm to the Home Mode.
- ◆ Changing this setting will affect all the portable remote controls used with the system and all hardwired loops programmed as arm/disarm (Type 9) key stations.




REMOTE CONTROL & HARDWIRE DISARMING LEVEL

- ◆ The factory setting causes the portable remote controls to disarm to the Off Mode.
- ◆ Alternately, the remote controls can disarm to the Chime Mode.
- ◆ Changing this setting will affect all the portable remote controls used with the system and all hardwired loops programmed as arm/disarm (Type 9) key stations.




ENTRY DELAY BEEPS

- ◆ The factory setting causes the keypad(s) to beep during Entry Delays.
- ◆ Alternately, the Entry Delay beeps can be silenced.
- ◆ With the Entry Delay beeps off, the keypad(s) will be silent after a delayed sensor is triggered until the Entry Delay expires, then the alarm siren will sound.




EXIT DELAY BEEPS

- ◆ The factory setting causes the keypad(s) to beep during Exit Delays.
- ◆ Alternately, the Exit Delay beeps can be silenced.
- ◆ With the Exit Delay beeps off, the keypad(s) will be silent after arming to the Away Mode until the Exit Delay expires, then a single "Gong" tone will sound.




SILENT BURGLARY ALARMS

- ◆ The factory setting causes audible burglary alarms.
- ◆ Alternately, the Control Panel can be programmed for silent burglary alarms.




SILENT EMERGENCY ALARMS

- ◆ The factory setting causes audible emergency alarms.
- ◆ Alternately, the Control Panel can be programmed for silent emergency alarms.




DISABLING QUICK ARMING

- ◆ The factory setting allows quick arming of the Control Panel by pressing down the mode keys for two seconds.
- ◆ Alternately, the Control Panel can be programmed to not allow quick arming.
- ◆ If quick arming is disabled, a user code *must* be entered before pressing the mode buttons.
- 📌 *NOTE: For commercial installations, it is recommended to disable quick arming to prevent customers from arming the system.*
- 📌 *NOTE: If quick arming is disabled the Home Instant Mode is unavailable.*




AUTOMATIC RESTORAL OF BYPASSED SENSORS

- ◆ Bypassed sensors are ignored by the Control Panel and cannot cause an alarm.
- ◆ The factory setting causes the Control Panel to not automatically restore (remove the bypass from) sensors that close. Bypassed sensors will remain bypassed until the system is disarmed.
- ◆ Alternately, the Control Panel can be programmed to automatically restore any bypassed sensor when the sensor closes. After it's restored, the sensor is ready to cause an alarm the next time it is opened.
- ◆ This setting effects all sensors.




AUTOMATIC BYPASSING OF OPEN SENSORS

- ◆ The factory setting requires the user to manually bypass any open sensors when the system is armed.
- ◆ If arming is attempted with open sensors, the keypad(s) will sound five two-tone Beeps and will not arm.
- ◆ Arming to the same mode again within five seconds will bypass any open sensors and arm the Control Panel.
- ◆ Alternately, the Control Panel can be programmed to automatically bypass any open sensors when the system is armed.
- ◆ This setting effects all sensors.




AUTOMATION OUTPUT MODE DURING ALARM

- ◆ The factory setting causes the Automation Output to flash if it is programmed to activate during or after an alarm.
- ↳ **NOTE:** For the Automation Output to activate during or after an alarm, that function must be enabled with Programming Step 71 or 72.
- ◆ Alternately, the output can be programmed to be a steady output.




AUTOMATION ACTIVATION TONE

- ◆ The factory setting causes the keypad(s) to sound a "Bing" when the Automation Output is activated by pressing the [(A)] key, or when it's triggered with a two-button remote control.
- ◆ Alternately, this sound can be silenced.




REMOTE CONTROL & HARDWIRE ARM/DISARM CHIRP

- ◆ When arming with the portable remote control or with a hardwired loop programmed as arm/disarm (Type 9), the factory setting causes the keypad(s) to "chirp" once when armed, twice when disarmed, and three times when arming with sensors bypassed.
- ◆ Alternately, these chirps can be silenced.
- ↳ **NOTE:** If these chirps are silenced, it is recommended to program the Automation Output to be active when the system is armed, so a light can be triggered displaying the arming status of the system.




AUTOMATION OUTPUT ON DURING AND AFTER ALARM

- ◆ The factory setting causes the Control Panel's Automation Output to activate when pressing the [(A)] key, or when it's triggered with a two-button remote control.
- ◆ In addition, the Control Panel can be programmed to activate the Automation Output during and after any alarms.
- ◆ The output will continue until the flashing sensor status lights are cleared.




AUTOMATION OUTPUT ON DURING ALARM

- ◆ The factory setting causes the Control Panel's Automation Output to activate when pressing the [(A)] key, or when it's triggered with a two-button remote control.
- ◆ In addition, the Control Panel can be programmed to activate the Automation Output during alarms.
- ↳ **NOTE:** The Automation Output can be programmed to flash or be steady during alarm, see Programming Step 68.




AUTOMATION OUTPUT WHILE ARMED

- ◆ The factory setting causes the Control Panel's Automation Output to activate when pressing the [(A)] key, or when it's triggered with a two-button remote control.
- ◆ In addition, the Control Panel can be programmed to activate the Automation Output when the system is armed.




AUTOMATION OUTPUT DURING EXIT/ENTRY DELAYS

- ◆ The factory setting causes the Control Panel's Automation Output to activate when pressing the [(A)] key, or when it's triggered with a two-button remote control.
- ◆ In addition, the Control Panel can be programmed to activate the Automation Output during the exit and Entry Delays.




AUTOMATION OUTPUT POLARITY

- ◆ The factory setting causes the Control Panel's Automation Output to provide a current limited voltage source when activated.
- ◆ Alternately, the Control Panel can be programmed so the Automation Output provides a current limited voltage source when deactivated.



REMOTE ACCESS PASSWORD


- ◆ This is the password used to gain access to the Control Panel when using the RA-2400 remote access software.
- ◆ The password must be 6-digits long.
- Log the remote access password in the box below.



REMOTE ACCESS PASSWORD

DURESS CODE


- ◆ The duress code will disarm the system, without any special indications or sounds, but will send the programmed duress code to the Central Station.
- ◆ The duress code should be two or more digits different than any user code.
- Log the duress code in the box below.



DURESS CODE

MASTER USER CODE

- ◆ The master user code is the code that was entered when power was first applied to the Control Panel.
- ◆ The master user code can be changed through programming to any 1-5 digit code. Only the master user can access Setup Mode, restricted users cannot.
- ↳ **NOTE: For maximum security, a 3-5 digit code is recommended.**
- Log the master user code in the box below.



MASTER USER CODE


RESTRICTED USER CODES

- ◆ The Control Panel can be programmed with six restricted user codes.
- ◆ The restricted user codes operate the system as usual, but cannot access Setup Mode.
- ◆ The restricted user codes can access a special Code Mode that can be used to change or remove any of the six restricted user codes and the duress code only.
- ◆ A restricted user code is a good one to give any user that should be restricted from programming the Control Panel.

☞ **NOTE:** For maximum security, a 3-5 digit code is recommended.

☞ **WARNING:** NEVER PROGRAM ANY RESTRICTED USER CODE THE SAME AS THE MASTER USER CODE!

- Log the restricted user codes in the boxes.




STEP # 93	RESTRICTED USER CODE #1	
STEP # 94	RESTRICTED USER CODE #2	
STEP # 95	RESTRICTED USER CODE #3	
STEP # 96	RESTRICTED USER CODE #4	
STEP # 97	RESTRICTED USER CODE #5	
STEP # 98	RESTRICTED USER CODE #6	

REMOVING USER CODES

- ◆ Any restricted or duress user code can be removed from the Control Panel.
- ◆ Because access to programming would be impossible without a master user code, it cannot be removed using these steps.
- ◆ The master user code can be changed using programming Step #99.


☞ **NOTE:** The master user code can be removed using the Control Panel master reset programming step, although all other system programming will be reset to factory values and all sensors programmed will be erased.



CONTROL PANEL MASTER RESET

- ◆ Master resetting the Control Panel will set all of the programming options back to the factory values.
- ☞ **CAUTION:** Master resetting the Control Panel will erase the master, restricted and duress user codes, and remove all programmed sensors. All Control Panel and communicator programming values will be reset to the factory defaults.

- Start with the system in Test Mode (Setup Mode cannot be reached from any other mode).
- From Test Mode, enter the master user code then press [TEST].
- * A "Gong" and five "Beeps" will sound, signaling that the system is in Setup Mode.
- Enter programming Step #999
- Press [TEST].
- Enter the numbers 999 again.
- Press [TEST] again.
- * A "Bing" will sound to indicate the beginning of the reset process. This process will take up to 10 seconds while the memory is being reset.
- ◆ The system will revert to the first time power-up condition and be ready to accept the new master user code. Go to the "Basic Control Panel Programming" section of this manual to begin re-programming the system.




USE THESE EXACT KEYSTROKES TO PERFORM A MASTER RESET

14. COMMUNICATOR PROGRAMMING

SETUP MODE

- ◆ To perform any of the communicator programming steps, the system must be in the Setup Mode.
- ◆ Each programming function is performed with similar keystrokes. After the system is in Setup Mode, enter the programming step number, press [HOME] (HOME = program), enter the new value, and press [AWAY] (AWAY = store). Follow the figures next to the programming step.
- Start with the system in Test Mode (Setup Mode cannot be reached from any other mode).
- From Test Mode, enter the **master** user code then press [TEST].
- ↳ **NOTE:** Only the master user code can be used to put the system into the Setup Mode. The restricted user codes cannot access Setup Mode.
- * A "Gong" and five "Beeps" will sound, signaling that the system is in Setup Mode.
- Press the [*] key then hold [OFF] for three seconds when you want to exit Setup Mode.
- ↳ **NOTE:** If the system is left unattended in Setup Mode, it will automatically switch back to Off Mode after three minutes.

SETUP MODE




GENERAL COMMUNICATOR OPTIONS				
STEP #	PROGRAMMING FUNCTION	POSSIBLE VALUES	FACTORY VALUE	INSTALLATION VALUE
76	2-WAY AUDIO	0 = NONE; 1 = LISTEN; 2 = 2-WAY MANUAL; 3 = 2-WAY FULL DUPLEX	0	
78	VOICE RESPONSE FROM KEYPAD SPEAKER	0 = VOICE RESPONSE DISABLED 1 = VOICE RESPONSE ENABLED	0	
100	REMOTE PROGRAMMING LOCKOUT	0 = UNLOCK; 1 = LOCK	0	
101	SWINGER ELIMINATOR	0 = OFF; 1 = FIVE OCCURRENCES PER ARMING PERIOD	0	
103	DIALING DELAY	0 = NO DELAY; 1 = 15 SECOND DELAY	0	
104	DIALING METHOD	0 = TONE; 1 = PULSE	0	
107	COMMUNICATOR ENABLE	0 = COMMUNICATOR OFF, 1 = COMMUNICATOR ON	0	

General Communicator Programming Table


COMMUNICATOR ENABLE

- ◆ The factory setting for the Control Panel disables the communicator. If the system is going to be a non-monitored, local alarm only, leave the communicator disabled.
- ◆ If the system is going to be monitored by a Central Station, enable the communicator with this programming step.




2-WAY AUDIO

- ◆ When the Model VB-2 voice module is installed, the communicator can provide 2-way audio capability.
- ◆ The audio module can be programmed for listen only, 2-way manual operation (using a pushbutton telephone at the Central Station), and 2-way full duplex hands free operation.
- ◆ Refer to the VB-2 installation instructions for details on operating the audio module.
- 📌 **NOTE: The Model VB-2 digital voice response module must be installed for this option to function.**
- ◆ The factory setting for the VB-2 audio module is OFF.
- ◆ Alternately, the audio module can be set for (1) listen-only, (2) 2-way manual, (3) 2-way full duplex.
- 📌 **NOTE: For safety, 2-way audio will not activate if the system is disarmed with the duress code.**




VOICE RESPONSE

- ◆ The Control Panel can be programmed to allow the keypad(s) speaker to play audio produced by the VB-2 or VB-3 digital voice response modules.
- ◆ This selection can also be used when a remote speaker is connected to the Control Panel.
- ◆ The factory setting is to disable the keypad(s) speaker from playing voice module audio.
- ◆ Alternately, the Control Panel can be programmed to enable voice module audio.
- 📌 **NOTE: Turning voice response OFF with this programming step will only effect the audio produced by the voice module. It will not stop the keypad(s) speaker from sounding local sirens and tones.**
- 📌 **NOTE: A Model VB-2 or VB-3 digital voice response module must be installed for this option to function.**




REMOTE LOCKOUT

- ◆ The factory setting for the communicator allows remote connection to the Control Panel with Linear's RA-2400 Remote Access Software and a modem (unlocked).
- ◆ Alternately, the Control Panel can be programmed to not answer incoming calls, thereby, not allowing remote access (locked).




SWINGER ELIMINATOR

- ◆ The factory setting for the swinger eliminator is OFF. This allows the communicator to report alarms as many times as they are triggered.
- ◆ Optionally, the Control Panel can be programmed to only allow five communicator reports per arming period.
- ⚠ **NOTE:** *If the swinger eliminator is enabled, and the swinger count of five has been reached, and the alarm is triggered additional times, the alarm will not cause a communicator report but will still sound the local siren.*




DIALING DELAY

- ◆ The factory setting will cause the communicator to dial the Central Station instantly when an alarm or supervisory event occurs.
- ◆ Alternately, the communicator can be programmed to wait 15 seconds before dialing. This gives the user time to disarm the system and prevent communications in the case of a subscriber generated false alarm.



DIALING METHOD


- ◆ The factory setting causes the communicator to dial using DTMF (dual-tone multi-frequency) tone dialing.
- ◆ Alternately, the communicator can be programmed to use pulse (rotary) dialing. Use this option if the telephone line in the installation does not support tone dialing.



COMMUNICATOR REPORTING OPTIONS


REPORTING FORMAT

- ◆ The factory setting causes the communicator to report using the 4 by 2 format. This format allows four-digit account numbers from 0000 to 9999 and provides two-digit alarm codes.
- ◆ Alternately ADEMCO CONTACT ID can be chosen as a reporting format. This format allows 4-digit account numbers from 0000 to 9999 and provides verbose report descriptions with Ademco Contact ID compatible Central Stations.



CALL ROUTING

- ◆ The communicator can be programmed with three telephone numbers; primary, secondary, and supervisory.
- ◆ The factory setting for the communicator is to route all calls to the primary telephone number. If communication is unsuccessful after five attempts to the primary number, the secondary number will be dialed for an additional five attempts. If the secondary number cannot be reached, the communicator will "sleep" for five minutes before starting the call process over again. A total of four sleep cycles (50 call attempts) can occur before the communicator stops calling.
- ◆ Alternately, the communicator can be programmed to report supervisory events (low battery, trouble, AC failure, etc.) to the supervisory telephone number instead of the primary or secondary telephone numbers.
- ◆ To disable supervisory reports, set call routing option to "1" and remove the supervisory telephone number.



⚠ **NOTE:** Do not program the primary and secondary telephone numbers the same. See the FCC Telephone Rules and Regulations on the rear cover of this manual.


COMMUNICATOR REPORTING OPTIONS

STEP #	PROGRAMMING FUNCTION	POSSIBLE VALUES	FACTORY VALUE	INSTALLATION VALUE
86	CALL ROUTING	0 = ALL CALLS TO PRIMARY OR SECONDARY NUMBER 1 = ALL ALARM CALLS TO PRIMARY OR SECONDARY NUMBER AND ALL OTHERS TO SUPERVISORY NUMBER	0	
88	ACCOUNT NUMBER	4 DIGITS	EMPTY	
89	PRIMARY PHONE NUMBER	UP TO 20 DIGITS (PRESSING THE (A) KEY INSERTS A 1-SECOND DELAY)	EMPTY	
90	SECONDARY PHONE NUMBER	UP TO 20 DIGITS (PRESSING THE (A) KEY INSERTS A 1-SECOND DELAY)	EMPTY	
91	SUPERVISORY PHONE NUMBER	UP TO 20 DIGITS (PRESSING THE (A) KEY INSERTS A 1-SECOND DELAY)	EMPTY	
105	REPORTING FORMAT	0 = 4 BY 2; 1 = ADEMCO	0	
108	REPORT SYSTEM TROUBLE	0 = NO; 1 = YES	0	
110	REPORT FORCE ARMING	0 = NO; 1 = YES	0	
113	POINT ID REPORTING FOR 4 BY 2 FORMAT	0 = NO; 1 = YES	1	

Communicator Reporting Option Table


ACCOUNT NUMBER

- ◆ The communicator's account number entered must be 4-digits long.
- ◆ Enter an account number from 0000 to 9999.



PRIMARY TELEPHONE NUMBER


- ◆ The primary Central Station telephone number can be up to 20-digits long.
- ◆ Digits 0-9 can be used.
- ◆ Press the [(A)] key to place a 1-second dialing delay at any location in the telephone number.



SECONDARY TELEPHONE NUMBER

- ◆ The secondary Central Station telephone number can be up to 20-digits long.
- ◆ Digits 0-9 can be used.
- ◆ Press the [(A)] key to place a 1-second dialing delay at any location in the telephone number.


⚠ **NOTE:** To remove the secondary telephone number, program Step # then press [TEST].



SUPERVISORY TELEPHONE NUMBER


- ◆ The supervisory Central Station telephone number can be up to 20-digits long.
- ◆ Digits 0-9 can be used.
- ◆ Press the [(A)] key to place a 1-second dialing delay at any location in the telephone number.

⚠ **NOTE:** To remove the supervisory telephone number, program Step # then press [TEST].




REPORT CONTROL PANEL TROUBLE

- ◆ The factory setting does not report Control Panel trouble events to the Central Station.
- ◆ Alternately, the communicator can be programmed to report Control Panel trouble events. These include all conditions that light the keypad(s) BATTERIES or TROUBLE indicator. It also includes low Control Panel backup battery.




REPORT FORCE ARMING

- ◆ The factory setting does not send force arming reports.
- ◆ Alternately, the communicator can be programmed to report force arming anytime the Control Panel is armed with one or more bypassed sensors.
- ◆ The factory set reporting code for force arming is "65" (Code 574 with Ademco).
- ⚠ **NOTE:** If force arming is enabled, and the Control Panel is force armed (armed with an open sensor) remotely by telephone, or with the RA-2400 Remote Access software, the caller will be disconnected if the communicator is enabled.




OPENING AND CLOSING REPORTS

- ◆ The factory setting does not send opening and closing reports.
- ◆ Alternately, the communicator can be programmed to send an opening report when the system is disarmed, and a closing report when the system is armed for all users, or just the master user.
- ⚠ **NOTE:** For commercial installations using opening and closing reports, it is recommended to disable quick arming to prevent customers from arming the system.
- ⚠ **NOTE:** The reporting codes are fixed for opening and closing. A unique code is reserved for the master user code and each of the six restricted user codes.




POINT ID REPORTING

- ◆ The factory setting enables Point ID and allows the communicator to send two-digit alarm and trouble codes for each sensor. The individual sensor that causes an alarm or trouble report can be identified at the Central Station.
- ◆ Alternately, Point ID can be disabled. The Central Station will only receive general alarm and trouble reports.




COMMUNICATOR REPORTING CODES

- ◆ The two-digit communicator reporting code for each event has a factory set value. These values may be customized to fit the specific installation and the reporting requirements of the Central Station monitoring the system.
- ◆ If Point ID reporting is enabled (the factory default setting), each sensor can report a unique alarm and trouble code.
- ◆ If Point ID is disabled, the "general" reporting codes for each event type will be used.
- ↳ **NOTE: The reporting codes are fixed for opening and closing. A unique code is reserved for the master user code and the six restricted user codes. See the Opening & Closing Reporting Codes Table.**
- ◆ Each programming function is performed with similar keystrokes. After the system is in Setup Mode, enter the programming step number, press [HOME] (HOME = program), enter the new value, and press [AWAY] (AWAY = store).




GENERAL REPORTING CODES

- ◆ Program Steps #201 - 206 for the communicator reporting codes when Point ID is disabled.
- ◆ Refer to the General Reporting Codes table to view/edit the reporting codes for each of the five events. The factory settings are listed, along with a blank area to write in the new installation values.
- ◆ Any value from 0-99 can be programmed for each event (enter "0" to stop an event from reporting).
- ↳ **NOTE: Be careful not to duplicate codes unless the Central Station requires specific codes for certain types of events.**



SYSTEM REPORTING CODES

- ◆ Program Steps #261 - 266 for the Control Panel reporting codes.
- ◆ Refer to the System Reporting Codes table to view/edit the reporting codes for the keypad [FIRE] and [EMERGENCY] buttons and for each of the four Control Panel conditions. The factory settings are listed, along with a blank area to write in the new installation values.



GENERAL REPORTING CODES


STEP #	PROGRAMMING FUNCTION	POSSIBLE 4 x 2 VALUES	FACTORY 4 x 2 VALUE	INSTALLATION 4 x 2 VALUE
201	GENERAL FIRE REPORT CODE	0 - 99	1	
202	GENERAL EMERGENCY REPORT CODE	0 - 99	2	
203	GENERAL SILENT PANIC REPORT CODE	0 - 99	3	
204	GENERAL BURGLARY REPORT CODE	0 - 99	4	
206	GENERAL TROUBLE REPORT CODE	0 - 99	6	

General Reporting Codes Table

FORCE ARMING REPORTING CODE

- ◆ Programming Step #258
- ◆ The factory set reporting code for force arming is "65" (Code 574 with Ademco).
- ◆ Any value from 0-99 can be programmed for this event.


📌 **NOTE:** For force arming reporting, force arming reports must be enabled. See Page 41.



DURESS REPORTING CODE

- ◆ Programming Step #259
- ◆ The factory set reporting code for Duress is "66" (Code 121 with Ademco).
- ◆ Any value from 0-99 can be programmed for this event.

📌 **NOTE:** For duress code reporting a keypad duress code must be programmed. See Page 34.



SYSTEM REPORTING CODES

STEP #	PROGRAMMING FUNCTION	POSSIBLE 4 x 2 VALUES	FACTORY 4 x 2 VALUE	ADEMCO VALUE	INSTALLATION 4 x 2 VALUE
261	SYSTEM FIRE REPORT CODE	0 - 99	68	110	
262	SYSTEM EMERGENCY REPORT CODE	0 - 99	69	120	
263	SYSTEM TEST/CANCEL REPORT CODE	0 - 99	70	406	
264	SYSTEM LOW BATTERY RESTORAL REPORT CODE	0 - 99	71	R302	
266	SYSTEM LOW BATTERY REPORT CODE	0 - 99	73	E302	
258	FORCE ARMING REPORT CODE	0 - 99	65	574	
259	DURESS REPORT CODE	0 - 99	66	121	

System Reporting Codes Table

OPENING & CLOSING REPORTING CODES TABLE

USER CODE	4 x 2 CLOSING (ARMING) CODE	4 x 2 OPENING (DISARMING) CODE	ADEMCO CLOSING (ARMING) CODE	ADEMCO OPENING (DISARMING) CODE
MASTER USER CODE	74	82	CLOSE U000	OPEN U000
RESTRICTED USER CODE #1	75	83	CLOSE U001	OPEN U001
RESTRICTED USER CODE #2	76	84	CLOSE U002	OPEN U002
RESTRICTED USER CODE #3	77	85	CLOSE U003	OPEN U003
RESTRICTED USER CODE #4	78	86	CLOSE U004	OPEN U004
RESTRICTED USER CODE #5	79	87	CLOSE U005	OPEN U005
RESTRICTED USER CODE #6	80	88	CLOSE U006	OPEN U006
REMOTE/HARDWIRE ARM (SENSOR TYPE 9) & QUICK ARM	81		R407 U007	
REMOTE/HARDWIRE DISARM (SENSOR TYPE 9)		89		E407 U007


Opening & Closing Reporting Codes Table

4 BY 2 FORMAT POINT ID ALARM REPORT CODES

◆ Refer to the 4 by 2 Format Point ID Reporting Code table to view/edit the alarm reporting codes for each of the 24 sensors. The communicator will send these codes if Point ID is enabled and any sensor triggers an alarm. The factory settings are listed, along with a blank area to write in the new installation values.

⚠ **NOTE: Be careful not to duplicate codes unless the Central Station requires specific codes for certain types of sensors.**

◆ Each programming function is performed with similar keystrokes. After the system is in Setup Mode, enter the programming step number, press [HOME] (HOME = program), enter the new value, and press [AWAY] (AWAY = store).




4 BY 2 FORMAT POINT ID TROUBLE REPORT CODES

◆ Refer to the 4 by 2 Format Point ID Reporting Code table to view/edit the trouble reporting codes for each of the 24 sensors. The communicator will send these codes if Point ID is enabled and any sensor has a low battery or trouble condition. The factory settings are listed, along with a blank area to write in the new installation values.

⚠ **NOTE: Be careful not to duplicate codes unless the Central Station requires specific codes for certain types of sensors.**

◆ Each programming function is performed with similar keystrokes. After the system is in Setup Mode, enter the programming step number, press [HOME] (HOME = program), enter the new value, and press [AWAY] (AWAY = store).



4 BY 2 FORMAT POINT ID REPORTING CODES

STEP #	PROGRAMMING FUNCTION	POSSIBLE 4 x 2 VALUES	FACTORY 4 x 2 VALUE	INSTALLATION 4 x 2 VALUE
210	SENSOR 1 ALARM REPORT CODE	0 - 99	11	
211	SENSOR 2 ALARM REPORT CODE	0 - 99	12	
212	SENSOR 3 ALARM REPORT CODE	0 - 99	13	
213	SENSOR 4 ALARM REPORT CODE	0 - 99	14	
214	SENSOR 5 ALARM REPORT CODE	0 - 99	15	
215	SENSOR 6 ALARM REPORT CODE	0 - 99	16	
216	SENSOR 7 ALARM REPORT CODE	0 - 99	17	
217	SENSOR 8 ALARM REPORT CODE	0 - 99	18	
218	SENSOR 9 ALARM REPORT CODE	0 - 99	19	
219	SENSOR 10 ALARM REPORT CODE	0 - 99	20	
220	SENSOR 11 ALARM REPORT CODE	0 - 99	21	
221	SENSOR 12 ALARM REPORT CODE	0 - 99	22	
222	SENSOR 13 ALARM REPORT CODE	0 - 99	23	
223	SENSOR 14 ALARM REPORT CODE	0 - 99	24	
224	SENSOR 15 ALARM REPORT CODE	0 - 99	25	
225	SENSOR 16 ALARM REPORT CODE	0 - 99	26	
226	SENSOR 17 ALARM REPORT CODE	0 - 99	27	
227	SENSOR 18 ALARM REPORT CODE	0 - 99	28	
228	SENSOR 19 ALARM REPORT CODE	0 - 99	29	
229	SENSOR 20 ALARM REPORT CODE	0 - 99	30	
230	SENSOR 21 ALARM REPORT CODE	0 - 99	31	
231	SENSOR 22 ALARM REPORT CODE	0 - 99	32	
232	SENSOR 23 ALARM REPORT CODE	0 - 99	33	
233	SENSOR 24 ALARM REPORT CODE	0 - 99	34	
234	SENSOR 1 TROUBLE REPORT CODE	0 - 99	41	
235	SENSOR 2 TROUBLE REPORT CODE	0 - 99	42	
236	SENSOR 3 TROUBLE REPORT CODE	0 - 99	43	
237	SENSOR 4 TROUBLE REPORT CODE	0 - 99	44	
238	SENSOR 5 TROUBLE REPORT CODE	0 - 99	45	
239	SENSOR 6 TROUBLE REPORT CODE	0 - 99	46	
240	SENSOR 7 TROUBLE REPORT CODE	0 - 99	47	
241	SENSOR 8 TROUBLE REPORT CODE	0 - 99	48	
242	SENSOR 9 TROUBLE REPORT CODE	0 - 99	49	
243	SENSOR 10 TROUBLE REPORT CODE	0 - 99	50	
244	SENSOR 11 TROUBLE REPORT CODE	0 - 99	51	
245	SENSOR 12 TROUBLE REPORT CODE	0 - 99	52	
246	SENSOR 13 TROUBLE REPORT CODE	0 - 99	53	
247	SENSOR 14 TROUBLE REPORT CODE	0 - 99	54	
248	SENSOR 15 TROUBLE REPORT CODE	0 - 99	55	
249	SENSOR 16 TROUBLE REPORT CODE	0 - 99	56	
250	SENSOR 17 TROUBLE REPORT CODE	0 - 99	57	
251	SENSOR 18 TROUBLE REPORT CODE	0 - 99	58	
252	SENSOR 19 TROUBLE REPORT CODE	0 - 99	59	
253	SENSOR 20 TROUBLE REPORT CODE	0 - 99	60	
254	SENSOR 21 TROUBLE REPORT CODE	0 - 99	61	
255	SENSOR 22 TROUBLE REPORT CODE	0 - 99	62	
256	SENSOR 23 TROUBLE REPORT CODE	0 - 99	63	
257	SENSOR 24 TROUBLE REPORT CODE	0 - 99	64	

4 by 2 Format Point ID Reporting Codes Table

IMPORTANT INFORMATION

LINEAR LIMITED WARRANTY

This Linear product is warranted against defects in material and workmanship for twelve (12) months. The Warranty Expiration Date is labeled on the product. This warranty extends only to wholesale customers who buy direct from Linear or through Linear's normal distribution channels. Linear does not warrant this product to consumers. Consumers should inquire from their selling dealer as to the nature of the dealer's warranty, if any. There are no obligations or liabilities on the part of Linear Corporation for consequential damages arising out of or in connection with use or performance of this product or other indirect damages with respect to loss of property, revenue, or profit, or cost of removal, installation, or reinstallation. All implied warranties, including implied warranties for merchantability and implied warranties for fitness, are valid only until Warranty Expiration Date as labeled on the product. This Linear Corporation Warranty is in lieu of all other warranties express or implied.

All products returned for warranty service require a Return Product Authorization Number (RPA#). Contact Linear Technical Services at 1-800-421-1587 for an RPA# and other important details.

WIRELESS PRODUCT NOTICE

Linear radio controls provide a reliable communications link and fill an important need in portable wireless signaling. However, there are some limitations which must be observed.

- * For U.S. installations only: The radios are required to comply with FCC Rules and Regulations as Part 15 devices. As such, they have limited transmitter power and therefore limited range.
- * A receiver cannot respond to more than one transmitted signal at a time and may be blocked by radio signals that occur on or near their operating frequencies, regardless of code settings.
- * Changes or modifications to the device may void FCC compliance.
- * Infrequently used radio links should be tested regularly to protect against undetected interference or fault.
- * A general knowledge of radio and its vagaries should be gained prior to acting as a wholesale distributor or dealer, and these facts should be communicated to the ultimate users.

FCC NOTICE

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- * Relocate the Control Panel away from the TV/radio receiver.
- * Plug the Control Panel into a different wall outlet so that the Control Panel is on a different branch circuit.
- * Re-orient the TV/radio antenna.
- * If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions.

FCC TELEPHONE RULES AND REGULATIONS

The FCC requires that this alarm dialer system not make more than 15 repetitive dialing attempts to a single telephone number. There are no limitations when the calls are made sequentially to two or more alternative numbers, or when these calls are spaced 10 minutes apart to a single number. The FCC Rules and Regulations do not specify the re-attempt period as this can vary for specific applications. When setting this period, take into consideration local, interstate, foreign and special network call completion characteristics, network processing time, a sufficient number of rings and busy/don't answer modes.

FIRE EVACUATION PLANNING

For systems that include fire protection, UL requires that the following information be available to the users of the system.

- * Draw up a floor plan showing two exits for each room.

The following procedures are to be discussed with the family:

- ① Status of bedroom doors.
- ② Familiarity with alarm signals.
- ③ Testing of door during a fire and use of alternate escape route if door is hot to touch.
- ④ Crawling and holding breath.
- ⑤ Escape fast. No stopping for packing.
- ⑥ Meet at designated outdoor spot.
- ⑦ Emphasize that no one is to return to a burning house.
- ⑧ Fire department notification from a neighbor's phone.
- ⑨ Periodic rehearsal is to be conducted.

INDUSTRY CANADA NOTICES

NOTICE: The ringer equivalence number (REN) assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the ringer equivalence numbers of all the devices does not exceed 5.

NOTICE: The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational and safety requirements. The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

CAUTION: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.