

Kodak ESP 9

All-in-One Printer

print copy scan



User Guide



Eastman Kodak Company
Rochester, NY 14650

© Eastman Kodak Company, 2010

Kodak is a trademark of Eastman Kodak Company.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc., and any use of such marks is under license.

©1989-2007 I.R.I.S. (Image Recognition Integrated Systems), All Rights Reserved

P/N 1K5944

March 2010

Table of contents

1 Getting Help

Help menu	1
Getting answers to frequently-asked questions	2
Contacting Kodak Customer Service & Support	2
Support at Kodak.com	2

2 Printer Overview

All-in-One Printer features	3
Major components of the ESP 9 All-in-One printer	3
Support for connecting digital memory devices to the printer	5
Memory card slots	5
Memory cards supported	5
USB host port	6
Control panel layout	6
LCD screen	8
Using the control panel	9
Adjusting the control panel position	9
About the “touch-sense” buttons on the control panel	9
Using the 4-way navigation buttons	10
Using the OK button	11
Using the Menu button	11
Using the Zoom buttons	12
Using the Start button	12
Using the Cancel button	12
Using the number keypad buttons	12
Using the on-screen keyboard	13
Using the All-in-One printer menus	14
Menu layout	14
Menu structure	15
Status lights	16
All-in-One printer Home Center software	19
Home Center for Windows	19
Home Center for Macintosh	20

3 Setting Up Your Printer

Selecting a printer location	21
Configuring printer settings	21
Configuring basic settings	21
Printer Settings options	22
Setting your Kodak printer as the default	24
Configuring network settings	24
Networking resources	24
Configuring an Ethernet network connection	24

Configuring a wireless network connection	25
What you need to know before you connect	26
Configuring basic wireless (Wi-Fi) settings	26
Network Settings options	26
Wi-Fi Setup Wizard	27
Setting up an IP address	30
Verifying network configuration	31
Printing network configuration	31
Installing your printer on additional computers on the same network	31
Switching the printer connection type	32
For Windows	32
For Macintosh	33
Setting up the fax	34
Telephone service delivery systems and All-in-One fax features	34
Using cordless telephones with the ESP 9 All-in-One fax	36
Using voice-messaging services with the ESP 9 All-in-One fax	36
Using an answering machine with the ESP 9 All-in-One fax	37
Connecting the phone and fax	37
Specifying rings to answer	40
Setting fax auto-answer	40
Manually receiving fax	41
Specifying a distinctive ring for fax auto-answer	41
Configuring fax settings	42

4 Handling Paper

Handling paper	44
Loading the paper trays	44
Things to keep in mind	44
Loading plain paper	45
Loading photo paper	46
Loading envelopes	47
Loading legal size paper	47
Loading originals	48
Loading an original for copying or scanning	48
Loading an original for faxing	49

5 Viewing and Printing Photos

Viewing photos	50
Configuring photo print settings	51
Print Photos options	52
Printing photos	53
Printing photos from a PictBridge camera	53
Printing photos from non-PictBridge digital cameras, memory cards, and USB flash drives	53

Printing tagged images.....	55
Printing from a Bluetooth-enabled device	55
Printing multiple photos.....	56
Printing panoramic photos	56
Zooming and cropping photos	56
Transferring images to a computer	58
Transferring images to a Windows computer	58
Transferring images to a Macintosh computer	58
6 Copying	
Simple copying	59
Adjusting copy settings.....	59
Copy Document options.....	60
Copy Photo options.....	61
7 Scanning	
Before you start	62
Simple scanning	63
Simple document scans	63
Simple image scans.....	63
Scanning multiple originals simultaneously	64
Adjusting scan settings	64
Scan options.....	65
8 Faxing	
Introduction.....	66
Fax settings.....	66
Sending faxes	66
Dialing a fax number on the control panel	67
Selecting a fax recipient from the fax phonebook.....	67
Using quick dial to select a fax phonebook entry	68
Canceling faxes	70
Receiving faxes	70
Receiving faxes automatically	70
Manually receiving faxes	70
Fax Phonebook entries	71
Adding a new Fax Phonebook entry	71
Editing an existing Fax Phonebook entry	72
Deleting an existing Fax Phonebook entry	72
Preparing a fax for transmission	72
Printing a fax cover page	73
Changing send fax settings	73
Fax reports	75
Printing a fax report	75

9 Maintaining Your Printer

General care.....	76
Cleaning the scanner glass.....	76
Cleaning the scanner lid.....	77
Monitoring and adjusting the printer's performance	78
Maintenance options.....	78
Replacing ink cartridges	79
Replacing the printhead	82
Upgrading the printer software - for Windows	87
Upgrading the printer software - for Macintosh	88

10 Troubleshooting

Troubleshooting "quick start"	89
General troubleshooting.....	89
Printer fails to power on	89
Device not recognized.....	90
Ink cartridge not recognized.....	91
Multiple paper feed.....	91
Multiple pictures not scanned properly	91
No communication with computer	92
No paper feed	93
One or more of the colors on the calibration sheet is missing	93
Paper jam.....	93
Printer not responding	94
Transfer pictures failure	94
User guide on the CD is obsolete.....	95
Wrong paper size	95
Macintosh OS X troubleshooting.....	95
Windows Vista troubleshooting	95
Home Center software on Windows works incorrectly following software upgrade	96
Print troubleshooting.....	96
Envelope printing incorrect.....	96
PictBridge camera not detected	97
Picture cropped.....	98
Picture print smudged.....	98
Picture will not print.....	98
Poor print quality	98
Print skewed or slanted	99
Print spotted	99
Print too dark	100
Print too light	100
Printing slow	100
Printing stops.....	100
White edges on borderless prints.....	101

Copy troubleshooting	101
Copy cut off.....	101
Scan troubleshooting	102
Scan fails	102
Scanned image blank	102
Network troubleshooting.....	103
Wired network troubleshooting	103
Wireless troubleshooting	107

11 Product and Safety Specifications

Print Performance	112
Photo Printing Features	112
Copy Document Features	113
Copy Photo Features	113
Scanning Features.....	113
Paper Tray Features	114
Ink Tanks	114
Connectivity	114
Software Support	115
Physical Specifications	115
Warranty	115
System Requirements.....	116
Windows PC	116
Macintosh.....	116
Papers Supported.....	117
Paper Types.....	117
Paper Sizes for PC and Macintosh computers.....	117
Safety Specifications	118
Parts	118
Power	118
Location.....	119
Environment.....	119
Regulatory Compliance	120
FCC Compliance and Advisory	120
FCC and Industry Canada.....	121
IC Radiation Exposure Statement.....	121
Canadian DOC Statement.....	121
European Compliance Statement.....	121
German Compliance Statement	121
Waste Electrical and Electronic Equipment Labeling.....	122
Declaration of Conformity	123

Glossary

Appendix A: If You Need to Call Customer Support

Getting Help

This user guide helps you learn to operate your All-in-One printer from the control panel. Kodak also provides online help in the Home Center software installed when you set up your printer, and helpful information about common tasks from the LCD screen on the printer control panel.

NOTE: Home Center software must be open on your computer to access its help.

NOTE: The “Start Here” booklet that came in the printer box provides instructions for setting up and configuring this All-in-One printer.

Help menu

You can get instructions for performing the following tasks from the menu displayed on the LCD screen.

Help Menu Options
Install Ink Cartridges
Copy a Document
Copy a Photo
Print a Photo
Scan a Document
Scan a Photo
Wi-Fi Setup

To display Help menu information on the LCD screen:

1. From the printer control panel, press **Menu**.
2. Press ▼ until **Help** is the highlighted option on the Main menu, and then press **OK**.
3. As needed, press ▼ until the desired option is highlighted, and then press **OK**.
4. Follow the prompts on the LCD screen to view the available information.



Tip: Press ▲ and ▼ as needed to scroll up and down to see all the available information.

Getting answers to frequently-asked questions

See [Chapter 10, Troubleshooting](#) for help resolving a number of issues about printing, copying, scanning, and configuring the wireless service on your printer.

Contacting Kodak Customer Service & Support

Kodak provides several resources to help you answer questions about your printer.

Support at Kodak.com

Support	Description	Internet Address
All-in-One printer support	Support Center home page	www.kodak.com/go/support
	Get support for your product (FAQs, troubleshooting information, etc.). Tip: Print a test page before contacting Kodak support (see If You Need to Call Customer Support, page 128).	www.kodak.com/go/faqs
	Purchase a full range of digital camera and printer accessories.	www.kodak.com/go/accessories
	Download latest printer software, firmware, drivers, setup booklet, and user guide for your printer.	www.kodak.com/go/downloads
Software	View online tutorials for using Home Center software (Windows only).	www.kodak.com/go/howto
	Get information on Kodak EasyShare software.	www.kodak.com/go/easysharesw
	Get help with the Windows operating system and working with digital images.	www.kodak.com/go/pcbasics
Wi-Fi and Ethernet	Get help with the Wi-Fi and Ethernet.	www.kodak.com/go/inkjetnetworking
Other	Learn ways to use your All-in-One printer to create fun and memorable projects.	www.kodak.com/eknec and then click the Tips & Projects Center tab on the page
	Register your printer.	www.kodak.com/go/register
	Locate Telephone Customer Support numbers in various countries.	www.kodak.com/go/contact

The Kodak ESP 9 All-in-One printer allows you to print, copy, scan, and fax images and documents. Although many functions can be operated directly from the control panel, you may also print, store, and manage digital images from a Windows or Macintosh computer connected to the printer via Kodak's All-in-One printer Home Center software, which installs during the printer setup process. In addition, this printer supports networking, allowing you to access the printer over a wireless (Wi-Fi) or wired (Ethernet) network.

All-in-One Printer features

This printer includes:

- A printhead system with two Kodak high-quality pigmented ink cartridges
- An integrated printing accessory that produces two-sided printing from a connected computer
- A bottom paper tray that supports multiple media, including A4, Letter, Legal, 8x10, 5x7, 4x6, 4x7, and 4x12 paper, transparencies, and envelopes
- A top paper tray that supports 4x6, 4x7, and 5x7 photo paper and engages and disengages automatically
- A scanner capable of scanning up to A4 (length) and Letter-width originals, and Legal size plain paper through the automatic document feeder
- An automatic document feeder for document copying and fax
- Multi-format memory card support
- A Universal Serial Bus (USB) host port on the front of the printer for connecting a variety of external devices to the printer, including PictBridge or Picture Transfer Protocol (PTP) enabled digital cameras, USB flash ("thumb") drives, and Kodak Bluetooth USB 2.0 adapters ("dongles")
- A client USB (USB) device port on the back of the printer, for connecting the printer to host Windows or Macintosh computers
- Energy-saving low power mode
- Networking capability, including wireless (Wi-Fi) and wired (Ethernet)
- An innovative touch-control panel, light indicators, and a 3-inch LCD screen
- One network (Ethernet) port
- A low-fidelity speaker
- A Fax modem
- A telephone jack

Major components of the ESP 9 All-in-One printer

The graphics below show the main components of the printer. The legend describing the parts shown in the images is in the table below



Number	Component Name
1	Scanner lid
2	LCD screen
3	Top paper tray
4	Bottom paper tray extender tab
5	Bottom paper tray
6	Paper edge guide
7	Paper output tray
8	USB host port
9	Memory card slots
10	Control panel
11	Automatic document feeder (ADF)
12	Power cord connection port
13	Ports for connecting printer to the computer or Ethernet
14	Two-sided printing accessory
15	Scanner glass
16	Paper output tray extender
17	Rear-access cleanout area
18	Printer access door
19	Recessed handle for printer access door
20	Printhead

Support for connecting digital memory devices to the printer

Your All-in-One printer allows you to connect both digital camera memory cards and USB-connected devices for previewing and printing. You can also transfer photos and document files to your connected computer.



CAUTION:

Connect only one external memory device to your printer at a time. If both memory card slots, or any memory card slot and the host USB port, have a device connected to them simultaneously, the printer cannot access the photos or documents contained on any of them. If your printer cannot recognize a device you have connected to it, make sure that only one device is connected at a time.

Memory card slots

Although this All-in-One printer has two card slots, insert and use only one memory card at a time.



WARNING: Do NOT remove the memory card while the light blinks, or you may damage the card.

A blue light, located above the memory card slots, blinks while the card is being accessed and stays lit while the card remains in the slot and the printer is on.

Memory cards supported

The Kodak ESP 9 All-in-One printer supports the following memory cards, used in most digital cameras:

- **XD** xD-Picture Card
- **MS** Memory Stick, Memory Stick Pro and Magic Gate
- **SD** Secure Digital Card, Multi-Media Card
- **CF** Compact Flash type I and type II, including micro drives
- **SDHC** Secure Digital High Capacity cards.



Additionally, the printer supports the following memory cards used with Memory Stick and SD/MMC card slot adapters, which you will need to purchase separately:


- Memory Stick Duo and Memory Stick Duo Pro
- miniSD
- MicroSD (TransFlash)

USB host port

This All-in-One printer works with most digital cameras. Using the USB port located on the front of the printer, you can connect one of the following devices to the printer at a time:


- PictBridge or PictBridge camera
- USB portable storage drive
- Kodak Bluetooth dongle
- Digital cameras

NOTE: This printer can read only one memory card OR one portable USB drive OR one Kodak Bluetooth dongle at a time.



Control panel layout

The legend describing the numbered parts of the control panel illustration is in the table below.



Number	Name	Description
1	On/Off button	Powers the printer ON or OFF.
2	LCD screen	Displays photos, messages, status, on-screen keyboard, and menus.
3	Attention light	Blinks or flashes when an error occurs.
4	Menu button	Displays the menu, and toggles between parameters screens and preview screens.
5	Cancel button	Cancels the current operation and control panel navigation, and returns you to the menu.
6	Cap-sense (touch-sense) number keypad	Dials a fax telephone number or Quick Dial number; can be used to enter information and Quick Dial setting into the Fax Phonebook, specify quantity for making copies, and entering information used to authenticate access to a network.
7	Wireless (Wi-Fi) network status light	When lit, signals that a wireless (Wi-Fi) network connection is active. If the LED is illuminated, you may not be connected to the network yet. Go to Network Settings, View Network Configuration, and verify that it says it is Network and Connected. Blinks when searching for an available Wi-Fi network within range, or when the existing signal is too weak to transmit or receive wireless signals.
8	Ethernet network icon	Label only. Does not shine.
9	4-way navigation buttons	Enables you to navigate menus. Also used to pan around and crop a photo when activated by pressing the Zoom+ button.
10	OK button	Enables you to complete a menu selection or photo print command, accept a current zoom setting for cropping a photo, or allows you to continue with the current operation. Also used to select menu items.
11	Zoom buttons	Lets you zoom in and out of the photo.
12	Start button	Starts the following operations: copy, scan, print, fax, maintenance tasks, and file transfer.

NOTE: See [Adjusting the control panel position, page 9](#) for instructions on raising and lowering the control panel so that it is easier to use.

LCD screen

The LCD screen displays photos, messages, instructions, and menu items. Menu navigation is accomplished with the 4-way Navigation buttons on the control panel.

The LCD Start-Up screen displays whenever the printer is ready for operation but is not performing a task. The Start Up screen also displays the current level of black and color ink.



The first time you use your Kodak ESP 9 All-in-One printer and press the **Menu** button (described in [Using the control panel, page 9](#)) on the control panel, the Main menu displays on the LCD screen.

The contents displayed in the Main menu include:

- Copy Document
- Copy Photo
- View and Print Photos
- Scan
- Send Fax
- Fax Auto-Answer
- Fax Settings
- Network Settings
- Printer Settings
- Maintenance
- Help

To review the tasks you perform when you use the options available on the Main menu, see [Using the All-in-One printer menus, page 14](#).

Using the control panel

Adjusting the control panel position

The position of the control panel can be adjusted from its default position (flush against the front of the printer) to lifted upward at an angle.



To adjust the control panel position:

1. On the rear side of the control panel, locate the release tab.
2. Press the front of the control panel and the release tab toward each other with your thumb and fingers; maintain this position and pull the control panel toward you gently.
3. When you are satisfied with the position of the control panel, let go.
4. To return the control panel to its default position, squeeze the release tab and gently push the control panel away from you. Let go when the panel is seated against the front panel of the printer.

About the “touch-sense” buttons on the control panel

The ESP 9 All-in-One printer features flat-panel buttons that do not depress when pushed, as in a traditional keyboard or calculator keypad. Each button on the control panel responds to the pressure of your finger and performs a specific action based on the task you are working on.

If this type of interface is unfamiliar to you, it may take a bit of practice getting used to it. You should discover that each button is quite sensitive to touch, and you may find that pressing a key too hard, or accidentally pressing one button several times in a row, may cause errors.

With practice, you will learn the right amount of pressure and the best rate for pressing the keys for using the buttons quickly and easily.



Tip: Make sure that the **Printer Sounds** option (available in the Printer Settings menu) is set to ON when learning to use the printer. With sound enabled, the printer gives you audible feedback when you press any button on the control panel.

Using the 4-way navigation buttons

NOTE: The **OK** button is located in the center of the 4-way navigation buttons on the control panel. Its use is described in [Using the OK button, page 11](#).


The 4-way navigation buttons allow you to update the content displayed on the LCD screen.

- Pressing ▼ highlights the next row down in the visible menu. When the last row in a menu is highlighted, pressing ▼ causes the visible page to be replaced with the following page in a multi-page menu, with the top row highlighted; in a one-page menu, this action highlights the top item.
- Pressing ▲ returns you to the previous page in a multi-page menu.
- After you have initiated the process of zooming when a photo is shown on the LCD screen, pressing ▼ or ▲ pans the focus up or down. (See [Using the Zoom buttons, page 12](#).)



Tip: When you have selected a photo or document shown on the LCD screen to be printed, pressing ▲ or ▼ increases or decreases the output quantity. If you have selected more than one item for printing, you can specify a different quantity for each one. The LCD screen displays the number of copies of each selected item to be printed. Using this feature does not change the number of files stored on your camera or portable USB drive, however.

- When there are two or more options for the setting shown on the selected menu row, the current value is displayed between the ◀ and ▶ symbols. Pressing ◀ or ▶ on the control panel scrolls through the choices.



- When a photo is displayed on the LCD screen, after you have pressed the **Zoom+** button pressing ◀, ▶ moves the focus in the direction you have used.

NOTE: The **Zoom+** and **Zoom-** buttons on the control panel are discussed in [Using the Zoom buttons, page 12](#).

- When you are viewing a group of photos stored on a portable memory storage device such as a USB drive, pressing the ◀ or the ▶ button allows you to scroll through the images.
- Continuing to press any of the 4-way navigation buttons causes them to repeat the action until you release it.


Using the OK button

Press **OK** to:

- Accept the setting displayed in the selected row in the current menu
- Accept the preview on the LCD screen of something that you want to print, copy, scan or fax as the content to be produced.
- Select a photo for printing.



Tip: When previewing a group of images from a digital camera, portable USB drive, or memory card connected to the printer, press and hold **OK** to select all of the images not previously selected for printing in the default quantity stored in your printer. (Images already selected will not be affected.) Press and hold **OK** again to deselect all images.



Using the Menu button

Press **Menu** when:


- You want to set up a new task and anything other than a menu is visible on the LCD screen.
- You are viewing an image on the LCD screen and want to use Photo Options menu.
- You want to view the parent of the last menu displayed.



Using the Zoom buttons


Press **Zoom+** when an image is displayed on the LCD and you want to adjust the area to be printed, copied, or scanned. When this feature is available, the printer displays a prompt to press **Zoom** on the image shown on the LCD.

Once you have activated zoom for the selected item, you can then use both the **Zoom+** (zoom in) and the **Zoom-** (zoom out) buttons.



Using the Start button

Press **Start** to initiate the task you are working on with the current settings.



Using the Cancel button

Press **Cancel** when:

- You want to interrupt an operation that has already started.
- You are viewing a menu that you opened by selecting an option on a different menu, and then decide that you want to view the previous one.



Using the number keypad buttons

The number keypad is used primarily as a resource for sending faxes from the ESP 9 All-in-One printer. It is also used to enter a quantity for making copies.



Use the number keypad to:

- Dial a fax phone number
- Enter the Quick Dial number for an entry in the Fax Phonebook
- Enter the fax telephone number for an entry in the Fax Phonebook
- Enter a quantity for making copies of a document or photo

As on a telephone dial pad, which the number keypad resembles, each key on the ESP 9 number keypad (except for the 1 key and the zero key) is associated with both a numerical value and with either three or four alphabetic characters, with typographic symbols, or with symbols and a space (used to separate two alphanumeric characters).




Tip: Many ESP 9 users find it helpful setting the **Printer Sounds** option (available in the Printer Settings menu) to ON when using the number keypad. Because most keys can express more than one alphanumeric character, depending on how many times it is pressed, the audible feedback helps users to press each key at the proper speed. This prevents “jumping” past the desired value, which can happen if a key is pressed too quickly.

Using the on-screen keyboard

The on-screen keyboard displays in the ESP 9 All-in-One printer LCD for the following tasks performed on the control panel:

- Entering authentication information, such as a security string, for connecting the printer to a wired (Ethernet) or wireless (Wi-Fi) network, in the Network Settings menu
- Entering or editing your **Fax Sender** information in the Fax Settings menu
- Entering or editing the fax recipient **Name** in the Fax Phonebook

To maneuver around the on-screen keyboard, use the 4-way navigation buttons, described in [Using the 4-way navigation buttons, page 10](#), and the OK button, described in [Using the OK button, page 11](#).



Using the All-in-One printer menus


Use the menus on the LCD screen to select stand-alone tasks (that is, tasks that can be performed without your computer), such as copying documents or photos; printing photos stored on memory cards, USB drives, Kodak Bluetooth adapter ("dongle"), or digital cameras plugged into the printer; or sending a fax.

Using the appropriate menu, you can also initiate tasks that will be completed on a computer connected to the printer, such as transferring photos from a compatible device connected to the printer (such as a memory card, digital camera, or USB drive) to the computer.

Your printer updates the content of the menu dynamically, according to the tasks you perform.

Menu layout

A description of how the menus are displayed in the printer control panel is shown in the illustration and the legend below.



Number	Description
1	The Menu Title displays at the top of the menu. It names the category of available options. For example: Copy Document Options, Print Photo Options, etc.
2	The text displayed in the Quick instruction section, when displayed below the Menu Title, describes how to activate the selected menu option. For example: Press OK to continue, etc.
3	Any option in a row with a white background has not been selected. To use the option in a white row, you must navigate to it by pressing either the ▼ or the ▲ button on the control panel. See Using the 4-way navigation buttons, page 10 .
4	The Current Value content displayed between ◀ and ▶ symbols indicates the active setting only when you have more than one setting available. For example: On/Off, Yes/No, a number representing a quantity, etc.
5	The option in the row with the golden background is the selected option. Its functionality is enabled when you press the appropriate control panel button. When ▼ or ▲ are pressed, the selected menu option changes according to the direction used. See Using the 4-way navigation buttons, page 10 .

Menu structure

The top-level menu on your All-in-One printer is called the Main menu. When you press **OK** on most Main menu items, another menu displays. You can press **Start** as specified in the Quick instruction section beneath the menu title (see item 2 in the “Menu layout” illustration and accompanying table, above) to initiate a task.

You can review details about each menu available in your All-in-One printer using the information below:

Main menu option	When you press OK :	To review details about the option:
Copy Document	Displays Copy Document Options menu	See Copy Document options, page 60
Copy Photo	Displays Copy Photo Options menu	See Copy Photo options, page 61
View and Print Photos	Displays Print Photos Options menu	See Print Photos options, page 52
Scan	Displays Scan Options menu	See Scan options, page 65
Send Fax	Displays Fax Options menu	See Using quick dial to select a fax phonebook entry, page 68
Fax Auto-Answer	Sets Fax Auto-Answer On or Off	See Setting fax auto-answer, page 40
Fax Settings	Displays Fax Settings menu	See Fax Settings options, page 42
Network Settings	Displays Network Settings menu	See Network Settings options, page 26
Printer Settings	Displays Printer Settings menu	See Printer Settings options, page 22
Maintenance	Displays Maintenance menu	See Maintenance options, page 78
Help	Displays Help menu	See Help menu, page 1

Status lights

The tables below describe the meaning of each light and condition, and offer tips on what action to take.

On/Off Lights		
Light Status	Cause	Action / Solution
Off	The printer is turned off.	Press On/Off to turn the printer on.
	The printer does not have power applied.	Ensure that the printer power cord is properly plugged into the back of the printer. Verify that the power supply and or power cord LED is lit. Check that the power supply is connected to the power cord, and that it is properly connected to the electrical outlet. ^a
Blinks	The printer is initializing or busy.	None. Allow the printer to finish the initialization process.
On	The printer is ready.	None.

^a Most power supplies used with this ESP All-in-One printer are equipped with a status light which illuminates when electricity is applied. If you cannot determine if the power supply is working properly, contact Kodak Service & Support for assistance.

Printer Power Cord Light		
Light Status	Cause	Action / Solution
Off	The printer power cord is not properly connected to the printer.	Reconnect the printer power cord plug to the printer.
	The electrical power cord is not properly connected to your electrical outlet.	Reconnect the cord to the electrical outlet. Ensure that the electrical power cord is fully connected to the alternating current (AC) adapter at the end of the printer power cord.
	The electrical outlet has no power.	Plug a working device into the wall outlet to test it, or have it checked by an electrician.
	The problem may lie with the power supply.	Check the power supply status light, if available. As needed, visit Kodak.com for additional troubleshooting steps, or contact Kodak Service & Support.
On	The power supply is supplying power to the printer.	None.

Memory Card Slot Light		
Light Status	Cause	Action / Solution
Off	Either the memory card is not inserted or is improperly inserted in the card slot.	Remove and reinsert the memory card.
Blinks	The internal card reader is initializing or communicating with a memory card.	None.
On	A memory card is properly inserted in the card slot.	None.

Attention Light	
Light Status	Error
Off	None.
Blinks (slow) The LCD screen describes the error.	Paper jam. Paper tray empty. Paper carriage stall. Paper size or type mismatch. Change ink cartridge. Ink cartridge not readable. Printhead not calibrated. Unit open, scanner lid open, rear access door open. Too many image sources. Printhead not installed. Unable to read memory card or USB host device.
Blinks (slow)	Ink cartridge(s) inserted incorrectly. Ink cartridge(s) not installed.
On	Media sensor failure. Printhead failure. Scanner failure.

Wi-Fi Light		
Light Status	Cause	Action / Solution
Off	This indicates that the Wi-Fi radio is turned off and the printer is not connected to a wireless network.	None.
Blinks continuously	The Wi-Fi radio is turned on and the printer is searching for available wireless networks within range.	None, unless you want to stop the connection process. If so, turn the Wi-Fi radio off.
Blinks intermittently The LCD screen displays an error message	The Wi-Fi radio is turned on and: <ul style="list-style-type: none"> The printer cannot find any available wireless networks within range. or The Wi-Fi network connection has been interrupted, or is too weak to send signals to and from the printer. 	Press OK to turn off the error message on the LCD screen and then turn the Wi-Fi radio off. Run the Wi-Fi Setup Wizard to find and connect to an available wireless network within range. ^a
On	The Wi-Fi radio is turned on and there is a working connection between the printer and a wireless network.	None.

^a If you acknowledge the error message by pressing **OK**, the light will go off. However, if the Wi-Fi radio is not turned off and the printer cannot establish a connection to an existing Wi-Fi network, the light will resume blinking, and the error message will display again.

All-in-One printer Home Center software

Kodak Home Center software is installed on your computer during the setup process. The software functionality for Windows or Macintosh users is described below.

Home Center for Windows

Once installed, Kodak All-in-One printer Home Center software allows you to print, copy, scan, and configure your All-in-One printer from your Windows XP or Vista computer.

To open the Home Center software window on your computer, use the Home Center icon on the Desktop or in the Start Menu.



From the All-in-One printer Home Center main menu, selecting one of the six menu items enables you to:

- Scan pictures and documents
- Enhance and copy pictures
- Enhance and print images
- Configure settings for printing, copying, and scanning from the control panel
- Access the Kodak Tips and Projects Center Web site
- Order supplies from the Kodak Web site

The functions of the three small icons located in the upper-right corner of the Home Center window are shown below:



Returns you to the main Home Center window



Displays the Status Monitor



Displays a Help panel for the Home Center software

Home Center for Macintosh

After installing the software on your Macintosh OS X computer, you can select the Home Center from the System Preference's **Print & Fax** pane by selecting your All-in-One printer in the Printer List, clicking the **Print Queue** button, and clicking the **Utility** icon. Or, you can use the Home Center icon displayed in your Dock.



The Home Center window displays three tabs: Select, Setup, and Maintenance.

From the **Select** tab, you can select your All-in-One printer from a list of connected printers.

From the **Setup** tab, you can configure stand-alone printing, copying, and scanning settings:

- **AiO Printer:** This option lets you:
 - Synchronize your printer's date and time to the computer
 - Select what quality you prefer for printing on plain (not photo-quality) paper
 - Specify whether a date will be printed on the front of a photo printed from the All-in-One printer
 - Specify whether the printer automatically applies "scene balance" to digital pictures it prints
 - Change the name of the printer
- **Scan:** This option lets you configure settings for scanning, saving, and specifying the application(s) used for opening and editing scanned pictures and documents.

From the **Maintenance** tab, you can:

- Print a test page
- Align the printhead
- Run a printhead nozzle correction
- Clean the printhead
- Click **About this Printer** to view the printer model number, its Kodak Service Number, and the version of printer firmware used to operate the printer

From both the **Setup** and **Maintenance** and tabs you can:

- **Order Supplies:** This option allows you to order supplies online from the Kodak web site.
- **View/Hide Status:** This option opens a drawer displaying the configuration status of your All-in-One printer.

Use this chapter to set up and start using your Kodak All-in-One printer.

Selecting a printer location

Place your printer on a clean, flat surface in a dry, well-ventilated location, away from direct sunlight. Avoid areas with high levels of dust and debris. Do not expose the printer and paper to ventilation ducts, open doors, or high traffic, as airborne particles can affect picture quality.

Allow enough space on all sides of the printer to comfortably connect and disconnect cables, change ink cartridges, and remove or load paper.

To ensure getting good signals from your networked computer(s), minimize obstacles between the network router and the printer (and other wireless devices, such as Bluetooth-enabled camera phones, etc.). The printer will function best with as clear a “line of sight” as possible between it and the router.

In addition, keep the printer away from microwaves, and away from 2.4 GHz wireless telephone handsets.

Configuring printer settings

Printer settings can be adjusted in two ways: via the control panel or the Home Center software that comes with your printer (see Home Center Help for more details).

Configuring basic settings

1. From the control panel, press **Menu**.
2. Press ▼ until **Printer Settings** is selected, and then press **OK**.
3. Press ▼ until the parameter you want to configure is selected, and then press **OK**. To review the available options and settings, see [Printer Settings options, page 22](#).
4. Press ▼ or ▲ to configure the **Date and Time**, **Tagged Image Printing**, **Control Panel Settings**, **Language**, **Country/Region**, or **Reset All Settings**.
5. Press ◀ or ▶ as needed to change the default value. The default value is displayed at the right margin of the setting. When the setting is highlighted, the current value is bracketed between the ◀ and ▶ symbols.
6. Press **OK** to save the setting(s).

Printer Settings options

Menu Options	Options	Settings
Date and Time^a	Year	2007 - 2099
	Month	January - December
	Day	1 - 31
	Hour	0 - 12 or 0 - 23
	Minute	00 - 59
Tagged Image Printing	On	
	Off	
Control Panel Settings	Button Sounds	On
		Off
	Time to Low Power	1-4 hours, in .5 hour increments
Language	English (U.S.)	
	English (International)	
	Deutsch	
	Français	
	Français (Canada)	
	Italiano	
	Español	
	Castellano	
	Português	
	Nederlands	

Menu Options	Options	Settings
Country/Region	United States	
	Canada	
	Mexico	
	France	
	Germany	
	Italy	
	Netherlands	
	Portugal	
	Spain	
	United Kingdom	
	Europe	
	Australia	
	New Zealand	
	Austria	
	Belgium	
	Denmark	
	Finland	
	Norway	
	South Africa	
	Sweden	
	Switzerland	
	United Arab Emirates	
Reset All Settings	OK	
NOTE: Restoring the factory defaults from the Reset All Settings option will not change the settings for any of the following: Fax Phonebook, Country/Region, Language, Date and Time.		

^a Setting the date and time via the control panel is a separate task from stamping the date and time on photo prints. You can also synchronize the printer's date and time using the Home Center software.

Setting your Kodak printer as the default

For Windows XP

1. Click **Start**, point to **Settings**, and then double-click **Printers and Faxes**.
2. Right-click the icon for the Kodak ESP 9 printer, and then select **Set as the Default Printer** on the shortcut menu.

For Windows Vista

1. Click **Start**, and then click **Control Panel**.
2. Click **Hardware and Sound**, and then click **Printers**.
3. Right-click the icon for the Kodak ESP 9 printer, and then select **Set as the Default Printer** on the shortcut menu.

For Macintosh

Whenever a new printer is installed on the Macintosh operating system, it becomes the default printer. If you have more than one printer connected to your computer, use the following steps to change your default printer.

1. Click **System Preferences**.
2. In the **Hardware** section, click **Print & Fax**.
3. Select the Kodak ESP 9 printer from the list of available printer as the default.

Configuring network settings

You can connect your ESP All-in-One printer to a wired (Ethernet) network or to a wireless (Wi-Fi) network. You may refer to the "Start Here" booklet that came with your printer, or review the following sections as needed.

Networking resources

This section only covers how to setup your printer with your existing network. It presumes you have a working understanding on how your network is configured. Additional resources for related topics, information, and network troubleshooting are available at www.kodak.com/go/inkjetnetworking.

If you are unsure of how your network is configured, please contact your network administrator or your internet service provider for assistance.


Configuring an Ethernet network connection

You will need the following items to connect the All-in-One printer to a wired (Ethernet) network:

- A functional Ethernet network that includes a router, switch, or hub with an Ethernet port
- A CAT-5 (or higher) Ethernet cable

Ethernet setup

1. Plug one end of the Ethernet cable into the Ethernet port located on the back of the All-in-One printer and the other end into an available port on your Ethernet router or hub.



2. Turn on the printer, if necessary.
3. From the control panel, press **Menu**.
4. Press ▼ until **Network Settings** is selected.
5. Press **OK**.
6. Verify the connection.

Configuring a wireless network connection

You can connect your printer to an 802.11 wireless (Wi-Fi) network from the All-in-One printer control panel.

The wireless (Wi-Fi) network status light on your printer has the following conditions:

LED Status	Description
Fully lit	When lit, signals that a wireless (Wi-Fi) network connection has authenticated to the router, but your connection may not be active. You can verify the connection through the Network Settings menu.
Blinking	Blinks when <ul style="list-style-type: none"> ▪ searching for an available Wi-Fi network within range ▪ existing signal is too weak to transmit The LED has a repetitive cycle of blinking, then resting for 15 seconds, followed by blinking again. The Wi-Fi radio will continue to attempt connection to the network until a connection is established.

What you need to know before you connect

To connect your ESP 9 All-in-One printer to a wireless network, you will need the following:

- A laptop or desktop computer equipped with a network interface card or wireless networking support, and the Kodak software installed
- A working 802.11 wireless network. Kodak recommends that you use a wireless access point/router that uses Dynamic Host Configuration Protocol (DHCP)
- Internet access (preferably Broadband access such as cable or DSL)
- Your network name (SSID). You can obtain your SSID from the wireless router or the access point using the router's embedded web server. See the manufacturer's documentation provided with your wireless system for more information.
- Your WEP key or WPA passphrase. You can obtain your WEP Key or WPA passphrase from the wireless router or the access point using the router's embedded web server
- Your network security string, if applicable
- Disable your firewall or accept the firewall prompts to allow installation

If you are unsure about any of the items listed above, please contact your network administrator or your internet provider for assistance.






Configuring basic wireless (Wi-Fi) settings

NOTE: You will need to know the network name (SSID) of the Wi-Fi network, and its security string to connect your printer to the network successfully. Contact your Internet provider or the person who helped you configure your network to assist you.



CAUTION:

If there is an Ethernet cable plugged in to the Ethernet port on the back of the printer, unplug it before starting this task.

1. From the control panel, press **Menu**.
2. Press  until **Network Settings** is selected, and then press **OK**.
3. If the message states **Turn Wi-Fi Radio On**, press **OK**. If the message states **Turn Wi-Fi Radio Off**, move to the next step.
4. As needed, press , ,  or  to view or configure an item, and then press **OK**.

Network Settings options

If the printer has not been configured to connect to the Wi-Fi network or the printer

Wi-Fi radio is turned off, the LCD screen displays the options below:

Menu Options	Settings / Action
Wi-Fi Setup Wizard	Press OK to start the Wizard.
Turn Wi-Fi Radio On / Off	Press OK to toggle between the Wi-Fi radio on or off states.
View Network Configuration	Press OK to view the configuration on the LCD screen.
Print Network Configuration	Press OK to print the network configuration.
Manual IP Address	Press OK to display the Manual IP Address menu.

Wi-Fi Setup Wizard

Review the procedures below and use the one that suits your network setup.


Connecting to a listed network

1. Complete Steps 1 and 2 of [Configuring basic wireless \(Wi-Fi\) settings, page 26](#).
2. **Wi-Fi Setup Wizard** is the first option; press **OK** to select it.

NOTE: The Wi-Fi radio is turned on automatically when **Wi-Fi Setup Wizard** is selected.

3. The printer searches for available Wi-Fi networks within range, then displays the list in alphabetical order on the LCD screen. The illustration below shows an example list. The row containing each <Network name> listed also shows the strength of the signal (shown below as xx%) as a percentage between 0 and 100, where 100 is the highest possible strength.
 - For best performance the signal strength should be at least 50%.
 - If more Wi-Fi networks are detected than can be shown on the LCD screen, the display includes the ▼ (page down) symbol and/or the ▲ (page up) symbol on the LCD screen. As appropriate, press ▼ or ▲ on the control panel until you locate the network you want to use. As appropriate, press ▼ or ▲ on the control panel until you locate the network you want to use.

The last two options displayed are **Unlisted network** and **Rescan for wireless networks**.



NOTE: In your setup, instead of **<Network name>** as shown in the illustration above, the LCD will show the actual network name (SSID), without the brackets, and the signal strength, displayed as a percentage, of each available Wi-Fi network within range.

4. With the desired network selected, press **OK**. You may need network identification information, such as a security string, in order to authenticate your connection.

NOTE: You will need to know the network name (SSID) of the Wi-Fi network and its security string to connect your printer to the network successfully. Contact your Internet provider or the person who helped you configure your network to assist you.

5. If you are looking for a Wi-Fi network that does not broadcast its SSID, see [Connecting to an unlisted network, page 29](#).

NOTE: If your printer was last connected to an available network on the list, the network settings are saved and the printer will automatically attempt to reconnect you to that network.

6. If the network requires the entry of a security string, the keyboard will be shown on the LCD screen. Press ▲, ▼, ◀ or ▶ to select a key. Press **OK**.
7. Enter the security string. The correct upper and lower case characters and numbers are required.

NOTE: To erase any letters or numbers entered in error, select **<BKSP>** (backspace) and press **OK**.

Key/Passphrase/ Security String	Description
WEP key	5 or 13 ASCII characters; case-insensitive or 10 or 26 Hexidecimal digits; case-insensitive
WPA/WPA2 phrase	8-63 printable ASCII characters; case-sensitive

8. After completing your entry, select the **DONE** key, and then press **OK**.

LED Status	Description
Fully lit	When lit, signals that a wireless (Wi-Fi) network connection has authenticated to the router, but your connection may not be active. You can verify the connection through the Network Settings menu.
Blinking	<p>Blinks when</p> <ul style="list-style-type: none"> ▪ searching for an available Wi-Fi network within range ▪ existing signal is too weak to transmit <p>The LED has a repetitive cycle of blinking, then resting for 15 seconds, followed by blinking again. The Wi-Fi radio will continue to attempt connection to the network until a connection is established.</p>

The LED will be continuously lit when you are connected to a wireless network. This does not guarantee you are connected. You must verify that you are connected. See [Verifying network configuration, page 31](#).

Connecting to an unlisted network

1. **Wi-Fi Setup Wizard** is the first option; press **OK** to select it.
2. If your network does not appear in the list and is configured to not broadcast its SSID, select **Unlisted Network** and press **OK**.
3. Follow the prompts to enter the network name using the keyboard visible on the LCD screen. Press **▲**, **▼**, **◀** or **▶** to select a key. Enter the alphanumeric string accurately, using the same upper and lower case letters as your SSID. After completing your entry, select **DONE**, and then press **OK**.
4. Select **WEP** or **WPA/WPA2** as required for your network's security setup, and then press **OK**.
5. Enter the security information required using the LCD screen keyboard.
 - Press **▲**, **▼**, **◀** or **▶** to select a key. Select **<BKSP>** to erase any incorrect characters. Then select **DONE** and press **OK**.
6. After the confirmation message appears on the LCD screen, press **OK** to display the Network Settings menu.

Scanning for wireless networks

If you don't see your network in a list or want to change your network:

1. Select **Rescan for wireless networks**.
2. Press **OK**.

Setting up an IP address

If you have discovered that you are connected to the access point but you are not connected to the network, you may need to set up your IP address on the printer.

1. From the Network Settings menu, select **Manual IP Address** and press **OK**
2. Select one of the options displayed:
 - **Dynamic (DHCP)**
 - **Automatic (Private)**
 - **Manual (Static)**
3. Press **OK** to continue.
4. Depending on the IP address type specified, you may be prompted to enter an IP address, a Subnet Mask, a Gateway Address, and a DNS Server address. Press **OK** after making each entry. See your network provider for more information.

All address entries are made in the following format: 000.000.000.000. Any address or subnet mask that has only 2 characters between stops shall have a leading zero entered in front of that number. For example:

Address or Subnet Mask Format	Printer Entry Format
149.89.138.149	149. 089 .138.149
149.2.40.149	149. 002.040 .149

To obtain the IP Address on a Windows operating system:

You must use a computer on your network.

- a. Select **Start > Run**.
- b. Type **cmd**.
- c. Type **ipconfig** and then press **Enter**. If configured, IP Address, Subnet Mask and Gateway Address (Default Gateway) are shown.



Tip: Your Gateway Address is usually the router address.

To obtain the IP Address on a Macintosh operating system:

You must use a computer on your network.

- a. Open **System Preferences**.
- b. Under **Internet and Network**, click **Network**. Select the **Wireless Network**. Your IP address will be shown.

Verifying network configuration

You can verify that you are connected to a network from your ESP 9 All-in-One printer menu.

1. Press ▼ until **Network Settings** is selected, and then press **OK**.
2. Press ▼ until **View Network Configuration** is selected, and then press **OK**. When you select this menu item, the printer displays the configuration settings for both Ethernet and Wi-Fi networks on the LCD screen.
3. Press ▼ until the second page appears.
4. Look for the text **Connected Network SSID**. Your network name should be listed.

Printing network configuration

When you select this option, a print of your current network configuration settings is generated. Settings with no values are displayed as zeros.

1. Press ▼ until **Network Settings** is selected, and then press **OK**.
2. Press ▼ until **Print Network Configuration** is selected, and then press **OK**.

Installing your printer on additional computers on the same network

For Windows

To install the printer on another computer in your network, use the following steps.

1. Install the Kodak software that came with your printer on the target computer.
2. Run the Kodak Printer Network Setup Utility. This is located on the **Start > All Programs > Kodak > Kodak Printer Network Setup Utility**.
3. Select **Connect via Network - Wireless / Wi-Fi** then click **Next** to proceed. The printer should be detected and driver installations begin. If you have more than one printer connected to your network, select the printer and then click **Next**.
4. After the driver installation completes, click **Next** to proceed.

The printer will be named Kodak ESP 9-XXXX, where XXXX is a number unique to your printer.

For Macintosh

To install the printer on another computer in your network, use the following steps:

1. Install the Kodak software that came with your printer on the target computer.
2. Click **System Preferences**.
3. Click **Print & Fax**.
4. Click the + sign to add the printer.
5. Select the Kodak ESP 9 printer from the list of available printer(s).

The printer will be named Kodak ESP 9-XXXX, where XXXX is a number unique to your printer.

Switching the printer connection type

You can change the way you connect to your All-in-One printer at any time.

For Windows

USB to Wi-Fi

To convert the USB connection from a PC to a wireless network connection:

1. Disconnect the printer from the computer.
2. Use the Windows Control Panel to delete the printer from your computer.
3. Configure the wireless network from the printer front panel. See [Configuring a wireless network connection, page 25](#).
4. Press **Menu**.
5. Press **▼** until **Network Settings** is selected, and then press **OK**.
6. Select **View Network Configuration** and confirm you have an IP address.
7. Run the Kodak Printer Network Setup Utility. This is located on the **Start > All Programs > Kodak > Kodak Printer Network Setup Utility**.
8. Select **Connect via Network - Wireless / Wi-Fi**, then click **Next** to proceed. The printer should be detected and driver installations begin. If you have more than one printer connected to your network, select the printer and then click **Next**.
9. After the driver installation completes, click **Done** to proceed.
10. The printer will be named Kodak ESP9-XXXX, where XXXX is a number unique to your printer.

USB to Ethernet

To convert the USB connection from a PC to an Ethernet connection:

1. Disconnect the printer from the computer.
2. Use the Windows Control Panel to delete the printer from your computer.
3. Connect the printer to the network (LAN port on Router) with an Ethernet cable.
4. Run the Kodak Printer Network Setup Utility. This is located on the **Start > All Programs > Kodak > Kodak Printer Network Setup Utility**.
5. Select **Connect via Network - Ethernet cable**, then click **Next** to proceed. The printer should be detected and driver installations begin. If you have more than one printer connected to your network, select the printer and then click **Next**.
6. After the driver installation completes, click **Done** to proceed.
7. The printer will be named Kodak ESP9-XXXX, where XXXX is a number unique to your printer.

Wi-Fi to Ethernet

To convert the Wi-Fi connection from a PC to an Ethernet connection:

1. Connect the printer to the network (LAN port on the Router) with an Ethernet cable.

Ethernet to Wi-Fi

To convert the Ethernet connection from a PC to a Wi-Fi connection:

1. Disconnect the Ethernet cable from the printer.
2. Configure the wireless network from the printer front panel. See [Configuring a wireless network connection, page 25](#).
3. Press **Menu**.
4. Press ▼ until **Network Settings** is selected, and then press **OK**.
5. Select **View Network Configuration** and confirm you have an IP address.

For Macintosh

USB to Wi-Fi

To convert the USB connection from a Macintosh to a wireless network connection:

1. Disconnect the printer from the computer.
2. Configure the wireless network from the printer front panel. See [Configuring a wireless network connection, page 25](#).
3. Press **Menu**.
4. Press ▼ until **Network Settings** is selected, and then press **OK**.
5. Select **View Network Configuration** and confirm you have an IP address.
6. Open **System Preferences** and then click **Print & Fax**. Click + button to view a list of available printers that can be added. Network printers are labeled "Bonjour" under "Kind".
7. The printer will be named Kodak ESP 9-XXXX, where XXXX is a number unique to your printer.
8. Select your printer and click **Add**.

USB to Ethernet

To convert the USB connection from a Macintosh to an Ethernet connection:

1. Disconnect the printer from the computer.
2. Connect the printer to the network (LAN port on Router) with an Ethernet cable.
3. Open **System Preferences** and then click **Print & Fax**. Click + button to view a list of available printers that can be added. Network printers are labeled "Bonjour" under "Kind".

4. The printer will be named Kodak ESP 9-XXXX, where XXXX is a number unique to your printer.
5. Select your printer and click **Add**.

Wi-Fi to Ethernet

To convert the Wi-Fi connection from a Macintosh to an Ethernet connection:

1. Connect the printer to the network (LAN port on the Router) with an Ethernet cable.

Ethernet to Wi-Fi

To convert the Ethernet connection from a Macintosh to a Wi-Fi connection:

1. Disconnect the Ethernet cable from the printer.
2. Configure the wireless network from the printer front panel. See [Configuring a wireless network connection, page 25](#).
3. Press **Menu**.
4. Press ▼ until **Network Settings** is selected, and then press **OK**.
5. Select **View Network Configuration** and confirm you have an IP address.

Setting up the fax

Your Kodak ESP 9 All-in-One printer allows you to send and receive faxes, set up quick dials, and other fax options from the control panel.

For more information about sending and receiving faxes using this All-in-One printer, see [Chapter 8, Faxing](#).

NOTE: If your home or office setup is not described in this section, set up the All-in-One printer fax connection as you would a regular phone. See [Connecting the printer to a standard telephone line, page 38](#).



WARNING: Use only the phone cord supplied in the All-in-One printer box to connect your telephone wall jack and the port labeled Line-In on the back of the printer. Using any other phone cord may prevent you from sending and receiving faxes.

Telephone service delivery systems and All-in-One fax features

Before setting up your ESP 9 All-in-One printer for faxing, determine which type of telephone service you use

If your telephone service is:	Review this section first:
Internet Phone (VOIP) telephone service	Multipurpose (broadband) digital telephone systems, page 35
Cable telephone delivered by a cable television service	Multipurpose (broadband) digital telephone systems, page 35

If your telephone service is:	Review this section first:
Standard telephone service	Standard telephone systems, page 35
Digital subscriber line (DSL) telephone service	Digital subscriber line (DSL) telephone systems, page 35



CAUTION:

You should also read the following sections before connecting your ESP 9 to your telephone system.

- [Using cordless telephones with the ESP 9 All-in-One fax, page 36](#)
- [Using voice-messaging services with the ESP 9 All-in-One fax, page 36](#)
- [Using an answering machine with the ESP 9 All-in-One fax, page 37](#)

Multipurpose (broadband) digital telephone systems

If you use one of the following types of telephone services, you use a multipurpose, or “broadband” digital system:

- Internet telephone (also known as Voice-Over-Internet-Protocol or VOIP)
- Cable telephone

These systems transmit telephone signals across the same cables that transmit Internet or cable television signals. They require the use of computer or cable modems to route telephone traffic to your telephone or fax machine.

By connecting the telephone cable that came with your printer to the computer or cable modem and also to the ESP 9, your printer can successfully send and receive faxes over this type of telephone system.

Standard telephone systems

Sometimes called “Plain Old Telephone Systems” (POTS), this type of telephone service relies on a network of dedicated telephone wiring that cannot be used to transmit any other type of signal.

Your printer needs only the standard telephone cable that came with your printer, connected to both the printer and to the wall telephone jack, in order to send and receive faxes through the standard wall telephone jack.

Digital subscriber line (DSL) telephone systems

A DSL telephone system is a dedicated telephone service that, like multipurpose digital systems, transmits packets of digital data over cables. Unlike multipurpose systems, DSL networks use the wires of a local telephone network to transmit its signals.

To transmit fax signals properly to your printer, you must connect the telephone cable that came with the printer to a cable equipped with a DSL filter, and then connect the filtered cable to the printer and to the wall jack.



CAUTION:

Your telephones will not work without the installation of the DSL filter.

Using cordless telephones with the ESP 9 All-in-One fax

Cordless telephones, which connect to a digital, standard, or DSL telephone system, can be used with your All-in-One printer. To do so, you must connect the base station of your telephone (i.e., the cradle which connects your phone to the wall telephone jack or digital modem) to the telephone cable that came with your printer.

Using voice-messaging services with the ESP 9 All-in-One fax

Voice messaging (also called voice mail) services are operated by your telephone company. Voice messaging systems use a centralized, computerized system for recording messages rather than equipment at your telephone. They do not record fax transmissions.

Your printer relies on recognizing fax signals via the cable connecting it to the telephone (or wall jack), and therefore cannot retrieve faxes routed to the voice messaging service.

To automatically retrieve faxes with your printer if you subscribe to voice messaging through your telephone company, you must have one of the following options in place:

- A dedicated phone line that does not have voice mail used exclusively for fax transmissions.
- If the telephone line connected to your printer accepts calls for two or more phone numbers, the number used for fax calls must use a distinctive ring not used by any other number sharing this line. See [Specifying a distinctive ring for fax auto-answer, page 41](#).

If neither of these configurations is available to you, you cannot accept faxes on your printer in the Fax Auto-Answer mode. You can accept them manually, though. See [Manually receiving fax, page 41](#).

Using an answering machine with the ESP 9 All-in-One fax

If you use an answering machine to retrieve and record messages from telephone callers when you are not available to pick up the handset, you can set up your telephone to work with both the answering machine and the printer.

However, because answering machines cannot recognize fax calls or record fax signals for conversion later to a fax printout, care must be taken if you plan to accept fax calls automatically.

Before using your printer to accept faxes automatically when you are also using an answering machine, make sure the answering machine is connected correctly to the printer (see the illustrations that follow). Make sure the answering machine is set to answer calls before the printer. See [Specifying rings to answer, page 40](#).

Connecting the phone and fax

Identify the type of fax connection appropriate for you from the information below, and follow the instructions to configure your printer for sending and receiving faxes.

Type of Fax Connections	Fax Setup Procedure
Multipurpose (broadband) digital telephone systems	Connecting the printer to a digital telephone service line, page 37
Standard telephone systems	Connecting the printer to a standard telephone line, page 38
Digital subscriber line (DSL) systems	Connecting the printer to a digital telephone service line, page 37

Connecting the printer to a digital telephone service line

If the telephone line you intend to use for faxing through the All-in-One printer is configured to either an Internet phone service or to a cable phone service, connect your printer to the phone as described below:


1. Disconnect the phone cord from the wall jack that connects your modem to the telephone wall jack and plug it into the port labeled **LINE-In** on your printer.
2. If you use an answering machine:
 - Connect your answering machine to the **EXT-Out** port on the back of your All-in-One printer.



CAUTION:

The answering machine should be set to a fewer number of rings than the Rings to Answer setting. This will ensure that the answering machine picks up first.

See [Specifying rings to answer, page 40](#).




NOTE: Check with your cable television provider to make sure you can send and receive faxes over your digital telephone service.

Connecting the printer to a standard telephone line

If you have a dedicated phone line that does not receive any voice calls, connect your printer to the **Line-In** on the printer as described below.

1. Connect one end of the phone cord supplied with your printer to your telephone wall jack and the other end to the port labeled **Line-In**.



2. When the phone rings your printer is set to answer automatically after the number of rings set in the **Rings to Answer** setting. See [Specifying rings to answer, page 40](#).
3. If you use an answering machine, connect your answering machine plug into the port labeled **EXT-Out** on your printer. Set the number the of rings on your answering machine to a lower number of rings than the **Rings to Answer** settings on your All-in-One printer. If you are using a dedicated telephone line to send or

receive faxes, use the **LINE-In** port on your printer. Do not connect the answering machine to the **EXT-Out** port on your printer.



If you have a separate fax line on that does not receive any voice calls, connect your printer to the phone line as described in [Connecting the printer to a digital subscriber \(DSL\) telephone line](#) below.

Connecting the printer to a digital subscriber (DSL) telephone line

If you use a digital subscriber line (DSL), you must connect a DSL filter between the telephone wall jack and your Kodak All-in-One printer. Without the DSL filter for your digital subscriber line, you not be able to send and receive faxes.

1. Obtain a DSL filter from your DSL provider.
2. Connect the one end of the phone cord supplied with your Kodak ESP 9 All-in-One printer to the open port on the DSL filter, and the other to the printer port labeled **Line-In**. When the phone rings your printer is set to answer automatically after the number of rings set in the **Rings to Answer** setting. See [Specifying rings to answer, page 40](#).
3. If you use an answering machine, connect your answering machine to the port labeled **EXT-Out** on your printer. This provides a direct connection between the printer and your answering machine.



CAUTION:

When the phone rings, your printer will answer after the number of rings set in the Rings to Answer setting. The incoming fax will be received when the printer detects there is an incoming fax.

See [Specifying rings to answer, page 40](#).

4. Connect the DSL filter cord to the telephone wall jack.



Specifying rings to answer

You can specify how many rings should occur before the All-in-One printer automatically answers an incoming call. This setting applies only if the fax auto-answer feature is set to **On**.

The **rings-to-answer** setting is critically important for you if an answering machine shares the same phone line as your All-in-One printer, because *the answering machine must answer the phone first*. If this parameter is not set correctly, the answering machine cannot record any incoming calls.

NOTE: If you use a voice messaging service instead of an answering machine, this option is not effective. See [Setting fax auto-answer](#) below and [Specifying a distinctive ring for fax auto-answer](#), page 41.

The All-in-One printer monitors every call into the phone line, including calls picked up by the answering machine. If it detects incoming fax tones, it will receive the fax. It ignores any call that does not transmit the fax tones and allows the answering machine to record it.

Set the number of rings-to-answer for the printer to exceed the number rings set for the answering machine.

NOTE: This ESP 9 All-in-One printer allows you to specify the **rings-to-answer** from 1-6 rings. Make sure your answering machine is set to answer calls in fewer rings than your choice for rings-to-answer for your printer. For more information, see [Fax Settings options](#), page 42.

Setting fax auto-answer

When set to **On**, the All-in-One printer accepts incoming fax transmissions automatically, based on the number set in **rings-to-answer** (see [Specifying rings to answer](#) above).

If your fax phone line is configured to work through a computer modem, disable fax auto-answer.

NOTE: Some phone system features may not be available with pulse dialing, which is slower than tone dialing. Contact your telephone company if you are unsure as to which setting to use.

Manually receiving fax

If fax auto-answer is set to **Off**, there are two ways to accept an incoming fax and print it with the All-in-One printer. You can:

- Press the **Start** button on the All-in-One printer control panel when you pick up the telephone handset and hear fax tones.
- Using any phone that uses the same telephone line used by the All-in-One printer for fax, dial the Remote Access Code **234**.



Tip: Is your All-in-One printer located in a separate room from a telephone with the same number used by the ESP 9 All-in-One printer? If so, remember to dial 234 when you pick up the phone and hear incoming fax tones.

Specifying a distinctive ring for fax auto-answer

If you have one phone line shared by two or more phone numbers, your telephone service provider may be able to provide distinctive ring patterns for each phone number. For example, if you have designated one number as the number for receiving and sending faxes, you may have a ring pattern different than the pattern used for the phone number used for your personal voice calls or your business voice calls. If you have voice mail on your shared phone line that you use for sending or receiving faxes and do not have access to distinctive ring through your telephone service, you should disable fax auto-answer.

By using the **distinctive ring** feature on the ESP 9 All-in-One printer, when the printer detects the ring pattern specified for incoming faxes, it will automatically answer the call and receive the fax.

NOTE: If you use one phone number and one phone line exclusively for faxes, set **distinctive ring** to **Any**. For more information about the Fax Settings menu, see [Fax Settings options, page 42](#).

If two or more phone numbers are shared, set the distinctive ring feature to answer one of the lines and set **fax auto-answer** to **On**. See [Specifying rings to answer, page 40](#) to review how to use fax auto-answer with an answering machine.

Also see the note discussing voice messaging services on [page 41](#) if you have this type of fax setup and subscribe to voice messaging through your telephone company.

Configuring fax settings

You can adjust fax settings on the control panel. Windows users can also create a list of frequently used Fax telephone numbers using Home Center software (for more details, see Home Center Help, discussed on [All-in-One printer Home Center software, page 19](#)).

Both Windows and Macintosh users can set up a list of fax telephone numbers on the control panel by selecting **Send a Fax** from the Main menu. Windows users can also set up and maintain their Fax Phonebooks using Home Center software. For information on setting up and maintaining the Fax Phonebook, see [Fax Phonebook entries, page 71](#).

Fax Settings options

Menu Options	Settings / Actions
Edit Phonebook	Press OK to view Fax Phonebook options
Fax Sender Information	Press OK to view on-screen keyboard and enter information
Fax Auto-Answer	Press ◀ or ▶ to switch setting between On/Off
Rings to Answer	Press ◀ or ▶ to change setting from 1-6 rings
Redial if No Answer	Press ◀ or ▶ to switch setting between Yes/No
Busy Redial Attempts	Press ◀ or ▶ to switch setting from 0-12
Disable Call Waiting	Press ◀ or ▶ to switch setting between Yes/No
Call-Waiting Disable Code	*70 is default
Distinctive Ring Press ◀ or ▶ to change setting	Any
	Single Ring
	Double Ring
	Triple Ring
Fax Speaker	Press ◀ or ▶ to switch setting between On/Off
Print Fax Confirmation Page Press ◀ or ▶ to change setting	Never
	Always
	After Failure Only
Print Fax Settings	Press OK , then press Start
Print Fax Cover Page	Press OK , then press Start
Print Fax Activity Log	Press OK , then press Start
Dialing Mode^a	Press ◀ or ▶ to switch setting between Tone/Pulse
Error Correction^b	Press ◀ or ▶ to switch setting On/Off

^a Some phone system features may not be available with pulse dialing, which is slower than tone dialing. Contact your telephone company if you are unsure about which setting to use.

^b When the **Error Correction** mode is enabled, the printer detects errors during transmission. Using this feature, the All-in-One printer will automatically re-transmit the fax. Although the Error Correction mode increases send time on poor phone lines, the fax is transmitted much more reliably.

NOTE: Error Correction is only applied to black-and-white faxes sent from the All-in-One printer. This feature does not affect the reliable transmission of faxes being received.

1. From the control panel, press **Menu**.
2. Press ▼ until **Fax Settings** is selected, and then press **OK**.
3. Press ▼ until the option you want to configure is selected, and then press **OK**.
4. As needed, press ▲ or ▼ to set the desired sub-setting, as in configuring your sender name and telephone numbers.
5. As needed, press ◀ or ▶ to change the setting.
6. Press **OK** to save the setting(s).

Your Kodak All-in-One printer accepts print stock of various types and sizes, including letter- and legal-size plain paper, photo paper, transparencies, T-shirt transfers, envelopes, cards, and labels. It automatically detects the size and whether or not photo paper is loaded into the paper tray. Kodak photo paper contains barcodes that allow your All-in-One printer to detect the paper type that optimizes your photo prints.

The bottom paper tray accepts media from 6 to 9 inches wide, and from 7 to 14 inches long (see the Note in [Loading plain paper, page 45](#)); its capacity is 100 sheets of 20 lb. plain paper. The top tray capacity is 40 sheets of 4X6, 4X7, or 5X7 inch paper.

The automatic document feeder (ADF) on the ESP 9 All-in-One printer accepts up to 35 sheets of plain paper.



WARNING: The printer cannot sense photo paper loaded in the automatic document feeder (ADF) and will not feed photo paper into the printer for either copy (document) or fax operations.

Handling paper

Follow the precautions below when handling paper:

- Hold the paper by the edges; avoid placing your fingerprints on it.
- Do not touch the glossy side of photo paper.
- Store paper flat, away from direct sunlight and heat (such as in a car parked in the sun).

Loading the paper trays

Things to keep in mind

- Before you start loading any type of media into the printer, lift the paper output tray.



- Pull the paper stop (at the edge of paper output tray) until it is fully extended.
 - If the paper you are going to use is less than A4 size, lift the hinged end of the paper stop toward you until it is perpendicular to the paper stop. This prevents the printed paper from sliding off of the paper output tray as it exits the printer.

- If the paper you use is longer than A4 size, including Legal and panoramic photo paper, make sure that the hinged end of the paper stop lays flat and is NOT pulled up. The longer paper should balance on the paper output tray without sliding off.



CAUTION:

This is crucially important when you are printing two or more sheets of long paper. Long paper that cannot extend straight to its full length when output from the printer can fold behind the object ahead of it. The curl can result in a job that dissatisfies you, and it can also causes a blockade preventing paper still being printed from exiting the printer properly.

Although a paper curl should not interrupt a job involving just one sheet of long paper, when a sheet's clean exit from the printer is impeded because the sheet before it is curled by the paper stop, the current sheet also curls upon itself, generally behind rather than atop the sheet that came before. This process repeats until the trapped sheets jam the paper inside the printer.

Loading plain paper

NOTE: Review [Things to keep in mind, page 44](#).



CAUTION:

The automatic document feeder (ADF) on the ESP 9 only accepts plain paper.

1. Pull the bottom paper tray toward you.

NOTE: To load media that is more than A4 size, such as 4X12 inch panoramic photo paper or legal plain paper, you must first extend the bottom paper tray to its full length. To do so:

- a. Remove all paper from the tray, as needed.
- b. Press and hold the paper tray extension-release, located on the inside of the front of the lower paper tray.



- c. Pull the tray extension toward you gently until it stops moving easily. DO NOT pull the extension far enough to disengage from the paper tray.
- d. Let go of the tray release, and then load the paper in the tray.



Tip: To return the lower paper tray to its default size, press and hold the extension-release and push the tray until the extension stops moving, and then let go.

2. As needed, squeeze and slide the paper edge guide on the tray to the left so that it does not block the paper from laying flat.
3. Insert the media into the paper tray, print side down with its near edge against the paper stop.
4. As needed, squeeze and slide the paper edge guide to align it to the left edge of the media.
5. Lower the paper output tray.
6. Gently push the tray forward until it is aligned to the edge of the paper output tray.



Loading photo paper

NOTE: Review [Things to keep in mind, page 44](#).



CAUTION:

The automatic document feeder (ADF) on the ESP 9 only accepts plain paper. If you try to run photo paper through it, the printer displays an error message on the LCD screen, and the printer will not complete the job.

1. Remove all other paper from the paper tray you plan to use.
2. Insert photo paper into the paper tray print-side down, with the short edge forward. Do not overload the tray.
3. Slide the paper forward until it stops.
4. Squeeze the paper edge guide and slide it to the right until it just touches the loaded paper.
5. Lower the paper output tray.
6. Gently push the tray forward until it is aligned to the edge of the paper output tray.



Loading envelopes



WARNING: Do not load envelopes with cutouts or cellophane windows in this printer.

NOTE: Review [Things to keep in mind, page 44](#).

1. Remove all other paper from the paper tray you plan to use.
2. Place one or more envelopes along the right edge of the paper tray, with the front side down and the envelope flaps pointing toward the left side of the tray.
3. Squeeze the paper edge guide and move it to the right until it just touches the loaded envelope(s).
4. Close the paper tray and lower the paper output tray.



Loading legal size paper

1. Remove all other paper from the bottom tray.
2. Press and hold the paper tray extension-release, located on the inside of the front of the bottom paper tray.




3. Pull the tray extension toward you gently until it stops moving easily. DO NOT pull the extension far enough to disengage from the paper tray.
4. Let go of the tray release and then load the paper in the tray.
5. Squeeze the paper edge guide and move it to the right until it just touches the loaded paper.
6. Squeeze the paper edge guide and move it towards the printer until it just touches the loaded paper.
7. Push the paper tray in towards the printer.
8. Press the bottom paper extender tab on the front left edge of the tray while pushing the paper tray in towards the printer.



Loading originals

Loading an original for copying or scanning

To copy or scan a document or photo, place your original directly on the scanner glass, print side-down, against the silver arrow on the right-front corner or in the automatic document feeder (ADF).



Loading an original for faxing



WARNING: If photo paper is loaded into the automatic document feeder for copying or faxing, a paper jam results. Do NOT use the automatic document feeder for scanning.

If the original is more than 11 inches (279 mm) long, you can pull the tray extender all the way out to keep the original flat.

1. Place the original (plain paper only) print side up into the ADF

NOTE: If you are faxing only one page or if you are faxing anything printed on photo paper, you can place the original on the scanner glass. See [Loading an original for copying or scanning, page 48](#).

2. Align the paper edge guides with the edges of the paper to center the original in the ADF tray.

Viewing and Printing Photos

You can print JPEG (.jpg) photo images directly from PictBridge cameras connected to the front panel of your All-in-One printer. You can print virtually any file type from digital cameras, USB flash ("thumb") drives, and memory cards connected to the front panel on your All-in-One printer. You can also print files from a PC or Mac computer connected to your All-in-One printer computer.

NOTE: For assistance on printing from a connected computer to your printer, refer to the instructions from the software application (such as a word-processing or image-editing program) used to send the file to the printer or review your computer's operating system instructions.



CAUTION:

Never load photo paper into the automatic document feeder (ADF) on the ESP 9; the ADF only accepts plain paper. If you load photo paper in the ADF, the printer displays a warning on the LCD screen and will not complete the job.

Although your printer is compatible with the Kodak 8-in-1 USB card reader (sold separately) as well as other Kodak USB card readers, it may not be compatible with other manufacturers' card readers.



WARNING: Do NOT remove a storage device (memory card, USB drive, or digital camera) from the printer while it is being accessed, or you may damage the files on it. Safely remove or disconnect the device. You can safely remove the storage device when the blue status light located above the memory card slots stops blinking.

Viewing photos

Insert one of the following devices into the appropriate opening:

NOTE: Always use the USB host port on the front of the printer. To avoid an error, use only one slot or port at a time.

Device Type	Printer Slot
Memory Card	Memory Card Reader
Portable Storage Drive	USB port
Digital Camera	USB port
Kodak Bluetooth dongle	USB port

NOTE: If Tagged Image Printing is enabled on this printer (see [Configuring printer settings, page 21](#)), it detects a Digital Print Order Format (DPOF) file when you insert a memory card. The printer LCD screen prompts you to verify that you want to print tagged images. See [Printing tagged images, page 55](#).

Most memory cards will work with this printer. When you insert a memory card, or connect a camera or portable flash drive to the printer, the last photo taken is displayed first.



CAUTION:

Do not insert more than one device, such as a USB thumb drive or memory card, into the printer at a time, or you will get an error message. Also, never remove or disconnect a memory card from its slot unless the blue light near the slot is not blinking.

NOTE: Photos stored on a PictBridge camera are displayed on the camera's LCD screen only. See [Printing photos from a PictBridge camera, page 53](#), as needed.

Configuring photo print settings

You can change the factory default print settings for your printer using the control panel. Windows users may adjust some settings using Home Center software (see Home Center Help, discussed in [All-in-One printer Home Center software, page 19](#), for information on using Home Center).

1. Insert a memory card into the appropriate slot, or plug a USB flash drive or digital camera to the front panel USB port. The last photo is displayed first.
2. From the control panel, press **Menu**.
3. Press ▼ until the option you want to configure is selected, and then press **OK**.
4. As needed, press ◀ or ▶ to change the setting.
5. Press **OK** to save the setting for the current print job.
6. To save the setting as the default value, select **Save as Default** and press **OK**.
7. As needed, press ▲ or ▼ until **View Photos** is selected in the Print Photos menu, and then press **OK** to return to viewing and selecting photos for printing. Or, press **Start** to print the selected photo(s) with the selected settings.

Print Photos options

Menu Options	View Settings / Select	Settings
View Photos	OK	
Transfer All to PC	OK	
Rotate This Photo	OK	
Quantity	◀ or ▶	1- 99
Tray Selection	◀ or ▶	Top Tray
		Bottom Tray
Print Size	◀ or ▶	3.5x5
		4x6
		4x7 (High Def)
		4x12 (Panoramic)
		5x7
		8x10
		8.5x11
		(2x3) Wallet
Quality^a	◀ or ▶	Normal
		Best
		Draft
Color	◀ or ▶	Color
		Black & White
Scene Balance^b	◀ or ▶	On
		Off
Add Date to Prints^c	◀ or ▶	No
		Yes
Save as Defaults	OK	

^a Your All-in-One printer automatically adjusts the print output to the best available quality for images printed on photo paper. You need to set **Plain Paper Quality** to Draft, Normal or Best only when printing images or documents on plain printer paper.

^b This printer is capable of automatically adjusting scene balance improvements (or the brightness) of photos printed from camera cards and USB connected devices. The default is **On**.

^c The default setting does not print the date on the photo print.

Printing photos

Printing photos from a PictBridge camera

You can print photos directly from a PictBridge camera, which controls photo selection and printing.

1. Load the desired paper tray with photo paper, print side down.
2. Connect a PictBridge camera to the USB port located on the front panel of your printer.
3. Use your PictBridge camera to select and print the photos.

Printing photos from non-PictBridge digital cameras, memory cards, and USB flash drives



CAUTION:

This printer does not support portable USB “flash” drives that:

- Require third party access software
- Are encrypted
- Contain multiple partitions
- Were formatted using any of the following file storage systems:
 - New Technology File System (NTFS)
 - Mac OS Standard (HFS) or Mac OS Extended (HFS Plus)

The printer can read data stored USB flash drives formatted using only the File Allocation Table (FAT) system.

If a flash drive is plugged into the USB port on the front panel that the printer cannot read, the printer does not display photos, makes an audible sound (“beep”), and displays an error message on the LCD screen.

See the first Tip below for a work-around if your flash drive cannot be read by your printer.



Tip: If you would like your printer to print photos stored on a non-FAT formatted device, or stored as non-.jpeg files, you must first send the files to your computer to be read.

- Windows computers can read NTFS-formatted drives
- Macintosh computers can read HFS- and HFS Plus-formatted drives
- Third-party applications which run on either Windows or Macintosh computers can read many different image file types


Use your computer to explore the files stored on the flash drive while it is still plugged in. Navigate to and open the file in the computer, or transfer the file(s) to the computer hard drive. Then, print the file from your computer.

1. Connect a digital camera or portable USB drive to the front panel USB port, or insert a memory card to the appropriate card reader on the front panel.
The printer displays the photos on the LCD screen, last photo first.
2. Load the paper tray with photo paper, print side down.
3. On the control panel, press ◀ or ▶ until a photo you want to print is displayed on the LCD screen.
4. Press **OK** to select the photo. A check mark displays on the LCD screen to indicate your action. If you change your mind and want to de-select the photo from printing, press **OK** again; the check mark is removed.



Tip: To select and print all the photos on a memory card or portable USB device which have not yet been selected, hold down the **OK** button for 2 seconds. Holding down the **OK** button again for 2 seconds de-selects all the photos.

5. If you are satisfied with the image shown, you can modify the quantity of copies to be printed by pressing ▲ until the number you want is shown on the LCD screen. To decrease any quantity greater than 1, press ▼ until the number you want displays.
6. If you want to specify different print parameters for the photo, press **Menu** to display the **Print Photos Options** menu. A sample of the menu is shown in the illustration below.



7. Here you can press ▼ until the parameter you want to adjust is selected. If a value is displayed between the ◀ and ▶ symbols in the row, press ◀ or ▶ to select the value you want.
8. Press **Start** to print the selected photo, or press ▲ until **View Photos** is selected.
9. Press ◀ or ▶ until you view another photo you want to print.
10. Repeat this process as needed.

NOTE: Each photo is automatically deselected after it has been printed

Printing tagged images

The Digital Print Order Format (DPOF) is an industry-standard file that can be created by some digital cameras. Camera selected photos are photos you tag for printing with your digital camera. When you select photos with your camera, the camera creates a DPOF file that identifies which photos have been tagged for printing. Your Kodak All-in-One printer can read the DPOF file from the memory card so you do not have to re-select the photos to print.

NOTE: Not all digital cameras support tagging or the creation of tagged image files. Refer to your camera's user guide to ensure it supports this function.

When you print tagged photos, the selected layout is applied unless your camera allows selection of sizes. If not specified by the DPOF information, the current default print photo size and other settings will be used.

Printing from a Bluetooth-enabled device

Bluetooth wireless technology allows wireless connectivity between compatible electronic devices. Your printer allows you to print .jpg images from a Bluetooth-enabled device, using an optional Kodak USB Bluetooth 2.0 USB adapter. You can purchase the Kodak Bluetooth adapter from Kodak at www.kodak.com/go/accessories.

The Kodak Bluetooth adapter (shown below) supports connectivity between your All-in-One printer and the following Bluetooth-enabled devices:



- Mobile camera phones
- Personal Digital Assistants (PDAs)
- Digital still cameras
- Computers

The Bluetooth adapter will not work when plugged directly into computers, Kodak printer-docks, other types of Kodak printers or devices made by other manufacturers. This adapter works exclusively with Kodak All-in-One printers.

To enable Bluetooth wireless connectivity, plug the Kodak Bluetooth adapter into the USB port located on the front panel of your printer.

NOTE: Before you can transmit photos to your printer from a Bluetooth-enabled device, you must first "pair" the printer and the device so that they can communicate. This "pairing" is performed from your device's interface. Review the instructions for pairing that came with your Bluetooth-enabled device, as needed.

When the device is searching for other Bluetooth enabled devices to pair with and if your printer is within range of the device (see [Range](#) below), your printer will appear in the list, with a name starting with **ESP**. (Your device may allow you to rename it, as appropriate.)

If your device prompts you for the printer's personal identification number (PIN) to authenticate and initiate the connection, enter **1111**.

Bluetooth devices do not use a Print command. You must use the device's Send function to transmit an image stored on it to the All-in-One printer. Only one file can be sent from the device at a time. Once received, your printer will print the image automatically using the default settings.

Range

When the device and the printer are connected, you can send photos from your Bluetooth device to the printer. Your printer supports connectivity to one Bluetooth device at a time.

For the highest transfer speed, Kodak recommends keeping a maximum distance of 10 meters (32.8 feet) between Bluetooth devices, as they may not work reliably beyond this range.

Printing multiple photos

When you select a print size that is smaller than the paper size, this printer automatically lays out multiple photos using the least amount of space, minimizing paper waste when separating the photos.

Printing panoramic photos

You can print a panoramic photo on 4 x 12 paper, or two panoramic photos on U.S. letter or A4 paper; some cropping will occur.

Zooming and cropping photos

Your printer enables you to zoom in or out on a specific area of a photo. When you print the photo, the photo is cropped so only the area bounded by the crop boundaries is printed.



CAUTION:

You cannot use the zoom or crop functions of this printer on photos located on a PictBridge camera connected to the printer. All changes made to photos stored on PictBridge camera are conducted on the camera.

NOTE: The changes you make to the photo apply only to viewing and printing the photo, and will not be saved on the memory card or storage device.

1. Select an image from the display. As needed, see [Printing photos from non-PictBridge digital cameras, memory cards, and USB flash drives, page 53](#).
2. As desired, press **Menu** to display the **Print Photos Options** menu. The first option is Print Size. Press the ◀ and ▶ navigation buttons on the control panel to change the size of the output that you want for the image, which will affect the zoom and crop displays. Press **OK** when you are satisfied.

- Press **Zoom +** to enable the zoom and crop function. You can enlarge the photo in .25X increments, up to a 5X magnification. Press **Zoom -** to decrease the magnification in .25X increments, to 1X.




NOTE: The changes you make to the photo apply only to viewing and printing the photo; they are not saved on the memory card or storage device.

- Use the ◀, ▲, ▼ and ▶ navigation buttons on the control panel to display the part of the picture you want to print.
- Press **OK** when finished. The photo is displayed with the original view, and a border ("crop box") is displayed around the area you want to use.



Tip: You can make more precise zoom and crop adjustments to your photos on your computer using photo editing software. To send a photo from the All-in-One printer to your computer, see [Transferring images to a computer](#), page 58.

- If you are satisfied with the image shown, press **Start** to print the area displayed in the crop box. If you want to specify additional print parameters for the photo, press **Menu** to display the **Print Photos Options** menu. A sample of the menu is shown in the illustration below.



- Here you can press ▼ until the parameter you want to adjust is selected. If a value is displayed between the ◀ and ▶ symbols in the row, press ◀ or ▶ to select the value you want.
- Press **Start** to print the selected photo, or press ▲ until **View Photos** is selected. Press **OK**.
- Press ◀ or ▶ until you view another photo you want to print.

10. Repeat this process as needed.

NOTE: If you want to print multiple copies of a photo displayed on the LCD screen, you can press ▲ until the number you want is shown. To decrease any quantity greater than 1 shown, press ▼ until the number you want displays.

Transferring images to a computer

You can transfer .jpg, .mov, or .wav files to your Windows or Macintosh computer from a digital camera, memory card, device connected to your printer via a Kodak Bluetooth dongle, and portable (USB) thumb drive connected to this All-in-One printer.

NOTE: To transfer large files, such as video files, from a memory card to a computer, Kodak recommends using a card reader attached directly to the computer instead of transferring the file(s) via the All-in-One printer.

Likewise, Kodak recommends transferring large groups of image files (400 or more) stored on a memory card to a computer via a card reader connected to the computer.

Transferring images to a Windows computer

1. Connect the device to the appropriate slot on the front panel of your printer.
2. From the control panel press **Menu** to display the **Print Photos** menu on the LCD screen.
3. Press ▼ until **Transfer All to PC** is highlighted, and click **OK**.
4. Press **Start**.
5. Follow the prompt on the computer.

Transferring images to a Macintosh computer

1. Connect the device to the appropriate slot on the front panel of your printer.
2. From the control panel, press **Menu** to display the options on the computer monitor (for a PictBridge camera) or the printer LCD screen (all other devices).
3. Press ▼ until **Transfer All to PC** is highlighted.
4. Press **OK**.
5. Press **Start**.
6. Use iPhoto or Image Capture to complete the transfer.

You can copy both images and documents directly from the control panel of your Kodak ESP All-in-One printer. The printer produces high-quality color or black and-white copies on a variety of paper types, including transparencies

NOTE: Before using your All-in-One printer to copy a document or photo for the first time, review the procedures for loading paper and originals in [Chapter 4, Handling Paper](#).

Simple copying

NOTE: **Copy Document** is the first setting on your Kodak All-in-One printer. This enables you to load a document face-up in the automatic document feeder (ADF) or place a one-page document on the scanner glass, and, if you have no need to change the default quantity, press **Start** from the Main menu to quickly initiate a copying job.

1. Place the original (document or photo) face down at the right front corner of the scanner glass or face up in the automatic document feeder (ADF).
2. From the control panel, press **Menu**.
3. **Copy Document** is the first menu option. As needed, press ▼ to select **Copy Photo**.

Copy Document ◀ 1 ▶

4. Modify the quantity of copies to be printed by pressing ▶ on the control panel until the number you want is between the ◀ and ▶ symbols displayed in the menu. To decrease any quantity greater than 1 shown, press ◀ until the number you want displays.
5. Press **Start** to initiate copying the document or photo.

Adjusting copy settings

You can change the default copy document settings for your printer using the control panel. Depending on whether you are copying a photo or a document, select the appropriate option submenu from the main menu.

1. From the control panel, press **Menu**.
2. **Copy Document** is the first option. As needed, press ▼ to select **Copy Photo**.
3. Press **OK** to display the **Copy Document Options** (or **Copy Photo Options**) menu.
4. You can press ▼ until the option you want to adjust is selected. If a value is displayed between the ◀ and ▶ symbols in the row, press ◀ or ▶ to select the value you want.
5. Any changes you make to the copy settings apply only to the current copy operation unless you save them as your default settings. To keep the settings as permanent, press ▼ until **Save as Defaults** is selected; press **OK**, and then select **Yes** and press **OK** to save the change(s) as the new default settings.

6. Press **Start** to initiate copying the document (or photo).

The available copy settings are shown in the table below:

Copy Document options

Menu Options	View Settings / Select	Settings
Quantity	◀ or ▶	1- 99
Copy Size^a	◀ or ▶	Same size
		20%-500%
Photo Paper Quality		Automatic
Plain Paper Quality^b	◀ or ▶	Normal
		Best
		Draft
Color	◀ or ▶	Color
		Black & White
Brightness	◀ or ▶	-3 to +3
Save As Defaults	OK	

^a Scaling is anchored to the upper left corner of the original.

Same Size The copy is the same size as the original. Cropping occurs if the original is larger than the paper size. The copy will contain white space if the original is smaller than the paper size. **Same Size** is the default copy setting.

Scaling Press ◀ or ▶ to set the scaling for your image.

^b Plain paper quality output:

Draft Produces the fastest print speed, but the lowest quality.

Normal Delivers high-quality output and is the default setting. **Normal** prints faster than **Best**.

Best Produces the highest quality for all paper and eliminates the banding (striping) effect that sometimes occurs in **Draft** and **Normal** modes. **Best** is the slowest print speed. If Kodak photo paper is loaded in the paper tray, this setting is used.

Copy Photo options

Menu Options	View Settings / Select	Settings
Quantity	◀ or ▶	1- 99
Copy Size	◀ or ▶	4x6
		4x7 (High Def)
		4x12 (Panoramic)
		5x7
		8x10
		8.5x11
		(Wallet) 2x3
Photo Paper Quality^a		Automatic
Plain Paper Quality^a	◀ or ▶	Normal
		Best
		Draft
Color	◀ or ▶	Color
		Black & White
Brightness	◀ or ▶	-3 to +3
Preview	◀ or ▶	No
		Yes
Save As Defaults	OK	

^a You need to specify a quality only for plain paper. If photo paper is loaded in the paper tray, the printer will output the best available quality using the **Automatic** setting. To review the settings for plain paper copying, see “Plain Paper Quality” under [Copy Document options, page 60](#).

Scanning converts text and images from documents and pictures placed on the scanner glass into electronic data, and then sends the data to your computer. To scan using the ESP 9 All-in-One printer, the printer must be connected to a computer. You can scan to the following destinations:

- Kodak Home Center
- Memory card or USB flash drive connected to the printer using the appropriate opening on the front panel of the computer
- Third-party scanner software application
- As a file on your computer

Before you start

Before you start scanning with this All-in-One printer, Kodak recommends that you use the Home Center software to configure the default scan settings. This way, you can easily manage the scan in your computer. See [All-in-One printer Home Center software, page 19](#) for additional information.

Using the Home Center software, you can adjust the following default settings for scanned photos and documents:

- Applications used for file destination(s).



CAUTION:

If you save a document scan to an application, the scan cannot be later accessed by optical character recognition (OCR) software. If you want to be able to edit the text of the document after scanning it, save the scanned document as a file.

- File type used to save the scan.
 - The default setting for saved documents is .pdf (Portable Document Format). With third-party .pdf viewer software installed, this type of file can be viewed on Web pages or computers. You may also save a scanned document as .rtf (Rich Text Format). This is a standard file type which can be opened and edited in standard word-processing software applications.
 - The default setting for image files is .jpg (Joint Photographic Experts Group) format. This standard file type can be opened and edited in standard image editing software applications, and can be viewed on Web pages.
- File storage location for saved scans.
 - Windows: Document scans are saved by default in the My Documents folder, and images are saved in the My Pictures folder. They are stored by default in these locations in a folder titled with the current date.
- Rule for naming scan files.
 - By default, scans are named "scan1", "scan2", etc.
- Default scan resolution and photo enhancement preferences.
- Color or black-and-white (Windows only).

- Print quality for scanning documents.

Before initiating a scan, you can also preview the scan in Home Center, and crop the output as desired. When you are satisfied with the intended results, you can initiate the scan directly from Home Center. See Home Center Help for instructions. To review how to access Home Center help, see [All-in-One printer Home Center software, page 19](#).

Scanning with Macintosh computers is accomplished by using the twain driver available with your Kodak software. Scanning is supported with any twain-enabled software application.

Simple scanning

Simple document scans

1. Place the original document at the right front corner of the scanner glass.
2. From the control panel, press **Menu**.
3. Press ▼ until **Scan** is selected. Press **OK**.
4. Press ▼ until **Scan To** is selected. Note that, if your printer is connected to a local computer, the default setting is **USB Connected Computer**. If you are connected to a network, all of the available computers are listed in alphabetical order.
5. Note that the default **Scan What** setting is **Document**.
6. Press ▼ until **Scan Destination** is selected. As needed, press ◀ or ▶ to specify which application on the computer will open the file. Kodak Home Center software appears on the list by default.
7. Press **Start**.
8. When the Scanner dialog window displays on your computer, follow the prompts to finish the scanning process.

Simple image scans

1. Complete Steps 1–4 from [Simple document scans](#) above.
2. Press ▼ until **Scan What** is selected. Press ▶ to specify **Photo**.



CAUTION:

Although you can scan a document using the Photo option and save it as an image (.jpg) file, you will not be able to edit the text later in your computer. If you want to edit a scanned document later, make sure that you scan it as a Document, not as a Photo.

3. Complete Steps 6–8 from [Simple document scans](#) above.

Scanning multiple originals simultaneously

When the **Scan What** option is set to **Photo** in the Home Center software, your

All-in-One printer can detect multiple photos placed on the scanner glass. Allow some space on the scanner glass between each item, and use the Home Center software to save each photo as a separate file. Any images on the scanner glass that overlap are interpreted by the software as a single image file.




CAUTION:

Home Center cannot interpret two or more documents, photos, or a combination of documents and photos, as separate scanned items when the Scan What option is set to Document.

Adjusting scan settings

You can change the default scan settings for your printer using the control panel. When you change scan settings from the control panel, the settings apply only to the current scan job. To apply scan settings to all future scan jobs, you can save your changes.

1. From the control panel, press **Menu**.
2. Press ▼ until **Scan** is selected.
3. Press **OK** to display the **Scan Options** menu. A sample of the menu is shown in the illustration below.



4. Here you can press ▼ until the option you want to adjust is selected. If a value is displayed between the ◀ and ▶ symbols in the row, press ◀ or ▶ to select the value you want.
5. Any changes you make to the scan settings apply only to the current scan operation. To keep the settings as permanent, press ▼ until **Save as Defaults** is selected, and then press **OK**.
6. Press **Start** to initiate the scan.

The available scan settings are in the following table:

Scan options

Menu Options	View Settings / Select	Settings
Scan What^a	◀ or ▶	Document
		Photo
Scan To^b	◀ or ▶	Computer
		Memory Card
Scan Destination^c	◀ or ▶	File
		[Application Name]
Save As Defaults	OK	

^a If you select **Document** and save the scan to a **File**, the scan is saved as a document (.pdf or rtf) file, even if the original is a photo. If you select **Photo**, a text document will be scanned as an image file, and cannot be read by optical character recognition (OCR) software.

^b If your printer is connected to a network, more than one computer name will appear in this list. If your printer is connected to a printer by the USB cable, the computer name in the menu is called **USB Connected Computer**.

^c You must create a list of one or more applications using Home Center software for any to display by name in the **Scan Destination** settings. Each application will appear as a separate setting in the display. (Kodak Home Center software is displayed by default; you do not need to configure your destinations to include it.)

In addition, before using a **Scan Destination** setting of **File**, familiarize yourself with the location where the files will be saved and with the file naming setting. This will prevent problems later in finding the scan file on your computer.

Introduction

Your Kodak ESP 9 All-in-One printer allows you to send and receive faxes (including color faxes), assign and use quick dial settings for frequently used fax recipients, and select a number of fax options from the control panel.

NOTE: On a Windows PC connected to the All-in-One printer, you can create and manage the Fax Phonebook using Home Center software. See Home Center Help for more information. Home Center software is discussed in [All-in-One printer Home Center software, page 19](#).

This feature is also available from Home Center software on a Macintosh.



CAUTION:

Faxing only receives and transmits single-sided documents.

Fax settings

Configuring the ESP 9 to send and receive fax transmissions is discussed in [Chapter 3, Setting Up Your Printer](#).

Sending faxes

Your printer provides three ways to send faxes. Use the procedure described below that best meets your needs:

If you want to send a fax to...	Use this procedure:
Someone not listed in your Fax Phonebook	Dialing a fax number on the control panel , below.
An entry listed in your Fax Phonebook	Selecting a fax recipient from the fax phonebook , page 67.
A Fax Phonebook entry assigned a Quick Dial number	Using quick dial to select a fax phonebook entry , page 68.




Tip: To hear sounds as your printer dials the recipient's fax number and transmits fax tones to the recipient's fax machine, make sure that **Fax Speaker** is set to ON in the Fax Settings menu. For more information about available settings, see [Setting up the fax, page 34](#). To review how to use fax auto-answer with an answering machine, see [Specifying rings to answer, page 40](#).

Dialing a fax number on the control panel

1. Load the original (plain paper only) in the automatic document feeder (ADF) or the scanner glass. See [Loading an original for faxing, page 49](#).
2. From the control panel, press **Menu**.
3. Press ▼ to select **Send Fax**.
4. Enter a number on the number keypad using the correct fax number for the recipient.

The number displays on the LCD screen, as shown in the illustration below.




NOTE: The Send Fax menu will display all Fax Phonebook (fax **Number** and **Quick Dial** entries) names that match the string of numbers you press on the number keypad. For example, if you press **123**, the LCD screen displays all entries starting with **123**.

5. Press **Start** to send the fax.

Selecting a fax recipient from the fax phonebook


1. Load the original. As appropriate review [Preparing a fax for transmission, page 72](#).
2. From the control panel, press **Menu**.
3. Press ▼ to select **Send Fax** and then press **OK**.

The list of Fax Phonebook entries displays in the Send Fax menu. The last Fax number selected is shown above the **Fax Options** menu. See the example, below.



4. To use the last fax number used, press **Start** now. Otherwise, press ▼ until the desired recipient is selected, and then press **OK**.

The Fax phone number of the selected entry displays in the menu header, replacing any previous number. See the illustration below.



5. Press **Start** to send the fax.

Using quick dial to select a fax phonebook entry

By assigning up to ten contacts in your Fax Phonebook with a number between 0 (zero) and 9, the Quick Dial feature in your ESP 9 All-in-One printer allows you to create shortcuts for quickly sending Faxes to them

NOTE: To configure a fax recipient as a Quick Dial entry, review [Fax Phonebook entries, page 71](#).


There are two ways to use the Quick Dial feature for sending faxes.

Specifying a quick dial recipient from the keypad

1. Load the original. As appropriate, review [Preparing a fax for transmission, page 72](#).
2. From the control panel, press **Menu**.
3. Press ▼ to select **Send Fax** and then press **OK**.
4. Select the appropriate key on the control panel's keypad associated with the Quick Dial entry, and then press **Start**. For example, press **8** to specify the entry assigned the Quick Dial value of "08." See the illustration below.



The **Send Fax** menu displays the Fax phone number of the Quick Dial entry on the LCD screen. The Quick Dial entry is highlighted (selected) on the LCD screen. See the illustration below.




5. Press **Start** to send the fax.

Specifying a quick dial recipient from the send fax menu

1. Load the original. As appropriate, review [Preparing a fax for transmission, page 72](#).
2. From the control panel, press **Menu**.
3. Press ▼ to select **Send Fax** and then press **OK**.

The list of Phonebook and Quick Dial entries displays in the **Send Fax** menu. The last Fax number used displays in the header, above the first row, as shown below.




4. To use the last fax number used, press **Start** now. Otherwise, press ▼ until the desired recipient is either shown in the display or is selected.
5. Use one of the following methods to specify a Quick Dial recipient:
 - a. Press the Quick Dial number on the keypad, and then press **Start**. For example, press **8** to specify the entry assigned the Quick Dial value of "08." See the illustration below.



- b. Press **OK** to accept the selected value, and then press **Start**.

The Fax number of the recipient display on the LCD screen, and the row representing the entered Quick Dial entry is selected in the display, as shown in the illustration below.



Canceling faxes

To abort a fax after dialing the number, press **Cancel** from the control panel.

Receiving faxes

If you use your All-in-One printer to receive faxes, remember to load the bottom paper tray with paper beforehand.

If you set Fax Auto-Answer **Off**, you will need to receive faxes manually. See below.

Each fax will be printed once it has been received. A Fax Confirmation page will be printed if setting is enabled. See [Fax reports, page 75](#).

Receiving faxes automatically

To receive faxes automatically, see [Setting up the fax, page 34](#).

Manually receiving faxes

When you hear the phone ring and want to receive a fax, press **Start** on the control panel.

NOTE: If the phone used to receive faxes uses a voice-messaging service provided by your telephone service provider, you may not be able to receive faxes automatically. Review [Setting up the fax, page 34](#). Contact your telephone company for additional information as needed.

Fax Phonebook entries

The Fax Phonebook stores information about frequently used fax recipients, including name (or other word or phrase, such as a title, used to identify the recipient), fax phone number, and Quick Dial value.

This section describes managing the Fax Phonebook from the control panel. Windows users can manage the Fax Phonebook from Home Center software; see [All-in-One printer Home Center software, page 19](#).

Adding a new Fax Phonebook entry

1. From the control panel, press **Menu**.
2. Press ▼ to select **Send Fax** and press **OK**.

NOTE: This option is also accessible by selecting **Edit Phonebook** from the Fax Settings menu.

3. Select **Fax Options** and press **OK**.
4. Select **Edit Phonebook** and press **OK**.
The Edit Phonebook menu displays on the LCD screen.
5. Press ▼ to select **Add New Entry** and press **OK**.
6. If the fax number field fails to display automatically on the LCD screen, press **OK** to select the **Number** field in the Edit Phonebook Entry menu.
The number field is highlighted.
7. Using the keypad on the control panel, enter the fax number in the field displayed on the LCD screen and then press **OK**.
8. When you are finished entering the fax phone number, press **OK**.
9. Press ▼ to select **Name** and press **OK**.
10. Using the LCD screen on-screen keyboard, enter a name for the recipient.
 - Notice the **abc/123** key is highlighted. As needed, press **OK** to display the **ABC/123** key. Toggle between these two keys by pressing **OK** as needed.
 - Here, press ▲, ▼, ◀ or ▶ to select a key. Use the **BKSP** key to erase an incorrect entry. Select the **Done** key when you are finished, and then press **OK**.
11. To assign a Quick Dial number to this name, press ▼ to select highlight **Quick Dial** and press **OK**.
12. Enter a number between 0 and 9 on the keypad on the control panel, and then press **OK**.
13. Press ▼ to select **DONE** when the entry is complete, and press **OK**.
14. To continue to add entries to the Fax Phonebook, repeat this procedure.

Editing an existing Fax Phonebook entry

1. From the control panel, press **Menu**.
 2. Press ▼ to select **Send Fax** and then press **OK**.
- NOTE: This option is also accessible by selecting **Edit Phonebook** from the Fax Settings menu.
3. Select **Fax Options** and press **OK**.
 4. Select **Edit Phonebook** and press **OK**.
- The Edit Phonebook menu displays on the LCD screen.
5. Press ▼ to select **Edit Entry** and press **OK**.
 6. Press ▼ to select the desired Phonebook entry and press **OK**.
 7. Select the field you want to edit, and press **OK**.
 8. Using the LCD screen keyboard or the control panel keypad, edit the entry as needed. Select **Done** on the LCD screen keyboard to indicate that you are finished using it.
 9. Select **Done** when the entry is complete, and press **OK**.
 10. Select another item to edit, or press **Cancel** to display the **Edit Phonebook** menu.

Deleting an existing Fax Phonebook entry

1. From the control panel, press **Menu**.
 2. Press ▼ to select **Send Fax** and then press **OK**.
- NOTE: This option is also accessible by selecting **Edit Phonebook** from the Fax Settings menu.
3. Select **Fax Options** and press **OK**.
 4. Select **Edit Phonebook** and press **OK**.
 5. Press ▼ to select **Delete Entry** and press **OK**.
 6. Press ▼ to select the desired Phonebook entry and press **OK**.
 7. Follow the prompts displayed on the LCD screen, and press **OK** to delete the entry displayed or cancel to go back to select an entry to delete.
 8. Select **Done** when the entry is complete, and press **OK**.
 9. Select another item to edit, or press **Cancel** to display the **Edit Phonebook** menu.

Preparing a fax for transmission

Before sending a fax, load the original (plain paper only) print side up in the automatic document feeder (ADF). See [Loading an original for faxing, page 49](#).

**CAUTION:**

Never load photo paper into the automatic document feeder (ADF) on the ESP 9; the ADF only accepts plain paper. If you load photo paper in the ADF, the printer displays a warning on the LCD screen, and will not send the Fax.

Printing a fax cover page

If you do not create a fax cover sheet using a third-party application (for example, word-processing software), you can print one with the ESP 9 All-in-One printer.

1. Before sending your Fax, press **Menu** from the control panel.
2. Press ▼ to select **Fax. Settings** and press **OK**.
3. Press ▼ to select **Print Fax Cover Page** and press **OK**.
4. Load 8.5x11 or A4 paper as needed, and then press **Start**.

The printer produces a Fax cover sheet, which provides space for entering the following:

- Information about the recipient (company, Fax number, recipient name)
 - Information about the sender (company, Fax number, phone number, sender name)
 - Number of pages in the Fax, including the cover page
 - Message to the recipient
5. Complete the items on the cover sheet as appropriate.
 6. Place the Fax Cover Sheet before the first page of the original document used for your fax transmission.
 7. Use one of the following procedures to send the fax:
 - [Dialing a fax number on the control panel, page 67](#)
 - [Selecting a fax recipient from the fax phonebook, page 67](#)
 - [Using quick dial to select a fax phonebook entry, page 68](#)

Changing send fax settings

If, before sending your fax, you want to modify any fax settings, you can use the Send Fax Options menu now.

1. From the control panel, press **Menu**.
2. Press ▼ to select **Send Fax** and then press **OK**. **Fax Options** is selected by default.
3. Press **OK** to display the Send Fax Options menu.
4. Press ▼ to select an item you want to change.

- To change the **Resolution**, **Color** or **Brightness** items, press the ◀ or ▶ buttons on the control panel to change the value for the setting; then press **OK**.
 - If you select **Edit Phonebook**, press **OK**. See [Fax Phonebook entries, page 71](#) to review the procedure for adding, editing, or deleting a Fax Phonebook entry. When you are finished, press **Menu** to return to the Send Fax Options menu.
 - Any changes you make in the Edit Phonebook menu are saved when you complete each entry.
 - Any changes you make to the fax settings apply only to the current fax operation.
5. If you want to save the changes as default settings, press ▼ to select **Save as Defaults** and then press **OK**.
 6. If you have not created a fax cover page, you can do so before sending your fax. See [Printing a fax cover page, page 73](#). Otherwise, use one of the following procedures to send the fax:
 - [Dialing a fax number on the control panel, page 67](#)
 - [Selecting a fax recipient from the fax phonebook, page 67](#)
 - [Using quick dial to select a fax phonebook entry, page 68](#)

Send Fax options

The available fax settings are shown below:

Menu Options	View Settings / Select	Settings
Edit Phonebook	OK	Add New Entry
		Edit Entry
		Delete Entry
Resolution	◀ or ▶	Standard
		Fine
		Photo
Color	◀ or ▶	Color
		Black & White
Brightness	◀ or ▶	-3 to +3
Save As Defaults	OK	

Fax reports

The following reports are available from the Fax Settings menu:

Fax report name	Contains:	To print:
Print Fax Confirmation Page	Details about faxes, one fax at a time, based on the menu setting.	Set the value for this option to Never , Always , or After Failure Only in the Fax Settings menu on the LCD screen. ^a NOTE: This report cannot be run from the control panel; it is generated automatically only after sending a fax, and only based on the setting.
Fax Settings	Information about the printer and a summary of the current fax settings for the device. See Fax Settings options, page 42 .	Press OK to select, then press Start .
Fax Activity Log	Details about the last 30 faxes sent and received.	Press OK to select, then press Start .

^a The printer also generates a **Fax Lost Job report**, which contains details about the time, date, and fax number. This option is NOT available as an option in the Fax Settings menu. Rather, if a fax was not received because your printer lost power (for instance, due to an electrical power outage), the printer automatically generates a Fax Lost Job report when power returns to the printer (and it is turned on). This feature allows you to notify the sender(s) about any fax that could not be received due to loss of power, and you can request re-transmission, as appropriate.

Printing a fax report

1. Load 8.5x11 or A4 paper into the bottom paper tray, as needed.
2. From the control panel, press **Menu**.
3. Press ▼ to select **Fax Settings** and press **OK**.
4. Press ▼ to select **Print Fax Confirmation Page** and press **OK**.
5. As appropriate, press ◀ or ▶ to change the **Print Fax Confirmation Page** setting.

NOTE: This report cannot be run from the control panel; the ESP 9 will output this report only after you send a fax, and only based on the setting. If you change this setting, press **OK** to save the setting, and then press **Cancel** to exit the Fax Settings menu, or you can continue (see Step 5).

6. Press ▼ until the desired report (**Print Fax Settings** or **Print Fax Activity Log** only) is selected.

NOTE: The option to **Print Fax Cover Page** is also available in the Fax Settings menu; see [Printing a fax cover page, page 73](#).

7. Press **OK** to select the option, and then press **Start** to print the report.

Maintaining Your Printer

Your Kodak ESP 9 All-in-One printer requires little maintenance. However, Kodak recommends cleaning the scanner glass and lid backing regularly to remove dust and fingerprints. Fingerprints and other debris on the glass or lid backing could slow down the printer's performance, and affect the quality and accuracy of scanning.

Service agreements are available in some countries. Contact dealers for Kodak products for more information.

For recycling and/or disposal information, contact your local authorities. In the U.S., visit the Electronics Industry Alliance Web site at www.eiae.org.

General care



CAUTION:

Always disconnect the power on the this All-in-One printer before cleaning it. Do not use harsh or abrasive cleaners or organic solvents on the printer or any of its parts.

- To clean the printer, wipe the outside with a clean, dry cloth.
- Keep the surrounding area vacuumed and litter-free.
- Protect the printer from tobacco smoke, dust, sand, other small particles (such as crumbs), and liquid spills.
- Avoid placing objects on the printer.
- Keep the printer supplies away from direct sunlight and out of high-temperature environments.
- Do not allow chemicals, such as suntan lotion, to come into contact with the painted surface of the printer.
- If the printer has been exposed to bad weather or has water inside it, turn it off and let it dry completely. If this does not solve the problem, contact customer support (see [Contacting Kodak Customer Service & Support, page 2](#)).

Cleaning the scanner glass

For good copies and scans, ensure the printer's scanner glass and lid backing are clean; dust the exterior as needed.



WARNING: Do not use abrasives, acetone, benzene, or carbon tetrachloride on the glass, as they can damage it. Do not place or spray liquid directly on the glass. The liquid might seep under the glass and damage the device.

1. Unplug the printer and raise the lid.



2. Clean the glass with a soft cloth or sponge slightly moistened with a nonabrasive glass cleaner.
3. Dry the glass with a lint-free cloth.
4. When finished cleaning, plug in the printer.

Cleaning the scanner lid

Minor debris can accumulate on the document backing located underneath the scanner lid of the Kodak printer.



WARNING: Do not use paper-based wipes, as these might scratch the underside of the scanner lid. Do not use harsh or abrasive cleaners or organic solvents on the printer or any of its parts.

1. Unplug the printer and raise the lid.



2. Clean the underside with a soft cloth or sponge, slightly moistened with a mild soap and warm water.
3. Wipe the underside gently to loosen debris. Do not scrub.
4. Dry the underside with a chamois or soft cloth.

5. If further cleaning is needed, repeat the previous steps using isopropyl (rubbing) alcohol, and wipe the underside thoroughly with a damp cloth to remove any residual alcohol.
6. When finished cleaning, plug in the printer.

Monitoring and adjusting the printer's performance

From the control panel, you can perform many tasks to keep this printer in good working order. For example, you can check the status of the printer's inkjet nozzle to ensure high-quality prints. Kodak recommends that you run a nozzle check if you are experiencing changes in image quality. You can also use the **Printhead Alignment** function if you see degradation in print quality.

1. Make sure that there are 5-10 sheets of plain paper loaded in the bottom paper tray.
2. Press **Menu** to display the main menu.
3. Press ▼ until **Maintenance** is selected.
4. As needed, press ▼ until the desired option is selected.
5. Press **OK**.
6. Follow the prompts on the LCD screen to initiate or cancel the task.

These available maintenance options are shown in the following table.

Maintenance options

Menu Options	Select
Check Ink Levels	OK
Check Paper Levels	OK
Nozzle Check	OK
Printhead Alignment	OK
Clean Printhead	OK
Print Test Page	OK
Format Memory Card	OK



WARNING: Formatting will erase all the data on a memory card.



Tip: A printhead alignment and a check of the inkjet nozzle can also be initiated from the Home Center software.

Windows: Open the Home Center Help panel by clicking Help  on the Home Center window, as needed. Click **Maintenance**, and then click **Nozzle Check** or **Printhead Alignment**.

Macintosh: Open Home Center window from the dock, and click **Maintenance**, and then click **Nozzle Correction** or **Printhead Alignment**.

Replacing ink cartridges

Your Kodak printer uses separate black and color ink cartridges. The ink levels are shown on the control panel and in the printer software.



CAUTION:

For the best quality prints, store ink cartridges in locations where the temperature does not exceed 85°F (30°C).




WARNING: Use genuine Kodak ink cartridges to ensure best results and avoid printhead damage not covered under warranty. Third-party ink cartridges may not work with your printer.


1. Make sure the printer is turned on.
2. Open the printer access door by lifting from the recessed hand-holds on the sides of the unit.



The printhead moves to an accessible position for handling the ink cartridges. The ink cartridges are seated in the printhead.



3. Wait until the printhead stops moving, and then pinch the latch on the old ink cartridge with your thumb and forefinger and lift it out of the printhead.



NOTE: You can take your used ink cartridges to most office supply or electronics stores for safe disposal.

4. Open the box containing the new ink cartridge.


5. Remove the bagged ink cartridge from the box, tear open the bag at the notch, and remove the ink cartridge.




CAUTION:

Insert the ink cartridge immediately to prevent any drying of the ink.


6. Remove the orange cap from the cartridge by grasping the top edge and pulling/rotating it off the ink cartridge. Discard the orange cap.



7. Insert the ink cartridge into the printhead.



8. Press down on the tab until you hear a click and feel the latch snap into position.



NOTE: Listen carefully during this step; make sure you hear the ink cartridges click into place in the printhead. This seats the cartridges properly, and prevents ink from being dispensed incompletely during your print or copy jobs.

9. Close the printer access door. The printhead moves to its ready position and prepares the new ink cartridge for use (this could take up to a minute).


Replacing the printhead

If your printhead is damaged or broken, you may replace it yourself.


1. Make sure your printer is turned on.
2. Open the printer access door by lifting from the recessed hand-holds on the sides of the unit.



The printhead moves to an accessible position for handling the ink cartridges. The ink cartridges are seated in the printhead.




3. Pinch the latch on the ink cartridge with your thumb and forefinger and lift it out of the print head. Remove both ink cartridges.




CAUTION:

Insert the ink cartridges into the newly installed printhead as soon as possible to prevent any drying of the ink.

4. Unlatch the printhead by lifting the rectangular latch on the top of the printhead.



5. Remove the old printhead from the carriage.



6. Remove the new printhead from its bag.







CAUTION:

Do not touch copper contacts on the printhead, as this may damage it.


7. Remove and discard the black plastic casing and the orange protective cap.




8. Place the new printhead into the carriage.



9. Push firmly against the target label on the printhead until you hear it click into place.



10. Reinstall the ink cartridges. As needed, see [Replacing ink cartridges, page 79](#).



Listen carefully during this step; make sure you hear the ink cartridges click into place in the printhead. This seats the cartridges properly, and prevents ink from being dispensed incompletely on your print or cop jobs.

11. Close the printer access door. The printer should now complete a printhead calibration to ensure that it is ready for normal operation.

Upgrading the printer software - for Windows

You can upgrade the software and firmware for in your All-in-One printer with the most recent release available. This requires an Internet connection.

NOTE: The firmware cannot be upgraded when your All-in-One printer is connected via a network or Wi-Fi. Your All-in-One printer must be connected to the computer with a USB cable in order to perform a firmware upgrade.

1. If your connection is via Ethernet, disconnect the Ethernet cable. If your connection is via Wi-Fi, press **Menu**. Navigate to **Network Settings** menu and press **OK**. Select **WIFI Radio off**.
2. Connect the printer to the computer with a USB cable. The computer must be connected to the internet.
3. A pop-up window appears at the bottom right corner of your computer monitor stating "Found New Hardware KODAK ESP 9 AIO," then it will change to "Found New Hardware. Your new hardware is installed and ready to use."
4. Open the Kodak AiO Home Center.
5. Click the **Help** button to open the Help Panel.
6. Under the General Links, click **Maintenance**. If there is an update available, you will receive a pop-up window or you can click on **Firmware Upgrade**.
7. Click **OK** to upgrade. The printer software will begin to load. Do not turn off your printer while the update is in progress.
8. When the update is complete click **OK**.
9. Close the maintenance window. The printer firmware is updated.
10. Next you will update the Home Center software, as well as the printer and scanner drivers.
11. Under the **Web Links** on the Help Panel, click on **Check for updates**.
12. If an update is available, download it to your computer.
13. When the update is complete, disconnect the USB cable and reconnect your printer to the Ethernet or Wi-Fi network.
14. Use the **Windows Control Panel** to delete the printer from your computer. The USB printer is named: Kodak ESP9 AiO. This will remove the USB drivers.

Upgrading the printer software - for Macintosh



You can upgrade the software and firmware for your All-in-One printer with the most recent release available. This requires an Internet connection.

NOTE: The firmware cannot be upgraded when your All-in-One printer is connected via a network or Wi-Fi. Your All-in-One printer must be connected to the computer with a USB cable in order to perform a firmware upgrade.

1. If your connection is via Ethernet, disconnect the Ethernet cable. If your connection is via Wi-Fi, press **Menu**. Navigate to **Network Settings** menu and press **OK**. Select **WIFI Radio off**.
2. Connect the printer to the computer with a USB cable. The computer must be connected to the internet.
3. Open a browser window and enter the following URL:
<http://www.kodak.com/go/aiosupport>.
4. Select your printer model.
5. Under **Downloads**, select **Software Driver and Firmware Downloads**.
6. Select your operating system from the drop down list.
7. Download the software.
8. Double-click on the *.dmg file.
9. Double-click on **Install Software**.
10. Follow the on-screen prompts on the installer.
11. Upon completion of the install, click **Restart**. The Home Center software and the printer and scanner drivers are updated.
12. Next you will update printer firmware.
13. Open a browser window and enter the following URL:
<http://www.kodak.com/go/aiosupport>.
14. Select your printer model.
15. Under **Downloads**, select **Software Driver and Firmware Downloads**.
16. Select your operating system from the drop down list.
17. Download the firmware.
18. Double-click on the *.dmg file.
19. Double-click on **Kodak AiO Updater**.
20. Upon completion of the install, click **Quit**. The printer firmware is updated.

Troubleshooting “quick start”

Kodak provides several methods to help you troubleshoot your All-in-One printer issues. Here are some quick tips:

- Turn off your printer and then unplug it. Wait five seconds, and then plug the power cord back into the printer. Finally, turn the printer back on.
- Confirm that you are using a 2.0 USB cable to connect the printer to your computer. If you need to buy one, they are available online at www.kodak.com/go/aio, or from your local electronics and printer retailer.
- Make sure that you have the most up-to-date All-in-One printer software and Help files from the Internet. Visit www.kodak.com/go/support to download the latest files.
- View the troubleshooting information found in Kodak Home Center software on your computer. After opening Home Center, click the question mark (?) button:
 - **Macintosh:** The  button is located at the lower-left of the Home Center window.
 - **Windows:** The  button is located at the upper-right of the Home Center window.Use the Help window to view troubleshooting topics. (Windows users can also select **Troubleshoot** from the Help panel on the main Home Center window.)
- You can also get troubleshooting help at the Kodak Web site. Visit www.kodak.com/go/support for support for your Kodak printer.

NOTE: Many issues with degradation in performance or print quality can be resolved by meeting or exceeding the recommended system requirements. See [Chapter 11, Product and Safety Specifications](#).

General troubleshooting

Printer fails to power on

Probable Cause

The power supply is not properly connected.

Corrective Action

- Make sure the electrical power cord is connected to the alternating current power adapter, and is plugged into a grounded power outlet or power strip.
- If using a power strip, make sure it is turned on.
- If using a switched power outlet, make sure the switch is on.
- Make sure the power outlet is supplying power.
- Verify the light on the Kodak printer power cord plug is lit.

Probable Cause 2

The USB cable was unplugged from the printer and then reconnected; or, power to the printer is interrupted.

Corrective Action

Restart the computer.

Probable Cause 3

The USB cable is not 2.0 compliant.

Corrective Action

1. Replace the USB cable with a USB 2.0 compliant cable.

NOTE: For optimal quality and performance, use a good-quality high speed USB 2.0 cable. When connecting to the Kodak All-in-One printer, use the USB ports located in the back of the computer. Any USB 2.0 hubs that are used should be self-powered.

2. Restart the computer.

If none of the above corrects the problem, contact Kodak support.

Device not recognized

Probable Cause

Any of the following can prevent your Kodak All-in-One printer from reading a connected device (digital camera, USB drive, or memory card).

- The camera is turned OFF.
- The USB connector on a USB drive is not fully inserted into the USB port.
- The memory card is not completely inserted, or is not inserted into the correct card slot.
- The file system on the device is corrupt.
- More than one device is inserted at a time.
- The USB device is not supported.
- The USB cable is faulty.

Corrective Action

- Correct any connection problems and try again.
- If the file system is corrupt, reformat it.
- Disconnect the unsupported device.

NOTE: If the USB drive uses an NTFS or HFS formatting system, the printer may not be able to read it. Macintosh users may need to transfer these files directly to their computer, and then print to the printer from there.

Ink cartridge not recognized

Probable Cause 1

The color or black ink cartridge installed was not recognized.



WARNING: Generic or non-Kodak ink cartridges may not function with the All-in-One printer. Kodak recommends using genuine Kodak ink cartridges.

Corrective Action

Install a genuine Kodak ink cartridge.

Probable Cause 2

One of the ink cartridges needs to be replaced.

Corrective Action

Replace the ink cartridge.

Multiple paper feed

Probable Cause

Multiple sheets of paper were pulled through the printer.

Corrective Action



CAUTION:

Kodak Inkjet paper is recommended for your Kodak All-in-One printer.

1. Remove the paper from the paper tray.
2. Carefully "fan" the paper to keep the sheets from sticking together.
3. Reload the paper tray. Do not overfill.
4. Press **OK**.

Multiple pictures not scanned properly

When scanning or copying, the Kodak printer can detect multiple images on the scanner glass, straighten them, and create individual files. If you are having trouble with this feature, check the following:

Probable Cause

Your photos are not placed optimally on the scanner glass.

Corrective Action

- Make sure that your photos do not overlap.
- Place photos away from the edges of the scanner glass.
- Some images do not scan well. Light-colored images may not be detected as separate images.
- You may need to make adjustments to the scanning area using the Preview feature in the Kodak Home Center.

Probable Cause 2

The scanner glass is dirty.

Corrective Action

Make sure the scanner glass is completely clean or the photos might not scan properly (see [Cleaning the scanner glass, page 76](#)).

Probable Cause 3

The scanner lid is dirty.

Corrective Action

Clean the scanner lid (see [Cleaning the scanner lid, page 77](#)).

Probable Cause 4

The **Scan What** ◀ **Document** ▶ option on the Scan menu was selected, instead of the **Scan What** ◀ **Photo** ▶ option.

Corrective Action

Scan the photos again in the appropriate format.

No communication with computer

Probable Cause

Your Kodak printer is not connected to your computer.

Corrective Action

- Make sure your printer is plugged in and turned on.
- Make sure you are using the proper USB cable (USB 2.0).
- If you are using a USB hub to connect the USB cable to the computer, make sure that it has power. Use a self-powered (connected to an electrical outlet) USB hub instead of one that uses the computer's internal power.
- Check the connection from your computer to your printer. Ensure that the square end of the USB cable is plugged in to the USB port on the back of your printer, and the flat end into a USB port on your computer.
- You may need to disconnect other printers or scanners from your computer.
- After checking connections, restart your computer.
- Make sure your computer meets the minimum system requirements, otherwise upgrade your system if necessary.

For more information on connecting your printer to your computer, see the "Start Here" booklet that came with your printer.

No paper feed

Probable Cause

The paper tray may be empty, or there may be a problem with the paper in the tray.



CAUTION:

Kodak Inkjet paper is recommended for your Kodak All-in-One printer.

Corrective Action

If the tray is empty, load paper into the paper tray, then resume printing. Check for a message from the printer status monitor (Windows) or the printer queue window (Macintosh) on your computer. Check for a problem with the paper in the tray.

To check the paper

1. Inspect the paper and make sure no paper sheets are damaged in any way. Reload with new paper, if necessary.
2. Carefully “fan” the paper to keep the sheets from sticking together.
3. Reload the paper tray. Do not overfill.
4. Press **OK**.

One or more of the colors on the calibration sheet is missing

Probable Cause

The printhead is not installed correctly. If the printhead has been working properly, it may have come loose.

Corrective Action

If the printhead has come loose:

1. Open the printer access door, and then remove the black and color ink cartridges.
2. Press the printhead release button.
3. Lift the printhead out.
4. Reinsert the printhead and ink cartridges.

NOTE: See [One or more of the colors on the calibration sheet is missing, page 93](#) for illustrated instructions for performing this procedure.

If this does not resolve your printing issue, contact Kodak Service and Support.

Paper jam

Probable Cause

The paper did not advance, was not picked up properly from the paper tray, or is lodged inside the printer.



CAUTION:

Kodak Inkjet paper is recommended for your Kodak All-in-One printer.

Corrective Action

1. Remove the paper from the tray you used when the jam occurred.
2. Turn off the printer.
3. Open the rear access area and pull the paper out from the rollers without tearing it.



CAUTION:

If the paper tears while removing it, make sure you remove all the torn pieces. More jams are likely to occur when torn pieces are left in the printer.

4. Reload the paper tray, but do not overfill it.
5. Turn the printer on.
6. Press **OK**.

Printer not responding

Probable Cause

The firmware or software is not in a ready state.

Corrective Action

- Turn the printer off and turn it back on.
- If the problem persists, unplug the power cord from the power supply and plug it back in.
- If the problem continues to persist, restart your computer.

Transfer pictures failure

Problem

Nothing happens when you try to transfer photos to the computer.

Corrective Action

- Remove the memory card or USB device and reinsert it.
- Check the power connection to the computer.
- If you are trying to transfer photos from a memory card and a PictBridge camera is connected, disconnect the camera.
- Close any unnecessary software applications, and minimize any remaining application windows. Follow any messages on the screen that may have been hidden by other windows.
- Disconnect, then reconnect the USB cable from the printer to the computer.
- Make sure you are using a high-quality USB cable which is communicating with the computer. (See [No communication with computer, page 92.](#))

- If the pictures are on a USB device, make sure it uses a supported file system (see [Device not recognized, page 90](#)).
- Make sure your computer meets the minimum system requirements for using your printer (see [General troubleshooting, page 89](#)). Upgrade your system if necessary.

User guide on the CD is obsolete

Probable Cause

The User Guide has been updated since the software CD was released.

Corrective Action

- Download the most recent version of the User Guide from Kodak.com.

Wrong paper size

Probable Cause

The print size or paper size you selected may be larger or smaller than the paper found in the paper tray.

Corrective Action

1. Replace the paper in the paper tray with the correct size.
2. Press **OK**.

If the situation continues, contact Kodak support.

Macintosh OS X troubleshooting

Non-Intel Mac only: black screen or screen freeze occurs when applying printer settings via the Home Center software

Probable Cause

This error only occurs with non-Intel Macintosh computers running Leopard OS version 10.5. Apple has confirmed that there are problems running the latest version (Leopard) on G5 processors.

Corrective Action

Upgrade to Macintosh OS 10.5.2.

Windows Vista troubleshooting

WIA (Windows Image Acquisition) error: service has stopped working

This results in the inability to connect a camera and transfer pictures from the camera. Neither the camera nor the printer is visible through the **Transfer All to My PC** option on the Print Photo Options menu.

Probable Cause 1

The USB cable is unplugged and reconnected to the printer.

Probable Cause 2

A printer-terminated error occurs.

Probable Cause 3

Power is interrupted.

Corrective Action

Restart the computer and printer.

Home Center software on Windows works incorrectly following software upgrade

Probable Cause

Some changes in the Home Center software on Windows systems may have been affected by enabled Security and/or User Account Control settings.

Corrective Action

1. Right-click on the Home Center icon (shortcut) on the Desktop.
2. Select **Properties**.
3. Select the Compatibility tab.
4. Check the box that says "Run the program as an administrator."

Print troubleshooting

Use this section to resolve print problems.

Envelope printing incorrect

Probable Cause

The envelopes are not loaded correctly.

Corrective Action

1. Remove the envelopes from the paper tray.
2. Straighten the stack of envelopes against a flat surface. Reload the stack into the paper tray print side down, with the envelope flap aligned to the left.
3. Squeeze the paper guide and slide it to the right until it touches the edge of the envelopes.

Multiple-page document not printing in reverse order (Windows only)

NOTE: On a Macintosh, **Reverse Page Order** printing is the default setting. See [To set a Macintosh to print the first page of a document first](#) below.

Probable Cause

The print settings on your computer are set to print the first page of your document first.

Corrective Action

Configure the printer to print the document in reverse order, so the pages are in the correct order when printing is complete.

To set a Windows PC to print in reverse order

1. On the Windows Desktop, click **Start > Settings > Control Panel**.
2. In the Control Panel window, open Printers or Printers and Faxes.
3. In the Windows Explorer window, right-click on the Kodak All-in-One printer in the **Name** column, and then select **Printing Preferences**.
4. On the Printing Preferences window, select **Print last page first** on the General tab.

Multiple-page document not printing in first-page first order (Macintosh only)

Probable Cause

The print settings on your computer are set to print the document in reverse order.

Corrective Action

Configure the printer to print the document first-page first.

To set a Macintosh to print the first page of a document first

1. On the File menu, select **Print**.
2. On the Print dialog, select **Paper Handling**.
3. Select the **Normal Page Order** option.

PictBridge camera not detected

Probable Cause

The camera is not communicating with the printer.

Corrective Action

- Make sure the camera is turned on.
- Check the USB connections from the PictBridge camera to the printer.
- If disconnected, reconnect the USB cable from the PictBridge camera to the printer.
- Make sure the connected camera is PictBridge-compatible. See your camera or device user's guide for details.
- Check the camera batteries.

Picture cropped

- Change the picture quality setting (or resolution) on your digital camera to 3:2. See your camera user's guide for details.
- Adjust cropped photos using the Kodak Home Center software (Windows only) or other image editing software on your computer.
- If you are printing from an application on your computer, select the proper paper size from the printer options.

NOTE: Cropping may vary, depending on the selected picture size and size of the output paper. The dimensions of the photo on the camera are slightly different from each paper size so a portion will be cropped to fit perfectly on whatever paper size was selected.

Picture print smudged

Probable Cause

Fingerprints are on the glossy side of paper.

Corrective Action

Handle paper by the edges.

Picture will not print

A selected picture does not print.

Probable Cause 1

The image file may be corrupt.

Corrective Action

Review the picture on the camera or computer and delete it if necessary.

Probable Cause 2

The image file may not be in JPEG format.

Corrective Action

The Kodak printer can print only JPEG files in stand-alone mode. Connect the printer to a computer and use software to print other image formats.

Poor print quality

Probable Cause

Low resolution image file or the printer may need maintenance.

Corrective Action

- Align the printhead (see [Monitoring and adjusting the printer's performance, page 78](#)).
- Perform a nozzle check with the Home Center software.

- Clean the printhead from Home Center, or from the **Maintenance** menu on the printer control panel. If the printhead is clogged, the printouts should begin to improve with two or three cleanings. Repeat the cleaning cycle until the printout stops improving.
- If the problem still persists, you may need to replace the printhead (see [Replacing the printhead, page 82](#)).

Print skewed or slanted

Probable Cause 1

The paper is not properly loaded in the tray.



CAUTION:

Kodak Inkjet paper is recommended for your Kodak All-in-One printer.

Corrective Action

Realign the paper in the paper tray.

1. Remove paper and check for wrinkles and tears.
2. Slide the paper edge guide away from the paper.
3. Straighten the stack of paper against a flat surface, and reload it into the paper tray.
4. Slide the paper edge guide up against the edge of the paper.

Probable Cause 2

More than one type or size of paper is loaded.

Corrective Action

Load only one type or size of paper at a time.

Print spotted

Probable Cause

Paper may be dirty.

Corrective Action

Use a dry, lint-free cloth to wipe clean. For excessive dirt or debris, thoroughly clean the paper tray, and load new paper.

NOTE: When you are not using the printer, keep paper tray covers closed to keep dust and debris from collecting on the paper or inside the printer.

Print too dark

- Try retaking the picture with the flash on, or move within the flash range of the camera. Refer to your camera user's guide for details.
- Adjust the exposure compensation on your camera and try taking the picture again. Refer to your camera user's guide for details.
- Edit the picture using Kodak Home Center (Windows only) or other image editing software.
- Make sure the printer is not placed in direct sunlight or is not operating in a high-temperature environment.

Print too light



CAUTION:

For best results, use Kodak paper and ink cartridges for your Kodak All-in-One printer.

- Make sure the paper is loaded with the print side face down. Reload it if necessary.
- Try taking the picture again with the flash off. Refer to your camera user's guide for details.
- Adjust the exposure compensation on your camera and try taking the picture again. Refer to your camera user's guide for details.
- Edit the picture on your computer.

Printing slow

NOTE: When printing a large number of prints, printing may slow down to prevent the printhead from overheating.

- Make sure the printer is not placed in direct sunlight or is not operating in a high-temperature environment (higher than 95° Fahrenheit or 35° Celsius).
- Close any unnecessary software applications.
- Make sure your computer meets the minimum system requirements. Upgrade your system if necessary.

Printing stops

Printing stops during mid-print. Paper stops feeding, and status light may blink.



CAUTION:

For best results, use Kodak paper and ink cartridges for your Kodak All-in-One printer.

To check the paper:

1. Remove any loose paper from the printer. Check the paper access door in the rear of the printer.
2. Inspect the paper supplies and reload with new paper if necessary.
3. Carefully “fan” the paper to keep the sheets from sticking together.
4. Reload the paper tray. Do not overload.
5. Press **Start** to continue.

White edges on borderless prints**Probable Cause 1**

White edges can appear when there are slight misalignments between the printer and paper. Some software applications are able to “hide” these small misalignments so that the prints look borderless.

Corrective Action

- Realign the paper in the tray.
- Use the application's Fill Page option or resize the picture so it is slightly larger than the paper size.

Probable Cause 2

If the image's proportions or dimensions are not compatible with the selected paper size, the print usually will not be borderless. For example, if a square image is printed on 4 x 6-inch paper, it will often print as a 4 x 4-inch image, with white edges on each side of the print job.

Corrective Action 2

Crop the image so it is compatible with the selected paper size.

Copy troubleshooting**Copy cut off****Probable Cause**

The original is larger than the paper loaded.

Corrective Action

When the original is larger than the paper loaded, reduce copy size to fit the size of the paper loaded.

Scan troubleshooting

Scan fails

Probable Cause 1

Your computer is not turned ON.

Corrective Action

Turn on your computer.

Probable Cause 2

Your Kodak printer is not connected to your computer.

Corrective Action

Connect your Kodak printer to your computer with a standard USB cable.

Probable Cause 3

The Kodak Home Center software is not installed.

Corrective Action

Insert the Kodak printer installation CD and install the software.

Probable Cause 4

Your computer system resources may be low.

Corrective Action

- Turn off your computer and the printer, and then turn them back on.
- If the problem still persists, try scanning at a lower resolution.

Probable Cause 5

The memory card to which you are scanning does not have enough free space to save the scanned photo.

Corrective Action

Remove some files from the memory card to free up some space.

Scanned image blank

Probable Cause

Your original is not placed correctly on the scanner glass.

Corrective Action

Place your original face down in the proper corner of the scanner glass.

Network troubleshooting

Wired network troubleshooting

Computer unable to detect the All-in-One printer

Probable Cause 1

Cables are not connected properly.

Corrective Action

Check the following cables to ensure they are properly connected.

- Cables between the hub or router and your computer
- Cables between the All-in-One printer and the hub or router
- Cables to and from your modem or printer Internet connection (if applicable)

Probable Cause 2

Your Local Area Network card (LAN card) is not set up properly.

Corrective Action

Verify the setup of your LAN card.

To check your LAN card (Windows)

1. Open the Control Panel.
2. Double-click **System**.
3. In the **System Properties** dialog box, click the Hardware tab.
4. Click **Device Manager**.
5. Make sure your card shows up under Network Adapters.
6. Refer to the documentation that came with your card.

To check your LAN card (Macintosh)

1. Click the Apple icon on the Menu bar.
2. Select **About This Mac** and then click **More Info**. The System Profiler is displayed.
3. In the System Profiler, click **Network**.
4. Make sure your LAN card appears in the list.

Probable Cause 3

You do not have an active network connection.

Corrective Action

Check to see if you have an active network connection.

To see if you have an active network connection

Check the two Ethernet indicator lights on the top and bottom of the RJ-45 Ethernet jack on the back of the printer. The lights indicate the following:

Top light	If this light is a solid green, the device is properly connected to the network, and communications have been established. If the top light is off, there is no network connection.
Bottom light	This yellow light flashes when data is being sent or received by the device over the network.

To establish an active network connection

1. Check the cable connections from the All-in-One printer to your gateway, router, or hub to ensure connections are secure.
2. If the connections are secure, turn off the power on the All-in-One printer, and then turn it on again. Press the **On/Off** button on the control panel to turn the printer off, and press it again to turn it back on. Also, turn off the power on your router or hub, and then turn it on again.

No TCP/IP

Probable Cause

Your Local Area Network (LAN) card is not installed properly.

Corrective Action

Make sure your LAN card is installed properly and set up for TCP/IP. See the instructions that came with your LAN card.

Printer not found

Probable Cause

The All-in-One printer is not turned on.

Corrective Action

Turn on the printer.

Probable Cause 2

You do not have an active network connection.

Corrective Action

Make sure you have an active network connection.

To make sure your network connection is active

1. If the connections are secure, turn off the power on the All-in-One printer, and then turn it on again. Press the **On/Off** button on the control panel to turn the printer off, and press it again to turn it back on. Also, turn off the power on your router or hub, and then turn it on again.
2. Check the cable connections from the printer to your gateway, router, or hub to ensure connections are secure.
3. Make sure the printer is connected to the network with a CAT-5 or better Ethernet cable.

Probable Cause 3

Cables are not connected properly.

Corrective Action

Check the following cables to ensure they are connected properly.

- Cables between the All-in-One printer and the hub or router
- Cables between the hub or router and your computer
- Cables to and from your modem or printer Internet connection (if applicable)

Probable Cause 4

A firewall, anti-virus, or anti-spyware application is preventing the printer from accessing your computer.

Corrective Action

Many firewall security programs have different levels of firewall security (Block All, High, Medium, Low), and some high levels of protection may prevent certain software applications and/or services from being permitted to operate through the network with enabled firewall security.

Via the firewall security program on your PC, manually allow inbound and outbound application permission through the firewall for the following services required for the wireless All-in-One operations:

Bonjour Service

(C:\Program Files\Bonjour\mDNSResponder.exe)

Kodak AiO Network Discovery Service

(C:\Program Files\Kodak\Printer\Center\EKDiscovery.exe)

Kodak AiO Device Service

(C:\Program Files\Kodak\Printer\Center\KodakSvc.exe)

Kodak AiO Home Center

(C:\Program Files\Kodak\Printer\Center\AiOHomeCenter.exe)

Please visit www.kodak.com/go/inkjetnetworking for detailed instructions on adding these firewall permissions for the Kodak printer network services for 20 of the top rated firewall security programs on the market. Please also visit your firewall Manufacturer's online help Web site if necessary.

More advanced network users may also choose to allow inbound and outbound port permission through their firewall for the following ports associated with the wireless printer:

Port 5353 (UDP)

Port 9322 (TCP)

Probable Cause 5

A Virtual Private Network (VPN) is preventing the printer from accessing your computer.

Corrective Action

Try temporarily disabling the VPN before proceeding with the installation.

NOTE: The All-in-One printer functionality will be limited during VPN sessions.

Probable Cause 6

The Ethernet cable is not plugged in to the router, switch, or hub. The cable may also be defective.

Corrective Action

Try reinserting the cables. Or, if necessary, try a different cable.

Probable Cause 7

The All-in-One printer is assigned an AutoIP address instead of DHCP.

Corrective Action

This indicates that the printer is not connected properly to the network. Check the following:

- Make sure all cables are connected properly and securely.
- If the cables are connected properly, your access point, router, or home gateway might not be sending an address. If this is the case, you might need to reset the device.
- Make sure the All-in-One printer is on the correct network.
- Restart your All-in-One printer.

Probable Cause 8

The printer is on the wrong Subnet or gateway.

Corrective Action

Print a network configuration page, and verify that the router and printer are on the same subnet and gateway.

To print the network configuration page

1. On the control panel of the printer, press **Menu**.
2. Press ▼ until **Network Settings** is highlighted, and then press **OK**.
3. Press ▼ until **Print Network Configuration** is highlighted, and then press **OK**.

No IP address with cable modem (without a router)

Probable Cause

If you have a computer with a cable modem, a separate Local Area Network (LAN) for your other computers, and no DHCP or router, you must use **AutoIP** to assign IP addresses to the other computers and to the printer.

Corrective Action**To obtain an IP address for the computer with the cable modem**

Your Internet Service Provider (ISP) assigns either a static or dynamic IP address to the computer with the cable modem.

To assign IP addresses to the remaining computers and the All-in-One printer

Use **AutoIP** to assign IP addresses to the remaining computers and the printer. Do not assign a static IP address.

Wireless troubleshooting**No SSID****Probable Cause 1**

Your access point is not broadcasting its network name (SSID) because the **Broadcast SSID** option is turned off.

Corrective Action

Access the Embedded Web Server and turn on the **Broadcast SSID** option.

Probable Cause 2

The access point (infrastructure) or computer (ad hoc) is out of range.

Corrective Action

In order to establish a good signal between the printer and access point (infrastructure) or computer (ad hoc), try doing the following things separately or in combination.

- If there is a long distance between your computer or access point and the printer, move them closer together.
- If there are metal objects (such as a metal bookcase or refrigerator) in the transmission path, clear the path between the printer and the computer or access point.
- If a cordless telephone, microwave, or other device that emits radio signals transmitting at 2.4 GHz is nearby, move it farther away to reduce radio interference.

NOTE: Devices like wireless speakers or wireless gaming accessories can emit radio interference at 2.4 GHz. You can verify this on your wireless desktop or laptop computer by viewing sporadic signal bars in your Wi-Fi status utility.

Repositioning your computer away from these sources of signal interference can improve your computer network performance. For example:

- **Do** place the AP/router in a central room.
- **Do not** place wireless entertainment devices between the AP/router and wireless computer.

- **Do not** place wireless entertainment devices between the AP/router and Wi-Fi All-in-One printer.

Probable Cause 3

The SSID is not visible because it is at the bottom of the list.

Corrective Action

Press ▼ to scroll to the bottom of the list. Infrastructure entries are listed first and ad hoc entries last.

Probable Cause 4

The access point firmware needs updating.

Corrective Action

Check for firmware updates for your access point on the manufacturer's Web site. Update the firmware on the access point.

Probable Cause 5

Your wireless adapter on your computer is not broadcasting the SSID (ad hoc).

Corrective Action

Verify that the wireless adapter is broadcasting the SSID. Print a network configuration page from the All-in-One printer, and verify that the SSID for the wireless adapter appears on the network configuration page. If the wireless adapter is not broadcasting the SSID, see the documentation that came with your computer.

Probable Cause 6

The firmware for the wireless adapter on your computer needs updating (ad hoc).

Corrective Action

Check for firmware updates for your wireless adapter on the manufacturer's Web site, and then update the firmware.

Probable Cause 7

An Ethernet cable is connected to the printer.

Corrective Action

Unplug the Ethernet cable.

Weak signal

Probable Cause

The access point is too far away or there is interference.

Corrective Action

- If there is a long distance between your computer or access point and the printer, move them closer together.

- If there are metal objects (such as a metal bookcase or refrigerator) in the transmission path, clear the path between the printer and the computer or access point.
- If a cordless telephone, microwave, or other device that emits radio signals transmitting at 2.4 GHz is nearby, move it farther away to reduce radio interference. See the note on [page 111](#).

Cannot connect to network

Probable Cause 1

The equipment is not turned on.

Corrective Action

Turn on the networked devices, such as the access point for an infrastructure network, or the computer for an ad hoc network. For more information on how to turn on the access point, see the documentation that came with your access point.

Probable Cause 2

The All-in-One printer is not receiving a signal.

Corrective Action

Move the access point and the printer closer together. Then go through setup again.

Probable Cause 3

You have entered the SSID incorrectly.

Corrective Action

Enter the SSID correctly. Remember that the SSID is case-sensitive.

Probable Cause 4

You have entered the WEP key incorrectly.

Corrective Action

Enter the WEP key correctly. Remember that the WEP key is case-sensitive.

Probable Cause 5

The wireless settings on the printer do not match the wireless settings of your access point.

Corrective Action

Print a network configuration page to compare the wireless settings of the printer with the wireless settings for your access point. Change either the device or access point settings so that both the printer and the access point have matching wireless settings.

Probable Cause 6

You entered the wrong mode (ad hoc or infrastructure) or security type.

Corrective Action

Enter the correct mode or security type. Print a network configuration page to compare the wireless settings of the printer with the wireless settings for your access point. Change either the device or access point settings so that both the printer and the access point have matching wireless settings.

Probable Cause 7

MAC filtering is enabled on your access point.

Corrective Action

Keep MAC filtering enabled, but change the settings to allow the access point to communicate with the printer.

Unsupported authentication or encryption type**Probable Cause**

Your network is configured with an authentication protocol not supported by the Kodak All-in-One printer.

Corrective Action

Open the Embedded Web Server of your access point and change the security settings. Use one of the supported protocol types.

NOTE: Types not supported include WPS, WPA2-Enterprise, LEAP, PEAP, EAP-MD5, EAP-TLS, and EAP-TTLS.

Invalid WEP Key**Probable Cause 1**

An invalid WEP key was entered.

Corrective Action

If you do not know the WEP key, see the documentation that came with your access point/router. The WEP key is stored within the access point. Usually you can find the WEP key by logging on to the Embedded Web Server of your access point through your computer.

Probable Cause 2

The WEP key index setting of your access point does not match the WEP key index setting of the All-in-One printer.

Corrective Action

The printer is looking for a WEP key index of 1. If the WEP key index setting was changed on the access point, open the Embedded Web Server for the printer and update the index setting to match the index setting of your access point. Once you've updated the index setting on the printer, repeat the setup procedure.

NOTE: Some access points provide more than one WEP key. Make sure you use the first WEP key (index 1) when setting up your wireless network.

Invalid WPA Passphrase

Probable Cause

You have entered the WPA passphrase incorrectly.

Corrective Action

Enter the correct passphrase. Make sure it has between 8 and 63 characters, and matches the passphrase programmed in the access point (case sensitive).

Another device connected to the access point

Probable Cause

Another device in the vicinity connected to your access point before the All-in-One printer was able to connect.

Corrective Action

Cancel the setup and start over.

Product and Safety Specifications

Specifications for this Kodak ESP All-in-One printer are described in the tables below.

Print Performance

Print Performance	
Black print speed	Up to 30 pages per minute on plain paper
Color print speed	Up to 29 pages per minute on plain paper
Print technology	Continuous-tone thermal ink jet
Print quality modes	Draft, Normal, and Best on plain paper Photo quality mode on photo paper

Photo Printing Features

Photo Printing Features	
Quantity	1- 99
Print sizes	2 x 3 inch (5 x 7.6 cm) 3.5 x 5 inch (9 x 12.7 cm) 4 x 6 inch (10 x 15 cm) 4 x 7 inch (10 x 18 cm) Panoramic (4 x 12 inch) (10 x 30 cm) 5 x 7 inch (13 x 18 cm) 8 x 10 inch (20 x 25 cm) US Letter (8.5 x 11 inch) (22 x 28 cm) A4 (21 x 30 cm)
Quality	Normal, Best, and Draft
Auto-detect media	Auto-detect plain paper, photo paper, and transparency Optimize image quality for Kodak Photo Papers with barcode
Image enhancement	Kodak Perfect Touch Technology with Home Center software
Add Dates to Prints	Yes, No
Color	Black & White or Color
Scene Balance	On, Off

Copy Document Features

Copy Document Features	
Color	Black & White or Color
Quantity	1 to 99 copies
Copy size	Same Size, 20% to 500%
Quality	Normal, Best, and Draft
Brightness	- 3 to + 3

Copy Photo Features

Copy Photo Features	
Color	Black & White or Color
Quantity	1 to 99 copies
Copy size	2 x 3 inch (5 x 7.6 cm) 4 x 6 inch (10 x 15 cm) 4 x 7 inch (10 x 18 cm) Panoramic (4 x 12 inch) (10 x 30 cm) 5 x 7 inch (13 x 18 cm) 8 x 10 inch (20 x 25 cm) US Letter (8.5 x 11 inch) (22 x 28 cm) A4 (21 x 30 cm)
Quality	Normal, Best, and Draft
Brightness	- 3 to + 3

Scanning Features

Scanning Features	
Scanner type	Contact Image Sensor (CIS) type scanner
Maximum scan size	8.5 x 11.7 in. (21.6 x 29.7 cm)
Functions	Segmentation scanning Auto-destination OCR

Paper Tray Features

Paper Tray	
Paper capacity:	100 sheets of 20 lb plain paper or 30 sheets of 10 mil photo paper
Tray size: top tray	4 x 6 in. to 8.5 x 14 in. (10 x 15 cm to 21.6 x 36 cm)
Tray size: bottom tray	4 x 6 in., 4 x 7 in., 5 x 7 in.

Ink Tanks

Ink Tanks	
Ink handling	2-cartridge, 6-ink system
Ink life	1-year warranty from date of purchase

Connectivity

Connectivity	
Protocols supported	USB 2.0, USB PTP, Bluetooth® 2.0, PictBridge, DPOF, MIPC
Devices supported	Windows and Macintosh computers, USB mass storage devices, memory cards (MS, XD, SD, SDHC, and CF), PictBridge-enabled digital still cameras, and Bluetooth® Technology-enabled imaging devices
Image formats supported	JPEG (EXIF V2.2) (progressive JPEG format not supported) AVI, MOV and WAV (transfer only)
Number of USB ports	One front host port (full speed), one rear device port (high speed)

Software Support

Software Support	
Application support	Third-party image management applications or Kodak EasyShare Software for photos; optical character reader (OCR) support for documents
Media support	Plain paper, photo paper, envelopes, greeting cards, transparencies, labels, t-shirt transfers
Scanner support	TWAIN and WIA import, including EasyShare Software, segmentation scanning
File transfer support	Automatic color, contrast, sharpness improvements upon transfer to PC
Update support	Software and firmware updates available through web support

Physical Specifications

Physical Specifications	
Power	US: 110-120 VAC, 60 Hz WW: 110-240 VAC, 50-60 Hz Output: 36 VDC 24V AC adapter (100-240 VAC 50/60 Hz)
Dimensions	445mm x 254mm x 427mm [W x H x D] (17.52 inches x 10.0 inches x 16.81 inches)
Weight	10kg (22 lbs)
Operating range	5°C (41°F) to 35°C (95°F), 15 to 85% RH (non-condensing), and atmospheric pressure to approximately 10,000 ft ASL
Full IQ environmental range	15°C (59°F) to 30°C (86°F), and 20 to 80 % RH

Warranty

Warranty	
Product	One year from purchase (with proof of purchase)
Printhead	One year from purchase (with proof of purchase)

System Requirements

The following specifications are subject to change without notice.

Windows PC

Windows PC	Minimum	Recommended
Operating System	Microsoft Windows XP SP2	Microsoft Windows Vista
CPU	Celeron	32- or 64-bit processor
Clock Speed	1.2 GHz	2 GHz
Memory	512 MB RAM	1024 MB RAM
Available Disk Space	500 MB available	500 MB available
Interface	USB 2.0	USB 2.0
Removable Drive	CD-ROM	CD-ROM
Other	Internet access capability	Internet access capability

Macintosh

Macintosh	Minimum	Recommended
Operating System	Macintosh OS X 10.4.8	10.4.9 or greater
Computer	PowerMac or Powerbook G3, G4; iMac; eMac; or iBook	Intel Mac
Clock Speed	2 GHz	2 GHz
Memory	512 MB RAM	1024 MB RAM
Available Disk Space	200 MB available	200 MB available
Interface	USB 2.0	USB 2.0
Removable Drive	CD-ROM	CD-ROM
Other	Internet access capability	Internet access capability

Papers Supported

Paper Types

Paper Types Supported	
Plain paper	20 to 24 lb (60 to 90 gsm)
Photo paper	10 mils
Card stock	110 lb index max (200 gsm)
Envelopes	20 to 24 lb (75 to 90 gsm)
Transparencies	All commercially available inkjet varieties (with or without a white stripe)
Labels	All commercially available inkjet varieties on 8.5 x 11 and A4 size sheets
Iron-on transfers	All commercially available inkjet varieties on 8.5 x 11 and A4 size sheets

Paper Sizes for PC and Macintosh computers

Paper Sizes Supported	
Usage	Size
Document page sizes	A4 (210 x 297 mm)
Labels	A5 (148 x 210 mm)
	A6 (105 x 148 mm)
	B5 (176 x 250 mm)
	US Executive (7.25 x 10.5 in.) (184 x 266 mm)
	US Letter (8.5 x 11 in.) (216 x 280 mm)
	US Legal (8.5 x 14 in.) (216 x 356 mm)
	Custom sizes from 4-8.5 in. wide and 6-14 in. long
Index card stock	4 x 6 in. index cards (101 x 152 mm)
	5 x 7 in. index cards (127 x 178 mm)
Transparency	A4 (210 x 297 mm)
Iron-on transfers	US Letter (8.5 x 11 in.) (216 x 280 mm)
Envelopes	C5 (6.38 x 9 in.) (162 x 299 mm)
	C6 (4.49 x 6.38 in.) (114 x 162 mm)
	A2 (4.37 x 5.75 in.) (111 x 146 mm)
	DL (designated long) (4.33 x 8.66 in.) (110 x 220 mm)
	US #10 (4.12 x 9.5 in.) (105 x 241 mm)

Paper Sizes Supported	
Photo	4 x 6 in. (102 x 152 mm) 4 x 7 in. (102 x 178 mm) 4 x 12 in. (102 x 305 mm) 5 x 7 in. (127 x 178 mm) 8 x 10 in. (203 x 254 mm) US Letter (8.5 x 11 in.) (216 x 280 mm) A4 (210 x 297 mm)
Greeting card	4 x 5.5 in. (101 x 140 mm) 4 x 8 in. (101 x 203 mm)

Safety Specifications

- Read and follow these cautions and warnings before using Kodak products.
- Always follow basic safety procedures.
- Follow all warnings and instructions marked on the Kodak All-in-One printer.

Parts



CAUTION:

Do not disassemble this product; there are no user-serviceable part(s) inside. Refer servicing to Kodak's qualified service personnel.



WARNING: Keep out of reach of children. Ink may be harmful if swallowed.

Power



CAUTION:

If the power cord or plug is frayed or damaged, the equipment gets wet, or the equipment does not operate normally when the operating instructions are followed, unplug your printer from the power outlet and have qualified service personnel service your printer.



CAUTION:

The alternating current (AC) adapter power supply is equipped with a three-wire grounding type plug. If you cannot insert the plug into the power outlet, contact an electrician to check or replace the power outlet.



CAUTION:

For added protection from damage during a lightning storm, or when your printer and its associated alternating current (AC) adapter are unused for long periods of time, unplug the AC adapter from the power outlet.



WARNING: Pushing objects through the equipment openings can result in an electric shock or fire.



CAUTION:

Do not plug the alternating current (AC) adapter into a household extension cord.



WARNING: The use of an accessory not recommended by Kodak could cause fire, an electric shock, or injury.

Location



CAUTION:

To prevent your printer from overheating, do not block or cover the slots and openings in the equipment, place it near a heat register, or install it in a cabinet without proper ventilation.



CAUTION:

Do not use your printer near water, or spill liquid on it.



WARNING: Do not place your printer on an unstable cart, stand, bracket, or table; this risks damaging the equipment and injuring people.

Environment



CAUTION:

Excessive dust levels may damage internal parts.



CAUTION:

Unplug the equipment from the electrical outlet before cleaning.



CAUTION:

Dropping your printer may damage the housing and result in extensive damage that will require replacement or repair by a qualified technician to restore normal operation.



WARNING: Do not expose this product to liquid, moisture, or extreme temperatures. Kodak alternating current (AC) adapters are intended for indoor use only. The use of controls, adjustments, or procedures other than those specified herein may result in exposure to shock and/or electrical or mechanical hazards.



CAUTION:

Adjust only those controls covered in the user guide or setup instructions.

For more information, go to www.Kodak.com/go/MSDS.

Regulatory Compliance



Kodak ESP All-in-One Printer

FCC Compliance and Advisory

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed or used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by one or more of the following measures: 1) reorient or relocate the receiving antenna; 2) increase the separation between the equipment and the receiver; 3) connect the equipment to a different outlet (on a circuit) than the one the receiver is connected to; 4) consult the dealer or an experienced radio/TV technician for additional suggestions.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. To ensure compliance with FCC regulations, use only the shielded interface cables provided with the product, or additional specified components or accessories that can be used with the installation of the product.



CAUTION:

When using the Bluetooth interface with a Kodak printer, the transmitter must not be collocated or operated in conjunction with any other antenna or transmitter.

FCC and Industry Canada

This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

This device has been designed to operate with an antenna having a maximum gain of 1.8dB.

Antenna having a higher gain is strictly prohibited per regulations of Industry Canada. The required antenna impedance is 50 ohms.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the EIRP is not more than required for successful communication.

IC Radiation Exposure Statement

IMPORTANT NOTE: This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.

Canadian DOC Statement

DOC Class B Compliance—This Class B digital apparatus complies with Canadian ICES-003.

Observation des normes-Class B—Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

European Compliance Statement



Hereby, Eastman Kodak Company declares that this KODAK all-in-one wireless printer is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

German Compliance Statement

Noise emissions for this equipment do not exceed 70 dB(A).

This equipment is not intended for use in the work place in accordance with BildscharbV regulations.

“Das Gerät ist nicht für die Benutzung am Bildschirmarbeitsplatz gemäß BildscharbV vorgesehen.”



Caution: There is a risk of explosion if the battery is replaced by an incorrect type. Dispose of used batteries according to the instructions. Contact your local Kodak representative or refer to www.kodak.com/go/recycle for additional information on the collection and recovery programs for batteries.

Achtung

Explosionsrisiko wenn die Batterie durch einen inkorrekten Typen ersetzt wird. Entsorgung der Batterie gemäss der Gebrauchsanweisung. Bitte kontaktieren Sie Ihren lokalen Kodak Repräsentanten oder www.kodak.com/go/recycle für mehr Informationen über das Sammeln und Wiederverwerten von Batterien.

Waste Electrical and Electronic Equipment Labeling



In the European Union, this symbol indicates that when the last user wishes to discard this product, it must be sent to appropriate facilities for recovery and recycling.



Contact your local Kodak representative or refer to www.kodak.com/go/recycle for additional information on the collection and recovery programs available for this product.

Declaration of Conformity

See www.kodak.com/go/declarationofconformity.

Glossary

A

Ad hoc The Kodak All-in-One printer communicates directly with each device on the network. No wireless access point is used. This is also called a peer-to-peer network. On an Apple Macintosh, ad hoc is called computer-to-computer.

AiO All-in-One.

B

Bluetooth An industrial specification for wireless personal area networks (PANs). Bluetooth provides a way to connect and exchange information between devices such as mobile phones, laptops, PCs, printers, digital cameras, and video game consoles over a secure, globally unlicensed short-range radio frequency. The Bluetooth specifications are developed and licensed by the Bluetooth Special Interest Group.

C

Computer-to-computer See [Ad hoc](#).

D

DNS Domain Name Server or Domain Name System. A DNS is a record that is located at the registry that tells a browser where to route your mail or where a Web site can be found. Basically a system that converts IP addresses into names, i.e. 123.456.789.0 to www.yourdomain.com. DNS entries translate the domain name (computer hostnames) to IP addresses.

DPI Dots per inch

DPOF Digital Print Order File. This file allows the user of a digital camera to define which captured images on the storage card are to be printed, together with information on the number of copies or other image information such as paper size, image title text, image orientation, contact information and more.

E

ESP EasyShare Printer.

Ethernet A family of computer networking technologies for local area networks (LANs). It defines a number of wiring and signaling standards of network access at the Media Access Control (MAC)/Data Link Layer, and a common addressing format.

EXIF	Exchangeable Image File Format. A standard for storing interchange information in image files, especially those using JPEG compression. Most digital cameras now use the EXIF format.
Gateway Address	A node on a network that serves as an entrance to another network. A node in this instance can be a computer or some other device. The address of the default gateway is assigned by the installation software, unless you have already set a manual IP address.
H	
Hex	Hexadecimal. A numeric system that uses sixteen distinct characters that are a combination of the numbers 0 - 9 (represent values zero to nine) and letters A - F (represent values ten to fifteen). Hexadecimal is used as a human friendly representation of binary coded values.
Hostname	The TCP/IP name assigned to the device by the installation software.
I	
Infrastructure	The Kodak All-in-One printer communicates with other network devices through a wireless access point, such as a wireless router or base station.
IP Address	Internet Protocol address. This address uniquely identifies the device on the network. IP addresses are assigned dynamically through DHCP or AutoIP. Static IP addresses can be set up. An invalid IP address during installation will prevent your network components from seeing the Kodak All-in-One printer.
J	
JPEG	Joint Photographic Experts Group. The name of the committee that developed the image file format. JPEG is a compressed image file format. JPEG is a "lossy" format, which means some quality is lost when the image is compressed.
K	
Kodak Perfect Touch	Automatically corrects for common image flaws and "mistakes," such as shadows, and backlighting. Kodak Perfect Touch technology also enhances the desirable qualities of pictures, for vibrant color and richer detail. This feature is available when scanning or copying pictures. Color restoration and Kodak Perfect Touch can be used together to enhance pictures. This feature is not available when scanning black and white pictures.
KPT	Kodak Perfect Touch.
M	
MAC	Media Access Control. The Media Access Control address identifies the Kodak All-in-One printer. This is a unique 12-digit identification number assigned to networking hardware for identification, including routers, switches, and other such devices. No two pieces of hardware have the same MAC address. Some Internet service providers (ISPs) require that you register the MAC address of the Network Card or LAN Adapter that was connected to your cable or DSL modem during installation.

N

Network Configuration

The protocol used to assign the [IP Address](#) to the device. For this Kodak All-in-One printer, the network configuration is:

AutoIP: The installation software automatically determines the configuration parameters.

DHCP: The configuration parameters are supplied by a dynamic host configuration protocol (DHCP) server on the network. On small networks, this could be a router.

Manual: The configuration parameters are set manually, such as a static IP address.

Not Specified: The mode used when the Kodak All-in-One printer is initializing.

O

OCR

Optical character recognition.

P

Peer-to-peer network See [Ad hoc](#).

PictBridge

A Camera and Imaging Products Association standardized technology that allows printing of images between any PictBridge compliant digital camera and any PictBridge compliant printer. Thus, you can print from a memory card in a digital camera directly to a printer, regardless of brand. No computer is necessary. Each device is automatically recognized by the other. The camera compares its PictBridge functions to the functions of the printer. The camera then displays the supported functions on menus on the LCD screen or in the viewfinder. Once a PictBridge digital camera is connected to a compliant printer, print options appear on the camera monitor (LCD). The camera menu system is used to select settings such as print size, layout, media type, and date. You can print a single image displayed on the camera, print two or more images, or print all of the images on the memory card. You can print part of an image by first cropping it within the camera and even create index prints (contact sheets). To find out if a camera or printer is PictBridge compatible, look for the PictBridge logo on the packaging or check the manual for specifications.

PTP

Picture Transfer Protocol. A standard for transferring pictures from a digital camera.

R

Red Eye

The red-eye effect in flash photography is caused by the light from the flash reflecting off the blood vessels and interior eye tissue in humans. Animal eye glow from reflections is caused by a different internal eye structure, which is much like a mirror. When not enough time elapses between the flash and exposure (as with most compact cameras), the light of the flash occurs too fast for the iris of the eye to close the pupil. The flash of light is focused by the lens of the eye onto the blood-rich retina at the back of the eye. The image of the illuminated retina is then focused by the lens of the eye back to the camera, resulting in a red appearance of the eye on the picture.

S**SSID**

Service Set Identifier: A unique identifier (up to 32 characters) that differentiates one wireless local area network (WLAN) from another. The SSID is also known as the network name. The name of the network to which the Kodak All-in-One printer is connected is called its SSID.

Speed

The speed at which data is transmitted over a network. Speeds include 10TX-Full, 10TX-Half, 100TX-Full, and 100TX-Half.

Subnet Mask

A subnet is an [IP Address](#) assigned by the installation software to make an additional network available as part of a larger network. Subnets are specified by a subnet mask. This mask determines which of the Kodak All-in-One printer IP address bits identify the network and subnet, and which bits identify the device itself. Kodak recommends that the All-in-One printer and the computers that use it all reside on the same subnet.

T**Tagged Images**

See [DPOF](#) above.

U**USB**

Universal Serial Bus. A connection protocol between a peripheral device and a computer, allowing electronic data/signals to be transmitted back and forth. It is used commonly to connect a portable storage device such, as a “thumb” or “flash” drive, to a PC or Macintosh desktop or laptop computer. The Kodak All-in-One printer has a USB port on the front panel for external USB devices to plug into, and another one on the back panel to connect the printer to a computer via a USB cable.

W**WEP**

Wired Equivalent Privacy. A deprecated algorithm to secure wireless networks. Wireless networks broadcast messages using radio, so are more susceptible to eavesdropping than wired networks. WEP was intended to provide confidentiality comparable to that of a traditional wired network. The WEP standard only defines a 10 or 26 character “key” in hexadecimal (0-9+A-F). A WEP password is generated by the router manufacturer and as such, a password for a Linksys router will not be the same on a NetGear router.

Wi-Fi

Wireless Fidelity. A common “shorthand” name for wireless computer networking.

WPA

Wi-Fi Protected Access. A class of systems to secure wireless (Wi-Fi) computer networks. WPA is designed to work with pre-WPA wireless network interface cards (through firmware upgrades), but not necessarily with first generation wireless access points. WPA2 implements the full standard, but will not work with some older network cards.

WPA Key

A WPA key is an encryption key for wireless networking devices.

WPS

Wireless Provisioning Services. A standards-based and integrated platform to provide secure Wi-Fi hotspots. WPS enables enterprises to easily provide guest access with enhanced security to private wireless Internet and corporate networks.


Appendix A: If You Need to Call Customer Support

When you contact Kodak Customer Support for All-in-One printer assistance, the service representative may ask you for some background information, as well as information about your specific issue. If you can have ready access to it, it may save you time.

Useful for the Kodak service technician:

- Kodak Service Number (located inside or on the outside of the printer)
- Printer model number (located on back of the printer)
- Control panel error message, if any
- A printed test page (see [Monitoring and adjusting the printer's performance, page 78](#))
- Computer model and operating system
- Computer processor type and speed (MHz)
- Amount of computer memory (RAM) and free hard disk space
- Exact Home Center error message received, if applicable

Windows PC only:

- Exact printer error message received in the printer status monitor
- Version of Kodak Home Center software. (From the Home Center Help panel, click the Info  button to view the About box)

Index

Symbols

.jpg, 62
.pdf files, 62
.rtf files, 62
*70. See Call-Waiting Disable Code

Numerics

1111 See Personal identification number, 56
2.0 USB See USB
234. See Fax Auto-Answer
4-way navigation buttons, 7, 10
8-in-1 card reader See Kodak

A

Aborting See Cancel
Ad hoc, definition, 124
Add Date to Prints, 52
Add Fax Phonebook entry, 71
Adjusting
 Control panel, 8
 Copy settings, 59
 Scan settings, 64
Align the printhead, 20
Apple Macintosh See Macintosh
Arrows See 4-way navigation buttons
Attention light, 7
Auto-Answer. See Fax Auto-Answer
Auto-detect, 112
AutoIP, definition, 126
Automatic document feeder, 3
Automatic fax reception, 40
Automatically receive faxes, 70

B

Battery recycling, 122
Black ink cartridge, 80, 83
Black print speed, 112
Blinking blue light, 5
Bluetooth
 Definition, 124
 Dongle, 55
 Pairing, 56
 Printing, 55
 Range, 56
Bluetooth dongle, 6
Borderless prints, white edges on, 101
Bottom paper tray, 4
Broadband telephone See Digital telephone systems
Busy fax number, 40
Busy Redial Attempts, 42

Button

4-way navigation, 10
Cancel, 12
Menu, 11
Number keypad, 12
OK, 11
Start, 12
Zoom, 12

C

Cable,USB, 92
Cables, USB 2.0 compliant, 90
Call-Waiting Disable Code, 42
Camera troubleshooting, 90
Canadian DOC Statement, 121
Cancel button, 7, 12
Canceling a fax, 70
Card reader, Kodak 8-in-1, 50
Castellano (Iberian/Spanish), 22
Changing See Edit. See also Replacing
Check ink levels, 78
Chemicals to avoid coming in contact with the
 printer, 76
Clean the printhead, 78
Cleaning the printer, 76
 Cleaning supplies to avoid, 77
Client port, 3
Color ink cartridge, 80, 83
Color print speed, 112
Communication between printer and computer,
 troubleshooting, 92
Compliance See Regulations
Components, 3
Computer-to-computer See Ad hoc
Configuring
 Ethernet settings, 24
 Network settings, 24
 Wireless settings, 25
Connecting phone and fax, 37
Connectivity, specifications, 114
Control panel, 4, 6
 Adjusting, 8
Copy Document, 59
 Settings, 60
Copy Photo, 59
 Settings, 61
Copy problems, troubleshooting, 101
Copying, 59
Cropped pictures, troubleshooting, 98
Cropping photos, 56
Customer Support See Support

D

Danger See Safety
Dark print, troubleshooting, 100
Declaration of Conformity, 123
Dedicated Fax Line, 38
Delete Fax Phonebook entry, 72
Device not recognized, troubleshooting, 90
DHCP, definition, 126
Dialing Mode, 42
Digital Print Order File, definition, 124
Digital Subscriber (DSL) Line, 39
Disable Call Waiting, 42
Display See LCD screen
Distinctive Ring, 42
DNS Server Address, definition, 124
Document paper sizes, 117
Document print order, troubleshooting, 97
Document, copy, 59
Dongle See Bluetooth
Download printer updates, 2
DPOF, 55
Draft quality, 60

E

EasyShare software, 2
Edit Fax Phonebook entry, 72
Electrical and Electronic equipment labeling See Labeling
Enabling error correction, fax, 42
Energy See Power
Envelope sizes, 117
Envelopes, loading, 47
Environmental hazards, 119
Error Correction, 42
Error Correction mode, fax, 42
Error correction, fax See Fax
ESP, definition, 124
Español (Latin-American Spanish), 22
Ethernet network status light, 7
Ethernet network, configuring, 24
Ethernet, definition, 124
European Union recycling, 122
EXIF, definition, 125

F

Fax
Busy number, 40
Dialing on control panel, 67
Enabling error correction, 42
Error Correction mode, 42
Receiving, 70
Receiving automatically, 40
Receiving manually, 41

Redial, 40
Remode Access Code, 41
Sending, 66, 72
 with automatic cover page, 73
Setting the dial mode, 41
Specifying distinctive ring, 41
Specifying rings to answer, 40
Fax Activity Log, 42, 75
Fax Auto-Answer, 40, 41
 Off, 70
Fax confirmation page, 42, 75
Fax cover page, 42, 73
Fax dial keypad, 7
Fax Lost Job report, 75
Fax recipients, selecting, 67
Fax reports, 66
Fax Settings, 42
Fax Speaker, 42, 66
FCC compliance, 120
File transfer support, 115
Flash drive See Portable storage device
Formatting a memory card in the printer, 78

G

Gateway Address, definition, 125
German Compliance Statement, 121
Greeting card size paper, 118

H

Handling originals, 44
Hazards
 Environmental, 119
 Parts, 118
 Placing the printer safely, 119
 Power, 118
Help
 Control panel options, 1
 Home Center software, 1
 Macintosh, 89
 Windows, 89
HFS Plus See Mac OS Standard
HFS See Mac OS Standard
Home Center software
 Macintosh, 20
 Maintenance options, 79
 Ordering supplies through, 19
 Scanning with, 62
 Troubleshooting, 96
 troubleshooting the printer, 89
 Windows, 19
Host port, 3
Hostname, definition, 125
Hub See USB

I

IC Radiation Exposure Statement, 121
 Image Capture software, 58
 Image formats supported, 114
 Image quality
 Setting, 52
 Troubleshooting, 78
 Index card stock sizes, 117
 Industry Canada rules, 121
 Ink cartridge
 Disposal, 80
 Installing, 86
 Replacing, 79
 Storing, 79
 Ink cartridge not recognized, troubleshooting, 91
 Ink levels, 79
 Ink, preventing drying out, 81
 Installing ink cartridges, 86
 IP Address, 30
 IP Address, definition, 125
 iPhoto software, 58
 Iron-on transfers, 117

J

Jammed paper, troubleshooting, 93
 JPEG, definition, 125

K

Keyboard See On-screen keyboard, 13
 Keypad buttons, 12
 Keypad See Number keypad
 Keypad, Fax, 7
 Kodak
 Bluetooth dongle, 6
 Ink cartridges, 79
 Support Center, 2
 Web site, 2
 Kodak 8-in-1 USB card reader, 50
 Kodak Bluetooth dongle
 Kodak Perfect Touch, 112, 125
 Kodak Service Number, 128
 Locate in Home Center (Macintosh) software, 20
 Kodak.com, 2
 Download printer updates from, 2
 Tips & Projects Center, 2
 KPT See Kodak Perfect Touch

L

Label sizes, 117
 Labeling, Waste Electrical and Electronic Equipment
 in European Union, 122
 Last page first, printing, 97
 LCD screen, 4, 8

Light print, troubleshooting, 100
 Lights, interpreting signals from the printer, 6
 Loading the paper tray, 44

M

MAC Address, definition, 125
 Mac OS Extended format (HFS Plus), 53
 Mac OS Standard format (HFS), 53
 Macintosh
 Formatted USB drives not recognized by the
 printer, 90
 Help, 89
 Home Center software, 20
 Print the first page of a document first, 97
 Software, 58
 System requirements, 116
 Troubleshooting, black screen or screen
 freeze, 95
 Main menu, 15
 Maintenance, 76
 Maintenance Settings, 78
 Manual fax reception, 41
 Manual IP Address, definition, 126
 Manually receive faxes, 70
 Media Access Control address See MAC Address
 Media supported, 117
 Memory cards, 5
 Compatible, 50
 Formatting, 78
 Printing photos from, 53
 Removing, 5
 Slots, 4
 Troubleshooting, 90
 Types supported, 5
 Menu button, 7
 Menus, 14
 Main, 15
 Model number. See Printer model number
 Modifying See Edit. See also Adjusting
 Monitoring printer performance, 78
 Multiple originals, scanning, 64
 Multiple photo printing, 56
 Multiple photos See Printing
 Multiple-page documents, printing in reverse
 order, 97

N

Network
 Configuring, 24
 Network configuration, definition, 126
 Network settings, 26
 Network settings, configuring, 24
 Network settings, Ethernet, 24

- Network settings, Wireless, 25
- No communication with computer,
 - troubleshooting, 92
- Noise emission, 121
- Nozzle check, 79
- Nozzle correction, 79
- Number keypad
 - Using, 12

O

- Obsolete User Guide, 95
- OCR, definition, 126
- OK button, 7, 11
- On/Off button, 7
- On-screen keyboard, 71
 - Using, 13
- Optical Character Recognition See OCR
- Ordering supplies, 19
- Originals
 - Handling, 44
 - Scanning, 64

P

- Pairing, Bluetooth, 56
- Panoramic photo paper, using, 56
- Panoramic photos, printing, 56
- Paper
 - Sizes supported, 117
 - Troubleshooting, 95
 - Types supported, 117
- Paper edge guide, 4
- Paper feed, troubleshooting, 91, 93
- Paper jam
 - Troubleshooting, 93
- Paper output tray, 4
- Paper output tray extender, 4
- Paper stop, 44
- Paper tray, 4
 - Bottom, 4
 - Extender, 4
 - Loading, 44
 - Top, 4
- Paper tray extension-release, 45, 47
- Parts hazards, 118
- Peer-to-peer network See Ad hoc
- Phonebook
 - Add entry, 71
 - Delete entry, 72
 - Edit entry, 72
 - Selecting recipient, 67
- Photo paper
 - Loading, 46
 - Setting image quality, 52

- Photo paper sizes, 118
- Photocopy, 59
- Photos
 - Cropping, 56
 - Panoramic, 56
 - Printing, 53
 - Printing multiple, 56
 - Select and print all, 54
 - Setting image quality, 52
 - Transferring, 52
- PictBridge camera
 - Definition, 126
 - Displaying photos on, 51
 - Printing photos from, 53
 - Troubleshooting, 97
- Picture Transfer Protocol See PTP
- PIN. See Personal identification number, 56
- Poor print quality, 98
- Portable storage device
 - Encrypted, 53
 - Multiple partitions on, 53
 - Printing photos from, 53
 - Third-party access software, 53
 - Types not supported, 53
- Power cord connection port, 4
- Power hazards, 118
- Power not working, troubleshooting, 89
- Print
 - Last page first, 97
- Print a test page, 20
- Print Fax Activity Log, 42
- Print Fax Confirmation Page, 42, 75
- Print Fax Cover Page, 42, 73
- Print Fax Settings, 42, 75
- Print order, 55
 - Macintosh, 97
 - Windows, 97
- Print problems, troubleshooting, 96
- Print quality, troubleshooting, 89
- Print skewed or slanted, troubleshooting, 99
- Print smudged, troubleshooting, 98
- Print spotted, troubleshooting, 99
- Print Test Page, 78
- Print too dark, troubleshooting, 100
- Print too light, troubleshooting, 100
- Printer
 - Configuring network settings, 24
 - Ethernet, 24
 - Wireless, 25
 - Personal identification number, 56
 - Updates from Kodak.com, 2
- Printer access door, 79, 82
- Printer fails to power on, troubleshooting, 89
- Printer location, selecting, 21

Printer model number, 128
 Printer not responding, troubleshooting, 94
 Printer performance, monitoring and adjusting, 78
 Printer Settings, 22
 Printer status lights, 6
 Printer supplies, 19
 at Kodak.com, 2
 Maintaining, 76
 Ordering from Home Center, 19
 Recycling, 76
 Printhead, 4
 Alignment, 20, 78
 Damage, avoiding, 79
 Damaged or broken, 82
 Removing, 84
 Replacing, 82
 Printing
 Fax cover page, 73
 From a computer, 50
 From Bluetooth, 55
 Multiple photos, 56
 Multiple-page document in reverse order, 97
 Panoramic photos, 56
 Photos
 Memory cards, 53
 PictBridge camera, 53
 Portable storage device, 53
 PTP camera, 53
 Tagged image photos, 55
 Troubleshooting, 96
 Printing stops, troubleshooting, 100
 Printing too slow, troubleshooting, 100
 Protecting the printer, 76
 PTP camera, printing photos from, 53
 PTP, definition, 126
 Pulse See Fax

Q

Quality settings
 Best, 60
 Draft, 60
 Normal, 60
 Quality, troubleshooting, 98

R

Rear-access cleanout area, 4
 Receiving faxes
 Automatically, 40, 70
 Manually, 41, 70
 Recovery See Recycling
 Recycling
 Battery, 122

European Union, 122
 Printer or printing supplies, 76
 Red Eye, definition, 126
 Redial fax number, 40
 Redial if No Answer, 42
 Register the printer, 2
 Regulations
 Canadian, 121
 FCC, 120, 121
 IC radiation exposure, 121
 Regulatory compliance, 120
 Remote Access Code for Fax, 41
 Remove See Delete
 Removing a memory device from the printer, 50
 Removing the printhead, 84
 Replacing ink cartridges, 79
 Reversing document print order, 97
 Ring pattern, telephone. See Fax
 Rings to Answer, 42

S

Safety
 Environmental, 119
 Parts, 118
 Placing the printer, 119
 Power, 118
 Safety requirements, 118
 Same size copies, 60
 Scale Percent copies, 60
 Scaling copy size, 60
 Scan Destination, 65
 Scan settings, adjusting, 64
 Scanned image is blank, troubleshooting, 102
 Scanner glass, 4
 Cleaning, 76
 Damage, avoiding, 76
 Scanner lid, 4
 cleaning, 77
 Scanning, 62
 Multiple originals, 64
 Problem troubleshooting, 102
 Using Home Center software, 62
 Scene Balance, 52
 Screen, 7
 Select and print all photos, 54
 Selecting fax recipient, from Phonebook, 67
 Selecting printer setup location, 21
 Self-powered USB hub, 92
 Sending faxes, 66, 72, 73
 Service agreements, 76
 Set up a network connection to the printer, 24, 25
 Setting fax dial mode, 41

Settings

- Ethernet, 24
- Network, 24
- Wireless network, 25

Setup, selecting location for the printer, 21

Shared Phone Line, 37

Sizes of copies, 60

Slow printing, troubleshooting, 100

Software See Home Center

Specifying distinctive ring, fax, 41

Specifying rings to answer, fax, 40

Spots on print, 99

SSID, definition, 127

Star 70. See Call-Waiting Disable Code

Start button, 7, 12

Status check, performing, 78

Status lights, 6, 16

Status Monitor, 19

Storing ink cartridges, 79

Subnet, definition, 127

Supplies, ordering, 19

Support, 1, 89

- at Kodak.com, 2
- Telephone numbers
- Web site, 2

System requirements, 116

T

Tagged images, 55

- Printing, 55

Technical Support See Support

Telephone company, when to contact, 41

Telephone ring pattern. See Fax. See also Fax
Auto-Answer

Test page, printing, 78

Thumb drive See Portable storage device

Tone See Fax

Touching the scanner glass, 76

Transfer picture failure, troubleshooting, 94

Transferring photos, 52

Transparency sizes, 117

Troubleshooting

- at Kodak.com, 2
- Camera, 90
- Copy problems, 101
- Cropped picture, 98
- Device not recognized, 90
- Document print order, 97
- Home Center software, 96
- Ink cartridge not recognized, 91
- Macintosh, 95
- Macintosh-formatted USB drive, 90
- Memory cards, 90

No communication with computer, 92

Paper, 95

Paper feed, 91, 93

Paper jam, 93

PictBridge camera, 97

Picture smudged, 98

Print quality, 89

Print skewed or slanted, 99

Print spotted, 99

Print too dark, 100

Print too light, 100

Printer fails to power on, 89

Printer not responding, 94

Printing, 96

Printing stops, 100

Printing too slow, 100

Scanning problems, 102

Status lights, 16

Transfer picture failure, 94

Water inside the printer, 76

White edges on borderless prints, 101

WIA error, 95

Windows Vista, 95

U

Universal serial bus

Definition, 127

Device port, 4

Port, 6

Update, 115

Printer software, firmware, drivers, 2

Updating the User Guide, 95

Upper paper tray, 3

USB

Cable, 92

Card readers, supported, 50

Definition, 127

Device port, 4

Host port, 4

Hub, self-powered, 92

Port, 6

USB 2.0 compliant cables, 90

User Guide

Outdated, 95

Updating, 95

Using

Number keypad, 12

On-screen keyboard, 13

Using Fax Quick Dial, 68

V

Vista troubleshooting, 95

W

- Warranty, 79, 114
- Waste labeling, 120
- Water exposure, troubleshooting, 76
- WEP, definition, 127
- White edges on borderless prints, troubleshooting, 101
- WIA error, troubleshooting, 95
- Wi-Fi Radio, 27
- Wi-Fi Setup Wizard, 27
- Wi-Fi, definition, 127
- Windows
 - Help, 89
 - Home Center software, 19
 - System requirements, 116
- Windows Vista troubleshooting, 95
 - WIA error, 95
- Wireless network status light, 7
- Wireless network, configuring, 25
- Wireless printing, Bluetooth
- WPA, definition, 127
- WPS, definition, 127

Z

- Zoom buttons, 7
- Zooming photos, 56