

XP8103 HELI DATA SHEET VENTURE CP BASIC SETUP

MODEL NO. _____

MODEL NAME _____

MODULATION SPCM - ZPCM - PPM _____

		AILE	ELEV	RUDD	
DUAL-RATE • EXP	0	D/R	90%	90%	90%
		EXP	Adjust as needed		
	1	D/R	100%	100%	100%
		EXP	Adjust as needed		

AUTO D/R (POS. 1)	ST1	INH • ACT
	ST2	INH • ACT
	ST2	INH • ACT

INPUT SEL	AUX2	HOLD SW • PIT.TRIM • INH
	GEAR	ACT • INH

	THRO	AILE	ELEV	RUDD	GEAR	PIT	AUX2	AUX3
REVERSE SW	<input type="radio"/> NORM • <input type="radio"/> REV	<input type="radio"/> NORM • <input type="radio"/> REV	<input type="radio"/> NORM • <input type="radio"/> REV	<input type="radio"/> NORM • <input type="radio"/> REV	<input type="radio"/> NORM • <input type="radio"/> REV	<input type="radio"/> NORM • <input type="radio"/> REV	<input type="radio"/> NORM • <input type="radio"/> REV	<input type="radio"/> NORM • <input type="radio"/> REV
SUB TRIM	Adjust as needed							
TRAVEL ADJUST	Refer to the CCPM section of this manual for proper settings							
FAIL SAFE (SPCM)								

	EXP	L	1	2	3	H	
THROTTLE CURVE	N	OFF • ON	0%	30%	50%	70%	100%
	1	OFF • ON	40%	50%	60%	80%	100%
	2	OFF • ON	Optional				
PITCH CURVE	N	OFF • ON	-2° pitch	%	5° pitch	%	10° pitch
	1	OFF • ON	-5° pitch	%	5° pitch	%	10° pitch
	2	OFF • ON	%	%	%	%	%
	H	OFF • ON	-5° pitch	%	5° pitch	%	13° pitch

GYRO SENS	INH • RUDD D/R • <input type="radio"/> AUTO	0	80%
		1	60%
		<input type="radio"/> NORM	0
		<input type="radio"/> STNT	1
		<input type="radio"/> HOLD	1
		<input type="radio"/> INVT	1

Refer to gyro gain section for settings

THRO HOLD	INH • <input type="radio"/> ACT	POS Set for idle
-----------	---------------------------------	---------------------

THRO HOLD	INH • <input type="radio"/> ACT	OFFSET Adjust as needed
-----------	---------------------------------	----------------------------

REVO MIX	NORMAL	UP	%
		DOWN	%
	STUNT	UP	%
		DOWN	%
ACC MIX			%

Refer to your gyro's instructions for proper settings

	CHANNEL	SW	EXP	L	1	2	3	H
PROGRAM MIX	MIX1	→	OFF-ON					
	MIX2	→	OFF-ON					
			+POS	-POS	OFFSET			
	MIX3	→	%	%				

Swash Type	1 Servo Norm 2 Servo 180° 3 Servo 120° 4 Servo 90°			
	Aile	Elev	Pit	
Exp Act • <input type="radio"/> INH	<input type="radio"/> 70%	<input type="radio"/> 70%	<input type="radio"/> 65%	

XP8103 HELI DATA SHEET VENTURE CP 3D SETUP

MODEL NO. _____

MODEL NAME _____

MODULATION SPCM - ZPCM - PPM _____

			AILE	ELEV	RUDD
DUAL-RATE • EXP	0	D/R	90%	90%	90%
		EXP	Adjust as needed		
	1	D/R	100%	100%	100%
		EXP	Adjust as needed		

AUTO D/R (POS. 1)	ST1	INH • ACT
	ST2	INH • ACT
	ST2	INH • ACT

INPUT SEL	AUX2	HOLD SW • PIT.TRIM • INH
	GEAR	ACT • INH

	THRO	AILE	ELEV	RUDD	GEAR	PIT	AUX2	AUX3
REVERSE SW	NORM • REV	NORM • REV	NORM • REV	NORM • REV	NORM • REV	NORM • REV	NORM • REV	NORM • REV
SUB TRIM	Adjust as needed							
TRAVEL ADJUST	Refer to the CCPM section of this manual for proper settings							
FAIL SAFE (SPCM)								

	EXP	L	1	2	3	H	
THROTTLE CURVE	N	OFF•ON	0%	30%	50%	70%	100%
	1	OFF•ON	100%	80%	50%	80%	100%
	2	OFF•ON	Optional				
PITCH CURVE	N	OFF•ON	-2° pitch	%	5° pitch	%	10° pitch
	1	OFF•ON	10° pitch	%	0° pitch	%	10° pitch
	2	OFF•ON	%	%	%	%	%
	H	OFF•ON	-5° pitch	%	5° pitch	%	13° pitch

GYRO SENS	INH • RUDD D/R • AUTO	0	80%
		1	60%
		NORM	0
		STNT	1
		HOLD	1
		INVT	1

Refer to your gyro's instructions for proper settings

THRO HOLD	INH • ACT	POS Set for idle
THRO HOLD	INH • ACT	OFFSET Adjust as needed

REVO MIX	NORMAL	UP	%
		DOWN	%
	STUNT	UP	%
		DOWN	%
ACC MIX			%

Refer to revolution mixing section for proper settings

		CHANNEL	SW	EXP	L	1	2	3	H
PROGRAM MIX	MIX1	→		OFF-ON					
	MIX2	→		OFF-ON					
	MIX3	→		%	+POS	-POS	OFFSET		

Swash Type	1 Servo Norm 2 Servo 180° 3 Servo 120° 4 Servo 90°			
	Aile	Elev	Pit	
Exp Act • INH	⊕ 70%	⊕ 70%	⊖ 65%	

10X HELI DATA SHEET
VENTURE CP 3D SETUP

MODEL NO. (84) _____

MODEL NAME (81) _____

MODULATION (85) SPCM-ZPCM-PPM _____

	THRO	AILE	ELEV	RUDD	GEAR	PITCH	AUX2	AUX3	AUX4	AUX5
REVERSE SW	<input type="radio"/> N	<input type="radio"/> N	<input type="radio"/> N	<input type="radio"/> N	<input type="radio"/> N	<input type="radio"/> N	<input type="radio"/> N	<input type="radio"/> N	<input type="radio"/> N	<input type="radio"/> N
TRAVEL ADJUST (12)	Refer to the CCPM section of this manual for proper settings									
SUB-TRIM (15)	Adjust as needed									
TRIM RATE (83)	%									

			AILE	ELEV	RUDD
D/R EXP (13)	0	D/R	90%	90%	90%
		EXP	Adjust as needed		
		TYPE			
	1	D/R	100%	100%	100%
		EXP	Adjust as needed		
		TYPE			
2	D/R	Optional			
	EXP				
	TYPE				
AUTO D/R (23)	ST-1	INH- <input type="radio"/> ACT	0 • <input type="radio"/> 1 • <input type="radio"/> 2	0 • <input type="radio"/> 1 • <input type="radio"/> 2	0 • <input type="radio"/> 1 • <input type="radio"/> 2
	ST-2	INH- <input type="radio"/> ACT	0 • 1 • 2	0 • 1 • 2	0 • 1 • 2
	ST-3	INH- <input type="radio"/> ACT	0 • 1 • 2	0 • 1 • 2	0 • 1 • 2
	ST-4	INH- <input type="radio"/> ACT	0 • 1 • 2	0 • 1 • 2	0 • 1 • 2
	HOLD	INH- <input type="radio"/> ACT	0 • <input type="radio"/> 1 • <input type="radio"/> 2	0 • <input type="radio"/> 1 • <input type="radio"/> 2	0 • <input type="radio"/> 1 • <input type="radio"/> 2

THROTTLE HOLD (16)	HOLD SW	INH- <input type="radio"/> HOLD GEAR
	POS	Adjust for Idle
	AUTO CUT	<input type="radio"/> INH- <input type="radio"/> ACT
	Delay	1/4 <input type="radio"/> 1/2 <input type="radio"/> 3/4 <input type="radio"/> 1

FUNCTION SELECT (17)	FLIGHT EXTRA	<input type="radio"/> INH- <input type="radio"/> GEAR AILE	
	GEAR SW	<input type="radio"/> INH- <input type="radio"/> GEAR HOLD	
	AUX2 SW	<input type="radio"/> INH- <input type="radio"/> ACT	
	PIT. LEVER	LOW	<input type="radio"/> INH- <input type="radio"/> ACT
		HI	<input type="radio"/> INH- <input type="radio"/> ACT
ADT STUNT	<input type="radio"/> INH- <input type="radio"/> ACT		

GYRO SENS (44)	INH- <input type="radio"/> AUX 3 AUTO	0	Refer to the Gyro Gain Section of this manual for proper settings					
		1						
		2						
		NR	S1	S2	S3	S4	HD	
		0	1				1	

		CHANNEL		TRIM	SW	OFFSET	+GAIN								-GAIN			
		MASTER	SLAVE				EXP	L	1	2	3	4	5	6	H			
PROGRAM MIX (51) - (58)	1	INH- <input type="radio"/> ACT	→	OFF ON	NR•S1•S2•S3•S4 HD•AX2•GER													
	2	INH- <input type="radio"/> ACT	→	OFF ON	NR•S1•S2•S3•S4 HD•AX2•GER													
	3	INH- <input type="radio"/> ACT	→	OFF ON	NR•S1•S2•S3•S4 HD•AX2•GER													
	4	INH- <input type="radio"/> ACT	→	OFF ON	NR•S1•S2•S3•S4 HD•AX2•GER													
	5	INH- <input type="radio"/> ACT	→	OFF ON	NR•S1•S2•S3•S4 HD•AX2•GER	OFF ON	IN OUT	0										100
	6	INH- <input type="radio"/> ACT	→	OFF ON	NR•S1•S2•S3•S4 HD•AX2•GER	OFF ON	IN OUT	0										100
	7	INH- <input type="radio"/> ACT	→	OFF ON	NR•S1•S2•S3•S4 HD•AX2•GER	OFF ON	IN OUT	0										100
	8	INH- <input type="radio"/> ACT	→	OFF ON	NR•S1•S2•S3•S4 HD•AX2•GER	OFF ON	IN OUT	0										100

10X HELI DATA SHEET

VENTURE CP INITIAL SETUP CONTINUED

		EXP		L	1	2	3	4	5	6	H	
THRO CURVE (18) TH,TRIM=SLOW HOV.T=CENTER	N	OFF ON	IN	0							100	
			OUT	0			50%				100	
			HOV.SEL	—	HOV	HOV	HOV	HOV	HOV	HOV	HOV	—
	1	OFF ON	IN	0								100
			OUT	100%			60%					100
	2	OFF ON	IN	0								100
			OUT									
	3	OFF ON	IN	0								100
			OUT									
	4	OFF ON	IN	0								100
			OUT									
	PITCH CURVE (68) P,TRIM=CENTER HOV.P=CENTER	N	OFF ON	IN	0							100
OUT				-2°Pitch			5°Pitch				10°Pitch	
HOV.SEL				—	HOV	HOV	HOV	HOV	HOV	HOV	HOV	—
1		OFF ON	IN	0								100
			OUT	-10°Pitch			0°Pitch					10°Pitch
2		OFF ON	IN	0								100
			OUT									
3		OFF ON	IN	0								100
			OUT									
4		OFF ON	IN	0								100
			OUT									
HOLD		OFF ON	IN	0								100
	OUT		-5°Pitch				5°Pitch				13°Pitch	
	HOV.SEL		—									

TAIL ROTOR CURVE (47)	N	NOR	IN	L	1	2	3	4	5	6	H
		ORG	OUT								
1	NOR	IN	0								100
		ORG	OUT								
2	NOR	IN	0								100
		ORG	OUT								
3	NOR	IN	0								100
		ORG	OUT								
4	NOR	IN	0								100
		ORG	OUT								

Refer to your gyro's instruction manual for proper settings

MIX RATE: 1/1 • 1/2 • 1/4 • 1/10

TRIM OFFSET (82)	HV.T	HV.P	LO.P	HI.P

Rudder→Throttle 4→1 MIX (41)	R	%
	L	%
MODE SELECTION	NR • S1 • S2 • S3 • S4 • AX2	

FAIL-SAFE (77)	Z	MODE	HOLD • 1.0s • 0.5s • 0.25s
		MEMORY	
	S	MEMORY	

Aileron→Throttle 2→1 MIX (41)	R	%
	L	%
MODE SELECTION	NR • S1 • S2 • S3 • S4 • AX2	

SWASHPLATE MIXING TYPE (65)	1 SERVO • 3SERVO - 120°CCPM		3SERVO - 140°CCPM			
	1 SERVO	ELE → AIL	D		%	
U				%		
AIL → ELE		L		%		
		R		%		
SWITCH	NR • S1 • S2 • S3 • S4 • HD					
3 SERVO 120° CCPM	AIL	+70%	ELE	+70%	PIT	-65%
3 SERVO 140° CCPM	AIL	%	ELE	%	PIT	%

Elevator→Throttle 3→1 MIX (41)	U	%
	D	%
MODE SELECTION	NR • S1 • S2 • S3 • S4 • AX2	

Now that the radio system is completely installed into the helicopter, it is necessary to check and adjust the following:

1. Servo Direction (Servo Reversing)

Check to insure that all servos have been set to the correct direction as shown in programming section, pages 20-22.

2. Dual Rates

It is suggested that for initial flights the Dual Rate function values be set as follows:

- 0 Position (low rate): 90%
- 1 Position (high rate): 100%

3. Exponential Settings

It is suggested that the exponential rate settings remain in the 0 value position until the initial test flights. After initial flights, adjust the exponential values to achieve the desired control feel.

4. Sub-Trim Settings


It is suggested that the correct neutral settings be achieved without the use of the sub-trim feature. If sub-trim is used for final flight adjustments, it is suggested that the sub-trim values not exceed 20. If the sub-trim values are greater, readjust the control linkages and reset the sub-trims to 0.

5. Pitch/Throttle Curve Adjustment

It is very important that the throttle and pitch curves are adjusted properly to achieve the best performance from your helicopter. When properly adjusted, the main rotor head rpm should remain consistent throughout all maneuvers and throttle stick positions. A constant rpm will also help to improve the effectiveness and accuracy of the tail rotor and gyro systems.

A. Pitch Curve Adjustment

It will now be necessary to adjust the main rotor blade pitch to match the settings shown in the chart. A main rotor blade pitch gauge (sold separately) will be necessary for this procedure. Prior to setting the main rotor blade pitch, it will be necessary to first set the required blade pitch at 1/2 (center) stick. Turn the system on and set the collective pitch stick to the center position as in previous steps. If all linkages are properly adjusted, the swashplate/rotor head system should appear as shown in the diagram below. Please note that at the center pitch position, the seesaw mixing arms located on the rotor head are parallel (level) to the seesaw shaft/flybar assembly.




Pitch Range Settings


Flight Mode	Application	Low Pitch (Low Stick)	Hovering Pitch (Half Stick)	High Pitch (High Stick)
N	Hovering	-2°	5°	10°
1	Stunt & Aerobatic Flight	-5°	5°	10°
2	3D Flight	-10°	0°	10°
H	AutoRotation	-5°	5°	13°

Pitch Curve Settings


Hovering (Linear Curve)




Stunt & Aerobatic Flight



3D Flight



Autoration



Venture™ 30 Standard Flight

Once the position of the seesaw mixing arms have been established, attach a main rotor pitch gauge (sold separately) to one rotor blade and check the current pitch setting. The current pitch should be approximately +5 at center stick. If the pitch is slightly less or more, this can be adjusted later through the radio's Pitch Curve function. Attach the pitch gauge to the second main rotor blade and match the pitch at this time.

Venture 30 3D Flight

Once the position of the seesaw mixing arms has been established, attach a main rotor pitch gauge (sold separately) to one rotor blade and check the current pitch setting. Adjust the pitch to the desired setting (0° pitch at center stick) by adjusting the seesaw mixing arm to the main blade holder control rods as shown in Step 4-5. Attach the pitch gauge to the second main rotor blade and match the pitch at this time.

It will now be necessary to establish the maximum pitch value required for your application prior to adjustment. For example, if you are a beginning pilot, then your maximum negative pitch will be -5, and your maximum positive pitch will be +10. The maximum pitch range that you will require will be 15°. If you are a 3D pilot flying the Venture, then your maximum negative pitch will be -10, and your maximum positive pitch will be +10 (+13 for autorotations). The maximum pitch range that you will require will be 23°.

The maximum pitch range mentioned above must be established through the use of the pitch travel value in the CCPM function. Do not try to establish the maximum pitch curve values through adjustment of the Travel Adjustment function, as this will alter the pitch-to-aileron and pitch-to-elevator travel values established in Steps 3-7 and 3-8. Please refer to the CCPM activation section, pages 20-22, for information on how to access the CCPM function.


Once the CCPM function has been activated, set the maximum positive pitch settings as mentioned above. Since the CCPM function does not allow for independent travel settings for positive and negative pitch, it will be necessary to establish the maximum positive pitch, since this is generally the largest degree of pitch in the pitch range. Once the maximum positive pitch range is set, the maximum negative Pitch range can be reduced as needed through the Pitch Curve function.

Set the main rotor pitch gauge to the desired maximum pitch setting, then increase or decrease the CCPM pitch travel (labeled Pitch or Ch6) as needed until this pitch setting is achieved.


B. Throttle Curve Settings

Below are several examples of possible throttle curves during various flight conditions. Since throttle curves can vary greatly due to engine and muffler combinations, it will be necessary to fine tune and adjust these values during test flights to achieve a constant main rotor rpm.


Hovering (Linear Curve)



Stunt & Aerobatic Flight



3D Flight (Optional)




XP652/XP662




Increase or decrease the value as needed.

X-378




Increase or decrease the value as needed.

PCM 10 Series



Increase or decrease the value as needed.

XP8103



Increase or decrease the value as needed.

Once this procedure has been completed, the positive and negative pitch settings for each flight mode can be adjusted through the radio's Pitch Curve function. Please refer to your radio's instruction manual for more information.


It will also be necessary to set the correct idle speed of the engine when the Throttle Hold function is activated. This idle value is located within the Throttle Hold function. This will allow the engine to remain at idle when practicing autorotations.

6. Gyro Gain Adjustment (Dual Remote Gain Gyros only)

It will be necessary to adjust the “gain” or compensation of the gyro to create the correct amount of “holding power” necessary for a solid neutral tail rotor. The intent of the gyro is to compensate for abrupt movements, or wind direction changes.


For hovering, it is recommended that you start with the gyro gain at approximately 80° and continue to increase slightly until the tail of the helicopter “hunts,” then reduce the value slightly.

**PCM 10 Series Radio with G460T,
G550T, and G5000T Gyros**




Press *SEL* to select AUX3 or AUTO GAIN function.


**XP8103 with G460T, G550T,
and G5000T Gyros**



**XP652 with G460T, G550T,
and G5000T Gyros**



**XP652 with G460T, G550T,
and G5000T Gyros**



Change
switch
Position

Please refer to your radio's instructions for more information.

This same adjustment will also be necessary to achieve proper forward flight. Generally, the gyro gain for forward flight will be approximately 10%–20% less than that of the established hover gain due to aerodynamic forces present in forward flight. We have recommended a 60% value as a good starting position.

7. Verifying Gyro Direction

It will also be necessary to confirm the direction the gyro compensates when the body of the helicopter is rotated.

To do this, turn the radio system on and suspend the helicopter by the main rotor head. Next, move the rudder stick to the right and watch the direction that the tail rotor servo arm travels. Now while watching the tail rotor servo arm, rotate the body of the helicopter counterclockwise. The servo arm should move in the same direction as when the rudder stick was moved to the left. If the arm moves in the opposite direction, reverse the gyro and re-test.


FINAL PREFLIGHT CHECK

Once all assemblies have been completed, please review the following suggestions before attempting initial flights.

- Review the instruction book and confirm that all assembly steps have been completed thoroughly.
- Verify that the tail rotor assembly rotates in the correct direction (see the diagram below).
- Verify that the gyro is operational and compensating in the correct direction (detailed in Step 8, page 49).

- Insure that all servos are operating smoothly and in the correct direction. Also verify that there is no binding in the control rods and that each servo horn is secured with a servo horn mounting screw.
- Make sure that both the transmitter and receiver have been fully charged (refer to your radio system instructions for proper charging procedures).
- Insure that the throttle is working properly and in the correct direction.

Correct Main/Tail Rotor Rotation Direction



Rotate the main rotor counterclockwise (backward) and note the rotation of the tail rotor.

BLADE TRACKING ADJUSTMENT

Blade tracking is an adjustment to the main rotor blade pitch that must be accomplished during the initial test flights. Although the blade pitch angle in each blade may appear equal, it is still possible for a set of main rotor blades to run “out of track,” making adjustment necessary. Main rotor blades that are out of track with one another can cause vibration, instability, and a loss of power due to additional drag.

On the initial flight, it will be necessary to increase the blade speed to just before lift-off rpm and view the rotor disc at eye level from a safe distance (approximately 15 to 20 feet).


Note which blade is running low (by colored tracking tape) and increase the pitch of the low blade one turn of the ball link at a time until each blade runs in track (on the same plane).

Please refer to the diagrams below to identify the different tracking situations, as well as several methods to mark each rotor blade for tracking identification.

BLADE TRACKING IDENTIFICATION

Out of Track

Incorrect



In Track


Correct

Adjustment is **not** necessary



Caution: Be sure to maintain a safe distance from the helicopter (15 to 20 feet) when tracking main rotor blades.

Blade Labeling for Tracking Purposes



- A: Use two different blade tracking tape colors (e.g., black and red) at the tip of each main rotor blade.
- B: Use the same color blade tracking tape located at different positions on each rotor blade.

Note: Adding additional blade tracking tape to the rotor blades at this stage will make it necessary to re-static balance the main rotor blades.

Flight Training

Flight Simulators

A model helicopter simulator is *highly recommended* and is an excellent training aid. Simulators like the CSM V10 will help you learn the orientation and inputs needed to fly a model helicopter, without the risk of damaging your model to learn these same reactions. In general, most beginning pilots find that using an RC simulator prior to their first actual flights with their model increase the speed in which they learn, and also decrease the number of crashes associated with learning to fly. Even the most experienced Heli pilots continue to practice with a flight simulator to learn new maneuvers and stick inputs prior to trying these maneuvers with their actual models.

Training Gear

Before you commence, it is also *highly recommended* that you first purchase and install helicopter flight training gear to your Venture to prevent accidental prior to tracking the blades, or attempting to fly the model.

Experienced Help

It is also *highly recommended* if possible that you seek help from an experienced RC helicopter pilot prior to your first flights. Contact your local hobby shop for more information on clubs and pilots in your area.

Where to Fly

It is recommended that for your first flights, you locate a large smooth parking lot or paved surface that is in a private setting. The training gear will allow the model to slide smoothly on a flat hard surface, which will reduce the risk of tipovers while learning. A smooth grass surface will also work if it is not possible to locate a large parking lot, however the training gear will have a tendency to catch in the grass which increases the possibility of a tip over.

When to Fly

For your first flights, it is recommended that you chose a day with calm or no wind as the model will be much easier to control without the additional wind factor. Generally, you will want to pick a day where the wind is below 5 mph if possible for the best results. Please also note that the model should always be positioned nose into the wind for the best results.

Basic Hover Training Practices

Once you have properly tracked the main rotor blades and have tuned the engine as needed, it is now time to move on to the initial flight training practices listed below.

Ground Skating

The first step towards learning to fly is ground skating. The model should be positioned nose into the wind, and the pilots should be located approximately 15-20 feet behind the model, and slightly to the left or right. The tail of the model should always face towards the pilot during these initial flight practices. To start ground skating, simply increase the throttle slowly until the model starts to become light in the training skids. Next, move the cyclic stick forward slightly; the model should slide forward. Begin to skate the model slowly to the left, right, forward and backwards gently until you become familiar with the stick inputs. Once you have become comfortable with this, you can also practice rotating the model to the left and right using the rudder stick. Be careful when doing this; if the model rotates the nose towards you, the cyclic controls will be reversed.

Short Stationary Hovering

Once you have become comfortable with ground skating, your next step is to try to perform a short stationary hover. To do this, increase the throttle slowly until the model starts to lift from the ground. When the model is 1 foot from the ground, gently reduce the throttle so that the model will settle back down gently. Continue this procedure, and try to increase the time that the model remains airborne. It is important that you keep the model within 3 feet of the ground while performing this exercise, as this will prevent an accidental tip over.

Long Stationary Hovering

Once you have become comfortable with the short stationary hover, the next step is to try to increase the length of time that you are able to keep the model in stationary hover. Continue to practice this exercise until you are able to keep the model in a stationary hover for a full tank of fuel.

Traveling Hover

Once you have become comfortable with the long stationary hover, the next step is to try to perform a traveling hover. To do this, lift the model into a stationary hover approximately 1 foot from the ground. Next, move the cyclic stick forward gently, the model will start moving forward. Once the model has traveled 10–15 feet, gently pull back on the cyclic stick until the model returns to stationary hover. Next, gently move the cyclic stick backwards until the model returns to its original position in stationary hover. Repeat this exercise for left and right cyclic as well.

Once you have completed these exercises, you are well on your way to learning to Hover. Please seek advice from an experienced heli pilot in your area on flight progression from this stage forward.

Engine

After each day of flying, fully drain the fuel tank. Then, start the engine and let it idle until the engine and the fuel line are completely burned off. It is also suggested that an after-run oil be used to prevent premature engine corrosion.

Tail Rotor Belt

Periodically check the tension on the tail drive belt (as shown in Step 1-2, page 8) to insure that it has sufficient tension for proper engagement. It is especially important to check this after initial test flights.

Check All Nuts and Bolts

A helicopter is subject to high vibration during flight. It is important to check that all screws, nuts, and bolts are properly secured after each day of flying. It is also suggested that you perform a “quick” inspection between each initial test flight for approximately the first 6–10 flights.

Check Ball Link Wear

Check to insure that all universal links fit freely but securely to the control balls. If there is excessive play noted, replace the universal link in question.

Battery Maintenance

Check to insure that your batteries are properly mounted and charged. The most frequent cause of crashes (aside from pilot error) is battery failure or disconnection. Be certain that your batteries are fully charged and limit your flight time to 3 or 4 flights between charging. If more flight time is required, purchase a reliable quick field charger.

Cleaning

At the end of each flight or flying session, wipe down your helicopter with a clean towel or rag. This is also a good time to inspect all parts for tightness or fatigue. A clean, well-maintained helicopter will provide you with many hours of trouble-free flight.

PROBLEM	CAUSE	CURE
Helicopter vibrates excessively	a. Rotor blades out of balance b. Flybar/paddles not centered c. Engine running roughly d. Excessive clutch run out	Re-balance rotor blades Re-center flybar on rotor head Re-adjust engine lean/rich settings Re-align clutch assembly
Engine runs inconsistent	a. Incorrect fuel mixture b. Fuel line problem c. Glow plug damaged	Re-adjust engine settings Check/replace lines (including inside the tank) Replace glow plug
Main rotor blades do not track	a. Blade pitch not equal b. Blades warped or twisted	Re-set blade pitch w/ gauge and retest Check and replace as needed
Model "wobbles" in hover	a. Rotor rpm too low	Increase throttle at hover or decrease pitch
Clutch grabs when at idle	a. Engine rpm too high b. Engine/clutch mis-aligned	Reduce trim value/engine rpm Re-align and retest
Model will not lift off the ground	a. Engine too rich b. Blade pitch incorrect c. Throttle curve incorrect	Lean needle valve settings Re-check with pitch gauge Re-check throttle curve settings
Model rotates uncontrollably	a. Gyro direction reversed b. Tail servo reversed c. Gyro gain too low d. Main rotor rpm too low	Re-check gyro direction and retry Re-check servo direction and retry Increase gyro gain and retry Increase throttle or decrease pitch
Model constantly drifts in same direction	a. Linkage out of adjustment b. Servo centering not correct c. Trim levers not centered	Re-check linkages per manual Re-check servo neutral and reset Check TX trim lever position

For additional questions, please contact:

Venture Help Line: 217-355-9511

9a.m.–5p.m. Mon–Fri CST


E-mail: venturehelp@horizonhobby.com

PREASSEMBLED COMPONENTS

The following parts included in your kit are preassembled. When maintenance or repair is necessary, please refer to these sections for disassembly or reassembly procedures.



1-1

CLUTCH BELL ASSEMBLY





1-2

TAIL DRIVE PINION/BEARING ASSEMBLY



1-3


ELEVATOR ARM ASSEMBLY



1-4

FUEL TANK ASSEMBLY


Trim to a length of 45 mm before installation.



After assembly, check to be sure the fuel tank clunk can move from the bottom to the top of the tank without touching the back wall of the fuel tank.

2-1

MAIN FRAME SECTION ASSEMBLY




Body Mounting Post, 20 mm (4)











3x14 mm Set Screw (4)

Install the servo mounting plates as shown.




2-2

MAIN FRAME CLUTCH/TAIL PINION/ELEVATOR/FUEL TANK INSTALLATION

-  
3x8 mm Socket Head Bolt (2)
-  
3x15 mm Socket Head Bolt (20)
-  
3 mm Lock Nut (20)
-  
Elevator Arm Bushing 32 mm (1)


Use Blue Threadlock




2-3


FRONT RADIO BED/COOLING FAN SHROUD INSTALLATION




3x10 mm Socket Head Bolt (4)



2.6x10 mm Self-Tapping Screw (4)



2.6x10 mm Self-Tapping Screw (4)




3-1

MAIN DRIVE GEAR/AUTOROTATION ASSEMBLY INSTALLATION



4x4 mm Set Screw (2)




3x22 mm Socket Head Bolt (1)



3mm Lock Nut (1)





Secure the autorotation hub to the main rotor shaft using the 3x22 mm socket head bolt. Next, slide the main shaft collar onto the main rotor shaft. While pulling upward on the main rotor shaft, secure the main shaft collar to the main rotor shaft using the four 4x4 mm set screws.


Use Blue Threadlock



3-2















LANDING GEAR ASSEMBLY INSTALLATION


-  3x8 mm Socket Head Bolt
-  3x12 mm Socket Head Bolt
-  3x4 mm Set Screw
-  3 mm Flat Washer (4)



4-1







FLYBAR CONTROL ARM/SEESAW ARM ASSEMBLY


-   3x16 mm Socket Head Bolt (2)
-   2x10 mm Flat Head Screw (4)
-   2x12 mm Flat Head Screw (2)
-   3 mm Flat Washer (4)
-   2 mm Hex Nut (2)
-   Joint Ball (4)
-   4x4 mm Set Screw (2)



4-2

MAIN BLADE HOLDER ASSEMBLY

-   4 mm Lock Nut (2)
-   Damper Rubber 50° (2)
-   Main Blade Spacer (2)



When removing the main blade holders, it will be necessary to turn the nuts both ends at a time using the two 7 mm hex nut drivers.


It will be necessary to remove one side of the main blade holders to remove the spindle shaft.

4-3

MAIN BLADE HOLDER ASSEMBLY




3x6 mm Self-Tapping Screw (4)




2x10 mm Flat Head Screw (2)



Joint Ball (2)




Main Blade Bearing Spacer, Outer (2)



5x13x4 Shielded Bearing (4)




Main Blade Bearing Spacer, Inner (2)



4-4

WASHOUT ASSEMBLY




3x15 mm Socket Head Bolt (2)



2x10 mm Flat Head Screw (2)



3 mm Flat Washer (2)



Washout Arm Pin (2)




2 mm CA Stopper Ring (4)



Joint Ball (2)

Be careful not to over-tighten the 3x15 mm socket head bolt.

If any clearance is detected between the washout arm and the washer base, an additional nylon washer (t0.13) can be used.



4-5

SWASHPLATE ASSEMBLY



4x4 mm Set Screws (3)

While holding the inside ball race, pivot the swashplate and check for excessive play. Adjust as necessary.


Swashplate Adjustment

The 120° CCPM swashplate is adjustable via the 3–4x4 mm set screws. If excessive play is found in the test above, gently tighten each of the 3–4 mm set screws the same amount and re-test. The swashplate should move freely, but without notable play.

Caution: If the 3–4 mm set screws are over tightened, damage to the swashplate bearings can occur.





Swashplate Adjustment Test




4-6

TAIL PITCH PLATE ASSEMBLY



4-7


SWASHPLATE/WASHOUT ASSEMBLY INSTALLATION



*Washout Assembly Installation

When installing the washout assembly be sure the long flange of the mixing base is positioned downward (toward the swashplate) with the short portion facing upward.




Washout Assembly








The long portion of mixing base flange must face downward.


4-8

ROTOR HEAD INSTALLATION


-  2.6x12 mm Socket Head Bolt (1)
-  3x20 mm Socket Head Bolt (1)
-  3 mm Flat Washer (1)

-  2.6 mm Lock Nut (1)
-  3 mm Lock Nut (1)
-  2x12 mm Flat Head Screw (2)

-  Steel Joint Ball (2)
-  2 mm Hex Nut (2)



Note: Be sure to engage the rotor hub pin into the washout base groove before securing the rotor head in place.




4-9

FLYBAR INSTALLATION


-  4x4 mm Set Screw



Center the flybar in the seesaw shaft before securing the flybar control arm.




Adjust so that A and B are exactly the same length.



4-10

FLYBAR PADDLE ATTACHMENT (TRAINER PADDLES)




Important:

Thread each flybar paddle onto the flybar until the threaded tip of the flybar protrudes approximately 5 mm.

Adjust each flybar paddle so they are parallel to the flybar control arms and to each other.

Note proper direction of each flybar paddle (short section forward, clockwise rotation).

Insert each weight fully to the end so that both ends balance (optional).





4-11

ROTOR HEAD/SWASHPLATE CONTROL ROD INSTALLATION


Important:

Thread each universal link onto the 2.3 mm threaded rod to the length shown below. Note the correct direction of the universal link. Next, install each rod so the JR Propo logo faces outward.




5-1

TAIL GEAR CASE PREPARATION




5-2

TAIL GEAR CASE ASSEMBLY




5-3


TAIL CENTER HUB ASSEMBLY




 3x3 mm Set Screw (2)



 3 mm Lock Nut (2)




 Use Red Threadlock




5-4


TAIL BLADE HOLDER ASSEMBLY




 2x8 mm Flat Head Screw (2)




 2x8 mm Socket Head Bolt (8)




 3x15 mm Socket Head Bolt (2)




 2 mm Hex Nut (8)



 3 mm Lock Nut (2)








 Steel Joint Ball (2)



5-5





TAIL PITCH CONTROL LEVER INSTALLATION


-  2x8 mm Flat Head Screw (1)
-  2x8 mm Socket Head Bolt (1)
-  2 mm Flat Washer (1)
-  Steel Joint Ball (1)




5-6

TAIL BOOM BRACE ASSEMBLY

-  2x8 mm Socket Head Bolt (4)
-  2.6x15 mm Socket Head Bolt (2)
-  2 mm Hex Nut (4)
-  2.6 mm Lock Nut (2)




MAIN ROTOR HEAD ASSEMBLY



MAIN ROTOR HEAD ASSEMBLY PARTS

PART #	DESCRIPTION	COMMENTS/ADDITIONAL CONTENTS	QUANTITY
JRP960729	Flybar Control Arm	Flybar Control Arm	1
		Steel Joint Balls	2
		Flat Head Screw 2x12 mm	2
		2 mm Hex Nuts	2
		4x4 mm Set Screws	2
JRP960060	Flybar 540 mm	Flybar 540 mm (Training)	2
JRP996057	Flybar 410 mm	Flybar 410 mm (3D)	2
JRP980009	2.6x12 mm Socket Head Bolt	2.6x12 mm Socket Head Bolt	10
JRP980060	3x20 mm Socket Head Bolt	3x20 mm Socket Head Bolt	10
JRP980135	Flat Head Screw 2x12 mm	Flat Head Screw 2x12 mm	10
JRP960861	Flybar Paddle	Flybar Paddle	2
		Insert Weight	4
		4x6 mm Set Screw	2
		3mm Lock Nut	2
JRP996067	Seesaw Arm	Seesaw Arm	2
		Seesaw Bearing Inner	2
		Steel Joint Ball	4
		Flat Head Screw M2x10	4
JRP996056	3D Flybar Paddle	3D Flybar Paddle	2
JRP997168	Universal Ball Links, Black	Universal Ball Links, Black	10
JRP997169	Universal Ball Links Short, Black	Universal Ball Links Short, Black	5
JRP980052	Control Rod M2.3x15	Control Rod M2.3x15	2
JRP980041	Control Rod M2.3x20	Control Rod M2.3x20	2
JRP980044	Control Rod M2.3x40	Control Rod M2.3x40	2
RVO0550P	Main Rotor Blade 550 mm	Main Rotor Blade 550 mm	1
JRP980023	Main Blade Bolt	Main Blade Bolt 4x30 mm	2
JRP984024	Main Rotor Head Assembly	Main Rotor Head Assembly	1
JRP960714	One-piece Main Rotor Hub	One-Piece Main Rotor Hub	1
JRP970279	Seesaw Shaft Bolt	Seesaw Shaft Bolt	2
JRP960068	Spindle Shaft	Spindle Shaft	1
JRP960070	Damper Rubber 50 degree	Damper Rubber	2
JRP960071	Damper Collar	Damper Collar	2
JRP970030	Main Blade Bearing Spacer	Inner Bearing Spacer	2
		Outer Bearing Spacer	2
JRP980028	Self-Tapping Screw 3x6 mm	Self Tapping Screw 3x6 mm	10
JRP980040	4 mm Lock Nut	4mm Lock Nut	10
JRP960867	Main Blade Holder	Main Blade Holder	2
		Steel Joint Ball	2
		Flat Head Screw 2x10 mm	2
JRP996067	Seesaw Shaft	Seesaw Shaft	1
		Seesaw Shaft Bolt	2
JRP960740	Head Linkage Set	Control Rod M2.3x40	2
		Control Rod M2.3x20	2
		Control Rod M2.3x15	2
		Ball Links, Long	8
		Ball Links, Short	4
JRP980036	Plate Washers, 3 mm	Plate Washers, 3 mm	10
JRP970002	Joint Balls/2x10 mm Screws	Joint Balls/2x10 mm Screws	10
JRP981004	Ball Bearings, 5x13x4 mm	Ball Bearings, 5x13x4 mm	2
JRP980039	Lock Nuts, 3 mm	Lock Nuts, 3 mm	10
JRP980129	Lock Nuts, 2.6 mm	Lock Nuts, 2.6 mm	10
JRP981032	Washout Arm Bearings	Washout Arm Bearings	2
JRP981038	Seesaw Pivot Bearings	Seesaw Pivot Bearings	2
JRP981049	Seesaw/Flybar Bearings	Seesaw/Flybar Bearings	2
JRP980032	Flat Head Screws, 2x10 mm	Flat Head Screws, 2x10 mm	10
JRP980037	Hex Nuts, 2 mm	Hex Nuts, 2 mm	10
JRP980069	Set Screws, 4x6 mm	Set Screws, 4x6 mm	10
JRP980004	Set Screws, 4x4 mm	Set Screws, 4x4 mm	10


CONTROL SYSTEM ASSEMBLY



CONTROL SYSTEM ASSEMBLY PARTS

PART #	DESCRIPTION	COMMENTS/ADDITIONAL CONTENTS	QUANTITY
JRP960848	V Elevator Arm	Elevator Arm Elevator Arm Bushing Long Ball Arm 14.5 Elevator Arm Pin L32 3 mm Lock Nut 3 mm Flat Washer Swashplate Arm Swashplate Arm Pin	1 2 1 1 1 1 1 1
JRP960022	Swashplate A Arm	Swashplate Arm Swashplate Arm Pin	1 1
JRP970016	Elevator Arm Bushing 32 mm	Elevator Arm Bushing 32 mm	2
JRP970323	Servo Mounting Plate	Servo Mounting Plate	10
JRP970184	Ball Arm 9 mm	Ball Arm 9 mm	1
JRP960860	120 Deg. Swashplate Assembly	120 Deg. Swashplate Assembly Steel Joint Ball Ball Arm 9mm Flat Head Screw 2x10 mm Flat Head Screw 2x12 mm 3x3 mm Set Screw	1 4 3 2 2 3
JRP970078	Joint Ball Spacer, 2.75 mm (3D)	Joint Ball Spacer	2
JRP960013	Washout Base	Washout Base	1
JRP980032	Flat Head Screw, 2x10 mm	Flat Head Screw, 2x10 mm	10
JRP980054	Control Rod M2.3x65	Control Rod M2.3x65	2
JRP980042	Control Rod M2.3x30	Control Rod M2.3x30	2
JRP981015	CA Stopper Ring 2 mm	CA Stopper Ring 2 mm	10
JRP994024	Washout Arm	Washout Arm Washout link Washout Bearing Shaft 4 mm Washout Link Pin Washout Bearing Collar M3x15 CAP.B Steel Joint Ball Flat Head Screw M2x10	2 2 2 2 2 2 2 2
JRP981021	Ball Bearing 4x8x3 mm (L-840ZZ)	Ball Bearing 4x8x3 mm (L-840ZZ)	2
JRP970010	Washout Link	Washout Link Washout Link Pin CA Stopper Ring	2 2 4
JRP997168	Universal Ball Link, Black	Universal Ball Link, Black	10
JRP960009	Main Rotor Shaft	Main Rotor Shaft	1
JRP980041	Control Rod, 2.3x20 mm	Control Rod, 2.3x20 mm	2
JRP980016	Socket Head Bolt, 3x15 mm	Socket Head Bolt, 3x15 mm	10
JRP970002	Joint Balls/2x10 mm Screws	Joint Balls/2x10 mm Screws	10
JRP980027	Self Tapping Screws, 2.6x12 mm	Self Tapping Screws, 2.6x12 mm	10
JRP980035	Plate Washer, 2.6 mm	Plate Washer, 2.6 mm	10
JRP980044	Control Rod, 2.3x40 mm	Control Rod, 2.3x40 mm	2
JRP980037	Hex Nuts, 2 mm	Hex Nuts, 2 mm	10
JRP980067	Set Screws, 3x3 mm	Set Screws, 3x3 mm	10
JRP980135	Flat Head Screw, 2x12 mm	Flat Head Screw, 2x12 mm	10
JRPA215	Heavy-Duty Servo Arms	Heavy-Duty Servo Arms	2


MAIN FRAME/DRIVE GEAR ASSEMBLY



MAIN FRAME/DRIVE GEAR ASSEMBLY PARTS

PART #	DESCRIPTION	COMMENTS/ADDITIONAL CONTENTS	QUANTITY
JRP960850	Main Frame L/R	Main Frame R	1
		Main Frame L	1
JRP980068	3x15 mm Set Screw	3x15 mm Set Screw	10
JRP960232	Body Mounting Standoff L21	Body Mounting Standoff L21	2
JRP980013	3x8 mm Socket Head Bolt	3x8 mm Socket Head Bolt	10
JRP980039	3 mm Lock Nut	3mm Lock Nut	10
JRP960851	Cooling Fan Shroud	Cooling Fan Shroud	1
		2.6x10 mm Self-Tapping Screw	4
		2.6 mm Flat Washers	4
JRP980147	M2.6x10 Self-Tapping Screw	2.6x10 mm Self-Tapping Screw	10
JRP960852	Front Radio Bed	Front Radio Bed	1
		3x10 mm Socket Head Bolts	4
JRP970324	Main Shaft Collar	Main Shaft Collar	1
		4x4 mm Set Screw	2
JRP980004	4x4 mm Set Screw	4x4 mm Set Screw	10
JRP980019	3x22 mm Socket Head Bolt	`	10
JRP960853	Main Drive Gear 88T	Main Drive Gear 88T	1
JRP960854	Autorotation Bearing Assembly	Oneway Bearing	1
		Autorotation Shaft	1
		Autorotation Spacer	2
		CA Stopper Ring 11 mm	1
JRP981048	CA Stopper Ring 11 mm	CA Stopper Ring 11 mm	1
JRP960009	Main Rotor Shaft	Main Rotor Shaft	1
JRP981005	Main Rotor Shaft Bearings	Main Rotor Shaft Bearings	2
JRP980016	Socket Head Bolts, 3x15 mm	Socket Head Bolts, 3x15 mm	10
JRP970025	Switch Damper Rubber	Switch Damper Rubber	4


ENGINE/CLUTCH/TAIL DRIVE PULLEY ASSEMBLY



ENGINE/CLUTCH/TAIL DRIVE PULLEY ASSEMBLY PARTS

PART #	DESCRIPTION	COMMENTS/ADDITIONAL CONTENTS	QUANTITY
JRP981005	Ball Bearing 10x19x7 mm (L-1910ZZ)	Ball Bearing 10x19x7 mm (L-1910ZZ)	2
JRP960847	Clutch Bell Assembly	Clutch Bell Assembly	1
JRP970321	Clutch Lining	Clutch Lining	1
JRP970322	Tail Drive Pinion	Tail Drive Pinion	1
		3x6 mm Socket Head Bolt	1
		3 mm Flat Washer	1
JRP960007	Front Tail Belt Pulley	Front Tail Belt Pulley	1
		3x6 mm Socket Head Bolt	1
		3 mm Flat Washer	1
JRP981006	Ball Bearing 6x19x6 mm (R-1960ZZ)	Ball Bearing 6x19x6 mm (R-1960ZZ)	2
JRP981025	Ball Bearing 5x19x6 mm (635ZZ)	Ball Bearing 5x19x6 mm (635ZZ)	2
JRP980016	3x15 mm Socket Head Bolt	3x15 mm Socket Head Bolt	10
JRP980021	3x30 mm Socket Head Bolt	3x30 mm Socket Head Bolt	10
JRP980033	3mm Spring Washer	3mm Spring Washer	10
JRP960857	Engine Mount .30 (Plastic)	Engine Mount .30	1
JRP996054	Cooling Fan Blades	Fan Blades & Screws	1
JRP996055	Cooling Fan Hub	Cooling Fan Hub	1
JRP996058	Clutch Assembly w/ Bearing	Clutch Assembly w/Bearing	1
		3x12 mm Socket Head Bolt	2
JRP970325	Engine Mount/Frame Washers	Engine Mount/Frame Washers	4
		3x12 mm Socket Head Bolt	4
		3mm Lock Nut	4
JRP960005	Starter Hex Adaptor	Starter Hex Adaptor	1
		4x4 mm Set Screw	1
JRP960471	Starter Shaft	Starter Shaft	1
JRP981007	Ball Bearing 20x32x7 mm (6804ZZ)	Ball Bearing 20x32x7 mm (6804ZZ)	1
JRP980056	Control Rod M2.3x85	Control Rod M2.3x85	2
JRP980004	Set Screws, 4x4 mm	Set Screws, 4x4 mm	10
JRP981028	Clutch Bell Bearing	Clutch Bell Bearing	1
JRP980015	Socket Head Bolts, 3x12 mm	Socket Head Bolts, 3x12 mm	10
JRP980036	Plate Washers, 3 mm	Plate Washers, 3 mm	10
JRP980039	Lock Nuts, 3 mm	Lock Nuts, 3 mm	10
JRP970002	Joint Balls/2x10 mm Screws	Joint Balls/2x10 mm Screws	10
JRP997168	Universal Ball Link, Black	Universal Ball Link, Black	10
JRP960785	Muffler, .30-.36	Muffler, .30-.36	1


BODY SET/FUEL TANK/LANDING GEAR ASSEMBLY



BODY SET/FUEL TANK/LANDING GEAR ASSEMBLY PARTS

PART #	DESCRIPTION	COMMENTS/ADDITIONAL CONTENTS	QUANTITY
JRP960849	Fuel Tank Assembly	Fuel Tank	1
		Fuel Tank Clunk	1
		Nipple	1
		Tank Grommet	1
		Silicone Tube(Small)	1
JRP960336	Tank Mounting Rubber	Tank Mounting Rubber (1 m)	1
JRP970197	Tank Grommet	Tank Grommet	2
JRP960855	Landing Struts	Landing Struts	2
		3x4 mm Set Screw	4
JRP980001	3x4 mm Set Screw	3x4 mm Set Screw	10
JRP960034	Landing Skids	Landing Skids	2
		Landing Skid Caps	4
JRP980015	3x12 mm Socket Head Bolt	3x12 mm Socket Head Bolt	10
JRP980036	3 mm Flat Washer	3 mm Flat Washer	10
JRP982227	Venture 30 Body Set	Body	1
		Canopy	1
		2.3x8 mm Self-Tapping Screw	6
		Rubber Grommet	4
JRP982228	Canopy	Canopy	1
		2.3x8 mm Self-Tapping Screw	6
JRP960856	Landing Gear Dampers	Landing Gear Dampers	4
		3x8 mm Socket Head Bolt	4
		3x12 mm Socket Head Bolt	4
		3mm Flat Washer	4
JRP960072	Rubber Grommet	Rubber Grommet	4
JRP980025	Self-Tapping Screws, 2.3x8 mm	Self-Tapping Screws, 2.3x8 mm	10
JRP980013	Socket Head Bolts, 3x8 mm	Socket Head Bolts, 3x8 mm	10


TAIL BOOM/TAIL FIN/TAIL BRACE ASSEMBLY



TAIL BOOM/TAIL FIN/TAIL BRACE ASSEMBLY PARTS

PART #	DESCRIPTION	COMMENTS/ADDITIONAL CONTENTS	QUANTITY
JRP980129	2.6 mm Lock Nut	2.6 mm Lock Nut	10
JRP980014	3x10 mm Socket Head Bolt	3x10 mm Socket Head Bolt	10
JRP996064	Horizontal Fin	Horizontal Fin	1
JRP960865	Fin Set	Horizontal and Vertical Fins	1
JRP983001	Tail Boom	Tail Boom	1
JRP983077	Tail Brace Set	Tail Brace Tube 430 mm	1
		Tail Brace Connector	2
		3x15 mm Socket Head Bolt	2
		2.6x15 mm Socket Head Bolt	2
		2x8 mm Socket Head Bolt	4
		3 mm Lock Nut	2
		2.6 mm Lock Nut	2
		2 mm Hex Nut	4
JRP960866	Tail Brace Clamp	Tail Brace Clamp U	1
		Tail Brace Clamp L	1
		3x12 mm Socket Head Bolt	2
		3x15 mm Socket Head Bolt	1
		3mm Lock Nut	3
		3mm Flat Washer	2
JRP983078	Tail Control Rod 880mm	Tail Control Rod 880 mm	1
		Universal Link	2
JRP960293	Tail Rod Guide B Set	Tail Rod Guide B Set	4
		Rod Guide	1
		Tail Control Rod Guide B	4
		Tail Control Rod Bush	1
		3x10 mm Socket Head Bolt	1
		2x8 mm Socket Head Bolt	4
JRP983034	Tail Control Tubing 600 mm	Tail Control Tubing 600 mm	2
JRP980024	Self-Tapping Screws, 2x8 mm	Self-Tapping Screws, 2x8 mm	10
JRP980039	Lock Nuts, 3 mm	Lock Nuts, 3 mm	10
JRP997168	Universal Ball Link, Black	Universal Ball Link, Black	10
JRP981015	CA Stopper Ring, 2 mm	CA Stopper Ring, 2 mm	10
JRP980016	CA Stopper Ring, 1.5 mm	CA Stopper Ring, 1.5 mm	10
JRP980036	Plate Washers, 3 mm	Plate Washers, 3 mm	10
JRP980006	Socket Head Bolts, 2x8 mm	Socket Head Bolts, 2x8 mm	10
JRP980010	Socket Head Bolts, 2.6x15 mm	Socket Head Bolts, 2.6x15 mm	10
JRP980037	Hex Nuts, 2 mm	Hex Nuts, 2 mm	10

TAIL CASE/TAIL ROTOR ASSEMBLY



TAIL CASE/TAIL ROTOR ASSEMBLY PARTS

PART #	DESCRIPTION	COMMENTS/ADDITIONAL CONTENTS	QUANTITY
JRP960049	Tail Drive Belt 564 mm	Tail Drive Belt 564 mm	1
JRP960862	Tail Case	Tail Case R Tail Case L Tail Pitch Base 3x8 mm Socket Head Bolt 3x6 mm Socket Head Bolt 2.6x12 mm Socket Head Bolt 2.6 mm Lock Nut	1 1 1 2 3 2 2
JRP981004	Ball Bearing 5x13x4 mm (R-1350ZZ)	Ball Bearing 5x13x4 mm (R-1350ZZ)	2
JRP980012	3x6 mm Socket Head Bolt	3x6 mm Socket Head Bolt	10
JRP970027	Tail Output Shaft	Tail Output Shaft	1
JRP960055	Tail Belt Puller	Tail Belt Pulley Spring Pin 2x13 mm	1 1
JRP970001	Steel Joint Ball A	Steel Joint Ball Flat Head Screw 2x8 mm	10 10
JRP980037	2 mm Hex Nut	2 mm Hex Nut	10
JRP980078	Sping Pin 2x13 mm	Sping Pin 2x13 mm	5
JRP960222	Tail Center Hub B	Tail Center Hub B 3x3 mm Set Screw 3 mm Lock Nut	1 2 2
JRP981022	Ball Bearing 3x8x4 mm (R-830ZZ)	Ball Bearing 3x8x4 mm (R-830ZZ)	2
JRP960863	Tail Blade Holder Set	Tail Blade Holder Set w/Ball Base Tail Blade Holder Set w/o Ball Steel Joint Ball Flat Head Screw 2x8 mm 2x8 mm Socket Head Bolt 2 mm Hex Nut 3x15 mm Socket Head Bolt 3 mm Lock Nut	2 2 2 2 4 4 2 2
JRP960864	Tail Rotor Blade	Tail Rotor Blade	2
JRP960054	Tail Pitch Control Lever	Tail Pitch Control Lever Tail Pitch Lever Bushing 2x20 mm Socket Head Bolt 2 mm Flat Washer Steel Joint Ball Flat Head Screw 2x8 mm Vertical Fin 3x8 mm Socket Head Bolt 3x10 mm Socket Head Bolt 3 mm Lock Nut	1 1 1 1 1 1 1 2 2 2
JRP980067	3x3 mm Set Screw	3x3 mm Set Screw	10
JRP980089	2.6x10 mm Socket Head Bolt	2.6x10 mm Socket Head Bolt	10
JRP960057	Tail Pitch Plate	Tail Pitch Control Plate	1
JRP981049	Ball Bearing 3x6x2.5 mm (L-630ZZ)	Ball Bearing 3x6x2.5 mm (L-630ZZ)	2
JRP960056	Tail Pitch Link	Tail Pitch Link Tail Pitch Link Pin CA Stopper Ring 2mm	2 2 4
JRP960050	Tail Slide Ring Assembly	Tail Slide Ring Tail Slide Ring Sleeve Tail Pitch Plate Tail Pitch Link Tail Pitch Link Pin	1 1 1 2 2
JRP980006	Socket Head Bolts, 2x8 mm	Socket Head Bolts, 2x8 mm	10
JRP980016	Socket Head Bolts, 3x15 mm	Socket Head Bolts, 3x15 mm	10
JRP980039	Lock Nuts, 3 mm	Lock Nuts, 3 mm	10
JRP960051	Tail Rotor Blades (3D)	Tail Rotor Blades (3D)	2
JRP980013	Socket Head Bolts, 3x8 mm	Socket Head Bolts, 3x8 mm	10
JRP980008	Socket Head Bolts, 2x20 mm	Socket Head Bolts, 2x20 mm	10
JRP980034	Plate Washers, 2 mm	Plate Washers, 2 mm	10
JRP960058	Tail Slide Ring	Tail Slide Ring	1
JRP970028	Tail Slide Ring Sleeve	Tail Slide Ring Sleeve	1
JRP960870	Venture 30 Decal Set	Decal A	1
JRP960871	Venture 30 Assembly Manual	Assembly Manual	1

