

Panasonic

Operating Instructions

Digital Cordless Phone

Model No. **KX-TG7331BX**

Digital Cordless Answering System

Model No. **KX-TG7341BX**



Model shown is KX-TG7331.

This unit is compatible with Caller ID. You must subscribe to the appropriate service offered by your service provider/telephone company.

Charge the batteries for about 7 hours before initial use.

Please read these operating instructions before using the unit and save them for future reference.

Table of Contents

Introduction	
Product information	3
Accessory information	4
For your safety	6
Important safety instructions	7
For best performance	7
Preparation	
Controls	9
Display	11
Connections	12
Battery installation and replacement	12
Battery charge	13
Wall mounting	14
Symbols used in these operating instructions	14
Turning the power on/off	15
Setting up the unit before use	15
Making/Answering Calls	
Making calls	17
Answering calls	18
Useful features during a call	19
Handset key lock	20
Handset phonebook	
Handset phonebook	21
Copying phonebook entries	22
Base unit speed dial	
Base unit speed dial	23
Programming	
Programmable settings	24
Special instructions for programmable settings	26
Registering a unit	27
Caller ID Service	
Using Caller ID service	29
Caller list	29
Answering System	
Answering system	31
Turning the answering system on/off	31
Greeting message	32
Listening to messages using the base unit	33
Listening to messages using the handset	33
Remote operation	34
Answering system settings	35
Voice Mail Service	
Voice mail service	38
Intercom/Locator	
Intercom	39
Transferring calls	39
Conference calls	40
Handset locator	41
Useful Information	
Character entry	42
Error messages	44
Troubleshooting	45
Specifications	50
Index	
Index	51

Introduction

Product information

Thank you for purchasing a Panasonic digital cordless phone.

Important:

- The suffix (BX) in the following model numbers will be omitted in these instructions:
KX-TG7331BX/KX-TG7341BX

Model composition

KX-TG7331



Model No.	Base unit	Handset	
	Part No.	Part No.	Quantity
KX-TG7331	KX-TG7331	KX-TGA731	1





KX-TG7341



Model No.	Base unit	Handset	
	Part No.	Part No.	Quantity
KX-TG7341	KX-TG7341	KX-TGA731	1

Introduction

Feature differences

Model No.	Answering system	Intercom	
		 ↔  *1	 ↔  *2
KX-TG7331	—	●	●*3
KX-TG7341	●	●	●*3

*1 Intercom calls can be made between the handset and base unit.

*2 Intercom calls can be made between the handsets.

*3 Intercom calls can be made between the handsets by purchasing and registering one or more optional handsets (page 5).

Accessory information

Supplied accessories

No.	Accessory item/Part number	Quantity
①	AC adaptor for base unit/PQLV207BX	1
②	Telephone line cord	1
③	Rechargeable batteries*1	2
④	Handset cover*2	1

*1 See page 4 for replacement battery information.

*2 The handset cover comes attached to the handset.



Additional/replacement accessories

Please contact your nearest Panasonic dealer for sales information.

No.	Accessory item	Model number
①	DECT repeater	KX-A272

Replacement battery information:

- Replace batteries only with a nickel metal hydride (Ni-MH) type of battery. This model requires 2 AAA (R03) batteries for every handset. For best performance, we recommend using Panasonic rechargeable batteries (Model No. HHR-4MPT).
- Replacement batteries may have a different capacity from that of the supplied batteries.






Expanding your phone system

You can expand your phone system by registering optional handsets (6 max.) to a single base unit.

- Optional handsets may be a different colour from that of the supplied handsets.

Handset (optional): KX-TGA731BX



Introduction

For your safety

To prevent severe injury and loss of life/property, read this section carefully before using the product to ensure proper and safe operation of your product.

WARNING

Power connection

- Use only the power source marked on the product.
- Do not overload power outlets and extension cords. This can result in the risk of fire or electric shock.
- Completely insert the AC adaptor/power plug into the power outlet. Failure to do so may cause electric shock and/or excessive heat resulting in a fire.
- Regularly remove any dust, etc. from the AC adaptor/power plug by pulling it from the power outlet, then wiping with a dry cloth. Accumulated dust may cause an insulation defect from moisture, etc. resulting in a fire.
- Unplug the product from power outlets if it emits smoke, an abnormal smell, or makes an unusual noise. These conditions can cause fire or electric shock. Confirm that smoke has stopped emitting and contact an authorised service centre.
- Never touch the plug with wet hands. Danger of electric shock exists.

Installation

- To prevent the risk of fire or electrical shock, do not expose the product to rain or any type of moisture.
- Do not place or use this product near automatically controlled devices such as automatic doors and fire alarms.

Radio waves emitted from this product may cause such devices to malfunction resulting in an accident.

Operating safeguards

- Unplug the product from power outlets before cleaning. Do not use liquid or aerosol cleaners.
- Do not disassemble the product.
- Do not spill liquids (detergents, cleansers, etc.) onto the telephone line cord plug, or allow it to become wet at all. This may cause a fire. If the telephone line cord plug becomes wet, immediately pull it from the telephone wall jack, and do not use.

Medical

- Consult the manufacturer of any personal medical devices, such as pacemakers or hearing aids, to determine if they are adequately shielded from external RF (radio frequency) energy. (The product operates in the frequency range of 1.88 GHz to 1.90 GHz, and the RF transmission power is 250 mW (max.).)
- Do not use the product in health care facilities if any regulations posted in the area instruct you not to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

CAUTION

Installation and relocation

- Never install telephone wiring during an electrical storm.
- Never install telephone line jacks in wet locations unless the jack is specifically designed for wet locations.

Introduction

- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.
- The AC adaptor is used as the main disconnect device. Ensure that the AC outlet is installed near the product and is easily accessible.
- This product is unable to make calls when:
 - the handset batteries need recharging or have failed.
 - there is a power failure.
 - the key lock feature is turned on.

Battery

- We recommend using the batteries noted on page 4. **USE ONLY rechargeable Ni-MH batteries AAA (R03) size.**
- Do not mix old and new batteries.
- Do not open or mutilate the batteries. Released electrolyte from the batteries is corrosive and may cause burns or injury to the eyes or skin. The electrolyte may be toxic if swallowed.
- Exercise care when handling the batteries. Do not allow conductive materials such as rings, bracelets or keys to touch the batteries, otherwise a short circuit may cause the batteries and/or the conductive material to overheat and cause burns.
- Charge the batteries provided with or identified for use with this product only, in accordance with the instructions and limitations specified in this manual.
- Only use a compatible base unit (or charger) to charge the batteries. Do not tamper with the base unit (or charger). Failure to follow these

instructions may cause the batteries to swell or explode.

Important safety instructions

When using your product, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

1. Do not use this product near water for example, near a bathtub, washbowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
2. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
3. Do not use the telephone to report a gas leak in the vicinity of the leak.
4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.

SAVE THESE INSTRUCTIONS

For best performance

Base unit location/avoiding noise

The base unit and other compatible Panasonic units use radio waves to communicate with each other.

- For maximum coverage and noise-free communications, place your base unit:
 - at a convenient, high, and central location with no obstructions

Introduction

- between the handset and base unit in an indoor environment.
- away from electronic appliances such as TVs, radios, personal computers, wireless devices or other phones.
- avoid facing radio frequency transmitters, such as external antennas of mobile phone cell stations (avoid putting the base unit on a bay window or near a window).
- Coverage and voice quality depends on the local environmental conditions.
- If the reception for a base unit location is not satisfactory, move the base unit to another location for better reception.

Environment

- Keep the product away from electrical noise generating devices, such as fluorescent lamps and motors.
- The product should be kept free from excessive smoke, dust, high temperature, and vibration.
- The product should not be exposed to direct sunlight.
- Do not place heavy objects on the power cord or top of the product.
- When you leave the product unused for a long period of time, unplug the product from the power outlet.
- The product should be kept away from heat sources such as radiators, cookers, etc. It should not be placed in rooms where the temperature is less than 5 °C or greater than 40 °C. Damp basements should also be avoided.
- The maximum calling distance may be shortened when the product is used in the following places: Near obstacles such as hills, tunnels, underground, near metal objects such as wire fences, etc.

- Operating the product near electrical appliances may cause interference. Move away from the electrical appliances.

Routine care

- **Wipe the outer surface of the product with a soft moist cloth.**
- Do not use benzine, thinner, or any abrasive powder.

Notice for product disposal, transfer, or return

- This product can store your private/confidential information. To protect your privacy/confidentiality, we recommend that you erase the information such as phonebook or caller list entries from the memory before you dispose of, transfer, or return the product.

Information on Disposal in other Countries outside the European Union




These symbols are only valid in the European Union. If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.

Preparation

Controls

Base unit


■ KX-TG7331



- 1 Charge contacts
- 2 Speaker
- 3 [▲]/[▼]: To adjust the ringer and speaker volumes.
[←]/[→]: To select the desired ringer tone.
- 4 Dial keypad
- 5 [Ⓜ] (Locator/Intercom)
- 6 In use indicator
- 7 [●] (Redial)
- 8 [P] (Pause)
- 9 Microphone
- 10 [☎] (Speakerphone)
Speakerphone indicator
- 11 [R] (Recall/Flash)
- 12 [⊗] (Mute)
- 13 [→] (Program/Speed dial)

Base unit


■ KX-TG7341



- 1 Charge contacts
- 2 Speaker
- 3 [■] (Stop)
- 4 [×] (Erase)
- 5 [▶] (Play)
Message indicator
- 6 [▲][▼]: To adjust the ringer and speaker volumes.
[←][→]: To select the desired ringer tone or to repeat or skip the recorded messages.
- 7 [Ⓜ] (Answer on)
Answer on indicator
- 8 [Ⓜ] (Locator/Intercom)
- 9 [☎] (Greeting)
- 10 In use indicator
- 11 Dial keypad
- 12 [●] (Redial)
- 13 [P] (Pause)
- 14 Microphone
- 15 [☎] (Speakerphone)
Speakerphone indicator
- 16 [R] (Recall/Flash)
- 17 [⊗] (Mute)
- 18 [→] (Program/Speed dial)

Preparation

Handset




- 1 Speaker
- 2 Soft keys
- 3 [↶] (Talk)
- 4 [☎] (Speakerphone)
- 5 Dial keypad
- 6 [R/⊙]
- R: Recall/Flash
- ⊙: Alarm shortcut key
- 7 Charge indicator
- Ringer indicator
- 8 Receiver
- 9 Display
- 10 [⏻/⊙] (Off/Power)
- 11 Navigator key ([▲]/[▼]/[◀]/[▶])
- ◀ (Volume: [▲]/[▼])
- 12 [C/⊘] (Clear/Mute)
- 13 [INT] (Intercom)
- 14 Microphone
- 15 Charge contacts

Using the navigator key


The handset navigator key can be used to navigate through menus and to select items shown on the display by pressing [▲], [▼], [◀], or [▶].

To adjust the receiver or speaker volume, press [▲] to increase the volume, or press [▼] to decrease the volume repeatedly while talking.



Soft keys

The handset features 3 soft keys. By pressing a soft key, you can select the feature shown directly above it on the display.



Preparation

Display

Handset display items

Item	Meaning
	Within range of a base unit <ul style="list-style-type: none"> When flashing: Handset is searching for base unit. (page 47)
	Handset is accessing base unit. (intercom, paging, changing base unit settings, etc.)
	Handset is on an outside call.
	Missed call* ¹ (page 29)
	<ul style="list-style-type: none"> When displayed next to the battery icon: Answering system is on.*² (page 31) When displayed with a number: New messages have been recorded.*² (page 33)
	Answering system is full.* ²
	Answering system answers calls with a greeting message and caller messages are not recorded.* ² ("Caller's recording time", page 36)
	Battery level
	Alarm is on. (page 26)
	Call privacy mode is on. (page 20)
	Ringer volume (page 24) is off.

Item	Meaning
	New voice mail message received.* ³ (page 38)
IN USE	<ul style="list-style-type: none"> Someone is using the line. Answering system is being used by another handset.*²

*1 Caller ID subscribers only
 *2 KX-TG7341
 *3 Voice mail subscribers only

Soft key icons

Icon	Action
	Returns to the previous screen.
	Displays the menu.
	Accepts the current selection.
	Displays a previously dialed phone number.
	Opens the phonebook.
	Turns the key lock feature off. (page 20)
	Selects a character entry mode.
	Stops recording or playback.* ¹
	Inserts a dialling pause.
	Erases the selected item.
	No function

*1 KX-TG7341


Preparation

Connections

Connect the AC adaptor cord (❶) by pressing the plug firmly (❷). Connect the telephone line cord until it clicks into the base unit and telephone line jack (❸).

Base unit

- Use only the supplied Panasonic AC adaptor PQLV207BX.
- Use only the supplied telephone line cord. Using another telephone line cord may not allow the unit to work properly.



Note:

- The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.)
- The AC adaptor should be connected to a vertically oriented or floor-mounted AC outlet. Do not connect the AC adaptor to a ceiling-mounted AC outlet, as the weight of the adaptor may cause it to become disconnected.

During a power failure


The unit will not work during a power failure. We recommend connecting a corded-type telephone (without AC adaptor) to the same telephone line or to

the same telephone line jack using a T-adaptor.

If you subscribe to a DSL/ADSL service

Please attach a DSL/ADSL filter (contact your DSL/ADSL provider) to the telephone line between the base unit and the telephone line jack in the event of the following:

- noise is heard during conversations.
- Caller ID features do not function properly.



Battery installation and replacement


Important:

- Use the supplied rechargeable batteries (Part No. HHR-55AAAB).
- When installing the batteries:
 - Wipe the battery ends (⊕, ⊖) with a dry cloth.
 - Avoid touching the battery ends (⊕, ⊖) or the unit contacts.
 - Confirm correct polarities (⊕, ⊖).
- When replacing the batteries:
 - USE ONLY rechargeable Ni-MH batteries AAA (R03) size.
 - Do NOT use Alkaline/Manganese/ Ni-Cd batteries.


Preparation

- We recommend using the Panasonic rechargeable batteries noted on page 4, 7.

- 1 Firmly press the notch on the handset cover and slide it in the direction of the arrow.



- 2 Insert the batteries negative (⊖) end first. Close the handset cover.




Important:

- If the handset does not automatically turn on after installing/replacing batteries, press **[*][0]** for about 1 second, or place the handset on the base unit or charger.

Note:

- When replacing batteries, remove the old batteries.



Battery charge

Place the handset on the base unit or charger for about 7 hours before initial use.

- While charging, "Charging" is displayed and the charge indicator on the handset lights up. When the batteries are fully charged, "Charge Completed" displays. The charge indicator stays lit even after the batteries are fully charged.



* Model shown is KX-TG7331.

Note:

- It is normal for the handset to feel warm during charging.
- If you want to use the unit immediately, charge the batteries for at least 15 minutes.
- Clean the charge contacts of the handset, base unit, and charger with a soft, dry cloth once a month. Clean more often if the unit is exposed to grease, dust, or high humidity.

Preparation

Battery level

Battery icon	Battery level
	High
	Medium
	Low <ul style="list-style-type: none"> When flashing: Needs charging.

Panasonic Ni-MH battery performance (supplied batteries)



Operation	Operating time
In continuous use	17 hours max.
Not in use (standby)	150 hours max.

Note:

- It is normal for batteries not to reach full capacity at the initial charge. Maximum battery performance is reached after a few complete cycles of charge/discharge (use).
- Actual battery performance depends on a combination of how often the handset is in use and how often it is not in use (standby).
- Even after the handset is fully charged, the handset can be left on the base unit or charger without any ill effect on the batteries.
- The battery level may not be displayed correctly after you replace the batteries. In this case, place the handset on the base unit or charger and let it charge for at least 7 hours.

Wall mounting

Base unit



Symbols used in these operating instructions

Symbol	Meaning
[]	The words in the brackets indicate button names on the handset and base unit. Example: Unit keys: [↶], [↷⊕]
→	Proceed to the next operation.
“ ”	The words in quotations indicate the menu on the display. Example: “Auto Talk”

Preparation

Symbol	Meaning
[▼]/[▲]: “ ”	Press [▼] or [▲] to select the words in quotations. Example: [▼]/[▲]: “Off”

desired language. → **OK** →
[↵]

Turning the power on/off

Power on

Press [↵] for about 1 second.

Power off

Press [↵] for about 2 seconds.

Dialling mode

If you cannot make calls, change this setting according to your telephone line service. The default setting is “Tone”.
“Tone”: For tone dial service.
“Pulse”: For rotary/pulse dial service.

- 1 [⏏] (middle soft key)
- 2 [▼]/[▲]: “Base Unit Setup” → **OK**
- 3 [▼]/[▲]: “Dial Mode” → **OK**
- 4 [▼]/[▲]: Select the desired setting. → **OK** → [↵]

Setting up the unit before use

Display language

You can select “English”, “العربية”, or “فارسی”.


- 1 [⏏] (middle soft key)
- 2 [▼]/[▲]: “Handset Setup” → **OK**
- 3 [▼]/[▲]: “Display Setup” → **OK**
- 4 [▼]/[▲]: “Select Language” → **OK**
- 5 [▼]/[▲]: Select your desired language. → **OK** → [↵]

Note:

- If you select a language you cannot read: [↵] → [⏏] → [▲] 2 times → **OK** → [▼] 2 times → **OK** 2 times → [▼]/[▲]: Select your

Preparation

Date and time

- 1  (middle soft key)
- 2 **[v]/[▲]**: "Handset Setup" →
OK
- 3 **[v]/[▲]**: "Time Settings" →
OK
- 4 **[v]/[▲]**: "Set Date & Time" →
OK
- 5 Enter the current date, month, and year.
Example: 15 July, 2008
[1][5] [0][7] [0][8]
- 6 Enter the current hour and minute.
Example: 15:30
[1][5] [3][0]
- 7 **OK** → **[↶⊙]**

Note:

- When you select Arabic as the display language, enter the current year, month, and date.
- To correct a digit, press **[←]** or **[→]** to move the cursor to the digit, then make the correction.
- The date and time may be incorrect after a power failure. In this case, set the date and time again.

Making/Answering Calls

Making calls

Using the handset

- 1 Lift the handset and dial the phone number.
 - To correct a digit, press [C/⊗].
- 2 [↶]
- 3 When you finish talking, press [⏏] or place the handset on the base unit or charger.

Using the speakerphone

- 1 Dial the phone number, and press [📞].
 - Speak alternately with the other party.
- 2 When you finish talking, press [⏏].

Note:

- For best performance, use the speakerphone in a quiet environment.
- To switch back to the receiver, press [↶].

Adjusting the receiver or speaker volume

Press [▲] or [▼] repeatedly while talking.

Making a call using the redial list

The last 10 phone numbers dialed are stored in the redial list (each 24 digits max.).

- 1 [📞] (right soft key)
- 2 [▼]/[▲]: Select the desired phone number.
- 3 [↶]

Erasing a number in the redial list

- 1 [📞] (right soft key)

- 2 [▼]/[▲]: Select the desired phone number. → [📞] → [OK]
- 3 [▼]/[▲]: "Yes" → [OK] → [⏏]

Using the base unit

- 1 [📞]
- 2 Dial the phone number.
- 3 When the other party answers, speak into the microphone.
 - Speak alternately with the other party.
- 4 When you finish talking, press [📞].

Note:

- Use the speakerphone in a quiet environment.
- While on a call, you can switch from the base unit to the handset:
 - Press [↶] on the handset, then press [📞] on the base unit.
 - If the handset is on the base unit, simply lift it.

Adjusting the speaker volume

Press [▲] or [▼] repeatedly while talking.

Redialling the last number dialed

[📞] → [📞]

Pause (for PBX/long distance service users)

A pause is sometimes required when making calls using a PBX or long distance service. When storing a calling card access number and/or PIN in the phonebook, a pause is also needed (page 22).

Example: If you need to dial the line access number "0" when making outside calls with a PBX:

Making/Answering Calls

Handset

- 1 [0] → [P]
- 2 Dial the phone number. → [↶]

Base unit

- 1 [☎]
- 2 [0] → [P]
- 3 Dial the phone number.

Note for handset and base unit:

- A 3 second pause is inserted each time [P] on the handset or [P] on the base unit is pressed. Repeat as needed to create longer pauses.

Answering calls

Using the handset

When a call is being received, the ringer indicator on the handset flashes.

- 1 Lift the handset and press [↶] or [☎] when the unit rings.
 - You can also answer the call by pressing any dial key from [0] to [9], [*], or [#]. (Any key answer feature)
- 2 When you finish talking, press [⏏] or place the handset on the base unit or charger.

Auto talk

You can answer calls simply by lifting the handset off the base unit or charger. You do not need to press [↶]. To turn this feature on, see page 24.

Adjusting the handset ringer volume

Press [▲] or [▼] repeatedly to select the desired volume while the handset is ringing for an incoming call.

Note:

- You can also program the handset ringer volume beforehand (page 24).

Using the base unit

When a call is being received, the in use indicator flashes rapidly.

- 1 Press [☎] when the unit rings.
- 2 Speak into the microphone.
- 3 When you finish talking, press [☎].

Adjusting the base unit ringer volume

Press [▲] or [▼] repeatedly to select the desired volume.

- To turn the ringer off, press and hold [▼] until the unit beeps.

Changing the base unit ringer tones

You can change the ringer tone used by the base unit.

■ KX-TG7331

- 1 Press [▲] or [▼] when the base unit is in standby mode.
- 2 Press [◀] or [▶] repeatedly to select the desired ringer tone.

■ KX-TG7341

- 1 Press [▲] or [▼] when the base unit is in standby mode.
- 2 Press [◀◀] or [▶▶] repeatedly to select the desired ringer tone. → [■]

Note:

- You can also select the desired tone by pressing a dial key ([1] – [6]) in step 2.

Making/Answering Calls

Useful features during a call

Mute

While mute is turned on, you can hear the other party, but the other party cannot hear you.

Handset

- 1 Press **[C/⊗]** during conversation.
- 2 To return to the conversation, press **[C/⊗]** again.

Base unit

- 1 Press **[⊗]** during conversation.
 - The speakerphone indicator on the base unit flashes.
- 2 To return to the conversation, press **[⊗]** again.

Recall/flash

[R/⊗] on the handset or **[R]** on the base unit allows you to use the special features of your host PBX such as transferring an extension call, or accessing optional telephone services.

Note:

- To change the recall/flash time, see page 25.

For call waiting or Call Waiting Caller ID service users

To use call waiting, you must first subscribe to the call waiting service of your service provider/telephone company.

This feature allows you to receive calls while you are already talking on the phone. If you receive a call while on the phone, you will hear a call waiting tone. **If you subscribe to both Caller ID and Call Waiting with Caller ID services**, the 2nd caller's information is displayed after you hear the call waiting tone on the handset.

- 1 Press **[R/⊗]** on the handset or **[R]** on the base unit to answer the 2nd call.
- 2 To switch between calls, press **[R/⊗]** on the handset or **[R]** on the base unit.

Note:

- Please contact your service provider/telephone company for details and availability of this service in your area.

Temporary tone dialling (for rotary/pulse service users)

You can temporarily switch the dialling mode to tone when you need to access touch-tone services (for example, telephone banking services).

- 1 Make a call.
- 2 Press **[*]** when prompted to enter your code or PIN, then press the appropriate dial keys.

Note:

- The dialling mode will return to pulse when you hang up.

Making/Answering Calls

Call share

This feature allows you to join an existing outside call.

Handset

To join the conversation, press **[↶]** when the other handset/base unit is on an outside call.

Base unit

To join the conversation, press **[↶]** when the handset is on an outside call.

Call privacy (Handset)

Call privacy allows you to prevent other users from joining your conversations with outside callers. To allow other users to join your conversations, leave this feature off. The default setting is "Off".

- 1 Press **[☰]** during an outside call.
- 2 **[↓]/[↑]**: Select the desired setting.
→ **OK**
 - When this feature is turned on, **☰** is displayed.

Note:

- This feature will turn off after you hang up the call.

Handset key lock

The handset can be locked so that no calls or settings can be made. Incoming calls can be answered, but all other functions are disabled while key lock is on.

To turn key lock on, press **[☰]** (middle soft key) for about 3 seconds.

- **☰** is displayed.
- To turn key lock off, press **[☰]** (middle soft key) for about 3 seconds.



Note:

- Calls to emergency numbers cannot be made until key lock is turned off.


Handset phonebook**Handset phonebook**

The phonebook allows you to make calls without having to dial manually. You can add 100 names and phone numbers.


Adding entries

- 1  (left soft key) → 
- 2 **[v]/[Δ]**: “New Entry” → **OK**
- 3 Enter the party's name (16 characters max.). → **OK**
 - You can change the character entry mode by pressing **1/A/?** (page 42).
- 4 Enter the party's phone number (24 digits max.). → **OK** 2 times
 - To add other entries, repeat from step 3.
- 5 **[*0]**

Finding and calling a phonebook entry**Scrolling through all entries**

- 1  (left soft key)
- 2 **[v]/[Δ]**: Select the desired entry.
 - You can scroll through the phonebook entry by pressing and holding **[v]** or **[Δ]**.
- 3 **[↶]**

Searching by first character (using a dial key)


- 1  (left soft key)
- 2 Press the dial key (**[0]** to **[9]**) which contains the character you are searching for (page 42).
 - Press the same dial key repeatedly to display the first

entry corresponding to each character located on that dial key.


- If there is no entry corresponding to the character you selected, the next entry is displayed.

- 3 **[v]/[Δ]**: Scroll through the phonebook if necessary.
- 4 **[↶]**



Editing entries

- 1 Find the desired entry (page 21). → 
- 2 **[v]/[Δ]**: “Edit” → **OK**
- 3 Edit the name if necessary (16 characters max.; page 42). → **OK**
- 4 Edit the phone number if necessary (24 digits max.). → **OK** 2 times → **[*0]**

Erasing entries**Erasing an entry**

- 1 Find the desired entry (page 21). → 
- 2 **[v]/[Δ]**: “Erase” → **OK**
- 3 **[v]/[Δ]**: “Yes” → **OK** → **[*0]**


Erasing all entries

- 1  (left soft key) → 
- 2 **[v]/[Δ]**: “Erase All” → **OK**
- 3 **[v]/[Δ]**: “Yes” → **OK**
- 4 **[v]/[Δ]**: “Yes” → **OK** → **[*0]**

Handset phonebook

Chain dial

This feature allows you to dial phone numbers in the phonebook while you are on a call. This feature can be used, for example, to dial a calling card access number or bank account PIN that you have stored in the phonebook, without having to dial manually.

- 1 During an outside call, press .
- 2 **[v]/[^]**: Select the desired entry.
- 3 Press **OK** to dial the number.


Note:

- When storing a calling card access number and your PIN in the phonebook as one phonebook entry, press **P** to add pauses after the number and PIN as necessary (page 17).
- If you are using this phone in pulse dialling mode, you may need to press **[*]** to change the dialling mode to tone before chain dialling. When adding entries to the phonebook, we recommend adding **[*]** to the beginning of phone numbers you wish to chain dial (page 21).

Copying phonebook entries

You can copy phonebook entries to the phonebook of another compatible Panasonic handset.



Copying an entry

- 1 Find the desired entry (page 21).
→ .
- 2 **[v]/[^]**: "Copy" → **OK**
- 3 Enter the handset number you wish to send the phonebook entry to.

- When an entry has been copied, "Completed" is displayed.
- To continue copying another entry: **[v]/[^]**: "yes" → **OK**
→ Find the desired entry. → **OK**

4 **[*0]**

Copying all entries

- 1  (left soft key) → .
- 2 **[v]/[^]**: "Copy All" → **OK**
- 3 Enter the handset number you wish to send the phonebook entry to.
 - When all entries have been copied, "Completed" is displayed.

4 **[*0]**

Base unit speed dial**Base unit speed dial**

You can assign one phone number to each of the 10 dial keys ([0] – [9]) on the base unit.

Adding phone numbers to speed dial**Important:**

- Before adding phone numbers, make sure the base unit is not in use.

1 [→]

- The in use indicator flashes.

2 Enter the phone number (24 digits max.).

- If a pause is required for dialling, press [P] where needed (page 17).
- If you enter incorrectly, continue and finish step 4, then start again from step 1.

3 [→]**4** Press a dial key ([0] – [9]).

- A long beep is heard and the in use indicator stops flashing.

Note:

- If a phone number is assigned to a dial key which already contains a phone number, the old number will be erased.
- We recommend you make a note of which phone numbers are stored in which dial keys.

To erase a stored phone number**1** [→] 2 times**2** Press the desired dial key ([0] – [9]).**Making a call using the speed dial keys****1** [☎] → [→]**2** Press the desired dial key ([0] – [9]).**Note:**


- Speed dial numbers can only be dialled from the base unit.

Programming

Programmable settings

You can customise the unit by programming the following features using the handset.

Programming by scrolling through the display menus

- 1  (middle soft key)
- 2 Press [▼] or [▲] to select the desired top-menu. → **OK**
- 3 Press [▼] or [▲] to select the desired item in sub-menu 1. → **OK**
 - In some cases, you may need to select from sub-menu 2. → **OK**
- 4 Press [▼] or [▲] to select the desired setting. → **OK**
 - This step may vary depending on the feature being programmed.
 - To exit the operation, press [**⏏**].

Note:

- For other top-menus, please refer to each chapter.
- In the following table, < > indicates the default settings.
- The current item or setting is highlighted on the display.

Top-menu	Sub-menu 1	Sub-menu 2	Page
Handset Setup	Time Settings	Set Date & Time ^{*1}	16
		Alarm	26
		Time Adjustment ^{*1} <Manual>	26
	Ringer Setup	Ringer Volume <Maximum>	-
		Ringtone ^{*2, *3} <Ringtone 1>	-
		Display Setup	Select Language <English>
		Contrast <Level 3>	-
	Register H.set	-	27
	Keytones ^{*4} <On>	-	-
	Auto Talk ^{*5} <Off>	-	18

Programming

Top-menu	Sub-menu 1	Sub-menu 2	Page
Base Unit Setup ^{*1}	Dial Mode <Tone>	–	15
	Recall/Flash ^{*6} <600 msec.>	–	19
	Area Code	–	27
	Base Unit PIN <0000>	–	27
	Repeater Mode <Off>	–	28

*1 If you program these settings using one of the handsets, you do not need to program the same item using another handset.

*2 If you select one of the melody ringer tones, the ringer tone continues to play for several seconds even if the caller has already hung up. You may either hear a dial tone or no one on the line when you answer the call.

*3 The preset melodies in this product are used with permission of © 2007 Copyrights Vision Inc.

*4 Turn this feature off if you prefer not to hear key tones while you are dialling or pressing any keys, including confirmation tones and error tones.

*5 If you subscribe to a Caller ID service and want to view the caller's information after lifting up the handset to answer a call, turn off this feature.

*6 The recall/flash time depends on your telephone exchange or host PBX. Contact your PBX supplier if necessary.

Programming

Special instructions for programmable settings

Alarm

You can set one of 2 different alarm options (once or daily) at a time for each handset. An alarm sounds at the set time for 3 minutes.

Important:

- Set the date and time beforehand (page 16).

- 1 (middle soft key)
- 2 **[v]/[▲]**: "Handset Setup" → **OK**
- 3 **[v]/[▲]**: "Time Settings" → **OK**
- 4 **[v]/[▲]**: "Alarm" → **OK**
- 5 **[v]/[▲]**: Select the desired alarm option. → **OK**

<p>"Off" Turns alarm off. Press OK again, then press [*0] to exit.</p>
<p>"Once" An alarm sounds once at the set time. Enter the desired date and month. If you select Arabic as the display language, enter the desired month and date.</p>
<p>"Daily" An alarm sounds daily at the set time.</p>

- 6 Set the desired time. → **OK**
- 7 **[v]/[▲]**: Select the desired ringer tone. → **OK** 2 times
 - We recommend selecting a different ringer tone to the one used for outside calls.

- When the alarm is set, is displayed.

8 **[*0]**

Note:

- You can skip to step 4 by pressing **[R/0]** in standby mode.
- To stop the alarm, press any dial key or place the handset on the base unit or charger.
- When the handset is in use, the alarm will not sound until the handset is in standby mode.
- If you select "Once", the setting changes to "Off" after the alarm sounds.
- Even when the ringer volume for outside calls is set to off (page 24), the alarm sound is heard at a low level.

Time adjustment (Caller ID subscribers only)

This feature allows the unit to automatically adjust the date and time each time caller information is received. To use this feature, your caller ID service has to provide caller information, including date and time. Contact your service provider/telephone company for details.

To turn this feature on, select "Caller ID [Auto]". To turn this feature off, select "Manual".

Important:

- To use this feature, set the date and time first (page 16).

- 1 (middle soft key)
- 2 **[v]/[▲]**: "Handset Setup" → **OK**
- 3 **[v]/[▲]**: "Time Settings" → **OK**
- 4 **[v]/[▲]**: "Time Adjustment" → **OK**

Programming

- 5 [▼]/[▲]: Select "Caller ID [Auto]" or "Manual". → **OK**
→ [ⓧ]

Selecting area codes to be deleted automatically

In some situations, phone numbers stored automatically in the caller list (page 29) will include area codes. If you do not want to dial the area codes when making calls from the caller list, you can store the area codes which you want the unit to delete automatically.

Example: You have stored the area code "123". If you make a call from the caller list to the phone number "123-456-7890", the unit dials "456-7890".

- 1 [ⓧ] (middle soft key)
- 2 [▼]/[▲]: "Base Unit Setup" → **OK**
- 3 [▼]/[▲]: "Area Code" → **OK**
- 4 Enter an area code (5 digits max.). → **OK** → [ⓧ]

Changing the base unit PIN (Personal Identification Number)**Important:**

- If you change the PIN, please make note of your new PIN. The unit will not reveal the PIN to you. If you forget your PIN, contact your nearest Panasonic service centre.

- 1 [ⓧ] (middle soft key)
- 2 [▼]/[▲]: "Base Unit Setup" → **OK**
- 3 [▼]/[▲]: "Base Unit PIN" → **OK**
- 4 Enter the current 4-digit base unit PIN (default: "0000").
- 5 Enter the new 4-digit base unit PIN. → **OK** → [ⓧ]

Registering a unit**Operating additional units****Additional handsets**

Up to 6 handsets can be registered to the base unit.

Important:

- The additional handset model recommended for use with this unit is noted on page 5. If another handset model is used, certain operations (handset settings, base unit settings, etc.) may not be available.

Registering a handset to the base unit

The supplied handset and base unit are pre-registered. If for some reason the handset is not registered to the base unit (for example, ⚡ flashes even when the handset is near the base unit), re-register the handset.

- 1 **Handset:**
[ⓧ] (middle soft key)
- 2 [▼]/[▲]: "Handset Setup" → **OK**
- 3 [▼]/[▲]: "Register H.set" → **OK**
- 4 **Base unit:**
Press and hold [ⓧ] for about 5 seconds, until the registration tone sounds.
 - If all registered handsets start ringing, press the same button to stop. Then repeat this step.
 - The next step must be completed within 90 seconds.

Programming

5 Handset:

Wait until "Enter Base PIN" is displayed. → Enter the base unit PIN (default: "0000"). → **OK**

- If you forget your PIN, contact your nearest Panasonic service centre.
- When the handset has been registered successfully, **Y** stops flashing.

Note:

- When you purchase an additional handset, refer to the additional handset's installation manual for registration.

Deregistering a handset

A handset can cancel its own registration (or the registration of another handset) that is stored in the base unit. This allows the handset to end its wireless connection with the system.

- 1 **[M]** (middle soft key)
- 2 **[v]/[Δ]**: "Base Unit Setup" → **OK**
- 3 **[3][3][5]**
- 4 **[v]/[Δ]**: "Deregistration" → **OK**

- The numbers of all handsets registered to the base unit are displayed.

- 5 Select the handset(s) you want to cancel by pressing the desired handset number. → **OK**

- The selected handset number(s) flashes.
- To cancel a selected handset number, press the number again. The number stops flashing.

- 6 **[v]/[Δ]**: "Yes" → **OK**

- A confirmation tone sounds as each handset number disappears.

- The handset does not beep when cancelling its own registration.

7 **[X]**

Increasing the range of the base unit

You can increase the signal range of the base unit by using a DECT repeater. Please use only the Panasonic DECT repeater noted on page 4. Contact your Panasonic dealer for details.

Important:

- Before registering the repeater to this base unit, you must turn the repeater mode on.
- Do not use more than one repeater at a time.

Setting the repeater mode

- 1 **[M]** (middle soft key)
- 2 **[v]/[Δ]**: "Base Unit Setup" → **OK**
- 3 **[v]/[Δ]**: "Repeater Mode" → **OK**
- 4 **[v]/[Δ]**: Select the desired setting. → **OK** → **[X]**

Note:

- After turning the repeater mode on or off, **Y** flashes on the handset momentarily. This is normal and the handset can be used once **Y** stops flashing.

Caller ID Service

Using Caller ID service

Important:

- This unit is Caller ID compatible. To use Caller ID features, you must subscribe to a Caller ID service. Contact your service provider/ telephone company for details.

Caller ID features

When an outside call is being received, the caller's phone number is displayed. Caller information for the last 50 callers is logged in the caller list from the most recent call to the oldest.

- If the unit cannot receive caller information, the following is displayed:
 - **"Out of Area"**: The caller dials from an area which does not provide a Caller ID service.
 - **"Private Caller"**: The caller requests not to send caller information.
- If the unit is connected to a PBX system, caller information may not be properly received. Contact your PBX supplier.

Missed calls

If a call is not answered, the unit treats it as a missed call and **↔** is displayed. This lets you know if you should view the caller list to see who called while you were away.

Even if only one missed call in the caller list is viewed (page 29), **↔** disappears from the display. When you receive another new call, **↔** is displayed again.

Phonebook name display

When caller information is received and it matches a phone number stored in the phonebook, the stored name in the

phonebook is displayed and logged in the caller list.

Caller list

Important:

- Only 1 person can access the caller list at a time.

Viewing the caller list and calling back

- 1 **[MFK]** (middle soft key)
- 2 **[▼]/[▲]**: "Caller List" → **OK**
- 3 Press **[▼]** to search from the most recent call, or press **[▲]** to search from the oldest call.
- 4 To call back, press **[↔]**. To exit, press **[X]**.

Note:

- If the item has already been viewed or answered, "✓" is displayed, even if it was viewed or answered using another handset.
- To erase the item, press **[X]**. → **[▼]/[▲]**: "Yes" → **OK**
- If you do not want to dial the area codes when making calls from the caller list, you can store the area codes which you want the unit to delete automatically (page 27).

Editing a caller's phone number before calling back

- 1 **[MFK]** (middle soft key)
- 2 **[▼]/[▲]**: "Caller List" → **OK**
- 3 **[▼]/[▲]**: Select the desired entry. → **[MFK]**
- 4 **[▼]/[▲]**: "Edit and Call" → **OK**
- 5 Edit the number.

Caller ID Service

- Press dial key ([0] to [9]) to add, [C/ⓧ] to delete.

6 [↶]

Erasing caller information

- 1 [Ⓜ] (middle soft key)
- 2 [▼]/[▲]: "Caller List" → **OK**
- 3 [▼]/[▲]: Select the desired entry.
→ [Ⓜ]
- 4 [▼]/[▲]: Select "Erase" or "Erase All". → **OK**
- 5 [▼]/[▲]: "Yes" → **OK** → [↶]

Storing caller information to the phonebook

- 1 [Ⓜ] (middle soft key)
- 2 [▼]/[▲]: "Caller List" → **OK**
- 3 [▼]/[▲]: Select the desired entry.
→ [Ⓜ]
- 4 [▼]/[▲]: "Add Phonebook" → **OK**
- 5 To store the name, continue from step 3, "Adding entries", page 21.

Answering System

Answering system

Available for:
KX-TG7341

The answering system can answer and record calls for you when you are unavailable to answer the phone. You can also set the unit to play a greeting message but not to record caller messages. Select “**Greeting Only**” as the recording time setting (page 36).

Important:

- Only 1 person can access the answering system (listen to messages, record a greeting message, etc.) at a time.
- When callers leave messages, the unit records the day and time of each message. Make sure the date and time have been set correctly (page 16).
- Answering system announcements are in English only.

Memory capacity

The total recording capacity (including your greeting message) is about 20 minutes. A maximum of 64 messages can be recorded.

Note:

- If message memory becomes full:
 - “**Answer Sys. Full**” is shown on the handset display.
 - the answer on indicator on the base unit flashes rapidly when the answering system is turned on.
- When the message memory becomes full:
 - If you use the pre-recorded greeting message, the unit automatically switches to another pre-recorded

greeting message asking callers to call again later.

- If you recorded your own greeting message, the same message is still announced to callers even though their messages are not recorded.

Turning the answering system on/off

The answering system is preset to on.

Base unit

Press **[OK]** to turn on/off the answering system.

- When the answering system is turned on, the answer on indicator lights up.

Handset

- 1 **[MFK]** (middle soft key)
- 2 **[v]/[^]**: “**Answer System**” → **OK**
- 3 **[v]/[^]**: Select “**Answer On**” or “**Answer Off**”. → **OK** → **[*][0]**

Note:

- When the answering system is turned on, **[OK]** is displayed next to the battery icon.

Call screening

While a caller is leaving a message, you can listen to the message being recorded through both the handset and base unit’s speaker. To adjust speaker volume, press **[^]** or **[v]** repeatedly. You can answer the call by pressing **[hook]** on the handset or **[hook]** on the base unit. Call screening can be set for each handset and/or base unit.

Answering System

Note:

- To turn this feature on/off, see page 37.

Greeting message

When the unit answers a call, callers hear a greeting message. You can record your own greeting message or use a pre-recorded greeting message.

Recording your greeting message

You can record your own greeting message (2 minutes max.).

Base unit

- 1 Press and hold **[☎]** for about 1 second.
 - Speak clearly about 20 cm away from the microphone.
- 2 Press **[■]** to stop recording.

Handset

- 1 **[☎]** (middle soft key)
- 2 **[▼]/[▲]**: "Answer System" → **OK**
- 3 **[▼]/[▲]**: "Record Greeting" → **OK**
- 4 Hold the handset about 20 cm away and speak clearly into the microphone.
- 5 Press **[■]** to stop recording.
- 6 **[⏏]**

Using a pre-recorded greeting message

If you erase or do not record your own greeting message, the unit plays a pre-recorded greeting message for callers

and asks them to leave a message. If the message recording time (page 36) is set to "Greeting Only", caller messages are not recorded and the unit plays a different pre-recorded greeting message asking callers to call again.

Playing back the greeting message

Base unit

Press **[☎]**.

Handset

- 1 **[☎]** (middle soft key)
- 2 **[▼]/[▲]**: "Answer System" → **OK**
- 3 **[▼]/[▲]**: "Play Greeting" → **OK**
- 4 **[⏏]**

Erasing your greeting message

If you erase your own greeting message, the unit plays a pre-recorded greeting message for callers.

Base unit

Press **[☎]**, and then press **[X]** while your greeting message is playing.

Handset

- 1 **[☎]** (middle soft key)
- 2 **[▼]/[▲]**: "Answer System" → **OK**
- 3 **[▼]/[▲]**: "Erase Message" → **OK**
- 4 **[▼]/[▲]**: "Erase Greeting" → **OK**
- 5 **[▼]/[▲]**: "Yes" → **OK** → **[⏏]**

Answering System

Listening to messages using the base unit

When new messages have been recorded, [▶] on the base unit flashes. Press [▶].

- If new messages have been recorded, the base unit plays back new messages.
- If there are no new messages, the base unit plays back all messages.

Note:

- When the answer on indicator on the base unit flashes rapidly, the message memory is full ("Memory capacity", page 31).

Operating the answering system

Key	Operation
[▲] or [▼]	Adjust the speaker volume
[◀◀]	Repeat message (during playback)*1
[▶▶]	Skip message (during playback)
[■]	Stop playback
[X]	Erase currently playing message

*1 If pressed within the first 5 seconds of a message, the previous message is played.

Erasing all messages

Press [X] 2 times while the unit is not in use.

Listening to messages using the handset

When new messages have been recorded, [M] is displayed on the handset with the total number of new messages.

- 1 [M] (middle soft key)
- 2 [▼]/[▲]: "Answer System" → **OK**
- 3 [▼]/[▲]: Select "Play New Msg." or "Play All Msg." → **OK**
- 4 When finished, press [⏏].

Note:

- To switch to the receiver, press [↶].

Operating the answering system

You can also operate the answering system by pressing dial keys or soft keys on the handset.

- [M] (middle soft key) → [▼]/[▲]: "Answer System" → **OK**

Key	Operation
[▲] or [▼]	Adjust the receiver/speaker volume
[1] or [←]	Repeat message (during playback)*1
[2] or [→]	Skip message (during playback)
[3]	Enter the "Settings" menu
[4]	Play new messages
[5]	Play all messages
[6]	Play greeting message
[7][6]	Record greeting message

Answering System

Key	Operation
[8]	Turn answering system on
[9] or	Stop recording Stop playback
[0]	Turn answering system off
[*][4] ^{*2}	Erase currently playing message
[*][5]	Erase all messages
[*][6]	Erase greeting message

*1 If pressed within the first 5 seconds of a message, the previous message is played.

*2 You can also erase as follows:
 → [▼]/[▲]: "Yes" → **OK**

Erasing all messages

- 1 (middle soft key)
- 2 [▼]/[▲]: "Answer System" → **OK**
- 3 [▼]/[▲]: "Erase Message" → **OK**
- 4 [▼]/[▲]: "Erase All" → **OK**
- 5 [▼]/[▲]: "Yes" → **OK** → []

Calling back (Caller ID subscribers only)

If caller information is received for the call, you can call the caller back while listening to a message.

- 1 Press during playback.
- 2 [▼]/[▲]: "Call Back" → **OK**

Editing the number before calling back

- 1 Press during playback.

- 2 [▼]/[▲]: "Edit and Call" → **OK**
- 3 Edit the number. → [

Remote operation

Using a touch-tone phone, you can call your phone number from outside and access the unit to listen to messages or change answering system settings. The unit's voice guidance prompts you to press certain dial keys to perform different operations.

Remote access code

A 3-digit remote access code must be entered when operating the answering system remotely. This code prevents unauthorised parties from listening to your messages remotely.

Important:

- In order to operate the answering system remotely, you must first set a remote access code.

- 1 (middle soft key)
- 2 [▼]/[▲]: "Answer System" → **OK**
- 3 [▼]/[▲]: "Settings" → **OK**
- 4 [▼]/[▲]: "Remote Code" → **OK**
- 5 To turn on remote operation, enter the desired 3-digit remote access code.
 - To turn off remote operation, press [*].
- 6 **OK** → [

Using the answering system remotely

- 1 Dial your phone number from a touch-tone phone.

Answering System

- 2 After the greeting message starts, enter your remote access code.
 - The unit announces the number of new messages.
- 3 Follow the voice guidance prompts as necessary or control the unit using remote commands (page 35).
- 4 When finished, hang up.

Voice guidance

During remote operation, the unit's voice guidance starts and prompts you to press **[1]** to perform a specific operation, or press **[2]** to listen to more available operations.

Remote commands

You can press dial keys to access certain answering system functions without waiting for the voice guidance to prompt you.

Key	Operation
[1]	Repeat message (during playback) ^{*1}
[2]	Skip message (during playback)
[4]	Play new messages
[5]	Play all messages
[6]	Play greeting message
[7]	Record greeting message
[9]	Stop recording Stop playback
[0]	Turn answering system off
[*][4]	Erase currently playing message
[*][5]	Erase all messages
[*][6]	Erase greeting message (during greeting message playback)
[*][#]	End remote operation (or hang up)

^{*1} If pressed within the first 5 seconds of a message, the previous message is played.

Turning on the answering system remotely

If the answering system is off, you can turn it on remotely.

- 1 Dial your phone number from a touch-tone phone.
- 2 Let the phone ring 15 times.
 - A long beep is heard.
- 3 Enter your remote access code within 10 seconds after the long beep.
 - The greeting message is played back.
 - You can either hang up, or enter your remote access code again and begin remote operation (page 34).

Skipping the greeting message to leave a message

You can leave a message just as any outside caller can. Call your phone number from a touch-tone phone. When the answering system picks up, press **[*]** to skip the greeting message and record your message after the beep.

Answering system settings

Number of rings before the unit answers a call


You can change the number of times the phone rings "**Number of Rings**"

Answering System

before the unit answers a call. You can select 2 to 7 rings, or "Auto".

The default setting is "4 Rings".

"Auto": The unit's answering system answers at the end of the 2nd ring when new messages have been recorded, or at the end of the 5th ring when there are no new messages. If you call your phone from outside to listen to new messages (page 34), you know that there are no new messages when the phone rings for the 3rd time. You can then hang up without being charged for the call.

- 1  (middle soft key)
- 2 **[v]/[▲]: "Answer System" → OK**
- 3 **[v]/[▲]: "Settings" → OK**
- 4 **[v]/[▲]: "Number of Rings" → OK**
- 5 **[v]/[▲]: Select the desired setting. → OK → [↶⊙]**

For voice mail service subscribers

To receive voice mail and use answering system properly, please note the following:

- To use the voice mail service (page 38) provided by your service provider/telephone company rather than the unit's answering system, turn off the answering system (page 31).
- To use this unit's answering system rather than the voice mail service provided by your service provider/telephone company, please contact your service provider/telephone company to deactivate your voice mail service.

If your service provider/telephone company cannot do this:

- Set this unit's "Number of Rings" setting so that this unit's answering system answers calls before the voice mail service of your


service provider/telephone company does. It is necessary to check the number of rings required to activate the voice mail service provided by your service provider/telephone company before changing this setting.

- Change the number of rings of the voice mail service so that the answering system can answer the call first. To do so, contact your service provider/telephone company.

Caller's recording time

You can change the maximum message recording time allotted to each caller.

You can also select "Greeting Only" which sets the unit to greet callers but not record messages. The default setting is "3 Minutes".

- 1  (middle soft key)
- 2 **[v]/[▲]: "Answer System" → OK**
- 3 **[v]/[▲]: "Settings" → OK**
- 4 **[v]/[▲]: "Recording Time" → OK**
- 5 **[v]/[▲]: Select the desired setting. → OK → [↶⊙]**

Note:

- You may create your own greeting-only message by following the steps on page 32.
The unit plays the pre-recorded greeting-only message asking callers to call again if your own greeting-only message is not recorded.

Answering System

Call screening

You can set the call screening feature on/off. For details, see page 31.

Base unit

The default setting is off.

To turn call screening on

Press and hold **[■]** until a long beep sounds.

To turn call screening off

Press and hold **[■]** until a short beep sounds.


Handset

The default setting is "On".


- 1 **[■]** (middle soft key)
- 2 **[v]/[▲]**: "Answer System" → **OK**
- 3 **[v]/[▲]**: "Settings" → **OK**
- 4 **[v]/[▲]**: "Call Screening" → **OK**
- 5 **[v]/[▲]**: Select the desired setting.
→ **OK** → **[*0]**

Voice Mail Service

Voice mail service

Voice mail is an automatic answering service offered by your service provider/telephone company. After you subscribe to this service, your service provider/telephone company's voice mail system answers calls for you when you are unavailable to answer the phone or when your line is busy. Messages are recorded by your service provider/telephone company, not your telephone. When you have new messages,  is displayed on the handset depending on your service provider/telephone company. Please contact your service provider/telephone company for details of this service.

Important:

- If  still remains on the display even after you have listened to new messages, turn it off by pressing and holding **[C/⊗]** for 2 seconds.
- To use the voice mail service provided by your service provider/telephone company rather than the unit's answering system, turn off the answering system (page 31). For details, see page 36. (KX-TG7341)

Intercom

Intercom calls can be made:

- between handsets.
- between the handset and base unit.

Note:

- If you receive an outside call while talking on the intercom, you hear interrupt tones.
 - To answer the call with the handset, press [**7**][**0**], then press [**7**].
 - To answer the call with the base unit, press [**4**] 2 times.
- When paging unit(s) for an intercom call, the paged unit(s) beeps for 1 minute.

Making an intercom call

Handset

- 1 [**INT**]
- 2 To page the base unit, press [**0**].
To page a specific handset, enter the handset number.
 - To stop paging, press [**7**][**0**].
- 3 When you finish talking, press [**7**][**0**].

Base unit

- 1 [**7**][**0**]
 - When only 1 handset is registered, the base unit pages the handset automatically.
- 2 To page a specific handset, enter the handset number.
To page all handsets, press [**0**].
 - To stop paging, press [**7**][**0**].
 - When you page all handsets, only the handset user who answers first can take the intercom call.
- 3 When you finish talking, press [**4**].

Note:

- When more than 2 handsets are registered, the base unit pages all handsets a few seconds after pressing [**7**][**0**] in step 1.

Answering an intercom call

Handset

- 1 Press [**7**] to answer the page.
- 2 When you finish talking, press [**7**][**0**].

Base unit

- 1 Press [**7**][**0**] to answer the page.
- 2 When you finish talking, press [**4**].

Note for handset and base unit:

- Even when the ringer volume for outside calls is set to off (page 18, 24), the handset and/or base unit rings at a low level for intercom calls.

Transferring calls

Outside calls can be transferred between 2 handsets, or between the handset and base unit.

Handset

- 1 During an outside call, press [**INT**] to put the call on hold.
- 2 To page the base unit, press [**0**].
To page a specific handset, enter the handset number.
- 3 Wait for the paged party to answer.
 - If the paged party does not answer, press [**INT**] to return to the outside call.
- 4 To complete the transfer, press [**7**][**0**].

Intercom/Locator

- The outside call is routed to the paged party.

Base unit

- 1 During an outside call, press **[M]** to put the call on hold.
- 2 To page a specific handset, enter the handset number.
To page all handsets, press **[0]**.
 - When you page all handsets, only the handset user who answers first can take the transferred call.
- 3 Wait for the paged party to answer.
 - If the paged party does not answer, press **[M]** to return to the outside call.
- 4 To complete the transfer, press **[A]**.
 - The outside call is routed to the handset.

Transferring a call without speaking to the other unit's user

Handset

- 1 During an outside call, press **[INT]** to put the call on hold.
 - **[A]** flashes on the handset display to indicate the outside call is on hold.
- 2 To page the base unit, press **[0]**.
To page a specific handset, enter the handset number.
- 3 **[*][0]**
 - The outside call rings at the paged party.

Base unit

- 1 During an outside call, press **[M]** to put the call on hold.
 - The in use indicator on the base unit flashes to indicate the outside call is on hold.

- 2 To page a specific handset, enter the handset number.
To page all handsets, press **[0]**.

3 [A]

- The outside call rings at the handset.

Note for handset and base unit:

- If the paged party does not answer the call within 1 minute, the call rings at the paging party again.

Answering a transferred call

Handset

Press **[A]** to answer the page.

Base unit

Press **[A]** to answer the page.

Note for handset and base unit:

- After the paging party disconnects, you can talk to the outside caller.

Conference calls

The handset and base unit, or 2 handsets can have a conference call with an outside party.

The following 2 methods are available:

- Another person presses **[A]** on the handset or **[A]** on the base unit while one person is talking with an outside party ("Call share", page 20).
- One person pages another person during an outside call as follows.

Handset

- 1 During an outside call, press **[INT]** to put the call on hold.
- 2 To page the base unit, press **[0]**.
To page a specific handset, enter the handset number.

Intercom/Locator

- 3 Wait for the paged party to answer.
 - If the paged party does not answer, press **[INT]** to return to the outside call.
- 4 To establish a conference call, press **[3]**.
 - To leave the conference, press **[*0]**. The other parties can continue the conversation.

Base unit

- 1 During an outside call, press **[*])** to put the call on hold.
- 2 To page a specific handset, enter the handset number.
To page all handsets, press **[0]**.
 - When you page all handsets, only the handset user who answers first can take the transferred call.
- 3 Wait for the paged party to answer.
 - If the paged party does not answer, press **[*])** to return to the outside call.
- 4 To establish a conference call, press **[3]**.
 - To leave the conference, press **[*])**. The other parties can continue the conversation.

Handset locator

You can locate a misplaced handset by paging it.

- 1 **Base unit:**
Press **[*])** and wait for a few seconds.
 - All registered handsets beep for 1 minute.
- 2 To stop paging:
Base unit:
Press **[*])**.
Handset:
Press **[INT]**, then press **[*0]**.

Note:

- Even when the ringer volume for outside calls is set to off (page 24), the handset rings at a high level for paging.

Useful Information

Character entry

The dial keys are used to enter characters and numbers. Each dial key has multiple characters assigned to it. The available character entry modes are Alphabet (ABC), Numeric (0-9), Arabic/Persian (ا ب ت) and Extended (AĂĂ). When in these entry modes except Numeric, you can select which character is entered by pressing a dial key repeatedly.

- Press [◀] or [▶] to move the cursor.
- Press dial keys to enter characters and numbers.
- Press [C/✕] to erase the character or number highlighted by the cursor. Press and hold [C/✕] to erase all characters or numbers.
- Press [✱] to switch between uppercase and lowercase.
- When entering another character located on the same dial key, operation will differ depending on the display language you select.

English

Press [▶] to move the cursor to the next space, then press the appropriate dial key.

Arabic/Persian

Press [◀] to move the cursor to the next space, then press the appropriate dial key.

Character entry modes

Several character entry modes can be used when entering text. The characters that can be entered depend on the entry mode.

Characters available in each character entry mode

When the unit displays the character entry screen:

1/A/? (right soft key) → [▼]/[▲]: Select a character entry mode. → **OK**

Note:

- When you select Arabic or Persian as the display language, numbers in the character table are displayed in Arabic or Persian.

Alphabet character table (ABC)

0	1	ABC 2	DEF 3	GHI 4	JKL 5	MNO 6	PQRS 7	TUV 8	WXYZ 9
Space	Space #	A B C	D E F	G H I	J K L	M N O	P Q R S	T U V	W X Y Z
0	& ' () *	2	3	4	5	6	7	8	9
	, - . / 1	a b c	d e f	g h i	j k l	m n o	p q r s	t u v	w x y z
		2	3	4	5	6	7	8	9

Useful Information

Numeric entry table (0-9)

0	1	ABC2	DEF3	GHI4	JKL5	MNO6	PQRS7	TUV8	WXYZ9
0	1	2	3	4	5	6	7	8	9

Arabic character table (اﺑﺖ)

- When you select Arabic as the display language, Arabic character table is available.

0	1	ABC2	DEF3	GHI4	JKL5	MNO6	PQRS7	TUV8	WXYZ9
Space .	# Space * () & / . - ,	ث ج ح ﺡ	ا ب پ ت ﺍ ﺏ ﺗ ﺘ	ط ظ ع غ ﻁ ﺿ ﻪ	س ش ص ﺵ ﺹ ﺻ	ذ ز ر ز ﺫ ﺯ ﺭ ﺯ	ي ء ي ﻱ ﺀ ﻱ	م ن ه و ﻡ ﻥ ﻫ ﻭ	ف ق ك ﻑ ﻕ ﻙ

Persian character table (اﺑﺖ)

- When you select Persian as the display language, Persian character table is available.

0	1	ABC2	DEF3	GHI4	JKL5	MNO6	PQRS7	TUV8	WXYZ9
Space .	# Space * () & / . - ,	ث ج ح ﺡ	ا ب پ ت ﺍ ﺏ ﺗ ﺘ	ط ظ ع غ ﻁ ﺿ ﻪ	س ش ص ﺵ ﺹ ﺻ	ذ ز ر ز ﺫ ﺯ ﺭ ﺯ	ي ء ي ﻱ ﺀ ﻱ	م ن ه و ﻡ ﻥ ﻫ ﻭ	ف ق ك ﻑ ﻕ ﻙ

Extended character table (AÄÄ)

0	1	ABC2	DEF3	GHI4	JKL5	MNO6	PQRS7	TUV8	WXYZ9
Space 0	Space # & ' () * , - . / 1	A Ä Å Â Ã Ä Å Æ B C Ç 2	D E È É Ê Ë Ë Ì Í Ï Î Ï 4	G Ğ H I Ì Í Î Ï Ï 4	J K L 5	M N Ñ O Ó Ô Ö Ø 6	P Q R S Ş ß 7	T U Û Ú Ü Û Ü V 8	W Ŵ X Y ŷ Z 9
		a à á â ã ä å æ b c ç 2	d e è é ê ë ë ì í ï î ï 4	g ğ h i Ì Í Î Ï Ï 4	j k l 5	m n ñ o ó ô ö ø 6	p q r s ş ß 7	t u ù ú û ü ü v 8	w Ŵ x y ŷ z 9

- The following are used for both uppercase and lowercase: ø Ş Ŵ ŷ

Useful Information

Error messages

If the unit detects a problem, one of the following messages is shown on the display.

Display message	Cause/solution
Answer Sys. Full *1	<ul style="list-style-type: none"> ● Erase unnecessary messages (page 33, 34).
Check Tel Line	<ul style="list-style-type: none"> ● The supplied telephone line cord has not been connected yet or not connected properly. Check the connections (page 12).
Error *1	<ul style="list-style-type: none"> ● Recording was too short. Try again.
Failed	<ul style="list-style-type: none"> ● Phonebook copy failed (page 22). Confirm the other handset (the receiver) is in standby mode and try again.
Incomplete	<ul style="list-style-type: none"> ● The receiver's phonebook memory is full. Erase the unnecessary phonebook entries from the other handset (the receiver) and try again.
Memory Full	<ul style="list-style-type: none"> ● The phonebook memory is full. Erase unnecessary entries (page 21). ● Message memory is full. Erase unnecessary messages (page 33, 34). *1
No link to base. Reconnect AC adaptor.	<ul style="list-style-type: none"> ● The handset has lost communication with the base unit. Move closer to the base unit and try again. ● Unplug the base unit's AC adaptor to reset the unit. Reconnect the adaptor and try again. ● The handset's registration may have been cancelled. Re-register the handset (page 27).
Use rechargeable battery.	<ul style="list-style-type: none"> ● A wrong type of batteries such as Alkaline or Manganese was inserted. Use only the rechargeable Ni-MH batteries noted on page 4, 12.
You must first subscribe to Caller ID.	<ul style="list-style-type: none"> ● You must subscribe to a Caller ID service. Once you receive caller information after subscribing to a Caller ID service, this message will not be displayed.


*1 KX-TG7341

Useful Information

Troubleshooting

If you still have difficulties after following the instructions in this section, disconnect the base unit's AC adaptor and turn off the handset, then reconnect the base unit's AC adaptor and turn on the handset.

General use



Problem	Cause/solution
The unit does not work.	<ul style="list-style-type: none"> • Make sure the batteries are installed correctly (page 12). • Fully charge the batteries (page 13). • Check the connections (page 12). • Unplug the base unit's AC adaptor to reset the unit and turn off the handset. Reconnect the adaptor, turn on the handset and try again. • The handset has not been registered to the base unit. Register the handset (page 27).
I cannot hear a dial tone.	<ul style="list-style-type: none"> • The base unit's AC adaptor or telephone line cord is not connected. Check the connections. • If you are using a splitter to connect the unit, remove the splitter and connect the unit to the wall jack directly. If the unit operates properly, check the splitter. • Disconnect the base unit from the telephone line and connect the line to a known working telephone. If the working telephone operates properly, contact our service personnel to have the unit repaired. If the working telephone does not operate properly, contact your service provider/telephone company.
The handset phonebook entries I copied are not displayed correctly.	<ul style="list-style-type: none"> • Undisplayable characters are replaced with spaces for entries copied from/to additional handsets other than KX-TGA731BX.
I do not know how to erase → (Missed call) from the display.	<ul style="list-style-type: none"> • There are unviewed missed calls remaining. View them and erase → in the following way. <ol style="list-style-type: none"> 1  (middle soft key) 2 [▼]/[▲]: "Caller List" → OK 3 Press [▼] to search from the most recent call, or press [▲] to search from the oldest call.

Useful Information

Programmable settings

Problem	Cause/solution
I have changed the display language to a language I cannot read.	<ul style="list-style-type: none"> Change the display language (page 15).
While programming, the handset starts to ring.	<ul style="list-style-type: none"> A call is being received. Answer the call and start again after hanging up.
I cannot register a handset to a base unit.	<ul style="list-style-type: none"> The maximum number of handsets (6) is already registered to the base unit. Cancel unused handset registrations from the base unit (page 28). You entered the wrong PIN. If you forget your PIN, contact your nearest Panasonic service centre. Place the handset and the base unit away from other electrical appliances.

Battery recharge

Problem	Cause/solution
The handset beeps and/or  flashes.	<ul style="list-style-type: none"> Battery charge is low. Fully charge the batteries (page 13).
I fully charged the batteries, but  still flashes.	<ul style="list-style-type: none"> Clean the charge contacts and charge again (page 13). It is time to replace the batteries (page 12).
I fully charged the batteries, but the operating time seems to be shorter.	<ul style="list-style-type: none"> Clean the battery ends (+, -) and the charge contacts with a dry cloth, and charge again.
The handset display is blank.	<ul style="list-style-type: none"> The handset is not turned on. Turn the power on (page 15).

Useful Information

Making/answering calls, intercom

Problem	Cause/solution
<p>☐ is flashing.</p>	<ul style="list-style-type: none"> ● The handset is not registered to the base unit. Register it (page 27). ● The handset is too far from the base unit. Move closer. ● The base unit's AC adaptor is not connected. Check the connections. ● You are using the handset or base unit in an area with high electrical interference. Reposition the base unit and use the handset away from sources of interference.
<p>Noise is heard, sound cuts in and out.</p>	<ul style="list-style-type: none"> ● You are using the handset or base unit in an area with high electrical interference. Reposition the base unit and use the handset away from sources of interference. ● Move closer to the base unit. ● If you use a DSL/ADSL service, we recommend connecting a DSL/ADSL filter between the base unit and the telephone line jack. Contact your DSL/ADSL provider for details.
<p>The handset does not ring.</p>	<ul style="list-style-type: none"> ● The ringer volume is turned off. Adjust ringer volume (page 24).
<p>The base unit does not ring.</p>	<ul style="list-style-type: none"> ● The ringer volume is turned off. Adjust ringer volume (page 18).
<p>I cannot make a call.</p>	<ul style="list-style-type: none"> ● The dialling mode may be set incorrectly. Change the setting (page 15). ● The handset is too far from the base unit. Move closer and try again. ● Another unit is in use. Wait and try again later. ● Answering system is being used by another handset.*¹ Wait and try again later. ● The key lock feature is turned on. Turn it off (page 20).

*1 KX-TG7341

Useful Information

Caller ID

Problem	Cause/solution
Caller information is not displayed.	<ul style="list-style-type: none"> You must subscribe to a Caller ID service. Contact your service provider/telephone company for details. If your unit is connected to any additional telephone equipment, remove and plug the unit directly into the wall jack. If you use a DSL/ADSL service, we recommend connecting a DSL/ADSL filter between the base unit and the telephone line jack. Contact your DSL/ADSL provider for details. Other telephone equipment may be interfering with this unit. Disconnect the other equipment and try again.
Caller information is slow to display.	<ul style="list-style-type: none"> Depending on your service provider/telephone company, the unit may display the caller's information at 2nd ring or later. Move closer to the base unit.
Time on the unit has shifted.	<ul style="list-style-type: none"> Incorrect time information from incoming Caller ID changes the time. Set the time adjustment to off (page 26).

Answering system (KX-TG7341)

Problem	Cause/solution
The unit does not record new messages.	<ul style="list-style-type: none"> The answering system is turned off. Turn it on (page 31). The message memory is full. Erase unnecessary messages (page 33). The recording time is set to "Greeting only". Change the setting (page 36). If you subscribe to the voice mail service, messages are recorded by your service provider/telephone company not your telephone. Change the unit's number of rings setting or contact your service provider/telephone company (page 35).
My own greeting message cannot be properly heard.	<ul style="list-style-type: none"> Record your own greeting message again (page 32).

Useful Information

Problem	Cause/solution
I cannot operate the answering system.	<ul style="list-style-type: none"> • Someone is using the unit. Wait for the other user to finish. • A caller is leaving a message. Wait for the caller to finish. • The handset is too far from the base unit. Move closer.
I cannot operate the answering system remotely.	<ul style="list-style-type: none"> • You are entering the wrong remote access code. If you have forgotten your remote access code, enter the remote access code setting to check your current code (page 34). • Press each key firmly. • The answering system is turned off. Turn it on (page 35). • You are using a rotary/pulse telephone. Try again using a touch-tone phone.
While recording a greeting message or listening to messages, the unit rings and recording stops.	<ul style="list-style-type: none"> • A call is being received. Answer the call and try again later.

Liquid damage

Problem	Cause/solution
Liquid or other form of moisture has entered the handset/base unit.	<ul style="list-style-type: none"> • Disconnect the AC adaptor and telephone line cord from the base unit. Remove the batteries from the handset and leave to dry for at least 3 days. After the handset/base unit are completely dry, reconnect the AC adaptor and telephone line cord. Insert the batteries and charge fully before use. If the unit does not work properly, contact your nearest Panasonic service centre.

Caution:

- To avoid permanent damage, do not use a microwave oven to speed up the drying process.

Useful Information

Specifications

- **Standard:**
DECT (Digital Enhanced Cordless Telecommunications),
GAP (Generic Access Profile)
- **Number of channels:**
120 Duplex Channels
- **Frequency range:**
1.88 GHz to 1.90 GHz
- **Duplex procedure:**
TDMA (Time Division Multiple Access)
- **Channel spacing:**
1,728 kHz
- **Bit rate:**
1,152 kbit/s
- **Modulation:**
GFSK (Gaussian Frequency Shift Keying)
- **RF transmission power:**
Approx. 10 mW (average power per channel)
- **Voice coding:**
ADPCM 32 kbit/s
- **Power source:**
220–240 V AC, 50/60 Hz
- **Power consumption:**
Base unit^{*1}:
Standby: Approx. 2.3 W
Maximum: Approx. 6.0 W
Base unit^{*2}:
Standby: Approx. 2.4 W
Maximum: Approx. 6.1 W
- **Operating conditions:**
5 °C–40 °C, 20 %–80 % relative air humidity (dry)
- **Dimensions:**
Base unit: Approx. 64 mm × 149 mm × 128 mm
Handset: Approx. 150 mm × 48 mm × 35 mm

■ Mass (weight):

Base unit^{*1}: Approx. 260 g

Base unit^{*2}: Approx. 270 g

Handset: Approx. 130 g

*1 KX-TG7331


*2 KX-TG7341

Note:

- Design and specifications are subject to change without notice.
- The illustrations in these instructions may vary slightly from the actual product.

Index

- A** Additional handsets: 27
- Alarm: 26
- Answering calls
 - Base unit: 18
 - Handset: 18
- Answering system: 31
 - Call screening: 31, 37
 - Erasing messages: 33, 34, 35
 - Greeting only: 36
 - Listening to messages: 33, 34
 - Number of rings: 35
 - Recording time: 36
 - Remote access code: 34
 - Remote operation: 34
 - Turning on/off: 31, 33, 35
- Area code: 27
- Auto talk: 18, 24
- B** Battery: 12, 14
- C** Caller ID service: 29
- Caller list: 29
- Caller list edit: 29
- Call privacy: 20
- Call share: 20
- Call waiting: 19
- Call Waiting Caller ID: 19
- Chain dial: 22
- Character entry: 42
- Conference calls: 40
- D** Date and time: 16
- Dialling mode: 15
- Display
 - Contrast: 24
 - Language: 15
- E** Error messages: 44
- H** Handset
 - Deregistration: 28
 - Locator: 41
 - Registration: 27
- I** Intercom: 39
- K** Key lock: 20
- Keytones: 24
- M** Making calls
 - Base unit: 17
 - Handset: 17
- Missed calls: 29
- Mute: 19
- P** Pause: 17
- Phonebook: 21
- Phonebook copy: 22
- PIN: 27
- Power failure: 12
- Power on/off: 15
- R** Recall/flash: 19, 25
- Redialling: 17
- Repeater: 28
- Ringer tone
 - Base unit: 18
 - Handset: 24
- S** Speakerphone: 17
- Speed dial: 23
- T** Temporary tone dialling: 19
- Time adjustment: 26
- Transferring calls: 39
- Troubleshooting: 45
- V** Voice mail: 38
- Volume
 - Receiver: 17
 - Ringer (Base unit): 18
 - Ringer (Handset): 18, 24
 - Speaker: 10, 17
- W** Wall mounting: 14





For your future reference

We recommend keeping a record of the following information to assist with any repair under warranty.

Serial No.	Date of purchase
(found on the bottom of the base unit)	
Name and address of dealer	

Attach your purchase receipt here.



Panasonic Communications Co., Ltd.

1-62, 4-chome, Minoshima, Hakata-ku, Fukuoka 812-8531, Japan

Copyright:

This material is copyrighted by Panasonic Communications Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic Communications Co., Ltd.

© Panasonic Communications Co., Ltd. 2008



TG7331 BX

PNQX1230ZA CC0808DG0

