
PREFACE

This Service Manual describes the technical features and servicing procedures for the KYMCO *MX'er* 125/150.

Section 1 contains the precautions for all operations stated in this manual. Read them carefully before starting any operation.

Section 2 is the removal/installation procedures for the frame covers which are subject to higher removal/installation frequency during maintenance and servicing operations.

Section 3 describes the inspection/adjustment procedures, safety rules and service information for each part, starting from periodic maintenance.

Sections 4 through 17 give instructions for disassembly, assembly and inspection of engine, chassis frame and electrical equipment.

Most sections start with an assembly or system illustration and troubleshooting for the section. The subsequent pages give detailed procedures for the section.

The information and contents included in this manual may be different from the motorcycle in case specifications are changed.

TABLE OF CONTENTS

ENGINE	GENERAL INFORMATION	1
	FRAME COVERS/EXHAUST MUFFLER	2
	INSPECTION/ADJUSTMENT	3
	LUBRICATION SYSTEM	4
	FUEL SYSTEM	5
	ENGINE REMOVAL/INSTALLATION	6
	CYLINDER HEAD/VALVES	7
	CYLINDER/PISTON	8
	DRIVE AND DRIVEN PULLEYS	9
	FINAL REDUCTION/TRANSMISSION SYSTEM	10
	CRANKCASE/CRANKSHAFT/BALANCE SHAFT	11
CHASSIS	FRONT WHEEL/FRONT BRAKE/FRONT SUSPENSION/STEERING SYSTEM	12
	REAR WHEEL /SWING ARM/HYDRAULIC BRAKE	13
ELECTRICAL EQUIPMENT	BATTERY/CHARGING SYSTEM/A.C. GENERATOR	14
	IGNITION SYSTEM	15
	STARTING SYSTEM	16
	LIGHTS/SWITCHES	17
ONLY ATV ON ROAD AVAILABLE		18


KWANG YANG MOTOR CO., LTD.
OVERSEAS SALES DEPARTMENT
OVERSEAS SERVICE SECTION

GENERAL INFORMATION



SERIAL NUMBER-----	1- 1
SPECIFICATIONS-----	1- 2
SERVICE PRECAUTIONS-----	1- 4
TORQUE VALUES-----	1-12
SPECIAL TOOLS-----	1-14
LUBRICATION POINTS-----	1-15
CABLE & HARNESS ROUTING-----	1-18
WIRING DIAGRAM-----	1-22
TROUBLESHOOTING-----	1-23

1. GENERAL INFORMATION

SERIAL NUMBER



Location of Frame Serial Number



Location of Engine Serial Number

1. GENERAL INFORMATION

Cooling Type

Forced air cooling

SPECIFICATIONS

Name & Model No.		LA30AA, AB		
Motorcycle Name & Type		MX'er		
Overall length (mm)		1600		
Overall width (mm)		980		
Overall height (mm)		990		
Wheel base (mm)		1120		
Engine type		O.H.C.		
Displacement (cc)		149.4		
Fuel Used		92# nonleaded gasoline		
Net weight (kg)	Front wheel	74		
	Rear wheel	78		
	Total	152		
Gross weight(kg)	Front wheel	80		
	Rear wheel	82		
	Total	162		
Tires	Front wheel	20*7-8		
	Rear wheel	22*10-8		
Ground clearance (mm)		130		
Performance	Breaking distance (m)(ANSI)	20.6 below		
	Min. turning radius (m)	3		
Engine	Starting system		Starting motor	
	Type		Gasoline, 4-stroke	
	Cylinder arrangement		Single cylinder	
	Combustion chamber type		Semi-sphere	
	Valve arrangement		O.H.C., chain drive	
	Bore x stroke (mm)		62 x 49.5	
	Compression ratio		9.7:1	
	Compression pressure (kg/cm ²)		16.0	
	Max. output (ps/rpm)		11/7500	
	Max. torque (kg m/rpm)		1.1/5500	
	Port timing	Intake (1mm)	Open	5.5° BTDC
			Close	27.5° ABDC
		Exhaust (1mm)	Open	36° BBDC
			Close	4° ATDC
	Valve clearance (cold) (mm)	Intake	0.06	
		Exhaust	0.06	
	Idle speed (rpm)		1700rpm	
	Lubrication System	Lubrication type		Forced pressure & wet sump
		Oil pump type		Inner/outer rotor type
		Oil filter type		Full-flow filtration
Oil capacity		1.0 liter		
Oil exchanging capacity		0.9 liter		

Fuel System	Air cleaner type & No		Sponge	
	Fuel capacity		8.1 liters	
	Carburetor	Type	PD	
		Float lever	14.8mm	
		Venturi dia.(mm)	φ25	
Throttle type		PISTON		
Electrical Equipment	Type		CDI	
	Ignition timing		15°BTDC/1700rpm	
	Contact breaker		Non-contact point type	
	Spark plug		NGK	
			CR8E	
	Spark plug gap		0.6 0.7mm	
Battery	Capacity	12V8AH		
Power Drive System	Clutch	Type	CVT	
	Transmission Gear	Type	Helical gear	
		Operation	Automatic centrifugal type	
	Reduction Gear	Type	Chain drive	
		Reduction ratio	1st	2.8-0.95
2nd	7.226			
Counter gear ratio		26.902		
Moving Device	Front Axle	Caster angle		
		Trail length		
	Tire pressure (kg/cm ²)	Front	0.2	
		Rear	0.25	
	Turning angle	Left	44°	
		Right	44°	
Brake system type		Rear	Disk brake Drum brake	
Damping Device	Front		Drum brake	
	Suspension type		Front	Swing
	Rear		Swing arm	
	Shock type	Front	Swing	
Rear		Swing arm		
Frame type		SP pipe		

1. GENERAL INFORMATION


SPECIFICATIONS

Name & Model No.		LA25AB		
Motorcycle Name & Type		MX'er		
Overall length (mm)		1685		
Overall width (mm)		980		
Overall height (mm)		990		
Wheel base (mm)		1120		
Engine type		OHC		
Displacement (cc)		124		
Fuel Used		92# nonleaded gasoline		
Net weight (kg)	Front wheel	74		
	Rear wheel	78		
	Total	152		
Gross weight(kg)	Front wheel	80		
	Rear wheel	82		
	Total	162		
Tires	Front wheel	20*7-8		
	Rear wheel	22*10-8		
Ground clearance (mm)		130		
Performance	Breaking distance (m)(ANSI)	20.6 below		
	Min. turning radius (m)	2.5		
Engine	Starting system		Starting motor	
	Type		Gasoline, 4-stroke	
	Cylinder arrangement		Single cylinder	
	Combustion chamber type		Semi-sphere	
	Valve arrangement		O.H..C., chain drive	
	Bore x stroke (mm)		56.5 x 49.5	
	Compression ratio		9.2:1	
	Compression pressure (kg/cm ²)		14.0	
	Max. output (ps/rpm)		9.8/7500	
	Max. torque (kg m/rpm)		0.98/5500	
	Port Timing	Intake (1mm)	Open	5.5° BTDC
			Close	27.5° ABDC
		Exhaust (1mm)	Open	36° BBDC
			Close	4° ATDC
	Valve clearance (cold) (mm)	Intake	0.06	
		Exhaust	0.06	
	Idle speed (rpm)		1700rpm	
	Lubrication System	Lubrication type		Forced pressure & wet sump
		Oil pump type		Inner/outer rotor type
		Oil filter type		Full-flow filtration
Oil capacity		1.0 liter		
Oil exchanging capacity		0.9 liter		
Cooling Type		Forced air cooling		


Fuel System	Air cleaner type & No		Sponge		
	Fuel capacity		8.1 liters		
	Carburetor	Type		PD	
		Piston dia. (mm)		14.8mm	
		Venturi dia.(mm)		φ25	
Throttle type		PISTON			
Electrical Equipment	Ignition System	Type		CDI	
		Ignition timing		15°BTDC/1700rpm	
		Contact breaker		Non-contact point type	
	Spark plug		NGK		
	Spark plug gap		0.6 0.7mm		
	Battery	Capacity		12V8AH	
Power Drive System	Clutch	Type		CVT	
		Transmission Gear	Type		Helical gear
	Operation		Automatic centrifugal type		
	Reduction Gear	Type		Chain drive	
		Reduction ratio	1st	2.8-0.95	
2nd			7.226		
Counter gear ratio		26.902			
Moving Device	Front Axle	Caster angle			
		Trail length			
	Tire pressure (kg/cm ²)	Front	0.2		
		Rear	0.25		
	Turning angle	Left	44°		
Right		44°			
Brake system type		Rear	Disk brake	Drum brake	
Damping Device	Suspension type	Front	Swing		
		Rear	Swing arm		
	Shock type	Front	Swing		
		Rear	Swing arm		
Frame type		SP pipe			

SERVICE PRECAUTIONS


- Make sure to install new gaskets, O-rings, circlips, cotter pins, etc. when reassembling.



- When tightening bolts or nuts, begin with larger-diameter to smaller ones at several times, and tighten to the specified torque diagonally.




- Use genuine parts and lubricants.



- When servicing the motorcycle, be sure to use special tools for removal and installation.




- After disassembly, clean removed parts. Lubricate sliding surfaces with engine oil before reassembly.




1. GENERAL INFORMATION


- Apply or add designated greases and lubricants to the specified lubrication points.




- After reassembly, check all parts for proper tightening and operation.




- When two persons work together, pay attention to the mutual working safety.



- Disconnect the battery negative (-) terminal before operation.
- When using a spanner or other tools, make sure not to damage the motorcycle surface.




- After operation, check all connecting points, fasteners, and lines for proper connection and installation.
- When connecting the battery, the positive (+) terminal must be connected first.
- After connection, apply grease to the battery terminals.
- Terminal caps shall be installed securely.




1. GENERAL INFORMATION


- If the fuse is burned out, find the cause and repair it. Replace it with a new one according to the specified capacity.




- After operation, terminal caps shall be installed securely.




- When taking out the connector, the lock on the connector shall be released before operation.



- Hold the connector body when connecting or disconnecting it.
- Do not pull the connector wire.




- Check if any connector terminal is bending, protruding or loose.




1. GENERAL INFORMATION


- The connector shall be inserted completely.
- If the double connector has a lock, lock it at the correct position.
- Check if there is any loose wire.




- Before connecting a terminal, check for damaged terminal cover or loose negative terminal.




- Check the double connector cover for proper coverage and installation.



- Insert the terminal completely.
- Check the terminal cover for proper coverage.
- Do not make the terminal cover opening face up.




- Secure wire harnesses to the frame with their respective wire bands at the designated locations. Tighten the bands so that only the insulated surfaces contact the wire harnesses.




1. GENERAL INFORMATION


- After clamping, check each wire to make sure it is secure.




- Do not squeeze wires against the weld or its clamp.




- After clamping, check each harness to make sure that it is not interfering with any moving or sliding parts.



- When fixing the wire harnesses, do not make it contact the parts which will generate high heat.




- Route wire harnesses to avoid sharp edges or corners. Avoid the projected ends of bolts and screws.
- Route wire harnesses passing through the side of bolts and screws. Avoid the projected ends of bolts and screws.




1. GENERAL INFORMATION


- Route harnesses so they are neither pulled tight nor have excessive slack.




- Protect wires and harnesses with electrical tape or tube if they contact a sharp edge or corner.




- When rubber protecting cover is used to protect the wire harnesses, it shall be installed securely.



- Do not break the sheath of wire.
- If a wire or harness is with a broken sheath, repair by wrapping it with protective tape or replace it.




- When installing other parts, do not press or squeeze the wires.




1. GENERAL INFORMATION


- After routing, check that the wire harnesses are not twisted or kinked.




- Wire harnesses routed along with handlebar should not be pulled tight, have excessive slack or interfere with adjacent or surrounding parts in all steering positions.



- When a testing device is used, make sure to understand the operating methods thoroughly and operate according to the operating instructions.



- Be careful not to drop any parts.



- When rust is found on a terminal, remove the rust with sand paper or equivalent before connecting.



1. GENERAL INFORMATION

■ Symbols:

The following symbols represent the servicing methods and cautions included in this service manual.



: Apply engine oil to the specified points. (Use designated engine oil for lubrication.)



: Apply grease for lubrication.



: Transmission Gear Oil (90#)



: Use special tool.



: Caution



: Warning

1. GENERAL INFORMATION

TORQUE VALUES

STANDARD TORQUE VALUES

Item	Torque (kgf-m)	Item	Torque (kgf-m)
5mm bolt, nut	0.45 0.6	4mm screw	0.15 0.4
6mm bolt, nut	0.8 1.2	5mm screw	0.3 0.5
8mm bolt, nut	1.8 2.5	6mm screw, SH bolt	0.7 1.1
10mm bolt, nut	3.0 4.0	6mm flange bolt and nut	1.0 1.4
12mm bolt, nut	5.0 6.0	8mm flange bolt and nut	2.4 3.0
14mm bolt, nut	6.0 8.0	10mm flange bolt and nut	3.5 4.5

Torque specifications listed below are for important fasteners.

ENGINE

Item	Q'ty	Thread dia.(mm)	Torque (kgf-m)	Remarks
Stud bolt	4	8	0.7 1.1	
Oil filter screen cap	1	30	1.0 2.0	
Seat ball stopper bolt	1	14	4.5 5.0	
Bearing hold	1	6	1.0 1.2	
L cover	8	6	1.0 1.4	
Stud bolt	4	6	0.7 1.1	
Cam holder	4	8	1.8 2.2	
Tappet ADJ nut	2	6	1.4 1.8	
Pivot tensioner	1	8	0.8 1.2	
Lifter tensioner	2	6	1.0 1.4	
Lifter tensioner	1	6	0.35 0.5	
MISTON oil drive bolt	9	6	0.8 1.2	
Driver face	1	12	5.5 6.5	
Clutch outer	1	12	5.0 6.0	
Oneway clutch	3	8	2.4 3.0	
Balancer shaft	1	16	4.0 5.0	
ACG flywheel	1	14	5.0 6.0	
Spark plug	1	8	1.1 2.3	
Drain bolt mission	1	8	0.8 1.2	
Drain plug	1	12	2.0 3.0	
Clamper wre harness	1	6	0.8 1.2	
Motor srart	2	6	0.8 1.2	
Oil pump	2	6	0.8 1.2	
Oil pump sprocket	2	6	0.8 1.2	
Head CYL bolt	2	6	0.8 1.2	
Drive plate nut	1	22	5.0 6.0	
Startor	4	5	0.8 1.2	

1. GENERAL INFORMATION

Item	Q'ty	Thread dia.(mm)	Torque (kgf-m)	Remarks
R cover	9	6	0.8 1.2	
Head cover	4	6	0.8 1.2	
Cap R cover	1	6	0.8 1.2	
Guide star change handle	3	6	0.8 1.2	
Sprocket drive plate	2	6	1.0 1.6	
Carburetor	2	6	0.8 1.2	
Check bolt oil	1	10	1.0 1.5	

FRAME

Item	Q'ty	Thread dia.(mm)	Torque (kgf-m)	Remarks
Steering stem nut	1	14	6.0 8.0	
Swing arm nut	4	10	4.0 5.0	
Rear wheel nut	2	14	6.0 8.0	
Front wheel nut	2	14	6.0 8.0	
Rear shock absorber upper mount bolt	1	10	3.5 4.5	
Front shock absorber upper mount bolt	2	10	3.5 4.5	
Front shock absorber lower mount bolt	2	10	3.5 4.5	
Rear fork axle	1	14	6.0 8.0	
Rear hub nut	4	12	6.0 8.0	
Rear wheel shaft nut	2	32	11.0 13.0	
Rear engine bracket up bolt	1	10	3.5 4.5	
Rear engine bracket bolt	1	10	3.5 4.5	
Engine hanger bracket bolt	1	10	3.5 4.5	
Exhaust muffler lock bolt	2	8	3.2 3.8	

1. GENERAL INFORMATION


SPECIAL TOOLS

Tool Name	Tool No.	Remarks Ref. Page
Flywheel puller	E003	
Lock nut wrench	E009	
Valve adjuster	E012	
Valve spring compressor	E040	
Oil seal and bearing install	E014	
Universal holder	E017	
Flywheel holder	E021	
Clutch spring compressor	E027	
Bearing puller	E008	
Bearing puller	E018	
Bearing puller	E020	
Bearing puller	E031	
Nut wrench	F010	
Float level gauge		

1. GENERAL INFORMATION

LUBRICATION POINTS


ENGINE

Lubrication Points	Lubricant
Valve guide/valve stem movable part Cam lobes Valve rocker arm friction surface Cam chain Cylinder lock bolt and nut Piston surroundings and piston ring grooves Piston pin surroundings Cylinder inside wall Connecting rod/piston pin hole Connecting rod big end Crankshaft right side oil seal Crankshaft one-way clutch movable part Oil pump drive chain Balance gear A.C. generator Starter one-way clutch Bearing movable part O-ring face Oil seal lip	<ul style="list-style-type: none"> •Genuine KYMCO Engine Oil (SAE15W-40) •API SG Engine Oil 
Transmission gear and movable parts	Gear oil: SAE90#


1. GENERAL INFORMATION

FRAME

The following is the lubrication points for the frame.
Use general purpose grease for parts not listed.
Apply clean engine oil or grease to cables and movable parts not specified. This will avoid abnormal noise and rise the durability of the motorcycle.




1. GENERAL INFORMATION




1. GENERAL INFORMATION


CABLE & HARNESS ROUTING




1. GENERAL INFORMATION



1. GENERAL INFORMATION




1. GENERAL INFORMATION



1. GENERAL INFORMATION


TROUBLESHOOTING

ENGINE WILL NOT START OR IS HARD TO START




1. GENERAL INFORMATION

ENGINE LACKS POWER




1. GENERAL INFORMATION

POOR PERFORMANCE (ESPECIALLY AT IDLE AND LOW SPEEDS)



1. GENERAL INFORMATION


POOR PERFORMANCE (AT HIGH SPEED)




1. GENERAL INFORMATION

POOR CHARGING (BATTERY OVER DISCHARGING OR OVERCHARGING)

Undercharging




Overcharging



1. GENERAL INFORMATION


NO SPARK AT SPARK PLUG



FRAME COVERS/EXHAUST MUFFLER

SERVICE INFORMATION-----	2- 2
TROUBLESHOOTING-----	2- 2
FRAME COVERS-----	2- 3
HEADLIGHT REMOVAL-----	2- 5
EXHAUST MUFFLER REMOVAL-----	2- 5

2. FRAME COVERS/EXHAUST MUFFLER



2. FRAME COVERS/EXHAUST MUFFLER

SERVICE INFORMATION

GENERAL INSTRUCTIONS

- When removing frame covers, use special care not to pull them by force because the cover joint claws may be damaged.
- Make sure to route cables and harnesses according to the Cable & Harness Routing.

TORQUE VALUES

Exhaust muffler lock bolt	3.2	3.8kgf-m
Exhaust muffler joint lock nut	0.8	1.2kgf-m

TROUBLESHOOTING

Noisy exhaust muffler

- Damaged exhaust muffler
- Exhaust muffler joint air leaks

Lack of power


- Caved exhaust muffler
- Exhaust muffler air leaks
- Clogged exhaust muffler

2. FRAME COVERS/EXHAUST MUFFLER

FRAME COVERS

SEAT REMOVAL


Pull the lever backward, then pull up the seat at the rear.
Remove the seat.




LEFT REAR FENDER REMOVAL

Remove seven screws and two bolts attaching the left rear fender.

During removal, do not pull the joint claws forcedly to avoid damage.



Remove the left rear fender under bolt.
Remove the left rear fender.



RIGHT REAR FENDER REMOVAL

Remove seven screws and two bolts attaching the right rear fender.

During removal, do not pull the joint claws forcedly to avoid damage.



2. FRAME COVERS/EXHAUST MUFFLER


Remove right rear fender under bolt.
Remove the right rear fender.



Bolt

FLOOR BOARD COVER REMOVAL

Remove the four bolts on the floorboard cover.
Remove the floorboard cover.



Floor Board Cover

Bolts

FRONT COVERS REMOVAL

Remove the two screws on the front cover.
Remove the left and right front fender under bolt.
Remove the front cover.



Front Cover

Screws

FRONT FENDER REMOVAL

Remove the left and right front fender under bolt.
Remove screws attaching the left and right front fender.
Remove the left and right front fender.

During removal, be careful not to damage the joint claws.



Bolt

HEADLIGHT REMOVAL


Remove the headlight connector wire.
Remove the two bolts on the headlight.



Bolts

EXHAUST MUFFLER REMOVAL

Remove the two bolts attaching the exhaust
muffler.



Bolts

Remove the two exhaust muffler joint lock
nuts.
Remove the exhaust muffler joint packing
collar.
When installing, first install the exhaust
muffler packing collar onto the engine and
then install the exhaust muffler.

Torque:

Exhaust muffler lock bolt: 3.2 3.8kgf-m

Exhaust muffler joint lock nut: 0.8
1.2kgf-m

Joint Lock Nuts



Be sure to install a new exhaust muffler
packing collar.

3. INSPECTION/ADJUSTMENT

3

INSPECTION/ADJUSTMENT

SERVICE INFORMATION-----	3- 1
MAINTENANCE SCHEDULE-----	3- 2
FUEL LINE/THROTTLE OPERATION/AIR CLEANER -----	3- 3
AIR FILTER FOR DRIVE BELT -----	3- 4
SPARK PLUG-----	3- 5
VALVE CLEARANCE/CARBURETOR IDLE SPEED-----	3- 6
IGNITION TIMING/CYLINDER COMPRESSION -----	3- 7
ENGINE OIL/FINAL REDUCTION GEAR OIL-----	3- 8
DRIVE BELT/BRAKE SHOE/BRAKE SYSTEM -----	3- 9
HEADLIGHT AIM -----	3-11
STEERING SYSTEM INSPECTION-----	3-11
TOE-IN ADJUSTMENT -----	3-12
WHEELS/TIRES -----	3-13
DRIVE CHAIN SLACK ADJUSTMENT-----	3-14
CABLE INSPECTION AND LUBRICATION-----	3-16
FRONT SUSPENSION LUBRICATION -----	3-16

3. INSPECTION/ADJUSTMENT

SERVICE INFORMATION

GENERAL

 **WARNING**

- Before running the engine, make sure that the working area is well-ventilated. Never run the engine in a closed area. The exhaust contains poisonous carbon monoxide gas which may cause death to people.
- Gasoline is extremely flammable and is explosive under some conditions. The working area must be well-ventilated and do not smoke or allow flames or sparks near the working area or fuel storage area.

SPECIFICATIONS

ENGINE

- Throttle grip free play : 1 4mm
- Spark plug gap : 0.6 0.7mm
- Spark plug: Standard : NGK: CR8E
- Valve clearance : IN: 0.06mm
EX: 0.06mm
- Idle speed : 1700±100rpm
- Engine oil capacity:
 - At disassembly : 1.0 liter
 - At change : 0.9 liter
- Gear oil capacity :
 - At disassembly : 400cc
 - At change : 200cc
- Cylinder compression : 16kg/cm²
- Ignition timing : BTDC 15°/1700rpm

CHASSIS

- Front brake free play: 10 20mm
- Rear brake free play: 10 20mm

TIRE PRESSURE

	1 Rider
Front	0.20kgf/cm ²
Rear	0.25kgf/cm ²

TIRE SIZE:

- Front : 20*7-8
- Rear : 22*10-8

TORQUE VALUES

- Front wheel nut 5.0 6.0kgf-m
- Rear wheel nut 5.0 6.0kgf-m

3. INSPECTION/ADJUSTMENT

MAINTENANCE SCHEDULE

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

Item	Remarks	Initial			Every	
		1 month	3 month	6 month	6 month	1 year
Valves	Check valve clearance. Adjust if necessary.	○		○	○	○
Spark plug	Check condition. Clean or replace if necessary.	○	○	○	○	○
Air clearance	Clean. Replace if necessary.		○	○	○	○
Carburetor	Check idle speed/starter operation. Adjust if necessary.		○	○	○	○
Fuel line	Check fuel hose for cracks or damage. Replace if necessary.			○	○	○
Engine oil	Replace (Warm engine before draining).	○		○	○	○
Engine oil filter screen	Clean. Replace if necessary.	○				○
Transmission oil	Check oil leakage. Replace every 12 months.	○				○
Brake system	Check operation. Adjust if necessary.	○	○	○	○	○
Drive belt	Check operation/replace if damage or excessive wear.	○				○
Wheels	Check balance/damage/runout. Replace if necessary.	○		○	○	○
Wheel bearings	Check bearings assembly for looseness/damage. Replace if damaged.	○		○	○	○
Steering system	Check operation/replace if damage. Check toe-in/adjust if necessary.	○	○	○	○	○
Knuckle shafts	Lubricate every 6 months.			○	○	○
Fitting/Fasteners	Check all chassis fittings and fasteners. Correct if necessary.	○	○	○	○	○

- In the interest of safety, we recommend these items should be serviced only by an authorized KYMCO motorcycle dealer.

FUEL LINE

Remove the met-in box.

3. INSPECTION/ADJUSTMENT

Check the fuel tubes and replace any parts, which show signs of deterioration, damage or leakage.

□ Do not smoke or allow flames or sparks in your working area.

THROTTLE OPERATION

Check the throttle to swing for smooth movement.
Measure the throttle to swing free play.
Free Play: 1-4mm






Minor adjustment is made with the adjusting nut at the throttle to swing above. Slide the rubber cover out and adjust by loosening the lock nut and turning the adjusting nut.



AIR CLEANER AIR CLEANER REPLACEMENT

Remove the rear side covers.
Remove four screws on the air cleaner case cover and the cover.
Check the element and replace it if it is excessively dirty or damaged.

Fuel tube



Lock Nut

Screws



Wash the element gently, but thoroughly in solvent.

3. INSPECTION/ADJUSTMENT

□ Use parts cleaning solvent only. Never use gasoline or low flash point solvents which may lead to a fire or explosion.

Squeeze the excess solvent out of the element and let dry.

□ Do not twist or wring out the foam element. This could damage the foam material.

Apply the engine oil.


Squeeze out the excess oil.

□ The element should be wet but not dripping.

CHANGE INTERVAL

More frequent replacement is required when riding in unusually dusty or rainy areas.

Air Cleaner Element



Front cover

Air Filter Case


AIR FILTER FOR DRIVE BELT

Remove the front cover.


Remove the screw, air filter case and air filter element.

Inspect the air filter element.

Replace if damage.



Screw



Clean air filter element steps:
Tap the element lightly to remove most of

3. INSPECTION/ADJUSTMENT

the dust and dirt.

Blow out the remaining dirt with compressed air.

Install the air filter element and air filter case.

Install the front cover.

SPARK PLUG

Remove the spark plug.

Check the spark plug for wear and fouling deposits.



Clean any fouling deposits with a spark plug cleaner or a wire brush.

Specified Spark Plug: NGK: CR8E

Measure the spark plug gap.

Spark Plug Gap: 0.6 - 0.7mm

- When installing, first screw in the spark plug by hand and then tighten it with a spark plug wrench.




VALVE CLEARANCE


- Inspect and adjust valve clearance while the engine is cold (below 35 °C).

3. INSPECTION/ADJUSTMENT

Remove the cylinder head cover.



Turn the flywheel counterclockwise so that the "T" mark on the flywheel aligns with the index mark on the crankcase to bring the round hole on the camshaft gear facing up to the top dead center on the compression stroke.




Inspect and adjust the valve clearance.

Valve Clearance: IN: 0.06mm
EX: 0.06mm

Loosen the lock nut and adjust by turning the adjusting nut

Special

Tappet adjuster E012



- Check the valve clearance again after the lock nut is tightened.



CARBURETOR IDLE SPEED

- The engine must be warm for accurate idle speed inspection and adjustment.

Warm up the engine before this operation. Start the engine and connect a tachometer. Turn the throttle stop screw to obtain the specified idle speed.

Idle Speed: 1700±100rpm

When the engine misses or run erratic, adjust the air screw.




Cylinder Head Cover

The CDI unit is not adjustable. If the ignition timing is incorrect, check the ignition system.

3. INSPECTION/ADJUSTMENT

Remove the timing hole cap.



Check the ignition timing with a timing light.
When the engine is running at idle speed, the ignition timing is correct if the "F" mark on the flywheel aligns with the index mark on the crankcase.

Timing Light

CYLINDER COMPRESSION

Warm up the engine before compression test.

Remove the spark plug.

Insert a compression gauge.

Open the throttle valve fully and push the starter button to test the compression.

Compression: 16kg/cm²


If the compression is low, check for the following:

- Leaky valves
- Valve clearance too small
- Leaking cylinder head gasket
- Worn piston rings
- Worn piston/cylinder

If the compression is high, it indicates that carbon deposits have accumulated on the combustion chamber and the piston head.



Compression Gauge



Timing Hole Cap

ENGINE OIL OIL LEVEL



3. INSPECTION/ADJUSTMENT

- Place the motorcycle upright on level ground for engine oil level check.
- Run the engine for 2-3 minutes and check the oil level after the engine is stopped for 2-3 minutes.

Remove the oil dipstick and check the oil level with the oil dipstick.
If the level is near the lower level, fill to the upper level with the specified engine oil.

OIL CHANGE

The engine oil will drain more easily while the engine is warm.

Remove the oil drain plug bolt located on the bottom of the engine to drain the engine oil thoroughly.

After the oil has been completely drained, install the oil drain plug bolt.



Torque: 2.0-3.0kgf-m

Recommended Oil: SAE30#

FINAL REDUCTION GEAR OIL

Place the motorcycle on level ground for oil level check.

Recommended Oil: GEAR OIL SAE90#



Lower Level


GEAR OIL CHANGE

Remove the oil filler bolt.

Remove the oil drain bolt and drain the oil


3. INSPECTION/ADJUSTMENT

thoroughly.
Install the oil drain bolt.
Torque: 0.8 1.2kgf-m




DRIVE BELT

Remove the left crankcase cover.
Inspect the drive belt for cracks, scaling, chipping or excessive wear.
Measure the V-belt width
Service limit: 17mm
Replace the drive belt if out of specification.



BRAKE SHOE

Replace the brake shoes if the arrow on the wear indicator plate aligns with the punch mark on the brake panel when the brake is fully applied.



BRAKE SYSTEM

FRONT BRAKE

Measure the front brake lever free play.
Free Play: 10 20mm
Adjust if out of specification.



Adjust brake lever free play:
Loosen the lock nuts.

3. INSPECTION/ADJUSTMENT

Turn the adjusters in or out until the specified free play is obtained.


Turning adjusters in that the free play is increased.

Turning adjusters out that the free play is decreased.

The difference between both clearances should be 2 mm or less when front brake is applied.

Tighten the lock nuts.

Make sure that the brake does not drag after adjusting.




REAR BRAKE

Measure the rear brake lever free play.

Free Play: 10 20mm



If the free play do not fall within the limit, adjust by turning the adjusting nut.



Turn the ignition switch ON and start the



3. INSPECTION/ADJUSTMENT

engine.

Turn on the headlight switch.

Adjust the headlight aim by turning the headlight aim adjusting screw.



Adjusting Screw



STEERING SYSTEM INSPECTION

Place the machine on a level place.

Check the steering column bushings and bearings:

Move the handlebar up and down, and/or back and forth.

Replace the steering column bushings and or bearings if excessive play

Check the tie-rod ends

Turn the handlebar to the left and/or right until it stops completely, then slightly move the handlebar from left to right.

Replace the tie-rod ends if tie-rod end has any vertical play.



Tie-rod Ends

Raise the front end of the machine so that there is no weight on the front wheels.

Check ball joints and/or wheel bearings.

Move the wheels laterally back and forth.

Replace the front arms and/or wheel bearings if excessive free play.



TOE-IN ADJUSTMENT

Place the machine on a level place.

Measure the toe-in

3. INSPECTION/ADJUSTMENT

Adjust if out of specification.

Toe-in measurement steps:

Mark both front tire tread centers.

Raise the front end of the machine so that there is no weight on the front tires.

Fix the handlebar straight ahead.

Measure the width A between the marks.

Rotate the front tires 180 degrees until the marks come exactly opposite.



Measure the width B between the marks.

Calculate the toe-in using the formula given below.

Toe-in = $B \cdot A$

Toe-in: 0 - 10mm

If the toe-in is incorrect, adjust the toe-in



Adjust the toe-in step:

Mark both tie-rods ends.


This reference point will be needed during adjustment.

Loosen the lock nuts (tie-rod end) of both tie-rods

The same number of turns should be given to both tie-rods right and left until the specified toe-in is obtained, so that the lengths of the rods will be kept the same.


Torque: 2.5 - 3.5kgf-m

Tie-rod



Tie-rod End Nuts

- Be sure that both tie-rod are turned the same amount. If not, the machine will drift right or left even though the handlebar is positioned straight which may lead to mishandling and accident.
- After setting the toe-in to specification, run the machine slowly for some distance with hands placed lightly on the handlebar and check that the handlebar responds correctly. If not, turn either the right or left tie-rod within the toe-in specification.




WHEELS/TIRES

Check the tires for cuts, imbedded nails or other damages.

Check the tire pressure.

3. INSPECTION/ADJUSTMENT

□ Tire pressure should be checked when tires are cold.



	1 Rider
Front	0.20kgf/cm ²
Rear	0.25kgf/cm ²

TIRE SIZE

Front : 20*7-8

Rear : 22*10-8

Check the front axle nut for looseness.
Check the rear axle nut for looseness.
If the axle nuts are loose, tighten them to the specified torque.

Torque: Front : 6.0 8.0kgf-m

Rear : 6.0 8.0kgf-m

Front Axle Nut



Rear Axle Nut




WHEEL INSPECTION

Inspect the tire surfaces.

Replace if wear or damage.

Tire wear limit: 3.0mm

□ It is dangerous to ride with a worn out tire. When a tire wear is out of specification, replace the tire immediately.



Inspect the wheel.

Replace if damage or bends

Always balance the wheel when a tire or wheel has been changed or replaced.

-
- Never attempt even small repairs to the wheel.
 - Ride conservatively after installing a tire to allow it to seat itself properly on the rim.

DRIVE CHAIN SLACK ADJUSTMENT

Before checking and/or adjusting, rotate the rear wheels several revolutions and check slack at several points to find the tightest point. Check and/or adjust the chain slack with the rear wheels in this “tightest” position.

- Too little of chain slack will overload the engine and other vital parts; keep the slack within the specified limits.

Place the machine on a level place.

- Wheels should be on the ground without the rider on it.

Check drive chain slack.

Adjust if out of specification.

Drive chain slack: Approximately 30mm




Adjust drive chain slack:

Elevate the rear wheels by placing a suitable stand under the rear of frame.

- Support the machine securely so there is no danger of it falling over.

Loosen four bolts attaching rear axle hub.



Turn the adjuster in or out until the specified slack is obtained.

3. INSPECTION/ADJUSTMENT


Turn out: Slack is decreased.

Turn in: Slack is increased.





Tighten four bolts attaching rear axle hub to the specification. While pushing up or down on the chain to zero slack.

Torque: 6.0 8.0kgf-m



Tighten the adjuster.

Torque: 1.8 2.5kgf-m



CABLE INSPECTION AND LUBRICATION

- Damaged cable sheath may cause corrosion and interfere with the cable movement. An unsafe condition may result so replace such cable as soon as possible.

3. INSPECTION/ADJUSTMENT

- Inspect the cable sheath.
- Replace if damage.
- Check the cable operation.
- Lubricate or replace if unsmooth operation.

Hold cable end high and apply several drops of lubricant to cable.


LEVER LUBRICATION

Lubricate the pivoting parts of each lever.

FRONT SUSPENSION LUBRICATION

Inject grease into the nipples using a grease gun until slight over flow is observed from the thrust covers.

Wipe off the excess grease.



Nipple

4. LUBRICATION SYSTEM


4

LUBRICATION SYSTEM

SERVICE INFORMATION-----	4- 2
TROUBLESHOOTING-----	4- 2
ENGINE OIL/OIL FILTER -----	4- 3
OIL PUMP-----	4- 3

4. LUBRICATION SYSTEM

LUBRICATION SYSTEM



4. LUBRICATION SYSTEM

SERVICE INFORMATION

GENERAL INSTRUCTIONS

- The maintenance of lubrication system can be performed with the engine installed in the frame.
- Use care when removing and installing the oil pump not to allow dust and foreign matters to enter the engine and oil line.
- Do not attempt to disassemble the oil pump. The oil pump must be replaced as a set when it reaches its service limit.
- After the oil pump is installed, check each part for oil leaks.

SPECIFICATIONS

Item		Standard (mm)	Service Limit (mm)
Oil pump	Inner rotor-to-outer rotor clearance	—	0.12
	Outer rotor-to-pump body clearance	—	0.12
	Rotor end-to-pump body clearance	0.05 0.10	0.2

TROUBLESHOOTING

Oil level too low

- Natural oil consumption
- Oil leaks
- Worn or poorly installed piston rings
- Worn valve guide or seal

Poor lubrication pressure

- Oil level too low
- Clogged oil filter or oil passages
- Not use the specified oil


4. LUBRICATION SYSTEM

ENGINE OIL/OIL FILTER

OIL LEVEL

- Place the motorcycle upright on level ground for engine oil level check.
- Run the engine for 2-3 minutes and check the oil level after the engine is stopped for 2-3 minutes.

Remove the oil dipstick and check the oil level with the oil dipstick. If the level is near the lower level, fill to the upper level with the specified engine oil.




OIL CHANGE

The engine oil will drain more easily while the engine is warm.

Remove the oil drain plug bolt located on the bottom of the engine to drain the engine oil thoroughly.

After the oil has been completely drained, install the oil drain plug bolt.

Torque: 2.0-3.0kgf-m



Refer to page 3-2 to clean the engine oil filter screen

After the oil has been completely drained, check the filter screen O-ring for damage and replace if necessary.

Install the oil filter screen, spring and filter screen cap.

Torque: 1.0-2.0kgf-m

Fill with the specified SAE15W40#, API: SG engine oil to the proper level.

Oil Capacity: At disassembly : 1.0 liter

At change : 0.9 liter

Check for oil leaks and then start the engine and let it idle for few minutes.

Recheck the oil level.

OIL PUMP

REMOVAL


Remove the right crankcase cover.

Remove the A.C. generator flywheel.

Special

Flywheel holder E021

Flywheel puller E003




4. LUBRICATION SYSTEM


Remove the starter idle gear and starter clutch.

Special

Lock nut socket wrench E009




Remove the two bolts and oil separator cover.




Oil Separator Cover

Remove the oil pump driven gear nut to remove the oil pump driven gear and drive chain.



Oil Pump Driven Gear

Remove the oil pump mounting two bolts and the oil pump.




Oil Pump

4. LUBRICATION SYSTEM

DISASSEMBLY


Remove the screw and disassemble the oil pump.



INSPECTION


Measure the pump body-to-outer rotor clearance.

Service Limit: 0.12mm



Measure the inner rotor-to-outer rotor clearance.

Service Limit: 0.12mm



Measure the rotor end-to-pump body clearance.

Service Limit: 0.2mm




4. LUBRICATION SYSTEM

ASSEMBLY

Install the outer rotor, inner rotor and pump shaft into the pump body.

Insert the pump shaft by aligning the flat on the shaft with the flat in the inner rotor.

Install the dowel pin.
Install the pump cover by aligning the hole in the cover with the dowel pin.




Tighten the screw to secure the pump cover.
Make sure that the pump shaft rotates freely without binding.




INSTALLATION

Install the oil pump into the crankcase.

Install the oil pump with the arrow on the pump body facing up and fill the oil pump with engine oil before installation.



After the oil pump is installed, tighten the two mounting bolts.




4. LUBRICATION SYSTEM

Install the pump driven gear and drive chain by aligning the pump driven gear with the cutout in the pump shaft.


Install and tighten the pump driven gear nut.

Torque: 0.8 1.2kgf-m



Pump Driven Gear

Install the oil separator cover and tighten the bolts.




Oil Separator Cover

Install the starter idle gear and starter clutch.

Install the starter clutch nut and tighten it to specified torque..

Torque: 9.5 kgf-m

Install the gasket and dowel pins.




Starter Idle Gear Starter Clutch Gasket

Install the A.C. generator flywheel.

Install the right crankcase cover.

Torque: 0.8 1.2kgf-m

Diagonally tighten the bolts in 2 3 times.



Flywheel

5. FUEL SYSTEM

5

FUEL SYSTEM

SERVICE INFORMATION-----	5- 2
TROUBLESHOOTING-----	5- 3
THROTTLE VALVE DISASSEMBLY/CARBURETOR REMOVAL--	5- 4
FLOAT/FLOAT VALVE/JETS-----	5- 5
CARBURETOR INSTALLATION -----	5- 8
FUEL TANK -----	5-9
FUEL VALVE REMOVAL -----	5-9
AIR CLEANER -----	5-10

5. FUEL SYSTEM

SERVICE INFORMATION

GENERAL INSTRUCTIONS



Gasoline is very dangerous. When working with gasoline, keep sparks and flames away from the working area.
Gasoline is extremely flammable and is explosive under certain conditions. Be sure to work in a well-ventilated area.

- Do not bend or twist control cables. Damaged control cables will not operate smoothly.
- When disassembling fuel system parts, note the locations of O-rings. Replace them with new ones during reassembly.
- Before float chamber disassembly, loosen the drain screw to drain the residual gasoline into a clean container.
- After the carburetor is removed, plug the intake manifold side with a clean shop towel to prevent foreign matters from entering.
- When cleaning the carburetor air and fuel jets, the O-rings and diaphragm must be removed first to avoid damage. Then, clean with compressed air.
- When the motorcycle is not used for over one month, drain the residual gasoline from the float chamber to avoid erratic idling and clogged slow jet due to deteriorated fuel.

SPECIFICATIONS

	MX'er 150	MX'er 125
Item	Standard	Standard
Type	PD	PD
Venturi dia.	φ25	φ25
Float level	14.8mm	14.8mm
Main jet No.	95	95
Adjust method	Piston	Piston
Idle speed	1700±100rpm	1700±100rpm
Throttle grip free play	1 4mm	1 4mm
Air screw opening	2±1/2	2±1/2

5. FUEL SYSTEM

SPECIAL TOOL

Float level gauge

TROUBLESHOOTING

Engine cranks but won't start

- No fuel in tank
- No fuel to carburetor
- Cylinder flooded with fuel
- No spark at plug
- Clogged air cleaner
- Intake air leak
- Improper throttle operation

Engine idles roughly, stalls or runs poorly

- Excessively used choke
- Ignition malfunction
- Faulty carburetor
- Poor quality fuel
- Lean or rich mixture
- Incorrect idle speed

Misfiring during acceleration

- Faulty ignition system
- Faulty carburetor

Backfiring at deceleration

- Float level too low
- Incorrectly adjusted carburetor
- Faulty exhaust muffler

Engine lacks power

- Clogged air cleaner
- Faulty carburetor
- Faulty ignition system

Lean mixture

- Clogged carburetor fuel jets
- Float level too low
- Intake air leak
- Clogged fuel tank cap breather hole
- Kinked or restricted fuel line


Rich mixture

- Float level too high
- Clogged air jets
- Clogged air cleaner


5. FUEL SYSTEM

THROTTLE VALVE DISASSEMBLY


Remove the front cover.
Remove the front fender.
Remove the carburetor cap.
Pull out the throttle valve.
Disconnect the choke knob cable.



Disconnect the throttle cable and remove the spring from the throttle valve.



Pry off the needle retainer and remove the jet needle.
Check the throttle valve and jet needle for wear or damage.




CARBURETOR REMOVAL

Switch the fuel valve OFF.
Loosen the drain screw to drain the gasoline from the float chamber.


- Keep sparks and flames away from the work area.
- Drain gasoline into a clean container.

Disconnect the fuel inlet tube and the choke cable.



5. FUEL SYSTEM

Loosen the air cleaner connecting tube band screw.
Remove the two carburetor lock nuts.
Remove the carburetor



Screw

FLOAT/FLOAT VALVE/JETS


FLOAT/FLOAT VALVE DISASSEMBLY

Remove the float chamber attaching three screws and remove the float chamber.



Screws

Remove the float pin, float and float valve.




Float Pin

Float Valve

FLOAT/FLOAT VALVE INSPECTION

Inspect the float valve seat for wear or damage.
Inspect the float for damage or fuel level inside the float chamber.



Float Valve Seat


5. FUEL SYSTEM

JETS/AIR SCREW/THROTTLE STOP SCREW REMOVAL

Remove the main jet, needle jet holder, and needle jet.


Remove the slow jet.

Remove the air screw and throttle stop screw.



CAUTIONS !

- Be careful not to damage the jets and jet holder when removing them.
- Before removal, turn the throttle stop screw and air screw in and count the number of turns until they seat lightly and then make a note of this.
- Do not force the screw against its seat to avoid seat damage.
- Be sure to install the O-ring in the reverse order of removal.




FUEL RESERVOIR O-RING CHECK

Remove the O-ring.

INSPECTION

Inspect the check the O-ring for damage. Replace with new ones if necessary



CARBURETOR CLEANING

Blow compressed air through all passages of the carburetor body.



5. FUEL SYSTEM


SLOW/MAIN JET INSTALLATION

Install the slow jet.


Install the needle jet, needle jet holder and main jet.

Install the throttle stop screw and air screw

- When installing the air screw, return it to the original position as noted during removal
- After the carburetor is installed, be sure to perform the Exhaust Emission




Install the float valve, float and float pin.



FLOAT LEVEL INSPECTION

Turn the carburetor upside down so that the float will go down to make the float valve contact the float valve seat.

Then slowly tilt the carburetor and measure the float level with the float level gauge while the float pin just contacts with float valve.



Float Level:

MX'er 150	14.8mm
MX'er 125	

When adjusting, carefully bend the float pin. Check the float for proper operation and then install the float chamber.


5. FUEL SYSTEM

CARBURETOR INSTALLATION

Install the carburetor onto the intake manifold and tighten the two lock nuts.

Torque: 0.8 1.2kgf-m

Install the air cleaner connecting tube and tighten the band screw.




Band Screw

Lock Nut

THROTTLE VALVE ASSEMBLY

Install the jet needle into the throttle valve and secure with the needle retainer.

Jet Needle Notch: 4th Notch
(Counted from top to bottom)




Throttle Valve

Clip

Needle Retainer

Jet Needle

Assemble the rubber cover, carburetor cap and throttle valve spring. Connect the throttle cable to the throttle valve.



Carburetor Cap

Spring


Throttle Valve

Notch

Install the throttle valve into the carburetor body.

Align the groove in the throttle valve with the throttle stop screw on the carburetor body.

Connect the accelerating pump cable. Fully open the throttle and adjust the accelerating pump cable to align the punch mark on the accelerating pump arm with the punch mark on the set plate.




Groove

Throttle Stop Screw

5. FUEL SYSTEM

Tighten the choke cable.




FUEL TANK


FUEL TANK REMOVAL

- Keep sparks and flames away from the work area.
- Wipe off any spilled gasoline.

Remove the seat.
Remove the center cover.
Remove the right and left front fender.




Switch the fuel valve "OFF".
Disconnect the fuel tube and remove two bolts on the end of the fuel tank.
Remove the fuel tank.



FUEL VALVE REMOVAL

Remove the fuel valve and fuel cup.




5. FUEL SYSTEM

Remove the screw on the fuel valve control switch.
Remove the two screws on the fuel valve body.

INSPECTION

Inspect the fuel valve strainer for dirt and clog. Clean if necessary.


Replace the O-rings with new ones if they are damaged or deteriorated.



AIR CLEANER

REMOVAL

Remove the seat.
Remove the four screws on the air cleaner case cover and the cover.
Remove the air cleaner screen and element.



ENGINE REMOVAL/INSTALLATION



SERVICE INFORMATION-----	6- 1
ENGINE REMOVAL -----	6- 2
ENGINE INSTALLATION -----	6- 4

6. ENGINE REMOVAL/INSTALLATION

SERVICE INFORMATION

GENERAL INSTRUCTIONS


- A floor jack or other adjustable support is required to support and maneuver the engine. Be careful not to damage the machine body, cables and wires during engine removal.
- Use shop towels to protect the motorcycle body during engine removal.
- Parts requiring engine removal for servicing:
 - Crankcase
 - Crankshaft

6. ENGINE REMOVAL/INSTALLATION

ENGINE REMOVAL

Drain engine oil and transmission oil.
Remove seat, front cover, center cover,
front fender and rear fender.
Remove the carburetor.

Disconnect the battery negative cable.
Remove the frame body cover.
Disconnect the engine negative cable.
Disconnect the A.C.G. wire connector.



Disconnect the starter motor cable from the starter relay.




Starter Relay

Starter Motor Cable

Disconnect the oil recycle tube at the engine body.

Disconnect the oil recycle tube at the cylinder head cover.




Oil Recycle Tube



Oil Recycle Tube

Loosen the drive belt air cleaner connecting tube band screw and remove the connecting tube.



Connecting Tube

Screw

A.C.G. Wire Connector

6. ENGINE REMOVAL/INSTALLATION

Disconnect the spark plug high-tension wire.

Remove the spark plug cap and disconnect the ignition coil wire from the set plate.




Remove the rear drive chain gear on the bolts.

Remove the drive chain gear.

Ignition Coil Wire

Drive Chain Gear


Remove the two bolts and two joint lock nuts attaching the exhaust muffler.
Remove the exhaust muffler.



ENGINE REMOVAL


Remove the engine any connector thing.

Remove the engine back bracket tow bolts.



6. ENGINE REMOVAL/INSTALLATION

Remove the engine front bracket bolt.




Bolt

Engine Hanger Bracket

ENGINE HANGER BRACKET REMOVE

Remove the two bolts on the left engine hanger bracket.
Remove the left engine hanger bracket.
Remove the engine.




ENGINE INSTALLATION

Install the engine and tighten the engine mounting bolts.

Torque: 3.5 4.5kgf-m

Install the removed parts in the reverse order of removal.

Route the wires and cables properly.




7. CYLINDER HEAD/VALVES

CYLINDER HEAD/VALVES

SERVICE INFORMATION-----	7- 2
TROUBLESHOOTING-----	7- 3
CAMSHAFT REMOVAL-----	7- 4
CYLINDER HEAD REMOVAL-----	7- 7
CYLINDER HEAD DISASSEMBLY-----	7- 8
CYLINDER HEAD ASSEMBLY-----	7-10
CYLINDER HEAD INSTALLATION-----	7-10
CAMSHAFT INSTALLATION-----	7-11



7. CYLINDER HEAD/VALVES



7. CYLINDER HEAD/VALVES

SERVICE INFORMATION

GENERAL INSTRUCTIONS

- The cylinder head can be serviced with the engine installed in the frame.
- When assembling, apply molybdenum disulfide grease or engine oil to the valve guide movable parts, valve arm and camshaft sliding surfaces for initial lubrication.
- The camshaft is lubricated by engine oil through the cylinder head engine oil passages. Clean and unclog the oil passages before assembling the cylinder head.
- After disassembly, clean the removed parts and dry them with compressed air before inspection.
- After removal, mark and arrange the removed parts in order. When assembling, install them in the reverse order of removal.

SPECIFICATIONS

Item		Standard (mm)	Service Limit (mm)
Valve clearance (cold)	IN	0.06	—
	EX	0.06	—
Cylinder head compression pressure		16kg/cm ²	
Cylinder head warpage		—	0.05
Camshaft cam height	IN	31.8	31.4
	EX	31.53	31.13
Valve rocker arm to shaft clearance		0.09 0.034	0.1
Valve stem-to-guide clearance	IN	0.010 0.037	0.06
	EX	0.025 0.052	0.08
Valve spring free length	IN	39.4	—
	EX	45.5	—
Valve spring compressed force	IN	7.7 8.9kg(at 33.7mm)	—
	EX	19.5 22.5kg(at 38.4mm)	—
Valve spring tilt	IN	1.7	—
	EX	1.95	—

7. CYLINDER HEAD/VALVES

TORQUE VALUES

Cylinder head nut	1.8 2.2kgf-m	Apply engine oil to threads
Valve clearance adjusting nut	1.4 1.8kgf-m	Apply engine oil to threads
Stud bolt	0.7 1.1kgf-m	

SPECIAL TOOLS

Valve spring compressor	E040
Tappet adjuster	E012

TROUBLESHOOTING

- The poor cylinder head operation can be diagnosed by a compression test or by tracing engine top-end noises.

Poor performance at idle speed

- Compression too low

Compression too low

- Incorrect valve clearance adjustment
- Burned or bend valves
- Incorrect valve timing
- Broken valve spring
- Poor valve and seat contact
- Leaking cylinder head gasket
- Warped or cracked cylinder head
- Poorly installed spark plug

Compression too high

- Excessive carbon build-up in combustion chamber

White smoke from exhaust muffler

- Worn valve stem or valve guide
- Damaged valve stem seal

Abnormal noise

- Incorrect valve clearance adjustment
- Sticking valve or broken valve spring
- Damaged or worn camshaft
- Worn cam chain guide
- Worn camshaft and rocker arm



7. CYLINDER HEAD/VALVES

CAMSHAFT REMOVAL


Remove seat, front cover, center cover.
Front fender, fuel tank and exhaust pipe.

Remove the four cylinder head cover bolts to remove the cylinder head cover.


Remove the cam chain tensioner cap bolt and the O-ring.



Turn the cam chain tensioner screw clockwise to tighten it.



Turn the flywheel counterclockwise so that the "T" mark on the flywheel aligns with the index mark on the crankcase to bring the round hole on the camshaft gear facing up to the top dead center on the compression stroke.




Cylinder Head Cover


7. CYLINDER HEAD/VALVES

Remove the four cylinder head nuts and washers.



Diagonally loosen the cylinder head nuts in 2 or 3 times.



Remove the camshaft holder and dowel pins.



Remove the camshaft gear from the cam chain and remove the camshaft.



CAMSHAFT INSPECTION

Check each cam lobe for wear or damage. Measure the cam lobe height.

Service Limits:

IN : 31.40mm replace if below

EX: 31.13mm replace if below



7. CYLINDER HEAD/VALVES

Check each camshaft bearing for play or damage. Replace the camshaft assembly with a new one if the bearings are noisy or have excessive play.



CAMSHAFT HOLDER DISASSEMBLY


Remove the bolt attaching the stop plate.
Take out the valve rocker arm shafts using a 5mm bolt.
Remove the valve rocker arms.

CAMSHAFT HOLDER INSPECTION


Inspect the camshaft holder, valve rocker arms and rocker arm shafts for wear or damage.

If the valve rocker arm contact surface is worn, check each cam lobe for wear or damage.

Measure the I.D. of each valve rocker arm.
Measure each rocker arm shaft O.D.
Measure arm to shaft clearance.
Replace as a set if out of specification.
Service limits: 0.10mm



Camshaft Holder



Rocker Arm Shafts



7. CYLINDER HEAD/VALVES

CYLINDER HEAD REMOVE





Remove the camshaft.
Remove the carburetor.
Remove the exhaust muffler.
Remove the carburetor intake manifold.

Remove the two cylinder head bolts.
Remove the cylinder head.

Remove the dowel pins and cylinder head gasket.
Remove the cam chain guide.

Remove all gasket material from the cylinder mating surface.

- Avoid damaging the cylinder mating surface.
- Be careful not to drop any gasket material into the engine.



7. CYLINDER HEAD/VALVES

CYLINDER HEAD DISASSEMBLY


Remove the valve spring cotters, retainers, springs, spring seats and valve stem seals using a valve spring compressor.

- Be sure to compress the valve springs with a valve spring compressor.
- Mark all disassembled parts to ensure correct reassembly.

Special

Valve Spring Compressor E040

Valve Spring Compressor



Remove carbon deposits from the combustion chamber.
Clean off any gasket material from the cylinder head mating surface.

Be careful not to damage the cylinder head mating surface.




INSPECTION

CYLINDER HEAD

Check the spark plug hole and valve areas for cracks.

Check the cylinder head for warpage with a straight edge and feeler gauge.

Service Limit: 0.05mm repair or replace if over




VALVE /VALVE GUIDE

Inspect each valve for bending, burning, scratches or abnormal stem wear.

Check valve movement in the guide.

Measure each valve stem O.D.



7. CYLINDER HEAD/VALVES

Measure each valve guide I.D.

Subtract each valve stem O.D. from the corresponding guide I.D. to obtain the stem-to-guide clearance.

Service limits: IN : 0.06mm replace if over
EX: 0.08mm replace if over

If the stem-to-guide clearance exceeds the service limits, replace the cylinder head as necessary.




VALVE SPRING FREE LENGTH

Measure the free length of the inner and outer valve springs.

Inner : 39.4mm replace if below

Outer: 45.5mm replace if below




Measure compressed force (valve spring) and installed length.

Replace if out of specification.

Service limits:

IN : 7.7 8.9kg (at 33.7mm)

EX : 19.5 22.5kg (at 38.4mm)




Measure the spring tilt.

Replace if out of specification.

Service limits: IN : 1.7mm

EX : 1.95mm



7. CYLINDER HEAD/VALVES

CYLINDER HEAD ASSEMBLY

Install the valve spring seats and valve stem seals.

Be sure to install new valve stem seals.

Lubricate each valve stem with engine oil and insert the valves into the valve guides. Install the valve springs and retainers.

Compress the valve springs using the valve spring compressor, then install the valve cotters.

- When assembling, a valve spring compressor must be used.
- Install the cotters with the pointed ends facing down from the upper side of the cylinder head.

Special

Valve Spring Compressor E040

Tap the valve stems gently with a plastic hammer for 2-3 times to firmly seat the cotters.


Be careful not to damage the valves.

CYLINDER HEAD INSTALLATION

Install the dowel pins and a new cylinder head gasket. Install the cam chain guide.




Valve Spring Compressor



Dowel Pins

Gasket




Cam Chain Guide

7. CYLINDER HEAD/VALVES

Install two cylinder head bolts do not tighten completely.

Install the cylinder head.

Torque: Stud Bolts :0.8 1.2kgf-m



Cylinder Head

CAMSHAFT HOLDER ASSEMBLY


Install the exhaust valve rocker arm to the "EX" mark side of the camshaft holder.

Install the intake valve rocker arm and the rocker arm shafts.

Tighten the bolt attaching stop plate.

- Align the cutout on the front end of the intake valve rocker arm shaft with the bolt of the camshaft holder.
- Align the cross cutout on the exhaust valve rocker arm shaft with the bolt of the camshaft holder.

Camshaft Holder




Valve Rocker Arm

CAMSHAFT INSTALLATION

Turn the flywheel so that the "T" mark on the flywheel aligns with the index mark on the crankcase.

Keep the round hole on the camshaft gear facing up and align the punch marks on the camshaft gear with the cylinder head surface (Position the intake and exhaust cam lobes down.) and install the camshaft onto the cylinder head.

Install the cam chain over the camshaft gear.



Punch Marks

Install the dowel pins.

Dowel Pins




7. CYLINDER HEAD/VALVES

Install the camshaft holder, washers and nuts on the cylinder head.
Tighten the four cylinder head nuts, then tighten two cylinder head bolts completely.


Torque: Cylinder head nut: 1.8 2.2kgf-m

- Apply engine oil to the threads of the cylinder head nuts.
- Diagonally tighten the cylinder head nuts in 2 3 times.



Washer

Adjust the valve clearance.
Turn the cam chain tensioner screw counter-clockwise to release it.



Tensioner Screw

Apply engine oil to a new O-ring and install it.
Tighten the cam chain tensioner cap bolt.


Be sure to install the O-ring into the groove properly.



Bolt

Install a new cylinder head cover O-ring and install the cylinder head cover.
Install and tighten the cylinder head cover bolts.

Be sure to install the O-ring into the groove properly.




Cylinder Head Cover

CYLINDER /PISTON

SERVICE INFORMATION-----	8- 2
TROUBLESHOOTING-----	8- 2
CYLINDER REMOVAL -----	8- 4
PISTON REMOVAL-----	8- 4
PISTON INSTALLATION-----	8- 8
CYLINDER INSTALLATION -----	8- 8



8. CYLINDER/PISTON



8. CYLINDER/PISTON

SERVICE INFORMATION

GENERAL INSTRUCTIONS

- The cylinder and piston can be serviced with the engine installed in the frame.
- After disassembly, clean the removed parts and dry them with compressed air before inspection.

TROUBLESHOOTING

- When hard starting or poor performance at low speed occurs, check the crankcase breather for white smoke. If white smoke is found, it means that the piston rings are worn, stuck or broken.

Compression too low or uneven

compression

- Worn, stuck or broken piston rings
- Worn or damaged cylinder and piston

Compression too high

- Excessive carbon build-up in combustion chamber or on piston head

Excessive smoke from exhaust muffler

- Worn or damaged piston rings
- Worn or damaged cylinder and piston

Abnormal noisy piston

- Worn cylinder, piston and piston rings
- Worn piston pin hole and piston pin

8. CYLINDER/PISTON

SPECIFICATIONS

Mx'er 150			Standard (mm)	Service Limit (mm)
Cylinder	I.D.		62.03 62.045	—
	Warpage		—	0.05
	Cylindricity		—	0.05
	True roundness		—	0.05
Piston, piston ring	Ring-to-groove clearance	Top	0.015 0.055	0.09
		Second	0.015 0.055	0.09
	Ring end gap	Top	0.10 0.25	0.5
		Second	0.10 0.25	0.5
		Oil side rail	0.2 0.7	—
	Piston O.D.		61.96 62	—
	Piston O.D. measuring position		5mm from bottom of skirt	—
	Piston-to-cylinder clearance		0.010 0.040	0.1
	Piston pin hole I.D.		15.002 15.008	15.04
Piston pin O.D		14.994 15.000	14.96	
Piston-to-piston pin clearance		0.002 0.014	0.02	
Connecting rod small end I.D. bore		15.016 15.034	15.06	


Mx'er 125			Standard (mm)	Service Limit (mm)
Cylinder	I.D.		56.53 56.545	—
	Warpage		—	0.05
	Cylindricity		—	0.05
	True roundness		—	0.05
Piston, piston ring	Ring-to-groove clearance	Top	0.015 0.055	0.09
		Second	0.015 0.055	0.09
	Ring end gap	Top	0.10 0.25	0.5
		Second	0.10 0.25	0.5
		Oil side rail	0.2 0.7	—
	Piston O.D.		56.46 56.5	—
	Piston O.D. measuring position		5mm from bottom of skirt	—
	Piston-to-cylinder clearance		0.010 0.040	0.1
	Piston pin hole I.D.		15.002 15.008	15.04
Piston pin O.D		14.994 15.000	14.96	
Piston-to-piston pin clearance		0.002 0.014	0.02	
Connecting rod small end I.D. bore		15.016 15.034	15.06	

8. CYLINDER/PISTON


CYLINDER REMOVAL

Turn the cam chain tension screw clockwise to tighten it.

Remove the two bolts on the cam chain tension.



Remove the cylinder head.
Remove the cam chain guide.
Remove the cylinder base bolts.
Remove the cylinder



Remove the cylinder gasket and dowel pins.
Clean any gasket material from the cylinder surface.




Dowel Pins

PISTON REMOVAL

Remove the piston pin clip.

Place a clean shop towel in the crankcase to keep the piston pin clip from falling into the crankcase.

Press the piston pin out of the piston and remove the piston.



Piston Pin Clip

8. CYLINDER/PISTON

Inspect the piston, piston pin and piston rings.

Remove the piston rings.

Take care not to damage or break the piston rings during removal.

Clean carbon deposits from the piston ring grooves.



Install the piston rings onto the piston and measure the piston ring-to-groove clearance.

Service Limits: **Top:** 0.09mm replace if over
2nd: 0.09mm replace if over




Remove the piston rings and insert each piston ring into the cylinder bottom.

Use the piston head to push each piston ring into the cylinder.

Measure the piston ring end gap.

Service Limit: 0.5mm replace if over



Measure the piston pin hole I.D.

Service Limit: 15.04mm replace if over



8. CYLINDER/PISTON

over

Measure the piston pin O.D.

Service Limit: 14.96mm replace if below



Measure the piston O.D.


Take measurement at 5mm from the bottom and 90° to the piston pin hole.

Piston O.D.: 61.96 62mm (MX'er 150)

Piston O.D.: 56.46 56.5mm (MX'er 125)

Measure the piston-to-piston pin clearance.

Service Limit: 0.02mm replace if over



CYLINDER INSPECTION

Inspect the cylinder bore for wear or damage. Measure the cylinder I.D. at three levels of top, middle and bottom at 90° to the piston pin (in both X and Y directions).

Cylinder I.D.:

62.03 62.045mm (MX'er 150)

56.53 56.545mm (MX'er 125)

Measure the cylinder-to-piston clearance.

Service Limit: 0.1mm repair or replace if over




The true roundness is the difference between the values measured in X and Y directions. The cylindricity (difference between the values measured at the three levels) is subject to the maximum value calculated.

Service Limits:

True Roundness: 0.05mm repair or replace if over

Cylindricity: 0.05mm repair or replace if



8. CYLINDER/PISTON

Inspect the top of the cylinder for warpage.
Service Limit: 0.05mm repair or replace if
over




Measure the connecting rod small end I.D.
Service Limit: 15.06mm replace if over



PISTON RING INSTALLATION

Install the piston rings onto the piston.
Apply engine oil to each piston ring.

- Be careful not to damage or break the piston and piston rings.
- All rings should be installed with the markings facing up.
- After installing the rings, they should rotate freely without sticking.



8. CYLINDER/PISTON


PISTON INSTALLATION

Remove any gasket material from the crankcase surface.

Be careful not to drop foreign matters into the crankcase.

Install the piston, piston pin and a new piston pin clip.

- Position the piston "IN" mark on the intake valve side.
- Place a clean shop towel in the crankcase to keep the piston pin clip from falling into the crankcase.




CYLINDER INSTALLATION

Install the dowel pins and a new cylinder gasket on the crankcase.

Coat the cylinder bore, piston and piston rings with clean engine oil.
Carefully lower the cylinder over the piston by compressing the piston rings.

- Be careful not to damage or break the piston rings.
- Stagger the ring end gaps at 120° to the piston pin.

Install the cam chain tension.
Tighten the cam chain tension bolts.



8. CYLINDER/PISTON


9. DRIVE AND DRIVEN PULLEYS

DRIVE AND DRIVEN PULLEYS

SERVICE INFORMATION..... 9-2
TROUBLESHOOTING..... 9-2
LEFT CRANKCASE COVER 9-3
DRIVE PULLEY 9-3
CLUTCH/DRIVEN PULLEY 9-3



9. DRIVE AND DRIVEN PULLEYS



9. DRIVE AND DRIVEN PULLEYS

SERVICE INFORMATION

GENERAL INSTRUCTIONS

- The drive pulley, clutch and driven pulley can be serviced with the engine installed in the frame.
- Avoid getting grease and oil on the drive belt and pulley faces. Remove any oil or grease from them to minimize the slipping of drive belt and drive pulley.

SPECIFICATIONS

Item	Standard (mm)	Service Limit (mm)
Movable drive face bushing I.D.	27.0 27.021	27.06
Drive face collar O.D.	26.97 26.99	226.94
Drive belt width	20.0 21.0	19.0
Clutch lining thickness	—	2.0
Clutch outer I.D.	130.0 130.2	130.5
Driven face spring free length	—	83.2
Driven face O.D.	33.965 33.485	33.94
Movable driven face I.D.	34.000 34.025	34.06
Weight roller O.D.	20.95 21.1	20.42

TORQUE VALUES

Drive face nut	5.5 6.5kgf-m
Clutch outer nut	5.0 6.0kgf-m

SPECIAL TOOLS

Universal holder	E017	Clutch spring compressor	E027
Bearing puller	E008	Oil seal and bearing install	E014

TROUBLESHOOTING

Engine starts but motorcycle won't move

- Worn drive belt
- Broken ramp plate
- Worn or damaged clutch lining
- Broken driven face spring

Lack of power

- Worn drive belt
- Weak driven face spring
- Worn weight roller
- Fouled drive face

Engine stalls or motorcycle creeps

- Broken clutch weight spring

9. DRIVE AND DRIVEN PULLEYS

LEFT CRANKCASE COVER

REMOVAL

Loosen the drive belt air tube band screw.




Remove the left crankcase cover bolts and left crankcase cover.
Remove the gasket and dowel pins.




DRIVE PULLEY

REMOVAL

Hold the drive pulley using an universal holder and remove the drive face nut and starting ratchet.
Remove the drive pulley face.

 Special

Universal Holder E017




Universal Holder

CLUTCH/DRIVEN PULLEY

Remove the drive pulley and drive belt.
Hold the clutch outer with the flywheel holder and remove the clutch outer nut.
Remove the clutch outer.
Remove the clutch/driven pulley and drive belt.

 Special

Universal Holder E017



Universal Holder


9. DRIVE AND DRIVEN PULLEYS

INSPECTION

Check the drive belt for cracks, separation or abnormal or excessive wear.
Measure the drive belt width.

Service Limit: 17.0mm replace if below

Use specified genuine parts for replacement.



Remove the movable drive face assembly.
Remove the drive pulley collar.

Drive Pulley Collar



Movable Drive Face Assembly

DISASSEMBLY

Remove the ramp plate.

Ramp Plate



Remove the weight rollers.

Weight Rollers



9. DRIVE AND DRIVEN PULLEYS

INSPECTION

Check each weight roller for wear or damage.
Measure each weight roller O.D.

Service Limit: 20.42mm replace if below.




Measure the movable drive face bushing I.D.

Service Limit: 27.06mm replace if over




Check the drive pulley bushing for wear or damage.
Measure the O.D. of the drive pulley bushing sliding surface.

Service Limit: 26.94mm replace if below



9. DRIVE AND DRIVEN PULLEYS

ASSEMBLY



Install the weight rollers into the movable drive face.



Weight Roller

Install the ramp plate.



Ramp Plate

9. DRIVE AND DRIVEN PULLEYS

Insert the drive pulley collar into the movable drive face.

Drive Pulley Collar



INSTALLATION

Install the movable drive face onto the crankshaft.




Movable Drive Face Assembly

INSPECTION


Inspect the clutch outer for wear or damage.
Measure the clutch outer I.D.

Service Limit: 130.5mm replace if over



CLUTCH/DRIVEN PULLEY DISASSEMBLY

Clutch



Driven Pulley

9. DRIVE AND DRIVEN PULLEYS

Hold the clutch/driven pulley assembly with the clutch spring compressor.

Be sure to use a clutch spring compressor to avoid spring damage.

Special

Clutch Spring Compressor E027



Set the clutch spring compressor in a vise and remove the clutch drive plate nut.

Loosen the clutch spring compressor and disassemble the clutch/driven pulley assembly. Remove the seal collar.

Check the driven face for wear or damage. Measure the clutch lining thickness.

Service Limit: 2.0mm replace if below

Pull out the guide roller pins and guide rollers. Remove the movable driven face from the driven face.




9. DRIVE AND DRIVEN PULLEYS

Remove the oil seal from the movable driven face.




INSPECTION


Measure the driven face spring free length.
Service Limit: 83.2mm replace if below



Check the driven face for wear or damage.
Measure the driven face O.D.
Service Limit: 33.94mm replace if below



Check the movable driven face for wear or damage.
Measure the movable driven face I.D.
Service Limit: 34.06mm replace if over




9. DRIVE AND DRIVEN PULLEYS

DRIVEN PULLEY FACE BEARING REPLACEMENT

Drive the inner needle bearing out of the driven pulley face.

Discard the removed bearing and replace with a new one.



Remove the snap ring and drive the outer bearing out of the driven face.

Discard the removed bearing and replace with a new one.




Apply grease to the outer bearing. Drive a new outer bearing into the driven face with the sealed end facing up.

Special

Bearing Puller E008

Seat the snap ring in its groove. Apply grease to the driven face bore areas.

Pack all bearing cavities with 9 9.5g grease.
Specified grease: Heat resistance 230°C



Press a new needle bearing into the driven face.


Special

Oil Seal And Bearing Install E014

CLUTCH DISASSEMBLY


Remove the circlips and retainer plate to disassemble the clutch.

Keep grease off the clutch linings.




9. DRIVE AND DRIVEN PULLEYS

CLUTCH / DRIVEN PULLEY ASSEMBLY




9. DRIVE AND DRIVEN PULLEYS

Install the damper rubbers on the drive plate pins.
 Install the clutch weights/shoes and clutch springs onto the drive plate.
 Install the retainer plate and secure with the circlips.




CLUTCH/DRIVEN PULLEY ASSEMBLY

Clean the driven pulley faces and remove any grease from them.
 Install the oil seal onto the moveable driven face.
 Apply grease to the Oil seal and install them onto the moveable driven face.



Install the movable driven face onto the driven face.
 Apply grease to the guide rollers and guide roller pins and then install them into the holes of the driven face.




Install the seal collar.
 Remove any excessive grease.

Be sure to clean the driven face off any grease.

Set the driven pulley assembly, driven face spring and clutch assembly onto the clutch spring compressor.

Align the flat surface of the driven face with the flat on the clutch drive plate.



9. DRIVE AND DRIVEN PULLEYS


Compress the clutch spring compressor and install the drive plate nut.
Set the clutch spring compressor in a vise and tighten the drive plate nut to the specified torque.

Torque: 5.0 6.0kgf-m

Be sure to use a clutch spring compressor to avoid spring damage.

Special

Clutch Spring Compressor E027



INSTALLATION

Install the clutch/driven pulley onto the drive shaft.

Keep grease off the drive shaft.




Install the clutch outer.
Hold the clutch outer with the flywheel holder.
Install and tighten the clutch outer nut.

Torque: 5.5kg-m

Special

Universal Holder E017

Install the drive belt.




Install the drive pulley face, starting ratchet and drive face nut.

When installing the drive pulley face, compress it to let the drive belt move downward to the lowest position so that the drive pulley can be tightened.

Install the starting ratchet by aligning the starting ratchet teeth with the crankshaft teeth.


Do not get oil or grease on the drive belt or pulley faces.

Torque: 5.5 6.5kgf-m



9. DRIVE AND DRIVEN PULLEYS

Install the left crankcase cover and tighten the cover bolts diagonally.
Connect the drive belt air tube and tighten the band screw.



FINAL REDUCTION/TRANSMISSION SYSTEM

SERVICE INFORMATION-----	10- 2
TROUBLESHOOTING-----	10- 2
FINAL REDUCTION DISASSEMBLY -----	10- 3
FINAL REDUCTION INSPECTION-----	10- 4
TRANSMISSION GEARS/CRANKSHAFT REMOVAL -----	10- 6
FINAL REDUCTION INSTALLATION -----	10- 7

10. FINAL REDUCTION/ TRANSMISSION SYSTEM

SERVICE INFORMATION

GENERAL INSTRUCTIONS

- When replacing the drive shaft, use a special tool to hold the bearing inner race for this operation.

SPECIFICATIONS

Specified Oil: GEAR OIL SAE 90#

Oil Capacity: At change : 0.2 liter
 At disassembly : 0.4 liter

TORQUE VALUES

Transmission case cover bolt 0.8 1.2kgf-m

SPECIAL TOOLS

Flywheel holder	E021
Flywheel puller	E005
Lock nut socket wrench	E009

TROUBLESHOOTING

Engine starts but motorcycle won't move

- Damaged transmission
- Seized or burnt transmission


Oil leaks

- Oil too rich
- Worn or damaged oil seal


10. FINAL REDUCTION/ TRANSMISSION SYSTEM

FINAL REDUCTION DISASSEMBLY


Drain engine oil and transmission gear oil into a clean container.
Remove the engine.
Remove the right crankcase cover.




Remove the shift gear spindle.
Remove the flywheel and starter clutch.
Remove the balance gear oil pump and starter motor.



Remove the left case bolt.




Remove the transmission case cover attaching bolts.



Crankcase Cover

10. FINAL REDUCTION/ TRANSMISSION SYSTEM

Remove gasket and two dowel pins.




FINAL REDUCTION/ TRANSMISSION INSPECTION

Inspect the change gear shaft for wear, damage or seizure.



Check the transmission operation.
Repair if unsmooth operation.



Remove the plug.




Gasket

10. FINAL REDUCTION/ TRANSMISSION SYSTEM

Remove spring, washer and shift cam stopper.

Shift Cam Stopper



Plug


Remove the transmission fork shaft and transmission fork.

Transmission fork




Transmission fork shaft

Measure the transmission fork shaft O.D.
Service Limit: 11.936



Measure the transmission fork shaft hole I.D.
Service Limit: 12.058



Washer

10. FINAL REDUCTION/ TRANSMISSION SYSTEM

Check the shift cam groove and shift cam gear.

Replace if wear or damage.




TRANSMISSION GEARS/ CRANKSHAFT REMOVAL

Remove the final gear and main shaft.

Driver Shaft

Countershaft




GEAR/SHAFT COLLAR INSPECTION

Check each gear and gear teeth for wear, damage, or poor lubrication.



Remove the counter shaft.

Countershaft




10. FINAL REDUCTION/ TRANSMISSION SYSTEM

FINAL REDUCTION INSPECTION


Inspect the countershaft and gear for wear or damage.



Inspect the drive shaft and gear for wear or damage.
Check the left crankcase bearings for excessive play and inspect the oil seal for wear or damage.



Inspect the final shaft gear for wear or damage.
Check the right crankcase bearings for excessive play and inspect the oil seal for wear or damage.



FINAL REDUCTION INSTALLATION

Install the final gear and final shaft into the left crankcase.
Install the countershaft and gear into the left crankcase.
Install the main shaft and gear into the left crankcase.




10. FINAL REDUCTION/ TRANSMISSION SYSTEM

Install the shift cam into the left crankcase.
Install the transmission fork to the main shaft gear and install the transmission fork guide pin into the shift cam groove.


Transmission Fork



Install the transmission fork shaft into the left crankcase.



Install the change gear shaft by aligning the punch mark between with the punch mark of the shift cam gear.



Install shift cam stopper, spring, washer and plug and tighten the plug.




10. FINAL REDUCTION/ TRANSMISSION SYSTEM


Install the dowel pins and a new gasket onto the right crankcase.

Tighten the crankcase attaching bolts.

Torque: 0.8 1.2kgf-m



Tighten the left crankcase attaching bolt.



Install the shaft gear, balance gear, oil pump, starter clutch and flywheel.

Install and tighten the right case cover bolt.

Install the shift gear spindle.

Install the cylinder.

Specified Gear Oil:

KYMCO SIGMA GEAR OIL 90#


Oil Capacity:

At disassembly : 0.4 liter

At change : 0.2 liter

Install and tighten the oil check bolt.

Torque: 0.8 1.2kgf-m



11. CRANKSCASE/CRANKSHAFT/ BALANCE SHAFT


MX'er SYSTEM

CRANKCASE/CRANKSHAFT/BALANCE SHAFT

SERVICE INFORMATION-----	11- 2
TROUBLESHOOTING-----	11- 2
CRANKCASE SEPARATION -----	11- 3
CRANKSHAFT INSPECTION-----	11- 4
CRANKCASE/BALANCE SHAFT ASSEMBLY-----	11- 5

11. CRANKCASE/CRANKSHAFT/ BALANCE SHAFT

MX'er SYSTEM



11. CRANKCASE/CRANKSHAFT/ BALANCE SHAFT

SERVICE INFORMATION

GENERAL INSTRUCTIONS

- This section covers crankcase separation to service the crankshaft. The engine must be removed for this operation.
- The following parts must be removed before separating the crankcase.
 - Cylinder head (⇒Section 7)
 - Cylinder/piston (⇒Section 8)
 - Drive and driven pulleys (⇒Section 9)
 - A.C. generator (⇒Section 4)
 - Carburetor/air cleaner (⇒Section 5)
 - Starter motor (⇒Section 16)
 - Oil pump (⇒Section 4)

SPECIFICATIONS

	Item	Standard (mm)	Service Limit (mm)
Crankshaft	Connecting rod big end side clearance	0.10 0.35	0.55
	Connecting rod big end radial clearance	0 0.008	0.05
	Run out	—	0.10

TORQUE VALUES

Crankcase bolt	0.8 1.2kgf-m
Cam chain tensioner slipper bolt	0.8 1.2kgf-m
Cam chain cover bolt	0.8 1.2kgf-m

TROUBLESHOOTING

- Excessive engine noise
- Excessive bearing play

11. CRANKCASE/CRANKSHAFT/ BALANCE SHAFT

MX'er SYSTEM



CRANKCASE SEPARATION

Remove the left and right crankcase
attaching bolts. (Section 10)
Separate the left and right crankcase halves.

Do not damage the crankcase gasket
surface.

Remove the gasket and dowel pins.

Remove balance shaft from the left
crankcase.




11. CRANKCASE/CRANKSHAFT/ BALANCE SHAFT

MX'er SYSTEM

Remove the crankshaft and cam chain from the left crankcase.

Clean off all gasket material from the crankcase mating surfaces.

Avoid damaging the crankcase mating surfaces.



CRANKSHAFT INSPECTION

Measure the connecting rod small end I.D.

Service Limit: 15.06 mm replace if over



Measure the connecting rod big end side clearance.

Service Limit: 0.55mm replace if over



11. CRANKCASE/CRANKSHAFT/ BALANCE SHAFT

MX'er SYSTEM


Turn the crankshaft bearings and check for excessive play.

Measure the crankshaft bearing play.

Service Limit:


Axial : 0.20mm replace if over

Radial : 0.05mm replace if over




Measure the crankshaft run out.

Service Limit: 0.10mm replace if over



CRANKCASE/BALANCE SHAFT ASSEMBLY

Install the cam chain into the left crankcase.
Install the crankshaft and balance shaft into the left crankcase.



Install the right and left crankcase.(10-8)


Tighten crankcase attach bolts.



11. CRANKSCASE/CRANKSHAFT/ BALANCE SHAFT

MX'er SYSTEM


Align the mark on the balance gear with the mark on the crankshaft gear.



Install the right and left case cover.



Install the cylinder.



**FRONT WHEEL/FRONT BRAKE/
FRONT SUSPENSION\STEERING SYSTEM**

SERVICE INFORMATION-----	12- 2
TROUBLESHOOTING-----	12- 3
FRONT WHEEL-----	12- 4
FRONT BRAKE -----	12- 7
FRONT SUSPENSION -----	12- 9
STEERING SYSTEM-----	12-13

12. FRONT WHEEL/FRONT BRAKE/FRONT SUSPENSION/STEERING SYSTEM



SERVICE INFORMATION

GENERAL INSTRUCTIONS

- Remove the machine frame covers before removing the front wheel. Jack the machine front wheel off the ground and be careful to prevent the machine from falling down.
- During servicing, keep oil or grease off the brake drum and brake linings.
- Inspect the brake system before riding.

SPECIFICATIONS

Item		Standard (mm)	Service Limit (mm)
Front wheel rim run out	Radial	—	2.0
	Axial	—	2.0
Front brake drum I.D		110	111
Front brake lining thickness		4	1.5
Tie rod length		266.5	—
Rod-end (tie rod) angle		180°	—

TORQUE VALUES

Steering stem nut	6.0	8.0kgf-m
Swing arm nut	4.0	5.0kgf-m
Front wheel nut	6.0	8.0kgf-m
Front wheel hub nut	6.0	8.0kgf-m
Front shock absorber upper mount bolt	3.5	4.5kgf-m
Front shock absorber lower mount bolt	3.5	4.5kgf-m

12. FRONT WHEEL/FRONT BRAKE/FRONT SUSPENSION/STEERING SYSTEM



SPECIAL TOOLS

Oil seal and bearing install E014

TROUBLESHOOTING

Hard steering (heavy)

- Insufficient tire pressure

Steers to one side or does not track straight

- Uneven front shock absorbers
- Bent front arm
- Bent steering knuckle

Poor brake performance

- Incorrectly adjusted brake
- Worn brake linings
- Contaminated brake lining surface
- Worn brake shoes at cam contacting area
- Worn brake drum
- Poorly connected brake arm

Front wheel wobbling

- Bent rim
- Excessive wheel bearing play
- Bent spoke plate
- Faulty tire
- Improperly tightened axle nut

Soft front shock absorber

- Weak shock springs
- Insufficient damper oil

Front shock absorber noise

- Slider bending
- Loose arm fasteners
- Lack of lubrication

12. FRONT WHEEL/Front BRAKE/Front SUSPENSION/STEERING SYSTEM


FRONT WHEEL

REMOVAL

Place the machine on a level place.
Remove four nuts attaching the wheel panel and front wheel.
Elevate the front wheels by placing a suitable stand under the frame.


Support the machine securely so there is no danger of it falling over.

Remove the cotter pin.
Remove nut attaching the wheel hub and washer.
Remove the collar and wheel hub.




FRONT BRAKE DISASSEMBLY

Loosen the lock nut and tighten the adjuster nut at brake lever. (Refer to the "FRONT BRAKE ADJUSTMENT" section in the CHAPTER 3.).
Disconnect the front brake cable from brake cam lever and remove the brake panel.
Remove the brake shoes.



REMOVE

Remove brake shoes and springs.
Remove the bolt attaching camshaft lever and remove camshaft lever.
Remove the wear indicator, camshaft and O-rings




12. FRONT WHEEL/Front BRAKE/Front SUSPENSION/STEERING SYSTEM

Measure the wheel run out.
Replace wheel or check bearing play if out of specification


Rim run out limits:

Vertical: 2.0mm

Lateral: 2.0mm




Inspect the front wheel hub.
Replace if cracks or damage.



Inspect the front brake drum.
Measure the front brake drum I.D.
Service limits: 111mm

Keep oil or grease off the brake drum.



FRONT WHEEL BEARING

Remove the side collar.



12. FRONT WHEEL/Front BRAKE/Front SUSPENSION/STEERING SYSTEM

Remove the dust seal.

Turn the inner race of each bearing with your finger to see if they turn smoothly and quietly. Also check if the outer race fits tightly in the hub.

Dust Seal



BEARING REPLACEMENT

Remove the front wheel bearings and distance collar.

Replace the bearings if the races do not turn smoothly, quietly, or if they fit loosely in the hub.


Apply grease to a new dust seal lip and install the dust seal.



Collar

Dust Seal

Side Collar



Wheel Bearing

Driver Handle

Pack all bearing cavities with grease.

Drive in the left bearing.

Install the distance collar.

Drive in the right bearing.

- Do not allow the bearings to tilt while driving them in.
- Drive in the bearing squarely with the sealed end facing out.

Special

Oil seal and bearing install E014



Outer Driver

12. FRONT WHEEL/FRONT BRAKE/FRONT SUSPENSION/STEERING SYSTEM

FRONT BRAKE

FRONT BRAKE LINING INSPECTION

Measure the front brake lining thickness.

Service limit: 2.0mm replace if below

Keep oil or grease off the brake linings.

Brake Lining



REMOVAL

Inspect the shoe springs, O-rings, camshaft lever and wear indicator.

Replace if damage.

Inspect the brake shoe plate.

Replace if cracks or damage.

Inspect the brake shoe pivot pin.

Replace if wear or damage.

Inspect the camshaft hole and camshaft.

Replace if scratches or excessive wear.

INSTALLATION



Reverse the "REMOVAL" procedures.

- Install the camshaft to the brake shoe plate with the slot of the camshaft placing at bass line of the wear indicator scale.
- Align the projection with the slot of the camshaft when installing the wear indicator to the camshaft.
- Align the cut-out of the camshaft lever with the slot of the camshaft when installing the camshaft lever to the camshaft.

Tighten the bolt for camshaft lever.

Torque: 1.8 2.5kgf-m


Apply the grease onto the o-ring, oil seal lips, pivot pin of brake shoe and camshaft.



12. FRONT WHEEL/FRONT BRAKE/FRONT SUSPENSION/STEERING SYSTEM

Install the brake shoe plate.

Make sure that the boss on the knuckle correctly engages with the locating slot on the brake shoe plate.




Apply the grease onto the bearings and oil seal lips of the wheel hub.
Install wheel hub, plate washer and tight the nut (wheel hub).

Torque: 6.0 8.0kgf-m

Install cotter pins.

Always use a new cotter pin.

Do not loosen the axle nut after torque tightening. If the axle nut groove is not aligned with the cotter pin hole, align groove with the hole by tightening it on the axle nut.



Install the front wheel and tighten the nuts (wheel).

Torque: 6.0 8.0kgf-m

Tapered wheel nuts are used for front wheels.
Install the nuts with its tapered side towards the wheel.



Adjust the front brake cable free play.

Refer to the "FRONT BRAKE ADJUSTMENT" section in the CHAPTER 3.

Brake cable free play: 10 20mm at lever pivot.

12. FRONT WHEEL/FRONT BRAKE/FRONT SUSPENSION/STEERING SYSTEM

FRONT SUSPENSION

REMOVAL

Elevate the front wheels by placing a suitable stand under the frame.

Support the machine securely so there is no danger of it falling over.

Remove the front wheel, wheel hub, brake shoe plate.

Remove the upper and lower bolt, then remove the shock absorber.


Remove the cotter pin and nut, then remove tie-rod from steering knuckle.

Remove cotter pin, nut, washer and bolt, then remove the steering knuckle, covers, collar and bush from the front arm.

Upper Bolt




Lower Bolt



Steering Knuckle

Cotter pin

Front arm Cotter pin Nut Steering Knuckle




Bolt

Washer

Bush

Cover

Collar



Bush

Cover

12. FRONT WHEEL/Front BRAKE/Front SUSPENSION/STEERING SYSTEM

INSPECTION

Check the front arm brackets of the frame.

If bent, cracked or damaged, repair or replace the frame.

Check the tightening torque of the front arms securing nuts.

Torque: 4.0 5.0kgf-m




Check the front arm side play by moving it from side to side.

If side play noticeable, replace the inner collar, bushings and thrust covers as a set.

Check the front arm vertical movement by moving it up and down.

If vertical movement is tight, binding or rough, replace the inner collar, bushings and thrust covers as a set.

Remove the two nut and two bolt attaching the front arm, then remove the front arm.



INSPECTION

Inspect the shock absorber rod.


Replace the shock absorber assembly if bends or damage.

Inspect the shock absorber.

Replace the shock absorber assembly if oil leaks.

Inspect the spring of the shock absorber by move the spring up and down.


Replace the shock absorber assembly if fatigue.



12. FRONT WHEEL/Front BRAKE/Front SUSPENSION/STEERING SYSTEM


KYMC **KYMC**
MX'er SYSTEM

Inspect the steering knuckle.
Replace if cracks, pitting or damage.




Inspect the front arm.
Replace if cracks, bends or damage.

Do not attempt to straighten a bent arm,
this may dangerously weaken the arm.



Inspect bushes.
Replace if wear or damage.



INSTALLATION

Reverse the "REMOVAL" procedures.

Apply the grease onto the bushes, collars
and covers.

Install the front arm nut onto the frame and
tighten the nuts.

Torque: 4.0 5.0kgf-m


12. FRONT WHEEL/FRONT BRAKE/FRONT SUSPENSION/STEERING SYSTEM

Apply the grease onto the bush, collars and covers, then install the steering knuckle onto the front arm and tighten the nut.

Torque: 4.0 5.0kgf-m

Install the cotter pin and band ends of cotter pin.

Always use a new cotter pin.




Install the tie-rod onto the steering knuckle and tighten the nut.

Torque: 4.0 5.0kgf-m

Install the cotter pin and band ends of cotter pin.

Always use a new cotter pin.



Bleed Valve

Install the shock absorber and tighten the upper and lower bolts.

Torque: 3.5 4.5kgf-m



Install the brake shoe plate, wheel hub and front wheel.

Refer to the "FRONT WHEEL INSTALLATION" section.

12. FRONT WHEEL/Front BRAKE/Front SUSPENSION/STEERING SYSTEM


STEERING SYSTEM

REMOVAL


Remove the following parts:
Seat, Front cover, Center cover and Front fender

Refer to the "FENDERS" section in the CHAPTER 2


Disconnect the main switch lead.
Remove the handlebar cover with main switch.




Disconnect the front brake cables from the brake lever, rear brake cable from the brake lever and brake switch from the bracket of the brake lever.



Disconnect the brake switch from the bracket of the brake lever while pushing the hook of the brake switch with a driver.




Remove the two screws to remove the cover of the throttle housing.
Disconnect the throttle cable from the lever.




12. FRONT WHEEL/FRONT BRAKE/FRONT SUSPENSION/STEERING SYSTEM

Remove the two screws and remove the handlebar switch.




Remove the two bolts and remove headlight unit.


Remove the four handlebar holder bolts and remove the handlebar.



Remove the cotter pins and nuts attaching the tie-rods, then remove tie-rods.




Remove the cotter pin and nut attaching the steering column, then remove steering column and collar.




12. FRONT WHEEL/FRONT BRAKE/FRONT SUSPENSION/STEERING SYSTEM

Remove the two bolts to remove the cable holder, steering bracket, collars and steering column.




INSPECTION

Inspect the handlebar.
Replace if cracks, bends or damage.




Inspect the steering column.
Replace if bends or damage.

Do not attempt to straighten a bent shaft, this may dangerously weaken the shaft.




Inspect the steering brackets and oil seal.
Replace if wear or damage.




12. FRONT WHEEL/FRONT BRAKE/FRONT SUSPENSION/STEERING SYSTEM

Inspect the tie-rod.
Replace if bend or damage.



Check the tie-rod end movement.
Replace if the tie-rod end exists free play or turns roughly.
Check the tapered surface of the tie-rod end.
Replace if pitting, wear or damage.



Adjust the tie-rod length.
Adjustment steps:
(The following procedures are done on both tie-rods, right and left.)
Loosen the lock nuts.
Adjust the tie-rod length by tuning both tie-rod ends.

Tie rod length: 266.5mm



Set the rod-end (steering column side) in an angle where the indentation surface of the tie-rod is parallel to the rod-end shaft, and then tighten the lock nut.

Torque: 2.5 3.5kgf-m

Set the other rod-end (knuckle arm side) in an angle as shown (right-hand tie-rod and left-hand tie-rod), and then tighten the lock nut.

Rod-end (tie rod) angle: 180°


Torque: 2.5 3.5kgf-m




After making adjustment on both tie rods be sure to mark them R and L for identification.

12. FRONT WHEEL/FRONT BRAKE/FRONT SUSPENSION/STEERING SYSTEM

The threads on both rod-end must be of the same length.




Inspect the collar, duty seal, snap ring and bearing.
Replace if wear or damage.



INSTALLATION


Reverse the "REMOVAL" procedures.

Apply the grease onto the collar, duty seal, and bearing.



Assembly the steering column and tighten the two bolts.

Torque: 1.8 2.5kgf-m
Band the lock washer tabs.




12. FRONT WHEEL/Front BRAKE/Front SUSPENSION/STEERING SYSTEM

Install the steering column and collar, then tighten the nut.

Torque: 6.0 8.0kgf-m

Install the cotter pin and band ends of cotter pin.

Always use a new cotter pin.




Install the tie rods and tighten the nut.


Torque: 4.0 5.0kgf-m

Install the cotter pin and band ends of cotter pin.

Always use a new cotter pin.




Be sure that the rod-end on the indentation surface side is connected to the steering column.




Install handlebar and handlebar holder, then tighten the four bolts.

Torque: 1.8 2.5kgf-m



12. FRONT WHEEL/FRONT BRAKE/FRONT SUSPENSION/STEERING SYSTEM

- Be sure the upper handlebar holder mark face to front.
- First tighten the bolts on the front side of the handlebar holder, and then tighten the bolts on the rear side.



Apply the grease onto the end of the throttle cable and end of the brake cable.

Refer to the “TOE-IN ADJUSTMENT” section in the CHAPTER 3 to adjust toe-in.


Refer to the “FRONT BRAKE ADJUSTMENT” section in the CHAPTER 3 to adjust front brake.

Refer to the “REAR BRAKE ADJUSTMENT” section in the CHAPTER 3 to adjust rear brake.


IGNITION SYSTEM

SERVICE INFORMATION-----	15- 2
TROUBLESHOOTING-----	15- 3
CDI UNIT INSPECTION-----	15- 4
IGNITION COIL-----	15- 6
PULSER COIL -----	15- 7

15. IGNITION SYSTEM



IGNITION CIRCUIT



15. IGNITION SYSTEM

SERVICE INFORMATION

GENERAL INSTRUCTIONS

- Check the ignition system according to the sequence specified in the Troubleshooting.
- The ignition system adopts CDI unit , change gear control and the ignition timing cannot be adjusted.
- If the timing is incorrect, inspect the CDI unit, A.C. generator, change gear control and replace any faulty parts. Inspect the CDI unit with a CDI tester
- Loose connector and poor wire connection are the main causes of faulty ignition system. Check each connector before operation.
- Use of spark plug with improper heat range is the main cause of poor engine performance.
- The inspections in this section are focused on maximum voltage. The inspection of ignition coil resistance is also described in this section.
- Inspect the ignition switch according to the continuity table specified in page 17-5.
- Inspect the spark plug referring to Section 3.

SPECIFICATIONS

Item		Standard	
Spark plug	Standard type	CR8E	
	Hot type		
	Cold type		
Spark plug gap		0.6□0.7mm	
Ignition timing	“F” mark Full advance	15°BTDC/1,700±100rpm	
Ignition coil resistance (20□)	Primary coil	0.2□0.3Ω	
	Secondary coil	with plug cap	3.2□4.8KΩ
		plug cap	4.2□5.2KΩ
Pulser coil resistance (20□)		50□60Ω	
Exciter coil resistance (20□)		100□120Ω	
Ignition coil primary side max. voltage		12V min.	
Pulser coil max. voltage		2.1V min.	

TESTING INSTRUMENT

Kowa Electric Tester

or commercially available electric tester with resistance over 10MΩ/CDV

15. IGNITION SYSTEM

TROUBLESHOOTING

High voltage too low

- Weak battery or low engine speed
- Loose ignition system connection
- Faulty CDI unit
- Faulty ignition coil
- Faulty pulser coil

Normal high voltage but no spark at plug

- Faulty spark plug
- Electric leakage in ignition secondary circuit
- Faulty ignition coil

Good spark at plug but engine won't start

- Faulty CDI or incorrect ignition timing
- Faulty change gear control unit
- Improperly tightened A.C. generator flywheel

No high voltage

- Faulty ignition switch
- Faulty CDI unit
- Poorly connected or broken CDI ground wire
- Dead battery or faulty regulator/rectifier
- Faulty ignition coil connector
- Faulty pulser coil

CDI UNIT INSPECTION


Remove the seat.
Disconnect the CDI coupler and remove the

15. IGNITION SYSTEM

CDI unit.

Measure the resistance between the terminals using the electric tester.

- Due to the semiconductor in circuit, it is necessary to use a specified tester for accurate testing. Use of an improper tester in an improper range may give false readings.
- Use a Sanwa Electric Tester or Kowa Electric Tester.
- In this table, “Needle swings then returns” indicates that there is a charging current applied to a condenser. The needle will then remain at “∞” unless the condenser is discharged.



Testing Range

Use the xKΩ range for the Sanwa Tester.

Use the xKΩ range for the Kowa Tester.

Unit: KΩ

Probe⊕ (-)Probe	Black/ White	Black/ Red	Blue/ White	Green	Green/ White	Black/ Yellow
Black/ White		∞	∞ Needle Swings then	∞ Needle Swings then	∞	∞
Black/ Red	3-6K		∞	∞	∞	∞
Blue/ White	35-42K	18-22K		8-10K	8-10K	∞
Green	15-18K	4.5-5.5K	7-9K		There is continuity	∞
Green/ White	15-18K	4.5-5.5K	8-9K	There is continuity		∞
Black/ Yellow	∞	∞	∞	∞	∞	

Note: The readings in this table are taken with a Sanwa Tester.

Change Gear Control



Test the CDI unit using the CDI tester.


Operate the CDI tester by following the manufacturer's instructions.

15. IGNITION SYSTEM


Connect the special connector to the CDI coupler and CDI tester.

Switch Range	Good CDI	Faulty CDI
1. OFF	No spark	—
2. P	No spark	—
3. EXT	No spark	Good spark
4. ON1	Good spark	No spark
5. ON2	Good spark	No spark

If the CDI unit is faulty, replace it with a new one.



Remove the seat.
 Disconnect the change gear control coupler and remove the change gear control unit.
 Measure the resistance between the terminals using the electric tester.



Testing Range

Use the xKΩ range for the Sanwa Tester.

Use the xKΩ range for the Kowa Tester.

Probe⊕ (-)Probe	Black	Green	Green/ Yellow	Green/ Pink	Light Green/ Red	Blue/ Yellow	Yellow/ Brown
Black		5-50K	5-50K	5-50K	5-50K	5-50K	5-50K
Green	∞		5-50K	5-50K	5-50K	5-50K	0
Green/ Yellow	∞	5-50K		10-50K	10-50K	10-50K	5-50K
Green/ Pink	∞	∞	∞		0	∞	∞
Light Green/ Red	∞	∞	∞	0		∞	∞
Blue/ Yellow	∞	50-200K	50-200K	50-200K	50-200K		
Yellow/ Brown	∞	0	5-50K	5-50K	5-50K	5-50K	

Note: The readings in this table are taken with a Sanwa Tester.

IGNITION COIL INSPECTION CONTINUITY TEST

15. IGNITION SYSTEM

Remove the front cover.
Remove the spark plug cap.
Disconnect the ignition coil wires.

This test is to inspect the continuity of ignition coil.

Measure the resistance between the ignition coil primary coil terminals.

Resistance: $0.2 \square 0.3 \Omega / 20 \square$

Remove the spark plug cap and measure the secondary coil resistance between the spark plug wire and the primary coil terminal.

Resistance: $3.2 \square 4.8 \text{K}\Omega / 20 \square$

This test is for reference only. Accurate test should be performed with a CDI tester.



Measure the spark plug cap resistance.

Remove the spark plug cap and measure the spark plug resistance.

Resistance: $4.2 \square 5.2 \text{K}\Omega / 20 \square$

Measure the resistance in the $\text{XK}\Omega$ range of the electric tester.



PERFORMANCE TEST

Test the performance with a CDI tester.

- Operate the CDI tester by following the manufacturer's instructions.
- Use the special connector to connect the CDI unit.

If the spark is weak, inspect the spark plug and CDI unit. If both of them are normal, replace the ignition coil with a new one.

Ignition Coil



PULSER COIL INSPECTION

15. IGNITION SYSTEM

Remove the front cover.

Disconnect the pulser coil wire coupler and measure the resistance between the blue/yellow and green/white wire terminals.


Resistance: $50 \square 60 \Omega$

EXCITER COIL


INSPECTION

Disconnect the exciter coil wire coupler and measure the resistance between the black/red wire terminal and ground.


Resistance: $100 \square 120 \Omega$



16. STARTING SYSTEM



STARTING CIRCUIT



16. STARTING SYSTEM

SERVICE INFORMATION

GENERAL INSTRUCTIONS

- The removal of starter motor can be accomplished with the engine installed.
- For the starter clutch removal, refer to Section 4.

SPECIFICATIONS

Item	Standard (mm)	Service Limit (mm)
Starter motor brush length	12.5	8.5

TROUBLESHOOTING

Starter motor won't turn

- Fuse burned out
- Weak battery
- Faulty ignition switch
- Faulty starter clutch
- Faulty front or rear stop switch
- Faulty starter relay
- Poorly connected, broken or shorted wire
- Faulty starter motor

Lack of power

- Weak battery
- Loose wire or connection
- Foreign matter stuck in starter motor or gear

Starter motor rotates but engine does not start

- Faulty starter clutch
- Starter motor rotates reversely
- Weak battery


16. STARTING SYSTEM

STARTER MOTOR

REMOVAL

Before removing the starter motor, turn the ignition switch OFF and remove the battery ground. Then, turn on the ignition switch and push the starter button to see if the starter motor operates properly.


Remove the two starter motor mounting bolts and the motor.
Remove the waterproof rubber jacket and disconnect the starter motor cable connector.



Starter Motor Cable

DISASSEMBLY

Remove the two starter motor case screws, front cover, motor case and other parts.



Case Screws

Front Cover

Motor Case


INSPECTION

Inspect the removed parts for wear, damage or discoloration and replace if necessary. Clean the commutator if there is metal powder between the segments.



Commutator

Check for continuity between pairs of the commutator segments and there should be continuity.
Also, make a continuity check between individual commutator segments and the armature shaft. There should be no continuity.



16. STARTING SYSTEM

STARTER MOTOR CASE CONTINUITY CHECK

Check to confirm that there is no continuity between the starter motor wire terminal and the motor front cover.

Also check for the continuity between the wire terminal and each brush.

Replace if necessary.



Wire Terminal

Measure the length of the brushes.

Service Limit: 8.5mm replace if below




Check for continuity between the brushes. If there is continuity, replace with new ones.



Check if the needle bearing in the front cover turns freely and has no excessive play.

Replace if necessary.

Check the dust seal for wear or damage.



Dust Seal

16. STARTING SYSTEM

ASSEMBLY


Apply grease to the dust seal in the front cover.
 Install the brushes onto the brush holders.
 Apply a thin coat of grease to the two ends of the armature shaft.
 Insert the commutator into the front cover.

- Be careful not to damage the brush and armature shaft mating surfaces.
- When installing the commutator, the armature shaft should not damage the dust seal lip.

Install a new O-ring to the front cover.
 Install the starter motor case, aligning the tab on the motor case with the groove on the front cover.
 Tighten the starter motor case screws.

- When assembling the front cover and motor case, slightly press down the armature shaft to assemble them.

Commutator




Front Cover

Tab Groove O-ring



Motor Case

Starter Relay



STARTER RELAY


INSPECTION

Remove the seat.
 Turn the ignition switch ON and the starter relay is normal if you hear a click when the starter button is depressed.
 If there is no click sound:

- Inspect the starter relay voltage
- Inspect the starter relay ground circuit
- Check for continuity between the starter relay yellow/red and green/red wire terminals

STARTER RELAY VOLTAGE INSPECTION

Connect a 12V battery across the starter relay yellow/red and green/red wire terminals.
 Connect an electric tester between the starter relay large terminals and check for continuity between the two terminals.
 The relay is normal if there is continuity.
 Replace the starter relay with a new one if there is no continuity.



STARTER MOTOR INSTALLATION


Connect the starter motor cable connector and properly install the waterproof rubber jacket.

Check the O-ring for wear or damage and replace if necessary.

Apply grease to the O-ring and install the starter motor.

Tighten the two mounting bolts.

The starter motor cable connector must be installed properly.




O-ring

LIGHTS/SWITCHES

SERVICE INFORMATION-----	17- 2
TROUBLESHOOTING-----	17- 2
HEADLIGHT -----	17- 3
INSTRUMENTS/STOP LIGHT/TAILLIGHT -----	17- 4
IGNITION SWITCH -----	17- 5
STOP SWITCH -----	17- 5
STARTER BUTTON-----	17- 6
HEADLIGHT SWITCH -----	17- 6
ENGINE STOP SWITCH -----	17- 6

17. LIGHTS/ SWITCHES

ELECTRICAL EQUIPMENT LAYOUT



17. LIGHTS/ SWITCHES

SERVICE INFORMATION

GENERAL INSTRUCTIONS

- An electric tester is needed to measure or test the electric equipment.
- Be sure to use fuses and bulbs of the same specifications to avoid damage of electrical equipment.
- After installation of each switch, a continuity check must be performed. A continuity check can usually be made without removing the part from the motorcycle.

TROUBLESHOOTING

Lights do not come on when ignition switch is "ON"

- Faulty ignition switch
- Fuse burned out
- Weak battery
- Burned bulb
- Faulty switch
- Poorly connected, broken or shorted wire

Engine starts but stalls during idling


- Clogged carburetor

HEADLIGHT

BULB REPLACEMENT

Disconnect the cover of the ignition switch and remove the two headlight attaching bolts.

Remove the headlight and disconnect the headlight wire coupler.



Remove the two headlight case attaching screws and disconnect the headlight.



Check the bulb for damage and replace with a new one if necessary.
Disconnect the headlight wire coupler.


Headlight Wire Coupler



Remove the rubber boot.
Push and disconnect the spring from the headlight cover.

Rubber Boot

Screws




17. LIGHTS/ SWITCHES

Remove the headlight bulb

INSTALLATION

Install the headlight in the reverse order of removal.

- After installation, adjust the headlight beam.




INSTRUMENTS

REMOVAL

Remove the two headlight attaching bolts. Remove the headlight and disconnect the headlight wire coupler. Remove the two headlight case attaching screws and disconnect the headlight.

Remove the light shell, rubber boot and bulb socket.

Check the bulb for damage and replace with a new one if necessary.




INSTALLATION

The installation sequence is the reverse of removal.


STOP LIGHT/TAILLIGHT

Remove the two taillight shell screws and the shell.



17. LIGHTS/ SWITCHES

Remove the bulb and check the bulb for damage. Replace with a new one if necessary.



IGNITION SWITCH

Check for continuity between the wires indicated below.

Color Position	Black	Red	Black/ White	Green
OFF			○ — ○	
ON	○ — ○			



STOP SWITCH

Disconnect the front stop switch wire coupler.

Check for continuity between the front stop switch wires.

Brake lever applied: There is continuity.

Brake lever released: There is no continuity.




17. LIGHTS/ SWITCHES

STARTER BUTTON

Remove the center cover.
Disconnect the starter button yellow/brown and yellow/red wires.
Check for continuity between the black and yellow/red wires.

Color Position	Yellow/Brown	Yellow/Red
FREE		
PUSH	○ —	— ○




Starter Button

HEADLIGHT SWITCH

Remove the center cover.
Disconnect the headlight switch wire coupler. Check for continuity between the headlight switch wires.

Color Position	Black	Brown	White	Blue
	○ —	○ —	— ○	
	○ —	○ —	— ○	— ○




Headlight Switch

Blue

ENGINE STOP SWITCH

Remove the center cover.
Disconnect the headlight switch wire coupler. Check for continuity between the headlight switch wires.

Color Position	Green/Red	Green
	○ —	— ○



Engine Stop Switch

Green

Green/Red


17. LIGHTS/ SWITCHES

ONLY ATV ON ROAD AVAILABLE

WARING DIAGRAM ----- 18- 1
BRAKE PEDAL ADJUSTMENT ----- 18- 2
INSTRUMENT ----- 18- 3
INDICATOR LIGHT----- 18- 3
HAZARD SWITCH ----- 18- 4
HORN ----- 18- 4

18. ONLY ATV ON ROAD AVAILABLE

WIRING DIAGRAM



HORN SW

HO	BAT
PUSH	O
COLOR	LG B

START SW

FREE	ST	C
PUSH	O	O
COLOR	Y/R	V/BR

WINKER SW

R	L	WR
O	O	O
COLOR	SB	GR

DIMMER SW

HL	LO	HI
O	O	O
COLOR	B	W L

HAZARD SW

BAT	HA
O	O
COLOR	R Y/B

COMB SW


BAT1	IG	E	BAT2
O	O	O	O
LOCK	R	B/W	G B

WHEEL RPM SENSOR


B	BLACK	BR	BROWN
G	GREEN	GR	GRAY
O	ORANGE	SB	SKY BLUE
L	BLUE	LG	LIGHT GREEN
W	WHITE	Y	YELLOW
R	RED		

BRAKE PEDAL ADJUSTMENT


The brake pedal free play should be adjusted to 10~20 mm (0.4~0.8 in) at the brake pedal pivot. If the free play is incorrect, adjust as Follows:




Keep front brake lever free play at 10~20 mm (0.4~0.8 in). (Refer to page 3-9)



Loosen the lock nut.
Turn the adjusting bolt until the front lower brake cable is tensed.
Apply the front brake lever and check front brake cam lever to make sure that the brake does not drag after adjusting.
Tighten the lock nut.



Turn the adjusting nut on the brake cam lever to decrease play or increase play.
Turn the adjusting nut until specified free play is obtained.



INSTRUMENT REMOVAL

Remove the two instrument attaching screws.


Disconnect the instrument.



Screws

Remove battery cover on instrument back to replace battery.


□ After replace battery, the instrument will be reset. (Refer to owner's manual)



Battery Cover

SENSOR WHEEL

If the sensor is lost or wore, the speed will be not calculated on the instrument.



Speed Wheel

INDICATOR LIGHT REMOVAL

Remove the screw and disconnect the cover of the ignition switch.




Screw

Remove the bulb socket and bulb.
 Check the bulb for damage and replace with a new one if necessary.

INSTALLATION


The installation sequence is the reverse of removal.



HAZARD SWITCH

Check for continuity between the wires indicated below.

Color Position	Yellow /Black	Black
	○ — ○	○
●		




HORN

REMOVAL

Disconnect the horn switch wire.
 Remove the bolt and remove horn.

INSTALLATION

The installation sequence is the reverse of removal.



18. ONLY ATV ON ROAD AVAILABLE

