



# **MA-X1**

## **Product Manual**

**Document Version: 01**

**Publication Date: 11 October 2018**



# 1

## Product Introduction

### 1.1 Appearance

Figure 1-1: Product Top View (Active Cooling Edition)






Figure 1-2: Product Bottom View



- ① : Finished product barcode label.

- **SN:98060410-1806105282**
  - ②: Electrostatic discharge (ESD) warning label.
- 
- 注意**  
**CAUTION**
1. 严禁裸手接触电子元器件或金手指，必要时请采取适当的防护措施。  
2. 只能接触板卡的外壳或面板进行取放。  
3. 请将板卡存放于有防静电措施的环境中。
- ③: CPLD\_Done – A flashing green LED indicates that the CPLD has loaded successfully.
  - ④: FPGA\_Done – A solid green LED indicates that the FPGA has loaded successfully.
  - ⑤: 8 Test LEDs (LED0 – LED7) can be programmed for debugging and testing via FPGA custom logic.
  - ⑥: CPLD\_JTAG – JTAG interface is in use for CPLD loading.


Figure 1-3: Product Panel View



- ①: 2x 100G QSPF28 optical interface with MPO connector.
- ②: Optical interface link indicator LEDs – LED1 for port 1 and LED2 for port 2. Solid green LED indicates link established; flashing yellow LED indicates transmission is in output state.
- ③: USB\_JTAG interface with micro-USB connector for JTAG programming support.
- ④: Power indicator LED – solid blue LED indicates that the power supply is operating normally.
- ⑤: RUN indicator LED – flashing green LED indicates that the product is operating normally.

## 1.2 Product Dimensions

Dual-Slot Active Cooling Edition (in mm)



## 1.3 Product Serial Number Identification

Material Code	Product Description	Corresponding Product Serial Number	Remarks
<b>98060410</b>	MA-X1 <b>dual-slot</b> standard product with active cooling, VU9P FPGA chip @ 300W power draw, 2x 100GE QSFP28 optical interface and <b>4x4GB</b> DDR4 RAM	<b>98060410-xxxxxxxxxx</b>	

# 2 Product Specifications

## 2.1 产品规格

Part	Description
Dimensions	<b>Active Cooling Edition (Dual-Slot)</b> Size (mm): 276.8 x 111.1 x 38.6 ( $\pm 0.4$ ) General linear dimensional tolerances are in compliance with GB1804-M standards
Main Processing Unit	Xilinx XCVU9P (full package name: XCVU9P-2LFLGB2104E) Vccint=0.72V (factory default) Supports variable Vccint adjustment between 0.72V-0.85V
PCIe Interface	PCIe Gen3 x16
RAM	4x DDR4 packages (each unit 4GB) Maximum speed 400Mbps 72-bit bit width (64-bit data and 8-bit ECC)
Flash	SPI NOR Flash, capacity to store 2 binary images (4x 2Gb)
EEPROM	64Kbit
Optical Interface	QSFP28, compatible with 100GE/4x 25GE (100GE QSFP28 MPO maximum line rate of 103.1 Gbps (wavelength 1310nm/850nm)
Power Supply	8-pin EPS-12V external power supply connector (up to 300W power draw)
SMBUS	SMBUS support for in-band and out-of-band management, independent power supply via CPLD ( <a href="#">XC3S200AN-4FTG256C</a> )
Clock	System clock 100MHz and 400MHz, other clocks are arranged by custom circuit logic design
Heat Dissipation	Active cooling via fans (dual-slot)
Debug Interface	The board provides a 6-pin JTAG interface and a micro-USB to JTGA interface for debugging
Operating Environment	Operating temperature: 5°C - 35°C Storage temperature: -20°C - 70°C

# 3

# Installation and Removal Guide

---

## 3.1 Installation

- Step 1: Wear anti-static gloves or anti-static wrist strap.
- Step 2: Power off the workstation and disconnect the power supply to the workstation to ensure the workstation chassis is grounded.
- Step 3: Open the workstation chassis according to workstation's operating manual, insert the MA-X1 into the PCIe x16 slot and connect the card's external power supply interface to the workstation's power supply unit.
- Step 4: Secure the card to the chassis with screws (where available).
- Step 5: Reconnect the power supply to the workstation and observe the Power and RUN indicator LEDs on the card's panel.
- If the power indicator LED is solid blue and the RUN indicator LED is flashing green, the board is operating normally.
  - If either or both the power and RUN indicator LEDs are off, the board might be malfunctioning. Please safely power off the workstation, remove the board and contact technical support.

## 3.2 Removal

- Step 1: Wear anti-static gloves or anti-static wrist strap.
- Step 2: Power off the workstation and disconnect the power supply to the workstation to ensure the workstation chassis is grounded.
- Step 3: Open the workstation chassis according to workstation's operating manual, remove the screws securing the card to the chassis (if used) and slowly pull the card straight out.
- Step 4: Place the card in the anti-static packaging and replace the workstation chassis cover.