



OpenStack Cinder Driver

Configuration Guide

Issue 01

Date 2018-10-15

Copyright © Huawei Technologies Co., Ltd. 2018. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

Trademarks and Permissions



HUAWEI and other Huawei trademarks are trademarks of Huawei Technologies Co., Ltd.

All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between Huawei and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

Huawei Technologies Co., Ltd.

Address: Huawei Industrial Base
Bantian, Longgang
Shenzhen 518129
People's Republic of China

Website: <http://www.huawei.com>

Email: support@huawei.com

Contents

1 Overview	1
2 Version Mappings	2
3 Cinder Driver Installation&deployment	4
3.1 Obtain Cinder Driver	4
3.2 Ubuntu Environment Deployment	5
3.3 RedHat OpenStack Deployment	5
4 Cinder Driver Basis Properties Configuration	7
4.1 Configuring the Cinder Driver for iSCSI Storage	7
4.1.1 Configuring the Cinder Driver for OceanStor T Series V1 (iSCSI)	8
4.1.2 Configuring the Cinder Driver for OceanStor T Series V2 (iSCSI)	9
4.1.3 Configuring the Cinder Driver for OceanStor V3/V5(iSCSI)	10
4.1.4 Configuring the Cinder Driver for OceanStor 18000 Series(iSCSI)	11
4.1.5 Configuring the Cinder Driver for Dorado Series V3(iSCSI)	12
4.1.6 Parameters in the Configuration File	13
4.1.7 Configuring iSCSI Multipathing	15
4.1.8 Configuring CHAP and ALUA	16
4.2 Configuring the Cinder Driver for Fibre Channel Storage	17
4.2.1 Configuring the Cinder Driver for OceanStor T Series V1 (Fibre Channel)	18
4.2.2 Configuring the Cinder Driver for OceanStor T Series V2 (Fibre Channel)	19
4.2.3 Configuring the Cinder Driver for OceanStor V3/V5 (Fibre Channel)	20
4.2.4 Configuring the Cinder Driver of OceanStor 18000 Series (Fibre Channel)	21
4.2.5 Configuring the Cinder Driver for Dorado Series V3(Fibre Channel)	22
4.2.6 Configuring the Auto Zoning	23
4.2.7 Parameters in the Configuration File	24
4.2.8 Configuring FC Multipathing	25
4.2.9 Configuring ALUA	26
4.3 Configuring Multi-Storage Support	26
4.4 Using tenant user	27
5 Cinder Driver Advanced Properties Configuration	28
5.1 Configuring the SmartQoS Property	29
5.1.1 Configuring the Front-end QoS	29
5.1.2 Configuring the Maximum Control IOPS	30

5.1.3 Configuring the Minimum Control IOPS.....	31
5.1.4 Configuring the Maximum Control Bandwidth.....	32
5.1.5 Configuring the Minimum Control Bandwidth.....	33
5.1.6 Configuring the Control Latency.....	34
5.1.7 Configuring Multiple Control Policies.....	35
5.2 Configuring the SmartPartition Property.....	37
5.3 Configuring the Thick Property.....	38
5.4 Configuring the Thin Property.....	39
5.5 Configuring the SmartCache Property.....	39
5.6 Configuring the SmartTier Property.....	40
5.7 Configuring the HyperMetro Property.....	41
5.8 Configuring the Replication V2.1.....	43
5.9 Create a volume on a certain storage pool.....	45
5.10 Create a volume with a certain disk type.....	46
5.11 Create a volume on a certain volume back end.....	47
5.12 Configuring Consistency Groups.....	48
5.13 Configuring Backup Snapshot.....	48
5.14 Configuring Certificate Verify.....	48
5.15 Configuring the Owning Controller of a LUN.....	49
5.16 Configuring the SmartDedupe Property.....	49
5.17 Configuring the SmartCompression Property.....	50
5.18 Create a volume with fast clone.....	52
5.19 Configuring the LUN Copy Speed.....	52
6 Best Practices.....	53
6.1 Quick Interconnection with Huawei Storage.....	53
7 FAQ.....	55
7.1 Need to manually create the mapping associated objects like Host, Host Group or Lun Group on Huawei storage beforehand before attaching volume via Cinder Driver?.....	55
7.2 Nova log prints "lsblk " command execution failed while attaching volume.....	55

1 Overview

This chapter describes the definition of the Cinder Driver.

Cinder Driver is a plug-in that is deployed on the OpenStack Cinder module. The plug-in can be used to provide functions such as the logical volume and snapshot for virtual machines (VMs) in the OpenStack Cinder Driver that supports iSCSI and Fibre Channel protocols.

2 Version Mappings

This chapter describes the version mappings among the Cinder Driver, Huawei storage system, and OpenStack.

You can query the version mapping table of eSDK plug-ins to obtain the storage system versions. To obtain the version mapping table, log in to <http://support.huawei.com/enterprise/en/index.html>. In the search box, enter **eSDK Enterprise Storage Plugins** to search for and download the *eSDK Enterprise Storage Plugins x.x.xxx Version Mapping*. x.x.xxx indicates the version number.

 **NOTE**

Huawei T series storages are not supported anymore from Rocky version.

Table 2-1 Version mappings among the Cinder Driver, Features and OpenStack. (√ :support, x:unsupport)

Features	Mitaka	Newton	Ocata	Pike	Queens	Rocky
Create Volume	√	√	√	√	√	√
Delete Volume	√	√	√	√	√	√
Attach Volume	√	√	√	√	√	√
Detach Volume	√	√	√	√	√	√
Extend Volume	√	√	√	√	√	√
Create Snapshot	√	√	√	√	√	√
Delete Snapshot	√	√	√	√	√	√
Create Volume from Snapshot	√	√	√	√	√	√
Create Volume from Image	√	√	√	√	√	√
Create Volume from Volume	√	√	√	√	√	√
Create Image from Volume	√	√	√	√	√	√
Volume Migration	√	√	√	√	√	√

Features	Mitaka	Newton	Ocata	Pike	Queens	Rocky
QoS	√	√	√	√	√	√
Auto zoning	√	√	√	√	√	√
SmartTier	√	√	√	√	√	√
SmartCache	√	√	√	√	√	√
SmartThin	√	√	√	√	√	√
SmartThick	√	√	√	√	√	√
SmartPartition	√	√	√	√	√	√
HyperMetro	√	√	√	√	√	√
Retype	√	√	√	√	√	√
Manage/Unmanage Volume	√	√	√	√	√	√
Manage/Unmanage Snapshot	√	√	√	√	√	√
Replication V2.1	√	√	√	√	√	√
HyperMetro Consistency Group	√	√	√	√	√	√
Create a volume on a certain storage pool	√	√	√	√	√	√
Create a volume with certain disk type	√	√	√	√	√	√
Backup Snapshot	√	√	√	√	√	√
Snapshot Consistency Group	√	√	√	√	√	√
Multipath	√	√	√	√	√	√
Consistency Group	√	√	√	√	√	√

NOTICE

- OceanStor Dorado does not support Thick LUN, SmartTier, SmartCache and SmartPartition features.
- Low-end storage system doesn't support some advanced features, please refer to the specifications of the corresponding storage system.

3 Cinder Driver Installation&deployment

[3.1 Obtain Cinder Driver](#)

[3.2 Ubuntu Environment Deployment](#)

[3.3 RedHat OpenStack Deployment](#)

3.1 Obtain Cinder Driver

Two ways to obtain OpenStack Driver:

One is through the OpenStack community warehouse. From Kilo, Huawei has contributed Huawei Storage Driver to OpenStack, users can download OpenStack Driver from OpenStack community for free. After installing the specified OpenStack, OpenStack Driver will be placed under the catalog of "../cinder/cinder/volume/drivers/huawei". If you don't find the corresponding installation files, you can download the OpenStack Driver from OpenStack community warehouse at <https://github.com/openstack/cinder>.

Another is through Huawei OpenStack Driver warehouse. By visiting https://github.com/huaweistorage/OpenStack_Driver, you can download OpenStack Driver that corresponds to OpenStack community version.

Steps to get Cinder Driver are as follows:

NOTE

- A community version cannot be integrated with new features once being released and has security risks because its debug process is time-consuming.
- However, OpenStack Driver obtained from OpenStack Driver repository can be integrated with newly launched features and debugged in a timely manner, when a supportive framework is used.
- The community only maintains two stable versions. However, Huawei OpenStack Driver library maintains six stable versions, ensuring long-term stable running of historical versions.
- You are strongly recommended to use Huawei OpenStack Driver library versions, instead of community versions.

Step 1 Enter the above warehouse address in the browser, for example Huawei warehouse address:

https://github.com/huaweistorage/OpenStack_Driver.

Step 2 Click the "Download ZIP" bottom to download Driver, and unzip it.

- Step 3** Find "Cinder" catalog in which the Diver is extracted, there are multiple OpenStack Driver for different OpenStack version, choose the corresponding Driver.

----End

3.2 Ubuntu Environment Deployment

The OpenStack standard deployment steps are as follows:

- Step 1** Before installation, delete all the installation files of Huawei OpenStack Dvrer, the default path is /usr/lib/python2.7/dist-packages/cinder/volume/drivers/huawei.

⚠ CAUTION

On my host, the version of Python is 2.7, if other version is used, make corresponding changes to the Driver path. You can also get the Cinder Driver installation directory by the following method:

```
root@ubuntu:~# find / -name huawei_driver.py
/usr/lib/python2.7/dist-packages/cinder/volume/drivers/huawei/huawei_driver.py
```

- Step 2** Copy OpenStack Cinder Driver to Cinder Driver installation directory, the default directory refer to step 1.

- Step 3** Refer to chapter 4 and 5 to do the configuration.

- Step 4** After configuration, restart Cinder-Volume service:

```
service cinder-volume restart
```

- Step 5** Check the status of services by inputting cinder service-list, if the "State" status of Cinder-Volume is up, that means Cinder-Volume is OK.

```
root@ubuntuL004:/# cinder service-list
+-----+-----+-----+-----+-----+-----+-----+-----+
+-----+-----+-----+-----+-----+-----+-----+-----+
State |Updated_at| Disabled Reason |-----+-----+-----+-----+
+-----+-----+-----+-----+-----+-----+-----+-----+
cinder-
scheduler |ubuntuL004| nova | enabled |up| 2016-02-01T16:26:00.000000 |-|
cinder-
volume|ubuntuL004@v3r3| nova | enabled |up| 2016-02-01T16:25:53.000000 |-|
+-----+-----+-----+-----+-----+-----+-----+-----+
+-----+-----+-----+-----+-----+-----+-----+-----+
```

----End

3.3 RedHat OpenStack Deployment

RedHat OpenStack deployment steps are as follows:

- Step 1** Before installation, delete all the installation files of Huawei OpenStack Dvrer, the default path is /usr/lib/python2.7/disk-packages/cinder/volume/drivers/huawei.

⚠ CAUTION

On my host, the version of Python is 2.7, if other version is used, make corresponding changes to the Driver path. You can also get the Cinder Driver installation directory by the following method:

```
root@redhatL004:~# find / -name huawei_driver.py
/usr/lib/python2.7/dist-packages/cinder/volume/drivers/huawei/huawei_driver.py
```

Step 2 Copy OpenStack Cinder Driver to Cinder Driver installation directory, the default directory refer to step 1.

Step 3 Refer to chapter 4 and 5 to do the configuration.

Step 4 After configuration, restart Cinder-Volume service:

```
systemctl restart openstack-cinder-volume.service
```

Step 5 Check the status of services by inputting cinder service-list, if the "State" status of Cinder-Volume is up, that means Cinder-Volume is OK.

```
root@redhatL004:/# cinder service-list
+-----+-----+-----+-----+-----+-----+
+-----+-----+-----+-----+-----+-----+-----+-----+-----+
State |Updated_at| Disabled Reason |+-----+-----+-----+-----+
+-----+-----+-----+-----+-----+-----+-----+-----+-----+
scheduler |redhatL004| nova | enabled |up| 2016-02-01T16:26:00.000000 |-| |cinder-
volume|redhatL004@v3r3| nova | enabled |up| 2016-02-01T16:25:53.000000 |-|
+-----+-----+-----+-----+-----+-----+
+-----+-----+-----+-----+-----+-----+
```

----End

4 Cinder Driver Basis Properties Configuration

This chapter describes how to configure the Huawei Cinder Driver for iSCSI storage and FC storage.

NOTICE

The storage pool that driver will use, must make sure that it already exists in Huawei storage, otherwise please create it manually, and the usage of this storage pool must be "Block Storage Service".

[4.1 Configuring the Cinder Driver for iSCSI Storage](#)

[4.2 Configuring the Cinder Driver for Fibre Channel Storage](#)

[4.3 Configuring Multi-Storage Support](#)

[4.4 Using tenant user](#)

4.1 Configuring the Cinder Driver for iSCSI Storage

This section describes how to configure the Cinder Driver for different products for iSCSI storage products.

Prerequisites

When create a volume from image, the multipath tool must be installed, and add the following configuration keys in the target back end configuration group of the `/etc/cinder/cinder.conf` file in Cinder Volume node:

```
use_multipath_for_image_xfer = True
enforce_multipath_for_image_xfer = True
```

4.1.1 Configuring the Cinder Driver for OceanStor T Series V1 (iSCSI)

Procedure

- Step 1** In `/etc/cinder`, create a Huawei-customized driver configuration file. The file format is XML. Change the name of the driver configuration file based on site requirements, for example, `cinder_huawei_conf.xml`.
- Step 2** Configure parameters in the driver configuration file, including mandatory and optional parameters.

Mandatory parameters:

```
<?xml version='1.0' encoding='UTF-8'?>
<config>
  <Storage>
    <Product>T</Product>
    <Protocol>iSCSI</Protocol>
    <ControllerIP0>x.x.x.x</ControllerIP0>
    <ControllerIP1>x.x.x.x</ControllerIP1>
    <UserName>xxx</UserName>
    <UserPassword>xxx</UserPassword>
  </Storage>
  <LUN>
    <StoragePool Name="xxx" />
    <StoragePool Name="xxx" />
  </LUN>
  <iSCSI>
    <DefaultTargetIP>x.x.x.x</DefaultTargetIP>
  </iSCSI>
  <Host OSType="Linux" HostIP="x.x.x.x, x.x.x.x" />
</config>
```

Optional parameters(Pick and add the optional parameter in the above XML file):

```
<LUN>
  <LUNType>xxx</LUNType>
  <StripUnitSize>xxx</StripUnitSize>
  <WriteType>xxx</WriteType>
  <Prefetch Type="xxx" Value="xxx" />
</LUN>
<iSCSI>
  <Initiator Name="xxx" TargetIP="x.x.x.x" />
</iSCSI>
```

NOTE

Make sure the owner and group of `/etc/cinder/cinder_huawei_conf.xml` file are the same as `/etc/cinder/cinder.conf` file's owner and group.

```
-rw-r--r-- 1 cinder cinder 2662 Jul 29 02:13 cinder.conf
-rw-r--r-- 1 cinder cinder 778 Jul 30 02:56 cinder_huawei_conf.xml
```

For details about the parameters in the configuration file, see section "4.1.6".

- Step 3** Configure the `cinder.conf` file.

Add a `[TV1_iSCSI]` section at the end of `/etc/cinder/cinder.conf` file, configure the TV1_iSCSI back end with the Huawei driver. The `volume_driver` indicates the loaded driver file, and `cinder_huawei_conf_file` indicates the specified Huawei-customized configuration file.

```
[TV1_iSCSI]
volume_driver = cinder.volume.drivers.huawei.huawei_t.HuaweiTISCSIDriver
```

```
cinder_huawei_conf_file = /etc/cinder/cinder_huawei_conf.xml
volume_backend_name = TV1_iSCSI
```

In the [DEFAULT] section, enable the TV1_iSCSI back end:

```
[DEFAULT]
...
enabled_backends=TV1_iSCSI
```

Step 4 Restart the Cinder service.

---End

4.1.2 Configuring the Cinder Driver for OceanStor T Series V2 (iSCSI)

Procedure

Step 1 In `/etc/cinder`, create a Huawei-customized driver configuration file. The file format is XML. Change the name of the driver configuration file based on site requirements, for example, `cinder_huawei_conf.xml`.

Step 2 Configure parameters in the driver configuration file, including mandatory and optional parameters.

Mandatory parameters:

```
<?xml version='1.0' encoding='UTF-8'?>
<config>
  <Storage>
    <Product>TV2</Product>
    <Protocol>iSCSI</Protocol>
    <RestURL>https://x.x.x.x:8088/deviceManager/rest/</RestURL>
    <UserName>xxx</UserName>
    <UserPassword>xxx</UserPassword>
  </Storage>
  <LUN>
    <StoragePool>xxx</StoragePool>
  </LUN>
  <iSCSI>
    <DefaultTargetIP>x.x.x.x</DefaultTargetIP>
  </iSCSI>
</config>
```

Optional parameters(Pick and add the optional parameter in the above XML file):

```
<LUN>
  <LUNType>xxx</LUNType>
  <WriteType>xxx</WriteType>
  <Prefetch Type="xxx" Value="xxx" />
  <LUNcopyWaitInterval>xxx</LUNcopyWaitInterval>
  <Timeout>432000</Timeout>
</LUN>
<iSCSI>
  <Initiator Name="xxx" TargetIP="x.x.x.x" />
</iSCSI>
```

NOTE

Make sure the owner and group of `/etc/cinder/cinder_huawei_conf.xml` file are the same as `/etc/cinder/cinder.conf` file's owner and group.

```
-rw-r--r-- 1 cinder cinder 2662 Jul 29 02:13 cinder.conf
-rw-r--r-- 1 cinder cinder 778 Jul 30 02:56 cinder_huawei_conf.xml
```

For details about the parameters in the configuration file, see section "4.1.6".

Step 3 Configure the **cinder.conf** file.

Add a [TV2_iSCSI] section at the end of "/etc/cinder/cinder.conf" file, configure the TV2_iSCSI back end with the Huawei driver. The **volume_driver** indicates the loaded driver file, and **cinder_huawei_conf_file** indicates the specified Huawei-customized configuration file.

```
[TV2_iSCSI]
volume_driver = cinder.volume.drivers.huawei.huawei_driver.HuaweiISCSIDriver
cinder_huawei_conf_file = /etc/cinder/cinder_huawei_conf.xml
volume_backend_name = TV2_iSCSI
```

In the [DEFAULT] section, enable the TV2_iSCSI back end:

```
[DEFAULT]
...
enabled_backends=TV2_iSCSI
```

Step 4 Restart the Cinder service.

---End

4.1.3 Configuring the Cinder Driver for OceanStor V3/V5(iSCSI)

Procedure

Step 1 In **/etc/cinder**, create a Huawei-customized driver configuration file. The file format is XML. Change the name of the driver configuration file based on site requirements, for example, **cinder_huawei_conf.xml**.

Step 2 Configure parameters in the driver configuration file, including mandatory and optional parameters.

Mandatory parameters:

```
<?xml version='1.0' encoding='UTF-8'?>
<config>
  <Storage>
    <Product>V3</Product>
    <Protocol>iSCSI</Protocol>
    <RestURL>https://x.x.x.x:8088/deviceManager/rest/</RestURL>
    <UserName>xxx</UserName>
    <UserPassword>xxx</UserPassword>
  </Storage>
  <LUN>
    <LUNType>Thin</LUNType>
    <StoragePool>xxx</StoragePool>
  </LUN>
  <iSCSI>
    <DefaultTargetIP>x.x.x.x</DefaultTargetIP>
  </iSCSI>
</config>
```

Optional parameters(Pick and add the optional parameter in the above XML file):

```
<LUN>
  <WriteType>xxx</WriteType>
  <Prefetch Type="xxx" Value="xxx" />
</LUN>
<iSCSI>
  <Initiator Name="xxx" TargetIP="x.x.x.x" />
</iSCSI>
```

 **NOTE**

Make sure the owner and group of "/etc/cinder/cinder_huawei_conf.xml" file are the same as "/etc/cinder/cinder.conf" file's owner and group.

```
-rw-r--r-- 1 cinder cinder 2662 Jul 29 02:13 cinder.conf
-rw-r--r-- 1 cinder cinder 778 Jul 30 02:56 cinder_huawei_conf.xml
```

For details about the parameters in the configuration file, see section "4.1.6".

Step 3 Configure the **cinder.conf** file.

Add a [V3_iSCSI] section at the end of "/etc/cinder/cinder.conf" file, configure the V3_iSCSI back end with the Huawei driver. The **volume_driver** indicates the loaded driver file, and **cinder_huawei_conf_file** indicates the specified Huawei-customized configuration file.

```
[V3_iSCSI]
volume_driver = cinder.volume.drivers.huawei.huawei_driver.HuaweiISCSIDriver
cinder_huawei_conf_file = /etc/cinder/cinder_huawei_conf.xml
volume_backend_name = V3_iSCSI
```

In the [DEFAULT] section, enable the V3_iSCSI back end:

```
[DEFAULT]
...
enabled_backends=V3_iSCSI
```

Step 4 Restart the Cinder service.

----End

4.1.4 Configuring the Cinder Driver for OceanStor 18000 Series(iSCSI)

This section describes how to configure the Cinder Driver for 18000 series for iSCSI storage products.

Procedure

- Step 1** In **/etc/cinder**, create a Huawei-customized driver configuration file. The file format is XML. Change the name of the driver configuration file based on site requirements, for example, **cinder_huawei_conf.xml**.
- Step 2** Configure parameters in the driver configuration file, including mandatory and optional parameters.

Mandatory parameters:

```
<?xml version='1.0' encoding='UTF-8'?>
<config>
  <Storage>
    <Product>18000</Product>
    <Protocol>iSCSI</Protocol>
    <RestURL>https://x.x.x.x:8088/deviceManager/rest/</RestURL>
    <UserName>xxx</UserName>
    <UserPassword>xxx</UserPassword>
  </Storage>
  <LUN>
    <StoragePool>xxx</StoragePool>
  </LUN>
  <iSCSI>
    <DefaultTargetIP>x.x.x.x</DefaultTargetIP>
  </iSCSI>
</config>
```

Optional parameters(Pick and add the optional parameter in the above XML file):

```
<LUN>
  <LUNType>xxx</LUNType>
  <WriteType>xxx</WriteType>
  <Prefetch Type="xxx" Value="xxx" />
  <LUNcopyWaitInterval>xxx</LUNcopyWaitInterval>
  <Timeout>432000</Timeout>
</LUN>
<iSCSI>
  <Initiator Name="xxx" TargetIP="x.x.x.x" />
</iSCSI>
```

NOTE

Make sure the owner and group of "/etc/cinder/cinder_huawei_conf.xml" file are the same as "/etc/cinder/cinder.conf" file's owner and group.

```
-rw-r--r-- 1 cinder cinder 2662 Jul 29 02:13 cinder.conf
-rw-r--r-- 1 cinder cinder 778 Jul 30 02:56 cinder_huawei_conf.xml
```

For details about the parameters in the configuration file, see section "4.1.6".

Step 3 Configure the **cinder.conf** file.

Add a [18000_iSCSI] section at the end of "/etc/cinder/cinder.conf" file, configure the 18000_iSCSI back end with the Huawei driver. The **volume_driver** indicates the loaded driver file, and **cinder_huawei_conf_file** indicates the specified Huawei-customized configuration file.

```
[18000_iSCSI]
volume_driver = cinder.volume.drivers.huawei.huawei_driver.HuaweiISCSIDriver
cinder_huawei_conf_file = /etc/cinder/cinder_huawei_conf.xml
volume_backend_name = 18000_iSCSI
```

In the [DEFAULT] section, enable the 18000_iSCSI back end:

```
[DEFAULT]
...
enabled_backends=18000_iSCSI
```

Step 4 Restart the Cinder service.

----End

4.1.5 Configuring the Cinder Driver for Dorado Series V3(iSCSI)

Procedure

Step 1 In **/etc/cinder**, create a Huawei-customized driver configuration file. The file format is XML. Change the name of the driver configuration file based on site requirements, for example, **cinder_huawei_conf.xml**.

Step 2 Configure parameters in the driver configuration file, including mandatory and optional parameters.

Mandatory parameters:

```
<?xml version='1.0' encoding='UTF-8'?>
<config>
  <Storage>
    <Product>Dorado</Product>
    <Protocol>iSCSI</Protocol>
    <RestURL>https://x.x.x.x:8088/deviceManager/rest/</RestURL>
    <UserName>xxx</UserName>
    <UserPassword>xxx</UserPassword>
```

```

</Storage>
<LUN>
  <LUNType>Thin</LUNType>
  <StoragePool>xxx</StoragePool>
</LUN>
<iSCSI>
  <DefaultTargetIP>x.x.x.x</DefaultTargetIP>
</iSCSI>
</config>

```

Optional parameters(Pick and add the optional parameter in the above XML file):

```

<LUN>
  <WriteType>xxx</WriteType>
  <Prefetch Type="xxx" Value="xxx" />
</LUN>
<iSCSI>
  <Initiator Name="xxx" TargetIP="x.x.x.x" />
</iSCSI>

```

 **NOTE**

Make sure the owner and group of "/etc/cinder/cinder_huawei_conf.xml" file are the same as "/etc/cinder/cinder.conf" file's owner and group.

```

-rw-r--r-- 1 cinder cinder 2662 Jul 29 02:13 cinder.conf
-rw-r--r-- 1 cinder cinder 778 Jul 30 02:56 cinder_huawei_conf.xml

```

For details about the parameters in the configuration file, see section "4.1.6".

Step 3 Configure the **cinder.conf** file.

Add a [Dorado_iSCSI] section at the end of "/etc/cinder/cinder.conf" file, configure the Dorado_iSCSI back end with the Huawei driver. The **volume_driver** indicates the loaded driver file, and **cinder_huawei_conf_file** indicates the specified Huawei-customized configuration file.

```

[Dorado_iSCSI]
volume_driver = cinder.volume.drivers.huawei.huawei_driver.HuaweiISCSIDriver
cinder_huawei_conf_file = /etc/cinder/cinder_huawei_conf.xml
volume_backend_name = Dorado_iSCSI

```

In the [DEFAULT] section, enable the Dorado_iSCSI back end:

```

[DEFAULT]
...
enabled_backends=Dorado_iSCSI

```

Step 4 Restart the Cinder service.

----End

4.1.6 Parameters in the Configuration File

Table 4-1 Mandatory parameters

Parameter	Description	Applicable To
Product	Type of a storage product. Possible values are T , TV2 , 18000 , V3 , V5 and Dorado .	All
Protocol	Type of a connection protocol. The possible value is iSCSI .	All

Parameter	Description	Applicable To
ControllerIP0	IP address of the primary controller on an OceanStor T series V100R005 storage device.	T series V1
ControllerIP1	IP address of the secondary controller on an OceanStor T series V100R005 storage device.	T series V1
RestURL	Access address of the REST interface, for example, https://x.x.x.x:8088/devicemanager/rest/. x.x.x.x indicates the management IP address. If you need to configure multiple RestURL, separate them by semicolons (;).	T series V2 V3 V5 18000 Dorado
UserName	User name of a storage administrator.	All
UserPassword	Password of a storage administrator.	All
StoragePool	Name of a storage pool to be used. If you need to configure multiple storage pools, separate them by semicolons (;). Refer to 4.1.1 to configure TV1 series.	All
DefaultTarget IP	Default IP address of the iSCSI target port that is provided for computing nodes.	All

Table 4-2 Optional parameters

Parameter	Default Value	Description	Applicable To
LUNType	Thick(except Dorado) Thin(Dorado)	Type of the LUNs to be created. The value can be Thick or Thin . Dorado only support Thin LUNs.	All
StripUnitSize	64	Stripe depth of a LUN to be created, optional values: 4, 8,16, 32, 64, 128, 256, 512. The unit is KB. This parameter is invalid when a thin LUN is created.	T series V1
WriteType	1	Cache write type. Possible values are: 1 (write back), 2 (write through).	All
Prefetch Type	3	Cache prefetch policy. Possible values are: 0 (no prefetch), 1 (fixed prefetch), 2 (variable prefetch) or 3 (intelligent prefetch).	All
Prefetch Value	0	Cache prefetch value.	All

Parameter	Default Value	Description	Applicable To
LUNcopyWaitInterval	5	After LUN copy is enabled, the plug-in frequently queries the copy progress. You can set a value to specify the query interval.	T series V2 V3 V5 18000 Dorado
Timeout	432000	Timeout interval for waiting LUN copy of a storage device to complete. The unit is second.	T series V2 V3 V5 18000 Dorado
Initiator Name	-	Name of a computing node initiator.	All
Initiator Target IP	-	IP address of the iSCSI target port that is provided for computing nodes.	All
Initiator TargetPortGroup	-	IP address of the iSCSI target port that is provided for computing nodes.	T series V2 V3 V5 18000 Dorado
HostIP	-	IP address of the Nova compute node's host.	T series V1
OSType	Linux	Operating system of the Nova compute node's host.	T series V1

⚠ CAUTION

- The value of **StoragePool** cannot contain Chinese characters
- All of the parameter values cannot include XML special character < > & ' "

4.1.7 Configuring iSCSI Multipathing

If you need to configure the multipathing for iSCSI, configure it as follows:

Procedure

- Step 1** Create a port group on the storage device using the DeviceManager, add service links that require multipathing into the port group.

Step 2 Add the port group settings in the Huawei-customized driver configuration file, and configure the port group name needed by an initiator.

```
<iSCSI>
  <Initiator Name="xxxxxx" TargetPortGroup="xxxx"/>
  <Initiator Name="xxxxxx" TargetPortGroup="xxxx"/>
</iSCSI>
```

Step 3 If the version of OpenStack is Juno, Kilo, Liberty or Mitaka, add **iscsi_use_multipath = True** in **[libvirt]** of **/etc/nova/nova.conf**.

If the version of OpenStack is Newton or Ocata, add **volume_use_multipath = True** in **[libvirt]** of **/etc/nova/nova.conf**.

Enable the multipathing switch of the OpenStack Nova module.

Step 4 Restart the nova-compute service.

----End

4.1.8 Configuring CHAP and ALUA

On a public network, any application server whose IP address resides on the same network segment as that of the storage system's iSCSI host port can access the storage system and perform read and write operations in it. This poses risks to the data security of the storage system. To ensure the storage system access security, you can configure CHAP authentication to control application servers' access to the storage system.

Procedure

Configure CHAP and ALUA.

Configure the driver configuration file as follows:

```
<iSCSI>
  <Initiator Name="xxx" ALUA="xxx" FAILOVERMODE="XXX" PATHTYPE="xxx"
  CHAPInfo="xxx"/>
  <Initiator Name="xxx" ALUA="xxx" FAILOVERMODE="XXX" PATHTYPE="xxx"
  CHAPInfo="xxx"/>
</iSCSI>
```

Table 4-3 Parameters description

Parameter	Default	Description
Name	-	iSCSI initiator name
ALUA	0	0: default(Huawei Ultrapath) 1: uses third-party multipathing software
FAILOVERMODE	-	Initiator switchover mode, this parameter needs to be delivered only when uses third-party multipathing software is enabled
SPECIALMODETYPE	-	Initiator special mode type, this parameter needs to be delivered only when initiator switchover mode is special ALUA

Parameter	Default	Description
PATHTYPE	-	Initiator path type, this parameter needs to be delivered only when uses third-party multipathing software is enabled
CHAPinfo	-	<p>The user name and password authenticated by CHAP.</p> <p>The format is mm-user;mm-user@storage1. The user name and password are separated by semicolons (;)</p> <p>CHAP name must contain 4 to 223 characters</p> <p>The password must contain 12 to 16 characters</p> <p>The password must contain any three types of uppercase letters, lowercase letters, digits, and special characters including `~!@#\$%^*()-_+=+\\ [{}];:./?` and spaces</p> <p>The password cannot be the same as the account or mirror writing of the account</p>

 **NOTE**

Due to the valid value ranges of parameter FAILOVERMODE, SPECIALMODETYPE and PATHTYPE are varied for different Huawei storage system, please refer to the API document of corresponding Huawei storage in use to get the valid parameter values.

4.2 Configuring the Cinder Driver for Fibre Channel Storage

This section describes how to configure Cinder Driver for different products for the Fibre Channel products.

Prerequisites

For a Fibre Channel network, the **sg** tool must be installed so that storage resources can be used.

When create a volume from image, the multipath tool must be installed, and add the following configuration keys in the target back end configuration group of the `/etc/cinder/cinder.conf` file in Cinder volume node:

```
use_multipath_for_image_xfer = True
enforce_multipath_for_image_xfer = True
```

4.2.1 Configuring the Cinder Driver for OceanStor T Series V1 (Fibre Channel)

Procedure

Step 1 In `/etc/cinder`, create a Huawei-customized driver configuration file. The file format is XML.

Change the name of the driver configuration file based on site requirements, for example, `cinder_huawei_conf.xml`.

Step 2 Configure parameters in the driver configuration file, including mandatory and optional parameters.

Mandatory parameters:

```
<?xml version='1.0' encoding='UTF-8'?>
<config>
  <Storage>
    <Product>T</Product>
    <Protocol>FC</Protocol>
    <ControllerIP0>x.x.x.x</ControllerIP0>
    <ControllerIP1>x.x.x.x</ControllerIP1>
    <UserName>xxx</UserName>
    <UserPassword>xxx</UserPassword>
  </Storage>
  <LUN>
    <StoragePool Name="xxx" />
    <StoragePool Name="xxx" />
  </LUN>
</config>
```

Optional parameters(Pick and add the optional parameter in the above XML file):

```
<LUN>
  <LUNType>xxx</LUNType>
  <StripUnitSize>xxx</StripUnitSize>
  <WriteType>xxx</WriteType>
  <Prefetch Type="xxx" Value="xxx" />
</LUN>
```

NOTE

Make sure the owner and group of `/etc/cinder/cinder_huawei_conf.xml` file are the same as `/etc/cinder/cinder.conf` file's owner and group.

```
-rw-r--r-- 1 cinder cinder 2662 Jul 29 02:13 cinder.conf
-rw-r--r-- 1 cinder cinder 778 Jul 30 02:56 cinder_huawei_conf.xml
```

For details about the parameters in the configuration file, see section "4.2.7".

Step 3 Configure the `cinder.conf` file.

Add a `[TV1_FC]` section at the end of `/etc/cinder/cinder.conf` file, configure the `TV1_FC` back end with the Huawei driver. The **volume_driver** indicates the loaded driver file, and **cinder_huawei_conf_file** indicates the specified Huawei-customized configuration file.

```
[TV1_FC]
volume_driver = cinder.volume.drivers.huawei.huawei_t.HuaweiTFCDriver
cinder_huawei_conf_file = /etc/cinder/cinder_huawei_conf.xml
volume_backend_name = TV1_FC
```

In the `[DEFAULT]` section, enable the `TV1_FC` back end:

```
[DEFAULT]
...
enabled_backends=TV1_FC
```

Step 4 Restart the Cinder service.

---End

4.2.2 Configuring the Cinder Driver for OceanStor T Series V2 (Fibre Channel)

Procedure

Step 1 In `/etc/cinder`, create a Huawei-customized driver configuration file. The file format is XML.

Change the name of the driver configuration file based on site requirements, for example, `cinder_huawei_conf.xml`.

Step 2 Configure parameters in the driver configuration file, including mandatory and optional parameters.

Mandatory parameters:

```
<?xml version='1.0' encoding='UTF-8'?>
<config>
  <Storage>
    <Product>TV2</Product>
    <Protocol>FC</Protocol>
    <RestURL>https://x.x.x.x:8088/deviceManager/rest/</RestURL>
    <UserName>xxx</UserName>
    <UserPassword>xxx</UserPassword>
  </Storage>
  <LUN>
    <StoragePool>xxx</StoragePool>
  </LUN>
</config>
```

Optional parameters(Pick and add the optional parameter in the above XML file):

```
<LUN>
  <LUNType>xxx</LUNType>
  <WriteType>xxx</WriteType>
  <Prefetch Type="xxx" Value="xxx" />
  <LUNcopyWaitInterval>xxx</LUNcopyWaitInterval>
  <Timeout>432000</Timeout>
</LUN>
```

NOTE

Make sure the owner and group of `"/etc/cinder/cinder_huawei_conf.xml"` file are the same as `"/etc/cinder/cinder.conf"` file's owner and group.

```
-rw-r--r-- 1 cinder cinder 2662 Jul 29 02:13 cinder.conf
-rw-r--r-- 1 cinder cinder 778 Jul 30 02:56 cinder_huawei_conf.xml
```

For details about the parameters in the configuration file, see section "4.2.7".

Step 3 Configure the `cinder.conf` file.

Add a `[TV2_FC]` section at the end of `"/etc/cinder/cinder.conf"` file, configure the `TV2_FC` back end with the Huawei driver. The `volume_driver` indicates the loaded driver file, and `cinder_huawei_conf_file` indicates the specified Huawei-customized configuration file.

```
[TV2_FC]
volume_driver = cinder.volume.drivers.huawei.huawei_driver.HuaweiFCDriver
cinder_huawei_conf_file = /etc/cinder/cinder_huawei_conf.xml
volume_backend_name = TV2_FC
```

In the `[DEFAULT]` section, enable the `TV2_FC` back end:

```
[DEFAULT]
...
enabled_backends=TV2_FC
```

Step 4 Restart the Cinder service.

----End

4.2.3 Configuring the Cinder Driver for OceanStor V3/V5 (Fibre Channel)

Procedure

Step 1 In `/etc/cinder`, create a Huawei-customized driver configuration file. The file format is XML.

Change the name of the driver configuration file based on site requirements, for example, `cinder_huawei_conf.xml`.

Step 2 Configure parameters in the driver configuration file, including mandatory and optional parameters.

Mandatory parameters:

```
<?xml version='1.0' encoding='UTF-8'?>
<config>
  <Storage>
    <Product>V3</Product>
    <Protocol>FC</Protocol>
    <RestURL>https://x.x.x.x:8088/deviceManager/rest/</RestURL>
    <UserName>xxx</UserName>
    <UserPassword>xxx</UserPassword>
  </Storage>
  <LUN>
    <LUNType>xxx</LUNType>
    <WriteType>xxx</WriteType>
    <LUNcopyWaitInterval>xxx</LUNcopyWaitInterval>
    <Timeout>432000</Timeout>
    <StoragePool>xxx</StoragePool>
  </LUN>
</config>
```

Optional parameters(Pick and add the optional parameter in the above XML file):

```
<LUN>
  <LUNType>xxx</LUNType>
  <WriteType>xxx</WriteType>
  <Prefetch Type="xxx" Value="xxx" />
  <LUNcopyWaitInterval>xxx</LUNcopyWaitInterval>
  <Timeout>432000</Timeout>
</LUN>
```

NOTE

Make sure the owner and group of `/etc/cinder/cinder_huawei_conf.xml` file are the same as `/etc/cinder/cinder.conf` file's owner and group.

```
-rw-r--r-- 1 cinder cinder 2662 Jul 29 02:13 cinder.conf
-rw-r--r-- 1 cinder cinder 778 Jul 30 02:56 cinder_huawei_conf.xml
```

For details about the parameters in the configuration file, see section "4.2.7".

Step 3 Configure the `cinder.conf` file.

Add a `[V3_FC]` section at the end of `/etc/cinder/cinder.conf` file, configure the `V3_FC` back end with the Huawei driver. The **volume_driver** indicates the loaded driver file, and **cinder_huawei_conf_file** indicates the specified Huawei-customized configuration file.

```
[V3_FC]
volume_driver = cinder.volume.drivers.huawei.huawei_driver.HuaweiFCDriver
cinder_huawei_conf_file = /etc/cinder/cinder_huawei_conf.xml
volume_backend_name = V3_FC
```

In the [DEFAULT] section, enable the V3_FC back end:

```
[DEFAULT]
...
enabled_backends=V3_FC
```

Step 4 Restart the Cinder service.

----End

4.2.4 Configuring the Cinder Driver of OceanStor 18000 Series (Fibre Channel)

This section describes how to configure the Cinder Driver for 18000 series for FC storage products.

Procedure

Step 1 In `/etc/cinder`, create a Huawei-customized driver configuration file. The file format is XML.

Change the name of the driver configuration file based on site requirements, for example, `cinder_huawei_conf.xml`.

Step 2 Configure the `cinder.conf` file, including mandatory and optional parameters.

Mandatory parameters:

```
<?xml version='1.0' encoding='UTF-8'?>
<config>
  <Storage>
    <Product>18000</Product>
    <Protocol>FC</Protocol>
    <RestURL>https://x.x.x.x:8088/deviceManager/rest/</RestURL>
    <UserName>xxx</UserName>
    <UserPassword>xxx</UserPassword>
  </Storage>
  <LUN>
    <StoragePool>xxx</StoragePool>
  </LUN>
</config>
```

Optional parameters(Pick and add the optional parameter in the above XML file):

```
<LUN>
  <LUNType>xxx</LUNType>
  <WriteType>xxx</WriteType>
  <Prefetch Type="xxx" Value="xxx" />
  <LUNcopyWaitInterval>xxx</LUNcopyWaitInterval>
  <Timeout>432000</Timeout>
</LUN>
```

NOTE

Make sure the owner and group of `"/etc/cinder/cinder_huawei_conf.xml"` file are the same as `"/etc/cinder/cinder.conf"` file's owner and group.

```
-rw-r--r-- 1 cinder cinder 2662 Jul 29 02:13 cinder.conf
-rw-r--r-- 1 cinder cinder 778 Jul 30 02:56 cinder_huawei_conf.xml
```

For details about the parameters in the configuration file, see section "4.2.7".

Step 3 Configure the **cinder.conf** file.

Add a [18000_FC] section at the end of "/etc/cinder/cinder.conf" file, configure the 18000_FC back end with the Huawei driver. The **volume_driver** indicates the loaded driver file, and **cinder_huawei_conf_file** indicates the specified Huawei-customized configuration file.

```
[18000_FC]
volume_driver = cinder.volume.drivers.huawei.huawei_driver.HuaweiFCDriver
cinder_huawei_conf_file = /etc/cinder/cinder_huawei_conf.xml
volume_backend_name = 18000_FC
```

In the [DEFAULT] section, enable the 18000V3_FC back end:

```
[DEFAULT]
...
enabled_backends=18000_FC
```

Step 4 Restart the Cinder service.

----End

4.2.5 Configuring the Cinder Driver for Dorado Series V3(Fibre Channel)

Procedure

- Step 1** In **/etc/cinder**, create a Huawei-customized driver configuration file. The file format is XML. Change the name of the driver configuration file based on site requirements, for example, **cinder_huawei_conf.xml**.
- Step 2** Configure parameters in the driver configuration file, including mandatory and optional parameters.

Mandatory parameters:

```
<?xml version='1.0' encoding='UTF-8'?>
<config>
  <Storage>
    <Product>Dorado</Product>
    <Protocol>FC</Protocol>
    <RestURL>https://x.x.x.x:8088/deviceManager/rest/</RestURL>
    <UserName>xxx</UserName>
    <UserPassword>xxx</UserPassword>
  </Storage>
  <LUN>
    <LUNType>Thin</LUNType>
    <StoragePool>xxx</StoragePool>
  </LUN>
</config>
```

Optional parameters(Pick and add the optional parameter in the above XML file):

```
<LUN>
  <WriteType>xxx</WriteType>
  <Prefetch Type="xxx" Value="xxx" />
</LUN>
```

NOTE

Make sure the owner and group of "/etc/cinder/cinder_huawei_conf.xml" file are the same as "/etc/cinder/cinder.conf" file's owner and group.

```
-rw-r--r-- 1 cinder cinder 2662 Jul 29 02:13 cinder.conf
-rw-r--r-- 1 cinder cinder 778 Jul 30 02:56 cinder_huawei_conf.xml
```

For details about the parameters in the configuration file, see section "4.2.7".

Step 3 Configure the **cinder.conf** file.

Add a [Dorado_FC] section at the end of "/etc/cinder/cinder.conf" file, configure the Dorado_FC back end with the Huawei driver. The **volume_driver** indicates the loaded driver file, and **cinder_huawei_conf_file** indicates the specified Huawei-customized configuration file.

```
[Dorado_FC]
volume_driver = cinder.volume.drivers.huawei.huawei_driver.HuaweiFCDriver
cinder_huawei_conf_file = /etc/cinder/cinder_huawei_conf.xml
volume_backend_name = Dorado_FC
```

In the [DEFAULT] section, enable the Dorado_FC back end:

```
[DEFAULT]
...
enabled_backends=Dorado_FC
```

Step 4 Restart the Cinder service.

----End

4.2.6 Configuring the Auto Zoning

Auto zoning is not compulsory, When you need to use this function, do the following configuration.

Procedure

Step 1 Configure the **cinder.conf** file.

For more details please refer to <https://docs.openstack.org/ocata/config-reference/block-storage/fc-zoning.html>

For example, configure the Brocade Exchanger:

```
[DEFAULT]
...
zoning_mode = fabric
[fc-zone-manager]
fc_fabric_names = swd77
zoning_policy = initiator
brcd_sb_connector =
cinder.zonemanager.drivers.brocade.brcd_fc_zone_client_cli.BrcdFCZoneClientCLI
fc_san_lookup_service =
cinder.zonemanager.drivers.brocade.brcd_fc_san_lookup_service.BrcdFCSanLookupService
zone_driver =
cinder.zonemanager.drivers.brocade.brcd_fc_zone_driver.BrcdFCZoneDriver
[swd77]
fc_fabric_address = x.x.x.x
fc_fabric_password = xxx
fc_fabric_port = 22
fc_fabric_user = xxx
principal_switch_wwn = xxx
zone_activate = True
```

Step 2 Restart the Cinder service.

----End

NOTICE

- Auto Zoning is not supported for tenant user.

4.2.7 Parameters in the Configuration File

Table 4-4 Mandatory parameters

Parameter	Description	Applicable To
Product	Type of a storage product. Possible values are T , TV2 , 18000 , V3 , V5 and Dorado .	All
Protocol	Type of a connection protocol. Possible value is FC .	All
ControllerIP0	IP address of the primary controller on an OceanStor T series V100R005 storage device.	T series V1
ControllerIP1	IP address of the secondary controller on an OceanStor T series V100R005 storage device.	T series V1
RestURL	Access address of the REST interface, for example, https://x.x.x.x:8088/devicemanager/rest/ . x.x.x.x indicates the management IP address. If you need to configure multiple RestURL, separate them by semicolons (;).	T series V2 V3 V5 18000 Dorado
UserName	User name of an administrator.	All
UserPassword	Password of an administrator.	All
StoragePool	Name of a storage pool to be used. If you need to configure multiple storage pools, separate them by semicolons (;). Refer to 4.1.1 to configure TV1 series.	All

Table 4-5 Optional parameters

Parameter	Default Value	Description	Applicable To
LUNType	Thick(except Dorado) Thin(Dorado)	Type of the LUNs to be created. The value can be Thick or Thin . Dorado only support Thin LUNs.	All
StripUnitSize	64	Stripe depth of a LUN to be created, optional values: 4, 8,16, 32, 64, 128, 256, 512. The unit is KB. This parameter is invalid when a thin LUN is created.	T series V1

Parameter	Default Value	Description	Applicable To
WriteType	1	Cache write type. Possible values are: 1 (write back), 2 (write through).	All
Prefetch Type	3	Cache prefetch policy. Possible values are: 0 (no prefetch), 1 (fixed prefetch), 2 (variable prefetch) or 3 (intelligent prefetch).	All
Prefetch Value	0	Cache prefetch value.	All
LUNcopyWait Interval	5	After LUN copy is enabled, the plug-in frequently queries the copy progress. You can set a value to specify the query interval.	T series V2 V3 V5 18000 Dorado
Timeout	432000	Timeout interval for waiting LUN copy of a storage device to complete. The unit is second.	T series V2 V3 V5 18000 Dorado
HostIP	-	IP address of the Nova compute node's host.	T series V1
OSType	Linux	Operating system of the Nova compute node's host.	T series V1

⚠ CAUTION

- The value of **StoragePool** cannot contain Chinese characters
- All of the parameter values cannot include XML special character `<` `>` `&` `'` `"`

4.2.8 Configuring FC Multipathing

If you need to configure the multipathing for FC, configure it as follows:

Procedure

Step 1 Enable the multipathing switch of the OpenStack Nova module.

If the version of OpenStack is Liberty or Mitaka, add **iscsi_use_multipath = True** in **[libvirt]** of **/etc/nova/nova.conf**.

If the version of OpenStack is Newton or Ocata, add **volume_use_multipath = True** in **[libvirt]** of **/etc/nova/nova.conf**.

Step 2 Restart the nova-compute service.

----End

4.2.9 Configuring ALUA

Procedure

Configure ALUA.

Configure the driver configuration file as follows:

```
<FC>
  <Initiator Name="xxx" ALUA="xxx" FAILOVERMODE="xxx" PATHTYPE="xxx"/>
  <Initiator Name="xxx" ALUA="xxx" FAILOVERMODE="xxx" PATHTYPE="xxx"/>
</FC>
```

Table 4-6 Parameters description

Parameter	Default	Description
Name	-	FC initiator WWN
ALUA	0	0: default(Huawei Ultrapath) 1: uses third-party multipathing software
FAILOVERMODE	-	Initiator switchover mode, this parameter needs to be delivered only when uses third-party multipathing software is enabled
SPECIALMODETYPE	-	Initiator special mode type, this parameter needs to be delivered only when initiator switchover mode is special ALUA
PATHTYPE	-	Initiator path type, this parameter needs to be delivered only when uses third-party multipathing software is enabled

NOTE

Due to the valid value ranges of parameter FAILOVERMODE, SPECIALMODETYPE and PATHTYPE are varied for different Huawei storage system, please refer to the API document of corresponding Huawei storage in use to get the valid parameter values.

4.3 Configuring Multi-Storage Support

Example for configuring multiple storage systems in `/etc/cinder/cinder.conf`:

```
[DEFAULT]
...
enabled_backends = t_fc, 18000_fc
[t_fc]
volume_driver = cinder.volume.drivers.huawei.huawei_t.HuaweiTFCDriver
cinder_huawei_conf_file = /etc/cinder/cinder_huawei_conf_t_fc.xml
volume_backend_name = t_fc
```

```
[18000_fc]
volume_driver = cinder.volume.drivers.huawei.huawei_driver.HuaweiFCDriver
cinder_huawei_conf_file = /etc/cinder/cinder_huawei_conf_18000_fc.xml
volume_backend_name = 18000_fc
```

4.4 Using tenant user

Configure the tenant user parameters in the driver configuration file, as below:

```
<?xml version='1.0' encoding='UTF-8'?>
<config>
  <Storage>
    ...
    <UserName>xxx</UserName>
    <UserPassword>xxx</UserPassword>
    <vStoreName>xxx</vStoreName>
  </Storage>
  ...
</config>
```

Table 4-7 Tenant parameters description

Parameter	Description
UserName	Tenant user name
UserPassword	Tenant user password
vStoreName	vStore name

NOTICE

- How to configure other parameters, please refer to the chapters above.
- Only can configure using tenant user while integrated with backend storage that supports multi-tenant feature.

5 Cinder Driver Advanced Properties Configuration

Huawei storage supports advanced properties, such as Smartx and HyperMetro. By associating with specified volume types in OpenStack, these properties make the combination of OpenStack and storage advanced properties possible.

[5.1 Configuring the SmartQoS Property](#)

[5.2 Configuring the SmartPartition Property](#)

[5.3 Configuring the Thick Property](#)

[5.4 Configuring the Thin Property](#)

[5.5 Configuring the SmartCache Property](#)

[5.6 Configuring the SmartTier Property](#)

[5.7 Configuring the HyperMetro Property](#)

[5.8 Configuring the Replication V2.1](#)

[5.9 Create a volume on a certain storage pool](#)

[5.10 Create a volume with a certain disk type](#)

[5.11 Create a volume on a certain volume back end](#)

[5.12 Configuring Consistency Groups](#)

[5.13 Configuring Backup Snapshot](#)

[5.14 Configuring Certificate Verify](#)

[5.15 Configuring the Owning Controller of a LUN](#)

[5.16 Configuring the SmartDedupe Property](#)

[5.17 Configuring the SmartCompression Property](#)

[5.18 Create a volume with fast clone](#)

[5.19 Configuring the LUN Copy Speed](#)

5.1 Configuring the SmartQoS Property

About This Chapter

Qos in OpenStack mainly depends on the front-end Hypervisor and the back-end storage. Huawei OpenStack Cinder Driver supports "frontend QoS" and "backend QoS". Front-end QoS options are:

total_bytes_sec, read_bytes_sec, write_bytes_sec, total_iops_sec, read_iops_sec, write_iops_sec

Huawei storage backends support the following QoS properties. One or multiple properties can be associated with one QoS property simultaneously.

Protection policies: latency, minIOPS, minBandWidth

Restriction policies: maxIOPS, maxBandWidth

CAUTION

Protection policies and Restriction policies are mutually exclusive. If they are configured together, volumes will fail to be created.

"IOType" is mandatory. If it isn't configured in qos, volumes will fail to be created.

5.1.1 Configuring the Front-end QoS

This section describes how to configure the front-end qos.

Procedure

- Step 1** Run the `cinder type-create XXX` command to create a volume type. XXX indicates the name of a volume type.

```
root@ubuntu:/# cinder type-create high-iops
+-----+-----+-----+-----+-----+
|          ID          | Name | Description | Is_Public |
+-----+-----+-----+-----+-----+
| 84b189d3-8984-4e92-aab0-fa4a913126bf | high-iops | - | True |
+-----+-----+-----+-----+-----+
```

- Step 2** Run the `cinder qos-create xxx consumer="front-end" read_iops_sec=xxx write_iops_sec=xxx` command to create front QoS control property parameters.

`read_iops_sec=2000 write_iops_sec=1000` is used as an example.

```
root@ubuntu:/# cinder qos-create high-iops consumer="front-end"
read_iops_sec=2000 write_iops_sec=1000
+-----+-----+-----+-----+-----+
| Property |          Value          |
+-----+-----+-----+-----+-----+
| consumer |          front-end      |
| id       | 7dc73b5b-1b19-4371-8dee-8edbc52cf625 |
| name    |          high-iops      |
| specs   | {'write_iops_sec': '1000', 'read_iops_sec': '2000'} |
+-----+-----+-----+-----+-----+
```

Step 3 Associate the volume type with QoS control properties.

1. Check the usage of the **cinder qos-associate qos** command.

The association command format is **cinder qos-associate** <ID of QoS specifications> <ID of volume type>.

```
root@ubuntu:/# cinder qos-associate
```

```
usage: cinder qos-associate <qos_specs> <volume_type_id>
```

try 'cinder help qos-associate' for more information.

2. Run the **cinder qos-associate 7dc73b5b-1b19-4371-8dee-8edbc52cf625 84b189d3-8984-4e92-aab0-fa4a913126bf**.

----End

Results

- Run the **cinder qos-list** command to view details about the QoS policy configuration.

```
root@lcl1404:~# cinder qos-list
+-----+-----+-----+
|          ID          | Name      | Consumer |
|          specs      |           |          |
+-----+-----+-----+
| 7dc73b5b-1b19-4371-8dee-8edbc52cf625 | high-iops | front-end |
| {'write_iops_sec': '1000', 'read_iops_sec': '2000'} |           |          |
+-----+-----+-----+
```

NOTE

If consumer="front-end" is configured in qos, front-end QoS will be created; if not, back-end QoS will be created.

5.1.2 Configuring the Maximum Control IOPS

This section describes how to configure the maximum Control IOPS.

Procedure

- Step 1** Run the **cinder type-create XXX** command to create a volume type. XXX indicates the name of a volume type.

```
root@ubuntu:/# cinder type-create maxIOPS
+-----+-----+-----+-----+
|          ID          | Name      | Description | Is_Public |
+-----+-----+-----+-----+
| 3d9cc52e-069b-4245-b201-945e0ef571cf | maxIOPS  | -           | True      |
+-----+-----+-----+-----+
```

- Step 2** Run the **cinder type-key maxIOPS set capabilities:QoS_support=<is> true'** command to set a key-value pair for the maxIOPS volume type.

- Step 3** Run the **cinder qos-create xxx maxIOPS=xxx IOType=xxx** command to create QoS control property parameters.

- The first **xxx** indicates the created QoS control properties name.
- **maxIOPS**: indicates the maximum IOPS. The value is an integer larger than **0**.
- **IOType**: indicates the read and write type. **0** indicates the control read I/Os, **1** indicates the control write I/Os, **2** indicates the control read and write I/Os.

NOTICE

Dorado storage only supports IOType "2".

maxIOPS=100 IOType=2 is used as an example.

```
root@ubuntu:/# cinder qos-create maxIOPS=100 IOType=2
+-----+-----+
| property |          value          |
+-----+-----+
| consumer |          back-end       |
|   id    | 1f772258-49f0-47a9-aa9c-d8f32d844bb1 |
| name    |          maxIOPS        |
| specs   | {u'IOType': u'2', u'maxIOPS': u'100'} |
+-----+-----+
```

Step 4 Associate the volume type with QoS control properties.

1. Check the usage of the **cinder qos-associate qos** command.

The association command format is **cinder qos-associate** <ID of QoS specifications> <ID of volume type>.

```
root@ubuntu:/# cinder qos-associate
```

usage: cinder qos-associate <qos_specs> <volume_type_id>

try 'cinder help qos-associate' for more information.

2. Run the **cinder qos-associate 1f772258-49f0-47a9-aa9c-d8f32d844bb1 3d9cc52e-069b-4245-b201-945e0ef571cf**.

----End

5.1.3 Configuring the Minimum Control IOPS

This section describes how to configure the minimum Control IOPS.

Procedure

Step 1 Run the **cinder type-create XXX** command to create a volume type. XXX indicates the name of a volume type.

```
root@ubuntu:/# cinder type-create minIOPS
+-----+-----+-----+-----+
|          ID          | Name | Description | Is_Public |
+-----+-----+-----+-----+
| 1a1dcee8-d9ae-4de9-b1c6-2317a4ad7219 | minIOPS | -          | True      |
+-----+-----+-----+-----+
```

Step 2 Run the **cinder type-key minIOPS set capabilities:QoS_support=<is> true** command to set a key-value pair for the minIOPS volume type.

Step 3 Run the **cinder qos-create xxx minIOPS=xxx IOType=xxx** command to create QoS control property parameters.

- The first **xxx** indicates the created QoS control properties name.
- **minIOPS**: indicates the minimum IOPS. The value is an integer larger than **0**.
- **IOType**: indicates the read and write type. **0** indicates the control read I/Os, **1** indicates the control write I/Os, **2** indicates the control read and write I/Os.

NOTICE

Dorado storage only supports IOType "2".

minIOPS=100 IOType=2 is used as an example.

```

root@ubuntu:/# cinder qos-create miniops minIOPS=50 IOType=2
+-----+-----+-----+-----+
| property |           value           |
+-----+-----+-----+-----+
| consumer |           back-end        |
| id       | 8deaf13c-bf1c-4a71-94d0-1149805693ce |
| name    |           miniops         |
| specs   | {u'IOType': u'2', u'minIOPS': u'50'} |
+-----+-----+-----+-----+

```

Step 4 Associate the volume type with QoS control properties.

1. Check the usage of the **cinder qos-associate qos** command.
The association command format is **cinder qos-associate** <ID of QoS specifications> <ID of volume type>.
root@ubuntu:/# cinder qos-associate
usage: cinder qos-associate <qos_specs> <volume_type_id>
try 'cinder help qos-associate' for more information.
2. Run the **cinder qos-associate 8deaf13c-bf1c-4a71-94d0-1149805693ce 1a1dcee8-d9ae-4de9-b1c6-2317a4ad7219**.

----End

5.1.4 Configuring the Maximum Control Bandwidth

This section describes how to configure the maximum control bandwidth.

Procedure

Step 1 Run the **cinder type-create XXX** command to create a volume type. XXX indicates the name of a volume type.

```

root@ubuntu:/# cinder type-create maxBandWidth
+-----+-----+-----+-----+
+
|           ID           | Name       | Description | Is_Public |
+-----+-----+-----+-----+
+
| 24200fbb-c984-4d99-9465-a820464662d6 | maxBandWidth | -          | True     |
+-----+-----+-----+-----+

```

Step 2 Run the **cinder type-key maxBandWidth set capabilities:QoS_support='<is> true'** command to set a key-value pair for the maxBandWidth volume type.

Step 3 Run the **cinder qos-create xxx maxBandWidth=xxx IOType=xxx** command to create QoS control property parameters.

- The first **xxx** indicates the created QoS control properties name.
- **maxBandWidth**: indicates the maximum BANDWIDTH. The value is an integer larger than 0 and expressed in MB/s.

- **IOType**: indicates the read and write type. **0** indicates the control read I/Os, **1** indicates the control write I/Os, **2** indicates the control read and write I/Os.

NOTICE

Dorado storage only supports IOType "2".

maxBandWidth=100 IOType=2 is used as an example.

```
root@ubuntu:/# cinder qos-create maxbandwidth maxBandWidth=100 IOType=2
+-----+-----+-----+-----+
| property |           value           |
+-----+-----+-----+-----+
| consumer |           back-end        |
|  id     | 2f51c955-e029-48ca-aa8c-5d7ae462481e |
| name    |           maxbandwidth    |
| specs   | {u'maxBandWidth': u'100', u'IOType': u'2'} |
+-----+-----+-----+-----+
```

Step 4 Associate the volume type with QoS control properties.

1. Check the usage of the **cinder qos-associate qos** command.
The association command format is **cinder qos-associate <ID of QoS specifications> <ID of volume type>**.
root@ubuntu:/# cinder qos-associate
usage: cinder qos-associate <qos_specs> <volume_type_id>
try 'cinder help qos-associate' for more information.
2. Run the **cinder qos-associate 2f51c955-e029-48ca-aa8c-5d7ae462481e 24200fbb-c984-4d99-9465-a820464662d6** command.

---End

5.1.5 Configuring the Minimum Control Bandwidth

This section describes how to configure the minimum control bandwidth.

Procedure

Step 1 Run the **cinder type-create XXX** command to create a volume type. XXX indicates the name of a volume type.

```
root@ubuntu:/# cinder type-create minBandWidth
+-----+-----+-----+-----+
| ID | Name | Description | Is_Public |
+-----+-----+-----+-----+
| 271bed0a-1cce-4e8f-a65e-b85ccb3b9a25 | minBandWidth | - | True |
+-----+-----+-----+-----+
```

Step 2 Run the **cinder type-key minBandWidth set capabilities:QoS_support='<is> true'** command to set a key-value pair for the minBandWidth volume type.

Step 3 Run the **cinder qos-create xxx minBandWidth=xxx IOType=xxx** command to create QoS control property parameters.

- The first **xxx** indicates the created QoS control properties name.
- **minBandWidth**: indicates the minimum BANDWIDTH. The value is an integer larger than **0** and expressed in MB/s.
- **IOType**: indicates the read and write type. **0** indicates the control read I/Os, **1** indicates the control write I/Os, **2** indicates the control read and write I/Os.

NOTICE

Dorado storage only supports IOType "2".

minBandWidth=100 IOType=2 is used as an example.

```
root@ubuntu:/# cinder qos-create minbandwidth minBandWidth=100 IOType=2
+-----+-----+
| property |          value          |
+-----+-----+
| consumer |          back-end       |
|   id    | 59c583d8-69d2-4c39-8c75-c1b21ef85f2e |
| name    |          minbandwidth   |
| specs   | {u'IOType': u'2', u'minBandWidth': u'100'} |
+-----+-----+
```

Step 4 Associate the volume type with QoS control properties.

1. Check the usage of the **cinder qos-associate qos** command.

The association command format is **cinder qos-associate <ID of QoS specifications> <ID of volume type>**.

```
root@ubuntu:/# cinder qos-associate
```

```
usage: cinder qos-associate <qos_specs> <volume_type_id>
```

try 'cinder help qos-associate' for more information.

2. Run the **cinder qos-associate 59c583d8-69d2-4c39-8c75-c1b21ef85f2e 271bed0a-1cce-4e8f-a65e-b85ccb3b9a25**.

----End

5.1.6 Configuring the Control Latency

This section describes how to configure the control latency.

Procedure

Step 1 Run the **cinder type-create XXX** command to create a volume type. XXX indicates the name of a volume type.

```
root@ubuntu:/# cinder type-create latency
```

```
+-----+-----+-----+-----+
|          ID          | Name | Description | Is_Public |
+-----+-----+-----+-----+
| ae34870a-21c0-4e50-8148-1e26f6ab6eab | latency | -          | True      |
+-----+-----+-----+-----+
```

Step 2 Run the **cinder type-key latency set capabilities:QoS_support='<is> true'** command to set a key-value pair for the latency volume type.

Step 3 Run the **cinder qos-create xxx latency=xxx IOType=xxx** command to create QoS control property parameters.

- The first **xxx** indicates the created QoS control properties name.
- **latency**: indicates LATENCY. The value is an integer larger than **0** and expressed in ms.
- **IOType**: indicates the read and write type. **0** indicates the control read I/Os, **1** indicates the control write I/Os, **2** indicates the control read and write I/Os.

NOTICE

Dorado storage only supports IOType "2".

latency=100 IOType=2 is used as an example.

```
root@ubuntu:/# cinder qos-create latency latency=100 IOType=2
+-----+-----+
| property |          value          |
+-----+-----+
| consumer |          back-end       |
|   id    | 6f305e9f-698b-4e9e-aa68-8efb80b43036 |
| name    |          latency       |
| specs   | {u'latency': u'100', u'IOType': u'2'} |
+-----+-----+
```

Step 4 Associate the volume type with QoS control properties.

1. Check the usage of the **cinder qos-associate qos** command.

The association command format is **cinder qos-associate <ID of QoS specifications> <ID of volume type>**.

```
root@ubuntu:/# cinder qos-associate
```

```
usage: cinder qos-associate <qos_specs> <volume_type_id>
```

```
try 'cinder help qos-associate' for more information.
```

2. Run the **cinder qos-associate 6f305e9f-698b-4e9e-aa68-8efb80b43036 ae34870a-21c0-4e50-8148-1e26f6ab6eab** command.

---End

5.1.7 Configuring Multiple Control Policies

This section describes how to configure multiple control policies.

Procedure

Step 1 Run the **cinder type-create XXX** command to create a volume type. XXX indicates the name of a volume type.

```
root@ubuntu:/# cinder type-create multi-strategy
+-----+-----+-----+-----+
+-----+
|          ID          | Name          | Description |
+-----+-----+-----+-----+
| df53d9d7-b1db-4e6b-847a-7a5150c39489 | multi-strategy |          -          |
+-----+-----+-----+-----+
| Is_Public | True |
+-----+-----+-----+-----+
```

Step 2 Run the **cinder type-key multi-strategy set capabilities:QoS_support=<is> true'** command to set a key-value pair for the multi-strategy volume type.

Step 3 Run the **cinder qos-create xxx latency=xxx minBandWidth=xxx IOType=xxx** command to create QoS control property parameters.

- The first **xxx** indicates the created QoS control properties name.
- **latency**: indicates LATENCY. The value is an integer larger than **0** and expressed in ms.
- **minBandWidth**: indicates the minimum BANDWIDTH. The value is an integer larger than **0** and expressed in MB/s.
- **IOType**: indicates the read and write type. **0** indicates the control read I/Os, **1** indicates the control write I/Os, **2** indicates the control read and write I/Os.

NOTICE

Dorado storage only supports IOType "2".

latency=100 minBandWidth=100 IOType=2 is used as an example.

```
root@ubuntu:/# cinder qos-create multi-strategy latency=100 minBandWidth=100
IOType=2
+-----+-----+
| Property | Value |
+-----+-----+
| consumer | back-end |
| id | 36f0fc4a-d5f5-4862-ab1f-e7fedeeddc41 |
| name | multi-strategy |
| specs | {'IOType': '2', 'minBandWidth': '100', 'latenct': '100'} |
+-----+-----+
```

Step 4 Associate the volume type with QoS control properties.

1. Check the usage of the **cinder qos-associate qos** command.
The association command format is **cinder qos-associate <ID of QoS specifications> <ID of volume type>**.
root@ubuntu:/# cinder qos-associate
usage: cinder qos-associate <qos_specs> <volume_type_id>
try 'cinder help qos-associate' for more information.
2. Run the **cinder qos-associate 36f0fc4a-d5f5-4862-ab1f-e7fedeeddc41 df53d9d7-b1db-4e6b-847a-7a5150c39489**.

----End

Results

- Run the **cinder qos-list** command to view details about the QoS policy configuration.

```
root@ubuntu:~# cinder qos-list
+-----+-----+-----+-----+
| ID | Name | Consumer |
+-----+-----+-----+-----+
| 36f0fc4a-d5f5-4862-ab1f-e7fedeeddc41 | multi-strategy | back-end |
| {'IOType': '2', 'minBandWidth': '100', 'latenct': '100'} | |
| 3e2b2fa5-aebb-4ea0-8dd2-52a577015769 | miniops | back-end |
| {'IOType': '2', 'minIOPS': '50'} | |
| 3fd0971e-f5fd-48d7-89d9-d2efb6fc44cf | maxbandwidth | back-end |
| {'maxBandWidth': '100', 'IOType': '2'} | |
| 6a4e24af-0e8c-4a64-91ee-859434414400 | latency | back-end |
| {'latency': '100', 'IOType': '2'} | |
```

```
| 9b34fbdf-91b5-473d-a5ff-0b4ea2ed9fd0 | maxiops | back-end
| {'IOType': '2', 'maxIOPS': '100'} | |
| f60a3374-cdf3-45cc-86c4-12c06a3db8d4 | minbandwidth | back-end
| {'IOType': '2', 'minBandWidth': '100'} | |
+-----+-----+-----+
+-----+
```

- Run the **cinder type-list** command to view the volume type.

```
root@ubuntu:~# cinder type-list
+-----+-----+-----+
+-----+
|          ID          |      Name      | Description |
Is_Public |
+-----+-----+-----+
+-----+
| 3f19ccd1-3ac2-4ce7-b907-d532b8ddbe52 | maxBandWidth | -          |
True |
| 92dbab58-07d8-46e6-9327-532a9a3b30b6 | maxIOPS      | -          |
True |
| 98d5ad9c-4591-4d18-ba09-199f6dba95a9 | minBandWidth | -          |
True |
| df53d9d7-b1db-4e6b-847a-7a5150c39489 | multi-strategy | -          |
True |
| e28d430e-ccc5-4f18-914a-b0c8008dc42d | latency      | -          |
True |
| f63f6eb4-7036-4452-bc46-9d31cba095d1 | minIOPS      | -          |
True |
+-----+-----+-----+
+-----+
```

5.2 Configuring the SmartPartition Property

The following example describes how to configure the SmartPartition property.

Procedure

- Step 1** Run the **cinder type-create XXX** command to create a volume type. XXX indicates the name of a volume type.

```
root@ubuntu-204:~# cinder type-create SmartPartition
+-----+-----+-----+
+-----+
|          ID          |      Name      | Description | Is_Public
|
+-----+-----+-----+
+-----+
| a7648f77-fb56-41f2-9d50-3c014534ef66 | SmartPartition | -          | True
|
+-----+-----+-----+
+-----+
```

- Step 2** Run the **cinder type-key SmartPartition set capabilities:smartpartition='<is> true'** command to set a key-value pair for the SmartPartition volume type.

- Step 3** Run the **cinder type-key SmartPartition set smartpartition:partitionname='test_partition'**

partitionname indicates the name of a SmartPartition partition that has been configured on the storage system.

- Step 4** Create a volume that supports **SmartPartition**.

```
root@ubuntu-204:~# cinder create 1 --display-name test001 --volume-type
SmartPartition
+-----+-----+-----+
|          property          |          value          |
+-----+-----+-----+
```

```

+-----+-----+
| attachments | [] |
| availability_zone | nova |
| bootable | false |
| created_at | 2015-06-26t13:40:10.483450 |
| display_description | none |
| display_name | test001 |
| encrypted | false |
| id | 1b2a87e4-eb8c-46ab-922c-63fcd7db8f20 |
| metadata | {} |
| multiattach | false |
| size | 1 |
| snapshot_id | none |
| source_valid | none |
| status | creating |
| volume_type | SmartPartition |
+-----+-----+

```

---End

5.3 Configuring the Thick Property

The following example describes how to configure the Thick property.

⚠ CAUTION

Dorado V3 doesn't support Thick volume.

Procedure

- Step 1** Run the **cinder type-create XXX** command to create a volume type. XXX indicates the name of a volume type.

```

root@ubuntu-204:~# cinder type-create Thick
+-----+-----+-----+-----+
| ID | Name | Description | Is_Public |
+-----+-----+-----+-----+
| a7648f77-fb56-41f2-9d50-3c014534ef66 | Thick | - | True |
+-----+-----+-----+-----+

```

- Step 2** Run the **cinder type-key Thick set capabilities:thick_provisioning_support='<is> true'** command to set a key-value pair for the Thick volume type.

- Step 3** Run the **cinder type-key Thick set provisioning:type='thick'** command to set the scheduling mechanism for the Thick volume.

- Step 4** Create a volume that supports **Thick**.

```

root@ubuntu-204:~# cinder create 1 --display-name test001 --volume-type Thick
+-----+-----+
| property | value |
+-----+-----+
| attachments | [] |
| availability_zone | nova |
| bootable | false |
| created_at | 2015-06-26t13:40:10.483450 |
| display_description | none |
| display_name | test001 |
| encrypted | false |
| id | 1b2a87e4-eb8c-46ab-922c-63fcd7db8f20 |
| metadata | {} |
| multiattach | false |
+-----+-----+

```

size	1
snapshot_id	none
source_volid	none
status	creating
volume_type	Thick

----End

5.4 Configuring the Thin Property

The following example describes how to configure the Thin property.

Procedure

- Step 1** Run the **cinder type-create XXX** command to create a volume type. XXX indicates the name of a volume type.

```
root@ubuntu-204:~# cinder type-create Thin
+-----+
| ID | Name | Description | Is_Public |
+-----+
| ba648f77-fb56-41f2-9d50-3c014534eedd | Thin | - | True |
+-----+
```

- Step 2** Run the **cinder type-key Thin set capabilities:thin_provisioning_support='<is> true'** command to set key-value pairs of the Thin volume type.

- Step 3** Create a volume that supports **Thin**.

```
root@ubuntu-204:~# cinder create 1 --display-name test001 --volume-type Thin
+-----+
| property | value |
+-----+
| attachments | [] |
| availability_zone | nova |
| bootable | false |
| created_at | 2015-06-26t13:40:10.483450 |
| display_description | none |
| display_name | test001 |
| encrypted | false |
| id | 1b2a87e4-eb8c-46ab-922c-63fcd7db8f20 |
| metadata | {} |
| multiattach | false |
| size | 1 |
| snapshot_id | none |
| source_volid | none |
| status | creating |
| volume_type | Thin |
+-----+
```

----End

5.5 Configuring the SmartCache Property

The following example describes how to configure the SmartCache property.

Procedure

- Step 1** Run the **cinder type-create XXX** command to create a volume type. XXX indicates the name of a volume type.

```

root@ubuntu-204:~# cinder type-create SmartCache
+-----+-----+-----+-----+
|          ID          | Name   | Description | Is_Public |
+-----+-----+-----+-----+
| a7648f77-fb56-41f2-9d50-3c014534ef66 | SmartCache | -          | True     |
+-----+-----+-----+-----+

```

Step 2 Run the **cinder type-key SmartCache set capabilities:smartcache='<is> true'** command to set a key-value pair for the SmartCache volume type.

Step 3 Run the **cinder type-key SmartCache set smartcache:cachename='test_cache'** command to config smartcache name.

cachename is the name of SmartCache partition that has been configured on the storage system.

Step 4 Create a volume that supports **SmartCache**.

```

root@ubuntu-204:~# cinder create 1 --display-name test001 --volume-type
Smartcache
+-----+-----+-----+-----+
|      property      |          value          |
+-----+-----+-----+-----+
| attachments        | []                     |
| availability_zone  | nova                   |
| bootable           | false                  |
| created_at         | 2015-06-26t13:40:10.483450 |
| display_description | none                   |
| display_name       | test001                |
| encrypted          | false                  |
| id                 | 1b2a87e4-eb8c-46ab-922c-63fcd7db8f20 |
| metadata           | {}                     |
| multiattach        | false                  |
| size               | 1                      |
| snapshot_id        | none                   |
| source_volid       | none                   |
| status             | creating               |
| volume_type        | SmartCache             |
+-----+-----+-----+-----+

```

----End

5.6 Configuring the SmartTier Property

The following example describes how to configure the SmartTier property.

Procedure

Step 1 Run the **cinder type-create XXX** command to create a volume type. XXX indicates the name of a volume type.

```

root@ubuntu-204:~# cinder type-create SmartTier
+-----+-----+-----+-----+
|          ID          | Name   | Description | Is_Public |
+-----+-----+-----+-----+
| fb3ec327-84f2-4af9-acc9-744dd6163dcf | SmartTier | -          | True     |
+-----+-----+-----+-----+

```

Step 2 Run the **cinder type-key SmartTier set capabilities:smarttier='<is> true'** command to set a key-value pair for the SmartTier volume type.

Step 3 Run the **cinder type-key SmartTier set smarttier:policy= 'xx'** command to set a key-value pair for the SmartTier volume type.

Policy: indicates migration policy. **0** indicates no migration, **1** indicates automatic migration, **2** indicates migration to high performance, **3** indicates migration to low performance.

Step 4 Create a volume that supports **SmartTier**.

```
root@ubuntu-204:~# cinder create 1 --display-name test001 --volume-type SmartTier
```

property	value
attachments	[]
availability_zone	nova
bootable	false
created_at	2015-06-26t13:40:10.483450
display_description	none
display_name	test001
encrypted	false
id	1b2a87e4-eb8c-46ab-922c-63fcd7db8f20
metadata	{}
multiattach	false
size	1
snapshot_id	none
source_volid	none
status	creating
volume_type	SmartTier

----End

5.7 Configuring the HyperMetro Property

The following example describes how to configure the HyperMetro property.

Prerequisites

Step 1 Add information about remote devices in `/etc/cinder/cinder.conf` in target back end section.

```
hypermetro_device =
    storage_pool:StoragePool001,
    san_address:https://IP:port/deviceManager/rest/,
    san_user:xxx,
    san_password:xxx,
    vstore_name:xxx,
    iscsi_default_target_ip:x.x.x.x,
    metro_domain:hypermetro-domain
```

Add information about remote devices for iscsi multipath:

```
iscsi_info: {Name:xxx;CHAPinfo:user#password;ALUA:1;
            TargetIP:0.0.0.0;TargetPortGroup:xxx};
            {Name:xxx;CHAPinfo:user#password;ALUA:1;
            TargetIP:0.0.0.0;TargetPortGroup:xxx}
```

NOTICE

Separate the key words by ","; separate the initiator informations in "iscsi_info" by ";".

Table 5-1 Parameter specification

Parameter	Description
san_address	Access address of the REST interface, for example, https://x.x.x.x:8088/deviceManager/rest/, x.x.x.x indicates the management IP address.
san_user	User name of a storage administrator or tenant of hypermetro remote device.
san_password	Password of a storage administrator or tenant of hypermetro remote device.
vstore_name	vstore name of hypermetro remote device(only needed using tenant user).
metro_domain	Hypermetro domain name configured on DeviceManager.
storage_pool	Remote storage pool for hypermetro.
iscsi_default_target_ip	Remote transaction port IP
Initiator Name	Name of a computing node initiator.
Initiator Target IP	IP address of the iSCSI target port that is provided for computing nodes.
Initiator TargetPortGroup	IP address of the iSCSI target port that is provided for computing nodes.

Step 2 Restart the Cinder volume service.

----End

Procedure

Step 1 Run the **cinder type-create XXX** command to create a volume type. XXX indicates the name of a volume type.

```
root@ubuntu-204:~# cinder type-create HyperMetro
+-----+-----+-----+-----+
|          ID          | Name   | Description | Is_Public |
+-----+-----+-----+-----+
| 0913e3dd-8b68-4b46-80ea-cf255617b13a | HyperMetro | -          | True      |
+-----+-----+-----+-----+
```

Step 2 Run the **cinder type-key HyperMetro set capabilities:hypermetro='<is> true'** command to set a key-value pair for the HyperMetro volume type.

Step 3 Create a volume that supports **HyperMetro**.

```
root@ubuntu-204:~# cinder create 1 --display-name test001 --volume-type
Hypermetro
+-----+-----+
| property | value |
+-----+-----+
| attachments | [] |
| availability_zone | nova |
| bootable | false |
```

created_at	2015-06-26t13:40:10.483450
display_description	none
display_name	test001
encrypted	false
id	1b2a87e4-eb8c-46ab-922c-63fcd7db8f20
metadata	{}
multiattach	false
size	1
snapshot_id	none
source_valid	none
status	creating
volume_type	HyperMetro

----End

5.8 Configuring the Replication V2.1

The following example describes how to configure the Replication V2.1.

Prerequisites

Step 1 Add information about remote devices in `/etc/cinder/cinder.conf` in target back end section.

```
replication_device =
    backend_id:huawei-replica-1,
    storage_pool:StoragePool001,
    san_address:https://IP:port/deviceManager/rest/,
    san_user:xxx,
    san_password:xxx,
    vstore_name:xxx,
    iscsi_default_target_ip:x.x.x.x
```

Add information about remote devices for iscsi multipath:

```
iscsi_info: {Name:xxx;CHAPinfo:user#password;ALUA:1;
            TargetIP:0.0.0.0;TargetPortGroup:xxx};
            {Name:xxx;CHAPinfo:user#password;ALUA:1;
            TargetIP:0.0.0.0;TargetPortGroup:xxx}
```

NOTICE

Separate the key words by ","; separate the initiator informations in "iscsi_info" by ";".

Table 5-2 Parameter specification

Parameter	Description
backend_id	Target device id
storage_pool	Pool name of target backend when failover.
san_address	Access address of the REST interface, for example, <code>https://x.x.x.x:8088/deviceManager/rest/</code> , <code>x.x.x.x</code> indicates the management IP address.
san_user	User name of a storage administrator of Replication V2.1 remote device

Parameter	Description
san_password	Password of a storage administrator of Replication V2.1 remote device.
vstore_name	vstore name of replication remote device(only needed using tenant user).
iscsi_default_target_ip	Remote transaction port IP
Initiator Name	Name of a computing node initiator.
Initiator Target IP	IP address of the iSCSI target port that is provided for computing nodes.
Initiator TargetPortGroup	IP address of the iSCSI target port that is provided for computing nodes.

Step 2 Run the `service cinder-volume restart` command to restart the Cinder service.

---End

Procedure

Step 1 Run the `cinder type-create XXX` command to create a volume type. XXX indicates the name of a volume type.

```
root@ubuntu-204:~# cinder type-create Replication_V2.1
+-----+
+-----+
|          ID          |      Name      | Description |
+-----+-----+-----+
| b9ff6a0d-7581-4e50-8ba9-0ab2703e42e7 | Replication_V2.1 |      -      |
+-----+-----+-----+
| True |
+-----+
+-----+
```

Step 2 Run the `cinder type-key Replication_V2.1 set capabilities:replication_enabled='<is> true'` command to set a key-value pair for the Replication V2.1 volume type.

Step 3 (Optional)Run the `cinder type-key Replication_V2.1 set replication_type='<in> sync'` command to set the type of Replication V2.1.

Optional values of "**replication_type**" are "sync" and "async". "sync" indicates synchronous replication; "async" indicates asynchronous replication. when skip this step, asynchronous replication will be applied.

Step 4 Create a volume that supports **Replication V2.1**.

```
root@ubuntu-204:~# cinder create 1 --display-name test001 --volume-type
Replication_V2.1
+-----+
+-----+
|      property      |      value      |
+-----+-----+-----+
|      attachments  |      []         |
|      availability_zone |      nova       |
|      bootable     |      false      |
|      created_at   |      2015-06-26t13:42:10.483450 |
|      display_description |      none       |
|      display_name  |      test001    |
+-----+-----+-----+
```

encrypted	false
id	1b2a87e4-eb8c-46ab-922c-63fcd7db8f31
metadata	{}
multiattach	false
size	1
snapshot_id	none
source_vol_id	none
status	creating
volume_type	Replication_V2.1

----End

5.9 Create a volume on a certain storage pool

This section describes how to create a volume on a certain storage pool in a back end that manages multiple pools. A volume type with a extra spec specified storage pool should be created first, then the user can use this volume type to create the volume.

Procedure

Step 1 Run the `cinder type-create XXX` command to create a volume type. XXX indicates the name of a volume type.

```
root@ubuntu-175:~# cinder type-create target-pool
```

ID	Name	Description	Is_Public
2ecf5589-507e-4ee5-995f-4aa1d0aaff83	target-pool	-	True

Step 2 Run the following command to configure the storage pool.

- Configure a single storage pool

```
cinder type-key target-pool set pool_name=StoragePool001
```
- Configure multiple storage pools.

```
cinder type-key target-pool set pool_name="<or> StoragePool001 <or> StoragePool002"
```

Step 3 Create a volume on a certain storage pool.

```
root@ubuntu-175:~# cinder create --volume-type target-pool 1
```

Property	Value
attachments	[]
availability_zone	nova
bootable	false
consistencygroup_id	None
created_at	2016-08-12T08:14:21.000000
description	None
encrypted	False
id	3023e949-ec25-4005-8bbc-6aa2c6860235
metadata	{}
migration_status	None
multiattach	False
name	None
os-vol-host-attr:host	None
os-vol-mig-status-attr:migstat	None
os-vol-mig-status-attr:name_id	None
os-vol-tenant-attr:tenant_id	53c46df66a084916876a08d7bcc31d87
replication_status	disabled
size	1
snapshot_id	None

source_volid	None
status	creating
updated_at	None
user_id	ec5b1bd5fa8646109381755037aacc82
volume_type	target-pool

----End

5.10 Create a volume with a certain disk type

This section describes how to create a volume with a certain disk type.

Procedure

Step 1 Run the `cinder type-create XXX` command to create a volume type. XXX indicates the name of a volume type.

```
root@ubuntu-175:~# cinder type-create disk-type
```

ID	Name	Description	Is_Public
c47fffc4-3510-4c24-b4ac-1880d44f12ff	disk-type	-	True

Step 2 Run the following command to configure the certain disk type.

- Configure one type of disk type.

```
root@ubuntu-175:~# cinder type-key disk-type set disk_type=sas
```

- Configure multiple types of disk type.

```
root@ubuntu-175:~# cinder type-key disk-type set disk_type="<or> sas <or> ssd"
```

optional values of disk type can be "ssd", "sas", "nl_sas" or "mix", the "mix" is a mixture of two or more of "ssd", "sas", "nl_sas".

Step 3 Create a volume with a certain disk type.

```
root@ubuntu-175:~# cinder create --volume-type disk-type 1
```

Property	Value
attachments	[]
availability_zone	nova
bootable	false
consistencygroup_id	None
created_at	2016-08-12T08:24:09.000000
description	None
encrypted	False
id	eca3a81b-0ef0-49b6-9202-d1bf1c16a96f
metadata	{}
migration_status	None
multiattach	False
name	None
os-vol-host-attr:host	ubuntu-175@234#StoragePool002
os-vol-mig-status-attr:migstat	None
os-vol-mig-status-attr:name_id	None
os-vol-tenant-attr:tenant_id	53c46df66a084916876a08d7bcc31d87
replication_status	disabled
size	1
snapshot_id	None
source_volid	None
status	creating
updated_at	2016-08-12T08:24:11.000000
user_id	ec5b1bd5fa8646109381755037aacc82

volume_type	disk-type

---End

5.11 Create a volume on a certain volume back end

This section describes how to create a volume on a certain volume back end.

Procedure

- Step 1** Run the **cinder type-create XXX** command to create a volume type. XXX indicates the name of a volume type.

```
root@ul404:~# cinder type-create volume-backend
+-----+-----+-----+-----+
|          ID          |      Name      | Description | Is_Public |
+-----+-----+-----+-----+
| 97cb1474-6019-41fc-a07c-0eefb19ecb30 | volume-backend |      -      |     True  |
+-----+-----+-----+-----+
+-----+-----+-----+-----+
```

- Step 2** Configure the volume back end name.

```
root@ul404:~# cinder type-key volume-backend set volume_backend_name=240_sh
root@ul404:~# cinder extra-specs-list
+-----+-----+-----+-----+
|          ID          |      Name      |
+-----+-----+-----+-----+
| 97cb1474-6019-41fc-a07c-0eefb19ecb30 | volume-backend |
| {'volume_backend_name': '240_sh'}      |                |
+-----+-----+-----+-----+
+-----+-----+-----+-----+
```

- Step 3** Create a volume on the volume back end.

```
root@ul404:~# cinder create --volume-type volume-backend 1
+-----+-----+-----+-----+
|          Property          |          Value          |
+-----+-----+-----+-----+
|      attachments          |          []             |
|  availability_zone        |          nova           |
|      bootable             |          false          |
|  consistencygroup_id     |          None           |
|      created_at           |          2017-04-17T19:36:11.000000 |
|      description          |          None           |
|      encrypted            |          False          |
|          id                |          01d1df8c-45f8-4af3-8ef6-62a708233474 |
|      metadata             |          {}             |
|  migration_status        |          None           |
|      multiattach          |          False          |
|          name              |          None           |
|  os-vol-host-attr:host   |          ul404@240_sh#Cinder-HXL |
|  os-vol-mig-status-attr:migstat |          None           |
|  os-vol-mig-status-attr:name_id |          None           |
|  os-vol-tenant-attr:tenant_id |          3692e4d8455741a8b0c47a6859f23e1c |
|  replication_status      |          disabled       |
|          size              |          1              |
|      snapshot_id         |          None           |
|      source_volid        |          None           |
+-----+-----+-----+-----+
```

status	creating
updated_at	2017-04-17T19:36:12.000000
user_id	3fdf4c2ee2964e23bb09decdeb24caa5
volume_type	volume-backend

----End

5.12 Configuring Consistency Groups

This section describes how to configure consistency groups and snapshot consistency groups.

Before using consistency groups, you must change policies for the consistency group APIs in the `/etc/cinder/policy.json` file. For more details please refer to <http://docs.openstack.org/admin-guide/blockstorage-consistency-groups.html>.

5.13 Configuring Backup Snapshot

This section describes how to configure backup snapshot.

Procedure

Step 1 Configure backup driver.

For more details please refer to <https://docs.openstack.org/ocata/config-reference/block-storage/backup-drivers.html>, and ensure `cinder-backup` service is working.

Step 2 Configure the `cinder.conf` file.

In the `[DEFAULT]` section add the following configuration.

```
backup_use_same_host = True
```

Add the following configuration in the target back end configuration group

```
backup_use_temp_snapshot = True
```

Step 3 Run the `service cinder-volume restart` and `service cinder-back restart` command to restart the Cinder service and Backup service.

----End

5.14 Configuring Certificate Verify

This section describes how to enable SSL certificate verify for Huawei storage connection.

Procedure

Step 1 Configure Huawei-defined configuration file of Driver.

Add `SSLCertVerify` and `SSLCertPath` in `<Storage>`, as follow:

```
<?xml version='1.0' encoding='UTF-8'?>
  <config>
    <Storage>
      <SSLCertVerify>True</SSLCertVerify>
      <SSLCertPath>xxx</SSLCertPath>
    </Storage>
  </config>
</?xml>
```

```

    ...
    </Storage>
    ...
</config>

```

SSLCertVerify denotes whether enable certificate verify, which's valid options are True/False. Default False if not explicitly specified.

SSLCertPath specifies the path to the certificate to use, only works when SSLCertVerify is True.

Step 2 Restart cinder-volume service.

----End

5.15 Configuring the Owning Controller of a LUN

This section uses an example to describe how to configure the owning controller of a LUN.

Procedure

Step 1 Run the **cinder type-create XXX** command to create a volume type. In this command, *XXX* indicates the volume type, which is specified by users.

```

root@ubuntu-p-200:~# cinder type-create controller_type_C
+-----+-----+-----+-----+-----+-----+-----+-----+
+-----+ | ID | Name |
+-----+ | Is_Public | +-----+
Description | a6f65c73-
ff74-4809-9e63-086052169e42 | controller_type_C | - | True |
+-----+-----+-----+-----+-----+-----+
+-----+

```

Step 2 Run the following command to configure the key-value pair whose **Huawei_controller** attribute is **true**.

```

root@ubuntu-p-200:~# cinder type-key controller_type_C set
capabilities:huawei_controller='<is> true'

```

Step 3 Configure the **huawei_controller** name that exists on the storage device and associate **controllername** to the volume type.

```

root@ubuntu-p-200:~# cinder type-key controller_type_C set
huawei_controller:controllername='CTE0.C'

```

Step 4 Create a volume with the owning controller attribute specified volume type.

----End

5.16 Configuring the SmartDedupe Property

This section uses an example to describe how to configure the SmartDedupe property of a LUN. Only Thin LUN supports this property.

Enable SmartDedupe Procedure

Step 1 Run the **cinder type-create XXX** command to create a volume type. In this command, *XXX* indicates the volume type name, which is specified by users.

```

root@ubuntu-p-200:~# cinder type-create Dedup
+-----+-----+-----+-----+-----+-----+-----+-----+

```

```

+-----+
| ID                               | Name           | Description |
+-----+-----+-----+
| a6f65c73-ff74-4809-9e63-086052169e42 | Dedup         | -          |
+-----+-----+-----+
True                               |
+-----+

```

Step 2 For Newton and later versions, run the **cinder type-key Dedup set capabilities:thin_provisioning_support='<is> true' capabilities:dedup='<is> true'** command to add volume type specs.

For Liberty and Mitaka versions, run the **cinder type-key Dedup set capabilities:thin_provisioning_support='<is> true' capabilities:dedup='<in> true'** command to add volume type specs.

Step 3 Create a SmartDedupe enabled volume by the Dedup volume type.

----End

Disable SmartDedupe Procedure

Step 1 Run the **cinder type-create XXX** command to create a volume type. In this command, *XXX* indicates the volume type name, which is specified by users.

```

root@ubuntu-p-200:~# cinder type-create NoDedup
+-----+-----+-----+
| ID                               | Name           | Description |
+-----+-----+-----+
| a6f65c73-ff74-4809-9e63-086052169e42 | NoDedup       | -          |
+-----+-----+-----+
True                               |
+-----+

```

Step 2 For Newton and later versions, run the **cinder type-key NoDedup set capabilities:thin_provisioning_support='<is> true' capabilities:dedup='<is> false'** command to add volume type specs.

For Liberty and Mitaka versions, run the **cinder type-key NoDedup set capabilities:thin_provisioning_support='<is> true' capabilities:dedup='<in> false'** command to add volume type specs.

Step 3 Create a SmartDedupe disabled volume by the NoDedup volume type.

----End

NOTE

Dorado series storages only support Thin LUN, the **capabilities:thin_provisioning_support** key at Step 2 is optional.

5.17 Configuring the SmartCompression Property

This section uses an example to describe how to configure the SmartCompression property of a LUN. Only Thin LUN supports this property.

Enable SmartCompression Procedure

- Step 1** Run the **cinder type-create XXX** command to create a volume type. In this command, *XXX* indicates the volume type name, which is specified by users.

```
root@ubuntu-p-200:~# cinder type-create Compression
+-----+
+-----+
| ID                               | Name           | Description |
Is_Public |
+-----+
| a6f65c73-ff74-4809-9e63-086052169e42 | Compression   | -          |
True      |
+-----+
+-----+
```

- Step 2** For Newton and later versions, run the **cinder type-key Compression set capabilities:thin_provisioning_support='<is> true' capabilities:compression='<is> true'** command to add volume type specs.

For Liberty and Mitaka versions, run the **cinder type-key Compression set capabilities:thin_provisioning_support='<is> true' capabilities:compression='<in> true'** command to add volume type specs.

- Step 3** Create a SmartCompression enabled volume by the Compression volume type.

----End

Disable SmartDedupe Procedure

- Step 1** Run the **cinder type-create XXX** command to create a volume type. In this command, *XXX* indicates the volume type name, which is specified by users.

```
root@ubuntu-p-200:~# cinder type-create NoCompression
+-----+
+-----+
| ID                               | Name           | Description |
Is_Public |
+-----+
| a6f65c73-ff74-4809-9e63-086052169e42 | NoCompression | -          |
True      |
+-----+
+-----+
```

- Step 2** For Newton and later versions, run the **cinder type-key NoCompression set capabilities:thin_provisioning_support='<is> true' capabilities:compression='<is> false'** command to add volume type specs.

For Liberty and Mitaka versions, run the **cinder type-key NoCompression set capabilities:thin_provisioning_support='<is> true' capabilities:compression='<in> false'** command to add volume type specs.

- Step 3** Create a SmartCompression disabled volume by the NoCompression volume type.

----End

NOTE

Dorado series storages only support Thin LUN, the **capabilities:thin_provisioning_support** key at Step 2 is optional.

5.18 Create a volume with fast clone

This section describes how to create a volume with the fast clone way of Dorado storage.

Procedure

- Step 1** While creating a volume from a snapshot or a source volume, specify the "--metadata" parameter with a "fastclone" key, as follows:

```
root@ubuntu:~# cinder create --snapshot-id *** --metadata fastclone=True
root@ubuntu:~# cinder create --source-volid *** --metadata fastclone=True
```

----End

NOTICE

- If the fastclone key is not explicitly specified for metadata, it defaults False, which means LUN copy way will be used as described in 5.19 section.
- Only Dorado storage system supports this feature.

5.19 Configuring the LUN Copy Speed

Defaultly LUN copy feature of Huawei storage is used to create a volume from a snapshot or a source volume. This section describes how to specify the LUN copy speed.

Procedure

- Step 1** While creating a volume from a snapshot or a source volume, specify the "--metadata" parameter with a "copyspeed" key, as follows:

```
root@ubuntu:~# cinder create --snapshot-id *** --metadata copyspeed=2
root@ubuntu:~# cinder create --source-volid *** --metadata copyspeed=2
```

----End

Table 5-3 Optional value of copyspeed parameter

Parameter value	Parameter Description
1	low
2	medium
3	high
4	highest

6 Best Practices

6.1 Quick Interconnection with Huawei Storage

6.1 Quick Interconnection with Huawei Storage

Configuration Process

This section demonstrates how to configure OpenStack Huawei Cinder Driver on OpenStack to interconnect with Huawei Storage.

Step 1 Obtain Cinder Driver.

OpenStack Kilo and later versions released in the OpenStack community are delivered with Huawei OpenStack Driver. You can obtain the latest codes of Driver through Huawei's OpenStack Driver repository. For details, see 3 .

NOTE

- A community version cannot be integrated with new features once being released and has security risks because its debug process is time-consuming.
- However, OpenStack Driver obtained from OpenStack Driver repository can be integrated with newly launched features and debugged in a timely manner, when a supportive framework is used.
- The community only maintains two stable versions. However, Huawei OpenStack Driver library maintains six stable versions, ensuring long-term stable running of historical versions.
- You are strongly recommended to use Huawei OpenStack Driver library versions, instead of community versions.

Step 2 Create or query the block storage pool which will be used in Huawei storage.

Step 3 Configure file **cinder.conf** and Huawei-defined configuration file of Driver. (The following uses Huawei OceanStor V3 series on the iSCSI network as an example. For details, see 4).

1. In **/etc/cinder**, create a Huawei-defined Driver configuration file in **.xml** format. In this example, **cinder_huawei_conf.xml** is used as the file name that can be changed based on actual conditions.
2. Set parameters for the created file.

```
<?xml version='1.0' encoding='UTF-8'?>
  <config>
    <Storage>
      <Product>V3</Product>
```

```
<Protocol>iSCSI</Protocol>
<RestURL>https://x.x.x.x:8088/deviceManager/rest/</RestURL>
<UserName>xxx</UserName>
<UserPassword>xxx</UserPassword>
</Storage>
<LUN>
  <StoragePool>xxx</StoragePool>
</LUN>
<iSCSI>
  <DefaultTargetIP>x.x.x.x</DefaultTargetIP>
</iSCSI>
</config>
```

3. Check the owner and owning group of the file.

Ensure that the owner and owning group of file `/etc/cinder/cinder_huawei_conf.xml` is the same as those of file `/etc/cinder/cinder.conf`.

```
-rw-r--r-- 1 cinder cinder 2662 Jul 29 02:13 cinder.conf
-rw-r--r-- 1 cinder cinder 778 Jul 30 02:56 cinder_huawei_conf.xml
```

4. Configure file `cinder.conf`.

At the end of file `/etc/cinder/cinder.conf`, add the following configuration item to add HuaweiDriver for V3_iSCSI. In this configuration item, `volume_driver` indicates the loaded Driver file, and `cinder_huawei_conf_file` indicates the Huawei-defined configuration file.

```
[V3_iSCSI]
volume_driver = cinder.volume.drivers.huawei.huawei_driver.HuaweiISCSIDriver
cinder_huawei_conf_file = /etc/cinder/cinder_huawei_conf.xml
volume_backend_name = V3_iSCSI
```

In the **[DEFAULT]** area, modify the configuration as follows to enable the V3_iSCSI back-end:

```
[DEFAULT]
...
enabled_backends=V3_iSCSI
```

Step 4 Restart the Cinder service.

Step 5 Check the service status.

```
root@u1404:~# cinder service-list +-----+-----+-----+-----+
+-----+-----+-----+-----+-----+-----+-----+-----+-----+
Binary      |      Host      | Zone | Status | State |
Updated_at  | Disabled Reason | +-----+-----+-----+-----+
+-----+-----+-----+-----+-----+-----+-----+-----+-----+
cinder-volume | u1404@38_sd    | nova | enabled | down |
2016-11-17T15:26:32.000000 | | cinder-volume |
u1404@V3_iSCSI | nova | enabled | up | 2017-04-18T15:44:09.000000 |
- | | cinder-volume | u1404@dorado | nova | enabled | down |
2017-03-17T11:15:43.000000 | - | +-----+-----+
+-----+-----+-----+-----+-----+-----+-----+-----+-----+
+-----+-----+-----+-----+-----+-----+-----+-----+-----+
```

In this example, the service status of `u1404@V3_iSCSI` is **up**, indicating that the service is started correctly.

----End

7 FAQ

[7.1 Need to manually create the mapping associated objects like Host, Host Group or Lun Group on Huawei storage beforehand before attaching volume via Cinder Driver?](#)

[7.2 Nova log prints "lsblk " command execution failed while attaching volume.](#)

7.1 Need to manually create the mapping associated objects like Host, Host Group or Lun Group on Huawei storage beforehand before attaching volume via Cinder Driver?

No, because Cinder Driver will create these mapping associated objects and the Mapping View. On the contrary, if these objects are manually created on Huawei storage, will cause Cinder Driver not properly function, so that please make sure these objects deleted before attaching volume.

7.2 Nova log prints "lsblk " command execution failed while attaching volume.

Nova will utilize "lsblk" tool to query the attached volume information, this error generally occurs due to this tool is not installed, please make sure it's installed correctly in Nova system.