




# UNIVERSAL ROBOTS



## Service Manual

Revision UR10\_en\_3.1.3

*"Original instructions"*

### **Robot:**

UR10 with CB3.0/3.1-controller

*CB3.0 valid from robot s/n 2014300001 to 2016301178*

*CB3.1 valid from robot s/n 2016301179*

# Contents

1.	General information.....	4
1.1	Purpose.....	4
1.2	Company details.....	5
1.3	Disclaimer .....	5
2	Preventive Maintenance .....	6
2.1	Controller .....	6
2.1.1	Inspection plan, Safety Functions .....	6
2.1.2	Visual inspection .....	8
2.1.3	Cleaning and replacement of filters.....	8
2.2	Robot arm.....	9
2.2.1	Visual inspection .....	9
3.	Service and Replacement of parts.....	10
3.1	Robot arm.....	10
3.1.1	Before returning any part to Universal Robots.....	10
3.1.2	Robot arm configuration.....	11
3.1.3	Brake release.....	12
3.1.4	General guidance to separate joint from counterpart .....	13
3.1.5	Torque values.....	17
3.1.6	Base joint – Base mounting bracket .....	18
3.1.7	Shoulder joint – Base joint .....	20
3.1.8	Upper arm – Shoulder joint .....	22
3.1.9	Elbow joint – Upper arm .....	24
3.1.11	Wrist 1 joint – Lower arm .....	26
3.1.12	Wrist 2 joint – Wrist 1 joint.....	28
3.1.13	Wrist 3 joint – Wrist 2 joint.....	30
3.1.14	Tool flange – Wrist 3 joint.....	30
3.1.15	Instructions for calibrating a joint.....	32
3.1.16	Dual Robot calibration .....	40
3.1.17	Change joint ID.....	41
3.1.18	Joint spare part adaptation.....	42
3.2	Controller .....	44

3.2.1 Handling ESD-sensitive parts .....	44
3.2.2 Replacement of motherboard 3.0 .....	48
3.2.3 Replacement of motherboard 3.1 .....	51
3.2.4 Replacement of Safety Control Board .....	54
3.2.5 Replacement of teach pendant.....	57
3.2.6 Replacement of 48V power supply .....	59
3.2.7 Replacement of 12V power supply .....	62
3.2.8 Replacement of current distributor .....	63
4. Software .....	64
4.1 Update software.....	64
4.2 Update joint firmware.....	66
4.3 Using Magic files.....	69
5. Troubleshooting .....	70
5.1 Error codes .....	70
5.2 LED indicators and Fuses on Safety Control Board .....	92
5.3 Error phenomena .....	94
5.3.1 ControlBox: NO CONTROLLER displayed in Initializing .....	94
5.3.2 NO CABLE displayed during power up .....	95
5.3.3 Protective stop.....	96
5.3.4 Power on failure in Initializing .....	97
5.3.5 Checklist after a collision .....	100
5.4 Electrical documentation .....	101
5.4.1 Schematic overview .....	101
5.4.2 E-Plan diagrams.....	107
6. Spare parts.....	120
6.1 Spare part list .....	120
6.2 Service kit .....	121
7. Packing of robot.....	122
8. Change log .....	123

# 1. General information

## 1.1 Purpose

The main purpose of this manual is to help the user safely perform service related operations and troubleshooting.

Universal Robots industrial robots are designed using high quality components designed for long lifetime. However any improper use of robot can potentially cause failures. For example, the robot may have been overloaded or have been dropped on the floor when relocating or have run with a load not recommended by Universal Robots. Any improper use of the robot will invalidate the guarantee.

Universal Robots recommends that you do not attempt repair, adjustment or other intervention in the mechanical or electrical systems of the robot unless a problem has arisen. Any unauthorized intervention will invalidate the guarantee. Service related operations and troubleshooting should only be performed by qualified personnel.

Before performing service related operations, always make sure to stop the robot program and disconnect power supply to any potential dangerous tool on the robot or in the work cell.

In the event of a defect, Universal Robots recommends ordering new parts from the Universal Robot distributor from where the robot has been purchased.

Alternatively, you can order parts from your nearest distributor, whose details you can obtain from Universal Robots official website at [www.universal-robots.com](http://www.universal-robots.com)

## **1.2 Company details**

Universal Robots A/S  
Energivej 25  
DK-5260 Odense Denmark  
Tel.: +45 89 93 89 89  
Fax +45 38 79 89 89

## **1.3 Disclaimer**

The information contained herein is the property of Universal Robots A/S and shall not be reproduced in whole or in part without prior written approval of Universal Robots A/S. The information herein is subject to change without notice and should not be construed as a commitment by Universal Robots A/S. This Manual is periodically reviewed and revised.


Universal Robots A/S assumes no responsibility for any errors or omissions in this document.

Copyright © 2016 by Universal Robots A/S

The Universal Robots logo is a registered trademark of Universal Robots A/S.

## 2 Preventive Maintenance

### 2.1 Controller



#### 2.1.1 Inspection plan, Safety Functions

The safety functions of the robots must be tested at least once a year to ensure correct function. The following tests must be performed.

- Test that the Emergency Stop button on the Teach Pendant functions:
  - Press the Emergency Stop button on the Teach Pendant
  - Observe that the robot stops and turns off the power to the joints
  - Power on robot again
- Test Free drive mode:
  - Unmount attachment or set TCP/Payload/CoG according to tool specifications
  - Set the robot in Free drive mode by pressing the *Free drive* button on the Teach Pendant
  - Move the robot to a position where it is stretched out horizontally
  - Monitor that the robot maintains its position when not holding the robot and the Free drive button still pressed.
- Test Back drive mode:

If robot is close to collision, the BACKDRIVE function can be used to move robot arm to safe position before initializing.

  - Press ON to enable power, state will change to *Idle*.
  - Press and hold Freedrive -> status will change to BACKDRIVE
  - Move the robot as done in Freedrive, brakes will be released on the joints where it's needed but only as long as the Freedrive button is activated. Robot will be "heavy" to move around.
  - Be sure to test this so that all joints have been tested.

- Verify safety settings:
  - Verify that the safety settings of the robot comply with the Risk Assessment of the robot installation
- Test that additional safety inputs and outputs are still functioning:
  - Check which safety inputs and outputs are active and test that they can be triggered.

## 2.1.2 Visual inspection


- Disconnect power cable from controller
- Check terminals are properly inserted on Safety Control Board
- Check all connections on Motherboard and connection between Safety Control Board and Motherboard
- Check for any dirt/dust inside of controller, clean with vacuum cleaner if needed
  - » Use a soft cloth. You can add: Water, Isopropyl alcohol, 10% Ethanol alcohol or 10% Naphtha

## 2.1.3 Cleaning and replacement of filters

- Controller box contains two filters, one on each side of controller
- Remove filters from controller box and clean them thoroughly using compressed air
  - Replace filters if necessary




- Gently remove the outer plastic frame and maintain the filter






## 2.2 Robot arm



### 2.2.1 Visual inspection

- If you observe dirt/oil on the robot arm you simply clean it with a soft cloth.  
Cleaning agent: Water, Isopropyl alcohol, 10% Ethanol alcohol or 10% Naphtha  
In very rare cases the grease is from the inside of the joint. There is still enough grease in the gear for life time you just clean the joint with a cloth.
- Move robot arm to HOME position (if possible)
- Turn off and disconnect power cable from controller
- Inspect cable between controller and robot arm for any damage
- Inspect flat rings for wear and damage
  - » Replace flat rings if worn out or damaged
- Inspect blue lids on all joints for any cracks or damage
  - » Replace blue lids if cracked or damaged.
- Inspect that screws for blue lids are in place and properly tightened
  - » Replace screws, tighten properly if necessary



Correct torque value for screws on blue lids are **0.4Nm**

If any damage is observed on a robot within the warranty period, contact the distributor from which the robot has been purchased.

## 3. Service and Replacement of parts

### 3.1 Robot arm

#### 3.1.1 Before returning any part to Universal Robots

- Remove all external non-UR equipment such as grippers, hoses, cables and so on. Universal Robots cannot be held responsible for damage caused to non-UR equipment mounted on the robot.
- Backup all relevant files before sending the robot/part to UR. Universal Robots cannot be held responsible for loss of programs, data or files stored in the robot.

**Safety notice:**

If the robot/part has been in contact with, or working in environments, where dangerous chemicals or materials are present, the robot must be cleaned before shipment.


If this is not possible, the shipment must be accompanied by an MSDA (Material Safety Data Sheet) in English and instructions for cleaning the chemicals.

The amount of labor hours needed for cleaning will be billed at the standard rate.

If UR finds the robot/part unsafe to service, UR reserve the right to get the robot/part cleaned or decline the case and send the part back, at customer's expense.

**Note:** Please note that the robot will be updated to newest software/firmware when repaired. New parts will also be updated to newest version (hardware/software). Therefore, updating PolyScope may be necessary when new parts are mounted.

### 3.1.2 Robot arm configuration



### 3.1.3 Brake release


If required, the brake on a joint can be released without power connected.

#### IMPORTANT NOTICE:


- Before releasing a brake, it is extremely important to dismount any dangerous parts to avoid any hazardous situations.
- If releasing the brake on Base joint, Shoulder joint or Elbow joint, it is important to make proper mechanical support prior to releasing the brake.
- Always make sure personnel are in no risk when releasing the brake.
- Do not move the joint more than necessary.  
No more than about 160 degrees in order for the robot to find its original physical position.

Procedure for releasing the joint


1. Shut down Controller.
2. Remove blue lid on joint.
3. Push brake pin down to release, joint can then be rotated.



Brake on Base and Shoulder joints,



Brake on Elbow joint,



Brake on Wrist joints

4. Make sure to mount blue lid properly on joint before turning on Controller.
5. Correct torque value for screws on blue lids are **0.4Nm**

### 3.1.4 General guidance to separate joint from counterpart

#### Disassemble:


1. Check if the necessary tools and documentation are available before starting a repair.
  - a. Service kit with torque tools, ESD Wristband, etc.
  - b. Thoroughly read and understand this guide.
2. Move the robot to a comfortable position for disassembly or if necessary dismount entire robot arm from work cell and place on a solid surface.
3. Shut down the controller.
4. Remove blue lid.
5. Reattach one of the screws from the blue lids, in order to connect an alligator Clip on the ESD wristband as shown below.




6. **Gently** unplug the cable connectors **without bending the printed circuit board**.  
The power supply connector for the size 1 has a lock that has to be engaged before it is pulled out of the printed circuit board.



7. Disconnect wires
8. Remove alignment screw.



9. Gently remove black flexible flat ring with a tiny screwdriver or similar tool and twist it around the joint housing.




10. Slide the grey Teflon ring back.  
10 screws become visible, 5 on each side of joint.  
Loosen the screws with an open-ended spanner approximately two full turns each.
11. Pull the two parts apart and gently twist them in opposite directions around 10 mm, until a mechanical stop is met (holes are keyhole-type). They can then be completely separated.






## Assemble:

1. After replacing a joint etc. do as follows to assemble the robot arm.
2. Gently insert one part with screws and washers into the other part.




3. Make sure the washers are fully inserted and flush against the head of the bolt (this is important) before gently twisting the parts in opposite directions until a mechanical stop is met.
4. Gently tighten the 10 screws, tighten in cross order with the correct torque. When shorter bolts are used (marked with red) drawing on the right shows where they are mounted.  
See [3.1.5 Torque values](#)



Tighten in numeric order.

5. Slide the grey Teflon ring into place and gently put the flat ring back on top of the Teflon ring.




6. Mount the alignment screw and tighten with **0.4Nm**.
7. **Twist the communication cable** 1.5 to 2 full rounds before it is connected.  
(To reduce electrical noise in the system)
8. Mount the blue lid on the joint and tighten with **0.4Nm**.
9. Proceed to chapter [3.1.16 Dual Robot calibration](#) for calibrating the robot.



### 3.1.5 Torque values

UR10 torque values			
CONNECTION		TORQUE	HEAD SIZE
Base mounting bracket	J0 BASE	8.0Nm	10 mm.
[J0] Base	[J1] Shoulder	8.0Nm	10 mm.
[J1] Shoulder	Upper arm	8.0Nm	10 mm.
Upper arm	[J2] Elbow	2.6-3.0Nm	7 mm.
[J2] Elbow	Elbow counter part	2.6-3.0Nm	7 mm.
Elbow counter part	Lower arm	2.6-3.0Nm	7 mm.
Lower arm	[J3] Wrist 1	1.3Nm	5.5 mm.
[J3] Wrist 1	[J4] Wrist 2	1.3Nm	5.5 mm.
[J4] Wrist 2	[J5] Wrist 3	1.3Nm	5.5 mm.
[J5] Wrist 3	Tool mounting bracket	1.3Nm	5.5 mm.
Alignment screw		0.4Nm	Torx T10
Blue lid		0.4Nm	Torx T10

Attention: **Click the torque tools 3 times before used** to get the correct calibrated torque.



### 3.1.6 Base joint – Base mounting bracket Disassemble

For details and photos please see: [3.1.4 General guidance to separate joint from counterpart](#)


1. Shut down the controller.
2. Remove alignment screw.
3. Gently remove black flexible flat ring with a tiny screwdriver or similar tool and twist it around the joint housing.
4. Slide the grey Teflon ring back. 10 screws become visible, 5 on each side of joint. Loosen the screws with a 7 mm. open-ended spanner about two full turns, approximately 3 mm. for each screw.
5. Pull the base mounting bracket and Base joint apart and gently twist the two parts in opposite directions around 10 mm. until a mechanical stop is met (holes are keyhole-type).
6. Pull away the base mounting bracket from Base joint.
7. Disconnect wires between base mounting bracket and Base joint.

2 x red wire	= 48V DC
2 x black wire	= GND
Black connector	= bus cable

## Base joint – Base mounting bracket: Assemble

For details and photos please see: [3.1.4 General guidance to separate joint from counterpart](#)

1. Replace base mounting bracket and reconnect wires according to illustration:
2. **Twist the communication cable** 1.5 to 2 full rounds before it is connected.  
(To reduce electrical noise in the system)



3. Gently insert base mounting bracket with screws and washers into the Base joint.
4. Make sure the washers are fully inserted and flush against the head of the bolt (this is important) before gently twisting the parts in opposite directions until a mechanical stop is met.
5. Gently tighten the 10 screws, and then tighten **in cross order with 8.0Nm**.
6. Slide the grey Teflon ring into place and gently put the flat ring back on top of the Teflon ring.
7. Mount the alignment screw and tighten with **0.4Nm**.
8. Mount blue lid on Base joint and tighten with **0.4Nm**.
9. Proceed to chapter [3.1.16 Dual Robot calibration](#) for calibrating the robot.

### 3.1.7 Shoulder joint – Base joint Disassemble

For details and photos please see: [3.1.4 General guidance to separate joint from counterpart](#)

1. Shut down the controller.
2. Remove blue lid on Base joint.
3. Connect ESD wristband
4. Disconnect wires between Base joint and Shoulder joint


2 x red wire	= 48V DC
2 x black wire	= GND
Black connector	= bus cable (NB: polarized)
5. Remove alignment screw
6. Gently remove black flexible flat ring between Base and Shoulder with a tiny screwdriver or similar tool and twist it around the joint housing.
7. Slide the grey Teflon ring back. 10 screws become visible, 5 on each side of joint. Loosen the screws with a 7 mm. open-ended spanner about two full turns, approximately 3 mm. for each screw.
8. Pull the Base joint and Shoulder joint apart and gently twist the two parts in opposite directions around 10 mm. until a mechanical stop is met (holes are keyhole-type).
9. Pull away the Base joint from Shoulder joint.



## Shoulder joint – Base joint: Assemble

For details and photos please see: [3.1.4 General guidance to separate joint from counterpart](#)

1. Gently insert Base joint with screws and washers into the Shoulder joint.
2. Make sure the washers are fully inserted and located on the correct side (this is important) before gently twisting the Base joint and Shoulder joint in opposite directions until a mechanical stop is met.
3. Tighten the 10 screws lightly, and then tighten **in cross order with 8.0Nm**.
4. Slide the grey Teflon ring in place and gently put back the flat ring on top of the Teflon ring.
5. Mount the alignment screw and tighten with **0.4Nm**.
6. Reconnect connectors as illustrated.
7. **Twist the communication cable** 1.5 to 2 full rounds before it is connected.  
(To reduce electrical noise in the system)



8. Mount blue lid on Base joint and tighten with **0.4Nm**.
10. Proceed to chapter [3.1.16 Dual Robot calibration](#) for calibrating the robot.

### 3.1.8 Upper arm – Shoulder joint

#### Disassemble

For details and photos please see: [3.1.4 General guidance to separate joint from counterpart](#)

1. Shut down the controller.
2. Remove blue lid on Shoulder joint.
3. Connect ESD wristband
4. Disconnect wires between Upper arm and Shoulder joint
  - 1 x red wire               = 48V DC
  - 1 x black wire           = GND
  - Black connector       = bus cable (NB: polarized)
5. Remove alignment screw.
6. Gently remove black flexible gasket between Upper arm and Shoulder with a tiny screwdriver or similar tool and twist it around the upper arm.
7. 10 screws become visible, 5 on each side of joint.  
Untighten gently the screw with a 10 mm. open-ended spanner about two full rounds, approximately 3 mm. for each screw.
8. Pull the Shoulder joint and upper arm apart and gently twist the two parts in opposite directions around 10 mm. until a mechanical stop is met (holes are keyhole-type).
9. Pull away the Shoulder joint from upper arm.




## Upper arm – Shoulder joint: Assemble

For details and photos please see: [3.1.4 General guidance to separate joint from counterpart](#)

1. Gently insert Shoulder joint with screws and washers into the upper arm.
2. Make sure the washers are fully inserted and flush against the head of the bolt (this is important) before gently twisting the parts in opposite directions until a mechanical stop is met.
3. Tighten the 10 screws lightly, and then tighten **in cross order with 8.0Nm**.
4. Gently put back the gasket.
5. Mount the alignment screw and tighten with **0.4Nm**.
6. Connect ESD wristband
7. Reconnect wires correctly.

**Twist the communication cable** 1.5 to 2 full rounds before it is connected.  
(To reduce electrical noise in the system)



8. Mount blue lid on Shoulder joint and tighten with **0.4Nm**.
11. Proceed to chapter [3.1.16 Dual Robot calibration](#) for calibrating the robot.

### 3.1.9 Elbow joint – Upper arm


#### Disassemble and assemble

Procedure for separating Elbow joint from Upper arm is similar to separation of Upper arm and Shoulder joint, consult chapter [3.1.8 Upper arm – Shoulder joint](#)

#### Disassemble

For details and photos please see: [3.1.4 General guidance to separate joint from counterpart](#)

1. Shut down the controller.
2. Remove blue lid on Elbow counterpart.
3. Disconnect wires between Elbow joint and Elbow counterpart
  - 1 x red wire = 48V DC
  - 1 x black wire = GND
  - Black connector = bus cable (NB: polarized)




4. Remove alignment screw.
5. Gently remove black flexible flat ring between Elbow and Elbow counterpart with a tiny screwdriver or similar tool and twist it around the joint housing.
6. Slide the grey Teflon ring back. 10 screws become visible, 5 on each side of joint. Loosen the screws with a 7 mm. open-ended spanner about two full turns, approximately 3 mm. for each screw.
7. Pull Elbow joint and Elbow counterpart apart and gently twist the two parts in opposite directions around 10 mm. until a mechanical stop is met (holes are keyhole-type).
8. Pull away the Elbow joint from Elbow counterpart.



## Elbow counterpart – Elbow joint: assemble

For details and photos please see: [3.1.4 General guidance to separate joint from counterpart](#)

1. Gently insert Elbow joint with screws and washers into the Elbow counterpart.
2. Make sure the washers are fully inserted and flush against the head of the bolt (this is important) before gently twisting the parts in opposite directions until a mechanical stop is met.
3. Tighten the 10 screws lightly, and then tighten **in cross order with 2.6-3.0Nm**.
4. Slide the grey Teflon ring in place and gently put back the flat ring on top of the Teflon ring.
5. Mount the alignment screw and tighten with **0.4Nm**.
6. Reconnect connectors as illustrated.
7. **Twist the communication cable** 1.5 to 2 full rounds before it is connected.  
(To reduce electrical noise in the system)



8. Mount blue lid on Elbow joint and tighten with **0.4Nm**.
9. Proceed to chapter [3.1.16 Dual Robot calibration](#) for calibrating the robot.

### 3.1.11 Wrist 1 joint – Lower arm

#### Disassemble

For details and photos please see: [3.1.4 General guidance to separate joint from counterpart](#) Shut down the controller.

1. Remove blue lid on Wrist 1 joint.
2. Connect ESD wristband
3. Disconnect wires between lower arm and Wrist 1 joint.



1 x red wire	= 48V DC
1 x black wire	= GND
Black connector	= bus cable (NB: polarized)
4. Remove alignment screw.
5. Gently remove black flexible gasket between lower arm and Wrist 1 joint with a tiny screwdriver or similar tool and twist it around the lower arm.
6. 10 screws become visible, 5 on each side of joint. Loosen the screws with a 5.5 mm. open-ended spanner about two full turns, approximately 3 mm. for each screw.
7. Pull the lower arm and Wrist 1 joint apart and gently twist the two parts in opposite directions around 8 mm. until a mechanical stop is met (holes are keyhole-type).
8. Pull away the lower arm from Wrist 1 joint.



## Wrist 1 joint – Lower arm: Assemble

For details and photos please see: [3.1.4 General guidance to separate joint from counterpart](#)

1. Gently insert Wrist 1 joint with screws and washers into the lower arm.
2. Make sure the washers are fully inserted and flush against the head of the bolt (this is important) before gently twisting the parts in opposite directions until a mechanical stop is met.
3. Tighten the 10 screws lightly, and then tighten **in cross order with 1.3Nm**.
4. Gently put back the gasket.
5. Mount the alignment screw and tighten with **0.4Nm**.
6. Connect ESD wristband
7. Reconnect wires between lower arm and Wrist 1 joint correctly.
8. **Twist the communication cable** 1.5 to 2 full rounds before it is connected.  
(To reduce electrical noise in the system)



9. Mount blue lid on Wrist 1 joint and tighten 2 pc M3x6 and 1 pc M3x10 with **0.4Nm**.
10. Proceed to chapter [3.1.16 Dual Robot calibration](#) for calibrating the robot.

### 3.1.12 Wrist 2 joint – Wrist 1 joint

#### Disassemble

For details and photos please see: [3.1.4 General guidance to separate joint from counterpart](#) Shut down the controller.

1. Remove blue lid on Wrist 1 joint.
2. Connect ESD wristband
3. Disconnect wires between Wrist 1 joint and Wrist 2 joint


1 x red wire	= 48V DC
1 x black wire	= GND
Black connector	= bus cable (NB: polarized)
4. Remove alignment screw.
5. Gently remove black flexible flat ring between Wrist 1 and Wrist 2 with a tiny screwdriver or similar tool and twist it around the joint housing.
6. Slide the grey Teflon ring back. 10 screws become visible, 5 on each side of joint. Loosen the screws with a 5.5 mm. open-ended spanner about two full turns, approximately 3 mm. for each screw.
7. Pull Wrist 1 joint and Wrist 2 joint apart and gently twist the two parts in opposite directions around 8 mm. until a mechanical stop is met (holes are keyhole-type).
8. Pull away Wrist 1 joint from Wrist 2 joint.



## Wrist 2 joint – Wrist 1 joint: Assemble

For details and photos please see: [3.1.4 General guidance to separate joint from counterpart](#)

1. Gently insert Wrist 1 joint with screws and washers into Wrist 2 joint.
2. Make sure the washers are fully inserted and flush against the head of the bolt (this is important) before gently twisting the parts in opposite directions until a mechanical stop is met.
3. Tighten the 10 screws lightly, and then tighten **in cross order with 1.3Nm**.
4. Slide the grey Teflon ring in place and gently put back the flat ring on top of the Teflon ring.
5. Mount the alignment screw and tighten with **0.4Nm**.
6. Connect ESD wristband
7. Replace Wrist 1 and reconnect connectors as illustrated into Wrist 2.
8. **Twist the communication cable** 1.5 to 2 full rounds before it is connected.  
(To reduce electrical noise in the system)



9. Mount blue lid on Wrist 1 joint and tighten 2 pc M3x6 and 1 pc M3x10 with **0.4Nm**.
10. Proceed to chapter [3.1.16 Dual Robot calibration](#) for calibrating the robot.

### 3.1.13 Wrist 3 joint – Wrist 2 joint

#### Disassemble and assemble

Procedure for separating Wrist 3 joint from Wrist 2 is similar to separation of Wrist 2 joint and Wrist 1 joint, consult chapter [3.1.12 Wrist 2 joint – Wrist 1 joint](#)

### 3.1.14 Tool flange – Wrist 3 joint

#### Disassemble

For details and photos please see: [3.1.4 General guidance to separate joint from counterpart](#)


1. Shut down the controller.
2. Remove alignment screw.
3. Gently remove black flexible flat ring with a tiny screwdriver or similar tool and twist it around the joint housing.
4. Slide the grey Teflon ring back. 10 screws become visible, 5 on each side of joint. Loosen the screws with a 5.5 mm. open-ended spanner about two full turns, approximately 3 mm. for each screw.
5. Pull the tool flange and Wrist 3 joint apart and gently twist the two parts in opposite directions around 8 mm. until a mechanical stop is met (holes are keyhole-type).
6. Pull away the tool flange from Wrist 3 joint.
7. Connect ESD wristband.
8. Disconnect the two connectors.



## Tool flange – Wrist 3 joint: Assemble

For details and photos please see: [3.1.4 General guidance to separate joint from counterpart](#)

1. Connect ESD wristband
2. Replace tool flange and reconnect connectors as illustrated.
3. **Twist the communication cable** 1.5 to 2 full rounds before it is connected (To reduce electrical noise in the system)



4. Gently insert tool flange with screws and washers into the Wrist 3 joint.
5. Make sure the washers are fully inserted and flush against the head of the bolt (this is important) before gently twisting the parts in opposite directions until a mechanical stop is met.
6. Tighten the 10 screws lightly, and then tighten **in cross order with 1.3Nm.**
7. Slide the grey Teflon ring in place and gently put back the flat ring on top of the Teflon ring.
8. Mount the alignment screw and tighten with **0.4Nm.**
9. Proceed to chapter [3.1.16 Dual Robot calibration](#) for calibrating the robot.

### 3.1.15 Instructions for calibrating a joint

After replacement calibration of the new joint is required in order to find the correct zero position. If it is possible and necessary, perform the [3.1.16 Dual Robot calibration](#) alternative perform a joint calibration.

Instructions for calibrating a joint:

1. Jog robot to HOME position






Illustration shows the HOME position, which is defined as zero position of all joints.

2. Drag a finger from left to right across the *UNIVERSAL*-sign on main screen of PolyScope.







3. Enter password *lightbot* and press *OK*.



4. You are now in *Expert Mode*, press *Low Level Control*.



## 5. Press *Turn power on* for enabling power to joints.



J0: POWER OFF P:+0.0000 S:+0.000 C:+0.000 V:+0.0 TM:+0.00 TE:+0.00 STS:0  
 J1: POWER OFF P:+0.0000 S:+0.000 C:+0.000 V:+0.0 TM:+0.00 TE:+0.00 STS:0  
 J2: POWER OFF P:+0.0000 S:+0.000 C:+0.000 V:+0.0 TM:+0.00 TE:+0.00 STS:0  
 J3: POWER OFF P:+0.0000 S:+0.000 C:+0.000 V:+0.0 TM:+0.00 TE:+0.00 STS:0  
 J4: POWER OFF P:+0.0000 S:+0.000 C:+0.000 V:+0.0 TM:+0.00 TE:+0.00 STS:0  
 J5: POWER OFF P:+0.0000 S:+0.000 C:+0.000 V:+0.0 TM:+0.00 TE:+0.00 STS:0  
 Tool: [OFF] DI:00 A1:0.0 A2:0.0 C:+0.01 mA V:+101.63  
 Safety Control Board: DI:00000000 DO:00000000 AI1:0.0 AI2:0.0 A01:0.0 A02:0.0  
 Safety Control Board: STATE: **Power off** MV:+48.3 RV:+0.0 CR:+0.36 mA CIO:+0.22 mA T:+33.84


General Move Calibration Firmware Joint ID

Turn power on Turn power off Arm current joint

STOP! ☒ Follow last line Back

Powering robot on...  
 SUCCESS: Command executed  
 Powering robot on...  
 SUCCESS: Command executed  
 Powering robot off...  
 SUCCESS: Command executed  
 Powering robot on...  
 SUCCESS: Command executed  
 Powering robot on...  
 SUCCESS: Command executed  
 Powering robot off...  
 SUCCESS: Command executed

## 6. Press *Go to Idle* for enabling the joints ready mode.



J0: BOOTLOADER P:+0.0000 S:+0.000 C:+0.000 V:+0.0 TM:+0.00 TE:+0.00 STS:0  
 J1: BOOTLOADER P:+0.0000 S:+0.000 C:+0.000 V:+0.0 TM:+0.00 TE:+0.00 STS:0  
 J2: BOOTLOADER P:+0.0000 S:+0.000 C:+0.000 V:+0.0 TM:+0.00 TE:+0.00 STS:0  
 J3: BOOTLOADER P:+0.0000 S:+0.000 C:+0.000 V:+0.0 TM:+0.00 TE:+0.00 STS:0  
 J4: BOOTLOADER P:+0.0000 S:+0.000 C:+0.000 V:+0.0 TM:+0.00 TE:+0.00 STS:0  
 J5: BOOTLOADER P:+0.0000 S:+0.000 C:+0.000 V:+0.0 TM:+0.00 TE:+0.00 STS:0  
 Tool: [OFF] DI:00 A1:0.0 A2:0.0 C:+0.01 mA V:+453.22  
 Safety Control Board: DI:00000000 DO:00000000 AI1:0.0 AI2:0.0 A01:0.0 A02:0.0  
 Safety Control Board: STATE: **Power on** MV:+48.3 RV:+48.3 CR:+0.82 mA CIO:+0.22 mA T:+33.96


General Move Calibration Firmware Joint ID

Go to Idle Turn power off Arm current joint


STOP! ☒ Follow last line Back

Powering robot on...  
 SUCCESS: Command executed  
 Powering robot off...  
 SUCCESS: Command executed  
 Powering robot on...  
 SUCCESS: Command executed  
 Powering robot on...  
 SUCCESS: Command executed  
 Powering robot off...  
 SUCCESS: Command executed

7. Select the desired joint by directly clicking the status line for that joint.




8. Press *Arm current joint* to release the brake on the selected joint.



Use the *Up* and *Down* buttons in the *Move* window to navigate the joint to the correct zero position according to the following illustrations.

Press *STOP* when the joint is in the correct position.



The screenshot shows the 'Move' window in the Universal Robots interface. At the top, there is a status bar with joint information for J0 through J5, including position (P), speed (S), current (C), voltage (V), temperature (TM), torque (TE), status (STS), K\_tau, and tau\_avg. Below this, the 'Tool' status is shown as [OFF] and the 'Safety Control Board' status is 'Idle'. The main window has tabs for 'General', 'Move', 'Calibration', 'Firmware', and 'Joint ID'. The 'Move' tab is active, showing a 'Step size' dropdown set to '0.0100 rad/sec'. There are 'Up' and 'Down' buttons for navigation. A red 'STOP!' button is visible, along with a 'Follow last line' checkbox and a 'Back' button. At the bottom, a log window displays various status messages, including 'Info: Setting current joint to 1', 'Info: Setting velocity of joint 1 to +0.0100 rads/sec', and 'Info: Sending stop all command'.


## 9. Zero position illustrations

Base:




Base zero position is aligned so that the output flange is offset 180 degrees from the cable in back of robot base.

Shoulder, Elbow, Wrist 1:




Shoulder, Elbow and Wrist 1 zero output flange is vertical aligned (if Base is horizontal). Make sure that base of robot is horizontal, use spirit level to align joints.

Wrist 2:




Wrist 2 zero position is aligned similar to Base joint, with tool flange parallel with wrist

Wrist 3:




Wrist 3 zero position is aligned so tool connector is pointing upward. Mount two bolts in tool holes and use spirit level to align joint.


10. Select *Calibration* tab and press *Zero current joint position* to calibrate the joint.



11. Press *Back* to exit Low Level Control.



12. Press *Return to Normal*.



13. Verify zero position by moving the robot to HOME.

If not satisfied with the zero position, perform the procedure once again.

### 3.1.16 Dual Robot calibration

Dual Robot Calibration kit (Part no: 185500)

Dual Robot Calibration is a calibration that calibrates the robot in the full work space. All robots are Dual Robot Calibrated when they are produced.

If a joint has been replaced on a calibrated robot the calibration is not correct anymore.

There are 2 options:

- Performing a Dual Robot Calibration after replacement of a joint will let the robot continue in the production line without modifying waypoints in the robot program. To perform a Dual Robot Calibration, you need: 2 robots (same size and same generation), calibration Horse and calibration tool connector.

Go to <http://www.universal-robots.com/support/> for downloading CalibrationManual.pdf.



- Joint calibration described in this section: After replacing a joint a zero position of the joint can be adjusted but the calibration level from the Dual Robot Calibration cannot be achieved. Adjustments of waypoints in the program should be expected.



### 3.1.17 Change joint ID

Each joint has a unique ID no. It is NOT possible to have two joints with the same ID no. on the same robot.

ID	Joint
J0	Base
J1	Shoulder
J2	Elbow
J3	Wrist 1
J4	Wrist 2
J5	Wrist 3


Example:

Wrist 1 (J3) has to be replaced. Spare joint is a Wrist 3 (J5)


1. Disconnect the joint with correct ID no.
2. Enter Low Level Control
3. Press *Turn power on* and the connected joints turn into BOOTLOADER



4. Press *Go to Idle* and the connected joints turn into READY



5. Select *Joint ID*
6. Select *J5* (The one to be changed)
7. Uncheck "Exchange IDs" box
8. In dropdown box, select ID no. 3
9. Press *Set it*



J0: READY P:+1.3389 S:+0.000 C:+0.047 V:+48.1 TM:+32.15 TE:+30.13 STS:3 K\_tau:+0.1266 tau\_avg:+0.1131  
J1: READY P:+4.9261 S:+0.000 C:+0.002 V:+48.1 TM:+32.72 TE:+30.75 STS:3 K\_tau:+0.1267 tau\_avg:+0.1348  
J2: READY P:+1.3800 S:-0.000 C:-0.022 V:+48.1 TM:+33.09 TE:+30.13 STS:3 K\_tau:+0.1274 tau\_avg:+0.1475  
J3: POWER OFF P:+0.0000 S:+0.000 C:+0.000 V:+0.0 TM:+0.00 TE:+0.00 STS:0  
J4: READY P:+4.7683 S:+0.000 C:+0.041 V:+48.2 TM:+39.95 TE:+34.27 STS:3 K\_tau:+0.0999 tau\_avg:+0.0360  
**J5: READY P:+6.1728 S:+0.000 C:+0.027 V:+48.1 TM:+37.80 TE:+28.07 STS:3 K\_tau:+0.1002 tau\_avg:+0.0262**

Tool: [???] DI:00 AI:0.0 A2:0.0 C:+0.00 mA V:+0.00  
Safety Control Board: DI:00000000 DO:00000000 AI1:0.0 AI2:0.0 A01:0.0 A02:0.0  
Safety Control Board: STATE: **Power on** MV:+48.3 RV:+48.3 CR:+0.93 mA CIO:+0.22 mA T:+32.16


General Move Calibration Firmware **Joint ID**

Set ID of current joint to **3**  
☐ Exchange IDs

**Set it**

**STOP!** ☐ Follow last line **Back**

#### 10. Confirm *Change ID*



J0: READY P:+1.3390 S:+0.000 C:+0.016 V:+48.1 TM:+31.02 TE:+28.79 STS:3 K\_tau:+0.1266 tau\_avg:+0.1131  
J1: READY P:+4.9261 S:+0.000 C:+0.034 V:+48.1 TM:+31.49 TE:+29.30 STS:3 K\_tau:+0.1267 tau\_avg:+0.1348  
J2: READY P:+1.3800 S:-0.000 C:-0.036 V:+48.1 TM:+32.02 TE:+28.88 STS:3 K\_tau:+0.1274 tau\_avg:+0.1475  
J3: POWER OFF P:+0.0000 S:+0.000 C:+0.000 V:+0.0 TM:+0.00 TE:+0.00 STS:0  
J4: READY P:+4.7682 S:+0.000 C:+0.037 V:+48.2 TM:+37.72 TE:+31.69 STS:3 K\_tau:+0.0999 tau\_avg:+0.0360  
**J5: READY P:+6.1729 S:+0.000 C:+0.043 V:+48.0 TM:+35.11 TE:+26.92 STS:3 K\_tau:+0.1002 tau\_avg:+0.0262**

Tool: [???] DI:00 AI:0.0 A2:0.0 C:+0.00 mA V:+0.00  
Safety Control Board: DI:00000000 DO:00000000 AI1:0.0 AI2:0.0 A01:0.0 A02:0.0  
Safety Control Board: STATE: **Power on** MV:+48.2 RV:+48.3 CR:+0.79 mA CIO:+0.22 mA T:+33.58

General Move Calibration Firmware **Joint ID**


Set ID of current joint to **3**  
☐ Exchange IDs

**Change ID of joint?**  
Change ID of joint 5 to 3?  
**Change ID** Cancel

**Set it**

**STOP!** ☐ Follow last line **Back**

#### 11. After you have turned power on you can see the joint J5 has changed to J3.



J0: READY P:+1.3390 S:+0.000 C:-0.004 V:+48.1 TM:+31.21 TE:+29.18 STS:3 K\_tau:+0.1266 tau\_avg:+0.1131  
J1: READY P:+4.9260 S:+0.000 C:+0.007 V:+48.1 TM:+31.72 TE:+29.68 STS:3 K\_tau:+0.1267 tau\_avg:+0.1348  
J2: READY P:+1.3800 S:-0.000 C:-0.000 V:+48.1 TM:+32.17 TE:+29.22 STS:3 K\_tau:+0.1274 tau\_avg:+0.1475  
**J3: READY P:+4.6020 S:+0.000 C:+0.018 V:+48.1 TM:+35.64 TE:+27.33 STS:3 K\_tau:+0.1002 tau\_avg:+0.0262**  
J4: READY P:+4.7683 S:+0.000 C:+0.012 V:+48.2 TM:+38.06 TE:+32.62 STS:3 K\_tau:+0.0999 tau\_avg:+0.0360  
**J5: POWER OFF P:+6.1728 S:+0.000 C:+0.037 V:+48.1 TM:+35.25 TE:+27.13 STS:0**

Tool: [???] DI:00 AI:0.0 A2:0.0 C:+0.00 mA V:+0.00  
Safety Control Board: DI:00000000 DO:00000000 AI1:0.0 AI2:0.0 A01:0.0 A02:0.0  
Safety Control Board: STATE: **Power on** MV:+48.3 RV:+48.3 CR:+0.86 mA CIO:+0.22 mA T:+33.32


General Move Calibration Firmware **Joint ID**

Go to Idle **Turn power off** Arm current joint

**STOP!** ☐ Follow last line **Back**

### 3.1.18 Joint spare part adaptation

The UR5 and UR10 are constructed of 4 joint sizes and have to be setup on the robot:

Recommended spare joints for UR5 and UR10 are marked with: 


#### Robot:

#### UR5


#### UR10

Wrist 3: ID =5 Size 1\*

Alignment screw




Size 2




Wrist 2: ID =4 Size 1




Size 2




Wrist 1: ID =3 Size 1




Size 2




Elbow: ID =2 Size 3\*




Size 3




Shoulder: ID =1 Size 3




Size 4





Base: ID =0 Size 3\*



Size 4



Wires under/over bracket



\* Using a joint size in a different location i.e. UR5 base as UR5 Elbow, it may be necessary to change ID, connect all joints electrically, turn the joint 180 degrees in low level control by using the Move tap's Up/Down function, before mechanical assemble the robot. The robot then needs to be zero positioned or dual robot calibrated - [3.1.15 Instructions for calibrating a joint](#)

## 3.2 Controller

### 3.2.1 Handling ESD-sensitive parts




To prevent damage to ESD-sensitive parts, follow the instructions below in addition to all the usual precautions, such as turning off power before removing logic cards:



**Keep the ESD-sensitive part in its original shipping container.**

(a special "ESD bag") until the part is ready to be installed




**Put the ESD wrist strap on your wrist. Connect the wrist band to the system ground point.**

This discharges any static electricity in your body to ground.




**Step 1:**

**Put OLD board into spare ESD bag.**




**Step 2:**

**Take NEW board out of ESD bag.**



Hold the ESD-sensitive part by its edges;  
**do not touch its pins.**


If a pluggable module is being removed, then  
use the correct tool.





**Do not** place the ESD-sensitive part on nonconductive material or on a metal table.


If the ESD-sensitive part needs to be put down for any reason, then first put it into its special ESD bag



**Machine covers and metal tables are electrical grounds. They increase the risk of damage**

because they make a discharge path from your body through the ESD-sensitive part. (Large metal objects can be discharge paths without being grounded.)





Prevent ESD-sensitive parts from being accidentally touched by other personnel and do not put unprotected ESD-sensitive parts on a table.

**Be extra careful in working with ESD-sensitive parts when cold-weather and heating is used**, because low humidity increases static electricity.



## 3.2.2 Replacement of motherboard 3.0


Take care of ESD handling [3.2.1 Handling ESD-sensitive parts](#)

Motherboard 3.0 uses flash memory card.


Motherboard 3.1 uses USB memory stick.



1. Shut down the controller and disconnect the power cable, open the controller cabinet and loosen the 3 Torx screws




2. Remove the aluminum cover plate






3. Disconnect cable connections from motherboard:
1. White plug with white, brown, yellow and green wires. 12 V Power
  2. Black USB cable for TP USB connector
  3. Ethernet cable to external connector
  4. Ethernet cable to Safety control board SCB
  5. DVI-cable for TP screen
  6. Black cable for RS232-connection for TP touch



12. Remove the 4 screws from the 2 holding brackets



**NB! Ethernet cable to Safety Control Board**



13. Replace Motherboard with new one
14. If controller is equipped with long-hole brackets, make sure to replace them with circular-hole brackets. Tighten the 4 screws gently
15. Insert the 6 cables in correct positions. Special attention on the **Ethernet cable to the Safety Control Board. It must be connected to the right connector on the mother board**
16. Re-install Flash card and RAM block
17. Carefully put back the grey aluminum cover plate, make sure to mount it correct and fix it with the 3 screws
18. Connect power and verify that teach pendant works properly

### 3.2.3 Replacement of motherboard 3.1


Take care of ESD handling [3.2.1 Handling ESD-sensitive parts](#)

Motherboard 3.0 uses flash memory card.


Motherboard 3.1 uses USB memory stick.



1. Shut down the controller and disconnect the power cable, open the controller cabinet and loosen the 3 Torx screws




2. Remove the aluminum cover plate







3. Disconnect cable connections from motherboard:
  1. White plug with white, brown, yellow and green wires. 12 V Power
  2. DVI-cable for TP screen
  3. Ethernet cable to Safety control board SCB
  4. Ethernet cable to external connector
  5. Black USB cable for TP USB connector
  6. Grey flat cable for RS232-connection for TP touch



4. Remove the 4 screws from the 2 holding brackets



5. Replace Motherboard.
6. Insert the 6 cables in correct connectors.



7. Re-install USB stick for UR system SW.
8. Carefully put back the aluminum cover plate, make sure to mount it correct and fix it with the 3 screws

### 3.2.4 Replacement of Safety Control Board


Take care of ESD handling [3.2.1 Handling ESD-sensitive parts](#)

How to replace Safety Control Board in Controller box




1. Check that the software on the robot is as new as the firmware version on the SCB.  
If the software on the robot is too old, then you get an error C203A0.

Find the SCB firmware ver. on the Ethernet connector.




Find the firmware versions in the “About” menu.


Shortcut to “About” is available from software version 3.2.18642



2. Shut down the controller and disconnect the power cable, open the controller cabinet  
Carefully remove all plugs and connectors




3. Loosen the 5 Torx screws and remove the aluminum cover.






4. Carefully remove all plugs and connectors



5. Remove 14 screws holding the Safety Control Board.



6. Replace Safety Control Board with new one and tighten the 14 screws to hold the board
7. Insert all connectors and plugs in correct positions.  
Eventually see section [5.4.1 Schematic overview](#)
8. Carefully attach the aluminum cover, make sure to mount it correct and fix it with the 5 screws.





### 3.2.5 Replacement of teach pendant

Take care of ESD handling [3.2.1 Handling ESD-sensitive parts](#)

Note: use the same procedure for power down and removing the aluminum cover plates as in chapter [3.2.2 Replacement of motherboard 3.0](#) or

[3.2.3 Replacement of motherboard 3.1](#) and [3.2.4 Replacement of Safety Control Board](#)

1. Disconnect 4 cables:
  1. Red plug with black cable
  2. Black DVI cable
  3. Black USB cable
  4. Black cable for RS232-connection to touchscreen



2. Remove the bracket (foot of the controller box) that holds the cable inlet and pull out the cables and plugs through this hole.



3. Replace teach pendant with new, insert cable in cable inlet and perform reconnection of all plugs and mounting of aluminum cover in reverse order to the above description.
4. Connect power and verify that teach pendant works properly.

### 3.2.6 Replacement of 48V power supply

Take care of ESD handling [3.2.1 Handling ESD-sensitive parts](#)

How to replace 48V power supply in Controller box


*Note: use the same procedure for power down and removing the aluminum cover plates as in chapter [3.2.2 Replacement of motherboard 3.0](#) or [3.2.3 Replacement of motherboard 3.1](#) and [3.2.4 Replacement of Safety Control Board](#)*




1. Remove the handle on Controller box by loosen the 2 screws holding it.




2. Removes the 2 wires for the energy eater/fan.



3. Remove the 2 nuts (M6) in the bottom of Controller module.





4. Gently take out the controller module from the Controller box without disconnecting the robot cable and power cable.
5. Power supplies are located in the rack under the controller module, the two 48V power supplies are the lower ones in the rack. (UR5 have one and the UR10 have two 48V power supplies)  
Before dismounting the 48V power supply, mark and disconnect the cables from that supply.





6. Remove the screws respectively of the defective 48V power supply from the side of the rack.



7. Replace 48V power supply with new one.
8. Reconnect the wires for the 48V power supply.
9. Re-install Controller module in reverse order and connect the 2 wires for the fan and cables for the teach pendant.
10. Carefully put back the grey aluminum cover plate, make sure to mount it correct and fix it with the screws.
11. Connect power and verify that teach pendant works properly.

### 3.2.7 Replacement of 12V power supply


Take care of ESD handling [3.2.1 Handling ESD-sensitive parts](#)

How to replace 12V power supply in Controller box

*Note: use the same procedure for power down and removing the aluminum cover plate and cables for teach pendant as in chapter [3.2.5 Replacement of teach pendant](#)*

To replace the 12V power supply follow exactly the same steps as for the procedure in chapter [3.2.6 Replacement of 48V power supply](#)

1. The 12V power supply is placed in top of rack. The screws holding it in the frame are placed on the sides.



2. Replace 12V power supply with new one.
3. Reconnect the wires for the 12V power supply.
4. Re-install Controller module in reverse order and connect the 2 wires for the fan and cables for the teach pendant.
5. Carefully put back the grey aluminum cover plate, make sure to mount it correct and fix it with the 5 screws.
6. Connect power and verify that teach pendant works properly.



### 3.2.8 Replacement of current distributor

Take care of ESD handling [3.2.1 Handling ESD-sensitive parts](#)

How to replace current distributor in Controller box


*Note: use the same procedure for power down and removing the aluminum cover plate and cables for teach pendant as in chapter [3.2.5 Replacement of teach pendant](#)*



1. Current distributor is placed on top of rack.



2. Before dismounting the current distributor, mark and disconnect the cables from the circuit board.



3. Replace current distributor with new one.
4. Reconnect the wires for the current distributor.
5. Re-install Controller module in reverse order and connect the 2 wires for the fan and cables for the teach pendant.
6. Carefully put back the grey aluminum cover plate, make sure to mount it correct and fix it with the 5 screws.
7. Connect power and verify that teach pendant works properly.

## 4. Software

### 4.1 Update software

Universal Robots software is named PolyScope.


**Read This Prior to Updating Your Software:**

**Updating the software may cause changes or restrictions to functionality.**

1. Do not downgrade the software to earlier version than the version the robot was produced with.
2. We advise you only to update, if you can benefit from the new features or the fixed issues.
3. We advise you to thoroughly read the release notes before doing an update, in order to avoid surprises, caused by changed or added functionality.
4. In case of concerns related to your actual or planned applications, please contact your supplier for advice and assistance.
5. Follow the instructions in the guide in the download section of the support web site.  
Find it under <http://universal-robots.com/support>

#### Instructions to update software:


1. Download software update. Carefully read requirements on support site relating to which software must be installed on robot prior to updating to the downloaded version.
2. Save it in the root folder on a USB-stick.
3. Insert USB-stick into USB-connector on right-hand side of teach pendant.
4. Go to main screen of PolyScope.




5. Press button *SETUP Robot*.



6. In left side menu, select *Update Robot*.



7. Press button *Search* for searching after software update on USB-stick.



8. Select the desired software update and press *UPDATE*.
9. Press YES to update the software.
10. Wait for update to complete, after successful update controller will automatically reboot.
11. Remove USB-stick and power on.

## 4.2 Update joint firmware

Each joint on the robot contains firmware to control the joint.

### Software version 3.1.16828 and newer:

When the software is updated on a robot the firmware is **automatically** updated.

After replacement of a joint on a robot the firmware is **automatically** updated.

### Software version before 3.1.16828:

#### IMPORTANT NOTICE:


19. When updating firmware controller power **MUST NOT** be turned off during update.
20. Universal Robots can by no means be held responsible for any failed update caused by improper operation.

Instructions for updating firmware:

Prior to updating firmware, robot software must be updated.

Please refer to chapter [4.1 Update software](#). When updating robot software, the firmware will automatically be copied to a folder on the controller.


1. Drag a finger from left to right across the *UNIVERSAL*-sign on main screen of PolyScope.




2. Enter password *lightbot* and press *OK*.




3. You are now in *Expert Mode*, press *Low Level Control*.



4. Press *Turn power on* to go into BOOTLOADER




5. Select the *Firmware* tab, mark All joints and press UPDATE Firmware.



6. Firmware update is being processed, await message that *robot firmware updated successfully*. Controller **MUST NOT** be powered off during this update.

7. After successful update, press *Back*.

8. Back in Expert Mode, press *Return to Normal*.



Firmware has now been updated.

## 4.3 Using Magic files

For easy backup, Universal Robots provides Magic files to automatically copy data from controller to USB-stick.

These files are available:

- URMagic log file
- URMagic backup programs
- URMagic configuration files
- URMagic upload programs
- URMagic screenshot

Function:

copies the entire log history file to USB-stick  
copies all programs and installation files to USB-stick  
copies all configuration files to USB-stick  
copies all programs and installation files *from* USB-stick  
generates a screenshot of GUI when USB-stick is inserted

Go to <http://www.universal-robots.com/support/> to download Magic files.

### Instruction for using Magic files.

1. Download Magic file.
2. Save it in the root folder on a USB-stick.  
If more than one Magic file is on USB-stick, they will be run in sequence; the warnings will then appear for each file. Do not remove the USB-stick until after the last file has been run. Multiple folders will be created and named with serial number plus a sequential no, like 201430xxxx\_0, 201430xxxx\_1etc.
3. Insert USB-stick into USB-connector on right-hand side of teach pendant.
4. After a few seconds a red **! USB !** -sign will appear on the screen, this is a warning not to remove the USB-stick, while the file will do its magic.
5. Await a green **<- USB** -sign appears on the screen, if there is more than one Magic file on the USB-stick then go to 4.
6. After the last Magic file is completed the USB-stick can be safely removed.
7. Remove USB-stick and the process is complete.

The Magic file creates a folder on USB-stick named with the serial number of the robot.

## 5. Troubleshooting

In the error codes different words have been used for the same thing:

- On the Safety Control Board: Processor A = A uP = SafetySys1
- On the Safety Control Board: Processor B = B uP = SafetySys2

PSU = Power Supply

PC = Controller

Open log files with Support Log Reader.

Go to <http://www.universal-robots.com/support/> to download Support Log Reader

### 5.1 Error codes

Code	Error description	Explanation	How to fix
<b>C0</b>	No error		
<b>C1</b>	Outbuffer overflow error		
<b>C1A1</b>	Buffer of stored warnings overflowed		
<b>C1A2</b>	Outbuffer to RS485 overflowed (problem with PCs message)		
<b>C2</b>	Inbuffer overflow error		
<b>C3</b>	Processor overloaded error	Processor in any part could give this error.	
<b>C4</b>	Broken communication		
<b>C4A1</b>	Communication with PC lost.	Between Safety Control Board and Motherboard	
<b>C4A2</b>	Communication with Safety Control Board A uP lost	If either processor A or processor B is communicating, the Safety Control Board or cable between the Motherboard and Safety Control Board is defect	a) Check TCP/IP connection between Motherboard and Safety Control Board. B) Exchange Safety Control Board
<b>C4A3</b>	Communication with Safety Control Board B uP lost	If either processor A or processor B is communicating, the Safety Control Board or cable between the Motherboard and Safety Control Board is defect	a) Check TCP/IP connection between Motherboard and Safety Control Board. B) Exchange Safety Control Board
<b>C4A4</b>	Communication with primary Teach Pendant uP lost	If either processor A or processor B is communicating, the Teach Pendant or cable between the Motherboard and Teach Pendant is defect	a) Check RS485-12V connection between Motherboard and Teach Pendant. B) Exchange Teach Pendant
<b>C4A5</b>	Communication with secondary Teach Pendant uP lost	If either processor A or processor B is communicating, the Teach Pendant or cable between the Motherboard and Teach Pendant is defect	a) Check RS485-12V connection between Motherboard and Teach Pendant. B) Exchange Teach Pendant

<b>C4A6</b>	Communication with primary EUROMAP67 uP lost	If either processor A or processor B is communicating, Euromap67 or cable between the Motherboard and Euromap is defect	a) Check Euromap67 connection between Motherboard and Euromap67. B) Exchange Euromap67
<b>C4A7</b>	Communication with secondary EUROMAP67 uP lost	If either processor A or processor B is communicating, Euromap67 or cable between the Motherboard and Euromap is defect	a) Check Euromap67 connection between Motherboard and Euromap67. B) Exchange Euromap67
<b>C4A8</b>	Primary EUROMAP67 uP present, but euromap67 is disabled	Incorrect safety configuration	Update the miscellaneous settings in the Safety Configuration
<b>C4A9</b>	Secondary EUROMAP67 uP present, but euromap67 is disabled	Incorrect safety configuration	Update the miscellaneous settings in the Safety Configuration
<b>C4A10</b>	Primary Teach Pendant present, but Teach Pendant safety is disabled	Incorrect safety configuration	Update the miscellaneous settings in the Safety Configuration
<b>C4A11</b>	Secondary Teach Pendant uP present, Teach Pendant safety is disabled	Incorrect safety configuration	Update the miscellaneous settings in the Safety Configuration
<b>C4A12</b>	Communication with joint 0 lost	More than 1 package lost	
<b>C4A13</b>	Communication with joint 1 lost	More than 1 package lost	
<b>C4A14</b>	Communication with joint 2 lost	More than 1 package lost	
<b>C4A15</b>	Communication with joint 3 lost	More than 1 package lost	
<b>C4A16</b>	Communication with joint 4 lost	More than 1 package lost	
<b>C4A17</b>	Communication with joint 5 lost	More than 1 package lost	
<b>C4A18</b>	Communication with tool lost	More than 1 package lost	
<b>C4A65</b>	Lost package from Primary Teach Pendant	1 package lost – warning	
<b>C4A66</b>	Lost package from Secondary Teach Pendant	1 package lost – warning	
<b>C4A67</b>	Lost package from Primary Euromap67	1 package lost – warning	
<b>C4A68</b>	Lost package from Secondary Euromap67	1 package lost – warning	
<b>C4A69</b>	Lost package from Secondary Masterboard	1 package lost – warning	
<b>C4A70</b>	Lost package from joint 0	1 package lost – warning	
<b>C4A71</b>	Lost package from joint 1	1 package lost – warning	
<b>C4A72</b>	Lost package from joint 2	1 package lost – warning	
<b>C4A73</b>	Lost package from joint 3	1 package lost – warning	
<b>C4A74</b>	Lost package from joint 4	1 package lost – warning	
<b>C4A75</b>	Lost package from joint 5	1 package lost – warning	

<b>C4A76</b>	Lost package from tool	1 package lost – warning
<b>C4A77</b>	Lost package from uPA to joints	1 package lost – warning
<b>C4A78</b>	Lost package from uPA to teach pendant	1 package lost – warning
<b>C4A79</b>	Lost package from uPA to uPB	1 package lost – warning
<b>C4A80</b>	Lost package from uPB	1 package lost – warning
<b>C4A81</b>	Packet counter disagreement in packet from Primary Screen	Safety processor 1 in Teach pendant has a packet disagreement
<b>C4A82</b>	Packet counter disagreement in packet from Secondary Screen	Safety processor 2 in Teach pendant has a packet disagreement
<b>C4A83</b>	Packet counter disagreement in packet from Primary Euromap67	
<b>C4A84</b>	Packet counter disagreement in packet from Secondary Euromap67	
<b>C4A85</b>	Packet counter disagreement in packet from Safety Control Board B	
<b>C4A86</b>	Packet counter disagreement in packet from joint 0	
<b>C4A87</b>	Packet counter disagreement in packet from joint 1	
<b>C4A88</b>	Packet counter disagreement in packet from joint 2	
<b>C4A89</b>	Packet counter disagreement in packet from joint 3	
<b>C4A90</b>	Packet counter disagreement in packet from joint 4	
<b>C4A91</b>	Packet counter disagreement in packet from joint 5	
<b>C4A92</b>	Packet counter disagreement in packet from tool	
<b>C4A93</b>	Packet counter disagreement in packet from processor A to joints	
<b>C4A94</b>	Packet counter disagreement in packet from processor A to B	
<b>C4A95</b>	Packet counter disagreement in packet from processor A to Teach Pendant and EUROMAP	
<b>C5</b>	Heavy processor load warning	
<b>C5A1</b>	Heavy processor load warning:1	
<b>C5A2</b>	Heavy processor load warning:2	



<b>C10</b>	Broken PC communication error		Eventually update the software
<b>C10A1</b>	Lost packet from PC		Eventually update the software
<b>C10A101</b>	PC packet received too early		Eventually update the software
<b>C10A102</b>	Packet counter does not match		Eventually update the software
<b>C10A103</b>	PC is sending packets too often		Eventually update the software
<b>C11</b>	Bad CRC error	Serial communication problem with joint	Check black 2-wire connectors and wires in joints. Eventually 2 joints with the same ID.
<b>C12</b>	Unknown message error		
<b>C14</b>	Debug message		
<b>C14A1</b>	{float}	Should not occur in the field	Do you see this error on a robot report it to Universal Robots.
<b>C14A2</b>	{signed}	Should not occur in the field	Do you see this error on a robot report it to Universal Robots.
<b>C14A3</b>	{unsigned}	Should not occur in the field	Do you see this error on a robot report it to Universal Robots.
<b>C17</b>	Inbuffer overflow in package from PC	Communication error between Safety Control Board and Motherboard	Check Ethernet connection between circuit boards. Eventually update the software
<b>C26</b>	Motor Encoder index drift detected	Joint mechanical problem	Replace joint
<b>C27</b>	Calibration data is invalid or does not exist, selftest is needed!		
<b>C29</b>	Online Calibration data checksum failed	Calibration data is not in the joint	a) Power OFF and Power ON. B) replace joint
<b>C30</b>	Master received data from too many joints		
<b>C31</b>	Caught wrong message (not from master)	Serial communication problem with joint	Check black 2-wire connectors and wires in joints
<b>C32</b>	Flash write verify failed	Debug message	Ignor
<b>C33</b>	Calibration flash checksum failed		
<b>C34</b>	Program flash checksum failed		Update Firmware
<b>C34A0</b>	Program flash checksum failed during bootloading		Update Firmware
<b>C34A1</b>	Program flash checksum failed at runtime		Update Firmware
<b>C35</b>	Joint ID is undefined		
<b>C36</b>	Illegal bootloader command	Debug message	Ignore

<b>C37</b>	Inbuffer parse error	Serial communication problem with joint	Check black 2-wire connectors and wires in joints
<b>C38</b>	Online RAM test failed		Replace Item
<b>C38A1</b>	Data-bus test failed		Replace Item
<b>C38A2</b>	Address-bus stuck-high test failed		Replace Item
<b>C38A3</b>	Address-bus stuck-low test failed		Replace Item
<b>C38A4</b>	Address-bus shorted test failed		Replace Item
<b>C38A5</b>	Memory-cell test failed		Replace Item
<b>C39</b>	Logic and Temporal Monitoring Fault		
<b>C39A1</b>	Max current deviation failure		The joint is broken; it must be replaced
<b>C39A2</b>	Max joint-encoder speed exceeded		The joint is broken; it must be replaced
<b>C39A3</b>	Max motor-encoder speed exceeded		The joint is broken; it must be replaced
<b>C39A4</b>	Illegal state change in joint detected		If this error occurs several times, report it as a bug
<b>C39A5</b>	Too fast state change in joint detected		If this error occurs several times, report it as a bug
<b>C39A6</b>	5V regulator voltage too low		Replace joint
<b>C39A7</b>	5V regulator voltage too high		Replace joint
<b>C39A100</b>	Watchpoint fault: ADC task timeout		
<b>C39A101</b>	Watchpoint fault: Motor-Control task timeout		
<b>C39A102</b>	Watchpoint fault: Motor-encoder task timeout		
<b>C39A103</b>	Watchpoint fault: Joint-encoder task timeout		
<b>C39A104</b>	Watchpoint fault: Communication task timeout		
<b>C39A105</b>	Watchpoint fault: RAM-test task timeout		
<b>C39A106</b>	Watchpoint fault: CalVal-test task timeout		
<b>C39A107</b>	Watchpoint fault: ROM-test task timeout		
<b>C40</b>	AD-Converter hit high limit joint	EMC issue external or electronics internal	Check grounding and shielding for EMC problems
<b>C44</b>	CRC check failure on primary bus	Serial communication problem with joint or secondary bus node	Check black 2-wire connectors and wires in joints
<b>C44A0</b>	Joint 0 CRC check failure on primary bus	Serial communication problem with joint or secondary bus node	Replace joint 0

<b>C44A1</b>	Joint 1 CRC check failure on primary bus	Serial communication problem with joint or secondary bus node	Replace joint 1
<b>C44A2</b>	Joint 2 CRC check failure on primary bus	Serial communication problem with joint or secondary bus node	Replace joint 2
<b>C44A3</b>	Joint 3 CRC check failure on primary bus	Serial communication problem with joint or secondary bus node	Replace joint 3
<b>C44A4</b>	Joint 4 CRC check failure on primary bus	Serial communication problem with joint or secondary bus node	Replace joint 4
<b>C44A5</b>	Joint 5 CRC check failure on primary bus	Serial communication problem with joint or secondary bus node	Replace joint 5
<b>C44A6</b>	Tool CRC check failure on primary bus	Serial communication problem with tool or secondary bus node	Replace Tool mounting bracket
<b>C44A80</b>	CRC Check failure on primary bus	Most likely an interference on the communication bus	a) Check green 2-wire connectors and wires in joints, b) If the error reappears contact your local service provider for assistance.
<b>C45</b>	AD-Converter error		Replace Item
<b>C46</b>	Loose gearbox or bad encoder mounting	Mechanical problem in gear related to encoder mounting	Replace joint
<b>C47</b>	AD-Converter hit low limit	EMC issue external or electronics internal	a) Check grounding and shielding for EMC problems. B) Replace Item
<b>C48</b>	Powerbus voltage drop detected.	Error on 48V powerbus to robot arm	Check 48V output from PSU. Check current-distributor PCB. Replacement of 48V PSU or current-distributor is necessary
<b>C49</b>	RS485 receive warning		
<b>C49A200</b>	Secondary RS485 bus is down	Bus for: Teach Pendant, Processor A and Processor B on the Safety Control Board.	Check TCP/IP-12V cable to Teach Pendant
<b>C50</b>	Robot powerup failure	Electrical error control box	Remove all external connections to I/O-interface of Safety Control Board. Check for short circuit. Argument of error code specifies in detail what causes the error.
<b>C50A1</b>	Voltage detected at 24V rail before startup		
<b>C50A2</b>	Voltage present at unpowered robot		

<b>C50A5</b>	Powersupply voltage too low		
<b>C50A6</b>	Powersupply voltage too high		
<b>C50A11</b>	Voltage not detected at 24V rail after startup	24 V to the I/O interface in the controller	
<b>C50A15</b>	Warning, waiting for SafetySYS2	SafetySYS2 = Processor B on Safety Control Board	
<b>C50A16</b>	The Teach Pendant does not respond	Loose wire or incorrect safety configuration. Message comes from Safety Control Board	Check the cable or change in the Safety Configuration of the Installation the miscellaneous settings
<b>C50A17</b>	The Euromap67 interface does not respond	Loose wire or incorrect safety configuration	Check the cable or change in the Safety Configuration of the Installation the miscellaneous settings
<b>C50A18</b>	Warning, waiting for SafetySYS1	SafetySYS1 = Processor A on Safety Control Board	
<b>C50A20</b>	5V, 3V3 or ADC error (5V too high)		
<b>C50A21</b>	5V, 3V3 or ADC error (5V too low)		
<b>C50A22</b>	Robot current sensor reading too high		
<b>C50A23</b>	Robot current sensor reading too low		
<b>C50A24</b>	48V not present (Check internal connection)  This error can have several root causes and you have to measure the voltage some places. There are 3 different components that could be the root cause and you have to measure the voltage to determine which one of them that is the faulty one. - 48 V power supply - Current distributor - Safety Control Board. Find the schematic drawing in this service manual		
<b>C50A25</b>	Robot voltage present at 48V PSU powereup		
<b>C50A26</b>	Voltage present on unpowered 48V power supply		
<b>C50A27</b>	12V, 3V3 or ADC error (12V too high)		
<b>C50A28</b>	12V, 3V3 or ADC error (12V too low)		
<b>C50A29</b>	Analog I/O error (-12V too high)		
<b>C50A30</b>	Analog I/O error (-12V too low)		
<b>C50A31</b>	The other safetySYS do not initialize		
<b>C50A40</b>	Wrong voltage from PSU1		
<b>C50A41</b>	Wrong voltage from PSU2		
<b>C50A42</b>	Voltage will not disappear from PSU		

<b>C50A43</b>	Warning, waiting for CB2 type answer from primary processor		
<b>C50A50</b>	Processor A 3.3V supply voltage out of bounds		
<b>C50A51</b>	Robot voltage below threshold		
<b>C50A52</b>	Robot voltage above threshold		
<b>C50A53</b>	58V generator deviation error		
<b>C50A54</b>	5V regulator too low		
<b>C50A55</b>	5V regulator too high		
<b>C50A56</b>	-4V generator too low		
<b>C50A57</b>	-4V generator too high		
<b>C50A80</b>	Last CPU reset caused by Low-Power-Reset		
<b>C50A81</b>	Last CPU reset caused by Window-Watchdog-Reset		
<b>C50A82</b>	Last CPU reset caused by Independent-Watchdog-Reset		
<b>C50A83</b>	Last CPU reset caused by Software-Reset		
<b>C50A84</b>	Last CPU reset caused by External-Pin-Reset		
<b>C50A85</b>	Last CPU reset caused by Brown-Out-Reset		
<b>C50A99</b>	Wrong software on PCB		
<b>C50A100</b>	Cable not connected	Robot Problem: Robot Cable is not detected	
<b>C50A101</b>	Short circuit in robot detected or wrong robot connected to control box	Robot Problem: 48V or wrong robot type	Check robot type. Look for short circuit in cable and in robot arm.
<b>C50A102</b>	Voltage rising too slowly	Robot Problem: 48V	
<b>C50A103</b>	Voltage failed to reach acceptable level	Robot Problem: 48V	
<b>C51</b>	CRC check failure on secondary bus		
<b>C51A0</b>	Processor B		
<b>C51A1</b>	Primary screen processor	CRC check failure on Safety processor 1 in Teach pendant	
<b>C51A2</b>	Secondary screen processor	CRC check failure on Safety processor 2 in Teach pendant	
<b>C51A3</b>	Primary E67		
<b>C51A4</b>	Secondary E67		
<b>C53</b>	IO overcurrent detected	Safety Control Board error	Remove all external connections to I/O-interface of Safety Control Board. Check for short circuit
<b>C53A1</b>	IO overcurrent detected, max is 800mA	Safety Control Board error	Remove all external connections to I/O-interface of Safety Control Board. Check for short circuit

<b>C53A2</b>	IO overcurrent detected, max is 600mA	Tool error	Remove tool connector. Check for short circuit
<b>C55</b>	Safety system error	Safety system malfunction	Check Motherboard, Safety Control Board, Screenboard, Current distributor (Euromap, if installed). Bypass safety connections to I/O-interface of Safety Control Board
<b>C55A23</b>	Safety relay error (minus connection)	Current distributor error	Fault: Cable SCB-Current distributor or 48V Power supply or Current distributor.
<b>C55A24</b>	Safety relay error (plus connection)	Current distributor error	Fault: Cable SCB-Current distributor or 48V Power supply or Current distributor.
<b>C55A33</b>	Safety relay error (a relay is stuck)	Current distributor error	Fault: Cable SCB-Current distributor or 48V Power supply or Current distributor.
<b>C55A34</b>	Safety relay error (relays are not on)	Current distributor error	Fault: Cable SCB-Current distributor or 48V Power supply or Current distributor.
<b>C55A50</b>	Voltage present at unpowered robot	SCB hardware fault	Replace Safety Control Board (SCB)
<b>C55A51</b>	Voltage will not disappear from robot	SCB hardware fault	Replace Safety Control Board (SCB)
<b>C55A52</b>	5V, 3V3 or ADC error (5V too low)	SCB hardware fault	Replace Safety Control Board (SCB)
<b>C55A53</b>	5V, 3V3 or ADC error (5V too high)	SCB hardware fault	Replace Safety Control Board (SCB)
<b>C55A90</b>	Bootloader error, robot voltage too low or current too high		
<b>C55A91</b>	Bootloader error, robot voltage too high		
<b>C55A100</b>	Safety violation		
<b>C55A101</b>	Safety Channel Error In Safety Control Board		
<b>C55A102</b>	Safety Channel Error In Screen		
<b>C55A103</b>	Safety Channel Error In Euromap67 Interface		
<b>C55A109</b>	Received fault message from PC		
<b>C55A110</b>	Safety State is changing too often		
<b>C55A111</b>	On/Off State is changing too often		

<b>C55A112</b>	Robot current sensors readings differ		
<b>C55A120</b>	Robot current is too high while emergency stopped		
<b>C55A121</b>	Robot current is too high while safeguard stopped		
<b>C56</b>	Overvoltage shutdown	Voltage exceeded 55V	Check Energy Eater. Cable to Energy eater, Replace Energy Eater
<b>C57</b>	Brake release failure		Check Brake, solenoid, Payload, TCP and Mount
<b>C57A1</b>	Joint did not move or motor encoder is not functioning		Check Brake, solenoid, Payload, TCP and Mount
<b>C57A2</b>	Large movement detected during brake release		Check Brake, solenoid, Payload, TCP and Mount
<b>C57A3</b>	Robot was not able to brake release, see log for details		Check Brake, solenoid, Payload, TCP and Mount
<b>C58</b>	Motor encoder not calibrated		Calibrate joint
<b>C59</b>	Overcurrent shutdown	Overcurrent in joint. Argument = Current in Amps.	Check for short circuit. Check program for singularity issues. Replace joint if necessary
<b>C62</b>	Joint temperature		
<b>C62A1</b>	High (80 C)	Warning	
<b>C62A3</b>	Static load too high warning	Warning	
<b>C62A11</b>	Shut down (85 C)	Stop	
<b>C62A13</b>	Static load too high	Stop	Check Payload
<b>C63</b>	Selftest failed		
<b>C68</b>	SPI error	Joint: Absolut encoder on joint communication error	Replace joint
<b>C70</b>	Close to gearbox shear limit	Acceleration / deceleration to high. Mechanical problem in gear related to encoder mounting	Reduce acceleration in user program. Replace joint if necessary
<b>C71</b>	Startup check error	Fault: Firmware in joint	
<b>C71A1</b>	Hardware is size1, software is not	Fault: Firmware in joint	
<b>C71A2</b>	Hardware is size2, software is not	Fault: Firmware in joint	
<b>C71A3</b>	Hardware is size3, software is not	Fault: Firmware in joint	
<b>C71A4</b>	Hardware is size4, software is not	Fault: Firmware in joint	
<b>C71A5</b>	Invalid hardware size read		
<b>C71A6</b>	Motor indication signal not working		
<b>C71A7</b>	Phase 1 and phase 2 not working	The motor wires are damaged, bad connection in screw terminals or defect PCB	Replace joint (Replace PCB)



<b>C71A8</b>	Phase 2 not working	The motor wires are damaged, bad connection in screw terminals or defect PCB	Replace joint (Replace PCB)
<b>C71A9</b>	Phase 1 not working	The motor wires are damaged, bad connection in screw terminals or defect PCB	Replace joint (Replace PCB)
<b>C71A10</b>	Invalid motor test result		
<b>C71A11</b>	ADC calibration failed	Only in joint	
<b>C71A12</b>	Phase 3 not working in joint failed	The wire is (1) damaged or (2) has been disconnected from the PCB (not likely) or (3) defect PCB	Replace the joint
<b>C71A50</b>	Current sensor test failed	Sensor reported wrong current when probed	Replace the joint. Defect Printed circuit board
<b>C71A51</b>	Current sensor test failed	Sensor reported wrong current when probed	Replace the joint. Defect Printed circuit board
<b>C71A52</b>	Current sensor test failed	Sensors reported different currents when probed	Replace the joint. Defect Printed circuit board
<b>C72</b>	Power Supply Unit failure	48 V Power problem	
<b>C72A1</b>	0 PSUs are active	PSU was not able to deliver 48V (In UR10: No 48V)	Check power connection between power supply and Safety Control Board
<b>C72A2</b>	1 PSU active, but we expect 2 (UR10)	PSU was not able to deliver 48V or UR10 flash card in UR5 robot	Check power connection between power supply and Safety Control Board and check that the flash card and robot match
<b>C72A3</b>	2 PSUs active, but we expect 1 (UR5)	UR5 flash card in UR10 robot	Check that the flash card and robot match
<b>C73</b>	Brake test failed during selftest, check brakepin		
<b>C74</b>	Joint encoder warning	Magnetic encoder error (Absolut encoder)	
<b>C74A1</b>	Invalid decode: Readhead misalignment, ring damaged or external magnetic field present.	Warning: The argument is the sum of C74 errors	
<b>C74A2</b>	Speed reading is not valid	Warning: The argument is the sum of C74 errors	
<b>C74A4</b>	System error=malfunction or inconsistent calibration detected	Warning: The argument is the sum of C74 errors	
<b>C74A8</b>	Supply voltage is out of range	Warning: The argument is the sum of C74 errors	
<b>C74A16</b>	Temperature is out of range	Warning: The argument is the sum of C74 errors	
<b>C74A64</b>	Signal low =Too far from magnetic ring	Warning: The argument is the sum of C74 errors	
<b>C74A128</b>	Signal saturation =Too close to magnetic ring	Warning: The argument is the sum of C74 errors	

<b>C74A207</b>	Joint encoder error	Example: Argument 207 is the sum of 128,64,8,4,2,1 which means that all the errors in connection to argument 1, 2, 4, 8, 64 and 128 have been reported.	Example.
<b>C75</b>	Joint encoder error	Magnetic encoder error (Absolut encoder)	
<b>C75A1</b>	Invalid decode: Readhead misalignment, ring damaged or external magnetic field present.	Error: The argument is the sum of C75 errors	Replace joint
<b>C75A2</b>	Speed reading is not valid	Error: The argument is the sum of C75 errors	Replace joint
<b>C75A4</b>	System error=malfunction or inconsistent calibration detected	Error: The argument is the sum of C75 errors	Replace joint
<b>C75A8</b>	Supply voltage is out of range	Error: The argument is the sum of C75 errors	Check previous error
<b>C75A16</b>	Temperature is out of range	Error: The argument is the sum of C75 errors	Check previous error
<b>C75A32</b>	Signal lost =Misaligned readhead or damaged ring	Error: The argument is the sum of C75 errors	Replace joint
<b>C75A64</b>	Signal low =Too far from magnetic ring	Error: The argument is the sum of C75 errors	Replace joint
<b>C75A128</b>	Signal saturation =Too close to magnetic ring	Error: The argument is the sum of C75 errors	Replace joint
<b>C75A207</b>	Joint encoder error	Example: Argument 207 is the sum of 128,64,8,4,2,1 which means that all the errors in connection to argument 1, 2, 4, 8, 64 and 128 have been reported.	Example
<b>C76</b>	Joint encoder communication CRC error	Error between sensor and joint circuit	Check connections or very heavy electrical noise
<b>C77</b>	Sudden position change detected on the joint-encoder	The position reading from the encoder was different than expected	
<b>C78</b>	Large sudden position change detected on the joint-encoder	The position reading from the encoder was severely different than expected, the latest measurement was discarded	Contact your local service provider for assistance
<b>C78A255</b>	Large sudden position change detected on the joint-encoder	The argument 255 is a number that relates to the size of the position change. In other words this can be treated as a C78 error.	Example.
<b>C80A51</b>	Window watchdog reset		
<b>C100</b>	Robot changed mode	Status warning, general modus change	Check preceding errors in log history
<b>C101</b>	Real Robot Connected		

<b>C102</b>	Real Robot not connected – Simulating Robot		
<b>C103</b>	UR Ethernet Error	Comm. Prob. Between Mother Board and Safety Control Board	Check cable
<b>C103A1</b>	Connection to Safety Control Board lost	PC did not receive 3 packets in a row	Check that the Ethernet cable between PC board and Safety Control Board is connected and restart system
<b>C103A2</b>	Package lost from Safety Control Board		
<b>C104</b>	Error=Empty command sent to robot		
<b>C111</b>	Something is pulling the robot		Check Payload setting
<b>C115</b>	Unknown robot type	The robot type specified in the configuration is unknown	
<b>C116</b>	Realtime part warning	Possible CPU-overload due to structure of user program	Restructure user program
<b>C117</b>	Restart SCB failed	The Safety Control Board couldn't be rebooted from the controller.	Reboot the robot
<b>C150</b>	Protective Stop: Position close to joint limits		
<b>C151</b>	Protective Stop: Tool orientation close to limits		
<b>C152</b>	Protective Stop: Position close to safety plane limits		
<b>C153</b>	Protective Stop: Position deviates from path		
<b>C154</b>	Protective Stop: Position in singularity	Robot cannot move linear in a singularity	Use jointspace movement or change the motion
<b>C155</b>	Protective Stop: Robot cannot maintain its position, check if payload is correct		
<b>C156</b>	Protective Stop: Wrong payload or mounting detected, or something is pushing the robot when entering Freedrive mode	The robot may move unexpected due to wrong settings	Verify that the TCP configuration and mounting in the used installation is correct
<b>C160</b>	Protective stop: The robot was powered off last time due to a joint position disagreement	1. Verify that the robot position in the 3D graphics matches the real robot, to ensure that the encoders function before releasing the brakes. Stand back and monitor the robot performing its first program cycle as expected. 2. If the position is not correct, the robot must be repaired. In	

		<p>this case, click “Power Off Robot”.</p> <p>3. If the position is correct, please tick the check box below the 3D graphics and click “Robot Position Verified”</p>	
<b>C161</b>	Protective stop: Large movement of the robot detected while it was powered off. The joints were moved while it was powered off, or the encoders do not function.	<p>1. Verify that the robot position in the 3D graphics matches the real robot, to ensure that the encoders function before releasing the brakes. Stand back and monitor the robot performing its first program cycle as expected.</p> <p>2. If the position is not correct, the robot must be repaired. In this case, click “Power Off Robot”.</p> <p>3. If the position is correct, please tick the check box below the 3D graphics and click “Robot Position Verified”</p>	
<b>C171</b>	Issue with blends		
<b>C171A0</b>	A MoveC-waypoint were skipped due to a blend.	The value for the blend radius is too large compared to the distance between the waypoints.	Decrease the blend radius or choose waypoints that are further apart.
<b>C171A1</b>	Blend radius too small in a MoveC		
<b>C171A3</b>	A ServoC-waypoint were skipped due to a blend.	The value for the blend radius is too large compared to the distance between the waypoints.	Decrease the blend radius or choose waypoints that are further apart.
<b>C171A4</b>	Overlapping Blends in a MoveJ, a waypoint was skipped		
<b>C171A5</b>	Overlapping Blends in a MoveJ, a waypoint was skipped		
<b>C171A6</b>	Overlapping Blends in a MoveJ, a waypoint was skipped		
<b>C171A7</b>	Overlapping Blends in a MoveJ, a waypoint was skipped		
<b>C171A9</b>	A MoveP-waypoint were skipped due to a blend.	The value for the blend radius is too large compared to the distance between the waypoints.	Decrease the blend radius or choose waypoints that are further apart.

<b>C171A10</b>	Blend radius too small error in a MoveP		
<b>C171A11</b>	Overlapping Blends in a MoveL, a waypoint was skipped		Decrease the blend radius or choose waypoints that are further apart.
<b>C171A12</b>	Overlapping Blends in a MoveL, a waypoint was skipped		Decrease the blend radius or choose waypoints that are further apart.
<b>C171A13</b>	Overlapping Blends in a MoveL, a waypoint was skipped		Decrease the blend radius or choose waypoints that are further apart.
<b>C171A14</b>	Overlapping Blends in a MoveL, a waypoint was skipped		Decrease the blend radius or choose waypoints that are further apart.
<b>C172</b>	Illegal control mode		
<b>C184</b>	Joint self test not received by controller		
<b>C185A1</b>	START_NORMAL_OPERATION is not allowed on selftest firmware		
<b>C185A2</b>	GOTO_BACKDRIVE_COMMAN D is not allowed on selftest firmware		
<b>C186A1</b>	joint_mode == JOINT_RUNNING_MODE is not allowed on selftest firmware		
<b>C191</b>	Safety system violation		
<b>C191A1</b>	Joint position limit violated		
<b>C191A2</b>	Joint speed limit violated		Reduce acceleration or speed for joint
<b>C191A3</b>	TCP speed limit violated		Reduce acceleration or speed for joint
<b>C191A4</b>	TCP position limit violated		
<b>C191A5</b>	TCP orientation limit violated		
<b>C191A6</b>	Power limit violated		Reduce acceleration or speed for joint
<b>C191A7</b>	Joint torque window violated		
<b>C191A8</b>	Joint torque window too large		
<b>C191A9</b>	Reduced mode output violation		
<b>C191A10</b>	Safeguard stop output violation		
<b>C191A11</b>	Emergency stop output violation		
<b>C191A12</b>	Momentum limit violation		
<b>C191A13</b>	Robot moving output violation		
<b>C191A14</b>	Robot is not braking in stop mode	During the braking process, the safety system monitors if the robot brakes as expected. If this is not the case, this error is generated	Check payload settings and mounting

<b>C191A15</b>	Robot is moving in stop mode	When the robot is stopped due to a safety violation or a safeguard stop, the safety system generates this error, if the robot moves while in this mode	Is the robot physically pushed while safeguard stopped?
<b>C191A16</b>	Robot did not stop in time		
<b>C191A17</b>	Received a null vector for TCP orientation	Fault in config file, when no GUI is used	
<b>C191A18</b>	Robot not stopping output violation		
<b>C191A19</b>	Invalid safety IO configuration	Fault in config file, when no GUI is used	
<b>C191A20</b>	Configuration information or limit sets not received		
<b>C191A21</b>	The other safety processor detected a violation		
<b>C191A22</b>	Received unknown command from Controller		Check Firmware
<b>C191A23</b>	Invalid setup of safety limits		Check Firmware
<b>C191A24</b>	Reduced Mode Output set, while it should not be		Check Firmware
<b>C191A25</b>	Reduced Mode Output not set, while it should be		Check Firmware
<b>C191A26</b>	Not Reduced Mode Output set, while it should not be		Check Firmware
<b>C191A27</b>	Not Reduced Mode Output not set, while it should be		Check Firmware
<b>C191A28</b>	Robot Emergency Stop exceeded maximum stop time	Too high payload	
<b>C191A29</b>	System Emergency Stop exceeded maximum stop time	Too high payload	
<b>C191A30</b>	Safeguard Stop exceeded maximum stop time	Too high payload	
<b>C191A31</b>	Operation mode switch is present while the three position switch is missing		
<b>C192</b>	Safety system fault		
<b>C192A1</b>	Robot still powered in emergency stop	When emergency stop is active, the robot arm powers off. The controller is responsible for sending the power off command. This error is generated, if the safety system detects that the robot arm still has power.	
<b>C192A2</b>	Robot emergency stop disagreement	E-stop in teach pendant or in Robot E-stop circuit problem	Check cables or replace Safety Control Board (SCB)
<b>C192A3</b>	System emergency stop disagreement	System E-stop circuit problem	Check cables or replace Safety Control Board (SCB)

<b>C192A4</b>	Safeguard stop disagreement	Safeguard circuit problem	Check cables or replace Safety Control Board (SCB)
<b>C192A5</b>	Euromap safeguard stop disagreement	Euromap circuit problem	Check cables from Safety Control Board to Euromap to external machine
<b>C192A6</b>	Joint position disagreement		Reduce payload, check for encoder problems
<b>C192A7</b>	Joint speed disagreement		Reduce payload, check for encoder problems
<b>C192A8</b>	Joint torque disagreement		Reduce payload, check for encoder problems
<b>C192A9</b>	TCP speed disagreement		Reduce payload, check for encoder problems
<b>C192A10</b>	TCP position disagreement		Reduce payload, check for encoder problems
<b>C192A11</b>	TCP orientation disagreement		Reduce payload, check for encoder problems
<b>C192A12</b>	Power disagreement	Power calculation: uP-A and uP-B disagreement	Joint error: Check previous error codes from the same joint and evaluate
<b>C192A13</b>	Joint torque window disagreement		
<b>C192A14</b>	Reduced mode input disagreement	Safety I/O uP-A and uP-B disagreement	Check cables
<b>C192A15</b>	Reduced mode output disagreement	Safety I/O uP-A and uP-B disagreement	Check Cables and Software error on motherboard
<b>C192A16</b>	Safety output failed		
<b>C192A17</b>	Safeguard stop output disagreement	Safety I/O uP-A and uP-B disagreement	Check Cables and Software error on motherboard
<b>C192A18</b>	The other safety processor is in fault		
<b>C192A19</b>	Emergency stop output disagreement	Safety I/O uP-A and uP-B disagreement	Check Cables and Software error on motherboard
<b>C192A20</b>	SPI output error detected	Safety Control Board	Check 24 V supply
<b>C192A21</b>	Momentum disagreement		
<b>C192A22</b>	Robot moving output disagreement	Safety I/O uP-A and uP-B disagreement	Check Cables and Software error on motherboard
<b>C192A23</b>	Wrong processor ID		
<b>C192A24</b>	Wrong processor revision		
<b>C192A25</b>	Potential brownout detected	Voltage drop on Safety Control Board(SCB) or defect SCB	
<b>C192A26</b>	Emergency stop output disagreement	Safety I/O uP-A and uP-B disagreement	Check Cables and Software error on motherboard
<b>C192A27</b>	Safeguard stop output disagreement	Safety I/O uP-A and uP-B disagreement	Check Cables and Software error on motherboard
<b>C192A28</b>	Robot not stopping output disagreement	Safety I/O uP-A and uP-B disagreement	Check Cables and Software error on motherboard
<b>C192A29</b>	Safeguard reset input disagreement	Safety I/O uP-A and uP-B disagreement	Check cables
<b>C192A30</b>	Safety processor booted up in fault mode		



<b>C192A31</b>	Reduced Mode Output disagreement	Safety I/O uP-A and uP-B disagreement	Check Cables and Software error on motherboard
<b>C192A32</b>	Not Reduced Mode Output disagreement	Safety I/O uP-A and uP-B disagreement	Check Cables and Software error on motherboard
<b>C192A33</b>	Checksum disagreement between uA and uB		
<b>C192A34</b>	User safety config checksum disagreement between uA and GUI		
<b>C192A35</b>	Robot config checksum disagreement between uA and GUI		
<b>C192A36</b>	Online RAM test failed		
<b>C192A37</b>	Not all safety related functionalities are running		
<b>C192A38</b>	Package too short for CRC calculation		
<b>C192A39</b>	Three position switch input disagreement		
<b>C192A40</b>	Operation mode switch input disagreement		
<b>C193</b>	One of the nodes is in fault mode	SCB has detected an error	See previous error or update the firmware on the joint or reboot system
<b>C193A0</b>	Joint 0 is in fault mode	SCB has detected an error	See previous error or update the firmware on the joint or reboot system
<b>C193A1</b>	Joint 1 is in fault mode	SCB has detected an error	See previous error or update the firmware on the joint or reboot system
<b>C193A2</b>	Joint 2 is in fault mode	SCB has detected an error	See previous error or update the firmware on the joint or reboot system
<b>C193A3</b>	Joint 3 is in fault mode	SCB has detected an error	See previous error or update the firmware on the joint or reboot system
<b>C193A4</b>	Joint 4 is in fault mode	SCB has detected an error	See previous error or update the firmware on the joint or reboot system
<b>C193A5</b>	Joint 5 is in fault mode	SCB has detected an error	See previous error or update the firmware on the joint or reboot system
<b>C193A6</b>	Tool is in fault mode	SCB has detected an error	See previous error or reboot system
<b>C193A7</b>	Screen 1 is in fault mode	SCB has detected an error on Safety processor 1 in Teach pendant	See previous error or reboot system
<b>C193A8</b>	Screen 2 is in fault mode	SCB has detected an error on Safety processor 2 in Teach pendant	See previous error or reboot system

<b>C193A9</b>	Euromap 1 is in fault mode	SCB has detected an error	See previous error or reboot system
<b>C193A10</b>	Euromap 2 is in fault mode	SCB has detected an error	See previous error or reboot system
<b>C194</b>	One of the nodes is not booted or not present		
<b>C194A0</b>	Joint 0 is not booted or not present	SCB has detected an error	
<b>C194A1</b>	Joint 1 is not booted or not present	SCB has detected an error	
<b>C194A2</b>	Joint 2 is not booted or not present	SCB has detected an error	
<b>C194A3</b>	Joint 3 is not booted or not present	SCB has detected an error	
<b>C194A4</b>	Joint 4 is not booted or not present	SCB has detected an error	
<b>C194A5</b>	Joint 5 is not booted or not present	SCB has detected an error	
<b>C194A6</b>	Tool is not booted or not present	SCB has detected an error	
<b>C194A7</b>	Screen 1 is not booted or not present	SCB has detected an error on Safety processor 1 in Teach pendant	
<b>C194A8</b>	Screen 2 is not booted or not present	SCB has detected an error on Safety processor 2 in Teach pendant	
<b>C194A9</b>	Euromap 1 is not booted or not present	SCB has detected an error	
<b>C194A10</b>	Euromap 2 is not booted or not present	SCB has detected an error	
<b>C194A128</b>	Joint 0 not ready while brake release requested	Must be at least in IDLE mode when the brake release is requested	1. Check for loose communication cable. 2. Replace base
<b>C194A129</b>	Joint 1 not ready while brake release requested	Must be at least in IDLE mode when the brake release is requested	1. Check for loose communication cable. 2. Replace shoulder
<b>C194A130</b>	Joint 2 not ready while brake release requested	Must be at least in IDLE mode when the brake release is requested	1. Check for loose communication cable. 2. Replace elbow
<b>C194A131</b>	Joint 3 not ready while brake release requested	Must be at least in IDLE mode when the brake release is requested	1. Check for loose communication cable. 2. Replace Wrist 1
<b>C194A132</b>	Joint 4 not ready while brake release requested	Must be at least in IDLE mode when the brake release is requested	1. Check for loose communication cable. 2. Replace Wrist 2
<b>C194A133</b>	Joint 5 not ready while brake release requested	Must be at least in IDLE mode when the brake release is requested	1. Check for loose communication cable. 2. Replace Wrist 3

<b>C194A134</b>	Tool not ready while brake release requested	Must be at least in IDLE mode when the brake release is requested	1. Check for loose communication cable. 2. Replace Tool
<b>C195</b>	Conveyor speed too high	Conveyor speed higher than robot is able to run	Make sure that conveyor tracking is set correct up
<b>C195A1</b>	Conveyor speed too high for joint speed safety limit		Make sure that conveyor tracking is set correct up
<b>C195A2</b>	Conveyor speed too high for TCP speed safety limit		Make sure that conveyor tracking is set correct up
<b>C195A3</b>	Conveyor speed too high for momentum safety limit		Make sure that conveyor tracking is set correct up
<b>C196</b>	MoveP speed too high	Too high speed in relation to blend radius	Reduce speed or increase blend radius in user program
<b>C197</b>	Blend overlap warning		
<b>C200</b>	Safety Control Board hardware error	SCB: uP-A has detected an error	
<b>C200A1</b>	Hardware ID is wrong	SCB: uP-A has detected an error: Wrong SCB	
<b>C200A2</b>	MCU type is wrong	SCB: uP-A has detected an error	
<b>C200A3</b>	Part ID is wrong	SCB: uP-A has detected an error	
<b>C200A4</b>	RAM test failed	SCB: uP-A has detected an error	Replace Safety Control Board (SCB)
<b>C200A5</b>	Register test failed	SCB: uP-A has detected an error	Replace Safety Control Board (SCB)
<b>C200A6</b>	pRom Crc test failed	SCB: uP-A has detected an error: firmware error	Replace Safety Control Board (SCB)
<b>C200A7</b>	Watchdog reset the processor	SCB: uP-A has detected an error	
<b>C200A8</b>	OVG signal test not passed	SCB: uP-A has detected an error: over voltage generator	Replace Safety Control Board (SCB)
<b>C200A9</b>	3V3A power good pin is low	SCB: uP-A has detected an error	Replace Safety Control Board (SCB)
<b>C200A10</b>	3V3B power good pin is low	SCB: uP-A has detected an error	Replace Safety Control Board (SCB)
<b>C200A11</b>	5V power good is low	SCB: uP-A has detected an error	Replace Safety Control Board (SCB)
<b>C200A12</b>	3V3 voltage too low	SCB: uP-A has detected an error	Replace Safety Control Board (SCB)
<b>C200A13</b>	3v3 voltage too high	SCB: uP-A has detected an error	Replace Safety Control Board (SCB)
<b>C200A14</b>	48V input is too low		Check: 48 V power supply, current distributer energy eater or replace SCB
<b>C200A15</b>	48V input is too high		Check: 48 V power supply, current distributer energy eater or replace SCB

<b>C200A16</b>	24V IO short circuited	Too high current	Disconnect external connections
<b>C200A17</b>	PC current is too high	Motherboard takes too high current	
<b>C200A18</b>	Robot voltage is too low		Check: Short circuit in robot arm, 48 V power supply, current distributor energy eater or replace SCB
<b>C200A19</b>	Robot voltage is too high		Check: 48 V power supply, current distributor energy eater or replace SCB
<b>C200A20</b>	24V IO voltage is too low		Disconnect I/O or replace SCB
<b>C200A21</b>	12V voltage is too high		Check 12 V power supply, cables or replace SCB
<b>C200A22</b>	12V voltage is too low		Check 12 V power supply, cables or replace SCB
<b>C200A23</b>	It took too long to stabilize 24V	Safety Control Board error(SCB)	External 24 V problem or replace SCB
<b>C200A24</b>	It took too long to stabilize 24V IO	Safety Control Board error(SCB)	External 24 V problem or replace SCB
<b>C200A25</b>	24V voltage is too high	Safety Control Board error(SCB)	Replace Safety Control Board (SCB)
<b>C200A26</b>	24V IO voltage is too high		Disconnect I/O or replace SCB
<b>C201</b>	Setup of safety board failed	Invalid safety parameters have been received	Verify that the setup of the Safety Configuration is valid. Check the Ethernet connection between Motherboard and Safety Control Board.
<b>C202</b>	SCE configuration was illegal, after applying tolerances		
<b>C203A0</b>	PolyScope detected a mismatch between the shown and (to be) applied safety parameters	The PolyScope continuously verifies that the shown safety parameters are equal to the running parameters	Check that the software version is the same or newer than the firmware on the safety control board. Reload the installation and re boot the robot
<b>C204A0</b>	Protective Stop: Invalid setpoint		
<b>C204A1</b>	Sudden change in target position		
<b>C204A2</b>	Inconsistency between target position and speed		
<b>C204A3</b>	Sudden stop	The program contains motions that are not ramped correctly down	To abort a motion, use "stopj(a)" or "stopl(a)" script commands to generate a smooth deceleration."


<b>C204A4</b>	Robot is not braking in stop or pause mode	If this happens, report it as a bug
<b>C204A5</b>	Robot program resulted in invalid setpoint	
<b>C204A6</b>	Blending failed and resulted in an invalid setpoint	Try changing the blend radius or contact technical support
<b>C205</b>	Target speed does not match target position	
<b>C205A0</b>	Inconsistency between target position and speed	
<b>C206</b>	Sanity check failed	The software version on the robot must be the same or later than the version the robot had from the factory.
<b>C206A0</b>	Target joint speed does not match target joint position – Joint 0 (Base)	
<b>C206A1</b>	Target joint speed does not match target joint position – Joint 1 (Shoulder)	
<b>C206A2</b>	Target joint speed does not match target joint position – Joint 2 (Elbow)	
<b>C206A3</b>	Target joint speed does not match target joint position – Joint 3 (Wrist 1)	
<b>C206A4</b>	Target joint speed does not match target joint position – Joint 4 (Wrist 2)	
<b>C206A5</b>	Target joint speed does not match target joint position – Joint 5 (Wrist 3)	
<b>C207</b>	Fieldbus input disconnected	Check fieldbus connections or disable the fieldbus in the installation

## 5.2 LED indicators and Fuses on Safety Control Board

### Safety Control Board (SCB)

Fuse 48 V:

The 5 A fuse "48 V" protects all 48 V for over current in the system inclusive Euromap.  
This information is only for troubleshooting. Do NOT replace the fuse on any circumstances.  
Do ONLY replace the SCB with a new tested board.



Fuse 24 V:

2 fuses 5 Amp in parallel for the DI/DO 24 V supply on the safety control board no matter if the 24 V is from the controller or external power supply. Do NOT replace the fuse on any circumstances. Do ONLY replace the SCB with a new tested board

LED indicators:

12V-PSU	On when the power plug is connected.
12V	System: On when the power on has been activated
5V	On when "12 V System" is on and indicate that 5 V is ok.
-4V	On when "12 V System" is on and indicate that - 4 V to analog I/O is ok.
3V3A	On when 5V is on and indicate 3.3 V for logic Safety circuit A
3V3B	On when 5V is on and indicate 3.3 V for logic Safety circuit B
48V	48 V is present on the safety control board
24V	48 V is detected and ok, indicate that internal 24 V is present for I/O's
R	48 V on robot arm
A	Status for Logic A: a blink sequence
B	Status for Logic B: a blink sequence

**Normal startup sequence for a CB3.x UR10:**

1. The 12V-PSU LED is on when the power plug is connected to a working power supply.
2. When the power button on the teach pendant is pressed, all LED indicators are turned on except for the 48V, 24V and R LEDs. The A and B LEDs also exhibit a special behavior by intermittently turning off and on ("blinking") once triggered.
3. The final phase of the startup sequence occurs (immediately) after the Polyscope software is done loading. At this stage, the 48V and 24V LED indicators become active (are switched on).

If the 48V LED indicator is off all the time in the startup sequence you should measure the voltage:


See the E-Plan diagram: [5.4.1 Schematic overview](#)

- 3.1. Measure the 48V on the Safety Control Board (SCB) where the 48V comes from the Current distributor. And check this 1 second pulse.
  - 3.1.1. The voltage is measured on the Safety Control Board. That means the Safety Control Board is defect.
  - 3.1.2. No voltage is measured on the Safety Control Board. Then measure the 230 V on the input side of the 48V power supply. If the voltage pulse of 1 second is present, the Power supply is defect.
  - 3.1.3. No voltage is measured on the input of the power supply. Then measure the 230 V on the input side of the Current distributor. If the voltage is present, the current distributor is defect.




## 5.3 Error phenomena


### 5.3.1 ControlBox: NO CONTROLLER displayed in Initializing



### 5.3.2 NO CABLE displayed during power up




### 5.3.3 Protective stop





### 5.3.4 Power on failure in Initializing

If power turns off a few seconds after Robot Power is turned On in the Initializing window, there are many possible causes for this phenomenon.


Most likely it is a control box failure or a communication failure with a joint or the tool.







### 5.3.5 Checklist after a collision






## 5.4 Electrical documentation

### 5.4.1 Schematic overview

Diagrams in pdf or in E-plan format, can be found on the Support site:


<http://www.universal-robots.com/support/>

										F26_001_UR
		UNIVERSAL ROBOTS								
Company		Universal Robots								
Drawing number		3.0.0.2								
Project name		Universal Robots UR10								
Created on		25-09-2014								
Edit date		24-11-2015								
		Number of pages 19								





CB3


Overview UR10



= 2		= UR10		+ 11	
Universal Robots		Overview UR10		3.0.0.2	
Date		24-11-2015		Page	
Ed				10	
Appr				Page	
Original				10	
Name		Replacement of		Page	
Date		Replaced by		10	








## 5.4.2 E-Plan diagrams

Diagrams in pdf or in E-plan format, can be found on the Support site:

<http://www.universal-robots.com/support/>









-UR10  
/15.0

-UR10  
/15.0

																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																</	
--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	----	--

-UR10  
/15.0

-UR10  
/15.0



-UR10  
/15.0

-UR10  
/15.0

-UR10  
/15.0

---

Servicemanual\_UR10\_en\_3.1.3

---

Servicemanual\_UR10\_en\_3.1.3

## 6. Spare parts

### 6.1 Spare part list

Item no.	Item designation
<b>Controller:</b>	
<b>122950</b>	Controller excl. Teach Pendant UR10
<b>124910</b>	Controller OEM CB3 UR10 (Excl. Teach Pendant and cabinet)
<b>122091</b>	Teach Pendant incl. Touch Screen & power cable UR5 & UR10
<b>180001</b>	Stylus Pen
<b>171022</b>	Flash card CB3.0
<b>171010</b>	USB Flash 2 GB for UR system SW CB3.1
<b>122600</b>	Motherboard kit CB3.0
<b>122650</b>	Motherboard kit CB3.1
<b>172290</b>	Safety Control board kit
<b>177002</b>	Power Supply Unit 12V
<b>177003</b>	Power Supply Unit 48V
<b>172080</b>	Current Distributor PCB
<b>122745</b>	Energy-eater incl. fan CB3
<b>164229</b>	Connector Epic w. cable UR10 CB3 (Controller output connector to robot arm)
<b>171030</b>	RAM module for Motherboard 3.0
<b>171031</b>	RAM module DDR3L for Motherboard 3.1
<b>177503</b>	Filter kit for controller
<b>106800</b>	Euromap E67 kit CB3
<b>122671</b>	Euromap E67 Bypass Plug
<b>122673</b>	Euromap E67 module CB3
<b>123670</b>	Euromap E67 cable 6 m
<b>Robot arm:</b>	
<b>111110</b>	UR10 robotarm stand-alone CB3
<b>164231</b>	Cable: Base to Controller UR10
<b>122071</b>	Base Mounting Bracket UR10
<b>122124</b>	Joint Size 4 Base UR10
<b>122224</b>	Joint Size 4 Shoulder UR10
<b>122324</b>	Joint Size 3 Elbow UR10
<b>104001</b>	Elbow counterpart and Lower arm kit UR10
<b>122122</b>	Joint Size 2 Wrist 1 UR10
<b>122222</b>	Joint Size 2 Wrist 2 UR10
<b>122322</b>	Joint Size 2 Wrist 3 UR10
<b>122061</b>	Tool Mounting Bracket UR10
<b>103310</b>	Sealing set UR10, external. Visible flat rings between joints
<b>103410</b>	Lid set complete UR10 incl. seal in the lids

Item no.	Item designation
<b>Accessories:</b>	
<b>173101</b>	Cable for tool, angle: external
<b>131095</b>	Lid, For tool connector. Tool protective cap Alu.
<b>139033</b>	Bracket for Mounting Teach Pendant
<b>132407</b>	Bracket for Mounting Controller
<b>107000</b>	Safety Control board Terminal Kit
<b>131510</b>	Bracket for mounting robot arm UR10 (Item & Bosch profile)

## 6.2 Service kit


Item no.	Item designation	
<b>109010</b>	Service kit UR5/UR10	(kit includes all of the below part no.'s)
<b>109101</b>	Spanner Hex 5.5mm	UR5 & UR10
<b>109102</b>	Spanner Hex 7.0mm	UR5 & UR10
<b>109110</b>	Spanner Hex 10.0mm	UR10 only
	Screwdriver Flat 2.5	UR3 & UR5 & UR10
<b>109103</b>	Screwdriver torx T10	UR5 & UR10
<b>109105</b>	Torque wrench Hex 5.5mm Size 1 and Size 2 (1.3 Nm)	UR5 & UR10
<b>109106</b>	Torque wrench Hex 7.0mm Size 3 (3.0 Nm)	UR5 & UR10
<b>109107</b>	Torque wrench Hex 10.0mm Size 4 (8.0 Nm)	UR10 only
<b>109104</b>	Torque screwdriver torx T8 + T10 (0.4 Nm)	UR3 & UR5 & UR10
<b>109111</b>	Torque screwdriver torx T10 (1.3 Nm)	UR3
<b>109112</b>	Torque screwdriver torx T20 (3.0 Nm)	UR3
<b>164084</b>	Bypass cable (for setting joint-ID)	UR3 & UR5 & UR10
<b>109180</b>	ESD wrist strap	UR3 & UR5 & UR10
	Service kit box	UR3 & UR5 & UR10



## 7. Packing of robot

Packing of robot and controller box for shipment

- Remove any external tooling and external electrical connections.
- Download the Put\_Into\_Box program to a USB stick. Download it from:  
<http://www.universal-robots.com/support/>
- Load program *Put\_into\_box\_ur10.urp* and follow instructions while removing mounting bolts.



While robot folds together, hold a piece of bubble wrap between Shoulder joint and wrists.

Note: If robot cannot run or power is not available, it is possible to manually release the brakes for each joint individually and pack the robot accordingly. For brake release, see [3.1.3 Brake release](#)

- Power down, disconnect power and disconnect robot arm from controller.
- Pack robot arm and Controller box in designated boxes. Make sure the robot arm is orientated correct in the box.



## 8. Change log

Date	Revision	Action	Changes
3. May 2014	UR10_en_3.0	Added	First revision 3.0 released
19. June 2014	UR10_en_3.0.1	Changed	Pictures and illustrations changed to match 3. gen. robot
11. July 2014	UR10_en_3.0.2	Changed	Error codes, Spareparts changed to match 3. Gen robot and ESD handling added
20. Octo. 2014	UR10_en_3.1.1	Changed	Electrical doc., E-plan , Spare parts update and error code update. New structure for disassemble/assemble guide. ESD handling modified.
January 2016	UR10_en_3.1.2	Changed	Update of electrical drawings, Joint spare part adaption, error codes. Dual robot calibration. Added Motherboard 3.1
December 2016		Added	3.1.4 Bolt length for joints
		Added	Error code C71A12
		Added	3.1.5 Added tolerance to Size 3 torque
		Corrected	5.2 LED startup sequence