

Multiaccess

Contents

About topex	1
Compatible Cards	2
Multiaccess Structure	2
Power Card	3
Processor Card	4
ISDN Card	7
Voip Card	9
GSM Card	10
Main Software	12
About centrala	12
SIP features	12
H323 apc	15
Mspd	16
Rtprx pool	21
Rtptx pool	21
Recmail	22
Smtplib	23
Sendsms	24
Mysql client	25
Radius billing	25
Pgsql sip pool	26
Pgsql pcodedel	26
Pgsql pcode	27
Pgsql pcodeerror	27
Pgsql sms	28
Administration	29
Default Passwords	29
Operating Sistem Structure	30
Telnet commands	32
OAM	48
Connecting with OAM	48
OAM / Card Map	50
OAM / Installing a GSM card	51

OAM / Installing a PRI card	55
OAM / Installing a VOIP card	58
OAM / Installing a MPPI card	67
OAM / EIR2	67
OAM / Call Flow	72
OAM / Create a Trunk	74
OAM / Access IN	75
OAM / Call Directions	77
OAM / Routing Table	85
OAM / Access Out	106
OAM / Max Call duration	107
OAM / Overflow	108
OAM / Monitor calls	111
OAM / SIM Management	116
OAM / DTMF	118
OAM / DISA	120
OAM / Forward Incoming GSM Calls	121
OAM / Send SMS	123
OAM / Check Credit	124
OAM / ALARMS	125
OAM / Check GSM Signal	126
OAM / Download Billing	127
OAM / Download ASR	133
How To's	134
Connect to Multiaccess or Qutex	134
Change IP Address	136
Change Date and Time	138
Check harddisk for problems	139
Clean restart/shutdown	140
Stop/Start Logs	141
Reroute on cause X	142
Upgrade Software	143
Call Control	147
CCTL features	147
CCTL flow	148
AccessIn	152

Users and Classes	152
Routing table	153
AccessOut	155
Configuration Files	156
Exec.cfg	156
Traffic.cfg	168
Dirname.cfg	170
Card.cfg	171
Port.cfg	172
Dir.cfg	174
Voip.cfg	181
Diripin.cfg	182
Diripout.cfg	183
Group.cfg	185
Sip pbx.cfg	187
Sip redirect.cfg	190
Prepaid.cfg	190
SIPusers.cfg	191
Voice mail.cfg	196
Simindex.cfg	197
Register users.cfg	197
Extended Port Config	199
Extended port config	199
VCSS files for Wavecom	200
Billing	203
Billing generic (PGSQL, MySQL, MSSQL)	203
PgSQL Billing	204
Mysql Billing	205
Dd-mm-yy.tax	208
Aplications	216
Voicemail2Email	216
Multiaccess Config for Simserver	219
Clean hdd.sh script	221
GSM Cell Selection	222
Voicemail	222

Glossary	227
----------	-----

References

Article Sources and Contributors	230
Image Sources, Licenses and Contributors	232

About topex

TOPEX is among the most innovative, fast growing European manufacturer of telecommunication equipment, providing a wide range of telecommunication applications. The company has over 18 years of experience in research, development and manufacture of both civil and military telecommunication devices. Our company acts like a bridge between analog, digital, IP telephony systems in wired and wireless environments.

TOPEX philosophy is built around the syntagm "everything connects". This is the expression of our credence, vehicle for the internal evolution of the company and interface for external contacts.

TOPEX's leveraged expertise includes: Next Generation Network solutions {Softswitch, Media Gateways for TDM, VoIP, GSM and CDMA (2G, 3G), Signaling Gateways (SS7, ISDN, R2, SIP, H323)}, Broadband Wi-Fi Mobile Routers, Fixed-Mobile Terminals (2G, 3G) and ATC Voice Communication Systems.

TOPEX products address the needs of business today that demand communication convergence at lower costs and the ability to exploit the Internet and existing data networks with VoIP for cheaper cost calling.

All the products are developed by TOPEX own Research & Development Department which has as its main goal the provision of future-ready telecommunications equipments.

Our company offers you profitable and practical solutions: the entire range of equipments is very easy to customize and enhance (flexible, upgradeable configurations). In order to achieve effective and flawless manufacturing of its products.

TOPEX has organized complete production facility in Europe. The company has proven the quality of its resources being permanently present in the most important markets on Europe. It delivers its products worldwide through a global distributor network.

Compatible Cards

Multiaccess Structure



Hardware Structure

- 19" 6U cabinet rack
 - * One power supply card
 - * E1 digital trunk card
 - * Main processor (PG) card
 - * Up to 16 cards that may be:
 - Cards with two mobile modules each
 - FXO cards with 8 interfaces each
 - E&M cards with 4 junctions each
 - FXS cards with 8 junctions each
 - ISDN cards
 - VoIP cards, etc.
 - * Antennas for the mobile network, which can be:
 - Individual antenna for each GSM, CDMA or UMTS channel (various external stick antennas with magnetic base and RF cable)
 - 1:16 or 1:32 concentrator (splitter) for use with high-gain, directional Yagi antennas

Cabinet rack description

- The multiAccess system is integrated in a 19" rack. The height of the equipment is 6U and the depth is 30 cm.
- The cabinet rack is made of aluminum.
- The front panel of the rack is open, equipped with guides for the plug-in cards.
- When not all interface cards are plugged in, the free sections of the front panel must be covered with a lid (cover panels).
- The bottom and upper sides of the cabinet are covered with perforated sheet.
- The proprietary backplane (system bus) of the equipment is designed as a printed circuit card (PCB) with two rows of connectors and fitted to the inner rack carrier profiles.

Basic Dimensions

Overall dimensions (except protrusions) are: 490 mm x 300 mm x 265 mm


Front Side

- * On the front, the TOPEX rack is has 19 slots for plug-in cards.
- * The first slots from the right are dedicated, for mandatory or optional cards. The power supply card, E1 trunk cards, and main processor card must be included in any case. The VoIP card may be used or not , but it must be inserted in a dedicated slot.
- * The remaining 16 slots may be fitted with mobile interface cards (GSM, CDMA, UMTS) or different analog or digital junction cards.

GoTo >Main Page > Multiacces&Qutex

Power Card

GoTo >Main Page > Multiacces&Qutex



This card is a double-width one, 40mm wide. It includes a power supply and optionally a call voltage generator and ensures the supply of the cabinet rack with +5V and -5V voltages. It draws its power from the regulated +24VD.C. voltage of the rack power supply. The power supply card must deliver these two voltages:

- * +5V 02% with maximum output current of 7 A
- * -5V 05% with maximum output current of 0,5 A

Significance of LED indicators

- 5V
Lights up green when -5V voltage is on

+ 5V
Lights up green when +5V voltage is on

RING
It holds significance only for the equipment version fitted with ringer generator.

If the equipment has ringer generator this LED will blink green with 25 Hz frequency.

Install: The card is inserted into the rack on top (the first wide slot).

Warning: Do not remove or insert power card while the equipment is ON

Processor Card

[GoTo >Main Page > Multiacces&Qutex](#)

Warning: Both processor cards use a hard disk to store files. It is very important to power off the equipment correctly using the power off button in OAM and then pressing the ON/OFF switch on the back of the equipment

Main processor card



The Main processor (PG) card is a double-width (40mm) card. It contains a powerful processor controlling the whole system.

The card includes multiple printed circuit cards and the harddisk for operating system, application programs and storage. It features on the front panel two serial interfaces (COM1, COM2) and one Ethernet connector (10Base-T). These interfaces are used to connect the TOPEX *multiAccess* system to a computer or to the Internet, for installation and servicing or for permanent operation. Through these ports you may perform the configuration, administration and maintenance operation for the equipment .

Note: This card is called PGRUC

Significance of indicators and controls

RESET

Hidden (recessed) button for reset

HB

Heartbeat LED, blinks green steadily during normal operation

GCK

Clock generation LED, lights green to indicate that the local clock generator on the PG card is active. Normally it is inactive, the clock signal is received from the E1 card.

ALRM

Alarm LED, lights up red to show an error

DEFAULT PASSWORDS

tpxadm / u53rp455

root / 5y5t3mp455 - root login is not allowed over ssh

Warning: Do not remove or insert processor card while the equipment is ON

Install: The card is inserted into the rack in position 3 of the (second slot wide).

Connectors card processor - the front COM1 - serial port to connect the OAM Serial port (RS-232) is located in the front of the card and PG can be used to connect to the computer which has installed the OAM

COM2 - serial port for console system LINUX The serial port is located on the front of the card and PG can be used to connect to a computer to access the console LINUX. DB9 connector is a father with the following standard configuration:

Level operating system (on older models) processors can not tell just by the amount of memory. This give the command **more / proc/meminfo**. Pentium will have 128M RAM and 8M RAM for 386

For Pentium

```
Mem: 129773568 12115968 117657600 6438912 630784 5251072
Swap: 134692864 0 134692864
MemTotal: 126732 kB
MemFree: 114900 kB
MemShared: 6288 kB
Buffers: 616 kB
Cached: 5128 kB
BigTotal: 0 kB
BigFree: 0 kB
SwapTotal: 131536 kB
SwapFree: 131536 kB
```

For Procesor 386

```
total: used: free: shared: buffers: cached:
Mem: 6864896 6639616 225280 3813376 163840 1957888
Swap: 134692864 1069056 133623808
MemTotal: 6704 kB
MemFree: 220 kB
MemShared: 3724 kB
Buffers: 160 kB
Cached: 1912 kB
BigTotal: 0 kB
BigFree: 0 kB
SwapTotal: 131536 kB
SwapFree: 130492 kB
```

IRQ - reserved sites are 5,7,9,11 and 15. If you reset the BIOS IRQ of your network card can jump on 11. (as below)

more /proc/pci

```
PCI devices found:
Bus 0, device 0, function 0:
Host bridge: Cyrix PCI Master (rev 0).
Medium devsel. Fast back-to-back capable. Master Capable. No bursts.
Bus 0, device 13, function 0:
Ethernet controller: Realtek 8139 (rev 32).
Medium devsel. Fast back-to-back capable. IRQ 11. Master Capable. Latency=32. Min Gnt=32.Max Lat=64.
I/O at 0xe000 [0xe001].
Non-prefetchable 32 bit memory at 0xd0000000 [0xd0000000].
```

more /proc/interrupts


CPU0

```
0: 24247558 XT-PIC timer
1: 8 XT-PIC keyboard
2: 0 XT-PIC cascade
3: 25 XT-PIC serial
4: 126477 XT-PIC serial
5: 102629 XT-PIC irq2ms
7: 0 XT-PIC DSP-ISR handler
```

```
9: 175197 XT-PIC ser0 RS485 handler
11: 0 XT-PIC eth0, ser1 RS485 handler (IRQ sharing-> am pus sercom.o nou)
13: 0 XT-PIC fpu
14: 336661 XT-PIC ide0
15: 0 XT-PIC HeartBeat ISR
NMI: 0
```

For more then 150 simultaneous calls a memory upgrade is necessary

Processor / E1 / VoiP card - PGVOIPD



*** Identification**

Note:Card is marked PGVoIP on the front panel.

Warning: Do not remove or insert processor card while the equipment is ON

This card shall perform the following functions:

- Card processor provides the basic functions of the systems that included namely:
 - Ensuring internal connection between interfaces
 - Ensuring BITE function on the module which it operates
- Ensure the VoIP connection interface between VoIP module managed and internal interfaces
- Link to the internal LAN system of TOPEX IP VCS can be redundant - using 2 Ethernet ports configured in bounding mode.
- Card PG VoIP can be equipped with 2xE1 interfaces
- configuration.

Connectors, buttons

On the card's front panel connectors are 5 x RJ-45 note from top to bottom as follows:

RS232 – used for PC serial connection,

LAN (LAN2 in figure) – used for LAN connection,

WAN (LAN1 in figure)– used for WAN connection,


E1/A, E1/B –used for E1 lines connection,

DEFAULT PASSWORDS

gsmgw / 5tgb4rf

root / 91qwerty19 - root login is not allowed over ssh

ISDN Card

	<p>The E1 trunk card is a single width card, 20mm wide.</p> <p>It features one or two E1 interfaces that conform to G. 703 and has a frame structure according to ITU-T (CCITT) standard G. 704. Supported signaling includes R2 generic CAS (Channel Associated Signaling - in accordance both with ITU-T Q.421/Q.422 and with Q.411/Q.412), ISDN DSS1, and SS7.</p> <p>The encoding follows the A Law and the bit rate is the standard 2,048 Kbps.</p> <p>Nominal impedance is 120 ohm standard</p> <p>Significance of indicators and controls:</p> <p>HB Heartbeat green LED, it pulses steadily when everything is OK, frequency depending of type of signalization used</p> <p>LOS Lights up red to show Loss of Incoming Signal</p> <p>R Reset button, that is recessed (can't be pressed accidentally)</p> <p>LR Reset LED, lights up red during card initialization (reset) or on error</p>
---	--

Connecting E1 cable

Description of E1 trunk connections

The E1 trunks must be connected to the RJ45 inputs located either on the back of multiAccess, near the power switch (ON/OFF) or at the front (two connectors for each 2xE1 card). The first E1 trunk is connected to the first pair of RJ45 connectors (from bottom up):


- first (lower) connector in straight connection (=): Rx on the wire pair 1,2 orange color and Tx on the wire pair 4,5 blue color
- second connector (on top of the previous) in cross connection (x): Tx on the wire pair 1,2 orange color and Rx on the wire pair 4,5 blue color

This allows easy connection by using universal **straight** cable (shipped with the equipment) to any equipment that has a standard output for the E1 trunk (RJ45 connectors with connections 1,2 respectively 4,5).

The dual-E1 card features the two E1 connectors on the front panel of TOPEX multiAccess equipment.



Correspondence of pins of the connector of the UTP straight (=) cable

Pin	Color	Significance of wire pairs	Color	Pin
1	Orange-White	Rx pair, reception	Orange-White	1
2	Orange	Orange	2	
3	Green-White	Pair not used	Green-White	3
6	Green	Green	6	
5	Blue-White	Tx pair, reception	Blue-White	4
4	Blue	Blue	4	
7	Brown-White	Pair not used	Brown-White	7
8	Brown	Brown	8	



After you wire the cable, you can plug this cable into corresponding E1 connector, as shown in figure 4.

Figure 4: Connecting the cables – rear panel (backside of unit)



Voip Card



The VoIP card (Voice over IP) is used to transmit voice packets through the Internet. It is a single width card, 20mm wide.

The card features on the front panel a serial interface (COM) and four Ethernet connectors (10/100 BASE-T). The serial interface is used to debug the processor card. The Ethernet connectors perform the followings functions:

- Upper ETH, labeled “**WAN**” is used to connect the TOPEX VoIP card to the IP network (Internet). The name WAN suggests it is intended for connection to the outside world!
- Middle connectors **LAN2** and **LAN1** can connect other devices to the TOPEX equipment (Laptop, notebook, PC, etc.). They are part of a switch for the local network.
- Lower **LAN3** is used to perform the connection between the VoIP card and the processor card (PG) of the TOPEX equipment.

Significance of indicators

RTP – RTP Activity

Blue LED, It signals RTP activity (voice packets are coming or going) of the VoIP card.

WON - WAN Active

Yellow LED, lights up to indicate activity on the WAN (remote network).

RST – Reset indicator

Red LED, lights up briefly to show that a reset has occurred.

RESET- The reset button of the card.

When the equipment starts (implicit when the VoIP card is supplied) these three indicators and the LEDs (green and yellow) from the Ethernet connectors turn on sequential. If not that means that the VoIP card is not working.

The voltage supply is 5V and the current intensity is 1.4 A.

Install: The card is inserted into the rack in position 2, the position immediately following the card supply (narrow first slot).

Supported codecs:

```
0   = G711u
4   = G723.1
8   = G711a
18  = G729
```




Best Practice

Don't connect any cables in the voip card until voip configuration is not complete. Check this page before connecting any cables

GSM Card

GoTo >Main Page > Multiacces&Qutex



The mobile interface card, UABxxx, assures the connection to a mobile network (GSM / CDMA / UMTS). It contains two modules (wireless modems) on the printed circuit card. There are three types of cards, for GSM, CDMA or UMTS networks. Furthermore, the mobile interface card can be equipped with modules for different frequency bands, such as GSM 900/1800 MHz, GSM 850 MHz, GSM 800/1800/1900 MHz, CDMA 450/800/1900 MHz respectively UMTS 2100 MHz.

In this picture you can see a drawing of the UABGSM card, with GSM modules. The CDMA/ GSM/UMTS cards are very similar in aspect, and the cards with mobile modules for different frequency bands look exactly the same!

On the front panel the code card is different, thus is listed hereunder:

UABGSM – is labeled the card that includes GSM modules

UACDMA – is labeled the card that includes CDMA modules

UABUMTS – is labeled the card that includes UMTS modules

Inside each mobile module, there is a 4-slot adapter (holder) for the SIM or RUIM cards, if your network operator uses subscriber cards.

Also, each mobile module features a connector for its external antenna. The SMA connector is located on the front panel. On the connector you may thread directly the discreet antenna or a cable to connect to external antennas, directly or through a splitter / concentrator.

On the front panel there are also nine optic indicators for the mobile modules card (four LED's per each mobile module and one general).

The significance of these LED indicators is shown in detail in the tables below. **Note: If there is no serial communication between the main processor card and the module card, after a delay of about 15 seconds the reset of this card will be triggered.**

Significance of LED indicators:

LED	Status	Description
MODE (green)	Blinking, frequency 1Hz	The wireless module is in standby and is logged on with the mobile network
Off	The wireless module is NOT logged on to the mobile network	
Lights continuously	Voice connection initiating or establishing; if the wireless module is not logged on to network or is initializing then the STAT LED will blink.	
STAT. (red)	Lights continuously	The wireless module is off
Blinking, frequency 2 Hz	The wireless module is initializing	
Blinking, frequency 0,5 Hz	The wireless module was initialized but is not logged on to the mobile network	
Off	The wireless module is logged on to the mobile network	

SIM/RUIM # (green)		Selected SIM or RUIM card
Off	Off	1
Off	On	2
On	Off	3
On	On	4

Main Software

About centrala

GoTo >Main Page > centrala

Centrala is the main application that is running on the following Topex products:

- Softswitch
- Multiaccess, Qutex, Eones
- VoiBridge, VoxiPlus, VoisTel
- Radio gateway
- VCS

Features:

- written from scratch in C language
- built in state machine mechanism
- incorporate ISDN, SIP, TETRA, TETRAPOL, R2, R1.5 stacks
- can manage via socket SS7 apc, H323 apc, Mspd applications

Note:See also [CCTL features and SIP features](#)

SIP features

GoTo >Main Page > centrala

SIP User Agent, SIP Registrar, SIP Proxy, SIP Redirect

- Events supported: presence, dialog, timer, replaces, keep-alive, message-summary, refer
 - Methods: REGISTER, OPTIONS, INVITE, ACK, CANCEL, BYE, INFO, UPDATE, REFER, SUBSCRIBE, NOTIFY, PUBLISH, MESSAGE
 - UDP/TCP/TLS used as transport protocol
 - SIP stack written from scratch in C language
 - Transaction Stateful Proxy
 - Call Stateful Proxy
 - Forking proxy
 - MD5 register authentication
 - Access list based on public/private IP class with max limit for simultaneous calls
 - Signaling/Media NAT traversal
 - Media transcoding
 - SIP Proxy redundancy
 - IP centrex
 - Presence and basic IM server
 - Multiple user name aliases
 - ANI/DNIS restriction rules
-

- Do not disturb
- Reject anonymous calls
- Caller ID Presentation/Restriction
- Call hold
- Call parking
- Call waiting
- Call forward (busy, no answer, offline, always, only for a specific list of numbers)
- Voicemail (busy, no answer, offline, always)
- Voicemail to e-mail
- Missed call to e-mail
- Missed call to SMS
- Call transfer Attended/Unattended
- Call pickup, directed pickup
- Call hunting
- Call waiting
- Call forking
- Fax: T38 udptl, pass through(G711U, G711A)
- Web address book, web callback
- Prepaid sip users
- Call center features
- User-Agent/Server REGISTER regexp access list
- Asymmetric User-Agent/Server regexp checking list
- Multiple network interfaces binding

Performance

Max calls per second

- hardware machine: Intel(R) Xeon(R) CPU 5140 @ 2.33GHz
- software test tool: SIPP
- 5500 calls per seconds on UDP
debug off
calls are sent to Serv AUTOANSWER
- 200 calls per seconds on TLS
debug off
calls are sent to Serv AUTOANSWER
- 7000 REGISTER per second on UDP
debug off

Memory configuration loading

- hardware machine: Intel(R) Xeon(R) CPU 5140 @ 2.33GHz
- 50000 sip users generated with web SIP User Generator loaded in memory in less than 60 seconds
file debug activated
- 500 sip users loaded from text file in about 60 seconds
debug activated

Max life working capacity

- 100000 SIP users supported with 600 seconds registration refresh interval
-

RFC:

- RFC 2069 ^[1] - MD5 Digest Access Authentication
- RFC 2327 ^[2] - SDP
- RFC 2617 ^[3] - HTTP Authentication: Basic and Digest Access Authentication
- RFC 2976 ^[4] - INFO method
- RFC 3261 ^[5] - SIP (version 2)
- RFC 3265 ^[6] - Event notification, SUBSCRIBE/NOTIFY mechanism
- RFC 3325 ^[7] - SIP Asserted Identity
- RFC 3326 ^[8] - Reason header
- RFC 3398 ^[9] - ISDN/ISUP to SIP mapping
- RFC 3515 ^[10] - REFER method
- RFC 3581 ^[11] - rport parameter for Via header
- RFC 3842 ^[12] - SIP Message Waiting
- RFC 3856 ^[13] - SIP presence
- RFC 3863 ^[14] - PIDF XML format
- RFC 3891 ^[15] - Replace header
- RFC 3892 ^[16] - SIP Referred-By mechanism
- RFC 3903 ^[17] - PUBLISH method
- RFC 4028 ^[18] - Session timer
- RFC 4235 ^[19] - Dialog-info XML format
- RFC 4497 ^[20] - Interworking between SIP and QSIG
- RFC 5589 ^[21] - SIP call transfer

Drafts:

- draft-ietf-sip-privacy-04
- draft-levy-sip-diversion-08

ITU-T:

Rec. T.38 (09/2005) - Annex D

H323 apc

GoTo >Main Page

h323_apc

Note: h323_apc is started by centrala and is configured in /mnt/app/cfg/voip.cfg the options below can be added to voip.cfg

```
/mnt/app/bin/h323_apc --help
options:
--user <username> - Name of the user. This will be used as display name for outbound calls
--productid <id> - Product id
--callerid <callerid> - Caller id
--user-number <number> - Caller number
--gk-discover - Discover gatekeeper
--gk <ip:port> - Use specific gatekeeper
--auto-answer - Enables auto answer mode
--h323id <h323id> - H323ID to be used for this endpoint
--log <file> - log file to be used for this endpoint
--logmaxfile <max> - max log file length(kB)
--e164 <number> - E164 number used as callerid for this endpoint
--use-ip <ip> - Ip address for the endpoint (default - uses gethostbyname)
--use-port <port> Port number to use for listening to incoming calls.(default-1720)
-p <cctlport> Port number to use for cctl data (default-9010)
--version - Version
--ignore-termcap - Ignore termcap received
-t - Trace. Use multiple times to increase trace level
--help - Prints this usage message
```

voip.cfg example of h323 maximum log file of 1000000=1GB

```
h323 127.0.0.1 9010
```

```
forkh323 /mnt/app/bin/h323_apc -p 9010 --logmaxfile 1000000 --logfile /mnt/app/out/
```

```
- fast start and tunneling can be on the class - Sign2 ( H323 No Tunnel H245, H323 No Fast Start )
Client_Classes#H323_No_Tunnel_H245
```

Note: Configuring a limit for logmaxfile will not stop logging after the limit is reached.H323 will simply create another log file

Rx DTMF method: H.245 alphanumeric, H.245 signal, Q.931 keypad

Tx DTMF method: H.245 alphanumeric only

See also H323 GK

Mspd

GoTo >Main Page

Definition: Multimedia Streaming Processor Daemon

It is an interface between Mindspeed M82xxx chips (Topex PGVoIP or Topex xVoip cards) and a client software (usually centrala).

As client software can also be "tunelohtdm", "telnet" or any other software knowing the msdp protocol.

Mspd provides an easier to use and debug interface to M82xxx chips. M82xxx represents IP_PABX chips.

Topex devices uses 2 of the M82xxx's interfaces : TDM and Ethernet.

Payload Types supported by M82xxx :

```
G.711:G.711 A-law and u-law (default) coding.
G.726:(IETF or ITU bit packing format) 16, 24, 32, 40 Kbps.
G.723.1 and G.723.1 A:5.3Kbps/6.3Kbps.
G.729 Annex A & B:Annex A and B are supported at 8Kbps.
Clear Channel: passes packet-to-PCM and PCM-to-packet data with no conversion
                (Tone detection and asymmetrical packet sizes are not supported in clear channel mode)
G.728*
G.729eg*
G.729.1*
iLBC*
-----
* => Optional features
```

This are Packetization intervals (packetization times) for different codecs on M82XXX:

```
G.711 u-law PCM (0): 5, 10, 20, 30, 40, 50, 60
G.711 A-law PCM (8): 5, 10, 20, 30, 40, 50, 60
G.723.1 (4): 20, 40, 60
G.728 (15): 30, 60, 90
G.729a (18): 5, 10, 20, 30, 40, 50, 60
G.726-32 (2): 5, 10, 20, 30, 40, 50, 60
```

Usually centrala requests msdp to:

- Open an RTP channel with codec p, packetization time m to ip xxx.xxx.xxx.xxx remote_port rp local_port lp from a tdm_timeslot;
- Generate a tone on a tdm_timeslot
- Open a tdm_timeslot.(for receiving Tone detected indications)
- Interconnect 2 tdm_timeslots (as in a TDM SWitch)

Some sample msdp protocol commands:

```
Rslot 5
Open timeslot 5
```

```
rslot 5
Close timeslot 5
```

```

Rrtp 4 -p 8 -m 40 31004 192.168.1.2 32222
Create RTP stream (codec 8, packetization_time 40, local_port 31004) to 192.168.1.2:32222 from TDM timeslot 4

Rtone 7 -r 255 450 -100 0 -100 1500 3500
Generate Ring-Back tone (repeat forever (255), freq1=450,power1=-100, freq2=0,power2=-100, cadence={1500 on,3500 off})

Rhtdm 64
Open HDLCoverTDM chanel on timeslot 64

Rhtdm 64 -frm 3 aabb11
Send 3 bytes HDLC frame {0xAA,0xBB,0x11} on TDM timeslot 64

Ihtdm 64 -frm 3 aabb11
3 bytes HDLC frame {0xAA,0xBB,0x11} received from TDM timeslot 64(indication to all clients)

Itone 130 3 435 134276143 -96
"DTMF tone 3" detected on TDM timeslot 130

Rstat 7
print in mspd_log the number of RX and TX IP packets on tdm_timeslot 7

Rxtdm 5 129
connect tdm_timeslot 5 with tdm_timeslot 129 (TDM SWitch)

```

mspd.cfg

The default configuration file for mspd is /mnt/app/cfg/mspd.cfg . A different configuration file can be specified with command line argument "--cfg".

```

File format is:

# lines starting with '#' are commented lines

# parameter value

# Some defaults values are changed depending on the system type or other configuration parameters.

# To be sure about a parameter value please check it in the log file at the mspd start.


daemonize 1           # Daemonize the server,otherwise starts a session on standard input. restart required after change
verbosity 1           # Verbosity level 0..5; restart required after change
port 9677              # Server port (to communicate with centrala); restart required after change
msp_ip 0.0.0.0         # Voip Card IP (!!Only set this params on XVoip cards); restart required after change
msp_mac 0:0:0:0:0:0    # Voip Card MAC (!!Only set this params on XVoip cards), restart required after change
mem 16                # SDRAM installed on MSP, restart required after change
tdm-clk 2:2:0:0       # TDM clock rates; default 2:2:0:0; restart required after change
log %d-%m-%y_mspd.log # Log file; default_value /dev/null

tstamp-freq 1000L*15*60 ms # A time stamp is printed every 15 minutes (or the number of seconds specified tstamp-freq)
axf miro_hdvoice.axf   # Firmware file to load(only for XVoip)
pkt-dly 0              # miro boot packet delay in ms; restart required after change
nowait-con 0           # do not wait for client to connect,otherwise mspd waits the first connection; restart required after change
trace-cmd 0            # Trace messages between mspd and client applications
vlan 0                 # Vlan TAG
ip_tos 0               # TOS
diag_ip 0.0.0.0        # diagnostics ip

```

```

diag_port 9699          # diagnostics port

t2p_gain 0              # tdm to packet gain in 0.1dB units; restart required after change

p2t_gain 0              # packet to tdm gain in 0.1dB units; restart required after change

bonding 0               # /0/1/bond3          enable bonding, 1=bond0

close_ssrcv 1           # Close channel on 3 SSRC Violations: ; 0=do not close; 1=close;restart required after change

mrst 0                  # MSP reset mode: 0 = do not reload MSP, 3 = reload firmware from file specified in "axf" parameter,
                        # 2 = reload firmware from NOR fash,10= execute /mnt/app/bin/msp_reset script;
                        # restart required after change

rc_cmd                  # execute command specified as value at the beginning # default_value ""

reg_2833 0              # regenerate received rfc2833 digit to TDM , default 1.

inband_dtmf 0           # do not suppress detected (on TDM) dtmf digit, play it inband,default 1.

tdm_to_2833 0           # detected (on TDM) dtmf digit, send as rfc2833,default 1.

syslog 1                # Activate syslog,default 0

skip_miro_init          # 0/1 defaults depends on systruct

sysstruct               # 0 => xVoIP, 1 => PGVoIP, 2 => PGetx+PCIVOIP

iptonedet 0             # detect some IP-side tones, default 1

bindir      /mnt/app/bin/      # /path/to/bin/directory/

datadir /mnt/app/data/        # /path/to/data/directory/

cfgdir /mnt/app/cfg/          # /path/to/cfg/directory/

outdir /mnt/app/out/          # /path/to/out/directory/

devdir /mnt/app/dev/          # /path/to/dev/directory/

libdir      /mnt/app/lib/      # /path/to/lib/directory/

report_csme 0                # activates csme tracing

ec 0x8007                    # echo cancelation bitmap (see CRM ECHOCAN); to disable EC = 0x0000, RGW_arad = 0x8012;

ecctrl 0x0005                # echo canceller features bitmap (see CRM EC_CONTROL); RGW_arad = 0x000B

dump_tdm 0                   # activate TDM trace bitmap          0x1:tx 0x2:rx

csme_if ""                   # <tcp_port|/mnt/app/dev/msppci_0|eth4> custom CSME interface

tdmXpar                      # SETUP_TDM_PARAMS bitmap=(par0<<16)|par1 (see CRM SETUP_TDM_PARAMS) ;defaults depends on systruct

arpd_ifs                      # <eth0 eth2> for custom arpd interfaces;defaults depends on systruct

emac_mii 0                   # 0/1 to select mii mod for EMACS

rtp_dmac 0:0:0:0:0:0          # to overwrite destination mac address for all rtp streams

debug_htdm 0                 # 0/1 debug htdm messages

ulaw 0                       # 0/1 ulaw

ascii_proto 0                # 0/1      ascii_proto

record_bmp 0                 # record tdm level bitmap 0x1:tx.raw 0x2:rx.raw 0x10:tx.npipe 0x20:rx.npipe

record_dir /mnt/app/rec       # /path/to/dir/for/record

jitterbuff 0xffff            # jitter_buffer in ms (0..200);

```

mspd_log

Some important info in mspd log file:

- **First column** represents timestamp in format hh:mm:ss.ms
- **First symbol in the second column** represents the messages priority (D diagnostic, I info,! important, W warning, E error, F fatal)
- **Rest of the second column** represents the sender thread (Mgr,SL,Msg,ARPD,RX,TX,CmdEx).

On first Mspd log line you can see:

- main thread pid
- MSPD release

- Build time stamp
- Start time stamp

Follows lines:

- **Firmware version:** test_bug36516_03_v2_04_1, checksum: 36B0,bond 0
- **Device Type :** M82820

All command received from clients (centrala) begins with **msgrx** and all indications sent to clients(centrala) begins with **msgtx**.

When msdpd has made its initialization and is ready to receiving commands from clients, the program broadcasts **Imsp 65535** to all connected clients.

Note: To find out the device type use command cat /proc/msp as root

Table 24 M825xx Channel Density Values⁽¹⁾

Supported Voice Codecs	Channel Density									
	M82501	M82505	M82506	M82510	M82511	M82514	M82515	M82520	M82524	M82530
G.711/20	16	32	32	64	64	64	64	128	128	128
G.711/10	16	32	32	64	64	64	64	96	96	96
G.711/5	16	32	32	32	32	32	32	64	64	64
G.726/20	4	8	8	16	16	24	32	32	48	64
G.726/10	4	8	8	16	16	24	32	32	48	64
G.729a	4	8	8	16	16	24	32	32	48	64
G.723.1	4	8	8	16	16	24	24	32	48	64
G.729e*	4	8	8	12	12	16	16	24	32	40
iLBC*	4	8	8	12	12	16	16	24	32	40
GSM FR*	4	8	8	16	16	16	24	24	48	64
AMR*	4	8	8	16	16	16	16	24	40	48

Table 24 M825xx Channel Density Values⁽¹⁾ (Continued)

Supported Voice Codecs	Channel Density									
	M82501	M82505	M82506	M82510	M82511	M82514	M82515	M82520	M82524	M82530
T.38	4	8	8	16	16	24	32	16	24	32
Conferencing	4	8	8	16	16	24	32	32	48	64
TDM Hairpinning	16	32	32	64	64	64	96	128	128	256
TDM Hairpinning (Guaranteed)	16	32	32	64	64	64	96	128	128	256

(1) The numbers represented in this table reflect the maximum channel densities for specific codecs on a specific device. For example, the maximum number of G.711 channels that can be created on the M82510 device is 64 channels. Any attempt to create an additional channel (even a Hairpinning channel) on that device is not permitted.

Table 25 M825xx Processing Details

Details
<ul style="list-style-type: none"> All Channel densities include support for: <ul style="list-style-type: none"> Echo Cancellation Tone Detection Tone Generation VAD and CNG For G.723, the minimum packet interval is 30 ms For G.726, supported packet intervals are 10 ms, 20 ms, 30 ms, 40 ms, 50 ms and 60 ms. For G.729ab, supported packet intervals are 10 ms, 20 ms, 30 ms, 40 ms, 50 ms, 60 ms, and 80 ms. <p>Note: Large packet intervals (50 ms, 60 ms, and 80 ms) are not recommended due to the additional latency that is introduced.</p>

Table 41 M828xx Voice Channel Density

Supported Voice Codecs	Channel Density					
	M82803	M82801	M82805	M82810	M82815	M82820
Hairpinning	N/A	32	64	128	192	256
G.711 -10 ms	N/A	16	32	48	64	64
G.726	N/A	4	8	16	24	32
G.729ab	N/A	4	8	16	24	32
G.723.1	N/A	4	8	16	20	24
T.38	N/A	4	8	16	16	16
AMR*	N/A	4	8	16	16	16
Conferencing*	N/A	4	8	10	20	24

* Contact your sales representative for information regarding this optional feature.

NOTE:

The M828xx device reaches 100 Mb/sec. full duplex data throughput for each of the two Ethernet ports with a standard packet size of 576 bytes.

Table 42 M828xx Processing Details

Details
<ul style="list-style-type: none"> All Channel densities include support for: <ul style="list-style-type: none"> Echo Cancellation Tone Detection Tone Generation VAD and CNG For G.711, supported packet intervals are 10 ms, 20 ms, 30 ms, 40 ms, 50 ms and 60 ms. For G.723, the minimum packet size is 30 ms and supported packet intervals are 30 ms and 60 ms. For G.726, supported packet intervals are 10 ms, 20 ms, 30 ms, 40 ms, 50 ms and 60 ms. For G.729a/b, supported packet intervals are 10 ms, 20 ms, 30 ms, 40 ms, 50 ms, 60 ms, and 80 ms. <p>Note: Large packet sizes (50 ms, 60 ms, and 80 ms) are not recommended due to the additional latency that is introduced.</p>

Rtprx pool

[GoTo >Main Page](#)

Rtptx pool

[GoTo >Main Page](#)

Definition: Build and send RTP packets. Payload content of RTP packets is taken from one or more files given as a parameter. Can receive maximum three files as parameters to play Used to play voice messages, see [Serv Play File](#) or [Serv Play Release](#)



Best Practice

Before they can be used rtprx_pool and rtptx_pool must be activated in file exec.cfg. Check the file for more details

```
./rtptx_pool -h
```

```
Usage: bin/rtptx_pool [OPTIONS]
```

OPTIONS:

-c,	--path_cfg	PATH_CFG	path to the configuration file, default ../cfg/
-p,	--pid	PID	PID of parent process
-h,	--help		Display usage informations
-v,	--version		Display version

Default binary file path: /mnt/app/bin/rtptx_pool

Default configuration file path: /mnt/app/cfg/rtptx_pool.cfg

```
# debug is the only parameter
# default 2
# 0 = NO debug
# 1 = ERROR debug
# 2 = ERROR + WARN debug
# 3 = ERROR + WARN + INFO debug
# 4 = ERROR + WARN + INFO + FULL debug
# 5 = ERROR + WARN + INFO + FULL + VERBOSE debug
debug 2
```

Accept ascii commands from stdin and send the response and debug on stdout.

```
Rx:
start
localport: 15001
remote: 10.0.0.10:11008
codec: pt=0;size=160;ms=20;ssrc=1948547190
file: ../raw//ivr/ivr_00.en
file2: ../raw//ivr/ivr2_00.en
```

```
file3: ../raw//ivr/ivr3_00.en
```

Rx:

```
stop - stop playing the files
```

Tx:

stop_ack - acknowledge sent to stop command

Recmail

[GoTo >Main Page](#)

Definition: This application is used to connect on an email account and retrieve mails which have as SUBJECT a phone number and send mail body as a SMS.

The application name is "recmail" and is

located in "/mnt/app/bin". To be able to send sms messages recmail works with **centrala** and **sendsms**

In order to be run at startup, you have to add a line in /mnt/app/bin/start_app: the line format will be "./recmail &".



Best Practice

When adding applications to start_app make sure they are added before centrala. Also don't forget to add & at the end of the application or centrala won't start

This application has a configuration file in /mnt/app/cfg/mail2sms.cfg. This file describes the IP (or the name) of the EMAIL server (POP3 mail server). The format of that line is "<username> <password> <IP/name server>".

This application is running correctly if "sendsms" application is located in "/mnt/app/bin" folder.

There are few limitations involving this application:

- the email with number declared in subject - which are the email for which body will be sent - has to be PlainText; other emails will be ignored (but deleted);
- one of the declared directions (trunks) from the TOPEX box has to be SENDSMS;
- one route has to be available for the number present in the mail subject;
- the length of the number from the subject has to be 10 digits;

To check the connectivity with the POP3 server, please try:

```
-> telnet <IP/name server> 110
```

```
+OK mail.ro POP3 server
```

```
-> user <username>
```

```
+OK
```

```
-> pass <password>
```

```
+OK
```

```
-> quit
```

Smtpmail

[GoTo >Main Page](#)

Definition: Command line SMTP client Used to send e-mails from centrala and heartbeat applications.

Starting with version 1.3.5 command line option have priority vs configuration file options

Starting with version 1.3.7 configuration file path can be given as command line argument, default ../cfg/

```
./smtpmail -h
```

```
Usage: ./smtpmail [options] recipients ...
```

Message Header Options:

```
-i, --ipaddress=STR      ip adress of my host
-s, --subject=STR        subject line of message
-f, --from=ADDR           address of the sender
-r, --reply-to=ADDR       address of the sender for replies
-e, --errors-to=ADDR      address to send delivery errors to
-c, --carbon-copy=ADDR    address to send copy of message to
-b, --body=FILE           message body file
-a, --attach=FILE         attach file
-D, --delete              delete body file on exit
-R, --remove              delete attach file on exit
```

Processing Options:

```
-S, --smtp-host=HOST      host where MTA can be contacted via SMTP
-P, --smtp-port=NUM       port where MTA can be contacted via SMTP
-M, --mime-encode         use MIME-style translation to quoted-printable
```

Giving Feedback:

```
-v, --verbose             enable verbose logging messages
-V, --version             display version string
-h, --help               display this page

-x, --path_cfg            path to the configuration file
```

Default binary file path: /mnt/app/bin/smtpmail

Default configuration file path: /mnt/app/cfg/smtpmail.cfg

```
# IP address of SMTP server used to send e-mail
smtp_server_ip 69.77.184.28
```

```
# IP port of SMTP server
smtp_server_port 25
```

```
# name of from header filled in e-mail
from_name VoiceMail
```

```
# this field (IP or hostname) will be shown in the From field of the e-mail
# this value has higher priority then the value of the ipaddress given from the command line
# smtpmail -h see all command line options
```

from_ip topex.ro

Sendsms

GoTo >Main Page

SMS can be send directly from TOPEX gateway based on 'sendsms' application. This application must be present in '/mnt/app/web/bin/' in case when SMS is sent from web page or in '/mnt/app/bin/' in case when recmail application is used.

You can send SMS directly to a GSM number with the following command:

```
./sendsms <number> <text> SendSms localhost
```

- number is the destination GSM number
- text is the SMS text (has to be urlencoded). When using sendsms from command line, use "+" instead of " " for formatting or put the entire text between quotation marks (for example: "Hi, how are you?").

If you want to send SMS to a group of numbers - you have to create in '/mnt/app/cfg/' the file sms_groups.cfg. Here you can use the 'grup' keyword to define names of groups. Following such a line are the GSM numbers belonging to that grup.

For example:

File: /mnt/app/cfg/sms_groups.cfg

```
grup test2
338732875435
32654326463
324762364234
2346327462346

grup test
07233378777
07212227878
07422211223
```

The name of the group in last sample was 'test2'.

The list of numbers continued until an empty line is present of another group is starting.

To send sms to a group of numbers try: smsgrp <group> <text> SendSms localhost where group is the name of the group of GSM numbers. (smsgrp is present in '/mnt/app/web/bin' or in '/mnt/app/bin/smsgrp').

To send a sms from a specific port use the following command. The port number should have 3 digits (ex:001,032,120) and on the gateway you should have a route with incoming direction SENDSMS, prefix – "***", action – SERV, destination – 11 (SELECT PORT), ignore =2. The port number can be seen on the port : G000, G032,G120. ./sendsms **<port_number><number> <text> SendSms localhost

Mysql client

[GoTo >Main Page](#)

Radius billing

[GoTo >Main Page](#)

Topex Radius AAA (Authentication, Authorization and Accounting) client
Used to send radius requests to the server.

Implemented requests:

- Access Request - for authentication and authorization
- Accounting Request - for accounting

Standards compliant:

- RFC 2865 - RADIUS
- RFC 2866 - RADIUS Accounting

Default binary path: /mnt/app/bin/radius_billing

Default configuration path: /mnt/app/cfg/radius_billing.cfg

```
# 0= no debug, 1=minimum debug, 2=full debug
debug 2
```

```
# radius server IP address
radius_server 192.168.1.11
```

```
# radius dictionary used by radius_billing client; 0=Topex; 1=Quintum; 2=Mind; default 0
# same value must be also in exec.cfg at radius_dictionary line
dictionary 0
```

```
# UDP port for authentication radius packets
auth_port 1812
```

```
# UDP port for accounting radius packets
acct_port 1813
```

```
# shared secret between NAS and RADIUS server
# in radius server the same value of secret must be configured for this client
secret 99SeCrET11
```

```
# value in seconds for waiting response from RADIUS server
timeout 4
```

```
# the maximum number of repeated requests before to give up
retries 3
```

```
# on SSW the IP of network interface used for sending radius packet
# on multiaccess, qutex, e-ones PG card IP must be used
```

NAS_IP 192.168.1.50

Pgsql sip pool

[GoTo >Main Page](#)

Pgsql pcodedel

[GoTo >Main Page](#)

Location: /mnt/app/bin/pgsql_pcodedel

Definition: Used by centrala to erase a recharging code from simserver database after successful recharge

Note: pgsql_pcodedel connects directly to postgresql server running on simserver. IP of the equipment must be added in postgresql access list

Config file:/mnt/app/cfg/pgsql_pcodedel.cfg

```
server 1
first_conn_string dbname=prepaid host=84.22.50.108 user=gsmgw password=db@prepaid
```

host=ip of simserver

Pgsql pcode

GoTo >Main Page

Location: /mnt/app/bin/pgsql_pcode

Definition: Used for recharging feature of simserver.Used by centrala to download a recharging code from simserver database

Note: **pgsql_pcode connects directly to postgresql server running on simserver. IP of the equipment must be added in postgresql access list**

Config file:/mnt/app/cfg/pgsql_pcode.cfg

```
server 1
first_conn_string dbname=prepaid host=84.22.50.108 user=gsmgw password=db@prepaid
```

host=ip of simserver

Pgsql pcodeerror

GoTo >Main Page

Location: /mnt/app/bin/pgsql_pcodeerror Used for recharging feature of simserver.

Definition: Used by centrala to signal that a error has been received when trying to use a recharging code from simserver database

Note: **pgsql_pcodeerror connects directly to postgresql server running on simserver. IP of the equipment must be added in postgresql access list**

Config file:/mnt/app/cfg/pgsql_pcodeerror.cfg

```
server 1
first_conn_string dbname=prepaid host=84.22.50.108 user=gsmgw password=db@prepaid
```

host=ip of simserver

Pgsql sms

GoTo >Main Page

Location: /mnt/app/bin/pgsql_sms

Definition: Used by centrala to insert received sms messages in to simserver database

Note: pgsql_sms connects directly to postgresql server running on simserver. IP of the equipment must be added in postgresql access list


Config file:/mnt/app/cfg/pgsql_sms.cfg

```
server 1
first_conn_string dbname=prepaid host=84.22.50.108 user=gsmgw password=db@prepay
host=ip of simserver
```

Administration

Default Passwords

Default Passwords




tpxadm/u53rp455

root/5y5t3mp455

Note: On older models passwd are

gsmgw/5tgb4rf

root/91qwerty19



gsmgw/5tgb4rf

root/91qwerty19

Operating Sistem Structure

As you may have noticed, Linux organizes its files differently from Windows. First the directory structure may seem unlogical and strange and you have no idea where all the programs, icons, config files, and others are. This is by no means a complete list of all the directories on Linux, but it shows you the most interesting places in your file system.

The **root** directory. The starting point of your directory structure. This is where the Linux system begins. Every other file and directory on your system is under the root directory. Usually the root directory contains only subdirectories, so it's a bad idea to store single files directly under root.

Don't confuse the root directory with the root user account, root password (which obviously is the root user's password) or root user's home directory.

/boot

As the name suggests, this is the place where Linux keeps information that it needs when booting up. For example, this is where the Linux kernel is kept. If you list the contents of `/boot`, you'll see a file called `vmlinuz` - that's the kernel.

/etc

The configuration files for the Linux system. Most of these files are text files and can be edited by hand. Some interesting stuff in this directory:

/etc/inittab A text file that describes what processes are started at system bootup and during normal operation.

/etc/fstab This file contains descriptive information about the various file systems and their mount points

/etc/passwd A file that contains various pieces of information for each user account. This is where the users are defined.

/bin, /usr/bin These two directories contain a lot of programs (binaries, hence the directory's name) for the system. The `/bin` directory contains the most important programs that the system needs to operate, such as the shells, `ls`, `grep`, and other essential things. `/usr/bin` in turn contains applications for the system's users. However, in some cases it really doesn't make much difference if you put the program in `/bin` or `/usr/bin`.

/sbin, /usr/sbin Most system administration programs are stored in these directories. In many cases you must run these programs as the root user.

/usr This directory contains user applications and a variety of other things for them, like their source codes, and pictures, docs, or config files they use. `/usr` is the largest directory on a Linux system, and some people like to have it on a separate partition. This is where you install apps and other files for use on the local machine. If your machine is a part of a network, the `/usr` directory may physically be on another machine and can be shared by many networked Linux workstations. On this kind of a network, the `/usr/local` directory contains only stuff that is not supposed to be used on many machines and is intended for use at the local machine only.

/lib The shared libraries for programs that are dynamically linked. The shared libraries are similar to DLL's on Windows.

/home This is where users keep their personal files. Every user has their own directory under `/home`, and usually it's the only place where normal users are allowed to write files. This is where `gsmgw` and `tpxadm` user home is located

/root The superuser's (root's) home directory. Don't confuse this with the root directory (`/`) of a Linux system.

/var This directory contains variable data that changes constantly when the system is running.

Some interesting subdirectories:

/var/log A directory that contains system log files. They're updated when the system runs, and checking them out can give you valuable info about the health of your system. If something in your system suddenly goes wrong, the log files may contain some info about the situation. Programs can write their temporary files here.

/dev The devices that are available to a Linux system. Remember that in Linux, devices are treated like files and you can read and write devices like they were files. For example, `/dev/fd0` is your first floppy drive, `/dev/cdrom` is your CD drive, `/dev/hda` is the first IDE hard drive, and so on. All the devices that a Linux kernel can understand are located under `/dev`, and that's why it contains hundreds of entries.

/mnt This directory is used for mount points. This attaching is called mounting, and the directory where the device is attached is called the mount point. This is where the partition containing Topex software and configurations is mounted

/mnt/app/bin

Folder containing binary files and modules. This is the folder that houses main applications like `centrala`, `h323_apc`, `mspd`, `SS7_apc` ...

/mnt/app/cfg

Folder containing configuration files.

/mnt/app/out

This folder contains all the files generated by `centrala` and other apps installed on the equipment. `Cdr` and `log` files are stored here

/mnt/app/dev

Similar to `/dev/` this folder contains devices used by Topex software

/mnt/app/lib

Similar to `/lib/` this folder contains libraries used by Topex software

/mnt/app/raw

Contains raw audio files that are used for apps such as `voicemail`, `music on hold`, `ivr`. These files are coded with G711 and G729 codec

/proc This is a special directory. Well, actually `/proc` is just a virtual directory, because it doesn't exist at all! It contains some info about the kernel itself. There's a bunch of numbered entries that correspond to all processes running on the system, and there are also named entries that permit access to the current configuration of the system. Many of these entries can be viewed.

Telnet commands

GoTo >Main Page > centrala

To view the telnet commands you have to check the telnet port in exec.cfg, see bellow line:

```
telnet 23 // it can be another port
```

Then you have to use the telnet command:

```
telnet localhost 23

Trying 127.0.0.1...
Connected to localhost.
Escape character is '^['.
```

COMMAND

help

```
help
topexsw>help
show all the commands that can be executed from command line and description
```

accessin

accessin
show the loaded accessin configuration

Example:
topexsw>accessin

Access IN:

Id	Classid	Resellerid	IP	Mask	Port	PortStart	PortEnd	Proto	Prefix	NrDig	EndCause	IgnANI	InsANI	IgnDNIS	InsDNIS
14	16	1	192.168.52.2	32	0	0	0	H323		0	34	0		0	
13	15	1	192.168.52.2	32	0	0	0	SIP		0	34	0		0	
12	10	1	192.168.52.221	32	0	0	0	H323		0	34	0		0	
11	12	1	192.168.52.23	32	0	0	0	SIP		0	34	0		0	

Total: 4

accessout

accessout
show the loaded accessout configuration

Example:
topexsw>accessout

Access OUT:

Id	Classid	Resellerid	IP	Port	Proto	Transport	MediaParam
4	7	1	192.168.52.60	0	SIP	UDP	
7	13	1	192.168.52.23	0	H323	DEFAULT	
1	2	1	0.0.0.0	0	SIP	UDP	

```
13      21      1          192.168.102.200      1722  H323      DEFAULT
Total: 4
```

add_to_credit [clientid] [add_credit]

increment/decrement credit of specified prepaid client id
in order to decrement credit put with '-' before add_credit paramater
starting with 09 Julie 2009; not included in version 4.3.30; see centrala version

all queue

show the calls that are waiting in the call center queue

ani users

show ANI users loaded in memory
starting with 19 August 2009, on versions >= 4.3.88

billing fields number

show the value of the billing fields number set in exec.cfg file

billing price [billing profile id] [billing price id]

- show billing price id linked to specified billing profile id
- implemented starting with 4.3.97, see centrala version
- starting with 07 Ian 09 billing profile id must not be passed as argument, only billing price id is needed

billing profile [profile id]

show specified profile id

billing profiles

show all billing profiles

cards

- show all cards loaded in memory
- starting with version 4.3.103

class translations [class id]

show translations for specified class id

connect2 [arg1 arg2]

connect two channels via local matrix, arg1 and arg2 is hexa format of channel|(flow<<5)
calls connect2(arg1, arg2) function

count all online users

```
count of all sip online users, include also forked online users
```

count billing prices

- count all billing prices loaded in memory
- starting with 5 Jan 09 on versions >= 4.3.88

clear all dialog states [sip user name]

```
clear all dialog states for specified user name
```

count offline users

```
count of all off line users
```

count online users

```
count of all online users
```

count prepaid users

- count of all prepaid users loaded in memory
- starting with 07 Jan 09 on versions >= 4.3.88

count sip users

```
count of all created users
```

class translations

```
show translations for specified class id
```

classes

```
show softswitch classes loaded into memory
```

debug on

```
enable the console debugging
```

debug off

```
disable the console debugging
```

dialog states

```
show call state for each dialog
```

destination groups

- show destination routing groups loaded in memory
-

- starting with version 4.3.117

equipments

```
show equipments list
starting with version 4.3.97, see centrala version
```

fdwatch connections

```
show all fdwacth connections (telnet, httpd etc.)
```

forking group [group number]

```
show sip users from specified forking group
```

fw subscriptions

```
show all event subscriptions forwarded by SIP proxy
```

global rules

```
show global admin rules list
```

global translation

```
show global translation list
```

hunting group [group number]

```
show sip users from specified hunting group
```

interface ip

```
show the interface ip configuration loaded from sip_pbx.cfg file
print also the file descriptor created on each interface
```

ivr [filename]

- show IVR (Interactive Voice Response) scrip file
- starting with version 4.3.117 if the IVR file is not specified command will list all IVR files configured on routes

kill all calls

```
kill all calls

kill all current calls connected; it kills both trunk and proxy calls, the calls that are in ringing, proceeding state will not be killed

Example:

topexsw>view calls

call port=65535 dir=SIP_USERS type=in state=connected proto=SIP ani=0317100027 dnis=0717100021 ips=192.168.144.148 iprtps=192.168.144.148
duration=2 sid=20ae5201 pid=1 hld_rq=65535

call port=65535 dir=OUT_H323_A_102_200 type=out state=connected proto=H323 ani=0317100027 dnis=0717100021 ips=192.168.102.200
iprtps=192.168.102.200 duration=2 sid=20ae5201 pid=2 hld_rq=65535
```



```
topexsw>kill all calls

Tx M_KILL to 1 connected calls


topexsw>view calls

NRCALLS 0
```

kill call [port]

kill call [port]

kill call from specified port

Note: if the call is made without transcoding you will see the 65535 port allocated to all the calls thees call can be killed with

kill pidcall [pid] command

Example:

```
topexsw>view calls

call port=65535 dir=SIP_USERS type=in state=connected proto=SIP ani=0317100027 dnis=0717100021 ips=192.168.144.148 iprtps=192.168.144.148
duration=6 sid=6fbf0b6b pid=19 hld_rq=65535

call port=65535 dir=OUT_H323_A_102_200 type=out state=connected proto=H323 ani=0317100027 dnis=0717100021 ips=192.168.102.200
iprtps=192.168.102.200 duration=6 sid=6fbf0b6b pid=20 hld_rq=65535

call port=1580 dir=SIP_USERS type=in state=connected proto=SIP ani=0317100033 dnis=0717100021 ips=192.168.52.21 iprtps=192.168.52.21
duration=3 sid=5daf55b5 pid=21 hld_rq=0

call port=1583 dir=OUT_H323_A_102_200 type=out state=connected proto=H323 ani=0317100033 dnis=0717100021 ips=192.168.102.200
iprtps=192.168.102.200 duration=3 sid=5daf55b5 pid=22 hld_rq=0

NRCALLS 4


topexsw>kill call 1580

kill call on port 1580 -> Tx M_KILL to pid 21


topexsw>view calls

call port=65535 dir=SIP_USERS type=in state=connected proto=SIP ani=0317100027 dnis=0717100021 ips=192.168.144.148 iprtps=192.168.144.148
duration=18 sid=6fbf0b6b pid=19 hld_rq=65535

call port=65535 dir=OUT_H323_A_102_200 type=out state=connected proto=H323 ani=0317100027 dnis=0717100021 ips=192.168.102.200
iprtps=192.168.102.200 duration=18 sid=6fbf0b6b pid=20 hld_rq=65535

NRCALLS 2
```

kill class calls [class id]

- kill all current (incoming and outgoing) calls on specified class id

kill pidcall [pid]

kill pidcall [pid]

kill cctl call with specified pid

Example:

```
topexsw>view calls

call port=65535 dir=SIP_USERS type=in state=connected proto=SIP ani=0317100027 dnis=0717100021 ips=192.168.144.148 iprtps=192.168.144.148
duration=8 sid=79cce832 pid=29 hld_rq=65535
```

```

call port=65535 dir=OUT_H323_A_102_200 type=out state=connected proto=H323 ani=0317100027 dnis=0717100021 ips=192.168.102.200
iprtps=192.168.102.200 duration=8 sid=79cce832 pid=30 hld_rq=65535

call port=1597 dir=SIP_USERS type=in state=connected proto=SIP ani=0317100033 dnis=0717100021 ips=192.168.52.21 iprtps=192.168.52.21
duration=5 sid=072d9439 pid=31 hld_rq=0

call port=1539 dir=OUT_H323_A_102_200 type=out state=connected proto=H323 ani=0317100033 dnis=0717100021 ips=192.168.102.200
iprtps=192.168.102.200 duration=5 sid=072d9439 pid=32 hld_rq=0

NRCALLS 4

topexsw>kill pidcall 29

send M_KILL to pid 29

topexsw>view calls

call port=1597 dir=SIP_USERS type=in state=connected proto=SIP ani=0317100033 dnis=0717100021 ips=192.168.52.21 iprtps=192.168.52.21
duration=19 sid=072d9439 pid=31 hld_rq=0

call port=1539 dir=OUT_H323_A_102_200 type=out state=connected proto=H323 ani=0317100033 dnis=0717100021 ips=192.168.102.200
iprtps=192.168.102.200 duration=19 sid=072d9439 pid=32 hld_rq=0

NRCALLS 2

```

kill proxypidcall [pid]

kill proxypidcall [pid]

kill proxy call with specified pid

licence

show license info

make offline [sip user name]

make offline all instances of the specified sip user

Example:

topexsw>sip online

SIP ON-LINE USERS:

clientid	classid	username	contact	expire	nat_bind	nat	cseq	transport
46	2	0317100027	0317100027@192.168.144.148:5060	56	192.168.144.148:5060	0	17206	UDP
40	2	0317100021	0317100021@192.168.52.221:5063	51	192.168.52.221:5063	0	3626	UDP
48	2	0317100033	0317100033@192.168.52.21:5060	20	192.168.52.21:50787	0	13107	UDP
9	2	0317100022	0317100022@192.168.144.144:2051	63	192.168.144.144:2051	0	4711	UDP

topexsw>make offline 0317100021

DELETE online user '0317100021' contact '0317100021@192.168.52.221:5063' expire 1234514389

topexsw>sip online

SIP ON-LINE USERS:

clientid	classid	username	contact	expire	nat_bind	nat	cseq	transport
46	2	0317100027	0317100027@192.168.144.148:5060	38	192.168.144.148:5060	0	17206	UDP
48	2	0317100033	0317100033@192.168.52.21:5060	57	192.168.52.21:50787	0	13109	UDP
9	2	0317100022	0317100022@192.168.144.144:2051	45	192.168.144.144:2051	0	4711	UDP

```
Total: 3
```

malloc counters

```
show some memory allocated counters from sip queues
```

monitored users

```
show monitored user (lawful intercepted)
starting with version 4.3.101, see centrala version
```

pickup group [group number]

```
show sip users from specified pickup group
```

port subscriptions

```
show all port event subscriptions
```

prepaid users

```
show all prepaid users loaded in memory
```

reject all calls

```
All incoming calls are rejected from now on!.
You need to restart the application in order to receive new calls!
```

queue [queue number]

```
show details from specified call center queue
```

quit

```
exit from telnet
```

register users

```
show memory SIP register users list
```

res block

```
unblock one cic or more cic's on a SS7 connection
```

res moni

```
release current monitored port from direct monitoring
```

reseller rules [reseller id]

```
show rules list for specified reseller id
```

reseller translate prefix [reseller id]

```
show translate prefix list for specified reseller id
```

resellers

```
show softswitch resellers loaded in memory
```

restrictions

- show restriction classes loaded in memory
- starting with version 4.3.116

ring state remote

```
show ring state remote queue
```

save billing queues

```
write SQL CDRs from billing pool queues to text files see Billing generic (apply to PGSQL, MySQL, MSSQL)  
you can check after the status of billing pools with command: view pools
```

search online [pattern]

```
search pattern in online sip users list  
matching is done with strstr function
```

search user [pattern]

```
search pattern in sip users list
```

sendmes

```
send a specific message to a card
```

sendmeseones

```
send a specific message to a card on a EONES equipment  
sendmeseones <card> 2 0001  
send messeones <card> 2 22001
```

set block

```
block one or more cics on a SS7 connection
```

set mind server

```
allow you to set manually the active mind radius server  
accepted values: 1=first server; 2=second server
```

Example:

```
topexsw>view mind server  
Active mind server is 1  
topexsw>set mind server 2
```

```
topexsw>view mind server
Active mind server is 2
```

set moni [port]

```
set one port for direct monitoring
```

show ani user [ANI] [classid]

- show all user details for specified ANI linked to specified class id; for global ANI users you can skip the class id parameter or you can put 65535
- Example:
 - topexsw>show ani user 111111111
- starting with date 16 November 2009 on versions >= 4.3.88

show cpc

- show calling party category map list

show accessin [id] [prefix]

- show access in details for specified id and prefix
- Starting with version 4.3.111

show prepaid user [client id]

- show all prepaid user details for specified client id
- Starting with 30 September 2009 on versions >= 4.3.88

show sip online [user name]

```
show all online details for specified username
```

Example:

```
topexsw>show sip online 0317100027
```

SIP ON-LINE USER:

```
Username:          '0317100027'
IP:                '192.168.52.119'
Contact:           '0317100027@192.168.144.148:5060'
Call-ID:           '8db5ec8e6c8ecd31@192.168.144.148'
Cseq:              17212
Expire:            1234514664
Expire2:           65
NAT bind:          '192.168.144.148:5060'
Dialog_event:      0
```

show sip user [user name]

show all user details for specified user name

Example:

```
topexsw>show sip user 0317100027
```

SIP USER:

Account_state:	0
ClientID:	46
ClassID:	2
PrepaidID:	0
BillingProfileID:	0
Username:	'0317100027'
GSM number:	
Alias:	none
Password:	'0317100027'
RTP proxy:	2
Transcoding:	0
Public:	'0.0.0.0/0'
Private:	'0.0.0.0/0'
Display_name:	
Privacy_display:	0
CLI_proxy:	'0317100027'
Privacy_proxy:	0
CLI_UA:	'0317100027'
Privacy_UA:	0
CLI_centrex	'Anonymous'
Privacy_centrex:	0
Centrex_gr	0
Centrex_alias:	none
Description:	
Callstate:	idle
CallForward:	0
CallForwardState:	0
ForwardSelective:	0
ForwardNr_offline:	
ForwardNr_busy:	
ForwardNr_noanswer:	
ForwardNr_always:	
CallWait:	0
CallWaitState:	0
VoiceMail:	0
VoiceMailState:	0
VoiceMailNumber:	
VoiceMail2emailState:	0
VoiceMail2email:	
Missed2email:	0
Missed2emailState:	0

```
Missed2email:
Reject_no_ANI:      0
Do_not_disturb:     0
CallPickUpGroup:    0
CallHuntingGroup:   0
CallHuntingPriority: 0
Forking_group:      0
Rules_in:           0
Rules_out:          0
Rule:               none
Publish_presence:    0
Multiple_contacts:   1
Queue[00]:          0
Queue[01]:          0
Queue[02]:          0
Queue[03]:          0
Queue[04]:          0
CC queue [00]:      NULL
CC queue [01]:      NULL
CC queue [02]:      NULL
CC queue [03]:      NULL
CC queue [04]:      NULL
```

sip pp

```
show SIP public/private IP class access list
```

sip publish

```
show all published events for specified online user
```

sip offline

```
show offline sip users list
```

sip online

```
show online sip users list
```

sip online forked

```
show forked online sip users list
```

sip subscriptions

```
show all sip users event subscriptions
```

sip users

```
show sip users list
```

sip vm notify

```
show SIP Voice mail notify list
```

subscriber [port]

```
show fxs subscriber settings on specified port
```

subscribers

```
show all fxs subscribers list
```

tetrapol

Show info about tetrapol ports installed.

This command is available only when centrala is built with TETRAPOL define, see centrala version

Example:

Tetrapol Ports Info:

Port	Coordcom_port	Address	STCP_version	RSW_id	BS_id	ST_init
24	9	008400806	5	0	0	1
Local	OG/COV	616/200 619/200				
National	OG/COV					

25	10	008400805	5	0	1	0
Local	OG/COV	616/200 619/200				
National	OG/COV					

26	11	008400802	5	0	0	0
Local	OG/COV	616/200 619/200				
National	OG/COV					

27	12	000000000	0	0	0	0
Local	OG/COV					
National	OG/COV					

Total: 4

Port = port number from Topex numbering plan.

Coordcom_port = port number from CoordCom numbering plan.

Address = is the number of tetrapol station.

STCP_version = System Terminal Control Protocol version


```
RSW_id      = Radio Switch Id
BS_id       = Base Station Id
ST_init     = indicate if the station is registered or not to the network
              0 = not registered
              1 = registered
```

transactions client

```
show number of free/busy SIP client transactions
```

tls sock [file descriptor]

```
show details for specified TCP/TLS socket
```

ts sock busy

```
show TCP/TCP sockets from busy queue
```

ts sock free

```
show TCP/TLS sockets from free queue
```

ts sock wait

```
show TCP/TLS sockets from time wait queue
```

unreject all calls

- The reverse of command 'reject all calls'
- Starting with version 4.3.106

update config

```
update (reload) configuration from database into memory
```

view allports

```
show all ports
```

view calls

```
show all the calls that are in/out on a trunk
```

Example:

```
topexsw>view calls
```

```
call port=65535 dir=SIP_USERS type=in state=connected proto=SIP ani=0317100027 dnis=0717100021 ips=192.168.144.148 iprtps=192.168.144.148
```

```
duration=2 sid=20ae5201 pid=1 hld_rq=65535
```

```
call port=65535 dir=OUT_H323_A_102_200 type=out state=connected proto=H323 ani=0317100027 dnis=0717100021 ips=192.168.102.200
```

```
iprtps=192.168.102.200 duration=2 sid=20ae5201 pid=2 hld_rq=65535
```

```
NRCALLS 2
```

view cicstate

show the status of each cic if the command returns a empty list the the cic is in the OK state

view class [classid]

view details for specified class id

view classes

view classes list

view cardstate

show the status of the cards loaded into memory

view dirasr

show a statistical asr/acd on each class

view dircounters

show a statistical cost/speach on each class

view groups

view groups info

view linkstate

show the status of the psychical link on each E1 port

view mind server

show the active mind radius server, see also Radius AAA

Note: if you have more than one mind server you can see the active one

Example:

```
topexsw>view mind server
```

Active mind server is 1

Stop the first MIND server and check again the active mind server:

```
topexsw>view mind server
```

Active mind server is 2

view pools

```
show client pools info
```

view ports

```
show installed ports with state != FREE
```

view port [port_number]

```
show specified port
```

view portsoncard [card_number]

```
show all ports on specified card
```

view portsonequipment [equipment_id]

```
show all MGCP/MEGACO ports on specified equipment id  
Starting with version 4.3.100 see centrala version
```

view portstate

Show a list of ports and the state of each port (ERROR,BLOCKED,BUSY...) if the port it is not in the list that means that the port is OK and it is not used.

Field1=PORT allways

Field2=port state

Field3=physical port number

Example:

```
topexsw>view portstate  
PORT STATE  
PORT BUSY    13  
PORT BUSY    131  
PORT BLOCK   132  
PORT BUSY    133  
PORT ERROR   1342
```

view proxycalls

```
show all proxy calls (between sip users)
```

view route [routeid]

```
view details for specified route id
```

view routes

```
view memory routes list
```

view simstate

```
view the state of SIM cards
```

web callback [A username] [B username] [A class id]

```
call A then call B and connect both
```

xconnect port1 port2

```
connect two ports via local Eones  
calls connect2EONES(port1, port2) function
```

[Back to centrala](#)

OAM

Connecting with OAM

[Back to Main Page > OAM](#)

Connecting With OAM

Note: Connection with OAM is possible only if centrala is running on the target machine. If connection with OAM is not established connect with serial or putty and check if centrala is running

Options for the OAM program

In order to allow additional facilities, the "gwconfig.exe" application may also be started at the command line prompt with the following parameters:

1) "-D"

The OAM software includes a protection against starting more than one instance of it. If it is necessary to start the software more than one time, you should use the following command to start the application: "gwconfig.exe -d" or "gwconfig.exe -D". The "D" parameter allows **simultaneous** administration of several TOPEX gateways.

2) "-C"

The parameter "-c" or "-C" allows automated connection of the administration program to a TOPEX gateway. The "c" parameter must be followed by a space delimiter and these three fields: identification name for the remote system, user name and password (to allow automated log-in).

For example: "gwconfig.exe -c TEST,<username>,<password>".

3) "-S"

Parameter "-s" or "-S" allows saving of several types of data. The information saved concerns the status of activation of monitoring, live monitoring and interrogation about mobile network information (cell IDs and signal levels).

For instance "gwconfig.exe -s" or "gwconfig.exe -S"

All these parameters can be combined and added to the command line.

4) "-Z"

Parameter "-Z" archives configuration and cdr files before downloading them with OAM. It will greatly increase the speed of OAM



Best Practice

Always use parameters "-z" and "-d"

The Systems menu contains two options: **Add** and **Remove**

SYSTEMS => ADD

Add a new TOPEX system to the structure. When you click the "Add" command, the window "Add system on position n" is displayed.

In the “Add system on position n” window you must specify:

- **Directory** – enter a name for the folder where the files downloaded from the TOPEX multiAccess system will be stored. On the computer hard disk it will be made a directory in the following shape "cfg_XXXXXXX" where XXXXXXX is the name typed in the "Directory" field. The folder will be created on hard disk in the directory where the executable 'gwconfig.exe' is located. In the picture above, the directory name is “GSM”.

- **Name** – enter a name for the connection to the system. It will be concatenated with "cfg_" and show up in the tree-like structure as "cfg_GSM". These concatenated names are text used from now on in the tree structure for identifying the system.
- **Serial communication / IP communication** – here you specify the type of link between OAM computer and E1/30 Mobile gateway.

There are two exclusive options for the communication with TOPEX equipment: IP or serial link.

A) IP Parameters if you choose IP communication, you must fill the next two fields:

IP address - enter the IP address of the system. It can be a numeric IP address or a text address (in that case a DNS request will be made by software).

IP Port num. - enter the number of the port through which the communication with the system is achieved. The default value is **9009**. This value is also established into the gateway system and should not be changed.

Dial-Up Connection field

- In case of IP communication, if this box is checked it allows you to establish a dial-up connection. The Dial-up connection must be created from Windows (from Control Panel "Dial-Up Networking") and the connection name must **not** contain the space character inside the text.
- Option **"Use PPP address"** is used to indicate to the "gwconfig" application that it must connect to the address of the dialup server, after a successful connection. If this option is **NOT** checked, then the "Gwconfig" program will try to connect to the address specified in the field "IP address" field.

SEO: Connecting with OAM, OAM, Topex Management Software,

OAM / Card Map

[Back to Main Page > OAM](#)

Multiaccess OAM card map

Power

First card in equipment is Power Card. This card is not numbered and it will not appear in OAM

PRI or VOIP

Positions **32-33** (as represented in OAM) are reserved for **VOIP** or **ISDN** card. The card is located between **POWER** and **PROCESSOR** and uses second slot

- VOIP card is installed on port 32 and uses 60 channels. For this reason it will use positions 32 and 33 in OAM
- ISDN card has 2 ports with 30 channels each. Upper port will use position 33 and lower port position 32

PROCESSOR

Installed in third slot PROCESSOR is not represented in OAM.

Special Position

Slot number 4 (right after PROCESSOR) is used by default for GSM,FXS,FXO,BRI,RADIO cards (position 0 in OAM). On special configurations this slot can be used for VOIP or ISDN cards. In this case VOIP or ISDN cards will use position 16 and 17 (as represented in OAM). Slot number 4 can't be adapted on site to be used for VOIP or ISDN equipment must be returned to Topex for backplane mod

- VOIP card is installed on port 16 and uses 60 channels. For this reason it will use positions 16 and 17 in OAM
- ISDN card has 2 ports with 30 channels each. Upper port will use position 17 and lower port position 16

GSM,FXS,FXO,BRI,RADIO

Note: Card 0 is the card closest to Processor

In slots 0 to 15 the following cards can be installed

- GSM check GSM Card for more info on gsm cards
- FXS
- FXO
- MPAI
- BRI
- RADIO

Warning: FXS FXO MPAI BRI cards require a 48V converter that is not installed by default on Multiaccess units. These cards can't be added to the equipment at a later time if this converter is not installed on the equipment

OAM / Installing a GSM card


Back to Main Page > OAM

Installing a GSM Card


- Insert the GSM board in the equipment

Note: GSM cards can be inserted while the equipment is running


- Right click on a empty position and select Add Card



Note: A password Box will pop-up. Password is topex




- Select as card type GSM



GSM Settings

- Card has been added to equipment configuration
- Click on one of the 2 gsm ports of the card to setup card settings



- Check **Installed** , **IN**, **OUT**, select a valid trunk (in this case GSM) and a Sim index

The “**Category**” area contains the following items:

- **Installed** – allow activation of that port; if that option is not selected it means the port cannot make calls or receive calls;
- **IN** – input, port used only for incoming calls;
- **OUT** – output, port used only for outgoing calls;
- **DISA** – activates the DISA service on that port;
- **Monitoring** - the system collects additional information for this port in activity (monitoring) files.

“**Direction**”– the direction to which this port has been assigned. “Direction” must be one of the directions specified in “Define directions names”. It can be a number from 0 to 19. If the port number is not assigned to any direction, then enter 255.

“**SIM index**” – an index (0-3) from the allocation table of the SIM cards that instructs the port what SIM to use. The list contains values from 0 to 7 and the 255 value to indicate an unallocated index.

“**Target**” – the number of the local extension to which the input junction should ring. If you enter “---” the calls that come in through this port will ring continuously.

“**Second Category**” - a category (8 digits) that can be assigned to the specified port. This value will be used in further developments.

“**SIM area**” (this area is situated on the bottom side of GSM configuration card)

The settings in this zone are about SIM cards: their PIN code, the loading for each SIM and the maximum time of usage for each SIM:

Pin Code 1 - PIN code of the SIM no. 1 (4 digits);

Pin Code 3 - PIN code of the SIM no. 2 (4 digits);

Pin Code 2 - PIN code of the SIM no. 3 (4 digits);

Pin Code 4 - PIN code of the SIM no. 4 (4 digits).

When option "Apply changes for entire direction" is set then the values for all four PIN codes are send to all GSM ports that are allocated on the same direction.

Note: Load Time is total talk time on current sim.Value must be reseted to 0 when SIM card is changed in order to have accurate readings

Note: Load Time on a SIM is not updated in real-time. The value is read only once when connecting with OAM. To update the value disconnect and connect OAM

Load Sim 1 - loading in seconds (minutes) for SIM no 1;

Load Sim 2 - loading in seconds (minutes) for SIM no 2;

Load Sim 3 - loading in seconds (minutes) for SIM no 3;

Load Sim 4 - loading in seconds (minutes) for SIM no 4.

You can reset each loading value by clicking the "Reset" button to the right of the "Load Sim" field; when option "Apply changes for entire direction" is set then a reset of a loading on a Sim x (x=1,2,3,4) will be send for Sim x on all GSM ports which are allocated on the same direction. In case of "load balancing algorithm" the next set of values are useful.

The next values are useful because each of them is establishing a maximum value of using time for a SIM; after the specified value the SIM will become blocked. If the actual values get over the Max value then the SIM becomes blocked.

Note: With Max Value sim in current position will be limited to a certain number of minutes of talk time

Max SIM1 - maximum time to use in seconds (minutes) for first SIM;

Max SIM2 - maximum time to use in seconds (minutes) for second SIM;

Max SIM3 - maximum time to use in seconds (minutes) for third SIM;

Max SIM4 - maximum time to use in seconds (minutes) for fourth SIM.

You can set each value by clicking the "Set" button to the right of the "Max 1...4" field. Here also, when option "Apply changes for entire direction" is selected, then a set of a maximum time on a Sim x (x=1, 2, 3, 4) will be send for Sim x on all GSM ports which are allocated on the same direction.

Apply changes for the entire direction - if it is selected, the values for PIN code, loading (**Load**) and maximum time (**Max**) will be automatically applied to all the mobile modules for that direction.

Save – saves the changes you performed;

Cancel – cancel the changes, closes the window without saving;

Help - shows a help window with help information about configuring the GSM board (this paragraph of the Operating Manual in online electronic format).


Refresh - if this option is selected, then the OAM software will request the current values for SIM loading from the gateway.

TChange - speaking time period in seconds following which the active SIM is changed (the gateway looks for the SIM card with the lowest load for the same GSM module). Usual values are 1800 or 3600 seconds. This parameter is the same for all GSM modules and can be viewed and changed in any GSM settings window. This parameter can be changed by using the "Set" button. Another command which is changing the same parameter is the command "set tchange xxx" - command which can be completed by choosing "Facilities - Commands".

Note1: The difference between GSM/UMTS modules and the CDMA modules is the special option DIRMODULECDMA allocated to the CDMA direction.

Note 2: Several of the fields have length limits: for target is 3, for second category is 8 and for pin codes it is 4.

Note 3: Also, verifications are performed for the fields PIN codes and target. For PIN codes digits can have values from 0 to 9 or characters "----" and for target it may be a number from 0 to 127 or characters "----". If a bad value is inserted an error message is shown and the specified field turns red.



Best Practice

Input Pin code before inserting sim cards in the equipment. Otherwise sim card will be blocked in about 10s

OAM / Installing a PRI card

Back to Main Page > OAM


Installing a PRI Card

Connect with OAM


- Add the card in positions 16 or 17: Right click on position and select Add Card 17

NOTE: Position 16 corresponds to E1/B slot on the equipment, position 17 corresponds to slot E1/A


- Enter the password **topex** and select the Isdn signaling you need(Supported signaling includes R2 generic CAS (Channel Associated Signaling - in accordance both with ITU-T Q.421/Q.422 and with Q.411/Q.412), ISDN DSS1, and SS7), for this example we will add the card as ISDN-PRI.



- Select the Layer 1 Network/ User interface.




- Select the the Trunk Settings you need.





NOTE: the trunk settings are explained at E1 settings

- Click the second port on the card (129 for position 16 or 161 for position 17), check the boxes INSTALLED, IN,OUT, Apply settings for all positions on card, CATEGORY, DIRECTION and select an Direction




NOTE: if the equipment has a Voip card, the first two ports (258 and 259 have to have Second Category 00200000)







- Leave RTP and Range settings to default and press OK



- Click on third port of the VOIP card and assign trunk (direction) MYVOIP, check **INSTALLED,IN** and **OUT**. To apply these settings on all ports on card check **Apply settings for all positions on the card**, **Category** and **Direction**. Press OK button



- Go to PG Configuration to start configuring the voip card




The screenshot shows a window titled "Computing VoIP Command Line". It contains the following fields and values:

- PG Card IP Address: 127.0.0.1
- VoIP Card IP Address: 89.38.174.221
- Port MSPD: 9677
- FORK: /mnt/app/bin/mspd
- ☒ Trace CMD
- VoIP Card MAC: 00:52:C2:40:36:B3
- IP GATEWAY MAC: 00:1A:E2:E8:04:C8
- ☐ LOG on MSP
- AXF IMAGE: /mnt/app/data/miro_hdvoice.axf

At the bottom, there are three buttons: OK (with a green checkmark icon), Cancel (with a red X icon), and Help (with a green question mark icon).

- **PG Card IP Address** -- Ip used to receive commands from call controller. Always use **127.0.0.1**
- **Port MSPD** --Port used to receive commands from call controller. Always use **9677**
- **VOIP CARD IP Address** --Ip address used by the VOIP card. This ip address must be in the same subnet with the ip address of the Processor card
- **FORK** --Path to voip manager. Always use **/mnt/app/bin/mspd**
- **VOIP Card MAC** -- MAC address of the VOIP card. This MAC is issued by Topex. Contact one of our engineers in the support team to issue a MAC address if MAC is not already configured
- **IP GATEWAY MAC** -- MAC address of the default gateway for the subnet in witch the equipment resides.This MAC is needed in order to be able to route RTP packets. Voip card is unable to route RTP so all packets are sent to the network gateway to be routed from there.
- **AXF IMAGE** --Firmware to be loaded in VOIP card at boot. Always use **/mnt/app/data/miro_hdvoice.axf**
- Press OK button after you configured all parameters
- Press RTP IP Button to edit RTP parameters




- Edit the ip address and press OK

```
rtp_ip 2 0.0.0.0/0 89.38.174.221
```

| |-----This is the ip address that must be edited


|-----Subnet for witch to use this ip address.Use 0.0.0.0/0

- Reboot equipment and connect voip cables




Configuration for PGVOIP processor

- Connect with OAM
- Add the voip card in position 32: Right click on position 32 and select Add Card 32 (password is: topex)




- Select IP and press OK button




- Leave RTP and Range settings to default and press OK


Warning: Changing RTP Start below 31000 will cause voice problems



- Click on third port of the VOIP card and assign trunk (direction) MYVOIP, check **INSTALLED, IN** and **OUT**. To apply these settings on all ports on card check **Apply settings for all positions on the card**, **Category** and **Direction**. Press OK button
- On ports 258 and 259 make sure Second Category is set to **00200000**




- Go to PG Configuration to start configuring the voip card
-



- Press Voip2 button to edit Voip Parameters

- **PG Card IP Address** -- Ip used to receive commands from call controller. Always use **127.0.0.1**
- **Port MSPD** --Port used to receive commands from call controller. Always use **9677**
- **VOIP CARD IP Address** Leave empty
- **FORK** --Path to voip manager. Always use **/mnt/app/bin/mspd**
- **VOIP Card MAC** --Leave empty

- **IP GATEWAY MAC** -- Leave empty
- **AXF IMAGE** --Leave empty
- Press OK button after you configured all parameters
- Press RTP IP Button to edit RTP parameters



- Edit the ip address and press OK

```
rtp_ip 2 0.0.0.0/0 89.38.174.221
      |           |-----This is the ip address that must be edited
      |-----Subnet for witch to use this ip address.Use 0.0.0.0/0
```


- Go to Action Menu and select Save Current Configuration
- Wait 10 sec for the configuration to be saved and reboot equipment

OAM / Installing a MPAI card

[Back to Main Page > OAM](#)

Installing a MPAI card

With the "MPAI" card, each port can be configured (depend on the physical module connected to the port) as FXS,FXO,BL or E&M port. In such a case the port settings will be changed (through the left mouse button) like in the case of FXS,FXO,BL or E&M card by passing first through the **MPAI Settings**: here the category of the port can be changed; the port settings can be changed through the "Edit" button.



OAM / E1R2

[Back to Main Page > OAM](#)

OAM / E1R2



Best Practice

In order to change settings on the card (CRC and Clock)you have to remove the card and add it again with the new settings.Make sure you reboot the equipment after the settings are altered

In order to install R2 chose what port will you use. On Topex equipments E1 card has two E1 ports : E1 A and E1 B.

In OAM software correspondance is like this :

Card 16 – is for E1 B port

Card 17 – is for E1 A port

In our example we choose to install Card 17 (in OAM software), meaning port E1 A on the equipment board (fig. 1).




Fig. 1

For this make right-click in the rectangle corresponding to card 17 and then click on “Add card 17” button. A new window will pop up wich will require a password (fig.2). Type the password “topex” and then click OK. A second window will pop up – Confirmation(“Add card 17 ?”), click OK (fig. 3).



fig. 2




fig. 3




fig. 4

In the next window you will chose the type of E1 card configuration – E1R2 and click OK (fig. 4).




fig. 5

Set the trunk parameters Clock and CRC according to your settings (fig. 5) and then click OK.
The card will appear installed on the main window of OAM (fig. 6).




fig. 6

For channel settings, click on rectangle D 161 and a E1R2 Settings Port window will pop up (fig. 7).




fig. 7 a




fig . 7 b

In Category area, check “Installed”, “IN”, “OUT”

Choose the direction assigned to the channels (fig. 7 b)

In Saving Options area check “Apply settings for all positions on card”, “Category” and “Direction”.

To set the “Second Category” field click on the grey square in it’s right side (fig. 7d).

A new window will pop up “Computing Second Category” (fig. 8) where you will select option

“R2(Q411, Q421 R2)” then click OK button.




fig. 7 d





fig. 8

OAM / Call Flow

[Back to Main Page > OAM](#)

Call flow in OAM



ISDN 2 GSM Case

Call Directions(incoming ISDN Trunk) > Routing Table > outgoing GSM trunk

- ISDN1 - incoming trunk
- GSM - outgoing trunk

ISDN 2 VOIP Case

Call Directions(incoming ISDN Trunk) > Routing Table > DIRIP OUT (outgoing VOIP trunk)

- ISDN1 - incoming trunk
- SIP_OUT - outgoing trunk

ISDN 2 ISDN Case

Call Directions(incoming ISDN Trunk) > Routing Table > outgoing ISDN trunk

- ISDN1 - incoming trunk
- ISDN2 - outgoing trunk

GSM 2 ISDN Case

Call directions(incoming GSM trunk) > Routing Table > outgoing ISDN trunk

- GSM - incoming trunk
- ISDN1 - outgoing trunk

GSM 2 VOIP Case

Call Directions(incoming GSM trunk) > Routing Table > DIRIP OUT (outgoing VOIP trunk)

- GSM - incoming trunk
- SIP_OUT - outgoing trunk

GSM 2 GSM Case

Call Directions(incoming GSM trunk) > Routing Table > DIRIP OUT (outgoing GSM trunk)

- GSM - incoming trunk
- GSM - outgoing trunk

Voip 2 GSM Case

DIRIP IN (incoming VOIP trunk) > Call Directions > Routing Table > outgoing GSM trunk

- SIP_IN - incoming trunk
- GSM - outgoing trunk

Voip 2 ISDN Case

DIRIP IN (incoming VOIP trunk) > Call Directions > Routing Table > outgoing ISDN trunk

- SIP_IN - incoming trunk
- ISDN1 - outgoing trunk

VOIP 2 VOIP Case

DIRIP IN (incoming VOIP trunk) > Call Directions > Routing Table > DIRIP OUT (outgoing VOIP trunk)

- SIP_IN - incoming trunk
- SIP_OUT - outgoing trunk

SEO: Topex Call Flow, Call Flow, Path of a call, Topex

OAM / Create a Trunk

Creating a trunk (also called a direction)

Note: Trunks cannot be created. A predefined list of 251 trunks already exist on the equipment. Rename one of the available trunks to use it

- Special trunks
 - MYVOIP (used for voip calls. This trunk must be always assigned to the VOIP Card)
 - SENDSMS (used for sendsms applications)
 - SENDCALL (used by the call generator, callback)




Best Practice

Do not rename or disable Special Trunks it will affect functionality of the equipment


Renaming a trunk

- From the **Actions** Menu Select **Direction Names**

A pop-up window will appear with the predefined trunks



Double click on one on the trunks that you are not using to rename it



Best Practice

After renaming a trunk always check Call Direction to see if the trunk it is enabled. All trunks must have Type **DIR** except trunks assigned to FXS ports which must have Type **PORT**

OAM / Access IN


Back to Main Page > OAM

Access IN or DIRIP IN

Warning: Type of trunk is very important especially when using VOIP. A trunk that is used to receive VOIP calls cannot be used to send calls out. Also OAM / Call Flow only applies to incoming calls

Note: Access IN is used to as a filtering mechanism for VOIP calls. Ip addresses of all clients who are sending traffic into the box must be added here

DIRIP IN is located at Call directions



In Access IN calls can be filtered by

- Source IP or Subnet
- Protocol (H323 or SIP)
- Number of Digits
- Prefix

Double click on one of the settings at DIRIP IN to edit

The screenshot shows a window titled "Edit incoming parameters". It contains the following fields and values:

- Protocol: SIP
- IP: 0.0.0.0/0
- Direction: SIP_Voluntari
- Max Calls In: 30
- Proxy: Not Used
- Transcoding: Not Used
- Congrate: 100
- Maxrate: 100
- Prefix: (empty)
- Maxcost: 0
- Nrdig: 0
- Endcause: 0

At the bottom, there are four buttons: OK (with a green checkmark), Cancel (with a red X), Help (with a question mark), and Wiki (with a sun icon).

- **Protocol** – the protocol used for the respective direction. You can select SIP or H.323.
- **IP** – the IP range for the incoming direction. Here you can complete either a single IP (such as 192.168.144.57) or a range of IP values (for example "192.168.1.0/24"). If you use an IP without specifying the range, then calls are accepted just from that IP. It is the same as using range /32; The name of the direction can be one of the already defined directions, so it can be "MYVOIP" - the generic direction used for group the VoIP channels or another direction if you want to use ignore / insert features. If you use the generic MYVOIP name, all VoIP calls will be treated in the same way, but if you use specific direction names, you can define different rules for different incoming IPs. This allows you to perform operations such ignoring / inserting digits on the incoming number or identity (see "Calls direction") like for ordinary calls.

Warning: Never use the default settings for DIRIPIN (0.0.0.0/0). They will allow access from any IP address

- **Direction** – the direction name. It is chosen from the list with defined directions;
 - **Max Calls In** – the maximum number of simultaneously calls accepted from the specified IP range. In the anterior example the maximum number of calls is 30. If you enter 0 (zero) in the field "Max Calls In", this means no restrictions are placed upon the number of incoming calls.
 - **Proxy** - must be enabled if the source IP is behind a NAT.
 - **Transcoding** - must be enabled when the source and the destination have different codecs. This feature works only on the Topex equipments supplied with a VoIP card (or there is a TOPEX slave machine with VoIP card).
 - **Cong Rate** this is the congestion rate. It should not be 0. The default value is 1000.
 - **Max Rate** this parameter represents the total number of setup calls on a second. It should not be 0. The default value is 1000.
 - **Prefix** Used to check incoming prefix. If prefix is not matched the call is rejected with **End Cause** In case of two such prefixes - the user can assign two different directions for the same IP source.
 - **Max Cost** this parameter will be used in further developments.
 - **Nr Dig** Used to check number of digits. If number of digits is not exacty the same, then the call is rejected with **End Cause**
 - **End Cause** this field is the release code used when the received number has a different number of digits then the expected ones - "NrDig" value. The default value is 34.
-

Note: In Access IN calls from a specific ip or range are assigned a trunk (direction). This trunk can be used as a identifier for the party from witch you receive voip calls



Best Practice

Don't use MYVOIP to accept all calls in DIRIPIN. Create a trunk (direction) for each subnet or ip that is added to the access list.

OAM / Call Directions

[Back to Main Page > OAM](#)

Call directions

Description:

Call directions is the second step in call flow and is used for digit manipulation and trunk (direction) properties



Best Practice

Before changing settings at Call Directions please check OAM / Call Flow and identify if the trunk is **Incoming** or **Outgoing** in your call flow. Some settings will apply only for **Incoming trunks** and some for **Outgoing trunks**.

- Connect with OAM
- Select Actions > Call Directions

Define calls directions (classes)

Name	Type	Overflow	Overflow2	Restriction	Ignore	Insert	Max_d	Ignore_Id	Insert_Id	Max_Id	Sign1	Sign2
00	Disabled	00	00	0	0		20	0		20	0000	00000
MYVOIP	DIR	MYVOIP	MYVOIP	0	0		20	0		20	0008	00000
Test	DIR	Test	Test	0	0	72	20	0		20	0003	00000
03	Disabled	03	03	0	0		20	0		20	0000	00000
04	Disabled	04	04	0	0		20	0		20	0000	00000
05	Disabled	05	05	0	0		20	0		20	0000	00000
06	Disabled	06	06	0	0		20	0		20	0000	00000
07	Disabled	07	07	0	0		20	0		20	0000	00000
08	Disabled	08	08	0	0		20	0		20	0000	00000
09	Disabled	09	09	0	0		20	0		20	0000	00000
10	Disabled	10	10	0	0		20	0		20	0000	00000
11	Disabled	11	11	0	0		20	0		20	0000	00000
SENDCALL	DIR	SENDCALL	SENDCALL	0	0		20	0		20	0000	00000
SIP_Voluntari	DIR	SIP_Volu...	SIP_Volu...	0	0		20	0		20	0008	00000
FXS_Voluntari	DIR	FXS_Volu...	FXS_Volu...	0	0		20	0		20	0008	00000
ORANGE	DIR	ORANGE	ORANGE	0	0		20	0		20	000f	00000
VODAFONE	DIR	VODAFON...	VODAFON...	0	0		20	0		20	0007	00000
ISDN	DIR	ISDN	ISDN	0	0		20	0		20	0000	00000
RT	DIR	RT	RT	0	0		20	0		20	0000	00000
RT_FAX	DIR	RT_FAX	RT_FAX	0	0		20	0		20	0000	00000
20	Disabled	20	20	0	0		20	0		20	0000	00000
FXS_Feleacu	DIR	FXS_Fele...	FXS_Fele...	0	0		20	0		20	0000	00000
SIP_Feleacu	DIR	SIP_Felea...	SIP_Felea...	0	0		20	0		20	0000	00000
SSW_Voluntari	DIR	SSW_Vol...	SSW_Vol...	0	0		20	0		20	0000	00000

DIR IP In Settings... DIR IP Out Settings...

Print OK Cancel Help Wiki FIND

- Double click on a trunk to edit his properties.

Edit direction (class) parameters

Name: ISDN

Type: DIR

Overflow: ISDN Overflow2: ISDN

Restriction: 0

Ignore: 0 Insert: Max_d: 20

Ignore_id: 0 Insert_id: Max_id: 20

Sign1: 0000 Sign2: 00000000

Sign3: 00000000

Sign4: 00000000

Sign5: 00000000

Sign6: 00000000

OK Cancel Help Wiki

Name

The name of the direction(trunk).This name is defined at Direction Names and it can't be changed here.

Type

- Applies for incoming and outgoing trunks

can be PORT or DIR and specifies how that direction is addressed. The associated list contains two strings "PORT"=local and "DIR"=junction (trunk).

Warning: A value of "Disabled" indicates that the direction is disabled; the entire line will be coloured in white. The name of the direction which has "Disabled" assigned to "Type" field will be displayed in red colour in the list used to assign a direction for each kind of port and also in all places in which the destination will be a direction name.

Overflow

- Applies only for outgoing trunks

Overflow direction for the current direction. The calls will be re-routed to this overflow direction when the current direction is unavailable you choose a name of a defined direction from the corresponding list;

Note:Overflow sends calls to another trunk only when current trunk is OUT OF SERVICE or OUT OF AVAILABLE CHANNELS Overflow works only for outgoing trunks not for incoming.

Overflow 2

- Applies only for outgoing trunks

Second overflow direction for the current direction. The calls will be re-routed to this second overflow direction when the first overflow direction becomes unavailable; you choose a name of a defined direction from the corresponding list;

Note: Overflow2 sends calls to another trunk only when trunk specified at Overflow is OUT OF SERVICE or OUT OF AVAILABLE CHANNELS Overflow works only for outgoing trunks not for incoming.

Restriction

- Applies only for outgoing trunks

The class of restriction applied to that direction; from the list a number from 0 to 19 can be selected; Restrictions work only for trunks of type PORT

Ignore

- Applies only for incoming trunks

Specifies how many digits are ignored from the numbers received on that direction; the first x digits of the received number will be ignored. The list contains a range of values from 0 to 20 digits;

Insert

- Applies only for incoming trunks

Specifies what digits will be inserted in the number received to that direction. The maximum allowed is 16 digits. If you don't want any digit to be inserted you must enter "---" for this field.

Max_d

- Applies for incoming and outgoing trunks

Maximum number of digits that may be dialled on that direction. When the maximum number is reached the system will automatically send out the call to routing analysis, without waiting to see if the caller part still sends digits. This option is especially useful when you define directions for which the number of figures to be dialed is well known (for example the numbers for certain GSM networks). The list contains a range of values from 0 to 20 digits;

Ignore_id

- Applies only for incoming trunks

Ignores from the identity of the caller (Caller ID) the number of digits you have specified; The maximum allowed is 20 figures. The Ignore command is performed before the Insert command. The list contains a range of values from 0 to 20 digits;

Insert_id

- Applies only for incoming trunks

Adds to the Caller ID the specified figures; The maximum allowed is 16 digits;

Max_id

- Applies for incoming and outgoing trunks

The maximum number of digits from the Caller ID to be sent to the subscriber who has been called. The list contains a range of values from 0 to 20 digits.

Sign1

Receive Identity

Used to receive identity of a call on the current trunk

Send Identity

Used to send identity of a call on the current trunk

Load Balancing Algorithm

Note: Load Balancing is used only for trunks that have GSM ports assigned.

Load balancing will automatically select a sim from the 4 slots that belong to a GSM port and try to even up consumption on all sims on the same port. Load balancing will always select sim with lowest value at **Load Sim** and use this sim in order to terminate calls. There is a programmable time frame on which a SIM is used, after which the sim with lowest value for speaking time is selected.

Coupling of ring-back tone

By setting it, you allow coupling of a false ring-back tone while dialing on the next link, before the called party answers.

Verify CLIR

Note: Verify CLIR is used only for trunks that have GSM ports assigned.

CLIR setting is verified each time after the CLIR setting is sent to a GSM module

DIRCATCALL

When this bit is set then all calls will be cut (stopped) on the GSM modules for which a reprogramming is necessary (for example when a SIM must be changed because of an used algorithm)

DIRGOODASR

DIRGOODASR - when this bit is set then a RELEASE message is sent on ISDN with a delay of 5 seconds when a congestion situation is encountered on GSM part. The call will wait on the specified time for a free GSM resource.

DIRTESTNET

DIRTESTNET (used in case of a direction which contains GSM modules) - when this bit is enabled, then the outgoing GSM module will be tested if it has a SIM registered

DIRCHECKCALLBACK


All incoming call on this direction will be checked (on received identity) against the 'Callback Table'.

Warning: Activating this option without configuring Callback Table will cause all incoming calls to fail

DIRMODULECDMA

When this bit is set all GSM ports placed on the selected direction will be treated as CDMA modules.

Warning: Activating DIRMODULECDMA on GSM ports will stop all ports assigned to this trunk



The image shows a Windows-style dialog box titled "Computing Signaling Field". It contains several sections for configuring signaling fields. The "Digit 4" section has four checkboxes: "Receive identity", "Send identity", "Load balancing algorithm", and "Coupling of the ring-back tone". The "Digit 3" section has a text box labeled "Audio Level" with the value "0". The "Digit 2" section has four checkboxes: "Verify CLIR", "DIRCATCALL", "DIRGOODASR", and "DIRTESTNET". The "Digit 1" section has two checkboxes: "DIRCHECKCALLBACK" and "DIRMODULECDMA". At the bottom, there are three buttons: "OK" with a green checkmark, "Cancel" with a red X, and "Help" with a question mark.

Digit	Option	Value / Status
Digit 4	Receive identity	<input type="checkbox"/>
	Send identity	<input type="checkbox"/>
	Load balancing algorithm	<input type="checkbox"/>
	Coupling of the ring-back tone	<input type="checkbox"/>
Digit 3	Audio Level	0
Digit 2	Verify CLIR	<input type="checkbox"/>
	DIRCATCALL	<input type="checkbox"/>
	DIRGOODASR	<input type="checkbox"/>
	DIRTESTNET	<input type="checkbox"/>
Digit 1	DIRCHECKCALLBACK	<input type="checkbox"/>
	DIRMODULECDMA	<input type="checkbox"/>

Buttons:

Sign2

Transmit Q850

"Transit Q.850" - is used to transfer the Q.850 termination code from the GSM link back on the E1-ISDN link. Those Q.850 codes are available only for the Siemens mobile modules. For Voxson modules and when the "Transit Q.850" option is not checked the main application sends a congestion message in case of NO DIALTONE message and for a NO CARRIER received in under two seconds (since the beginning of the call in the mobile network). The BUSY message is also received from GSM network and is sent as it is. A NO CARRIER message received for a delay value greater than two seconds will be treated as a release from the GSM network.

Load Balancing Algorithm on SIM index

is used to enable the load-balancing algorithm ("equal load") on the SIM/RUIM cards that are already selected by SIM index algorithm.

Calculate Tax Pulses

"Calculate Tax Pulses" - for each direction (group of trunks) for incoming calls, you can establish the computing (and sending out) of the tax (billing) pulses (main box application must have 'TAX' licence). These pulses for billing will be generated according to rules you specify and will accumulate in the billing files. In any case, the calculated billing pulses are saved in the files. In the case of an ISDN connection (E1-ISDN trunk) these pulses are also sent out, using ISDN - AOC messages. You must remember that the mask must be applied to the direction to which the E1-ISDN channels belong.

Note: You can establish the prefixes that will be charged with billing pulses in "Routing Table".

Search UP

Selects how channels are selected. From lowest to highest.

Note: it is important on E1 trunk to avoid double seizing of the same channel

Search DOWN


Selects how channels are selected. From highest to lowest

Note: it is important on E1 trunk to avoid double seizing of the same channel

Priority

Selects priority for this trunk. Only works for outgoing trunks

For example - when a TOPEX softswitch is used to route calls to several TOPEX gateways - then each outgoing direction will have assigned a priority. The customer can assign higher priority to the machines with higher traffic capabilities and performances. The lowest priority is 0 and the higher is 9.




Sign4

Forward Call without Answer

In order to accept an incoming call on a GSM module, the IN and DISA option must be activated in the gsm port settings. The call can be forwarded directly to a destination if digits are inserted in the definition of the direction to which the GSM port belongs. If the "Forward Call Without Answer" option is activated then the call will be forwarded to destination and the answer to the GSM side will be committed when the destination will answer. Otherwise the incoming GSM call will be answered before the answer from the destination.


Don't play Announcement



Sign6

Used for Dtmf check OAM / DTMF

- **RxDTMF** - DTMF that will be received. Multiple types of DTMF can be selected by enabling the possibility to receive the DTMF codes.
- **TxDTMF** - DTMF that will be sent. Only one can be selected.



SEO: Call Directions, OAM Call direction, Trunk properties

OAM / Routing Table

[Back to Main Page > OAM](#)

Routing Table

Note: Routing table is responsible with finding a outgoing direction to a call.

- Connect with OAM
- Select Actions > Routing table

[illegible]

- Double click on a route to edit.

Edit routing table

Incoming direction:

DEFAULT

Prefix:

072

Action:

DIR

Destination:

GSM

Ignore:

0

Ignore_Id:

0

Sign1:

00b1

Tax:

0000

Sign2:

00000000

Ctime:

0

Search Mode:

2

Search Param:

1

Sign3:

00000000

Sign4:

00000000

Sign5:

00000000

Sign6:

00000000

Start Time:

00:00:00

End Time:

23:59:59

Dows:

FF

Billing Profile:

0

Play File Name:

Out Billing Profile:

0

Route Name:

ROUTE1234780249_0

IP:

Port:

0

Insert:

Insert_Id:

Cancel

Help

Incoming Direction

Used to create routing rules based on source of the call. If a trunk is specified at **Incoming Direction** then this rule will be valid only for calls received for that trunk. Also routing rules with specific **Incoming Direction** will have higher priority over rules with Default **Incoming Direction** for the same prefix.

Example of dir.cfg:

```
r DEFAULT 072 DIR GSM 0 0 00 c 00 c 00b1 0000 0 0 2 1 0 0 0 0 00:00:00 23:59:59 255 0 ROUTE1234780249_0 c 0
r ISDN1 072 DIR GSM2 0 0 00 c 00 c 00b1 0000 0 0 0 0 0 0 0 00:00:00 23:59:59 255 0 ROUTE1238059346_0 c 0
```

Edit routing table

Incoming direction:

DEFAULT

Prefix:

072

Action:

DIR

Destination:

GSM

Ignore:

0

Ignore_Id:

0

Sign1:

00b1

Tax:

0000

Sign2:

00000000

Ctime:

0

Search Mode:

2

Search Param:

1

Sign3:

00000000

Sign4:

00000000

Sign5:

00000000

Sign6:

00000000

Start Time:

00:00:00

End Time:

23:59:59

Dows:

FF

Billing Profile:

0

Play File Name:

Out Billing Profile:

0

Route Name:

ROUTE1234780249_0

IP:

Port:

0

Insert:

Insert_Id:

OK

Cancel

Help

Edit routing table

Incoming direction:

ISDN1

Prefix:

072

Action:

DIR

Destination:

GSM2

Ignore:

0

Ignore_Id:

0

Sign1:

00b1

Tax:

0000

Sign2:

00000000

Ctime:

0

Search Mode:

0

Search Param:

0

Sign3:

00000000

Sign4:

00000000

Sign5:

00000000

Sign6:

00000000

Start Time:

00:00:00

End Time:

23:59:59

Dows:

FF

Billing Profile:

0

Play File Name:

Out Billing Profile:

0

Route Name:

ROUTE1238059346_0

IP:

Port:

0

Insert:

Insert_Id:

OK

Cancel

Help

Default route for prefix 072 will send calls to DIR GSM except calls originating from trunk ISDN1 which be sent to trunk GSM2

Prefix


Note: *f* can be used as a wild-card. It will represent 1 digit from 0-9

For example "1f2" means all prefixes from "102", "112" until "192". This feature is very useful because it allows to reduce the number of records in the routing table. The first digits of the number, these are the digits received from the originating party after processing in **Call Direction**. Number of digits added here are very important it will indicate how many digits equipment will analyse to find a outgoing direction.

Warning: Routes that have a common prefix must have the same number of digits at prefix.

Correct Example:


```
r DEFAULT 072 DIR GSM 0 0 00 c 00 c 00b1 0000 0 0 2 1 0 0 0 0 00:00:00 23:59:59 255 0 ROUTE1234780249_0 c 0
r DEFAULT 072 DIR GSM2 0 0 00 c 00 c 00b1 0000 0 0 0 0 0 0 0 00:00:00 23:59:59 255 0 ROUTE1238059346_0 c 0
```



If a call is received with prefix 072 then the equipment will analyse 3 digits and will find 2 routes available. When multiple routes are found equipment will look at route **Search Algorithms Search Mode** and **Search Param** (digits in bold) to determine which one of the routes will use. First route has a higher priority and will always be selected first. In case GSM trunk is full calls will be sent to GSM2 (this is also a example of overflow)

Incorrect Example

```
r DEFAULT 072 DIR GSM 0 0 00 c 00 c 00b1 0000 0 0 0 0 0 0 0 00:00:00 23:59:59 255 0 ROUTE1234780249_0 c 0
r DEFAULT 07 DIR GSM2 0 0 00 c 00 c 00b1 0000 0 0 0 0 0 0 0 00:00:00 23:59:59 255 0 ROUTE1238059346_0 c 0
```



In this case only 2 digits will be analysed and equipment will always use second route to terminate calls. To correct this error a wild-card **f** must be added to the second route.

```
r DEFAULT 072 DIR GSM 0 0 00 c 00 c 00b1 0000 0 0 0 0 0 0 0 00:00:00 23:59:59 255 0 ROUTE1234780249_0 c 0
r DEFAULT 07f DIR GSM2 0 0 00 c 00 c 00b1 0000 0 0 0 0 0 0 0 00:00:00 23:59:59 255 0 ROUTE1238059346_0 c 0
```

In this case 3 digits will be analysed and equipment will send calls starting with 072 to trunk GSM and calls starting with 070,071,073,074,075,076,078,079 to trunk GSM2

Action

Specifies the action to be taken for the call. It is a list of six strings: "PORT", "DIR", "SERV", "HUNT", "DIRIP" and "LCR".

- PORT - the call will get out through the port specified in the "Destination" list (routing by port);
- DIR - the call will get out by the trunk you have specified in the "Destination" list (routing by trunk);
- SERV - the call will get out through the service that was specified in the "Destination" list (send call to a service like voicemail, flashing,...);
- HUNT - the call will get out through the hunting group that you have specified in the "Destination" list (send call to a hunting group);
- DIRIP - in such a case the "Destination" field will be interpreted as VoIP protocol - SIP or H323. The user must provide destinations IP address and port (in case when the default values of 1720 for H323 and 5060 for SIP are not used) (send call to a ip destination);
- LCR - the call will get out by analysing the LCR table for the index specified in the "Destination" field. This field can take a value from 0 to 6. Each value represents a rule to be applied in order to find a direction at the specified moment. (deprecated)

Destination

Destination of the call which may be:

- A port number (in the range 0-127); when **Action** Port is selected
- A direction name specified in "Define directions names" (from the list); when **Action** Dir is selected; it indicates an error allocation by red color when the allocated direction is declared as 'Disabled' in 'Calls Directions'.
- A service number (from 0 to 19);
- A number for a group of hunting (from 0 to 19);
- An index to the LCR table. (deprecated)

Ignore

The number of digits that will be ignored (omitted) from the numbering sent out through “Destination”. There is a list with values from 0 to 20.

Ignore_id

The number of digits that will be ignored from the Caller ID sent out through “Destination”. There is a list with values from 0 to 20;

Insert

Digits inserted at **Insert** field will be inserted in front of the number

Insert_id

Digits inserted at **Insert_id** field will be inserted in front of the identity received

Note:Ignore and Insert are always done from the front of the number. Ignore is done first and then Insert

IP and PORT

This option is enabled only when calls are sent to a ip destination (**DIRIP** must be selected at **Action**). Protocol must be selected at **Destination** and remote ip and port must be inserted here.

Sign1

Action='DIR'

If selected action is 'DIR' or 'DIRIP' then the Sign1 window is displayed as follows:

- **Alloc BSS** - this option is used in the situations when the ring-back tone must be identified in order to declare the call as answered. This option is useful in cases when the gateway application must make the difference between a call answered without ring-back tone and a call answered after a ring-back tone. Additional software must be installed on the gateway.

Note: Alloc BSS feature is not supported anymore.

- **Simulate Tax** - is used in case of FXO junction - in which the answer at destination can't be recognized. In such a situation this option has to be validated. The call is considered as answered as soon as the call is made on output link.
- **Retry Attempt** - when this bit is 1 one retry attempt will be made in case of a first failure on this direction; when this bit is 0 no retry attempts will be made.

This option is used to reroute calls. In order to have a reroute on cause "X" scenario you have to define 2 routes with the same prefixes and with different priorities. The "Retry Attempt" option will be set for both routing records. In "/mnt/app/cfg/traffic.cfg" a line has to be added indicating the rerouting on cause option. Line format is as follows: "rerouteoncause X 1".


- **Check Operator** (mask 0x0800) - is used when portability facility is desired. For each call, a database interrogation is performed. The portability database can be located on the same gateway or on another PC. Additional software must be installed on the gateway.
 - **Restrict ID** (mask 0x0400) - is used for SS7 direction in order to indicate that the identity is restricted.
-

The identity can be hidden if in the routing record - the ignore identity field is put to maximum digit allowed - 20.

- **Number of Digits** - number of digits which are waiting to take the action specified in the field "Action"
- **Number of Seconds** - time delay between two digits after which the selected action is chosen.

Action='SERV',Destination='FLASHING'

If selected action is 'SERV' and destination is 'FLASHING' then the Sign1 window is displayed as follows:




- **Connect To Music** - the gateway flashing tonality is provided to the incoming call;
- **Connect To DSP** - the tonality will be obtained from a DSP (with possible values from 0 to 63);
- **Loop** - the "Tx" and "Rx" sense are looped together;
- **Quiet** - no tonality will be provided to the incoming call; the user will not hear anything;

The "Timer" field is used as follows: if a "0" value is used then the tonality will be heard continuously; otherwise the value will specify the amount of time on which the tonality will be played to the incoming call.

Action='SERV',Destination='PLAY RELEASE'

If selected action is 'SERV' and destination is 'PLAY RELEASE' then the Sign1 window is displayed as follows:



This service is used to release calls (with cause specified in ***Release Cause** field) with a specified Q850 code and optionally to play a file before release. In routing table you need to route a prefix to service PLAY_RELEASE.

In case of playing files, then the files are stored on HDD then the path will be "/mnt/app/raw/q850/".

File format is the following: <file name>.<codec(2 digits)>.<language(2 characters)> Example: inex_00.ro, user_busy_08.en, no_answer_18.en etc.

- **Language** is specified in "Language" field.

File name is hard coded and is directly related with Q850 code. File name list:

- 1 = inex
- 3 = no_route_to_destination
- 16 = normal_call_clearing
- 17 = user_busy
- 18 = no_user_responding
- 19 = no_answer
- 21 = call_rejected
- 23 = redirect_to_new_destination
- 27 = destination_out_of_order
- 28 = invalid_number_format
- 31 = normal_unspecified
- 34 = congestion
- 38 = network_out_of_order
- 41 = temporary_failure
- 65 = bearer_capability_not_implemented
- 127 = interworking_unspecified

anything else = protocol_error

Note:Codec will be matched according to the source codecs of call

. Default language from /mnt/app/cfg/prepaid.cfg wil be used.

Note:Requirements: rtptx pool must be activated, see 'exec.cfg'


On PGVoIP (MGU) for FXS calls must be added in group.cfg the following line: (Order is important, bellow line must be the first rtp_ip line from specified group):

```
# rtp_ip nr_grup pg_ip/32 10.0.0.10
rtp_ip 2 192.168.110.18/32 10.0.0.10
```

- **TxACM** - is used on SS7 (Address Complete Message) - it is a signalling message sent to indicate that a switched circuit has been established to the requested endpoint. This message is an acknowledgement to the IAM message(Initial Address Message).

Action='SERV',Destination='PLAY FILE'

If selected action is 'SERV' and destination is 'PLAY FILE' then the Sign1 window is displayed as follows:



This service is used for playing files to source of calls routed to this service. In routing table you need to route a prefix to service PLAY_FILE. If routing **Play File Name** field is empty, default will play the file named "music".

HDD files path: /mnt/app/raw/flashing/

File format: <file name>_<codec(2 digits)>.<language(2 characters)> Example: play_00.ro, test_08.en, test_play_18.en etc.

Note:Play_file field from route will contain only file_name, without codec and language extensions.

Codec will be matched according to the source codecs of call. Default language is configured from prepaid.cfg.

- **Timer** - specify the number of second after wich it will stop play file; if is 0 it play until the file is finished.
 - **Repeat Playing the File** - it enables/disables infinite loop play file; if activated will play the file from beginning when end is reached
-

Note:Requirements: rtptx pool must be activated, see 'exec.cfg'

On PGVoIP (MGU) for FXS calls must be added in group.cfg the following line: (Order is important, bellow line must be the first rtp_ip line from specified group):

```
# rtp_ip nr_grup pg_ip/32 10.0.0.10
rtp_ip 2 192.168.110.18/32 10.0.0.10
```

Tax

You can establish the prefixes that will be charged with billing pulses in “Routing Table”. To can handle charging issues you must change the field “Tax”.

There are three methods (rules) for configuring calculation of tax pulse. The first digit (the leftmost of the four) of “Tax” field is used to differentiate between those methods. Allowed values for the method are:


- 0 – no method,
- 1 – method 1,
- 2 – method 2,
- 3 – method 3.
- **Method 1:**

“1xyy” – upon answering the call is charged with “x” pulses. During the state of conversation the call is charged with one pulses every “yy” seconds. So if you select “1” you must specify the number of pulses at response (10 in the example below) and the time period for pulse generation (20 seconds in the example below).


The screenshot shows a window titled "Computing Tax Field". Inside, there are three labeled input fields: "Method" with a dropdown menu currently showing "1", "Number of pulses at response" with a text box containing "10", and "Puls generating period (seconds)" with a text box containing "20". At the bottom of the window are three buttons: "OK" (with a green checkmark icon), "Cancel" (with a red X icon), and "Help" (with a green question mark icon).

- **Method 2:**

“200x” – the calls are charged according to several zones and tariffs. The zones are geographical areas where the tariff is the same. This kind of taxation is performed by several fixed telephony (PSTN) operators. If you select Method 2 you may change only the “Tariff Index” value.



The list of all zones and tariffs is defined in the next window, “Pulse calculation based on Zones” that is displayed by pressing “...” button.




You can easily handle zones and tariffs. A maximum number of ten zones and four tariffs can be defined. In the image above you can notice the tariff allocation on each day of the week. First, you have the day-tariff assignment.

“day=>1,0” means that the tariff 0 is applied on each “Monday”. The days of the week are allocated beginning with Monday – 1 up to Sunday – 7. There is also an 8th day of the week, the holidays the first value is 8. These special days that begin with 8 are defined in “Define Holidays” After day – tariff allocation the tariff – zone correspondence follows: - each line starts with a triplet “tariff=x,yy,zz”, where “x” is the number of the tariff and “yy-zz” is the time interval when the settings that follow are applied. - After the characters “tariff=x,yy,zz” come the ten columns, the zones showing time period when a pulse is generated. The temporization values are in msec, so if a value is “60000” this means 60 seconds

- **Method 3:**

“ 3xxx” – the calls are charged according with a tariff. This is an extension (refinement) of Method1. Besides the number of pulses upon answering and the period for generating pulses, now you can specify also a period without tax pulses and the number of pulses per taxing period. This kind of billing is used by several mobile telephony carriers. If you select method 3, you may change only the “Tariff Index” value. There are maximum 10 tariffs, so values for “Tariff Index” can be value from 0 to 9.



The list of all tariffs is defined in the window “Pulse Calculation based on Tariffs”, which is displayed by pressing the button “...”.

Pulses Calculation based on Tariffs

Number of pulses at response

Period without pulses generation

Number of pulses at defined period

Pulses generating period (seconds)

☒ Tariff0

5

60

1

10

☒ Tariff1

1

60

1

10

☐ Tariff2

☐ Tariff3

☐ Tariff4

☐ Tariff5

☐ Tariff6

☐ Tariff7

☐ Tariff8☐ Tariff9

OK

Cancel

Help

In the picture above, “Tariff1” is defined as follows: - one pulse is sent upon answering - then follows a one minute pause, for 60 seconds no pulses are sent - after 60 seconds one pulse is sent every 10 seconds.

Note:In the “Tax” field, there is also a facility for limiting the maximum duration of a call limit.

For this, you select “4” for the value of the field “Method”. This is NOT really a method for calculating the charge for a call!

Computing Tax Field

Method

4

Time

60

OK

Cancel

Help

With this, you may impose a time limit for the call. The value for "Time" is in minutes, so the example above means that no calls longer than one hour will be allowed.

Sign2

Action='DIR' - for SS7

Here the user can specify in case of a SS7 route some translations parameters as follows:

Computing Translation Parameters (for SS7 route)

Nature of Address

<input type="checkbox"/> Check Called Party NAI	Called Party NAI	Unkown
<input type="checkbox"/> Override Called Party NAI	Override Called Party NAI	Unkown
<input type="checkbox"/> Override Calling Party NAI	Override Calling Party NAI	Unkown

Type of Media Required

<input type="checkbox"/> Check Media Required	Media Required	speech
---	----------------	--------

☐ Translation Occured

OK Cancel Help

- **Nature of Address** - the first zone is related to 'Nature of Address' information.

We can allow the route to be available just for a specific "NAI" field by selecting the '**Check Called Party NAI**' checkbox and value from "Called Party NAI" list. We offer the possibility to override the '**Called Party**' nature of address and '**Calling Party**' nature of address. The '**Called Party**' nature of address is changed by enabling the first two options '**Check Called Party NAI**' and '**Override Called Party NAI**'. The original '**Called Party NAI**' - Subscriber, Unkown, National, International and UK Specific - can be changed to '**Override Called Party NAI**' which contains the same list as the first one.


Moreover the '**Calling Party NAI**' can be override by selecting a value from '**Override Calling Party NAI**' and enabling the '**Override Calling Party NAI**' option.

- **Type of Media Required** - the route will be available just for the specified type of media.

Possible values are 'speech', '64k_unrestr' and '3K1Hz_audio'.

- **Translation Occured** - is used to indicate for SS7 that a translation of number has occurred

Action='SERV',Destination='PLAY RELEASE'



First option is used to enable/disable playing the appropriate file. The second option is used to enable/disable "Tx Progress".

Ctime


This parameter establish the maximum call duration (in minutes). It is similar to "Tax" method 4. If this value is set here (not 0) the "Tax" method 4 will be ignored.

Search Mode/Search Param

This parameter is used for routing in case of using routes with the same prefix. In such a case a method for overflowing and dividing the traffic between several routes must be provided. Each routes from such a group must have "Retry Atempt" option in "Sign1 field" (0x1000).

Overflow is performed if one of the following situations occurs: - when the call is routed on VoIP - the main application is checking if the number of simultaneously calls is greater then the maximum number of output calls established in diripout settings (see DIRIPOUT section). - when the call is dropped from the remote side with a release cause which is set for rerouting in "traffic.cfg". For example to reroute on congestion message the line "rerouteoncause 34 1" must be added in "traffic.cfg".

We assume this premise in the following explanations. This parameter is used in conjunction with "Search Param" parameters:



Search Mode:

- **ASR - Search Param** is not used; the route will be chosen based on ASR value
- **ACD - Search Param** is not used; the route will be chosen based on ACD value
- **Priority - Search Param** is not used; the call will be routed based on direction priority (direction specified in "dest" field). Calls from the routing group (with the same prefix) will go mostly on the direction with the highest priority. If the maximum number of calls is reached (for example for a direction specified in "DIR IP OUT" settings when "Max Calls Out" value is passed)
- **Down - Search Param** is not used; the route will be chosen from the first to the last one. Depending on the position in routing table the first route from the group will have the highest priority.
- **Up - Search Param** is not used; the route will be chosen from the last to the first one. Depending on the position in routing table the last route from the group will have the highest priority.
- **Circular - Search Param** is not used; the route will be chosen circularly.
- **Percent - Search Param** specifies the percent Calls will be routed based on percentage. The application running on TOPEX machine knows the number of calls on each machine.


Sign3

Action='SERV',Destination is a QUEUE service

When 'Action' field is 'SERV' and "Destination" field is 'SERV_QUEUE','LOGIN_QUEUE','LOGOUT_QUEUE' or 'SERV_GET_FROM_QUEUE' - those services are used to implement the call center feature. It allows incoming calls to be queued until an operator is available to answer. Operators are normal SIP users registered to the system (in case when the box allows SIP registration). For the operators it is not allowed to register multiple sip phones with the same username and password.

SERV_QUEUE

In order to put a call in queue it must be routed to the 'SERV_QUEUE'. The 'Sign3' field contains information about the number of the queue group (possible values are "- Not Used -" or a value from 1 to 50) and about the chosen queue algorithm. Those values can be easily changed by pressing the "..." button located in the right side of the 'Sign3' field.




The "Queue Algorithm" can be selected from the following list:

- 0=queue_only - just put the call on queue until somebody will pick it up
- 1=circular - send calls to each operator logged in in circular mode
- 2=priority - priority can be set from sip user settings for each allowed queue
- 3=min time speech - send calls always to the operator with lowest time speech
- 4=min calls - send calls always to the operator with lowest numbers of calls

LOGIN_QUEUE

To login into a queue, the operator must dial the prefix routed to 'LOGIN_QUEUE'.

The 'Sign3' field contains information about the number of the queue group (possible values are '- Not Used -' or a value from 1 to 50). These value can be easily changed by pressing the "..." button located in the right side of the 'Sign3' field.



LOGOUT_QUEUE

To logout from a queue operator must dial the prefix routed to 'LOGOUT_QUEUE'.

The "Sign3" field contains information about the number of the queue group (possible values are "- Not Used -" or a value from 1 to 50). These value can be easily changed by pressing the "..." button located in the righth side of the "Sign3" field. The "Computing Queue Signaling Field" window which is displayed is the same with the one used for "LOGIN_QUEUE".


SERV_GET_FROM_QUEUE

Allow an operator to pickup a call from queue by dialing "SERV_GET_FROM_QUEUE" prefix and optional followed by id or ani. The "Sign3" field contains information about:

- the **queue number** (possible values are "- Not Used -" or a value from 1 to 50)


Pickup algorithms:

- 0=max call duration; pickup the call with max duration
- 1=ANI; pickup the call with specified ANI
- 2=Id; pickup the call with specified Id
- the third option is '**Operators Only**' indicating that the service is used just by the operators.



Action='SERV',Destination='CONFERENCE'


- **Conference_id**: represents the number of the conference, the conference room.
- **Conference Length** : represents the dimension of the conference (how many users(ports) will be allocated for this conference room) if the conference has one call then the main application will reserve in advanced the number of voip ports present in the dimension field for the conference.



The dialog box titled "Computing Conference Signaling Field" contains two input fields: "Conference Id" with a dropdown menu showing the value "3", and "Conference Length" with a dropdown menu showing the value "15". At the bottom, there are three buttons: "OK" with a green checkmark icon, "Cancel" with a red X icon, and "Help" with a green question mark icon. A small icon of a document with a pencil is located in the top right corner of the dialog box.

Action='SERV',Destination='HUNTING'

The pair of settings "SERV" and "Dest=HUNTING" is used for hunting in case of SIP users. There is a setting in SIP user's window definition regarding the membership into a hunting group (a value from 1 to 50). An incoming call routed on SERV and HUNTING will ring to all SIP users belonging to the same hunting group. You can define a timeout for this action. Those two fields are stored in Sign3 field and can be edited through the "..." button.



The dialog box titled "Computing Hunting Signaling Field" contains two input fields: "Hunting Group" with a dropdown menu showing the value "1", and "Timeout Ring" with a text box containing the value "10". At the bottom, there are three buttons: "OK" with a green checkmark icon, "Cancel" with a red X icon, and "Help" with a green question mark icon. A small icon of a document with a pencil is located in the top right corner of the dialog box.

Sign4

Action='DIR' - contains settings for SS7

Computing Translation Parameters (for SS7 route)

Calling Category

<input type="checkbox"/> Check IN Category	IN Category	unknown
<input type="checkbox"/> Override IN Category	Override IN Category	unknown
<input type="checkbox"/> Check NOA Calling Party	NOA Calling Party	Unkown

☐ ROUTEPLAYBEFOREANSWER

☐ ROUTEPLAYATANSWER

☐ CATEGTOSIP

OK Cancel Help

We can allow the route to be available just for a specific '**IN Category**' field by selecting the '**Check IN Category**' checkbox and value from "IN Category" list.


To override the **incoming category** - the '**Check IN Category**' and '**Override IN Category**' must be selected. In the '**IN Category**' list - you select the incoming category which will be replaced with '**Override IN Category**'. The possible values are:

- "unknown"
- "op_french"
- "op_english"
- "op_german"
- "op_russian"
- "op_spain"
- "op_rsrv1"
- "op_rsrv2"
- "op_rsrv3"
- "notused"
- "ord_subscr"
- "prio_subscr"
- "data_call"
- "test_call"
- "payphone"
- "uk_oper_call"
- "uk_admin_diverted"

The '**NOA**' field can be checked in order to validate the route record. This is performed based on the '**Check NOA Calling Party**' checkbox and '**NOA Calling Party**' list - with the following values

- "Subscriber"
- "Unknown"
- "National"
- "International"
- "UK Specific"
- **ROUTEPLAYBEFOREANSWER**
- **ROUTEPLAYATANSWER**
- **CATEGTOSIP** - it enables to forward the calling party category to SIP

Sign5



- **Play only for Ported Numbers** - If is set then will play routing announcement only to ported numbers


OAM / Access Out

Back to Main Page > OAM

Access OUT

Note: Access OUT is used to establish the destination for VOIP calls

DIRIP OUT is located at Call directions



In Access OUT user defines for each direction name (class):

- **Protocol** – a protocol (SIP or H323)
- **IP** - a destination IP
- **Port** - a port used for signaling for example 1720 for H323 and 5060 for SIP (or 0 for default value for both protocols)
- **MaxCallsOut** - the maximum number of outgoing calls.
- **RTPProxy** - must be enabled if the destination IP is behind a NAT.
- **Transcoding** - must be enabled when the source and the destination has different codecs. The codec may be changed if, for instance if the destination IP does “know” just one codec, so we must perform a transcoding;
- **Priority** - this parameter represents the priority of the direction. This parameter can be also set in "Sign2" field in the direction definition ("Define calls direction")

Note: Based on "MaxCallsOut" the gateway application offer the possibility to allow overflow over an IP direction


OAM / Max Call duration

[Back to Main Page > OAM](#)

Max call duration

- Connect with OAM
- Go to routing table

Double click on the route you want to limit and at Tax select method 4 and input time in minutes.



The image shows a dialog box titled "Computing Tax Field". It has a close button (X) in the top right corner and a print icon. The dialog contains two fields: "Method" with a dropdown menu showing "4" and a button with three dots, and "Time" with a text input field containing "60". At the bottom, there are three buttons: "OK" with a green checkmark, "Cancel" with a red X, and "Help" with a green question mark.



Best Practice

To avoid problems always setup a max talk time for your calls

OAM / Overflow


Back to Main Page > OAM

Overflow

Warning: Work in progress. This article may be incomplete. Come back in a few days.

Overflow can be easily configured using Routing Table. In the example below i will overflow calls from GSM to ISDN. Calls will first attempt to use a GSM port and if none is available they will use the ISDN trunk to get out

- Connect with OAM
- Open Routing Table



- There are 2 routes present both with prefix 0 One has destination GSM and one ISDN1

Edit routing table

Incoming direction: **DEFAULT**

Prefix: **0**

Action: **DIR**

Destination: **GSM**

Ignore: **0**

Ignore_Id: **0**

Sign1: **10a3**

Tax: **0000**

Sign2: **00000000**

Ctime: **0**

Search Mode: **0**

Search Param: **0**

Sign3: **00000000**

Sign4: **00000000**

Sign5: **00000000**

Sign6: **00000000**

Start Time: **00:00:00**

End Time: **23:59:59**

Dows: **FF**

Billing Profile: **0**

Play File Name:

Out Billing Profile: **0**

Route Name: **ROUTE1245233013_0**

IP: **---** Port: **0**

Insert:

Insert_Id:

Computing Signaling Field

Digit 4
Number of Seconds: **8**

Digit 3 and Digit 2
Number of Digits: **10**

☐ Restrict ID

☐ Check Operator

Digit 1

☐ Simulate Tax

☒ Retry Attempt

☐ Alloc BSS

OK **Cancel** **Help**

Editing routing table

Incoming direction:

DEFAULT

Prefix:

0

Action:

DIR

Destination:

ISDN1

Ignore:

0

Ignore_Id:

0

Sign1:

10a3

Tax:

0000

Sign2:

00000000

Ctime:

0

Search Mode:

0

Search Param:

0

Sign3:

00000000

Sign4:

00000000

Sign5:

00000000

Sign6:

00000000

Start Time:

00:00:00

End Time:

23:59:59

Dows:

FF

Billing Profile:

0

Play File Name:

Out Billing Profile:

0

Route Name

ROUTE1251357486_0

IP:

Port:

0

Insert:

Insert_Id:

Computing Signaling Field

Digit 4

Number of Seconds

8

Digit 3 and Digit 2

Number of Digits

10

☐ Restrict ID

☐ Check Operator

Digit 1

☐ Simulate Tax

☒ Retry Attempt

☐ Alloc BSS

OK

Cancel

OK

Cancel

Help

OAM / Monitor calls

[Back to Main Page > OAM](#)

Monitor calls with OAM

For viewing **online calls** on the gateway equipment - you can choose icon to start call monitoring (" "). If the call monitoring process is started then the icon will be displayed in a gray rectangle. The call monitoring can be stopped at any time by pressing one more time the same icon or the window closing box. Following the validation of the icon, several types of monitoring windows can be displayed:

a) LIVE Monitoring (n), where n may be from 1 to 4

b) LIVE Monitoring – Report on DIRECTIONS

c) LIVE Monitoring – IP signaling

a) The first type of window, “LIVE Monitoring (n)”, is used to see on line the calls passing all the range of ports of the gateway. The range is defined from 0 to 1471, for all directions on incoming and outgoing sides. The user has the possibility to open up to 4 (four) windows of that type. The tooltip displayed for the live monitoring icon is “Calls monitoring – new window”. When all the four windows are opened the icon tooltip will show “Calls monitoring – no window available”. Through those four windows you have the possibility to filter calls from different directions on both incoming or outgoing ways.

The digit “n” shown between the round brackets (and) represents the index of the window - it can be a value from one to four. In this example you see the window (1):

Type	PortS	Number	Identity	Day and Time	Duration1	Duration2	Status	PortD	End	End2
IN	258	100		10-03-06 12:24:48	4		CONNECTED	32		

Each call in progress is displayed with following parameters:

- **type** (IN / OUT),
- **the port source** ("PortS"), **-number made** ("Number"), **-identity of the call** ("Identity"), **-day and time**, **-the field "Duration1"** is filled with the time of selection. **-the field "Duration2"** is filled with the conversation time. **-the status of a call** can take the following values: "SETUP", "PROCEED", "ALERTING", "CONNECTED" and "RELEASED" (the background color is different for each type of status). **-the destination port** ("PortD") - can

take a value of "65535" until the incoming call is routed through an destination port. - **"End"** - finalization call mode - possible values are AOK, BOK, ARELS, BRELS, AINEX, BINEX, ACONG, BCONG, ASERR, BSERR, ANERR, BNERR, ANANS, BNANS, ABUSY, BBUSY, ATOUT and BTOUT. It indicates the mode of ending the call:

- first character indicates who has released the call: A=caller party or B=called party
- next characters are keywords detailing how the call was ended: OK - ANSWER (response in the destination part), RELS - RELEASE (release in other situation then ring-back tone or busy), INEX - INEX (non-existent from equipment point of view - no defined route), CONG - CONG (congestion from equipment point of view - no available resources), SERR - SERR (Signaling error), NERR - NERR (Network error), NANS - NO ANSWER (release on ring-back tone), BUSY - BUSY (release on busy situation) and TOUT - TIMEOUT (timer expiration)
- **"End2"** - finalization call mode on ISDN calls - possible values are '31' (normal call) for non ISDN calls or values from ISDN standard for release code - **"IP:Port (sign)"** – the IP signaling port – filled in case of incoming voip calls and viewing IN records or in case of outgoing calls and viewing OUT records (IN, OUT settings are performed through the "Filer" option). - **"IP:Port (RTP)"** – the IP signaling RTP – filled in case of incoming voip calls and viewing IN records or in case of outgoing calls and viewing OUT records (IN, OUT settings are performed through the "Filer" option).

Day and Time	Duration1	Duration2	Status	PortD	End	End2	IP:Port (sign)	IP:Port (RTP)
10-03-06 12:30:05	2	1	RELEASED	157	BOK	16	0.0.0.0:65535	0.0.0.0:65535
10-03-06 12:30:05	2	1	RELEASED	158	BOK	16	0.0.0.0:65535	0.0.0.0:65535
10-03-06 12:30:05	2	1	RELEASED	159	BOK	16	0.0.0.0:65535	0.0.0.0:65535
10-03-06 12:30:03	0		SETUP				0.0.0.0:65535	0.0.0.0:65535
10-03-06 12:30:03	1	0	RELEASED	65535	ACONG	34	0.0.0.0:65535	0.0.0.0:65535
10-03-06 12:30:03	1	0	RELEASED	65535	ACONG	34	0.0.0.0:65535	0.0.0.0:65535
10-03-06 12:29:15	2		CONNECTED	32			192.168.1.152:25349	192.168.1.152:49192

Note1: The fields "Duration2", "End" and "End2" are filled only when the status field takes the value "RELEASED".

Note2: Initially the LIVE MONITORING window displays the IN records (the incoming side of each call; not the output side of the call. This is performed in order not to have the same call into two records. Because for an incoming call will have in case of routing succes another correspondent line in which the source port is the destination port from the other record.)

The Filter option displays a window "Live Monitoring Filter" in which you can select as you wish the range of ports to be monitorized through the live monitoring process.

Live Monitoring Filter

Port Section:

Select port range: 0-1471

Direction (Port Source): 255

Type: ☒ IN ☒ OUT

Direction (Port Destination): 255

OK Cancel


You can select a range of ports for which to display the "LIVE Monitoring". The format to be used is "xx-yy" for a range of port or simple 'x' for just a port. The separation character is a comma ",". The monitoring will be displayed for the selected ports (the cumulation for the range of ports and ports). The default range which is used is from 0 to 1471. Also you can select a direction for viewing incoming or outgoing calls (Direction – port source or port destination).

The name of log file is always "livex.txt" (where 'x' is 1,2,3 or 4 depending of the "LIVE Monitoring" window rank). The content of the file can be reset with the option "Reset".

On the bottom of "LIVE Monitoring" window there is a statistic (which can be restarted through the "Clear" button), which contains the live number of total calls and connected calls, the ASR and ACD values and the time since the supervision was started.



The "Graph" button is used to display a statistic on the last 60 minutes upon the values of ASR and ACD.



In the upper part of the previous picture you can see a statistic on the ACD (Average call duration). The color which is used for ACD is blue, and for the average ACD is yellow.

On the bottom half of the last picture there is a statistic on the ASR. The color which is used for ASR is green, and for the average ACD is yellow.

The calculated values for both ASR and ACD are highlighted in blue color. Tooltips with the calculated values are displayed if the user put the mouse over those points.

b) LIVE Monitoring – Report on Directions

This live monitoring window show an online statistic on each direction (input and output) and a total. Only the directions for which at least a port is installed on the gateway will be displayed. There is an indication on each

direction about the number of connected calls (displayed with blue color), number of attempted calls (displayed with red color) and online ASR. By pressing on a column (IN or OUT) for a direction a new window will be displayed ("Type of call end" window).

Direction	IN	OUT
LOCAL	45/108 41%	
TEST		
ISDN1		0/3 0%
SS71		45/99 45%
TETRA		
MYVOIP		
---TOTAL---	45/108 41%	45/102 44%

Here you can obtain detailed information regarding the end of a call attempt. The information is structured in three columns:

- first column "Side A" contains all calls released from caller party.- second column "Side B" contains all calls released from called party. - third column "Total" contains all calls.


For each zone, when you click over a column, the causes for calls releasing are detailed as shown:

	Side A	Side B	TOTAL
OK	0/50 0%	39/40 97%	39/90 43%
RELS	50/50 100%	1/40 2%	51/90 56%
INEX	0/50 0%	0/40 0%	0/90 0%
CONG	0/50 0%	0/40 0%	0/90 0%
SERR	0/50 0%	0/40 0%	0/90 0%
NERR	0/50 0%	0/40 0%	0/90 0%
NANS	0/50 0%	0/40 0%	0/90 0%
BUSY	0/50 0%	0/40 0%	0/90 0%
TOUT	0/50 0%	0/40 0%	0/90 0%

c) LIVE Monitoring – IP Signaling

A single window which provides access to the calls which are passing through our equipment. This happens when the gateway is performing just the VoIP signaling and when the RTP is made without using the resources of gateway

VoIP channels, or in case of incoming VoIP calls. The first type of calls are not using the VoIP ports of EONES and therefore cannot be displayed in one normal windows of the LIVE MONITORING feature. Thus you need the "IP signaling" window to be able to monitor the calls that are bypassing the equipment:



Idx	IdxR	Number	Identity	Day and Time	Duration1	Duration2	Status	End	End2	IP:Port (sign)	IP
0	1	5235		10-03-06 12:54:09	14		CONNECTED			192.168.1.152:32261	19
1	0	235		10-03-06 12:54:09	14		CONNECTED			192.168.244.167:47110	19

Those are temporary records. For the first type of windows – the records are preserved after disconnection until a new records is coming on the same input or output port. In this second case the records are deleted after 20 seconds.

To close live monitoring windows – you should close down all windows of the first type. Then Live monitoring windows for directions and IP signaling will be also closed, automatically.

Note1: the fields "Duration2", "End" and "End2" are filled only when the status field is takes the value "RELEASED".

Note2: You can select a range of ports for which to display the "LIVE Monitoring". The format to be used is "xx-yy". The calls monitoring will be displayed for the ports in range from "xx" to "yy". Those two values must be separated by the minus character "-". The option "Set" must be used to validate the new port range. The default range which is used is ports from 0 to 319.

Note3: You can select the option "IN" or "OUT". Those two options are about the type of the call (from the point of view of the TOPEX gateway): incoming or outgoing calls. The default option is "IN", it is automatically selected at startup of live monitoring.

Note4: You may also save all online messages regarding the progress of the calls into a log file. The name of this log file is always "live.txt". The content of the file can be reset with the option "Reset".

OAM / SIM Management

Back to Main Page > OAM

SIM Management

There are 2 way of managing sims.

Load balancing

Load Balancing

Load balancing will attempt to equalize the talk time on the sims installed for a GSM port (where multiple sims are present)

It is algorithm that will automatically select first available sim for a GSM port. It is activated at Call Directions

Load Balancing will always select SIM with the lowest Load.

If multiple SIMS are present the equipment will switch to another SIM every TChange seconds or every 30 min if Tchange is not present

Note: 4 ports GSM boards have only 1 sim slot. Don't activate Load Balancing use Sim Index instead



Best Practice

If you have only one sim per GSM port use **Sim Index** to select the sim. Load balancing will increase SIM registration time

Load Balancing over SIM Index

Is used to enable the load-balancing algorithm ("equal load") on the SIM/RUIM cards that are already selected by SIM index algorithm. **Load Balancing over SIM Index** will spread the calls over all the ports available in the same direction.

Sim Index

Sim Index is a predefined list specifying what sim to be active (from the 4 sims per port) at a certain time.

- SIM INDEX 0 -- will use first sim
- SIM INDEX 1 -- will use second sim
- SIM INDEX 2 -- will use third sim
- SIM INDEX 3 -- will use third sim

All list can be customized at **SIM Table**

In the list are displayed the periods (intervals) that specify the SIM/RUIM card (1, 2, 3 or 4) to be used. The time periods are structured in hours and minutes separated by the colon character ":".

When the user changes the selection in the list, the fields which are located at the bottom of the window are automatically filled with the line information: period "From" to "Until" and the active SIM card. These values can be modified and validated by option "Mod". If user selects "Add" option a new line will be added in the list. The "Del" option is used to delete a record from the list.

The periods are checked before adding or modifying operation. An error message is generated if the character ":" is not preserved or the values used are wrong (hours or minutes).

The lines that are containing "255" instead of an active SIM card are not saved in the "simindex" file. The format of the "simindex" file is compacted in order to have a smaller size.

OAM / DTMF


Using DTMF

Dual-tone multi-frequency (DTMF) signaling is used for telephone signalling over the line in the voice-frequency band to the call switching center. ...

<http://en.wikipedia.org/wiki/DTMF>

Note:By default DTMF is not activated. DTMF reception and transmission must be activated on each trunk at Call Directions

- Connect with OAM
- Go to Call Directions
- Double click on the trunk on which you need to activate DTMF
- Go to Signaling6 and select the type of DTMF that will be used



- Press OK button

RxDTMF - DTMF that will be received. Select only one type

Note:In case of GSM select "IN BAND". In order to send DTMF over GSM you must have a good GSM signal over 24/31

TxDTMF - DTMF that will be sent. Only one can be selected

Types of DTMF

Sip Info - <http://www.faqs.org/rfcs/rfc2976.html>

H245 Alphanumeric - <http://www.itu.int/rec/T-REC-H.245/e>

H245 Signal - <http://www.itu.int/rec/T-REC-H.245/e>

Q931 Keypad - http://www.ttc.or.jp/j/document_list/sum/sumE_JT-Q931v9.pdf

RFC2833 - <http://www.faqs.org/rfcs/rfc2833.html>

In Band - <http://www.rfc-editor.org/rfc/rfc4733.txt>

NOTE

For dtmf over gsm it might be necessary to set the modems to use full rate codecs. To do this you must edit the vcss files of the equipment and add the file bellow:

For more details see: VCSS files for Wavecom

```
[general]
typeport=GSM
name=000
[configAT]
cmd=>0,cmd,AT&F
cmd=>0,answer,OK
cmd=>0,timeout,1000
cmd=>1,cmd,AT+CFUN=1
cmd=>1,timeout,30000
cmd=>2,cmd,AT+SPEAKER=0
cmd=>2,timeout,1000
cmd=>3,cmd,AT+WSVG=1
cmd=>3,timeout,3000
cmd=>4,cmd,AT+VGR=144
cmd=>4,timeout,3000
cmd=>5,cmd,AT+VGT=0
cmd=>5,timeout,3000
cmd=>6,cmd,AT+WVR=0,0
cmd=>6,timeout,2000
cmd=>7,cmd,AT+CMGF=1
cmd=>7,answer,OK
cmd=>7,timeout,3000
cmd=>8,cmd,AT+CNMI=2,2,0,0,1
cmd=>8,answer,OK
cmd=>8,timeout,1000
cmd=>9,cmd,AT+CLIP=1
```

```
cmd=>9,timeout,2000
```

OAM / DISA

[Back to Main Page > OAM](#)

DISA

DISA will allow incoming calls from gsm. Callers will be connected to a DISA tone allowing them to dial into the equipment.



Best Practice

In order to use DISA a valid route must be present in the routing table. That route must have a larger timer at **Number of seconds** to allow the caller to dial the entire number. Check Routing table for more details about **Number of Seconds**

- Connect with OAM
- Click on a gsm port

GSM Settings Port 32

Category:

- ☒ Installed
- ☒ IN
- ☒ OUT
- ☒ DISA
- ☐ Monitoring

Saving Options:

- ☐ Apply settings for all positions on card
- ☐ Category
- ☐ Director
- ☐ Sim index
- ☐ Target

Direction (class): Vodafone

Sim index: 0

Target: 032

Second Category: 02000000
(simserver ready - 02000000)

Save Cancel Help

Pin Code	Load Sim	Reset	Max	Set
Pin Code 1: 0000	Load Sim 1: 0 (0:0)	Reset	Max1: 1073741823 (17895697:3)	Set
Pin Code 2: 0000	Load Sim 2: 0 (0:0)	Reset	Max2: 1073741823 (17895697:3)	Set
Pin Code 3: 0000	Load Sim 3: 0 (0:0)	Reset	Max3: 1073741823 (17895697:3)	Set
Pin Code 4: 0000	Load Sim 4: 0 (0:0)	Reset	Max4: 1073741823 (17895697:3)	Set

TChange: 1800 Set

☐ Apply changes for entire direction Refresh

- Activate DTMF on the gsm trunk.
- Make sure that **DISA** and **IN** box are checked and press **SAVE** button

OAM / Forward Incoming GSM Calls

Back to Main Page > OAM

Forward Incoming calls from GSM



Best Practice

Check OAM / Call Flow to find out the path of a incoming GSM call

- Activate DISA on all gsm ports that you want to use to receive incoming calls.
- Go to Call Directions
- Double click on the gsm trunk
- At Insert Field input the number to witch you want to forward all calls.

Note: If no number is inserted at Call Directions call will be connected to a DISA tone that will allow the caller to dial the number. DTMF must be activated on the GSM trunk otherwise number dialled will not be recognised. Check DTMF for more details

Edit direction (class) parameters

Name: vodafone

Type: DIR

Overflow: vodafone

Overflow2: vodafone

Restriction: 0

Ignore: 0

Ignore_id: 0

Sign1: 000b

Sign2: 00000000

Sign3: 00000000

Sign4: 00000000

Sign5: 00000000

Sign6: 00000000

Insert: 2004

Max_d: 20

Max_id: 20

OK Cancel Help

- Check "Forward call without answer" at Sign4.
- Go to Routing Table and make sure there is a valid prefix for the number that you inserted at Call Directions

Edit routing table

Incoming direction:	DEFAULT	Route Name	ROUTE1236254128_0	
Prefix:	2	IP:	---	Port: 0
Action:	DIR	Insert:		
Destination:	ISDN1	Insert_Id:		
Ignore:	0			
Ignore_Id:	0			
Sign1:	0045			
Tax:	0000			
Sign2:	00000000			
Ctime:	0			
Search Mode:	0			
Search Param:	0			
Sign3:	00000000			
Sign4:	00000000			
Sign5:	00000000			
Sign6:	00000000			
Start Time	00:00:00			
End Time	23:59:59			
Dows	FF			
Billing Profile	0			
Play File Name				

OK Cancel Help


Note: If you need to forward the calls to a VOIP you must first create an entry with the ip of the remote equipment in DIRIPOUT Settings

OAM / Send SMS


[Back to Main Page](#) > OAM

Send SMS from OAM

Right click on a gsm port and select Send SMS.



A popup box will appear. Enter phone number and text message. SMS center is not mandatory



Note: At this time sending sms to a group of numbers is not possible from OAM

OAM / Check Credit

[Back to Main Page > OAM](#)

Checking credit from OAM

Warning: Checking Credit or Recharging only works if there are no calls on the equipment at that time

Check credit works by matching a pattern just before the string with the credit value. If the OAM matches the pattern then he assumes that right after the pattern the next digits are the credit value. The file below must be edited and the correct number to check credit must be inputted and the correct pattern.

1. Create a txt file in OAM folder (in the folder where OAM exe file resides) and add the following text. Save the file as check_credit.txt (remove the comments before)

Warning: Make sure that no spaces exist at the end of all the commands or the script will fail to execute

```
at+cmgf=1
OK
20
0
at+cnmi=2,2,0,0,1
OK
20
0
atd*123# //this is the number where you check credit. Do not leave default !
apeluri: //this is the pattern that the OAM will try to match. Do not leave default !
40
3
```

2. Connect with OAM to the equipment
3. From OAM select Facilities and then Commands
4. Write command:

```
execute -f check_credit.txt -d GSM
```

Note: GSM is the name of the trunk on which you want to check credit

or

```
execute -f check_credit.txt -p 121
```

Note: 121 is the port number on which you want to check credit

A file called atresp.txt, will be created in OAM folder containing credit received from the operator.

Recharging from OAM

To recharge simcards from OAM you need to create 2 txt files in the OAM folder. One file will contain the commands used to recharge credit the other will contain the recharge codes

1. Create a txt file in OAM folder (in the folder where OAM exe file resides) and add the following text. Save the file as load_credit.txt (remove the comments before)

```
at+cmgfb=1
OK
25
0
at+cnmi=2,2,0,0,1
OK
25
0
atd*525*$# //this is the number where you recharge credit. Do not leave default !
apeluri: //this is the pattern that the OAM will try to match. Do not leave default !
50
5
```

2. Create a second file called coduri.txt . This file will contain the recharge code and the port on which that recharge code will be used

```
0609143178918 120
1234567890123 121
```

3. Connect with OAM to the equipment

4. From OAM select Facilities and then Commands

5. Write command: execute -f load_credit.txt -i coduri.txt

OAM / ALARMS

[Back to Main Page > OAM](#)

Alarms

99 not known or not detectable



Best Practice


Make sure you have a good gsm signal before starting calls on the equipment. A low signal will influence the quality of the calls and ASR and ACD of the equipment. Use an outdoor antenna when possible to get the best signal available

OAM / Download Billing


Back to Main Page > OAM

Downloading CDR Files


- Connect with OAM. From Actions select Auto Downloading Files



- Select the time period and the type of file



- Click on billing to show downloaded files. Files are also downloaded to the OAM folder, in the Billing folder of the equipment. The downloaded files have the .tax extension, they have to be renamed to .csv in order to be opened with a spread-sheet program. The format of the file can be found at: [1]



- go to the billing file you want to see, and by double clicking the left mouse button a dialog window will pop up, allowing you to build a filter for selective display of the billing information. This filter for billing (taxation) files permits the setting of options and values for searching records inside the subdirectory for billing.

The first field, "**Period**", indicates the time period corresponding by default to the name of the billing that you have selected. You may change this default period to extend the time interval that is analyzed. For each of the "**From**" and "**Until**" limits, subfields are "**Day**" and "**Hour**". The program will look for records in the billing files whose name falls inside the selected time period.

From the **source** point of view you may specify these options: - physical position of the **source port- port number** (for an exchange subscriber call) or **caller identity- a direction** - a name of a direction defined in "Directions Names"- the **source port type**: local or junction (trunk)From the call **destination** (called part) point of view you may specify these options:- **digits** from the destination digits. You can choose to select only records with the number of destination digits less, equal or greater than the value typed.- physical position of **destination port- a direction**- a name of a direction defined in "Directions Names"- a value for **SIM card** (1,2,3,4 or 255)(when the destination port is a GSM port)- a value for IMSI code - a value for CELL codeThe section "**IP and Port Filter**" contains several options to select:

From the incoming call side:	From the outgoing call side:
- signaling IP	- signaling IP
- signaling port	- signaling port
- RTP IP	- RTP IP
- RTP port	- RTP port

You may specify a filter on the **finalization call mode**. All calls and also the billing records have a caller and a called party. For an incoming call on E1 trunk the source party will be a channel on the trunk and the call will be routed over a GSM interface (the destination port). Caller party will be represented by 'A' and called party by 'B' (field "**Release Side**"). Depending by the side which ends the call a letter ('A' or 'B') will be shown and the finalization mode will contain one of the following strings:

OK - ANSWER, RELS - RELEASE, INEX - INEX, CONG - CONG, SERR - SERR, NERR - NERR, NANS - NO ANSWER, BUSY - BUSY, TOUT - TIMEOUT.

"**Call Type**" lets you to specify the mode of ending of the call.

Note: physical port position on a E1 trunk is computed in the following procedure: for E1 trunk installed on card 32 (trunk 6) the port will be 256 + channel number on E1 trunk, for E1 trunk installed on card 33 (trunk 7) the port will be 288 + channel number on E1 trunk, for E1 trunk installed on card 16 (trunk 2) the port will be 128 + channel number on E1 trunk and for E1 trunk installed on card 17 (trunk 3) the port will be 160 + channel number on E1 trunk.

You may set a value for "**ISDN EndType**" which represents call release code for ISDN calls. Other types of calls will display a value of '31' in the billing records.

You may also set the option to select the records with the **conversation duration** and the **selection duration** (in seconds) less, equal or greater than the value typed.

The maximum size of the fields is 8 for the periods (date and hour), 2 for the number of digits, 3 for the source port position, sim index and ISDN EndType, 5 for destination port position, 6 for duration, 3 for selection duration, 16 for specifying IMSI code and 20 for specifying destination digits.

Certain values from the billing filter are checked before validation (by pressing the button "OK"). The program checks correctness of the following:

- **period definition** (day and hour - day less or equal to 31, month less or equal to 12, year less or equal to 36, hour less or equal to 23, minute less or equal to 59 and second less or equal to 59);
- **port position of the call source** (in range 0 to 319);
- **sim index** (in range 1 to 4 or 255);
- **destination port position** (65535 or a value in the range from 0 to 319);
- **duration and selection duration** (a value greater or equal to zero);
- **number of digits** (a value greater or equal to zero);
- **ISDN EndType** (a value greater or equal to zero);

If something is wrong, an error message will be shown to the user and the field that has caused the error will be colored in red (while the text color becomes white). When the user goes back to the incorrect field in order to correct the wrong data, then the red color will disappear. In the following example an error message "Wrong port value" is displayed because of an error field on port position (a value "342" which is greater than the maximum number of 319)

Billing Filter

Period
 Day From: 21-04-07 Until: 21-04-07
 Hour From: 00:00:00 Until: 23:59:59

Call Source
☒ Specify port position value: 433
☐ Specify identity value: All
☐ Specify trunk value: CNX_CRG
 Port Type: ☒ SUBSCRIBER ☒ JUNCTION

Release Side
☒ A Side ☒ B Side

Call Type
☒ ANSWER ☒ CONG ☒ NO ANSWER
☒ RELEASE ☒ SERR ☒ BUSY
☒ INEX ☒ NERR ☒ TIMEOUT

ISDN EndType
☐ Specify value: All

Selection Duration
☐ Specify value: All

Duration
☐ Specify value: All

Call Destination
☐ Destination digits: All
☐ Number of destination digits: All
☐ Destination Port Position: All
☐ Specify trunk value: CNX_CRG

IP and Port Filter
☐ Activate IP Filter
 Signaling IP Source: All
 Signaling Port Source: All
 RTP IP Source: All
 RTP Port Source: All
 Signaling IP Dest: All
 Signaling Port Dest: All
 RTP IP Dest: All
 RTP Port Dest: All

CELL
☐ Specify value: All

Report Type
☐ Display only the records without a total
☐ Display only the total without the records

Report Definition

OK Cancel Help

Finally, you can set the option for viewing only the totals of the recording (option **"Display only the total without the records"**) that corresponds to the selected criteria or you can choose to display the values without totals (option **"Display only the records without a total"**).

The option "Display only the records without a total" is useful for filtering out the records in a certain time interval for the purpose of post-processing of the stored billing information (post-processing is done for cost analysis). For these applications, you need a text file with values only (that may be imported into a spreadsheet like Excel) but without totals interspread in it.

The option **"Report Definition"** is used to define the columns to be displayed in the "Billing Report". These columns will be explained later in this chapter. The information regarding the billing columns to be displayed is stored in the file "tax_rep.dat" on the harddisk in the same directory from where "gwconfig" software is running. In this file it is also saved the information about the size of the columns presented in the billing report.

Billing Report Definition

<input checked="" type="checkbox"/> File	<input checked="" type="checkbox"/> SIM	<input checked="" type="checkbox"/> RTP IP Source	<input checked="" type="checkbox"/> Client_id	<input checked="" type="checkbox"/> Nr_out
<input checked="" type="checkbox"/> Type	<input checked="" type="checkbox"/> PortID	<input checked="" type="checkbox"/> RTP Port Source	<input checked="" type="checkbox"/> DirNameOut	<input checked="" type="checkbox"/> Orig_ANI
<input checked="" type="checkbox"/> PortS	<input checked="" type="checkbox"/> End	<input checked="" type="checkbox"/> Signaling IP Destination	<input checked="" type="checkbox"/> Protoln	<input checked="" type="checkbox"/> Con_DNIS
<input checked="" type="checkbox"/> Ident	<input checked="" type="checkbox"/> End2	<input checked="" type="checkbox"/> Signaling Port Destination	<input checked="" type="checkbox"/> ProtoOut	
<input checked="" type="checkbox"/> CallDigits	<input checked="" type="checkbox"/> IMSI	<input checked="" type="checkbox"/> RTP IP Destination	<input checked="" type="checkbox"/> PayloadType	
<input checked="" type="checkbox"/> Day and Time	<input checked="" type="checkbox"/> CELL	<input checked="" type="checkbox"/> RTP Port Destination	<input checked="" type="checkbox"/> PacketizationTime	
<input checked="" type="checkbox"/> Selection	<input checked="" type="checkbox"/> Direction	<input checked="" type="checkbox"/> SessionID	<input checked="" type="checkbox"/> Out_client_id	
<input checked="" type="checkbox"/> Duration	<input checked="" type="checkbox"/> Signaling IP Source	<input checked="" type="checkbox"/> Jitter	<input checked="" type="checkbox"/> Gw_name	
<input checked="" type="checkbox"/> TaxUnits	<input checked="" type="checkbox"/> Signaling Port Source	<input checked="" type="checkbox"/> PacketLoss	<input checked="" type="checkbox"/> Id_out	

OK Cancel Default

By pressing "OK" button all Billing records corresponding to the filter criteria will be seen.

Viewing file cfg_TEST\viewer\100304_100304.tot

File	Type	PortS	Ident	CallDigits	Day and Time	Duration	TaxUnits	SIM	PortD	End	End2	IMSI
10-03-04.tax	TLI	00120	120	81712345678	10-03-04 12:16:05	000000	00001	#	85535	AINEX	1	
10-03-04.tax	TLI	00120	120	81712345678	10-03-04 12:16:33	000000	00001	#	85535	ACONG	34	
10-03-04.tax	TLI	00120	120	81712345678	10-03-04 12:25:15	000000	00001	1	00008	BBUSY	17	2222222222222222
10-03-04.tax	TLI	00120	120	81712345678	10-03-04 12:41:13	000000	00001	1	00009	ARELS	16	2222222222222222
10-03-04.tax	TLI	00120	120	81712345678	10-03-04 14:28:29	000006	00001	1	00008	ADK	16	2222222222222222
10-03-04.tax	TLI	00120	120	81712345678	10-03-04 14:30:43	000004	00001	1	00008	BOK	16	2222222222222222

File 10-03-04.tax

```

00-01: Att: 0000000000,Conn: 0000000000,ASR: --- ,Dur: 0000000000,TU: 00000000
01-02: Att: 0000000000,Conn: 0000000000,ASR: --- ,Dur: 0000000000,TU: 00000000
02-03: Att: 0000000000,Conn: 0000000000,ASR: --- ,Dur: 0000000000,TU: 00000000
03-04: Att: 0000000000,Conn: 0000000000,ASR: --- ,Dur: 0000000000,TU: 00000000
04-05: Att: 0000000000,Conn: 0000000000,ASR: --- ,Dur: 0000000000,TU: 00000000
05-06: Att: 0000000000,Conn: 0000000000,ASR: --- ,Dur: 0000000000,TU: 00000000
06-07: Att: 0000000000,Conn: 0000000000,ASR: --- ,Dur: 0000000000,TU: 00000000

```

Buttons: FIND, NEXT, Print, Cancel, Help

In the dialog window that shows up you can see a total for each day (from the selected interval) and time intervals that include: **total number of attempts** (field "Attempts"), **total number of connected calls** (field "Connected"), **ASR** (field "ASR"), **total duration** of calls (conversation part-field "Duration"), associated billing units (field "TaxUnits"), and at the end a **total** for all of the intervals - total number of attempts, total number of connected calls, ASR, total duration and billing units.

Note1: All the recordings, together with the totals, are saved in the "Viewer" subdirectory for the chosen system in a file with the "tot" extension and the name corresponding to the selected time interval. This way you may get both the total of calls for several days and also a general total.

Note2: Once you have defined a filter for the billing files, some of its settings will be saved, so you can apply the same filter to several billing files. The settings established in the billing filter are saved in the file "tax_fl.dat" on the harddisk in the directory where "gwconfig" software is running. These settings are: "Port Type" (section "Call Source") - subscriber part and junction part, "Release Side" ("A Side" or "B Side"), "Call Type" ("ANSWER", "RELEASE", "INEX", "CONG", "SERR", "NERR", "NO ANSWER", "BUSY" and "TIMEOUT") and the options regarding the viewing of totals and billing records ("Display only the total without the records" and "Display only the records without a total"). These settings are loaded before the showing of the billing filter in order to be pre-established.

Note3: a sorting operation can be performed on all fields (except "Type" field). The sorting operation is activated by clicking the desired column. The first operation on a field is an ascending sort. The indication will be the character "^" which is added to the column name. `Ident ^` A second click on the same field will give an descending sort. The indication will be the character "v" which is added to the column name. `Ident v` An example of sorting the column "Ident" is provided for both ascending and descending sort. Depending of the number of records the sorting operation can take a significant amount of time.

OAM / Download ASR

[Back to Main Page](#) > OAM


ASR Statistics

How To's

Connect to Multiaccess or Qutex

Connecting using serial cable

Serial



Baud rate: 115200 bps

Data bits: 8

Parity: none

Stop bits: 1

Flow control: none

Note:Username and password depend on the type of processor card installed in the equipment check this page for default passwords of your equipment

Important warning: *It is highly recommended that you change the default password, in order to prevent unauthorized accesses to the TOPEX multiAccess! So as soon as you finished performing the settings, please change the default initial password with one of your own choosing. Use the command `change_passwd` to change the log-in password.*

If the connection was successful, the window below shows up with the message "Logon OK!". If you do not see the "login" cursor, you must wait until it will show up again (usually the delay is of maximum 60 seconds) to repeat the login procedure.

After connecting to the TOPEX system, you may use Linux commands for navigating through the directory structure of the TOPEX system,

Connecting using SSH

SSH

Note: User name and password depend on the type of processor card installed in the equipment check this page for default passwords of your equipment

In case of using an Ethernet connection, you can use a remote connection to the TOPEX equipment. This is done by “ssh” from Linux or using a program that performs **ssh** under another operating system (for instance Putty).

[Secure Shell (SSH), also known as Secure Socket Shell, is a command interface and protocol for getting **secure** access to a remote computer. To ensure this secure access **ssh** commands are encrypted and secure in several ways: both ends of the client/server connection are authenticated using a digital certificate, and passwords are protected by being encrypted.]


Note: Default ssh port is 2222

In Linux, you enter the following command to connect to the multiAccess gateway:

ssh -p 2222 tpxadm@<IP address of TOPEX EoneS>

When using Putty the connection is done as shown in the window below:

On the screen will appear a window which asks for the user name (login name) and the password.



Note: For security reasons, the direct login as „root” can be performed only from those terminals that are included in the list of „secure” (trusted) terminals. From terminals that are not included in this list log-in can be done only indirectly, by log-in as a non-privileged user and going into root mode with the command **su** - followed by the root password.

[On a Linux system, privileged user is the system or network administrator, who has access right above those of an ordinary, non-privileged user. Direct access to **root** is available only for privileged users].

Remember that the terminal on COM2 serial port is included in the list of trusted terminals, while the pseudo-terminals used by **ssh** are not on this list.

Change IP Address

Changing Ip Address

Changing ip for PGRUC board

Warning:To change ip address you need root access

- The equipment is configured with a default ip address. The ip is **192.168.1.21**. To change ip address you must connect to equipment first.

```
rw
```

- You have to edit 2 files

```
vi /etc/sysconfig/eth0
```

- Used to change ip address and netmask
- To setup default gateway edit /etc/sysconfig/gw

```
vi /etc/sysconfig/gw
```

Note:Reboot equipment to use the new settings

```
/sbin/reboot
```



Best Practice

If you have a Voip Board in the equipment is is necessary to configure the voip before rebooting equipment

Changing ip for PGVOIP board

- The equipment is configured with a default ip address. The ip is 192.168.1.21. To change ip address you must connect to equipment first.

Note:All equipments that are using PGVOIP card have a read only operating system. To put the system in read-write use the folowing command:

```
rw
```

- Edit file /etc/network/interfaces

```
vi /etc/network/interfaces
```

Warning: Do not change ip on interface eth1

Note: Interface eth0 is labelled LAN interface eth2 is labelled WAN

File: /etc/network/interfaces

```
# eth0: LAN_interface:
# eth1: CSP<-->MSP communication interface (DO NOT CHANGE OR REMOVE!! THE SYSTEM WILL NOT START PROPERLY!!)
# eth2: WAN_interface:

#auto bond0
#iface bond0 inet static
#   address 192.168.110.15
#   netmask 255.255.0.0
#   gateway 192.168.1.2
#   broadcast 192.168.255.255
#   post-up ifenslave bond0 eth0
#   post-up ifenslave bond0 eth2
#   pre-down ifenslave -d bond0 eth0 eth2

auto lo
iface lo inet loopback

auto eth0
iface eth0 inet static
    address 89.28.22.129
    network 89.28.22.0
    netmask 255.255.254.0
    broadcast 89.28.23.255
    gateway 89.28.22.1

auto eth2
iface eth2 inet static
    address 10.10.10.1
    network 10.10.0.0
    netmask 255.255.0.0
    broadcast 10.10.255.255

auto eth1
iface eth1 inet static
    address 10.0.0.9
    network 10.0.0.0
    netmask 255.255.255.255
    broadcast 10.0.0.255
```

- Reboot system with command:

/sbin/reboot

Change Date and Time

Changing Date on Multiaccess, Qutex and Voibridge

- Root access is needed in order to change date on equipments. Please check this page for more information

Warning: In order to change date all topex software running on the machine must be stopped. Check this page for informations regarding the correct stop procedure

- Stop centrala (main application)

```
killall centrala
```

or

```
ps -e f  
kill -2 <pid centrala>
```

- Run /mnt/app/delmod

```
/mnt/app/bin/delmod
```

- Change date (type date --help in a linux console for more information about date command)

```
date MMDDHHMMYY
```

- Make disk read-write:

```
rw
```

- Write Date in BIOS

```
/sbin/hwclock --systohc --utc
```

- Reboot Equipment

```
/sbin/reboot
```

Using a NTP Server

- Configure correct timezone

```
ln -s /usr/share/zoneinfo/"timezone" /etc/localtime
```

- Edit /mnt/app/bin/start_app and input the ip of the NTP server

Note: Ping pool.ntp.org from your computer if you don't have your own NTP server, and use the ip discovered

```
ntpdate 91.121.92.90 &
```

Note: For Voibridge you must first make the partition read-write with the rw command and after you modify start_app, save the modifications with saveconfig

- Reboot System

```
/sbin/reboot
```

SEO: Change date Multiaccess, Change date Qutex, Change date Topex

Check harddisk for problems

Checking Hard disk for Problems

Note: From the hardware point of view hard disk is the most sensitive part of the equipment. Stopping equipments that use a hard disk directly from the power button will damage the hard disk. We strongly recommend using a UPS if the power grid is unreliable

- Gain root access to the equipment. Check this page for more informations
- Change working folder to /mnt/app/bin

```
cd /mnt/app/bin
```

- Rename start_app to start_app.bak

```
mv start_app start_app.bak
```

- Reboot the system

```
/sbin/reboot
```

- After reboot reconnect to equipment and unmount /mnt partition

Warning: On older boxes /dev/hda2 is the correct partition. On newer boxes you must unmount /dev/hda3. Unmounting the partition by his mount point will always unmount the correct partition

```
umount /mnt
```

- Run fsck on the unmounted partition until no errors are reported

Warning: Running fsck.ext3 on a mounted partition will cause damage to the partition. Always check if the partition is still mounted with command mount

```
fsck.ext3 -f /dev/hda3
```

- Remount partition

```
mount /mnt
```

- Rename start_app.bak to start_app

```
cd /mnt/app/bin
```

```
mv start_app.bak start_app
```

- Reboot the system

```
/sbin/reboot
```


Clean restart/shutdown

GoTo >Main Page > centrala

Bellow commands are useful for centrala upgrade or clean shutdown.

Telnet commands:

- **reject all calls**
All incoming calls are rejected from now on!. You need to restart the application in order to receive new calls!
- **kill all calls**
Kill all connected calls; you can check after this command if you still have calls with commands: view calls or view proxy calls
- **save billing queues**
write SQL CDRs from billing pool queues to text files, see Billing generic (apply to PGSQL, MySQL, MSSQL).
You can check after the status of billing pools with command: view pools
Starting with version 4.3.51 (see centrala version) it will kill also calls in ringing states.

Command flow example:

1. telnet 127.0.0.1
2. reject all calls
3. kill all calls
4. view calls
5. view proxycalls
Repeat step 3 until you have 0 calls on step 4 and 5.
6. save billing queue
Repeat step 6 until you have queue value 0 at pools: pgsql_bill_pool, pgsql_bill_pool2, mysql_bill_pool, mssql_bill_pool.
7. quit
8. /etc/ini.d/softswitch stop/restart or killall centrala

Stop/Start Logs

GoTo > Main Page > centrala

Note: All log files will be generated in folder /mnt/app/out/

Start Logging



Best Practice

Activating full logging can generate more then 100M of log files per hour. Don't forget logging activated or it will fill-up the hard disk in 12-14h

- Edit /mnt/app/cfg/exec.cfg to activate logging and change **db_cons** and **db_file** to 1 like below

```
# SerSpeed(0-OFF) COM IPport(0-OFF) db_cons db_file db_alarms db_cfg db_gsm s_txt s_bin bin/txt outfile outmnt www_chg
o 115200          1  9009          1      1      1      1      1      1      1      0      1      1      1
```

Note: There are multiple files in /mnt/app/cfg that need to be edited in order to start logging

exec.cfg -- Here main log file can be enabled and also some logging levels can be defined

sip_pbx.cfg -- Sip logs can be enabled here

traffic.cfg -- Port monitoring can be enabled here (what ports activity will be included in logging)

mspd.cfg -- Voip logging

Stop Logging

- All log files can be stopped by editing file /mnt/app/cfg/exec.cfg. In order to stop logs change **db_cons** and **db_file** to 0 like below

```
# SerSpeed(0-OFF) COM IPport(0-OFF) db_cons db_file db_alarms db_cfg db_gsm s_txt s_bin bin/txt outfile outmnt www_chg
o 115200          1  9009          0      0      1      1      1      1      1      0      1      1      1
```

Note: changing **db_cons** and **db_file** to 0 will stop all logging regardless of the configuration in other cfg files

Reroute on cause X

GoTo >Main Page > centrala

Reroute on cause allows the called to be retried on another destination if it fails on the default destination with a predefined cause

Note:In order to have a reroute on cause X scenario you have to define 2 routes with the same prefix and with different priorities:

Ex: dir.cfg (2 routes with the same prefix pointing to 2 directions)

```
r DEFAULT 1820019 DIR RT 0 0 00 c 00 c 0091 1000 131300 0 0 0 0 0 0 00:00:00 23:59:59 255 0 ROUTE1232373180_0 c
r DEFAULT 1820019 DIR RT2 0 0 00 c 00 c 0091 1000 131300 0 0 0 0 0 0 00:00:00 23:59:59 255 0 ROUTE1233318595_0 c
```

Note: On both routes you have to set the retry attempt for each route in Sign 1 (value: 1000) (check routing in OAM)

In this example traffic will be rerouted to RT2 if it fails on first route (RT) with cause 34 or 24 In trafic.cfg you have to add the lines:

```
rerouteoncause 34 1
rerouteoncause 27 1
|               | |---1=ON 0=OFF
|               |-----Q931 Cause
```

|-----keyword for rerouting function

Upgrade Software

GoTo > Main Page > centrala

Warning: *You need root access to be able to upgrade software on the equipments*

Automatic Update

- Login to the equipment using SSH and gain root access

Warning: *Do not use this update process on VoxyPlus Advanced or on Multiaccess with PGVOIP card*

- Issue command

```
rw
```

- Edit file "/etc/resolv.conf" and add a namserver

```
nameserver 8.8.8.8
```

- Move to folder /home/gsmgw/

```
cd /home/gsmgw/
```

- Download latest software

```
wget http://update.pabx.ro/PGVOIP_updates/_current-app.img
```

- Begin update by issuing command

```
upgrade /home/gsmgw/_current-app.img
```

- Reboot equipment once the update is done

```
reboot
```

Manual Update



Best Practice

Execute the upgrades in the order described here

Main software:

- * centrala is the main application software.
- * h323_apc is implementation of h323 protocol.
- * mspd = Multimedia Streaming Protocol Daemon, is an interface between Mindspeed M82xxx chip set (Topex PGVoIP or Topex xVoip cards) and a and centrala.

Upgrade centrala

* Software Version

```
/mnt/app/bin/centrala -v |grep Ver
```

```
Ver 4.1.34
```

- Upload new version of software to the machine (use WinSCP or scp to upload software). Upload the new file to tpxadm or gsmgw home folder

Note: Newer processors use the harddisk in read only mode. In order to upload new software you need to put the harddisk in read-write mode with command *rw*

- Centrala software is sometimes archived as tar.bz2. Unpack the software before moving to the next step

```
tar jxvfp name_of_archive.tar.bz2
```

- Find the centrala pid in order to stop it. Use command:

```
ps -e f
```

PID	TTY	STAT	TIME	COMMAND
1	?	S	0:00	init
2	?	SN	0:00	[ksoftirqd/0]
3	?	S<	0:03	[events/0]
4	?	S<	0:00	_ [khelper]
5	?	S<	0:24	_ [kblockd/0]
8	?	S	0:00	_ [pdflush]
9	?	S	0:49	_ [pdflush]
11	?	S<	0:00	_ [aio/0]
84	?	S<	0:00	_ [sercom kthread]
89	?	S<	0:04	_ [mfvs engine]
94	?	S<	0:01	_ [mtp3engine]
95	?	S<	0:00	_ [netmanag]
5402	?	S<	0:16	_ [xdsp_sgtrm_engi]
6	?	S	0:00	[khubd]
7	?	S	0:00	[kapmd]
10	?	S	0:00	[kswapd0]
12	?	S	0:00	[kseriod]
13	?	S	0:04	[kjournald]
54	?	S	11:23	[kjournald]
61	?	Ss	0:00	/bin/sh /mnt/app/bin/start_app
102	?	S	0:01	_ /bin/sh /mnt/app/bin/run_clean.sh
6096	?	S	0:00	_ sleep 3200
104	?	S	642:49	_ /mnt/app/bin/centrala -c /mnt/app/cfg/ -d /mnt/a
108	?	S	5:22	_ /mnt/app/bin/h323_apc_new -p9010
111	?	S	0:01	_ /mnt/app/bin/mspd - -v --mem 16 --no-gw -m 00
112	?	S	0:00	_ /mnt/app/bin/mspd - -v --mem 16 --no-gw -
113	?	S	0:00	_ /mnt/app/bin/mspd - -v --mem 16 --no-
115	?	S	1:59	_ /mnt/app/bin/mspd - -v --mem 16 --no-
116	?	S	0:00	_ /mnt/app/bin/mspd - -v --mem 16 --no-
117	?	S	0:15	_ /mnt/app/bin/mspd - -v --mem 16 --no-
118	?	S	0:00	_ /mnt/app/bin/mspd - -v --mem 16 --no-
127	?	S	0:00	_ /mnt/app/bin/mspd - -v --mem 16 --no-
128	?	S	0:00	_ /mnt/app/bin/mspd - -v --mem 16 --no-
63	?	Ss	0:00	/sbin/syslogd -f /etc/syslog.conf
64	tty2	Ss+	0:00	/sbin/agetty tty2 19200
65	tty3	Ss+	0:00	/sbin/agetty tty3 19200
66	ttyS1	Ss+	0:00	/sbin/agetty ttyS1 19200 ansi

```

 81 ?      Ss      0:02 /usr/sbin/sshd
6097 ?      Ss      0:00  \_ sshd: gsmgw [priv]
6099 ?      S       0:00      \_ sshd: gsmgw@pts/0
6100 pts/0   Ss      0:00          \_ -bash
6101 pts/0   S       0:00              \_ -bash
6102 pts/0   R+      0:00                  \_ ps -e f -e f

```

Warning: Stopping centrala will stop all calls on the equipment check Clean restart/shutdown for instructions on how to stop all calls before upgrade

- To stop centrala use command:

```
kill -2 104
```

104 is centrala PID . If centrala is stopped with -2 (SIGINT) he will then stop all slave applications such as MSPD, SS7, H323.

- Move to centrala folder/**/mnt/app/bin/**

```
cd /mnt/app/bin/
```

- Copy centrala from user folder to **/mnt/app/bin/**

```
cp /home/tpxadm/centrala_4.2.27 ./
```

- Create a new symlink to point to new centrala

```
ln -sf centrala_4.2.27 centrala
```



Best Practice

Don't delete or overwrite old software. Use ln to create a symlink. This will allow you to revert to the previous version if something goes wrong during update

Upgrade H323

*H323 is located in /mnt/app/bin and is managed by centrala

Software Version

```
/mnt/app/bin/h323_apc -v
```

```
h323 version 2.5
```

- Upload new version of software to the machine (use WinSCP or scp to upload software). Upload the new file to tpxadm or gsmgw home folder

Note: Newer processors use the hardisk in read only mode. In order to upload new software you need to put the hardisk in read-write mode with command *rw*

- Move to h323_apc folder/**/mnt/app/bin/**

```
cd /mnt/app/bin/
```

- Copy h323_apc from user folder to **/mnt/app/bin/**

```
cp /home/tpxadm/h323_apc-2.5 ./
```

- Create a new symlink to point to new h323_apc

```
ln -sf h323_apc-2.5 h323_apc
```

- Restart h323_apc

```
killall -9 h323_apc
```

Update MSPD

MSPD is the voip manager

It is located in /mnt/app/bin and it is managed by centrala

- Upload new version of software to the machine (use WinSCP or scp to upload software). Upload the new file to tpxadm or gsmgw home folder

Note: Newer processors use the hardisk in read only mode. In order to upload new software you need to put the hardisk in read-write mode with command *rw*

- Move to mspd folder

```
cd /mnt/app/bin/
```

- Copy mspd from user folder

```
cp /home/gsmgw/mspd-mg-2.5.175 ./
```

- Create a new symlink

```
ln -sf mspd-mg-2.5.175 mspd
```

- Reboot the equipment

/sbin/reboot

Call Control

CCTL features

GoTo >Main Page > centrala

Call Control Core Features

- CCTL Interfaces: SIP, H323, SS7, ISDN, R2, R1.5, Tetra, Tetrapol, GSM, CDMA, FXS, FXO, uiuiyu
- Extensible ASCII headers communication protocol between CCTL and adjacent signaling interfaces
- Master/Slave architecture: one master can manage multiple slaves (ex. Media Gateways controlled by Soft switch)
- Text/PostgreSQL Database configuration loaded into memory
- High Availability redundancy for PostgreSQL database (configuration and billing)
- CCTL call state replication for SIP connected calls
- Advanced routing based on regular expressions
- Forked child pool process used for CPU consuming and locking operation tasks
- Least Cost Routing - End cause rerouting
- Routing algorithms: ASR, ACD, priority, up/down, circular, percent, fork answer, fork ring
- E164 routing and billing
- Audio/Video RTP Proxy
- Audio Codec/DTMF Transcoding
- Supported DTMF types: SIP INFO, H245 alphanumeric (Rx only), H245 signal (Rx only), Q931 keypad, RFC 2833 ^[1], In-band (bypass, codec G711)
- CDR: CSV, PostgreSQL, MySQL, MsSQL
- Script configurable IVR states
- AccessIn list based on: IP/Netmask, IP Port, Protocol
- Number portability
- Users: SIP, FXS, Prepaid, ANI
- Call center features
- T38 fall back on pass through
- Billing profiles/prices for prepaid/postpaid and time/cost restrictions
- Radius AAA; Interconnect with: Mind, Quintum and FreeRadius
- Telnet interface
- Dynamic CLIP Routing
- Transfer from GSM


CCTL flow

GoTo >Main Page > centrala

Call control flow


IP to IP case

Access In -> Incoming Class -> Optional DB checks -> Routing table -> Outgoing class -> Access Out




SIP Users to IP case

SIP Users -> SIP Users Class -> Optional DB checks -> Routing table -> Outgoing class -> Access Out




IP to SIP Users case

Access In -> Incoming Class -> Optional DB checks -> Routing table -> Outgoing class(SIP Users Class) -> Access Out (0.0.0.0)




SIP Users to SIP Users case

SIP Users -> SIP Users Class -> Location Table -> Outgoing class(SIP Users Class) -> Access Out (0.0.0.0)




TDM to TDM case

Incoming Class -> Optional DB checks -> Routing table -> Outgoing class




IP to TDM case

Access In -> Incoming Class -> Optional DB checks -> Routing table -> Outgoing class




TDM to IP

Incoming Class -> Optional DB checks -> Routing table -> Outgoing class -> Access Out




SIP Users to Special Services

SIP Users -> SIP Users Class -> Optional DB checks -> Routing table -> Special Services




IP to Special Services

Access In -> Incoming Class -> Optional DB checks -> Routing table -> Special Services



TDM to special service

Incoming Class -> Optional DB checks -> Routing table -> Service | Hunting | Port



Access In

Is used only for IP call (SIP/H323).

For TDM calls port is directly assigned to incoming class.

It assign an incoming class for each call according to:

- IP/netmask
- TCP/UDP port
- protocol (SIP/H323)
- Prefix
- Number of digits from DNIS

Incoming class

Each call has an incoming class

Settings from incoming class will be applied to the calls assigned to it.

Here you can activate some optional database checks see bellow.

Optional DB checks:

- translate ANI
- translate DNIS
- portability
- ANI users

Routing table

It route calls to one of the following:

- outgoing class
- special service
- hunting service
- directly to a specific TDM port

Outgoing class

Settings from outgoing class will be applied to the calls routed to it.

Access Out

Is used only for IP call (SIP/H323).

For TDM calls port is directly assigned to outgoing class.

Specify the IP:Port, Protocol (SIP/H323) and Transport (UDP/TCP/TLS) where the calls are sent.

Relation between Outgoing Class and Access Out is one to one

AccessIn

GoTo > Main Page > centrala

Filtering mechanism for VOIP calls

Assigns an incoming class based on source ip/netmask, protocol, prefix.

Configuration:

- Via SSH edit file diripin.cfg
- WEB PGSQL Interface > Access In
- WEB CGI Interface

Users and Classes

GoTo > Main Page > centrala

The following type of users are supported:

- SIP users
- prepaid users
- ANI users
- FXS users

SIP users configuration:

- via SSH edit file SIPusers.cfg (text config mode)
- WEB PGSQL Interface > User Management > SIP (db config mode)
- WEB CGI Interface (text config mode)

Prepaid users configuration:

- via SSH edit file prepaid_users.cfg (text config mode)
- WEB PGSQL Interface > User Management > Prepaid (db config mode)

ANI users configuration:

- via SSH edit file callback.cfg (text config mode)
- WEB PGSQL Interface > User Management > ANI (db config mode)
- OAM > Callback table (text config mode)

FXS users configuration:

- via SSH edit files port.cfg, subscribers.cfg (text config mode)
- WEB PGSQL Interface > User Management > FXS (db config mode)

A class is a group of users or TDM ports.

Call that arrive in access_in are also assigned to a class.

Class is also known as direction in OAM interface.

Reserved class names:

- **MYVOIP** - is a reserved class name and must be configured when you have VoIP/RTPproxy cards. All ports from this cards must be assigned to class MYVOIP.
WARNING: If you have VoIP/RTPProxy cards installed without MYVOIP defined, centrala application may crash.
- **SENDSMS** - Used to send SMS from recmail or WEB CGI Interface.
- **SENDCALL** - Used to send calls from web interface
- **DEFAULT** - is a reserved name and must never be used as a class name; it is equivalent with Any value on source class filed from database config

Class configuration:

- via SSH edit file dir.cfg (text config mode)
- WEB PGSQL Interface > Server Management > Client Classes (db config mode)
- WEB CGI Interface (text config mode)

Classes are also used in routing table, see Routing table

Routing table

GoTo >Main Page > centrala

Definition

The routing table routes calls to an OutgoingClass|Service|Port according to the prefix and Incoming class

Routing algorithm takes digits from left to right one by one and try to find a match.

If a matching is done digit by digit until the end of an prefix call is routed on outgoing class assigned.

'f' - is a special character used in prefix field and means any digit.

If more that one prefix is matched used route is selected according to the search_mode algorithm. See search_mode field bellow.

If source class is specified it take precedence over other routes with "Any" as source class. I mean it first try to match source class and if no match is found it search on routes with "Any".

Caution

If you want to route calls to FXS or BRI (NT mode) destination class must have type: Port.

Reg exp prefix

Regular expression prefix are available.

Regular expression prefix must be preceded with special character 'r'.

Example: r^07[2-3]*

Prefix priority

Additional in case of reg exp prefixes, prefix priority can be specified directly into prefix field preceded by special character 'p'. Prefix priority is different than routing priority. Routing priority specify destination order for a group of matched routes with same priority prefix. In case that is not directly specified, prefix priority is given by the prefix matching length. Prefix priority must always be putted in front of the reg exp prefix. It cannot be used for normal prefixes.

Example:

DNIS: 0723235888

p12r^07[0-9]* = prefix priority is 12

072f235f = prefix priority is 6, (character f is excluded)

r0723* = prefix priority is 10

r0723 = prefix priority is 4

Caution:

DO NOT USE "f" inside a regexp expression, f has different meaning in reg exp.

Examples

- If you have for example a prefix with 3 digits 072 and one with the same first three and extra 6 digits 072333555 routing decision will be taken according to the most specific route, and that is 072333555.
- If you have a prefix with 3 digits 072 and another route with 3 digits ending with an 'f' symbol 07f, routing decision will be taken according to the most specific route, and that is 072.

Example 1:

Call info: DNIS=0723286299

Routing:

Incoming class -> Prefix -> Outgoing class

Any -> 072 -> Test_Out_1

Any -> 0723286299 -> Test_Out_2

Call will be routed on class Test_Out_2

Example 2:

Call info: DNIS=0723286299

Routing:

Incoming class -> Prefix -> Outgoing class

Any -> 072f -> Test_Out_1

Any -> 0723286299 -> Test_Out_2

Call will be routed on class Test_Out_2

Example 3:

Call info: DNIS=0723286299

Routing:

Incoming class -> Prefix -> Outgoing class

Any -> 072ffffff -> Test_Out_1

Any -> 0723286299 -> Test_Out_2

Call will be routed on class Test_Out_2

Example 4:

Call info: Incoming class=Test_In_1; DNIS=0723286299

Routing:

Incoming class -> Prefix -> Outgoing class

Test_In_1 -> 072ffffff -> Test_Out_1

Any -> 0723286299 -> Test_Out_2

Call will be routed on class Test_Out_1

Example 5:

Call info: Incoming class=Test_In_1; DNIS=0723286299

Routing:

Incoming class -> Prefix -> Outgoing class

Test_In_1 -> 072 -> Test_Out_1

Test_In_1 -> 073 -> Test_Out_2

Any -> 0723 -> Test_Out_3

Call will be routed on class Test_Out_1 because the incoming class is Test_In_1 and this is more specific.

Configuration

- via SSH edit file Dir.cfg
- OAM > Routing table
- WEB PGSQL Interface > Routes
- WEB CGI Interface

AccessOut

GoTo > Main Page > centrala

Allow you to specify destination class settings for outgoing VoIP calls.

You can see this as an extension of class settings.

Classes defined in AccessOut are mapped 1 to 1 with classes from ClientClasses.

Configuration:

- Via SSH edit file diripout.cfg
 - WEB PGSQL Interface > Access Out
 - WEB CGI Interface
-

Configuration Files

Exec.cfg

GoTo >Main Page > centrala

Warning: If you changed a value from/to 0(disable) to/from 1(enable) and you want to change it back, DO NOT comment the line, change the value back to 0 or 1. If you comment the line the value will remain unchanged

Debug Settings

```
# SerSpeed - serial speed used to open serial port (by centrala) in order to connect with OAM on it
#
# - this speed must not be changed because in OAM this speed is hard coded
#
# - 0 = disable open the serial port for OAM connection
#
# COM - Serial COM used for OAM connection
#
# IPport - IP port used for OAM connection
#
# - 0 = disable open IP port for OAM connection
#
# db_cons - 1=enable/0=disable console debug
#
# db_file - 1=enable/0=disable console debug
#
# - Important: if both db_cons and db_file are 0, debug is disabled also in SIP log file
#
# www_chg - 1=enable/0=disable reading automatically of config files when are changed
#
# - if enabled checking is done at every 5 seconds
#
# - the following files are watched: card.cfg, port.cfg, dir.cfg, restr.cfg, simindex.cfg
#
#       sim.cfg, dirname.cfg, trafic.cfg, lcr.cfg, exec.cfg, callback.cfg, bss.cfg, voice_mail.cfg
#
#       voip.cfg, group.cfg
#
# SerSpeed(0-OFF) COM IPport(0-OFF) db_cons db_file db_alarms db_cfg db_gsm s_txt s_bin bin/txt outfile outmnt www_chg
o 115200          1  9009          1      1      1      1      1      1      1      0      1      1      1
```



Best Practice

Don't change **outfile** and **outmnt** to 0. This will prevent creation of any output files including CDR

```
# Debug type configuration
# Accepted values are between 0-5 interval
#
# 0 = NO debug
#
# 1 = ERROR debug
#
# 2 = ERROR + WARN debug
#
# 3 = ERROR + WARN + INFO debug
```

```
# 4 = ERROR + WARN + INFO + FULL debug
# 5 = ERROR + WARN + INFO + FULL + VERBOSE debug
```

Configuration Debug

```
# configuration; default 5
set_cfg_debug 5
```

Telnet Debug

```
# telnet; default 2
set_telnet_debug 2
```

Call Control Debug

```
# call control; default 5
set_cctl_debug 5
```

Application Debug

```
# application; default 5
set_app_debug 5
```

Alarms

```
# alarms; default 5
set_alr_debug 5
```

OAM Debug

```
# OAM; default 2
set_oam_debug 2
```

Database Debug

```
# db forked clients; default 5
set_db_debug 5
```

Database pool clients

```
# db pool clients; default 5
set_dbp_debug 5
```

Voicemail Debug

```
# voice mail; default 5
set_vm_debug 5
```

PBX Services Debug

```
# pbx services; default 5
set_srv_debug 5
```

GSM debug

```
# gsm; default 5
set_gsm_debug 5
```

File descriptor debug

```
# file descriptors watching; default 2
set_fdw_debug 2

# matrix connections; default 5
set_connect_debug 5

# SS7 ACC; default 0
set_acc_debug 0

# serial communication; default 2
set_serial_debug 2

# ISDN Q921; default 5;
set_q921_debug 5

# ISDN Q931; default 5;
set_q931_debug 5

# database configuration loading; default 5
set_db_config_debug 5

# H323 debug from H323 log
set_debug_h323 5

# obsolete
# set_h323_debug 5

# H323 communication debug from centrala log; default 2
set_debug_pbx_h323 2

# R2S; default 5
set_r2s_debug 5
```

Process Activation

```
# process poll activation/deactivation
# format: pool_name enable/disable pool_configuration_file
# 1=enable; 0=disable; default 0
# number of process from each pool is hard coded and can be viewed by running ./centrala -v

# used for reading configuration (sip users, prepaid users, classes, ports etc) from database
# for this pool enable/disable field is not used
# you can only set the configuration file used by this pool
# pool activation is done by setting the register 4 in sip_pbx.cfg
# when register != 4 pgsql sip pool is deactivated
pgsql_sip_pool 0 pgsql_sip_pool.cfg

# used to send CDRs into Postgresql database table
pgsql_billing 0 pgsql_billing.cfg

# used to send CDRs into a second postgresql database table
# it is mostly used for redundancy reasons, in case that one database server is down
pgsql_billing_alt 0 pgsql_billing_alt.cfg

# used to send CDRs into MySQL database table
mysql_billing 0

# used to send CDRs into Microsoft SQL Server database table
mssql_billing 0

# not used, reserved for future developments
pgsql_prepaid_pool 0

# used for running in real time (during the call) pgsql queries for ANI checking
# it is also used for saving alarms to pgsql
pgsql_ani_pool 0

# used for getting info from simserver
pgsql_simserver_pool 0

# used to play rtp files
rtptx_pool 0

# used to record rtp streams
rtprx_pool 0

# used to make dns queries
dns_pool 0
```

Radius Settings

```
# Radius AAA
# enable/disable first radius pool;
# 0=disable;1=enable;default 0
# default configuration file: radius_billing.cfg
radius_billing 0 radius_billing.cfg

# enable/disable second radius pool
# this pool is used for redundancy purposes, see also Radius AAA
# 0=disable;1=enable;default 0
# default configuration file: radius_billing.cfg
radius_billing_alt 0 radius_billing_alt.cfg

# 0=Topex; 1=Quintum; default 0
# same dictionary must be configured also in pool configuration file, see Radius billing
radius_dictionary 0

# enable/disable sending radius access request for authentication
# 0=disable;1=enable;default 1
tx_access_request 1

# enable/disable sending radius access request for authorization
# 0=disable;1=enable;default 1
# starting with date 24 Sept 09 on version >= 4.3.88
tx_authorization 1

# enable/disable sending radius accounting start
# 0=disable;1=enable;default 1
# accounting can be done also without sending access request by sending only accounting stop
# anyway some special application requires also sending accounting start
tx_accounting_start 1

# specify value sent in username field from access request at incoming trunk calls
# possible values: cli/ip/class_name
# cli = caller id, ANI
# ip = source IP of the call
# class_name = source class (direction) of the call
# default empty string
radius_auth cli

# specify value sent in username field from access request at incoming calls initiated by sip users
# possible values: cli/ip
# cli = caller id, ANI
# ip = source IP of the call
# default empty string
radius_sip_user_auth ip

# enable/disable writing CDRs in mind format
# 0=disable;1=enable;default 0
mind_cdr 0
```

```
# default 0
# 0=send to radius number from routing
# 1=send to radius initial incoming number
radius_dnis 0
```

RTPPROXY Settings

```
# RTP Proxy from centrala
# number of rtpproxy ports from centrala
rtp_proxy_range 10

# number of first rtpproxy port
rtp_proxy_port 15000

# rtp ip used for calls through rtpproxy from centrala
# not used yet
rtp_ip 192.168.0.0/16 192.168.1.107
rtp_ip 0.0.0.0/0 89.38.123.34
```

```
# script executed when centrala is master
script_master script_master_name.sh
```

```
# script executed when centrala is slave
script_slave script_slave_name.sh
```

```
# 0=send DTMF at tone ON
# 1=send DTMF at tone OFF
dtmf_off 0/1

# 1=enable/0=disable t38 fax
# if you enable t38 and receive a bypass (inband G711) fax the gw will automatically switch to bypass mode
t38 0/1

# 1=block console at write on STDOUT|STDERR
# put 1 for debug only, otherwise let 0
block_cons 0/1

# if 1 put connect time of calls in billing
# if 0 put end time of calls in billing
taxstarttime 0/1

# 1=enable/0=disable voice mail
voice_mail 0/1

# 1=enable - DTMF tones are read by voip board
# 0=disable - DTMF tones are read by DSP
voip_dtmf 0/1

# telnet port
```

```
telnet 23

# 1=accept/0=reject remote telnet access
remote_telnet 0/1

# gw name
# if set this name precede the name of cdr, log and alr files from /mnt/app/out/
name topex

# timeout in milliseconds for waiting a provisional response from destination
# default is 1000 ms (1 sec)
sip_trying_timeout 1000

# 1=enable, 0=disable; default 0
# if enabled it will play the content of /mnt/app/raw/acl_reject_<codec>.<language>
# in case that the call is rejected from accessin mismatch
play_accessin 0

# comma separated dn timer list
# max 10 numbers
# First use
# If call from a SIP user belonging to a centrex group does not found a destination
# user in the same centrex group and it match one of the numbers from emergency
# list, call is routed via UA instead of being rejected with inex code
# keep in mind that destination user is searched first, so it is not recommended to have
# centrex aliases the same as emergency numbers
#
# Second use
# For trunk calls that are checked in ANI table if call identity is found (with callbackstate: Allow In)
# and match an emergency dn timer it will be rejected after playing file /mnt/app/raw/cli/emergency_<codec>.<language>
emergency_dn timer 112,911,961

# default 1GB=1000000KB
# Starting with 14 May 2009 (check build date from centrala version) default is 200 MB
# value is in kilobytes
# it is recommended to not put a higher value than default because removing old large files
# from hdd could lock the main application centrala
set_length_log_file 1000000
```

Database Configuration Settings

```
# loading configuration from database
# read cards config from db
# default 0
db_card 1

#read routes config from db
# default 0
```

```
db_route 1

# db_type must be always 2
db_type 2

# read config pupitre from db
# default 0
db_pup 0
```

Others

```
voicecallwithoutsemicolon 1 ## Don't add ; at the end of ATD string
voicecallwithoutsemicolon 0 (default)
```

```
# specify the maximum number of simultaneous IVR calls
# if a new calls is sent to the IVR while this limit is reached that will be kept in ringing
# state until an connected IVR calls is finished or it leaves the IVR state
# default 0=unlimited
max_ivr_calls 4
```

```
# default 15
gsm_callback_timeout_ring 15
```

```
# default 60000
timer_refresh_op_clock 60000
```

```
# default 15000
timerwaitloadcreditgsm 15000
```

```
# default 1500
timerwaitfornextcallgsm 1500
```

```
# default 0
set_tranzit_ss7 0/1
```

```
# default 0
set_keepalive_h323 0
```

```
# default 0
# 0 - master PG / 1 - slave PG, the slave PG will wait a period of time until it will load the cards.
backplaneaddr 0
```

```
# default 2
save_asr_dir 2
```

```
# maximum simultaneous incoming calls supported by the system
# default 10000
maxsysincallrate 10000
```



```
# maximum simultaneous outgoing calls supported by the system
# default 10000
maxsysoutcallrate 10000

# default 10000
consysincallrate 10000

# default 10000
consysoutcallrate 10000

# default 0
save_mon_file 0

# 1=enable/0=disable;default 0
# if enabled the application will cut the call when
# max cost/time in/out counters are reached
use_class_counters 0

my_pg_ip 192.168.1.23

# default 0
# if set mspd will put virtual_ip in RTP packets
use_rtp_local 0

# virtual_ip virtual_mask gw_ip
virtualIP 192.168.158.51 255.255.0.0 192.168.1.2

# default 0
slave_on_link_down 0

# default 0
use_vad_vcsc 0
```

ASCII protocol

```
# 0=disable; 1=enable; default 1
# enable ascii protocol on SIP interface
# starting with version 4.3.79 this parameter is not used anymore
set_asci_sip 1

# enable ascii protocol on H323 interface
set_asci_h323 1

# enable ascii protocol on ISDN interface
set_asci_isdn 1

# enable ascii protocol on SS7 interface
set_asci_ss7 1
```

```
# specify the number fields written in billing
# default value is 43
# 255 means to write all the fields available
# you can see the range of configurable fields on telnet with command "billing fields number"
# see also Billing generic (apply to PGSQL, MySQL, MSSQL
billing_fields_number 255

# Folositi Pentru schimbarea comunicatiei cu cartele gsm.
use_8_bit_ser_gsm 1

# size of of callback list
# default value 100
# valid range between [10 ... 5000]
# Starting with 19 August 2009 on versions >= 4.3.88 this parameter has been removed
# From that point ANI users are loaded in memory using linked list so the only limitation that
# can occur is the memory available on system
max_callback 100

# 1=enable/0=disable; default 0
dual_processor 0

# 1=enable/0=disable; default 0
# on MGU if dual_processor is activated dual_processor_new must be also activated
dual_processor_new 0

# enable=1/disable=0; default=1
# if enabled DTMF will be read by the kernel mfc module and sent to the centrala
# if disabled DTMF will be read by the app centrala directly
# put 0 on MGU to be able to send DTMF on FXO
kernel_mfc 1

# 1=enable/0=disable; default 0
# must be enabled when radio gateway is used with Coordcom
# if enabled calls to the radio ports (analogue, tetra, tetrapol)
# must be sent with the value from name field
# ex. if name=10 uri must be r109.rt3.f1.c1.d0010900821.dt1@192.168.104.14
# instead of
#          r9.rt3.f1.c1.d0010900821.dt1@192.168.104.14
use_radiogw_name 0

# 1=enable/0=disable; default 0
# must be enabled when radio gateway is used with Coordcom
# if enabled radio ports will numbered in module of 4 instead of 8 as it is in topex
radiogw_coordcom 0

# 1=centrala does NOT send AT+COPS=0 command at module initialization
# 0=centrala does send AT+COPS=0 command at module initialization
# available for centrala version newer than 4.3.30.r4250
# does not block the module if the sim is cut-off by the operator
gsm_NO_COPS 1
```

```
#1=enable, 0=disable; default 0
#specifies whether or not to add succesfull calls to Dynamic CLIP Routing
add_DCR_on_answer 1
```

```
#represents the time the call will be stored in DCR table
#time given in miliseconds
timeout_DCR 3600000
```

```
# 1=enable/0=disable; default 1
# if enabled it will accept REFER messages on trunk
trunk_REFER 1
```

```
# 1=enable/0=disable; default 0
proxy_media_transfer 0
```

```
#For 1xE1.
wait_cfg2_e1 0
```

```
# 1=enable, 0=disable; default 0
# if enabled centrala will also play a disconnect message before releasing the call
# if enabled it will play the content of /mnt/app/raw/q850/q850_<release cause>_<codec>.<language>
# If calling party is behind NAT, call will be released without play
# this feature is still under development
play_disconnect_msg 0
```

```
# default 5
# specify how many times a call can be forwarded
# max value 9
max_forward 5
```

```
# Max limit for test calls from simserver
# Time is in milliseconds
digits_timeout 300000
```

```
# default 1; 0=disable; 1=enable
# if enabled will check user name and password on OAM socket connection
# It has been introduced starting with version 4.3.94 and it replaces define NOLOGIN
oam_check_credentials 1
```

```
# default 0; 0=disable; 1=enable
# if enabled will use 1 voip slot for HDLC communication for each E1 flow
# It has been introduced starting with version 4.3.94 and it replaces define HDLCFROMVOIP
# on change restart is required
hdlc_from_voip 0
```

```
# default 0; 0=disable; 1=enable
# if enabled centrala will fork a child that will heat the heartbeat device
# otherwise centrala itself will heat the heartbeat device
# It has been introduced starting with version 4.3.94 and it replaces define CHLDHIT
# on change restart is required
```

```
child_hit_hb 0
```

```
# default 1; 0=disable; 1=enable
```

```
# if enabled centrala will fork an internal child process for each outgoing process resulted from routing  
# this applies only to forked (until ring/answer) prefixes on multiple destinations.
```

```
# if enabled involves extra CPU load, according to the number of calls forked.
```

```
# It has been introduced starting with version 4.3.94 and it replaces define MULTIROUTESCALL
```

```
fork_childs_in 1
```

```
# default 0; 0=disable; 1=enable
```

```
# It has been introduced starting with version 4.3.94 and it replaces define CALLREC
```

```
# on change restart is required
```

```
call_record 0
```

```
# default 0; 0=disable; 1=enable
```

```
# CFD=Concentrator Digital Ferroviar (Digital railway multiplexer)
```

```
# It has been introduced starting with version 4.3.94 and it replaces define CFD
```

```
# on change restart is required
```

```
CFD 0
```

```
# default 0; 0=disable; 1=enable
```

```
# It has been introduced starting with version 4.3.94 and it replaces define VCSS_DB
```

```
# on change restart is required
```

```
vcss_db_config 0
```

```
# default 0; 0=disable; 1=enable
```

```
# It has been introduced starting with version 4.3.94 and it replaces define NEWVOTING
```

```
# on change restart is required
```

```
new_voting 0
```

```
# default 0; 0=disable; 1=enable
```

```
# It has been introduced starting with version 4.3.94 and it replaces define PUPI_INTERFON
```

```
# on change restart is required
```

```
pupi_interfon 0
```

```
# default 0; 0=disable; 1=enable
```

```
# It has been introduced starting with version 4.3.94 and it replaces define USEDSP4FORRADIO
```

```
# on change restart is required
```

```
use_dsp4_for_radio 0
```

```
# default 0; 0=disable; 1=enable
```

```
STCR 0
```

```
# default 0.10
```

```
tax_unit 0.10
```

```
# default 180000 seconds, 3 minutes
```

```
# timeout until the call is still up after receiving of SUSPEND message from SS7
```

```
# this timer is configurable starting with date 02 June 2009, see build date from centrala version
```

```
timeout_suspend 180000
```

```
# enable set control command
control_gsm_from_telnet 1

# timeout in milliseconds for query a provider
# default 300000 ms
timer_gqueryprovider 300000

#insert IMSI in *.sms file
#default is disabled
gsm_sms_CIMI_2_db 1

#sms cache available from centrala_snr_15708
#default value is 1
#if disabled the sms will be dropped if no channel available or no exists for that destination
no_sms_cache 1
```

GoTo >Main Page > centrala

Trafic.cfg

GoTo >Main Page > centrala

Warning: If you changed a value from/to 0(disable) to/from 1(enable) and you want to change it back, DO NOT comment the line, change the value back to 0 or 1. If you comment the line the value will remain unchanged

```
# time interval for calculating instantaneous ASR
# default 30 seconds
asr 30
```

```
# param1: 1=enable/0=disable port debug
# param2: port start
# param3: port end
# param4: 1=enable/0=disable write to file
debug 1 0 2000 1
```

```
#param1: 1=Alerts Activated/0=Disabled
#param2: ASR Alert Limit(minutes)
#param3: Time period for checking (minutes)
#param4: Minimum calls number
#param5: Alarms for alerting
#param6: timer for testing alerts(minutes)
wake 0 80 60 100 00 0
```

```
# 00=deactivated; 18=full debug
q921_debug 00
```

```
# 00=deactivated; 18=full debug
q931_debug 00
```

```
#send ATD command without semicolon, used in conjuncture with DIRSENDDATAATD. For centrala 4.3.88_rev10000 or newer
#0 = deactivated 1=activated
voicecallwithoutsemicolon 1

# 1=enable; 0=disable; default=1
# If enabled will generate PROGRESS message for calls terminated on FXS/GSM/CDMA ports
# For SIP calls 183 Session Progress message will be sent
# It is useful if the caller want to hear the ring back or voice announcement from destination
tx_progress 1

Send ANI in fsck format for FXS ports
# default 0
tx_fsck 0

# after 20 subsequent calls not connected ring back GSM module is reseted
maxgsmfailure 20

# after 20 subsequent calls without ring back GSM module is reseted
maxgsmnoringback 20

# param1=Q850 cause received from destination
# param2=enable/disable reroute call on cause specified
rerouteoncause 34 1/0

# param1=Q850 cause received from destination
# param2=Q850 cause sent to the source of the call
translatecause 133 34

# param1= E1 card number on which you want to enable translate id
# param2=common prefix
# param3=start range
# param4=end range
translate_id_out 16 23204 00 99

#simserver
#simserver ip address
#simserver communication port
#gateway name (must be identical in simserver web interface)
simserver 192.168.1.18 13001 Voibridge

# enable/disable test calls generator
run 0
pause 10

#connex time
con 30
```

```
# in order to work SENDCALL class (direction) must be created
777 98 98 0
traffic_run 0 4 test
traffic_idle 15 1
traffic_sel 4 5
traffic_con 1 5
traffic_call 777 100
traffic_call 777 100
traffic_call 777 100
traffic_call 777 100
```

```
#resetare contori de timp pe toate modulele gsm
```

```
initcountersgsm hh mm dd
```

Dirname.cfg

GoTo >Main Page > centrala

This file contains only correspondence between id and name.
Class settings are made in dir.cfg file.
This file is used only in text configuration mode.

Important:

Starting with version 4.3.92 (see centrala version) this file is not used anymore

Default path: /mnt/app/cfg/dirname.cfg

```
:m Lines starting with ':m' character represent comments and are ignored
:m Lines starting with ':n' represent valid lines
:m Format: :n class_id class_name(direction name)
:m class_id: - integer value between >= 0 and < NR_DIR_PBX,
:m           - NR_DIR_PBX is hard coded, run centrala -v to see the value for NR_DIR_PBX
:m           - must be unique across all classes
:m class_name: max 19 characters
:n 00 MYVOIP
:n 01 FXO
:n 02 GSM
:n 03 SENDSMS
:n 04 E1R2
```

```
:n 05 ISDN1
```

Card.cfg

GoTo > Main Page > centrala

File card.cfg stores card configuration

Example of a card.cfg file with 16 GSM cards and 1 VOIP card

```
File: /mnt/app/cfg/card.cfg
#---CARD FILE---
#c nrcard type (SUB,GSM,JPABX,E&M,BL,E1R2,E1ISDNU,E1ISDNN,E1SS7,E1R1)
#c nrcard IPH323 RTPSTART (%d) NRPORTS (%d)
c 00 GSM
c 01 GSM
c 02 GSM
c 03 GSM
c 04 GSM
c 05 GSM
c 06 GSM
c 07 GSM
c 08 GSM
c 09 GSM
c 10 GSM
c 11 GSM
c 12 GSM
c 13 GSM
c 14 GSM
c 15 GSM
c 32 IPH323 31000 64
```

For ISDN Card: Even number ISDN cards have priority in establishing the system clock (It is recommended to use these ports for connecting to the PSTN. When dealing with an equipment with 4 E1 links, from which 2 E1 links are with PSTN, it is recommended to plug one PSTN link in each card, and activate Synchronize Clock on them, as E1 card activation may differ from one boot up to another.

```
c 16 E1ISDNU 2 10
c 17 E1ISDNN 6 30
```

```
#c nrcard type(E1ISDNU,E1ISDNN) [aa] [bb]
```

aa - bitmap:

0x01 - Send MFAS

0x02 - Send CRC (one side send and the other receive)

0x03 - Receive CRC (one side send and the other receive)

0x04 - Synchronize Clock - Network (one side with sync and the other with no sync); This E1 link will synchronize the system clock

0x20 - Non Generate Clock - delays the clock generation on bus giving priority to other cards (It refers to whole 2E1 card not only one E1 link)

bb:

terminalul de semnalizare 0

terminalul de semnalizare 1

```
bit.no. 8 7 6 5 | 4 | 3 2 1 0
         0 0 0 0 | 1 | 0 0 0 0 (10)
```



```
0 0 0 1 | 1 | 0 0 0 0 (30)
```

```
8 4 2 | 1 | 8 4 2 1
```

Port.cfg

GoTo >Main Page > centrala

File port.cfg stores port configuration.

FXS cat bit values:

```
- MSKINST      0x0001
- MSKLOC       0x0002
- MSKBC        0x0004
- MSKDTMFALARM 0x0004
- MSKOPPRG     0x0004
- MSKDTMF      0x0010 // Can dial in DTMF mode
- MSKAPE       0x0020 // Can make calls
- MSKBL        0x0040 // BL
- MSKIPO       0x0080 // Busy Intrusion
- MSKPUPUI     0x0100
- ISDNTYPE     0x0c00
- ISDNTYPEVCSS 0x0000
- ISDNTYPEEBRI 0x0400
- ISDNTYPEPERG 0x0800
- ISDNTYPEFREE 0x0c00
- MSKELIBBL    0x0800
- MSKURCALL    0x0800
- MSKPLTEST    0x1000
- MSKCONF      0x2000
```

FXO cat values:

```
- MSKINST      0x0001
- MSKJON       0x0002
- MSKJI        0x0004
- MSKJO        0x0008
- MSKDISA      0x0010
- MSKTON       0x0020
- MSKCROSS     MSKTON
- MSKRXSQ      0x0010 // Rx on SQ(not VOTING)
- MSKTXSQ      0x0020 // Activate SQ on Tx
- MSKEM        0x0040
- MSKEMR       0x0080
- MSKGSM       0x0080
- MSKPAG       0x0800
- MSKB1        0x0400
- MSKB2        0x0800
- MSKTAXIN     0x1000
- MSKTAXOUT    0x2000
```

```
- MSKIP      0x0200
- MSKE1      0x4000
- MSKJ       0x000c
- MSKTAX     0x3000
```

MYVOIP cat1 bit values:

```
- TRANSCODINGVOIPPORT 0x00000000
- RTPPROXYVOIPPORT    0x00100000
- HDLCVOIPPORT         0x00200000
```

GSM cat bit values

```
-NODISA 0x019f // No DISA tone
-DISA   0x018f // DISA tone
```

Example

```
#---PORT FILE---
#p port card cat(%x) cat1(%x) dir      number  restr  target (FXS)
#p port card cat(%x) cat1(%x) dir      sim      target      (GSM/CDMA)
#p port card cat(%x) cat1(%x) dir      target      (FXO)
#p port card cat(%x) cat1(%x) dir      (E1/VoIP)
p  1    1    0031    00000037 FXS      285      0        0
p  2    1    0031    00000037 FXS      ---      0        0
p  0    14    19bf    00000000 ORANGE  0        0
p  1    14    19bf    00000000 ORANGE  0        0
p  20   16    440f    00000000 ISDN
p  2    32    020f    00000000 MYVOIP
```

p 2 32 020f 00100000 MYVOIP

Dir.cfg

GoTo >Main Page > centrala

Intro

Configuration file for classes (directions) and routes.

This file is used only in text configuration mode.

See also Users and Classes and Routing table.

On save diripin.cfg and diripout.cfg are also reloaded into memory.

Route prefix order is important, must be sorted ascending from up to down.

Default path: /mnt/app/cfg/dir.cfg

Example

```
# Lines starting with '#' character represent comments and are ignored
# Lines starting with 'd' represent class settings
# Lines starting with 'r' represent routing settings
# Class settings must always be defined before routes settings
# d class type overflow_class overflow_class2 restr ign ins maxd ignid insid maxid sign1 sign2 sign3
# sign4 sign5 sign6 time_in cost_in max_time_in max_cost_in
d xxx DIR xxx xxx 00 00 c 20 00 c 20 0000 00000000 00000000 00000000 00000000 00000000
d MYVOIP DIR MYVOIP MYVOIP 00 00 c 20 00 c 20 0000 00000000 00000000 00000000 00000000 00000000
d SIPusers DIR SIPusers SIPusers 00 00 c 20 00 c 20 0000 00000000 00000000 00000000 00000000 00000000
d MYVOIP2 DIR MYVOIP2 MYVOIP2 00 00 c 20 00 c 20 0000 00000000 00000000 00000000 00000000 00000000
d SIPusers2 DIR SIPusers2 SIPusers2 00 00 c 20 00 c 20 0000 00000000 00000000 00000000 00000000 00000000
# ---ROUTE---
# r in_class prefix action destination IP Port ign ins ignid insid sign1 tax sign2 max_con_time search_mode search_data
# sign3 sign4 sign5 sign6 start_time end_time dows billing_profile_id_in route_name play_file billing_profile_id_out
r DEFAULT 1ff DIRIP SIP 192.168.192.40 0 00 c 00 c 0035 0000 0 0 0 0 0 0 0 00:00:00 23:59:59 127 0 rucu ceeee
r DEFAULT 2 SERV 00020 0 0 00 c 00 c 0000 0000 0 0 0 0 0 0 0 00:00:00 23:59:59 127 0 r1121 c
r DEFAULT 3ff DIR SIPusers 0 0 00 c 00 c 0035 0000 0 0 0 0 0 0 0 00:00:00 23:59:59 255 0 ROUTE1224991520_2 c
r DEFAULT 4 SERV 00004 0 0 00 c 00 c 0000 160a 0 0 0 0 0 0 0 00:00:00 23:59:59 255 0 ROUTE1224991520_3 c
```

Class fields description

Field 0: 'd'

Must be always 'd', comes from direction (class)

Indicate that current line is a class line

Field 1: Class name

Must be one the class names defined in dirname.cfg

Field 2: Class type

Accepted values: PORT and DIR

Field 3: Overflow class name

Overflow class name used in old style rerouting, not recommended anymore.

Field 4: Second overflow class name

Second overflow class name used in old style rerouting, not recommended anymore.

Field 5: Restriction index

Specify an restriction index defined in restr.cfg file.

Field 6: Ignore from DNIS

Specify how many digits to ignore from the beginning of DNIS.

Field 7: Insert into DNIS

Specify digits that will be inserted at the beginning of DNIS.

Field 8: Max DNIS

Specify maximum length of DNIS.

Field 9: Ignore from ANI

Specify how many digits to ignore from the beginning of ANI.

Field 10: Insert into ANI

Specify digits that will be inserted at the beginning of ANI.

Field 11: Max ANI

Specify maximum length of ANI.

Field 12: Signaling 1

Two octets bit mask.

Values:

- DIRRXID 0x0001
Receive identity
- DIRTXID 0x0002
Send identity
- DIRLOADBALANCED 0x0004
Load balancing algorithm for GSM/CDMA SIM cards
- DIRPREANSWERREVTONE 0x0008
Coupling of ring back tone
- DIRLEVEL 0x00f0
Audio level (used for GSM/CDMA modules)
- DIRTESTNET 0x0100
Test network before sending the call on GSM/CDMA
- DIRGOODASR 0x0200
In case that first call to GSM/CDMA fails it try to send call on a second module in order to have a good ASR
- DIRCATCALL 0x0400
It will cat the call when max time speech is reached used only for SIM cards; max time is set in GSM/CDMA settings
- DIRCHECKTXID 0x0800
Check if the identity is set corectly (according to DIRRXID/DIRRXID) before sending each call on GSM/CDMA module
- DIRCHECKCALLBACK 0x1000
Activate ANI checking for callback or ani users matching; see ANI users
- DIRCALCULATECOST 0x2000
- DIRBALANCEDCOST 0x4000
If this bit is not set => balanced on time
- DIRMODULECDMA 0x8000
For CDMA modules

Field 13: Signaling 2

For octets bit mask.

Values:

- DIR1TRANZITQ850 0x00000001

- DIR1BALANCEDSIMINDEX 0x00000002
- DIRSENDTAX 0x00000004
- DIRGETTAX 0x00000008
- DIRCHECKCREDIT 0x00000010 // check credit
- DIRNOPOWEROFF 0x00000020
- DIRLOADCREDIT 0x00000040 // load credit
- DIRPLAYTONE 0x00000080
- DIR1JPABXWAITDIALTONE 0x00000700 // cate 500ms asteapta venire ton pe jonctiune PABX
- DIRDELAYCDMA 0x00000f00
- DIRRINGBACKDETECT 0x00001000 // for CDMA
- DIRDELAYRESETSS7 0x00002000
- DIRTYPESEARCH 0x0000c000
- DIRTYPESEARCHUP 0x00004000
- DIRTYPESEARCHDOWN 0x00008000
- DIRCHECKCREDITFIRST 0x00010000
- DIRPRIORITY 0x0ff00000
- DIRH323NOTUNNELH245 0x10000000
- DIRH323NOFASTSTART 0x20000000
- DIRPLAYCLIERROR 0x40000000
- DIRANSWERCLIERROR 0x80000000

Field 14: Signaling 3

For octets bit mask.

- DIRTXCHANNELISDNUSER 0x00000001
- DIRCHECKDNIS 0x00000002
- DIRCHECKKANI 0x00000004
- DIRTRANSLATEDNIS 0x00000008
- DIRLIMITONTIME 0x00000010
Enable max time (in seconds) checking on this class, use_class_counters from exec.cfg must be on
- DIRCUTONERRORDB 0x00000020
- DIRLIMITONCOST 0x00000040
Enable max cost checking on this class, use_class_counters from exec.cfg must be on and a billing profile to be set
- DIRCHECKSUFIX 0x00000080
- DIRSENDLRQ 0x00000100

Field 15: Signaling 4 For octets bit mask. Values:

- DIRDELAYANSWER 0x00000001
Used for calls from GSM modules. If set it will not answer to the call until the destination answer. In order to work DISA must be checked also in GSM port category
- DIRNUMBERNORM 0x00000002
- DO_NOT_PLAY_ANN 0x00000004
If set will not play routing announcement for calls received on this class
- DIRSENDATAATD 0x00000008
- SET_ALL_DNIS 0x00000010
If set will mark ALLDIGITBIT for all calls received on this class
- DIRATDNETWORKID 0x00000020
If set call will use the gsm networks CLI settings, gsm modifiers i or I will not be used. Used only for physical

sims.

Field 16: Signaling 5

Not used yet, reserved for future developments.

Field 17: Signaling 6

- RX_SIP_INFO 0x00000001
Accept/Ignore incoming DTMF via INFO method on SIP signaling
- RX_H245_ALPHA 0x00000002
Accept/Ignore incoming DTMF via H245_Alphanumeric method on H323 signaling
- RX_H245_SIGNAL 0x00000004
Accept/Ignore incoming DTMF via H245_Signal method on H323 signaling
- RX_Q931_KEYPAD 0x00000008
Accept/Ignore incoming DTMF via Q931_Keypad method on H323 signaling
- RX_RFC2833 0x00000010
Accept/Ignore incoming DTMF via RTP with RFC 2833
- RX_INBAND 0x00000020
Accept/Ignore incoming DTMF via RTP inband (bypass). Should be used only with G711 codecs
- TX_SIP_INFO 0x00000100
Only one of the bellow values must be set at a time. Tx outgoing DTMF via INFO method on SIP signaling
- TX_H245_ALPHA 0x00000200
Tx outgoing DTMF via H245_Alphanumeric method on H323 signaling
- TX_H245_SIGNAL 0x00000400
Tx outgoing DTMF via H245_Signal method on H323 signaling. Not supported yet
- TX_Q931_KEYPAD 0x00000800
Tx outgoing DTMF via Q931_Keypad method on H323 signaling. Not supported yet
- TX_RFC2833 0x00001000
Tx outgoing DTMF via RTP with RFC 2833
- TX_INBAND 0x00002000
Tx outgoing DTMF via RTP inband (bypass). Should be used only with G711 codecs

Field 18: Time in

Represents current time (in seconds) speech on this class.

Field 19: Cost in

Represents current cost (in default currency) charged on this class.

Field 20: Max time in

Max time (in seconds) allowed to speech on this class.

Field 21: Max cost in

Max cost (in default currency) allowed on this class.

Route fields description

Field 0: 'r'

Must be always 'r', comes from route

Indicate that current line is a route line

Field 1: Incoming class name

Incoming class name according to which will be routed the call.

DEFAULT is a reserved name and means any class. Must not be defined as class name in Dirname.cfg.

Field 2: Prefix

Prefix from call DNIS that match this route.

Special characters:

f = any digit; allowed anywhere into the prefix field once or more times (ex: 07f23f56f).

r = indicates a regular expression prefix

p = specify the priority for this prefix; allowed only before the prefix a reg exp prefix.

Field 3: Action

Specify type of destination, which can be:

- **DIR(Class):**
Indicate that destination field contains a class id. For VoIP calls IP and port of outgoing class must be configured in AccessOut (Dir IP Out Settings from OAM Define calls directions window)
- **DIRIP:**
Indicate that destination field contains VoIP protocol (SIP/H323). Allow you to specify in routing rule the IP and port of destination. This action is deprecated because some of the routing features will not be supported, action Class (DIR) must be used instead.
- **LCR**
Indicate that destination field will contain a LCR (Leas Cost Routing) index. On LCR index you specify according to the time interval different destination class
- **SERV(Service)**
Indicate that destination will contain the special service number. Used to route the call on a special service.
- **HUNT(Hunting)**
Indicate that destination will contain the number of FXS hunting group. Allow you to route a call on a FXS hunting group. For SIP hunting groups SERV_HUNTING must be used.
- **PORT**
Indicate that destination will contain a port number. Used when you route a call directly to a FXS or BRI (NT mode) port

Field 4: Destination

Specify outgoing ClassId/Protocol/LCRindex/ServiceCode/HuntingGroup/PortNumber for the call. Destination type is directly related with value of Action field.

Field 5: IP

Used only when action is DIRIP.

Specify the remote IP where the call will be sent.

Field 6: Port

Used only when action is DIRIP.

Specify the remote port where the call will be sent.

Field 7: Ignore from DNIS

Specify how many digits to ignore from the beginning of DNIS.

When action is DIR and class type is PORT changed DNIS must match an ANI assigned to a port from destination class.

Ex: If FXS/BRI user numbering pool is between [100 an 199] and you have the prefix 6661ff routed to FXS/BRI class you will have to ignore 3 digits (666) from DNIS in routing, otherwise you will receive INEX.

Field 8: Insert into DNIS

Specify digits that will be inserted at the beginning of DNIS.

When action is DIR and class type is PORT changed DNIS must match an ANI assigned to a port from destination class.

Ex: If FXS/BRI user numbering pool is between [110 an 119] and you have the prefix 1f routed to FXS/BRI class you will have to insert digit '1' in front of from DNIS in routing, otherwise you will receive INEX.

Field 9: Ignore from ANI

Specify how many digits to ignore from the beginning of ANI.

Field 10: Insert into ANI

Specify digits that will be inserted at the beginning of ANI.

Field 11: Signaling 1

Two octets hexa bit mask.

- DIRCALLTOUT 0x000f - DIRCALLMAXDIG 0x01f0 - DIRREZERVE 0x0600 - DIRSIMULATECONNECT 0x0200 - ROUTERRESTRICTID 0x0400 - DIRCHECKOPERATOR 0x0800 - DIRCALLRETRY 0x1000 - CLEARDIRCALLRETRY 0xffff - DIRSIMULATETAX 0x2000 - DIRTRANZIT 0x4000 - DIRALLOCBSS 0x8000

Field 12: Tax units**Field 13: Signaling 2**

Four octets hexa bit mask.

- NOACALLEDPARTY 0x0000000f
- CHECKNOACALLEDPARTY 0x00000010
- NEWNOACALLEDPARTY 0x00000f00
- OVERRIDENOACALLEDPARTY 0x00001000
- NEWNOACALLINGPARTY 0x000f0000
- OVERRIDENOACALLINGPARTY 0x00100000
- INTMR 0x0f000000
- CHECKINTMR 0x10000000
- ROUTEPRIORITY 0x20000000
- ROUTETRANSLATENR 0x40000000

Field 14: Max connection time

Allow you to configure a max duration (in seconds) for calls on that route.

Field 15: Search_mode

Specify routing algorithm used in case you have more routes with the same prefix.

Algorithms list:

- ASR (Average Seizure Rate)
- ACD (Average Call Duration)
- Priority
- Down
- Up
- Circular
- Percent
- Fork Answer
- Fork Ringing

Field 16: Search_data

Specify values for selected algorithm in Search Mode field.

In case of Priority algorithm range value is from 0 to 9; Higher value (9) indicate higher priority.

Field 17: Signaling 3

Four octets hexa bit mask.

Specific to each special service selected.

Field 18: Signaling 4

Four octets hexa bit mask.

- INCATEGORY 0x0000000f
 - CHECKINCATEGORY 0x00000010
 - NEWINCATEGORY 0x00000f00
-

- OVERRIDEINCATEGORY 0x00001000
- ROUTEPLAYBEFOREANSWVER 0x00002000
- ROUTEPLAYATANSWER 0x00004000
- CATEGTOSIP 0x00008000 // Tx calling party category to SIP
- CALLINGNOA 0x00f00000 //national 3,subscriber 1,international 4,unknown 2,UK_specific 5
- CHECKCALLINGNOA 0x01000000 //set this bit to 1 if you want that this route to be valid only for specified NOA in CALLINGNOA

Field 19: Signaling 5 Four octets hexa bit mask.

- PLAY_PORTED_ONLY 0x00000001
If set will play routing announcement only to ported numbers

Field 20: Signaling 6

Four octets hexa bit mask.

Not used yet, reserved for future developments.

Field 21: Start time

Specify start time of day since when the route is enabled.

Format: hh-mm-ss (hour-minutes-seconds)

Example: 00:00:00

Field 22: End time

Specify end time of day after which the route is disabled.

Format: hh-mm-ss (hour-minutes-seconds)

Example: 23:59:59

Field 23: Dows

Bit mask field.

Values: Mon=0x01 Tue=0x02 Wen=0x04 Thu=0x08 Fri=0x10 Sat=0x20 Sun=0x40 Holiday=0x80

Specify days of week when the route is enabled.

You can specify also if route is valid during holidays.

Holidays are defined in Simindex.cfg file and have higher priority vs normal days.

For example if today is a defined holiday (let say 01 January) routes will be enabled/disabled according to the holiday value set ignoring the value for current day (let say Tuesday).

Field 24: Billing profile id in

Field 25: Route name

Field 26: Play file name

It is used to:

- play announcement to call source before sending the call to destination.

In this case rtp proxy is activated automatically for all calls on this route.

File path: /mnt/app/raw/

File format: <file name>_<codec(2 digits)>.<language(2 characters)>

Example: play_00.ro, test_08.en, test_play_18.en etc.

Important: play_file field from route will contain only file_name, without codec and language extensions.

Codec will be matched according to the source codecs of call.

Default language from /mnt/app/cfg/prepaid.cfg will be used.

- assign the name of IVR script that will be processed for that prefix.

In this case action=service and destination=IVR.

File path: /mnt/app/raw/ivr/

Field 27: Billing profile id out

Voip.cfg

GoTo >Main Page > centrala

Default path: /mnt/app/cfg/voip.cfg

```
# 0/1/2

# on VERSION 1 transcoding is done for all calls

# starting with version 4.3.79 this parameter is not used anymore
VERSION 2

# 0/1 dtmf INFO disabled/enabled

# deprecated, not used anymore

dtmfINFO 1

# dtmf rfc 2833

# dtmfRTP pt redundant_pt redundancy_scheme (0=IETF/1=AAL2)

# rfc2833 is disabled if this line is missing

dtmfRTP 101 100 1

# voice active detection

vad 0

# codec/ptime format

# Codec can have the following values:

# 0 PCMU

# 2 G726-32

# 4 G723

# 8 PCMA

# 18 G729a

audio_codecs 18 20 8 20 4 20 0 20

voipgw 192.168.1.2 (VOIP card IP address)

# public voip card ip

publicvoipgw 192.168.1.2

# ip of the host where the mspd application runs, usually local ip

msp 192.168.1.1

forkmspd /mnt/app/bin/mspd - -v --mem 16 --gw-mac 00:54:C2:40:7B:70 -m 00:54:C2:40:7B:71 192.168.1.2 --log /mnt/app/out/&d-&m-&y_mspd.log

h323 192.168.1.1 9010

forkh323 /mnt/app/bin/h323_apc -p9010

ss7 /tmp/ccs_sock2

forkss7 /mnt/app/bin/SS7_apc -l0 -scs_sock2 -d../dev/
```

Warning: If /mnt/app/cfg/group.cfg exists then voipgw, publicvoipgw, msp, forkmspd settings are taken from group.cfg

Diripin.cfg

GoTo >Main Page > centrala

Changes made on diripin.cfg file are loaded into memory only after saving dir.cfg file. From OAM diripin.cfg can be edited in window "Calls directions > DIR IP In Settings". If you made any changes you need to click OK twice: first in DIR IP In Settings window then in "Calls directions" window.

This file is used only in text configuration mode. AccessIn is the correspondence of diripin.cfg when database configuration mode is used.

Important:

If you have more than one line with same class name, last line will override some of the previous lines fields. The following fields value will be overwritten: maxcall, rtpproxy, transcoding, congrate, maxrate.

Default path: /mnt/app/cfg/diripin.cfg

```
# Lines starting with '#' means comments and are ignored
# Lines starting with 'i' means valid lines and are loaded into memory
# i protocol ip/netmask class_name maxcalls rtpproxy transcoding congrate maxrate prefix maxcost nrdig endcause
i SIP 0.0.0.0/0 MYVOIP 1000 0 0 1000 1000 p 0 0 0
i H323 89.38.23.78/32 GW_IN 100 1 0 100 100 p0723 0 0 0
```

Fields descriptions:

- **Field0: 'i'**
Always character 'i'
 - **Field1: Protocol**
Incoming call signaling protocol; Values: SIP or H323
 - **Field2: IP/Netmask**
Signaling source IP class
Examples:
 - 192.168.0.0/16
 - 89.38.23.144/32
 - **Field3: Class name**
Class id assigned for calls matching this line.
 - **Field4: MaxCalls**
Maximum number of simultaneous incoming calls for class assigned
 - **Field5: RTPProxy**
RTP proxy on assigned class
Values: 0=Not Used; 1=Used except same NAT; 2=Always
 - **Field6: Transcoding**
Transcoding on assigned class;
Values: 0=Not Used; 1=Different Codec; 2=Different DTMF RTP; 3=Different Codec/Different DTMF RTP; 4=Always;
 - **Field7: CongRate**
Congestion rate
-

- **Field8: MaxRate**
- **Field9: Prefix**
Incoming prefix of call. Must always have character 'p' in front.
- **Field10: MaxCost**
- **Field11: NrDig**
Number of digits received in DNIS. In number of digits received don't match the value specified here, call will be rejected with cause specified in End Cause field. 0 = disable checking the number of digits received
- **Field12: EndCause**
Q850 end code.

Diripout.cfg

[GoTo >Main Page > centrala](#)

Definition: Allows you to specify destination class settings for outgoing VoIP calls.

You can see this as an extension of class settings.

Classes defined in diripout.cfg are mapped 1 to 1 with classes from dir.cfg.

Default path: /mnt/app/cfg/diripout.cfg

Changes made on diripout.cfg file are loaded into memory only after saving dir.cfg file. From OAM diripout.cfg can be edited in window "Calls directions > DIR IP Out Settings". If you made any changes you need to click OK twice: first in "DIR IP Out Settings" window then in "Calls directions" window.

This file is used only in text configuration mode. AccessOut is the correspondence of diripout.cfg when database configuration mode is used.

Important:

If you have more than one line with same class name, last line will override some of the previous lines fields. The following fields value will be overwritten: maxcalls, rtpproxy, transcoding, congrate, maxrate, acctimer, accstep, accm, acc2timer, accproc.

```
# Lines starting with '#' means comments and are ignored
# Lines starting with 'o' means valid lines and are loaded into memory

# o class_name protocol ip port maxcalls rtpproxy transcoding congrate maxrate acctimer accstep accm acc2timer accproc transport mediaparam
o SIPusers SIP 0.0.0.0 0 30 0 0
o OUT SIP 172.18.254.254 0 30 0 0
```

Fields description:

- **Field 0: 'o'**
Always character 'i'
- **Field 1: ClassName**
Outgoing class name to which the settings from this line apply
- **Field2: Protocol**
Outgoing call signaling protocol; Values: SIP or H323.
- **Field3: IP**
Signaling destination IP.
- **Field4: Port**
Signaling destination port; 0 means default protocol value, 5060 for SIP, 1720 for H323.

- **Field5: MaxCalls**
Maximum number of simultaneous outgoing calls for this class.
- **Field6: RTPProxy**
RTP proxy on assigned class
Values: 0=Not Used; 1=Used except same NAT; 2=Always
- **Field7: Transcoding**
Transcoding on this class
Values: 0=Not Used; 1=Different Codec; 2=Different DTMF RTP; 3=Different Codec/Different DTMF RTP; 4=Always;
- **Field8: Congrate**
Congestion rate

```
default 1000
```

- **Field9: MaxRate**

```
default 1000
```

- **Field10: ACCTimer**

```
default 0
```

- **Field11: ACCStep**

```
default 0
```

- **Field12: ACCM**

```
default 0
```

- **Field13: ACC2Timer**

```
default 0
```

- **Field14: ACCproc**

```
default 0
```

- **Field15: Transport**

Transport layer used for IP call

- 0 = UDP
- 1 = TCP
- 2 = TLS

- **Field16: MediaParameters**

Format: pt=<codec_value>;ms=<ms_value>...

ms is optional and if is missing default value is 20

Example: pt=0;ms=20;pt=18;ms=20

Group.cfg

GoTo >Main Page > centrala

Warning: If file group.cfg exists Voip settings will be read from here. group.cfg has precedence over voip.cfg file

Warning: Starting Topex Ver 4.3.30 Rev: 5489, on old equipments, group 0 hast to be:

```
g 0 0 0 0 0 0 0
```

Telnet command

- view groups - show groups configuration loaded in memory

```
# master line
```

```
# 1=master, 0=slave
```

```
m 1
```

```
# group line
```

```
# field 1: g = group line indicator;
```

```
#
```

```
# field 2: group number; on versions over 4.1.90 you can see the number of groups with
```

```
#          wich centrala was builded by running centrala -v and look for NRGROUP value
```

```
#
```

```
# field 3: group type:
```

```
#          - 0=FXS, FXO, BRI, GSM, CDMA, BL, E&M, MPAAI, RADIO, ISDN-VCSS
```

```
#          - 1=E1
```

```
#          - 2=VoIP|RTPproxy
```

```
#
```

```
# field 4: remote IP
```

```
#          This field must be filled the same for all groups assigned to an equipment
```

```
#          Master case
```

```
#          - this is the IP where the master will try connect on TCP socket
```

```
#          - if IP is different than 0.0.0.0 or 0 means that the master will try to connect
```

```
#          to this IP and port from next field; so in this case you don't need a second line
```

```
#          starting with voip; this line will appear in slave group.cfg
```

```
#          - keep in mind that always the master is trying to connect to slaves defined here
```

```
#          in this file
```

```
#          Slave case:
```

```
#          - this is the bind IP of TCP server
```

```
#          - if set to 0.0.0.0 or or it will bind on all network interfaces
```

```
#
```

```
# field 5: remote Port
```

```
#          This field must be filled the same for all groups assigned to an equipment
```

```
#          Master case: this is the port where the master will try connect on TCP socket
```

```
#          Slave case: this the port on wich the server will listen for TCP connections
```

```
#
```

```
# field 6: Slave (equipment) type:
```

```
#          - 0 = Multiacces/Qtex; max 3 groups
```

```
#          - 1 = Eones; max 12 groups
#          - 2 = MGU(VoiBridge, VoxiPlus, VoxiTel); max 3 groups
#
# field 7: reserved for future development

g 0 2 195.114.116.235 9000 1 0
```

```
# voip line
# bellow line appear when type of group is 2
# filed 1: voip - voip line indicator
# field 2: group number to which this line refer
# field 3: group type, always 2
# field 4: connection IP to rtpproxy/mspd
# field 5: connection port to rtpproxy/mspd
# field 6: fork always
# field 7: path to rtpproxy/mspd and command line arguments
# next fields are are option passed to rtpproxy/mspd application

voip 2 2 127.0.0.1 9081 fork /mnt/app/bin/rtpproxy -p 9081
voip 2 2 195.114.116.235 9671 fork /mnt/app/bin/mspd -p 9671
--trace-cmd -v --mem 16 --gw-mac 00:19:AA:D2:3C:25 -m 00:52:C2:40:3E:43
195.114.116.239 --log /mnt/app/out/%d-%m-%y_mspd.log -
```

```
# rtp_ip line
# rtp_ip <group_nr> <ip_class(format: ip/netmask_len)> <rtp ip used for this class>

rtp_ip 2 192.168.0.0/16 192.168.1.193
rtp_ip 2 0.0.0.0/0 89.38.173.23
```

```
# Starting with date 25 mai 2009 (see centrala version build date) on MGU platform centrala
# will fill by default rtp_ip array for each voip group with bellow two lines
# my_pg_ip is a global variable filled by default with the IP from eth0. If eth0 is missing eth1 IP is taken and so one
# until eth4. This value can be also overwritten from exec.cfg see my_pg_ip.

rtp_ip 2 my_pg_ip/32 10.0.0.10
rtp_ip 2 0.0.0.0/0 my_pg_ip
```

RTP Proxy with Transcoding

Following configuration rule must be applied:

For each RTP proxy group, show IP (from rtp_ip) must be configured in all transcoding groups as rtp_ip pattern with mask 32.

Example of group.cfg

File: /mnt/app/cfg/group.cfg

```

m 1
#group number type location ip_remote port_remote rez1 rez2
g 0 0 0 0 0 0
g 1 1 0 0 0 0
g 2 2 0 0 0 0
rtp_ip 2 0.0.0.0/0 89.38.174.221
voip 2 2 127.0.0.1 9677 fork /mnt/app/bin/mspd -p 9677 --trace-cmd
--axf /mnt/app/data/miro_hdvoice.axf - -v --gw-mac 00:1A:E2:E8:04:C8
--mem 16 -m 00:52:C2:40:36:B3 89.38.174.221

```

Sip pbx.cfg

WARNING: Article could not be rendered - ouputting plain text.

Potential causes of the problem are: (a) a bug in the pdf-writer software (b) problematic Mediawiki markup (c) table is too wide

GoTo >Main Page > centralaExample File: /mnt/app/cfg/sip_pbx.cfg # all debug values are between 0 and 5 # 0=no debug # 1=ERROR only # 2=ERROR+WARN # 3=ERROR+WARN+INFO # 4=ERROR+WARN+INFO+DEBUG # 5=ERROR+WARN+INFO+DEBUG+VERBOSE # values higher that 5 are reserved for developers only # general debug #default 5 debug 5 # user agent calls # default 5 agent_debug 5 # sip users registration to ssw # default 2 register_server_debug 2 # ssw registration to other proxy # default 5 register_client_debug 5 # loading configuration from database # default 5 database_config_debug 5 # SUBSCRIBE/NOTIFY/PUBLISH debug # default 5 notify_debug 5 # proxy calls debug # default 5 proxy_debug 5 # OPTIONS requests # default 2 options_debug 2 # internal queues # default 2 queue_debug 2 # call state redundancy messages # default 5 redundancy_debug 5 # 0=disable, 1=enable, default 1 console_debug 1 # 0=disable, 1=enable, default 1 file_debug 1 # in kilobytes, default 1GB # Staring with 14 May 2009 (check build date from [[centrala version]]) default is 200 MB # make sure to put it under 2GB, which is default max file size on many Linux systems # it is recommended to not put a higher value than default because removing old large files # from hdd could lock the main application centrala max_log_size 200000 # 0=disable, 1=enable, default 0 tcp 0 # 0=disable, 1=enable, default 0 tls 0 #udp sip port, default 5060 sip_udp_port 5060 #tcp sip port, default 5060 sip_tcp_port 5060 #tls sip port, default 5061 sip_tls_port 5061 # 0=not used, default value # 1=postgresql database, fork precess for each request; deprecated # 2=load user settings to memory from text file # 3=postgresql database process poll; deprecated # 4=load user settings to memory from database register 0 # Keep database registration history for sip users # Specify start/end time interval within a sip user is online # 0=disable, 1=enable, default 0 register_history 0 # Update online users memory status to database table siplocation # 0=disable, 1=enable, default 1 update_location 1 # Must be always enabled # 0=disable, 1=enable, default 1 proxy 1 # Must be always enabled # if enabled all dialog messages will go through the SIP proxy # 0=disable, 1=enable, default 1 record_route 1 # Register authentication # 0=disable, 1=enable, default 0 register_auth 0 # authenticate incoming invite request on UA from sip users # 0=disable, 1=enable, default 0 users_invite_auth 1 # try to match INVITE contact with REGISTER contact of a sip user # if no match is found the call is rejected with 403 sip code # it applies only to sip users # 0=disable, 1=enable, default 1 check_invite_contact 1 # 0=disable, 1=enable, default 0 # restrict transfer on trunk restrict_trunk_transfer 0 # default empty string # if not empty this prefix will be inserted before dnis to all calls from sip users that are linked # to prepaid accounts with pin field set; this prefix must be routed to Serv IVR # On Serv IVR you need to create a script that will will prompt the user to enter # PIN code and it will check it against PIN code from linked prepaid account. check_pin_prefix *121# # timer in seconds; default

600 # used if the incoming REGISTER/SUBSCRIBE/PUBLISH don't have an expire header/parameter in request
 default_register_expire 600 default_subscribe_expire 600 default_publish_expire 600 # timer in seconds; default 200
 # force the expire refresh interval to value configured here # it has higher priority than default_xxx_expire
 forced_register_expire 600 forced_subscribe_expire 600 forced_publish_expire 600 # Type Of Service, integer
 value, default 0 to 10 # default 16 # accepted values 4, 8, 16, 32, 64 # transaction timeout, real value in seconds is
 N64/2 # ex if N64=16, transaction timeout is 8 seconds N64 16 # enable=1/disable=0 music on hold; default 0; # if
 enabled it will play file /mnt/app/raw/flashing/music_on_hold_*.** # rtpx_pool must be activated, see exec.cfg
 music_on_hold 1 # default empty string # if set will play the announcement file for each proxy call before
 forwarding INVITE on called sip user play_announcement announcement_file # Regular expressions that match
 'User-Agent' or 'Server' fields from clients that are asymmetric # regarding SIP signaling. Needed to detect when a
 client is asymmetric regarding SIP signaling. # A UA is asymmetric from SIP signaling point of view when it send
 requests from one UDP port # and expects responses on other UDP port specified in Via header. Most UA are
 symmetric. # First is looking after User-Agent and then on Server header. # If both of them are missing client is
 supposed to be SIP symmetric. # Asymmetric checking applies only when UDP is used and not for TCP and TLS. #
 On TCP and TLS source port is usually different than the Via port. # Determining the type of UA asymmetric or
 symmetric is important when checking if a UA is behind NAT. # When symmetric ip and port from Via headers is
 checked with source ip and port of received. # When asymmetric ip only from Via headers is checked with source ip
 of received request. # Keep in mind that asymmetric clients don't work behind NAT # Max 50 lines are allowed #
 default empty list asymmetric_ua Grandstream HT496 1.0.3.* asymmetric_ua Linksys/SPA922* # Regular
 expressions that try match 'User-Agent' or 'Server' fields from REGISTER requests # First is looking after
 User-Agent and then on Server header. # If both of them are missing will try to match empty string. # Max 50 lines
 are allowed # default empty list; that means also ua_acl checking is disabled # when enable only user agent that
 match bellow list will be allowed to REGISTER on proxy # introduced starting with version 4.3.96 see centrala
 version ua_acl Cisco-SIPGateway/IOS* ua_acl snom370/7.1.* # remote heartbeat udp port where the KEEP_ALIVE
 messages are sent # 0=disable sending of KEEP_ALIVE messages # default 0 # same port must be configured also
 in heartbeat application at app_port or second_app_port # centrala will bind this port minus 1, in this case 9000, so
 KEEP_ALIVE messages will have source port 9000 and destination port 9001 # heartbeat application will check
 source port in order to match KEEP_ALIVE with a specific centrala heartbeat 9001 # configure the ip:port of server
 redundant equipment # one equipment must be client and the other one must be server # a TCP socket is used; one
 equipment is server and the other one is client # this IP is the server IP and it has to be the same on both
 equipments redundancy client/server 192.168.1.193:8001 # Enable a SIP user to redirect (forward) a call from SIP
 phone instead using call forward setting from SSW # 0=disable, 1=enable, default 1 user_redirect 0 # 0=disable,
 1=enable, default 0 # Used in conjunction with [[register_users.cfg]] # Specify how the REGISTER requests (for
 each user from register_users.cfg) are sent to the proxy # If disabled will all REGISTER requests to SIP proxy at
 once. # If enabled will send REGISTER requests to SIP proxy at a random interval # in range [0 ... 120] seconds. # If
 enabled it can be used also as testing tool to simulate real behavior when a proxy receives # REGISTER requests
 randomly. register_client_random 0 # Number of database records read once from a database table (ex. sipusers,
 sipuseralias etc.) # interval between 10 and 500, default 50 database_row_chunk 50 # string value, default version of
 centrala application (run centrala -v to see version) user_agent "TopeX" # Max call time for proxy calls # if this value
 is reached the proxy will cut the current call # time in seconds # 0=disable; default 0 max_call_time 3600 # time in
 seconds # interval between 90 and 7200, default 1800 session_expires 1800 # time in seconds # interval between 90
 and 7200, default 90 min_session_expires 90 # Used for testing purposes on multiaccess/quotex # if enabled the rtp ip
 from SIP SDP content will contain the PG IP instead of VoIP IP # 0=disable, 1=enable, default 0 test_rtp 0 #
 add_country_code classid <regular expression pattern> <ignore from dnis> <country code prefix added for that
 pattern> # this line it useful for example if you want to add a country code for calls initiated # by the SIP users to
 destinations on UA (other than SIP users) # each line applies to the specified class id of sip user # you can add max
 20 lines # in this way you can keep in routing table only prefixes with country code (E164 format) # this change is

also called E164 format number conversion # you can add multiple lines for the same class id # matching is done from up to down, if one line is matched subsequent lines are ignored and search is finished # country code reg exp is also used to build E164 billing number # For calls through SIP proxy B user name is used to match country code reg exp # That is because on SIP proxy you can also call B party dialing his alias (ex: alice) instead of user name (ex: 031233497) add_country_code 20 0[1-9][0-9]{4,} 1 004 add_country_code 20 [1-9][0-9]{5,} 0 0040 # enable=1/disable=0; default 1 # if enabled ani info received from CCTL will replace presentation info # it is enabled by default because most of the carriers don't send this info, except British Telecom ani_override_display 1 # enable=1/disable=0; default 0 # bind ani to sip register users (see register_users.cfg) # if enabled for each outgoing UA call wil try to match the ANI with the username of register user # if a match is found will fill the Contact, To, From SIP headers with register users info bind_ani_to_sipusers 0 #0=disabled; 1=enabled;default 0 #if enabled dnis will be taken from SIP To header URI instead of request URI #starting with date 28 March 2011 on version 4.3.88 to_header2dnis 0 # SECTION CONFIGURATIONS STARTS FROM HERE # section names are enclosed between []; ex [interface_ip] # Only section parameters are allowed from now one until end of file # allowed sections are detailed bellow # Credentials used for outgoing INVITE authorization on User Agent # realm(ip/dns_name) user_name password [credentials] 192.168.1.100 306 306 # IP/Netmask Signaling_IP Bind_IP DNS_name # This feature is useful on SSW with more than one network card # (ex. one for local class 192.168.0.0/16 and one for public class) # can be configured different IP/DNS_name for each source/destination IP class # It is also useful for equipments behind NAT; in this case you put signaling IP the IP of NAT and # bindIP the IP of network interface used in that NAT # # Important: always last rule must have class 0.0.0.0/0, application is searching from up to # down and must always must one class ip_class/netmask signaling_ip_used dns_name_used # Restart required if you add/remove lines in this section. # Starting with date 12 August 2009 (see centrala version) restart is required only if you add lines (in this section) # with bind_ip that match ip of a new added network card (physical). # # if you don't have a dns name for a specific ip address you can omit dns name from config # you can use "interface ip" telnet command to check the values read by centrala # from the file into the memory and see also the fd created for each interface # in case of redundancy only the master will create sip udp sockets when virtual ip is up # if centrala is slave the sip udp sockets will be closed [interface_ip] # bellow line is for calls from private class 192.168.0.0/16 received on local network card 192.168.0.0/16 192.168.1.1 192.168.1.1 local.turu.ro # bellow line is for calls from public class 80.27.127.0/24 received on local network card (NAT case) 80.27.127.0/24 80.27.127.10 192.168.1.1 public.turu.ro # for each trunk that use dns you need to add a line as bellow # this line will be used to match signaling interface (in case there are more than one) based on remote DNS # <Invalid_IP/32> Signaling_IP Bind_IP Remote_DNS_name 127.0.0.2/32 89.249.83.193 89.249.83.193 hsbc.com # bellow line is for calls from class 0.0.0.0/0 received on public network card 0.0.0.0/0 89.249.83.193 89.249.83.193 public.turu.ro # cpc_code cpc_cause # cpc_code interval: 0-255 # cpc_cause len: max 32 characters # route sign4&0x00008000 must be set in order to receive category from cctl # bellow values are just some examples [cpc_category] 0 unknown 1 op_french 2 op_english 3 op_german 4 op_russian 5 op_spain 6 op_rsrv1 7 op_rsrv2 8 op_rsrv3 9 notused 10 ord_subscr 11 prio_subscr 12 data_call 13 test_call 15 payphone 252 uk_oper_call 254 uk_admin_diverted GoTo >Main Page > centrala

Sip redirect.cfg

GoTo >Main Page > centrala

Used to redirect sip calls

When an INVITE is received SIP server check the request user name against sip redirect table.

If a match is found the call is redirected with code 302 to the contact header composed from username@address fields.

Also a billing record will be written in CDRs.

Sip redirect list is loaded in memory from configuration file.

Changes to the file are loaded in maximum 5 seconds.

Memory list loaded can be viewed on telnet with command "sip redirect"

File path: /mnt/app/cfg/sip_redirect.cfg

```
# user name address(ip:port)
```

```
333 192.168.1.190:5060
```

```
555 89.34.33.22:5061
```

Prepaid.cfg

GoTo >Main Page > centrala

```
# file path: /mnt/app/cfg/prepaid.cfg
```

```
# first language is default language
```

```
# numbering is done starting from 1
```

```
define_language
```

```
1 ro
```

```
2 en
```

```
3 fr
```

Note:

if you change prepaid.cfg language settings restart centrala

SIPusers.cfg

GoTo >Main Page > centrala

```
; lines that begin with ';' are commented lines
; user name must be enclosed between square brackets
; all next streak lines are setting of this user
[301000]
```

```
; default empty string
password=1234
```

```
; must be unique across al the sip users
; start from 1
; default 0
clientid=1
```

```
; default 0xffff, which means an invalid class
classid=10
```

```
;the prepaid id of the account configured in prepaid_users.cfg
prepaid_id=0
```

```
; a user can have multiple aliases
; user aliasses must be global unique across all the sip users
; there is no max number of aliases supported
; the only limitations comes from file size or memory available, wich quite huge
alias=gogu
alias=boss
alias=0212329988
```

```
; a user can have multiple centrex aliases
; centrex aliases must be less than 5 digits
; if centrex alias contain also characters it can be higher than 5 characters
; centrex aliases must be unique across all the sip users from the same centrex group
; there is no max number of centrex aliases supported
; the only limitations comes from file size or memory available, which quite huge
; Important: centrex_group line must be defined before centrex_alias line for each user settings
centrex_alias=100
centrex_alias=testing123
```

```
; gsm number of sip user; default empty string
; if this field is set every time the user is called o sip phone, the call will be forked and will call also this number
; gsm is not a proper name for this field because it can contain all king of numbers (ex PSTN), not only gsm
; anyway this is the syntax and must followed in order to work
gsm=0723287999
```

```
; 0=enabled; 1=receive only; 2=suspended; 128=disabled;
; default=0
account_state=0
```

```
; 0=not used; 1=used, except for users in same nat; 2=used always;  
; default 0  
rtp_proxy=0
```

```
; 0=not used; 1=used on different codec; 2=used on dtmf in rtp(inband or rfc2933); 3=used on diff codec/dtmf rtp; 4=used always  
; default=0  
transcoding=0
```

```
; default empty string  
display_name=funny alice
```

```
; default 0  
privacy_display=0
```

```
; default empty string  
; must always contain user name or one of the user aliases  
cli_proxy=301000
```

```
; default 0  
privacy_proxy=0
```

```
; default empty string  
cli_ua=0212329988
```

```
; default 0  
privacy_ua=0
```

```
; must always contain one of the user centrex aliases  
cli_centrex=100
```

```
; default 0  
privacy_centrex=0
```

```
; ip/netmask  
; default 0.0.0.0/0  
public=86.38.12.8/32
```

```
; ip/netmask  
; default 0.0.0.0/0  
private=192.168.0.0/16
```

```
; default 1  
multiple_contacts=1
```

```
; default empty string  
description=Topex Romania
```

```
; default 0  
publish_presence=0
```

```
; default 60  
; value in seconds  
; specify no answer timeout for calls sent to a sip user
```

```
noanswer_timeout=60

; default 0
callforward=0

; default 0
callforwardstate=0

; default 0
callforward_selective=0

; default empty string
callforwardnumber_offline=888

; default empty string
callforwardnumber_busy=999

; default empty string
callforwardnumber_noanswer=777

; default empty string
callforwardnumber_always=666

; default 0
callwait=0

; default 0
callwaitstate=0

; default 0
voicemail=0

; default 0
voicemailstate=0

; default empty string
voicemailnumber=77301000

; default 0
voicemail2emailstate=0

; default empty string
voicemail2email=gogu@example.com

; default 0
missed2email=0

; default 0
missed2emailstate=0

; default empty string
missed2emailemail=gogu@example.com
```

```
; default 0
missed2sms=0
```

```
; default 0
missed2smsstate=0
```

```
; default empty string
missed2smsnumber=0734555666
```

```
; default 0
reject_no_ani=0
```

```
; default 0
do_not_disturb=0
```

```
; 0=not used
; default 0
callpickupgroup=0
```

```
; 0=not used
; default 0
callhuntinggroup=0
```

```
; default 0
callhuntingpriority=0
```

```
; 0=not used
; default 0
forking_group=0
```

```
; 0=disabled; 1=enabled; default 0
; if enabled a sip user will be able to call other sip user via proxy (see Trunk/Proxy mode)
; only if the called user is in the same class
proxy_class_only=0
```

```
; default 0
rules_in=0
```

```
; default 0
rules_out=0
```

```
; rule name mode ani dnis
; mode values: a=allow, r=restrict; f=forward
rule allow_123    a 123 -
rule reject_00    r -    00
rule forward_777  f 777 -
```

```
; 0=not used
; default 0
queue1=0
```

```
; 0=not used
; default 0
```

```
queue2=0

; 0=not used
; default 0
queue3=0

; 0=not used
; default 0
queue4=0

; 0=not used
; default 0
queue5=0

; 0=not used
; default 0
queue1_value=0

; 0=not used
; default 0
queue2_value=0

; 0=not used
; default 0
queue3_value=0

; 0=not used
; default 0
queue4_value=0

; 0=not used
; default 0
queue5_value=0
```


Voice mail.cfg

GoTo >Main Page > centrala

```
# /mnt/app/cfg/voice_mail.cfg - configuration file for voice_mail
# Lines starting with '#' character represent comments and are ignored

# in milliseconds
# default 180000
ring_timeout 180000

# max number of messages that can be receive by one subscriber
# default 15
max_msg 15

# max duration of one message received (in seconds)
# default 30
max_time 30

# range UDP ports used for playing and recording voice messages
# default 15000
begin_rtp_port 15000

# default 20000
end_rtp_port 20000

# 1=enable; 0=diabile; default 0
# if enabled voice mail will be done without transcoding;
# it useful in case of ssw that do not have a transcoding machine or for MGU without internal matrix
# in this case SIP phones must use same codec
# in case that you want to use voice mail also from TDM you have to set in voip.cfg only one codec in the list of codecs
# (audio_codecs)

same_codec 0
```

Simindex.cfg

GoTo >Main Page > centrala

Define SIM indexes and holidays.

Holidays are used in routing table when valid days is specified for a route.

Default path: /mnt/app/cfg/simindex.cfg

```
# ---SIM INDEX FILE---
# Day type Mon=0x01 Tue=0x02 Wen=0x04 Thu=0x08 Fri=0x10 Sat=0x20 Sun=0x40 Holiday=0x80
# s index_sim day_type_bitmap(%x) start_hour:min end_hour:min sim(%x)
s 00 ff 00:00 24:00 0
s 01 ff 00:00 24:00 1
s 02 ff 00:00 24:00 2
s 03 ff 00:00 24:00 3

# ---HOLIDAYS---
# h day month
h 01 01
```

h 25 12

Register users.cfg

GoTo >Main Page > centrala

Allow you to configure informations needed to register to a SIP registrar.

The number of users defined in this file is limited only by the max Linux size of file.

Allow registration to one or more SIP registrar servers; one server for each user defined.

It can be used also as a testing tool for SIP registrar.

Default file path: /mnt/app/cfg/register_users.cfg

Telnet command:

- register users - show users loaded in memory from configuration file

```
; commented lines begin with ';'
[301]
```

```
; authentication password
; default empty string
password=301
```

```
; authentication user name
; by default is filled with user name
; this field has been added starting with revision 10733 on version 4.3.88
auth_name=302@sip.mypbx.net
```

```
; ip/dns_name of first server to which the client try to register
; will appear in sip request uri of REGISTER request
```

```
first_proxy=sip.mypbx.net
```

```
; ip/dns domain of first server to which the client try to register  
; will appear in sip From/To header of REGISTER request  
; if is not defined first proxy will be used  
first_domain=mypbx.net
```

```
; ip/dns_name of second server to which the client try to register  
; will appear in sip request uri of REGISTER request  
; in case it does not succeed to the first one  
second_proxy=192.168.244.167
```

```
; ip/dns domain of second server to which the client try to register  
; will appear in sip From/To header of REGISTER request  
; if is not defined first proxy will be used  
second_domain=mydomain.net
```

```
; registration time (in seconds) offered in REGISTER message to the server  
; registration time used is the one received from server  
; depending of the server configuration regsitartion time can be  
; the one sent in REGISTER or any other value  
expires=200
```

```
; time interval in seconds at which the client send keep alive messages  
; to the server in order to keep NAT connection open  
; recommended value is between 20 and 60 seconds  
nat_refresh=30
```

```
[302]  
password=302  
auth_name=302@sip.mypx.ro  
first_proxy=sip.mypbx.ro  
first_domain=mypbx.ro  
second_proxy=89.38.11.22  
second_domain=mydomain.ro  
expires=120
```

```
nat_refresh=50
```

Extended Port Config

Extended port config

GoTo >Main Page > centrala

Note: Extended port config files are used to pass parameters at port start-up. They can be used for setting permanent volume levels, check credit,gsm cell selection

Extended port configuration can be found in `/mnt/app/cfg/vcss/` directory. For each port one configuration file is created. Settings from this files are complementary to the setting from `port.cfg`

File name format: <port number(4 digits)>.cfg

Example: 0008.cfg

Example of a vcss file for Radio Cards

```
[general]
# Available types: RADIOANALOG, RADIOTETRA, RADIOTETRAPOL, TRUNK, E&MRADIO, ALARMDTMF, R2S, RTP&UDPSGN
typeport=RADIOTETRAPOL

name=0011

[parameters]
activechannel=1

# 0=2400; 1=4800; 2=9600;
serialspeed=1

timechannelscan=5000
timechannellock=30000
group=8

# Used only on TETRAPOL ports connected to TCP stations
# Specify the IP:Port of the station
remote_ip=10.111.2.105:2500

delayaftertx=
crosscouplinggroup=
votinggroup=
alarmDTMF=
activechannel=
UDPsettings=
Target=
RTPsettings=
RTPlocalport=
VAD=
```

```
backup=  
interfon=  
[channels]  
1=>408  
2=>403  
3=>650
```

```
4=>651
```

VCSS files for Wavecom

Vcss files for Wavecom module



Best Practice

Vcss files can be imported in simserver at ussd file

Definition: Vcss files work like autoexec.bat file in windows. They are a series of commands that are passed to the port when port is initialized

Note: This is a example of a vcss file for setting audio level for Wavecom module. Check AT commands for Wavecom modules ^[1] for more details on audio levels

VCSS files must be created in folder /mnt/app/cfg/vcss/.

Note: If the folder doesn't exist create it with command `mkdir /mnt/app/cfg/vcss`

Note: For Voibridge it is necessary to give the command `rw` before you edit the file and `saveconfig` after.

Name of the file must be number of the GSM port and it must have 4 digits

Ex:

```
0008.cfg  
0009.cfg  
0120.cfg  
0121.cfg
```

File: /mnt/app/cfg/vcss/0000.cfg

```
[general]
typeport=GSM
name=000
[configAT]
cmd=>0,cmd,AT+CUSD=1
cmd=>0,answer,OK
cmd=>0,timeout,1000
cmd=>1,cmd,AT+CREG=1
cmd=>1,timeout,1000
cmd=>2,cmd,AT+VGR=96
cmd=>2,timeout,1000
cmd=>3,cmd,AT+VGT=12
cmd=>3,timeout,1000
```

Warning: After a vcss file is edited the port must be reinitialized for the settings to be applied.

```
cmd=>0,cmd,AT+CUSD=1 // First AT command
cmd=>0,answer,OK      // Answer for AT command
cmd=>0,timeout,1000    // Time-out
```

Warning: In total a series of 10 commands (numbered from 0 to 9) can be passed to a port

Note: Example of vcss file used for checking credit. This is used to enable receiving of USSD messages

File: /mnt/app/cfg/vcss/0000.cfg

```
[general]
typeport=GSM
name=000
[configAT]
cmd=>0,cmd,at+cmgf=1
cmd=>0,timeout,1000
cmd=>0,answer,OK
cmd=>1,cmd,at+cusd=1
cmd=>1,timeout,1000
cmd=>1,answer,OK
cmd=>2,cmd,at+cnmi=2,2,0,0,1
cmd=>2,timeout,1000
```

Note: Example of vcss file used for volume, echo cancellation, dtmf and USSD. The below vcss file is also used if all the calls are released with BRELS 31

```
[general]
typeport=GSM
name=000
[configAT]
cmd=>0,cmd,AT&F
cmd=>0,timeout,1000
cmd=>1,cmd,AT+CFUN=1
cmd=>1,timeout,30000
cmd=>2,cmd,AT+SPEAKER=0
```

```
cmd=>2,timeout,1000
cmd=>3,cmd,AT+WSVG=1
cmd=>3,timeout,3000
cmd=>4,cmd,AT+VGR=144
cmd=>4,timeout,3000
cmd=>5,cmd,AT+VGT=0
cmd=>5,timeout,3000
cmd=>6,cmd,AT+ECHO=1,1,0,3,31,0
cmd=>6,timeout,2000
cmd=>7,cmd,AT+CMGF=1;+WVR=0,0
cmd=>7,timeout,3000
cmd=>8,cmd,AT+CNMI=2,2,0,0,1
cmd=>8,timeout,1000
cmd=>9,cmd,AT+CUSD=1;+CLIP=1
```

```
cmd=>9,timeout,2000
```

Billing

Billing generic (PGSQL, MySQL, MSSQL)

GoTo >Main Page > centrala

Default CSV CDRs path: /mnt/app/out/dd-mm-yy.tax

Note: Starting with version 4.1.306 in case of insert error or pool process overflow CDR SQL queries are written in the following files:

```
- /mnt/app/out/dd-mm-yy_pg.sql (for PostgreSQL, first pool)
- /mnt/app/out/dd-mm-yy_pg2.sql (for PostgreSQL, redundant pool)
- /mnt/app/out/dd-mm-yy_my.sql (for MySQL)
- /mnt/app/out/dd-mm-yy_ms.sql (for MicrosoftSQL)
```

In this way this files can be executed directly into database without loosing billing records.

centrala -v show the number of client process from each pool.

- Starting with version 4.1.314 number of billing fields sent in billing is configurable.

Edit /mnt/app/cfg/exec.cfg

```
# default 43, first 43 fields will be sent in billing
# specified value must be in range shown on telnet with command "billing fields number"
# 255 means to sent all the fields available in billing
billing_fields_number xxx
```

- **Important:**

1. Before adding more fields in billing by changing the value in exec.cfg, make sure that you have already created this fields into the database.
2. Make sure that you use a clean_hdd.sh version higher that 1.0.25, otherwise lower version will delete .sql files when the HDD is reaching max limit set in clean_hdd.sh script.

- **Billing fields order:** dd-mm-yy.tax

PgSQL Billing

GoTo >Main Page > centrala

Postgresql Billing



Best Practice

Configure postgresql server first. Make sure that equipment has access to database before starting configuration. Please read this [1]

To use postgresql billing you need the following

- /mnt/app/bin/pgsql_sip_pool
- /mnt/app/cfg/pgsql_sip_pool.cfg
- Connect with putty to equipment and gain root access
- Activate postgresql billing from file exec.cfg Starting with version 4.1.306 pgsql_billing can use 2 databases

```
vi /mnt/app/cfg/exec.cfg
```

```
# enable/disable pgsql billing pool
# configuration file name is optional;
# default is pgsql_sip_pool.cfg
pgsql_billing 1/0 [configuration file name]

# enable/disable pgsql_billing pool redundancy
# configuration file name is optional;
# default is pgsql_sip_pool.cfg
pgsql_billing_alt 1/0 [configuration file name]
```

- Edit /mnt/app/cfg/pgsql_sip_pool and add correct connection information

```
vi /mnt/app/cfg/pgsql_sip_pool.cfg
```

```
# pgsql_sip.cfg - configuration file for pgsql_sip

# Lines starting with '#' character represent comments and are ignored
# Changes made on this file are loaded automatically by pgsql_status app

# 0=no debug, 1=min debug, 2=full debug
debug 0

# connection string for connection to postgresql database
conn_string dbname=softswitch host=192.168.192.111 user=softswitch password=99softswitch11
```

- Change working directory to /mnt/app/bin
- Run pgsql_sip_pool to make sure that database connection is OK

```
./pgsql_sip_pool
```

- Reboot equipment

```
/sbin/reboot
```

Equipment will create the database and tables needed to dump billing. Tables fore next 2 months will also be created. Tables used will have format billing_yyyy_mm.

Note:If software is updated and new software has more billing fields those fields must be added manually for current month and next 2 months

Ex: ALTER TABLE billing_2008_06 add column in_billing_profileid INT NOT NULL DEFAULT 0;

Mysql Billing

GoTo >Main Page > centrala



Best Practice

Configure mysql server first. Make sure that equipment has access to database before starting configuration. Please check <http://dev.mysql.com/doc/>

Starting with version 4.3.111 centrala will create in advance (at startup) billing tables: one for current month and another two tables for next two months. Make sure that the user has th rights to create tables. Billing fields and order are the same as the same as in defined here Dd-mm-yy.tax. For each month one billing table will be created.

If you have a version prior to 4.3.111 follow the steps bellow:

- Connect to server and create a database (ex:billing)
- Use this structure for the database

```
CREATE TABLE billing(
id INT NOT NULL AUTO_INCREMENT, PRIMARY KEY (id),
tip CHAR(3),
port_src MEDIUMINT,
identity VARCHAR(32),
number VARCHAR(32),
date date,
time time,
duration INT,
units SMALLINT,
SIM CHAR(2),
port_dest MEDIUMINT,
`release` VARCHAR(15),
rel_Q850 SMALLINT,
CIMI VARCHAR(30),
selection SMALLINT,
GSM_cell VARCHAR(10),
direction VARCHAR(20),
IP_s VARCHAR(20),
PORT_s INT,
IP_RTP_s VARCHAR(20),
PORT_RTP_s INT,
IP_d VARCHAR(20),
PORT_d VARCHAR(20),
```

```

IP_RTP_d VARCHAR(20),
PORT_RTP_d INT,
session_id VARCHAR(20),
jitter INT,
packet_loss INT,
client_id INT,
direction_out VARCHAR(20),
proto_in VARCHAR(20),
proto_out VARCHAR(20),
codec VARCHAR(10),
ptime INT,
out_clientid INT,
gw_name VARCHAR(30),
id_out VARCHAR(32),
nr_out VARCHAR(32),
orig_ani VARCHAR(32),
con_dnis VARCHAR(32),
in_billing_profileid INT,
out_billing_profileid INT,
in_classid INT,
out_classid INT,
billing_prefix VARCHAR(32),
price_in NUMERIC(65,5),
currency_in VARCHAR(10),
call_type VARCHAR(32)
);

```

Starting with date 17 August 2009 (see centrala version built date), 5 new fields have been added, see bellow:

```

ani_ton_in INT
ani_ton_out INT
dnis_ton_in INT
dnis_ton_out INT
centrex_group INT

```

Starting with date 28 Sept 2009 on versions >= 4.3.88, price_out field have been added, see bellow:

```

price_out NUMERIC(99,5)
currency_out VARCHAR(10)

```

To use mysql billing you need

- /mnt/app/bin/mysql_client
- /mnt/app/cfg/mysql_client.cfg
- Connect with putty to equipment and gain root passwords
- Edit file /mnt/app/cfg/exec.cfg and add bellow line

```
mysql_billing 1
```

- Edit /mnt/app/cfg/mysql_client.cfg and add relevant information

```
# 0 = NO debug
# 1 = ERROR debug
# 2 = ERROR + WARN debug
# 3 = ERROR + WARN + INFO debug
# 4 = ERROR + WARN + INFO + FULL debug
# default 3
debug 3
# 0=disable; 1=enable; default 0
# If enabled log will be written in ../out/dd-mm-yy_bmysql.log
file_debug 0
# mysql server ip
host 89.38.8.19
# username used to login into mysql server
user topex
# password used to login into mysql server
password 99topex11
# server database name to which the client will connect
database billing
```

Test connection with database

- Change working directory to /mnt/app/bin/

```
cd /mnt/app/bin
```

- Run mysql client to make sure that connection with mysql server is ok

```
./mysql_client
```

Answer should be

```
Connection with Server OK
```

- Reboot equipment

```
/sbin/reboot
```

Dd-mm-yy.tax

Description Default path: /mnt/app/out/dd-mm-yy.tax

This file contains the complete call record (CDR's) CDR is in CSV (comma separated fields) format.

Type

- Three characters combination of the following letters:
- T = Terminated
- J = Junction (FXO)
- L = Local (FXS)
- I = Incoming call leg
- O= Outgoing call leg Examples: TLI, TJ0

Source transcoding port

- Physical position of the source port (5 digits).

This values indicates the physical port position (ex: 00263) In case that transcoding port is not allocated value is 65535.

Incoming ANI

- Automatic Number Identification = Calling Party Maximum 32 digits Example: 0817100002

Incoming DNIS

- Dialed Number Identification Service = Called party
- Maximum 32 digits
- Example: 0617100000

Date

- Day of the call in the following shape dd-mm-yy (day-month-year), (end date) (ex: 26-01-09)

Time

- Time of the call in the following shape hh:mm:ss (hour:minute:second) (end time) (ex: 17:57:20)

Call duration

- Speaking duration of the call in seconds (6 digits) (ex: 000034)

If the real call duration is for example 10 seconds and 1 milisecond (or more) it will appear in CDR with duration of 11 seconds.

Billing units

- Billing Units for the call (5 digits) (ex: 00000)
- This field is usually filled with 0 for non-answered calls and with 1 for answered calls.
- However if tax pulses calculation is set on incoming direction (see "Signaling2" settings in "Define Calls Direction") then this value will be filled according with the number of pulses charged at response and on time bases (see "Tax" field in "Routing Table").

SIM number

- The SIM number used on called GSM module (ex: ff)
- When the destination port is a GSM port it specifies a value for SIM from the next list: (0,1,2,3 or ff).
- The OAM application is adding a unit to the SIM value - this approach is used for simplicity - this rule is applied when billing records are displayed. The same rule is applied for the "SIM index" case when the SIM card to be used (1,2,3,4) is chosen.

Destination transcoding port

- Physical position of the destination port (5 digits) (when the call is unfinished a value of 65535 will be found in this field (5 digits) (ex: 65535)
- In case of a TOPEX multiswitch - calls terminated with success will have also 65535 in this field.

End cause

Centrala internal release cause. Here is the list of available release causes:

- AOK - Call connected and disconnected by calling party
 - BOK - Call connected and disconnected by called party
 - OK - Call connected and disconnected by centrala
 - ARELS - Call released before connect by calling party before connect
 - BRELS - Call released before connect by called party before connect
 - AINEX - Call released before connect by calling party with cause 1 (inex)
 - BINEX - Call released before connect by called party with cause 1 (inex)
 - ACONG - Call released before connect by calling party with cause 34 (congestion)
 - BCONG - Call released before connect by called party with cause 34 (congestion)
 - ASERR - Call released before connect by calling party with cause 111 (protocol error)
 - BSERR - Call released before connect by called party with cause 111 (protocol error)
 - ANERR
 - BNERR
 - ANOANS - Call released before connect by calling party with cause 19 (no answer)
 - BNOANS - Call released before connect by called party with cause 1trc9 (no answer)
 - ABUSY - Call released before connect by calling party with cause 17 (user busy)
 - BBUSY - Call released before connect by called party with cause 17 (user busy)
 - ATOUT - Timeout on calling party leg; call not connected
 - BTOUT - Timeout on called party leg; call not connected
 - ERRAUTH - Authentication error; used on prepaid
 - NOCREDIT - No credit available; used on prepaid
 - FINCRED - Credit finished; used on prepaid
 - AVMAIL - Call connected to calling party voice mail
 - BVMAIL - Call connected to called party voice mail
-

- NOVOIPCH - No voip channel available (voip congestion)
 - CODECERR - Codec error; codec mismatch between calling and called party
 - NOLICENCE - License expired
 - ACLREJECT - Access list reject; source of call is not added in access in table
 - ANI_RESTRICTED - ANI is not allowed to complete the call
 - DNIS_RESTRICTED - DNIS is not allowed to complete the call
 - NORTPPROC - No RTP pool process available
 - MOREDIG - Need more digits in order to take a routing decision
 - RELEASE - Call released by centrala
 - ENDOK - Call connected and disconnected by centrala
 - SERR - Signaling error, call released by centrala before connect
 - INEX - DNIS does not exist
 - A_CONGRES -
 - NOPRICE - No price found; Call released by centrala
 - ENDCONG - Congestion; Call released by centrala
 - NOROUTE - No route found
 - DNIS REJECTED - Call rejected (not allowed) by centrala
 - REDIRECTED - Call redirected by centrala
 - REROUTED - Call rerouted on other route
 - TIMEOUT - Centrala internal timeout; call not connected
 - PRICE_ERROR - Error in definition of billing price
 - BREDIRECT - Call redirected by called party
 - PREPAID_NOT_FOUND - Prepaid user not found
 - ACCT_DISABLED - Account is disabled
 - USER_OFFLINE - SIP user is offline
 - CONTACT_ERROR - Contact checking error; SIP user is not registered and is trying to make calls, but is not allowed on current configuration, see check_invite_contact line from Sip pbx.cfg
 - CLASS_DISABLED - Incoming class assigned to the call is disabled
 - INVALID_CLASSID - Incoming class id assigned to the call is invalid
 - CLASS_RESTRICT - Incoming class restricted due to max time, max cost, max calls, max rate limits
 - KILLED - Call killed before connect; Call can be killed from telnet see kill all calls or kill call from Telnet commands Call can also be killed due to some card errors or physical layer alarms (ex LIS, RJA, AIS)
 - OK_KILLED - Connected call killed; see the above cases
 - OK_SERR - Connected call released due to some signaling errors
-

End code

- Q850 release code, see Q850 Release codes

IMSI

International Mobile Subscriber Identity. Filled when the destination port is a GSM port.

Call selection time

Time in seconds passed since the call setup arrived until call is connected. xxx - three digits; exmaple: 012

GSM CELL

For a call routed through a GSM port it represents the cell id from mobile network where the SIM was registered.

Incoming class name

Class assigned to incoming call leg, see also Users and Classes

Source signaling IP

Filled only for SIP/H323 calls Example: 85.67.52.221

Source signaling port

Filled only for SIP/H323 calls Example: 31166

Source RTP IP

Filled only for SIP/H323 calls Example: 192.168.52.221

Source RTP port

Filled only for SIP/H323 calls Example: 13224

Destination signaling IP

Filled only for SIP/H323 calls Example: 192.168.52.200

Destination signaling port

Filled only for SIP/H323 calls Example: 5060

Destination RTP IP

Filled only for SIP/H323 calls Example: 192.168.52.200

Destination RTP port

Filled only for SIP/H323 calls Example: 30010

Call session id

This is an unique identifier of a call inside the equipment software. It is useful for a call debugging inside the equipment log files. (ex: 0ae1bfb6)

Packet loss

VoIP packet loss occurs when a large amount of traffic on the network causes dropped packets. This results in dropped conversations, a delay in receiving the voice communication, or extraneous noise on the call. (ex: 0)

Jitter

Jitter is a variation in packet transit delay caused by queuing, contention and serialization effects on the path through the network(ex: 0)

Incoming client id

Integer value

Outgoing class name

Class assigned to incoming call leg, see also Users and Classes

Incoming protocol

Protocol used on incoming call leg Possible values: CAS, H323, SIP, ISDN, SS7, R2S, UNKNOWN

Outgoing protocol

Protocol used on outgoing call leg Possible values: CAS, H323, SIP, ISDN, SS7, R2S, UNKNOWN

Codec

Payload Type of the call. In case of media changes during the call last negotiated codec is written Integer value of the codec Example: 0 for G711, 18 for G729 etc.

Packetization time

Value in milliseconds (ex: 20) Packetization time is the length of the digital voice segment that each packet holds. Selecting 10 millisecond packets enhances the voice quality, as less information is lost due to packet loss, but doubles the load on the network traffic.

Outgoing client id

Integer value

Gateway name

Name of the gateway Default: empty string In OAM can be set in "Gateway Parameters" window See also name line in Exec.cfg

Outgoing ANI

ANI send on the outgoing call leg ANI can be changed based on the settings involving the identity from "Calls Directions" and/or "Routing Table"

Outgoing DNIS

DNIS sent on outgoing call leg DNIS which can be changed based on the settings involving the dialed number from "Calls Directions" and/or "Routing Table"

Original ANI

Original ANI of the call; this field is usually the same as incoming ANI. In case of call forward original ANI will store the identity of the first party that has initiated the call.

Connected DNIS

Connected DNIS of the call; this field is usually the same as outgoing dnis. In case of a call forwarding connected DNIS will store the number of the party that has answered to the call.

Incoming billing profile id

Integer value

Outgoing billing profile id

Integer value

Incoming class id

Integer value

Outgoing class id

Integer value

Billing DNIS

E164 format Used for billing Example: 40723222333

Incoming price

Example: 0.20000

Incoming currency

Example: EUR

Call type

Field under development. Extensible ascii character type list:

- 0 = U/0 User Agent/Proxy
- 1 = P/0 RTP proxy
- 2 = S/0 Service
- 3,4 = XX/00 XX=Reroute counter
- 5 = F/0 Forking
- 6 = C/0 Centrex
- 7 = H/0 Hunting
- 8 = f/0 Forward
- 9 = V/0 Voice mail
- 10 = p/0 Pickup
- 11 = T/0 Transfer
- 12 = \$/0 Prepaid
- 13 = S/A/P/F/B/0 SIP/ANI/Prepaid/FXS/BRI

Incoming ANI Nature of Address Indicator

ANI Type of Number IN (Nature of address) Starting with 17 August 2009

Incoming DNIS Nature of Address Indicator

DNIS Type of Number IN (Nature of address) Starting with 17 August 2009

Outgoing ANI Nature of Address Indicator

ANI Type of Number OUT (Nature of address) Starting with 17 August 2009

Outgoing DNIS Nature of Address Indicator

DNIS Type of Number OUT (Nature of address) Starting with 17 August 2009

Centrex group

Id of centrex group in case of centrex call Starting with 17 August 2009

Outgoing price

Example: 0.20000 Starting with 29 September 2009 on versions \geq 4.3.88

Outgoing currency

Example: EUR Starting with 29 September 2009 on versions \geq 4.3.88

Applications

Voicemail2Email

GoTo >Main Page > centrala

Requirements:

To be able to use the service Voicemail to Email you have to configure Voicemail first. Please follow the steps from the Voicemail configuration page

The files needed to be able to send e-mails are:

- /mnt/app/bin/smtpmail - this program is used for sending the e-mails
- /mnt/app/cfg/smtpmail.cfg - the configuration file for the smtpmail program

To be able to send e-mails with the voicemail files(.wav) attached you have to configure the sending server
/mnt/app/cfg/smtpmail.cfg

```
# the IP address of the SMTP server that is used by the smtpmail program to send e-mails
smtp_server_ip 192.168.52.200

# the port on witch the SMPT server listens for requests
smtp_server_port 25

# the user shown in the From field of the e-mails
from_user voicemail

# this field (IP or host name) will be shown in the From field of the e-mail
# this value has higher priority then the value of the ipaddress given from the command line
# smtpmail -h see all command line options
from_ip topex.ro
```

Voice Mail 2 Email Activation:

To activate Voicemail2Email on a sip user you have to check VoiceMail to Email State and in the VoiceMail 2 eMail field write the e-mail address where the user wishes to receive the voicemail:

- Voicemail to Email State - activate/deactivate the voicemail to email service
 - the option can be changed by user and/or administrator
- VoiceMail 2 eMail - the e-mail address where the user will receive the voicemail messages
 - the option can be changed by user and/or administrator

Once activated the voicemail2email service the SIP user will receive the voicemail messages on the e-mail.

The message it is converted automatically by the centrala application in wav format to be played by any player
ex. winamp, windows media player etc.)

The e-mail send to the client will contain the date and hour when the voicemail message has been received and the identity(the

number) of the person who has left the message.

WEB PGSQL Interface:

Voice to Mail Activation:

SIP Users			
Reseller Administrator			
Billing Group	00000001 Default Billing Group		
Client ID	00000003 0317100025		
Account Created	2008-12-16 10:06:37		
Account State	Enabled		
Class	SIP_USERS		
Username	0317100025		Password [Set]
Centrex Group	- Not Used -	Call Pick Up Group	- Not Used -
Call Hunting Group	- Not Used -	Call Hunting Priority	0
Forking Group	- Not Used -	Transcoding	Not Used
RTP_proxy	Always Used	Private	0.0.0.0/0
Public	0.0.0.0/0		
GSM Number			
Rules	<input type="checkbox"/> Incoming <input type="checkbox"/> Outgoing <input type="checkbox"/>		
Reject Calls with no ANI	<input type="checkbox"/>	Publish Presence	<input type="checkbox"/>
Multiple Contacts	<input type="checkbox"/>		
Do Not Disturb	<input type="checkbox"/>		
Call Forward	<input type="checkbox"/>	Selective Forwarding	<input type="checkbox"/>
Call Forward State	<input type="checkbox"/> Offline <input type="checkbox"/> Busy <input type="checkbox"/> No Answer <input type="checkbox"/> Always		
Number [Offline]		Number [Busy]	
Number [No Answer]		Number [Always & Selective]	
Call Wait	<input type="checkbox"/>	Call Wait State	<input type="checkbox"/>
VoiceMail	<input checked="" type="checkbox"/>	Voice Mail Number	9990317100025
VoiceMailState	<input type="checkbox"/> Offline <input type="checkbox"/> Busy <input type="checkbox"/> No Answer <input checked="" type="checkbox"/> Always		
VoiceMail to Email State	<input checked="" type="checkbox"/>		
VoiceMail 2 eMail	toxep@toxep.ro		
Missed Calls to eMail	<input type="checkbox"/>	Missed Calls to eMail State	<input type="checkbox"/>
Missed Calls to eMail eMail			
Missed Calls to SMS	<input type="checkbox"/>	Missed Calls to SMS State	<input type="checkbox"/>
Missed Calls to SMS Number			
Billing Profile	- Not Used -		
Media Parameters			
Queue 1	Not allowed	Queue Value 1	0
Queue 2	Not allowed	Queue Value 2	0
Queue 3	Not allowed	Queue Value 3	0
Queue 4	Not allowed	Queue Value 4	0
Queue 5	Not allowed	Queue Value 5	0
Call Queues			
Prepaid Account	- Not Used -		
Submit			

OAM:

Voice to Mail Activation:

Adding / modifying users settings

Username: 0317100024 Password: 0317100024

Alias: Alias1, Alias2, Alias3, Alias4, Alias5, Alias6

Description: Account State: Enabled Client ID: 1 Class ID: SIP_USERS

Centrex: Centrex Group: - Not Used - Centrex Alias1, Centrex Alias2, Centrex Alias3, Centrex Alias4, Centrex Alias5, Centrex Alias6

RTP Proxy: Not Used Pickup: - Not Used - Hunting_Group: - Not Used - Hunting_Priority: 0

Transcoding, Reject Calls with no ANI, Publish Presence, Do Not Disturb, Multiple Contacts

Call Forward: Call Forward, Selective Forward, Call Forward State: Offline, Busy, No Answer, Always

Number [Offline], Number [Busy], Number [Noanswer], Number [Always&Selective]

Call Wait: Call Wait, Call Wait State

Access: Public IP, Private IP, Rules_in, Rules_out

GSM Number

VoiceMail: VoiceMail, VoiceMail State: Offline, Busy, No Answer, Always, VoiceMail Number: 9990317100024

VoiceMail2Email: Enabled, VoiceMail 2 eMail: topex@topex.ro

MissedCalls2Email: Missed Calls to eMail, Missed Calls to eMail State, Missed Calls to eMail eMail

MissedCalls to SMS: Missed Calls to SMS, Missed Calls to SMS State, Missed Calls to SMS Number

CLI, Rules, Call Queues, Ok, Cancel, Help

SEO: Voicemail, Voicemail 2 Email, Topex Voicemail

GoTo > Main Page > centrala

Multiaccess Config for Simserver

[Back to Multiaccess si Qutex](#) or [Back to Simserver & Simbox](#)

Note: Apelurile cu atd din OAM nu functioneaza cand accesul foloseste simuri virtuale

Se verifica 4 lucruri.

1* Firewall /etc/iptables.conf

```
more /etc/iptables.conf
```

```
# Generated by iptables-save v1.2.9 on Mon Jun  7 19:40:31 2004
*nat
:PREROUTING ACCEPT [0:0]
:POSTROUTING ACCEPT [0:0]
:OUTPUT ACCEPT [0:0]
COMMIT
# Completed on Mon Jun  7 19:40:31 2004
# Generated by iptables-save v1.2.9 on Mon Jun  7 19:40:31 2004
*filter
:INPUT DROP [0:0]
:FORWARD DROP [0:0]
:OUTPUT ACCEPT [0:0]
-A INPUT -i lo -j ACCEPT
-A INPUT -m state --state RELATED,ESTABLISHED -j ACCEPT
-A INPUT -p icmp -m icmp --icmp-type 8 -j ACCEPT
-A INPUT -p tcp -m tcp --dport 2222 -j ACCEPT ##Portul SSH
-A INPUT -p tcp -m tcp --dport 9009 -j ACCEPT ##Portul de OAM
-A INPUT -p udp -m udp --dport 5060 -j ACCEPT ##Portul de SIP
-A INPUT -p tcp -m tcp --dport 1720 -j ACCEPT ##Portul de H323
-A INPUT -p tcp -m tcp --dport 9200 -j ACCEPT ##SIMSERVER
-A INPUT -p tcp -m tcp --dport 9201 -j ACCEPT ##SIMSERVER
COMMIT
# Completed on Mon Jun  7 19:40:31 2004
```

2* Versiunea Centralei

```
/mnt/app/bin# /mnt/app/bin/centrala -v |grep SIM
```

Raspunsul comenzi ar trebui sa fie:

```
with      SIMSERVERCLIENT
```

Compilata fara aceasta optiune centrala nu va cere sim virtual.

3* Adaugarea Simserver-ului la configuratia Maccess

Se adauga linia urmatoare la trafic.cfg

```
simserver <IP SIMSERVER> 13001 nume_multiaccess
```

Numele adaugat trebuie sa fie identic cu cel adaugat in configuratia SIMSERVER-ului altfel Maccess-ul nu va fi vazut on-line

4* Modificarea fisierului /mnt/app/cfg/port.cfg Se modifica cat1 din 00000000 in 02000000. Astfel se seteaza porturile care vor folosi simuri virtuale

```
#---PORT FILE---
#p port card cat(%x) cat1(%x) dir number restr target(local port)
#p port card cat(%x) cat1(%x) dir sim target(gsm trunk port)
#p port card cat(%x) cat1(%x) dir target(trunk port)
#p port card cat(%x) cat1(%x) dir (E1 trunk port)
p 0 0 018f 02000000 GSM 0 0
p 1 0 018f 02000000 GSM 0 0
p 0 1 018f 02000000 GSM 0 8
p 1 1 018f 02000000 GSM 0 9
p 0 2 018f 02000000 GSM 0 0
p 1 2 018f 02000000 GSM 0 0
p 0 3 018f 02000000 GSM 0 0
p 1 3 018f 02000000 GSM 0 25
p 0 4 018f 02000000 GSM 0 32
p 1 4 018f 02000000 GSM 0 33
p 0 5 018f 02000000 GSM 0 40
p 1 5 018f 02000000 GSM 0 41
p 0 6 018f 02000000 GSM 0 48
p 1 6 018f 02000000 GSM 0 49
p 0 7 018f 02000000 GSM 0 0
p 1 7 018f 02000000 GSM 0 57
p 0 8 018f 02000000 GSM 0 64
p 1 8 018f 02000000 GSM 0 65
p 0 9 018f 02000000 GSM 0 72
p 1 9 018f 02000000 GSM 0 73
p 0 10 018f 02000000 GSM 0 80
p 1 10 018f 02000000 GSM 0 80
p 0 11 018f 02000000 GSM 0 0
p 1 11 018f 02000000 GSM 0 0
p 0 12 018f 02000000 GSM 0 96
p 1 12 018f 02000000 GSM 0 96
p 0 13 018f 02000000 GSM 0 0
p 1 13 018f 02000000 GSM 0 0
p 0 14 018f 02000000 GSM 0 0
p 1 14 018f 02000000 GSM 0 0
p 0 15 018f 02000000 GSM 0 0
p 1 15 018f 02000000 GSM 0 0
```

[Back to Multiaccess si Qutex](#) or [Back to Simserver & Simbox](#)

Clean hdd.sh script

[GoTo >Main Page](#)

Clean_hdd.sh

This is a shell script who is checking the size of directory given as parameter to clean_hdd.sh script, default /mnt and if it is over than \$max he start to delete files from /mnt/app/out/ directory keeping only the *.tax, *.sql, *.mind and some *.log files (in limit of \$max_log). After this, he is checking again the size of param1 directory and if the size is still over \$max he start to delete the oldest 5 *.tax, *.sql, *.mind files. He is running this step until the level is under \$max MB.

The cleand_hdd.sh script is started by /mnt/app/bin/run_clean.sh script or it can be run from crontab (where is available). In oder to change starting parameters you should edit run_clean.sh file or the line you added in crontab. run_clean.sh should be added to start_app file to be automatically started after reboot he will run in background and at every sleep interval (configured in run_clean or in crontab) will start the clean_hdd.sh script.

USAGE

```
./clean_hdd.sh [OPTIONS] directory_name
```

OPTIONS:

- v show script version; in this case directory_name should not be provided
- d force the script to write debug information in file /mnt/app/bin/clean_hdd.log instead of printing them in console
- h show the usage parameters; in this case directory_name should not be provided
directory_name is /mnt default

Check if the script is running

run ps -ef command on Linux system on multiACCESS/Qtex/Eones. If the script is running you should see the process [run_clean.sh] and [sleep] running. This is valid only if you use run_clean.sh. On machines where crontab exists you don't see above processes.

To run clean_hdd.sh from crontab add bellow line in /etc/crontab. This will run clean_hdd.sh at every 10 minutes.

```
*/10 * * * * root /mnt/app/bin/clean_hdd.sh /mnt/
```

Note: Clean Hdd must be configured according to size of disks in the equipment

Configuring clean_hdd.sh

Configuration can be done by changing bellow variables values using a text editor (ex. vi or mc). Bellow variables can be found at the beginning of the script.

```
# the log file path where clean_hdd.sh writes his logs
log_file=/mnt/app/bin/clean_hdd.log

# the max value of counted files param1 directory
# du -sm is used to check the size of param1 directory
# specified value is in megabytes
# settings in clean_hdd.sh depend on the size of the partitions.
max=1500

# the max value of counted log files from the $out_path directory
# specified value is in megabytes
```

```
max_log=1800

# directory path of out directory
# default /mnt/app/out
# It is useful in case you have more that one app directory structure on the same machine
# For example Master with slave on the same machine
```

```
out_path=/mnt/app/out
```

GSM Cell Selection

GSM cell Selection

Warning: Use only for Wavecom modules

To select a specific gsm cell use command

```
AT+CCELL =<freq>
```

<freq> is the freq of the cell on witch you whant to register the gsm module . (you can obtain information about gsm cells using command AT+ CCED).

Check AT commands for Wavecom modules ^[1] for more informations about AT+CCED

Voicemail

GoTo >Main Page > centrala

General

VM_NOANSWER_BUSY service code: 21

READ_VOICE_MAIL service code: 17

Requirements:

- In /mnt/app/cfg/exec.cfg you have to configure

```
voice_mail 1
rtptx_pool 1
rtprx_pool 1
```

- You have to copy the raw directory from distrib root@192.168.1.100:/home/dbica/distrib/raw in /mnt/app/
- check if you have the last versions of rtptx_pool si rtprx_pool from distrib distrib(192.168.1.100)
- create the directory /mnt/app/msg/
- configure the default language in /mnt/app/cfg/prepaid.cfg, see Prepaid.cfg

Voice Mail Activation:

- To be able to activate the Voicemail on a sip user you have to create a route, Action=SERV to Destination=VM_NOANSWER_BUSY
- If a user has enabled voicemail the calls will be redirected to the prefix of the VM_NOANSWER_BUSY route. This prefix can have any value, this value has to be in the settings of the sip user voicemail number

To activate voice mail you have to check Voicemail and VoicemailState

- Voicemail - can be changed by administrator only (enable/disable service)
- VoicemailState - can be changed by user and/or administrator (activate/deactivate service):
 - Offline - forwarded to voicemail only if the number is offline.
 - Busy - forwarded to voicemail only if the number is busy.
 - No Answer - forwarded to voicemail only if the number does no answer in. In case you have activated this option, in voicemail.cfg file you have to configure the ring_timeout value, see Voice mail.cfg
 - Always - forwarded to voicemail all the calls Always

Example:

If the voicemail prefix is 999 then the SIP user 0317100025 voicemail configuration in the Voice Mail Number will be: 9990317100025

Reading the messages:

- to read a message you have to create a route, Action=SERV to Destination=READ_VOICE_MAIL
- the prefix is the number that sip users will call to listen to their messages
- the message numbering is made from 2 digits, this means if you want to select the first message you have to dial 01 instead of 1, and so on till 09
- if you enter 1 digit instead of 2 digits to select the message, the user will be disconnected with time out

Limitations:

The default files for voicemail are recorded in Romanian and English languages, and only for 0(G711u) and 18(G729) codecs. The user can record his own files in the wanted codec and language.

Note:

In the file Voice mail.cfg the value of same_codec variable depends if you can do transcoding or not: The values that same_codec can have: same_codec 1=enable; 0=disabled default 0

- 1 = enabled - voice mail will be done without transcoding, it is useful in case of a softswitch that does not have a transcoding machine or for MGU without internal matrix. In this case SIP phones must use the same codec. In case that you want to use voice mail also from TDM you have to set in Voip.cfg only one codec in the list of codecs (audio_codecs variable)
- 0 = disabled - voice mail will be done with transcoding; this means that your machine supports transcoding

WEB PGSQL Interface configuration

Voice Mail Activation:

To create the voicemail route go to: Home -> Routes and click on New Route

Routing / New Route	
Reseller	Administrator
Name	R_TO_VOICEMAIL
Source Class	SIP_USERS [0002]
Prefix	999
Action	Service
Destination Class	- None -
Service Type	0021 VM_NOANSWER_BUSY
Ignore from DNIS	0
Insert into DNIS	
Ignore from ANI	0
Insert into ANI	
Sign 1	0000
Sign 2	00000000
Max. Connection Time	3600
Search Mode	ASR
Search Data	0
Sign 3	00000000
Sign 4	00000000
Sign 5	00000000
Sign 6	00000000
Play File	
Start Time	00:00:00
End Time	23:59:59
Days	<input checked="" type="checkbox"/> Sun <input checked="" type="checkbox"/> Mon <input checked="" type="checkbox"/> Tue <input checked="" type="checkbox"/> Wed <input checked="" type="checkbox"/> Thu <input checked="" type="checkbox"/> Fri <input checked="" type="checkbox"/> Sat
<input type="button" value="Submit"/>	

To activate the voice mail on a sip user go to: Home ->

SIP and Edit the SIP User you wish to activate the voice mail

Reseller Administrator	
Billing Group	00000001 Default Billing Group
Client ID	00000003 0317100025
Account Created	2008-12-16 10:06:37
Account State	Enabled
Class	SIP_USERS
Username	0317100025
Centrex Group	- Not Used -
Call Hunting Group	- Not Used -
Forking Group	- Not Used -
RTP_proxy	Always Used
Public	0.0.0.0/0
GSM Number	
Rules	<input type="checkbox"/> Incoming <input type="checkbox"/> Outgoing <input type="checkbox"/>
Reject Calls with no ANI	<input type="checkbox"/>
Multiple Contacts	<input type="checkbox"/>
Do Not Disturb	<input type="checkbox"/>
Call Forward	<input type="checkbox"/>
Call Forward State	<input type="checkbox"/> Offline <input type="checkbox"/> Busy <input type="checkbox"/> No Answer <input type="checkbox"/> Always
Number [Offline]	
Number [No Answer]	
Call Wait	<input type="checkbox"/>
Voice Mail	<input checked="" type="checkbox"/>
Voice Mail State	<input type="checkbox"/> Offline <input type="checkbox"/> Busy <input type="checkbox"/> No Answer <input checked="" type="checkbox"/> Always
Voice Mail to Email State	<input type="checkbox"/>
Voice Mail 2 eMail	<input type="checkbox"/>
Missed Calls to eMail	<input type="checkbox"/>
Missed Calls to eMail eMail	<input type="checkbox"/>
Missed Calls to SMS	<input type="checkbox"/>
Missed Calls to SMS Number	
Billing Profile	- Not Used -
Media Parameters	
Queue 1	Not allowed
Queue 2	Not allowed
Queue 3	Not allowed
Queue 4	Not allowed
Queue 5	Not allowed
Call Queues	
Prepaid Account	- Not Used -

Reading the messages:

To create the read voice mail route go to: Home -> Routes and click on New Route

Routing / New Route

Reseller Administrator

Name

Source Class

Prefix

Action

Destination Class

Service Type

Ignore from DNIS

Insert into DNIS

Ignore from ANI

Insert into ANI

Sign 1

Sign 2

Max. Connection Time

Search Mode

Search Data

Sign 3

Sign 4

Sign 5

Sign 6

Play File

Start Time

End Time

Days ☒ Sun ☒ Mon ☒ Tue ☒ Wed ☒ Thu ☒ Fri ☒ Sat

OAM configuration

Voice Mail Activation:

To create the voice mail route go to: Actions -> Routing Table and click on Add, in the routing table you will see the new route, double click for edit the new created route

Edit routing table

Incoming direction:

Prefix:

Action:

Destination:

Route Name:

IP:

Port:

Ignore:

Insert:

Ignore_Id:

Insert_Id:

Sign1:

Tax:

Sign2:

Ctime:

Search Mode:

Search Param:

Sign3:

Sign4:

Sign5:

Sign6:

Start Time:

End Time:

Dows:

Billing Profile:

Play File Name:

To activate the Voicemail

on a sip user go to: Actions -> SIP Users and double click for edit the SIP User you wish to activate voice mail

Adding / modifying users settings

Username: 0317100024 Password: 0317100024

Alias1: Alias2: Alias3: Alias4: Alias5: Alias6:

Description: Client ID: 1 Account State: Enabled Class ID: SIP_USERS

Centrex: Centrex Group: - Not Used - Centrex Alias1: Centrex Alias2: Centrex Alias3: Centrex Alias4: Centrex Alias5: Centrex Alias6:

RTP Proxy: Not Used Transcoding: Publish Presence: Reject Calls with no ANI: Do Not Disturb: Multiple Contacts: Pickup: - Not Used - Hunting_Group: - Not Used - Hunting_Priority: 0 Forking_Group: - Not Used -

CallForward: Call Forward: Selective Forward: Call Forward State: Offline: Busy: No Answer: Always: Number [Offline]: Number [Busy]: Number [Noanswer]: Number [Always&Selective]:

CallWait: CallWait: CallWaitState:

Access: Public IP: Private IP: Rules_in: Rules_out: GSM Number:

VoiceMail
☒ VoiceMail
 VoiceMail State: ☐ Offline ☐ Busy ☐ No Answer ☒ Always
 VoiceMail Number: 9990317100024

VoiceMail2Email: Enabled: VoiceMail 2 eMail:

MissedCalls2Email: Missed Calls to eMail: Missed Calls to eMail State: Missed Calls to eMail eMail:

MissedCalls to SMS: Missed Calls to SMS: Missed Calls to SMS State: Missed Calls to SMS Number:

CLI Rules Call Queues
 Ok Cancel Help

Reading the messages:

To create the read voicemail route go to: Actions -> Routing Table and click on Add, in the routing table you will see the new route, double click for edit the new created route

Edit routing table

Incoming direction: SIP_USERS Route Name: ROUTE1233910101_0

Prefix: 888

Action: SERV

Destination: (17) READ VOICE MAIL

Ignore: 0 Ignore_Id: 0

Sign1: 0000 Sign2: 00000000

Ctime: 0 Search Mode: 0 Search Param: 00000000

Sign3: 00000000 Sign4: 00000000 Sign5: 00000000 Sign6: 00000000

Start Time: 00:00:00 End Time: 23:59:59 Dows: FF Billing Profile: 0 Play File Name:

IP: Port: 0

Insert: Insert_Id:

OK Cancel Help

GoTo >Main Page > centrala

Glossary

GoTo >Main Page

CAS - Acronym for **Channel-Associated Signaling**. A type of **signaling** in which the signals needed to switch a given telephone circuit are transmitted via the voice circuit itself (the same channel that will afterwards be used for the call). Also, the signaling information can be sent through a signaling channel permanently associated with the voice channel.

CCS - Acronym for **Common-Channel Signaling**. Another type of signaling in which one data channel in each link is dedicated for signaling needed to control, account for, and manage traffic on all the voice or data channels of the link. Unlike CAS, in CCS the transmission of signaling information is performed out of the voice band. The link is a collection of junction channels that have the same properties.

DISA – Acronym for **Direct Inward System Access**. This function allows an outside caller to directly access a local subscriber by using DTMF codes (for example when you call directly a local subscriber without need for a human operator at the phone exchange).

Directions – groups of phone lines through which the calls are routed, depending upon the routing rules and the numbering that was dialed. In TOPEX equipment, "Directions" are groups of local lines, inbound or outbound trunks that have common routing characteristics. To ensure adequate routing of calls, you assign one or more trunks to each direction.

Direction for overflow calls – the direction used as alternative for the "overflow" calls. Overflow calls are calls that get redirected to another direction when the primary direction is not available. This way, no incoming calls are lost, even if the initial direction is busy.

DTMF - Acronym for **Dual Tone Multi Frequency**, also known as "touch tone". Advanced method for dialing a number, instead of the older Pulse mode. When you press a key on the keypad a combination of two audio frequencies is sent on the line. DTMF capability is important because it allows access to a wide range of interactive voice applications.

DSS1 - Acronym for **Digital Subscriber Signaling System No 1**. Common channel signaling specific to the connection between PBX and terminal or between two PBX. DSS1 encompasses the entire suite of signaling protocols used across the ISDN Basic Rate and Primary Rate user-network interfaces. It is defined by ITU-T Recommendations Q.920, Q.921, and Q.922 for the suite's data link layer protocol (LAPD) and by ITU-T's recommendations Q.930, Q.931 and Q.933 for the suite's basic control procedures for calls and access connections.

E1 digital trunk – PCM communication system with 30 voice channels and data rate of 2,048kbit/s. E1 is mainly used in Europe. The T1 version (not currently supported by the TOPEX gateway) is used in North America.

Encoding law – compression scheme used in the PCM system, for 64 kbit/s 8kHz encoding of 8-bit PCM audio (voice) data. There are two variants of encoding widely used: **A Law** (Encoding Law **A** as per ITU G.711 standard) is used as a telephony standard in Europe, Asia, South America, Africa, etc. **u-law** is a similar encoding commonly used in North America and Japan for digital telephony. The official definition is of these non – linear schemes for compression / decompression of voice signal is the ITU-T standard G.711 (formally CCITT G.711).

G.703 - Electrical specifications for the E1 trunk. Described in the ITU-T Recommendation G.703, "Physical/Electrical Characteristics of Hierarchical Digital Interfaces".

G.704 - frame structure specs for the E1 trunk, described by the ITU-T Recommendation G.704, "Synchronous Frame Structures Used at Primary and Secondary Hierarchy Levels".

HDB3 – Acronym for **High Density Bipolar 3** Code (ITU-T). A line code used in the E1 digital multiplex trunk. The "3" stands for a maximum of three zeroes.

ISDN - Acronym for **Integrated Services Digital Network**. ISDN is a worldwide digital network providing high-speed connection between the terminal devices (telephone, fax machines, computers) for a wide range of telecommunication services, using the existing telephony infrastructure. ISDN is based upon two types of communication channels: a B channel that carries data at a rate of 64Kbps and a D channel that carries control information at the rate of 16 or 64Kbps.

ISDN also represents an effort to standardize subscriber services, user / network interfaces, and network and internetwork capabilities: the computers and other terminal devices can connect to ISDN through simple, standard interfaces.

ISUP – Acronym for **ISDN User Part** is the protocol that supports ISDN in the PSTN. It provides the signalling required for circuit-mode bearer services of basic ISDN as well as supplementary services that have end-to-end meaning.

ITU-T - Acronym for **International Telecommunication Union Standardization, Section Telecommunications**. Since 2001 TOPEX is a sector member of I.T.U.

PCM trunk – digital multiplex of phone channels where analog signal are sampled, digitized and compressed. The telephone channels are separated by time using a new type of transmission method known as **Pulse Code Modulation** (PCM). The compression (encoding) of the analog signal can be performed according to two different encoding laws, A-law or μ -law.

PT – Payload Type (7 bits), identifies the format of the RTP payload and determines its interpretation by the application. A profile specifies a default static mapping of payload type codes to payload formats. Additional payload type codes may be defined dynamically through non-RTP means. An RTP sender emits a single RTP payload type at any given time; this field is not intended for multiplexing separate media streams.

MTP – Acronym for **Message Transfer Part** - is the part of the SS7 used for communication in Public Switched Telephone Network. MTP is responsible for the correct and reliable end-to-end data transport of SS7 messages between communication partners.

Q411/412 and **Q421/422** – ITU Recommendations for digital line signal codes to be used with the Signaling system **R2**. ITU Q411/412 is for R2 analog line signaling while Q421/422 is for the digital version. By making use of the increased signaling capacity in PCM systems, simplification of the outgoing and incoming switching equipment can be achieved since the timing conditions necessary for the System R2 line signaling, analogue version, are not required. The digital version of System R2 line signaling uses two signaling channels in each direction of transmission per speech circuit.

QSIG - Acronym for **Q-Signaling protocol** (by the European Association for Standardizing and Communication Systems). Another common channel signaling protocol, based on ISDN. It enables signaling between nodes (PBX) and is widely deployed for the interoperability of different voice communications platforms and equipment in a multi-vendor environment.

R2 – regional system no. 2 for CAS signaling, used in Romania.

Restriction classes – the classes of restrictions are groups of prefixes that can NOT called through certain external (outgoing) phone lines. For example in order to restrict the access of a local subscriber to international calls he must belong to a class of restrictions for which the 00 prefix is forbidden. Within each class you may define a maximum of 20 restrictions.

RTCP – Acronym for **RTP Control Protocol** - is used for control and diagnostic on RTP sessions. Like RTP, RTCP typically runs on top of UDP and is defined in the IETF RFC1889. RTCP is a companion protocol to RTP that is used to maintain Quality of Service. RTP nodes analyze network conditions and periodically send each other RTCP packets that report on network congestion.

Signaling – the totality of information exchanges between the phone central and the terminal device or between two phone exchanges. This information is required in order to establish, maintain, and clear switched telephony

connections. The signaling can be type **CAS** or **CCS**.

SS7 – Signaling System no. 7. Signaling system used for signaling between PBX, in ISDN. In order to be able to establish and disconnect 64 Kbit/s connections with circuit switching, the ISDN phone exchanges must be able to exchange signaling information. The signaling used in ISDN phone centrals is Signaling System No. 7 (**SS7**) according to CCITT.

System 7 with ISUP – The ISUP (ISDN User Part) software layer provides the interface for applications to establish, maintain and clear telephony connections via the SS7 network, in accordance with the recommendations CCITT Q.761-Q.764 and ANSI T1.113 (from 1988 and respectively 1992). The ISUP layer is also responsible for circuit (group) management, such as blocking, unblocking, and resetting of circuits and circuit groups.

VAD - Voice Activity Detection detects whether or not speech is present. A VAD-device can reduce the bandwidth of a call by not transmitting “silent packets” when you are not speaking. Moreover, a VAD-device often generates “comfort noise” or artificial ambient sound when the other party is not speaking. This lets you know that the line is still connected as total silence could easily be mistaken for a lost connection.

Article Sources and Contributors

About topex Source: <http://www.embedded.ro/index.php?oldid=28533> Contributors: Admin

Multiaccess Structure Source: <http://www.embedded.ro/index.php?oldid=13733> Contributors: Admin

Power Card Source: <http://www.embedded.ro/index.php?oldid=13529> Contributors: Admin

Processor Card Source: <http://www.embedded.ro/index.php?oldid=17344> Contributors: Admin

ISDN Card Source: <http://www.embedded.ro/index.php?oldid=78518> Contributors: Alexandra

Voip Card Source: <http://www.embedded.ro/index.php?oldid=6549> Contributors: Admin

GSM Card Source: <http://www.embedded.ro/index.php?oldid=13531> Contributors: Admin

About centrala Source: <http://www.embedded.ro/index.php?oldid=17530> Contributors: Jenuc

SIP features Source: <http://www.embedded.ro/index.php?oldid=15090> Contributors: Jenuc

H323 apc Source: <http://www.embedded.ro/index.php?oldid=14974> Contributors: Jenuc

Mspd Source: <http://www.embedded.ro/index.php?oldid=85930> Contributors: Alexandra, Igor

Rtprx pool Source: <http://www.embedded.ro/index.php?oldid=64391> Contributors: Jenuc

Rtp tx pool Source: <http://www.embedded.ro/index.php?oldid=13512> Contributors: Admin

Reemail Source: <http://www.embedded.ro/index.php?oldid=13501> Contributors: Admin

Smtptmail Source: <http://www.embedded.ro/index.php?oldid=13503> Contributors: Admin

Sendsms Source: <http://www.embedded.ro/index.php?oldid=85878> Contributors: Alexandra

Mysql client Source: <http://www.embedded.ro/index.php?oldid=64405> Contributors: Jenuc

Radius billing Source: <http://www.embedded.ro/index.php?oldid=70479> Contributors: Jenuc

Pgsq sip pool Source: <http://www.embedded.ro/index.php?oldid=64398> Contributors: Jenuc

Pgsq pcodedel Source: <http://www.embedded.ro/index.php?oldid=13518> Contributors: Admin

Pgsq pcode Source: <http://www.embedded.ro/index.php?oldid=13517> Contributors: Admin

Pgsq pcodeerror Source: <http://www.embedded.ro/index.php?oldid=13519> Contributors: Admin

Pgsq sms Source: <http://www.embedded.ro/index.php?oldid=14914> Contributors: Ioana

Default Passwords Source: <http://www.embedded.ro/index.php?oldid=7298> Contributors: Admin

Operating Sistem Structure Source: <http://www.embedded.ro/index.php?oldid=13848> Contributors: Admin

Telnet commands Source: <http://www.embedded.ro/index.php?oldid=85626> Contributors: Jenuc

Connecting with OAM Source: <http://www.embedded.ro/index.php?oldid=12685> Contributors: Admin

OAM / Card Map Source: <http://www.embedded.ro/index.php?oldid=10838> Contributors: Suceveanu

OAM / Installing a GSM card Source: <http://www.embedded.ro/index.php?oldid=28060> Contributors: Admin

OAM / Installing a PRI card Source: <http://www.embedded.ro/index.php?oldid=7355> Contributors: Admin

OAM / Installing a VOIP card Source: <http://www.embedded.ro/index.php?oldid=10835> Contributors: Suceveanu

OAM / Installing a MPAI card Source: <http://www.embedded.ro/index.php?oldid=11888> Contributors: Suceveanu

OAM / EIR2 Source: <http://www.embedded.ro/index.php?oldid=10849> Contributors: Suceveanu

OAM / Call Flow Source: <http://www.embedded.ro/index.php?oldid=12683> Contributors: Admin

OAM / Create a Trunk Source: <http://www.embedded.ro/index.php?oldid=7641> Contributors: Admin

OAM / Access IN Source: <http://www.embedded.ro/index.php?oldid=12044> Contributors: Admin

OAM / Call Directions Source: <http://www.embedded.ro/index.php?oldid=12687> Contributors: Admin

OAM / Routing Table Source: <http://www.embedded.ro/index.php?oldid=85635> Contributors: Alexandra, Suceveanu

OAM / Access Out Source: <http://www.embedded.ro/index.php?oldid=10827> Contributors: Suceveanu

OAM / Max Call duration Source: <http://www.embedded.ro/index.php?oldid=13043> Contributors: Admin

OAM / Overflow Source: <http://www.embedded.ro/index.php?oldid=13051> Contributors: Admin

OAM / Monitor calls Source: <http://www.embedded.ro/index.php?oldid=10832> Contributors: Suceveanu

OAM / SIM Management Source: <http://www.embedded.ro/index.php?oldid=12883> Contributors: Admin

OAM / DTMF Source: <http://www.embedded.ro/index.php?oldid=17308> Contributors: Admin

OAM / DISA Source: <http://www.embedded.ro/index.php?oldid=10845> Contributors: Suceveanu

OAM / Forward Incoming GSM Calls Source: <http://www.embedded.ro/index.php?oldid=17410> Contributors: Admin

OAM / Send SMS Source: <http://www.embedded.ro/index.php?oldid=10831> Contributors: Suceveanu

OAM / Check Credit Source: <http://www.embedded.ro/index.php?oldid=14978> Contributors: Alexandra

OAM / ALARMS Source: <http://www.embedded.ro/index.php?oldid=10852> Contributors: Suceveanu

OAM / Check GSM Signal *Source:* <http://www.embedded.ro/index.php?oldid=10847> *Contributors:* Suceveanu

OAM / Download Billing *Source:* <http://www.embedded.ro/index.php?oldid=17583> *Contributors:* Admin

OAM / Download ASR *Source:* <http://www.embedded.ro/index.php?oldid=10854> *Contributors:* Suceveanu

Connect to Multiaccess or Qutex *Source:* <http://www.embedded.ro/index.php?oldid=5681> *Contributors:* Admin

Change IP Address *Source:* <http://www.embedded.ro/index.php?oldid=14350> *Contributors:* Alexandra

Change Date and Time *Source:* <http://www.embedded.ro/index.php?oldid=85917> *Contributors:* Admin, Alexandra, Victor

Check harddisk for problems *Source:* <http://www.embedded.ro/index.php?oldid=5696> *Contributors:* Admin

Clean restart/shutdown *Source:* <http://www.embedded.ro/index.php?oldid=7720> *Contributors:* Jenuc

Stop/Start Logs *Source:* <http://www.embedded.ro/index.php?oldid=14167> *Contributors:* Admin

Reroute on cause X *Source:* <http://www.embedded.ro/index.php?oldid=6701> *Contributors:* Admin

Upgrade Software *Source:* <http://www.embedded.ro/index.php?oldid=85516> *Contributors:* Admin

CCTL features *Source:* <http://www.embedded.ro/index.php?oldid=10816> *Contributors:* Jenuc

CCTL flow *Source:* <http://www.embedded.ro/index.php?oldid=12782> *Contributors:* Admin

AccessIn *Source:* <http://www.embedded.ro/index.php?oldid=12780> *Contributors:* Admin

Users and Classes *Source:* <http://www.embedded.ro/index.php?oldid=7492> *Contributors:* Jenuc

Routing table *Source:* <http://www.embedded.ro/index.php?oldid=8058> *Contributors:* Teo

AccessOut *Source:* <http://www.embedded.ro/index.php?oldid=12781> *Contributors:* Admin

Exec.cfg *Source:* <http://www.embedded.ro/index.php?oldid=86020> *Contributors:* Alexandra, Jenuc

Traffic.cfg *Source:* <http://www.embedded.ro/index.php?oldid=85585> *Contributors:* Admin, Victor

Dirname.cfg *Source:* <http://www.embedded.ro/index.php?oldid=8514> *Contributors:* Jenuc

Card.cfg *Source:* <http://www.embedded.ro/index.php?oldid=7890> *Contributors:* Jenuc

Port.cfg *Source:* <http://www.embedded.ro/index.php?oldid=7891> *Contributors:* Jenuc

Dir.cfg *Source:* <http://www.embedded.ro/index.php?oldid=77039> *Contributors:* Admin

Voip.cfg *Source:* <http://www.embedded.ro/index.php?oldid=85706> *Contributors:* Jenuc, Victor

Diripin.cfg *Source:* <http://www.embedded.ro/index.php?oldid=8084> *Contributors:* Jenuc

Diripout.cfg *Source:* <http://www.embedded.ro/index.php?oldid=13330> *Contributors:* Admin

Group.cfg *Source:* <http://www.embedded.ro/index.php?oldid=85865> *Contributors:* Alexandra, Teo

Sip pbx.cfg *Source:* <http://www.embedded.ro/index.php?oldid=64324> *Contributors:* Jenuc

Sip redirect.cfg *Source:* <http://www.embedded.ro/index.php?oldid=6140> *Contributors:* Jenuc

Prepaid.cfg *Source:* <http://www.embedded.ro/index.php?oldid=12447> *Contributors:* Teo

SIPusers.cfg *Source:* <http://www.embedded.ro/index.php?oldid=13917> *Contributors:* Jenuc

Voice mail.cfg *Source:* <http://www.embedded.ro/index.php?oldid=6159> *Contributors:* Jenuc

Simindex.cfg *Source:* <http://www.embedded.ro/index.php?oldid=7895> *Contributors:* Jenuc

Register users.cfg *Source:* <http://www.embedded.ro/index.php?oldid=78486> *Contributors:* Jenuc

Extended port config *Source:* <http://www.embedded.ro/index.php?oldid=85921> *Contributors:* Admin, Jenuc

VCSS files for Wavecom *Source:* <http://www.embedded.ro/index.php?oldid=85718> *Contributors:* Admin, Alexandra

Billing generic (PGSQL, MySQL, MSSQL) *Source:* <http://www.embedded.ro/index.php?oldid=14102> *Contributors:* Admin

PgSQL Billing *Source:* <http://www.embedded.ro/index.php?oldid=6826> *Contributors:* Admin

Mysql Billing *Source:* <http://www.embedded.ro/index.php?oldid=85620> *Contributors:* Admin, Victor

Dd-mm-yy.tax *Source:* <http://www.embedded.ro/index.php?oldid=14351> *Contributors:* Ioana

Voicemail2Email *Source:* <http://www.embedded.ro/index.php?oldid=12777> *Contributors:* Admin

Multiaccess Config for Simserver *Source:* <http://www.embedded.ro/index.php?oldid=7879> *Contributors:* Ioana

Clean hdd.sh script *Source:* <http://www.embedded.ro/index.php?oldid=13509> *Contributors:* Admin

GSM Cell Selection *Source:* <http://www.embedded.ro/index.php?oldid=13839> *Contributors:* Admin

Voicemail *Source:* <http://www.embedded.ro/index.php?oldid=7549> *Contributors:* Jenuc

Glossary *Source:* <http://www.embedded.ro/index.php?oldid=17978> *Contributors:* Mihai.cretu

Image Sources, Licenses and Contributors

Image:Maccess.jpeg Source: <http://www.embedded.ro/index.php?title=File:Maccess.jpeg> License: unknown Contributors: Admin

Image:salga.jpg Source: <http://www.embedded.ro/index.php?title=File:Salga.jpg> License: unknown Contributors: Admin

Image:pgruc.jpg Source: <http://www.embedded.ro/index.php?title=File:Pgruc.jpg> License: unknown Contributors: Admin

Image:pgvoip.jpg Source: <http://www.embedded.ro/index.php?title=File:Pgvoip.jpg> License: unknown Contributors: Admin

Image:fux.jpg Source: <http://www.embedded.ro/index.php?title=File:Fux.jpg> License: unknown Contributors: Admin

Image:rj45_e1.jpg Source: http://www.embedded.ro/index.php?title=File:Rj45_e1.jpg License: unknown Contributors: Admin

Image:connectin_pri.jpg Source: http://www.embedded.ro/index.php?title=File:Connectin_pri.jpg License: unknown Contributors: Admin

File:T1_crossover.png Source: http://www.embedded.ro/index.php?title=File:T1_crossover.png License: unknown Contributors: Alexandra

Image:xvoip.jpg Source: <http://www.embedded.ro/index.php?title=File:Xvoip.jpg> License: unknown Contributors: Admin

Image:best_practice.png Source: http://www.embedded.ro/index.php?title=File:Best_practice.png License: unknown Contributors: Admin

Image:Gsm.jpg Source: <http://www.embedded.ro/index.php?title=File:Gsm.jpg> License: unknown Contributors: Admin

File:825_ch_dens_and_ptime_1.png Source: http://www.embedded.ro/index.php?title=File:825_ch_dens_and_ptime_1.png License: unknown Contributors: Alexandra

File:825_ch_dens_and_ptime_2.png Source: http://www.embedded.ro/index.php?title=File:825_ch_dens_and_ptime_2.png License: unknown Contributors: Alexandra

File:828_ch_dens_and_ptime.png Source: http://www.embedded.ro/index.php?title=File:828_ch_dens_and_ptime.png License: unknown Contributors: Alexandra

Image:New_connection.jpg Source: http://www.embedded.ro/index.php?title=File:New_connection.jpg License: unknown Contributors: Admin

Image:Add_gsm.png Source: http://www.embedded.ro/index.php?title=File:Add_gsm.png License: unknown Contributors: Admin

Image:Passwd_window.png Source: http://www.embedded.ro/index.php?title=File:Passwd_window.png License: unknown Contributors: Admin

Image:Card_type_gsm.png Source: http://www.embedded.ro/index.php?title=File:Card_type_gsm.png License: unknown Contributors: Admin

Image:Port_gsm.png Source: http://www.embedded.ro/index.php?title=File:Port_gsm.png License: unknown Contributors: Admin

Image:Pin_oam.jpg Source: http://www.embedded.ro/index.php?title=File:Pin_oam.jpg License: unknown Contributors: Admin

File:addcard.png Source: <http://www.embedded.ro/index.php?title=File:Addcard.png> License: unknown Contributors: Admin

File:isdnpri.png Source: <http://www.embedded.ro/index.php?title=File:Isdnpri.png> License: unknown Contributors: Admin

File:layer1.png Source: <http://www.embedded.ro/index.php?title=File:Layer1.png> License: unknown Contributors: Admin

File:trunksettings.png Source: <http://www.embedded.ro/index.php?title=File:Trunksettings.png> License: unknown Contributors: Admin

File:installports.png Source: <http://www.embedded.ro/index.php?title=File:Installports.png> License: unknown Contributors: Admin

File:Hdlc.png Source: <http://www.embedded.ro/index.php?title=File:Hdlc.png> License: unknown Contributors: Admin

image:add_voip_card.png Source: http://www.embedded.ro/index.php?title=File:Add_voip_card.png License: unknown Contributors: Admin

image:select_ip.png Source: http://www.embedded.ro/index.php?title=File:Select_ip.png License: unknown Contributors: Admin

image:rtp_and_range.png Source: http://www.embedded.ro/index.php?title=File:Rtp_and_range.png License: unknown Contributors: Admin

image:voip_port.png Source: http://www.embedded.ro/index.php?title=File:Voip_port.png License: unknown Contributors: Admin

image:pg_config.png Source: http://www.embedded.ro/index.php?title=File:Pg_config.png License: unknown Contributors: Admin

image:pg_voip.png Source: http://www.embedded.ro/index.php?title=File:Pg_voip.png License: unknown Contributors: Admin

image:rtp_ip.png Source: http://www.embedded.ro/index.php?title=File:Rtp_ip.png License: unknown Contributors: Admin

image:voip_cables.jpg Source: http://www.embedded.ro/index.php?title=File:Voip_cables.jpg License: unknown Contributors: Admin

image:voip_port2.png Source: http://www.embedded.ro/index.php?title=File:Voip_port2.png License: unknown Contributors: Admin

image:pgvoip_voip.png Source: http://www.embedded.ro/index.php?title=File:Pgvoip_voip.png License: unknown Contributors: Admin

image:OAMmpai.png Source: <http://www.embedded.ro/index.php?title=File:OAMmpai.png> License: unknown Contributors: Suceveanu

Image:Oam_r2_1.png Source: http://www.embedded.ro/index.php?title=File:Oam_r2_1.png License: unknown Contributors: Admin

Image:Oamr22.png Source: <http://www.embedded.ro/index.php?title=File:Oamr22.png> License: unknown Contributors: Admin

Image:Amr23.png Source: <http://www.embedded.ro/index.php?title=File:Amr23.png> License: unknown Contributors: Admin

Image:Oamr24.png Source: <http://www.embedded.ro/index.php?title=File:Oamr24.png> License: unknown Contributors: Admin

Image:Oamr25.png Source: <http://www.embedded.ro/index.php?title=File:Oamr25.png> License: unknown Contributors: Admin

Image:Oamr26.png Source: <http://www.embedded.ro/index.php?title=File:Oamr26.png> License: unknown Contributors: Admin

Image:Oamr27.png Source: <http://www.embedded.ro/index.php?title=File:Oamr27.png> License: unknown Contributors: Admin

Image:Oamr28.png Source: <http://www.embedded.ro/index.php?title=File:Oamr28.png> License: unknown Contributors: Admin

Image:Oamr29.png Source: <http://www.embedded.ro/index.php?title=File:Oamr29.png> License: unknown Contributors: Admin

Image:Oamr210.png Source: <http://www.embedded.ro/index.php?title=File:Oamr210.png> License: unknown Contributors: Admin

Image:Oamr211.png Source: <http://www.embedded.ro/index.php?title=File:Oamr211.png> License: unknown Contributors: Admin

image:call_flow.png Source: http://www.embedded.ro/index.php?title=File:Call_flow.png License: unknown Contributors: Admin

Image:Direction_names.png Source: http://www.embedded.ro/index.php?title=File:Direction_names.png License: unknown Contributors: Admin

Image:Rename_trunk.png Source: http://www.embedded.ro/index.php?title=File:Rename_trunk.png License: unknown Contributors: Admin

Image:diripin.png Source: <http://www.embedded.ro/index.php?title=File:Diripin.png> License: unknown Contributors: Suceveanu

Image:diripin_settings.png Source: http://www.embedded.ro/index.php?title=File:Diripin_settings.png License: unknown Contributors: Suceveanu

Image:Call_directions1.png Source: http://www.embedded.ro/index.php?title=File:Call_directions1.png License: unknown Contributors: Suceveanu

Image:Call_directions2.png Source: http://www.embedded.ro/index.php?title=File:Call_directions2.png License: unknown Contributors: Suceveanu

image:sign1_oam.png Source: http://www.embedded.ro/index.php?title=File:Sign1_oam.png License: unknown Contributors: Admin

image:sign2_oam.png Source: http://www.embedded.ro/index.php?title=File:Sign2_oam.png License: unknown Contributors: Admin

image:sign4_oam.png Source: http://www.embedded.ro/index.php?title=File:Sign4_oam.png License: unknown Contributors: Admin

image:sign6_oam.png Source: http://www.embedded.ro/index.php?title=File:Sign6_oam.png License: unknown Contributors: Admin

image:oamrouting1.png Source: <http://www.embedded.ro/index.php?title=File:Oamrouting1.png> License: unknown Contributors: Suceveanu

image:oamrouting2.png Source: <http://www.embedded.ro/index.php?title=File:Oamrouting2.png> License: unknown Contributors: Admin

image:oam072gsm.png Source: <http://www.embedded.ro/index.php?title=File:Oam072gsm.png> License: unknown Contributors: Admin

image:oam072gsm2.png Source: <http://www.embedded.ro/index.php?title=File:Oam072gsm2.png> License: unknown Contributors: Admin

image:072over1.png Source: <http://www.embedded.ro/index.php?title=File:072over1.png> License: unknown Contributors: Admin

image:072over2.png Source: <http://www.embedded.ro/index.php?title=File:072over2.png> License: unknown Contributors: Admin

image:072wrong.png Source: <http://www.embedded.ro/index.php?title=File:072wrong.png> License: unknown Contributors: Admin

image:07fcorrect.png Source: <http://www.embedded.ro/index.php?title=File:07fcorrect.png> License: unknown Contributors: Admin

image:routingsig1.png Source: <http://www.embedded.ro/index.php?title=File:Routingsig1.png> License: unknown Contributors: Admin

[illegible]

Image:Readvm_oam.jpg *Source:* http://www.embedded.ro/index.php?title=File:Readvm_oam.jpg *License:* unknown *Contributors:* Teo