

ZEN MICRO

User's Guide

Copyright © 2004 by Creative Technology Ltd. All rights reserved.

The Creative logo, and Creative MediaSource are trademarks or registered trademarks of Creative Technology Ltd. in the United States and/or other countries. Microsoft, Windows, Windows Media, Outlook and the Windows logo are registered trademarks of Microsoft Corporation. Intel and Pentium are registered trademarks of Intel Corporation. All other products are trademarks or registered trademarks of their respective owners. All specifications are subject to change without prior notice. Actual contents may differ slightly from those pictured.

Information in this document is subject to change without notice and does not represent a commitment on the part of Creative Technology Ltd. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose without the written permission of Creative Technology Ltd. The software described in this document is furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. It is against the law to copy the software on any other medium except as specifically allowed in the license agreement. The licensee may make one copy of the software for backup purposes only.

The Software License Agreement can be found on the Installation CD.

Version 1.00 October 2004

Zen Micro at a Glance	6
Zen Micro	6
Touch Pad	9
Main Menu	12
Now Playing screen	13
Creative MediaSource Player/Organizer	14
Zen Media Explorer	14
Accessories	15
Earphones	15
Belt Clip	16
Pouch.....	17
Neckstrap.....	18
Remote Control.....	19
Importing Music into Creative MediaSource Player/ Organizer	21
Importing music from audio CDs	21
Shopping for music on the Internet.....	22
Transferring Music to Zen Micro	24
Transferring music tracks	24
Creating and transferring playlists	26
Synchronizing music with your computer	26
Playing and Managing Music	27
Turning Zen Micro on and off.....	27
Adjusting volume	27
Locking Zen Micro	27
Selecting and playing music tracks.....	30


Searching for similar tracks	30
Selecting tracks with Zen Micro's DJ	31
Managing the list of selected tracks.....	31
Shuffling and repeating the list of selected tracks	32
Searching within a track.....	33
Using bookmarks	34
Listening to the radio	35
Deleting radio presets.....	37
Recording radio broadcasts.....	37
Recording with the built-in microphone.....	38
Playing recorded tracks	39
Deleting tracks	39
Viewing track information.....	39
Viewing player information.....	39
Using Zen Micro's Organizer Features	41
Synchronizing with Microsoft Outlook.....	41
Viewing the calendar	41
Viewing today's tasks	42
Viewing contacts.....	42
Storing Data Files in Zen Micro	43
Using Zen Micro as a Removable Disk.....	43
Changing the amount of memory space in Removable Disk mode	47
Personalizing Zen Micro	49
Adjusting Touch Pad settings	49
Setting the date and time.....	49
Setting the alarm.....	50

Using Zen Micro's equalizer (EQ).....	50
Setting playback at a constant volume	51
Labeling Zen Micro with your name.....	52
Setting the backlight duration	52
Setting the display contrast.....	52
Setting the idle shutdown time.....	53
Enabling Sleep Timer	53
Changing the menu language.....	53
Resetting Zen Micro.....	54
Adding and removing main menu items	54
Frequently Asked Questions	55
Safety Advice	63
General Specifications	64

Zen Micro at a Glance

After completing the setup instructions in the Quick Start booklet, take some time to read this User's Guide to learn how to get the most out of your player.

Zen Micro



-  ① **Next/Fast-Forward button**

Press this button to go the next track.
Press and hold this button to move forward within a track.
-  ② **Options button**

Press this button to display the options available.
-  ③ **Touch Pad**

Use the Touch Pad to scroll through and select menu items.
During playback, use the Touch Pad to adjust the volume.
For more information using the Touch Pad, see "Touch Pad" on page 9.
-  ④ **Menu/Back button**

During playback, press this button to display the main menu.
When scrolling through menu items, press this button to return to the previous menu.
-  ⑤ **Play/Pause button**

Starts, pauses and resumes playback.
-  ⑥ **Previous/Rewind button**

Press this button to go the previous track.
Press and hold this button to move back within a track.
-  ⑦ **Power switch**

Turns your player on and off.

**⑧ Lock**

Slide the Power switch to the Lock position to disable your player's controls.

**⑨ Headphone jack**

Connect Zen Micro's earphones to this jack.


USB 2.0**⑩ USB 2.0 port**

To charge Zen Micro's battery, connect one end of Zen Micro's Power Adapter to this port, and the other end to a power outlet. Turn on the power outlet if necessary. To transfer music and data files, connect one end of the supplied USB cable to this port, and the other end of the USB cable to the your computer's USB port.


**⑪ Microphone**

Make instant recordings with this built-in microphone.


Touch Pad



Move your finger up and down the Touch Pad to scroll through menu items.




To rapidly scroll through menu items, hold down the top or bottom portion of the Touch Pad with your finger.



To select a menu item, lightly tap the Touch Pad.


Main Menu

Press the Menu/Back  button to view Zen Micro's main menu. Move your finger up and down the Touch Pad to scroll through menu items, and press the Menu/Back  button to return to the previous menu or screen.



Now Playing screen

The Now Playing screen appears when you turn on Zen Micro, or when a song is playing. When you see the Now Playing screen, move your finger up and down the Touch Pad to adjust the volume. Status icons at the top right corner of the LCD indicate Zen Micro's current settings and battery status.



NOTE

When you see the Now Playing screen, lightly tap the Touch Pad to view the Selected Music screen. The Selected Music screen shows you your list of selected music tracks.

Creative MediaSource Player/Organizer

Use Creative MediaSource™ Player/Organizer to import music into your computer and transfer it to Zen Micro. Creative MediaSource Player/Organizer is your digital music center for playing, creating, organizing and transferring digital music.

Creative MediaSource Player/Organizer is included with your player and is automatically installed when you set up the Zen Micro software on your computer.

TIP

By default, Creative MediaSource Player/Organizer automatically starts when you connect Zen Micro to your computer. You can disable this feature at any time. For more information, refer to Creative MediaSource Player/Organizer's online Help.

Zen Media Explorer

Zen Media Explorer offers you the ease of managing music tracks and data files in Zen Micro, in a Windows Explorer environment.

Zen Media Explorer is included with your player and is automatically installed when you set up the Zen Micro software on your computer.

NOTE


- After Zen Media Explorer is installed, the **Zen Media Explorer**  icon appears in Windows Explorer under **My Computer**.
- When you connect your player to your computer, an icon representing Zen Micro  appears under the **Zen Media Explorer** icon. To start Zen Media Explorer, click the icon that represents Zen Micro.

Accessories

Zen Micro comes with some of the accessories described below. Accessories that are not included with your player are available from your Creative Labs dealer or at our online store at www.creative.com.

Earphones


Zen Micro's earphones feature dynamic bass response and enhanced audio clarity.



WARNING! For your safety and the safety of others, do not use your earphones while driving, cycling or any other activity that requires your full attention.

Belt Clip

Use the Zen Micro belt clip to fasten Zen Micro to your belt.




Pouch

Zen Micro's protective pouch keeps Zen Micro snug and safe.



Neckstrap

With Zen Micro's neckstrap, your music collection goes wherever you go.




NOTE

Zen Micro's neckstrap is available separately in selected countries.

Remote Control

Zen Micro's optional remote control gives you easy access to basic playback functions.



NOTE Zen Micro's remote control is available separately in selected countries.

+ ① Volume Increase button
Press this button to increase the volume.

- ② Volume Decrease button
Press this button to decrease the volume.

▶/|| ③ Play/Pause button
Starts, pauses and resumes playback.

▶▶ ④ Next/Fast-Forward button
Press this button to go the next track.
Press and hold this button to move forward within a track.

◀◀ ⑤ Previous/Rewind button
Press this button to go the previous track.
Press and hold this button to move back within a track.

🎧 ⑥ Headphone jack
Connect Zen Micro's earphones to this jack.

MODE ⑦ MODE button
Press this button to switch between the Now Playing and FM Radio modes.

🔒 ⑧ Lock switch
Slide to the Lock position to disable the remote control.

Importing Music into Creative MediaSource Player/Organizer

To listen to music on Zen Micro, first import music into Creative MediaSource Player/Organizer, and then transfer this music to your player. Music can be ripped from your CD collection, or downloaded from Internet music sites.

Importing music from audio CDs

WARNING! It may be illegal to encode MP3 or WMA files for trade or sale unless you have the express or explicit permission of the copyright holder(s).

To get music tracks from your CDs, you will need a CD-ROM or DVD-ROM drive that can extract digital audio data. Creative MediaSource Player/Organizer reads the audio information on your CD and convert it to MP3 or WMA files using the bitrate you choose.

The standard bitrate of most MP3 files is 128 kbps, although some are set higher, at 160 or 192 kbps. The standard bitrate for WMA files is 64 Kbps. Using the standard bitrate will ensure that your MP3 and WMA files retain much of their audio quality. Higher bitrates will result in larger file sizes, but better audio quality.

The time needed to successfully extract audio from a CD depends on:

- CD-ROM/DVD-ROM drive speed
- defects, like scratches on the audio CD
- error-checking features on the CD-ROM/DVD-ROM drive
- bitrate selected for encoding

To rip an audio CD using Creative MediaSource Player/Organizer

- 1 Start Creative MediaSource Player/Organizer.
- 2 Insert an audio CD into your CD-ROM/DVD-ROM drive.
- 3 If Creative MediaSource Player/Organizer is in Player view, click the **Player/Organizer View** button to switch to Organizer view.
- 4 In the **Sources** window, select [**d:**] **Audio CD** (replace **d:** with the drive letter of your CD-ROM/DVD-ROM drive).
- 5 In the Task bar, click the **Rip Now** button.

TIP

If you have an Internet connection, you can set Creative MediaSource Player/Organizer to automatically retrieve track information about the tracks being ripped, instead of manually entering this information. For more information about this feature, refer to Creative MediaSource Player/Organizer's online Help.

Shopping for music on the Internet

If you have an Internet connection, you can use a search engine to locate sites where you can purchase digital music content. Follow the instructions on these sites to download the music tracks to your computer.

Once you have downloaded music tracks, you can import these tracks into Creative MediaSource Player/Organizer using the **Import Wizard**.

To import music tracks into Creative MediaSource Player/Organizer

- 1 Start Creative MediaSource Player/Organizer.
- 2 If Creative MediaSource Player/Organizer is in Player view, click the **Player/Organizer View** button to switch to Organizer view.


- 3 In the Task bar, click the **Import** button, and select **Import Tracks**.
The Import Wizard dialog box appears.
- 4 In the **My Computer** panel, locate the track or folder you want to import, and then click the **Add File** or **Add Folder** button.
- 5 Click the **Continue** button and follow the instructions on the screen.

Transferring Music to Zen Micro


Music tracks that you transfer to Zen Micro must be MP3 or WMA files if you want to play them back.

Transferring music tracks


- 1 Connect Zen Micro to your computer's USB port with the supplied USB cable.



- 2 When your computer detects Zen Micro, Creative MediaSource Player/Organizer starts automatically. Transfer your music tracks (MP3 or WMA files) to Zen Micro using the drag-and-drop method.
- 3 When you have finished transferring music tracks, disconnect Zen Micro. Wait till you see the *inactive* Docked screen before disconnecting Zen Micro. DO NOT disconnect Zen Micro if you see the *active* Docked screen on the LCD. Transfer is still in progress and disconnecting Zen Micro may damage the tracks being transferred.



Inactive Docked screen



Active Docked screen

TIP

You can also use Zen Media Explorer to transfer music tracks to Zen Micro. For more information, refer to its online Help.

Creating and transferring playlists

With Creative MediaSource Player/Organizer, organizing music tracks into playlists (tracks you have organized into lists) has never been easier. You can create as many playlists as you like and transfer these to Zen Micro.

You can compile playlists using the drag-and-drop method, or automatically generate playlists based on your preferences using the Smart Playlist feature.

TIP

- For more information about using Creative MediaSource Player/Organizer, refer to its online Help.
- You can also directly create playlists on Zen Micro. For more information, see "Managing the list of selected tracks" on page 31.

Synchronizing music with your computer

You can use Sync Manager to update and synchronize music in Zen Micro and your computer.

- 1 Connect Zen Micro to your computer.
- 2 Start Sync Manager.
You can start Sync Manager in either Creative MediaSource Player/Organizer or Zen Media Explorer.
- 3 Select **My Computer** and **Zen Micro** as the devices you want to synchronize, and then click **Sync Now**.
- 4 Select the **Audio** check box, and then click the **Next** button.
- 5 Follow the instructions of the screen.
- 6 Click the **Finish** button.

Playing and Managing Music

After transferring music to Zen Micro, read on to learn how to get the most out of your player.

Turning Zen Micro on and off

- 1 To turn on Zen Micro, slide the Power switch towards the Power  icon and hold it there until the LCD lights up.
- 2 To turn off Zen Micro, slide the Power switch towards the Power  icon and hold it there until **Shutting down...** appears.

Adjusting volume

In the Now Playing screen, move your finger up and down the Touch Pad to adjust the volume.

To adjust the volume when browsing the menu, press the Options  button and select **Volume**.


Locking Zen Micro

Locking Zen Micro disables all controls on Zen Micro. Lock Zen Micro when you want to prevent buttons from being accidentally pressed.

You can lock Zen Micro with your player's Power switch. To lock the optional Zen Micro remote control, use the Lock switch on the remote control.


To lock Zen Micro

Slide the Power switch towards the Lock  icon. The Locked icon  appears on the Now Playing screen.



To lock the Zen Micro remote control

Slide the Lock switch towards the Lock  icon.



Selecting and playing music tracks

You can search for music tracks by album, artist, genre or title. If you have created playlists (tracks you have organized into lists) on Zen Micro, or transferred playlists from Creative MediaSource Player/Organizer, you can search for music tracks in playlists as well.

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **Music Library** and select a music category, such as **Albums** or **Genres**. Select **All Tracks** if you want to search by track title.
- 3 Continue searching with the Touch Pad until you find what you want.
At any time, press the Options  button for more search and playback options.
- 4 To start playing a music track or a category of music tracks (like an album), scroll to the item and press the Play/Pause  button.
The currently playing track appears on the Now Playing screen. Lightly tap the Touch Pad when viewing the Now Playing screen to view the Selected Music screen. The Selected Music screen shows you your list of selected music tracks.
- 5 To add music tracks to the list of selected tracks, select a music track, and then select **Add to Selected**.

NOTE

For more information about creating playlists on Zen Micro, see "Managing the list of selected tracks" on page 31.

Searching for similar tracks

During playback, you can search for another track that is similar to the currently playing track. In the Now Playing screen, press the Options  button and select **Lookup Artist** to start playing a similar track.

You can also select this option when viewing the Selected Music screen. Lightly tap the Touch Pad when viewing the Now Playing screen to view the Selected Music screen. The Selected Music screen shows you your list of selected music tracks.

Selecting tracks with Zen Micro's DJ

Instead of selecting tracks yourself, you can let Zen Micro's DJ pick out tracks for you.

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **Music Library ▶ DJ**.
- 3 Select **Album of the Day** to play an album of music tracks selected by Zen Micro's DJ.
- 4 Select **Random Play All** to let Zen Micro's DJ randomly play all tracks, including your recorded tracks.

Managing the list of selected tracks

Tracks you have selected for playback can be viewed and managed in the Selected Music screen.

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **Now Playing**.
- 3 Lightly tap the Touch Pad.
The Selected Music screen appears.

- 4 Press the Options  button and select one of the following playlist management options:
 - **Remove... ▶ Remove Track**
Removes the current track from the list.
 - **Remove... ▶ Remove All**
Clears the list.
 - **Save As Playlist**
Saves the list as a playlist. Name the playlist using the characters in the list box that appears, and then select **Ok**.

TIP These playlist management options are also available in the Now Playing screen.

Shuffling and repeating the list of selected tracks

You can shuffle or repeat your list of selected tracks by selecting a different play mode.

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **Play Mode**.

3 Select one of the following items in the Play Mode screen:

- **Normal**
Plays your selected tracks in sequential order.
- **Repeat Track**
Repeats the current track. When you select this play mode,  appears on the Now Playing screen.
- **Repeat All**
Repeats all selected tracks. When you select this play mode,  appears on the Now Playing screen.
- **Shuffle**
Plays all selected tracks in random order, once only. When you select this play mode,  appears on the Now Playing screen.
- **Shuffle Repeat**
Plays and repeats all selected tracks, in random order. When you select this play mode,  appears on the Now Playing screen.
- **Track Once**
Stops playing after the current track ends. When you select this play mode,  appears on the Now Playing screen.

TIP

To change the play mode during playback, press the Options  button and select Play Mode.

Searching within a track

You can search for a particular point within a track and start playing from there. For example, if you want to start playback one minute into a music track, you can pinpoint or *seek to* the one minute position and then play from there.

- 1 In the Now Playing screen, press the Options  button and select **Seek To**.
- 2 Move your finger up and down the Touch Pad to scroll to any point within the current track.

- 3 Lightly tap the Touch Pad to start playing from the selected position.

Using bookmarks

You can insert bookmarks during playback. A bookmark helps you mark a point within a track, so you can return to it at a later time.

For example, if you are listening to your recording of an interview, insert a bookmark if you need to stop halfway through. When you want to continue listening from where you left off, go to this bookmark.

You can use up to 10 bookmarks at any one time.

To insert a bookmark

- 1 In the Now Playing screen, press the Options  button and select **Set Bookmark**. Playback pauses and the Set Bookmark screen appears.
- 2 Select a bookmark number.
Your bookmark is assigned to the selected bookmark number. If all 10 bookmark numbers have been assigned, you can replace an existing bookmark with the new one.

To go to a bookmark

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **Music Library ▶ Bookmarks**.
- 3 Select the bookmark that you want.


Listening to the radio

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **FM Radio**.
- 3 To automatically scan and save radio stations, press the Options  button and select **Autoscan**.
The player scans for all radio stations with clear reception. At the end of the autoscan, Zen Micro automatically saves all stations as presets and tunes in to the first preset.
- 4 Press the Next/Fast-Forward  button or Previous/Rewind  button to select a different preset.

NOTE

- Make sure your earphones are connected to your player when scanning for radio stations. The earphone cable acts as an antenna for radio reception.
- If you're using the optional Zen Micro remote control, you can press the MODE button to switch between the Now Playing and FM Radio screens.

- 5 To fine tune or manually scan for a radio station, press the Play/Pause ►|| button to switch to the manual tuning view.



Manual tuning view

Preset information disappears in the manual tuning view.

- 6 Press the Next/Fast-Forward ►► button or Previous/Rewind ◀◀ button to fine tune the radio frequency.
- 7 Hold down the Next/Fast-Forward ►► button or Previous/Rewind ◀◀ button for one second to scan for the next available radio station.
- 8 To save a radio station as a preset, press the Options ⌵ button, select **Save As Preset**, and then select a preset number.

Deleting radio presets

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **FM Radio**.
- 3 Press the Next/Fast-Forward  button or Previous/Rewind  button to select the preset you want to delete.
- 4 Press the Options  button and select **Delete Preset**.

Recording radio broadcasts

- 1 While listening to a radio broadcast, press the Options  button and select **Record Radio** to start recording.
- 2 While recording, you can press the Options  button and select one of the following items:
 - **Pause**
Pauses the recording. You can also pause the recording by pressing the Play/Pause  button.
 - **Split**
Starts a new recording.
 - **Stop**
Stops and saves the recording.
- 3 The recorded track is named **FM** followed by the date and time of the recording (**FM YYYY-MM-DD HH:MM:SS**). For example, if you record a track on March 15, 2004 at 2:57 pm, the track is named **FM 2004-03-15 14:57:00**.

- 4 To view and play back recorded tracks, see "Playing recorded tracks" on page 39.

NOTE Make sure your earphones are connected to your player when recording radio broadcasts. The earphone cable acts as an antenna for radio reception.

Recording with the built-in microphone

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **Extras ▶ Microphone**.
- 3 Press the Play/Pause  button to start recording.

TIP For a clear recording, make sure you place Zen Micro as close as possible to what you want to record.

- 4 While recording, you can press the Options  button and select one of the following items:
 - **Pause**
Pauses the recording. You can also pause the recording by pressing the Play/Pause  button.
 - **Split**
Starts a new recording.
 - **Stop**
Stops and saves the recording.
- 5 The recorded track is named **MIC** followed by the date and time of the recording (**MIC YYYY-MM-DD HH:MM:SS**). For example, if you record a track on March 15, 2004 at 2:57 pm, the track is named **MIC 2004-03-15 14:57:00**.
- 6 To preview your new recording, press the Options  button and select **Preview**. To delete it, select **Delete Recording**.

To view and play back recorded tracks, see "Playing recorded tracks" on page 39.

Playing recorded tracks

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **Music Library** ▶ **Recordings**, and select the recording you want to play.

Deleting tracks

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **Music Library**.
- 3 Continue searching with the Touch Pad until you find the track or category of tracks that you want to delete.
- 4 Press the Options  button and select **Delete Playlist**, **Delete Album**, **Delete Artist**, **Delete Genre** or **Delete Track**.
For more song management tasks, connect your player to your computer and use Creative MediaSource Player/Organizer.

Viewing track information

To view detailed information about a track, such as its duration, scroll to the track, press the Options  button, and select **View Details**.

Viewing player information

You can view player information, such as memory space and the total number of tracks, in the Information screen.

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **System ▶ Information**.

Using Zen Micro's Organizer Features

Zen Micro stores your contacts, calendar events and tasks from Microsoft Outlook®. Read on to learn how to use these organizer features.

Synchronizing with Microsoft Outlook

- 1 Connect Zen Micro to your computer.
- 2 Start Sync Manager.
You can start Sync Manager from Zen Media Explorer or Creative Media Source Player/Organizer.
- 3 Select the My Computer and Zen Micro as the devices you want to synchronize, and then click **Sync Now**.
- 4 Select the information you want to import from Microsoft Outlook, and then click the **Next** button.
- 5 Follow the instructions on the screen.
- 6 Click the **Finish** button.

TIP

You can also use Sync Manager to synchronize music tracks between Zen Micro and your computer. For more information, see "Synchronizing music with your computer" on page 26

Viewing the calendar

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **Extras ▶ Organizer ▶ Calendar**.

- 3 Use the Next/Fast Forward  and Previous/Rewind  buttons to scroll between months, and use the Touch Pad to scroll between the days in the selected month.
- 4 Lightly tap the Touch Pad to view the events and to-do list of the selected day.

Viewing today's tasks

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **Extras ▶ Organizer ▶ Tasks**.

Viewing contacts

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **Extras ▶ Organizer ▶ Contacts**.
- 3 Select a name in your contact list to view details about the selected person.

Storing Data Files in Zen Micro

You can use Zen Micro to store backup copies of your computer's data files, or use it to transfer files from one computer to another.


Use Zen Media Explorer if you need to transfer data files between Zen Micro and your computer. Zen Media Explorer is automatically installed when you set up the Zen Micro software on your computer. If you want to use Zen Micro to transfer files between different computers, make sure you set up the Zen Micro software on these computers.

If you are using a shared computer in school or at the office, and installing Zen Media Explorer is not possible, you can still transfer data files. However, you must enable Zen Micro's Removable Disk mode when you do this.


Using Zen Micro as a Removable Disk

- 1** Press the Menu/Back  button.
The main menu appears.
- 2** Select **Extras ▶ Removable Disk**.
When you select this menu item for the first time, you must select the the amount of memory space you want to use for the Removable Disk mode.
- 3** When you see **Removable Disk** on Zen Micro's LCD, you are ready to transfer data files to and from any computer.

- 4 Connect Zen Micro to your computer using the supplied USB cable.



Zen Micro appears as a Removable Disk under **My Computer** in Windows Explorer.



- 5 Use the drag-and-drop method in Windows Explorer to copy files to and from Zen Micro.
- 6 When you have finished copying files, safely disconnect Zen Micro using the **Windows Eject** or **Safely Remove Hardware** icon on the Taskbar. Follow these steps below to safely disconnect your player:

CAUTION! Only disconnect Zen Micro after the **Do not Disconnect** message disappears from the LCD. If not, your player may not be able to function normally.


To stop your player in Windows XP, Windows 2000 or Windows Me

Click the **Safely Remove Hardware** icon  on the Taskbar, click **Safely remove USB Mass Storage Device**, and disconnect your player when you are prompted to do so.



To stop your player in Windows 98 SE

In Windows Explorer, right-click the **Removable Disk** icon, click the **Eject** option, and disconnect your player when you are prompted to do so.



- 7 To return to the Now Playing screen and continue listening to music on Zen Micro, press the Menu/Back  button.

Remember to disconnect Zen Micro first. Zen Micro cannot return to the Now Playing screen if the USB cable is still connected to it.

NOTE

- Data files saved in the Recovery Mode memory space cannot be viewed or managed with Zen Media Explorer.
- Similarly, data files transferred to Zen Micro using Zen Media Explorer cannot be viewed or managed in Recovery Mode.

Changing the amount of memory space in Removable Disk mode

You can change the amount of memory space in Removable Disk mode at anytime.

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **Extras ▶ Removable Disk**.
- 3 Press the Options  button, select **Set Capacity**, and select the capacity that you want.
Before you can decrease the amount of memory space, the existing data files stored in Removable Disk mode must be able to fit into the decreased space.

NOTE

- To delete all the data files in the Removable Disk memory space, press the Options  button and select **Format**.
- Use Windows Explorer if you want to delete individual data files stored in Removable Disk mode.

- 4 Alternatively, connect Zen Micro to your computer and use Creative Removable Disk Manager to increase or decrease the amount of memory space in Removable Disk mode.

TIP

- Creative Removable Disk Manager is included with your player and is automatically installed when you set up the Zen Micro software on your computer.
- To start Creative Removable Disk Manager, click **Start** → **Programs** or **All Programs** → **Creative** → **Zen Micro** → **Creative Removable Disk Manager**.

Personalizing Zen Micro

Zen Micro's settings can be adjusted to suit your needs.

Adjusting Touch Pad settings

You can change the Touch Pad's sensitivity, and to turn the Touch Pad's clicking sound on or off.

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **System ▶ Player Settings ▶ Touch Pad**.
- 3 To adjust the Touch Pad's sensitivity, select Sensitivity and use the Touch Pad to scroll to the setting that you want.
- 4 To turn the clicking sound on or off, select **Clicker: On** or **Clicker: Off**.

Setting the date and time

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **Extras ▶ Date & Time**. The current date and time are displayed.
- 3 Press the Options  button and select **Set Time** or **Set Date** to change the time or date settings respectively.
- 4 You can adjust how the date and time are displayed by selecting **Date Separator**, **Date Format** and **Time Format**.

Setting the alarm

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **Extras ▶ Date & Time**. The current date and time are displayed.
- 3 To adjust time, date and alarm settings, press the Options  button and select **Set Alarm**.

Using Zen Micro's equalizer (EQ)

EQ is Zen Micro's collection of equalizer settings that enhance the sound of your music. You can select equalizer settings to suit the genre or style of your music, or customize your own setting.

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **System ▶ Audio Settings ▶ EQ**.
- 3 Select one of the EQ menu items.
When an EQ setting is selected,  appears on the Now Playing screen.

To create a customized equalizer setting

- 1 In the EQ screen, select **Custom EQ**.
Each slider on the Custom EQ screen represents successively higher frequencies that can be adjusted.
 - **80** controls bass frequency
 - **250** adjusts the low mid-range frequency
 - **1k** adjusts the mid-range frequency
 - **4k** adjusts the upper mid-range frequency
 - **13k** adjusts the treble frequency.
- 2 Select a slider, and move your finger up and down the Touch Pad to move the control knob up or down to vary the amount of boost or reduction in the selected frequency range.
- 3 Lightly tap the Touch Pad to confirm the setting for the selected slider.
- 4 Repeat steps 2 and 3 for the remaining sliders.
- 5 Select the check mark to save and enable the **Custom EQ** settings.

Setting playback at a constant volume

You can limit the volume range of playback with Smart Volume. When enabled, Smart Volume sets playback at a constant volume, so you do not have to continually adjust the volume when you play back different tracks.

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **System ▶ Audio Settings ▶ Smart Volume: On**.

Labeling Zen Micro with your name

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **System ▶ Player Settings ▶ Owner**.
- 3 Spell out your name using the characters in the list box that appears, and then select **Ok**.

Setting the backlight duration

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **System ▶ Player Settings ▶ Backlight Time**.
- 3 Use the Touch Pad to scroll to the backlight duration that you want.

Setting the display contrast

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **System ▶ Player Settings ▶ Contrast**.
- 3 Use the Touch Pad to scroll to the contrast setting that you want.

Setting the idle shutdown time

You can specify how long Zen Micro remains inactive before it automatically shuts down. This feature helps you conserve battery power.

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **System ▶ Player Settings ▶ Idle Shutdown**.
- 3 Use the Touch Pad to scroll to the timing that you want.

Enabling Sleep Timer

You can specify a fixed period of time before Zen Micro automatically turns off. When enabled, Sleep Timer overrides the Idle Shutdown settings.

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **System ▶ Player Settings ▶ Sleep Timer**.
- 3 Use the Touch Pad to scroll to the timing that you want.

Changing the menu language

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **System ▶ Language**, and select the language that you want.

Resetting Zen Micro

You can reset Zen Micro to its original settings.

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Select **System ▶ Reset Settings**.

Adding and removing main menu items

You can personalize the main menu by adding and removing menu items. For example, if you usually search for songs by album, you can add Albums to the main menu so you can access the Albums screen more easily.

- 1 Press the Menu/Back  button.
The main menu appears.
- 2 Press the Options  button and select **Configure Menu**.
- 3 Select the check boxes to add menu items and clear the check boxes to remove these menu items from the main menu.
- 4 To change the order of the menu items, press the Options  button and select **Change Order**.
- 5 Use the Touch Pad to change the position of the the highlighted menu item.
- 6 To revert to the default menu settings, press the Options  button and select **Default Menu**.

Frequently Asked Questions

If the tips and advice in this chapter do not answer your question, refer to the Creative Knowledge Base for more information. Creative's 24-hour self-help Knowledge Base helps you resolve and troubleshoot technical queries. Go to www.creative.com and select your region.

What are the minimum system requirements for setting up Zen Micro's software?

- Microsoft® Windows® XP, Windows 2000, Windows Millennium Edition (Me) or Windows 98 Second Edition (SE)
- Intel® Pentium® II 350 MHz, AMD®-K6-2® 450 MHz or better processor (Pentium III 450 MHz or higher recommended for MP3 encoding)
- CD-ROM/DVD-ROM drive with digital audio extraction support
- USB 1.1 (USB 2.0 port recommended for faster transfers)
- 64 MB RAM (128 MB recommended)
- 30 MB free hard disk space (more for audio content storage)
- Internet connection for Internet content downloading and CDDDB2™ support (any charges incurred are the responsibility of the user)

NOTE

The software applications on the Zen Micro CD may have higher requirements for basic functionality. Refer to each application's documentation for details.

Should I leave Zen Micro plugged into the Power Adapter?

No, you should not. After charging the battery or using Zen Micro, disconnect it from the Power Adapter. Leaving it plugged in leads to heat buildup, which is not good for Zen Micro or its battery.

Can I jog with my Zen Micro?

You should not subject Zen Micro to continuous shocks, such as those that are likely to occur while you jog or run.

Can I transfer DRM protected WMA files to my player?

Yes. To transfer DRM protected WMA files to Zen Micro, you can use Creative MediaSource Player/Organizer or Zen Media Explorer.

Can I use the player for portable data storage?

Yes, you can. For more information, see "Storing Data Files in Zen Micro" on page 43.

If I damage or lose my Power Adapter, can I buy a similar, off-the-shelf adapter?


No. An off-the-shelf adapter may not be compatible with Zen Micro, and may even damage it. You should get a replacement Power Adapter from Creative at www.creative.com, or your local Creative office/distributor.

I have to recharge Zen Micro's battery quite often. Is there anything I can do to make it last longer?


Generally, any operation requiring Zen Micro to access the hard disk uses battery power. Consequently, filling your player to capacity is not recommended. However, some operations consume more battery power:

- a long backlight timeout setting. A shorter timeout conserves battery power.
- a high contrast setting. Position the player so that you can read the display without using a high contrast setting.
- fast-forwarding or rewinding.
- turning the player on and off too many times.
- prolonged use at high volumes.

One of the following diagrams appears on the LCD. What does it mean?



Your computer is actively managing your player. Warning: DO NOT disconnect your player while your computer is still actively managing it.



Your computer is not actively managing your player. To use your player, disconnect it from your computer.



You are upgrading your player's firmware.



The firmware upgrade is complete. Reset your player to enable the new firmware to take effect.



There was an unexpected power loss during audio file transfer. Use your player only after this library rebuilding is completed.



There was an unexpected power loss while saving settings. Reload the firmware, download a newer firmware version or contact Customer Support Services.



The firmware is corrupted. Reload the firmware, download a newer firmware version or contact Customer Support Services.

How do I reset Zen Micro?

You can solve most problems with Zen Micro by resetting it.

- 1 Turn off Zen Micro.
- 2 Slide open the battery cover.
- 3 Remove the battery and wait five seconds before reinserting the battery.

Zen Micro does not turn on or stops responding. What do I do?

- Make sure the Power switch is not in the Lock  position.
- If you're using the optional Zen Micro remote control, make sure the remote control's Lock switch is not is the Lock  position.
- Your battery may need to be recharged. Connect your player to the Zen Micro Power Adapter, and then connect the Power Adapter to a power outlet. If necessary, turn on the power outlet.

Do I need to defragment Zen Micro hard disk drive?

Zen Micro may occasionally operate at less than optimal performance for a number of reasons, for example, if Music Library is rebuilt frequently when no changes are made to it. Selecting **CleanUp** in Zen Micro's Recovery Mode menu cleans, rebuilds and reorganizes Music Library and restore it to optimal efficiency. Save a copy of Zen Micro's content before cleaning up your player.

To clean up Zen Micro's hard disk drive

- 1 Turn off Zen Micro.
- 2 Slide open the battery cover.
- 3 Remove the battery.
- 4 Slide the Power switch towards the Power  icon and hold it there while you reinsert the battery.
The Recovery Mode screen appears when Zen Micro turns on.
- 5 Four menu items are available in the Recovery Mode screen: **CleanUp**, **Format All**, **Reload Firmware** and **Reboot**.
- 6 To clean up your player's hard disk drive, select **Cleanup**.
- 7 When the clean up is complete, select **Reboot**. Your player restarts and starts rebuilding Music Library.

- CAUTION!**
- Selecting **Format All** clears Zen Micro's memory and erases all hard disk content. Save a copy of your player's content before formatting your player.
 - Selecting **Reload Firmware** erases your player's firmware. **DO NOT** Select the **Reload Firmware** unless you have downloaded a newer firmware version for Zen Micro, or have been advised to do so by the Creative Customer Services center.

My optional Zen Micro remote control is not working. What do I do?

- Make sure the remote control's Lock switch is not in the Lock  position.
- Make sure the remote control is properly connected to Zen Micro, and the earphones are properly connected to the remote control.

What is PC Music Library?

PC Music Library is your collection of digital audio tracks in Creative MediaSource Player/Organizer. In Creative MediaSource Player/Organizer, you can have more than one PC Music Library. When sharing the same computer, multiple users can each have their own music library, each with its own settings. However, only one music library can be active at one time.

Can PC Music Library be automatically updated?

Yes. You can use Media Sniffer tool in Creative MediaSource Player/Organizer to monitor or 'watch' folders in your computer. With Media Sniffer enabled, PC Music Library is updated when tracks in monitored folders are added, deleted or moved. This helps to prevent broken links in PC Music Library. For more information about using Creative MediaSource Player/Organizer, refer to its online help.

Where can I get more information on Creative products?

Visit **www.creative.com** and select your region or country for updates and downloads relating to all Creative products.

Safety Advice

The following precautions apply to Zen Micro, its battery and its accessories.

- Store away from direct sunlight.
- Do not expose to heat or fire.
- Avoid using or storing in environments that exceed 45°C (113°F).
- Keep away from excessive moisture.
- Do not subject to excessive force or impact.
- Do not modify or disassemble.
- Avoid contact with metal objects.
- Do not pierce or crush.
- If there is leakage, an unusual odor, discoloration or deformation during use, remove the battery and do not use it again. Clean your hands well before handling food or touching sensitive areas of your body, for example, your eyes.

General Specifications

Size (WxHxD)

- 51 mm (2.0") x 84 mm (3.3") x 19 mm (0.7")

Weight

- 108 g (3.8 oz) with battery

Capacity

- 5 GB

Power Source

- Battery: 1 x Rechargeable Lithium Ion battery
- USB bus powered when connected to a power outlet or powered USB port on a computer

Battery Life

- MP3 128 kbps: Up to 12 hours of continuous playback with a full battery charge

Playback Formats

- MP3: Up to 320 kbps
- WMA: Up to 320 kbps
- WMA with Digital Rights Management (DRM) 9

Recording Formats

- Voice (via built-in microphone): IMA ADPCM (16 kHz, Mono)
- FM Radio: IMA ADPCM (22 kHz, Stereo)

FM Radio

- Stereo and Mono
 - Up to 32 preset stations
 - FM region support
- International:** 87.5 MHz ~ 108.0 MHz, 100 kHz intervals
Japan: 76.0 MHz ~ 90.0 MHz, 100 kHz intervals

MP3 Playback Performance

- Signal-to-Noise Ratio: Up to 98 dB
- Channel Separation: Up to -70 dB
- Frequency Response: 20 Hz ~ 20 kHz
- Harmonic Distortion Output: <0.1%

Connectors

- Headphone jack: 3.5 mm (1/8") stereo minijack, 5~7 mW per channel
- USB 2.0 port: Standard USB mini-B receptacle
- USB 2.0 (High speed)
- USB 1.1 (Full speed)

LCD

- 160 x 104 pixel display with white LED backlight

Firmware Support

- Upgradable via USB (firmware upgrades are available from www.creative.com)

Earphone Specifications

- Frequency Range: 20 Hz ~ 20 KHz
- Sensitivity: 111 dB \pm 5 dB (I/P Level:1 mW)
- Impedance: 32 Ω \pm 15%
- Plug: 3.5 mm (1/8") stereo minijack