

53-1002177-13
14 January 2016

Brocade DCX 8510-4 Backbone

Hardware Installation Guide

BROCADE 

© 2016, Brocade Communications Systems, Inc. All Rights Reserved.

Brocade, Brocade Assurance, the B-wing symbol, ClearLink, DCX, Fabric OS, HyperEdge, ICX, MLX, MyBrocade, OpenScript, VCS, VDX, Vplane, and Vyatta are registered trademarks, and Fabric Vision is a trademark of Brocade Communications Systems, Inc., in the United States and/or in other countries. Other brands, products, or service names mentioned may be trademarks of others.

Notice: This document is for informational purposes only and does not set forth any warranty, expressed or implied, concerning any equipment, equipment feature, or service offered or to be offered by Brocade. Brocade reserves the right to make changes to this document at any time, without notice, and assumes no responsibility for its use. This informational document describes features that may not be currently available. Contact a Brocade sales office for information on feature and product availability. Export of technical data contained in this document may require an export license from the United States government.

The authors and Brocade Communications Systems, Inc. assume no liability or responsibility to any person or entity with respect to the accuracy of this document or any loss, cost, liability, or damages arising from the information contained herein or the computer programs that accompany it.

The product described by this document may contain open source software covered by the GNU General Public License or other open source license agreements. To find out which open source software is included in Brocade products, view the licensing terms applicable to the open source software, and obtain a copy of the programming source code, please visit <http://www.brocade.com/support/oscd>.

Contents

Preface.....	7
Document conventions.....	7
Text formatting conventions.....	7
Command syntax conventions.....	7
Notes, cautions, and warnings.....	8
Brocade resources.....	9
Contacting Brocade Technical Support.....	9
Document feedback.....	10
 About This Document.....	 11
Supported hardware and software.....	11
What's new in this document.....	11
 Product Overview.....	 13
Product features.....	13
Hardware components.....	14
Port side view of the device	15
Nonport side view of the device	16
Supported blades.....	17
Chassis slots numbering.....	19
Port numbering.....	19
High availability.....	20
Reliability.....	21
Serviceability.....	21
Software features.....	22
Security.....	22
Network manageability.....	23
 Device Installation.....	 25
Time and items required.....	25
Preparing for the installation.....	26
Unpacking and installing the device.....	27
Items included with the device.....	28
Providing power to the device.....	29
Cable management.....	29
High-density cabling for the FC8-64 port blade.....	30
Qualified cables for the FC8-64 port blade.....	31
Cable types supported on the FC16-64 port blade.....	32
Installing inter-chassis links (ICLs)	33
 Rack installation options.....	 41
 Initial Configuration.....	 43
Configuring the device.....	43
Establishing a serial connection to the device.....	44

Logging in to the serial console port.....	45
Configuring the IP addresses.....	46
Logging off the serial console port and disconnecting the serial cable.....	47
Establishing an Ethernet connection to the device.....	47
Customizing a switch name.....	48
Customizing a chassis name.....	48
Setting the domain ID.....	48
Setting the date and time.....	49
Setting the date.....	49
Setting the time zone.....	49
Synchronizing local time.....	50
Verifying the PID mode.....	50
Determining installed software licenses.....	51
Installing transceivers and attaching cables.....	51
Installing SFP+ and mSFP transceivers and cables.....	51
Qualified transceivers for the FC16-64 and CR16-x blades.....	52
Installing QSFP transceivers and cables.....	53
Managing cables.....	54
Verifying correct operation and backing up the configuration.....	55
Powering off the chassis.....	56
System Monitoring.....	57
Monitoring overview.....	57
Determining the status of a port, application, or extension blade.....	60
FC8-32E port blade LEDs.....	60
FC8-48E port blade LEDs.....	61
FC8-64 port blade LEDs.....	61
FC16-32 port blade LEDs.....	62
FC16-48 port blade LEDs.....	62
FC16-64 port blade LEDs.....	63
FS8-18 encryption blade LEDs.....	63
FX8-24 extension blade LEDs.....	64
Port, application, and extension blade power LED description.....	64
Port blade status LED description.....	64
FC ports status LED description.....	65
GbE and 10-GbE ports status LED description.....	66
Determining the status of a control processor blade (CP8).....	67
Determining the status of a core switch blade (CR16-4).....	68
Determining the status of a power supply.....	70
Determining the status of a blower assembly.....	71
Determining the status of a WWN card.....	72
Removal and Replacement Procedures.....	75
Introduction.....	75
ESD precautions.....	75
Chassis door removal and replacement.....	76
Time and items required.....	76
Removing a chassis door.....	76
Replacing a chassis door.....	76
Vertical cable management fingers removal and replacement.....	77
Time and items required.....	77
Removing a cable management finger assembly.....	77
Replacing a cable management finger assembly.....	78
Port and application blade removal and replacement.....	78
Time and items required.....	79
Removing a blade.....	79

Replacing a blade.....	81
Blade filler panel removal and replacement.....	82
Blade filler panel removal and replacement.....	82
Removing a filler panel.....	82
Replacing a filler panel.....	83
Control processor blade (CP8) removal and replacement.....	83
Time and items required.....	84
Faulty CP blade indicators.....	84
Recording critical device information.....	85
Power-up procedure.....	86
Power-down procedure.....	88
Verifying operation of the new CP blade.....	89
Completing the replacement.....	92
Core switch blade (CR16-x) removal and replacement.....	93
Time and items required.....	93
Faulty core switch blade indicators.....	93
Removing a core switch blade (CR16-x).....	94
Replacing a core switch blade (CR16-x).....	95
Power supply removal and replacement.....	96
Time and items required.....	96
Identifying power supplies.....	96
Removing a power supply.....	97
Replacing a power supply.....	97
Blower assembly removal and replacement.....	98
Time and items required.....	98
Removing a blower assembly	98
Replacing a blower assembly.....	99
WWN card removal and replacement.....	99
Time and items required.....	100
Using the wwnrecover utility.....	100
Verifying the need for replacement.....	101
Preparing for WWN card replacement.....	102
Hot-swap replacement.....	102
Power-down replacement.....	103
Removing the WWN card and WWN bezel (logo plate).....	105
Transceiver and fiber optic cable removal and replacement.....	107
Time and items required.....	108
Items required.....	108
Removing an SFP+ transceiver.....	108
Replacing an SFP+ transceiver.....	109
Removing and replacing an mSFP optical transceiver and cable.....	110
Removing and replacing a QSFP and cable.....	111
Chassis removal and replacement.....	113
Time and items required.....	113
Faulty chassis indicators.....	114
Recording critical device and SAN information.....	114
Disconnecting from network and fabric.....	118
Removing components from the chassis.....	118
Installing the replacement chassis.....	119
Installing components into the chassis.....	119
Downloading the configuration.....	120
Verifying correct operation of system.....	121
Reconnecting the system to the network and fabric.....	122
Verifying correct configuration of the fabric.....	122
Cable routing table.....	123

Application and Encryption Blades..... 127

Introduction.....	127
FS8-18 blade.....	127
FX8-24 blade.....	127
Port Numbering Templates.....	131
CR16-4 core blade port numbering.....	131
FC8-32E port blade port numbering.....	133
FC8-48E port blade port numbering.....	133
FC8-64 port blade port numbering.....	134
FC16-32 port blade port numbering.....	134
FC16-48 port blade port numbering.....	135
FC16-64 port blade port numbering.....	135
FS8-18 encryption blade port numbering.....	135
FX8-24 extension blade port numbering.....	136
Diagnostics and Troubleshooting.....	137
Introduction.....	137
Obtaining chassis and component status.....	137
Interpreting POST and boot results.....	138
POST.....	138
Boot.....	139
Diagnostics.....	139
Troubleshooting.....	139
Regulatory Statements.....	143
BSMI statement (Taiwan).....	143
Canadian requirements.....	143
CE statement.....	143
China ROHS.....	144
FCC warning (US only).....	144
Germany statement.....	144
KCC statement (Republic of Korea).....	144
VCCI statement.....	145
Brocade DCX 8510 Technical Specifications.....	147
Caution and Danger Notices.....	161
Cautions.....	161
Danger Notices.....	162
Index.....	167

Preface

- Document conventions.....7
- Brocade resources.....9
- Contacting Brocade Technical Support.....9
- Document feedback.....10

Document conventions

The document conventions describe text formatting conventions, command syntax conventions, and important notice formats used in Brocade technical documentation.

Text formatting conventions

Text formatting conventions such as boldface, italic, or Courier font may be used in the flow of the text to highlight specific words or phrases.

Format	Description
bold text	Identifies command names
	Identifies keywords and operands
	Identifies the names of user-manipulated GUI elements
	Identifies text to enter at the GUI
<i>italic text</i>	Identifies emphasis
	Identifies variables
	Identifies document titles
<code>Courier font</code>	Identifies CLI output
	Identifies command syntax examples

Command syntax conventions

Bold and italic text identify command syntax components. Delimiters and operators define groupings of parameters and their logical relationships.

Convention	Description
bold text	Identifies command names, keywords, and command options.
<i>italic text</i>	Identifies a variable.
value	In Fibre Channel products, a fixed value provided as input to a command option is printed in plain text, for example, --show WWN.

Convention	Description
[]	Syntax components displayed within square brackets are optional. Default responses to system prompts are enclosed in square brackets.
{ x y z }	A choice of required parameters is enclosed in curly brackets separated by vertical bars. You must select one of the options. In Fibre Channel products, square brackets may be used instead for this purpose.
x y	A vertical bar separates mutually exclusive elements.
< >	Nonprinting characters, for example, passwords, are enclosed in angle brackets.
...	Repeat the previous element, for example, <i>member[member...]</i> .
\	Indicates a “soft” line break in command examples. If a backslash separates two lines of a command input, enter the entire command at the prompt without the backslash.

Notes, cautions, and warnings

Notes, cautions, and warning statements may be used in this document. They are listed in the order of increasing severity of potential hazards.

NOTE

A Note provides a tip, guidance, or advice, emphasizes important information, or provides a reference to related information.

ATTENTION

An Attention statement indicates a stronger note, for example, to alert you when traffic might be interrupted or the device might reboot.



CAUTION

A Caution statement alerts you to situations that can be potentially hazardous to you or cause damage to hardware, firmware, software, or data.



DANGER

A Danger statement indicates conditions or situations that can be potentially lethal or extremely hazardous to you. Safety labels are also attached directly to products to warn of these conditions or situations.

Brocade resources

Visit the Brocade website to locate related documentation for your product and additional Brocade resources.

You can download additional publications supporting your product at www.brocade.com. Select the Brocade Products tab to locate your product, then click the Brocade product name or image to open the individual product page. The user manuals are available in the resources module at the bottom of the page under the Documentation category.

To get up-to-the-minute information on Brocade products and resources, go to [MyBrocade](#). You can register at no cost to obtain a user ID and password.

Release notes are available on [MyBrocade](#) under Product Downloads.

White papers, online demonstrations, and data sheets are available through the [Brocade website](#).

Contacting Brocade Technical Support

As a Brocade customer, you can contact Brocade Technical Support 24x7 online, by telephone, or by e-mail. Brocade OEM customers contact their OEM/Solutions provider.

Brocade customers

For product support information and the latest information on contacting the Technical Assistance Center, go to <http://www.brocade.com/services-support/index.html>.

If you have purchased Brocade product support directly from Brocade, use one of the following methods to contact the Brocade Technical Assistance Center 24x7.

Online	Telephone	E-mail
Preferred method of contact for non-urgent issues: • My Cases through MyBrocade • Software downloads and licensing tools • Knowledge Base	Required for Sev 1-Critical and Sev 2-High issues: • Continental US: 1-800-752-8061 • Europe, Middle East, Africa, and Asia Pacific: +800-AT FIBREE (+800 28 34 27 33) • For areas unable to access toll free number: +1-408-333-6061 • Toll-free numbers are available in many countries.	support@brocade.com Please include: • Problem summary • Serial number • Installation details • Environment description

Brocade OEM customers

If you have purchased Brocade product support from a Brocade OEM/Solution Provider, contact your OEM/Solution Provider for all of your product support needs.

- OEM/Solution Providers are trained and certified by Brocade to support Brocade® products.
- Brocade provides backline support for issues that cannot be resolved by the OEM/Solution Provider.

- Brocade Supplemental Support augments your existing OEM support contract, providing direct access to Brocade expertise. For more information, contact Brocade or your OEM.
- For questions regarding service levels and response times, contact your OEM/Solution Provider.

Document feedback

To send feedback and report errors in the documentation you can use the feedback form posted with the document or you can e-mail the documentation team.

Quality is our first concern at Brocade and we have made every effort to ensure the accuracy and completeness of this document. However, if you find an error or an omission, or you think that a topic needs further development, we want to hear from you. You can provide feedback in two ways:

- Through the online feedback form in the HTML documents posted on www.brocade.com.
- By sending your feedback to documentation@brocade.com.

Provide the publication title, part number, and as much detail as possible, including the topic heading and page number if applicable, as well as your suggestions for improvement.

About This Document

- [Supported hardware and software](#)..... 11
- [What's new in this document](#)..... 11

Supported hardware and software

This document includes information specific to the Brocade DCX 8510-4 running Brocade Fabric OS version 7.4.0 and later.

What's new in this document

The following changes have been made:

- Added step to record WWN, SKU, and serial number from chassis label on defective chassis to [Installing components into the chassis](#) on page 119.
- Added information to [Using the wwnrecover utility](#) on page 100 and [Hot-swap replacement](#) on page 102 about RASlog message that generates when WWN card is removed.
- Added steps for removing configuration on FX8-25 blade as part of blade removal procedure in [Port and application blade removal and replacement](#) on page 78.

What's new in this document

Product Overview

- [Product features.....](#) 13
- [Hardware components.....](#) 14
- [Supported blades.....](#) 17
- [Chassis slots numbering.....](#) 19
- [Port numbering.....](#) 19
- [High availability.....](#) 20
- [Reliability.....](#) 21
- [Serviceability.....](#) 21
- [Software features.....](#) 22
- [Security.....](#) 22
- [Network manageability.....](#) 23

Product features

Key product features include the following:

- Up to 256 16-Gbps external ports in a single chassis , enabling high density SAN configurations with reduced footprint.
- Support for 2, 4, 8, and 16-Gbps autosensing Fibre Channel ports. Trunking technology groups up to eight ports to create high performance 128-Gbps ISL trunks between switches.
- 10-Gbps FC-type SFPs in 32/48-port 16-Gbps port blades, and 10-GbE SFPs in the FX8-24 application blades. The two types of SFPs are not interchangeable.
- The 10-Gbps ports can be manually configured on only the first eight ports of the 32- and 48-port 16-Gbps port blades.
- Support for many of the application, port blade, and control processor (CP) blades supported in the Brocade DCX family of backbones (with the exception of the Core Switch Blade), thereby providing flexible system configurations and fewer types of new blades.
- Beginning with Fabric OS v7.0.1, up to nine chassis can be connected with the use of 4x16-Gbps quad SFP (QSFP) inter-chassis links (ICLs). Fabric OS v7.0.0 permits up to six chassis to be linked.
- Support for high-performance port blades running at 2, 4, 8, 10, or 16-Gbps, enabling flexible system configuration.
- Redundant and hot-swappable control processor and core switch blades, power supplies, blower assemblies, and WWN cards that enable a high availability platform and enable nondisruptive software upgrades for mission-critical SAN applications.
- Universal ports that self-configure as E_Ports, F_Ports, EX_Ports and M_Ports (mirror ports). 10-Gbps ports are E_Ports only.
- Diagnostic port (D_Port) functionality.
- In-flight data cryptographic (encryption/decryption) and data compression capabilities through the 16-Gbps port blades when configured as ISLs.
- Fibre Channel over IP (FCIP) functionality through the FX8-24 blade.

Hardware components


The device has a modular and scalable mechanical construction that allows a wide range of flexibility in installation, fabric design, and maintenance. The chassis can be mounted with the cables facing the front of the equipment rack or to the rear, and consists of the following:

- Up to four hot-swappable port blade assemblies that can be configured in a single chassis, delivering up to 256 16-Gbps Fibre Channel ports .
- Two slots for control processor blades (CP8):
 - A single active CP8 blade can control all the ports in the chassis.
 - The standby CP8 blade assumes control of the chassis if the active CP fails.
- Two slots for core switch blades (CR16-4):
 - CR16-4 blade interconnects all port blades.
 - Inter-chassis link (ICL) connectors to connect to as many as nine neighboring chassis using Fabric OS v7.0.1 or later. Only six chassis can be connected using Fabric OS v7.0.0.
 - Both CR16-4 blades are active.
- Modular, hot-swappable port blades:
 - 32-port, 8-Gbps blades (FC8-32E)
 - 48-port, 8-Gbps blades (FC8-48E)
 - 64-port, 8-Gbps blades (FC8-64)
 - 32-port, 16-Gbps blades (FC16-32)
 - 48-port, 16-Gbps blades (FC16-48)
 - 64-port, 16-Gbps blades (FC16-64)
- Modular, hot-swappable application blades:
 - FX8-24: 24-port (12 FC, 10 1-GbE, and 2 10-GbE) FCIP extension blade enabling long distance communication over existing IP infrastructure.
- Modular, hot-swappable encryption blades:
 - FS8-18: 16-port, up to 4 blades per chassis, supporting in-flight data cryptographic (encryption/decryption) and data-compression capabilities.
- Modular, hot-swappable field-replaceable units (FRUs):
 - Two blower assemblies.
 - Two power supplies (100-240 VAC autosensing).
 - At 110 VAC (nominal): A minimum of two power supplies is required, regardless of the number of port or application blades. This configuration does not support high availability.
 - 220 VAC (nominal) is recommended for efficiency. A second power supply is required to support high availability.
 - Redundant AC primary power connections ensure high availability. Each power supply has its own connector, so the number of primary power connections is two for optimum efficiency and redundancy.
 - Two WWN cards.
 - Blades use small form-factor pluggable (SFP+, mSFP, and QSFP) optical transceivers.
 - The 8-Gbps SFP+s and mSFPs auto-negotiate at 2, 4, and 8 Gbps.
 - The 10-Gbps speed must be manually set and requires special 10-Gbps FC SFP+ transceivers.
 - The 16-Gbps SFP+ transceivers support speeds of 2, 4, 8, 10, and 16 Gbps.
 - The 16-Gbps QSFPs supported on FC16-64 port blade auto-negotiate at 4, 8, and 16 Gbps.
 - The 16-Gbps QSFPs based inter-chassis link (ICL) on the core blades run at 64-Gbps (four fixed 16-Gbps clustered in a single quad connector and cable).

- Blades are serviced from the port side of the chassis. Blowers, power supplies, and power cables are serviced from the nonport side.
- World Wide Name (WWN) cards on the nonport side, with WWN status LEDs located under the bezel.
- Two vertical cable management finger assemblies and a redesigned chassis door for improved cable management.

Port side view of the device

FIGURE 1 Port side view of the Brocade DCX 8510-4 (sample configuration)




1. Port blade (FC16-32)
2. Core switch blade (CR16-4)
3. Control processor blade (CP8)
4. Exhaust vent

NOTE


Airflow is from the nonport side to the port side and out the exhaust vents. If you use the Port Side Exhaust Kit, the air vents are all on the port side of the chassis.

FIGURE 2 Port side view of the Brocade DCX 8510-4 with the Port Side Exhaust Kit installed (sample configuration)



Nonport side view of the device

The following figure shows a sample configuration of the nonport side view of the Brocade DCX 8510-4.

FIGURE 3 Nonport side view of the Brocade DCX 8510-4 (sample configuration)

1. WWN card bezel (logo plate)
2. Power supply
3. Blower assembly
4. Label with serial number and WWN

Supported blades

The following table summarizes the port, application, control processor, and core switch blades that are supported in the device.

TABLE 1 Blades available for the device

Description	Name	Function
Control processor blade	CP8	The CP8 blade contains the control plane for the chassis. There are two CP8 blades for redundancy. This control processor blade is compatible with the Brocade DCX 8510-8, Brocade DCX 8510-4, Brocade DCX-4S, and Brocade DCX platforms.

TABLE 1 Blades available for the device (Continued)

Description	Name	Function
Core switch blade	CR16-4	The CR16-4 blade contains the ASICs for switching between port blades. Every port blade connects to each core switch blade. There can be up to 256 16-Gbps or 8-Gbps total ports for port blades. Each core switch blade connects to 128 backplane ports. Core switch blades have additional front port connectivity to connect multiple chassis and backplane connections for the storage server blade. This core switch blade is compatible only with the Brocade DCX 8510-4 and requires specific type of QSFP transceivers.
32-port 8-Gbps port blade	FC8-32E	A 32-port Brocade port blade supporting 2, 4, and 8 Gbps Fibre Channel port speeds. This port blade is compatible with the Brocade DCX 8510-8 and Brocade DCX 8510-4. This blade requires Fabric OS v7.0.1 or later to run in this chassis.
48-port 8-Gbps port blade	FC8-48E	A 48-port Brocade port blade supporting 2, 4, and 8 Gbps Fibre Channel port speeds. This port blade is compatible with the Brocade DCX 8510-8 and Brocade DCX 8510-4. This blade requires Fabric OS v7.0.1 or later to run in this chassis.
64-port 8-Gbps port blade	FC8-64	A 64-port Brocade port blade supporting 2, 4, and 8 Gbps port speeds with mSFPs. This port blade is compatible with the Brocade DCX 8510-8, Brocade DCX 8510-4, Brocade DCX-4S, and Brocade DCX platforms.
32-port 16-Gbps port blade	FC16-32	A 32-port Brocade port blade supporting 2, 4, 8, 10, and 16 Gbps Fibre Channel port speeds. The blade also supports port-based in-flight encryption/decryption and compression/decompression. This port blade is compatible with the Brocade DCX 8510-8 and Brocade DCX 8510-4 and requires Fabric OS v7.0.0 or later to run in this chassis.
48-port 16-Gbps port blade	FC16-48	A 48-port Brocade port blade supporting 2, 4, 8, 10, and 16 Gbps Fibre Channel port speeds. The blade also supports port-based in-flight encryption/decryption and compression/decompression. This port blade is compatible with the Brocade DCX 8510-8 and Brocade DCX 8510-4 and requires Fabric OS v7.0.0 or later to run in this chassis.
64-port 16-Gbps port blade	FC16-64	A 64-port Brocade port blade supporting 4, 8, and 16-Gbps Fibre Channel port speeds. The blade also supports port-based in-flight encryption/decryption and compression/decompression. This port blade is compatible with the Brocade DCX 8510-8 and Brocade DCX 8510-4 and requires Fabric OS v7.3.0 or later to run in this chassis. Requires specific type of QSFP transceivers and those are not the same as used in the core blades.
Storage encryption blade	FS8-18	The FS8-18 blade enables data cryptographic (encryption/decryption) and data-compression capabilities for data-at-rest. It has 16 Fibre Channel optical SFP ports. This application blade is compatible with the Brocade DCX 8510-8, Brocade DCX 8510-4, Brocade DCX-4S, and Brocade DCX platforms and requires Fabric OS v7.0.0 or later to run in the 8510-4 and 8510-8 chassis.

TABLE 1 Blades available for the device (Continued)

Description	Name	Function
FCIP extension blade	FX8-24	The FX8-24 blade enables FCIP functionality over existing IP infrastructure. It has 12 FC ports, 10 1-GbE ports, and two 10-GbE ports available. This application blade is compatible with the Brocade DCX 8510-8, Brocade DCX 8510-4, Brocade DCX-4S, and Brocade DCX platforms and requires Fabric OS v7.0.0 or later to run in the DCX 8510-4 and DCX 8510-8 chassis.

Chassis slots numbering

The chassis slots are numbered and used for the following purpose.

- Numbered 1 through 8, from bottom to top when facing the port side of the Brocade DCX 8510-4.
- Slots 4 and 5 can be used only to install the control processor blades (CP8).
- Slots 3 and 6 can be used only to install the core switch blades (CR16-4).
- Slots 1-2 and 7-8 can be filled with port, application, or encryption blades.
- Unused slots must be filled with blade filler panels to maintain adequate cooling.

Port numbering

The device uses the following port numbering method.

TABLE 2 Port numbering and trunking port groups

Blade	Port numbering	Trunking port groups
CR16-4 core blade	0 through 7 from right to left.	• Trunk group 0: QSFP ports 0-3 • Trunk group 1: QSFP ports 4-7 Each connector is a group of four 16-Gbps ports. For supported QSFPs, refer to Qualified transceivers for the FC16-64 and CR16-x blades on page 52
FC8-32E port blade	• 0 through 15 from right to left on the lower set of ports • 16 through 31 from right to left on the upper set of ports.	Trunk groups: 0-7, 8-15, 16-23, and 24-31.

NOTE

Individual FC ports within the same QSFP port cannot form a trunk. A trunk has to comprise of individual FC ports from different consecutive QSFP ports. Only four FC ports from consecutive QSFP ports can form a trunk in Brocade DCX 8510-4

TABLE 2 Port numbering and trunking port groups (Continued)

Blade	Port numbering	Trunking port groups
FC8-48E port blade	0 through 23 from right to left on the lower set of ports 24 through 47 from right to left on the upper set of ports.	Trunk groups: 0-7, 8-15, 16-23, 24-31, 32-39, and 40-47.
FC8-64 port blade	0 through 31 from right to left on the lower set of ports. 32 through 63 from right to left on the upper set of ports.	Trunk groups: 0-7, 8-15, 16-23, 24-31, 32-39, 40-47, 48-55, and 56-63.
FC16-32 port blade	0 through 15 from right to left on the lower set of ports. 16 through 31 from right to left on the upper set of ports.	Trunk groups: 0-7, 8-15, 16-23, and 24-31.
FC16-48 port blade	0 through 23 from right to left on the lower set of ports. 24 through 47 from right to left on the upper set of ports.	Trunk groups: 0-7, 8-15, 16-23, 24-31, 32-39, and 40-47.
FC16-64 port blade	0 through 63 from right to left.	Trunk groups: 0-7, 8-15, 16-23, 24-31, 32-39, 40-47, 48-55, and 56-63. These are QSFP ports 0-15. For supported QSFPs, refer to Qualified transceivers for the FC16-64 and CR16-x blades on page 52.
FS8-18 blade	16 FC ports: 0 through 15 from right to left. - Two 10/100/1000 BaseT ports: GE0 and GE1 from right to left.	- Trunk group 0: FC ports 0-7 - Trunk group 1: FC ports 8-15
FX8-24 blade	- FC ports labeled FC on the front panel: 0 through 11 in two horizontal rows of six ports starting from the lower right and upper right in the right group of 12 ports. - Two 10-GbE ports labeled 10GE on the front panel: 0 and 1 in the lower row to the left of the FC ports. 1-GbE ports labeled GE on the front panel: 0 through 9 in both rows to the left of the FC and 10GE ports.	- Trunk group 0: FC ports 0-1 - Trunk group 1: FC ports 6-7 - Trunk group 2: FC ports 2-5 and 8-11

High availability

The following features contribute to the high availability the device:

- Redundant, hot-swappable FRUs, including blades, power supplies, blowers, and WWN cards
- Enhanced data integrity on all data paths
- Fabric Shortest Path First (FSPF) rerouting around failed links
- Integration with Simple Network Management Protocol (SNMP) managers
- Automatic control processor failover

- Nondisruptive "hot" software code loads and activation
- Easy configuration, save, and restore

The high availability software architecture provides a common framework for all applications that reside on the system, allowing global and local states to be maintained through any component failure. High availability elements consist of the High Availability Manager, the heartbeat, the fault/health framework, the replicated database, initialization, and software upgrade.

The High Availability Manager controls access to the standby control processor, facilitates software upgrades, prevents extraneous CP failover activity, closes and flushes streams, provides flow control and message buffering, and supports a centralized active and standby state.

Reliability

The device uses the following error detection and correction mechanisms to ensure reliability of data:

- Error Detection and Correction over main control processor memory.
- Error Detection and Correction mechanism, which checks for encoder errors and fault isolation (EDFI), such as cyclic redundancy checking (CRC), parity checking, checksum, and illegal address checking.
- Power-on self-test (POST).
- Dual control processors that enable hot, nondisruptive fast firmware upgrades.
- One serial port and two Ethernet ports (on each control processor) for management and for service. Offline control processor diagnostics and remote diagnostics simplify troubleshooting. The standby control processor monitors diagnostics to ensure the system is operational should a failover be necessary.
- Bus monitoring and control of blades and other field-replaceable units (FRUs).

Serviceability

The device provides the following features to enhance and ensure serviceability:

- Modular design with hot-swappable components.
- Flash memory that stores two firmware images per control processor.
- USB port on control processor blades for most tasks that formerly required an FTP/SCP server, including software and firmware upgrades.
- Nonvolatile random-access memory (NVRAM), containing the OEM serial number, Brocade serial number, revision information, and part number information.
- Background health-check daemon.
- Memory scrubber, self test, and bus ping to determine if a bus is not functioning.
- RASlog messages.
- SMI-S compliant.
- Hardware and software watchdog timers.
- Status LEDs.
- Predictive diagnostics analysis through Fabric Watch.
- SNMP (including version 3) integration with higher-layer managers.

Software features

The Fabric OS allows any Fibre Channel-compliant device to attach to the switches as long as it conforms to the device login, name service, and related Fibre Channel standards. Each operating environment requires that a Fibre Channel host bus adapter (HBA) be available with a standards-compliant driver for correct interface to the fabric.

Fabric OS consists of a set of embedded applications running on top of an embedded Linux operating system kernel. Some of these applications include:

- Name server
- Alias server
- Zone server
- Simple Network Management Protocol (SNMP) agent
- SMI-S compliant API
- Syslog auditing
- Reliable Commit Service (RCS)
- NTP
- Tasks to manage address assignment, routing, link initialization, fabric initialization, link shutdown, the device shutdown, and the user interface

Security

The following list highlights some of the key security features available in the device and in other Brocade enterprise-class products running Fabric OS 7.0.1 or later. For details, contact your device supplier and refer to the Brocade White Paper, "The Growing Need for Security in Storage Area Networks."

- DH-CHAP
- SSHv2 (using AES, 3DES, RSA)
- HTTPS (using AES)
- SNMPv3
- FC-SP
- Secure RPC
- Secure file copy (SCP)
- Telnet disable
- Telnet timeout
- IP filters (block listeners)
- Secure passwords (centralized control through RADIUS/CHAP)
- Multiple user accounts (MUAs) (Up to 255)
- Role-based access controls (RBACs)
- Administrative domains/Virtual fabrics
- Boot PROM password reset
- Password hardening policies
- Up front login in Web Tools
- Login banner
- Monitoring of attempted security breaches (through audit logging)
- Monitoring of attempted security breaches (through Fabric Watch Security Class)
- Fibre Channel security policies: DCC and SCC
- Trusted Switch (FCS) for central security management

- Management access controls (SNMPv3, Telnet, FTP, serial port, front panel)
- Hardware-enforced zoning by WWN, domain/port ID, or both
- Default zoning
- RSCN suppression and aggregation
- Configurable RSCN suppression by port
- NTPv3 (to synchronize timestamps)
- Event auditing
- Change tracking
- Firmware change alerts in Fabric Manager
- Persistent port disable
- Persistent domain ID
- E_Port disable

Network manageability

The device has a single domain and is managed as a single element with Brocade Network Advisor. The device responds to its own IP address and appears as a separate entity to the Telnet protocol and SNMP.

All management interfaces, such as Telnet, Web Tools, standards-compliant SMI-S, and Management Server, support a "port N within blade M" naming scheme.

The device supports SNMPv1 and SNMPv3. When SNMP devices send SNMP messages to a management console running SAN management software, the information is stored in a management information base (MIB). Fabric OS v7.0.0 and later supports the latest Fibre Alliance Fibre Channel Management (FCMGMT) and Storage Management Initiative (SMI) MIBs, which allow common information necessary for management software to provide information to a SAN administrator. Refer to the *Fabric OS MIB Reference* for additional MIB information.

Device Installation

- Time and items required..... 25
- Preparing for the installation..... 26
- Unpacking and installing the device..... 27
- Items included with the device..... 28
- Providing power to the device..... 29
- Cable management..... 29

Time and items required

You can set up and install the device in the following ways:

- As a standalone unit on a flat surface.
- In a 19-inch Electronic Industries Association (EIA) cabinet, using a Brocade DCX 8510-4, Brocade DCX-4S Rack Mount Kit either a 27-31 inch or 18-24 inch kit depending on the rack used.
- In a chassis with the Port Side Exhaust Kit that is provided with the device in an approved rack.
- In a mid-mount telecommunications (Telco) rack, using the Mid-Mount Rack Kit available from your device supplier.

This chapter describes how to set up the device as a standalone unit. For rack-mount installation instructions, refer to the appropriate manual as described in the following table.

The following table describes the main installation and setup tasks, the estimated time required for each, and the items required to complete the task for a device that is fully populated with FC16-64 port blades. Configurations with fewer blades or ports require less time. These time estimates assume a prepared installation site and appropriate power and network connectivity.

TABLE 3 Installation tasks, time, and items required

Installation task	Time estimate	Items required
Site preparation and unpacking the device	30 minutes	1/2-in. socket wrench (to remove pallet bolts). Pallet jack. Hydraulic lift or assisted lift, able to raise to a minimum of 140 cm (55 in.), with a minimum capacity of 115 kg (254 lb). To know the weight of your device fully populated with the required port blades, refer to the Brocade DCX 8510 Technical Specifications on page 147.
Installing rack mount kit or Port Side Exhaust Kit	30 minutes	Refer to the one or more of the following documents:
Mounting and securing the device in rack	30 minutes	• Port Side Exhaust Kit Installation Procedure • Mid-Mount Rack Kit (Backbone) Installation Procedure • 27-31 Inch Rail Rack Mount (Backbone) Kit Installation Procedure

TABLE 3 Installation tasks, time, and items required (Continued)

Installation task	Time estimate	Items required
Installing power cables and powering on the device	20 minutes	Power cables (provided in the device accessories kit).
Establishing serial connection, logging in to the device, and configuring IP addresses	20 minutes	Serial cable (provided in the accessory kit). Workstation computer with a serial port or terminal server port and a terminal emulator application (such as HyperTerminal). Ethernet IP addresses for the device and for both control processor blades: total three addresses.
Installing an Ethernet cable, opening a Telnet session, and configuring the device domain ID, date and time, and additional system parameters. Verify and back up configuration.	20 minutes	Ethernet cabling (optional) for Telnet access. Refer to the <i>Fabric OS Administrator's Guide</i> .
Installing transceivers as needed	20-30 minutes or longer if you are using high-density port blades.	SFP+, mSFP, and QSFP optical transceivers as needed.
Attaching fiber-optic cables, cable ties, and cable guides	2-3 hours	Fiber-optic cables and cable ties.

Preparing for the installation

Read the following sections before preparing to install the device.

- [Caution and Danger Notices](#) on page 161.
- [Brocade DCX 8510 Technical Specifications](#) on page 147; power supply specifications section and plan for meeting the power supply standards based on your device configuration.
- [Managing cables](#) on page 54 and plan for cable management.

The following steps are required to ensure correct installation and operation.

1. Ensure that the following amount of space is available in the rack.

- 9 rack units (9U) high.
- 8 rack units (8U) high, if you do not use the *Port Side Exhaust Kit*.
- 61.29 cm (24.09 inch) deep.
- 43.74 cm (17.22 inch) wide.

1U is equal to 4.45 cm (1.75 inches).

Plan to install the device with the nonport side facing the air-intake aisle. The device can be installed facing either direction, if serviceability and cooling requirements are met.

2. Ensure that dedicated electrical branch circuits with the following characteristics are available:
 - 200 - 240 VAC, 50-60 Hz, two branch circuits are recommended for high availability and maximum blade usage when configured with 192 or more 16-Gbps ports.
 - Two cables for 200 - 240 VAC service

- Protected by a circuit breaker in accordance with local electrical codes
- Supply circuit, line fusing, and wire size adequate to the electrical rating on the chassis nameplate
- Location close to the chassis and easily accessible
- Grounded outlets installed by a licensed electrician and compatible with the power cords

**CAUTION**

Use a separate branch circuit for each power cord, which provides redundancy in case one of the circuits fails.

3. Plan for cable management before installing the chassis.

Cables can be managed in a variety of ways, such as by routing cables below the chassis, to either side of the chassis, through cable channels on the sides of the cabinet, or by using patch panels.

4. Ensure that the following is available for configuration of the device:
 - Workstation with an installed terminal emulator, such as HyperTerminal
 - Serial cable (provided)
 - Three Ethernet cables (including one spare)
 - Access to an FTP server for backing up the switch configuration or collecting **supportsave** output data (optional)
 - A Brocade USB stick for collecting **supportsave** output data (optional)
 - Transceivers (copper and optical) and compatible cables
5. Ensure that the air intake and exhaust vents have a minimum of 5.1 cm (2 in.) of airspace.
6. Ensure that the air temperature on the air intake side is less than 40°C (104°F) during operation.

Unpacking and installing the device

Use the following procedure to unpack and install your device.

**DANGER**

A fully populated chassis (four FC16-64 port cards, 256 ports) weighs approximately 69.5 kg (153 lbs) and requires a hydraulic or assisted lift to install it.

1. Unpack the device.
 - a) Cut the bands that encircle the packaging.
 - b) Remove the lid and the kits and foam from the top of the chassis.
 - c) Lift the cardboard box off the chassis and remove the plastic bag from around the chassis. Save the packing materials for use when returning the old chassis.
 - d) Leave the chassis on top of the plastic shipping tray if the chassis must be transported to the installation location.

NOTE

The device packaging does not incorporate a wood pallet and pallet brackets. The chassis sits on top of a plastic shipping tray.

2. Use a pallet jack or other assisted lift to transport the new chassis to the installation area. Doorways must be wider than 36 in. (91 cm) to accommodate the chassis.
3. Remove the following items from the chassis and set aside.
 - *Brocade DCX 8510-4 Port Side Exhaust Kit* (if ordered)
 - Accessory kit

- Packing foam
 - Antistatic plastic
4. Remove the chassis door from the device.
 5. Remove the vertical cable management fingers.
 6. Use a lift to raise the chassis to the correct level. If installing the chassis in a cabinet, follow the instructions provided by the rack kit manufacturer.
 7. If applicable, lock the wheels of the lift.
 8. Gently slide the chassis onto the final installation surface, ensuring that it remains supported during the transfer.
 9. Ensure that the chassis is oriented so that the nonport side has access to intake air (cool).
 10. Reinstall the vertical cable management fingers.
 11. Reinstall the door. The door must be installed to meet EMI compliance.

Items included with the device

The device ships with the following:

- The chassis, populated with:
 - Control processor blades (CP8)
 - Core switch blades (CR16-4)
 - Port blades, application blades, and encryption blades (included based on customer specification)
 - Blade slot filler panels (for slots not filled by blades)
 - Port Side Exhaust Kit (included based on customer specification)
 - WWN cards
 - WWN bezel (logo plate)
 - Power supplies
 - Power supply filler panel (included if there is only one power supply)
 - Blower assemblies
 - Cable management finger assemblies
 - Chassis door
- Accessory kit containing the following items:
 - A QuickStart Guide
 - ESD grounding strap
 - USB device
 - RS-232 serial cable. The RS-232 cable has an adapter at one end that can be removed to provide an RJ-45 style connector.
- Rack mount kit (as ordered) with instructions

Order the Brocade-branded optical transceivers (SFP+, mSFP, and QSFP). The device supports SWL, LWL, and ELWL transceivers. The mSFPs and QSFPs are SWL transceivers only.

NOTE

For information about the SFP+, mSFP, and QSFP transceivers that are qualified for the device, refer to [Transceiver and fiber optic cable removal and replacement](#) on page 107.

Providing power to the device

For this procedure, refer to the power supply specifications section in the [Brocade DCX 8510 Technical Specifications](#) on page 147 for power supply requirements of your chassis.

Complete the following steps to provide power to the chassis.



DANGER

Make sure that the power source circuits are properly grounded, then use the power cord supplied with the device to connect it to the power source.

1. Connect the two AC power cords to the two power supplies.
2. Connect the power cords to a power source with voltage of 200 to 240 VAC, 47 to 63 Hz or optionally to a power source with voltage of 110 to 120 VAC, 47 to 63 Hz. If using any application blades in the chassis, the 200 to 240 VAC option is necessary to achieve power supply redundancy.

NOTE

Use of the high-voltage line (200 to 240 VAC) is highly recommended because of better power-conversion efficiency. For a fully-loaded Brocade DCX 8510-4, 200 to 240 VAC is required for high availability (ability to hot swap a failed power supply without affecting system operation).

3. Switch the AC power switches on the power supplies to I. The AC power switches light green when switched on and power is supplied.

The device performs a power-on self-test (POST) each time it is powered on. POST takes approximately 10 minutes and is complete when the indicator light activity displays the operational state. You can bypass POST by using the **fastBoot** command. You can also disable POST for successive reboots on the device using the **diagDisablePost** command.

NOTE

Do not connect the switch to the network until the IP addresses are configured.

For information about LED patterns, refer to [System Monitoring](#) on page 57.

Cable management

The cable management finger assemblies are attached to the chassis on either side of the port side of the chassis and allow for simple cable management. The cable management finger assemblies can be installed without service disruption.

Route the cables across in front of the blades to keep LEDs visible. Leave at least one meter of slack for each fiber-optic cable to provide room to remove and replace blades.

NOTE

The minimum radius to which a 50 micron cable can be bent under full tensile load is 5.1 cm (2 in.). For a cable under no tensile load, that minimum is 3.0 cm (1.2 in.).



CAUTION

Before plugging a cable into any port, be sure to discharge the voltage stored on the cable by touching the electrical contacts to ground surface.

Cables can be organized and managed in a variety of ways, for example, using cable channels on the sides of the cabinet or patch panels to minimize cable management. Following is a list of recommendations:

NOTE

You should not use tie wraps with optical cables because they are easily overtightened and can damage the optic fibers.

- Plan for rack space required for cable management before installing the switch.
- Leave at least 1 m (3.28 ft) of slack for each port cable. This provides room to remove and replace the switch, allows for inadvertent movement of the rack, and helps prevent the cables from being bent to less than the minimum bend radius.
- If you are using Brocade ISL Trunking, consider grouping cables by trunking groups. The cables used in trunking groups must meet specific requirements, as described in the *Fabric OS Administrator's Guide*.
- For easier maintenance, label the fiber-optic cables and record the devices to which they are connected.
- Keep LEDs visible by routing port cables and other cables away from the LEDs.
- Use Velcro® type straps to secure and organize fiber-optic cables.


NOTE

Do not route the cables in front of the air exhaust vent, which is located at the top of the port side of the chassis.

If you are using the Port Side Exhaust Kit with your Brocade DCX 8510-4, there is also an exhaust vent at the bottom of the port side of the chassis. Use the cable management finger assemblies to keep the cables away from this exhaust vent as well.

High-density cabling for the FC8-64 port blade

The FC8-64 high density port blade cannot use the standard LC cables because the pitch between optics in the new mini-SFP (mSFP) transceiver is smaller than in standard SFPs. Patch cables and panels can be used to attach standard size cabling to the blade if necessary. The following figure illustrates the mSFP to SFP patch cable. Refer to "Best Practices Guide: High Density Cable Management Solutions" (available at <http://www.brocade.com>) for cable management guidelines for high-density port solutions, and cable and patch panel part numbers.

FIGURE 4 Cable design for the mSFP patch cables for the FC8-64 high density port blade

1. mSFP connector
2. Duplex clip (black)
3. 6 mm cable
4. SFP connector

Note that the duplex clip on the mSFP end of the cable is black for easier recognition. For a listing of the qualified mSFP optical cables for the FC8-64 port blade, refer to [Qualified cables for the FC8-64 port blade](#) on page 31.

If ISL Trunking is in use, group the cables by trunking group. The ports are color-coded to indicate which ports can be used in the same ISL Trunking group: eight ports marked with solid black ovals alternate with eight ports marked with oval outlines.

Qualified cables for the FC8-64 port blade

The following table lists the third-party cables that have been qualified for use with the mSFP transceivers in the FC8-64 high density port blade.

TABLE 4 Qualified cables for mSFP connections for the FC8-64 high density port blade

Description	Length	Corning part number	Molex part number	Amphenol part number
Patch cables - mSFP to LC		S50502S5120XXXM (XXX = length)		943-99865-1XXXX (XXXX = length)
mSFP LC - standard LC, duplex, multi-mode, OM3, 50/125	1 m	S50502S5120001M	106273-0525	943-99865-10001
mSFP LC - standard LC, duplex, multi-mode, OM3, 50/125	2 m	S50502S5120002M	106273-0526	943-99865-10002
mSFP LC - standard LC, duplex, multi-mode, OM3, 50/125	3 m	S50502S5120003M	106273-0527	943-99865-10003
mSFP LC - standard LC, duplex, multi-mode, OM3, 50/125	5 m	S50502S5120005M	106273-0528	943-99865-10005

TABLE 4 Qualified cables for mSFP connections for the FC8-64 high density port blade (Continued)


Description	Length	Corning part number	Molex part number	Amphenol part number
mSFP LC - standard LC, duplex, multi-mode, OM3, 50/125	10 m	S50502S5120010M	106273-0529	943-99865-10010
Patch cables - mSFP to mSFP		S5S502S5120XXXM (XXX = length)		943-99866-1XXXX (XXXX = length)
mSFP LC - mSFP LC, duplex, multi-mode, OM3, 50/125	1 m	S5S502S5120001M	106273-0560	943-99866-10001
mSFP LC - mSFP LC, duplex, multi-mode, OM3, 50/125	2 m	S5S502S5120002M	106273-0561	943-99866-10002
mSFP LC - mSFP LC, duplex, multi-mode, OM3, 50/125	3 m	S5S502S5120003M	106273-0562	943-99866-10003
mSFP LC - mSFP LC, duplex, multi-mode, OM3, 50/125	5 m	S5S502S5120005M	106273-0563	943-99866-10005
mSFP LC - mSFP LC, duplex, multi-mode, OM3, 50/125	10 m	S5S502S5120010M	106273-0564	943-99866-10010
Trunk cables - mSFP to MTP		tbd		
mSFP LC - MTP-female, 12 fiber, 12" breakout, OM3, 50/125		H93S5TE9-BMU-XXXM (XXX = length)		943-99867-1XXXX (XXXX = length)
mSFP LC - MTP-female, 12 fiber, 6" breakout, OM3, 50/125	2 m		106272-0327	
mSFP LC - MTP-female, 24 fiber, 12" breakout, OM3, 50/125	2 m		106272-0328	
Bag of clips (quantity 64)		TRIGGER-BP-NP	n/a	n/a

Cable types supported on the FC16-64 port blade


The FC16-64 port blade supports simplified cable management using QSFP cables. Each QSFP cable has four links internally that run at 16-Gbps speed and the cables come in specific predetermined fixed lengths.

The FC16-64 port blade supports the following types of cables:

- QSFP to QSFP standard cables
- QSFP-SFP/LC Break-out/Split-out cables

FIGURE 5 QSFP to QSFP standard cables

1. QSFP MTP connector

FIGURE 6 QSFP-SFP/LC Break-out/Split-out cables

1. QSFP MTP connector

2. SFP+ LC connectors

With the support for breakout cables, each port can be in a different mode. Inside the single physical QSFP port, individual ports can be configured as an E_Port, F_Port or EX_Port. Also, each internal port inside a single physical QSFP can be part of different Logical Switches.

With the support for breakout cables, trunking can be enabled on ports in a QSFP port group, with ports connected through breakout cables at the other end.

Installing inter-chassis links (ICLs)

Follow these guidelines when installing ICLs using fiber optic cables and transceivers. Refer to the *Fabric OS Administrator's Guide* for the configuration procedure and requirements. Refer to "Removing and replacing a QSFP and cable" in this hardware installation guide to install cables and transceivers.

- The QSFP ports on the core switch blades can be used only with an inter-chassis link (ICL) license. After the addition or removal of a license, the license enforcement is performed on the ports only when the **portdisable** and **portenable** commands are issued on the ports. An ICL license must be installed on all Brocade Backbones forming the ICL connection. Up to nine neighboring Brocade DCX 8510 series chassis can be connected with the MTP cables.
- An off-the-shelf MTP cable up to 100 meters can be used as an ICL cable when using the standard SWL optics. The Brocade 2 km QSFP with LWL optics has an integrated 3 meter single-mode pigtail with a male MTP connector for connectivity to a patch panel or female terminated MTP patch cable to achieve up to 2 km distances. Refer to [Using Brocade 2 km LWL QSFPs](#) on page 38 for more information.
- Brocade supports fully populating a switch with ICL connections using a mixture of 50 and 100 meter SWL optics and 2 km LWL optics.
- Following are examples of maximum ICL port connections in a DCX 8510 when using 2 km LWL QSFPs. Note that limits are based on the number of buffers. If using ICLs for shorter distances, more

ICL ports can be connected. There are no limitations on number of ICL ports if all ICL distances are a few hundred meters.

- Up to 10 ICL ports can be used for 2 km distances when 16 buffer credits are configured per virtual channel.
- Up to 16 ICL ports can be used for 1,375 meter distances when 11 buffer credits are configured per virtual channel.

The following table describes the connector port LED patterns and the recommended actions for those patterns.

TABLE 5 ICL QSFP connector port LEDs

LED purpose	Color	Status	Recommended action
QSFP connector status	No light (LED is off)	No QSFP module, all four QSFP ports are disabled.	No action is required if QSFP not present or verify that the QSFP is fully inserted.
	Steady amber	QSFP module is in, all four ports have no signal/no sync.	No action required if QSFP only is installed or ensure that the cable is properly connected. If the LED remains amber, consult the device supplier.
	Blinking amber	Port is disabled or faulted, FC link activity, segmented, loopback mode, also during transition between MTP cable insertion and confirmation.	Check for console messages or wait for all four ports to come online.
	Steady green	Both ends of MTP cable are in and all ports are online. Full link is established.	No action required.

The following figures illustrate types of MTP cables and transceivers:

- Separate MTP cable and transceiver. The transceiver is inserted into the blade port connector and the cable plugs into a QSFP on the other end of the ICL.




FIGURE 7 MTP cable and transceiver

NOTE

If the fiber optic cables are not connected to transceivers, make sure the rubber gaskets are plugged into the transceivers.

- Brocade 2 km LWL QSFP transceiver with integrated MTP cable. The transceiver is inserted into the blade port connector and integrated cable plugs into a QSFP on the other end of the ICL, a patch panel, or a patch cable.





FIGURE 8 2 km QSFP with integrated cable

- A third type of transceiver has a pull-tab to aid in removing the transceiver from the port connector (like shown in previous illustration), but has a separate MTP cable that plugs into the transceiver.

The QSFP connectors on the core blades are labeled by trunk group (trunking is optional) for ease of installation.

Possible ICL configurations


The following figures show acceptable cabling configurations for the ICL feature. The recommended topology is the parallel type where there are four QSFP cables connected between any pair of Brocade DCX 8510 series chassis. The full-mesh configuration is also supported. Each of two cores in one chassis should be interconnected with each of two cores in the second chassis. This provides for inter-chassis link (ICL) trunking between chassis, ensuring redundancy. Parallel connections between core blades are recommended.

FIGURE 9 QSFP cable connections for Brocade DCX 8510 chassis (sample configuration)

1. Chassis 1 - DCX 8510-8


2. Chassis 2 - DCX 8510-4

The DCX 8510 chassis can be connected in a core/edge configuration. The following figure shows two core and four edge chassis. Although DCX 8510-8 chassis are shown in the figure, the chassis can be either DCX 8510-4 or DCX 8510-8. The cabling scheme should follow the parallel example shown in the previous figure. Each line in the example actually represents four cables running between the chassis.

FIGURE 10 DCX 8510 core/edge ICL topology

The DCX 8510 chassis can also be connected in a full mesh configuration as shown in the following figure. Although DCX 8510-8 chassis are shown in the figure, the chassis can be either DCX 8510-4 or DCX 8510-8. In this example, the trunk groups are shown in color.

FIGURE 11 DCX 8510 full mesh ICL topology



Using Brocade 2 km LWL QSFPs

Up to 10 ICL ports using the 2km ICL QSFP are supported in a DCX 8510 backbone switch at the two km distance, which requires configuring 16 buffer credit per virtual channel. The 10 ICL limit is based on the number of buffers. If the 2km QSFPs are used at shorter distances, then more ICLs can be used.

The Brocade 2 km LWL QSFP, is a hot-swappable, low-voltage (3.3 V) digital diagnostic optical transceiver that supports high-speed serial links over parallel single-mode optical fibers at signaling rates up to 4×14.025 Gbps. The QSFP is integrated with a 3-meter ribbon fiber cable with a male MTP 1 x 12 connector. The QSFP supports 2 km link length on parallel single-mode fiber.




FIGURE 12 2 km LWL QSFP transceiver with integrated cable

Following are cabling options and recommendations:

- Connect the 3 meter integrated single mode transceiver cable directly to a female-terminated connector in a patch panel or patch cable using a key-up/key-down MPO/MTP coupler.
- Use female-to-female patch cable with the following specifications:
 - Single-mode (not OM3 MMF or OMM MMF)
 - MTP/MPO 1 x 12 fiber
 - MTP female angled polished connector (APC)
 - Key-up/key-down connectors for polarity

FIGURE 13 Female-to-female patch cable for QFSP connections



Rack installation options

The following rack mount kits can be used for the Brocade DCX 8510-4.

- Mid-Mount Rack Kit (Backbone) - XBR-DCX4S-0126
- Port Side Exhaust Kit (27-31 inch) - XBR-DCX4S-0121
- Port Side Exhaust Kit (18-24 inch) - XBR-DCX4S-0130

When installing this device in a rack, observe the following requirements:

- Ensure that the air intake and exhaust vents have a minimum of 5.1 cm (2 in.) of airspace.
- Ensure that the air temperature on the air intake side is less than 40°C (104°F) during operation.

Initial Configuration

• Configuring the device.....	43
• Establishing a serial connection to the device.....	44
• Logging in to the serial console port.....	45
• Configuring the IP addresses.....	46
• Logging off the serial console port and disconnecting the serial cable.....	47
• Establishing an Ethernet connection to the device.....	47
• Customizing a switch name.....	48
• Customizing a chassis name.....	48
• Setting the domain ID.....	48
• Setting the date and time.....	49
• Verifying the PID mode.....	50
• Determining installed software licenses.....	51
• Installing transceivers and attaching cables.....	51
• Managing cables.....	54
• Verifying correct operation and backing up the configuration.....	55
• Powering off the chassis.....	56

Configuring the device

The device must be configured before it is connected to the fabric, and all of the configuration commands must be entered through the active CP blade. The device configuration includes the following parameters:

- IP address and subnet mask for the chassis
- IP addresses, host names, subnet masks, and gateway addresses for both control processor (CP) blades
- Switch name
- Domain ID for the device (optional)
- WWN for the device

The device WWN is initially set by the factory to match the license ID (which is based on the chassis serial number). The WWN can be changed but the license ID cannot be modified.


The configuration information is mirrored to the standby CP blade, which allows the current configuration to remain available even if the active CP blade fails. The configuration information for the device is stored in the WWN cards and the flash memory of the CP blades. The configuration can be backed up to a workstation (uploaded) and then downloaded to the active CP blade if necessary.

NOTE

If the Brocade FS8-18 encryption blade is installed, refer to the *Fabric OS Encryption Administrator's Guide* for the procedures to configure the encryption functions.

The following figure illustrates the flow of the basic configuration tasks.

FIGURE 14 Configuration tasks



Establishing a serial connection to the device

To establish a serial connection to the console port on the device, complete the following steps.

1. Verify that the device is powered on and that POST is complete by verifying that all power LED indicators on the port, control processor, and core switch blades display a steady green light.
2. Remove the shipping cap from the CONSOLE port on the active CP. Use the serial cable provided with the device to connect the CONSOLE port on the active CP to a computer workstation. The active CP blade is indicated by an illuminated (blue) LED.

NOTE

The CONSOLE port is intended primarily for the initial setting of the IP address and for service purposes.

3. Access the device using a terminal emulator application (such as HyperTerminal in a Windows environment or tip in a UNIX environment).
4. Disable any serial communication programs running on the workstation (such as synchronization programs).
5. Open a terminal emulator application (such as HyperTerminal on a PC, or term, tip, or kermi in a UNIX environment), and configure the application as follows:
 - In a Windows environment:

Parameter	Value
Bits per second	9600
Data bits	8
Parity	None
Stop bits	1
Flow control	None

NOTE

Flow control is not supported on the serial consoles when attached to remote terminal servers and must be disabled to ensure proper operation.

- In a UNIX environment, enter the following string at the prompt:

```
tip /dev/ttyb -9600
```

If ttyb is already in use, use ttya instead and enter the following string at the prompt:

```
tip /dev/ttya -9600
```

When the terminal emulator application stops reporting information, press **Enter**. You receive the following login prompt:

```
CP0 Console Login:
```

6. Proceed to the next task.

Logging in to the serial console port

To log in to the device through the serial connection, follow these steps.

1. Log in to the device as **admin**. The default password is *password*. At the initial login, you are prompted to enter new admin and user passwords. Make sure to write down the new passwords and keep this information in a secure location.

```
Fabric OS (swDir)
swDir login: admin
Password:
Please change your passwords now.
Use Control-C to exit or press 'Enter' key to proceed.
```

```
swDir:admin>
```

2. (Optional) Modify passwords. To skip modifying the password, press **Ctrl+C**.

NOTE

Passwords can be 8 to 40 characters long. They must begin with an alphabetic character. They can include numeric characters, the period (.), and the underscore (_) only. Passwords are case-sensitive, and they are not displayed when you enter them on the command line. For more information on passwords, refer to the *Fabric OS Administrator's Guide*.

Configuring the IP addresses

The device requires three IP addresses, which are configured using the **ipAddrSet** command. IP addresses are required for both CP blades (CP0 and CP1) and for the chassis management IP (shown as SWITCH under the **ipAddrShow** command) in the device.

NOTE

The default IP addresses and host names for the device are:

- 10.77.77.75 / CP0 (the CP blade in slot 4 at the time of configuration)
 - 10.77.77.74 / CP1 (the CP blade in slot 5 at the time of configuration)
-

NOTE

Resetting an IP address while the device has active IP traffic or has management and monitoring tools running, such as DCFM, Fabric Watch, and SNMP, can cause traffic to be interrupted or stopped.

Complete the following steps to set the IP addresses for the device.

1. Log in to the active CP as admin using the serial cable connection.
2. Set up the device IP address by entering the **ipaddrset -chassis** command:

```
swDir:admin> ipAddrSet -chassis
```

Enter the information at the prompts. Specify the **-chassis** IP address. The **-sw 0** IP address is not valid on this chassis.

NOTE

The addresses 10.0.0.0 through 10.0.0.255 are reserved and used internally by the device. External IPs must not use these addresses.

3. Set up the CP0 IP address by entering the **ipaddrset -cp 0** command:

```
swDir:admin> ipAddrSet -cp 0
```

Enter the information at the prompts.

4. Set up the CP1 IP address by entering the **ipaddrset -cp 1** command:

```
swDir:admin> ipAddrSet -cp 1
```

Enter the information at the prompts.

This is a sample IP configuration:

```
swDir:admin> ipaddrset -chassis
Ethernet IP Address [0.0.0.0]: 192.168.1.1
Ethernet Subnetmask [0.0.0.0]: 255.255.255.0
Fibre Channel IP Address [0.0.0.0]:
Fibre Channel Subnetmask [0.0.0.0]:
Issuing gratuitous ARP...Done.
Committing configuration...Done.

swDir:admin>
ipaddrset -cp 0
Host Name [cp0]:
Ethernet IP Address [10.77.77.75]: 192.168.1.2
Ethernet Subnetmask [0.0.0.0]: 255.255.255.0
Gateway IP Address [0.0.0.0]: 192.168.1.254
IP address is being changed...Done.
Committing configuration...Done.
swDir:admin> ipaddrset -cp 1
Host Name [cp1]:
Ethernet IP Address [10.77.77.74]: 192.168.1.3
Ethernet Subnetmask [0.0.0.0]: 255.255.255.0
Gateway IP Address [0.0.0.0]: 192.168.1.254
IP address of remote CP is being changed...Done.
Committing configuration...Done.
```

Logging off the serial console port and disconnecting the serial cable

You can use the serial port to monitor error messages through the serial connection. If the serial port is no longer required, use the **logout** command to log out of the serial console, remove the serial cable, and replace the plug in the serial port.

Establishing an Ethernet connection to the device

After using a serial connection to configure the IP addresses for the device, you can connect the active CP blade to the local area network (LAN).

NOTE

Connecting the CP blades to a private network or VLAN is recommended.

By establishing an Ethernet connection, you can complete the device configuration using a serial session, Telnet, or management applications, such as Web Tools or Brocade Network Advisor.

Perform the following steps to establish an Ethernet connection to the device.

1. Remove the shipping plug from the Ethernet port on the active CP blade.
2. Insert one end of an Ethernet cable into the Ethernet port.
3. Connect the other end to an Ethernet 10/100/1000 BaseT LAN.

The device can be accessed through a remote connection using the command line via Telnet or any of the management tools, such as Web Tools or Brocade Network Advisor.

4. To complete any additional device configuration procedures through a Telnet session, log in to the device by Telnet, using the **admin** login. The default password is *password*.

Customizing a switch name

The switch name of the device can be up to 30 characters long and must begin with a letter. It can include letters, numbers, hyphens, and underscore characters.

NOTE

Changing the name causes a domain address format RSCN to be issued.

1. Enter **switchName** followed by the new name in double quotes.

```
swDir:admin> switchName "swModularSwitch5"
Committing configuration...
Done.
swModularSwitch5:admin>
```

2. Record the new name for reference.

Customizing a chassis name

The chassis name of the device can be up to 15 characters long; can include letters, numbers, hyphens, and underscore characters; and must begin with a letter.

1. Enter **chassisName** followed by the new name in double quotes.

```
switch:admin> chassisname
"DCX8510_chassis"
Committing configuration...
Done.
```

2. Enter **chassisName** by itself to show the name.

```
switch:admin> chassisname
DCX8510_chassis
```

3. Record the new name for reference.

Setting the domain ID

Each switch in the fabric must have a unique domain ID. The domain ID can be manually set through the **configure** command or can be automatically set. The default domain ID for the device is 1. Use the **fabricShow** command to view the already assigned domain IDs.

1. Enter **switchDisable** to disable the device.
2. Enter **configure**.
3. Enter **y** at the *Fabric parameters* prompt:

```
Fabric parameters (yes, y, no, n): [no] y
```

4. Enter a unique domain ID:

```
Domain: (1.239) [1] 3
```

5. Complete the remaining prompts or press **Ctrl+D** to accept the settings and exit.
6. Enter **switchEnable** to re-enable the device.

Setting the date and time

The date and time settings are used for logging events. Switch operation does not depend on the date and time; a switch with an incorrect date and time value still functions properly. However, because the date and time are used for logging, error detection, and troubleshooting, they should be set correctly.

Setting the date

To set the date, follow these steps.

1. If necessary, log on to the device by Telnet, using the **admin** account.

The default password is password.

2. Enter the **date** command, using the following syntax:

```
date "mmddHHMMyy"
```

The values are:

- mm is the month; valid values are 01 through 12.
- dd is the date; valid values are 01 through 31.
- HH is the hour; valid values are 00 through 23.
- MM is minutes; valid values are 00 through 59.
- yy is the year; valid values are 00 through 99 (values greater than 69 are interpreted as 1970 through 1999, and values less than 70 are interpreted as 2000 through 2069).

```
switch:admin> date
Fri Sep 28 17:01:48 UTC 2010
switch:admin> date "0927123010"
Thu Sep 27 12:30:00 UTC 2010
switch:admin>
```

Setting the time zone

You must perform the procedure on *all* chassis for which the time zone must be set. Because the value is written to nonvolatile memory, you only need to set the time zone once on each switch.

Use one of the two following procedures to set the time zone.

The following procedure describes how to set the current time zone using `timezone_fmt` mode to Central Standard time.

1. Log in to the switch using the default password, which is password.
2. Enter the **tsTimeZone** command as follows:

```
switch:admin> tstimezone [--interactive]/ [, timezone_fmt]
```

Use **timezone_fmt** to set the time zone by Country/City or by time zone ID, such as PST.

The following example shows how to change the time zone to US/Central.

```
switch:admin> tstimezone
Time Zone : US/Pacific
switch:admin> tstimezone US/Central
switch:admin> tstimezone
Time Zone : US/Central
```

The following procedure describes how to set the current time zone using interactive mode to Pacific Standard Time.

1. Enter the **tsTimeZone** command as follows:

```
switch:admin> tstimezone --interactive
```

You are prompted to select a general location.
Please identify a location so that time zone rules can be set correctly.
2. Enter the appropriate number or **Ctrl+D** to quit.
3. At the prompt, select a country location.
4. At the prompt, enter the appropriate number to specify the time zone region or **Ctrl+D** to quit.

Synchronizing local time

To synchronize the local time of the principal or primary switch with that of an external NTP server, follow these steps.

1. If necessary, log on to the switch by Telnet, using the **admin** account.
2. Enter the **tsClockServer** command:

```
switch:admin> tsclockserver
"<ntp1;ntp2>"
```

In this syntax, *ntp1* is the IP address or DNS name of the first NTP server, which the switch must be able to access. The variable *ntp2* is the second NTP server and is optional. The operand "<ntp1;ntp2>" is optional; by default, this value is LOCL, which uses the local clock of the principal or primary switch as the clock server.

The **tsClockServer** command accepts multiple server addresses in IPv4, IPv6, or DNS name formats. When multiple NTP server addresses are passed, **tsClockServer** sets the first obtainable address as the active NTP server. The rest will be stored as backup servers that can take over if the active NTP server fails. The principal or primary FCS switch synchronizes its time with the NTP server every 64 seconds.

```
switch:admin> tsclockserver
LOCL
switch:admin> tsclockserver "132.163.135.131"

switch:admin> tsclockserver
132.163.135.131
switch:admin>
```

The following example shows how to set up more than one NTP server using a DNS name:

```
switch:admin> tsclockserver "10.32.170.1;10.32.170.2;ntp.localdomain.net"
Updating Clock Server configuration...done.
Updated with the NTP servers
Changes to the clock server value on the principal or primary FCS switch are
propagated to all switches in the fabric
```

Verifying the PID mode

Before connecting the device to the fabric, verify that the WWN-based persistent port identifier (PID) feature on the device matches the other switches in the fabric. This parameter must be identical for all switches in the fabric and is set using the **configure** command as shown in the following example:

```
switch:admin>configure
```

```

Configure...
Fabric parameters (yes, y, no, n): [no] y
Domain: (1..239) [1]
Enable a 256 Area Limit
  (0 = No,
   1 = Zero Based Area Assignment,
   2 = Port Based Area Assignment): (0..2) [0] 1
WWN Based persistent PID (yes, y, no, n): [no] yes
<command output truncated>

```

You can check the PID setting using the **configshow** command as in the following example. You can use the `| grep -i pid` qualifier to pinpoint the PID information.

```

switch:admin> configshow | grep -i pid
fabric.ops.mode.pidFormat:1
fabric.wwnPidMode:1

```

The 1 indicates that the WWN-based persistent PID feature is enabled. The default value is 0 for disabled.

Determining installed software licenses

Depending on the vendor agreement, certain licenses are factory installed on the device. To determine which licenses are enabled, use the **licenseShow** command.

```

swDir:admin> licenseshow
AAbbccDDeeFFeeGG:
  Web license
  Zoning license
  Extended Fabric license
  Fabric Watch license
  Performance Monitor license
  Trunking license
  Security license

```

In this example, the license key is AAbbccDDeeFFeeGG. Keep a copy of the license key for reference.

The 64-bit chassis ID is required to obtain and activate licenses for the device. The chassis ID is available through the **licenseIdShow** command. The **licenseShow** and **licenseIdShow** commands must be entered on the active CP blade. Refer to the *Fabric OS Administrator's Guide* for more information.

Installing transceivers and attaching cables

The following two sets of steps cover the installation of transceivers and cables for most SFPs and for QSFPs.

For a list of qualified transceivers for FC16-64 and CR16-x blades, refer to [Qualified transceivers for FC16-64 and CR16-x blades](#) on page 52

Installing SFP+ and mSFP transceivers and cables

Complete the following steps to install SFP-type optical transceivers.

NOTE

mSFP transceivers are compatible only with the FC8-64 port blade. While they will fit in other blades, this configuration is unsupported and will generate an error.

1. Add the optical transceivers and cables to the Fibre Channel ports.

The ports are color-coded to indicate which can be used in the same port group for trunking (trunking port groups can be up to 8 ports). The ports and cables used in trunking groups must meet specific requirements. Refer to the *Fabric OS Administrator's Guide*.

2. Position one of the optical transceivers so that the key is oriented correctly to the port. Insert the transceiver into the port until it is firmly seated and the latching mechanism clicks.

Transceivers are keyed so that they can only be inserted with the correct orientation. If a transceiver does not slide in easily, ensure that it is correctly oriented.

3. Position a cable so that the key (the ridge on one side of the cable connector) is aligned with the slot in the transceiver. Insert the cable into the transceiver until the latching mechanism clicks.

Cables are keyed so that they can be inserted in only one way. If a cable does not slide in easily, ensure that it is correctly oriented.

4. Repeat steps 1 through 3 for the remaining ports.
5. Organize the cables. Refer to [Managing cables](#) on page 54.
6. Verify the device and port status using the **switchShow** command.
7. Verify fabric connectivity using the **fabricShow** command.

Qualified transceivers for the FC16-64 and CR16-x blades

The following table shows the qualified transceivers for the FC16-64 port blade and the CR16-4/8 core blades.

TABLE 6 Qualified transceivers for FC16-64 port blade and the CR16-x core blades

Brocade part number	Part type	Cable length	Port speeds	Supported blades
57-1000310-01	QSFP transceiver with integrated 3 m optical cable	Supports 2 km	16 Gbps	CR16-4/8 See Note below.
57-1000294-01	QSFP transceiver	100 m OM4	Auto-negotiable 4-, 8-, and 16-Gbps	FC16-64 See Note below.
57-1000267-01	QSFP transceiver	100 m OM4	Only fixed 16-Gbps	CR16-4/8
57-0000090-01	QSFP transceiver	50 m OM3	Only fixed 16-Gbps	CR16-4/8

NOTE

The QSFP transceivers supported on FC16-64 port blade are not interchangeable with QSFP transceivers supported on the CR16-4/8 core blades.

Installing QSFP transceivers and cables

Follow these steps to install the QSFPs and cables in the FC16-64 port blades and the 16-Gbps core blades. In the core blades, these transceivers and cables are used to form the inter-chassis links (ICLs) with neighboring Backbones. The transceivers should be installed in the blades before connecting the cables. As each QSFP contains four 16-Gbps ports, be aware that any problems with one port could affect all four ports in the quad if the QSFP must be replaced.

NOTE

Even though the installation and removal procedures are the same for QSFP ports in FC16-64 port blades and the core blades, the physical QSFP transceivers designed for FC16-64 are not compatible with the QSFP transceivers designed for the core blades, and are not interchangeable.

1. Position one of the QSFP transceivers so that the key is oriented correctly to the port. Insert the transceiver into the port until it is firmly seated.

Transceivers are keyed so that they can only be inserted with the correct orientation. If a transceiver does not slide in easily, ensure that it is correctly oriented.

When the transceiver is correctly seated, the status LED will flash amber several times and then turn solid amber.

2. Remove the protective cap from the special QSFP cable and insert it into the transceiver until it is firmly seated.

The cables are also keyed to fit into the transceivers correctly.

When the cable is correctly seated, the status LED will change from amber to green.

Repeat steps 1 and 2 for the remaining QSFP ports.

3. Organize the cables. Refer to information on managing cables in this installation guide.
4. Verify the device and connector and port status using the **switchShow -qsfp** command.

NOTE

The following example is from a DCX chassis with four slots for port blades and a core blade installed in slot 3. Some details for a chassis with eight slots for ports blades will display differently, but the reported information for the QSFPs will be similar.

QSFP 7 (ports 3/28-3/31, Index 748-751) in the following example shows the results for a connected QSFP.

```
switch:FID128:admin> switchshow -qsfp
switchName:      switch_name
switchType:      142.0
switchState:     Online
switchMode:      Native
switchRole:      Subordinate
switchDomain:    75
switchId:        fffc4b
switchWwn:       10:00:00:05:1e:4f:eb:00
zoning:          ON (zoning_name
)
switchBeacon:    OFF
FC Router:       OFF
Allow XISL Use:  OFF
LS Attributes:   [FID: 128, Base Switch: No, Default Switch: Yes, Address Mode 0]
Index Slot Port QSFP  Address Media  Speed  State      Proto
=====
256   3    0    0    -----  id    16G   No_SigDet  FC
257   3    1    0    -----  id    16G   No_SigDet  FC
258   3    2    0    -----  id    16G   No_SigDet  FC
259   3    3    0    -----  id    16G   No_SigDet  FC
260   3    4    1    -----  --    16G   No_Module  FC
```

```

261 3 5 1 ----- -- 16G No_Module FC
262 3 6 1 ----- -- 16G No_Module FC
263 3 7 1 ----- -- 16G No_Module FC
264 3 8 2 ----- -- 16G No_Module FC
265 3 9 2 ----- -- 16G No_Module FC
266 3 10 2 ----- -- 16G No_Module FC
267 3 11 2 ----- -- 16G No_Module FC
268 3 12 3 ----- -- 16G No_Module FC
269 3 13 3 ----- -- 16G No_Module FC
270 3 14 3 ----- -- 16G No_Module FC
271 3 15 3 ----- -- 16G No_Module FC
736 3 16 4 ----- -- 16G No_Module FC
737 3 17 4 ----- -- 16G No_Module FC
738 3 18 4 ----- -- 16G No_Module FC
739 3 19 4 ----- -- 16G No_Module FC
740 3 20 5 ----- -- 16G No_Module FC
741 3 21 5 ----- -- 16G No_Module FC
742 3 22 5 ----- -- 16G No_Module FC
743 3 23 5 ----- -- 16G No_Module FC
744 3 24 6 ----- -- 16G No_Module FC
745 3 25 6 ----- -- 16G No_Module FC
746 3 26 6 ----- -- 16G No_Module FC
747 3 27 6 ----- -- 16G No_Module FC
748 3 28 7 ----- id 16G OnLine FC E-Port 10:00:00:05:1e:39:e4:5a trunkmaster
name
(Trunk_master)
749 3 29 7 ----- id 16G Online FC E-Port 10:00:00:05:1e:39:e4:5a trunkmaster
name
(Trunk_master)
750 3 30 7 ----- id 16G Online FC E-Port 10:00:00:05:1e:39:e4:5a trunkmaster
name
(Trunk_master)
751 3 31 7 ----- id 16G Online FC E-Port 10:00:00:05:1e:39:e4:5a trunkmaster
name
(Trunk_master)

```

NOTE

The State reported for an unconnected QSFP (shown QSFP 0 and Ports 0-3 in the example) is No_SigDet. This is different from the State of No_Synch that is reported for regular SFPs that are unconnected.

Managing cables

Cables can be organized and managed in a variety of ways, for example, using cable channels on the port sides of the cabinet or patch panels to minimize cable management.

With the horizontal orientation of the blades in the Brocade DCX 8510-4, a pair of vertical cable management finger assemblies are provided to keep the cables from hanging down in front of other blades.

Following is a list of recommendations:

- Leave at least 1 m (3.28 ft) of slack for each port cable. This provides room to remove and replace the device, allows for inadvertent movement of the rack, and helps prevent the cables from being bent to less than the minimum bend radius.
- The minimum bend radius should be no smaller than ten times the cable radius. The minimum radius to which a 50 micron cable can be bent under full tensile load is 5.1 cm (2 in.). For a cable under no tensile load, that minimum is 3.0 cm (1.2 in.).
- If ISL Trunking is in use, group the cables by trunking group. The ports are color-coded to indicate which ports can be used in the same ISL Trunking group: eight ports marked with solid black ovals alternate with eight ports marked with oval outlines.

- Generally, Velcro® type cable restraints are recommended to avoid creating sharp bends in the cables. Do not use tie wraps with optical cables because they are easily overtightened and can damage the optic fibers.
- For easier maintenance, label the fiber-optic cables and record the devices to which they are connected.
- Do not route cables in front of the air exhaust vents.
- Keep LEDs visible by routing port cables and other cables away from the LEDs.

NOTE

Refer to "Cabling Best Practices" (available at <http://www.brocade.com>) for cable management guidelines.

For the procedure to install the ICL cables, refer to [Installing inter-chassis links \(ICLs\)](#) on page 33

Verifying correct operation and backing up the configuration

To verify correct operation and back up the device configuration, follow these steps. For information about LED patterns, refer to information on determining the status of extension, application, or port blades in the "System Monitoring" section.

Complete the following steps to back up the configuration for the device.

1. Check the LEDs to verify that all components are functional.
2. If necessary, log in to the switch by Telnet, using the **admin** account.
3. Verify the correct operation of the device by entering the **switchShow** command from the workstation. This command provides information about switch and port status.
4. Verify the correct operation of the device in the fabric by entering the **fabricShow** command from the workstation. This command provides general information about the fabric.
5. To back up the configuration, run the following two steps:
 - a) Enter the **configupload -vf** command. This command uploads the device's virtual fabric data.
 - b) Enter the **configupload** command. This command uploads the device configuration.
6. You can run the following commands to see additional configuration information that you can copy to a file to save:

- **configShow**
- **ipaddrShow**
- **licenseShow**
- **switchShow**

Alternatively, you can save the configuration file to a Brocade USB device by using the **usbstorage** command.

Observe the following notes about configuration data:

- Passwords are not saved in the configuration file, and are not uploaded during a configuration upload.
- It is recommended that the configuration be backed up on a regular basis to ensure that a complete configuration is available for downloading to a replacement chassis.

Powering off the chassis

Perform the following steps to power off the chassis.

1. Shut down the chassis using the **sysShutdown** command.

```
switch::admin> sysshutdown
This command will shutdown the operating systems on your switch.
You are required to power-cycle the switch in order to restore operation.
Are you sure you want to shutdown the switch [y/n]?y
HA is disabled
Stopping blade 1
Shutting down the blade....
Stopping blade 2
Shutting down the blade....
Stopping blade 8
Shutting down the blade....
Broadcast message from root (pts/1) Tue Aug 23 14:23:06 2010...
The system is going down for system halt NOW !!
```

2. Power off the chassis by flipping the AC power switches on the power supplies to O (LEDs inside AC power switches should turn off). To maintain the ground connections, leave power cords connected to the power supplies and to the electrical outlets.

System Monitoring

- Monitoring overview..... 57
- Determining the status of a port, application, or extension blade..... 60
- Determining the status of a control processor blade (CP8)..... 67
- Determining the status of a core switch blade (CR16-4)..... 68
- Determining the status of a power supply..... 70
- Determining the status of a blower assembly..... 71
- Determining the status of a WWN card..... 72

Monitoring overview

The Brocade DCX 8510-4 is engineered for reliability and requires no routine operational steps or maintenance. This chapter provides information about determining the status of each component using LEDs and CLI commands. Refer to the *Web Tools Administrator's Guide* and the *Fabric OS Administrator's Guide* for additional information.

There are two commands that can be especially helpful in monitoring the health of the Brocade DCX 8510-4. These commands are **switchShow** and **chassisShow**.

Note in the **switchShow** command the new switchType for the Brocade DCX 8510-4 as well as the 16-Gbps speed identification for capable ports. The output has been truncated to reduce information duplication.

```
DCX-4_130:admin> switchshow
switchName:      DCX-4_130
switchType:      121.3_
switchState:     Online
switchMode:      Native
switchRole:      Principal
switchDomain:     130
switchId:        fffc82
switchWwn:       10:00:00:05:33:03:2c:00
zoning:          ON (BB)
switchBeacon:    OFF
FC Router:       ON
FC Router BB Fabric ID: 10
Address Mode:    0
Index Slot Port Address Media Speed State Proto
=====
0 1 0 820000 id N8 Online FC F-Port 10:00:00:05:1e:f8:a0:b4
1 1 1 820100 id N8 Online FC F-Port 10:00:00:05:33:26:0e:65
2 1 2 820200 id N8 Online FC F-Port 10:00:00:05:33:48:5e:f5
3 1 3 820300 id N8 Online FC F-Port 10:00:00:05:1e:f8:a0:b3
4 1 4 820400 id N8 Online FC F-Port 10:00:00:05:33:26:10:15
5 1 5 820500 id N8 Online FC F-Port 10:00:00:05:1e:f8:a0:b1
6 1 6 820600 id N8 Online FC F-Port 10:00:00:05:33:48:5e:d0
7 1 7 820700 id N8 Online FC F-Port 10:00:00:05:33:26:df:6b
8 1 8 820800 id N8 Online FC F-Port 10:00:00:05:33:26:df:6a
9 1 9 820900 id N8 Online FC F-Port 10:00:00:05:33:48:6b:ea
10 1 10 820a00 id N8 Online FC F-Port 10:00:00:05:33:26:10:28
11 1 11 820b00 id N8 Online FC F-Port 10:00:00:05:33:26:10:73
12 1 12 820c00 id N8 Online FC F-Port 10:00:00:05:33:48:5e:d1
13 1 13 820d00 id N8 Online FC F-Port 10:00:00:05:33:26:10:29
14 1 14 820e00 id N8 Online FC F-Port 10:00:00:05:1e:f9:72:47
15 1 15 820f00 id N8 Online FC F-Port 10:00:00:05:33:26:0e:8a
16 1 16 821000 id N8 Online FC F-Port 10:00:00:05:33:26:0e:8b
17 1 17 821100 id N8 Online FC F-Port 10:00:00:05:33:48:6b:eb
```

```

18 1 18 821200 id N8 Online FC F-Port 10:00:00:05:1e:f9:72:46
19 1 19 821300 id N8 Online FC F-Port 10:00:00:05:33:26:10:14
20 1 20 821400 id N8 Online FC F-Port 10:00:00:05:33:26:0e:64
21 1 21 821500 id N8 Online FC F-Port 10:00:00:05:33:26:10:72
22 1 22 821600 id N8 Online FC F-Port 10:00:00:05:33:48:5e:f4
23 1 23 821700 id N8 Online FC F-Port 10:00:00:05:1e:f8:a0:b2
24 1 24 821800 -- N16 No_Module FC
25 1 25 821900 -- N16 No_Module FC
26 1 26 821a00 -- N16 No_Module FC
27 1 27 821b00 -- N16 No_Module FC
28 1 28 821c00 id N8 No_Light FC
29 1 29 821d00 id N8 No_Light FC
30 1 30 821e00 id N8 No_Light FC
31 1 31 821f00 id N8 No_Light FC
32 1 32 822000 id N8 No_Light FC
33 1 33 822100 id N8 No_Light FC
34 1 34 822200 id N8 No_Light FC
35 1 35 822300 id N8 No_Light FC
36 1 36 822400 id N8 No_Light FC
37 1 37 822500 id N8 No_Light FC
38 1 38 822600 id N8 No_Light FC
39 1 39 822700 id N8 No_Light FC
40 1 40 822800 id N8 No_Light FC
41 1 41 822900 id N8 No_Light FC
42 1 42 822a00 id N8 No_Light FC
43 1 43 822b00 id N8 No_Light FC
44 1 44 822c00 id N8 No_Light FC
45 1 45 822d00 -- N16 No_Module FC
46 1 46 822e00 -- N16 No_Module FC
47 1 47 822f00 -- N16 No_Module FC
256 3 0 ----- id 16G No_SigDet FC
257 3 1 ----- id 16G No_SigDet FC
258 3 2 ----- id 16G No_SigDet FC
259 3 3 ----- id 16G No_SigDet FC
260 3 4 ----- id 16G No_SigDet FC
261 3 5 ----- id 16G No_SigDet FC
262 3 6 ----- id 16G No_SigDet FC
263 3 7 ----- id 16G No_SigDet FC
264 3 8 ----- id 16G No_SigDet FC
265 3 9 ----- id 16G No_SigDet FC
<output truncated>
DCX-4_130:admin>

```

Note in the **chassisShow** command the Chassis Family designation for the Brocade DCX 8510-4 along with specific information about every field-replaceable unit in the chassis.

```

DCX-4 130:admin> chassisshow
Chassis Family: DCX8510-4
Chassis Backplane Revision: 2
SW BLADE Slot: 1
Header Version: 2
Power Consume Factor: -160
Power Usage (Watts): -106
Factory Part Num: 60-1002144-02
Factory Serial Num: BQB0345F00X
Manufacture: Day: 19 Month: 11 Year: 2010
Update: Day: 29 Month: 3 Year: 2011
Time Alive: 32 days
Time Awake: 0 days
CP BLADE Slot: 4
Header Version: 2
Power Consume Factor: -40
Factory Part Num: 60-1000376-08
Factory Serial Num: AHJ0420F08K
Manufacture: Day: 21 Month: 5 Year: 2010
Update: Day: 29 Month: 3 Year: 2011
Time Alive: 229 days
Time Awake: 0 days
CP BLADE Slot: 5
Header Version: 2
Power Consume Factor: -40
Factory Part Num: 60-1000376-08
Factory Serial Num: AHJ0420F086
Manufacture: Day: 21 Month: 5 Year: 2010
Update: Day: 29 Month: 3 Year: 2011
Time Alive: 229 days

```

```

Time Awake:                0 days
CORE BLADE Slot: 3
Header Version:            2
Power Consume Factor:      -135
Power Usage (Watts):       -88
Factory Part Num:          60-1002142-02
Factory Serial Num:        BQD0344F01K
Manufacture:               Day: 18 Month: 11 Year: 2010
Update:                   Day: 29 Month: 3 Year: 2011
Time Alive:                47 days
Time Awake:                0 days
CORE BLADE Slot: 6
Header Version:            2
Power Consume Factor:      -135
Power Usage (Watts):       -87
Factory Part Num:          60-1002099-01
Factory Serial Num:        BQD0337F00A
Manufacture:               Day: 16 Month: 9 Year: 2010
Update:                   Day: 29 Month: 3 Year: 2011
Time Alive:                77 days
Time Awake:                0 days
AP BLADE Slot: 7
Header Version:            2
Power Consume Factor:      -250
Factory Part Num:          60-1001157-21
Factory Serial Num:        ATM0431F008
Manufacture:               Day: 20 Month: 9 Year: 2010
Update:                   Day: 29 Month: 3 Year: 2011
Time Alive:                4 days
Time Awake:                0 days
SW BLADE Slot: 8
Header Version:            2
Power Consume Factor:      -140
Power Usage (Watts):       -95
Factory Part Num:          60-1002145-02
Factory Serial Num:        BQA0344F00S
Manufacture:               Day: 6 Month: 11 Year: 2010
Update:                   Day: 29 Month: 3 Year: 2011
Time Alive:                32 days
Time Awake:                0 days
POWER SUPPLY Unit: 1
Header Version:            2
Power Consume Factor:      2000
Factory Part Num:          23-0000067-01
Factory Serial Num:        AGC2M03FR4P
Manufacture:               Day: 7 Month: 6 Year: 2010
Update:                   Day: 29 Month: 3 Year: 2011
Time Alive:                229 days
Time Awake:                0 days
POWER SUPPLY Unit: 2
Header Version:            2
Power Consume Factor:      2000
Factory Part Num:          23-0000067-01
Factory Serial Num:        AGC2M03FR7T
Manufacture:               Day: 7 Month: 6 Year: 2010
Update:                   Day: 29 Month: 3 Year: 2011
Time Alive:                221 days
Time Awake:                0 days
FAN Unit: 1
Header Version:            2
Power Consume Factor:      -126
Factory Part Num:          60-1000384-09
Factory Serial Num:        AGB0623F0AM
Manufacture:               Day: 7 Month: 6 Year: 2010
Update:                   Day: 29 Month: 3 Year: 2011
Time Alive:                229 days
Time Awake:                0 days
FAN Unit: 2
Header Version:            2
Power Consume Factor:      -126
Factory Part Num:          60-1000384-09
Factory Serial Num:        AGB0623F0AK
Manufacture:               Day: 7 Month: 6 Year: 2010
Update:                   Day: 29 Month: 3 Year: 2011
Time Alive:                229 days
Time Awake:                0 days
WWN Unit: 1
Header Version:            2

```

```
Power Consume Factor: -1
Factory Part Num: 60-1000888-05
Factory Serial Num: ANN2524F01N
Manufacture: Day: 7 Month: 6 Year: 2010
Update: Day: 29 Month: 3 Year: 2011
Time Alive: 229 days
Time Awake: 0 days
ID: BRD0000CA
Part Num: SLKWRM0000X4S
WWN Unit: 2
Header Version: 2
Power Consume Factor: -1
Factory Part Num: 60-1000888-05
Factory Serial Num: ANQ0417F03P
Manufacture: Day: 7 Month: 6 Year: 2010
Update: Day: 29 Month: 3 Year: 2011
Time Alive: 229 days
Time Awake: 0 days
Chassis Factory Serial Num: ANP2523F00E
DCX-4_130:admin>
```

Determining the status of a port, application, or extension blade

Use the following procedure to determine the status of a blade.


1. Check the LEDs on the blade.

The LED patterns may temporarily change during POST and other diagnostic tests. For information about how to interpret the LED patterns, refer to the table following the blade descriptions.

2. Check the blade status by entering **slotShow**.

FC8-32E port blade LEDs


FIGURE 15 FC8-32E port blade LEDs



1. Blade status LED
2. Blade power LED
3. Fibre Channel port
4. Port status LED

FC8-48E port blade LEDs


FIGURE 16 FC8-48E port blade LEDs



1. Blade status LED
2. Blade power LED
3. Fibre Channel port
4. Port status LED

FC8-64 port blade LEDs


FIGURE 17 FC8-64 port blade LEDs



1. Blade status LED
2. Blade power LED
3. Fibre Channel port
4. Port status LED

FC16-32 port blade LEDs


FIGURE 18 FC16-32 port blade LEDs



1. Blade status LED
2. Blade power LED
3. Fibre Channel port
4. Port status LED

FC16-48 port blade LEDs


FIGURE 19 FC16-48 port blade LEDs



1. Blade status LED
2. Blade power LED
3. Fibre Channel port
4. Port status LED

FC16-64 port blade LEDs


FIGURE 20 FC16-64 port blade LEDs



1. Blade status LED
2. Blade power LED
3. Port status LED for FC port 36
4. QSFP port 9; FC ports 36-39 (right to left)

FS8-18 encryption blade LEDs


FIGURE 21 FS8-18 encryption blade LEDs



1. Blade status LED
2. Blade power LED
3. Fibre Channel port
4. Port status LED

FX8-24 extension blade LEDs

FIGURE 22 FX8-24 extension blade LEDs



- 1. Blade status LED
- 2. Blade power LED
- 3. GbE (GE) port 6
- 4. Port status LED for GbE port 6
- 5. GbE (XGE) port 0
- 6. Port status LED for 10-GbE port 0
- 7. Port map

Port, application, and extension blade power LED description

The following table describes the port, application, and extension blade power LED patterns and the recommended actions for those patterns.

TABLE 7 Port, application, and extension blade power LED description

LED purpose	Color	Status	Recommended action
Power LED	Steady green	Blade is enabled.	No action required.
	No light (LED is off)	Blade is not powered on.	Ensure that the blade is firmly seated and either the thumbscrew is fully engaged or the slider is pushed up and the ejectors are fully engaged.

Port blade status LED description

The following table describes the port and application blades status LED patterns and the recommended actions for those patterns.

TABLE 8 Port and application blades status LED description

LED purpose	Color	Status	Recommended action
Status LED 	No light (LED is off)	Blade is either healthy or does not have power.	Verify that the power LED is on.
	Steady amber	Blade is faulty.	Ensure that the blade is firmly seated and check the status by entering the slotShow command. If LED remains amber, consult the device supplier.
	Slow-flashing amber (on 2 seconds, then off 2 seconds)	Blade is not seated correctly or is faulty.	Pull the blade out and reseal it. If LED continues to flash, replace the blade.
	Fast-flashing amber (on 1/2 second, then off 1/2 second)	Environmental range exceeded.	Check for out-of-bounds environmental condition and correct it.

FC ports status LED description

The following table describes blade FC ports status LED patterns and the recommended actions for those patterns.

TABLE 9 FC ports status LED description

LED purpose	Color	Status	Recommended action
FC Port Status	No light (LED is off)	Port has no incoming power, or there is no light or signal carrier detected.	Verify that the power LED is on, check the transceiver and cable.
		Polling is in progress.	Allow 60 seconds for polling to complete.
		Connected device is configured in an offline state.	Verify the status of the connected device.
	Steady green	Port is online (connected to an external device) but has no traffic.	No action required.
	Slow-flashing green (on 1 second, then off 1 second)	Port is online but segmented, indicating a loopback plug or cable or an incompatible switch.	Verify that the correct device is attached to the chassis.

TABLE 9 FC ports status LED description (Continued)

LED purpose	Color	Status	Recommended action
	Fast-flashing green (on 1/4 second, then off 1/4 second)	Port is in internal loopback (diagnostic).	No action required.
	Flickering green	Port is online, with traffic flowing through port.	No action required.
	Steady amber	Port is receiving light or signal carrier, but it is not online yet.	Reset the port from the workstation using the portEnable or portCfgPersistentEnable command.
	Slow-flashing amber (on 2 seconds, then off 2 seconds)	Port is disabled due to diagnostic tests or portDisable or portCfgPersistentEnable command.	Reset the port from the workstation using the portEnable or portCfgPersistentEnable command.
	Fast-flashing amber (on 1/2 second, then off 1/2 second)	Transceiver or port is faulty.	Change the transceiver or reset the switch from the workstation.
	Alternating green/amber	Port is bypassed.	Reset the port from the workstation using the portEnable or portCfgPersistentEnable command.

GbE and 10-GbE ports status LED description

The following table describes blade GbE and 10-GbE port status LED patterns and the recommended actions for those patterns.

TABLE 10 1-GbE and 10-GbE port status LED description

LED purpose	Color	Status	Recommended action
GbE Port Status both 1-GbE and 10-GbE ports	No light (LED is off)	Port has no incoming power, or there is no light or signal carrier detected.	Verify that the power LED is on, check the transceiver and cable.
	Steady green	Port is online but has no traffic.	No action required.
	Slow-flashing green (on 1 second, then off 1 second)	Beacon. Used to identify specific ports.	No action required.


TABLE 10 1-GbE and 10-GbE port status LED description (Continued)

LED purpose	Color	Status	Recommended action
	Flickering green	Port is online, with traffic flowing through port.	No action required.
	Fast-flashing amber (on 1/4 second, then off 1/4 second)	Transceiver or port is faulty.	Change the transceiver or reset the switch from the workstation.

Determining the status of a control processor blade (CP8)

Complete the following steps to determine the status of a control processor blade (CP8)

1. Check the LED indicators on the CP blade. The LED patterns may temporarily change during POST and other diagnostic tests. For information about how to interpret the LED patterns, refer to the following table.
2. Check the port blade status by entering **slotShow** and **haShow**.

FIGURE 23 Control processor blade (CP8)

1. Power LED
2. Status LED
3. USB LED
4. USB port
5. Console port (Serial)
6. Ethernet port (Mgmt IP)
7. Ethernet port (Service IP)
8. Active CP LED

The following table describes the CP blade LED patterns and the recommended actions for those patterns.


TABLE 11 CP blade LED descriptions

LED purpose	Color	Status	Recommended action
Power 	Steady green	CP blade is on.	No action required.
	No light (LED is off)	CP blade is not on.	Ensure that the blade is firmly seated and has power.
Status 	No light (LED is off)	CP blade is either healthy or does not have power.	Verify that the power LED is on.
	Steady amber	CP blade is faulty or the switch is still booting.	Ensure that the blade is firmly seated and the switch has completed booting. If LED remains amber, consult the device supplier.
	Slow-flashing amber (on 2 seconds, then off 2 seconds)	CP blade is not seated correctly or is faulty.	Pull the blade out and reseal it. If the LED continues to flash, replace the blade.
	Fast-flashing amber (on 1/2 second, then off 1/2 second)	Environmental range exceeded.	Check for out-of-bounds environmental condition and correct it.
Ethernet Link Status	No light (LED is off)	Either an Ethernet link is not detected, or it does not have incoming power.	Ensure that the blade has power, the Ethernet cable is firmly seated, and the connected device is functioning.
	Flickering green/amber	Ethernet link is healthy and traffic is flowing through port.	No action required.
Ethernet Link Speed	No light (LED is off)	Ethernet link speed is 10 Mb/s or CP blade does not have incoming power.	Ensure that the CP has power. NOTE: To force a persistent Ethernet link speed, enter the ifModeSet command.
	Steady green	Ethernet link speed is 100/1000 Mb/s.	No action required.
USB Status	Lamp on	USB stick enabled.	No action required.
	Lamp off	USB stick not present or disabled.	No action required.
Active CP	Steady blue	Active CP blade.	No action required.
	No light (LED is off)	Standby CP blade.	No action required.

Determining the status of a core switch blade (CR16-4)

Complete the following steps to determine the status of a core switch blade (CR16-4).

1. Check the LED indicators on the core switch blade. The LED patterns may temporarily change during POST and other diagnostic tests. For information about how to interpret the LED patterns, refer to the following table.
2. Check the core switch blade status by entering **slotShow** and **haShow**.

FIGURE 24 Core switch blade (CR16-4)

1. Power LED
2. Status LED
3. QSFP port map and trunking diagram
4. QSFP connectors

The following table describes the core switch blade LED patterns and the recommended actions for those patterns.

TABLE 12 CR blade LED descriptions

LED purpose	Color	Status	Recommended action
Power 	Steady green	CR16-4 blade is on.	No action required.
	No light (LED is off)	CR16-4 blade is not on.	Ensure that the blade is firmly seated and has power.
Status 	No light (LED is off)	CR16-4 blade is either healthy or does not have power.	Verify that the power LED is on.
	Steady amber	CR16-4 blade is faulty or the switch is still booting.	Ensure that the blade is firmly seated and the switch has completed booting. If the LED remains amber, consult the supplier for your Brocade device.
	Slow-flashing amber (on 2 seconds, then off 2 seconds)	CR16-4 blade is not seated correctly or is faulty.	Pull the blade out and reseal it. If the LED continues to flash, replace the blade.
	Fast-flashing amber (on 1/2 second, then off 1/2 second)	Environmental range exceeded.	Check for out-of-bounds environmental condition and correct it.
QSFP connector status LED	No light (LED is off)	No QSFP module, all four QSFP ports are disabled	No action needed if the QSFP is not installed or verify that the QSFP is fully inserted.

TABLE 12 CR blade LED descriptions (Continued)

LED purpose	Color	Status	Recommended action
	Steady amber	QSFP module is in, all four ports have no signal/no sync.	Ensure that the cable is properly connected. If the LED remains amber, consult the supplier for your Brocade device.
	Blinking amber	Port is disabled or faulted, FC link activity, segmented, loopback mode, also during transition between cable plug in and all four ports online.	Check for console messages or wait for all four ports to come online.
	Steady green	QSFP module is in and all ports are online.	No action needed.

Refer to the Port Numbering section of this guide for a map of the ports and a table of external ports to internal ports as shown in the **slotShow** command.


Determining the status of a power supply

Complete the following steps to determine the status of a power supply. The Brocade DCX 8510-4 has two power supplies.

1. Check the LED indicator on the power supply. The LED patterns may temporarily change during POST and other diagnostic tests; for information about how to interpret the LED patterns, refer to the following table. Be sure to check all the power supply modules.
2. Check the power supply status by entering **psShow**.

The power supply status displays OK, Absent, or Faulty. If a power supply displays absent or faulty, contact the device supplier to order replacement parts. Both physically absent or faulty could also be the result of the power supply not being properly seated or being turned off.

FIGURE 25 Power supply



1. Power LED

The following table describes the power supply LED patterns and the recommended actions for those patterns.

TABLE 13 Power supply LED descriptions


LED purpose	Color	Status	Recommended action
Power 	No light (LED is off)	Power supply does not have incoming power and is not providing power to the device.	Ensure that the power supply is firmly seated, the device has incoming power, both power cables are connected, and AC power switches are on.
	Steady green	Power supply has incoming power and is providing power to the device.	No action required.
	Flashing green	Power supply is about to fail.	Replace the power supply.

Determining the status of a blower assembly

Complete the following steps to determine the status of a blower assembly. The Brocade DCX 8510-4 has two blowers.

1. Check the LED indicators on the blower assembly. The LED patterns may temporarily change during POST and other diagnostic tests; for information about how to interpret the LED patterns, refer to the following table. Be sure to check all the blower modules.
2. Check the blower assembly status using the **fanShow** command.

The status for each blower assembly displays OK, Absent, or Faulty. The RPM of each fan in the assembly is also provided. If a blower assembly displays absent or faulty, contact the device supplier to order replacement parts. Both physically absent or faulty could also be the result of the power supply not being properly seated.

FIGURE 26 Blower assembly

1. Power LED
2. Fault LED

The following table describes the LED patterns for the blower assembly.

TABLE 14 Blower assembly LED descriptions

LED purpose	Color	Status	Recommended action
Power 	No light (LED is off)	Blower assembly does not have power.	Ensure that the blower assembly is firmly seated and has power.
	Steady green	Blower assembly has power.	No action required.
Fault 	No light (LED is off)	Blower assembly is either healthy or does not have power.	Ensure that the blower assembly has power.
	Steady amber	Blower assembly has a failure (full or partial).	Replace the blower assembly.
	Slow-flashing amber (on 2 seconds, then off 2 seconds)	Blower assembly is not seated correctly or is faulty.	Pull the unit out and reseal it. If the LED continues to flash, replace the unit.
	Flashing amber (on 1/2 second, then off 3.5 seconds)	Fan is disabled.	Run the fanEnable command to enable the fan.
	Fast-flashing amber (on 1/2 second, then off 1/2 second)	Environmental range exceeded.	Check for out-of-bounds environmental condition, resolve any problems, and reseal the unit. If the LED continues to flash, replace the unit.

Determining the status of a WWN card

Complete the following steps to determine the status of a WWN card.

NOTE

The WWN bezel (logo plate) covers the WWN cards.

The LEDs on the WWN cards are not visible unless the bezel is removed.

Enter the **chassisShow** command to display information about the WWN card. (WWN units correspond to information specific to the WWN card.) Error messages that may indicate problems with a WWN card are summarized in the following table.


TABLE 15 Messages that may indicate WWN card failure

Type of message	Sample error message
WWN unit fails its field-replaceable unit (FRU) header access.	0x24c (fabos): Switch: switchname, error EM-I2C_TIMEOUT, 2, WWN 1 I2C timed out: state 0x4
WWN unit fails to power on.	<timestamp>, [EM-1004], <sequence-number>,, CRITICAL, <system-name>, WWN # failed to power on or <timestamp>, [EM-1043], <sequence-number>,, WARNING, <system-name>, Can't power <FRU Id> <state (on or off)>.

TABLE 15 Messages that may indicate WWN card failure (Continued)

Type of message	Sample error message
WWN unit is being faulted.	0x24c (fabos): Switch: switchname, Critical EM-WWN UNKNOWN, 1, Unknown WWN #2 is being faultedor<timestamp>, [EM-1003], 40, SLOT 7 FFDC CHASSIS, CRITICAL, Brocade DCX, WWN 2 has unknown hardware identifier: FRU faultedor<timestamp>, [EM-1034], <sequence-number>,, ERROR, <system-name>, WWN # set to faulty, rc=<return code>
WWN unit is not present or is not accessible.	0x24c (fabos): Switch: switchname, Error EM-WWN ABSENT, 2, WWN #1 not presenter<timestamp>, [EM-1036], <sequence-number>,, WARNING, <system-name>, <FRU Id> is not accessible.
Writing to the FRU history log (hilSetFruHistory) has failed.	0x24c (fabos): Switch: switchname, Error EM-HIL_FAIL, 2, HIL Error: hilSetFruHistory failed, rc=-3 for SLOT 3
WWN unit insertion was detected.	<timestamp>, [EM-1049], <sequence-number>,, INFO, <system-name>, FRU WWN # insertion detected.
WWN unit removal was detected.	<timestamp>, [EM-1050], <sequence-number>,, INFO, <system-name>, FRU WWN # removal detected.

The following figure displays the WWN bezel (logo plate). The WWN cards are under the bezel.

FIGURE 27 WWN bezel (logo plate) on Brocade DCX 8510-4

Removal and Replacement Procedures

- Introduction..... 75
- ESD precautions..... 75
- Chassis door removal and replacement..... 76
- Vertical cable management fingers removal and replacement..... 77
- Port and application blade removal and replacement..... 78
- Blade filler panel removal and replacement..... 82
- Control processor blade (CP8) removal and replacement..... 83
- Core switch blade (CR16-x) removal and replacement..... 93
- Power supply removal and replacement..... 96
- Blower assembly removal and replacement..... 98
- WWN card removal and replacement..... 99
- Transceiver and fiber optic cable removal and replacement..... 107
- Chassis removal and replacement..... 113

Introduction

NOTE

Read the safety notices before servicing ([Caution and Danger Notices](#) on page 161).

The field-replaceable units (FRUs) in the device can be removed and replaced without special tools. The device can continue operating during many of the FRU replacements if the conditions specified in the procedures are followed.

The following sections contain FRU removal and replacement procedures (RRPs).

ESD precautions

The device contains ESD-sensitive FRUs. When working with any device FRU, use correct electrostatic discharge (ESD) procedures.

- Wear a wrist grounding strap connected to chassis ground (if the device is plugged in) or a bench ground.



DANGER

For safety reasons, the ESD wrist strap should contain a series 1 megaohm resistor.

- Store all ESD-sensitive components in antistatic packaging.



CAUTION

Static electricity can damage the chassis and other electronic devices. To avoid damage, keep static-sensitive devices in their static-protective packages until you are ready to install them.

Chassis door removal and replacement

NOTE

The chassis door must be installed to ensure that the device meets EMI and other regulatory certifications.


Time and items required

The replacement procedure for the chassis door takes less than five minutes.

Removing a chassis door

Support the door to prevent it from falling. Pull and remove the door. It will pop off the ball studs.

FIGURE 28 Removal and replacement of the chassis door



Replacing a chassis door

Complete the following steps to reinstall the door.

1. Align the holes in the door with the ball studs on the chassis.
2. Push the door into place. It will snap onto the studs.

Vertical cable management fingers removal and replacement

The Brocade DCX 8510-4 comes equipped with two vertical cable management finger assemblies. It can continue to operate during the replacement of the cable management fingers. Due to the horizontal orientation of the blades in the Brocade DCX 8510-4, the finger assemblies are attached to the uprights of the mounting rack.

Time and items required


The replacement procedure for the cable management fingers takes less than five minutes. A #1 Phillips screwdriver is required.

Removing a cable management finger assembly

Complete the following steps to remove the cable management finger assembly.

1. Remove the chassis door.
2. Remove the cables from the cable management finger assembly and rearrange the cables around the assembly.
3. Unscrew and save the three (3) screws holding the finger assembly to the rack upright. Support the assembly to prevent it from falling.
4. Remove the cable management finger assembly.
5. If necessary, repeat steps 1 through 4 for the other finger assembly.

FIGURE 29 Removal and replacement of the vertical cable management finger assemblies



Replacing a cable management finger assembly

Complete the following steps to replace the cable management finger assembly.

1. Position and tighten the three (3) screws to secure the vertical cable management finger assembly to the rack upright.
2. Arrange the cables along the cable management finger assembly.
3. If necessary, repeat steps 1 and 2 for the other cable management finger assembly.
4. Replace the chassis door.

Port and application blade removal and replacement

This section describes how to remove and replace port and application blades. It does not cover the core (CR) blades or the control processor (CP) blades.



CAUTION

If you do not install a module or a power supply in a slot, you must keep the slot filler panel in place. If you run the chassis with an uncovered slot, the system will overheat.

Slots are numbered from 1 through 8, from bottom to top when facing the port side of the Brocade DCX 8510-4. Port and application blades can be installed in slots 1-2 and 7-8.

This section is applicable for all the following port and application blades supported on the chassis:

Blade	DCX 8510-4	DCX 8510-8
FS8-18 port blade	Supported	Supported
FC8-32E port blade	Supported	Supported
FC8-48 port blade	Supported	Supported
FC8-64 port blade	Supported	Supported
FC16-32 port blade	Supported	Supported
FC16-48 port blade	Supported	Supported
FC16-64 port blade	Supported	Supported
FCOE10-24 application blade	Not supported	Supported only on slot 1
FX8-24 extension blade	Supported	Supported

NOTE

The FCOE10-24 blade is not supported in the same chassis with FC8-64, FC16-48, FC16-64, or FX8-24 blades. For complete list of limitations on the FCOE10-24 application blade, refer to the *Fabric OS Release Notes*.

Time and items required

The replacement procedure for each blade takes less than 10 minutes. Removing and restoring transceivers and cables may take longer depending on how many must be changed. The following items are required for the blade and filler panel replacement:

- Electrostatic discharge (ESD) grounding strap
- Workstation computer
- Replacement blade or filler panel
- #2 Phillips screwdriver
- Small form-factor pluggable (SFP+, mSFP, or QSFP) transceivers (as needed)
- Optical and copper cables (as needed)

NOTE

For information about the transceivers that are qualified for the Brocade chassis, refer to the Transceiver Removal and Replacement section.

Removing a blade

Complete the following steps to remove a blade.

Follow electrostatic discharge (ESD) precautions when removing a blade. Wear a wrist grounding strap connected to chassis ground (if the device is plugged in) or a bench ground.

**DANGER**

For safety reasons, the ESD wrist strap should contain a series 1 megaohm resistor.

NOTE

Before removing any cables from a blade, note the cable order (identify each cable by its physical port). It is a good practice to keep a table of cable to port mapping.

NOTE

If multiple blades are being replaced, replace one blade at a time.

This procedure is applicable for all the port and application blades supported on the device.

1. Remove the chassis door.
2. Check the power LED, status LED, and port status LED to identify any possible problems. A failed port or application blade can be identified by inspecting the LEDs on the front panel of each blade.
3. Establish a Telnet or console session.

Before replacing a blade, establish a Telnet or console connection to determine a failure and verify operation after replacement. Use the **switchShow** command to view the status of the blades.
4. Check for adequate cable slack. Ensure there is plenty of cable slack to remove a blade without cable obstruction.
5. Ensure that the part number on the unit being replaced matches the replacement part number. The **chassisShow** command displays information about the blades, including part numbers (xx-xxxxxx-xx), serial numbers, and additional status.
6. Ensure that traffic is not flowing through the blade (port status LED should be off) prior to disconnecting cables.
7. Ensure that traffic is not flowing through the blade.
8. Disconnect all cables and transceivers from the blade. For mSFP transceivers (FC8-64 only), it is recommended that you use the pull tab to remove the transceiver from the blade.
9. If removing an FX8-24 extension blade, perform the following steps:
 - a) Delete all fcip tunnel configurations via the **portcfg fciptunnel slot / vePort** command.
 - b) Delete all IP Routes defined on the blade to be removed via the **portcfg iproute** command.
 - c) Delete all IP interfaces (IPIFs) defined on the blade via the **portcfg ipif slot/geX | xgeX** command.
 - d) If logical switches are used on the switch, move all FX8-24 ports back to the default logical switch.


NOTE

If you are removing the FX8-24 blade to install in a different slot, you must remove configuration using the preceding steps, then reconfigure the blade in the new slot. If you move the blade without performing these steps and the blade faults, you must move the blade to the original slot and remove configuration.

10. Unscrew the two thumbscrews from the ejectors on the blade using the Phillips screwdriver. Unscrew the left thumbscrew until it pops out. This initiates a hot-swap request.
11. Wait for the power LED to turn off in response to the hot-swap request before removing the blade.

12. Open the ejectors by rotating them toward the center of the blade face. Pull the blade out of the chassis using the ejectors.
13. If the blade is not being replaced by another blade, install a filler panel.

FIGURE 30 Removal and replacement of the port and application blades (FC16-48 port blade shown)



Replacing a blade

Complete this procedure to replace a blade.

Follow electrostatic discharge (ESD) precautions when replacing a blade. Wear a wrist grounding strap connected to chassis ground (if the device is plugged in) or a bench ground.



DANGER

For safety reasons, the ESD wrist strap should contain a series 1 megaohm resistor.

1. Orient the blade so that the ports are at the front of the chassis and the flat side of the blade is on the bottom.
2. Open the ejectors by rotating them toward the center of the blade face, align the flat side of the blade inside the left and right rail guides in the slot, and slide the blade into the slot until it is firmly seated.
3. Close the ejectors by rotating them away from the center of the blade. The levering action of the ejectors seats the blade in the slot.
4. Tighten the thumbscrews using the Phillips screwdriver.
5. Verify that the power LED on the port blade is displaying a steady green light. If it does not turn on, ensure that the blade is firmly seated.

6. Verify that the Status LED on the blade shows amber until POST completes for the blade. The status LED should then display green. If the LED remains amber, the board may not be properly seated in the backplane or the board may be faulty.
7. Install the transceivers and cables in the blade. For mSFP (**FC8-64** port blade only) and QSFP (**FC16-64** port blade only) transceivers, it is recommended that you install the cables in the transceivers before installing the transceivers in the blade.
8. Group and route the cables through the vertical cable management finger assemblies.
9. Replace the chassis door.

Blade filler panel removal and replacement

This section describes how to remove and replace blade filler panels.

NOTE

Some filler panels have two thumbscrews and some have only one. Be sure to unscrew or tighten both if you are using the two-screw version.

Blade filler panel removal and replacement

This section describes how to remove and replace blade filler panels.

NOTE

Some filler panels have two thumbscrews and some have only one. Be sure to unscrew or tighten both if you are using the two-screw version.

Removing a filler panel


Complete the following steps to remove a filler panel from the chassis.



CAUTION

If you do not install a module or a power supply in a slot, you must keep the slot filler panel in place. If you run the chassis with an uncovered slot, the system will overheat.

1. Remove the chassis door.
2. Unscrew the thumbscrews on the panel using the Phillips screwdriver.
3. Using the tabs, pull the filler panel out of the chassis.

FIGURE 31 Removal and replacement of the blade filler panel

Replacing a filler panel

Do not leave a slot empty. This will adversely affect cooling of the chassis.

1. Orient the filler panel.
2. Slide the filler panel into the slot until it is firmly seated.
3. Tighten the thumbscrews.
4. Replace the chassis door.

Control processor blade (CP8) removal and replacement

This document describes how to remove and replace a control processor (CP8) blade.

Each chassis has two CP8 blades. They are located in slots 4 and 5.

NOTE

The CP8 blade is compatible only with the Brocade DCX Backbones (including the DCX 8510 Backbones).

NOTE

The firmware upgrade policy for CP8 blades specifies testing for the current Fabric OS release and one version earlier. It is possible to upgrade by more than one version, but it is a very specific and detailed

process. Read the directions under [Downloading firmware from an FTP server](#) on page 90 or [Downloading firmware from a USB device](#) on page 91 carefully.

NOTE

If the new CP blade does not have the same firmware as the active CP blade, the new blade must be upgraded to the same firmware version. You can determine the firmware version on the replacement blade and perform a firmware upgrade if necessary after inserting the blade in the chassis, but you must disable high availability (HA) before inserting the new blade. If the new CP blade is severely down-level, a very specific procedure must be followed to bring the blade up to the correct firmware version.

Time and items required

The replacement procedure for the CP blade takes approximately 30 minutes. The following items are required for the CP blade replacement:

- Electrostatic discharge (ESD) grounding strap
- Workstation computer
- Serial cable
- IP address of an FTP server for backing up the device configuration
- #2 Phillips screwdriver
- Replacement CP blade

Faulty CP blade indicators

Confirm that you need to replace the CP blade. The following events may indicate that a CP blade is faulty:

- The status LED on the CP blade is lit steady amber, or the power LED is not lit.
- The CP blade does not respond to Telnet commands, or the serial console is not available.
- The **slotShow** command does not show that the CP blade is enabled.
- The **haShow** command indicates an error.
- The clock is inaccurate, or the CP blade does not boot up or shut down normally.
- Any of the following messages display in the error log:
 - "Slot unknown" message relating to a CP slot
 - CP blade errors or I2C timeouts
 - FRU: FRU_FAULTY messages for a CP blade
 - Configuration loader messages or "Sys PCI config" messages
 - Generic system driver messages ("FABSYS")
 - Platform system driver messages ("Platform")
 - EM messages that indicate a problem with a CP blade
 - Function fail messages for the CP master

For more information about error messages, refer to the *Fabric OS Message Reference*.

Recording critical device information

Back up the backbone configuration before you replace a CP blade. Refer to the *Fabric OS Administrator's Guide* for backup information.

NOTE

The following instructions reference specific slot numbers as examples. These numbers will be different on a chassis with slots for four port blades and a chassis with slots for eight port blades. These numbers will be different between the DCX 8510-8/DCX and the DCX 8510-4/DCX-4S chassis.

1. Connect to the chassis and log in as **admin**, using a serial console connection.
2. Enter **haShow** to determine which CP blade is active. The following example is from an 8-slot chassis.


```
DCX_124:admin> haShow
Local CP (Slot 7, CP1) : Active
Remote CP (Slot 6, CP0) : Standby, Healthy
HA Enabled, Heartbeat Up, HA State Synchronized
```
3. Enter all remaining commands from the serial console for the active CP blade, unless otherwise indicated. For more information about commands, refer to the *Fabric OS Command Reference*.
4. If the active CP blade is faulted, automatic fail over to the standby CP blade should have occurred. Confirm that the standby CP blade is active and power off the faulted CP blade, log in to the standby CP blade, and skip to step 7.

If automatic fail over has not occurred, manually fail over the faulty blade by moving the slider to the off position (to the right). Then power off the faulted blade, log in to the standby CP blade, and skip to step 7.
5. If both CP blades are healthy and you want to replace the standby CP blade, log in to the active CP blade and skip to step 7.
6. If both CP blades are healthy and you want to replace the active CP blade, log in to the active CP blade and run the following steps:
 - a) Run the **haFailover** command to make the standby CP blade the active blade. The currently active CP blade becomes the standby blade. Wait until the status LED on the currently active CP blade is no longer lit.
 - b) Confirm the completion of the failover by running the **haShow** command.
 - c) Log in to the new active CP blade.
7. Run **firmwareShow** to note the firmware version of the active CP blade.

The following example shows the results of the **firmwareshow** command when the firmware versions on the two CP blades are not the same. Note the warning message at the end of the output.

```
DCX_120:root> firmwareshow
Slot Name      Appl      Primary/Secondary Versions      Status
-----
04 CP0         FOS       v7.1.0a                      STANDBY
              v7.1.0a
05 CP1         FOS       v7.3.0b                      ACTIVE *
              v7.3.0b
WARNING: The local CP and remote CP have different versions
of firmware, please retry firmwaredownload command.
DCX_120:root>
```

8. Run **haDisable** from the active CP blade to prevent failover or communication between the CP blades during the replacement.
9. Enter the **configupload -vf** command. This command uploads the backbone virtual fabric data.

- 10 Enter the **configupload -all** command. This command uploads the chassis and switch configuration for all logical switches.
- 11 In a FICON environment, log in as root and enter **configupload --map** to upload port-to-area mapping information.
With Fabric OS 7.4.0, you need to upload the configuration with **-map** option in a FICON-enabled DCX 8510 chassis if port-bound addressing is used.

Power-up procedure

Use the procedures in this section to remove and replace a single control processor (CP) blade while chassis power is on. To replace both CP blades, refer to the power-down replacement procedures.

Removing a control processor blade (CP8)


The chassis continues to operate while a CP blade is being replaced if the redundant CP blade is active and a failover does not occur. You can prevent failover by entering the **haDisable** command.

Complete the following steps to remove a CP8 control blade.

1. Remove the chassis door.
2. Log in to the active CP as the admin user. You can use a serial cable or Telnet, Web Tools, or Fabric Manager. Determine which CP is active using the **haShow** command or view the active LED on the front of the CP.
3. If the faulty CP is the active CP, issue the **haFailover** command. Wait until the failover has completed. Use the **haShow** command to verify the CPs are synchronized and the failover is complete.

Depending on the nature of the CP failure, it is possible that the **haFailover** command may not work. Proceed to the next step anyway.

4. Enter the **haDisable** command. This is required before physically removing and replacing a CP blade.
5. Power off the blade by sliding the slider switch in the left ejector to the right to the off position. Do not eject the blade until the power LED is off and you have completed the next two steps.
6. Disconnect all cables from the faulty (standby) CP.
7. Unscrew the thumbscrew from both ejectors using the Phillips screwdriver.
8. Lever open both ejector handles simultaneously to approximately 45 degrees and pull the CP blade out of the chassis.

FIGURE 32 Removal and replacement of the control processor blade (CP8)

Replacing a control processor blade (CP8)

NOTE

Read all of the instructions for replacing the CP blade before beginning the procedure. Use the same version of Fabric OS on both CP blades. Using different versions is not supported and may cause malfunctioning. If the replacement CP blade has a different version of Fabric OS, bring both blades to the same firmware version. Once you have installed the replacement CP blade, determine the version of firmware on the replacement CP blade and upgrade it if necessary.

Complete the following steps to remove a CP8 control blade.

1. Open the ejector handles to approximately 45 degrees. Orient the CP blade so that the handles are toward you and the flat metal side should be facing down.
2. Align the flat metal side of the CP blade inside the left and right blade guides in the slot. Slide the CP blade into the slot until it is firmly seated.
3. Tighten the thumbscrew inside each handle using the Phillips screwdriver.
4. Turn the CP blade on by sliding the ON/OFF switch in the left handle to the left, to cover the thumbscrew.
5. Verify that the power LED is green. If not, ensure that the CP blade has power and is firmly seated and that the ejectors are in the locked position.
6. Connect the cables to the new CP blade.
7. Remain logged in to the active CP and continue to [Verifying operation of the new CP blade](#) on page 89.

Power-down procedure

Use the following procedure to power down the chassis and replace both CP blades. You can replace a single CP blade using the power-up procedures.

1. Remove the chassis door.
2. If you haven't already done so, enter **configupload -all**, specifying a file name for saving configuration data.
This saves all system configuration data including chassis and switch configuration for all logical switches to the file name specified. For more information, refer to the *Fabric OS Command Reference*.
3. If you haven't already done so, enter **configupload -vf**, specifying a file name for saving configuration data.
This saves the backbone virtual fabric data to the file name specified. For more information, refer to the *Fabric OS Command Reference*.
4. If you haven't already done so, enter **configupload -map**, specifying a folder name.
This command saves the port-to-area addressing mode configuration files to the folder specified. With Fabric OS 7.4.0, you need to upload the configuration with **-map** option in a FICON-enabled DCX 8510 chassis if port-bound addressing is used. For more information, refer to the *Fabric OS Command Reference*.
5. Power down the chassis.
6. Remove CP blades using the following steps:
 - a) Disconnect all cables from the blades.
 - b) Unscrew the thumbscrew from both ejectors for a blade using the Phillips screwdriver.
 - c) Lever open both ejector handles simultaneously to approximately 45 degrees and pull the CP blade out of the chassis.
7. Replace the blades using the following steps:
 - a) Open the ejector handles to approximately 45 degrees. Orient the CP blade so that the handles are toward you.
 - b) Align the flat metal side of the CP blade inside the blade guides in the slot. Slide the CP blade into the slot until it is firmly seated.
 - c) Tighten the thumbscrew inside each handle using the Phillips screwdriver.
 - d) Turn the CP blade on by sliding the ON/OFF switch in the left handle to the left to cover the thumbscrew.
8. Power up the chassis.
9. Verify that each blade's power LED is green. If not, ensure that the CP blade has power and is firmly seated and that the ejectors are in the locked position.
10. Connect the cables to the new CP blade.
11. Enter **chassisDisable**.
12. Enter **configDownload -vf** to download backbone virtual fabric data to the local system.
The chassis reboots and partitions are restored.
13. Enter **chassisDisable**.
14. Enter **configDownload -map** to download port-to-area addressing mode configuration files to the local system.
15. Enter **chassisReboot -m**.
The system recovers.
16. Enter **chassisDisable**.
17. Enter **configDownload -all** to download system configuration data, including chassis and switch configuration for all logical switches, to the local system.
All the licenses, configurations, and FCIP tunnels are restored.
18. Enter **reboot**.
The chassis becomes fully functional with the new CP blades.

Verifying operation of the new CP blade

To verify that boot and POST are complete on the new CP blade and that the CP blade has achieved failover redundancy, perform the following steps.

1. Enter **slotShow**. The command output shows the new CP blade as "enabled."

If the standby CP is unresponsive, you can try unplugging the new CP blade, running **haDisable** on the active CP blade, and plugging the new CP blade back in. At that point, you can repeat step 1 to begin the verification process again.

2. Log into each CP blade and enter the **haShow** command to display the CP status. Verify the CP state, status, health, and that the HA state is synchronized. Remedy any issues before proceeding. For more information on **haShow** output, refer to the *Fabric OS Command Reference*.
3. Determine the version of installed CP blades by entering **firmwareShow**. If the serial console on the replacement CP blade is connected, issue the **firmwareShow** command there. More information is available through the console.

NOTE

The device requires Fabric OS 7.0.0 or later to be recognized. If the firmware on the replacement blade is earlier than 7.0.0 it must be brought up to the version on the active CP blade, which must be at least 7.0.0.

4. If the firmware versions for both CP blades are the same, skip to [Completing the replacement](#) on page 92.

If the firmware version on the replacement blade does not match that on the active CP blade, a warning message appears with the results of the ***firmwareshow*** command. The results of the ***firmwareshow*** command may look similar to the following. Note the warning message at the end of the output.

```
DCX xyz:admin> firmwareshow
Slot Name      Appl      Primary/Secondary Versions      Status
-----
  4 CP0        FOS        v7.1.0
               v7.1.0
  5 CP1        FOS        v7.3.0a
               v7.3.0a
* Local CP
WARNING: The local CP and remote CP have different versions
of firmware, please retry firmwaredownload command.
```

5. Bring the replacement blade firmware to the same firmware level as the active blade using one of the following procedures:

- Run the **firmwaresync** command on the active CP blade to copy all firmware from the active CP blade to the standby CP blade.

NOTE

Using this command requires that existing telnet, secure telnet or SSH sessions to the standby CP blade to be restarted.

- Run the **firmwareDownload -s** command on the replacement blade to bring it up to the proper level.

6. Perform one of the following tasks to download firmware:

- If you are using an FTP server to download the firmware, skip to the procedure for downloading firmware from an FTP server.
- If you are using a USB device to download the firmware, skip to the procedure for downloading firmware from a USB device. If the firmware on the standby CP blade is more than one level down

from the level on the active CP blade, you must have formatted USB devices for each of the versions you will need to upgrade.

For details on supported upgrade paths and steps to upgrade through multiple versions of Fabric OS, refer to the *Fabric OS Release Notes*, and the *Fabric OS Upgrade Guide*

Downloading firmware from an FTP server

For this task, determine the correct sequence of upgrading firmware versions to reach your target version.

Complete the following steps to download the firmware from an FTP server.

1. Log in to the standby CP blade as **admin**. If you need to know the IP address of the standby blade, run **ipaddrshow**.

You should remain logged in to the active CP blade in order to monitor it.

2. Run **firmwareDownload -s** to download the firmware to the standby CP blade. The **-s** option also disables the autoreboot, so you will have to manually issue a reboot after the download finishes to initiate **firmwarecommit**. Enter all requested information (use default values).
3. When the download process finishes, run **firmwareDownloadStatus** to verify that the firmware has been updated. The command displays a running account of the progress of the **firmwareDownload** command (if it is still running) until the command has completed. The final message is similar to the following and will appear with a date and time stamp.

NOTE

The slot number for the CP blade is different for a chassis with slots for four port blades and a chassis with slots for eight port blades. The slot number in the following example is for a chassis with slots for four port blades.

```
Slot 4 (CP0, active): Firmwaredownload command has completed successfully. Use
firmwareshow to verify the firmware versions.
```

4. On the standby CP blade (the blade for which you just changed the firmware level), run **reboot**. The reboot of the standby CP will initiate a **firmwarecommit** to the secondary partition and log you out.

```
DCX_124:admin> reboot
Broadcast message from root (ttyS0) Fri Jun 18 14:49:45 2010...
The system is going down for reboot NOW !!
INIT: Switching to runlevel: 6
INIT: Sending processes the TERM signal DCX_124:admin> HAMu Heartbeat down, stop
FSS
Unmounting all f##exiting due to signal: 9, pending signals: 0x20000, 0x0
ilesystems.
Please stand by while rebooting the system...
Restarting system.
The system is coming up, please wait...
.
.
.
Fri Jun 18 14:53:13 2010: Doing firmwarecommit now.
Please wait ...
Fri Jun 18 14:55:27 2010: Firmware commit completes successfully.
Validating the filesystem ...
Fri Jun 18 22:36:05 2010: Doing firmwarecommit now.
Please wait ...
Fri Jun 18 22:36:48 2010: Firmware commit completes successfully.
2010/06/18-14:56:50, [SULB-1004], 908, SLOT 7 | CHASSIS, INFO, Brocade_DCX,
Firmwarecommit has completed.
2010/06/18-14:56:50, [SULB-1036], 909, SLOT 7 | CHASSIS, INFO, Brocade_DCX, The
new Version: Fabric OS [version]
2010/06/18-14:56:50, [SULB-1002], 910, SLOT 7 | CHASSIS, INFO, Brocade_DCX,
Firmwaredownload command has completed successfully.
```

5. Log back in to the standby CP blade and run **firmwareDownloadStatus** on the standby CP blade to validate a successful commit. This may take 10 minutes.

6. If you are upgrading through several levels of the Fabric OS, repeat step 2 through step 5 as often as necessary based on the path outlined in the preceding table. Otherwise, proceed to step 7.
7. Log out of the standby CP blade and log in to the active CP blade.
8. Proceed to the procedures for verifying operation of the new CP blade.

Downloading firmware from a USB device

For this task, determine the correct sequence of upgrading firmware versions to reach your target version.

Complete the following steps to download the firmware from a USB device.

This section assumes that the new firmware has already been copied onto the USB device. The folder structure on the USB device must be as follows in order to allow the device to be enabled:

- brocade>
 - config
 - firmware
 - firmwareKey
 - support

The firmware folder contains the folder for the specific release you are installing.

1. Insert the USB device into the active CP blade.
2. Attach a serial cable from the PC to the active CP blade.
3. Log in to the active CP blade as **admin** if you are not still logged in and enter **usbStorage -e** to enable the USB device.
4. Remove the serial cable from the active CP blade and attach it to the standby CP blade and log in as **admin**.
5. Run **firmwareDownload -s** to download the firmware to the standby CP blade. The **-s** option also disables the autoreboot, so you will have to manually issue a reboot after the download finishes to initiate **firmwarecommit**. Enter all requested information (use default values).
6. When the download process finishes, run **firmwareDownloadStatus** to verify that the firmware has been updated. The command displays a running account of the progress of the **firmwareDownload** command until the command has completed. The final message is similar to the following and will appear with a date and time stamp.

NOTE

The slot number for the CP blade is different for a chassis with slots for four port blades and a chassis with slots for eight port blades. The slot number in the following example is for a chassis with slots for four port blades.

```
Slot 4 (CP0, active): Firmwaredownload command has completed successfully. Use
firmwareshow to verify the firmware versions.
```

7. Ensure that you are still logged in to the standby CP blade (the blade for which you just changed the firmware level) and type **reboot**. The reboot of the standby CP will initiate a **firmwarecommit** to the secondary partition and log you out.

```
DCX_124: admin> reboot
Broadcast message from root (ttyS0) Fri Jun 18 14:49:45 2010...
The system is going down for reboot NOW !!
INIT: Switching to runlevel: 6
INIT: Sending processes the TERM signal DCX_124:admin> HAMu Heartbeat down, stop
FSS
Unmounting all ##exiting due to signal: 9, pending signals: 0x20000, 0x0
ilesystems.
Please stand by while rebooting the system...
```

```
Restarting system.
The system is coming up, please wait...
.
.
.
Fri Jun 18 14:53:13 2010: Doing firmwarecommit now.
Please wait ...
Fri Jun 18 14:55:27 2010: Firmware commit completes successfully.
Validating the filesystem ...
Fri Jun 18 22:36:05 2010: Doing firmwarecommit now.
Please wait ...
Fri Jun 18 22:36:48 2010: Firmware commit completes successfully.
2010/06/18-14:56:50, [SULB-1004], 908, SLOT 7 | CHASSIS, INFO, Brocade_DCX,
Firmwarecommit has completed.
2010/06/18-14:56:50, [SULB-1036], 909, SLOT 7 | CHASSIS, INFO, Brocade_DCX, The
new Version: Fabric OS v6.3.0c
2010/06/18-14:56:50, [SULB-1002], 910, SLOT 7 | CHASSIS, INFO, Brocade_DCX,
Firmwaredownload command has completed successfully.
```

NOTE

The time stamp on the co-CPU may not be in sync with the main CPU on the blade. This is not a cause for concern.

8. Log back in to the standby CP blade and enter **firmwareDownloadStatus** on the standby CP blade to validate a successful commit. This may take 10 minutes.
9. If you are upgrading through several levels of the Fabric OS, repeat step 5 through step 8 as often as necessary based on the path outlined in the preceding table. Otherwise, proceed to step 10.
- 10 Log out of the standby CP blade and log in to the active CP blade.
- 11 Proceed to the procedures to "Completing the replacement."

Completing the replacement

Complete the following steps to complete the CP blade replacement procedure.

1. Enter **haEnable** to re-enable HA on the active CP blade.

NOTE

The **haEnable** command will cause the standby CP blade to reboot. Wait until POST completes before moving to the next step. POST is complete when the Status LED on the CP blade returns to a steady green state.

2. Enter **haShow** and verify that the command output includes "HA Enabled, Heartbeat Up". If it is not yet enabled, re-enter the command until you have verified that redundancy is achieved.

NOTE

The **haEnable** command will cause the standby CP blade to reboot. The slot number for the CP blade is different for a chassis with slots for four port blades and a chassis with slots for eight port blades. The slot number in the following example is for a chassis with slots for eight port blades.

```
DCX 124:admin> hashow
Local CP (Slot 7, CP1) : Active
Remote CP (Slot 6, CP0) : Standby, Healthy
HA Enabled, Heartbeat Up, HA State Synchronized
```

3. Enter **firmwareShow** to verify that the firmware version has been updated and that the versions are the same on the two CP blades.

NOTE

The slot number for the CP blade is different for a chassis with slots for four port blades and a chassis with slots for eight port blades. The slot number in the following example is for a chassis with slots for four port blades.

```
DCX_8510:admin> firmwareshow
Slot Name      Appl      Primary/Secondary Versions  Status
-----
 2  FX8-24  FOS        v7.4.0
 4  CP0     FOS        v7.4.0                STANDBY
 5  CP1     FOS        v7.4.0                ACTIVE *
 7  FX8-24  FOS        v7.4.0
```

4. Pack the faulty CP blade in the packaging provided with the new CP blade, and contact the switch supplier to determine the return procedure.
5. Replace the chassis door.

If you have one or more application or extension blades in the chassis, the Fabric OS automatically detects mismatches between the active CP firmware and the blade's firmware and triggers the auto-leveling process. This auto-leveling process automatically updates the application blade firmware to match the active CP. At the end of the auto-leveling process, the active CP, application, and extension blades will run the same version of the firmware.

Core switch blade (CR16-x) removal and replacement

This section describes how to remove and replace a core switch blade (CR16-x). The device has two core switch blades:

- One CR16-4 blade in slot 3.
- One CR16-4 blade in slot 6.

Time and items required

The replacement procedure for the core switch blade takes approximately 30 minutes. The following items are required for the core switch blade replacement:

- Electrostatic discharge (ESD)) grounding strap
- #2 Phillips screwdriver
- Replacement core switch blade

Faulty core switch blade indicators

Confirm that you need to replace the core switch blade before continuing. The following events may indicate that a core switch blade is faulty:

- The status LED on the core switch blade is lit steady amber, or the power LED is not lit.
- The **slotShow** command does not show that the core switch blade is enabled.
- The **haShow** command indicates an error.
- Any of the following messages display in the error log:

- "Slot unknown" message relating to a core switch slot
- Core switch blade errors or I2C timeouts
- FRU: FRU_FAULTY messages for a core switch blade
- Configuration loader messages or "Sys PCI config" messages
- Generic system driver messages ("FABSYS")
- Platform system driver messages ("Platform")
- EM messages that indicate a problem with a core switch blade
- Function fail messages for the core switch master

For more information about error messages, refer to the *Fabric OS Message Reference*.

Removing a core switch blade (CR16-x)

Follow electrostatic discharge (ESD) precautions when removing a blade. Wear a wrist grounding strap connected to chassis ground (if the device is plugged in) or a bench ground.



DANGER

For safety reasons, the ESD wrist strap should contain a series 1 megaohm resistor.

NOTE


The CR16-4 blade is compatible only with the Brocade DCX 8510-4.

NOTE

The device continues to operate while a core switch blade is being replaced.

Complete the following steps to remove the core switch blade.

1. Remove the chassis door.
2. Unscrew the two thumbscrews from the ejectors on the blade using the Phillips screwdriver.
Unscrew the left thumbscrew until it pops out. This initiates a hot-swap request.
3. Label and then disconnect cables from the faulty core switch blade.
4. Open the ejectors by rotating them toward the center of the blade face. Pull the blade out of the chassis using the ejectors.

FIGURE 33 Removal and replacement of the core switch blade (CR16-4)

Replacing a core switch blade (CR16-x)

Follow electrostatic discharge (ESD) precautions when replacing a blade. Wear a wrist grounding strap connected to chassis ground (if the device is plugged in) or a bench ground.



DANGER

For safety reasons, the ESD wrist strap should contain a series 1 megaohm resistor.

NOTE

The CR16-4 blade is compatible only with the Brocade DCX 8510-4.

NOTE

The device continues to operate while a core switch blade is being replaced.

Complete the following steps to replace the core switch blade.

1. Open the ejectors by rotating them toward the center of the blade face. Orient the CR blade so that the handles are toward you.
2. Align the flat side of the blade inside the left and right rail guides in the slot with the components facing upwards, and slide the blade into the slot until it is firmly seated.
3. Close the ejectors by rotating them away from the center of the blade. The levering action of the ejectors seats the blade in the slot.
4. Power on the blade by screwing in the thumbscrews.
5. Verify that the power LED is green (might require a few seconds). If not, ensure that the core switch blade has power and is firmly seated and that the ejectors are in the locked position.

6. Verify that the status LED on the new blade is initially amber and will be until POST for the blade completes. this may take as long as several minutes. It then turns green.
7. Connect the cables to the new core switch blade. For the DCX 8510 models, if the QSFP cables are not used, make sure the rubber gaskets are in the QSFP transceivers.
8. Replace the chassis door.
9. Pack the faulty core switch blade in the packaging provided with the new core switch blade, and contact the device supplier to determine the return procedure.

Power supply removal and replacement

Use this procedure to remove and replace a power supply.

NOTE

Depending on the blade configuration of the chassis and the number of power supplies installed, the device may be able to continue operating during the replacement. Refer to the power supply specifications section in the "Technical Specifications" for this DCX device to determine your power requirements. If there is insufficient power, the chassis will start powering down blades until the power demand can be met. The device power supplies are 100-240 VAC, autosensing.

NOTE

A chassis with slots for eight port blades can have up to four power supplies installed. If you are adding additional power supplies, you can use the procedures in this section under "Replacing a power supply" to install the new power supplies. Be sure to follow steps on those procedures to enable sending notifications if the additional power supplies should fail.


Time and items required

The replacement procedure for each power supply takes less than five minutes. A power supply unit or filler panel is required for the power supply replacement.

Identifying power supplies

The following figure shows the location and identification of the power supplies.

FIGURE 34 Power supply identification




1. Power supply 1 (PS1)
2. Power supply 2 (PS2)

Removing a power supply

To remove a power supply, complete the following steps.

1. Perform the appropriate following action based on whether the device is operating:
 - If the device is not operating during the replacement procedure, go to step 2.
 - If the device is operating and will continue to operate during the replacement, check the power LEDs to verify that the minimum number of power supplies is functioning. Refer to [Providing power to the device](#) on page 29 to check your power requirements.
2. Turn off the power switch.
3. Unlatch the power cord retainer clip.
4. Remove the power cord.
5. Loosen the thumbscrew.
6. Grasp the handle and pull, sliding the power supply from the chassis and supporting the power supply from beneath as you remove it.

FIGURE 35 Removal and replacement of the power supply



Replacing a power supply

To replace a power supply, complete the following steps.

1. If you are not replacing the power supply, insert a filler panel into the slot.
2. Otherwise, insert the power supply into the slot. Verify that the power supply is seated by gently pulling on the handle.
3. Tighten the thumbscrew.
4. Replace the power cord.
5. Latch the power cord retainer clip.
6. Turn on the power switch.
7. Verify that the power LED on the power supply displays a steady green light.

Blower assembly removal and replacement

Use this procedure to remove and replace a blower assembly.

NOTE

The device can continue operating during the replacement if the second blower assembly is operating. To ensure continuous adequate cooling, maintain two operating blower assemblies at all times except for the brief period when replacing a blower assembly.

Time and items required


The replacement procedure for each blower assembly takes less than 5 minutes. The following items are required for the blower assembly replacement:

- Replacement blower assembly
- #2 Phillips screwdriver

Removing a blower assembly

Complete the following steps to remove a blower assembly from the chassis.

1. Before removing a blower assembly, verify that the other blower assemblies are functioning correctly. The power LEDs should be steady green.
2. Use the screwdriver to loosen the captive screws at the ends of the blower assembly.
3. Grasp the handle and pull, sliding the blower assembly from the chassis and supporting the blower assembly from beneath as you remove it.

FIGURE 36 Removal and replacement of the blower assembly

Replacing a blower assembly

Complete the following steps to replace the blower assembly in a chassis.

1. Orient the blower assembly and slide it into the chassis, pushing firmly to ensure that it is seated.
2. Verify that the power LED displays a green light.
3. Use the screwdriver or your fingers to tighten the captive screws.

WWN card removal and replacement

There are two WWN cards located beneath the WWN bezel (logo plate). As you are facing the bezel on the non-port-side of the chassis, WWN 1 is located on the left side, and WWN 2 is on the right. Before replacing cards, reference RASlog messages and use the WWN Recovery Tool (**wwnrecover**) as directed in the following sections to recover WWN cards. The tool will direct you to contact customer support if recovery fails. In these cases, Brocade Support will determine whether one or both WWN cards need replaced and will request the partner or OEM to send WWN cards from FRU inventory to the nearest Brocade Support office to be reprogrammed.

This section provides information on RASlog messages indicating WWN card problems, the WWN Recovery Tool, and complete steps to remove and replace WWN cards.

The following WWN card replacement procedures are available:

- Hot-swap procedure. Use this procedure when replacing one WWN card only. This procedure is non-disruptive as a system reboot is not required under most conditions.

NOTE

After replacing a WWN card using this procedure, RASlog messages EM-1220 or EM-1222 may indicate that a discrepancy or mismatch is detected between the WWN cards. You must monitor messages for errors and warnings, and then follow directions in messages to use **wwnrecover** for recovery. The **wwnrecover** tool may prompt you to reboot the control processors (CP) if the system is running with invalid IP addresses because the system was booted with a replacement card for WWN card 1.

- System power-down procedure. Use this procedure when replacing both WWN cards. This procedure disrupts system operations. Observe the following when replacing both WWN cards:
 - No additional reboot is required following card replacement after powering the system down.
 - If Brocade support has determined that both WWN cards need replaced, you must power-down the chassis, and then replace both WWN cards as a matched pair.
 - Be aware that if replacing both WWN cards, the IP addresses on the new WWN cards will be in effect when the chassis powers up. If these IP addresses are different from the previous cards, then you will not be able to establish ssh or other sessions that use the previous IP addresses. You can change IP addresses on the new cards using the **ipaddrset** command.

NOTE

If replacing the chassis, you do not need to remove WWN cards from chassis as they ship with replacement chassis.

Time and items required

If there is a need to replace one or both WWN cards, allow approximately 20 minutes. Refer to [Using wwnrecover 7.4](#) on page 100 and [Verifying the need for replacement](#) on page 101 before replacement.

The following items are needed to replace the WWN cards:

- Electrostatic discharge (ESD) grounding strap
- #2 Phillips screwdriver (required only for some versions of the WWN card)
- If a serial console session is used: serial cable and a workstation computer with a terminal emulator application (such as HyperTerminal for Windows systems or TIP for Solaris systems)

Using the wwnrecover utility

The **wwnrecover** utility permits a recovery of WWN card data in the event of corruption. Recovery is not possible if hardware issues prevent access to either WWN card or if the primary and backup copy of the license ID on either card is corrupted. This utility is not available in Fabric OS prior to v7.4.0.

Identical data must be maintained on each WWN card at all times so that if one card fails, the system can use the other card to provide valid system operation. To maintain data and ensure its integrity, the audits both WWN cards one hour after the first system boot-up, every 24 hours after boot-up, and any time a WWN card is inserted to compare the critical data.

If a data mismatch is detected during the audit, messages in the RASlog will provide a summary of all errors detected and prompt you through a data recovery process. The data recovery mechanism may vary depending on the error encountered and the data being compared. Problems such as a mismatch between license IDs cannot be fixed with **wwnrecover**, and the output will direct you to call Brocade Technical Support. For other problems, running **wwnrecover** can pinpoint the problem and, in some cases, permit you to fix it. Mismatched data can be resolved, and corrupt data can sometimes be recovered.

The following table lists RASlog messages that can occur during the WWN card audit routine.

TABLE 16 RASlog messages from WWN card audit

Error message	Issue
[EM-1220]...M1, ERROR ... A problem was found on one or both CID cards (x), please run the wwnrecover tool to get more information and recovery options.	Some kind of error or mismatch has been detected in the WWN card audit.
[EM-1221], ... M1, INFO, ... A WWN card has been inserted, a WWN verification audit will be run to detect any mismatches or other problems.	A second WWN card is enabled and the WWN card audit will be run. If an error is detected during the audit, EM-1220 and EM-1222 messages are generated.
[HIL-1650], CHASSIS, ERROR...Unable to detect WWN card in chassis. Access to WWN halted...	WWN card has been removed from the chassis. Replace as soon as possible since system is in degraded state.
[EM-1222], ... M1, WARNING, ... A WWN card access problem has been encountered, please run the wwnrecover tool to get more information and recovery options.	An error is detected during normal access to the WWN cards; typically, one of the cards is corrupted or inaccessible.
Recovery is not possible. Please contact Brocade Technical Support for replacement of the corrupted or inaccessible WWN(s).	The license ID on the two WWN cards do not match.

The **wwnrecover** utility must be used to maintain data integrity when replacing one or both WWN cards using instructions in the WWN card removal and replacement section. To run **wwnrecover**, log in as admin and enter the following command:

```
switch:admin# wwnrecover
```

For more information on **wwnrecover** and command syntax, refer to the *Fabric OS Command Reference*.

Verifying the need for replacement

Before replacing a WWN card, verify that the replacement is necessary. Any of the following events can indicate that the card requires replacement:

- Status LEDs on the WWN bezel not reflecting the actual status of the components.
- Power or Status LEDs on WWN card (beneath logo plate) indicate a problem.
- Problems viewing or modifying the data stored on the WWN card.
- Error messages regarding WWN units #1 or #2 from the **chassisshow** output.
- If an EM-1220 or EM-1222 error message occurs in the RASlog and WWN card recovery is not successful using **wwnrecover**.

NOTE

In the event of an EM-1220 or EM-1222 error message due to WWN card data corruption or data mismatches across WWN cords, data recovery may be possible using the **wwnrecover** utility. For more information on using this utility, refer to [Using wwnrecover](#) on page 100.

Preparing for WWN card replacement

If the WWN cards require replacement, complete the following steps. Follow electrostatic discharge (ESD) precautions.

**DANGER**

For safety reasons, the ESD wrist strap should contain a series 1 megaohm resistor.

1. Open a Telnet session to the chassis and log in to the active CP as admin. The default password is "password".
2. Verify that you are logged in to the active CP. Run the **haShow** command to determine the active CP.
3. Run the **supportSave** command on the active CP to capture all settings. These settings will be referenced to verify the settings have been correctly programmed after WWN replacement.
4. Contact Brocade Technical Support for replacement of WWN cards. Brocade Support will request the partner or OEM to send WWN cards from FRU inventory to the nearest Brocade Support office to be reprogrammed. Brocade Support will require the **Supportsave** data taken in the previous step so that the replacement cards can be reprogrammed prior to shipping to the partner or your site. If Brocade support has determined that both WWN cards need replaced, you must power-down the chassis, and then replace both WWN cards as a matched pair.

NOTE

Do not execute the **frureplace** command. The command will no longer be functional beginning with the release of Fabric OS 7.0.0c, but users with earlier versions of the Fabric OS should also *not* run the command.

Hot-swap replacement

You may replace one WWN card with the system powered on using the following steps to avoid interruption of system operation.

Use this procedure if Brocade Customer Support has determined that a WWN card needs replaced and you have received replacement cards. These procedures require use of the **wwnrecover** utility. For more information on this utility, refer to [Using wwnrecover](#) on page 100.

You can use this procedure to replace one WWN card at a time while power is on. Follow all steps for one card, and then repeat the same steps to replace the other card. To replace both WWN cards simultaneously, use procedures under [Power-down replacement](#) on page 103.

1. Remove the defective WWN card using procedures under [Removing the WWN card and WWN bezel \(logo plate\)](#) on page 105 applicable to hot-swap replacement of WWN cards.

NOTE

Do not use steps in the WWN card and WWN bezel removal procedures to disable logical switches and power down the chassis.

Removing a WWN card will result in RASlog messages indicating that a WWN card cannot be detected. Since the system will be in a degraded state, install a WWN card as soon as possible.

2. Install the replacement WWN card into the empty slot.

When replacing cards, hold each card by the edges and slide the card into the chassis. Use the Phillips screwdriver and the screws to secure the WWN card to the chassis.

3. Verify that the WWN card is correctly connected by noting if the LEDs on the card reflects the status of the components.
 4. Address any issues flagged by any RASlog EM-1220 and EM-1222 messages that display for the new card before proceeding.
-

NOTE

Issues relating to data recovery on new WWN cards must be resolved at this point before proceeding to avoid invalid WWN data, errors, and operating problems. If EM-1220 messages indicate that IP addresses on installed WWN cards do not match, follow instructions in the message to recover the IP address so that both cards use the same address.

5. Determine the active CP by entering the **haShow** command.
6. On the active CP, run the **wwnrecover** command and specify the WWN card that you replaced (WWN 2 or WWN 1) when prompted.
7. If **wwnrecover** messages prompt for a system reboot, reboot both CPs to ensure the system is running with valid WWN card data.
8. Enter the **hafailover** command to force failover so that the standby CP becomes the active CP. This command is necessary so that the correct IP address for the new card displays for the **ipaddrshow** command. For more information on these commands, refer to the *Fabric OS Command Reference*.
9. Verify the new card settings by running the following commands and comparing the output with the original **supportsave** data:
 - **licenseidshow**
 - **ipaddrshow**
 - **switchname**
 - **chassisname**
 - **wwncardshow ipdata**
 - **chassisshow** (look at the WWN and Chassis information at the bottom)
- 10 If replacing the second WWN card, repeat steps 1-11 for the other card.
- 11 Install the WWN bezel. Orient the bezel on the chassis. Insert and tighten the screws.
- 12 Pack faulty WWN cards in the packaging provided with the replacement cards, and return them to Brocade Support for failure analysis (FA).

Power-down replacement

Use these procedures when you can interrupt system operation and replace one or both WWN cards with the system powered down.

Use this procedure if Brocade Customer Support has determined that a WWN card needs replaced and you have received the replacement card. These procedures require use of the **wwnrecover** utility.

NOTE

You can use this procedure if replacing one or both WWN cards, however you *must* use this procedure if replacing both WWN cards. If Brocade support has determined that both WWN cards need replaced, you must power-down the chassis, and then replace both WWN cards as a matched pair. Obtain replacement cards through your Brocade product support representative.

Follow electrostatic discharge (ESD) precautions. Wear a wrist grounding strap connected to chassis ground (if the chassis is plugged in) or a bench ground.

**DANGER**

*For safety reasons, the **ESD** wrist strap should contain a series 1 megaohm resistor.*

NOTE

Be aware that if replacing both WWN cards, the IP addresses on the new WWN cards will be in effect when the chassis powers up. If these IP addresses are different from the previous cards, then you will not be able to establish ssh or other sessions that use the previous IP addresses. You can change IP addresses on the new cards using the **ipaddrset** command.

1. Unpack the replacement WWN card(s) and save the packaging for the faulty WWN card(s). The WWN cards and cables are labeled #1 for the left slot and #2 for the right slot.
2. Power down the chassis and remove the defective WWN card(s) following appropriate steps under [Removing the WWN card and WWN bezel \(logo plate\)](#) on page 105.

NOTE

There are two WWN cards located beneath the WWN bezel (logo plate). As you are facing the bezel, WWN 1 is located on the left side, and WWN 2 is on the right.

3. Install the replacement WWN card into the empty slot.
When replacing cards, hold each card by the edges and slide the card into the chassis. Use the Phillips screwdriver and the screws to secure the WWN card to the chassis.
4. Power on the chassis and wait for five minutes for the chassis to boot.
5. Verify that the new WWN card is correctly connected by noting if the LEDs on the card reflects the status of the components.

NOTE

The LEDs may take up to two minutes after WWN card installation to begin functioning.

6. Resolve any issues flagged by RASlog EM-1220 and EM-1222 messages that display for the new card(s) before proceeding.

NOTE

Issues relating to data recovery on new WWN cards must be resolved at this point before proceeding to avoid invalid WWN data, errors, and operating problems.

7. Determine the active CP by entering the **haShow** command.
8. On the active CP, run the **wwnrecover** command and specify WWN 2 card for recovery when prompted in **wwnrecover** output messages. Refer to [Using wwnrecover](#) on page 100 for more information on this command.

9. If **wwnrecover** messages prompt for a system reboot, reboot both CPs to ensure the system is running with valid WWN card data.
10. Verify the new card settings by running the following commands and comparing the output with the original **supportsave** data:
 - **licenseidshow**
 - **ipaddrshow**
 - **switchname**
 - **chassisname**
 - **wwncardshow ipdata**
 - **chassisshow** (look at the WWN and Chassis information at the bottom)
11. Run the **switchcfgpersistentenable** command to persistently enable each logical switch, that was disabled before removing the WWN card(s):


```
switch:FID128:root> switchcfgpersistentenable
Switch's persistent state set to 'enabled'
```
12. Install the WWN bezel on the chassis.
 - a) Orient the bezel on the chassis.
 - b) Insert and tighten the screws.
13. Pack faulty WWN cards in the packaging provided with the replacement cards, and return them to Brocade Support for failure analysis (FA).

Removing the WWN card and WWN bezel (logo plate)

Two WWN cards located beneath the WWN bezel (logo plate). As you are facing the bezel on the non-port-side of the chassis, WWN 1 is located on the left side, and WWN 2 is on the right. When cards have been determined faulty and the replacement WWN cards have been received, complete the following steps to remove the bezel and faulty WWN cards.

Follow electrostatic discharge (ESD) precautions. Wear a wrist grounding strap connected to chassis ground (if the chassis is plugged in) or a bench ground.



DANGER

For safety reasons, the ESD wrist strap should contain a series 1 megaohm resistor.

1. Open a Telnet session to the chassis and log in to the active CP as admin. The default password is "password".
2. Verify that you are logged in to the active CP. Run the **haShow** command to determine the active CP.
3. Run the **supportsave** command on the active CP to capture all settings. If any problem occurs during the replacement, the **supportsave** information will be important for solving the problem.
4. Run the following commands on the chassis before replacing the cards so that the data can be verified after the replacement:
 1. **licenseidshow**
 2. **ipaddrshow**
 3. **switchname**
 4. **chassisname**
 5. **wwncardshow ipdata**
 6. **chassisshow** (look at the WWN and Chassis information at the bottom)
 7. **ficonshow switchrnid** (FICON/mainframe environments only)
 8. **configupload**

The factory serial number and the sequence number in the following outputs should match, except in the **ficonshow switchrnid**, which will have a number appended to the front indicating that the logical switch number, if virtual fabrics is enabled:

```
switch:FID128:admin> chassisshow
<output truncated>
WWN Unit: 1
Header Version:      2
Power Consume Factor: -1
Factory Part Num:     60-1000491-05
Factory Serial Num: AFX2533G001
Manufacture:         Day: 19 Month: 1 Year: 2012
Update:              Day: 5 Month: 5 Year: 2014
Time Alive:          756 days
Time Awake:          3 days

WWN Unit: 2
Header Version:      2
Power Consume Factor: -1
Factory Part Num:     60-1000491-05
Factory Serial Num:   AJX0416G02H
Manufacture:         Day: 12 Month: 8 Year: 2011
Update:              Day: 5 Month: 5 Year: 2014
Time Alive:          897 days
Time Awake:          3 days


Chassis Factory Serial Num: AFY2530G00S

switch:admin> ficonshow switchrnid
{
  {Switch WWN          Flag Parm
   10:00:00:05:1e:95:b1:00 0x00 0x200a00
   Type number:          SLKWRM
   Model number:         DCX
   Manufacturer:         BRD
   Plant of Manufacture: CA
   Sequence Number:    0AFX2533G001
   tag:                  b6ff
  }
}
```

5. If performing the power-down replacement procedure, perform the following steps. If hot-swapping WWN cards, skip to step 6.
 - a) Log in to the chassis and execute the **switchcfgpersistentdisable** command on the main switch and other logical switches. The **switchcfgpersistentdisable** command disables the switches, and ensures they remain disabled after the power is cycled. This allows you to check all the settings so that you can verify the settings before placing the chassis back into production.


```
switch:admin> switchcfgpersistentdisable
Switch's persistent state set to 'disabled'
```

If there are other logical switches on your chassis, use the **setcontext** command to connect to all the other switches and then run **switchcfgpersistentdisable** on these switches as well.
 - b) Power down the entire chassis.
6. Remove the screws from the WWN bezel on the back of the chassis. Pull the bezel away from the chassis and set it aside. The two WWN cards are now visible.

FIGURE 37 Removal and replacement of the WWN bezel (logo plate) and WWN card

7. Use a Phillips screwdriver to unscrew the screws that secure the WWN card to the chassis.
8. Depending on the WWN card removed, label the card and cables with #1 for the left side and #2 for the right side for future reference.
9. Hold the WWN card by its edges and gently pull it out from the chassis.
10. Set the WWN card on a static-free surface, such as a grounding pad.

Transceiver and fiber optic cable removal and replacement

Use the procedures in this section to remove and replace fiber optic cables and the various types of transceivers supported on the device.

Blade	Transceiver	Auto-negotiate/Fixed	Speeds supported(xGbps)
FC8-32E and FC8-48E	SFP+	Auto negotiate	2, 4, and 8
FC8-64	mSFP	Auto negotiate	2, 4, and 8
FC16-32 and FC16-48	SFP+	Auto negotiate	2, 4, 8, and 16

Blade	Transceiver	Auto-negotiate/Fixed	Speeds supported(xGbps)
FC16-32 and FC16-48	10-Gbps SFP+	Fixed	10
FC16-64	QSFP	Auto negotiate	4, 8, and 16. However, all the four ports within a quad-SFP should be of the same speed.
CR16-4/8	QSFP	Fixed	16

Time and items required

The replacement procedure for a transceiver takes less than five minutes.

Items required

The following items are needed to replace a transceiver:

- Replacement mSFP, SFP, SFP+, or XFP
- Optical transceiver extraction tool (for SFP, SFP+, and XFP transceivers)

Most Brocade switches and backbones come with a transceiver extraction tool and holster. The extraction tool is designed to remove transceivers from switches and blades where the space is limited.

FIGURE 38 Optical transceiver (SFP+) extraction tool




Removing an SFP+ transceiver


Complete the following steps to remove an SFP+ transceiver.

1. Remove any cables that are inserted into the transceiver. Use the extraction tool to open the cable latching mechanism.
2. Using the hooked end of the tool, pull the bail (wire handle) away from its pivot point and out, sliding the transceiver out of the switch or blade.

The 16 Gbps SFP+ transceivers have an attached pull tab like the mSFPs. Instead of using the tool, simply grasp the pull tab and pull straight out to remove the 16 Gbps SFP+ from the switch or blade. Refer to the illustration for the mSFP transceiver for the basic appearance of the 16 Gbps transceiver.

FIGURE 39 Replacing an optical transceiver

1. Bail

FIGURE 40 Replacing a 16 Gbps SFP+ optical transceiver

Replacing an SFP+ transceiver

Complete the following steps to replace an SFP+ transceiver.

1. Making sure that the bail (wire handle) is in the unlocked position, position the optical transceiver so that the key is oriented correctly to the port. Insert the transceiver into the port until it is firmly seated and the latching mechanism clicks; then close the bail.

The 16 Gbps SFP+ transceivers do not have bails. Use the tab on the 16 Gbps SFP+ transceivers to help gently push the transceiver into the port. Do not push so hard as to bend the tab.

Transceivers are keyed so that they can only be inserted with the correct orientation. If a transceiver does not slide in easily, ensure that it is correctly oriented.

2. Position a cable so that the key (the ridge on one side of the cable connector) is aligned with the slot in the transceiver. Insert the cable into the transceiver until the latching mechanism clicks.

Cables are keyed so that they can be inserted in only one way. If a cable does not slide in easily, ensure that it is correctly oriented. Do not insert a cable intended for an mSFP transceiver into a

regular SFP+ transceiver. You may damage the cable. Do not force a standard SFP cable into an mSFP transceiver. You may damage the transceiver.

Removing and replacing an mSFP optical transceiver and cable

Use the procedures in this section to remove and replace mSFP transceivers. Follow these guidelines while removing and replacing mSFP transceivers.


- Do not use the SFP+ extraction tool to remove the mSFP transceivers.
- The mSFP transceivers are used only with the FC8-64 port blade. Narrower OM-3 LC cables are used to connect the FC8-64.
- It is recommended that the optical cable should be either removed from or inserted into the mSFP while the transceiver is out of the blade due to the port density.
- mSFP optical transceivers should not be inserted into ports intended for SFP+ transceivers. They will be faulted on power-up for Fabric OS 7.0.0 and later.
- Cables for mSFP transceivers should not be used with standard SFP+ transceivers.
- The pull tabs are not designed to be bent. Doing so may result in damage to the pull tab.

Removing an mSFP transceiver

Complete the following steps to remove an mSFP transceiver.

1. Grasp the pull tab firmly and pull the unit out of the port.
2. Remove the cable from the transceiver.

FIGURE 41 Optical mSFP transceiver



1. Pull tab
2. mSFP transceiver

Replacing an mSFP transceiver

Complete the following steps to replace an mSFP transceiver.

1. Insert the cable into the new transceiver until the latching mechanism clicks.
2. Position the optical transceiver so that the key is oriented correctly to the port. Insert the transceiver into the port until it is firmly seated and the latching mechanism clicks.

Transceivers are keyed so that they can only be inserted with the correct orientation. If a transceiver does not slide in easily, ensure that it is correctly oriented.

Removing and replacing a QSFP and cable

Use this procedure to remove and replace QSFP transceivers and cables supported on the FC16-64 port blades and core switch blades. Do not use the extraction tool to remove the QSFP transceivers. Follow these guidelines while removing and replacing QSFP transceivers:

- The QSFP transceivers are used only with the FC16-64 port blades and core switch blades. However, the part numbers of QSFP transceivers supported on FC16-64 port blade and the core blades are not the same and are not interchangeable.
- For QSFPs with separate transceivers and optical cables, it is recommended that the cable be either removed from or inserted into the QSFP while the transceiver is out of the blade due to the port density.
- The pull tabs on QSFPs are not designed to be bent. Doing so may result in damage to the pull tab.

Qualified transceivers for the FC16-64 and CR16-x blades

The following table shows the qualified transceivers for the FC16-64 port blade and the CR16-4/8 core blades.

TABLE 17 Qualified transceivers for FC16-64 port blade and the CR16-x core blades

Brocade part number	Part type	Cable length	Port speeds	Supported blades
57-1000310-01	QSFP transceiver with integrated 3 m optical cable	Supports 2 km	16 Gbps	CR16-4/8 See Note below.
57-1000294-01	QSFP transceiver	100 m OM4	Auto-negotiable 4-, 8-, and 16-Gbps	FC16-64 See Note below.
57-1000267-01	QSFP transceiver	100 m OM4	Only fixed 16-Gbps	CR16-4/8
57-0000090-01	QSFP transceiver	50 m OM3	Only fixed 16-Gbps	CR16-4/8

NOTE


The QSFP transceivers supported on FC16-64 port blade are not interchangeable with QSFP transceivers supported on the CR16-4/8 core blades.

Removing a QSFP transceiver and cable

QSFP transceivers are of three types:


- Transceiver with separate cable and a bail-type latch.

FIGURE 42 QSFP transceiver (bail open)



1. MTP cable
 2. Bail
 3. Transceiver
- Transceiver with integrated cable and pull-tab.

FIGURE 43 2 km LWL QSFP transceiver with pull-tab and integrated cable



1. MTP 1x12 fiber male connector
 2. Integrated 3 meter MTP cable
 3. Transceiver with pull-tab
- Transceiver with separate cable and pull-tab. A third type of transceiver has a pull-tab to remove the transceiver from the blade port connector (like shown in previous illustration) but a separate MTP cable that plugs into the transceiver.

Complete the following steps to remove a MTP cable and transceiver.

1. For a transceiver with a bail-type latch and removable cable, perform the following steps:
 - a) Remove the cable by grasping the rubber housing on the end of the cable and pulling it straight out of the QSFP transceiver.
 - b) If the QSFP transceiver also needs to be replaced, remove it by rotating the bail down and using the bail to pull the transceiver out of the connector on the blade.
 - c) Repeat step a or b for each cable or transceiver that requires replacement.
2. For a transceiver with integrated cable and pull-tab, perform the following steps:
 - a) Grasp the pull tab and firmly, but gently, pull until transceiver releases from connector and blade port.
 - b) Slide the transceiver and cable from the port.
 - c) Repeat step a or b for each cable or transceiver that requires replacement.
3. For a transceiver with removable cable and a pull-tab, perform the following steps:
 - a) Remove the cable by grasping the rubber housing on the end of the cable and pulling it straight out of the QSFP transceiver.
 - b) If the QSFP transceiver also needs to be replaced, remove it by grasping the pull tab and firmly, but gently, pulling until the transceiver releases from connector and blade port.

Replacing a QSFP transceiver and cable

Complete the following steps to replace a QSFP transceiver and fiber optic cable.

1. If replacing a transceiver that has a separate cable and a bail-type latch, perform the following steps:
 - a) Grasp the bail of the new QSFP and push the QSFP into the connector in the blade port until it is firmly seated. The QSFP is keyed to fit into the connector in one way.
The status LED initially blinks amber after installation, then displays steady amber.
 - b) Grasp the QSFP cable by the rubber housing and push it into the QSFP transceiver until it is firmly seated. The cable housing is keyed to fit into the QSFP in one way.
The status LED displays steady amber until both ends of the cable are inserted and the link is established. When the link is fully established, the LED displays steady green.
 - c) Repeat for each cable that requires replacement.
 - d) Once all the cables are attached, refer to the *Fabric OS Administrator's Guide* for the configuration procedure.
2. If replacing a transceiver that has an integrated cable and pull-tab, perform the following steps:
 - a) Align the transceiver with the blade port. Grasp the transceiver body and firmly, but gently, push it into the port. The transceiver is keyed to fit into the connector in one way
 - b) Press firmly on the front of the transceiver with your thumb to fully seat into the blade connector.
The status LED displays steady amber until both ends of the cable are inserted and the link is established. When the link is fully established, the LED displays steady green.
3. Repeat step 1 or 2 for each transceiver that requires replacement.
4. Once all the transceivers are installed, refer to the *Fabric OS Administrator's Guide* for the configuration procedure.

Chassis removal and replacement

This section describes how to remove and replace the chassis with its backplane. The basic steps are:

1. [Faulty chassis indicators](#) on page 114.
2. [Recording critical device and SAN information](#) on page 114.
3. [Disconnecting from network and fabric](#) on page 118.
4. [Removing components from the chassis](#) on page 118.
5. [Installing the replacement chassis](#) on page 119.
6. [Installing components into the chassis](#) on page 119.
7. [Downloading the configuration](#) on page 120.
8. [Verifying correct operation of system](#) on page 121.
9. [Reconnecting the system to the network and fabric](#) on page 122.
10. [Verifying correct configuration of the fabric](#) on page 122.

NOTE

The device must be removed from the fabric and powered off to perform this procedure. Contact your support provider if you have any questions about whether the chassis requires replacement.

Time and items required

The chassis replacement takes approximately 3 hours.

The following items are required for the chassis replacement:

- Electrostatic discharge (ESD) grounding strap
- ESD grounding pads for protecting all blades and WWN cards
- Serial cable and workstation computer with a terminal emulator application (such as HyperTerminal for Windows systems or TIP for Solaris systems), required only if serial console session used
- Pallet jack or hydraulic or assisted lift that raises a minimum of 140 cm (55 in.) and carries a minimum of 113 kg (250 lb)
- A surface on which to place the old chassis, such as a second lift or the pallet originally provided with the old chassis
- #2 Phillips screwdriver

Faulty chassis indicators

Verify that replacement of the chassis is necessary. Ensure that the components are firmly seated when troubleshooting, and contact your support provider with any questions about whether the chassis should be replaced.

Any of the following events might indicate the need to replace the chassis:

- Visible mechanical damage to the chassis, including damage to sheet metal or card guides that prevents correct installation of a blade.
- Bent or damaged connectors on the backplane (the surface inside the chassis to which the blades connect).
- One or more components (such as a power supply, blower assembly, port blade, control processor blade, core switch blade, or WWN card) do not function properly even after the component was replaced.
- Intermittent FAULTY codes for blades. Reseat the blade and visually inspect the right ejector stiffening rail for possible wear or damage. It is important that the blade ejector handles not slip out during blade installation. If this happens, it is usually due to excessive wear or damage to the right-hand ejector stiffening rail.
- The **psShow** or **fanShow** commands continue to show a faulty component even though the component was replaced.
- The **slotShow** command continues to show a faulty control processor, core switch, or port blade even though the blade was replaced.

Recording critical device and SAN information

All commands must be entered from a CLI session (Telnet or serial) to the active CP blade unless otherwise indicated.

NOTE

Run **supportShow**, which includes most of the information in the following table and more. The customer should record the location of the .txt files, which are created by the customer in this procedure and are not called out in the **supportShow** results.

For detailed information about Fabric OS commands, refer to the *Fabric OS Command Reference*. Use a checklist to ensure that all required information is recorded.

TABLE 18 Critical information checklist

Checked?	Data	Notes
Configuration information		
	Location of "config-switch.txt" file	
	Location of "config-miscinfo.txt" file	
	IP address, subnet mask	
	WWN for the device	
SAN profile		
	Location of "SANbefor.txt" file	
	Notes regarding nsshow output	
	Notes regarding nsallshow output	
	Notes regarding switchshow output	
	Notes regarding fabricshow output	
Output from licenseshow command		
	License keys and other licensing data for licensed products enabled on device.	
Output from supportshow command		
	Location of "sptshow.txt" file	
	Notes regarding supportshow output	
Information about the new chassis		
	New factory serial number	
	New serial number (if available)	

1. Open a Telnet session and log in to the device as **admin**. The default password is *password*. Enable the logging function on your Telnet or serial console connection.
2. Back up the current configuration.

NOTE

If you are using the Virtual Fabric feature, you should run **configupload -vf** before running the **configupload** command to save the logical switch configuration.

- Enter **configUpload -all**; then enter the requested information at the prompts.

This command uploads the device configuration to the customer-defined FTP server, making it available for downloading. For more information about this command, refer to the *Fabric OS Command Reference*.

```
switch:admin> configupload
Protocol (scp or ftp) [ftp]: ftp
Server Name or IP Address [host]: 123.123.123.123
User Name [user]: Admin24
File Name [config.txt]: config-switch0.txt
Password:
Upload complete
switch:admin>
```

- Alternatively, you can save the configuration file to a Brocade USB device.

3. Record the WWN value: Enter **wwn**; then copy the command output into a file named config-miscinfo.txt.

```
switch:admin> wwn
10:00:00:60:69:00:00:0a
```

4. Record the IP address information.

Enter **ipAddrShow -sw**; then copy the command output into the config-miscinfo.txt file.

```
switch:admin> ipaddrshow -sw
SWITCH
Ethernet IP Address: 10.32.50.12
Ethernet Subnetmask: 255.55.0.0
Fibre Channel IP Address: 1.2.3.4
Fibre Channel Subnetmask: 255.255.255.0
CP0
Ethernet IP Address: 10.32.50.10
Ethernet Subnetmask: 255.55.0.0
HostName : cp0
Gateway Address: 10.32.40.1
CP1
Ethernet IP Address: 10.32.50.11
Ethernet Subnetmask: 255.55.0.0
HostName : cp1
Gateway Address: 10.32.40.1
Backplane IP address of CP0 : 10.0.0.6
Backplane IP address of CP1 : 10.0.0.7
switch:admin>switch:admin>
```

5. Display and record the manufacturer serial numbers.

Enter **chassisShow**; then copy the command output into the config-miscinfo.txt file.

"Factory Serial Num" and "Serial Num" are listed under "Chassis/WWN Unit 1." If the current WWN cards are the original cards, the factory serial number listed is the same as the chassis serial number.

```
switch:admin> chassisshow
Chassis Backplane Revision: 1F
SW BLADE Slot: 1
Header Version: 2
Power Consume Factor: -50
Factory Part Num: 60-0001532-03
Factory Serial Num: KP000000195
Manufacture: Day: 1 Month: 1 Year: 2007
Update: Day: 14 Month: 3 Year: 2012
Time Alive: 187 days
Time Awake: 3 days
<output truncated>
CHASSIS/WWN Unit: 1 (in same assembly as WWN Unit: 2)
Header Version: 2
```

```

Power Consume Factor:    -3
Factory Part Num:       60-0001501-07
Factory Serial Num:     FT02X805BE2
Manufacture:            Day: 26  Month: 3  Year: 2007
Update:                 Day: 14  Month: 3  Year: 2009
Time Alive:             207 days
Time Awake:             3 days
<output truncated>
switch:admin>

```

6. Create a SAN "profile" by entering and recording the information provided by the following commands:

- **nsShow**
- **nsAllShow**
- **switchShow -qsf**
- **fabricShow**

Copy the command output into a text file named "SANbefor.txt." After the device is restored to the fabric, this information can be used to verify that no unintentional changes have occurred to the fabric.

```

switch:admin> nsshow
Enter Pid COS PortName NodeName TTL
<output truncated>
switch:admin> nsallshow
12 Nx Ports in the Fabric
<output truncated>
switch:admin> switchshow
switchName: switch
<output truncated>
switch:admin> fabricshow
Switch ID Worldwide Name Enet IP Addr FC IP Addr Name
<output truncated>
switch:admin>

```

7. Enter **licenseShow**; then copy the command output into a text file named "licenseshow.txt."

```

switch:admin> licenseshow
S9bddb9SQbTAceeC:
Fabric license
eezeRRySff0fSe:
Remote Switch license
bzbzRcbcSc0c0SY:
Remote Fabric license
dSeR9RcSeeTfSAq:
Extended Fabric license
RyeSzRScycTzfT09:
Entry Fabric license
RyeSzRScyczfT0G:
Trunking license
RyeSzRScycS0fT09:
4 Domain Fabric license

```

8. Enter **supportShow**; then copy the command output into a text file named "spptshow.txt."

NOTE

The **supportShow** command has a very long output and time for completion. It may last 20 minutes or longer depending on the size of the SAN.

This file provides a backup of all the information that might be required by Technical Support. The information can be used after the device is restored to the fabric to verify that no unintentional changes have occurred to the fabric.

```

switch:admin> supportshow
version: 7.4.0
<output truncated>
switch:admin>

```

9. Record the cable connections between the chassis and the target device and ports.
- 10 Run **supportSave** on the active CP. The information recorded can be very important in case you have difficulties during the replacement process.

Disconnecting from network and fabric

Complete the following steps to disconnect the chassis from the network.

1. Shut down the device using the **sysShutdown** command on the active CP.

```
switch:admin> sysshutdown
This command will shutdown the operating systems on your switch.
You are required to power-cycle the switch in order to restore operation.
Are you sure you want to shutdown the switch [y/n]?y
HA is disabled
Stopping blade 1
Shutting down the blade....
Stopping blade 2
Shutting down the blade....
Stopping blade 8
Shutting down the blade....
Broadcast message from root (pts/1) Tue Jul 18 14:23:06 2008...
The system is going down for system halt NOW !!
```



DANGER

Disconnect the power cord from all power sources to completely remove power from the device.

2. Power off the chassis by flipping all AC power switches to the off position. (The power supply status LED should turn off.)
3. Remove the power cords from the power supplies and the power outlets.
4. Remove the chassis door.
5. Label the cables connected to all blades and record the connections.
6. Disconnect the cables from the SFP+ transceivers in the application and port blades and set them aside. If you have mSFP transceivers in FC8-64 port blades, or QSFP transceivers in FC16-64 port blades, remove the transceivers and cables together and set them aside. The SFP+ transceivers can be left in the port blades or removed.
7. Disconnect all cables from the control processor and core switch blades.
8. Disconnect any ICL or QSFP cables.

Removing components from the chassis

Follow electrostatic discharge (ESD) precautions when removing components. Wear a wrist grounding strap connected to chassis ground (if the device is plugged in) or a bench ground.

NOTE

You do not need to remove WWN cards from the chassis as new WWN cards are shipped with the replacement chassis.



DANGER

For safety reasons, the ESD wrist strap should contain a series 1 megaohm resistor.

1. Remove the chassis door ([Chassis door removal and replacement](#) on page 76) if not already done.
2. Remove the cable management finger assemblies ([Vertical cable management fingers removal and replacement](#) on page 77).

3. Remove the port blades or filler panels ([Port and application blade removal and replacement](#) on page 78 and [Blade filler panel removal and replacement](#) on page 82).
4. Remove the core switch blades (CR16-x) ([Core switch blade \(CR16-x\) removal and replacement](#) on page 93).
5. Remove the control processor blades (CP8) ([Control processor blade \(CP8\) removal and replacement](#) on page 83).
6. Remove the power supplies or filler panels ([Power supply removal and replacement](#) on page 96).
7. Remove the blower assemblies ([Blower assembly removal and replacement](#) on page 98).

Installing the replacement chassis

Complete the following steps to install the replacement chassis.



DANGER

Use safe lifting practices when moving the product.



DANGER

A completely empty Brocade DCX 8510-4 chassis weighs approximately 25.4 kg (56 lb) and requires a hydraulic or assisted lift to install it.



DANGER

Make sure the rack housing the device is adequately secured to prevent it from becoming unstable or falling over.

1. If the chassis is in a cabinet, remove it from the cabinet.
2. Place the chassis on a lift or on the shipping pallet provided with the original chassis.
3. Unpack the new chassis:
 - a) Cut the bands that encircle the packaging.
 - b) Remove the lid and the kits and foam from the top of the chassis.
 - c) Lift the cardboard box off the chassis and remove the plastic bag from around the chassis. Save the packing materials for use when returning the old chassis.
 - d) Leave the chassis on top of the plastic shipping tray if the chassis must be transported to the installation location.

NOTE

The device packaging does not incorporate a wood pallet and pallet brackets. The chassis sits on top of a plastic shipping tray.

4. Use a pallet jack or other assisted lift to transport the new chassis to the installation area. Doorways must be wider than 91 cm (36 in.) to accommodate the chassis on the pallet.
5. Use a lift to raise the chassis to the correct level. If installing the chassis in a cabinet, follow the instructions provided by the rack kit manufacturer.

Installing components into the chassis

Follow electrostatic discharge (ESD) precautions when installing new components. Wear a wrist grounding strap connected to chassis ground (if the device is plugged in) or a bench ground.



DANGER

For safety reasons, the ESD wrist strap should contain a series 1 megaohm resistor.

1. Replace the blower assemblies ([Blower assembly removal and replacement](#) on page 98).
2. Replace the power supplies or filler panels ([Power supply removal and replacement](#) on page 96).
3. Replace the control processor blades (CP8) ([Control processor blade \(CP8\) removal and replacement](#) on page 83).
4. Replace the core switch blades (CR16-x) ([Core switch blade \(CR16-x\) removal and replacement](#) on page 93).
5. If ICL cables are not used, insert EMI plugs in the ICL sockets in the core switch blades (CR16-x).
6. Replace the port blades or filler panels ([Port and application blade removal and replacement](#) on page 78 and [Blade filler panel removal and replacement](#) on page 82).
7. Replace the cable management finger assemblies ([Vertical cable management fingers removal and replacement](#) on page 77).
8. Connect the power cords to the power supplies and the power outlets.
9. Replace the chassis door ([Chassis door removal and replacement](#) on page 76).
10. Power on the device ([Providing power to the device](#) on page 29).

The device performs a power-on self-test (POST). The POST takes a minimum of three minutes and is complete when LED activity returns to the standard state.

11. Verify that the device is powered on and POST is complete (all power LED indicators on the blades should be a steady green).
12. Verify that all components are functioning correctly by checking their LEDs. If the LEDs do not indicate correct operation, try reinstalling the corresponding component.

Downloading the configuration

Once the chassis and its various components have been reassembled and powered back on, use the **configDownload** command to restore the original configuration. The **configDownload** command can be entered through a Telnet or serial session, but the device must have an Ethernet connection to the server name or IP address of the host for the download process to complete. For more information, refer to the **help configdownload** command or the *Fabric OS Command Reference*.

Complete the following steps to download the configuration.

1. Log in to the device as **admin**.

```
switch:admin> login
login: admin
password: xxxxxxxx
switch:admin>
```

NOTE

If you are using the Virtual Fabric feature, you must run **configdownload -vf** before running the **configdownload** command to restore the logical switch configuration.

2. Enter the **chassisDisable** command.
3. Enter the **configDownload** command.

```
switch:admin> configdownload -all
Server Name or IP Address [host]: 123.123.123.123
User Name [None]: Admin24
File Name [config.txt]: config-switch.txt
Password: xxxxxxxx
```



```
download complete
switch:admin>
```

4. Reboot the device.

Verifying correct operation of system

Complete the following steps to verify the correct operation of the device.

1. Log in to the device as **admin**.

```
switch:admin> login
login: admin
password: xxxxxxxx
switch:admin>
```

2. Enter the **slotShow -m** command and verify that all the installed cards are detected and that their status is operational (enabled).

```
switch:admin> slotShow -m
```

Slot	Blade Type	ID	Model Name	Status
1	SW BLADE	97	FC16-32	ENABLED
2	SW BLADE	77	FC8-64	ENABLED
3	CORE BLADE	99	CR16-4	ENABLED
4	CP BLADE	50	CP8	ENABLED
5	CP BLADE	50	CP8	ENABLED
6	CORE BLADE	99	CR16-4	ENABLED
7	SW BLADE	96	FC16-48	ENABLED
8	SW BLADE	77	FC8-64	ENABLED

3. Verify that the device is functioning correctly by entering **switchShow** or **switchStatusShow**.

This **switchShow** command displays the device and port status information. The example is from a DCX 8510-8. The other backbone chassis are similar.

```
DCX-4_130:admin> switchshow
switchName:      DCX8510-4_130
switchType:      121.3
switchState:      Online
switchMode:      Native
switchRole:      Principal
switchDomain:     130
switchId:         fffc82
switchWwn:        10:00:00:05:33:03:2c:00
zoning:          ON (ZONE_CONFIG_NAME)
switchBeacon:     OFF
FC Router:       ON
FC Router BB Fabric ID: 10
Address Mode:     0
```

Index	Slot	Port	Address	Media	Speed	State	Proto
0	1	0	820000	id	N8	Online	FC F-Port
10:00:00:05:1e:f8:a0:b4							
1	1	1	820100	id	N8	Online	FC F-Port 10:00:00:05:33:26:0e:
65							
2	1	2	820200	id	N8	Online	FC F-Port
10:00:00:05:33:48:5e:f5							
3	1	3	820300	id	N8	Online	FC F-Port
10:00:00:05:1e:f8:a0:b3							

(output truncated)

4. Verify that all the IP address information is correct by entering **ipAddrShow** and checking the results against the IP information recorded in the config-miscinfo.txt file.

```
switch:admin> ipaddrshow
SWITCH
Ethernet IP Address: xxx.xxx.xxx.12
Ethernet Subnetmask: 255.55.0.0
Fibre Channel IP Address: 1.2.3.4
Fibre Channel Subnetmask: 255.255.255.0
CP0
Ethernet IP Address: xxx.xxx.xxx.10
Ethernet Subnetmask: 255.55.0.0
```

```
HostName : cp0
Gateway Address: xxx.xxx.xxx.1
CP1
Ethernet IP Address: xxx.xxx.xxx.11
Ethernet Subnetmask: 255.55.0.0
HostName : cp1
Gateway Address: .1
Backplane IP address of CP0 : 10.0.0.4
Backplane IP address of CP1 : 10.0.0.5
switch:admin>switch:admin>
```

Reconnecting the system to the network and fabric

Refer to the cable routing information recorded in Cable Routing table in this section for the following steps.

Complete the following steps to reconnect the device to the network and fabric.

1. Connect the CP blades to the local area network.
 - a) Insert the appropriate Ethernet cables into each Ethernet port.
 - b) Connect the other ends to an appropriate Ethernet LAN, if not already connected.

NOTE

The device can be accessed by remote connection using any of the available management tools, such as Telnet or Web Tools. Ensure that the device is not modified using other connections during the rest of this procedure.

2. Reconnect the transceivers and cables to the port blades.

NOTE

The ports and cables used in trunking groups must meet specific requirements. For a list of these requirements, refer to the *Fabric OS Administrator's Guide*.

- a) Position one of the transceivers so that the key is oriented correctly to the port and insert the transceiver into the port until it is firmly seated and the latching mechanism clicks.
- b) Select the cable that corresponds to the port and position it so that the key (the ridge on one side of the cable connector) is aligned with the slot in the transceiver. Insert the cable into the transceiver until the latching mechanism clicks.
- c) Repeat step a and step b for the remaining ports.
- d) Organize the cables as required.

NOTE

Do not route cables in front of the air exhaust vents.

Verifying correct configuration of the fabric

Copying the command outputs from this section into a file is recommended. You must be logged in with Admin privileges.

1. Create an "after" SAN profile by entering the following commands and copying the output to a text file named SANafter.txt:

- **nsShow**
- **nsAllShow**
- **switchShow**

- **fabricShow**
- **lscfg --show** (if using the Virtual Fabric feature)

```
switch:admin> nsshow
Type Pid      COS      PortName NodeName TTL(sec)
N      020f00;    3;10:00:00:01:73:00:29:46;10:00:00:01:73:00:29:46; na
      Fabric Port Name: 20:0f:00:60:69:90:03:f0
<output truncated>
switch:admin> nsallshow
{
  020f00 021fda 021fdc 021fe0 021fe1
  5 Nx Ports in the Fabric}
switch:admin> switchshow
switchName: rsl8-st03-dcx-01
<output truncated>
switch:admin> fabricshow
Switch ID Worldwide Name Enet IP Addr FC IP Addr Name
<output truncated>
switch:admin> lscfg --show
Created switches: 128(ds) 1 2(bs)
Port          0      1      2      3      4      5      6      7      8      9
-----
FID           1 | 1 | 1 | 1 | 1 | 128 | 128 | 128 | 128 | 128 |
<output truncated>
switch:admin>
```

- Determine any differences between the information in the SANafter.txt file and the information in the SANbefor.txt file created earlier. In particular, look for differences in the following:
 - Device types
 - Number of devices
 - ISL and port states
 - Number of switches in the fabric
- Resolve any issues or unintentional changes to the device or fabric:
 - If there are any mechanical problems, try reseating the associated component.
 - If the configuration information is not correct for the device, modify as required.
 - If other issues exist, contact your support provider.

Cable routing table

The following table is a 64-port template for a cable routing table. Make copies of the table to cover the total number of ports in the device.

TABLE 19 Cable routing table for 64 ports

Slot/port	Cable labels		Connected device	Slot/port of device
Slot	Port	Switch end	Device end	
0				
1				
2				
3				
4				
5				

TABLE 19 Cable routing table for 64 ports (Continued)

Slot/port	Cable labels	Connected device	Slot/port of device
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			
17			
18			
19			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
30			
31			

TABLE 19 Cable routing table for 64 ports (Continued)

Slot/port	Cable labels	Connected device	Slot/port of device
32			
33			
34			
35			
36			
37			
38			
39			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
50			
51			
52			
53			
54			
55			
56			
57			

TABLE 19 Cable routing table for 64 ports (Continued)

Slot/port	Cable labels	Connected device	Slot/port of device
58			
59			
60			
61			
62			
63			

Application and Encryption Blades

• Introduction.....	127
• FS8-18 blade.....	127
• FX8-24 blade.....	127

Introduction

This appendix provides details about the application and encryption blades that are available optionally for the device. Contact your device supplier for additional information.

FS8-18 blade

The FS8-18 encryption blade is a high performance 16-port autosensing blade with data cryptographic (encryption/decryption) and data compression capabilities designed for enterprises to secure their data against theft or unauthorized use and to compress tape data for maximum utilization of tape media. The encryption blade is a network-based solution that secures data-at-rest for heterogeneous tape drives, disk array LUNs, and virtual tape libraries.

The FS8-18 blade provides the following major features:

- 16 autosensing F_Ports, FL_Ports, E_Ports, EX_Ports, and M_Ports at 8 Gbps FC ports
- 16 SFP media interfaces
- Encryption engines
- Key management/generation
- Key management with these hardware interfaces:
 - Two 1000Base copper type media interfaces
 - One smart card interface
- Security supervisor tamper detection and response capability
- Common Criteria (CC) EAL-3 compliant

FX8-24 blade

The FX8-24 blade has 12 external Fibre Channel (FC) SFP ports supporting the Fibre Channel Routing Services and 10 external 1 Gigabit Ethernet (GbE or GE) SFP ports supporting the Fibre Channel Over IP (FCIP) feature. There are also 2 licensable external 10 Gigabit Ethernet (10-GbE or 10-GE) SFP ports supporting FCIP. It operates with the Brocade Fabric Operating System and can communicate with another FX8-24 or a Brocade 7800 for both Fibre Channel Routing Services and FCIP, or a Brocade AP7420 for Fibre Channel Routing Services. The GbE ports on the FX8-24 are not compatible with the GbE ports on the FR4-18i blade, the Brocade 7500 switch, and the Brocade 7840 switch.

NOTE

The port diagram on the front panel uses the abbreviations GE for 1-GbE ports and 10 GE for 10-GbE ports.

NOTE

The 10-GbE SFPs used in the FX8-24 blade and the 10-Gbps FC SFPs used in the FC16-32/48 blades are not interchangeable.

The FX8-24 operates in one of three modes: 1) ten 1-GbE ports, 2) ten 1-GbE ports and one 10-GbE port, or 3) two 10-GbE ports depending on licensing and subsequent configuration of GbE port mode. If operating in 10-GbE mode, the other end of the circuit must also be an FX8-24 operating in either 10-GbE mode or dual mode with the corresponding VE_ports in 10-GbE mode. All GbE ports on the blade can be configured to work with either copper or optical SFPs.

The FX8-24 blade is intended as a platform for FCIP and Fibre Channel Routing Services. Refer to the *Fabric OS Administrator's Guide* for information on configuring these features.

The FX8-24 blade provides the following hardware features:

- 12 autosensing FC ports with link speeds of 1, 2, 4, or 8 Gbps
- Ten GbE ports supporting FCIP with fixed link speed at 1 Gbps
- Two 10 GbE ports (licensable) supporting FCIP with fixed link speed at 10 Gbps

The FX8-24 blade also provides the following functionality features:

- FCIP
- Compression (on FC frames before FCIP encapsulation)
- FC Routing (licensable)
- FCIP Trunking (licensable) with network-based failure recovery (failover only) and load balancing
- Multiple circuits per trunk:
 - Four per trunk through the GbE ports
 - Ten per trunk through the 10 GbE ports
- SO-TCP with reorder resistance
- FastWrite over FCIP
- Tape pipelining over FCIP
- FICON XRC emulation and tape pipelining over FCIP (licensable)
- FICON CUP (licensable)
- Virtual E_Ports
- FCIP QoS
- Support for 200 ms RTT (on a limited number of GbE ports)
- Adaptive Rate Limiting (licensable)
- TCP performance graphing in Web Tools
- FCIP Tunnels:
 - A maximum of 10 FCIP Tunnels for all GbE ports
 - Four tunnels maximum per GbE port
 - Two 10 GbE ports can support up to ten FCIP tunnels each
 - Each FCIP tunnel is represented and managed as a virtual Fibre Channel E_Port
 - Fibre Channel Routing Services can be used over the FCIP link
 - The Link Cost is equal to the sum of all established/low metric (or currently active) circuits' MAX rates in the tunnel.
 - Fabrics connected through FCIP merge if the ports are configured as VE_Ports, and do not merge if they are configured as VEX_Ports. If VE_Ports are used in a Fibre Channel Routing

Services backbone fabric configuration, then the backbone fabric merges, but the EX_Port-attached edge fabrics do not merge. For more information, refer to the *Fabric OS Administrator's Guide*.

- Up to three FC trunking groups:
 - Trunk group 0: FC ports 0, 1
 - Trunk group 1: FC ports 6, 7
 - Trunk group 2: FC ports 2, 3, 4, 5, 8, 9, 10, 11


A RoHS-compliant version of the FX8-24 blade is available. To determine if this blade is installed, enter the **chassisshow** command. Output for the Factory Part Number will be 60-1003135-XX. Downgrading to these FOS versions is also not recommended if this blade is installed.

Port Numbering Templates

- CR16-4 core blade port numbering..... 131
- FC8-32E port blade port numbering..... 133
- FC8-48E port blade port numbering..... 133
- FC8-64 port blade port numbering..... 134
- FC16-32 port blade port numbering..... 134
- FC16-48 port blade port numbering..... 135
- FC16-64 port blade port numbering..... 135
- FS8-18 encryption blade port numbering..... 135
- FX8-24 extension blade port numbering..... 136

CR16-4 core blade port numbering

FIGURE 44 CR16-4 core blade port numbering



- 1. Port map
- 2. QSFP ports 4-7 (right to left)
- 3. QSFP ports 0-3 (right to left)

The following table shows the mappings from the numbered ports on the face of the core blade to the port mappings as shown by the **slotShow** command. Each external port maps to four actual ports. The CR16-4 core blade has external ports 0 through 7 only.

TABLE 20 External port to slotShow port mapping for core blades

External port number	slotShow port numbers
0	0-3
1	4-7
2	8-11
3	12-15
4	16-19
5	20-23

TABLE 20 External port to slotShow port mapping for core blades (Continued)

External port number	slotShow port numbers
6	24-27
7	28-31

FC8-32E port blade port numbering




FIGURE 45 FC8-32E port blade port numbering

FC8-48E port blade port numbering




FIGURE 46 FC8-48E port blade port numbering

FC8-64 port blade port numbering




FIGURE 47 FC8-64 port blade port numbering

FC16-32 port blade port numbering




FIGURE 48 FC16-32 port blade port numbering

FC16-48 port blade port numbering




FIGURE 49 FC16-48 port blade port numbering

FC16-64 port blade port numbering





FIGURE 50 FC16-64 port blade port numbering


FS8-18 encryption blade port numbering



- 1 Gigabit Ethernet ports GE0-GE1
- 2 Smart card port
- 3 Fibre Channel ports 0-15 (right to left)

FIGURE 51 FS8-18 encryption blade port numbering

FX8-24 extension blade port numbering



- 1 10-GbE ports 0-1 (right to left)
- 2 1-GbE ports 0-3 (right to left)
- 3 1-GbE ports 4-9 (right to left)
- 4 FC ports 6-11 (right to left)
- 5 FC ports 0-5 (right to left)
- 6 Blade Power LED
- 7 Blade Status LED

FIGURE 52 FX8-24 extension blade port numbering

Diagnostics and Troubleshooting

- Introduction..... 137
- Obtaining chassis and component status..... 137
- Interpreting POST and boot results..... 138
- Diagnostics..... 139
- Troubleshooting..... 139

Introduction

For information about troubleshooting the entire fabric, refer to the *Fabric OS Troubleshooting and Diagnostics Guide*.

The device includes a number of diagnostic aids to assist with troubleshooting, including LEDs on the hardware, commands that display current status, diagnostic tests for hardware and software, and error messages. In addition, a number of managing and monitoring features are available, such as Fabric Manager, Web Tools, Fabric Watch, and Advanced Performance Monitoring.

If the device does not operate as expected, the following steps can be taken to diagnose the problem:

- Check the LEDs on system components on the front and back of the device and refer to the LED tables in the "System Monitoring" section for interpretation and recommended actions.
- Review the results of the last POST run by the device and refer to the "Interpreting POST and boot results" section for more information.
- Review the error logs. Refer to the *Fabric OS Troubleshooting and Diagnostics Guide* for more information.
 - Review RASlog entries.
 - Use the **sensorShow** command to determine the status of the hardware components.
 - Refer to "Diagnostics" in the "Diagnostics and Troubleshooting" section to run diagnostic tests.
 - Reboot the device or power the entire chassis off and then on using procedures in "Powering off the device" and "Providing power to the device" in the "Device Installation" section.

If the problem is still unresolved after these steps, contact your support provider.

Obtaining chassis and component status

The CLI commands in the following table provide status and environmental information about the chassis and its components. These commands provide information only, and they do not interrupt traffic flow. For more information about these commands, refer to the *Fabric OS Command Reference*.

TABLE 21 Environmental status and maintenance commands

Command	Information displayed
sensorShow	Temperature readings for the port blades

TABLE 21 Environmental status and maintenance commands (Continued)

Command	Information displayed
	Temperature readings for the CP blades
	Status and RPM of all operational fans
	Status of all operational power supplies
tempShow	Temperature readings for the port blades
	Temperature readings for the CP blades
psShow	Status of all operational power supplies
fanShow	Status and RPM of all operational fans
chassisShow	Serial number, time awake, and additional information about each component
slotShow	Slot occupancy
errShowerrDump	System error log. Refer to the <i>Fabric OS Message Reference</i> for more information on the messages in this log.

Interpreting POST and boot results

The device performs Power-On Self-Test (POST) by default each time the chassis is powered on, rebooted, or reset. The device can be rebooted using the **reboot** (to reboot each CP individually) or **fastBoot** commands. The **fastBoot** command reboots the switches without running POST. If the active CP blade is rebooted, it fails over to the standby CP blade.

POST

The device automatically performs POST each time it is powered on or reset.

To verify that POST has completed without error, do the following:

- Verify that all LEDs return to a normal state after POST completes.
If one or more LEDs do not return to a normal state, and this is not due to the device being set to beacon, refer to the relevant LED table to identify and correct the problem. For port blades, and CP and core switch blades, the **slotShow** command can be used to check the status of the slots. For information about turning beaconing on or off, refer to the *Fabric OS Administrator's Guide*.
- Verify that the switch prompt displays when POST completes.
If it does not display, POST was not successfully completed. Contact the device supplier for support.
- Review the system error log using the **errShow** or **errDump** commands.
Any errors detected during POST are written to the system log, which is accessible through the **errShow** command. For information about error messages, refer to the *Fabric OS Message Reference*.

POST includes the following steps:

1. Preliminary POST diagnostics are run.
2. Operating system is initialized.
3. Hardware is initialized.
4. Diagnostic tests are run on several functions, including circuitry, port functionality, ability to send and receive frames, all aspects of memory, parity, statistics counters, and serialization.

Boot

In addition to POST, boot includes the following steps after POST is complete:

1. Universal port configuration is performed.
2. Links are initialized.
3. Fabric is analyzed. If any ports are connected to other switches, the device participates in a fabric configuration.
4. The device obtains a domain ID and assigns port addresses.
5. Unicast routing tables are constructed.
6. Normal port operation is enabled.

Diagnostics

Diagnostic tests are automatically run during POST to check the status of the device. Any error messages generated during POST are sent to the error logs and to the serial console, if connected.

Diagnostic tests can also be run manually to test and troubleshoot the hardware and the firmware, including internal connections and circuitry, transceivers, and port cables. However, diagnostic tests are generally intended for use by support personnel.

NOTE

Error messages do not necessarily indicate that the device requires maintenance.

Each diagnostic test can be implemented by entering the related command through a Telnet or serial session. For a list of diagnostic tests and commands, refer to the *Fabric OS Administrator's Guide*.

All diagnostic tests are run at all supported link speeds. They might temporarily lock the transmit and receive speeds to a specific speed. Some diagnostic tests require interconnecting the ports to each other or using loopback plugs. If ports are interconnected, the media (cables and transceivers) at each end of the connection must be of the same type. For example, short wavelength media must be connected to short wavelength media, and likewise with long wavelength media and copper media.

For more information about diagnostic tests and how to run them, refer to the *Fabric OS Administrator's Guide* and the *Fabric OS Command Reference*. For information about system error messages (**errShow** or **errDump**), refer to the *Fabric OS Troubleshooting and Diagnostics Guide*.

Troubleshooting

The following table provides a list of issues, possible causes, and recommended actions.

TABLE 22 Troubleshooting the device

Issue	Possible cause	Recommended action
Entire chassis powers off automatically.	Power supplies are inadequate to support the installed components.	Add an additional power supply.
Several or all components are not operating.	One or both power cables may not be connected to a live source.	Ensure that both power cables are connected to live outlets.
	One or both AC power switches might be off.	Ensure that both AC power switches are on (AC switches light up green when on).
Serial connection is faulty or serial port logs have incorrect or missing information.	Serial cable is not connected correctly.	Ensure that the cable is firmly connected to workstation computer and to the device.
	Terminal emulator application parameters are not set correctly.	Ensure that the terminal emulator application is configured as follows: 9600 bits per second, 8 databits, no parity, 1 stop bit, no flow control.
	Serial port might be incompatible (only RS-232 is supported).	Ensure that the device is connected to an RS-232 port. RS-423 serial ports might experience difficulties due to corner-case incompatibilities of the standards.
	Pins on the serial cable or serial port might be damaged.	Remove the cable and inspect the pins on the cable and in the serial port. Do not reinstall if the pins on either component have any visible damage, as this could damage the pins on the other component. Replace the components as required.
CP Ethernet link speed is different than expected or a link cannot be established.	There might be a conflict with the CP Ethernet link speed negotiation set up by the network.	Specify the CP Ethernet link speed by typing the ifModeSet command. For more information about Ethernet connectivity to the device, refer to the LAN guidelines provided through the MyBrocade website.
Configuration data is inaccurate or cannot be accessed.	Chassis was powered off/on while a WWN card was uninstalled or failed.	Install an operational WWN card and power the system off/on again.
	The device was rebooted while an WWN card was uninstalled or failed.	
Initial setup results in IP address/Domain ID conflict.	The device was connected to the fabric before being configured.	Refer to the <i>Fabric OS Administrator's Guide</i> for configuration information.
LEDs on one or more components are changing rapidly or do not indicate a healthy state.	The device might be booting or running POST.	Verify that boot and POST are complete. The device requires a minimum of 3 minutes, usually, after power-on to complete POST.
	Beaconing might be on for the entire device or for individual components.	Determine whether beaconing is on by typing the switchShow command and determine whether switch beaconing or blade beaconing are on.

TABLE 22 Troubleshooting the device (Continued)

Issue	Possible cause	Recommended action
	Individual components might have failed.	Refer to the LED tables in the "System Monitoring" section for interpretation and recommended actions.
	Pins on the components might be damaged.	Remove the component from the chassis and inspect the pins on the component and inside the chassis. Do not reinstall if pins on either component are damaged, as this could damage pins on other components. Replace the parts as required.
None of the LEDs on a component are on.	Component might not be seated correctly.	Ensure that the device has power and the component is firmly seated. If the problem continues, enter the sensorShow command to determine the component status. If the component is a CP blade or port blade, enter the slotShow command to determine the status.
	Component might have failed.	Replace the component as necessary.
CP blades are failing over frequently.	There is excessive serial port activity.	Ensure that the serial port activity remains below specified amount.
	CP blade is attached to an Ethernet with high traffic loads.	Ensure that the Ethernet traffic remains below specified amount
	Chassis is overheated.	Enter the tempshow and sensorShow commands to check internal temperature. If components are overheating, shut down port blades as necessary to return the temperature to operating range. Also try moving the blades in the chassis because it is possible that airflow might not be adequate to cool everything in certain configurations.
One or more port blades have either shut down or failed POST as indicated by the error log.	Blades might be overheated.	Enter the sensorShow command to check the internal temperature readings. If components are overheating, shut down port blades as necessary to return the temperature readings to the operating ranges. Also try moving the blades in the chassis because it is possible that airflow might not be adequate to cool everything in certain configurations.
	Blades might be faulty.	Enter the slotShow command to determine status. For more information, enter the diagDisablePost command; then, use the slotPowerOff [slot number] and slotPowerOn [slot number] command. Resolve the source of the problem or replace the blade as required.
	Pins on the blade or the backplane might be damaged.	Remove the blade from the chassis and inspect the pins on the blade and on the backplane inside the slot. Do not reinstall if the pins on either component are damaged, as this could damage pins on other components. Replace the components as required.

TABLE 22 Troubleshooting the device (Continued)

Issue	Possible cause	Recommended action
An individual component is not operating as expected.	Component may not have power or may not be firmly seated.	Ensure that the component is receiving power (power LED should be on) and the component is firmly seated.
	Pins on the component or the backplane might be damaged.	Remove the component from the chassis and inspect the pins on the blade and inside the chassis. Do not reinstall if the pins on either component are damaged, as this could damage pins on other components. Replace parts as required.
	The component might have failed.	Enter the tempshow and sensorShow command to determine the component status. If the component is a CP blade or port blade, enter the slotShow command to determine the status. Replace the component as necessary.

Regulatory Statements

- BSMI statement (Taiwan)..... 143
- Canadian requirements..... 143
- CE statement..... 143
- China ROHS..... 144
- FCC warning (US only)..... 144
- Germany statement..... 144
- KCC statement (Republic of Korea)..... 144
- VCCI statement..... 145

BSMI statement (Taiwan)

警告使用者：
這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，
在這種情況下，使用者會被要求採取某些適當的對策。

Warning:
This is Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Canadian requirements

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations, ICES-003 Class A.
Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

CE statement

ATTENTION
This is a Class A product. In a domestic environment, this product might cause radio interference, and the user might be required to take corrective measures.

The standards compliance label on this device contains the CE mark which indicates that this system conforms to the provisions of the following European Council directives, laws, and standards:

- Electromagnetic Compatibility (EMC) Directive 2004/108/EEC
- Low Voltage Directive (LVD) 2006/95/EC
- EN50082-2/EN55024:1998 (European Immunity Requirements)

- EN61000-3-2/IEC61000-3-2 (European and Japanese Harmonics Spec)
- EN61000-3-3

China ROHS

Refer to the latest revision of the China ROHS document (P/N 53-1000428-xx) which ships with the product.

FCC warning (US only)

This equipment has been tested and complies with the limits for a Class A computing device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, might cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at the user's own expense.

Germany statement

Machine noise information regulation - 3. GPSGV, the highest sound pressure level value is 79.0 dB(A) in accordance with EN ISO 7779.

Maschinenlärminformations-Verordnung - 3. GPSGV, der höchste Schalldruckpegel beträgt 79.0 dB(A) gemäß EN ISO 7779.

KCC statement (Republic of Korea)

A급 기기 (업무용 방송통신기기): 이 기기는 업무용(A급)으로 전자파적합등록을 한 기기이오니 판매자 또는 사용자는 이 점을 주의하시기 바라며, 가정외의 지역에서 사용하는 것을 목적으로 합니다.

Class A device (Broadcasting Communication Device for Office Use): This device obtained EMC registration for office use (Class A), and may be used in places other than home. Sellers and/or users need to take note of this.

VCCI statement

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI-A

This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance might arise. When such trouble occurs, the user might be required to take corrective actions.

Brocade DCX 8510 Technical Specifications

This document highlights the features and specifications for the Brocade DCX 8510-4 and the Brocade DCX 8510-8 switches.

System specifications

System component	Description
Enclosure	Brocade DCX 8510-4 - 8U rack-mountable chassis; mid-mount, 27-31 in. rail, mid-mount, and port-side exhaust shelf options Brocade DCX 8510-8 - 14U rack-mountable chassis, 27-31 in. and 22 in. rail options
Control processor	Redundant (active/standby) control processor blades
Scalability	Full fabric architecture: a maximum of 239 switches
Performance	• 2.125 Gbps line speed, full duplex • 4.25 Gbps line speed, full duplex • 8.50 Gbps line speed, full duplex • 10.51875 Gbps line speed, full duplex • 16 Gbps line speed, full duplex Autosensing of 2, 4, 8, and 16 Gbps port speeds depending on SFPs used. Speed matching between 2, 4, 8, and 16 Gbps port speeds. 10 Gbps port speeds with dedicated SFPs.
ISL Trunking	Can use up to 8 ports in a trunk group to form a 128 Gbps trunk. Automatically uses up to four ICL ports in a QSFP to form a 64 Gbps trunk. Using FC16-64 blade, two QSFPs (8 ISL ports) are used to form a 128 Gbps trunk.
Chassis bandwidth	Brocade DCX 8510-4: 4.1 Tbps per chassis (256 ports × 16 Gbps data rate + 1.024 Tbps UltraScale ICL bandwidth) Brocade DCX 8510-8: 8.2 Tbps per chassis (512 ports × 16 Gbps data rate + 2.048 Tbps UltraScale ICL bandwidth)
Slot bandwidth	512 Gbps (data rate)
Local switching bandwidth	256 Gbps for Brocade FC8-32E: 32 ports × 8 Gbps (data rate) 384 Gbps for Brocade FC8-48E: 48 ports × 8 Gbps (data rate) 512 Gbps for Brocade FC16-32: 32 ports × 16 Gbps (data rate) 768 Gbps for Brocade FC16-48: 48 ports × 16 Gbps (data rate) 512 Gbps for Brocade FC8-64: 64 ports × 8 Gbps (data rate) 1 Tbps for Brocade FC16-64: 64 ports × 16 Gbps (data rate)

System component	Description
UltraScale ICL bandwidth	Brocade DCX 8510-4: 1.024 Tbps; 16 UltraScale ICL ports provide the equivalent of 64 16-Gbps ports. Each UltraScale ICL port provides 64 Gbps bandwidth over a QSFP (16 Gbps x 4) link. Brocade DCX 8510-8: 2.048 Tbps; 32 UltraScale ICL ports provide the equivalent of 128 16-Gbps ports. Each UltraScale ICL port provides 64 Gbps bandwidth over a QSFP (16 Gbps x 4) link. Both models: Frame-based trunking is enabled between four UltraScale ICLs. DPS distributes exchanges across all frame trunks.
Power inlet	C20; power from non-port side
Power supplies	Brocade DCX 8510-4: Two modular, hot-swappable 2000 W AC power supply modules (100-240 VAC autosensing), 1+1 redundancy Brocade DCX 8510-8: Four modular, hot-swappable power supplies (100-240 VAC autosensing), 2+2 redundancy
Fans	Brocade DCX 8510-4: Two blower assemblies per chassis Brocade DCX 8510-8: Three blower assemblies per chassis
Cooling	Brocade DCX 8510-4: Two blower assembly modules (one required for operation); rear panel-to-door airflow Brocade DCX 8510-8: Three blower assemblies; non-port (non-cable) side to the port (cable) side airflow
System architecture	Nonblocking shared memory
System processors	FreeScale 8548, 1.2 GHz
Aggregate bandwidth	Brocade DCX 8510-4: 5 Tbps populated with four FC16-64 port blades and using 16 ICL ports at 64 Gbps Brocade DCX 8510-8: 10 Tbps populated with eight FC16-64 port blades and using 16 ICL ports at 64 Gbps
Switch latency	FC8-32E, FC8-48E, and FC8-64 blades: <700 ns any port to any port local switching and 2.1 µsec blade to blade at 8-Gbps, cut-through routing. FC16-32, FC16-48, and FC16-64 blades: <700 ns any port to any port local switching and 2.1 µsec blade to blade at 16-Gbps, cut-through routing. FX8-24 blade - FC to FC: <2.1 µsec any port to any port at 8 Gbps, cut-through routing. Fcoe10-24 blade - CEE to CEE (different ASIC) and Fcoe to FC: <5 µsec any port to any port at 8 Gbps, cut-through routing.
Maximum frame size	2112-byte payload
Frame buffers	8000 per CR16 core switch blade ASIC, with 5000 more that can be borrowed from neighboring ASIC if enabled

System component	Description
Port types	FC8-32E port blade : F_Port, E_Port, EX_Port, and M_Port FC8-48E port blade : F_Port, E_Port, EX_Port, and M_Port FC8-64 port blade : F_Port, FL_Port, E_Port, EX_Port, and M_Port FS8-18 application blade : FL_Port, F_Port, E_Port, EX_Port, and M_Port FC16-32 port blade : F_Port, E_Port, EX_Port, M_Port, and D_Port FC16-48 port blade : F_Port, E_Port, EX_Port, M_Port, and D_Port FC16-64 port blade : F_Port, E_Port, EX_Port, M_Port, and D_Port FX8-24 application blade : F_Port, FL_Port, E_Port, and EX_Port on FC VE_Port on GbE NOTE: Self-discovery is based on switch type (U_Port) with an optional port type control.
Data traffic types	Fabric switches supporting unicast, multicast (255 groups), and broadcast
Media types	8 Gbps: FC8-32E, -48E, and FS8-18 blade require Brocade hot-pluggable SFP+, LC connector; 8 Gbps SWL 8 Gbps: FC8-64, requires Brocade hot-pluggable mSFP; 8 Gbps SWL only 16 Gbps: FC16-32 and -48, require Brocade hot-pluggable SFP+; 16 Gbps, 10 Gbps, or 8 Gbps SWL and LWL 16 Gbps: FC16-64, requires Brocade-branded, hot-pluggable QSFP; 4 Gbps, 8 Gbps, or 16 Gbps x 4 SWL only 16 Gbps: Core blades, require Brocade-branded, hot-pluggable QSFP; 16 Gbps x 4 SWL only 1 GbE: FX8-24 can use Brocade-branded 4 Gbps SFP 10 GbE: FCOE10-24 blades use Brocade-branded SFP+ transceivers, either short-reach (SR) or long-reach (LR) Core blade (CR16-4) uses Brocade-branded, hot-pluggable QSFP; 16 Gbps x 4 SWL only for ICL connections Distance subject to fiber-optic cable and port speed.
USB	One USB port per control processor for firmware download, support save, and configuration upload or download
Fabric Services	Advanced Performance Monitoring; Adaptive Networking (Ingress Rate Limiting, Traffic Isolation, QoS); BB credit recovery; Brocade Advanced Zoning (default zoning, port/WWN zoning, broadcast zoning); Dynamic Path Selection (DPS); Extended Fabrics; Fabric Watch; FDMI; FICON CUP; Frame Redirection; FSPF; Integrated Routing (FR4-18i SAN Extension blade not required for routing); IPFC; ISL Trunking; Management Server; N_Port Trunking; NPIV; NTP v3; Port Fencing; Registered State Change Notification (RSCN); Reliable Commit Service (RCS); Simple Name Server (SNS); syslog; Top Talkers; Virtual Fabrics (Logical Switch, Logical Fabric)

System component	Description
Extension	Supports DWDM, CWDM, and FC-SONET devices; Fibre Channel, in-flight compression (Brocade LZO) and encryption (AES-GCM-256) BB credit recovery; FCIP, Adaptive Rate Limiting (ARL), data compression, Fast Write, read/write Tape Pipelining, QoS
FICON	FICON cascading (Brocade Fabric OS: Brocade DCX 8510-8, DCX 8510-4); support for lossless DLS; FICON CUP; Advanced Accelerator for FICON (FICON Global Mirror and XRC emulation and read/write Tape Pipelining) The Brocade FC8-64 blade does not support FICON.
Inter-chassis link (ICL)	Chassis-to-chassis linkage through connectors on the core switch blade (CR16-4)

Fibre Channel

System component	Description
Fibre Channel ports	Brocade DCX 8510-4: Up to 256 16-Gbps ports, universal (F_Port, E_Port, EX_Port, M_Port, D_Port) Brocade DCX 8510-8: Up to 512 16-Gbps ports, universal (E_Port, F_Port, EX_Port, M_Port, D_Port, FICON)
Classes of service	Class 2, Class 3, Class F (interswitch frames)
ANSI Fibre Channel protocol	FC-PH (Fibre Channel Physical and Signalling Interface standard)
Modes of operation	1) ten 1 GbE ports, 2) ten 1 GbE ports and one 10 GbE port, or 3) two 10 GbE ports depending on licensing and subsequent configuration of GbE port mode
Fabric initialization	Complies with FC-SW 5.0
FCIP (IP over Fibre Channel)	Complies with FC-IP 2.3 of the FCA profile
Port to port latency	Local switching - 700 ns (any port to any port); Blade to blade - 2.1 microseconds (E_Port to E_Port)
Switching capacity	An aggregate switching capacity of 3.36 billion frames per second (for Class 2, Class 3, and Class F frames for a 256-port chassis)

LEDs

System component	Description
Switch status and management	Unicolor LED (amber) displaying four different LED states based on blade activity and status

System component	Description
Port Status	Bicolor port status LED (green and amber) displaying nine different LED states based on FC port activity and status

Other

System component	Description
Serial Cable	RS-232 serial cable
RJ-45 to DB9 adapter	RS-232 cable has an adapter at one end that can be removed to provide an RJ-45 style connector
RJ-45 connector	Serial port 10/100/1000 Ethernet (RJ-45) per control processor

Weight and physical dimensions

"Fully Loaded": Brocade DCX 8510-4: 256-port configuration with four FC16-64 port blades including two CP blades, two core switch blades, two blowers, two power supplies, and two cable management finger assemblies.

"Fully Loaded": Brocade DCX 8510-8: 512-port configuration with eight FC16-64 port blades including two CP blades, two core switch blades, three blowers, four power supplies, and one cable management comb.

Model	Height	Width	Depth	Weight (empty)	Weight (fully loaded)
DCX 8510-4	35.60 cm	43.74 cm	61.29 cm	25.40 kg	69.00 kg
	14.00 inches	17.22 inches	24.09 inches	56.00 lb	152.00 lb
DCX 8510-4 with Port Side Exhaust Kit	40.00 cm	43.74 cm	61.29 cm		
	15.75 inches	17.22 inches	24.09 inches		
DCX 8510-4 with door	35.60 cm	43.74 cm	73.20 cm		
	14.00 inches	17.22 inches	28.82 inches		
DCX 8510-8	62.23 cm	43.74 cm	61.29 cm	37.30 kg	103.38 kg
	24.50 inches	17.22 inches	24.09 inches	82.20 lb	227.90 lb
DCX 8510-8 with door	62.23 cm	43.74 cm	73.20 cm		
	24.50 inches	17.22 inches	28.82 inches		

Blade	Description	Height	Width	Thickness	Weight
CP blade (CP8)	Contains control plane for the chassis.	41.91 cm	29.7 cm	3.3 cm	3.00 kg
		16.5 inches	11.7 inches	1.3 inches	6.60 lb
CR blade (CR16-4)	Core blade for DCX 8510-4.	41.91 cm	29.7 cm	3.3 cm	3.30 kg
		16.5 inches	11.7 inches	1.3 inches	7.30 lb
CR blade (CR16-8)	Core blade for DCX 8510-8.	41.91 cm	29.7 cm	3.3 cm	3.70 kg
		16.5 inches	11.7 inches	1.3 inches	8.10 lb
FC8-32E port blade (without media)	32-port Brocade port blade supporting 2, 4, and 8 Gbps speeds.	41.91 cm	29.7 cm	3.3 cm	2.80 kg
		16.5 inches	11.7 inches	1.3 inches	6.20 lb
FC8-48E port blade (without media)	32-port Brocade port blade supporting 2, 4, and 8 Gbps speeds.	41.91 cm	29.7 cm	3.3 cm	3.30 kg
		16.5 inches	11.7 inches	1.3 inches	7.30 lb
FC8-64 port blade (without media)	64-port Brocade port blade supporting 2, 4, and 8 Gbps port speeds with mSFPs.	41.91 cm	29.7 cm	3.3 cm	3.36 kg
		16.5 inches	11.7 inches	1.3 inches	7.40 lb
FC16-32 port blade (without media)	32-port Brocade port blade supporting 2, 4, 8, 10, and 16 Gbps speeds.	41.91 cm	29.7 cm	3.3 cm	2.80 kg
		16.5 inches	11.7 inches	1.3 inches	6.20 lb
FC16-48 port blade (without media)	48-port Brocade port blade supporting 2, 4, 8, 10, and 16 Gbps speeds.	41.91 cm	29.7 cm	3.3 cm	3.30 kg
		16.5 inches	11.7 inches	1.3 inches	7.30 lb
FC16-64 port blade (without media)	64-port Brocade port blade supporting 4, 8, and 16 Gbps speeds.	41.91 cm	29.7 cm	3.3 cm	3.56 kg
		16.5 inches	11.7 inches	1.3 inches	7.85 lb
FCOE10-24 FCoE blade	24-port Brocade port blade to provide FCoE support.	41.2 cm	27.9 cm	3.6 cm	3.72 kg
		16.2 inches	11.0 inches	1.4 in	8.20 lb

Blade	Description	Height	Width	Thickness	Weight
FX8-24 extension blade (without media)	Enables FCIP functionality over existing IP infrastructure. Has 12 FC ports, 10 1-GbE ports, and two 10-GbE ports.	42.1 cm	29.9 cm	3.6 cm	4.20 kg
		16.6 inches	11.8 inches	1.4 inches	9.20 lb
FS8-18	Enables data cryptographic (encryption/ decryption) and data- compression for data-at-rest. Has 16 Fibre Channel SFP ports.	41.11 cm 16.19 inches	27.98 cm 11.02 inches	3.6 cm 1.4 inches	5.5 kg 12.00 lbs

FRU	Description	Weight
Port card filler panel	Used when a port card is not replaced by another.	1.50 kg 3.20 lb
Power supply	Redundant +48 VDC power distribution system with a provision for up to two 2000-watt, 48 VDC bulk power supplies.	2.45 kg 5.40 lb
Blower assembly	Two operating blower assemblies ensure continuous cooling of the system.	5.73 kg 12.60 lb
WWN card bezel	Logo plate containing the two WWN cards beneath.	0.30 kg 0.60 lb
Cable management device	Brocade DCX 8510-4: Two vertical cable management finger assemblies. Brocade DCX 8510-8: One cable management comb.	0.45 kg 1.00 lb
Chassis door	Chassis door for improved cable management.	2.09 kg 4.60 lb

Environmental requirements

Condition	Operational	Non-operational
Ambient temperature	0°C to 40°C (32°F to 104°F)	-25°C to 70°C (-13°F to 158°F)

Condition	Operational	Non-operational
Relative humidity (non-condensing)	5% to 93% at 40°C (104°F) with maximum gradient of 10% per hour	10% to 93% at 70°C (158°F)
Altitude (above sea level)	0 to 3000 m (10,000 feet)	0 to 12000 m (40,000 feet)
Shock	20 G, 6 ms, half-sine wave	33 G, 11 ms, half-sine wave
Vibration	0.5 G sine, 0.4 gms random, 5-500 Hz	2.0 G sine, 1.1 gms random, 5-500 Hz
Airflow	Maximum: 90.1 cmh (53 cfm) Nominal: 59.5 cmh (35 cfm)	N/A
Heat dissipation	Brocade DCX 8510-4: 4078 BTU/hr Brocade DCX 8510-8: 7654 BTU/hr	N/A

Power supply specifications (per PSU)

Power supply model	Maximum output power rating (DC)	Input voltage	Input line frequency	Maximum input current	Input line protection	Maximum inrush current
XBR-DCX-0104	1000/2000 W	1000 W Output 100 - 120 V (nominal) 85 - 132 V (range) 2000 W Output 200 - 240 V (nominal) 180 - 264 V (range)	50/60 Hz (nominal) 47 - 63 Hz (range)	15 A	Line & Neutral Fused	60 A peak for <10 ms <15A peak for 10 ms - 150 ms

Power consumption (maximum configuration)

The maximum power consumption configuration features blowers at maximum speed and the FC16-48 blade configured with optics to draw the maximum MSA power per specification of 1 W (does not include the power draw for intelligent blades such as the FS18-8 or FX8-24).

Model name	@100 VAC input	@200 VAC input	@-48 VDC input	Minimum number of power supplies	Notes
DCX 8510-4	17 A 1752 W 5979 BTU/hr	8 A 1691 W 5773 BTU/hr	N/A	2 for AC Low Line (100-120 VAC) 1 for AC High Line (200-240 VAC)	DCX 8510-4 fully loaded: 2 CPs, 2 Core, 4 FC16-48, 2 Fan FRUs
DCX 8510-8	25.2 A 2515.7 W 8586 BTU/hr	12.1 A 2429 W 8290 BTU/hr	N/A	3 for AC Low Line (100-120 VAC) 2 for AC High Line (200-240 VAC)	DCX 8510-8 fully loaded: 2 CPs, 2 Core, 8 FC16-48, 3 Fan FRUs

Power consumption (modules)

Module name	Module description	Maximum power consumption
CP8	Control Blade	40 W
CR16-8	Core Blade for DCX 8510-8	240 W
CR16-4	Core Blade for DCX 8510-4	135 W
FC8-32	32 x 8 Gbps Port Blade	80 W
FC8-48	48 x 8 Gbps Port Blade	115 W
FC8-64	64 x 8 Gbps Port Blade	126 W
FCOE10-24	24 x10 Gbps Port SFP+ FCoE Port Blade	250 W
FC16-32	32 x 16 Gbps Port Blade	140 W
FC16-48	48 x 16 Gbps Port Blade	160 W
FC16-64	64 x 16 Gbps QSFP Port Blade	134 W
FS8-18	Encryption Blade	360 W
FX8-24	Extension Blade	250 W
Blower	Fan FRU	90 W

Data port specifications (Fibre Channel)

Name	Number	Description
Brocade DCX 8510-4	192	16 Gbps (E, F, D, M, and EX) Fibre Channel ports using four 48-port 16 Gbps Fibre Channel blades
	256	8 Gbps (E, F, D, M, and EX) Fibre Channel ports using four 64-port 8 Gbps Fibre Channel blades
Brocade DCX 8510-8	384	16 Gbps (E, F, D, M, and EX) Fibre Channel ports using eight 48-port 16 Gbps Fibre Channel blades
	512	8 Gbps (E, F, D, M, and EX) Fibre Channel ports using eight 64-port 8 Gbps Fibre Channel blades

Fibre Channel data transmission ranges

Port speed (Gbps)	Cable size (microns)	Short wavelength (SWL)	Long wavelength (LWL)	Extended long wavelength (ELWL)
2	50	300 m (984 ft) (OM2) 500 m (1,640 ft) (OM3)	N/A	N/A
	62.5	150 m (492 ft)	N/A	N/A
	9	N/A	30 km (18.6 miles)	N/A
4	50	150 m (492 ft) (OM2) 380 m (1,246 ft) (OM3) 400 m (1,312 ft) (OM4)	N/A	N/A
	62.5	70 m (230 ft)	N/A	N/A
	9	N/A	30 km (18.6 miles)	N/A
8	50	50 m (164 ft) (OM2) 150 m (492 ft) (OM3) 190 m (623 ft) (OM4)	N/A	N/A
	62.5	21 m (69 ft)	N/A	N/A
	9	N/A	10 km (6.2 miles) or 40 km (24.8 miles)	N/A

Port speed (Gbps)	Cable size (microns)	Short wavelength (SWL)	Long wavelength (LWL)	Extended long wavelength (ELWL)
10	50	82 m (269 ft) (OM2) 300 m (984 ft) (OM3) 550 m (1804 ft) (OM4)	N/A	N/A
	62.5	33 m (108 ft)	N/A	N/A
	9	N/A	10 km (6.2 miles)	N/A
16	50	35 m (115 ft) (OM2) 100 m (328 ft) (OM3) 125 m (410 ft) (OM4)	N/A	N/A
	62.5	15 m (49 ft)	N/A	N/A
	9	N/A	10 km (6.2 miles)	N/A
4 x 16	50	50 m (49 ft)	N/A	N/A
	62.5	N/A	N/A	N/A
	9	N/A	N/A	N/A

Serial port specifications (DB9)

Pin	Signal	Description
1	Reserved	Reserved
2	TXD (output)	Transmit data
3	RXD (input)	Receive data
4	Reserved	Reserved
5	GND	Logic ground
6	Reserved	Reserved
7	Reserved	Reserved
8	Reserved	Reserved
9	Reserved	Reserved

Serial port specifications (pinout mini-USB)

Pin	Signal	Description
1	+5V	Not used
2	UART0_TX	Debug port
3	UART0_RX	Console port
4	IN	Not used
5	GND	Ground

Serial port specifications (pinout RJ-45)

Pin	Signal	Description
1	Not supported	N/A
2	Not supported	N/A
3	UART1_TXD	Transmit data
4	GND	Logic ground
5	GND	Logic ground
6	UART1_RXD	Receive data
7	Not supported	N/A
8	Not supported	N/A

Serial port specifications (protocol)

Parameter	Value
Baud	9600
Data bits	8
Parity	None
Stop bits	1
Flow control	None

Regulatory compliance (EMC)

- FCC Part 15, Subpart B (Class A)
- EN 55022 (CE mark) (Class A)
- EN 55024 (CE mark) (Immunity) for Information Technology Equipment
- ICES-003 (Canada) (Class A)
- AS/NZ 55022 (Australia) (Class A)
- VCCI (Japan) (Class A)
- EN 61000-3-2
- EN 61000-3-3
- EN 61000-6-1

Regulatory compliance (safety)

- CAN/CSA-C22.2 No. 60950-1-07/UL60950-1 - Safety of Information Technology Equipment
- EN 60825-1 Safety of Laser Products - Part 1: Equipment Classification, Requirements and User's Guide
- EN 60825-2 Safety of Laser Products - Part 2: Safety of Optical Fibre Communications Systems
- EN 60950-1, IEC 60950-1 Safety of Information Technology Equipment

Regulatory compliance (environmental)

- 2011/65/EU - Restriction of the use of certain hazardous substance in electrical and electronic equipment (EU RoHS).
- 2012/19/EU - Waste electrical and electronic equipment (EU WEEE).
- 94/62/EC - packaging and packaging waste (EU).
- 2006/66/EC - batteries and accumulators and waste batteries and accumulators (EU battery directive).
- 1907/2006 of the European Parliament and of the Council of 18 December 2006 concerning the Registration, Evaluation, Authorisation and Restriction of Chemicals (EU REACH).
- Section 1502 of the Dodd-Frank Wall Street Reform and Consumer Protection Act of 2010 - U.S. Conflict Minerals.
- 30/2011/TT-BCT - Vietnam circular.
- SJ/T 11363-2006 Requirements for Concentration Limits for Certain Hazardous Substances in EIPs (China).
- SJ/T 11364-2006 Marking for the Control of Pollution Caused by EIPs (China).

Caution and Danger Notices

- [Cautions.....](#) 161
- [Danger Notices.....](#) 162

Cautions

A Caution statement alerts you to situations that can be potentially hazardous to you or cause damage to hardware, firmware, software, or data.

Ein Vorsichtinweis warnt Sie vor potenziellen Personengefahren oder Beschädigung der Hardware, Firmware, Software oder auch vor einem möglichen Datenverlust

Un message de mise en garde vous alerte sur des situations pouvant présenter un risque potentiel de dommages corporels ou de dommages matériels, logiciels ou de perte de données.

Un mensaje de precaución le alerta de situaciones que pueden resultar peligrosas para usted o causar daños en el hardware, el firmware, el software o los datos.

Electrical cautions



CAUTION

Use a separate branch circuit for each power cord, which provides redundancy in case one of the circuits fails.

VORSICHT	Es empfiehlt sich die Installation eines separaten Stromkreisweiges für jede Elektroschnur als Redundanz im Fall des Ausfalls eines Stromkreises.
----------	---

MISE EN GARDE	Utilisez un circuit de dérivation différent pour chaque cordon d'alimentation ainsi, il y aura un circuit redondant en cas de panne d'un des circuits.
---------------	--

PRECAUCIÓN	Use un circuito derivado separado para cada cordón de alimentación, con lo que se proporcionará redundancia en caso de que uno de los circuitos falle.
------------	--



CAUTION

Before plugging a cable into any port, be sure to discharge the voltage stored on the cable by touching the electrical contacts to ground surface.

VORSICHT	Bevor Sie ein Kabel in einen Anschluss einstecken, entladen Sie jegliche im Kabel vorhandene elektrische Spannung, indem Sie mit den elektrischen Kontakten eine geerdete Oberfläche berühren.
----------	--

MISE EN GARDE	Avant de brancher un câble à un port, assurez-vous de décharger la tension du câble en reliant les contacts électriques à la terre.
---------------	---

PRECAUCIÓN	Antes de conectar un cable en cualquier puerto, asegúrese de descargar la tensión acumulada en el cable tocando la superficie de conexión a tierra con los contactos eléctricos.
------------	--



CAUTION

Static electricity can damage the chassis and other electronic devices. To avoid damage, keep static-sensitive devices in their static-protective packages until you are ready to install them.

VORSICHT	Statische Elektrizität kann das System und andere elektronische Geräte beschädigen. Um Schäden zu vermeiden, entnehmen Sie elektrostatisch empfindliche Geräte erst aus deren antistatischer Schutzhülle, wenn Sie bereit für den Einbau sind.
----------	--

MISE EN GARDE	L'électricité statique peut endommager le châssis et les autres appareils électroniques. Pour éviter tout dommage, conservez les appareils sensibles à l'électricité statique dans leur emballage protecteur tant qu'ils n'ont pas été installés.
------------------	---

PRECAUCIÓN	La electricidad estática puede dañar el chasis y otros dispositivos electrónicos. A fin de impedir que se produzcan daños, conserve los dispositivos susceptibles de dañarse con la electricidad estática dentro de los paquetes protectores hasta que esté listo para instalarlos.
------------	---



CAUTION

If you do not install a module or a power supply in a slot, you must keep the slot filler panel in place. If you run the chassis with an uncovered slot, the system will overheat.

VORSICHT	Falls kein Modul oder Netzteil im Steckplatz installiert wird, muss die Steckplatztafel angebracht werden. Wenn ein Steckplatz nicht abgedeckt wird, läuft das System heiß.
----------	---

MISE EN GARDE	Si vous n'installez pas de module ou de bloc d'alimentation dans un slot, vous devez laisser le panneau du slot en place. Si vous faites fonctionner le châssis avec un slot découvert, le système surchauffera.
------------------	--

PRECAUCIÓN	Si no instala un módulo o un fuente de alimentación en la ranura, deberá mantener el panel de ranuras en su lugar. Si pone en funcionamiento el chasis con una ranura descubierta, el sistema sufrirá sobrecalentamiento.
------------	---

Danger Notices

A Danger statement indicates conditions or situations that can be potentially lethal or extremely hazardous to you. Safety labels are also attached directly to products to warn of these conditions or situations.

Ein Gefahrenhinweis warnt vor Bedingungen oder Situationen die tödlich sein können oder Sie extrem gefährden können. Sicherheitsetiketten sind direkt auf den jeweiligen Produkten angebracht um vor diesen Bedingungen und Situationen zu warnen.

Un paragraphe Danger indique des conditions ou des situations potentiellement mortelles ou extrêmement dangereuses. Des labels de sécurité sont posés directement sur le produit et vous avertissent de ces conditions ou situations

Una advertencia de peligro indica condiciones o situaciones que pueden resultar potencialmente letales o extremadamente peligrosas. También habrá etiquetas de seguridad pegadas directamente sobre los productos para advertir de estas condiciones o situaciones.

Electrical dangers



DANGER

Make sure that the power source circuits are properly grounded, then use the power cord supplied with the device to connect it to the power source.

GEFAHR	Stellen Sie sicher, dass die Stromkreise ordnungsgemäß geerdet sind. Benutzen Sie dann das mit dem Gerät gelieferte Stromkabel, um es an die Stromquelle anzuschließen.
DANGER	Vérifiez que les circuits de sources d'alimentation sont bien mis à la terre, puis utilisez le cordon d'alimentation fourni avec le dispositif pour le connecter à la source d'alimentation.
PELIGRO	Verifique que circuitos de la fuente de corriente están conectados a tierra correctamente; luego use el cordón de potencia suministrado con el instrumento para conectarlo a la fuente de corriente



DANGER

For safety reasons, the ESD wrist strap should contain a series 1 megaohm resistor.

GEFAHR	Aus Sicherheitsgründen sollte ein EGB-Armband zum Schutz von elektronischen gefährdeten Bauelementen mit einem 1 Megaohm-Reihenwiderstand ausgestattet sein.
DANGER	Pour des raisons de sécurité, la dragonne ESD doit contenir une résistance de série 1 méga ohm.
PELIGRO	Por razones de seguridad, la correa de muñeca ESD deberá contener un resistor en serie de 1 mega ohmio.



DANGER

Remove both power cords before servicing.

GEFAHR	Trennen Sie beide Netzkabel, bevor Sie Wartungsarbeiten durchführen.
DANGER	Retirez les deux cordons d'alimentation avant toute maintenance.
PELIGRO	Desconecte ambos cables de alimentación antes de realizar reparaciones.



DANGER

Disconnect the power cord from all power sources to completely remove power from the device.

GEFAHR	Ziehen Sie das Stromkabel aus allen Stromquellen, um sicherzustellen, dass dem Gerät kein Strom zugeführt wird.
DANGER	Débranchez le cordon d'alimentation de toutes les sources d'alimentation pour couper complètement l'alimentation du dispositif.
PELIGRO	Para desconectar completamente la corriente del instrumento, desconecte el cordón de corriente de todas las fuentes de corriente.



DANGER

If the installation requires a different power cord than the one supplied with the device, make sure you use a power cord displaying the mark of the safety agency that defines the regulations for power cords in your country. The mark is your assurance that the power cord can be used safely with the device.

GEFAHR	Falls für die Installation ein anderes Stromkabel erforderlich ist (wenn das mit dem Gerät gelieferte Kabel nicht passt), müssen Sie sicherstellen, dass Sie ein Stromkabel mit dem Siegel einer Sicherheitsbehörde verwenden, die für die Zertifizierung von Stromkabeln in Ihrem Land zuständig ist. Das Siegel ist Ihre Garantie, dass das Stromkabel sicher mit Ihrem Gerät verwendet werden kann.
DANGER	Si l'installation nécessite un cordon d'alimentation autre que celui fourni avec le dispositif, assurez-vous d'utiliser un cordon d'alimentation portant la marque de l'organisation responsable de la sécurité qui définit les normes et réglementations pour les cordons d'alimentation dans votre pays. Cette marque vous assure que vous pouvez utiliser le cordon d'alimentation avec le dispositif en toute sécurité.
PELIGRO	Si la instalación requiere un cordón de corriente distinto al que se ha suministrado con el instrumento, verifique que usa un cordón de corriente que venga con la marca de la agencia de seguridad que defina las regulaciones para cordones de corriente en su país. Esta marca será su garantía de que el cordón de corriente puede ser utilizado con seguridad con el instrumento.

Dangers related to equipment weight



DANGER

Use safe lifting practices when moving the product.

GEFAHR	Beim Bewegen des Produktes ist auf eine sichere Hubtechnik zu achten.
DANGER	Utiliser des techniques de levage sûres pour déplacer le produit.
PELIGRO	Tenga mucho cuidado al levantar el producto para moverlo



DANGER

A fully populated chassis (four FC16-64 port cards, 256 ports) weighs approximately 69.5 kg (153 lbs) and requires a hydraulic or assisted lift to install it.

GEFAHR	Ein vollständig bestücktes Gerät (vier FC16-64-Port-Karten, 256 Ports) wiegt etwa 69 kg und erfordert zur Installation eine hydraulische oder Servo-Hebevorrichtung.
DANGER	Un commutateur complet (quatre cartes de port FC16-64, 256 ports) pèse environ 69.5 kg et requiert un dispositif de levage hydraulique ou électrique pour l'installation.
PELIGRO	Un chasis con la configuración completa (cuatro tarjetas para puertos FC16-64, 256 puertos) pesa aproximadamente 69.5 kg (153 libras) y requiere un elevador hidráulico o asistido para realizar su instalación.

Index

10 GbE ports [127](#)

A

application blade
 replacing [78](#)

B

backbone configuration [43](#)
back up configuration [55](#)
bezel, WWN, replacing [99](#)
blade
 CP, LEDs [67](#)
 FS8-18 [127](#)
 FX8-24 [127](#)
blades
 application, replacing [78](#)
 CR, LEDs [68](#)
 port, replacing [78](#)
 support for [13](#)
blower assembly
 LEDs [71](#)
 replacing [98](#)
 status [71](#)
boot results, interpreting [138](#)
BSMI statement (Taiwan) [143](#)

C

cable management fingers, replacing [77](#)
cables
 attach SFP [51](#)
 for FC8-64 [31](#)
 managing [54](#)
 QSFP [54](#)
Canadian requirements [143](#)
CE statement [143](#)
chassis, replacing [113](#)
chassis door, replacing [76](#)
chassis hardware components [14](#)
chassis name, customizing [48](#)
chassisName command [48](#)
command

 chassisName [48](#)
 configShow [55](#)
 configUpload [55](#)
 configUpload -vf [55](#)
 configure [48](#), [50](#)
 date [49](#)
 fabricShow [48](#), [51](#), [55](#)
 frureplace [102](#)
 ipaddrSet [46](#)
 ipaddrSet -chassis [46](#)
 ipaddrSet -cp0 [46](#)
 ipaddrSet -cp1 [46](#)
 ipAddrShow [46](#), [55](#)
 licenseIdShow [51](#)
 licenseShow [51](#), [55](#)
 logout [47](#)
 slotShow [60](#)
 switchDisable [48](#)
 switchEnable [48](#)
 switchName [48](#)
 switchShow [51](#), [55](#)
 switchShow -qsfp [53](#)
 sysShutdown [56](#)
 tsClockServer [50](#)
 tsTimeZone [49](#)
 usbStorage [55](#)
configShow command [55](#)
configUpload command [55](#)
configUpload -vf command [55](#)
configuration, backbone [43](#)
configuration backup [55](#)
configuration data
 troubleshooting [139](#)
configure command [48](#), [50](#)
configuring IP address [46](#)
core switch blade
 determining status [68](#)
 replacing [95](#)
CP blade
 determining status [67](#)
 replacing [83](#)
 troubleshooting [139](#)
 verifying operation [89](#)
CR blade
 determining status [93](#)
 removing [94](#)
 replacing [93](#)
customizing

chassis name [48](#)
switch name [48](#)

D

date, setting [49](#)
date command [49](#)
diagnostics
 boot results [138](#)
 POST [138](#)
diagnostic tests [139](#)
domain ID
 setting [48](#)
domain IDs
 troubleshooting [139](#)

E

encryption blade [127](#)
error messages, WWN card [72](#)
Ethernet, establish connection [47](#)
Ethernet link speed
 troubleshooting [139](#)
extension blade [127](#)

F

fabricShow command [48](#), [51](#), [55](#)
FC8-64
 qualified cables [31](#)
FCC warning (US only) [144](#)
FCIP [127](#)
FC trunking groups [127](#)
features, software [22](#)
Fibre Channel Routing Services [127](#)
field-replaceable units
 See FRUs [14](#)
filler panel, replacing [82](#)
firmwaredownload
 from USB [91](#)
frureplace command [102](#)
FRUs
 application blade
 replacing [78](#)
 blower assembly
 LEDs [71](#)
 replacing [98](#)
 cable management fingers, replacing [77](#)
 chassis
 replacing [113](#)
 chassis door
 replacing [76](#)

CP blade
 LEDs [67](#)
 replacing [83](#)
CR blade
 LEDs [68](#)
 replacing [93](#)
filler panel, replacing [82](#)
port blade
 replacing [78](#)
power supply
 LEDs [70](#)
 replacing [96](#)
SFP [51](#)
transceivers and cables, replacing [107](#)
troubleshooting [139](#)
WWN bezel
 replacing [99](#)
WWN card
 replacing [99](#)
FS8-18 blade [127](#)
FX8-24 blade [127](#)

G

GbE ports [127](#)

H

high availability [20](#)

I

ICL
 installing [33](#)
installation
 items required [26](#)
 SFP [51](#)
installation tasks [25](#)
installed licenses [51](#)
inter-chassis linking (QSFP) [33](#), [54](#)
IP address, configuring [46](#)
ipaddrSet -chassis command [46](#)
ipaddrSet command [46](#)
ipaddrSet -cp0 command [46](#)
ipaddrSet -cp1 command [46](#)
ipAddrShow command [46](#), [55](#)

L

LEDs

- blower assembly [71](#)
- CP blade [67](#)
- CR blade [68](#)
- power supply [70](#)
- troubleshooting [139](#)
- license, chassis software [51](#)
- licenseIdShow command [51](#)
- licenseShow command [51](#), [55](#)
- local time, synchronizing [50](#)
- logout command [47](#)

M

- manageability, network [23](#)
- managing cables [54](#)

N

- NTP server, external [50](#)
- numbering, port [19](#)

P

- PID mode [50](#)
- port
 - numbering [19](#)
- port blade
 - replacing [78](#)
 - troubleshooting [139](#)
- port identifier mode [50](#)
- POST, interpreting [138](#)
- power, providing [29](#)
- power supply
 - LEDs [70](#)
 - replacing [96](#)
 - status [70](#)

Q

- QSFPs
 - as inter-chassis links [53](#)
- QSFP transceivers [33](#)

R

- rack space requirement [26](#)
- reliability, features [21](#)
- removal and replacement procedure
 - See RRP [75](#)
- RRP

- application blade [78](#)
- blade filler panel [82](#)
- blower assembly [98](#)
- chassis [113](#)
- chassis door [76](#)
- CP blade [83](#)
- CR blade [93](#)
- port blade [78](#)
- power supply [96](#)
- QSFP cables [33](#)
- transceivers [107](#)
- vertical cable management fingers [77](#)
- WWN bezel [99](#)
- WWN card [99](#)

S

- safety guidelines [26](#)
- security [22](#)
- serial connection
 - establishing [44](#)
 - troubleshooting [139](#)
- serial port logout [47](#)
- serviceability, features [21](#)
- setting
 - time zone [49](#)
- SFPs [51](#)
- site planning [26](#)
- slotShow command [60](#)
- software features [22](#)
- status
 - application blade [60](#)
 - blower assembly [71](#)
 - core switch blade [68](#)
 - CP blade [67](#)
 - extension blade [60](#)
 - port blade [60](#)
 - power supply [70](#)
 - WWN card [72](#)
- switch
 - connect to [45](#)
 - domain ID [48](#)
- switchDisable command [48](#)
- switchEnable command [48](#)
- switch name
 - customizing [48](#)
 - length [48](#)
- switchName command [48](#)
- switchShow command [51](#), [55](#)
- switchShow -qsfp command [53](#)
- sysShutdown command [56](#)

T

- tasks, installation [25](#)
- terminal emulator, configuring [44](#)
- tool, extraction, transceivers [107](#)
- transceivers
 - extraction tool [107](#)
 - QSFP [33](#)
 - supported types [28](#)
- transceivers and cables
 - replacing [107](#)
- troubleshooting
 - chassis power [139](#)
 - configuration data [139](#)
 - CP blade [139](#)
 - domain IDs [139](#)
 - Ethernet link speed [139](#)
 - FRUs [139](#)
 - general [137](#)
 - IP addresses [139](#)
 - LEDs [139](#)
 - port blade [139](#)
 - serial connection [139](#)
- trunking groups [127](#)
- tsClockServer command [50](#)
- tsTimeZone command [49](#)

U

- usbStorage command [55](#)

V

- VCCI statement [145](#)
- verifying, CP blade operation [89](#)

W

- WWN bezel
 - replacing [99](#)
- WWN card
 - determining status [72](#)
 - error messages [72](#)
 - preparing for replacement [102](#)
 - replacing [99](#)
 - verifying need to replace [101](#)
- WWN card hot-swap replacement [102](#)
- WWN card power-down replacement [103](#)

Copyright © 2015 EMC Corporation. All rights reserved. Published in USA.

EMC believes the information in this publication is accurate as of its publication date. The information is subject to change without notice.

The information in this publication is provided as is. EMC Corporation makes no representations or warranties of any kind with respect to the information in this publication, and specifically disclaims implied warranties of merchantability or fitness for a particular purpose. Use, copying, and distribution of any EMC software described in this publication requires an applicable software license.

EMC², EMC, and the EMC logo are registered trademarks or trademarks of EMC Corporation in the United States and other countries.

All other trademarks used herein are the property of their respective owners.

For the most up-to-date regulatory document for your product line, go to EMC Online Support (<https://support.emc.com>).