

Alarm Controller v1.0 Installation Guide

This installation guide provides the basic wiring, programming and troubleshooting information required to install the PowerSeries Neo alarm controller. **Use this guide in conjunction with the PowerSeries Neo Reference Manual available online from the DSC website at www.dsc.com.** Available models: HS2016, HS2032, HS2064, HS2128.

Quick Setup

1	Plan	Plan the installation including all alarm detection devices, zone expanders, keypads and other required modules.
2	Mount	Decide on a location for the alarm panel and secure it to the wall using suitable mounting hardware.
3	Wire	Complete all wiring including modules, zones, bells/sirens, telephone line connections and ground connections. Record module serial numbers on page 13.
4	Power	Connect the battery and power up the system. The battery must be connected.
5	Enroll First Keypad	<u>Hardwired:</u> Wire the keypad to the Corbus, power up the alarm panel then press any button on the keypad. <u>Wireless:</u> Wire the HSM2Host to the Corbus, then power up the alarm panel and a wireless keypad. Press any button on the keypad to enroll it. The HSM2Host is then enrolled on the alarm panel. Alternately, enroll an RF keypad.
6	Enroll modules	[*][8][Installer Code][902] subsection [000]. Press [*] to begin auto-enrollment. Module slots are automatically assigned. Use scroll keys to view slots. Change slot by typing a 2-digit number.
7	Enroll wireless devices	[*][8][Installer Code][804] subsection [000]. Note: An HSM2HOST or RF keypad must be enrolled first.
8	Program	Basic programming: [*][8][installer code] [001]/[002]> Zone Type/Zone Attribute [005]>[001] Partition 1 Timers: – Entry Delay 1 – Entry Delay 2 – Exit Delay [301]>[001] Phone #1 [310]>[000] System Account Code
9	Test	Test the panel completely to ensure that all features and functions operate as programmed. – [901] Walk Test – [904][000] Wireless Placement Test

Compatible Devices

Throughout this document, x in the model number represents the operating frequency of the device as follows: 9 (912-919 MHz), 8 (868MHz), 4 (433MHz).
NOTE: Only models operating in the band 912-919 MHz are UL/ULC listed where indicated. Only ^{UL} approved devices are to be used with UL/ULC listed systems.

Table 1-1 Compatible Devices

Modules		
Wireless keypads:	HS2LCDWFx ^{UL} HS2LCDWFPx ^{UL}	HS2LCDWFPVx ^{UL}
Hardwired keypads with 2-way wireless integration module:	HS2LCDRFx ^{UL} HS2LCDRFPx ^{UL}	HS2ICNRFx ^{UL} HS2ICNRPx ^{UL}
Hardwired keypads:	HS2LCD ^{UL} HS2LCDP ^{UL} HS2ICN ^{UL}	HS2ICNP ^{UL} HS2LED ^{UL}
2-way wireless integration module:	HSM2HOSTx ^{UL}	
8-zone expander:	HSM2108 ^{UL}	
8-output expander:	HSM2208 ^{UL}	
Power supply:	HSM2300 ^{UL}	
4 high current output expander:	HSM2204 ^{UL}	
Alternate communicator:	3G2080 ^{UL} 3G2080R ^{UL} TL280 ^{UL} TL280R ^{UL}	TL2803G ^{UL} TL2803GR ^{UL} PCL-422 ^{UL}
Hardwired Devices		
2-wire smoke detectors:	FSA-210x ^{UL} FSA-210xT ^{UL} x= A, B, or C A: ULC listed models B: UL listed models C: European and Australian models	FSA-210xR ^{UL} FSA-210xRT ^{UL} FSA-210xRS ^{UL} FSA-210xRST ^{UL} FSA-210xLRST ^{UL}
4-wire smoke detectors:	FSA-410x ^{UL} FSA-410xT ^{UL} x= A, B, or C A: ULC listed models B: UL listed models C: European and Australian models	FSA-410xR ^{UL} FSA-410xRT ^{UL} FSA-410xRS ^{UL} FSA-410xRST ^{UL} FSA-410xLRST ^{UL}
CO detectors:	CO-12/24 ^{UL} 12-24SIR ^{UL} FW-CO12 ^{UL}	FW-CO1224 ^{UL} CO1224 ^{UL}
Wireless Devices		
Wireless PG smoke detectors:	PGx926 ^{UL}	PGx916 ^{UL}
Wireless PG CO detector:	PGx913	
Wireless PG PIR motion detectors:	PGx904(P) ^{UL} PGx934(P) ^{UL} PGx974(P) ^{UL}	PGx924 ^{UL} PGx984(P) PGx994 ^{UL}
Wireless PG glass break detector:	PGx912	
Wireless PG shock detector:	PGx935 ^{UL}	
Wireless PG flood detector:	PGx985 ^{UL}	
Wireless PG temperature detector (indoor use):	PGx905 ^{UL}	
Outdoor temperature probe (requires PGx905)	PGTEMP-PROBE	
Wireless PG keys:	PGx939 ^{UL} PGx929 ^{UL}	PGx938 ^{UL} PGx949 ^{UL}
Wireless PG sirens:	PGx901 ^{UL}	PGx911 ^{UL}
Wireless PG repeater:	PGx920 ^{UL}	
Wireless PG door/window contacts:	PGx975 ^{UL}	PGx945 ^{UL}
Central Station Receivers		
SG-System I, II, III, IV		
Enclosures		
PC5003C, PC4050CR (ULC Fire Monitoring), PC4050CAR (UL Commercial Burg), CMC-1(UL Commercial Burg) Other enclosures are available to suit a variety of system configurations.		



WARNING: This manual contains information on limitations regarding product use and function and information on the limitations as to liability of the manufacturer. The entire manual should be carefully read.

Safety Instructions for Service Persons

Warning: When using equipment connected to the telephone network, always follow the basic safety instructions provided with this product. Save these instructions for future reference. Inform the end-user of the safety precautions that must be observed when operating this equipment.

Before Installing The Equipment – Ensure package includes the following:

- Installation and user manuals, including the SAFETY INSTRUCTIONS *READ and SAVE these instructions!*
- Follow ALL WARNINGS AND INSTRUCTIONS specified in this document and/or on the equipment
- HS2016/2032/2064/2128 alarm controller
- Power supply, direct plug-in
- Hardwired transformer (ULC Fire Monitoring)

Selecting A Suitable Location For The Alarm Controller

Use the following list as a guide to find a suitable location to install this equipment:

- Locate near a telephone socket and power outlet.
- Select a location free from vibration and shock.
- Place alarm controller on a flat, stable surface and follow the installation instructions. Do **NOT** locate this product where people may walk on the secondary circuit cable(s). Do **NOT** connect alarm controller to electrical the same circuit as large appliances. Do **NOT** select a location that exposes your alarm controller to direct sunlight, excessive heat, moisture, vapors, chemicals or dust.
- Do not install this equipment near water. (e.g., bath tub, kitchen/laundry sink, wet basement, near a swimming pool).
- Do **NOT** install this equipment and accessories in areas where risk of explosion exists. Do **NOT** connect this equipment to electrical outlets controlled by wall switches or automatic timers.
- AVOID** interference sources.
- AVOID** installing equipment near heaters, air conditioners, ventilators, and refrigerators.
- AVOID** locating equipment close to or on top of large metal objects (e.g., wall studs).

Safety Precautions Required During Installation

- Never install this equipment and/or telephone wiring during a lightning storm.
- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Position cables so that accidents can not occur. Connected cables must not be subject to excessive mechanical strain.
- Use only the power supply provided with this equipment. Use of unauthorized power supplies may cause damage.
- For direct plug-in versions, use the transformer supplied with the device.

WARNING: THIS EQUIPMENT HAS NO MAINS ON/OFF SWITCH. THE PLUG OF THE DIRECT PLUG-IN POWER SUPPLY IS INTENDED TO SERVE AS THE DISCONNECTING DEVICE IF THE EQUIPMENT MUST BE QUICKLY DISCONNECTED. IT IS IMPERATIVE THAT ACCESS TO THE MAINS PLUG AND ASSOCIATED MAINS SOCKET/OUTLET IS NEVER OBSTRUCTED.

IMPORTANT NOTE!

This alarm system must be installed and used within an environment that provides the pollution degree max 2 and over-voltages category II NON-HAZARDOUS LOCATIONS, indoor only. The equipment is direct plug-in (external transformer) and is designed to be installed, serviced and/or repaired by service personnel only; [service person is defined as an individual having the appropriate technical training and experience to recognize hazards associated with the installation and operation of this equipment and of measures to minimize the risks to themselves and others]. This equipment contains no user-serviceable parts. The wiring (cables) used for installation of the alarm system and accessories must be insulated with PVC, TFE, PTFE, FEP, Neoprene or Polyamide.

- The equipment enclosure must be secured to the building structure before operation.
 - Internal wiring must be routed in a manner that prevents:
 - Excessive strain or loosening of wire on terminal connections or damage of conductor insulation
 - Disposal of used batteries must be made in accordance with local waste recovery and recycling regulations.
 - Before servicing, disconnect the power and telephone connection.
 - Do not route any wiring over circuit boards.
 - The installer must ensure that a readily accessible disconnect device is incorporated into the building for permanently connected installations.
- The power supply must be Class II, fail safe with double or reinforced insulation between the primary and secondary circuit/enclosure and be an approved type acceptable to the local authorities. All national wiring rules must be observed.

Installation

Mounting the Enclosure

Locate the panel in a dry area, preferably near an unswitched AC power source and the incoming telephone line. Complete all wiring before applying AC or connecting the battery.

Terminal Descriptions

The following terminals are available on the PowerSeries Neo alarm controller:

Terminal	Description
AC	Power terminals. Connect the battery before connecting the AC. Do not connect the battery or transformer until all other wiring is complete.
BAT+, BAT-	Battery terminals. Use to provide backup power and additional current when system demands exceed the power output of the transformer, such as when the system is in alarm. Do not connect the battery until all other wiring is complete.
AUX+, AUX-	Auxiliary terminals. Use to power modules, detectors, relays, LEDs, etc. (700mA MAX). Connect the positive side of device to AUX+, the negative side to AUX-.
BELL+, BELL-	Bell/Siren power. Connect the positive side of any alarm warning device to BELL+, the negative side to BELL-.
RED, BLK, YEL, GRN	Corbus terminals. Use to provide communication between the alarm controller and connected modules. Each module has four Corbus terminals that must be connected to the Corbus.
PGM1 to PGM4	Programmable output terminals. Use to activate devices such as LEDs. (PGM1, PGM3, and PGM4: 50mA; PGM2: 300mA or can be configured as an input)
Z1 to Z8 COM	Zone input terminals. Ideally, each zone should have one detection device; however, multiple detection devices can be wired to the same zone.
TIP, RING, T-1, R-1	Telephone line terminals.
EGND	Earth ground connection.
PCLINK_1	DLS/SA
PCLINK_2	DLS/SA, Alternate Communicator

Corbus Wiring

The RED and BLK Corbus terminals are used to provide power while YEL and GRN are used for data communications. The 4 Corbus terminals of the alarm controller must be connected to the 4 Corbus terminals or wires of each module.


The following conditions apply:

- Corbus should be run with minimum 22 gauge quad, two pair twisted preferred.
- The modules can be home run to the panel, connected in series or can be T-tapped.
- Any module can be connected anywhere along the Corbus. Separate wire runs for keypads, zone expanders etc. are not necessary.
- No module can be more than 1,000/305m (in wire length) from the panel.

NOTE: Do not use shielded wire for Corbus wiring.

Diagram 1-1: Corbus Wiring

Module (A) is wired correctly as it is within 1,000/305m of the panel, in wire distance. Module (B) is wired correctly as it is within 1,000/305m of the panel, in wire distance. Module (C) is NOT wired correctly as it is further than 1,000/305m from the panel.



Current Ratings

In order for the system to operate properly, the power output of the alarm controller and power supply modules cannot be exceeded. Use the data below to ensure that the available current is not exceeded.

Table 1-1 System Output Ratings

Device	Output	Rating (12VDC)
HS2016 HS2032 HS2064 HS2128	AUX:	700mA. Subtract the listed rating for each keypad, expansion module and accessory connected to AUX or Corbus. At least 100mA must be reserved for the Corbus.
	BELL:	700mA. continuous rating. 2.0A. short term. Available only with standby battery connected. not for UL/ULC or EN certified applications
HSM2208	AUX:	250mA. Continuous rating. Subtract for each device connected. Subtract the total load on this terminal from the alarm panel AUX/Corbus output.
HSM2108	AUX:	100mA. Subtract for each device connected. Subtract the total load on this terminal from the panel AUX/Corbus output.

Alarm Control Panel

AUX - 700mA available for devices connected to the AUX and PGM terminals, and modules connected to Corbus terminals. At least 100mA must be reserved for the Corbus.

Alarm Controller Current Calculation Maximum (Standby or Alarm)

AUX (700mA max. including PGM1/2/3/4)	
Corbus (700mA max.)**	
PCLink+ (Alt. Com: 125mA)	
Total (must not exceed 700mA)	

**See "Corbus Current Calculation Chart" below.

NOTE: For UL, ULC and Commercial Listed applications, the total standby and alarm current cannot exceed 700mA.

Table 1-2 Corbus Current Calculation Chart

Item	Current (mA)	x	Quantity	Total (mA)
HS2LCD	105	x		
HS2ICN	105	x		
HS2LED	105	x		
HS2LCDP	105	x		
HS2ICNP	105	x		
HS2LCDRF	50	x		
HS2ICNRF	50	x		
HS2ICNRFP	50	x		
Current required for connected devices =				
HSM2108*	30	x		
HSM2208*	40	x		
HSM2300/2204*	35	x		
HSM2HOSTx	35	x		
3G2080(R)/ TL2803G(R)/TL280(R)	125 (PCLINK)			
Total Corbus Current =				

*These units draw current from the Corbus to power devices external to the module. This current must be added to the total Corbus current. See manufacturer's specifications for the current draw of each device.

Capacitance Limits

An increase in capacitance on the Corbus causes the system to slow down. The following chart indicates the total wire distance allowed for the capacitance rating of the wire used:

Table 1-3 Wire Capacitance

Wire Capacitance per 1000' (300m)	Total Corbus Wire Length
15nF	5300'/1616m
20nF	4000'/1220m
25nF	3200'/976m
30nF	2666'/810m
35nF	2280'/693m
10nF	2000'/608m

Zone Wiring

Power down the alarm controller and complete all zone wiring. Zones can be wired to supervise normally open devices (e.g., smoke detectors) or normally closed devices (e.g., door contacts). The alarm controller can also be programmed for SEOL or DEOL.

Zone programming is done using the following programming sections:

- [001] selects zone definition
- [013] Opt [1] for normally closed or EOL; Opt [2] for SEOL or DEOL

Observe the following guidelines when wiring zones:

- For UL listed installations use SEOL or DEOL only
- Minimum 22 AWG wire, maximum 18 AWG
- Do not use shielded wire
- Do not exceed 100Ω wire resistance. Refer to the chart below:

Table 1-4 Burglary Zone Wiring Chart

Wire Gauge	Maximum Length to EOL Resistor (ft/meters)
22	3000 / 914
20	4900 / 1493
19	6200 / 1889
18	7800 / 2377

Figures are based on maximum wiring resistance of 100Ω.

Aux Power Wiring

These terminals provide 11.3-12.5VDC/700mA of current (shared with PGM outputs). Connect the positive side of any device to the AUX+ terminal, the negative side to GND. The AUX output is protected; if too much current is drawn from these terminals (wiring short) the output is temporarily shut off until the problem is corrected.

NOTE: If using a 12V, 14Ah battery, maximum AUX capacity for 24-hour standby is 470mA.


PGM Wiring

PGMs switch to ground when activated from the alarm controller. Connect the positive side of the device to the AUX+ terminal and the negative side to a PGM terminal.

PGM 1, 3, 4 supply up to 50mA; PGM 2 supplies up to 300mA.

A relay is required for current levels greater than 50mA or 300mA. PGM2 can also be used for 2-wire smoke detectors.

NOTE: Use SEOL resistors on Fire zones only.

Diagram 1-2: LED output with resistor and optional relay driver output.


IMPORTANT: Minimum 6.4mm (1/4") separation must be maintained between RM-1 circuits and all other wiring

UL Compatibility ID For FSA-210B Series is: FS200

NOTE: For ULC listed installations, use FSA-210A and FSA-410A series.

Single End-of-Line (SEOL) Resistor

When SEOL resistors are installed at the end of a zone loop, the alarm panel detects if the circuit is secure, open, or shorted.


**Diagram 1-3: SEOL Wiring**

The SEOL resistor must be installed at the end of the loop for proper supervision.

To enable SEOL supervision, program section [013], options [1] and [2] to OFF.

Double End of Line (DEOL) Resistors


When double end-of-line (DEOL) resistors are installed at the end of a zone loop, the second resistor enables the panel to determine if the zone is in alarm, tampered or faulted.

**Diagram 1-4: DEOL Wiring**

To enable DEOL supervision, program section [013], option [1] to OFF and option [2] to ON.

Bell Wiring


These terminals supply 700mA of current at 10.4 - 12.5VDC for commercial/ residential installations. To comply with NFPA 72 Temporal Three Pattern requirements, section [013] Opt [8] must be ON. Note that steady and pulsed alarms are also supported.

**Diagram 1-5: Bell Wiring**

The Bell output is supervised and power limited by 2A PTC. If unused, connect a 1000Ω resistor across Bell+ and Bell- to prevent the panel from displaying a trouble.

Telephone Line Wiring

Wire the telephone connection terminals (TIP, Ring, T-1, R-1) to an RJ-31x connector as indicated in diagram 1.6. For connection of multiple devices to the telephone line, wire in the sequence indicated. Use 26 AWG wire minimum for wiring.


**Diagram 1-6: Telephone Line Wiring**

Telephone format is programmed in option [350].

Telephone call directions are programmed in options [311]-[318].

Ground Wiring**Diagram 1-7: Ground Installation**

Tighten nut to break paint and make good connection to the cabinet



NOTE: Using an insulated green wire (minimum 22AWG), connect the EGND terminal on the Corbus and the grounding wire from the building electrical installation to any of the available holes on the back or side of the metal cabinet. See the diagram attached to the cabinet for suggested GND point location and hardware recommendations.

NOTE: Wire and installation hardware not included.

Connecting AC Power (UL Listed Installations)

Primary: 120VAC/60Hz/0.33A
Secondary: 16.5VAC/40VA DSC PTD1640U, DSC PTC1640U Class 2 transformer.

NOTE: Use DSC PTD1640 for Canadian installations.

For ULC S559 applications, Standex transformer (Model FTC3716) shall be employed for direct-wiring.

NOTE: For UL/ULC installations use only 60Hz

Batteries

A sealed, rechargeable, lead acid or gel type battery is required to meet UL requirements for power standby times. Refer to Aux Loading and Battery Selection on page 15.

Enrollment

All optional modules and devices must be enrolled on the system. During enrollment, the electronic serial number (ESN) of each device is identified to the control panel and zones are assigned. A wireless transceiver HSM2HOST or an RF keypad must be enrolled first before wireless devices can be enrolled.

Enrolling Modules

During automatic and manual enrollment, if an attempt is made to enroll more than the maximum number of modules, an error tone sounds and a message is displayed on LCD keypads.

Table 1-5 Module Capacity

Module	HS2016	HS2032	HS2064	HS2128
HSM2108 8 Zone expander	1	3	7	15
HSM2208 8 Output expander	2	4	8	16
Wireless Keypad: HS2LCDRF(P)4 HS2ICNRF(P)4 HS2LCDWF(P)(V)4	8	8	8	16
HSM2300 Power Supply 1A	3	3	3	4
HSM2204 4 High Current Output	1	1	3	4
HSM2HOSTx Transceiver	1	1	1	1
PC5950 Audio Verification (not UL evaluated)	1	1	1	1

Modules can be enrolled automatically or manually using section [902] of Installer programming.

To confirm that a module has been successfully enrolled, use Installer Programming section [903].

Enroll Wireless Devices

Wireless devices are enrolled via the wireless transceiver module and Installer Programming section [804][000].

Auto Enrollment

To enroll a wireless device using this method, press and hold the Enroll button on the device for 2-5 seconds until the LED lights then release the button. The alarm panel automatically recognizes the device and the keypad displays a confirmation message. The device ID and next available zone number are displayed. Press [*] to accept or scroll to another available zone number.

Pre-Enrollment

Pre-enrollment is a two step process. The first step requires entering each device ID ([804][001]-[716]). Every wireless device has an ID printed on the sticker attached to the device. The format is XXX-YYYY where:

- XXX identifies the type or model of the device
- YYYY is a short encrypted ID used by the system to identify the specific device

Pre-enrollment can be done at a remote location and using DLS. The second step is to press the enrollment button on the device, usually done on location. Installer Programming does not have to be entered at this step. Both steps must be performed in order to complete the enrollment.

Programming Methods

The alarm system can be programmed using the following methods:

Table 1-6 Programming Methods

Method	Description	Procedure
Template programming	Use pre-defined templates to quickly apply basic programming and to set up DLS downloading.	Press [899] at the "Enter Section" screen. See the PowerSeries Neo Reference Manual for details.
DLS programming	Download and apply programming using DLS-5™ (v.1.3 or higher) software.	For local DLS, use a PC-Link cable and laptop with DLS-5 software installed. For remote DLS, use a telephone line, cellular network or the Internet.
Installer programming	Manually program all alarm system and device options.	Press [*][8][installer code] while the system is disarmed.

Viewing Programming

Programming sections can be viewed from any system keypad. The method for viewing and selecting programming options using LCD, LED and ICON keypads depends on the keypad type used.

Generally, programming options are accessed in the following way:

1. Enter Installer Programming mode ([*][8]).
2. Navigate to a specific programming section.
3. Select an option to view or change it's programming.

All programming options are numbered and can be accessed by navigating through the menu (LCD) or by keying in the program section number.

For toggle options, the name of the option is displayed (LCD) or LEDs 1-8 are illuminated (LED and ICON).

Use the keypad numbers to toggle options on or off. Sections requiring data input, such as phone numbers, display the full data in fields up to 32 characters long (LCD). To input data, use the scroll keys to select a character then press the keypad button corresponding to the number/letter required. Scroll to the next character and repeat the procedure as needed. Press the [#] key to save changes and exit the program section.

Minimum Required Programming

Once basic installation of the alarm panel is complete, the following general configuration options can be set.

[000] Language Selection

(LCD keypads only)

Use this section to set the language displayed by LCD keypads. To select a language:

1. Enter Installer Programming: [*][8][Installer Code].
2. Enter programming section [000]>[000].
3. Key in the 2-digit number corresponding to the language required. See below:

01 = English	11 = Swedish	21 = Russian
02 = Spanish	12 = Norwegian	22 = Bulgarian
03 = Portuguese	13 = Danish	23 = Latvian
04 = French	14 = Hebrew	24 = Lithuanian
05 = Italian	15 = Greek	25 = Ukrainian
06 = Dutch	16 = Turkish	26 = Slovakian
07 = Polish	18 = Croatian	27 = Serbian
08 = Czech	19 = Hungarian	28 = Estonian
09 = Finnish	20 = Romanian	29 = Slovenian
10 = German		

Time and Date

Use this section to program the alarm system clock.

Menu: [*][6][master code] > Time and Date

Keypad: [*][6][master code] + 01

Enter time and date using the following format: (HH:MM); (MM-DD-YY). Valid time entries are 00-23hours, 00-59 minutes. Valid date entries are 1-12 months, 1-31 days.

Setting Up a Partition

Partitions are added or removed from the system by applying or removing a partition mask via Installer Programming section [200]. The number of available partitions depends on the alarm panel model.

Bell/Siren Operation

Each partition must have a siren. The system siren connected to the bell output of the alarm controller can be mounted in a central location within hearing range of all partitions. Each partition can also have wireless sirens activated only on the assigned partition.

Keypad Partition Setup

Keypads can be configured to control an individual partition or all partitions.

1. Enter Installer Programming [*][8][installer code].
2. Select [861]-[876] to program keypads 1-16.
 - Press [000] for partition assignment.
 - For global operation, key in 00.
 - To assign a keypad to a partition, key in 01-08 for partition 1-8.
3. Press the [#] key twice to exit programming.
Continue this procedure at each keypad until all have been programmed.

Users are assigned partition access rights via the [*][5] menu.

Assign sirens to partitions:

[804]>[000]>[551]-[556]>[000]

Set up partition account codes:

[310]>[001]-[008]

Set up partition timers:

- Entry/exit delay, settle delay – [005]>[001]-[008]
- Automatic arming/disarming schedule – [151]-[158]>[001]/[002]
- Auto disarming holiday schedule – [151]-[158]>[003]
- No activity arming – [151]-[158]>[006]
- Automatic clock adjust – [005]>[000], option 6
- Delay between dialing attempts – [377]>[012]

Assign Zone Types

[001]>[001]-[128]> Every zone on the system must be assigned one of the following zone types:

000 – Null Zone	041 – 24-Hour CO
001 – Delay 1	042 – 24-Hour Holdup*
002 – Delay 2	043 – 24-Hour Panic
003 – Instant	045 – 24-Hour Heat
004 – Interior	046 – 24-Hour Medical*
005 – Interior Stay/Away	047 – 24-Hour Emergency
006 – Delay Stay/Away	048 – 24-Hour Sprinkler*
007 – Delayed 24-Hour Fire	049 – 24-Hour Flood
008 – Standard 24-Hour Fire	051 – 24-Hour Latching Tamper
009 – Instant Stay/Away	052 – 24-Hour Non-Alarm
010 – Interior Delay	056 – 24-Hour High Temperature
011 – Day Zone	057 – 24 Hour Low Temperature
012 – Night Zone	060 – 24-Hour Non-Latching Tamper
017 – 24-Hour Burglary	066 – Momentary Keyswitch Arm
018 – 24-Hour Bell/Buzzer	067 – Maintained Keyswitch Arm
023 – 24-Hour Supervisory	068 – Momentary Keyswitch Disarm
024 – 24-Hour Supervisory Buzzer	069 – Maintained Keyswitch Disarm
025 – Auto Verified Fire	071 – Door Bell
027 – Fire Supervisory	* Not UL evaluated
040 – 24-Hour Gas	

Assign zone attributes:

[002]>[001]-[128]>Select one of the following zone attributes:

1 – Bell Audible	9 – Normally Closed EOL
2 – Bell Steady	10 – Single EOL
3 – Chime Function	11 – Double EOL
4 – Bypass Enabled	12 – Fast/Normal Loop Response
5 – Force Arm	
6 – Swinger Shutdown	
7 – Transmission Delay	
8 – Burglary Verification	

Create labels:

[000]>[001]-[821] 2 x 14 ASCII characters.

Add access codes:

To program an access code: [006] then one of the following:

- [001] – Installer code
- [002] – Master code
- [003] – Maintenance code

Access codes are either 4 or 6 digits in length, depending on the setting of programming section [041]. Duplicate codes are not valid.

Alternate Communicator Setup

The following configuration steps are required to set up the alternate communicator:

- Install the alternate communicator and wire it to the alarm panel
- Enroll the alternate communicator with Connect 24
- Set the communication path: [300]
- Enable the alternate communicator: [382] option 5
- Enable event reporting: [307]/[308]
- Program communication delay timer: [377]
- Program DLS access: [401] option 07

Refer to the 3G2080(R)/ TL2803G(R)/ TL280(R) installation manual for details.

Panel/Receiver Communication Paths

This section is used to select the path of communications between the alarm system and the central station.

- To use as the communications path, program section [300] options 001 through 004 as [01] 1.
- To use the alternate communicator to establish a communications path, program two of the receivers (section [300] options 001, 002, 003 or 004) as [03] and [04] for Ethernet, and two of the receivers as [05] and [06] for cellular.

Testing the System

Installer Walk Test

Enter section [901] to initiate a walk test. When a zone is tripped, all sirens emit a tone to indicate that the zone is working correctly.

After 15 minutes without zone activity, the walk test terminates automatically. To manually exit walk test mode, enter [901] again.

Viewing the Event Buffer

The event buffer displays logs of events that have occurred on the alarm system beginning with the most recent. To view the event buffer, press [*][6][master code][*][*].

Troubleshooting

To view troubles:

- Press [*][2] followed by an access code if required.
- Use the arrow keys to scroll through all trouble conditions present on the system.
- Refer to the trouble summary list below for trouble descriptions.

[*][2]Trouble Summary

Trouble	Detailed Trouble	
01 – Service Required	01 – Bell circuit 02 – RF jam detected 03 – Aux supply trouble	04 – Time and date 05 – Output 1 fault
02 – Module Low Battery	01 – Panel low battery 02 – Panel no battery 04 – HSM2204 1-4 low battery	05 – HSM2204 1-4 no battery 07 – HSM2300 1-4 low battery 08 – HSM2300 1-4 no battery
03 – Bus Low Voltage	01 – HSM2HOST voltage 02 – Keypad 1-16 voltage 04 – HS2108 1-15 voltage	05 – HSM2300 1-4 voltage 06 – HSM2204 1-4 voltage 11 – HSM2208 1-4 voltage
04 – AC Troubles	01 – Zone 1-128 AC 03 – Siren 1-16 AC 04 – Repeater 1-8 AC	05 – HSM2300 1-4 AC 06 – HSM2204 1-4 AC 07 – Alarm Controller AC
05 – Device Faults	01 – Zone 1-128 – Freeze – Probe Disconnected – Fire – Gas – Heat – CO	02 – Keypad 1-16 03 – Siren 1-16 04 – Repeater 1-8
06 – Device Low Battery	01 – Zone 1-128 02 – Keypad 1-16 03 – Siren 1-16	04 – Repeater 1-8 05 – User 1-32
07 – Device Tamper	01 – Zone 1-128 02 – Keypad 1-16	03 – Siren 1-16 04 – Repeater 1-8
08 – RF Delinquency	01 – Zone 1-128 02 – Keypad 1-16	03 – Siren 1-16 04 – Repeater 1-8
09 – Module Supervisory	01 – HSM2HOST 02 – Keypad 1-16 04 – HS2108 1-15	05 – HSM2300 1-4 06 – HSM2204 08 – HSM2208 1-4
10 – Module Tamper	01 – HSM2HOST 02 – Keypad 1-16 04 – HS2108 1-15	05 – HSM2300 1-4 06 – HSM2204 08 – HSM2208 1-4
11 – Communications	01 – TLM 02 – Phone number 01-04 03 – Alt. comm SIM lock 04 – Alt. comm cellular 05 – Alt. comm Ethernet	06 – Receiver 1-4 absent 07 – Receiver 1-4 supervision 09 – Alt. comm fault
12 – Not Networked	01 – Zone 1-128 02 – Keypad 1-16 03 – Siren 1-16	04 – Repeater 1-8 05 – User 1-32

Trouble [1] Service Required	Press [01] to determine specific trouble
Trouble	Troubleshooting
[01] Bell Circuit Bell+, Bell-...open circuit.	• Disconnect Bell-/+ leads and measure resistance: • Open circuit indicates break in wiring or defective siren/bell. • Jumper Bell+/- with 1K resistor (Brown, Black, Red):
[02] RF Jam Detected Wireless receiver - excessive noise detected.	• Check event buffer to determine specific trouble. • If buffer logs RF jam, check for RF interference. • Disable RF Jam: section [804] sub-section [801].
[03] Aux Supply An auxiliary power supply trouble is present.	• Check for a short between Aux+ and Aux- or other system ground. • Ensure the aux current draw has not exceeded the documented limits.
[04] Time and Date The alarm controller internal clock is not set.	To program the time and date: • Enter [*][6][Master Code] then press [01]. • Enter the time and date (24-hour clock) using the following format: HH:MM MM/DD/YY e.g., For 6:00 pm, June 29, 2010: Enter: [18] [00] [06] [29] [10]
[05] Output 1 Fault HSM2204 output#1 open circuit.	• If output #1 is unused: ensure terminals O1, AUX are jumpered with 1K resistor (brown, black, red). • If output #1 is used: disconnect wire leads from O1, AUX terminals, measure resistance of leads: • Open circuit indicates a break in wiring.

Trouble [2] Module Battery	Press [02] to determine specific trouble
Trouble	Troubleshooting
[01] Panel Low Battery The panel detects that the battery is below the low battery threshold (less than 11.5VDC).	• NOTE: If battery is new allow 1 hour to charge. • Verify voltage measured across AC terminals is 16-18 VAC. Replace transformer if required. • Disconnect battery wire leads: • Verify battery charging voltage measured across battery leads = 13.70 - 13.80 VDC. • Connect battery, remove AC power. • Verify measured voltage across Aux terminals is 12.5VDC min.
NOTE: This trouble condition will not clear until the battery voltage is 12.5VDC min., under load.	

[02] Panel No Battery The panel detects that no battery is present or that the battery is shorted.	- Verify battery is connected. - Refer to troubleshooting steps for panel low battery.
[04] 4 High Current output 1-4 Low Battery (HSM2204) HSM2204 battery less than 11.5VDC. NOTE: This trouble condition will not clear until the battery voltage is 12.5VDC min., under load.	- Charge battery. It may be low due to a long period without AC. - Replace battery if it is no longer able to hold a charge due to age.
[05] 4 High Current output 1-4 No Battery (HSM2204) Enter 05 to view which HSM2204 does not have a battery connected.	- Verify battery is connected. - Refer to troubleshooting steps for panel low battery.
[7] Power Supply 1-4 Low Battery (HSM2300) Enter 07 to view which HSM2300 has a battery voltage less than 11.5V.	- Charge battery. It may be low due to a long period without AC. - Replace battery if it is no longer able to hold a charge due to age.
[8] Power Supply 1-4 No Battery (HSM2300) Enter 08 to view which HSM2300 does not have a battery connected.	- Verify battery is connected. - Refer to troubleshooting steps for panel low battery.

Trouble [3] Bus Voltage Trouble Press [03] to determine specific trouble	
Trouble	Troubleshooting
[01] HSM2HOST Bus Low Voltage The 2-way wireless integration module has detected a voltage less than 6.3V on its aux input.	- Ensure voltage at module is higher than the documented limits. - Ensure wire run is not too long. - Check voltage of panel battery.
[02] Keypad 1-16 Bus Low Voltage Enter 02 to view hardwired keypads with a bus voltage of less than 6.9V for ICON/LCD models that include a wireless transceiver, 7.7V for the ICON/LCD/LED models that do not.	- Trouble should clear when AC is re-applied and the battery has had time to charge. - Disconnect AC and allow the panel to run on battery power. Ensure voltage at module is higher than the documented limits.
[04] HSM2108 Bus Low Voltage Enter 04 to view zone expanders that with a bus voltage of less than 5.9V.	
[05] HSM2300 Bus Low Voltage Enter 05 to view power supplies with a bus voltage of less than 6.9V.	
[06] HSM2204 Bus Low Voltage Enter 06 to view high current output modules that have detected a bus voltage of less than 6.9V.	
[08] HSM2208 Bus Low Voltage The low current output module has detected a voltage less than 5.9V on its aux input.	

Trouble [4] AC Failure Press [04] to determine specific trouble	
Trouble	Troubleshooting
[01] Zone 1-128 AC [05] HSM2300 AC 1-4 [06] HSM2204 1-4 AC [07] Alarm Controller An AC trouble has been detected on a device or module.	Verify voltage measured across AC terminals is 16-18VAC. Replace transformer if required.

Trouble [05] Device Faults Press [05] to determine specific trouble	
Trouble	Troubleshooting
[01] Zone 1-128 faults Wireless zones: Enter [01] to view zones in fault. This trouble is generated by a zone wireless supervisory trouble.	- Ensure fire zones have a 5.6K resistor (green, blue, red) connected. - Remove wire leads from Z and COM terminals and measure resistance of the wire leads: - Check for a short on DEOL zones or an open condition on SEOL fire zones. - Connect a 5.6K resistor across the Z and COM terminals. Verify the trouble condition clears. - Placement test a wireless device and re-locate it if bad results are received.
Hardwired zones: Enter [01] to view zones in fault. “Fire Zone” is displayed in the [*][2] menu if an open circuit is present on PGM2 being used as a 2-wire smoke detector input. This trouble is generated by a short on hardwired zones when DEOL is used.	- Ensure a 2.2K EOL resistor is connected (red, red, red). - Remove wire leads from PGM2 and AUX+ terminals and measure resistance of the wire leads: - An open circuit indicates a break in the wiring or no resistor connected. - Connect a 2.2K resistor across PGM2 and AUX+ terminals. Verify that trouble clears.

[02] Keypad 1-16 faults Enter [02] to view keypads in fault. This trouble is caused by a wireless supervisory fault if the keypad is wireless.	Placement test the wireless keypad and re-locate if needed.
[03] Siren 1-16 faults This trouble is caused by a wireless supervisory fault on a wireless siren.	See [02] Keypad 1-16 faults above.
[04] Repeater 1-8 faults This trouble is caused by a wireless supervisory fault on a wireless repeater, or by the repeater shutting down due to a loss of AC/DC power.	See [02] Keypad 1-16 faults above.
Additional trouble conditions: - Fire (2-W Smoke, PGX916, PGX926, PGX936) - Gas (PGX923) - Heat (PGX946)	- Freeze (PGX905) - CO (PGX913) - Probe Disconnected (PGX905)

Trouble [6] Device Low Battery Press [06] to toggle through specific devices with low battery trouble	
Trouble	Troubleshooting
[01] Zones 1-128 [02] keypad 1-16 [03] Siren 1-16 [04] Repeater 1-8 [05] User 1-95 One or more wireless devices has a low battery. NOTE: The event is not logged to the event buffer until the wireless device low battery delay time expires. Programming section [377], Opt 002.	- Verify zone operation. - Verify that tamper and low battery condition is cleared and reported. - View which device is in low battery though the [*][2] menu.

Trouble [7] Device Tamper Press [07] to determine specific trouble	
Trouble	Troubleshooting
[01] Zone 1-128 tampers [02] Keypad 1-16 tampers [03] Siren 1-16 tampers [04] Repeater 1-8 tampers An open circuit is present on one or more zones with DEOL resistors enabled.	- Check that the tamper switch is securely attached to the wall. - Remove the wire leads from I/O and COM and measure the resistance of the wire leads. - Connect a 5.6K resistor (Green, Blue, Red) across the I/O and COM terminals. - Verify the trouble condition clears.
A tamper condition is present on one or more wireless devices.	- Ensure device cover is secure. - Ensure device is correctly mounted for wall tamper operation. - Trip, then restore the tamper. If tamper condition persists, replace wireless device.

Trouble [8] RF Delinquency Press [08] to determine specific trouble	
Trouble	Troubleshooting
[01] Zone 1-128 faults [02] Keypad 1-16 faults [03] Siren 1-16 faults [04] Repeater 1-8 faults HSM2HOST has not received a supervisory signal from a wireless device for 13 minutes. Arming disabled until trouble acknowledged in [*][2] or the trouble is cleared.	- Open/close the device, press a key on the keypad or tamper/restore. - Ensure the device is physically present. - Check for device faults (e.g., low battery). - Check the current signal strength and during the last 24 hours. - Replace the battery. - Replace the device.

Trouble [9] Module Supervisory Press [09] to determine specific zones with a tamper trouble	
Trouble	Troubleshooting
[01] HSM2HOST [02] Keypad 1-16 [04] HSM2108 1-15 [05] HSM2300 1-4 [06] HSM2204 [08] HSM2208 1-4 No supervisory response from enrolled module.	- Modules are immediately enrolled and supervised. If a module is removed, or if the keypad slot is changed, module supervision must be reset. - View the event buffer to identify the specific module(s) in trouble. - To reset module supervision: - Enter programming section [902]. - Select auto or manual enrollment. - Enter programming section [903] to identify modules connected to the Corbus.

Trouble [10] Module Tamper	Press [10] to determine specific trouble
Trouble	Troubleshooting
[01] HSM2HOST [02] Keypad 1-16 [04] HSM2108 1-15 [05] HSM2300 1-4 [06] HSM2204 [08] HSM2208 1-4 A tamper condition is present on one or more modules.	- Ensure the TAM terminal on HSM2108, HSM2300, HSM2204 and HSM2208 modules is shorted to ground if tamper support is not used. - Ensure module cover is secure. - Ensure module is correctly mounted for wall tamper operation. - Trip, then restore the tamper. If tamper condition persists, replace the module.

Trouble [11] Communications	Press [11] to determine specific trouble
Trouble	Troubleshooting
[01] Phone Line Trouble Phone line voltage at TIP, RING on main panel less than 3VDC.	- Measure the voltage across TIP and RING on the panel: - No phone off-hook – 50VDC (approx). - Any phone off-hook – 5VDC (approx). - Wire incoming line directly to TIP and RING. - If trouble clears, check wiring or the RJ-31 phone jack.
[02] Phone Number 1-4 FTC The system failed to communicate with a receiver using one of the enabled phone numbers. Enter [02] to view phone numbers with failure to communicate troubles.	- Ensure adequate line voltage at the panel Tip and Ring (On hook ~41VDC, Off hook ~7VDC). - Ensure panel phone number is programmed correctly when using . If using IP or cellular, ensure alternate communicator has the correct IP addresses and programming.
[03] Alternate Comm SIM Lock SIM lock is enabled and the unit does not have the correct SIM PIN.	See the communicator installation manual for details.
[04] Alternate Comm Cellular The alternate communicator has detected a radio or SIM failure, a cellular network trouble, or insufficient signal strength.	See the communicator installation manual for details.
[05] Alternate Comm Ethernet The alternate communicator has detected a network absent condition.	See the communicator installation manual for details.
[06] Receiver 1-4 Absent Alternate communicator supervision loss or failure to initialize a receiver.	See the communicator installation manual for details.
[07] Receiver 1-4 Supervision The alarm system loses communication with an Ethernet or cellular receiver on the system.	See the communicator installation manual for details.
[09] Alternate Comm Fault The alternate communicator has not responded to any poll commands. Alt Comm Fault is displayed in [*][2] and the event buffer.	See the communicator installation manual for details.
[10] Alternate Comm FTC Fault	Refer to the communicator installation manual for more details.

Trouble [12] Not Networked	Press [12] to toggle through troubles
Trouble	Troubleshooting
[01] Zones 1-128 [02] keypad 1-16 [03] Siren 1-16 [04] Repeater 1-8 [05] User 1-16 A device is out of sync with the wireless network or was not synchronized with the network after enrollment.	- Ensure the device is physically present. - Check the current signal strength and during the last 24 hours. - Replace the battery or press the tamper switch. - Enroll the device again.

Specifications

Warning Device Output

- Integral sounder capable of 85 dB @ 3m, self-powered type Z
- 2 remote, wireless warning devices supported: PGX901 (indoor), PGX911 (outdoor) (X=4, 8, or 9)
- Programmable as steady, pulsed or temporal three (as per ISO8201) and temporal four (CO alarm) output
- Warning device sounds alarms in the following priority: fire, CO, medical, burg

Memory

- CMOS EEPROM memory
- Retains programming and system status on AC or battery failure for 20 years min. (not verified by UL)

Power Supply

Transformer: DSC PTD1640U

Primary: 120V, 60Hz Class II

Secondary: 16.5VAC, 40VA Max.

Regulated power supply:

- 700mA auxiliary supply, 12V DC
- Positive temperature coefficient (PTC) for Bell, Aux+ and Battery terminals
- Reverse battery detection/protection
- Supervision for AC power and low battery
- Normal and high current battery charge options
- Supervised battery charging circuit

Current draw (panel): 85mA (nominal) 2A(Max)

Bell Output:

- 12V, 700mA supervised (1k Ohm) bell output (current limited at 2 amps)
- Steady, Pulsed, Temporal 3 fire, CO alarm cadences
- Bell short detection (software + hardware)

Aux+:

- Voltage range = 9.6V - 13.8V DC
- Current = 700mA (shared with PGM outputs)
- Output ripple voltage: 270mVp-p max.
- Onboard programmable outputs:
 - PGM 1 - 50mA switched programmable output
 - PGM 2 - 300mA current-limited switched programmable output. 2-Wire smoke detectors (90mA current limited) are supported using this PGM
 - PGM 3 - 50mA switched programmable output
 - PGM 4 - 50mA switched programmable output
 - Hardware PGM over current protection

Battery

- 12V sealed lead acid, rechargeable
- Battery capacity:
 - 4Ah (PS4-12)
 - 7Ah (BD7-12)
 - 14Ah
- Maximum standby time: 24 hours (with 14Ah battery and Aux current limited to 470mA)
- Recharging time to 80% 72 hours
- Recharging rate: 240mA (12 hours max.), 480mA (24 hour backup)
- Backup time: 24 hours (UL)
- Battery lifespan: 3-5 years
- Low battery trouble indication threshold 11.5VDC
- Battery restore voltage 12.5V
- Main board current draw (battery only):
 - HS2016/32/64/128 (no alternate communicator) standby 80mA DC
 - HS2016/32/64/128, (including alternate communicator) standby 190mA DC
 - Transmit (alternate communicator module) 195mA DC
- Resettable fuses (PTC) used on circuit board
- Supervision for loss of primary power source (AC fail), battery loss or battery low voltage (battery trouble) with indication provided on the keypad
- Internal clock locked to AC power frequency

Battery Charging Current: 400mA/700mA*		
Battery Size	Standby	
	4Hr	24Hr
4Ahr	700mA	----
7Ahr	700mA	180mA
14Ahr	700mA	470mA

* with high current battery charge option enabled: [982] bit 1.

Battery capacity deteriorates with age and the number of charge/discharge cycles. Replace every 3-5 years.

Operating Environmental Conditions

- Temperature range: **UL**= 0°C to +49°C (32°F-120°F)
- Relative humidity: <93% non condensing

Alarm Transmitter Equipment (ATE) Specification

- Digital dialer integral to the main control board
- Supports SIA and Contact ID
- Complies with TS203 021-1, -2, -3 Telecom equipment requirements and EN50136-1-1, EN50136-2-1, EN50136-2-3 ATS 2
- Optional Dual IP/Cellular communicators (3G2080(R)/ TL2803G(R)/ TL280(R)) can be installed in the same enclosure and configured as primary or back-up, with AES 128-bit encryption
- Compliant with EN50136-1-1, EN50136-2-1 ATS2 requirements

Programming Directory

This section provides a list of all available programming options in numerical order. To program, access Installer Programming mode by keying in [*][8][Installer Code]. Use the scroll keys to navigate through the menus or jump directly to a specific section by keying in a section number and pressing [*]. Programming consists of toggling on and off options in each section or by populating data fields. Press [*] to select options and [#] to exit to the previous menu. For descriptions of all programming options and programming worksheets, refer to the PowerSeries Neo Reference Manual. ✓= Default

Label Programming

000 Label Programming

- 000 – Language Selection (01)
- 001 – Zone Labels
 - 001-128 – Zone Labels 1-128
- 051 – Zone Tamper Label
- 052 – Zone Fault Label
- 064 – CO Alarm Message
- 065 – Fire Alarm Message
- 066 – Fail to Arm Event Message
- 067 – Alarm When Armed Event Message
- 100 – System Label
- 101-108 – Partition 1-8 Labels
- 201-208 – Partition 1-8 Command Output Labels
 - 001-004 – Command output 1-4 Labels
- 601-604 – Schedule 1-4 Labels
- 801 – Keypad Labels
 - 001-016 Keypad 1-16 Labels
- 802 – Zone Expander Labels
 - 001-015 – Zone Expander 1-15 Labels
- 803 – Output Expander Labels
 - 001 Output Expander 1 Label
- 806 – HSM2HOST Label
- 809 – Power Supply Label
 - 001-004 Power Supply 1-4 Label
- 810 – High Current Output Supply Label
 - 001-004 Power Supply 1-4 Label
- 815 – Alternate Communicator Label
- 820 – Siren Label
 - 001-016 Siren 1-16 Label
- 821 – Repeater Label
 - 001-008 Repeater 1-8 Label
- 999 – Default Labels

Zone Type

001 Zone Type

- 001-128 Zone Types (000)
 - 000 – Null Zone
 - 001 – Delay 1
 - 002 – Delay 2
 - 003 – Instant
 - 004 – Interior
 - 005 – Interior Stay/Away
 - 006 – Delay Stay/Away
 - 007 – Delayed 24-Hour Fire
 - 008 – Standard 24-Hour Fire
 - 009 – Instant Stay/Away
 - 010 – Interior Delay
 - 011 – Day Zone
 - 012 – Night Zone
 - 017 – 24-Hour Burglary
 - 018 – 24-Hour Bell/Buzzer
 - 023 – 24-Hour Supervisory
 - 024 – 24-Hour Supervisory Buzzer
 - 025 – Auto Verify Fire
 - 027 – Fire Supervisory
 - 040 – 24-Hour Gas
 - 041 – 24-Hour CO
 - 042 – 24-Hour Holdup
 - 043 – 24-Hour Panic
 - 045 – 24-Hour Heat
 - 046 – 24-Hour Medical*
 - 047 – 24-Hour Emergency
 - 048 – 24-Hour Sprinkler
 - 049 – 24-Hour Flood
 - 051 – 24-Hour Latching Tamper
 - 052 – 24-Hour Non-Alarm
 - 056 – 24-Hour High Temperature
 - 057 – 24-Hour Low Temperature

- 060 – 24-Hour Non-Latching Tamper
- 066 – Momentary Keyswitch Arm
- 067 – Maintained Keyswitch Arm
- 068 – Momentary Keyswitch Disarm
- 069 – Maintained Keyswitch Disarm
- 071 – Doorbell Zone

002 – Zone Attributes

001-0128 (see PowerSeries Neo reference manual for defaults)

- 1 – Bell Audible
- 2 – Bell Steady
- 3 – Door Chime
- 4 – Bypass Enabled
- 5 – Force Arm
- 6 – Swinger Shutdown
- 7 – Transmission Delay
- 8 – Burglary Verification
- 9 – Normally Closed EOL
- 10 – Single EOL
- 11 – Double EOL
- 12 – Fast Loop/Normal Loop Response

System Times

005 System Times

- 000 – System Area
 - Bell Cutoff (004 min.)
 - Burglary Verification Timer (060 sec.)
 - Zone Loop Response (250 ms)
 - Automatic Clock Adjust (060 sec.)
- 001 – 008 System Times - Partition 1-8
 - Entry Delay 1 (030 sec.)
 - Entry Delay 2 (045 sec.)
 - Exit Delay (120 sec.)
- 901 – Daylight Savings Begin:
 - Month (003)
 - Week (002)
 - Day (000)
 - Hour (002)
 - Increment (001)
- 902 – Daylight Savings End
 - Month (011)
 - Week (001)
 - Day (000)
 - Hour (002)
 - Increment (001)

Access Codes

006 Installer Defined Access Codes

- (4-digit decimal)
- 001 – Installer Code (555555)
- 002 – Master Code (123456)
- 003 – Maintenance Code (AAAA00)

PGM Programming

007 – PGM Programming

- 000 – Main Bell Partition Assignment
 - 1 – Partition 1
 - 2 – Partition 2
 - 3 – Partition 3
 - 4 – Partition 4
 - 5 – Partition 5
 - 6 – Partition 6
 - 7 – Partition 7
 - 8 – Partition 8
- 001-164 – PGM 1-164 Partition Assignment (default: partition 1)
 - 1-8 – Partition 1-8

008 – PGM Timer Programming

- 000 – PGM Timer-Minutes or Seconds
- 001-164 – PGM 1-164 Timer (005)

009 – PGM Types

- 001-164 – PGM 1-164 Type Assignment (default: PGM1=121, PGM2=156, 3-164=101)
- 100 – Null PGM

- 101 – Burg and Fire Bell Follower
- 102 – Delayed Fire and Burg
- 103 – Sensor Reset [*][7][2]
- 104 – 2-Wire Smoke
- 109 – Courtesy Pulse
- 111 – Keypad Buzzer Follow
- 114 – Ready To Arm
- 115 – System Armed Status
- 116 – Away Armed Status
- 117 – Stay Armed Status
- 120 – Away Armed with no Zone Bypass Status
- 121 – Command Output 1
- 122 – Command Output 2
- 123 – Command Output 3
- 124 – Command Output 4
- 129 – Partition Status Alarm Memory
- 132 – Holdup Output
- 134 – 24Hr Silent Input
- 135 – 24Hr Audible Input
- 146 – TLM and Alarm
- 147 – Kissoff
- 148 – Ground Start
- 149 – Alternate Communicator
- 155 – System Trouble
- 156 – Latched System Event
- 157 – System Tamper
- 161 – DC Trouble
- 165 – Prox Used
- 175 – Bell Status and Programming Access Output
- 176 – Remote Operation
- 184 – Open After Alarm
- 200 – Zone Follower
- 201 – Follower-Zones 1-8
- 202 – Follower-Zones 9-16
- 203 – Follower-Zones 17-24
- 204 – Follower-Zones 25-32
- 205 – Follower-Zones 33-40
- 206 – Follower-Zones 41-48
- 207 – Follower-Zones 49-56
- 208 – Follower-Zones 57-64
- 209 – Follower-Zones 65-72
- 210 – Follower-Zones 73-80
- 211 – Follower-Zones 81-88
- 212 – Follower-Zones 89-96
- 213 – Follower-Zones 97-104
- 214 – Follower-Zones 105-112
- 215 – Follower-Zones 113-120
- 216 – Follower-Zones 120-128

010 PGM Attributes

- 000 – Main Bell Mask
 - Fire Alarm (✓)
 - CO Alarm (✓)
 - Burglary Alarm (✓)
 - 24-Hour Flood Alarm (✓)
 - Bell Squawks (✓)
- 001-164 PGM 1-164 Attributes
- 100 – Null PGM
- 101 – Fire and Burglary
 - 01 – True Output (✓)
- 102 – Delay Fire and Burglary
 - 01 – True Output
- 103 – Sensor Reset [*][7][2]
 - 03 – Code Required
- 109 – Courtesy Pulse
 - 01 – True Output
- 111 – Keypad Buzzer Follow
 - 01 – True Output (✓)
 - 02 – Timed Output
 - 09 – Entry Delay (✓)
 - 10 – Exit Delay (✓)
 - 11 – Door Chime (✓)
 - 12 – Keypad Buzzer Zone (✓)

- 13 – Audible Exit Fault (✓)
- 14 – Auto-Arm Pre-Alert (✓)
- 114 – Ready To Arm
 - 01 – True Output (✓)
- 115 – Armed Status
 - 01 – True Output (✓)
- 116 – Armed Away Mode
 - 01 – True Output (✓)
- 117 – Armed Stay Mode
 - 01 – True Output (✓)
- 121-124 – Command Output 1-4
 - 01 – True Output (✓)
 - 02 – Timed Output (✓)
 - 03 – Code Required (✓ 121 only)
 - Schedule (✓)
- 129 – Partition Status Alarm Memory
 - 01 – True Output (✓)
- 132 – Holdup Output
 - 01 – True Output (✓)
 - 02 – Timed Output
- 146 – TLM and Alarm
 - 01 – True Output (✓)
- 147 – Kissoff Output
 - 01 – True Output (✓)
- 148 – Ground Start
 - 01 – True Output (✓)
- 149 – Alternate Communicator
 - 01 – True Output (✓)
 - 02 – Timed Output (✓)
 - 04 – Fire Alarm
 - 05 – Panic Alarm
 - 06 – Burglary Alarm
 - 07 – Open/Close
 - 08 – Zone Auto Bypass
 - 09 – Medical Alarm
 - 10 – Burglary Verified
 - 11 – Open after Alarm
 - 12 – Emergency Alarm
 - 13 – Duress Alarm
 - 14 – Holdup Verified
- 155 – System Trouble
 - 01 – True Output (✓)
 - 02 – Timed Output
 - 04 – Service Required (✓)
 - 05 – Loss of Clock (✓)
 - 06 – AC Fail (✓)
 - 07 – DC Fail (✓)
 - 08 – TLM (✓)
 - 09 – FTC (✓)
 - 10 – Ethernet (✓)
 - 11 – Zone Fault (✓)
 - 12 – Zone Tamper (✓)
 - 13 – Zone Low Battery (✓)
- 156 – Latched System Event
 - 01 – True Output (✓)
 - 02 – Timed Output
 - 04 – Fire Alarm (✓)
 - 05 – Panic Alarm (✓)
 - 06 – Burglary Alarm (✓)
 - 07 – Medical Alarm (✓)
 - 08 – Supervisory (✓)
 - 09 – Priority Event (✓)
 - 10 – Holdup (✓)
 - 11 – Duress (✓)
 - 12 – Emergency (✓)
 - 13 – Fire Supervisory (✓)
 - 14 – Fire Trouble (✓)
 - 15 – CO Alarm (✓)
- 157 – System Tamper
 - 01 – True Output (✓)
 - 02 – Timed Output
 - 09 – Module Tamper (✓)
 - 10 – Zone Tamper (✓)
- 161 – DC Trouble
 - 01 – True Output (✓)
 - 02 – Timed Output

* 24-Hour Medical not UL evaluated

- 09 – Battery Low (✓)
- 10 – Battery Absent (✓)
- 165 – Prox Used
 - 01 – True Output (✓)
- 175 – Bell Prog Access
 - 01 – True Output (✓)
- 176 – Remote Operation01 – True Output (✓)
- 184 – Open After Alarm
 - 01 – True Output (✓)
 - 02 – PGM Timer (✓)
- 201-216 Zone Follow Zones 1-128
 - 01 – True Output (✓)
 - 02 – Timed Output
 - 09-016 – Zone Terminal 1-16
- 011 PGM Configuration Options**
 - 001-164 – PGM 1-164 Configuration
 - Zone Follower by Zone
 - Proximity Tag Used
 - Command Output Schedules
- 012 System Lockout** (attempts/min.)
 - Keypad Lockout Attempts (000)
 - Keypad Lockout Duration (000)
 - Remote Lockout Attempts (006)
 - Remote Lockout Duration (060)
- System Options**
- 013 System Options 1**
 - 1 – NC Loop/EOL
 - 2 – DEOL/SEOL
 - 3 – Show All Troubles when Armed (✓)
 - 4 – Tamper/Faults Do Not show as open
 - 5 – Auto-Arm Schedule in [*][6] (✓)
 - 6 – Audible Exit Fault (✓)
 - 7 – Event Buffer Follows Swinger (✓)
 - 8 – Temporal Three Fire Signaling
- 014 System Options 2**
 - 1 – Bell Squawk
 - 2 – Bell Squawk Auto-Arm
 - 3 – Bell Squawk on Exit
 - 4 – Bell Squawk on Entry
 - 5 – Bell Squawk on Trouble
 - 6 – Not Used
 - 7 – Exit Delay Termination
 - 8 – Fire Bell Continues
- 015 System Options 3**
 - 1 – [F] Key (✓)
 - 2 – [P] Key Annunciation
 - 3 – Quick Exit
 - 4 – Quick Arming/Function Key (✓)
 - 5 – Not Used
 - 6 – Master Code Not User Changeable
 - 7 – Telephone Line Monitor Enable (✓)
 - 8 – TLM Audible When Armed
- 016 System Options 4**
 - 1 – AC Trouble Display (✓)
 - 2 – AC Trouble Light Flashes
 - 3 – Keypad Blanking
 - 4 – Keypad Blanking Requires Code
 - 5 – Keypad Backlighting (✓)
 - 6 – Power Save Mode
 - 7 – Bypass Display When Armed
 - 8 – Keypad Tamper Enabled
- 017 System Options 5**
 - 1 – Chime On Opening
 - 2 – Chime On Closing
 - 4 – Multi-Hit
 - 5 – Late to Close
 - 6 – Daylight Savings Time
 - 7 – Not Used
 - 8 – Bell Squawk on Away Arm/Disarm Only
- 018 System Options 6**
 - 1 – Test Transmission Exception
 - 2 – Real-Time Bypass Reporting
 - 3 – Not Used
 - 4 – Not Used
 - 5 – Keypad Buzzer Alarm
 - 6 – Not Used
 - 7 – Exit Delay Restart
 - 8 – AC Fail Trouble Beeps
- 019 System Options 7**
 - 1 – Not Used
 - 2 – Latching Troubles
- 3 – Not Used
- 4 – Not Used
- 5 – Audible Bus Fault
- 6 – Duress Codes
- 7 – Temperature in Celsius (✓)
- 020 System Options 8**
 - 1 – Access Code Entry during Entry Delay
 - 3 – [*][8] Access While Armed
 - 7 – Installer Access follows DLS
- 021 System Options 9**
 - 1 – Not Used
 - 2 – Not Used
 - 3 – Auto-Arming Bypass
 - 8 – Audible Exit Delay for Stay Arming
- 022 System Options 10**
 - 1 – [F] Key Option
 - 2 – Not Used
 - 3 – Not Used
 - 4 – Test Transmission Counter in Hours
 - 5 – Away to Stay Toggle
 - 7 – Trouble Beeps Are Silent
 - 8 – Keyswitch Arms in Away Mode
- 023 System Options 11**
 - 1 – Ready LED Flash for Force Arm
 - 4 – Access Code Required for [*][1]
 - 5 – Access Code Required for [*][2]
 - 6 – Access Code Required for [*][3]
 - 7 – Access Code Required for [*][4]
 - 8 – [*][6] Accessibility
- 024 System Options 12**
 - 1 – 50Hz AC / 60 Hz AC
 - 2 – Crystal Timebase
 - 3 – AC/DC Inhibits Arming
 - 4 – Not Used
 - 5 – Real Time Clock Option
 - 6 – Not Used
 - 7 – Not Used
 - 8 – DLS Disconnect
- 025 System Options 13**
 - 1 – European Dial
 - 2 – Force Dial (✓)
 - 3 – Not Used
 - 4 – Not Used
 - 5 – ID Tone
 - 6 – Tone Generated-2100Hz
 - 7 – 1 Hour DLS Window
 - 8 – FTC Audible Bell
- 040 User Authentication**
 - 01 – User Code or Proximity Tag (✓)
 - 02 – User Code and Proximity Tag
- 041 Access Code Digits**
 - 00 – 4-Digit Access Codes (✓)
 - 01 – 6-Digit Access Codes
- 042 Event Verification**
 - 01 – Burglary Verified Counter (002)
 - 03 – Burglary Verification Selection
 - 001 – Police Code (✓)
 - 002 – Cross Zoning
- 151-158 Partition 1-8 Auto-Arm/Disarm**
 - 001 – Auto-Arming Times (9999)
 - 24-Hour
 - Sunday
 - Monday
 - Tuesday
 - Wednesday
 - Thursday
 - Friday
 - Saturday
 - 002 – Auto-Disarm Times (9999)
 - 24-Hour
 - Sunday
 - Monday
 - Tuesday
 - Wednesday
 - Thursday
 - Friday
 - Saturday
 - 003 – Auto-Disarming Holiday Schedule
 - Holiday 1
 - Holiday 2
- Holiday 3
- Holiday 4
- 004 – Auto-Arming Pre-Alert (004)
- 005 – Auto-Arming Postpone Timer (000)
- 006 – No Activity Arming Timer (000)
- 007 – No Activity Arming Pre-Alert Timer (001)
- 200 Partition Mask**
 - 001 – Partition 1 to 8 Enable Mask
 - 1 – Partition 1 (✓)
 - 2 – Partition 2
 - 3 – Partition 3
 - 4 – Partition 4
 - 5 – Partition 5
 - 6 – Partition 6
 - 7 – Partition 7
 - 8 – Partition 8
- 201-208 Partition 1-8 Zone Assignment**
 - 001 – Zone 1-8 (✓)
 - 002 – Zn 9-16
 - 003 – Zn 17-24
 - 004 – Zn 25-32
 - 005 – Zn 33-40
 - 006 – Zn 41-48
 - 007 – Zn 49-56
 - 008 – Zn 57-64
 - 009 – Zn 65-72
 - 010 – Zn 73-80
 - 011 – Zn 81-88
 - 012 – Zn 89-96
 - 013 – Zn 97-104
 - 014 – Zn 105-112
 - 015 – Zn 113-120
 - 016 – Zn 121-128
- 300 Panel/Receiver Communications Path**
 - 001 – 004 Receiver 1-4
 - 01 – Phone Line (✓)
 - 02 – Alt Comm Auto Routing
 - 03 – Alt Comm Rec 1- Ethernet
 - 04 – Alt Comm Rec 2- Ethernet
 - 05 – Alt Comm Rec 3- Cellular
 - 06 – Alt Comm Rec 4- Cellular
- 301 Phone Number Programming**
 - 001 – 004 Phone Number 1 -4 Programming (DFFF...32-digit)
- 304 Call Waiting Cancel String** (DB70EF)
- Event Reporting**
- 307 Zone Reporting**
 - 001-128 Zone Reporting for Zones 1-128
 - 01 – Alarm
 - 02 – Alarm Restore
 - 03 – Tamper
 - 04 – Tamper Restore
 - 05 – Fault
 - 06 – Fault Restore
- 308 Event Reporting**
 - 001 – Miscellaneous Alarm 1
 - 01 – Duress Alarm (✓)
 - 02 – Opening After Alarm (✓)
 - 03 – Recent Closing Alarm (✓)
 - 04 – Zone Expander Supervisory Alarm (✓)
 - 05 – Zone Expander Supervisory Alarm Restore (✓)
 - 06 – Burglary Verified (✓)
 - 07 – Burg Not Verified Alarm (✓)
 - 08 – Alarm Cancel (✓)
 - 002 – Miscellaneous Alarm 2
 - 01 – Holdup Verified Alarm (✓)
 - 011 – Priority Alarms
 - 01 – Keypad Fire Alarm-F Key (✓)
 - 02 – Keypad Fire Restore (✓)
 - 03 – Keypad Medical Alarm-M Key (✓)
 - 04 – Keypad Medical Restore (✓)
 - 05 – Keypad Panic Alarm (P) (✓)
 - 06 – Keypad Panic Restore (✓)
 - 07 – Auxiliary Input Alarm (✓)
 - 08 – Aux Input Alarm Restore (✓)
- 021 – Fire Alarms 1
 - 03 – PGM 2 2-Wire Alarm (✓)
 - 04 – PGM 2 2-Wire Restore (✓)
- 101 – Tamper Events
 - 03 – Module Tamper (✓)
 - 04 – Module Tamper Restore (✓)
 - 05 – Keypad Lockout (✓)
 - 07 – Remote Lockout (✓)
- 201 – Open/Close Events 1
 - 01 – User Closing (✓)
 - 02 – User Opening (✓)
 - 05 – Special Closing (✓)
 - 06 – Special Opening (✓)
- 202 – Open/Close Events 2
 - 01 – Automatic Closing (✓)
 - 03 – Auto Arm Cancellation/Postpone (✓)
- 211 – Miscellaneous Open/Close Events
 - 01 – Late to Close (✓)
 - 02 – Late to Open (✓)
 - 05 – Exit Fault (✓)
- 221 – Bypass Events
 - 01 – Auto Zone Bypass (✓)
 - 02 – Auto Zone Unbypass (✓)
 - 03 – Partial Closing (✓)
- 301 – Panel Events 1
 - 01 – Panel AC Fail Trouble (✓)
 - 02 – Panel AC Fail Restore (✓)
 - 03 – Panel Low Battery (✓)
 - 04 – Panel Low Battery Restore (✓)
 - 05 – Panel Battery Absent (✓)
 - 06 – Panel Battery Absent Trouble Restore (✓)
- 302 – Panel Events 2
 - 01 – Bell Circuit Trouble (✓)
 - 02 – Bell Circuit Restore (✓)
 - 03 – Telephone Line Trouble (✓)
 - 04 – Telephone Line Trouble Restore (✓)
 - 05 – Auxiliary Trouble (✓)
 - 06 – Auxiliary Trouble Restore (✓)
- 305 – Panel Events 5
 - 03 – PGM 2 2-Wire Trouble (✓)
 - 04 – PGM 2 2-Wire Restore (✓)
- 311 – Maintenance Events 1
 - 01 – RF Jam Trouble (✓)
 - 02 – RF Jam Trouble Restore (✓)
 - 03 – Fire Trouble (✓)
 - 04 – Fire Trouble Restore (✓)
 - 05 – Cold Start (✓)
 - 06 – Delinquency (✓)
- 312 – Maintenance Events 2
 - 01 – Installer Lead IN (✓)
 - 02 – Installer Lead OUT (✓)
 - 03 – DLS Lead IN (✓)
 - 04 – DLS Lead OUT (✓)
 - 05 – SA Lead IN (✓)
 - 06 – SA Lead OUT (✓)
 - 07 – Event Buffer 75% Full (✓)
- 313 – Maintenance Events 3
 - 01 – Firmware Update Begin (✓)
 - 02 – Firmware Update Success (✓)
 - 03 – Firmware Update Fail (✓)
- 314 – Maintenance Events 4
 - 01 – Gas Trouble (✓)
 - 02 – Gas Trouble Restore (✓)
 - 03 – Heat Trouble (✓)
 - 04 – Heat Trouble Restore (✓)
 - 05 – Freeze Trouble (✓)
 - 06 – Freeze Trouble Restore (✓)
 - 07 – Probe Disconnected (✓)
 - 08 – Probe Disconnect Restore (✓)
- 321 – Receiver Events
 - 02 – Receiver 1 FTC Restore (✓)
 - 04 – Receiver 2 FTC Restore (✓)
 - 06 – Receiver 3 FTC Restore (✓)
 - 08 – Receiver 4 FTC Restore (✓)
- 331 – Module Events 1
 - 01 – Module AC Trouble (✓)
 - 02 – Module AC Trouble Restore (✓)
 - 03 – Module Battery Trouble (✓)
 - 04 – Module Battery Trouble Restore (✓)
 - 05 – Module Battery Absent (✓)

- 06 – Module Battery Absent Restore (✓)
 - 332 – Module Events 2
 - 01 – Module Low Voltage (✓)
 - 02 – Module Low Voltage Restore (✓)
 - 03 – Module Supervisory (✓)
 - 04 – Module Supervisory Restore (✓)
 - 05 – Module Aux Trouble (✓)
 - 06 – Module Aux Trouble Restore (✓)
 - 335 – Module Events 5
 - 01 – Output 1 Fault (✓)
 - 02 – Output 1 Fault Restore (✓)
 - 351 – Alternate Communicator 1
 - 01 – Alt. Comm. Module Comm Fault (✓)
 - 02 – Alt. Comm. Module Comm Fault Restore (✓)
 - 07 – Alt. Comm. Radio/SIM Failure (✓)
 - 08 – Alt. Comm. Radio/SIM Failure (✓) Restore
 - 352 – Alternate Communicator 2
 - 01 – Alternate Comm. Network Fault (✓)
 - 02 – Alt. Comm. Network Fault Restore (✓)
 - 03 – Alt. Comm. Low Signal Trouble (✓)
 - 04 – Alt. Comm. Low Signal Trouble Restore (✓)
 - 05 – Alt. Comm. Ethernet (✓)
 - 06 – Alt. Comm. Ethernet Trouble Restore (✓)
 - 07 – Alt. Comm. Lockout (✓)
 - 08 – Alt. Comm. Lockout Trouble Restore (✓)
 - 354 – Alternate Communicator 4
 - 01 – Alt. Comm Receiver 1 (✓)
 - 02 – Alt. Comm Receiver 1 Restore (✓)
 - 03 – Alt. Comm Receiver 2 (✓)
 - 04 – Alt. Comm Receiver 2 Restore (✓)
 - 05 – Alt. Comm Receiver 3 (✓)
 - 06 – Alt. Comm Receiver 3 Restore (✓)
 - 07 – Alt. Comm Receiver 4 (✓)
 - 08 – Alt. Comm Receiver 4 Restore (✓)
 - 355 – Alternate Communicator 5
 - 01 – Alt. Comm Receiver 1 Supervision Failure (✓)
 - 02 – Alt. Comm Receiver 1 Supervision Failure Restore (✓)
 - 03 – Alt. Comm Receiver 2 Supervision Failure (✓)
 - 04 – Alt. Comm Receiver 2 Supervision Failure Restore (✓)
 - 05 – Alt. Comm Receiver 3 Supervision Failure (✓)
 - 06 – Alt. Comm Receiver 3 Supervision Failure Restore (✓)
 - 07 – Alt. Comm Receiver 4 Supervision Failure (✓)
 - 08 – Alt. Comm Receiver 4 Supervision Failure Restore (✓)
 - 361 – Wireless Device Events
 - 01 – Device AC Fail (✓)
 - 02 – Device AC Restore (✓)
 - 03 – Device Low Battery (✓)
 - 04 – Device Low Battery Restore (✓)
 - 05 – Device Fault (✓)
 - 06 – Device Fault Restore (✓)
 - 401 – System Test Events
 - 01 – Walk Test Start (✓)
 - 02 – Walk Test End (✓)
 - 03 – Periodic Test Transmission
 - 04 – Periodic Test Transmission with Trouble (✓)
 - 05 – System Test (✓)
- Communications**
- 309 System Call Direction**
- 001 – Maintenance Events
 - 1 – Receiver 1 (✓)
 - 2 – Receiver 2
 - 3 – Receiver 3
 - 4 – Receiver 4
 - 002 – Test Transmission Events
 - 1 – Receiver 1 (✓)
 - 2 – Receiver 2
 - 3 – Receiver 3
 - 4 – Receiver 4
- 310 Account Codes**
- 000 – System Account Code (FFFFFF)
 - 001-008 – Partition 1-8 Account Code (FFFF)
- 311-318 Partition 1-8 Call Direction**
- 001 – Partition Burglary Alarm/Restore Call Direction
 - 1 – Receiver 1 (✓)
 - 2 – Receiver 2
 - 3 – Receiver 3
 - 4 – Receiver 4
 - 002 – Partition Tamper/Restore Call Direction
 - 1 – Receiver 1 (✓)
 - 2 – Receiver 2
 - 3 – Receiver 3
 - 4 – Receiver 4
 - 003 – Partition Opening/Closing Call Direction
 - 1 – Receiver 1 (✓)
 - 2 – Receiver 2
 - 3 – Receiver 3
 - 4 – Receiver 4
- 350 Communicator Formats (04 - SIA)**
- 001 – Communicator Format - Receiver 1
 - 002 – Communicator Format - Receiver 2
 - 003 – Communicator Format - Receiver 3
 - 004 – Communicator Format - Receiver 4
- 377 Communication Variables**
- 001 – Swinger Shutdown Attempts
 - Alarms and Restore (003)
 - Tamper and Restore (003)
 - Maintenance and Restore (003)
 - 002 – Communication Delays
 - Zone Delay (000 sec.)
 - AC Failure Communication Delay (030 min./hrs.)
 - TLM Trouble Delay (010 sec. x 3)
 - WLS Zone Low Battery Transmission Delay (007 days)
 - Delinquency Transmission Delay (030 hours/days)
 - Communications Cancel Window (000 min.)
 - 003 – Periodic Test Transmission Cycle (030 hrs./days)
 - 004 – Periodic Test Transmission Time of Day (9999)
 - 011 – Maximum Dialing Attempts (005)
 - 012 – PSTN Delay (003 sec.)
 - 013 – Delay Between Force Attempts (020 sec.)
 - 014 – Post Dial Wait for Handshake (040 sec.)
 - 015 – T-Link Wait for Ack (060 sec.)
 - 016 – IP/Cellular Fault Check Timer (010)
- 380 Communicator Option 1**
- 1 – Communications Enabled (✓)
 - 2 – Restore on Bell Timeout
 - 3 – Pulse Dialing
 - 4 – Pulse Dial After 5th Attempt
 - 5 – Parallel Communications
 - 6 – Alternate Dial
 - 7 – Reduced Dialing Attempts
 - 8 – Activity Delinquency

381 Communicator Option 2

- 1 – Keypad Ringback
- 2 – Bell Ringback
- 4 – Closing Confirmation
- 8 – Communications Priority

382 Communicator Option 3

- 2 – Walk Test Communication
- 4 – Call Waiting Cancel
- 5 – Alternate Communicator Enable
- 6 – AC Failure TX in Hours

383 Communicator Option 4

- 1 – Phone Number Account Code
- 2 – 6-Digit Account Code
- 5 – Communicate FTC Events

384 Communicator Backup Options

- 2 – Backup Options - Receiver 2 (✓)
- 3 – Backup Options - Receiver 3
- 4 – Backup Options - Receiver 4

DLS Programming**401 DLS/SA Options**

- 1 – Double Call
- 2 – User Enables DLS
- 3 – DLS Callback
- 4 – User Call Up
- 6 – Panel Call-Up and Baud Rate
- 7 – Alt. Comm DLS

402 DLS Phone Number

Programming (31-digit decimal)

403 DLS Access Code (212800)**404 DLS/SA Panel ID (2128000000)****405 PSTN Double Call Timer (060 sec.)****406 PSTN Number of Rings to Answer On (000)****407 SA Access Code (FFFFFF)****410 Automatic DLS Options**

- 001 – Automatic DLS Toggle Options
 - 1 – Periodic DLS
 - 3 – DLS on Event Buffer 75% Full
 - 5 – SA on Event Buffer 75% Full
- 002 – Periodic DLS Days (000 days)
- 003 – Periodic DLS Time (0000)
- 007 – Delay Call Window
 - Delay Call Window Start (0000)
 - Delay Call Window End (0000)

Schedule Programming**601-604 Programming Schedule 1-4**

- 101 – 401 Interval 1-4
 - 101 – Start Time (0000)
 - 102 – End Time (0000)
 - 103 – Days Assignment
 - 01 – Sunday
 - 02 – Monday
 - 03 – Tuesday
 - 04 – Wednesday
 - 05 – Thursday
 - 06 – Friday
 - 07 – Saturday
- 104 – Holiday Assignment
 - 09 – Holiday 1
 - 10 – Holiday 2
 - 11 – Holiday 3
 - 12 – Holiday 4

711-714 Holiday Group 1-4

- 001 – 099 Holiday Group 1-4 Date 1-99 (000000, MMDDYY)

Wireless Programming**804 Wireless Programming**

- 000 – WLS Device Enrollment Zones (3-digit decimal)
 - Zone Type (2-digit decimal)
 - Partition Assignment
 - Zone Label (LCD only)
- WLS Keys
 - Partition Assignment
 - User Assignment
- Sirens
 - Partition Assignment
 - Siren Label (LCD only)

Keypads

- Keypad Assignment
- Keypad Label (LCD only)
- Repeaters
 - Repeater Label (LCD only)

001- 128 – Configure Wireless Zones
Refer to the installation instructions provided with the HSM2Host for more wireless programming options.

850 Cellular Signal Strength**851 Alternate Communicator****Programming**

Refer to the installation instructions provided with the alternate communicator for details.

Keypad Programming**860 Keypad Slot Number****861-876 Keypad Programming****000 – Keypad Partition Mask**

- 00 – Global Keypad
- 01 – Partition 1 (✓)
- 02 – Partition 2
- 03 – Partition 3
- 04 – Partition 4
- 05 – Partition 5
- 06 – Partition 6
- 07 – Partition 7
- 08 – Partition 8

001 – Function Key 1 (03)**002 – Function Key 2 (04)****003 – Function Key 3 (06)****004 – Function Key 4 (22)****005 – Function Key 5 (16)**

- 00 – Null Key
- 02 – Instant Stay Arm
- 03 – Stay Arm
- 04 – Away Arm
- 05 – No Entry Arm
- 06 – Chime On/Off
- 07 – System Test
- 09 – Night Arm
- 12 – Global Stay Arm
- 13 – Global Away Arm
- 14 – Global Disarming
- 16 – Quick Exit
- 17 – Arm Interior
- 21-24 – Command Output 1-4
- 29 – Bypass Group Recall
- 31 – Local PGM Activate
- 32 – Bypass Mode
- 33 – Bypass recall
- 34 – User Programming
- 35 – User Functions
- 37 – Time/Date Programming
- 39 – Trouble Display
- 40 – Alarm Memory
- 51 – [M] Key Alarm
- 52 – [P] Key Alarm
- 61-68 – Partition Select 1-8

011 – Keypad I/O (000)**012 – Local PGM Output Timer**

- Pulse Time (00 minutes)
- Pulse Time (05 sec.)

021 – Keypad Option 1

- 1 – [F] Key Enabled (✓)
- 2 – [M] Key Enabled (✓)
- 3 – [P] Key Enabled (✓)
- 4 – Display Code or X's (✓)

022 – Keypad Option 2

- 1 – Local Clock Display (✓)
- 2 – Local Clock Display 24 Hour
- 3 – Auto Alarm Scroll (✓)
- 5 – Power LED Option
- 6 – Power LED AC Present (✓)
- 7 – Alarms Displayed if Armed (✓)
- 8 – Auto Scroll Open Zones

023 – Keypad Option 3

- 1 – Armed LED Power Save*
- 2 – Keypad Show Arm Mode (✓)*
- 3 – 5th Terminal is PGM Output/Zone
- 7 – Local Display of Temp.

- 8 – Low Temperature Warning
- 030 – LCD Message** (16 x 2 hex)
- 031 – Download LCD Message Duration (000)**
- 041 – Indoor Temperature Zone Entry (000)**
- 042 – Outdoor Temperature Zone Entry(000)**
- 101-228 – Door Chime Sound-Zone 1-128**

- 00 – Disabled
- 01 – 6 beeps (✓)
- 02 – "Bing-Bing" Sound
- 03 – "Ding-Dong" Sound
- 04 – Alarm Tone
- 05 – Zone Name

899 Template Programming

- 5-Digit Template Code (5-digit decimal)
- Central Station Telephone Number (32-digit decimal)
- Central Station Account Code (4/6-digit decimal)
- Partition Account Code (4-digit decimal)
- DLS Access Code (6-digit decimal)
- Partition Entry Delay (000-255 sec.)
- Partition Exit Delay (000-255 sec.)
- Installer Code

System Information and Testing**900 System Information**

- 000 – Control Panel Version
- 001- 016 – Keypad 1-16 Version Info
- 101-116 – 8-HSM2108 1-16 Version Info
- 201-216 – HSM2208 Version Information
- 460 – Alternate Communicator
- 461 – HSM2HOST Version Info
- 501 – 504 HSM2300 1-4 Version Info
- 521 – 524 HSM2204 1-4 Version Info

901 Installer Walk Test

* Wireless keypads only

Module Programming**902 Add/Remove Modules**

- 000 – Auto-Enroll All Modules
- 001 – Enroll Modules
- 002 – Slot Assignment
- 003 – Edit Module Slot Assignment
- 101 – Delete Keypads
- 102 – Delete HSM2108
- 103 – Delete HSM2208
- 106 – Delete HSM2HOST
- 109 – Delete HSM2300
- 110 – Delete HSM2204

903 Confirm Modules

- 000 – View All Modules
- 001 – Keypads
- 002 – HSM2108
- 003 – HSM2208
- 006 – HSM2HOST
- 009 – HSM2300
- 010 – HSM2204

904 Wireless Placement Test

- 001-128 – Placement Test Zones 1-128
- 521-528 – Placement Test Repeaters 1-28
- 551-566 – Placement Test Sirens 1-16
- 601-632 – Placement Test Wireless Keys 1-32
- 701-716 – Placement Test Wireless Keypads 1-16

Battery Settings**982 Battery Settings**

- 000– Panel Battery Settings
 - 01– Panel High Charge Current
- 010 – HSM2204 Battery Settings
 - 01 – HSM2204 1 High Charge Current
 - 02 – HSM2204 2 High Charge Current
 - 03 – HSM2204 3 High Charge Current
 - 04 – HSM2204 4 High Charge Current
- 020 – HSM2300 Battery Settings
 - 01 – HSM2300 1 Charge
 - 02 – HSM2300 2 Charge

- 03 – HSM2300 3 Charge
- 04 – HSM2300 4 Charge

Defaults**990 Installer Lockout Enable/Disable****991 Default Keypads**

- 901-916 – Default Keypad 1-16
- 999 – Default all Keypads

993 Default Alt Comm**996 Default HSM2HOST****999 Default System**

IMPORTANT - READ CAREFULLY: DSC Software purchased with or without Products and Components is copyrighted and is purchased under the following license terms:

This End-User License Agreement ("EULA") is a legal agreement between You (the company, individual or entity who acquired the Software and any related Hardware) and Digital Security Controls, a division of Tyco Safety Products Canada Ltd. ("DSC"), the manufacturer of the integrated security systems and the developer of the software and any related products or components ("HARDWARE") which You acquired.

If the DSC software product ("SOFTWARE PRODUCT" or "SOFTWARE") is intended to be accompanied by HARDWARE, and is NOT accompanied by new HARDWARE, You may not use, copy or install the SOFTWARE PRODUCT. The SOFTWARE PRODUCT includes computer software, and may include associated media, printed materials, and "online" or electronic documentation.

Any software provided along with the SOFTWARE PRODUCT that is associated with a separate end-user license agreement is licensed to You under the terms of that license agreement.

By installing, copying, downloading, storing, accessing or otherwise using the SOFTWARE PRODUCT, You agree unconditionally to be bound by the terms of this EULA, even if this EULA is deemed to be a modification of any previous arrangement or contract. If You do not agree to the terms of this EULA, DSC is unwilling to license the SOFTWARE PRODUCT to You, and You have no right to use it.

SOFTWARE PRODUCT LICENSE

The SOFTWARE PRODUCT is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. The SOFTWARE PRODUCT is licensed, not sold.

1. GRANT OF LICENSE This EULA grants You the following rights:

- (a) Software Installation and Use - For each license You acquire, You may have only one copy of the SOFTWARE PRODUCT installed.
- (b) Storage/Network Use - The SOFTWARE PRODUCT may not be installed, accessed, displayed, run, shared or used concurrently on or from different computers, including a workstation, terminal or other digital electronic device ("Device"). In other words, if You have several workstations, You will have to acquire a license for each workstation where the SOFTWARE will be used.
- (c) Backup Copy - You may make back-up copies of the SOFTWARE PRODUCT, but You may only have one copy per license installed at any given time. You may use the back-up copy solely for archival purposes. Except as expressly provided in this EULA, You may not otherwise make copies of the SOFTWARE PRODUCT, including the printed materials accompanying the SOFTWARE.

2. DESCRIPTION OF OTHER RIGHTS AND LIMITATIONS

- (a) Limitations on Reverse Engineering, Decompilation and Disassembly - You may not reverse engineer, decompile, or disassemble the SOFTWARE PRODUCT, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation. You may not make any changes or modifications to the Software, without the written permission of an officer of DSC. You may not remove any proprietary notices, marks or labels from the Software Product. You shall institute reasonable measures to ensure compliance with the terms and conditions of this EULA.
- (b) Separation of Components - The SOFTWARE PRODUCT is licensed as a single product. Its component parts may not be separated for use on more than one HARDWARE unit.
- (c) Single INTEGRATED PRODUCT - If You acquired this SOFTWARE with HARDWARE, then the SOFTWARE PRODUCT is licensed with the HARDWARE as a single integrated product. In this case, the SOFTWARE PRODUCT may only be used with the HARDWARE as set forth in this EULA.
- (d) Rental - You may not rent, lease or lend the SOFTWARE PRODUCT. You may not make it available to others or post it on a server or web site.
- (e) Software Product Transfer - You may transfer all of Your rights under this EULA only as part of a permanent sale or transfer of the HARDWARE, provided You retain no copies. You transfer all of the SOFTWARE PRODUCT (including all component parts, the media and printed materials, any upgrades and this EULA), and provided the recipient agrees to the terms of this EULA. If the SOFTWARE PRODUCT is an upgrade, any transfer must also include all prior versions of the SOFTWARE PRODUCT.
- (f) Termination - Without prejudice to any other rights, DSC may terminate this EULA if You fail to comply with the terms and conditions of this EULA. In such event, You must destroy all copies of the SOFTWARE PRODUCT and all of its component parts.

- (g) Trademarks - This EULA does not grant You any rights in connection with any trademarks or service marks of DSC or its suppliers.

3. COPYRIGHT - All title and intellectual property rights in and to the SOFTWARE PRODUCT (including but not limited to any images, photographs, and text incorporated into the SOFTWARE PRODUCT), the accompanying printed materials, and any copies of the SOFTWARE PRODUCT, are owned by DSC or its suppliers. You may not copy the printed materials accompanying the SOFTWARE PRODUCT. All title and intellectual property rights in and to the content which may be accessed through use of the SOFTWARE PRODUCT are the property of the respective content owner and may be protected by applicable copyright or other intellectual property laws and treaties. This EULA grants You no rights to use such content. All rights not expressly granted under this EULA are reserved by DSC and its suppliers.

4. EXPORT RESTRICTIONS - You agree that You will not export or re-export the SOFTWARE PRODUCT to any country, person, or entity subject to Canadian export restrictions.

5. CHOICE OF LAW - This Software License Agreement is governed by the laws of the Province of Ontario, Canada.

6. ARBITRATION - All disputes arising in connection with this Agreement shall be determined by final and binding arbitration in accordance with the Arbitration Act, and the parties agree to be bound by the arbitrator's decision. The place of arbitration shall be Toronto, Canada, and the installation manual of the arbitration shall be English.

7. LIMITED WARRANTY

(a) NO WARRANTY - DSC PROVIDES THE SOFTWARE "AS IS" WITHOUT WARRANTY. DSC DOES NOT WARRANT THAT THE SOFTWARE WILL MEET YOUR REQUIREMENTS OR THAT OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE.

(b) CHANGES IN OPERATING ENVIRONMENT - DSC shall not be responsible for problems caused by changes in the operating characteristics of the HARDWARE, or for problems in the interaction of the SOFTWARE PRODUCT with non-DSC-SOFTWARE or HARDWARE PRODUCTS.

(c) LIMITATION OF LIABILITY; WARRANTY REFLECTS ALLOCATION OF RISK - IN ANY EVENT, IF ANY STATUTE IMPLIES WARRANTIES OR CONDITIONS NOT STATED IN THIS LICENSE AGREEMENT, DSC'S ENTIRE LIABILITY UNDER ANY PROVISION OF THIS LICENSE AGREEMENT SHALL BE LIMITED TO THE GREATER OF THE AMOUNT ACTUALLY PAID BY YOU TO LICENSE THE SOFTWARE PRODUCT AND FIVE CANADIAN DOLLARS (CAD\$5 00). BECAUSE SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

(d) DISCLAIMER OF WARRANTIES - THIS WARRANTY CONTAINS THE ENTIRE WARRANTY AND SHALL BE IN LIEU OF ANY AND ALL OTHER WARRANTIES, WHETHER EXPRESSED OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON THE PART OF DSC. DSC MAKES NO OTHER WARRANTIES. DSC NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON PURPORTING TO ACT ON ITS BEHALF TO MODIFY OR TO CHANGE THIS WARRANTY, NOR TO ASSUME FOR IT ANY OTHER WARRANTY OR LIABILITY CONCERNING THIS SOFTWARE PRODUCT.

(e) EXCLUSIVE REMEDY AND LIMITATION OF WARRANTY - UNDER NO CIRCUMSTANCES SHALL DSC BE LIABLE FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, OR ANY OTHER LEGAL THEORY. SUCH DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, LOSS OF PROFITS, LOSS OF THE SOFTWARE PRODUCT OR ANY ASSOCIATED EQUIPMENT, COST OF CAPITAL, COST OF SUBSTITUTE OR REPLACEMENT EQUIPMENT, FACILITIES OR SERVICES, DOWNTIME, PURCHASERS TIME, THE CLAIMS OF THIRD PARTIES, INCLUDING CUSTOMERS, AND INJURY TO PROPERTY.

WARNING: DSC recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this SOFTWARE PRODUCT to fail to perform as expected.

Zone Record

Zone	Label	Location	Type	Attribute	Zone	Label	Location	Type	Attribute
001					065				
002					066				
003					067				
004					068				
005					069				
006					070				
007					071				
008					072				
009					073				
010					074				
011					075				
012					076				
013					077				
014					078				
015					079				
016					080				
017					081				
018					082				
019					083				
020					084				
021					085				
022					086				
023					087				
024					088				
025					089				
026					090				
027					091				
028					092				
029					093				
030					094				
031					095				
032					096				
033					097				
034					098				
035					099				
036					100				
037					101				
038					102				
039					103				
040					104				
041					105				
042					106				
043					107				
044					108				
045					109				
046					110				
047					111				
048					112				
049					113				
050					114				
051					115				
052					116				
053					117				
054					118				
055					119				
056					120				
057					121				
058					122				
059					123				
060					124				
061					125				
062					126				
063					127				
064					128				

Aux Loading and Battery Selection

HS2128/HS2064/HS2032/HS2016 Board current draw 50mA	UL Resi Burg ULC Resi Burg	UL Com Burg	UL Resi Fire/ UL Home Health Care/ ULC Resi Fire/ ULC Com Burg	ULC Fire Monitoring
Max AUX (NSC) current loading	0.7A	0.7A	0.5A	0.5A
Max BELL (Alarm) current loading	0.7A	0.7A	0.7A	0.7A (no local alarm notification allowed, only remote transmission to SRC)
UL/ULC Listed enclosure	PC500C PC5003C	CMC-1 PC4050CAR	PC5003C	PC5003C (when used in conjunction with hard-wired transformer mounted in an electrical box) PC4050CR (red/transformer mounted inside)
Transformer requirements	16.5V/40VA (plug in type) PTC1640U (USA) PTC1640CG (CND)			FTC3716 (cUL listed) 16.5V/37VA (Hardwired type, mounted inside the enclosure or outside using electrical box)
Battery Capacity requirements	7Ah	7Ah	14Ah (2 x 7Ah in parallel)	14Ah (2 x 7Ah in parallel)
Standby Time	4 hours	4 hours	24 hours	24 hours
Alarm time	4 minutes	15 minutes	4 min (UL resi fire) 5 min (Home Health Care and ULC Resi Fire)	5 minutes (Alarm Transmission only)
Recharging current setting	400mA, 700mA	400mA, 700mA	400mA, 700mA	400mA, 700mA

WARNING - READ CAREFULLY
Note to Installers
This warning contains vital information. As the only individual in contact with system users, it is your responsibility to bring each item in this warning to the attention of the users of this system.

System Failures
This system has been carefully designed to be as effective as possible. There are circumstances, however, involving fire, burglary, or other types of emergencies where it may not provide protection. Any alarm system of any type may be compromised deliberately or may fail to operate as expected for a variety of reasons. Some but not all of these reasons may be:

Inadequate Installation
A security system must be installed properly in order to provide adequate protection. Every installation should be evaluated by a security professional to ensure that all access points and areas are covered. Locks and latches on windows and doors must be secure and operate as intended. Windows, doors, walls, ceilings and other building materials must be of sufficient strength and construction to provide the level of protection expected. A reevaluation must be done during and after any construction activity. An evaluation by the fire and/or police department is highly recommended if this service is available.

Criminal Knowledge
This system contains security features which were known to be effective at the time of manufacture. It is possible for persons with criminal intent to develop techniques which reduce the effectiveness of these features. It is important that a security system be reviewed periodically to ensure that its features remain effective and that it be updated or replaced if it is found that it does not provide the protection expected.

Access by Intruders
Intruders may enter through an unprotected access point, circumvent a sensing device, evade detection by moving through an area of insufficient coverage, disconnect a warning device, or interfere with or prevent the proper operation of the system.

Power Failure
Control units, intrusion detectors, smoke detectors and many other security devices require an adequate power supply for proper operation. If a device operates from batteries, it is possible for the batteries to fail. Even if the batteries have not failed, they must be charged, in good condition and installed correctly. If a device operates only by AC power, any interruption, however brief, will render that device inoperative while it does not have power. Power interruptions of any length are often accompanied by voltage fluctuations which may damage electronic equipment such as a security system. After a power interruption has occurred, immediately conduct a complete system test to ensure that the system operates as intended.

Failure of Replaceable Batteries
This system's wireless transmitters have been designed to provide several years of battery life under normal conditions. The expected battery life is a function of the device environment, usage and type. Ambient conditions such as high humidity, high or low temperatures, or large temperature fluctuations may reduce the expected battery life. While each transmitting device has a low battery monitor which identifies when the batteries need to be replaced, this monitor may fail to operate as expected. Regular testing and maintenance will keep the system in good operating condition.

Compromise of Radio Frequency (Wireless) Devices
Signals may not reach the receiver under all circumstances which could include metal objects placed on or near the radio path or deliberate jamming or other inadvertent radio signal interference.

System Users
A user may not be able to operate a panic or emergency switch possibly due to permanent or temporary physical disability, inability to reach the device in time, or unfamiliarity with the correct operation. It is important that all system users be trained in the correct operation of the alarm system and that they know how to respond when the system indicates an alarm.

Smoke Detectors
Smoke detectors that are a part of this system may not properly alert occupants of a fire for a number of reasons, some of which follow. The smoke detectors may have been improperly installed or positioned. Smoke may not be able to reach the smoke detectors, such as when the fire is in a chimney, walls or roofs, or on the other side of closed doors. Smoke detectors may not detect smoke from fires on another level of the residence or building. Every fire is different in the amount of smoke produced and the rate of burning. Smoke detectors cannot sense all types of fires equally well. Smoke detectors may not provide timely warning of fires caused by carelessness or safety hazards such as smoking in bed, violent explosions, escaping gas, improper storage of flammable materials, overloaded electrical circuits, children playing with matches or arson. Even if the smoke detector operates as intended, there may be circumstances when there is insufficient warning to allow all occupants to escape in time to avoid injury or death.

Motion Detectors
Motion detectors can only detect motion within the designated areas as shown in their respective installation instructions. They cannot discriminate between intruders and intended occupants. Motion detectors do not provide volumetric area protection. They have multiple beams of detection and motion can only be detected in unobstructed areas covered by these beams. They cannot detect motion which occurs behind walls, ceilings, floor, closed doors, glass partitions, glass doors or windows. Any type of tampering whether intentional or unintentional such as masking, painting, or spraying of any material on the lenses, mirrors, windows or any other part of the detection system will impair its proper operation. Passive infrared motion detectors operate by sensing changes in temperature. However their effectiveness can be reduced when the ambient temperature rises near or above body temperature or if there are intentional or unintentional sources of heat in or near the detection area. Some of these heat sources could be heaters, radiators, stoves, barbecues, fireplaces, sun-light, steam vents, lighting and so on.

Warning Devices
Warning devices such as sirens, bells, horns, or strobes may not warn people or waken someone sleeping if there is an intervening wall or door. If warning devices are located on a different level of the residence or premise, then it is less likely that the occupants will be alerted or awakened. Audible warning devices may be interfered with by other noise sources such as stereos, radios, televisions, air conditioners or other appliances, or passing traffic. Audible warning devices, however loud, may not be heard by a hearing-impaired person.

Telephone Lines
If telephone lines are used to transmit alarms, they may be out of service or busy for certain periods of time. Also an intruder may cut the telephone line or defeat its operation by more sophisticated means which may be difficult to detect.

Insufficient Time
There may be circumstances when the system will operate as intended, yet the occupants will not be protected from the emergency due to their inability to respond to the warnings in a timely manner. If the system is monitored, the response may not occur in time to protect the occupants or their belongings.

Component Failure
Although every effort has been made to make this system as reliable as possible, the system may fail to function as intended due to the failure of a component.

Inadequate Testing
Most problems that would prevent an alarm system from operating as intended can be found by regular testing and maintenance. The complete system should be tested weekly and immediately after a break-in, an attempted break-in, a fire, a storm, an earthquake, an accident, or any kind of construction activity inside or outside the premises. The testing should include all sensing devices, keypads, consoles, alarm indicating devices and any other operational devices that are part of the system.

Security and Insurance
Regardless of its capabilities, an alarm system is not a substitute for property or life insurance. An alarm system also is not a substitute for property owners, renters, or other occupants to act prudently to prevent or minimize the harmful effects of an emergency situation.

LIMITED WARRANTY
Digital Security Controls warrants the original purchaser that for a period of twelve months from the date of purchase, the product shall be free of defects in materials and workmanship under normal use. During the warranty period, Digital Security Controls shall, at its option, repair or replace any defective product upon return of the product to its factory, at no charge for labour and materials. Any replacement and/or repaired parts are warranted for the remainder of the original warranty or ninety (90) days, whichever is longer. The original purchaser must promptly notify Digital Security Controls in writing that there is defect in material or workmanship, such written notice to be received in all events prior to expiration of the warranty period. There is absolutely no warranty on software and all software products are sold as a user license under the terms of the software license agreement included with the product. The Customer assumes all responsibility for the proper selection, installation, operation and maintenance of any products purchased from DSC. Custom products are only warranted to the extent that they do not function upon delivery. In such cases, DSC can replace or credit at its option.

International Warranty
The warranty for international customers is the same as for any customer within Canada and the United States, with the exception that Digital Security Controls shall not be responsible for any customs fees, taxes, or VAT that may be due.

Warranty Procedure
To obtain service under this warranty, please return the item(s) in question to the point of purchase. All authorized distributors and dealers have a warranty program. Anyone returning goods to Digital Security Controls must first obtain an authorization number. Digital Security Controls will not accept any shipment whatsoever for which prior authorization has not been obtained.

Conditions to Void Warranty
This warranty applies only to defects in parts and workmanship relating to normal use. It does not cover: damage incurred in shipping or handling; damage caused by disaster such as fire, flood, wind, earthquake or lightning; damage due to causes beyond the control of Digital Security Controls such as excessive voltage, mechanical shock or water damage; damage caused by unauthorized attachment, alterations, modifications or foreign objects; damage caused by peripherals (unless such peripherals were supplied by Digital Security Controls Ltd.); defects caused by failure to provide a suitable installation environment for the products; damage caused by use of the products for purposes other than those for which it was designed; damage from improper maintenance; damage arising out of any other abuse, mishandling or improper application of the products.

Items Not Covered by Warranty
In addition to the items which void the Warranty, the following items shall not be covered by Warranty: (i) freight cost to the repair centre; (ii) products which are not identified with DSC's product label and lot number or serial number; (iii) products disassembled or repaired in such a manner as to adversely affect performance or prevent adequate inspection or testing to verify any warranty claim. Access cards or tags returned for replacement under warranty will be credited or replaced at DSC's option. Products not covered by this warranty, or otherwise out of warranty due to age, misuse, or damage shall be evaluated, and a repair estimate shall be provided. No repair work will be performed until a valid purchase order is received from the Customer and a Return Merchandise Authorization number (RMA) is issued by DSC's Customer Service.

Digital Security Controls Ltd.'s liability for failure to repair the product under this warranty after a reasonable number of attempts will be limited to a replacement of the product, as the exclusive remedy for breach of warranty. Under no circumstances shall Digital Security Controls be liable for any special, incidental, or consequential damages based upon breach of warranty, breach of contract, negligence, strict liability, or any other legal theory. Such damages include, but are not limited to, loss of profits, loss of the product or any associated equipment, cost of capital, cost of substitute or replacement equipment, facilities or services, down time, purchaser's time, the claims of third parties, including customers, and injury to property. The laws of some jurisdictions limit or do not allow the disclaimer of consequential damages. If the laws of such a jurisdiction apply to any claim by or against DSC, the limitations and disclaimers contained here shall be to the greatest extent permitted by law. Some states do not allow the exclusion or limitation of incidental or consequential damages, so that the above may not apply to you.

Disclaimer of Warranties
This warranty contains the entire warranty and shall be in lieu of any and all other warranties, whether expressed or implied (including all implied warranties of merchantability or fitness for a particular purpose) and of all other obligations or liabilities on the part of Digital Security Controls. Digital Security Controls neither assumes responsibility for, nor authorizes any other person purporting to act on its behalf to modify or to change this warranty, nor to assume for it any other warranty or liability concerning this product. This disclaimer of warranties and limited warranty are governed by the laws of the province of Ontario, Canada.

WARNING: Digital Security Controls recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this product to fail to perform as expected.

Out of Warranty Repairs
Digital Security Controls will at its option repair or replace out-of-warranty products which are returned to its factory according to the following conditions. Anyone returning goods to Digital Security Controls must first obtain an authorization number. Digital Security Controls will not accept any shipment whatsoever for which prior authorization has not been obtained. Products which Digital Security Controls determines to be repairable will be repaired and returned. A set fee which Digital Security Controls has predetermined and which may be revised from time to time, will be charged for each unit repaired. Products which Digital Security Controls determines not to be repairable will be replaced by the nearest equivalent product available at that time. The current market price of the replacement product will be charged for each replacement unit.

SIA False Alarm Reduction Installations: Quick Reference

Minimum required system consists of one Control unit model HS2128 or HS2064 or HS2032 or HS2016 and any one of the compatible listed keypads: HS2LCDRF9, HS2LCDRFP9, HS2ICNRF9, HS2ICNRF9P, HS2LCD, HS2LCDP, HS2ICN, HS2ICNP, HS2LED.

The following wireless keys can also be used in SIA compatible installations: PG9929, PG9939, PG9949.

NOTE: For models PG9929 and PG9939, the panic/emergency key shall be disabled for SIA compliant installations.

For a list of the default values programmed when the unit is shipped from the factory, and for any other programming information, refer to the table below.

The following optional subassembly modules also bear the SIA CP-01-2010 classification and may be used if desired: HSM2108 zone expander, HSM2208 PGM output module, HSM2300 auxiliary power supply, HSM2204 output module, HSM2HOST9 2-way wireless transceiver, PG9901 indoor siren, PG9911 outdoor siren, and 3G2080(R)/ TL2803G(R)/ TL280(R) cellular and PSDN communication module.

Caution

- For SIA FAR installations use only modules/devices that are listed on this page.
- Fire Alarm Verification feature (Auto Verified Fire Zone type [025]) is not supported on 2-wire smoke detectors zones, model FSA-210B(T)(S)(ST)(LST)(R)(RT)(RD)(RST)(LRST). This feature may be enabled for 4-wire smoke detectors only (FSA-410B(T)(S)(ST)(LST)(R)(RT)(RST)(LRST) and wireless detectors PG9916/PG9926). The fire alarm delay is 60s.
- Call Waiting Cancel (Section [382], Option 4) feature on a non-Call Waiting line will prevent successful communication to the supervising station.
- All smoke detectors on the system must be tested annually by conducting the Installer Walk Test. Prior to exiting walk test mode, a sensor reset must be done on the system, [*][7][2], to reset all latching 4-wire smoke detectors. Refer to the installation instructions supplied with the detector for details.

Notes

- Programming at installation may be subordinate to other UL requirements for the intended application.
- Cross zones have the ability to individually protect the intended area (e.g. motion detectors which overlap).
- Cross zoning is not recommended for line security Installations nor is it to be implemented on exit/entry zones.
- This control panel has a communication delay of 30 seconds. It can be removed or increased up to 45 seconds by the end user in consultation with the installer.
- The security system shall be installed with the sounding device activated and the communicator enabled for transmission using SIA or CID format.
- ULC commercial burglary installations require DEOL resistors.

SIA Feature Programming Section	Comments	Range/Default	Requirement
Exit Time [005]>[001], option 3	Access to Entry and Exit delays and Bell Time Out for the system.	Range: 45- 255 seconds Default: 60 sec.	Required (programmable)
Progress Annunciation/Disable - for Silent Exit [014], option 6 ON	Enables audible exit beeps from the keypad for the duration of exit delay.	Individual keypads may be disabled Default: Enabled	Allowed
Exit Delay Restart [018], option 7	Opening a Delay zone door after it has already been opened and closed during an exit delay restarts the exit delay timer.	Default: Enabled	Required
Auto Stay Arm on Un-vacated Premises [001]>[001]-[128] Zone type 05, 06, 09	Function key: Forces the system to arm in Stay mode if the occupant does not exit the premises after pressing the Away function key.	If no exit after full arm Default: Enabled	Required
Exit Time and Progress Annunciation/Disable or Remote Arming [861]>[001]-[005], option 4	System times and audible exit beeps can be disabled when using the wireless key to stay arm the system. When away arming, audible exit beeps can not be disabled.	Default: Enabled	Allowed
Entry delay(s) [005]>[001]-[008], options 1 and 2	Access to entry and exit delays and bell time out for the system Note: Combined entry delay and communications delay (abort window) shall not exceed 60s.	Range: 30 sec. to 4 min. Default: 30 sec.	Required (programmable)
Abort Window for Non-Fire zones [002]>[001]-[128], option 7 ON	Access to zone attributes, i.e., swinger shutdown, transmission delay and cross zone. May be disabled by zone or zone type.	Default: Enabled	Required
Abort Window Time - for Non-Fire zones [377]>[002], option 1	Access to the programmable delay before communicating alarms Note: Combined entry delay and communications delay (abort window) shall not exceed 60 seconds.	Range: 00 - 45 sec. Default: 30 sees	Required (programmable)
Abort Annunciation	An audible tone is generated when an alarm is aborted during the abort window.	Hard-coded ON	Required
Duress Feature [*][5]> master code> user 2-95> 5> 2	When this feature is enabled, selected user codes send a duress reporting code to the central station when used to perform any function on the system. Section [019], option [6] must be enabled.	Default: N	Required
Cancel Window [377]>[002], option 6	Access to the communications cancel window. Minimum duration must be 5 minutes.	Range: 005-255 Default: 005	
Cancel Annunciation [308]>[001], option 8	Access to the reporting code for Alarm Canceled.	A Cancel was transmitted Default: Enabled	Required
Cross Zoning [042]>Selection 3, option 002	Enables cross zoning for entire system. Zones can be enabled for cross zoning via zone attribute option 8 in sections [002][101] - [128].	Programming required Default: Disabled	Required
Burglary Verification Timer [005]>[000], option 3	Access to the programmable Cross Zone timer.	Range: 000-255 sec. Default: 60 seconds	Allowed
Swinger Shutdown for Alarms [377]>[001], option 1	Access to the swinger shutdown limit for zone alarms For all non-fire zones, shut down at 1 to 6 trips.	Default: 2 trips	Required (programmable)
Swinger Shutdown Enable [002]>[001] - [128], option 6 ON	Access to swinger shutdown, transmission delay and cross zone attributes. Zone attribute option 6 (Swinger Shutdown enabled) is ON.	Non-police response zones Default: Enabled	Allowed
24-Hr. Auto-verified Fire [001]>[001]-[128], Zone type 025 ON	Access to 24-Hr. Auto-verified Fire Activates if Not restored within the specified time.	Must choose zone type for application	Required
Call Waiting Cancel [382], option 4 OFF	Access to the dialing sequence used to disable call waiting. Call waiting string can be programmed in [034]	Depends on user phone line Default: Disabled	Required
System Test: [*][6] Master Code, option 4	The system activates all keypad sounders, bells or sirens for 2 seconds and all keypad lights turn on. Refer to user manual (<i>part no. 29008365</i>).		
Walk Test Mode: [*][8][Installer code][901]	This mode is used to test each zone on the system for proper functionality.		
Walk Test Communications [382], option 2	Enables communication of zone alarms while walk test is active.	Default: Disabled	
Walk Test Start/ End Reporting Codes [308][401], options 1 and 2	Access to the reporting codes for walk test start and end times.		

© 2014 Tyco International Ltd. and its Respective Companies. All Rights Reserved.

The trademarks, logos, and service marks displayed on this document are registered in the United States [or other countries]. Any misuse of the trademarks is strictly prohibited and Tyco International Ltd. will aggressively enforce its intellectual property rights to the fullest extent of the law, including pursuit of criminal prosecution wherever necessary. All trademarks not owned by Tyco International Ltd. are the property of their respective owners, and are used with permission or allowed under applicable laws.

Product offerings and specifications are subject to change without notice. Actual products may vary from photos. Not all products include all features. Availability varies by region; contact your sales representative.

DSC

A Tyco International Company

Technical Support: 1-800-387-3630 (Can/US)
905-760-3000 (Intl.) www.dsc.com



29008721R001