

Epson Stylus® TX100



Quick Guide

Basic Copying, Printing, and Scanning
Maintaining Your Stylus TX100
Solving Problems
Warranty

Contents

- Introduction 3**
- Loading Paper 4**
 - Using Special Papers 5
- Copying a Document or Photo 7**
 - Placing the Original on the Glass 7
 - Copying a Document 8
 - Copying a Photo 9
 - Copying Draft Documents 10
- Printing From Your Computer 11**
 - Printing in Windows 11
 - Printing With a Macintosh 13
 - Selecting the Correct Paper Type 17
- Scanning a Photo or Document 18**
 - Basic Scanning 18
 - Restoring and Correcting Photos 19
- Maintaining Your TX100 20**
 - Checking the Print Head Nozzles 20
 - Cleaning the Print Head 21
 - Checking the Ink Cartridge Status 22
 - Replacing Ink Cartridges 23
- Solving Problems 27**
 - Checking for Software Updates 27
 - Error Indicators 27
 - Problems and Solutions 28
 - Where To Get Help 30
- Notices. 32**

Introduction

After you have set up your Epson Stylus® TX100 as described on the *Start Here* sheet, turn here to:

- Load paper
- Make a copy of a document or photo
- Get the basic steps for printing from your computer
- Scan a document or photo and restore or correct the color, if necessary
- Perform routine maintenance
- Solve simple problems

This book tells you how to do most of these things without ever turning on your computer! Of course, your TX100 can do a lot more when you connect it to your Windows® or Macintosh® computer. For additional instructions, see the on-screen *User's Guide* by double-clicking the icon for it on your desktop.

Please follow these guidelines as you read your TX100 instructions:

Warning:

Warnings must be followed carefully to avoid bodily injury.

Caution:

Cautions must be observed to avoid damage to your equipment.

Note:

Notes contain important information about your TX100.



Tip:

Tips contain hints for better copying, scanning, and printing.



Loading Paper

You can print on a variety of paper types and sizes. For details, see page 5.


1. Open the paper support, then open the output tray and pull out the extension.



2. Flip the clear plastic feeder guard forward, then squeeze the edge guide and slide it left.



3. Insert paper, glossy or printable side up, short edge first, against the right side and beneath the tab. (Load letterhead or pre-printed paper top edge first.)



Always load paper short edge first, even for landscape printing.

You can load up to 80 sheets of plain paper, Epson Bright White Paper, or Presentation Paper Matte, or 20 sheets of photo paper. Load other special papers one sheet at a time.

Note:

The type of paper you choose affects the way your printout looks. If you are just making a copy or printing a rough draft, plain paper is fine. However, for the best results, you'll want to use one of Epson's special ink jet papers designed for your printer. See the next section for more information.

- 4. Slide the edge guide against the paper, but not too tightly.
- 5. Flip the clear plastic feeder guard back.

Note:

For instructions on loading envelopes, see your on-screen *User's Guide*.

Using Special Papers

Epson offers a wide array of high quality papers, making it easy to maximize the impact of your photos, presentations, and creative projects.

You can purchase genuine Epson ink and paper from an Epson Authorized reseller. To find the nearest reseller, call your nearest Epson sales office. See “Where To Get Help” on page 30.

Paper type	Size	Part number	Sheet count
Epson Bright White Paper	Letter (8.5 × 11 in. [21.6 × 28 cm])	S041586	500
Epson Photo Paper Glossy	4 × 6 in. (10.2 × 15.2 cm)	S041809	50
		S042038	100
	Letter (8.5 × 11 in. [21.6 × 28 cm])	S041141	20
		S041649	50
		S041271	100

Paper type	Size	Part number	Sheet count
Epson Premium Photo Paper Glossy	Borderless 4 × 6 in. (10.2 × 15.2 cm)	S041808 S041727	40 100
	Borderless 5 × 7 in. (12.7 × 17.8 cm)	S041464	20
	Borderless 8 × 10 in. (20.3 × 25.4 cm)	S041465	20
	Letter (8.5 × 11 in. [21.6 × 28 cm])	S042183 S041667	25 50
Epson Ultra Premium Photo Paper Glossy	Borderless 4 × 6 in. (10.2 × 15.2 cm)	S042181 S042174	60 100
	Borderless 5 × 7 in. (12.7 × 17.8 cm)	S041945	20
	Borderless 8 × 10 in. (20.3 × 25.4 cm)	S041946	20
	Letter (8.5 × 11 in. [21.6 × 28 cm])	S042182 S042175	25 50
Epson Premium Photo Paper Semi-gloss	Borderless 4 × 6 in. (10.2 × 15.2 cm)	S041982	40
	Letter (8.5 × 11 in. [21.6 × 28 cm])	S041331	20
Epson Presentation Paper Matte	Letter (8.5 × 11 in. [21.6 × 28 cm])	S041062	100
	Legal (8.5 × 14 in. [21.6 × 35.6 cm])	S041067	100
Epson Premium Presentation Paper Matte	Borderless 8 × 10 in. (20.3 × 25.4 cm)	S041467	50
	Letter (8.5 × 11 in. [21.6 × 28 cm])	S041257 S042180	50 100
Epson Premium Presentation Paper Matte Double-sided	Letter (8.5 × 11 in. [21.6 × 28 cm])	S041568	50
Epson Photo Quality Self-adhesive sheets	A4 (21.1 × 29.7 cm)	S041106	10
Epson Iron-on Cool Peel Transfer Paper	Letter (8.5 × 11 in. [21.6 × 28 cm])	S041153	10

* Availability of media varies by country.



6 Using Special Papers

Copying a Document or Photo


Follow the instructions in this section to position your originals correctly on the glass and make color or black-and-white copies.

Placing the Original on the Glass

1. Open the document cover and place your original face-down on the glass, with the top facing into the front right corner.




2. Close the cover gently so you don't move the original.



Copying a Document

You can copy documents onto letter- or A4-size plain paper or Epson special paper just like a copy machine.

1. Load letter- or A4-size plain paper or Epson special paper.
2. Place your original document on the document table.
3. Press the  **Iniciar**  button (for black-and-white documents) or  **Iniciar**  button (for color documents) to start copying.



If you want to enlarge your document to fit on letter- or A4-size paper, press and hold either the  **Iniciar**  button (for black-and-white documents) or  **Iniciar**  button (for color documents) for three seconds.

If you need to cancel copying, press the  **Cancelar** (Stop) button.


Note:

Copies may not be exactly the same size as your original document.

Copying a Photo

You can copy photos onto 4 × 6-inch (10 × 15-cm) Epson photo paper (various types available) for borderless photo reprints.

1. Load up to 20 sheets of 4 × 6-inch (10 × 15-cm) Epson photo paper.
2. Place your original photo on the document table.
3. Press the  **Foto** (Photo)  button to start copying. The TX100 automatically sizes your photo to fit on the paper you loaded.



If you need to cancel copying, press the  **Cancelar** (Stop) button.


Note:

Copies may not be exactly the same size as your original photo, and cropping may occur at the edges.

Copying Draft Documents

You can make quick draft copies of documents on plain paper or Epson Bright White paper. Draft copies have reduced print quality, but they print faster.

1. Load letter- or A4-size plain paper or Epson Bright White paper.
2. Place your original document on the document table.
3. Press and hold the Ⓢ Cancelar (Stop) button as you press either the
◆ Iniciar ● button (for black-and-white documents) or
◆ Iniciar ●●● button (for color documents).



If you need to cancel copying, press the Ⓢ Cancelar (Stop) button.

Note:

Copies may not be exactly the same size as your originals.

Printing From Your Computer

This section describes the basic steps for printing a photo or document stored on your Windows or Macintosh computer. For detailed instructions on printing, see the on-screen *User's Guide*.


Before you start, make sure you've installed your printer software and connected the TX100 to your computer as described on the *Start Here* sheet.

Tip:

It's a good idea to check for updates to your TX100 software (see page 27 for instructions).

Printing in Windows

1. Open a photo or document in an application.
2. Open the File menu and select **Print**. You see a window like this one:



3. Make sure **EPSON TX100 Series** is selected, then click the **Preferences** or **Properties** button.


(If you see a **Setup**, **Printer**, or **Options** button, click it. Then click **Preferences** or **Properties** on the next screen.)

4. On the Main tab, select the basic print settings. Make sure you choose the correct paper **Type** setting for the paper you are using (see page 17 for details).

Select the type of document you're printing
(choose **Photo** or **Best Photo** for pictures)

Select your
paper **Type**

Select your
paper **Size**



Click here for
borderless photos

Select your
document
Orientation

Tip:

For quick access to the most common settings, click the **Shortcuts** tab and select one of the presets. You can create your own presets by clicking the **Save Settings** button on the **Advanced** tab. For details, see your on-screen *User's Guide*.


5. To improve the color, contrast, and sharpness of photos, select **Fix Photo**.
6. To reduce or remove red-eye effects in photos, select **Fix Red-Eye**.
7. If you want to reduce or enlarge your printout, or print double-sided, click the **Page Layout** tab and select settings as necessary.
8. For more printing options, click the **Advanced** tab.

Note:

For more information about print settings, click **Help** or see your on-screen *User's Guide*.

9. Click **OK** to save your settings.

10. Click **OK** or **Print** to start printing. This window appears and shows the progress of your print job.




Printing With a Macintosh

See one of the sections below for your Mac OS® operating system.

Mac OS X 10.5

1. Open a photo or document in an application.
2. Open the **File** menu and select **Print**.
3. Select **EPSON Stylus TX100** as the **Printer** setting.




4. Click ▼ to expand the **Print** window, if necessary.


5. Select the basic page setup options. For borderless photos, choose a **Paper Size** setting with a **Sheet Feeder - Borderless** option.

Note:

If the setting you want isn't shown (for example, **Scale**), check for it in your application before printing.



6. Choose **Print Settings** from the pop-up menu, then select the following settings that appear on the bottom of the screen:




7. Choose any other printing options you may need from the pop-up menu. See the on-screen *User's Guide* for details.

Tip:

To reduce or remove red-eye effects in photos, choose **Extension Settings** from the pop-up menu and select **Fix Red-Eye**.


8. Click **Print**.

- To monitor your print job, click the printer icon in the dock. Select your print job, then select an option to cancel, pause, or resume printing, if necessary.



Mac OS X 10.3 to 10.4


- Open a photo or document in an application.
- Select **Page Setup** from the File menu. Select the following settings:




For borderless printing, choose a **Sheet Feeder - Borderless** option in the Paper Size list for your paper size.

- Click **OK** to close the Page Setup window.

4. Select **Print** from the File menu. You see a window like this one:



5. Choose **Print Settings** from the pop-up menu and select the following settings as necessary:



Note:

In certain programs, you may need to select **Advanced** before you can select **Print Settings**. For more information about printer settings, click the ? button.

6. Click the **Advanced** button to change additional settings.


Note:

For more information on advanced settings click ?.

7. Choose any other printing options you may need from the pop-up menu. See your on-screen *User's Guide* for details.

8. Click **Print**.

9. To monitor the progress of your print job, click the printer icon in the dock (or click the **Print Center** icon and double-click **Stylus TX100** on the next screen).



Selecting the Correct Paper Type

Select the correct **Type** (see page 12) or **Media Type** (see page 14 or page 16) setting in your printer software. This tells the TX100 what kind of paper you're using, so the ink coverage can be adjusted accordingly.

For this paper	Select this setting
Plain paper Epson Bright White Paper Epson Presentation Paper Matte	Plain Paper/Bright White Paper
Epson Ultra Premium Photo Paper Glossy	Ultra Premium Photo Paper Glossy
Epson Premium Photo Paper Glossy	Premium Photo Paper Glossy
Epson Photo Paper Glossy	Photo Paper Glossy
Epson Premium Photo Paper Semi-gloss	Premium Photo Paper Semi-Gloss
Epson Premium Presentation Paper Matte Epson Premium Presentation Paper Matte Double-sided Epson Photo Quality Self-adhesive Sheets Epson Iron-on Cool Peel Transfer Paper	Premium Presentation Paper Matte
Envelopes	Envelope

Scanning a Photo or Document

You can use your TX100 to scan a photo or document and save it on your computer or other device.

You can even restore and correct photographs as you scan (see page 19).

The Epson Scan software provides three scanning modes:

- **Full Auto Mode** scans quickly and easily using automatic settings.
- **Home Mode** previews your image and provides preset options for scanning.
- **Professional Mode** previews your image and provides a full array of tools.

Note:

For detailed scanning instructions, see your on-screen *User's Guide*.


Basic Scanning

You can scan from any TWAIN-compliant application using Epson Scan. Or you can start Epson Scan directly from your computer and save your image to a file.

1. Open the document cover and place your original face-down on the glass, in the front right corner, as shown on page 7.
2. Close the cover gently so you don't move the original.
3. Do one of the following to start Epson Scan:
 - **Windows:**
Double-click the **EPSON Scan** icon on your desktop.
 - **Macintosh:**
Double-click **EPSON Scan** in the Applications folder.
 - If you are scanning from an application, start your application. Then open the File menu, choose **Import** or **Acquire**, and select **Epson Stylus TX100**.

You see the Epson Scan standby window:

4. If the Mode setting in the upper right corner is set to **Full Auto Mode**, click the **Scan** button.
- If you are in Home or Professional Mode, you see a different Epson Scan settings window. (You can change the mode using the Mode selector in the upper right corner.)
5. If you want to restore faded color in a photo or make other corrections, click **Customize**. Then follow the instructions below.
6. Click **OK**. The image is scanned and you see its icon in Windows Explorer or Macintosh Finder.




Restoring and Correcting Photos

You can automatically transform a faded, dusty, or badly exposed color photo into one with true-to-life color and sharpness as you scan. Use the **Color Restoration** and **Dust Removal** options in Epson Scan's Full Auto Mode. In Home and Professional Mode, you can also select **Backlight Correction** to remove shadows from images with too much background light.

Full Auto Mode

Click the **Customize** button, click **Dust Removal** and/or **Color Restoration**, click **OK**, and click **Scan**.



Select **Auto Photo Orientation** to orient your photos based on detected faces, the sky, etc. If your photo is not oriented correctly, turn it off.

Note:

For more information, see your on-screen *User's Guide*. You can also click **Help** on the Epson Scan screen for information about all the available settings.

Maintaining Your TX100

Follow the instructions in this chapter for checking and cleaning the print head nozzles and replacing ink cartridges. To align the print head, if necessary, see your on-screen *User's Guide*.


Caution:

To keep your TX100 looking like new, don't place anything on top of the cover or use it as a writing surface. If you need to clean the cover, use only a soft, non-abrasive microfiber-type cloth.

Checking the Print Head Nozzles

If your printouts are faint or have gaps in them, some of the nozzles in the print head may be clogged or ink may be running low in one or more of the ink cartridges. Follow the steps below to check the print head nozzles.


1. Load letter-size paper in the sheet feeder.
2. Turn off the TX100.
3. Hold down the ⏻ Cancelar (Stop) button as you press the ⏻ Encender/Ligar (On) button to turn the TX100 back on. Hold down both buttons until the ⏻ Encender/Ligar (On) light begins to flash, then release the buttons.



4. Check the nozzle check pattern that prints to see if there are gaps in the lines.



Nozzles are clean



Nozzles need cleaning

5. If there are no gaps, the print head is clean. If there are gaps or the pattern is faint, clean the print head as described in the next section.

Cleaning the Print Head

If print quality has declined and the nozzle check pattern indicates clogged nozzles, you can clean the print head. Print head cleaning uses ink, so clean it only if necessary.

Note:

You cannot clean the print head if an ink cartridge is expended, and you may not be able to clean it when a cartridge is low. You must replace the cartridge first (see page 23).

1. Make sure the TX100 is on and the  ink light is off.
2. Hold down the  **Cancel** (Stop) button for three seconds to start the cleaning cycle, which lasts around one minute.

Caution:

Never turn off the TX100 during head cleaning or you may damage it.

3. When the  **Encoder/Light** (On) light stops flashing, run a nozzle check (as described on page 20) to verify that the print head is clean.
4. If there are still gaps or lines, or the test patterns are faint, run another cleaning cycle and check the nozzles again.

Note:

If you don't see any improvement after cleaning the print head two times, turn off your TX100 and wait at least six hours to let any dried ink soften. Then try cleaning the print head again. If quality does not improve, one of the ink cartridges may need to be replaced. If that doesn't help, contact Epson as described on page 30.

If you do not use your TX100 often, it is a good idea to print a few pages at least once a month to maintain good print quality.

Checking the Ink Cartridge Status

When the  ink light starts flashing, a cartridge is low on ink. You can continue printing until a cartridge needs replacement. When the  ink light stays on, you need to replace a cartridge.

Note:

You cannot print or copy when an ink cartridge is expended even if the other cartridges are not expended. Replace any expended cartridges before printing or copying.

A window may also appear on your computer screen when you try to print when ink is low. This window can optionally display ink offers and other updates retrieved from an Epson website. Select **Do not display this message again** to not receive on-line offers. Promotional offers are not valid in Latin America.

Tip:

If a cartridge is more than six months old, print quality may decline. If necessary, try cleaning the print head (see page 21). If printouts still do not look their best, you may need to replace the cartridge.

You can purchase genuine Epson ink and paper from an Epson Authorized reseller. To find the nearest reseller, call your nearest Epson sales office. See page 30.

See your *Start Here* sheet for ink cartridge codes.

Note:

We recommend that you use genuine Epson cartridges and do not refill them. The use of other products may affect your print quality and could result in printer damage.

The printer ships with full cartridges and part of the ink from this first set of cartridges is used for priming the printer.

Yields vary considerably based on images printed, print settings, paper type, frequency of use, and temperature. For print quality, a small amount of ink remains in the cartridge after the "replace cartridge" indicator comes on.

For best printing results, use up a cartridge within six months of opening the package.

Store ink cartridges in a cool, dark place. If cartridges have been exposed to cold temperatures, allow them to warm up to room temperature for at least 3 hours before using them.

Replacing Ink Cartridges

Make sure you have a new ink cartridge before you begin. You must install new cartridges immediately after removing the old ones.

Warning:

Keep ink cartridges out of the reach of children and do not drink the ink.

Caution:

Do not open ink cartridge packages until you are ready to install the ink. Cartridges are vacuum packed to maintain reliability.

Note:


Leave the expended cartridge installed until you have obtained a replacement, or the ink remaining in the print head nozzles may dry out.

1. Turn on the TX100.

Note:

If you need to change a cartridge before it is expended (the  ink light is flashing or off), run the ink cartridge replacement utility. See the on-screen *User's Guide* for details.

2. Open the scanner and prop it up with its support.




Caution:

Do not touch the white cable inside the printer or you may damage it.




3. Press the  **Cancel** (Stop) button. The print head moves to the  position to indicate which cartridge is low or expended.



Caution:

Do not move the print head by hand; this may damage your TX100. Always press the  **Cancel** (Stop) button to move it.

4. Press the  **Cancel** (Stop) button again.
 - If another cartridge is low or expended, it moves to the  position. Press the  **Cancel** (Stop) button again to see if any more cartridges are low or expended.
 - If no other cartridges are low or expended, the print head moves to the replacement position.
5. Squeeze the tab on the cartridge and lift it up. Dispose of it carefully. Do not take the used cartridge apart or try to refill it.




Caution:

Do not touch the white cable inside the printer or you may damage it.

Warning:

If ink gets on your hands, wash them thoroughly with soap and water. If ink gets into your eyes, flush them immediately with water. Keep ink cartridges out of the reach of children.



- Before you open the new cartridge package, shake it four or five times. Then remove it from the package.



Caution:



Do not touch the green chip on the front of the cartridge. This can damage the ink cartridge.

- Remove the yellow tape from the bottom of the ink cartridge.





Caution:


Do not remove any other labels or seals, or ink may leak.



- Insert the new ink cartridge into the holder and push it down until it clicks into place.



9. Once you replace all the cartridges that need replacing, lift the scanner slightly, release its support, and lower the scanner.



10. Press the **Cancel (Stop)** button to begin charging the ink. This takes about 1 1/2 minutes. When it's finished, the **Encoder/Light (On)** light stops flashing and remains on, and the **ink** light goes out.

Caution:

Never turn off the TX100 while ink is charging or you'll waste ink. If the **ink** light flashes, press the **Cancel (Stop)** button and press down all the cartridges securely.

Note:

If you replaced a cartridge while copying a document or photo, cancel printing and make sure your original is still placed correctly on the document table. Then copy your original again.

If you remove a low or expended ink cartridge, you cannot reinstall and use the cartridge.

Solving Problems

If you have a problem with your TX100, check the lights on the control panel to diagnose the cause.

You can also check “Problems and Solutions” on page 28 for basic troubleshooting suggestions, or double-click the *User’s Guide* icon on your computer desktop for more detailed help.

Checking for Software Updates

Periodically, it’s a good idea to check Epson’s support website at www.latin.epson.com for free updates to your Epson Stylus TX100 software.

With Windows, you can select **Driver Update** on the Maintenance tab in the printer settings window. You can also click  or **Start**, select **All Programs** or **Programs**, select **EPSON**, select **EPSON TX100 Series**, and click **Driver Update**.

Error Indicators

Light status	Problem and Solution
 Encender/Ligar (On) light slowly flashing No other lights are on	The TX100 is in sleep mode. Press any button except the  Encender/Ligar (On) button to wake it up.
 Error/Erro light on	Paper is out or multiple pages have fed. Load or reload paper in the sheet feeder.
 Error/Erro and  Encender/Ligar (On) light flashing at same rate	Paper is jammed. Carefully remove the jam, as described on page 29.
 ink light flashing	One or more cartridges have low ink. You can continue printing until a cartridge needs replacement. Check the cartridge status to determine which cartridges are affected (see page 22).

Light status	Problem and Solution
▲ ink light on	One or more ink cartridges are expended, incorrectly installed, or cannot be used with the printer. If an ink cartridge is likely to be expended, you must replace the cartridge to be able to print. If you just replaced a cartridge and the light is still on, the cartridge is not installed correctly. Press the ⏏ Cancelar (Stop) button to move the cartridges to the replacement position. Press down on all the installed cartridges, then press the ⏏ Cancelar (Stop) button to continue.
All lights are on	Parts inside the TX100 are at the end of their service life. Contact Epson for help (see page 30).
All lights are flashing	There is a problem with the TX100. Turn it off, wait a few moments, and turn it back on again. If the error is not resolved, contact Epson for help (see page 30).

Problems and Solutions

Check the solutions below if you're having trouble using your TX100.

Printing and Copying Problems

- Make sure your original is positioned in the front right corner of the glass. If the edges are cropped, move your original away from the edges slightly.
- Make sure your paper is loaded short edge first and is positioned against the right side with the edge guide against its left side. Don't load paper above the arrow mark inside the edge guide.
- Make sure the paper size settings are correct for the paper you loaded.

Paper Feeding Problems

- If paper doesn't feed, remove it from the sheet feeder. Flip through the stack to separate the sheets a little. Then reload the paper against the right side, and slide the left edge guide against the paper (but not too tightly).
- Do not load too many sheets at once. Load up to 20 sheets of photo paper, 80 sheets of matte paper, or 100 sheets of plain paper. Load other special papers one sheet at a time.

- Do not load paper with holes punched in it.
- If paper is jammed, follow these steps:
 1. Gently pull out jammed paper from the output tray or sheet feeder.
 2. If paper is stuck inside, turn off the TX100.
 3. Lift the scanner, check everywhere for jammed paper and torn pieces, remove them, lower the scanner, and turn the TX100 back on.

Print Quality Problems

If you have any problems with the copy or print quality, try these solutions:

- Make sure the document is placed flat against the document table glass and the TX100 is not tilted or placed on an uneven surface.
- Load the paper printable side up (usually the whiter, brighter, or glossy side).
- Make sure your paper isn't damp or curled.
- Use a support sheet with special paper or load your paper one sheet at a time. Remove sheets from the output tray so not too many collect at a time.
- Make sure the type of paper you loaded matches the paper size and paper type settings in your printer software (see page 17).
- For the best print quality, use Epson special paper (see page 5) and genuine Epson ink cartridges (see page 22).
- If you notice light or dark bands across your printouts or they are too faint, you may need to clean the print head (see page 21). This unclogs the nozzles so they can deliver ink properly. Run a nozzle check (see page 20) to see if the print head needs cleaning.
- Clean the print head as described on page 21.
- If you notice jagged vertical lines, you may need to align the print head. See your *User's Guide* for instructions.
- The ink cartridges may be low on ink. Check your cartridge status (see page 22) and replace cartridges, if necessary (see page 23).
- If a dotted line appears in the image, clean the document table glass with a soft, dry, lint-free cloth (paper towels are not recommended and may permanently scratch the surface), or use a small amount of glass cleaner on a soft cloth, if necessary. Do not spray glass cleaner directly on the glass.

Where To Get Help

Epson Technical Support

Internet Support

Visit Epson's support website at www.latin.epson.com for your Epson Stylus TX100 for solutions to common problems. You can download drivers, get FAQs and troubleshooting advice, or e-mail Epson with your questions.

Speak to a Support Representative

Before you call Epson for support, please have the following information ready:

- Product name (Epson Stylus TX100)
- Product serial number (located on the back of product)
- Proof of purchase (such as a store receipt) and date of purchase
- Computer configuration
- Description of the problem

Then call:

Country	Telephone
Argentina	(54 11) 5167-0300
Brazil	(55 11) 3956-6868
Chile	(56 2) 230-9500
Colombia	(57 1) 523-5000
Costa Rica	(50 6) 2210-9555 (800) 377-6627
Mexico Mexico City Other Cities	(52 55) 1323-2052 (01 800) 087-1080
Peru	(51 1) 418-0210
Venezuela	(58 212) 240-1111

Toll or long distance charges may apply.

Purchase Supplies and Accessories

You can purchase genuine Epson ink and paper from an Epson Authorized reseller. To find the nearest reseller, call your nearest Epson sales office, as described above.

Notices

System Requirements

To use the Epson Stylus TX100 and its software, your computer system should meet or exceed the requirements in these sections:

Windows Requirements

- A Microsoft® Windows compatible PC with an 800 MHz or faster processor recommended
- Microsoft Windows 2000, Windows XP, Windows XP Professional x64 Edition, or Windows Vista
- 256MB RAM for Windows 2000, Windows XP, and Windows XP Professional x64 Edition (512MB recommended)
1GB RAM for Windows Vista
- 450MB free hard disk space (550MB recommended)
- 4× or faster CD-ROM drive for installing the software
- A Windows-compliant USB port and shielded USB “AB” cable up to 2 meters long. Using an improperly shielded USB cable may cause the Epson Stylus TX100 to malfunction.

Macintosh Requirements

- An Apple® Macintosh
- Mac OS X 10.3.9, 10.4.x, or 10.5.x
- 256MB RAM (512MB recommended)
- 450MB free hard disk space (550MB recommended)
- 4× or faster CD-ROM drive for installing the software
- A USB port and a shielded USB “AB” cable up to 2 meters long. Using an improperly shielded USB cable may cause the Epson Stylus TX100 to malfunction.

Important Safety Instructions

Before using your TX100, read and follow these safety instructions:

- Be sure to follow all warnings and instructions marked on the TX100.
- Use only the type of power source indicated on the TX100 label.
- Use only the power cord that comes with the TX100. Use of another cord may cause fires or shock. Do not use the cord with any other equipment.
- Place the TX100 near a wall outlet where the plug can be easily unplugged.
- If you won't be using the TX100 for a long period, unplug the power cord from the electrical outlet.
- Always turn off the TX100 using the ⏻ **Encender/Ligar (On)** button, and wait until the ⏻ **Encender/Ligar (On)** light stops flashing before unplugging the printer or cutting off power to the electrical outlet.
- Avoid plugging the TX100 into an outlet on the same circuit as a photo copier or air control system that regularly switches on and off, or on an outlet controlled by a wall switch or timer.
- Do not let the power cord become damaged or frayed.
- If you use an extension cord with the TX100, make sure the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating. Also, make sure the total ampere rating of all devices plugged into the wall outlet does not exceed the wall outlet's ampere rating.
- Avoid locations that are subject to rapid changes in heat or humidity, shocks or vibrations, or dust.
- Leave enough room around the TX100 for sufficient ventilation. Do not block or cover openings in the case or insert objects through the slots.
- Do not place or store the TX100 near a radiator or heating vent, in a dusty or moist environment, in direct sunlight, or outdoors.
- Keep the away from potential sources of electromagnetic interference, such as loudspeakers or the base units of cordless telephones.
- Do not use aerosol products that contain flammable gases inside or around the TX100. Doing so may cause fire.
- Place the TX100 on a flat, stable surface that extends beyond its base in all directions. It will not operate properly if it is tilted or at an angle.
- Do not open the scanner section while the TX100 is copying, printing, or scanning.
- Do not touch the flat white cable inside the TX100, and be careful not to trap your fingers when closing the scanner.

- Do not spill liquid on the TX100 or use it with wet hands.
- Except as specifically explained in your documentation, do not disassembly, modify, or attempt to service the TX100 yourself.
- Unplug the TX100 and refer servicing to qualified service personnel under the following conditions: if the power cord or plug is damaged; if liquid has entered the product; if the product has been dropped or the case damaged; if the product does not operate normally or exhibits a distinct change in performance. Adjust only those controls that are covered by the operating instructions.
- When storing or transporting the TX100, do not tilt it, stand it on its side, or turn it upside down; otherwise ink may leak from the cartridges.

Ink Cartridge Safety

- Keep ink cartridges out of the reach of children and do not drink the ink.
- Be careful when you handle used ink cartridges; there may be ink remaining around the ink supply port. If ink gets on your skin, wash it off with soap and water. If it gets in your eyes, flush them immediately with water.
- Do not put your hand inside the TX100 or touch any cartridges during printing.
- Install a new ink cartridge immediately after removing an expended one. Leaving cartridges uninstalled can dry out the print head and may prevent the TX100 from printing.
- If you remove an ink cartridge for later use, protect the ink supply area from dirt and dust and store it in the same environment as the TX100. Note that there is a valve in the ink supply port, making covers or plugs unnecessary, but care is needed to prevent the ink from staining items that the cartridge touches. Do not touch the ink cartridge ink supply port or surrounding area. Store cartridges with their labels facing upward.

Technical Specifications

Impresión	
Paper path	Sheet feeder, top entry
Sheet feeder capacity	Approx. 100 sheets at 75 g/m ²

Escaneado	
Tipo de escáner	Escáner con superficie plana para imágenes a color
Dispositivo fotoeléctrico	CIS
Píxeles efectivos	5.1200 × 14.040 píxeles a 1200 ppp
Tamaño de documento	216 × 297 mm, A4 o Carta US
Resolución de escaneado	600 ppp (digitalización principal) 1200 ppp (subdigitalización)
Resolución de salida	De 50 a 4800, 7200 y 9600 ppp (de 50 a 4800 ppp en incrementos de 1 ppp)
Datos de imagen	16 bits internos por píxel por color 8 bits externos por píxel por color (máximo)
Fuente de luz	LED de tres colores RGB
Cartuchos de tinta	
Color	Cian, magenta, amarillo, negro
Duración del cartucho	6 meses
Temperatura	Almacenados: -20 °C a 40 °C 1 mes a 40 °C Congelación*: -12 °C
*Espere aproximadamente tres horas para utilizar la tinta después de haberla descongelado en un ambiente a 25 °C.	
Precaución: para garantizar resultados óptimos, utilice cartuchos de tinta Epson originales y no los rellene. Otros productos podrían dañar su impresora y no estarán cubiertos por la garantía de Epson. No utilice un cartucho de tinta cuya fecha de caducidad haya expirado.	
Mecánicas	
Recorrido del papel	Alimentador de hojas, entrada superior
Capacidad del alimentador	Aproximadamente 120 hojas de 90 g/m ²
Dimensiones	Ancho: 434 mm Profundidad: 326,5 mm Altura: 185,2 mm
Peso	4,45 kg sin los cartuchos de tinta

Eléctricas		
	Modelo 100-127 V	Modelo 220-240 V
Voltaje de entrada	90 - 132 V	198 - 264 V
Frecuencia nominal	50 a 60 Hz	
Corriente nominal	0,6 A (0.7 A [MAXIMUM])	0,3 A (0.4 a [MAXIMUM])
Consumo de energía	11,7 W (22.1 W [MAXIMUM]) en funcionamiento 3,8 W en modo de reposo 1 W apagado	11,5 W (22.4 W [MAXIMUM]) en funcionamiento 3,8 W en modo de reposo 1 W apagado
Nota: revise las especificaciones de voltaje en la parte posterior de la impresora.		
Ambientales		
Temperatura	En funcionamiento: 10 a 35 °C Almacenado: -20 a 60 °C 1 mes a 40 °C 120 [HOURS AT] 60 °C	
Humedad (sin condensación)	En funcionamiento: 20% a 80% de humedad relativa Almacenado: 5% a 85% de humedad relativa	
Interface		
Tipo de interface	Un cable 2.0 de velocidad estándar (para computadoras)	
Normas y certificados de aprobación		
Seguridad	UL 60950-1 CAN/CSA C22.2 N° 60950-1	
EMC	FCC parte 15 Subparte B clase B CAN/CSA-CEI/IEC CISPR 22 clase B	

FCC Compliance Statement

For United States Users

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio and television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING

The connection of a non-shielded equipment interface cable to this equipment will invalidate the FCC Certification of this device and may cause interference levels which exceed the limits established by the FCC for this equipment. It is the responsibility of the user to obtain and use a shielded equipment interface cable with this device. If this equipment has more than one interface connector, do not leave cables connected to unused interfaces. Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

For Canadian Users

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Declaration of Conformity

According to 47CFR, Part 2 and 15 for: Class B Personal Computers and Peripherals;
and/or CPU Boards and Power Supplies used with Class B Personal Computers:

We: Epson America, Inc.
Located at: MS 3-13
3840 Kilroy Airport Way
Long Beach, CA 90806
Telephone: (562) 290-5254

Declare under sole responsibility that the product identified herein, complies with 47CFR Part 2 and 15 of the FCC rules as a Class B digital device. Each product marketed is identical to the representative unit tested and found to be compliant with the standards. Records maintained continue to reflect the equipment being produced can be expected to be within the variation accepted, due to quantity production and testing on a statistical basis as required by 47CFR §2.909. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Trade Name: Epson
Type of Product: Multifunction printer
Model: C411A

Copyright Notice

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. The information contained herein is designed only for use with this Epson product. Epson is not responsible for any use of this information as applied to other equipment.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

Responsible Use of Copyrighted Materials

Epson encourages each user to be responsible and respectful of the copyright laws when using any Epson product. While some countries' laws permit limited copying or reuse of copyrighted material in certain circumstances, those circumstances may not be as broad as some people assume. Contact your legal advisor for any questions regarding copyright law.

Trademarks

Epson and Epson Stylus are registered trademarks, and Epson Exceed Your Vision is a registered logomark of Seiko Epson Corporation.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.

This information is subject to change without notice.

© 2008 Epson America, Inc. 5/08





411418400

CPD-25638
Printed in XXXXXX