

# SOL4MTX 'Bodywire'

## User Manual

**Version 1.12**  
30 September 2011

**Cobham Tactical Communications and Surveillance**  
The Cobham Centre – Solent, Fusion 2  
1100 Parkway  
Solent Business Park  
Whiteley, Hampshire  
PO15 7AB, England

T: +44 (0)1489 566 750  
F: +44 (0)1489 880 538

## Table of Contents

<b>Table of Contents</b> .....	<b>2</b>
<b>Change History</b> .....	<b>3</b>
<b>About this Manual</b> .....	<b>4</b>
<b>Introduction</b> .....	<b>5</b>
<b>Warranty and Support</b> .....	<b>6</b>
1.1 Warranty Cover .....	6
<b>Safety, Compliance and Approvals</b> .....	<b>7</b>
1.1 Safe Operating Procedures .....	7
1.2 EMC / Safety and Radio Approvals.....	7
1.3 CE marking.....	8
1.4 Caution.....	8
1.5 FCC Subpart 15A/RSS-Gen/RSS-102:.....	8
<b>Getting Started and Basic Operation</b> .....	<b>10</b>
1.1 Which Model do I have? .....	10
Controls.....	12
1.2 Getting Started with the Transmitter .....	12
<b>Powering on the System</b> .....	<b>23</b>
1.1 Domo Batteries and Battery Charging .....	24
1.2 Using the Clip On 1W Amplifier.....	26
1.3 Using the booster 5W Amp .....	28
1.4 Using the booster 500mW Amp .....	30
<b>Advanced Operation</b> .....	<b>32</b>
1.1 SOLO System PC Controller Application Software .....	32
1.2 Transmitter Control Application.....	34
<b>Fault Finding</b> .....	<b>42</b>
<b>Connector Pin Outs</b> .....	<b>43</b>
1.1 Power - 4-pin 0B LEMO Socket (TX and RX).....	43
1.2 15Way Lemo DType Cable.....	43
1.3 CA0317 Break Out Cable .....	44
<b>Control Protocols</b> .....	<b>45</b>
1.1 RS232 Control – General Principles .....	45
1.2 Packet Structure Sending (from PC).....	45
1.3 Packet Structure Reply (from controlled device) .....	46
1.4 Transmitter Command List.....	47
<b>Default Configurations</b> .....	<b>55</b>

## Change History

Version	Main Changes from Previous Version	Edited By
v1.0	Initial Release	MB
v1.1	Updated Part Numbers	MB
v1.2	Updated remote control protocol	JGS
v1.3	Update	MB
v1.4	Added SDI to license mask	JGS
v1.5	Updated remote control protocol	RL
v1.6	Made use of 1W PA a special	MB
v1.8	Updates to frequency range available	RDPC
v1.9	Added missing remote commands	RL
v1.10	Added RF power level calibration commands	AL
v1.11	Updates to commands	AL
v1.12	Added extra preset mode commands	AL

## About this Manual

This manual describes the operation of **domo** SOL4MTX 'Bodywire' Transmitter. The manual is divided into three main sections.

- **Getting started and basic operation**

This section describes to users how to deploy and use a **domo** SOL4MTX transmitter.

- **Advanced operation**

This section describes the operation of the equipment in more detail, concentrating particularly on how to store and recall configurations, with use of the PC Controller Application.

- **Technical reference**

This section provides technical specification and control protocol data and will be of interest to those integrating the SOL4MTX into a larger system.

## Introduction

The SOLO4 Bodywire Transmitter is a COFDM digital video transmitter, designed specifically for covert video installations and body worn applications.

The small size and low power consumption of the SOLO4 Bodywire make it the product of choice for covert video hides, or applications requiring long term battery power deployments, small unmanned aerial vehicles, and body worn or body wire use.

The SOLO4 Bodywire transmitter employs MPEG2 (MPEG4 is also available) encoding for excellent image quality retention. Equipped with integral COFDM modulation, the SOLO4 transmitter is ideal for establishing rugged wireless video links in all environments including mobile and urban environments. Offering several user selectable modes that trade off image quality against range, the SOLO4 transmitter is ideal for all mission types. The SOLO4 Bodywire includes RF up-conversion and PA circuitry to make a complete single board transmitter. SOLO4 Bodywire is supplied in a simple light weight case with an attached break out cable.

Security is ensured with optional in AES128/256 Encryption.

The SOLO4 Bodywire transmitter will transmit images in a non line of sight environment up to 750m depending on mode and frequency; further range can be achieved with the booster PA.

### IMPORTANT NOTE

The SOLO4 and SOLO2 product range has been specifically designed for government security and law enforcement users, the equipment will tune across frequencies that are only available to licensed government users. Non-government users should employ the equipment restricted to the license exempt bands only typically 1.389 to 1.399GHz, 2.400 to 2.483GHz and 5.725 to 5.875GHz, or in bands specified by the appropriate authorities.

### 1.1 Warranty Cover

domo offers a 12 month standard product warranty. During this period, should the customer encounter a fault with the equipment we recommend the following course of action:

- Check the support section of the website for information on that product and any software/firmware upgrades. If fault persists;
- Call our support line and report the fault. If fault persists and you are informed to return the product please obtain an RMA number from the domo support department, and ship the equipment with the RMA number displayed and a description of the fault. Please email the support section the airway bill/consignment number for tracking purposes.
- If you have extended warranty provisions then domo will send an immediate advance replacement to you. Under most circumstances this must be returned once the fault item is repaired.

Depending on the nature of the fault domo endeavor to repair the equipment and return it to the customer within 14 days of the item arriving at our workshops.

Obviously it is impossible to cater for all types of faults and to manage 100% replacement part availability, and delays are sometimes inevitable. This is why domo recommend that its customers take out an extended warranty (which includes advanced replacement of faulty items), and/or hold a basic level of spare parts, which can be held by domo on the customer's behalf.

Please contact domo for details of packages that can be tailored to meet your individual needs, whether they are service availability, technical training, local geographic support or dedicated spares holdings.

## 1.1 Safe Operating Procedures

- Ensure that the power supply arrangements are adequate to meet the stated requirements of the SOL4MTX 'Bodywire' transmitter.
- Operate within the environmental limits specified for the product.
- Do not subject the indoor equipment to splashing or dripping liquids.
- Only authorized, trained personnel should open the product. There are no functions that required the User to gain access to the interior of the product.

## 1.2 EMC / Safety and Radio Approvals

The equipment has been designed to meet and has been tested against the following harmonized EMC and safety standards:

- EN 301 489-1 & EN 301 489-5
- EN 61000-3-2:2000
- EN 61000-3-3:1995
- EN 55022:1998, Class B
- EN 61000-4-2:1995
- EN 61000-4-3:1996
- EN 61000-4-4:1995
- EN 61000-4-5:1995
- EN 61000-4-6:1996
- EN 61000-4-11:1994
- EN 60950:2000
- The license exempt equipment (SOL2TX-138139, SOL2TX-240248, SOL4TX-138139 and SOL4TX-240248) meets the following radio approvals.
- EN 302 064-1

### 1.3 CE marking

The CE mark is affixed to all SOLO4 and SOLO2 products, and the CE Declaration of Conformity, as well as the technical file are available on request.

### 1.4 Caution

The Bodywire Transmitter if coupled with a SOLOAMP500mw will dissipate increased power, resulting in elevated case temperatures (55 Degrees C). Care should be taken to ensure the device is properly mounted and cooled where appropriate. Cobham supply a heat shield which it is recommended remains mounted to the unit. In all cases of body worn deployment the appropriate risk assessment should be completed prior to deployment to prevent any heat associated injury.

### 1.5 FCC Subpart 15A/RSS-Gen/RSS-102:

*This device complies with part 15 of the FCC Rules and Industry Canada RSS standard(s). Operation is subject to the following two conditions:*

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received,*
- (2) including interference that may cause undesired operation.*

*Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.*

*Changes or modifications not expressly approved by Cobham could void the user's authority to operate the equipment.*

*NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:*

- Reorient or relocate the receiving antenna.*
- Increase the separation between the equipment and receiver.*
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- Consult the dealer or an experienced radio/TV technician for help.*



*This Class B digital apparatus complies with Canadian ICES-003.*

*Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.*

- The FCC require that the installer is provided with adequate information with the module which explain the labelling requirements and any operating requirements applicable to the transmitter and to ensure compliance with RF Exposure requirements.

For **mobile** usage, the following or similar statement is recommended in respect of RF Exposure:

To satisfy RF expose requirements, this device and its antenna must operate with a separation distance of a least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

For labelling guidance, the manual should state that the host product must include a label which states "Includes FCC ID: XRFSOLOMTX, Includes IC ID: 8638A-SOLOMTX"

- Antenna gain information shall also be provided in the user guide for the module, i.e. if the RF Exposure calculations were carried out using a 4dBi gain:

This device has been designed to operate with an antenna having a maximum gain of 4 dBi.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen than the equivalent isotropic radiated power (EIRP) is not more than the required for successful communication.

## Getting Started and Basic Operation

### 1.1 Which Model do I have?

Each unit in the domo SOLO4 and SOLO2 product range is marked with two panels.

- Product Code Panel. Give product code and manufacturers information.
- CE and Serial Number Panel. Gives CE mark and product serial number.

<b>domo</b> SOL4MTX-200250 SN 123456 Made in the UK    CE
---

The domo product code can be referenced in the table below.

Product Code	Product	Accompanying items
SOL4MTX-100150 (1.0 to 1.5GHz)	100mW Digital Video transmitter LBand	Cables: Multi-way break out cable. 12V DC cable 3m Blank D-type mating connector for user integration.
SOL4MTX-200250 (2.0 to 2.5GHz)	100mW Digital Video transmitter SBand	Cables: Multi-way break out cable. 12V DC cable 3m Blank D-type mating connector for user integration.
SOL4MTX-168250 (1.68 to 2.5GHz)	100mW Digital Video transmitter L and S Band	Cables: Multi-way break out cable. 12V DC cable 3m Blank D-type mating connector for user integration.
SOL4MTX-450500 (4.5 to 5.0GHz)	100mW Digital Video transmitter C-Band	Cables: Multi-way break out cable. 12V DC cable 3m

Blank D-type mating connector for user integration.

## Controls

The SOL4MTX has no local control panel or indicators. The SOL4MTX is controlled by connecting a local PC and using the domo PC control GUI application, or alternatively by using the separate domo 'Field Gun' controller.

The use of the domo PC GUI application is described fully in section 3 'Advanced Operation'.

### The domo 'Field Gun' controller

The domo 'Field Gun' controller is an in-line controller designed specifically for field use. The controller can be connected directly to the Bodywire transmitter, and used to set frequency, encryption key and other commonly configured items. The 'Field Gun' controller is due for release in April 2009. The use of the 'Field Gun' controller will be explained in more detail at the time of release.



## 1.2 Getting Started with the Transmitter

### Cables and Connections

This section describes how to connect the following domo model numbers.

- SOL4MTX-100150 (1.00 to 1.5GHz)
- SOL4MTX-200250 (2.00 to 2.50GHz)

The pictures below shows the domo SOLO4 Bodywire transmitter.



The domo transmitter is supplied with the following cables.

- CA0317 Break out Cable, the drawing of this cable is shown below.
- CA0002 lemo to banana plug 12V cable

There are 4 ways to connect to the SOLO4 Bodywire transmitter, depending on the application.

**Option 1.** Use the CA0317 Break Out Cable provided.

**Option 2.** Use the domo 'Bodywire Harness' for true body worn applications.

**Option 3.** Use the unsoldered 15 way Dtype connector supplied to make a dedicated user cable.

**Option 4.** Cut off the 15 way DType Male connector, and wire direct to the cables.


Each option is explained in detail below.

### Option 1. Using the CA0317 Break Out Cable

The CA0317 cable is terminated with a 15 way DType female connector and this plugs directly to the 15 way DType Male connector on the SOLO4 Bodywire transmitter. A drawing of the CA0317 is shown below.

The CA0317 cable provides a break out to standard interface connectors.

- Video BNC Male
- Power 4 way OB Lemo (connect to the CA0002 cable for easy connection to DC source).
- Audio (Left and right) Phono Male
- Control and Data interfaces on DType Female.



## Option 2. Using the Domo Bodywire Harness

For true bodyworn applications, domo can supply a domo Bodywire Harness cable for minimal cabling. The harness integrates, a compact battery holder, camera power and camera interface, microphone interface.

The domo Harness is due for release in early 2009 and will have the following features.

- Regulated camera supply
- Video input
- Audio input
- Battery holder, with ON/OFF switch

## Option 3. User constructed cable

The SOLO4 Bodywire is supplied with a black unsoldered 15way female DType connector. This allows users to simply create their own cable for easy integration. Users should make the solder connections shown below for integration with the SOLO4 Bodywire transmitter.

Signal	HD15 Pin
Vin	1
Vin	6
GND	2
GND	7
Amp control	10
Video	9
Vid GND	8
Audio 1	3
Audio 2	5
Aud GND	4
Control TX	11
Control RX	12
Data TX	15
Data RX	14
RS232 GND	13


## Option 4. Cutting off the connector and wiring direct to the cable

For very small integrations, or integrations where weight is a premium, it is possible to cut away the 15 way DType connector and wire direct to the cables. Domo would prefer this did not happen, but understands that it may be necessary. If this is the preferred integration route, then users should contact domo for technical advise, and for confirmation of warranty implications.

This operation will require users to cut the wires to the transmitter, peeling back the wire sheath to reveal the inner core. Many of the wires are multi-cored. The core of of the wires is coloured to help with

identification. However 2 of the 5 wires are identical in which case it is position information that is used to identify them.

Looking at the five wires as they enter the rubber grommet on the base of the unit you will see.



Signal	DType HD15 Pin	Inner Body Colour of Wire	Core Wire Colour	Position
Vin	1	Black	Black	Middle Wire
Vin	6	Black	Red	Middle Wire
GND	2	Black	Brown	Middle Wire
GND	7	Black	Orange	Middle Wire
Amp control	10	Black	Green	Middle Wire
Video	9	Blue Coax Inner	Blue Coax Inner	
Vid GND	8	Blue Coax Inner	Silver Coax Shield	
Audio 1	3	Red Coax Inner	Red Coax Inner	
Audio 2	5	Green Coax Inner	Green Coax Inner	
Aud GND	4	Red and Green Coax Inner	Red and Green Silver Coax Shield	
Control TX	11	Black	Black	Outer Wire
Control RX	12	Black	Brown	Outer Wire
Data TX	15	Black	Green	Outer Wire
Data RX	14	Black	Orange	Outer Wire
RS232 GND	13	Black	Red	Outer Wire



## Video and Audio Source

Depending of which of the 4 connection options are employed, video and audio sources with the following characteristics should be employed.

Connector	Signal
Video Input	75 ohm composite video source, PAL or NTSC software selectable
Audio Input	Line / Microphone level audio, switchable. Line level -2dBu clip level low impedance source (< 600 ohm) Microphone level 12, 24, 36 and 48dB preamp stages software switchable

Microphone power is provided on the audio connectors at approximately 3V (suitable for Electret microphones)

Typically the video source will be a small colour or black and white CCD camera.

Typically the audio source will be an Electret microphone.

## DC Power Source

The transmitter unit can be powered from a nominal 12V DC supply or an AC to DC adapted supply.

The connected 12V DC input should have the following characteristics.

- Input Voltage Range – 5.9V to 16V, reverse voltage protected.
- Current draw - 0.35 to 0.28A at 12V (mode dependant)

domo can supply optional AC to DC converter blocks to power the transmitter unit, the domo part number is **PSU12**

## Antennas

domo transmitters are supplied as standard without antennas. An antenna must be connected for normal operation. The transmitter unit is supplied with a panel mounted SMA connector which carries the RF output. The antenna should be connected by screwing it onto the SMA, but care should be taken to not over tighten the connector.

The transmitter has the following RF output characteristics.

RF Spec	Model Number ending - 100150	Model Number ending - 200250
Output Frequency	1.0 to 1.5GHz	2.0 to 2.5GHz
Output Bandwidth	2.5MHz	2.5MHz
Output Power	100mW (nominal)	100mW (nominal)
Output Impedance	50 ohm	50 ohm

Note. It is recommended that the antennas be connected directly to the transmitter unit. The use of RF cables at this point will degrade the performance of the system.

The optimum choice of antenna will vary according to application. The following table gives some suggestions for suitable transmit antennas with the associated domo part number.

Application	Antenna model number
Overt mobile body worn application	1.00 to 1.40GHz - ANT4L 2.28 to 2.50GHz - ANT4S
Covert body worn applications	Domo can supply covert patch antennas, and split front back patch antennas. Contact domo for advise.
Mobile vehicle application	1.00 to 1.40GHz – ANT4L 2.28 to 2.50GHz - ANT4S 4.80 to 5.15GHz – ANT6C
Long range point to point link	1.00 to 1.40GHz – ANT12L 2.28 to 2.50GHz – ANT12S

Note. When using antenna types ANT4L, ANT4S, ANT6C, ANT12L and ANT12S with domo transmitters SMA to TNC adaptor connectors will be needed.

Other antennas for more specialist applications, such as aircraft use or covert surveillance use are available on request from domo.

## Control Cable

The control cable is used for connecting the transmitter unit to a PC when using the domo PC control application. The PC control application is described in more detail the Advanced Operation section of this handbook.


## Installation Notes

The domo SOLO4 body wire transmitter has been designed specifically for body worn applications; however it is a general-purpose wireless video transmitter and can be used in many applications including the following.

- Body worn portable applications.
- Integration in covert hides.
- Integration in Vehicles.

This section gives guidelines for how to install the transmitter in the above applications.

The drawing below shows the precise dimensions of the SOLO4 Body worn transmitter, and in particular the position of the mounting holes.



### Integration in Covert Hides

Users should be aware of the following issues when integrating the equipment in any covert hide.

- 1) Ventilation: The equipment does not require forced air cooling, but ideally should be mounted to a metal surface for cooling effect. Ideally the low power 50mW mode should be employed to reduce the consumed power.
- 2) Long cable runs from the RF output to the antenna should be avoided, for maximum range.
- 3) The antenna should be mounted vertically ideally, and exposed to free space.
- 4) The equipment should be supplied with a clean supply in the range 5.9 to 16V and capable of 0.4A maximum.
- 5) The equipment should not be exposed for any long periods to any form of liquids.

### Integration in Vehicles

Users should be aware of the following issues when integrating the equipment into vehicles.

- 1) Ventilation: The equipment does not require forced air cooling, but ideally should be mounted to a metal surface for cooling effect. Ideally the low power 50mW mode should be employed to reduce the consumed power.
- 2) For the additional range required in vehicle applications, the use of amplifiers should be considered. domo offers a range of power amplifiers. Interconnection between the transmitter and any power amplifier should be kept as short as possible, but where this is not possible, special attention should be taken to use only low loss cables. An appropriate cable might be RG213C/U. It is essential to minimise the distance between the amplifier and the antenna.
- 3) Long cable runs from the RF output to the antenna should be avoided, for maximum range.

- 4) The antenna should be mounted vertically ideally, and exposed to free space.
- 5) The equipment should be supplied with a clean supply in the range 5.9 to 16V and capable of 0.4A maximum. Care should be taken to avoid direct supply from the vehicle 12V which can be very noisy. Power conversion will be required for 24V vehicles.
- 6) The video input can be connected across long video cable lengths so remotely mounted cameras should pose no problem.
- 7) The SOLO4 Bodywire transmitter has an IP66 rating, however equipment should not be exposed for any long periods to any form of liquids.

### **Overt Body Worn Applications**

Body worn applications will either be covert or overt and this will dictate the style of antennas and mounting of cameras. For overt applications domo can supply a harness as shown below (domo part number **ACCBCH**)



With all body worn systems the antenna should be selected to transmit power away from body and domo recommends the use of the domo body worn antenna (part numbers **ANTBCL** and **ANTBCS**).

Experimentation has shown that unlike traditional analogue systems, front and rear antennas are not normally required. The nature of COFDM and its immunity to reflections will ensure that the signal normally bounces back to the receive site even when the operators body is between the transmit and receive antenna.

The SOLO4 Bodywire transmitter has been successfully tested with a wide variety of standard and pinhole cameras. domo can supply cameras on request.

The domo transmitter will become warm to the touch after prolonged operation, and so insulation between the operators' body and the transmitter unit should be considered.

The SOLO4 Bodywire transmitter has an IP66 rating, however equipment should not be exposed for any long periods to any form of liquids.

### **Covert Body Worn Applications**

For covert body worn applications domo recommends the use of its body worn harness cable (available early 2009). This cable integrates to a variety of cameras, and microphones. The cable enables camera power, provides ON/OFF capability and battery interfacing.

In covert applications, ultra slim patch antennas can be used, for best coverage ideally split front back patch assemblies. domo can supply both single and dual split patches in ultra slim configurations, please contact domo for details.



## Powering on the System

All external connection to the SOLO4 Bodywire transmitter should be made, as described in the previous sections, before proceeding to power on the system.

Users should ensure that a suitable receiver is available and configured to the appropriate frequency before proceeding with the remainder of this chapter (see handbook for the SOLO4 receiver or SOLO4 MicroVue)

### Apply power to the transmitter

Power the transmitter directly from a 12V source, or from a connected battery, allow 5 seconds for the transmitter to boot. Once the transmitter has booted lock will occur at the receiver.

There are no external indicators on the transmitter.

If lock does not occur at the receiver, the following possibilities should be considered.

### RF Lock was not achieved at the Receiver

If power has been applied to the transmitter, but no RF lock has been achieved at the receiver, then there are several possibilities, however most of these possibilities require the connection of either the PC GUI controller (see section on Advanced Operation), or the Field Gun (see Field Gun section) to diagnose.

- The frequency of the receiver and transmitter are different. Use PC Controller or Field Gun to change frequency.
- The RF Output of the transmitter is OFF. Use PC Controller or Field Gun to set the RF output ON.
- The Modulation styles are set differently between the transmitter and receiver. Use PC Controller or Field Gun to set modulation styles to be the same.
- Check connections to the antennas and down converters at each end.

### Diagnostic On Screen Display

The SOLO2/SOLO4 Receiver is equipped with a diagnostic on screen display. This facility will 'burn' diagnostic data onto the video output for test and set-up purposes. Pressing the RF button will enable this facility and a diagnostic screen will appear in the video as shown below.



The displayed diagnostic data includes a spectrum display, signal to noise data, input power level and frequency. The received spectrum display is useful when checking for interference signals, the SNR indicated signal quality. For more information on use of this facility a domo training course is recommended.

## Using the OSD as a Set-up / Diagnostic Tool

The On Screen Display (OSD) is an extremely useful tool for system set-up and diagnostic.

When setting a domo system up the OSD should be used in the following way.

### **Check Channel is Clear**

With the transmitter OFF, check that the channel is empty of interference signals, this is confirmed by ensuring that the reported power in the channel is at  $-99\text{dBm}$  and that the spectrum is shown as a rounded dome with no obvious spikes or tones.

### **Check Quality of Link**

Switch on the transmitter and confirm that SNR is 6 or greater and that power level is at least  $-92\text{dBm}$  or greater. This represents approximately a 5dB margin. Failure of the link will occur when the power level reaches  $-97\text{dBm}$  or the SNR reaches 2dBm

## 1.1 Domo Batteries and Battery Charging

Although domo equipment can be powered directly from user 12V batteries, domo also supplies a rechargeable battery pack. The following domo battery items are described in this section.

SOLBAT: 7.2V 4AH rechargeable NiMH battery pack.

SOLBCH: Battery Charger

SOLBCC: Adaptor cable that allows SOLBAT to connect to SOLO4 Bodywire



## Using the SOLBAT

The domo SOLBAT is used for powering domo transmitters.



The domo SOLOBAT can not be connected directly to the Bodywire Transmitter, instead it must be connected using the SOLBCC adaptor cable. The SOLBCC adaptor cable provides an interface between the 4 pin DC In Lemo on the CA0317 transmitter break out cable and the 6 pin DC Out Lemo on the battery. The cable is shown below.



When connected a fully charged SOLBAT will power the transmitter for more than 4 hours.

## Charging the SOLBAT

The SOLBAT can be recharged by connecting it to the SOLBCH battery charger. The SOLBAT battery can be connected directly to the SOLBCH battery charger, the interface cable is not required. When connected the SOLBAT indicator LED has the following meaning.

LED Yellow:	Battery not connected.
LED Orange:	Battery fast charging.
LED Green / Yellow flash:	Battery 'Top Off' final charging
LED Green:	Charging Complete / trickle charging
LED Orange / Green flash:	Error

Approximately 2 hours should be allowed for a full charge of the SOLBAT battery.

## 1.2 Using the Clip On 1W Amplifier

Additional range can be achieved by connecting the SOLAMP1W clip on amplifier to the domo Bodywire transmitter. However unlike the SOLBTX, SOL4TX and SOL2TX, the bodywire transmitter does not mount directly to the SOLAMP1W, they must be used separately.

### Connections

This section describes how to connect the following model numbers.

- SOLAMP1W



The domo SOLAMP1W is supplied with the following cables:

- RF Cable (SMA to SMA semi-rigid bridge cable)
- DC Power Cable (with Control breakout)
- Lemo to Dtype control cable

### Amplifier Connection

The domo SOLAMP1W is designed to mount directly onto the SOL4/SOL2 transmitter. It will not mount directly to the SOLO4 Bodywire, to achieve connection following steps should be taken.

1. Connect the RF output of the transmitter (SMA) to the RF input of the amplifier (SMA) using the short semi rigid SMA cable provided. The SOLAMP is designed to work directly with the SOL2/SOL4 transmitter.
2. Domo can provide a 'special cable' to connect into the power lemo of the PA, that provides power to the PA and permanently enables the PA.

## Antennas

Domo SOLAMP is supplied without antennas as standard. It is good practice to ensure that an antenna is always connected before powering the device. Prolonged operation without an antenna is not recommended. The antenna should be connected by screwing it to the TNC Type output connector with adapters as required, but care should be taken not to over-tighten.

Note: It is recommended that where possible antennas should be connected directly to the SOLAMP. Use of cables will degrade performance.

## Installation Notes

The domo SOLAMP has been designed specifically for vehicle applications, however it is a general-purpose amplifier and can be used in many applications including the following.

- Vehicle applications
- Aircraft applications
- Long Range fixed links

Interconnection between the SOLAMP transmitter and the antenna, or any intermediate optional power amplifier should be kept as short as possible. Special attention should be taken to use only low loss cables. An appropriate cable might be RG213C/U. It is essential to minimise the distance between any amplifier and the antenna.

The SOLAMP is equipped with a self-regulating 12V input that can be connected directly to the vehicle battery. Power conversion will be required for 24V vehicles or 28V aircraft systems.

The SOLAMP is splash resistant, but is NOT waterproof, so it should not be exposed to moisture for prolonged periods. The SOLAMP is self-cooling; however it should be mounted in a ventilated environment.

### 1.3 Using the booster 5W Amp

Additional range can be achieved by connecting the AMP5W-xxxxxx booster amplifier to the domo SOLO4 Bodywire transmitter.

#### Connections

This section describes how to connect the following model numbers.

- SOLAMP5W-115140
- SOLAMP5W-225255



The domo SOLAMP-xxxxxx is supplied with the following cables:

- RF Cable

- DC Power Cable

## RF Connection

The domo AMP5W has the following input power requirements.

AMP5W-115140: Input Power 100mW or 20dBm

AMP5W-225255: Input Power 100mW or 20dBm

Therefore care must be taken when connecting the AMP5W-225255 product to the SOLO4 Bodywire transmitter.

Ideally when balancing the 5W Amplifier and domo transmitter a power meter should be employed, this will give best results, because cable losses can be factored.

Note the 5W power is illegal in many frequency bands and should not be used by unlicensed users. If customers are concerned on this issue, they should contact domo for advise.

If customers are concerned about balancing the input power when connecting 5W amplifiers, then they should contact domo directly.

## DC Power

Push the connector on the DC power cable into the socket labelled DC, taking care to align the connectors. Connect the banana connectors on the other end of the cable to a suitable DC source.

The 12V DC input has the following characteristics.

- Input Voltage Range – 12V +/- 1V, reverse voltage protected.
- Current Draw 4A SOLAMP5W-225255, 2.5A SOLAMP5W-115140

## Antennas

domo 5W Amp is supplied without antennas as standard. It is good practice to ensure that an antenna is always connected before powering the device. Prolonged operation without an antenna is not recommended. The antenna should be connected by screwing it to the N Type output connector with adapters as required, but care should be taken not to over-tighten.

Note: It is recommended that where possible antennas should be connected directly to the 5W Amp. Use of cables will degrade performance.

## Installation Notes

The domo 5W AMP has been designed specifically for vehicle applications, however it is a general-purpose amplifier and can be used in many applications including the following.

- Vehicle applications
- Aircraft applications
- Long Range fixed links

Interconnection between the 5W AMP transmitter and the antenna, or any intermediate optional power amplifier should be kept as short as possible. Special attention should be taken to use only low loss cables. An appropriate cable might be RG213C/U. It is essential to minimise the distance between any amplifier and the antenna.

The 5W AMP is equipped with a self-regulating 12V input that can be connected directly to the vehicle battery. Power conversion will be required for 24V vehicles or 28V aircraft systems.

The 5W AMP is splash resistant, but is NOT waterproof, so it should not be exposed to moisture for prolonged periods. The 5W AMP is not self-cooling so should be connected to a metal surface; if this is not possible the heat sink should be fitted and the unit should be deployed in a ventilated environment.

### 1.4 Using the booster 500mW Amp

Additional range can be achieved by connecting the SOLAMP500MW-200250 booster amplifier to the domo SOLO4 Bodywire transmitter.



The SOLAMP500mW-200250 is a 2 to 2.5GHz 500mW booster power amplifier designed specifically to mate with the domo SOLMTX Micro transmitter. The convenient small size and low power consumption make it the ideal booster PA for applications such as body worn where space is a premium, but additional range may be required.

Output Power – 500mW (27dBm)

Input Power – 100mW (20dBm)

Gain – 7dB

Frequency 2 – 2.5GHz

Input RF Connector – SMA

Output RF Connector – SMA

Input Voltage – 11-14V

Consumed Power – 4W

Temperature-10 to +50 deg C

Dimensions – L89mm, W 49mm, H 11mm

Weight Base Unit – 100g (target)



### 1.1 SOLO System PC Controller Application Software

Advanced control of the SOLO4 Bodywire system is available by using PC control applications.

Typically users may want to customize the default configurations to control settings such as frequency, scrambling keys, modulation parameters, and video resolution.

- The SOLO4 Bodywire transmitter products are controlled by the `solo_tx_ctrl.exe` application available on the CD delivered with the product.

Note that exact file names may change as software version information is a part of `demo` file names.

A PC is required with two RS232 Serial COM ports to control both a transmitter and receiver simultaneously. Where changes are to be made to either a transmitter, or a receiver, at different times, a PC with a single RS232 Serial COM port can be used.

Installation of the two control programs is as simple as copying them from the CD to a suitable location on the PC. No install shield routine is launched. Note that the controllers generate their own log and initialisation files, so it is best to create a dedicated directory for these applications, perhaps with links to the applications from the desktop of the PC.

Use the supplied cables to connect the chosen COM port(s) of the PC to unit(s) to be configured.

Launch each application in turn by double clicking or using the run command.

Connection with a SOLO product should be automatic, but the user can force selection of the correct COM port using the drop down, followed by the "Connect" button.

Errors such as the following may appear during the connection process if the PC is unable to automatically ascertain which unit is connected to which COM port.

- Error attempting to read invalid address
- Error has occurred during polling, polling has been disabled



For both controllers, changes can be made to the unit configuration using the drop down and data entry fields.


Changes are only applied to the unit when the “Apply” button is clicked.

Current values, as running in the unit, can be read using the “Refresh” button.

Parameters that are status information only appear in greyed in the application.

Further engineering and configuration controls can be found within the “Options” and “File” drop down menus in the application title bars.

## 1.2 Transmitter Control Application



The 'Advanced' button allows the user to navigate to the controller page which exposes all available Transmitter settings.

### Output Frequency (MHz)

The transmit frequency can be changed by entering the new desired frequency in this field. Values outside the range supported by a particular transmitter type will be rounded to the highest or lowest supported frequency as appropriate.

The transmit frequency can be set in step sizes of 250kHz.

## Bandwidth Mode

The Bandwidth Mode switches the unit between either narrowband (2.5MHz or 1.25MHz channel bandwidths) or DVB-T 8MHz bandwidth. To select 6MHz and 7MHz DVB-T modes the user must first click on 'Advanced' to enter the Advanced setting page.

## Audio

Turns 'On' or 'Off' a basic audio setting – the audio settings are optimised considering the bit-rate of the selected Transmit mode. The user can set their own audio settings using the 'Advanced' page, if required.

## Default Transmit Mode

In Narrowband the user has the following pre-defined modes available from the main window. Note that the Ultra Long Range Mode is only available to users who have purchased the SOLO4TXUP option (1.25MHz and MPEG-4 modes). The user can of course define their own specific FEC, bandwidth and modulation requirements from the 'Advanced' page.

Ultra Long Range:	1.25MHz QPSK FEC 1/3 (optional)
Long Range:	2.5MHz QPSK FEC 1/3
Medium Range:	2.5MHz QPSK FEC 2/3
Short Range:	2.5MHz 16QAM FEC 2/3

In DVB-T the available modes are

QPSK  $\frac{1}{2}$  FEC 8MHz 1/32 Guard Interval

QPSK  $\frac{3}{4}$  FEC 8MHz 1/32 Guard Interval

16QAM  $\frac{1}{2}$  FEC 8MHz 1/32 Guard Interval

## Scrambling

If the AES scrambling option has been purchased for the SOLO4 Bodywire system in use, then it is possible to encrypt the link. Scrambling must be enabled at the transmitter by selecting either AES128 or AES 256 in the scrambling field. The actual scrambling key can then be entered by clicking on the yellow 'key' icon.

## File Options


**Load Config** – used for loading a single configuration data from text file.

**Save Config** - used for saving configuration data to text file.

**Load Config Set** – used for loading all 8 configurations from a text file

**Save Config Set** - used for saving all 8 configurations to a text file

## Advanced TX Controller Window



### Output Frequency (MHz)

The transmit frequency can be changed by entering the new desired frequency in this field. Values outside the range supported by a particular transmitter type will be rounded to the highest of lowest supported frequency as appropriate.

The transmit frequency can be set in step sizes of 250kHz.

### Modulation Bandwidth

For the SOLO2 transmitter products, the modulation bandwidths 8, 7 or 6MHz can be selected.

For the SOLO4 transmitter products, the modulation bandwidths 8, 7, 6 or 2.5MHz can be selected. If the Ultra Narrow band upgrade has been purchased the 1.25MHz will also be available to select.

The normal mode of operation is 2.5MHz.

### Modulation Output

This control is used to turn on and off the RF output. After a configuration change, the output always reverts to OFF.

### Narrow Band FEC

This option applies to SOLO4 transmitters only. The default FEC is 2/3, however improved range operation can be achieved by selecting FEC 1/3. FEC 1/3 will improve signal range by 3dB. However FEC 1/3 reduces link capacity to 1.2Mb/s therefore reducing picture quality.

FEC	Link Bitrate	Sensitivity
2/3	2.4Mb/s	-99dBm
1/3	1.2Mb/s	-102dBm

### Narrow Band Guard Interval

This option applies to SOLO4 transmitters only. The Guard Interval defaults to 1/16. Interval 1/8 is also available for very long range (aircraft downlinks) applications.

### Narrow Band Modulation

This option applies to SOLO4 transmitters only. The COFDM mode can be changed between QPSK and 16QAM. QPSK is the default mode and will give the strongest most rugged RF link performance. Selecting 16QAM reduces the link performance by 5dB but improves the link data throughput, giving significantly better video quality.

Note: The terminology DVB-T refers to the 8,7,6MHz wide bandwidth modulation employed in the SOLO2 products. The SOLO4 product is also capable of DVB-T, but this mode is not recommended for normal operation

### DVB-T Service Name

Applicable in DVB-T mode only, defaults to Unit 1. This should not be changed in normal operation

### DVB-T FEC

Applicable in DVB-T mode only, the default FEC is 1/2. Other FEC rates will all reduce the range of the product, but will improve image quality and capacity of the link.

### DVB-T Guard Interval

Applicable in DVB-T mode only. The Guard Interval defaults to 1/32. Other guard intervals such as 1/16 or 1/8 are available for very long range (aircraft downlinks) applications.

### DVB-T Modulation

Applicable in DVB-T mode only, the COFDM mode can be changed between QPSK, 16QAM and 64QAM. QPSK is the default mode and will give the strongest most rugged RF link performance. Selecting 16QAM reduces the link performance by 5dB but improves the link data throughput, giving significantly better video quality.

## Output Attenuation

This control can be used to make minor adjustments to the output power level, but in normal operation should be disregarded.

## Video Input

This control is used to select the composite video input standard. Options are PAL, and NTSC both with and without 7.5 IRE pedestal.

The licensed SDI digital video input can also be selected.

## MPEG Mode

The default encoding mode is MPEG2, however for SOLO4 products if the Ultra Narrow Band upgrade has been purchased, then MPEG4 will also be available. It is recommended that MPEG4 be employed when the unit is operating at low bitrates (2.5MHz bandwidth FEC1/3 or 1.25MHz bandwidth FEC1/3).

## MPEG2 GOP Length

By default MPEG2 GOP length is set to a low delay stripe refresh mode. This option allows the user to set the GOP length for a standard GOP structure at the expense of an additional delay.

## MPEG4 Encoding Mode

This option is only available on SOLO4 products installed with the Ultra Narrow Band Upgrade. This defaults to low delay interlace. Other modes are available but advice should be sought from domo before selection.

## MPEG4 Frame Rate

This option is only available on SOLO4 products installed with the Ultra Narrow Band Upgrade. This option allows the user to select lower frame rate encoding (1/2 frame rate, 1/4, 1/8 etc) It is recommended that MPEG4 reduced frame rates be employed when the unit is operating at low bitrates (1.25MHz bandwidth FEC1/3).

## Video Bitrate

This control can be used to set the video bitrate within the constraints of capacity available in the channel, but only when "Chaining Input" is set to ON.

When the Manual radio button is enabled, the user can manually set a video bitrate upto the maximum value. When manual bitrate is selected, the user is in control of the video bitrate, this can be usefull when configuring chaining systems.

## Horizontal resolution

The video coding resolution can be selected from 704, 528, 480 and 352 pixels. Changing the horizontal resolution to lower values will make the coded picture softer.

Care should be taken to match the horizontal resolution to the resolution of the camera connected to the transmitter; this will give best image results.

## Video Profile

This allows the user to select between the default 4:2:0 profile and the ultra high quality 4:2:2 profile (only of interest to Broadcast customers). Note 4:2:2 is a licensed feature.

## Audio Encoder

The Audio can be turned on and off with this control. Audio is OFF by default, but there are several audio modes that vary from very high quality to speech grade that can be selected with this control. Enabling audio will degrade the video quality, because some of the available data capacity is diverted away from video to audio. Selecting high fidelity audio modes will degrade the video quality more than lower fidelity audio modes. The Audio encoder can also be switched to 32 kHz and 48 kHz MPEG Layer 1/2 modes.

Note: The Solo4 receiver only supports 48 kHz sampling in MPEG Audio mode and bit-rates in the range 192 to 448kbits/s.

## Audio Input Level

This control is used to define the audio gain to be applied to the audio input signal. 0dB is used for line level audio and various options up to 48dB of gain can be applied for microphone inputs.

## Unit Name

This field allows the user to enter an identifier for the service that they wish to transmit. This must match that selected at the receiver for the service to be decoded. The unit name can be constructed of any eight ASCII characters.

## Sleep Mode

This control allows the unit to be forced into a Sleep Mode where main functions are disabled, and the power consumption is significantly reduced.

## Data

With this ON / OFF control the user can select whether the transmitter passes serial RS232 data across the RF link to the receiver.

## Data Baud Rate

This field is used to select the baud rate of any RS232 serial data component to be passed from the transmitter to the receiver across the RF link.

## Chaining Input

This control is not used in current SOLO products.

## Chain Number

This control is not used in current SOLO products.

## Current Config

This field reports the last loaded configuration number. Note that for the SOLO transmitter, changes applied after the configuration has been loaded are saved immediately into the current configuration.

## Scrambling

If the AES scrambling option has been purchased for the SOLO2 or SOLO4 system in use, then it is possible to encrypt the link. Scrambling must be enabled at the transmitter by selecting either AES128 or AES 256 in the scrambling field. At this point the user will need to ensure that the correct key is in use and this is done by using **Options / Write AES Key**.

The key is a 128bit key for AES128 and a 256bit key for AES256 and is entered as either 32 or 64 ASCII hexadecimal characters (0..F).

## Video Locked (Status Only)

This status information indicated whether the transmitter is successfully locked to the incoming composite video signal. Unlocked status may indicate cabling faults, or poor quality incoming video feeds to the unit.

## Software Version (Status Only)

This status information describes the version of the software running the SOLO transmitter product.

## FPGA Version (Status Only)

This information is for **domo** engineering use only.



## Serial Number (Status Only)

This status information is the electronic serial number of the transmitter PCB. This number can be exchanged with **domo** to purchase extra licensable features, such as upgrades to support AES encryption.

## Chaining (Status Only)

This field reports the status of the chaining input to the SOLO transmitter, and is not active in current units.

## Options

**Engineering** – provides access to further diagnostic and calibration features. The **Diagnostic** and **Power calibration** pages must not be altered. The **Advanced Options** under the Engineering menu allow the user to **Change RS232 address**, which can be useful when connecting multiple units together via a multi drop RS485 bus for control purposes. The **Serial control** dialogue box allows the user to change timeouts used during the serial communications between the unit and the controller.

**Enable Polling** – selecting this option makes the control application automatically refresh the data presented to the user every few seconds.

**Polling Options** – selecting this option allows the user to define parameters to be regularly polled.

**Write Encryption Key** – opens a dialogue box for entering an ABS or AES scrambling key, as 32 ASCII hexadecimal characters (0...F)

**Write License Code** – open a further box for entering license codes for the activation of licensable features (e.g. AES scrambling) in the transmitter. Contact **domo** for support in applying new licenses as required.

**Restore Defaults** – restores factory default settings in the transmitter.

## File

**Set Icon Source, Set logo source, Set logo size and Set application title** – allow the user to define a controller branding

**Exit** – exits the SOLO receiver control application

## Fault Finding

Symptom	Suggested Action
No RF Link	Check a suitable transmitter RF source is active, on correct frequency. Ensure Downconverters are connected. Ensure antennas are connected to downconverters. Ensure there is no interfering signal.
Poor link performance	<p>Poor performance of the link can occur for the following reasons.</p> <ul style="list-style-type: none"> <li>Interference. Should an interfering RF signal occur on the same frequency the performance of the link will be affected. Remove the interferer or move to an alternative frequency.</li> <li>Unsuitable antennas, or out of band antennas. See the antenna sections for guidance on antenna selection and use.</li> <li>Reduced transmit power, ensure that the attenuation setting on the transmitter is appropriate for direct output, or for amplifiers connected.</li> <li>Receive antenna positioning, where possible mount the receive antennas away from other objects, unobstructed and as high as possible. Poor alignment of directional antennas.</li> <li>No Diversity operation. Ensure both down converters are operational.</li> </ul>
Blue screen at receiver	<p>Receiver RF LED not lit - see "No RF Link" section</p> <p>Receiver RF LED lit. Check video is enabled at the transmitter. Check correct unit name is selected at the receiver to match the transmitter. Check scrambling keys are matched.</p>
Reduced Image quality	<p>Image quality is affected by the selected horizontal resolution. The image will become progressively softer for each horizontal resolution below the sharpest resolution of 704 pixels. It is advisable to select a horizontal resolution that matches the resolution of the camera.</p> <p>Image quality is also affected by the video bit rate which can be read from the video bit rate field of the SOLO transmitter controller). The standard setting is 2.3Mb/s. However enabling audio, particularly the high quality audio modes, will reduce the video bit rate substantially. Therefore ensure an appropriate audio mode is selected or audio is fully disabled if not required.</p>
No audio	Ensure audio is enabled at the transmitter (disabled by default).

## Connector Pin Outs


### 1.1 Power - 4-pin 0B LEMO Socket (TX and RX)

Pin No	Function
1	12 V
2	12 V
3	GND
4	GND

### 1.2 15Way Lemo DType Cable

Signal	DType HD15 Pin	Inner Body Colour of Wire	Core Wire Colour	Position
Vin	1	Black	Black	Middle Wire
Vin	6	Black	Red	Middle Wire
GND	2	Black	Brown	Middle Wire
GND	7	Black	Orange	Middle Wire
Amp control	10	Black	Green	Middle Wire
Video	9	Blue Coax Inner	Blue Coax Inner	
Vid GND	8	Blue Coax Inner	Silver Coax Shield	
Audio 1	3	Red Coax Inner	Red Coax Inner	
Audio 2	5	Green Coax Inner	Green Coax Inner	
Aud GND	4	Red and Green Coax Inner	Red and Green Silver Coax Shield	
Control TX	11	Black	Black	Outer Wire
Control RX	12	Black	Brown	Outer Wire
Data TX	15	Black	Green	Outer Wire
Data RX	14	Black	Orange	Outer Wire
RS232 GND	13	Black	Red	Outer Wire

### 1.3 CA0317 Break Out Cable



## Control Protocols

The following section describes the control protocol employed on the RS232 link for controlling the SOLO transmitters and receiver equipment.

Connection details are detailed in previous sections.

Note that only features that are licensed for use in the SOLO units can be controlled. The protocols listed here cover all possible features. Attempting to activate an unlicensed feature will simply result in the command being ignored by the SOLO unit.

### 1.1 RS232 Control – General Principles

The physical interface is RS232 but this can be converted to RS 485 with an external adapter where multiple units are controlled over one RS 485 bus.

Normal operation involves sending a packet from the control device (normally a PC) to the device being controlled. If the packet satisfies an address integrity check, then the controlled device will action the command and send a reply.

For compatibility with modems an ASCII style protocol is used.

Ports are set for 8 bits, No parity, 1 stop

### 1.2 Packet Structure Sending (from PC)

ASCII	Value	
STX	02h	Start byte
0-9	30h-39h	4 byte unit address. In range 0-9999
R m misc	20h-7Eh	1 byte command type. <b>r</b> read, <b>w</b> write or
I	20h-7E	1 byte indicator of internal data block
ABC	20h-7Eh	Command –three byte mnemonic
;	3Bh	Separator
PQR	20h-7Eh	Data –Optional, variable length
;	3Bh	Separator
X	20h-7Eh	Sum Check
ETX	03h	End byte

### 1.3 Packet Structure Reply (from controlled device)

ASCII	Value	
STX	02h	Start byte
0-9	30h-39h	4 byte unit address. In range 0-9999
Z	20h-7Eh	Status BYTE
PQR	20h-7Eh	Data –Optional, variable length
;	3Bh	Separator
X	20h-7Eh	Sum Check
ETX	03h	End byte

The Sum check byte is the summation of all bytes in the packet, not including the start and end bytes. Higher order bytes are ignored and the final byte result is modified to prevent ASCII control characters being sent. Bit 7 (highest) is forced high.

Status byte will indicate command performed OK, or indicate an error.

ASCII	Meaning
1	All OK
E	General error, Command could not be actioned

Typically E will be returned if the message is formatted incorrectly (separators in wrong place) or if commands are in upper case, or if commands do not match against the allowed list of commands, or if the checksum is wrong.

Addresses in the range 0001 to 9998 are for general use. Address 0000 is reserved and 9999 is a broadcast address. i.e. any device will reply to this address. Its reply will contain its own specific address.

All data in the transmitter and receiver is stored as one of 5 data types, Double, String, List, Integer or HexInteger. The data type dictates the contents of the data section of the reply.

- List – 1 byte for sending. Value is hexadecimal coded as ASCII. 2 byte reply. Reply represents index into original choice list. e.g. Reply 02 indicates entry 2 in original list.
- Double - variable length. Reply always contains decimal point and 4 decimal places. Can have 1 to 3 digits before decimal.
- Integer - 6byte reply. integer value with stuffed with preceding zeros. e.g. GOP reply 000012 = GOP length 12
- String - Variable length. Reply is string excluding null terminator
- HexInteger – 8byte Hex reply

## 1.4 Transmitter Command List

### Type 'o' messages for Modulation commands

Function	R/W	Block	Command	Data	Type
Set Modulation IF output	r/w	o	out	1 byte 0 OFF 1 COFDM	int
Set Narrow Band Modulation FEC	r/w	o	fec	1 byte 1 = 2/3 2 = 1/3	int
Set Narrow Band Modulation Guard Interval	r/w	o	gua	1 byte 1 = 1/16 2 = 1/8	int
Set Narrow Band COFDM mode	r/w	o	mod	1 byte 0 = QPSK 1 = 16 QAM 2 = BPSK 3 = 8PSK	int
Set Modulation Freq	r/w	o	fre	Set Frequency in MHz, decimal point allowed.	double
Spectrum Inversion	r/w	o	spe	1 byte 0 = Normal 1 = Inverted	int
COFDM Bandwidth	r/w	o	wid	0 = 6MHz 1 = 7MHz 2 = 8MHz 3 = 2.5MHz 4 = 1.25MHz 5 = 625kHz	list
Output level attenuation high	r/w	o	lev	Default level is 0 Value 0 to 32 1dB steps	int
Output High Low switch	r/w	o	hls	0 = low level 1 = high level (default)	int
Output level attenuation low	r/w	o	llv	Default level is 32 Value 0 to 32 0.25dB steps	int
DVB-T FEC	r/w	o	dfe	0 = 1/2 1 = 2/3 2 = 3/4 3 = 5/6 4 = 7/8	int
DVB-T Guard	r/w	o	dgu	0 = 1/32 1 = 1/16 2 = 1/8 3 = 1/4	int
DVB-T mode	r/w	o	dmo	0 = QPSK 1 = 16QAM 2 = 64QAM	int
DVB-T 4K Offset	r/w	o	4ko	0 = none 1 = +4KHz 2 = -4KHz	Int
Range Mode Preset	r/w	o	txm	0 = none selected(default) 1 = short range 2 = medium range 3 = long range 4 = ultra long range 5 = extra long range 1 6 = extra long range 2	int
IQ Control	r/w	o	iqc	For Engineering Use Only	int
IQ Gain	r/w	o	iga	For Engineering Use Only	int

## Type 'z' messages for Scrambling commands

Function	R/W	Block	Command	Data	Type
Scrambling	r/w	z	scr	1 byte 0 = Off 1 = ABS 4 = AES128 6 = AES256 8 = Bcrypt128 10 = Bcrypt256	int
AES Key lower 128	w	z	kez	Encryption key for AES lower 128	Hex string (32 characters)
AES Key upper 128 used in AES 256 only	w	z	kex	Encryption key for AES upper 128	Hex string (32 characters)
ABS key	w	z	key	Encryption key for ABS	Hex string (12 characters)
BISS 1 Clear Session Word	w	z	csw	For use with external modulator	Hex string (12 characters)
BISS E Encrypted Session Word	w	z	esw	For use with external modulator	Hex string (16 characters)
BISS E Injected ID	w	z	iid	For use with external modulator	Hex string (14 characters)

## Type 'c' and 'm' messages for Chaining commands

Function	R/W	Block	Command	Data	Type
Chaining Input	r/w	c	inp	0 = Off 1 = On 2 = Relay	int
Chaining Output	r/w	c	out	0 = Off 1 = On	int
Chaining Loop	r/w	c	hio	0 = Off 1 = output loop to input for external encryption	int
Chaining status – describes if chaining input is active	r	c	sta	0 = Not Active 1 = Active 2 = Overflow	int
Chain Number	r/w	c	cha	0 - 9	int
Transport Stream Switch	r/w	g	osw	Bit 2 Input Switch (0=ASI, 1=Chaining) Bit 3 Output Switch (0=ASI, 1=Chaining) Eg 0 = ASI in and out, 12 = Chaining in and out	int
ASI lock	r	a	loc	0 = no 1 = yes	int
ASI overflow	r	a	ovf	0 = no 1 = yes	int
Auto Muxrate	r/w	m	aut	For Engineering Use Only	int



## Type 'v' and 'e' messages for Video commands

Function	R/W	Block	Command	Data	Type
Video Input	r/w	v	inp	1 byte 0 = Off 2 = PAL 3 = NTSC 4 = NTSC No Pedestal 5 = PAL S-vid 6 = NTSC S-vid 7 = NTSC S-Vid No pedestal 8 = SDI PAL 9 = SDI NTSC	int
Video Locked	r	v	loc	1 byte 0 = No 1 = Yes	int
Video Bitrate (Only applicable when chain in enabled)	r/w	e	vid	Value in Mbps	double
Video Horizontal resolution	r/w	e	hor	1 byte 0=704 1=528 2=480 3=352	int
Sleep if no video lock	r/w	v	sle	0 = normal 1 = sleep if no video	int
MPEG mode	r/w	e	enc	0 = MPEG2 1 = MPEG4	int
MPEG2 GOP length	r/w	e	gop	0 = stripe refresh mode (default) 1 = intra only 2-100 = GOP length in frames	int
MPEG4 frame rate	r/w	e	frm	0 = full 1 = 1/2 2 = 1/4 3 = 1/8 4 = 1/24	int
MPEG4 encoding option	r/w	e	cmd	0 = low delay interlaced (default) 1 = standard delay interlaced 2 = low delay progressive 3 = standard delay progressive 4 = standard delay progressive SIF 5 = standard delay progressive QSIF	
MPEG4 video sharpness	r/w	e	sha	0 = normal (default) 1 = sharp	int
Manual Video Bitrate	r/w	e	vbr	Video bitrate manual over ride 0 = no override (default) Non-zero (sets the video bit-rate in kbps)	int
Video Profile	r/w	e	pro	0 = 4:2:0 1 = 4:2:2	int
Video PID	r/w	v	pid	0 = default Other = value	int
Manual video bitrate	r/w	v	vbr	0 = automatic Non-zero = video bitrate in kbps	float

## Type 'a' messages for Audio commands

Function	R/W	Block	Command	Data	Type
Audio Encoder	r/w	a	enc	1 byte 0 = Off 1 = 32kHz, 12cbit, S 2 = 32kHz, 12cbit, M 3 = 32kHz, 8cbit, S 4 = 32kHz, 8cbit, M 5 = 16kHz, 8cbit, S 6 = 16kHz, 8cbit, M 7 = 8kHz, 8cbit, S 8 = 8kHz, 8cbit, M 9 = 32kHz MPEG Layer1 stereo 10 = 32kHz MPEG Layer1 mono 11 = 48kHz MPEG Layer1 stereo 12 = 48kHz MPEG Layer1 mono 13 = 32kHz MPEG Layer2 stereo 14 = 32kHz MPEG Layer2 mono 15 = 48kHz MPEG Layer2 stereo 16 = 48kHz MPEG Layer2 mono	int
Audio Input Level	r/w	a	lev	1byte 0 = 0dB (line level) 1 = 12dB (mic level) 2 = 24dB (mic level) 3 = 36dB (mic level) 4 = 48dB (mic level) and 4 also enables ALC	int
MPEG Layer 1 Audio Bitrate	r/w	a	mpr (for channel 1)  mp2 (for channel 2)	1byte 2 = 64kbit 3 = 96kbit 4 = 128kbit 5 = 160kbit 6 = 192kbit 7 = 224kbit 8 = 256kbit 9 = 288kbit 10 = 320kbit 11 = 352kbit 12 = 384kbit 13 = 416kbit 14 = 448kbit	int
MPEG Layer 2 Audio Bitrate				2 = 48kbit 3 = 56kbit 4 = 64kbit 5 = 80kbit 6 = 96kbit 7 = 112kbit 8 = 128kbit 9 = 160kbit 10 = 192kbit 11 = 224kbit 12 = 256kbit 13 = 320kbit 14 = 384kbit	
Audio PID 1	r/w	a	pd1	0 = default Other = value	int
Audio PID 2	r/w	a	pd2	0 = default Other = value	int
Audio DID SDI Data Identifier	r/w	a	did	DID value	int
Audio 2 enable	r/w	a	en2	0 = disabled 1 = enabled 2 = input2 to input1	int

Audio Source	r/w	a	src	0 = analogue 1 = aes/ebu digital 2 = embedded	int
MPEG Audio Offset	r/w	a	pts	PTS offset for MPEG Audio	int
Audio Left/Right Swap	r/w	a	lrs	0 = normal stereo 1 = swapped stereo	int
Audio Mono Select	r/w	a	rmo	0 = left mono 1 = right mono	int

### Type 'g' messages for Unit Level commands

Function	R/W	Block	Command	Data	Type
Software Version	r	g	ver	Software version number	Hex string
FPGA Version	r	g	fpg	FPGA version number	Hex string
Serial Number	r	g	ser	Hex based serial number	Hex string
License Code	w	g	lic	License number for software facilities	Hex string
Narrow band Service Name	r/w	g	nam	Unit Name String	string
Set Unit address	r/w	g	add	Unit Address 0001 - 9998	int
Load Configuration Number	r/w	g	lod	Config Number	int
Restore Default Build	w	g	def	0 = No 1 = Yes	int
Sleep Mode	r/w	g	sle	0 = No 1 = Yes	int
Front Panel Lock	r/w	g	fpl	0 = unlocked 1 = locked	int
DVB-T Service name	r/w	g	dna	Unit Name String	string
Heart beat enable	r/w	g	blo	0 = off 1 = on	int
License Mask	r	g	lma	Returns hex value with bits as follow 0 – Video 1 – 4:2:2 2 – Set to 0 3 – Set to 0 4 – Ultra Narrowband and MPEG4 5 – Narrowband 6 – DVB-T 7 – License Exempt 8 – SDI 9 – Set to 0 10 – AES128 11 – AES256 12 – Bcrypt128 13 – Set to 1 14 – Bcrypt256 15 – Set to 1	hex
Board Type	r	g	bty	Returns D550	string
Unit Type	r	g	uty	12 = D550 13 = D551	int
Turn LEDs Off	r/w	g	lof	0 = LEDs on 1 = LEDs off	int
Core Temperature	r	g	tmp	Temperature in degrees C	int
VCC Int	r	g	vnt	Voltage	int

VCC Aux	r	g	vax	Voltage	int
Disable sleep button	r/w	g	dsl	0 = no 1 = yes	int
GPIO Control	r/w	g	gpsw	For Engineering Use Only	int

### Type 'p' messages for SI

Function	R/W	Block	Command	Data	Type
PCR PID	r/w	p	cpd	0 = default Other = value	int
PMT PID	r/w	p	mpd	0 = default Other = value	int
Video Stream ID	r/w	e	sid	0 = default Other = value	int
Audio Stream ID	r/w	a	sid	0 = default Other = value	int
Transport Stream Version	r/w	t	svr	0 = default Other = value	int
Provider Name	r/w	g	pro	0 = default Other = value	string

### Type 'd' messages for Data commands

Function	R/W	Block	Command	Data	Type
Data On/Off	r/w	d	inp	1 byte 0 = Off 1 = On 2 = On (even parity) 3 = On (odd parity)	int
Input Data Baudrate	r/w	d	bau	1 byte 0 = 1200 baud 1 = 2400 baud 2 = 4800 baud 3 = 9600 baud 4 = 19200 baud 5 = 38400 baud 6 = 57600 baud (note 57600 is not supported in DVB-T modes) 7 = 115200 baud	int
Data PID	r/w	d	pid	0 = default Other = value	int
Metadata Enable	r/w	m	eta	1 byte 0 = Off 1 = On	int
Metadata PID	r/w	m	pid	0 = default Other = value	int

### Type 'c' messages for Calibration commands

Function	R/W	Block	Command	Data	Type
IQ trim point	r/w	c	itr	0 = Normal unit operation 1 – 11 = Trim mode Note: Must be set back to 0 after using trim mode.	int
I trim value for current IQ trim point	r/w	c	iqi	-128 to +127 Signed but set and read as unsigned (255 = -1)	int
Q trim value for current IQ trim point	r/w	c	iqq	-128 to +127 Signed but set and read as unsigned (255 = -1)	int
Lowest Operating Frequency	r/w	c	flo	Frequency in MHz	double
Highest Operating Frequency	r/w	c	fhi	Frequency in MHz	double
Intermediate Operating Frequency 1	r/w	c	fi1	Frequency in MHz	double
Intermediate Operating Frequency 2	r/w	c	fi2	Frequency in MHz	double
Intermediate Operating Frequency 3	r/w	c	fi3	Frequency in MHz	double
Intermediate Operating Frequency 4	r/w	c	fi4	Frequency in MHz	double
Intermediate Operating Frequency 5	r/w	c	fi5	Frequency in MHz	double
Intermediate Operating Frequency 6	r/w	c	fi6	Frequency in MHz	double
Calibration lowest point	r/w	c	pl1	0 – 32 in 0.25dB steps	int
Calibration intermediate point 1	r/w	c	pl2	0 – 32 in 0.25dB steps	int
Calibration intermediate point 2	r/w	c	pl3	0 – 32 in 0.25dB steps	int
Calibration intermediate point 3	r/w	c	pl5	0 – 32 in 0.25dB steps	int
Calibration intermediate point 4	r/w	c	pl6	0 – 32 in 0.25dB steps	int
Calibration intermediate point 5	r/w	c	pl7	0 – 32 in 0.25dB steps	int
Calibration intermediate point 6	r/w	c	pl8	0 – 32 in 0.25dB steps	int
Calibration highest point	r/w	c	pl4	0 – 32 in 0.25dB steps	int
RF level vs temperature offset gradient	r/w	c	rtg	0 – 8 (default 4) = -1dB / 10°C to 1dB / 10°C gain in 0.25dB steps	Int

RF level vs temperature offset mid point	r/w	c	rtn	0 - 100°C mid point for RF level temperature gradient	Int
--	-----	---	-----	---	-----



## Default Configurations

This section tabulates the default configuration settings for **demo** SOLO products.

Item	SOL4MTX-200250 (2.0 to 2.5GHz)	SOL4MTX-100150 (1.0 to 1.5GHz)
RF Output	OFF	OFF
Frequency	2405MHz	1395MHZ
Modulation	QPSK	QPSK
Power	Maximum	Maximum
Standby	OFF	OFF
Unit Address	0001	0001
Unit name	Solo-01 (SOLO4) Unit 1 (SOLO2)	Solo-01 (SOLO4) Unit 1 (SOLO2)
Horizontal Resolution	528	528
Video Input	PAL	PAL
Audio	OFF	OFF
Data	OFF	OFF
Audio Input	Line level	Line level
Scrambling	OFF	OFF
AES Key	None	None

