

**GSM Mobile Phone**

**Model:RING MINI**

**Brand:Ice Mobile**

**FCC ID: C89RINGMINI**

# Content

<b>1</b>	<b>General Information</b>	<b>3</b>
1.1	Profile	3
1.2	Safety Information	3
1.3	Safety warning and Attentions	3
<b>2</b>	<b>Your phone</b>	<b>6</b>
2.1	Phone overview	6
2.2	Functions of Keys	6
2.3	Technical specifications	7
<b>3</b>	<b>Getting started</b>	<b>8</b>
3.1	Installing the SIM Cards and the Battery	8
3.2	Installing memory card	10
3.3	Charging the Battery	11
3.4	Powering On/Off the Mobile Phone	13
3.5	Linking to the Network	13
3.6	Dialing Calls	14
3.7	Using the Headset	15

<b>4</b>	<b>Input method .....</b>	<b>15</b>
4.1	Icons for Input Methods.....	15
4.2	To Shift Entry Methods.....	16
4.3	Numeric Input .....	16
4.4	English input and numeric input: .....	16
4.5	Inserting a Symbol .....	17
<b>5</b>	<b>Using the Menus.....</b>	<b>18</b>
5.1	Message .....	18
5.2	Phonebook.....	19
5.3	User profiles.....	19
5.4	Call center .....	20
■	Call logs .....	20
■	Call settings.....	21
5.5	Multimedia.....	22
5.6	Settings.....	24
5.7	Tools.....	26
5.8	Services .....	27
5.9	Cherry Zone .....	28

## 1 General Information

### 1.1 Profile

Please read this pamphlet carefully in order to make your phone in perfect condition.

Perfectly combining humanized design and fine art, this mobile phone provides a streamlined outlook, comfortable hand-feeling, pleasant sounds and MP3 player which bring convenience and fun to your work.

Our company may change this mobile phone without prior written notice and reserves the final right to interpret the performance of this mobile phone.

Due to different software and network operators, display on your phone may be different, refer to your phone for details.

### 1.2 Safety Information

If your phone has lost or been stolen, notify the telecommunication office the SIM card is disabled (network support is required). This can avoid economic loss caused by unauthorized use.

Please take measures as following to avoid your phone being unauthorized use:

- Set PIN code of SIM card
- Set phone password

### 1.3 Safety warning and Attentions

#### Safety warning

> **ROAD SAFETY COMES FIRST**

Do not use a hand-held phone while driving. Use hands-free fittings when calls are unavoidable while driving. In some countries, dialing or receiving calls while driving is illegal!

> **SWITCH OFF IN AIRCRAFT**

Wireless devices can cause interference in aircraft. Using a mobile phone in flight is illegal and risky.

Please make sure that your mobile phone is powered off in flight.

> **SWITCH OFF BEFORE ENTERING RISKY AREAS**

Strictly observe the relevant laws, codes, and regulations on the use of mobile phones in risky areas. Turn off your mobile phone before entering a place susceptible to explosion, such as an oil station, oil tank, chemical plant or a place where a blasting process is under way.

> **OBSERVE ALL SPECIAL REGULATIONS**

Follow any special regulations in force in any area such as hospitals and always switch off your phone whenever it is forbidden to use it or, when it may cause interference or danger. Properly use your mobile phone near medical apparatuses, such as pacemakers, hearing aids and some other electronic medical devices, as it may cause interference to such apparatuses.

> **INTERFERENCE**

The conversation quality of any mobile phone may be affected by radio interference. An antenna is built inside the mobile phone and located below the microphone. Do not touch the antenna area during a conversation, lest that the conversation quality deteriorate.

> **QUALIFIED SERVICE**

Only qualified personnel may install or repair phone equipment. Installing or repairing the mobile phone on your own may bring great danger and violates the warranty rules.

➤ **ACCESSORIES AND BATTERIES**

Use only approved accessories and batteries.

➤ **USE SENSIBLY**

Use only in a normal and proper manner.

➤ **EMERGENCY CALLS**

Ensure the phone is switched on and in service, enter the emergency number, e.g. 112, then press the Dial key. Give your location and state your situation briefly. Do not end the call until told to do so.

*Note: Just like all other mobile phones, this mobile phone does not necessarily support all the features described in this manual due to network or radio transmission problems. Some networks even do not support the emergency call service. Therefore, do not rely solely on the mobile phone for critical communications such as first aid. Please consult the local network operator.*

Precautions

This mobile phone is well designed with fine art. Please exercise special care when using it. The following suggestions will help your mobile phone survive the warranty period and extend its service life:

- Keep the mobile phone and all its fittings beyond children's reach.
- Keep the mobile phone dry. Keep away from rain, moisture, liquid or other substances that may corrode electronic circuits.
- Do not use or store the mobile phone in dusty places, lest that active parts of the mobile phone be damaged.
- Do not store the mobile phone in a high-temperature place. High temperature will shorten the life of electronic circuits and damage the battery and some plastic parts.
- Do not store the mobile phone in a chilly place. Otherwise, moistures will be formed inside the mobile

- phone to damage electronic circuits when the mobile phone is moved to a constant temperature place.
- Do not throw, knock or shock the mobile phone, as that will destroy the internal circuits and high-precision components of the mobile phone.

## 2 Your phone

### 2.1 Phone overview

### 2.2 Functions of Keys

The mobile phone provides the following keys:

- ◆ Left and right soft key  
The bottom line on the screen displays the functions of the Left and Right soft key.
- ◆ Dial key  
Press it to originate a call by entering the called number or selecting a contact from the phonebook; or press it to receive an incoming call; or press it in standby state to show the latest call records
- ◆ End key  
Press it to end a call being dialed or end an ongoing call; or press it to exit the menu and return to the standby state; or hold it for two or three seconds to power on or off the mobile phone.

◆ **Direction key**

Press them to scroll the options when browsing a function list. In edit state, press direction keys to navigate. In standby state, press a direction key to enter the specified function page. You can also customize direction keys to match the desired functions.

◆ **OK key**

Press it to confirm your selection. In standby interface, pressing it can enter the main menu, long press it can turn on/off the flashlight which situates at the top of the phone.

◆ **Number keys, \* key and # key**

Press number keys 0 through 9 to input or edit state to input numbers and characters;

The # key and the \* key represent different functions in different states or different function menus.

Hold the # key up to 2s in standby state to switch between silent, meeting and normal mode.

Press the # key in edit state to switch between input methods.

In idle screen, you can press left soft key then \* key to lock keypad. When the keypad is locked, you can press left soft key then \* key to unlock it.

Press the \* key twice can input "+" in standby interface. "+" are used for dialing an international call.

### **2.3 Technical specifications**

Phone

Dimensions (W×D×H):

Weight:

Lithium battery

Rated capacity:

Continuous standby duration: (Relates to network status)

Continuous conversation duration: (Relates to network status)

Please refer to their labels for other data related to the battery and the charger.

## 3 Getting started

### 3.1 Installing the SIM Cards and the Battery

An SIM card carries useful information, including your mobile phone number, PIN (Personal Identification Number), PIN2, PUK (PIN Unlocking Key), PUK2 (PIN2 Unlocking Key), IMSI (International Mobile Subscriber Identity), network information, contacts data, and short messages data.

Note:

*After powering off your mobile phone, wait for a few seconds before removing or inserting an SIM card.*

*Exercise caution when operating an SIM card, as friction or bending will damage the SIM card.*

*Properly keep the mobile phone and its fittings such as the SIM cards beyond children's reach.*

Installation

- ◆ Hold the End key for a while to power off the mobile phone
- ◆ Push the back cover above the battery downward and remove it.
- ◆ Take the battery away.
- ◆ Insert the SIM card into the SIM card slot lightly with the corner cutting of the card aligning to the notch of the slot and the gold plate of the card facing downward, till the SIM card cannot be further

pushed in.

- ◆ Aim the positive pole and negative pole of the battery at the battery connector of the mobile phone, and press the left of the battery to install the battery into the battery tank.

### **Using code**

The mobile phone and the SIM cards support sorts of passwords, in order to prevent the phone and the SIM cards from being misused. When you are prompted to input any of the codes mentioned below, just input the correct code and then press the OK key. If you input a wrong code, press the Right soft key to clear it and then input the correct code.

#### ◆ **Phone lock code**

The phone lock code may be set to prevent your mobile phone from being misused. In general, this code is provided along with the mobile phone by the manufacturer. The initial phone lock code is set to 0000 by the manufacturer. If the phone lock code is set, you need to input the phone lock code when powering on the mobile phone.

#### ◆ **PIN**

The PIN (Personal identification number, 4 to 8 digits) code prevents your SIM card from being used by unauthorized people. In general, the PIN is supplied with SIM card by the network operator. If PIN check is enabled, you need to input the PIN each time when you power on your mobile phone. The SIM card will be locked if you input wrong PIN code for three times.

Unlocking methods as follows:

- Input the correct PUK according to the screen tips to unlock the SIM card.
- Then input the new PIN and press the OK key.
- Input the new PIN again and then press the OK key.

-If the input PUK is correct, the SIM card will be unlocked and the PIN will be reset.

*Note: The SIM card will be locked if you input wrong PIN code for three times. To unlock the SIM card, you need to input the PUK. In general, the PUK can be obtained from the network operator.*

◆ **PUK**

The PUK code (Personal Unlocking Key, 8digits) is required to change a blocked PIN. It is supplied with SIM card. If not, contact your network operator. If you input wrong PUK code for 10 times, SIM card will be invalid. Please contact the network operator to replace the SIM card.

◆ **Barring code**

A barring code is required for setting the call barring function. You can obtain this code from the network operator to set the call barring function.

### **3.2 Installing memory card**

The memory card is a pluggable mobile storage card inside the mobile phone.

To install the memory card, open its latch, place its indented side downward, insert the card into the card slot, and then close the latch.

To remove the memory card, open its latch and slightly press the card inward. The card will automatically pop out. Close the latch.

Note:

*1. The mobile phone cannot automatically identify the memory card being inserted when the mobile phone is powered on. You must power off the mobile phone and then power it on, so that the phone can identify the Memory card.*

*2. The memory card is a miniature object. Keep it out of the reach of children for fear that children swallow it!*

### 3.3 Charging the Battery

The lithium battery delivered with the mobile phone can be put into use immediately after being unpacked. A new battery will have maximum performance after the first three full charge/discharge cycles.

Battery level indication:

- ◆ Your mobile phone can monitor and display the battery state.
- ◆ Normally the remaining energy of the battery is indicated by the battery level icon at the upper right corner of the display screen.
- ◆ When the battery energy is insufficient, the mobile phone prompts "Battery low". If you have set an alert tone, an alert tone will be given off when the battery level is too low.
- ◆ A charging animation appears when the battery is being charged. When the charging is complete, the animation disappears.

Using a travel adapter:

- ◆ Install the battery into the mobile phone before charging the battery.
- ◆ Connect the adapter of the travel charger with the charging slot in the mobile phone. Ensure that the adapter is fully inserted.
- ◆ Insert the plug of the travel charger to an appropriate power outlet.
- ◆ During the charging, the battery level grids in the battery icon keep flickering till the battery is fully charged.
- ◆ It is normal when the battery is become hot during the charging period.
- ◆ The battery icon does no longer flicker when the charging process ends.

Note:

*Ensure that the plug of the charger, the plug of the earphone, and the plug of the USB cable are inserted in the right direction. Inserting them in a wrong direction may cause charging failure or other problems. Before the charging, ensure that the standard voltage and frequency of the local mains supply match the rated voltage and power of the travel charger.*

#### Using the Battery

The performance of a battery is subject to multiple factors: radio network configuration, signal strength, ambient temperature, chosen functions or settings, phone fittings, and the voice, data or other application mode you choose to use.

To guarantee the optimal performance of your battery, please stick to the following rules:

- ◆ Use only the battery provided by the vendor. Otherwise, damages or even injuries could be caused during the charging.
- ◆ Power off the mobile phone before removing the battery.
- ◆ The charging process lasts a longer time for a new battery or a battery not in use for long. If the battery voltage is too low to enable the mobile phone to be powered on, charge the battery for a longer time. In this case, the battery icon does not flicker until a long time after the battery enters the charge status.
- ◆ During the charging, ensure the battery is placed in a room temperature environment or in an environment close to room temperature.
- ◆ Immediately stop using the battery if the battery produces odor, overheats, cracks, distorts or has other damage, or if the electrolyte leaks.
- ◆ The battery wears out with use. A longer charging time is required as the battery is put into use for a long time. If the total conversation duration decreases but the charging time increases even though the battery is properly charged, purchase a standard battery from the OEM or use a battery approved by

our company. Using any poor-quality fittings will cause harm to your mobile phone or even incur danger!

***Note:** To guarantee your personal safety and protect the environment, do not litter the battery! Return the old battery to the mobile phone manufacturer or place it in specified battery reclamation areas. Do not litter any battery with other rubbish.*

***Warning:** Short-circuits of the battery may cause explosion, fire, personal injury or other severe consequences!*

### **3.4 Powering On/Off the Mobile Phone**

Hold the End key for a while to power on the mobile phone. A power-on animation appears on the display screen.

Input the phone lock code and press the OK key if the mobile phone prompts you to input the phone lock code. The original code is 0000.

Input the PIN and press the OK key if the mobile phone prompts you to input the PIN. The PIN is provided by the network operator for new opening SIM card.

Enter the standby interface.

To power off the mobile phone, hold the End key for a while.

### **3.5 Linking to the Network**

After the SIM card and the mobile phone are successfully unlocked, the mobile phone automatically searches for an available network. After finding a network, the mobile phone enters the standby state. When the mobile phone is registered in the network, the name of the network operator is displayed on the screen. Then you can dial or receive a call.

### 3.6 Dialing Calls

In the standby interface, press number keys to input the area code and the telephone number, and then press the Dial key to dial a call. To end the call, press the End key.

#### ◆ **Dialing an international call**

Press the \* key twice can input "+". Then input the country code, the area code and the telephone number. Finally, press the Dial key.

#### ◆ **Dialing a call to a number in the phonebook**

Enter the phonebook and use the up and/or down direction keys to find the telephone number you want to call.

Press the Dial key. The mobile phone automatically dials the chosen telephone number.

#### ◆ **Redialing the last number**

In the standby interface, press the dial key to show the dialed calls.

Press the up and/or down direction keys to select a number you want to dial and then press the Dial key.

#### ◆ **Adapting volume**

During a conversation, you can press the Up and/or Down direction keys to tune the sound volume.

#### ◆ **Answering incoming calls**

Press the Dial key or the Left soft key to answer an incoming call.

Press the End key to end the current conversation.

To reject an incoming call, press the End key or the Right soft key.

*Note: If the caller can be identified, the mobile phone will present the calling number. If the calling number exists in the phonebook, the mobile phone will present both the name and the phone number of the caller. If*

*the caller cannot be identified, the mobile phone will present the calling number only. You can answer an incoming call when using a function list or browsing the phonebook.*

◆ **Using options during a conversation**

Select Menu during a conversation to turn on hands-free, switch and start recording, etc. For details, refer to the menu guide.

**3.7 Using the Headset**

It would enter headset mode automatically when you insert headset to the slot. Make sure of inserting it at the bottom of the slot, or you can't use it normally.

## **4 Input method**

This mobile phone provides multiple input methods, including smart English input, English input and numeric input. You can use these input methods when editing the phonebook, short messages, files and greeting text.

**4.1 Icons for Input Methods**

After you enter an edit window such as a window for editing the phonebook, short messages or the memorandum, an icon is displayed to indicate the current input method:

Numeric input: "123"

English input: “ABC, Abc, abc”

Smart English input: “sEN, sEn, sen”

## 4.2 To Shift Entry Methods

Press the # key to switch between input methods.

## 4.3 Numeric Input

You can input numbers with the numeric input method. Press a number key to input the corresponding number.

## 4.4 English input and numeric input:

The keyboards for English input and numeric input are defined in the following table:

Key	Character or Function	Remarks
Number key 1	. , - ? ! ' @ : / _ 1	
Number key 2	ABCabc2	
Number key 3	DEFdef3	
Number key 4	GHIghi4	
Number key 5	JKLjkl5	
Number key 6	MNOmno6	
Number key 7	PQRSpqrs7	
Number key 8	TUVtuv8	
Number key 9	WXYZwxyz9	
Number key 0	0	

# key	Press it to switch between input methods	
Left direction key	Press it to move to the left	
Right direction key	Press it to move to the right	
Left soft key	Equivalent to OK or Options	
Right soft key	Equivalent to Back or Delete	
End key	Press it to return to the standby interface	

English input:

- Each key is used to represent multiple characters. Quickly and continuously press a key till the character you want appears. Input the next character after the cursor moves.
- Press the # key to switch between input methods
- To input a blank, switch to the English input mode (in upper or lower case) and then press number key **0**.
- To clear wrong inputs, press the **Right soft** key.

#### 4.5 Inserting a Symbol

Press the number key 1 to enter a symbol you want.

## 5 Using the Menus

### 5.1 Message

If the short message memory is full, a blinking message icon appears on the top of the screen. To normally receive short messages, you need to delete some of the existing short messages.

#### **Write message**

Through this function, you can create a new text message. You can type a message, and you're also able to insert a pre-defined message from “**Templates**”.

#### **Inbox**

Received messages are listed in this menu.

#### **Outbox**

Messages sent failed are stored in this item.

#### **Drafts**

Draft messages are listed in this item.

#### **Sent box**

The messages which are sent successfully are stored in this menu.

## 5.2 Phonebook

The mobile phone can store up to 100 telephone numbers. The telephone numbers that an SIM card can store depends on the storage capacity of the SIM card. The telephone numbers stored in the mobile phone and in the SIM cards form a phonebook.

The phonebook search function enables you to view contacts. You can search a contact as required from the phonebook. Select this option, in the **search** interface, input the name of the contact you want to search or the first letter(s) of the name. All the contacts meeting the search condition are listed. Press the Up and Down direction keys to browse the contacts and select contact. Press left or right direction key to view other groups: Unclassified, family, business, classmates, blacklist and so on.

## 5.3 User profiles

The mobile phone provides multiple user profiles, so that you can customize some settings to adapt to the specific events and environments.

Customize the user profiles according to your preference and then activate the user profiles. The user profiles fall into five scenarios: **General, Silent, Meeting, Indoor and Earphone.**

Select **Options** and you can perform the following operations: Activate, Customize and Rename.

### **Activate**

Select **Activate** to activate the selected mode.

### **Customize**

- ◆ **Ring settings:** Set call ring and message ring.
- ◆ **Adjust volume:** Set the volume of the caller ringtone, message ringtone, call, alarm & calendar ringtone

and power ringtone.

- ◆ **Call alert:** Select ringtone, vibrate, silent, ring and vibrate, or vibrate then ring mode.
- ◆ **Message alert:** Select ringtone, vibrate, silent or ring and vibrate.
- ◆ **Alarm & calendar remind:** Select ring, vibrate, silent or ring and vibrate.
- ◆ **Key tone:** Silent, Ringtone1 and Ringtone2 are available. Users can select one of them as needed.
- ◆ **Battery low alert:** Activate or deactivate this function as needed.
- ◆ **Power ringtone:** Activate or deactivate this function as needed.

### **Rename**

Select **Rename** to rename the selected profile.

## **5.4 Call center**

### ■ **Call logs**

#### **Dialed calls**

You can view the latest dialed calls. Choose **Dialed calls** and then select a dialed call to call, delete or delete all (or send SMS to it) etc.

#### **Received calls**

You can view the latest received calls. Choose **Received calls** and then select a received call to call, delete or delete all (or send SMS to it) etc.

## Missed calls

You can view a list of the latest missed calls.

**Note:** When the mobile phone indicates that some calls are missed, you can select **Details** to enter the missed calls list. Navigate to a missed call and then press the **Dial** key to dial the number that originated that call.

## Rejected calls

You can view a list of the latest rejected calls.

## Delete all

You can delete the latest call records. Choose **Delete all** and confirm to delete all the numbers in the call history.

## Call timers

Choose **Call timers** to view the last call time, the total time of all dialed calls, the total time of all received calls and the total time of call history, and/or to reset all the time.

### ■ Call settings

- ◆ **Network selection:** Set Network selection mode to Auto select or Manual select. Auto select is recommended. When Network selection mode is set to Auto select, the mobile phone will prefer the network where the SIM card is registered. When Network selection mode is set to Manual select, you need to select the network operator's network where the SIM card is registered.
- ◆ **Call divert:** This network function enables you to forward incoming calls to another number you have

previously specified.

- ◆ **Call barred:** The call barred function enables you to bar calls as needed.
- ◆ **Call waiting:** After you choose Activate, the mobile phone will contact the network. A moment later, the network will make a response and send a message to acknowledge your operation. If the call waiting function is activated, the network will alert you and the mobile phone screen will display the incoming call number if others are calling you while you are already in a conversation.
- ◆ **Hide ID:** When you call someone, he or she can't find out your number if you enable this function.
- ◆ **Flight mode:** When this function is engaged, it will suspend many signal transmitting functions of some devices – thereby disabling the device's capacity to place or receive calls or text messages– while still permitting use of other functions that do not require signal transmission (e.g., games, built-in camera, MP3 player.)
- ◆ **Others:** It includes 50 secs warning, vibration when connected, answer/reject mode and auto redial.

## 5.5 Multimedia

### Camera

The phone is provided with a camera, which supports the photographing functions. Roll the phone to align the camera to the picture and then press OK key to capture photos. Pictures will be saved in the file system of the phone or the memory card. You can change the image/camera settings, by accessing the options after entering the camera mode.

### Video recorder

Use this function to record video files. Press OK key to start/pause recording, press left soft key to stop.

## **Video player**

Use this function to play video files. By pressing the corresponding key can you control the playing process of video player: play/pause (up direction key, stop(down direction key) switch to last video/next video (press left or right direction key) , fast forward (press and hold right direction key) and rewind (press and hold left direction key). In video player interface, you can press \* or # key to tune volume, number key 2 to switch to full screen play.

## **Audio player**

Use this function to play video files. By pressing the corresponding key can you control the playing process of video player: play/pause (up direction key, stop(down direction key) switch to last video/next video (press left or right direction key) , fast forward (press and hold right direction key) and rewind (press and hold left direction key). In video player interface, you can press \* or # key to tune volume.

## **Recorder**

Use this function to record audio files. The phone support WAV. The recording file you stopped would be stored in record file list automatically.

## **FM radio**

You can use the application as a traditional FM radio. You need to insert headset into its corresponding slot before using this function.

When the radio is on, press LSK key and select:

Channel list: To save the channel you have found, press and select edit. Key in the name of the channel and

frequency press OK. You can save 9 radio channels in the handset.

**Manual input:** If you know the frequency of the radio channel you would like to listen to (between 87.5 and 108.0 MHz), key it in press OK.

**Auto Search:** If you want to search radio channel, press Yes when Preset list confirm message show up. The search stops when channels has been found and show channel in Channel list.

Note: Before use FM radio, please insert the headset first

### **File management**

The phone supports the memory card. The capacity of the memory card is selectable. You can use the file manager to conveniently manage various directories and files on the memory card.

Choose **File management** to enter the root directory of the memory. The root directory will list the default folders, new folders and user files. When the mobile phone is powered on for the first time or when you have not changed the directory, the root directory contains the default folders only.

## **5.6 Settings**

### **Phone settings**

- ◆ **Time & date:** Set time, date, time format and date display type.
- ◆ **Select language:** Select the display language for the mobile phone.

- ◆ **Shortcut settings:** Customize the shortcut functions of the Up, Down, Left, and Right direction keys. In the standby interface, you can press a direction key to directly enter the function menu corresponding to that direction key.
- ◆ **Auto power on/off:** Set the time when the mobile phone will be automatically powered on or off.  
Alert: Before entering an area where the use of mobile phones is forbidden, make sure that the scheduled power-on function is deactivated to avoid accidents.
- ◆ **Power management:** Show the remaining battery level.

### **Display settings**

Users can access this item to set wallpaper, backlight, animation effect, etc.

### **Security settings**

**PIN:** The PIN (Personal identification number, 4 to 8 digits) code prevents your SIM card from being used by unauthorized people. In general, the PIN is supplied with SIM card by the network operator. If PIN check is enabled, you need to input the PIN each time when you power on your mobile phone. The SIM card will be locked if you input wrong PIN code for three times

**PIN2:** The PIN2 code (4 to 8 digits), supplied with SIM card, is required to access some functions such as “call costs setup” and “fixed dialing setup”. Please contact the network operator to verify whether your SIM card supports these functions. If you input wrong PIN2 for three times, the PIN2 will be locked.

**Privacy:** The initial password is 0000. After accessing this function, you can select some items. Once an item is selected, you need to input correct password whenever you want to enter this item to perform further operations.

**Auto keypad lock:** The function enables you to lock/unlock the keypad. Set the auto locking time, 5s,

15s, 30s, 1min and 5mins are available.

**Lock screen by end-key:** Users can activate/deactivate this function as needed.

**Power-on password:** Once this function is activated, password is required when powering on the phone.

### **Restore factory settings**

Use this function to restore factory settings. The initial password is 0000.

## **5.7 Tools**

### **Alarm**

Three alarm clocks are set but deactivated by default. You can activate one, multiple or all of them as needed. For each alarm clock, the ringing date and the ringing time can be set.

### **Bluetooth**

With Bluetooth, you can make a wireless connection to other compatible devices, such as mobile phones, computers, headsets and car kits. You can use the Bluetooth to send images, video clips, music, sound clips and notes, and transfer files from your compatible pc.

Power On/Off: Turn on/off the Bluetooth feature.

Inquiry Audio Device: Search the devices that are available.

My device: Select to connect to devices that you predefined.

Active Device: Activate the selected device.

Settings: Allows you to set the following Options : Visibility, Change Device Name, Authentication, Audio path, Storage and FTP Setting.

About: You can view the device name and address.

Note: The received file saved in the Received folder.

### **Calendar**

Once you enter this menu, there is a monthly-view calendar for you to keep track of important appointments, etc. Days with events entered will be marked.

### **Calculator**

The calculator can add, subtract, multiply and divide. To use the calculator:

- ◆ Press the up, down, left, right and OK key to select +, -, ×, ÷ and = respectively.
- ◆ Press right soft key to delete the figure.

### **Flashlight**

You can long press numeric key 0 in idle screen to turn on/off the flashlight which situates at the top of the phone.

## **5.8 Services**

### **WAP**

You can surf the internet through this function.

## STK

STK service is the tool kit of SIM card. This phone supports the service function .The specific items are depended by SIM card and network. Service menu will be auto added to the phone menu when supported by network and SIM card.

### 5.9 Cherry Zone

#### Boxman

A game named Boxman is embedded in the phone. For specific operation, please refer to 'help' option the game.

#### Cherry shop

You can access cherry shop via Internet through this function.

## 6 Appendix

### Appendix 1: Troubleshooting

If you find exceptions when operating the mobile phone, restore the factory settings and then refer to the following table to solve the problem. If the problem persists, contact the distributor or service provider.

Fault	Cause	Solution
SIM card error	The SIM card is damaged.	Contact your network service provider

	The SIM card is not in position.	Check the SIM card
	The metal face of the SIM card is polluted.	Clean the SIM card with a clean cloth
Poor received signal quality	Signals are obstructed. For instance, radio waves cannot be effectively transmitted nearby a high building or in a basement.	Move to a place where signals can be effectively transmitted

	Line congestions occur when you use the mobile phone in high-traffic hours	Avoid using the mobile phone in high-traffic hours
The mobile phone cannot be powered on	The battery energy is exhausted.	Charge the battery
Calls cannot be dialed	Call barring is activated	Cancel call barring

The mobile phone cannot connect the network	The SIM card is invalid	Contact your network service provider
	The mobile phone is not in a service area of the GSM network	Move to the network operator's service area
	The signal is weak	Move to a place where the signal quality is high
The battery cannot be charged	The charging voltage does not match the voltage range indicated on the charger	Ensure the charging voltage matches the voltage range indicated on the charger
	An improper charger is used	Use the charger specially designed for the mobile phone

	Poor contact	Ensure the charger plug is in good contact with the mobile phone
--	--------------	--

**FCC RF EXPOSURE INFORMATION:**

**WARNING!! Read this information before using your phone**

In August 1986 the Federal Communications Commission (FCC) of the United States with its action in Report and order FCC 96-326 adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of this phone complies with the FCC guidelines and these international standards. Use only the supplied or an approved antenna. Unauthorized antennas modifications, or attachments could impair call quality, damage the phone, or result in violation of FCC regulations. Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Please contact your local dealer for replacement antenna.

**BODY-WORN OPERATION:**

This device was tested for typical body-worn operations with the back of the phone kept 1.5cm from the body. To comply with FCC RF exposure requirements, a minimum separation distance of 1.5cm must be maintained between the user's body and the back of the phone, including the antenna, whether extended or retracted. Third-party belt-clips, holsters and similar accessories containing metallic components shall not be used. Body-worn accessories that cannot maintain 1.5cm separation distance between the user's body and the back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RF exposure limits and should be avoided.

For more information about RF exposure, please visit the FCC website at [www.fcc.gov](http://www.fcc.gov)

Your wireless handheld portable telephone is a low power radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals. In August, 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless phones. Those guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies:

<ANSIC95.1> (1992) / <NCRP Report 86> (1986) / <ICIMIRP> (1996)

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. For example, over 120 scientists, engineers, and physicians from universities, government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C95.1). Nevertheless, we recommend that you use a hands-free kit with your phone (such as an earpiece or headset) to avoid potential exposure to RF energy. The design of your phone complies with the FCC guidelines (and those standards).

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

**NORMAL POSITION:**

Hold the phone as you would any other telephone with the antenna pointed up and over your shoulder.

**TIPS ON EFFICIENT OPERATION:**

For your phone to operate most efficiently:

- Extend your antenna fully.
- Do not touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

# RF Exposure Information:

FCC RF Exposure requirements: The highest SAR value reported under this standard during product certification for use next to the body with the minimum separation distance of 1.5cm is 0.430W/kg, next to the head is 1.193W/kg. This transmitter must not be collocated or operating in conjunction with any other antenna or transmitter.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.