

November 2009

Types 66R and 66RR Relief Valves

Introduction

Scope of the Manual

This manual describes and provides instructions, installation, and parts list for Type 66R direct-operated relief valve* and for Type 66RR pilot-operated relief valve* complete with Type Y695RR pilot. Instructions and parts list for other Fisher® equipment used with these relief valves are found in separate manuals.

Product Description

Types 66R and 66RR throttling relief valves (Figure 1) are used to help protect a system against overpressure, or to maintain an inlet or backpressure. The Type 66R direct-operated construction is used for set pressure ranges of 2-inches w.c. to 5 psig (5 mbar to 0,34 bar), while the Type 66RR pilot-operated construction with the Type Y695RR pilot is used for set pressure ranges of 4-inches w.c. to 7 psig (10 mbar to 0,48 bar).

Specifications

Refer to Specifications for Types 66R and 66RR constructions listed on page 2. Some specifications for a given relief valve as it originally comes from the factory are stamped on nameplates located on the Type 66R relief valve body or Type 66RR main valve body.

Principle of Operation

Type 66R Relief Valve

Refer to Figure 2. Inlet pressure registers under the diaphragm and is opposed by the spring. When the inlet pressure increases above the spring setting, the valve plug opens in a throttling manner and relieves the inlet pressure. As inlet pressure drops back to set pressure, the spring closes the valve plug.

Type 66RR Relief Valve

Refer to Figure 2. Inlet pressure registers on the bottom of the pilot diaphragm through the upstream control line and bleeds through a fixed restriction in the pilot to provide loading pressure that helps the main valve spring keep the main valve plug tightly shut off. When inlet pressure exceeds the setting of the pilot spring, the pilot diaphragm moves upward, opening the pilot valve disk and relieving



W1935

TYPE 66R RELIEF VALVE



W1908

TYPE 66RR RELIEF VALVE

Figure 1. Typical Constructions

*Relief valve defined in ANSI standard B95.1-1972. Not all codes or regulations permit these valves to be used as final overpressure protection devices.

Types 66R and 66RR

Specifications

Body Sizes and End Connection Styles

| NOMINAL SIZE, NPT (DN) | END CONNECTION STYLES AND RATINGS ⁽¹⁾ | |
|---------------------------|--------------------------------------------------|-------------------------------------|
| | Standard Cast Iron Body | Optional Steel Body |
| 2 (50) | NPT or CL125 FF flanged | NPT, CL150 RF, and CL300 RF flanged |
| 3, 4 (80, 100) | CL125 FF flanged | CL150 RF flanged |

Maximum Relief Inlet Pressure⁽¹⁾

Type 66R: 8 psig (0,55 bar), including build-up
Type 66RR: 10 psig (0,69 bar), including build-up

Relief Set Pressure Ranges⁽¹⁾

Type 66R: 2-inches w.c. to 5 psig
 (5 mbar to 0,34 bar) in 7 ranges
Type 66RR: 4-inches w.c. to 7 psig
 (10 mbar to 0,48 bar) See Table 1

Allowable Emergency Outlet Pressure

Type 66R: 8 psig (0,55 bar)
Type 66RR: 10 psig (0,69 bar)

Port Diameters

NPS 2 (DN 50) Body: 2-inch (51 mm)
NPS 3 (DN 80) Body: 3-inch (76 mm)
NPS 4 (DN 100) Body: 4-inch (102 mm)

Temperature Capabilities

Standard Elastomers: -20° to 180°F (-29° to 82°C)
High-Temperature Elastomers:
 0° to 350°F (-18° to 177°C)

Pressure Setting Adjustment

Adjusting screw

Pressure Registration

Type 66R: Internal (standard) or external
Type 66RR: External on pilot and internal in main valve

Pressure Connections

Type 66R
Control Line (If Used): 3/4 NPT internal
Spring Case Vent: 3/4 NPT internal with removable
 Type Y602-10 vent assembly

Type 66RR
Pilot Body: 3/4 NPT internal
Pilot Diaphragm Case: 1/2 NPT internal
Pilot Spring Case: 1/4 NPT internal

Approximate Weights

NPS 2 (DN 50) Body
NPT: 50 pounds (23 kg) for Type 66R or
 65 pounds (30 kg) for Type 66RR
Flanged: 55 pounds (25 kg) for Type 66R or
 70 pounds (32 kg) for Type 66RR
NPS 3 (DN 80) Body: 100 pounds (45 kg) for
 Type 66R or 115 pounds (52 kg) for Type 66RR
NPS 4 (DN 100) Body: 155 pounds (70 kg) for
 Type 66R or 170 pounds (77 kg) for Type 66RR

1. The pressure/temperature limits in this Instruction Manual and any applicable standard or code limitation should not be exceeded.

Table 1. Type Y695RR Pilot Control Spring Selection

| MAIN VALVE CONSTRUCTION | RELIEF SET PRESSURE RANGE | PILOT CONTROL SPRING | | | |
|----------------------------|-----------------------------------------------------|----------------------|-------------|----------------------------|--------------------------|
| | | Part Number | Color Code | Wire Diameter, NPT (mm) | Free Length, NPT (mm) |
| Standard | 4 to 9-inches w.c. (10 to 22 mbar) ⁽¹⁾ | 1B653827052 | Red | 0.085 (2,16) | 3.625 (92,1) |
| | 5 to 15-inches w.c. (12 to 37 mbar) ⁽¹⁾ | 1B653927022 | Olive drab | 0.105 (2,67) | 3.750 (95,3) |
| | 12 to 28-inches w.c. (30 to 70 mbar) ⁽¹⁾ | 1B537027052 | Yellow | 0.114 (2,90) | 4.188 (106) |
| | 0.9 to 2.5 psig (0,06 to 0,17 bar) | 1B537127022 | Light green | 0.156 (3,96) | 4.060 (103) |
| | 1.3 to 4.5 psig (0,09 to 0,31 bar) | 1B537227022 | Light blue | 0.187 (4,75) | 3.938 (100) |
| Special | 3.8 to 7 psig (0,26 to 0,48 bar) | 1B537327052 | Black | 0.218 (5,54) | 3.980 (101) |

1. Published ranges are with the spring case pointed up.

some of the pressure from the top of the main valve diaphragm. At the same time, the inlet pressure increase registers on the bottom of the main valve diaphragm.

The pressure differential acting on the main valve diaphragm moves this diaphragm upward, opening the main valve. Further increases in inlet pressure continue to open the pilot valve disk and the main valve plug. When inlet pressure returns to the pilot control spring setting, the pilot disk closes, allowing inlet pressure to load the top of the main valve diaphragm through the fixed restriction. This equalizes the pressures acting on this diaphragm, and the main valve spring closes the main valve plug.

Installation



WARNING

Installing Types 66R and 66RR relief valve where its capabilities can be exceeded may cause leakage, part damage, or personal injury due to bursting of pressure-containing parts or explosion of accumulated gas. To avoid this, install a Type 66R or 66RR relief valve where:

Types 66R and 66RR




Figure 2. Operational Schematics

- Service conditions are within unit capabilities (including those given in the Specifications section),
 - Service conditions are within applicable local, state, or federal codes or regulations, and
 - The unit is protected from exposure to physical damage and/or corrosive substances.
1. Use qualified personnel when installing, operating, and maintaining these relief valves. Before installing, inspect the relief valve, and pilot if used, for any damage or foreign material that may have collected.
 2. Make certain the body interior is clean and that pipelines are free of foreign material. Apply pipe compound to only the male pipeline threads with an NPT body, or use suitable line gaskets and acceptable bolting practices with a flanged body.
 3. Install a Type 66R or 66RR relief valve in a horizontal pipeline with the diaphragm casings above the body. Other orientations will change the relief set pressure and set pressure range due to the weight of the internal parts. The flow through the relief valve must comply with the flow arrow on the body.
 4. An upstream control line is not required for a standard Type 66R relief valve with internal registration through a stem guide (key 41, Figure 6). However, for an optional Type 66R relief valve with sealing diaphragm (key 14, Figure 6), connect a control line to the 3/4-inch NPT tapped connection boss on the diaphragm case (key 3, Figure 6) as shown in Figure 3.
 5. For a Type 66RR relief valve used in a relief application, connect an upstream control line to the 1/2 NPT connection on the pilot diaphragm case (key 4, Figure 8). For other typical applications, piping arrangements are shown in Figures 4 and 5. Regardless of Type 66RR installation, the pipe plug (key 78, not shown) will have to be removed from the vent of the Type Y695RR pilot spring case (key 3, Figure 8).
 6. On backpressure or bypass applications, install a three-valve isolating bypass, and vent valves immediately upstream and downstream of the unit, if system operation is necessary during maintenance.

WARNING

Relief valves vent gas from the main valve outlet and from the exhaust of the pilot if used. In hazardous gas service, personal injury and equipment damage may occur due to fire or explosion of vented gas that has accumulated. To prevent such injury and damage, provide piping or tubing to vent the gas to a safe location. Protect the vent opening against anything that could clog it.

7. The standard Type 66R spring case (key 2, Figure 6) has a Type Y602-10 vent assembly (key 30, Figure 6) installed in the 3/4 NPT spring case tapping. The vent may be removed and obstruction-free piping or tubing installed for remote piping of the spring case or for pressure loading of the spring case as shown in Figure 5. If kept in the spring case, the vent must be protected against clogging.

Types 66R and 66RR

8. Each unit is factory-set for the set pressure specified on the order. If no setting is specified, set pressure is factory set at the mid-range of the Type 66R spring (key 6, Figure 6) or the Type 66RR pilot control spring (key 6, Figure 8). The set pressure of a unit is adjusted by changing the compression of the appropriate spring. Check and verify the spring setting to make sure that it is correct for the application.
9. Set pressure for a Type 66RR relief valve is defined as the pressure at which the main valve starts-to-discharge. Type 66RR units have been designed so that either a 1-inch w.c. (2,50 mbar) build-up or a 5 percent build-up (whichever is greater) above this set pressure will open the main valve and permit it to yield full open capacity.




Figure 3. Type 66R Relief Valve Installation at Outlet of Sewage Treatment Plant Digester Tank

Startup

Key numbers are referenced in Figure 6 for the Type 66R relief valve, in Figure 7 for the Type 66RR main valve, and in Figure 8 for the Type 66RR relief valve pilot.

With proper installation and adjustment completed, slowly open the upstream shutoff valve while using gauges to monitor pressure. To monitor inlet pressure, remove the pipe plug (key 31, not shown) on the side of the body opposite the flow arrow, and then temporarily install a gauge.

On backpressure or bypass applications using an isolating bypass, also open the downstream shutoff valve and close the bypass valve.

If set pressure adjustment is necessary, monitor inlet pressure with a gauge during the adjustment procedure. Adjust a Type 66R relief valve by removing the closing cap (key 27) if necessary, loosening the locknut (key 45) if used, and turning the adjusting screw (key 25) clockwise to increase or counterclockwise to decrease the set pressure. After adjustment, tighten the locknut or install the closing cap. To adjust a Type 66RR relief, remove the Type Y695RR pilot closing cap (key 22), turn the adjusting screw (key 35) clockwise to increase or counterclockwise to decrease the set pressure, and then install the closing cap.




Figure 4. Type 66RR Relief Valve Installation in Vacuum Breaker System

Shutdown

Relief Installations

Slowly close the upstream shutoff valve. Release all pressure from the relief valve, and pilot if used, by opening the upstream vent valve.

Backpressure or Bypass Installations

Slowly close the upstream shutoff valve, while opening the bypass valve if an isolating bypass is used. Then, close the downstream shutoff valve, and open both vent valves to release all pressure from the relief valve (and pilot if used).




Figure 5. Type 66R Relief Valve Installation in Vacuum Regulation System

Maintenance

Relief valve parts are subject to normal wear and must be inspected and replaced as necessary. The frequency of inspection and replacement of parts depends upon the severity of service conditions and the requirements of local, state, and federal regulations.



WARNING

Avoid personal injury or property damage from sudden release of pressure or explosion of accumulated gas. Before starting to disassemble:

- Isolate the relief valve from line pressure,
- Release trapped pressure from the body, and
- Vent any trapped loading pressure.

Type 66R Relief Valve or Type 66RR Main Valve Body

This section gives procedures for complete disassembly and assembly of the relief valve or main valve body. Disassemble the valve only as far as required to gain access to the necessary parts. Then, begin the "Assembly" procedure at the appropriate step. Key numbers for the Type 66R relief valve are referenced in Figure 6 and, for the Type 66RR main valve, in Figure 7.

Note

All disassembly and assembly steps in this section may be performed with the relief valve in the main line. If used, the pilot and its mounting parts (keys 60 through 65, and 67, Figure 7) may remain on the spring case (key 2) unless the pilot body is to be removed or the entire pilot replaced as a unit.

Disassembly

1. With a Type 66RR relief valve, disconnect the pilot control and/or vent lines.
2. Loosen the locknut (key 45) if used, and remove the closing cap (key 27) and closing cap gasket (key 26).
3. In order to facilitate resetting spring compression during assembly, be sure to note the position of the adjusting screw (key 25) before removing it. Then, turn the screw out of the spring case (key 2) to remove spring compression, and remove the upper spring seat (key 24), spring (key 6), cap screws and nuts (keys 21 and 22), and spring case.
4. Unscrew the stem nut (key 23) from the top of the stem (key 13). To keep the stem from twisting, lift the diaphragm (key 5) and attached parts far enough to hold

the stem with an open-end wrench. Or, remove the pipe plug (key 31, not shown) from the side of the body opposite the arrow, and insert a 5/16-inch (7,94 mm) or smaller rod through the pipe plug hole and the hole in the stem.

5. Remove the spring seat washer (key 36) if used, lower spring seat (key 17), stiffener plate (key 39) if used, upper diaphragm plate (key 4), diaphragm (key 5), lower diaphragm plate (key 15), stem gasket (key 18), diaphragm spacer (key 16) if used, and another stem gasket and lower diaphragm plate if used. With a high-temperature fluorocarbon (FKM) diaphragm, remove the diaphragm gasket (key 66, not shown) that goes between the diaphragm and diaphragm case (key 3).
6. Remove the cap screws (key 20) and washers (key 34) that attach the diaphragm case to the body (key 1).
7. Remove the diaphragm case and diaphragm case gasket (key 35). Depending on construction, remove either the stem guide (key 41) or the sealing diaphragm (key 14) and last lower diaphragm plate (key 15) and stem gasket (key 18). If used, remove the rod from the stem and the pipe plug hole in the body.
8. Lift out the stem and attached parts.
9. Unscrew the stem nut (key 23) from the bottom of the stem, and remove the valve plug skirt (key 10), O-ring (key 8), O-ring retainer (key 9), and seal washer (key 37).
10. Slide a seat ring puller, T-wrench, or other suitable tool over the seat ring (key 11). Engage the tool with the seat ring lugs. Unscrew the seat ring.
11. If necessary to replace the bottom flange gasket (key 19), remove the cap screws (key 20), bottom flange (key 7), and gasket.

Assembly

1. Apply pipe compound to the threads of the seat ring (key 11). Screw in the seat ring, using a seat ring puller or similar device. Wipe off any excess pipe compound.
2. Place the seal washer (key 37), O-ring retainer (key 9), O-ring (key 8), and valve plug skirt (key 10) on the stem (key 13) in the order shown in Figure 6 or 7.
3. Secure the stem nut (key 23) to the stem. Install the stem and attached parts into the body.
4. If necessary, install a new bottom flange gasket (key 19) and the bottom flange (key 7) on the valve body. Secure the flange with the cap screws (key 20).
5. Depending on construction, either install the stem guide (key 41) on the body, or install the stem gasket (key 18), lower diaphragm plate (key 15), and the sealing diaphragm (key 14) on the stem. Make sure that on a sealing diaphragm, the diaphragm holes are aligned with the body flange holes.

Types 66R and 66RR

6. Install the diaphragm case gasket (key 35) and diaphragm case (key 3) on either the body flange or sealing diaphragm, making sure the gasket and case holes are aligned with the body flange holes.
7. Secure the diaphragm case with the washers (key 34) and cap screws (key 20), tightening the cap screws with an even crisscross pattern. With a high-temperature fluorocarbon (FKM) diaphragm, use a new case gasket (key 66, not shown), and install it on top of the diaphragm case.
8. With a sealing diaphragm construction, place another lower diaphragm plate on the sealing diaphragm so that the cupped side of the plate faces up, followed by another stem gasket (key 18) and the diaphragm spacer (key 16) if used.
9. Place a stem gasket (key 18) on the stem or diaphragm spacer, followed by the lower diaphragm plate (key 15), diaphragm (key 5), upper diaphragm plate (key 4), stiffener plate (key 39) if used, lower spring seat (key 17), and spring seat washer (key 36) if used.
10. To keep the stem (key 13) from rotating, insert a 5/16-inch (7,9 mm) or smaller rod into the pipe plug hole and through the hole in the stem, or reach far enough under the diaphragm with an open-end wrench to hold the stem. Install the other stem nut (key 23) on the stem.
11. Remove the rod (if used) from the pipe plug hole, and install the pipe plug (key 31, not shown) in the body.
15. Turn a Type 66RR adjusting screw into the spring case to the position noted in “Disassembly” step 3. If this position was not marked, turn the adjusting screw until the valve begins to open when inlet pressure just exceeds 2-inches w.c. (5 mbar).
16. Complete the relief valve adjustment according to the “Startup” section.

Type 66RR Relief Valve Pilot

Body Area

This procedure is for gaining access to the disk assembly, orifice, and body seal O-ring. All pressure must be released from the regulator, before the following steps can be performed. Key numbers are referenced in Figure 8.

1. To inspect and replace the disk assembly (key 13) remove the body cap assembly (key 43).
2. Remove the disk assembly (key 13) from the disk spacer (key 44) and replace if necessary.
3. To inspect the orifice (key 5), remove the cap screws (key 2) and separate the diaphragm case assembly (key 4) from the body (key 1).
4. Remove and inspect the body seal O-ring (key 11) and the backup ring (key 49). Replace if damaged.
5. Inspect and replace the orifice (key 5) if necessary. Lightly lubricate the threads of the replacement orifice. Install with 29 to 37 foot pounds (39 to 50 N•m) of torque.
6. Install the backup ring (key 49) into the body (key 1). Next place the body seal O-ring (key 11) into the body. See Figure 8.
7. Replace the diaphragm casing (key 4) on the body (key 1) and secure with the cap screws (key 2) using 7 to 9 foot pounds (9,50 to 12 N•m) of torque.
8. Secure the disk assembly (key 13) to the disk spacer (key 44). Place the back disk spring (key 41) and a new back body seal O-ring (key 42) on the back body cap (key 43).
9. Lightly lubricate the threads when replacing the body cap assembly.

Diaphragm and Spring Case Area

This procedure is for gaining access to the control spring, diaphragm, and lever assembly stem. All pressure must be released from the diaphragm case assembly before performing the following steps. Key numbers are referenced in Figure 8.

When changing from one spring to another, a new spring case with set screw in a different location must be matched to the replacement spring. Installing an incorrect spring case when changing from one spring to another may cause the spring to go solid and restrict the full opening of the valve plug. This could keep the relief valve from full-capacity performance and thus cause personal injury or equipment damage. To avoid this, order a replacement spring case according to the “Parts List”.

12. Install the spring case (key 2) on the diaphragm, and secure with the cap screws and nuts (keys 21 and 22), finger-tightening only at this point.
13. Install the spring (key 6), upper spring seat (key 24), adjusting screw (key 25), and new closing cap gasket (key 26). With some constructions, the closing cap (key 27) will have to be installed before the adjusting screw.
14. Compress the spring slightly with the adjusting screw to ensure proper slack in the diaphragm. Tighten the nuts and cap screws alternately in equal increments to avoid crushing the diaphragm.



WARNING

To Change the Control Spring:

1. Remove the closing cap (key 22), and turn the adjusting screw (key 35) counterclockwise to remove all compression from the control spring (key 6).
2. Remove the adjusting screw (key 35) and change the control spring to match the desired spring range.
3. Install the adjusting screw (key 35) and refer to the Startup section for adjustment.
4. Install a replacement closing cap gasket (key 25), if necessary, and reinstall the closing cap (key 22).
5. If the spring range was changed, be sure to change the stamped spring range on the spring case nameplate.

To Disassemble and Reassemble Diaphragm Parts:

1. Remove the closing cap (key 22) and the adjusting screw (key 35).
2. Remove the hex nuts (key 23, not shown) and cap screws (key 24), lift off the spring case assembly (key 3) and remove the control spring (key 6).
3. Remove the diaphragm (key 10) plus attached parts by tilting them so that the pusher post (key 8) slips off the lever assembly (key 16). To separate the diaphragm assembly (key 10) from the attached parts, unscrew the diaphragm plate cap screw (key 38) from the pusher post (key 8). If the only further maintenance is to replace the diaphragm parts, skip to step 7.
4. To replace the lever assembly (key 16), remove the machine screws (key 17). To replace the stem (key 14), perform Body Area Maintenance procedure step 3, and pull the stem (key 14) out of the guide insert (key 18).
5. Install the stem (key 14) into the guide insert (key 18) and perform Body Area Maintenance procedure steps 6 and 7 as necessary.
6. Install the lever assembly (key 16) into the stem (key 14) and secure the lever assembly (key 16) with the machine screws (key 17).
7. Reassemble the diaphragm parts as follows:
 - Pusher post (key 8)
 - Diaphragm head gasket (key 45)
 - Diaphragm head (key 7)
 - Diaphragm (key 10)
 - Diaphragm head (key 7)
 - Lower spring seat (key 50)
 - Washer (key 36)
 - Diaphragm plate cap screws (key 38)

Secure using 5 to 6 foot-pounds (7 to 8 N•m) of torque.

8. Install the pusher post (key 8) plus attached diaphragm parts onto the lever assembly (key 16).

9. Install the spring case (key 3) on the diaphragm casing (key 4) so that the vent assembly (key 26) is correctly oriented, and secure it with the cap screws (key 24) and hex nuts (key 23, not shown) fingertight.
10. Install the control spring (key 6) and the adjusting screw (key 35) in the spring case (key 3). Turn the adjusting screw (key 35) clockwise until there is enough control spring (key 6) force to provide proper slack to the diaphragm (key 10). Using a crisscross pattern, finish tightening the cap screws (key 24) and hex nuts (key 23, not shown) to 160 to 190 inch-pounds (18 to 21 N•m) of torque. To adjust the outlet pressure to the desired setting, refer to the Startup and Adjustment section.
11. Install a replacement closing cap gasket (key 25) if necessary, and then install the closing cap (key 22).

Parts Ordering


A Type 66R or 66RR relief valve has a serial number stamped on a nameplate attached to the diaphragm case. When corresponding with your local Sales Office, always refer to this serial number. Also, when ordering replacement parts, give the complete 11-character part number of each needed part as found in the following parts list.

Parts List


Type 66R Relief Valve (Figure 6) or Type 66RR Main Valve Body (Figure 7)

| Key | Description | Part Number |
|-----|----------------------------------------------------------|---------------------|
| 1 | Body | |
| | Cast iron (not for use with sealing diaphragm) | |
| | 2 NPT | 2K556819012 |
| | CL125 FF flanged | |
| | NPS 2 (DN 50) | 2K557019012 |
| | NPS 3 (DN 80) | 2K557219012 |
| | NPS 4 (DN 100) | 2K557419012 |
| | Cast iron for use with sealing diaphragm (Type 66R only) | |
| | 2 NPT | 2K556719012 |
| | CL125 FF flanged | |
| | NPS 2 (DN 50) | 2K5569X0012 |
| | NPS 3 (DN 80) | 2K557119012 |
| | NPS 4 (DN 100) | 2K557319012 |
| | WCC Steel (not for use with sealing diaphragm) | |
| | 2 NPT | 2L3505X0012 |
| | CL150 RF flanged | |
| | NPS 2 (DN 50) | 2J840122012 |
| | NPS 3 (DN 80) | 2P936022012 |
| | NPS 4 (DN 100) | 2N850022012 |
| | NPS 2 (DN 50) CL300 RF flanged | 2L4426X0012 |
| 2 | Spring Case, Steel (complete with SST drive screw) | See following table |


Types 66R and 66RR



COMPLETE STANDARD ASSEMBLY WITH INTERNAL REGISTRATION



DETAIL OF OPTIONAL CAST IRON CONSTRUCTION WITH SEALING DIAPHRAGM AND TAPPED DIAPHRAGM CASE



CLOSING CAP AND ADJUSTING SCREW DETAIL FOR 3 TO 5 PSIG (0,21 to 0,34 bar) CONSTRUCTION

Figure 6. Type 66R Relief Valve

| Key | Description | Part Number | Key | Description | Part Number |
|-----|-----------------------------------------------------------------------|-------------|-----|---------------------------|---------------------|
| 3 | Diaphragm Case, Steel Standard | | 6 | Spring, Zinc-plated steel | See following table |
| | NPS 2 (DN 50) body | 3D478728992 | 7 | Bottom Flange, Steel | |
| | NPS 3 (DN 80) body | 3D478928992 | | NPS 2 (DN 50) body | 1D477825062 |
| | NPS 4 (DN 100) body | 3D479128992 | | NPS 3 (DN 80) body | 17A9250X012 |
| | Optional 3/4 NPT tapped (for Type 66R with sealing diaphragm only) | | | NPS 4 (DN 100) body | 1D478025062 |
| | NPS 2 (DN 50) body | 1F4421000A2 | 8* | O-Ring | |
| | NPS 3 (DN 80) body | 1F4419000A2 | | Nitrile (NBR) | |
| | NPS 4 (DN 100) body | 1F1319000A2 | | NPS 2 (DN 50) body | 1D785306992 |
| 4 | Upper Diaphragm Plate, Zinc-plated steel | | | NPS 3 (DN 80) body | 1D785406992 |
| | NPS 2 (DN 50) body | | | NPS 4 (DN 100) body | 1D785506992 |
| | 2-inches w.c. to 2 psig (5 mbar to 0,14 bar) | | | Fluorocarbon (FKM) | |
| | set pressures for Type 66R or 3-inches w.c. | | | NPS 2 (DN 50) body | 1N115606382 |
| | to 3.25 psig (7 mbar to 0,22 bar) set | | | NPS 3 (DN 80) body | 1N115706382 |
| | pressures for Type 66RR | 1D255625072 | | NPS 4 (DN 100) body | 1D2658X0022 |
| | 1.5 to 5 psig (0,10 to 0,34 bar) | | 9 | O-Ring Retainer | |
| | set pressures for Type 66R or 3.25 to | | | Brass | |
| | 7 psig (0,22 to 0,48 bar) set | | | NPS 2 (DN 50) body | 1D475814012 |
| | pressures for Type 66RR | 1D555725012 | | NPS 3 (DN 80) body | 1D475914012 |
| | NPS 3 (DN 80) body | 1D477328992 | | NPS 4 (DN 100) body | 1D476014012 |
| | NPS 4 (DN 100) body | 1D477425062 | | 316 SST | |
| 5* | Diaphragm | | | NPS 2 (DN 50) body | 1D475835072 |
| | Nitrile (NBR) | | | NPS 3 (DN 80) body | 1D475935072 |
| | NPS 2 (DN 50) body | 1D477002072 | | NPS 4 (DN 100) body | 1D476035072 |
| | NPS 3 (DN 80) body | 1D477102072 | 10 | Valve Plug Skirt | |
| | NPS 4 (DN 100) body | 1D477202072 | | Brass | |
| | Fluorocarbon (FKM) | | | NPS 2 (DN 50) body | 1D476112012 |
| | NPS 2 (DN 50) body | 1D477002332 | | NPS 3 (DN 80) body | 1D476212012 |
| | NPS 3 (DN 80) body | 1D477102332 | | NPS 4 (DN 100) body | 1D476312012 |
| | NPS 4 (DN 100) body | 1D477202332 | | 316 SST | |
| | | | | NPS 2 (DN 50) body | 1D476133092 |
| | | | | NPS 3 (DN 80) body | 1D476233092 |
| | | | | NPS 4 (DN 100) body | 1D476333092 |

*Recommended spare part.

Types 66R and 66RR




Figure 7. Type 66RR Main Valve and Pilot Mounting Parts

| Key | Description | Part Number | Key | Description | Part Number |
|-----|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------|
| 11 | Seat Ring Bronze NPS 2 (DN 50) body NPS 3 (DN 80) body NPS 4 (DN 100) body 316 SST NPS 2 (DN 50) body NPS 3 (DN 80) body NPS 4 (DN 100) body | 1D783012022 1D783112022 1D783212022 1D783033092 1D783133092 1D783233092 | 14* | Sealing Diaphragm (for Type 66R with tapped diaphragm case only) Nitrile (NBR) NPS 2 (DN 50) body NPS 3 (DN 80) body NPS 4 (DN 100) body Fluorocarbon (FKM) NPS 2 (DN 50) body NPS 3 (DN 80) body NPS 4 (DN 100) body | 1H737002042 1J198102042 1H727502042 1H7370X0012 1J1981X0012 1H7275X0012 |
| 13 | Valve Stem For use without sealing diaphragm Brass NPS 2 (DN 50) body NPS 3 (DN 80) body Cast iron body Steel body NPS 4 (DN 100) body 316 SST NPS 2 (DN 50) body NPS 3 (DN 80) body Cast iron body Steel body NPS 4 (DN 100) body For use with sealing diaphragm Brass NPS 2 (DN 50) body NPS 3 (DN 80) body NPS 4 (DN 100) body For use with sealing diaphragm 316 SST NPS 2 (DN 50) body NPS 3 (DN 80) body NPS 4 (DN 100) body | 1D752914012 1D754514012 1N4455X0012 1D759614012 1D752935072 1D754535072 1N445535072 1D759635072 1J820214012 1J259114012 1J130814012 1J820235072 1J259135072 1J130835072 | 15 | Lower Diaphragm Plate, Zinc-plated steel (1 required without and 3 required with sealing diaphragm) NPS 2 (DN 50) body NPS 3 (DN 80) body NPS 4 (DN 100) body | 1D475725062 1D479325062 1D479425062 |
| | | | 16 | Diaphragm Spacer (for Type 66R with sealing diaphragm only), Zinc-plated steel NPS 2 (DN 50) body NPS 3 (DN 80) body NPS 4 (DN 100) body | 1J820326092 1J259226092 1J130926092 |
| | | | 17 | Lower Spring Seat Type 66R thru 3 psig (0,21 bar) set pressures and all Type 66RR, Aluminum Type 66R for 3 to 5 psig (0,21 to 0,34 bar) set pressures, Brass | 0X014744012 1J331314012 |
| | | | 18* | Stem Gasket, Composition (1 required without and 3 required with sealing diaphragm) NPS 2 or 3 (DN 50 or 80) body NPS 4 (DN 100) body | 1D255304022 1D478404022 |

*Recommended spare part.

Types 66R and 66RR

Key 2, Spring Case Assembly
Key 6, Spring

| BODY SIZE, NPS (DN) | CONSTRUCTION | RELIEF SET PRESSURE RANGE | SPRING CASE ASSEMBLY PART NUMBER | SPRING PART NUMBER |
|---------------------|---------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|--------------------|
| 2 (50) | Type 66R | 2 to 8-inches w.c. (5 to 20 mbar) | 1D7614X0012 | 1D765427012 |
| | Type 66RR | 3 to 8-inches w.c. (7 to 20 mbar) | 12A6056X012 | |
| | Type 66R only | 6 to 16-inches w.c. (15 to 40 mbar) 11-inches w.c. to 1 psig (27 mbar to 0,07 bar) 0.75 to 1.5 psig (0,05 to 0,10 bar) 1 to 2 psig (0,07 to 0,14 bar) 1.5 to 3 psig (0,10 to 0,21 bar) 3 to 5 psig (0,21 to 0,34 bar) | 1D7614X0022 | 1D765527012 |
| | | | 1D7614X0032 | 1D765627032 |
| | | | 1D7614X0042 | 1D765727032 |
| | | | 1D7614X0052 | 1D765827032 |
| 1D7614X0062 | 1D962627032 | | | |
| 1D4792000A2 | 1N506427142 | | | |
| 3 (80) | Type 66R | 2 to 8-inches w.c. (5 to 20 bar) | 1D7614X0072 | 1D770727012 |
| | Type 66RR | 3 to 8-inches w.c. (7 to 20 mbar) | 12A6057X012 | |
| | Type 66R only | 6 to 16-inches w.c. (15 to 40 mbar) 11-inches w.c. to 1 psig (27 mbar to 0,07 bar) 0.75 to 1.5 psig (0,05 to 0,10 bar) 1 to 2 psig (0,07 to 0,14 bar) 1.5 to 3 psig (0,10 to 0,21 bar) 3 to 5 psig (0,21 to 0,34 bar) | 1D7614X0082 | 1D770827032 |
| | | | 1D7614X0092 | 1D765727032 |
| | | | 1D7614X0102 | 1D765827032 |
| | | | 1D7614X0112 | 1D770927032 |
| 1D7614X0122 | 1E204427032 | | | |
| 1D5391000A2 | 1N506527142 | | | |
| 4 (100) | Type 66R | 2 to 8-inches w.c. (5 to 20 mbar) | 1D7614X0132 | 1D771027012 |
| | Type 66RR | 3 to 8-inches w.c. (7 to 20 mbar) | 12A6058X012 | |
| | Type 66R only | 6 to 16-inches w.c. (15 to 40 mbar) 11-inches w.c. to 1 psig (27 mbar to 0,07 bar) 0.75 to 1.5 psig (0,05 to 0,10 bar) 1 to 2 psig (0,07 to 0,14 bar) 1.5 to 3 psig (0,10 to 0,21 bar) | 1D7614X0142 | 1D771127032 |
| | | | 1D7614X0152 | 1D527627032 |
| | | | 1D7614X0162 | 1D771227032 |
| | | | 1D7614X0172 | 1D771327032 |
| 1D7614X0182 | 1E204527032 | | | |

| Key | Description | Part Number | Key | Description | Part Number |
|-----|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------|-----|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------|
| 19* | Bottom Flange Gasket, Composition NPS 2 (DN 50) body NPS 3 (DN 80) body NPS 4 (DN 100) body | 1D476404022 1D476504022 1D476604022 | 25 | Adjusting Screw Type 66R thru 2 psig (0,14 bar) set pressures and all Type 66RR, Aluminum | 1L928608012 |
| 20 | Cap Screw, Zinc-plated steel NPS 2 (DN 50) body Cast iron body (13 required) Steel body (12 required) NPS 3 (DN 80) body (17 required for cast iron or 16 for steel body) NPS 4 (DN 100) body (17 required for cast iron or 16 for steel body) | 1C631224052 1C275224052 1D529824052 1D530824052 | | Type 66R for 1.5 to 3 psig (0,10 to 0,21 bar) set pressures, Brass Type 66R for 3 to 5 psig (0,21 to 0,34 bar) set pressures [except NPS 4 (DN 100) body], Zinc-plated steel NPS 2 (DN 50) body NPS 3 (DN 80) body | 1V9069X0012 1A279128982 1N506624102 |
| 21 | Cap Screw, Zinc-plated steel [16 required for NPS 2 (DN 50), 20 for NPS 3 (DN 80), or 24 for NPS 4 (DN 100) body] | 1D529624052 | 26* | Closing Cap Gasket Neoprene | 1N446206992 |
| 22 | Hex Nut, Zinc-plated steel [16 required for NPS 2 (DN 50), 20 for NPS 3 (DN 80), or 24 for NPS 4 (DN 100) body] | 1A309324122 | 27 | Closing Cap Type 66R thru 3 psig (0,21 bar) set pressures and all Type 66RR, Die-cast zinc Type 66R for 3 to 5 psig (0,21 to 0,34 bar) set pressures, Brass | 1A589544022 1H798714012 |
| 23 | Stem Nut (2 required) Brass NPS 2 or 3 (DN 50 or 80) body NPS 4 (DN 100) body SST NPS 2 or 3 (DN 50 or 80) body NPS 4 (DN 100) body | 1D529718992 1D530918992 1D5297X0022 1D5309X0052 | 28 | Flapper Valve (for Type 66R only), Brass | 1C901715072 |
| 24 | Upper Spring Seat Type 66R for 3 to 5 psig (0,21 to 0,34 bar) set pressures, Brass NPS 2 or 3 (DN 50 or 80) body NPS 4 (DN 100) body | 1J331214012 1E271114012 | 29 | Snap Ring (for Type 66R only), Bronze | 1D178016012 |
| | | | 30 | Type Y602-10 Vent Assembly, SST/Zinc/Monel® | EMY602X1-A10 |
| | | | 31 | Pipe Plug (not shown) Cast iron Steel | 1A361919012 1A369224492 |

*Recommended spare part.
Monel® is a mark owned by Special Metals Corporation

Types 66R and 66RR

| Key | Description | Part Number | Key | Description | Part Number |
|-----|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|-----|------------------------------------------------------------------------------------------|-------------|
| 34 | Washer, Zinc-plated steel NPS 2 (DN 50) body (7 required for cast iron or 6 for steel body) | 1D793624152 | 65 | Hex Nut (for Type 66RR only), Zinc-plated steel (4 required) | 1A345724122 |
| | NPS 3 (DN 80) body (9 required for cast iron or 8 for steel body) | 1D716228982 | 66* | Diaphragm Gasket (for Fluorocarbon (FKM) diaphragm only), Fluorocarbon (FKM) (not shown) | |
| | NPS 4 (DN 100) body (9 required for cast iron or 8 for steel body) | 1D716328982 | | NPS 2 (DN 50) body | 1U6985X0012 |
| 35* | Diaphragm Case Gasket, Neoprene Cast iron body | | | NPS 3 (DN 80) body | 1U6986X0012 |
| | NPS 2 (DN 50) | 1D843604082 | | NPS 4 (DN 100) body | 1U6989X0012 |
| | NPS 3 (DN 80) | 1D843704082 | 67 | Pipe Nipple (for Type 66RR), Steel | 1B539126012 |
| | NPS 4 (DN 100) | 1D843804082 | | | |
| | Steel body | | | | |
| | NPS 2 (DN 50) | 1D753004082 | | | |
| | NPS 3 (DN 80) | 1D754704082 | | | |
| | NPS 4 (DN 100) | 1D843804082 | | | |
| 36 | Spring Seat Washer [for use only with NPS 2 or 3 (DN 50 or 80) body], Zinc-plated steel | 1H723125072 | | | |
| 37 | Seal Washer NPS 2 or 3 (DN 50 or 80) body, Steel | 1F990428982 | | | |
| | NPS 4 (DN 100) body, Brass | 1H720799012 | | | |
| 39 | Stiffener Plate, Steel 2-inches w.c. to 2 psig (5 mbar to 0,14 bar) set pressures for Type 66R or 3-inches w.c. to 3.25 psig (7 mbar to 0,22 bar) set pressures for Type 66RR | | | | |
| | NPS 2 or 3 (DN 50 or 80) body | 1D753125062 | | | |
| | NPS 4 (DN 100) body | 1D760725072 | | | |
| | 1.5 to 5 psig (0,10 to 0,34 bar) set pressures for Type 66R or 3.25 to 7 psig (0,22 to 0,48 bar) set pressures for Type 66RR [not used with NPS 2 (DN 50) body] | | | | |
| | NPS 3 (DN 80) body | 1E204325012 | | | |
| | NPS 4 (DN 100) body | 1A355325012 | | | |
| 40 | Drive Screw, 18-8 SST | 1A368228982 | | | |
| 41 | Stem Guide (not for use with sealing diaphragm) Steel | | | | |
| | NPS 2 (DN 50) body | 1D752824092 | | | |
| | NPS 3 (DN 80) body | 1D754625032 | | | |
| | NPS 4 (DN 100) body | 1D759725032 | | | |
| | SST | | | | |
| | NPS 2 (DN 50) body | 1D752835132 | | | |
| | NPS 3 (DN 80) body | 1D754635132 | | | |
| | NPS 4 (DN 100) body | 1D759735072 | | | |
| 45 | Locknut for 3 to 5 psig (0,21 to 0,34 bar) set pressure Type 66R only, Zinc-plated steel | 1A352424122 | | | |
| 60 | U-Bolt (for Type 66RR only), Steel | 11A7488X012 | | | |
| 61 | U-Bolt (for Type 66RR only), Steel | 11A7489X012 | | | |
| 62 | Mounting Bar (for Type 66RR only), Steel NPS 2 (DN 50) body | 11A7490X012 | | | |
| | NPS 3 (DN 80) body | 11A8938X012 | | | |
| | NPS 4 (DN 100) body | 11A8939X012 | | | |
| 63 | Pipe Union (for Type 66RR only), Malleable iron | 1B540621992 | | | |
| 64 | Pipe Nipple (for Type 66RR only), Steel | 1K994226012 | | | |

Type Y695RR Pilot

| Key | Description | Part Number |
|-----|--------------------------------------------|-------------|
| 1 | Body, Ductile iron | 17B9020X012 |
| 2 | Cap Screw (2 required), Steel | 1C856228992 |
| 3 | Spring Case Assembly, Ductile iron/SST | 13B0109X042 |
| 4 | Diaphragm Casing, Ductile iron | 47B3063X012 |
| 5 | Orifice, 316 SST 7/16-inch (11 mm) | 0L0832X0012 |
| 6 | Spring | See Table 1 |
| 7 | Diaphragm Head 304 SST | 17B9723X032 |
| 8 | Pusher Post, 316 SST | 18B3465X012 |
| 10 | Diaphragm Nitrile (NBR) | 37B9720X012 |
| | Fluorocarbon (FKM) | 23B0101X052 |
| 11 | Body Seal O-Ring Nitrile (NBR) | 1H993806992 |
| | Fluorocarbon (FKM) | 1H9938X0012 |
| 12 | Insert Seal O-Ring Nitrile (NBR) | 1B885506992 |
| | Fluorocarbon (FKM) | 1B8855X0012 |
| 13 | Disk Assembly Nitrile (NBR) | 1E9848X0042 |
| | Fluorocarbon (FKM) | 1E9848X0032 |
| 14 | Stem, 316 SST | 17B5278X012 |
| 16 | Lever Assembly, 302 SST | 1B5375000B2 |
| 17 | Machine Screw (2 required) | 19A7151X022 |
| 18 | Guide Insert, 316 SST | 27B4028X022 |
| 22 | Closing Cap Plastic (standard) | T11069X0012 |
| | Steel | 1E422724092 |
| 23 | Hex Nut (8 required), Steel | 1A352724122 |
| 24 | Cap Screw (8 required), Steel | 1A352524052 |
| 25 | Gasket, (Steel closing cap only), Neoprene | 1P753306992 |
| 26 | Vent, Type Y602-1 (spring case up) | 17A6570X012 |
| 35 | Adjusting Screw, Cast Zinc | 1B537944012 |
| 36 | Washer, Steel | 18B3440X012 |
| 38 | Cap Screw, Steel | 1B290524052 |
| 41 | Back Disk Spring, 302 SST | 1E984637022 |
| 42 | Back Body Seal O-Ring Nitrile (NBR) | 13A1584X012 |
| | Fluorocarbon (FKM) | 13A1584X022 |
| 43 | Back Body Cap, 316 SST | 1F2737X0012 |
| 44 | Disk Spacer, 316 SST | 1E9861X0012 |
| 45 | Lower Head Gasket, Composition | 18B3450X012 |
| 49 | Backup Ring, 302 SST | 18B3446X012 |
| 50 | Lower Spring Seat, Steel | 1B636325062 |

*Recommended spare part.

Types 66R and 66RR




Figure 8. Type Y695RR Pilot Assembly

Industrial Regulators

Emerson Process Management Regulator Technologies, Inc.

USA - Headquarters
McKinney, Texas 75069-1872 USA
Tel: 1-800-558-5853
Outside U.S. 1-972-548-3574

Asia-Pacific
Shanghai, China 201206
Tel: +86 21 2892 9000

Europe
Bologna, Italy 40013
Tel: +39 051 4190611

Middle East and Africa
Dubai, United Arab Emirates
Tel: +971 4811 8100

For further information visit www.fisherregulators.com

Natural Gas Technologies

Emerson Process Management Regulator Technologies, Inc.

USA - Headquarters
McKinney, Texas 75069-1872 USA
Tel: 1-800-558-5853
Outside U.S. 1-972-548-3574

Asia-Pacific
Singapore, Singapore 128461
Tel: +65 6777 8211

Europe
Bologna, Italy 40013
Tel: +39 051 4190611
Gallardon, France 28320
Tel: +33 (0)2 37 33 47 00

TESCOM

Emerson Process Management Tescom Corporation

USA - Headquarters
Elk River, Minnesota 55330-2445 USA
Tel: 1-763-241-3238

Europe
Selmsdorf, Germany 23923
Tel: +49 (0) 38823 31 0

The Emerson logo is a trademark and service mark of Emerson Electric Co. All other marks are the property of their prospective owners. Fisher is a mark owned by Fisher Controls, Inc., a business of Emerson Process Management.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. We reserve the right to modify or improve the designs or specifications of such products at any time without notice.

Emerson Process Management does not assume responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use and maintenance of any Emerson Process Management product remains solely with the purchaser.