

# Types 98LD and 98HD Differential Pressure Relief Valves

W6157



TYPE 98LD



W6158

TYPE 98HD

Figure 1. Types 98LD and 98HD Differential Pressure Relief Valves



## WARNING

Failure to follow these instructions or to properly install and maintain this equipment could result in an explosion, fire and/or chemical contamination causing property damage and personal injury or death.

Fisher® relief valves must be installed, operated, and maintained in accordance with federal, state, and local codes, rules, and regulations, and Emerson Process Management Regulator Technologies, Inc. instructions.

If a leak develops or if the outlet continually vents gas, service to the unit may be required. Failure to correct trouble could result in a hazardous condition. Only a qualified person must install or service the unit.

Installation, operation, and maintenance procedures performed by unqualified personnel may result in improper adjustment and unsafe operation. Either condition may result in equipment damage or personal injury. Use qualified personnel when installing, operating, and maintaining the Types 98LD and HD differential pressure relief valves.

## Introduction

### Scope of the Manual

This manual provides instructions for the installation, maintenance, and parts ordering information of Types 98LD and 98HD Differential Relief Valves. Instructions and parts lists for other equipment mentioned in this instruction manual are found in separate manuals.

# Types 98LD and 98HD

## Specifications

### Available Configurations

**Type 98LD:** Pressure-loaded with handwheel adjustment. Relief pressure ranges are 2 to 38 psig (0,14 to 2,62 bar).

**Type 98HD:** Direct-operated with standard adjusting screw. Relief pressure ranges are 15 to 200 psig (1,03 to 13,8 bar).

### Body Sizes and End Connection Styles

TYPE	BODY MATERIAL	
	Cast Iron	WCC Steel, CF8M Stainless steel, Hastelloy® C, Monel®
98LD	NPS 1/4, 1/2, 3/4, 1, NPT	NPS 1/4 through 1, NPT; NPS 1/2 through 1, SWE, CL150 RF, CL300 RF, PN 16/25/40 RF
98HD	NPS 1/4, 1/2, 3/4, 1, 1-1/2, 2, NPT	NPS 1/4 through 2, NPT; NPS 1/2 through 2, SWE, CL150 RF, CL300 RF, PN 16/25/40 RF

### Maximum Cold Working Pressures of Body Size and Material<sup>(1)(2)</sup>

REGULATOR	BODY SIZE	BODY AND SPRING CASE MATERIALS	MAXIMUM INLET PRESSURE <sup>(3)</sup> , PSIG (bar)
Type 98LD	All Sizes	Cast Iron Steel Stainless Steel	60 (4,1) 150 (10,3) 150 (10,3)
Type 98HD	All Sizes	Cast Iron Steel Stainless Steel	300 (20,7) 300 (20,7) 400 (27,6)

### Flow Coefficient

$C_1$ : 35

### IEC Sizing Coefficients

BODY SIZE, NPS (DN)	$X_T$	$F_D$	$F_L$	$K_m$
1/4	0.78	0.50	0.91	0.83
1/2 (15)			0.83	0.69
3/4 and 1 (20 and 25)			0.88	0.77
1-1/2 and 2 (40 and 50)			0.92	0.85

### Relief Pressure Ranges

See Table 1

### Shutoff Classification Per ANSI/FCI 70-3-2004

**Metal Seats:** Class IV

**PTFE:** Class IV

**Elastomer Seats:** Class VI

### Maximum Spring Case Loading Pressures, Psig (bar) (Spring Setting Plus Loading Pressure)<sup>(1)</sup>

TYPE NUMBER	STEEL (WCC) OR STAINLESS STEEL BODY, SST / ALL TRIMS TO 150°F <sup>(2)</sup> (66°C)	CAST IRON BODY	
		All Trims to 150°F <sup>(3)</sup> (66°C)	Metal Trims
98LD	125 (8,62)	50 (3,4)	50 (3,4)
98HD	300 (20,7)	250 (17,2)	----

### Maximum Temperature Ranges of Diaphragm and Seat Materials<sup>(1)(4)</sup>

MATERIAL	TEMPERATURE RANGE, °F (°C)
Metal (All)	-40° to 450°F (-40° to 232°C)
Nitrile (NBR)	-20° to 180°F (-29° to 82°C)
Neoprene (CR)	-40° to 180°F (-40° to 82°C)
Fluorocarbon (FKM)	0° to 300°F (-18° to 149°C)
Ethylenepropylene (EPDM)	-40° to 450°F (-40° to 232°C)
Polytetrafluoroethylene (PTFE)	-40° to 450°F (-40° to 232°C)
PerFluorocarbon (FKM) (FFKM)	-20° to 450°F (-29° to 232°C)

### Maximum Temperature Ranges of Body Materials<sup>(1)(4)</sup>

REGULATOR	BODY AND SPRING CASE MATERIALS	TEMPERATURE RANGE
Type 98LD	Cast Iron	-40° to 406°F (-40° to 208°C)
Type 98HD	Steel Stainless Steel	-20° to 450°F (-29° to 232°C) -40° to 450°F (-40° to 232°C)

### Pressure Registration

Internal

### Approximate Weights

#### Type 98HD

NPS 1/4 Body: 7 pounds (3 kg)

NPS 1/2 (DN 15) Body: 7 pounds (3 kg)

NPS 3/4 (DN 20) Body: 16 pounds (7 kg)

NPS 1 (DN 25) Body: 16 pounds (7 kg)

NPS 1-1/2 (DN 40) Body: 55 pounds (25 kg)

NPS 2 (DN 50) Body: 55 pounds (25 kg)

#### Type 98LD

NPS 1/4 Body: 6 pounds (3 kg)

NPS 1/2 (DN 15) Body: 13 pounds (6 kg)

NPS 3/4 (DN 20) Body: 30 pounds (14 kg)

NPS 1 (DN 25) Body: 30 pounds (14 kg)

1. The pressure/temperature limits in this Instructional Manual and any applicable standard or code limitation should not be exceeded.

2. Temperature and/or the body end connection may decrease these maximum pressures.

3. Maximum inlet pressure is equal to set pressure plus build-up.

4. Pressure and/or the body end connection may decrease these maximum temperatures.

5. Fluorocarbon is limited to 200°F (93°C) hot water.

Hastelloy® C is a mark owned by Haynes International, Inc.

Monel® is a mark owned by Special Metals Corporation




Figure 2. Type 98HD Relief Valve Operational Schematic

## Product Description

The Types 98LD and 98HD (see Figure 1) are differential pressure relief valves that are suitable for service on water, steam, air, gas, oil, and other fluids. They are used to maintain differential pressure control on testing fixtures, wash tanks, sterilizers, steam tables, fuel lines, and plant air supplies.

Type 98LD bodies are available in sizes NPS 1/4 to 1 (DN 25). Type 98HD bodies are available in sizes NPS 1/4 to 2 (DN 50). There are four relief pressure ranges for each relief valve. For Type 98LD, the ranges are between 2 and 38 psig (0,14 and 2,6 bar). For Type 98HD, they are between 15 and 200 psig (1,0 and 13,8 bar).

## Specifications

The Specifications section gives some general specifications for the Types 98LD and 98HD regulators. The nameplates give detailed information for a particular regulator as it comes from the factory.

## Principle of Operation

See Figures 2 and 3. The Types 98LD and 98HD relief valves are used to maintain a differential between the controlled pressure and loading pressure of a system. The spring setting determines the differential. The Types 98LD and 98HD can also be pressure loaded to remotely change the relief setpoint.

The relief valve responds to both controlled pressure and loading pressure and opens or closes as these pressures change. If the loading pressure increases, pressure on the upper side of the diaphragm increases. The valve plug moves closer to the orifice and restricts the flow through the relief valve. When loading pressure decreases, pressure on the upper side of the diaphragm decreases. This allows the valve plug to move away from the orifice and allow more flow through the relief valve (to atmosphere or back into the system). The relief valve opens and closes in response to changes in the controlled pressure. In this way, the differential pressure between the controlled and uncontrolled pressures is maintained.

# Types 98LD and 98HD




Figure 3. Installation Schematics for Types 98LD and 98HD Relief Valves

Table 1. Differential Relief Pressure Ranges

BODY SIZE, INCHES (DN)	TYPE 98LD <sup>(1)</sup>		TYPE 98HD <sup>(1)</sup>		COLOR CODE	PART NUMBER	SPRING WIRE DIAMETER, INCHES (mm)	SPRING FREE LENGTH, INCHES (mm)
	Psi	bar	Psi	bar				
1/4	2 to 7	0,14 to 0,48	15 to 35	1,03 to 2,4	Yellow	1E392527022	0.148 (3,76)	2.00 (50,8)
	6 to 14	0,41 to 0,97	25 to 75	1,7 to 5,2	Green	1E392627012	0.170 (4,32)	2.00 (50,8)
	12 to 25	0,83 to 1,7	70 to 140	4,8 to 9,7	Red	1E392727142	0.207 (5,26)	1.93 (49,0)
	20 to 38	1,4 to 2,6	130 to 200	9,0 to 13,8	Blue	1L346127142	0.225 (5,72)	2.08 (52,8)
1/2 (15)	2 to 7	0,14 to 0,48	15 to 35	1,03 to 2,4	Yellow	1E395627022	0.207 (5,26)	2.50 (63,5)
	6 to 14	0,41 to 0,97	25 to 75	1,7 to 5,2	Green	1D7455T0012	0.234 (5,94)	1.02 (25,9)
	12 to 25	0,83 to 1,7	70 to 140	4,8 to 9,7	Red	1E395727192	0.281 (7,14)	2.44 (62,0)
	20 to 38	1,4 to 2,6	130 to 200	9,0 to 13,8	Blue	1L380027142	0.331 (8,41)	2.25 (57,2)
3/4 and 1 (20 and 25)	2 to 7	0,14 to 0,48	15 to 35	1,03 to 2,41	Yellow	1E398927022	0.306 (7,77)	4.00 (102)
	6 to 14	0,41 to 0,97	25 to 75	1,7 to 5,2	Green	1E399027142	0.343 (8,71)	4.00 (102)
	12 to 25	0,83 to 1,7	70 to 140	4,8 to 9,7	Red	1E399127162	0.406 (10,3)	4.00 (102)
	20 to 38	1,4 to 2,6	130 to 200	9,0 to 13,8	Blue	1L380127092	0.468 (11,9)	3.75 (95,3)
1-1/2 and 2 (40 and 50)	----	----	5 to 35	0,34 to 2,4	Dark Gray	1E792327092	0.468 (11,9)	6.56 (167)
	----	----	20 to 65	1,4 to 4,5	Light Blue	1E795327082	0.531 (13,5)	6.56 (167)
	----	----	50 to 100	3,5 to 6,9	Light Gray	1E795427082	0.562 (14,2)	6.56 (167)
	----	----	80 to 170	5,5 to 11,7	Black	1P788827082	0.625 (15,9)	6.56 (167)

1. All springs may be backed off to 0 psig (0 bar). However, highest capacities and best performances are obtained by using these springs in their recommended ranges.

## Installation

Unbox and inspect the valve. Remove pipe scale and other foreign material from the connecting pipeline. Apply a suitable pipe compound to the male threads.

The relief valve can be installed in any position as long as the flow is in the direction indicated by the arrow cast on the body. The design of the valve isolates diaphragm and pressure response chamber from the main flow stream. The higher pressure is measured inside the body through a registration hole on the inlet side of the body. Connect the low pressure line to the NPT connection in the spring case (see Figure 2). This connection is 1/8 NPT for NPS 1/4 and 1/2 (DN 15) bodies, and 1/2 NPT for NPS 3/4 and 1 (DN 20 and 25) bodies.

Maximum operating temperatures for the Types 98LD and 98HD relief can be seen in the Specifications section.



## WARNING

Personal injury or system damage may result if this relief valve is installed where service conditions could exceed the limits given on the Specifications section or regulator nameplate. Installations should be adequately protected from physical damage.

Overpressuring any portion of this equipment may cause equipment damage, leaks in the relief valve, or personal injury due to bursting of pressure-containing parts. System operation within the limits shown in the Specifications section does not eliminate the possibility of damage from external sources or debris in the

pipeline. The relief valve regulator should be inspected for damage regularly and after any overpressure condition.

## Overpressure Protection



### WARNING

Overpressuring any portion of this equipment may result in equipment damage, leaks in the relief valve, or personal injury due to bursting of pressure-containing parts. The system should be inspected after any overpressure condition.

Relief pressure ranges are from 2 to 200 psig (0,14 to 13,8 bar). The individual spring range of your relief valve is stamped on the nameplate. Maximum inlet pressures depend upon body materials and temperatures. See Specifications for the maximum inlet pressures and maximum spring case loading pressures for Types 98LD and 98HD relief valves.

## Relief Valve Outlet



### WARNING

If using a Type 98LD or 98HD Relief Valves on hazardous or flammable gas service, personal injury and property damage could occur due to fire or explosion of vented gas that may have accumulated.

To prevent such injury or damage, provide piping or tubing to vent the gas to a safe, well-ventilated area. Also, when venting a hazardous gas, the piping or tubing should be located far enough away from any buildings or windows so not to create a further hazard, and the vent opening should be protected against anything that could clog it.

If remote venting is necessary, install a remote vent line in the outlet connection of the relief valve. The vent line must have the largest practical diameter and be as short as possible with a minimum number of bends or elbows.

## Startup

### Note

The Specifications section and Table 1 show the maximum inlet and the differential pressures for specific constructions. Use pressure gauges

to monitor inlet pressure, outlet pressure, and any intermediate pressure during startup.

With proper installation completed and system equipment properly adjusted, close any block and vent valves, and back out the adjusting screw by turning it counterclockwise (or by turning the handwheel in the same manner).

Slowly open the following valves in this order: loading supply and control line, inlet block valve and outlet block valve.

Set pressure is adjusted by following the Adjustment procedure.

## Adjustment

Each unit is factory set for the pressure setting specified on the order. The allowable spring range is stamped on the nameplate. If a pressure setting beyond the indicated range is required, substitute the appropriate spring. Be sure to label the relief valve to indicate the new pressure range.

Always use a pressure gauge to monitor pressure when making adjustments. If the differential pressure needs to be increased, turn the handwheel (key 38, Figure 4 or 5) clockwise. Turn the handwheel counterclockwise to decrease the differential pressure.

## Shutdown

Close the upstream shutoff valve and release all pressure from the relief valve.

## Maintenance



### WARNING

To avoid personal injury and equipment damage, isolate the relief valve from all pressure. Cautiously release pressure from the relief valve before attempting disassembly.

Due to normal wear and damage that may occur from external sources, relief valve parts such as the O-rings, gaskets, diaphragm, orifice, and valve plug should be inspected periodically and replaced as necessary. The frequency of inspection and replacement depends upon the severity of service conditions or the requirements of state and federal laws.

Instructions are given below for disassembly of the Types 98LD and 98HD relief valves. These relief valves do not have to be removed from the pipeline

# Types 98LD and 98HD

to inspect internal parts. Suitable lubricants are indicated on the assembly drawings. Apply the lubricant as the relief valve is being reassembled. Refer to Figure 4 or 5 while servicing the relief valve.

## Disassembly to Replace Diaphragm and Seats

If the relief valve is leaking, the diaphragm may be ruptured or the seating surfaces nicked or scratched. Proceed as follows to replace or repair the diaphragm, orifice, and valve plug.

1. Release all spring compression by turning the adjusting screw (key 33) counterclockwise until it turns freely without resistance from the spring.
2. Remove cap screws (key 16) and lift off the spring case (key 2), spring (key 11), upper spring seat (key 9), and diaphragm assembly. (The diaphragm assembly includes the locknut (key 26); pusher post (key 6); lockwasher (key 23); lower spring seat (key 8); diaphragm (key 12); gasket (key 10); and valve plug (key 4). In Type 98LD, there is also a diaphragm head (key 25). Type 98HD has another washer (key 7); and an O-ring (key 45)).

### Note

**Two diaphragms are used if the diaphragm material is metal or Fluorocarbon (FKM) except only for Type 98LD, NPS 1/4, 2 to 7 psi (0,14 to 0,48 bar) range which uses only one metal diaphragm.**

3. Check the orifice (key 3). If it needs replacing or repairing, unscrew the valve plug guide (key 5) and then the orifice. The valve plug can be removed by sliding it off of the pusher post.

### Note

**If damage to elastomer or metal seating surfaces is severe, replace the orifice and valve plug O-ring with new parts. However, by following the lapping procedure below, it is possible to repair metal seating surfaces if they are only slightly worn or scratched.**

4. Lapping procedure:

- a. Place a small amount of 500-grit silicon carbide or aluminum oxide lapping compound on a flat surface such as a piece of heavy plate glass.

- b. Take the valve plug or orifice and move it in a Figure 8 motion on the lapping compound. Do not allow the part to tip or rock since this would round the corners.
- c. Repeat step b for each part, using an 800-grit or 1000-grit silicon carbide or aluminum oxide lapping compound.
- d. Wash away all traces of the lapping compound. To help prevent scratching the seating surfaces, a light coat of oil may be applied before returning the valve plug and orifice to the body.
5. Return the orifice and valve plug guide to the body.
6. To replace the valve plug O-ring (key 22), remove the screw (key 24) and O-ring retainer (key 21) from the plug. Remove and replace the O-ring.
7. Remove the locknut from the pusher post in order to separate the parts of the diaphragm assembly. Inspect and replace if necessary, the diaphragm, diaphragm gasket (key 19, Type 98LD), and pusher post gaskets (key 10, Type 98LD).

### Note

**These relief valves have either a metal or elastomer diaphragm. If a metal diaphragm is to be replaced with an elastomer diaphragm, or an elastomer diaphragm with a metal diaphragm, a new pusher post is required.**

8. If the regulator unit has metal diaphragms:
  - a) Find the pusher post (key 6) and place on a surface with the larger flat surface down and the thread stem up (metal diaphragm pusher post has a recessed diameter in the bottom surface). Then, find one smaller composition gasket (key 10) and fit it over the threaded end of the pusher post. Find and take one of the diaphragm heads and slip it over the threaded end of the pusher post with the chamfered side of the diaphragm head toward the gasket. Take a second gasket and place it over the threaded end of the pusher post on top of the diaphragm head.
  - b) Replace one of the two large diaphragm gaskets (key 19) on the surface of the body that will support the diaphragms. There will be two diaphragms used per regulator, except for Type 98LD, NPS 1/4 with 2 to 7 psi (0,14 to 0,48 bar) outlet setting which uses only one metal




Figure 4. Type 98LD Relief Valve Assembly

Table 2. Torque Specifications

BODY SIZE, NPS (DN)	SPRING CASE, FOOT-POUND (N·m)	ORIFICE, FOOT-POUND (N·m)
1/4	6 to 8 (8,1 to 10,8)	8 to 12 (10,8 to 16,3)
1/2 (15)	10 to 13 (13,6 to 17,6)	29 to 35 (39,3 to 47,5)
3/4 to 1 (20 to 25)	24 to 30 (32,5 to 40,7)	33 to 42 (44,7 to 56,9)
1-1/2 to 2 (40 to 50)	40 to 50 (54,2 to 67,8)	140 to 170 (190 to 231)

diaphragm (the metal diaphragm is in between two diaphragm gaskets). Another diaphragm gasket is placed above the second diaphragm. The raised surfaces of the metal diaphragms should be placed in the unit so that they are facing toward the assembler (toward the spring) except only when one metal diaphragm is being used then the raised surface should be facing down (towards the body). See Figures 4 and 5 as references.

9. Put the diaphragm assembly into position in the body.
10. Replace the packing as instructed below.

## Disassembly to Replace Packing

Leakage around the adjusting screw may be caused by worn packing in the packing box. To check the packing, follow the instructions below.

1. Before returning the upper spring case to the body, replace the packing (key 36) in the packing box (key 32).
2. Take out the machine screw (key 41) and lift off the washer (key 44) and handwheel (key 38).
3. Unscrew the packing box. Unscrew the packing nut (key 35) and take it and the packing follower (key 34) off of the adjusting screw (key 33).
4. Unscrew and pull the adjusting screw out through the bottom of the packing box.
5. Pull out the packing (key 36) and replace it. Replace the packing box gasket (key 37).

# Types 98LD and 98HD

6. Reassemble the packing box unit by returning the adjusting screw to the inside of the packing box. Slip the packing follower onto the adjusting screw and into the packing box. Screw on the packing nut. See Table 2 for torque specifications.
7. Put the packing box onto the spring case. Set the handwheel and washer on the adjusting screw and screw in the machine screw.
8. Set the spring and upper spring seat over the lower spring seat. Place the spring case on the body, tightening the cap screws finger-tight only.
9. To ensure proper slack in the diaphragm, apply some spring compression by turning the adjusting screw clockwise. Tighten the cap screws.

## Parts Ordering

When corresponding with your local Sales Office about this equipment, always reference the equipment serial number stamped on the nameplate.

When ordering replacement parts, specify the complete 11-character part number of each required part as found in the following parts list. Separate kits containing all recommended spare parts are available.

## Parts List

### Note

**In this parts list, parts marked NACE are intended for corrosion-resistant service as detailed in the NACE International standard MR0175-92.**

Key	Description	Part Number	Part Number
	Parts kit (included are keys 3, 4, 10, 12, 19, 21, 22 and 24)		
	Type 98HD		
	Elastomer Trim		
	NPS 1/4 body	R98HX000012	
	NPS 1/2 (DN 15) body	R98HX000022	
	NPS 3/4 and 1 (DN 20 and 25) bodies	R98HX000032	
	NPS 1-1/2 and 2 (DN 40 and 50) bodies	R98HX000072	
	Metal Trim		
	NPS 1/4 body	R98HX000042	
	NPS 1/2 (DN 15) body	R98HX000052	
	NPS 3/4 and 1 (DN 20 and 25) body	R98HX000062	
	NPS 1-1/2 and 2 (DN 40 and 50) bodies	R98HX000082	
1	Body		See following table
2	Spring Case		
	Type 98HD		
	Steel		
	NPS 1/4 body	2L443222012	
	NPS 1/2 (DN 15) body	2L324122012	
	NPS 3/4 and 1 (DN 20 and 25) bodies	3E408822012	
	316 SST		
	NPS 1/4 body	2L443233092	
	NPS 1/2 (DN 15) body	2L3241X0012	
	NPS 3/4 and 1 (DN 20 and 25) bodies	3E4088X00A2	
	Type 98LD		
	Steel		
	NPS 1/4 body	2L443422012	
	NPS 1/2 (DN 15) body	3L324222012	
	NPS 3/4 and 1 (DN 20 and 25) bodies	4F432322012	
	316 SST		
	NPS 1/4 body	2L4434X0012	
	NPS 1/2 (DN 15) body	3L3242X0012	
	NPS 3/4 and 1 (DN 20 and 25) bodies	4F4323X0022	
3*	Orifice		See following table
4*	Valve Plug		See following table
5	Valve Plug Guide		
	416 SST		
	NPS 1/4 body	1L345835132	
	NPS 1/2 (DN 15) body	1L341635132	
	NPS 3/4 and 1 (DN 20 and 25) bodies	1L342935132	
	316 SST		
	NPS 1/4 body (NACE)	1L345835072	
	NPS 1/2 (DN 15) body (NACE)	1L3416X0102	
	NPS 3/4 and 1 (DN 20 and 25) bodies (NACE)	1L342935072	
6	Pusher Post		See following table
7	Washer (elastomer diaphragm only)		
	416 SST		
	NPS 1/4 body	1L344736012	
	NPS 1/2 (DN 15) body	1L339836012	
	NPS 3/4 and 1 (DN 20 and 25) bodies	1L342836012	
	316 SST		
	NPS 1/4 body (NACE)	1L344736142	
	NPS 1/2 (DN 15) body (NACE)	1L339835072	
	NPS 3/4 and 1 (DN 20 and 25) bodies (NACE)	1L342836142	
8	Lower Spring Seat		
	NPS 1/4 body, Aluminum	1L344609012	
	NPS 1/2 (DN 15) body, Aluminum	1L339708012	
	NPS 3/4 and 1 (DN 20 and 25) bodies, Aluminum	1L342708012	
9	Upper Spring Seat, Steel		
	NPS 1/4 body	1B798525062	
	NPS 1/2 (DN 15) body	1D667125072	
	NPS 3/4 and 1 (DN 20 and 25) bodies	1E398725072	
10*	Gasket, Composition		
	(2 required for metal diaphragm)		
	NPS 1/4 body	1L344804022	
	NPS 1/2 (DN 15) body	1L341104022	
	NPS 3/4 and 1 (DN 20 and 25) bodies	1L343404022	
11	Relief Valve Spring		
	Steel plate		See following table
12*	Diaphragm		
	NPS 1/4 body		
	Type 98LD		
	Neoprene (CR)	1L345302112	
	Fluorocarbon (FKM) (2 required)	1L345302402	
	302 SST (2 required)	1L345436012	
	Type 98HD		
	Neoprene (CR)	1L344902112	
	Fluorocarbon (FKM) (2 required)	1L344902402	
	302 SST (2 required)	1L345036012	

\*Recommended spare part.

# Types 98LD and 98HD




Figure 5. Type 98HD Relief Valve Assembly

Key	Description	Part Number	Key	Description	Part Number
12*	Diaphragm (continued) NPS 1/2 (DN 15) body Type 98LD Neoprene (CR) Fluorocarbon (FKM) (2 required) 302 SST (2 required) Type 98HD Neoprene (CR) Fluorocarbon (FKM) (2 required) 302 SST (2 required) NPS 3/4 and 1 (DN 20 and 25) bodies Type 98LD Neoprene (CR) Fluorocarbon (FKM) (2 required) 302 SST (2 required) Type 98HD Neoprene (CR) Fluorocarbon (FKM) (2 required) 302 SST (2 required)	1L341302112 1L341302402 1L341436012 1L341202112 1L341202402 1L339936012 1L342302112 1L342302402 1L342236012 1L343302112 1L3433X0032 1L343236012	16	Cap Screw, Steel plate Type 98LD NPS 1/4 body (10 required) NPS 1/2 (DN 15) body (10 required) NPS 3/4 and 1 (DN 20 and 25) bodies (12 required) Type 98HD NPS 1/4 body (6 required) NPS 1/2 (DN 15) body (8 required) NPS 3/4 and 1 (DN 20 and 25) bodies (8 required)	1A407824052 1A381624052 1A336924052 1A391724052 1A352624052 1A341824052 1A368228982
13	Nameplate	- - - - -	18	Drive Screw, SST (2 required) (not shown)	1A368228982
			19*	Diaphragm Gasket (Use with 302 SST diaphragm) Type 98LD NPS 1/4 body (2 required) NPS 1/2 (DN 15) body (2 required) NPS 3/4 and 1 (DN 20 and 25) bodies (2 required)	1E394004022 1E397004022 1E390404022

\*Recommended spare part.

# Types 98LD and 98HD

Key	Description	Part Number	Key	Description	Part Number
19*	Diaphragm Gasket (continued) (Use with 302 SST diaphragm) Type 98HD NPS 1/4 body (2 required) NPS 1/2 (DN 15) body (2 required) NPS 3/4 and 1 (DN 20 and 25) bodies (2 required)		34	Packing Follower NPS 1/4 body, 316 SST NPS 1/2, 3/4, and 1 (DN 15, 20, and 25) bodies	1K885035072
21	O-Ring Retainer (elastomer seat only) NPS 1/4 body 416 stainless steel 316 stainless steel (NACE) NPS 1/2 (DN 15) body 416 stainless steel 316 stainless steel (NACE) NPS 3/4 and 1 (DN 20 and 25) bodies 416 stainless steel 316 stainless steel (NACE)	1E393104022 1E397004022 1E399304622	35	Packing Box Nut Steel zinc-plated	1K884924092 0P077624102
22*	O-Ring (elastomer seat only) NPS 1/4 body Nitrile (NBR) Fluorocarbon (FKM) NPS 1/2 (DN 15) body Nitrile (NBR) Fluorocarbon (FKM) NPS 3/4 and 1 (DN 20 and 25) bodies Nitrile (NBR) Fluorocarbon (FKM)	1L346035132 1L346035072 1L341535232 1L341535072 1L343035132 1L343035072	36*	Packing, PTFE (3 required) NPS 1/4 body NPS 1/2, 3/4, 1, 1-1/2, and 2 (DN 15, 20, 25, 40, and 50) bodies	1C752601012 1H784301012
23	Lockwasher, Steel NPS 1/4 and 1/2 (DN 15) bodies NPS 3/4 and 1 (DN 20 and 25) bodies	1C853806992 1C8538X0052	37*	Packing Box Gasket, Steel/composition NPS 1/4 body NPS 1/2, 3/4, 1, 1-1/2, and 2 (DN 15, 20, 25, 40, and 50) bodies	1B487099202 1N499199202
24	Machine Screw, Stainless steel (Elastomer seat only) NPS 1/4 body (NACE) NPS 1/2 (DN 15) body (NACE) NPS 3/4 and 1 (DN 20 and 25) bodies NPS 3/4 and 1 (DN 20 and 25) bodies (NACE)	1C225628982 1H624328992	38	Handwheel NPS 1/4 body NPS 1/2, 3/4, and 1 (DN 15, 20, and 25) bodies NPS 1-1/2 and 2 (DN 40 and 50) bodies	1L217544992 1L369644992 1J410819042
25	Diaphragm Head Type 98LD, Steel zinc-plated NPS 1/4 body NPS 1/2 (DN 15) body NPS 3/4 and 1 (DN 20 and 25) bodies	1L346238992 1J4159X0012 1L343538992	39*	Female Adaptor, PTFE NPS 1/4 body NPS 1/2, 3/4, 1, 1-1/2, and 2 (DN 15, 20, 25, 40, and 50) bodies	1F124401012 1H784401012
26	Locknut, Steel zinc-plated NPS 1/4 and 1/2 (DN 15) bodies NPS 3/4 and 1 (DN 20 and 25) bodies	1L342125072	40*	Male Adaptor, PTFE NPS 1/4 body NPS 1/2, 3/4, 1, 1-1/2, and 2 (DN 15, 20, 25, 40, and 50) bodies	1F124801012 1H784201012
32	Packing Box, Steel NPS 1/4 body NPS 1/2, 3/4 and 1 (DN 15, 20 and 25) bodies NPS 1-1/2 and 2 (DN 40 and 50) bodies, Type 98H only	1L449624092	41	Machine Screw, steel plate NPS 1/4 body NPS 1/2, 3/4 and 1 (DN 15, 20 and 25) bodies NPS 1-1/2 and 2-inch (DN 40 and 50) bodies	1A340828992
33	Adjusting Screw, SST NPS 1/4 body NPS 1/2 (DN 15) body NPS 3/4 and 1 (DN 20 and 25) bodies NPS 1-1/2 and 2 (DN 40 and 50) bodies, Type 98H only	1L449535232 1L449735232 1L324435232	42	Spring, 316 stainless steel Washer, 316 stainless steel NPS 1/4 body NPS 1/2, 3/4, and 1 (DN 15, 20, and 25) bodies	1F125437012 1F125236042 1H981836042
		21A9808X012	43	Washer, Steel NPS 1/4 body NPS 1/2, 3/4, and 1 (DN 15, 20, and 25) bodies	1A329128982
			44	NPS 1-1/2 and 2 (DN 40 and 50) bodies, Type 98H only	1A352332992
			45*	O-Ring, Nitrile (NBR) (Use with elastomer diaphragm) NPS 1/4 and 1/2 (DN 15) bodies NPS 3/4 and 1 (DN 20 and 25) bodies NPS 1-1/2 and 2 (DN 40 and 50) bodies Type 98H only	1E794128992
			51	NACE Tag	1D687506992
			52	Tag Wire (NACE)	1E547706992 1C782206992 19A6034X012 1U7581X0022

\*Recommended spare part.

# Types 98LD and 98HD

## Key 1 Regulator Body, NPT

BODY SIZE, NPS (DN)	TYPE 98HD BODY MATERIAL			TYPE 98LD BODY MATERIAL		
	Cast Iron	Steel	Stainless Steel	Cast Iron	Steel	Stainless Steel
1/4	1L346419012	1L372122012	1L372133092	1L346519012	1L372322012	1L372333092
1/2 (15)	2L339519012	2L368722012	2L368733092	2L339219012	2L368922012	2L368933092
3/4 (20)	2L342519012	2L373422012	2L373433092	2L341919012	2L318222012	2L318233092
1 (25)	2L342619012	2L373522012	2L373533092	2L342019012	2L318322012	2L318333092
1-1/2 (40)	3P786819012	3P786822012	3P786833092	----	----	----
2 (50)	3P786719012	3P786722012	3P786733092	----	----	----

## Key 1 Regulator Body, ASME CL150 and CL300 Flanges

BODY SIZE, NPS (DN)	TYPE 98HD BODY MATERIAL				TYPE 98LD BODY MATERIAL			
	Steel		Stainless Steel		Steel		Stainless Steel	
	CL150 RF	CL300 RF	CL150 RF	CL300 RF	CL150 RF	CL300 RF	CL150 RF	CL300 RF
1/2 (15)	1V5178X0012	20A4987X0A2	1V5178X0022	20A4987X012	25A9930X022	20A4701X012	25A9930X012	20A4701X022
3/4 (20)	15A6098X022	23B9543X022	15A6098X012	23B9543X012	2V4264X0022	14B2317X012	2V4264X0012	14B2317X022
1 (25)	2V3805X0012	2U8048X0012	2V3805X00B2	2U8048X0022	2V3641X0022	2U8047X0012	2V3641X0012	2U8047X0062
1-1/2 (40)	21B0804X012	1V4541X0012	21B0804X022	1V4541X0022	----	----	----	----
2 (50)	10A0192X012	10A4986X012	10A0192X022	10A4986X052	----	----	----	----

## Key 1 Regulator Body, SWE

BODY SIZE, NPS (DN)	TYPE 98HD BODY MATERIAL			TYPE 98LD BODY MATERIAL		
	Steel	Stainless Steel	Steel	Stainless Steel	Steel	Stainless Steel
1/2 (15)	2L9673X0022	2L9673X0012	2U8059X0012	2U8059X0022		
3/4 (20)	2N443922012	2N4439X0012	2N4463X0012	2N4463X0022		
1 (25)	2N414422012	2N4144X0012	2N445222012	2N4452X0012		
1-1/2 (40)	3V4542X0012	3V4542X0022	----	----		
2 (50)	30A0191X012	30A0191X032	----	----		

## Key 3\* Orifice

BODY SIZE, NPS (DN)	METAL TO METAL		ELASTOMER SEAT			
			NACE	For Other Than Sour Gas Corrosion Resistance Applications		
	416 SST	316 SST		416 SST	316 SST	
1/4	1E391646172	1E391635072	1L345935072	1L345935132	1L345935072	
1/2 (15)	1E395046172	1E395035072	1L341735072	1L341735132	1L341735072	
3/4, 1 (20, 25)	1E398046172	1E398035072	1L343135072	1L343135132	1L343135072	
Type 98HD only 1-1/2, 2 (40, 50)	2P787046172	2P787035072	1P787135072	1P787135132	1P787135072	

## Key 4\* Valve Plug

BODY SIZE, NPS (DN)	METAL TO METAL		ELASTOMER SEAT			
			NACE	For Other Than Sour Gas Corrosion Resistance Applications		
	416 SST	316 SST		416 SST	316 SST	
1/4	1L345246172	1L345235072	1L345135072	1L345135132	1L345135072	
1/2 (15)	1L344146172	1L344135162	1L344335072	1L344335132	1L344335072	
3/4, 1 (20, 25)	1L343746172	1L343735162	1L343635072	1L343635132	1L343635072	
Type 98HD only 1-1/2, 2 (40, 50)	1P787246172	1P787235072	1P787335072	1P787346172	1P787335072	

\*Recommended spare part.

# Types 98LD and 98HD

## Key 6 Pusher Post

BODY SIZE, NPS (DN)	METAL TO METAL		ELASTOMER SEAT		
			NACE	For Other Than Sour Gas Corrosion Resistance Applications	
	416 SST	316 SST		416 SST	316 SST
1/4 1/2 (15) 3/4, 1 (20, 25)	1L345735132 1L344535132 1L343935132	1L345735072 1L344535072 1L343935072	1L345635072 1L344235072 1L343835072	1L345635132 1L344235132 1L343835132	1L345635072 1L344235072 1L343835072
Type 98HD only 1-1/2, 2 (40, 50)	1P788335132	1P788335072	1P788435072	1P788435132	1P788435072

## Key 11 Relief Valve Spring

BODY SIZE, NPS (DN)	TYPE 98LD RANGE		TYPE 98HD RANGE		COLOR CODE	PART NUMBER
	Psi	bar	Psi	bar		
1/4	2 to 7	0,14 to 0,48	15 to 35	1,0 to 2,4	Yellow	1E392527022
	6 to 14	0,41 to 0,97	25 to 75	1,7 to 5,2	Green	1E392627012
	12 to 25	0,83 to 1,7	70 to 140	4,8 to 9,7	Red	1E392727142
	20 to 38	1,4 to 2,6	130 to 200	9,0 to 13,8	Blue	1L346127142
1/2 (15)	2 to 7	0,14 to 0,48	15 to 35	1,0 to 2,4	Yellow	1E395627022
	6 to 14	0,41 to 0,97	25 to 75	1,7 to 5,2	Green	1D7455T0012
	12 to 25	0,83 to 1,7	70 to 140	4,8 to 9,7	Red	1E395727192
	20 to 38	1,4 to 2,6	130 to 200	9,0 to 13,8	Blue	1L380027142
3/4 and 1 (20 and 25)	2 to 7	0,14 to 0,48	15 to 35	1,0 to 2,4	Yellow	1E398927022
	6 to 14	0,41 to 0,97	25 to 75	1,7 to 5,2	Green	1E399027142
	12 to 25	0,83 to 1,7	70 to 140	4,8 to 9,7	Red	1E399127162
	20 to 38	1,4 to 2,6	130 to 200	9,0 to 13,8	Blue	1L380127092
1-1/2 and 2 (40 and 50)	----	----	5 to 35	0,34 to 2,4	Dark Gray	1E792327092
	----	----	20 to 65	1,4 to 4,5	Light Blue	1E795327082
	----	----	50 to 100	3,4 to 6,9	Light Gray	1E794527082
			80 to 170	5,5 to 11,7	Black	1P788827082

### Industrial Regulators

#### Emerson Process Management Regulator Technologies, Inc.

USA - Headquarters  
McKinney, Texas 75069-1872 USA  
Tel: 1-800-558-5853  
Outside U.S. 1-972-548-3574

Asia-Pacific  
Shanghai, China 201206  
Tel: +86 21 2892 9000

Europe  
Bologna, Italy 40013  
Tel: +39 051 4190611

Middle East and Africa  
Dubai, United Arab Emirates  
Tel: +971 4811 8100

### Natural Gas Technologies

#### Emerson Process Management Regulator Technologies, Inc.

USA - Headquarters  
McKinney, Texas 75069-1872 USA  
Tel: 1-800-558-5853  
Outside U.S. 1-972-548-3574

Asia-Pacific  
Singapore, Singapore 128461  
Tel: +65 6777 8211

Europe  
Bologna, Italy 40013  
Tel: +39 051 4190611

Gallardon, France 28320  
Tel: +33 (0)2 37 33 47 00

### TESCOM

#### Emerson Process Management Tescom Corporation

USA - Headquarters  
Elk River, Minnesota 55330-2445 USA  
Tel: 1-763-241-3238

Europe  
Selmsdorf, Germany 23923  
Tel: +49 (0) 38823 31 0

For further information visit [www.emersonprocess.com/regulators](http://www.emersonprocess.com/regulators)

The Emerson logo is a trademark and service mark of Emerson Electric Co. All other marks are the property of their prospective owners. Fisher is a mark owned by Fisher Controls, Inc., a business of Emerson Process Management.

*The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. We reserve the right to modify or improve the designs or specifications of such products at any time without notice.*

Emerson Process Management does not assume responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use and maintenance of any Emerson Process Management product remains solely with the purchaser.



**EMERSON**  
Process Management™