




Enecsys Micro-Inverters Double Repeater User Manual



Version 1.0

CONTENTS

Introduction	1
Conventions used in this manual	2
Safety	3
Scope of delivery	4
Enecsys Double Repeater	5
When to install an Enecsys Double Repeater	5
Installation	6
Attaching the internal antenna	7
Mounting the Enecsys Double Repeater	8
Wall mounting the Enecsys Double Repeater (adhesive pad method)	9
Wall mounting the Enecsys Double Repeater (screw fixed method)	10
Mounting with a cable tie	11
Installing the external antenna	12
Turning the Enecsys Double Repeater on	13
Turning the Enecsys Double Repeater off	14
Technical specification	15
Compliance	18
Printing	19

1. Introduction

This manual contains information specific to the installation of an Enecsys Double Repeater. Although the installation is simple a basic knowledge of internet routers, wired or wireless may be beneficial although not necessary. Installation of the Enecsys Double Repeater is a 'plug and play'. Enecsys have designed the hardware to be as simple as possible for the installer and end-user alike.

Your solar PV (photo-voltaic) installation, when combined with an Enecsys Micro-Inverter with its in-built wireless antenna is able to communicate wirelessly with the Gateway. This allows for comprehensive monitoring of the solar PV array, module-by-module.

Monitoring an array module by module enables the user to see energy generation at module level. Monitoring also allows the end-user to see the performance of any module at any time of the day.

An Enecsys Double Repeater acts as a bridge between the Micro-inverter and the Gateway in situations where a sufficient communication link cannot be established.

For circumstances where it may be necessary to install an Enecsys Double Repeater, [See “When to install an Enecsys Double Repeater” on page 5.](#)

1.1 Conventions used in this manual

The following conventions are used throughout this manual, these conventions should be noted and followed at all times.



Warning: Warning statements must be heeded at all times. A warning symbol indicates that a process or instrument has the potential to harm or cause lethal injury if the correct method of handling is not employed.



Caution: Caution statements are used to indicate where a part of the installation process may require special attention. Caution statements should be followed at all times.



Attention: Attention statements are used to indicate where a part of the process or instrument has a special requirement. Attention statements should be followed at all times.

1.2 Safety

Before installing and using the any Enecs Sys Repeater please ensure that you have fully read and understand all of the installation and user instructions and heed all warnings and cautions given. Install in a clean dry environment, indoors and if possible away from heat sources and out of direct sunlight.



- All electrical installations should be performed in accordance with all local and national electrical installation codes and practice.
- There are no user serviceable parts inside this unit.
- There are no replaceable or re-chargeable batteries contained within the Repeater.



- Do not attempt to open the unit. Tampering with the Repeater may result in electrical shock or death.



- Do not install this equipment in adverse weather conditions or in a wet environment.
- Do not install this equipment during an electrical storm.

1.3 Scope of delivery

The following list details the scope of delivery, please ensure that all parts are present before starting the installation.

- A. 1 x Enecsys Double Repeater.
- B. 1 x Fixed antenna.
- C. 1 x External antenna.
- D. 1 x Coaxial cable reverse polarity with RP SMA connectors, 15 - 30 meter lengths.
- E. 1 x Plug-top 5V DC, 1A adaptor with 2.1mm jack.
- F. 3 x Double sided adhesive pads.




FIGURE I. Scope of delivery.

1.4 Enecsys Double Repeater

The Enecsys Double Repeater provides a 'hop' between nodes in a network. The Enecsys Double Repeater is used to allow communication between the Micro-inverters and Gateway where the propagation losses are too high for a reliable communication link, particularly where metallic structures prevent RF propagation. There are various implementations of Enecsys Double Repeaters, more than one Enecsys Double Repeater can be used to cover larger distances. An Enecsys Double Repeater differs from a Single Repeater in that two antennas are used. One antenna can be connected via coaxial cable to an external antenna, positioned on the roof, close to the inverters. The second antenna communicates with the Gateway located in the house.

1.5 When to install an Enecsys Double Repeater

Depending upon the house construction and build materials it may be necessary to add an Enecsys Double Repeater in order to provide stable communications between the inverters and the Gateway over a long time period. An Enecsys Double Repeater is used in situations where a Single Repeater is unable to provide the Gateway with a strong sustainable communication link.

The Enecsys Double Repeater acts a bridge between the Micro-inverter and the Gateway, improving the communication link and providing an uninterrupted flow of information between the two devices. Certain building materials can prevent a strong signal from being established in the communication link.

- A roof may be made out a metallic material or be a foil insulated.
- The distance between the micro-inverters and the wireless antenna is too great.
- UV screened windows.

2. Installation

Enecsys Double Repeaters are employed to improve the communication link between the inverters and the Gateway. The Enecsys Double Repeater is a 'plug and play' device; it is quickly and easily installed. The Enecsys Double Repeater should be installed within the roof-space of the building and positioned within easy connection distance of a mains supply AC power source.




FIGURE 2. The Enecsys Double Repeater.

© ENECSYS 2010. All rights reserved.

2.1 Attaching the internal antenna

Attach the antenna to the RP SMA connector on the right hand side of the Enecsys Gateway.

1. Attach the antenna to the lower SMA plug on the right hand side of the Repeater, screw the antenna into place in a clockwise direction.
2. Move the antenna into an upright position.




FIGURE 3. Attaching the antenna.

2.2 Mounting the Enecsys Double Repeater

The Enecsys Double Repeater can be either free standing or wall mounted. In each case the Enecsys Double Repeater should be installed in a location where it is unlikely to be moved, indoors, away from heat sources and out of direct sunlight. If choosing a free standing Enecsys Double Repeater installation simply place the Enecsys Double Repeater within reach of a power source. It is recommended that the Enecsys Double Repeater be placed as high as possible within the building such as the loft space.




FIGURE 4. The Enecsys Double Repeater reverse showing mounting points and distances.

2.3 Wall mounting the Enecsys Double Repeater (adhesive pad method)

When mounting an Enecsys Double Repeater always ensure that you have connected the power supply and antenna to the device before the final fit. Locate the Enecsys Double Repeater away from metal structures.

The adhesive pad placement areas are shown in [Figure 4 on page 8](#).

1. Ensure that the back-plate of the Enecsys Double Repeater and the wall or mounting surface is clean from dust and grease.
2. Connect the supplied external 5V DC power supply to a mains supply AC power source.
3. Connect the supplied external 5V DC power jack-plug to the DC power port on the reverse of the Enecsys Double Repeater, thread the cable through the semi-circular channel on the back-plate of the Enecsys Double Repeater, this will help to keep the cable in place and prevent it from becoming detached.
4. Remove the backing material from one of the double sided adhesive pads and place firmly onto the fixing points on the back of the Enecsys Double Repeater. Complete the process for the remaining two double sided adhesive pads.
5. Remove the remaining backing material from the adhesive pads attached to the back-plate of the Enecsys Double Repeater, press the Enecsys Double Repeater firmly into place on the wall/mounting surface.

2.4 Wall mounting the Enecsyz Double Repeater (screw fixed method)

When mounting an Enecsyz Double Repeater always ensure that you have connected the power supply and antenna to the device before the final fit.

The screw fixing points are shown in [Figure 4 on page 8](#).

1. Attach the antenna to the SMA plug on the right hand side of the Enecsyz Double Repeater, screw the antenna into place in a clockwise direction.
2. Connect the 5V DC power supply jack-plug to the DC power port on the reverse of the Enecsyz Double Repeater, thread the cable through the semi-circular channel on the back-plate of the Enecsyz Double Repeater, this will help to keep the cable in place and prevent it from becoming detached.
3. Select the appropriate location for mounting the Enecsyz Double Repeater.
4. Using the wall mount template locate the desired position of the Enecsyz Double Repeater; ensure that there is adequate free-space around the Enecsyz Double Repeater to allow for any future movement or maintenance of the device.
5. Mark two horizontal spots on the wall 50 millimetres apart, install the screws into the wall.
6. Line up the back plate holes of the Enecsyz Double Repeater with the screws on the wall and then slide the Enecsyz Double Repeater down to fix the unit in position.

2.5 Mounting with a cable tie

When mounting a Enecsys Double Repeater always ensure that you have connected the power supply and antenna to the device before the final fit.

There may be situations where it is not possible to mount the Enecsys Double Repeater using the screw fixed or adhesive pad method. A cable tie can be utilised to fix the Enecsys Double Repeater to an internal pillar or suitable structure.

1. Ensure that the cable tie is of the correct width and length.
2. Run the cable tie through the cable tie fixing point on the back of the Enecsys Double Repeater.
3. Wrap the cable tie around the internal pillar or suitable mounting object and secure.




FIGURE 5. Mounting with a cable tie.

2.6 Installing the external antenna

When installing an external antenna always make sure that cable entry to building is waterproofed.

Always ensure that the cable isn't arranged such that water or condensate can run down coaxial cable and onto the repeater.

1. Ensure that you have enough coaxial cable to reach from the mounting point to the Enecsys Double Repeater.
2. Secure the external antenna to the mounting rack of the solar array or other suitable structure using two self-tapping screws. Cable ties may also be used to hold the antenna in a secure position.
3. Connect the co-ax cable the bottom of the external antenna and screw into place.
4. Feed the coaxial cable through the installed cabling conduit and into the loft space of the building, use cable ties to hold the co-axial cable in place.
5. Connect the SMA connector (male) to the upper SMA connector (female) on right hand side of the Enecsys Double Repeater, screw the connector into place in a clockwise direction.
6. Secure the external coaxial.

2.7 Turning the Enecsys Double Repeater on

The Enecsys Double Repeater comes supplied with an external 5V DC power supply. The power adaptor serves as the disconnect device - a socket outlet in accordance to the national wiring codes for the country shall be installed near the equipment and shall be easily accessible.

To turn the Enecsys Double Repeater on feed the power cable through the power cable conduit, attach the 5V DC power supply jack-plug from the power port on the reverse of the Repeater.




FIGURE 6. Connecting the Enecsys Double Repeater's power supply.

2.8 Turning the Enecsys Double Repeater off

The Enecsys Double Repeater comes supplied with a 5V DC external power supply. The power adaptor serves as the disconnect device - a socket outlet in accordance to the national wiring codes for the country shall be installed near the equipment and shall be easily accessible.




FIGURE 7. Disconnecting the Enecsys Double Repeater's power supply.

3. Technical specification

Power	
Mains	Plug-top P.S.U.
	Input: 100-240V AC 50-60Hz 0.3A.
	Output; 5V DC, 1.2A. with 2.1mm jack.

Table 1: Power adapter.

Operating Temperature	
Temperature range	10°C to +40°C.

Table 2: Operating temperature.

Interface Specifications	
Ethernet Interface	RJ45, 10Base-T or 100Base-TX.

Table 3: Interface specification.

Life Expectancy	
Usable lifetime	12 months warranty.

Table 4: Life expectancy.

Fixed Internal Antenna	
Radiating element	1/2 Wave Element.
Frequency range	2.4 GHz.
Peak gain	2.0 dBi.
Polarisation	Linear.
Connector	SMA Male.
Dimensions	139 x 13mm.

Table 5: Fixed antenna.

*External Antenna	
Radiating element	1/2 Wave Element
Frequency range	2.4 GHz
Peak gain	2.0 dBi
Polarisation	Linear
Return loss	-13 dB
Connector	SMA Male
Dimensions	139 x 13mm

Table 6: External Antenna.

*External Antenna - For a detailed technical description of installation of the external antenna please refer to external antenna installation guide.

4. Compliance

Enecsys Double Repeaters conform to the following compliance codes.

IC: 9052A-DEREP01

FCC: YIWDEREPEATER0001

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Changes or modifications made to this device that are not expressly approved by Enecsys Ltd may void the user's authority to operate the equipment.

Electrical Product Safety

IEC 60950-1:2005 (2nd Edition); Am 1:2009;

Compliance with National Differences :IEC60950_1B attachment EN60950-1:2006/A11:2009/A1:2010

EMC

EN 301 489-17 V2.1.1 - ElectroMagnetic compatibility and Radio spectrum Matters (ERM); ElectroMagnetic Compatibility (EMC) standard for radio equipment and services; Part 1: Common Technical Requirements.

Spectrum

EN 300 328 V1.7.1 - (Radio Module) Electromagnetic Compatibility and Radio Spectrum Matters (ERM) Wideband transmission systems; Data transmission equipment operating in the 2.4GHz

ISM band and using wideband modulation techniques; Harmonised EN covering essential requirements under article 3.2 of the R&TTE Directive.

5. Printing

Please print this manual once and then keep it in a safe place for future reference.

If you intend to dispose of this manual please recycle.



Please Recycle



Enecsys Limited

Harston Mill, Royston Rd
Cambridge, CB22 7GG, UK

T: +44 (0) 1223 792 101

F: +44 (0) 1223 792 103

E: info@enecsys.com

www.enecsys.com

Registered Office:

Enecsys Limited, 24 Hills Road,
Cambridge, CB2 1JP, England

Registration No: 04832321

Document reference: ENEC-DOC-012