

刀模线不印刷

尺寸：85*110mm

材质：80g书纸，正反面单色印刷，4折页

正面印刷

M/N: 5B575BT



WLCS-12/0836 Wireless LED Flashing Light Cube Speaker



INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY
& RETAIN FOR FUTURE USE

1

Getting Started

Remove the speaker from the box. Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

Package Contents

Wireless LED Flashing Light Cube Speaker
Instruction manual

Features


- Bluetooth Speaker
- LED Flashing Lights
- Built-in Rechargeable Battery
- Streams Music Wirelessly
- Use as Hands-Free speaker phone device, with a built-in microphone
- Built-in Micro SD (TF) card slot
- Built-in aux jack

IMPORTANT SAFETY INFORMATION

- Read all instructions before using this product.
- Do not leave this product unattended while connected to the power supply.
- Do not immerse in water or any other liquids.
- Do not use if unit has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by qualified personnel. Improper repairs may place user at serious risk.
- Place unit on sound, even surface, free of vibrations and away from sources of heat.
- Do not use with wet hands.
- Do not put objects into openings.
- Keep free of dust, lint, hair etc.
- Do not use this unit for anything other than its intended use.
- Keep this product out of reach of children.
- This product is not a toy.
- Do not play music at excessive levels especially near children, as damage to hearing may occur.

2

DESCRIPTION OF PARTS



1	Micro SD (TF) card slot	6	Mode Button / LED Flashing Light Button
2	USB Charging Port	7	Skip Backward / Decrease Volume (-)
3	Charge Indicator	8	ON/OFF/Play/Pause/Phone Button
4	Skip Forward / Increase Volume (+)	9	Speaker
5	AUX-Input	10	Built-in Mic

INSTRUCTIONS FOR USE

Charging the speaker

For best results, fully charge the speaker before use.

- Connect the USB cord (included) to the charging port of the speaker and insert the other end into a port on your computer or similar suitable power source.
- The Red LED turns on, indicating that the battery is being charged. Once it is fully charged, the Red LED will turn off. It takes about 2 hours to charge the speaker fully.

Turn On/Off the Speaker

Press and hold the ON/OFF button for 2-3 seconds to turn on/off the unit.

LED Flashing Light Mode

- Turn ON the speaker.
- Short press the LED Flashing Light button once to change different LED Flashing Light Mode.

3

IMPORTANT: SPEAKER & LED LIGHTS WORK INDEPENDENTLY OF EACH OTHER. THESE TWO FUNCTIONS CAN WORK TOGETHER AS WELL INDEPENDENT OF EACH OTHER.

Switch the speaker to Bluetooth pairing mode -

- Turn ON the speaker.
- You would hear the indication tone, and blue LED lights will flash. The speaker is now in pairing mode.

(Note: Speaker will automatically pair with previously paired devices)

Pairing your device with Bluetooth Speaker -

Your Bluetooth Speaker can wirelessly stream audio from any Bluetooth enabled device within 27-33 Feet. Simply follow the below steps.

- Turn ON the speaker.
- You would hear the indication tone, and blue LED lights will flash. The speaker is now in pairing mode.
- Turn on the Bluetooth on your Mobile Phone or Tablet or Computer.
- It will search for various devices.
- The pairing name of our Bluetooth Speaker is "SL CUBIC SPKR", pair it with this device.
- If required, enter the password '0000' to confirm to finalize pairing.
- Once paired successfully, you would hear another indication tone.
- If you fail to pair it within the time frame or you want to pair it with a new device please follow the steps outlined above.

Select your favorite song at the Bluetooth device and music would now stream through bluetooth speaker.

Talking using the Bluetooth Speaker

Please ensure that your cell phone is paired with the Bluetooth Speaker to use the below functions.

Function	Operation	Button
Answer Incoming Call	Incoming Call	Press the Phone button once to answer an incoming call.
End Call	Incoming Call	After your phone conversation, short press the Phone button
Volume Increase	During a call	Long press on the + button will increase the volume
Volume Decrease	During a call	Long press on the - button will decrease the volume
Redial last number	Standby mode and connected to a device	Short press the Phone button twice

4

反面印刷

Listening to Music Wirelessly

Please ensure that your device (iPhone, Tablet or Other Smart Phone) is paired with the Bluetooth Speaker to stream music wirelessly. Once it is paired, play music from your device.

Function	Operation	Button
Increase Volume	Playing music	Long press on the + button once will increase the volume
Decrease Volume	Playing music	Long press on the - button once will decrease the volume
Pause	Playing music	Short press Play/Pause once to pause the music
Play	Pause	Short press Play/Pause once resume the music
Previous track	Playing music	Short press the - button to the previous track
Next track	Playing music	Short press the + button to the next track

Aux function of the Speaker (to play music from non-Bluetooth devices)

- Turn on the speaker.
- Plug the 3.5 mm auxiliary cord (included) in to the auxiliary port of the speaker. And, connect the other end of the cable to the audio device (such as MP3 Players / computer / tablet etc.).
- Select your favorite song at the source device.

Note: Once AUX cable is connected to the Speaker, music through the Bluetooth will be stopped. Functions (except increase/decrease volume) like Skip Backward, Skip Forward etc can be only controlled through source devices, while playing music in Auxiliary mode.

Listening to Music using Micro SD (TF) Card Slot

- Turn on the speaker.
- Insert Micro SD (TF) card into the Micro SD (TF) Card Slot. Music would be automatically streamed.
- Short press + or - button to move forward or backward on your playlist.
- Short press Play/Pause button to Play or Pause a track.

Note: While using Bluetooth, if you insert Micro SD (TF) Card, speaker would disconnect the Bluetooth connection and switch to Micro SD (TF) card function. You can long press Mode button each time until it goes back Bluetooth mode. Micro SD (TF) Card is not included.

5

Tips!!

- Long press the Mode button each time to switch different functions of the speaker. The modes appear in the following sequence - Bluetooth / Micro SD (TF) / AUX-In.
- When the unit is not in use, turn OFF the device to save the battery power.

Do's and Don'ts

Do not play music at excessive levels as damage to hearing and/or equipment may result.

Do not use in wet or in damp surroundings.

Specification

Bluetooth version : 2.1+EDR
 Speaker Output : 3W
 Unit Size : 2-3/4"x2-3/4"x2-3/4"
 Unit Weight : 6.6 oz
 Play time : up to 1 hour (max. volume), and 2 hours (moderate volume)
 Charge Voltage : DCSV (USB)
 Bluetooth Range : 27 - 33 Feet
 Built-In Rechargeable Battery: 3.7V / 350mA
 (Note: Battery life & charging time may vary based on usage & types of devices used.)

Troubleshooting

Problem	Possible Cause	Solution
Low sound level	Source (Tablet, Mobile Phone, Laptop, etc.) volume too low. Battery dead	Adjust source volume. Charge Battery.
Sound distorted	Battery nearly dead	Charge Battery.
No sound at all.	Source (Tablet, Mobile Phone, Laptop.) turned off. Speaker turned off. Volume turned down source. Media paused on source.	Turn the source on. Turn the speaker on. Adjust volume source. Play media from source.

Care and Maintenance

Clean the unit with a soft, damp cloth. Never use chemicals or hard abrasives. Keep this unit away from wet or damp surroundings.

6

FCC Instructions

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Limited Warranty

This manufacturer's product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer warranty.

WARRANTY DURATION: All materials and workmanship are warranted to the original consumer purchaser for a period of ninety (90) days from the original purchase date.

WARRANTY COVERAGE: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in USA, and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

7

WARRANTY DISCLAIMERS: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contractor commercial law including but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract. Under no circumstances will Manufacturer's / Distributor's maximum liability exceed the retail value of the product.

WARRANTY PERFORMANCE: During the above 90 day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the 90 day warranty period and an additional one-month period. No charge will be applicable for such repair or replacement.

SERVICE AND REPAIR: If service is required for this product, you should first contact Midwest Trading Group Customer Service at info@mtradinggroup.com or by calling 1 (866) 815-4714, Monday to Friday 10am to 6pm EST.

NOTE: Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment, and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

8